


Modeling Transient Rocket Operation

(Lecture 7.2: Solid Rockets)



- .. The primary goal of man is survival ... food, shelter ... basic necessities ...
- *A second aim of man is to build things that run very HOT and very LOUD and move really, really FAST ...*

- Sutton and Biblarz: Chapter 11
- Richard Nakka Web Page:

* http://members.aol.com/ricnakk/th_pres.html

Transient Pressure Model

- Combustion Produces High temperature gaseous By-products
- Gases Escape Through Nozzle Throat
- Nozzle Throat Chokes (maximum mass flow)
- Since Gases cannot escape as fast as they are produced
 - ... Pressure builds up
- As Pressure Builds .. Choking mass flow grows
- Eventually Steady State Condition is reached

Choking Massflow per Unit Area

- maximum Massflow/area Occurs when When $M=1$
- Effect known as *Choking* in a Duct or Nozzle
- i.e. nozzle will Have a mach 1 throat

$$\left(\frac{\dot{m}}{A_c} \frac{\sqrt{T_0}}{p_0} \sqrt{R_g} \right)_{\max} = \left(\frac{\dot{m}}{A^*} \frac{\sqrt{T_0}}{p_0} \sqrt{R_g} \right) =$$

$$\frac{\sqrt{\gamma}}{\left[1 + \frac{(\gamma - 1)}{2} \right]^{\frac{\gamma+1}{2(\gamma-1)}}} = \sqrt{\gamma \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \rightarrow$$


$$\frac{\dot{m}}{A^*} = \sqrt{\frac{\gamma}{R_g} \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \frac{p_0}{\sqrt{T_0}}$$

Chamber Pressure Model

- Gaseous Mass Trapped in Chamber

$$\frac{\partial}{\partial t} M_c = \left[\dot{m}_{fuel} + \dot{m}_{ox} \right] - \dot{m}_{nozzle}$$

$$\frac{\partial}{\partial t} M_c = \frac{\partial}{\partial t} [r_c V_c] = \frac{\partial}{\partial t} [r_c] V_c + r_c \frac{\partial}{\partial t} [V_c]$$



- Assuming nozzle chokes immediately

$$\frac{\partial}{\partial t} [\rho_c] V_c + \rho_c \frac{\partial}{\partial t} [V_c] = \left[\dot{m}_{fuel} + \dot{m}_{ox} \right] - A^* \sqrt{\frac{\gamma}{R_g}} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \frac{P_0}{\sqrt{T_0}}$$

Chamber Pressure Model (cont'd)

- Using ideal gas law, *Assuming constant flame temperature*

$$\rho_c = \frac{P_0}{R_g T_0} \rightarrow \frac{\partial}{\partial t} [\rho_c] \approx \frac{1}{R_g T_0} \frac{\partial}{\partial t} [P_0]$$

- Subbing into mass flow equation

$$\frac{\partial P_0}{\partial t} \frac{V_c}{R_g T_0} + \frac{P_0}{R_g T_0} \frac{\partial V_c}{\partial t} = \left[\dot{m}_{fuel} + \dot{m}_{ox} \right] - \frac{R_g T_0}{V_c} A^* \sqrt{\frac{\gamma}{R_g} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \frac{P_0}{\sqrt{T_0}}$$


$$\frac{\partial P_0}{\partial t} + P_0 \frac{1}{V_c} \frac{\partial V_c}{\partial t} + \frac{R_g T_0}{V_c} A^* \sqrt{\frac{\gamma}{R_g} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \frac{P_0}{\sqrt{T_0}} = \frac{R_g T_0}{V_c} \left[\dot{m}_{fuel} + \dot{m}_{ox} \right]$$

$$\frac{\partial P_0}{\partial t} + P_0 \left[\frac{1}{V_c} \frac{\partial V_c}{\partial t} + \frac{A^*}{V_c} \sqrt{\gamma R_g T \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right] = \frac{R_g T_0}{V_c} \left[\dot{m}_{fuel} + \dot{m}_{ox} \right]$$

Transient Operation Model For Solid Rockets


- Revisit General Model

$$\frac{\partial P_0}{\partial t} + P_0 \left[\frac{1}{V_c} \frac{\partial V_c}{\partial t} + \frac{A^*}{V_c} \sqrt{\gamma R_g T \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right] = \frac{R_g T_0}{V_c} \left[\dot{m}_{propellant} \right]$$



- For Solid Rocket Motors





$$\frac{\partial V_c}{\partial t} \neq 0$$



Solid Rocket Example

$$\frac{\partial P_0}{\partial t} + P_0 \left[\frac{1}{V_c} \frac{\partial V_c}{\partial t} + \frac{A^*}{V_c} \sqrt{\gamma R_g T \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right] = \frac{R_g T_0}{V_c} \left[\dot{m}_{propellant} \right]$$


$$\frac{\partial V_c}{\partial t} = A_{burn} r \rightarrow \begin{array}{l} A_{burn} = \text{Grain Surface Burn Area} \\ r = \text{Grain Linear Regression Rate} \end{array}$$



Solid Rocket Example (cont'd)

$$\frac{\partial V_c}{\partial t} = A_{burn} \cdot r \rightarrow \left[\begin{array}{l} A_{burn} = \text{Grain Surface Burn Area} \\ r = \text{Grain Linear Regression Rate} \end{array} \right]$$

$$\left[\dot{m}_{propellant} \right] = \rho_p \cdot A_{burn} \cdot \dot{r}$$



EFFECT OF PRESSURE ON BURN RATE - Saint-Robert's Law

$$\dot{r} = ap^n$$

r = linear burning rate

a = an empirical constant moderately influenced by propellant grain temperature

n = burning rate pressure exponent

•
 $\dot{r} = aP_o^n \rightarrow \{a, n\} \rightarrow$ empirically derived constants

Solid Rocket Example (cont'd)

- Propellant burn rate may be expressed in terms of the chamber pressure by the Saint Robert's law ...
- $r = aP_o^n \rightarrow \{a, n\} \rightarrow$ empirically derived constants

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right]$$

- careful with units on a ...

$$a \sim \frac{m}{\text{sec}} \left(\frac{1}{kPa} \right)^n$$

Solid Rocket Example (cont'd)

$$\log \left[\frac{\dot{r}}{r} \right] = n \log [P] + y_0$$


$$\bullet \quad \dot{r} = e^{\log[P_o^n] + y_0} = e^{y_0} P_o^n \rightarrow e^{y_0} \equiv a$$

→

$$\bullet \quad r = a P_o^n$$

- careful with units on a ...

Sutton and Biblarz,
Chapter 11



Solid Rocket Example (cont'd)

Solid Propellant Saint Robert's Curve Fit (P_0 -psia, r_{dot} - in/sec)

<u>Propellant Name</u>	<u>n</u>	<u>a (in/sec-psiaⁿ)</u>
Composite Ammonium Nitrate, -40F	0.463474	0.002965
Composite Ammonium Nitrate, 60F	0.445084	0.003909
Composite Ammonium Nitrate, 140F	0.426803	0.005243
High Energy XLDB Composite	0.720473	0.002293
Composite Ammonium Perchlorate, -30F	0.187867	0.072001
Composite Ammonium Perchlorate, 60F	0.170286	0.094044
Composite Ammonium Perchlorate, 150F	0.172255	0.107348
JPN-type Double Base, 10F	0.712606	0.003818
JPN-type Double Base, 70F	0.701667	0.004624
JPN-type Double Base, 130F	0.678433	0.006260
High Burn Rate Composite @ 68F	0.380710	0.126409

•

$$r = a P_o^n$$

- Input, Psia
- Output, in/sec

Solid Rocket Example (cont'd)

Propellant, Saint Robert's Curve Fit (P0-kPa, rdot- cm/sec)

<i>propellant name</i>	<i>n</i>	<i>a (cm/sec-kPa^n)</i>
Composite Ammonium Nitrate, -40F	0.463474	0.003077
Composite Ammonium Nitrate, 60F	0.445084	0.004204
Composite Ammonium Nitrate, 140F	0.426803	0.005841
High Energy XLDB Composite	0.720473	0.001449
Composite Ammonium Perchlorate, -30F	0.187867	0.127245
Composite Ammonium Perchlorate, 60F	0.170286	0.171940
Composite Ammonium Perchlorate, 150F	0.172255	0.195519
JPN-type Double Base, 10F	0.712606	0.002450
JPN-type Double Base, 70F	0.701667	0.003030
JPN-type Double Base, 130F	0.678433	0.004291
High Burn Rate Composite @ 68F	0.380710	0.153949


•

$$r = a P_o^n$$


- Input, kPa
- Output, cm/sec

Solid Rocket Example (cont'd)

- Propellant Burn rate is extremely sensitive to exponent, n
- Stable operation requires $0.001 < n < 0.990$
- High values of n make for a propellant whose burn rate is sensitive to chamber pressure



Exponent Effect on Burn Rate (Pressure Excursion)



Source: Barrere et al., Raketenantriebe, Fig 5.1 (1961)


Effect of Burn Exponent

n>1 : Slight positive pressure excursion might lead to explosion of the chamber.


n ~ < 0.8: Maximum pressure exponent tolerated with typical solid rocket propellants.

n < 0: Slight negative pressure excursion might lead to continuing decay of chamber pressure and premature extinguishment of propellant.

Effect of Burn Exponent (2)






Grain Temperature Effect on Burn Rate



Sutton, & Biblarz p. 268 (1986)

Example from (2009) USLI Design Team Motor Tests (2)


Motor Burn Profiles



Chamber pressure

19


Example from (2009) USLI Design Team Motor Tests (3)






Measures of Burn Time

Example from (2009) USLI Design Team Motor Tests (4)

Temperature Adjusted Burn Profiles



Burn Rate Revisited




- Show that for Uniform Cylindrical Propellant grain necessarily leads to Progressive burn

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$

Burn Rate Revisited ₍₂₎

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right] =$$

$$\rightarrow C^* = \left(\frac{\dot{m}_{exit}}{\frac{P_0 A^*}{\gamma R_g T_0}} \right) = \frac{\sqrt{\gamma R_g T_0}}{\gamma \sqrt{\left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}}}$$



$$\frac{\partial P_0}{\partial t} = R_g T_0 \left(\frac{A_{burn} a P_o^n}{V_c} [\rho_p - \rho_0] - \left(\frac{P_0 A^*}{V_c C^*} \right) \right)$$

Burn Rate Revisited ₍₃₎

$$\frac{\partial P_0}{\partial t} = R_g T_0 \left(\frac{A_{burn} a P_o^n}{V_c} [\rho_p - \rho_0] - \left(\frac{P_0 A^*}{V_c C^*} \right) \right)$$



$$\rho_p \gg \rho_0 \rightarrow$$

$$\frac{\partial P_0}{\partial t} \approx R_g T_0 \left(\frac{A_{burn} a P_o^n}{V_c} \rho_p - \left(\frac{P_0 A^*}{V_c C^*} \right) \right)$$

- Cylindrical Port ... $\frac{A_{burn}}{V_{burn}} = \frac{2\pi \cdot r \cdot L}{\pi \cdot r^2 \cdot L} = \frac{2}{r}$

$$\frac{\partial P_0}{\partial t} \approx R_g T_0 \left(\frac{2 a P_o^n}{r} \rho_p - \left(\frac{P_0 A^*}{\pi \cdot r^2 \cdot L \cdot C^*} \right) \right)$$

Burn Rate Revisited (4)

- Cylindrical Port ... $\frac{A_{burn}}{V_{burn}} = \frac{2\pi \cdot r \cdot L}{\pi \cdot r^2 \cdot L} = \frac{2}{r}$

$$\frac{\partial P_0}{\partial t} \approx R_g T_0 \left(\frac{2aP_o^n}{r} \rho_p - \left(\frac{P_0 A^*}{\pi \cdot r^2 \cdot L \cdot C^*} \right) \right)$$

$$\rightarrow \left(\frac{1}{\pi \cdot r^2} \right) \cdot \left(\frac{P_0 A^*}{L \cdot C^*} \right) > 0 \rightarrow \frac{\partial P_0}{\partial t} > 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \left(\frac{aP_o^n}{r} \right)$$

$$\rightarrow \dot{r} = aP_o^n \rightarrow \frac{\partial P_0}{\partial t} > 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \left(\frac{\dot{r}}{r} \right) = 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \frac{\partial}{\partial t} (\ln(r))$$



Burn Rate Revisited (5)

- Cylindrical Port ... $\frac{A_{burn}}{V_{burn}} = \frac{2\pi \cdot r \cdot L}{\pi \cdot r^2 \cdot L} = \frac{2}{r}$


→ $\dot{r} = aP_o^n \rightarrow \frac{\partial P_0}{\partial t} > 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \left(\frac{\dot{r}}{r} \right) = 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \frac{\partial}{\partial t} (\ln(r))$

$$\frac{\partial P_0}{\partial t} > 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \frac{\partial}{\partial t} (\ln(r)) \rightarrow P_{0(t)} > P_{0(0)} + 2 \cdot \rho_p \cdot R_g \cdot T_0 \cdot \ln \left(\frac{r_{(t)}}{r_{(0)}} \right)$$

For a Cylindrical Port Burn, Pressure Rises Logarithmically with time



Space Shuttle RSRM Numerical Example



- All dimensions are approximate


- Propellant:

Ammonium Perchlorate (69.6%) as oxidizer, Aluminum Powder (16%) as fuel, Iron Oxidizer Powder (0.4%) as catalyst, Polybutadiene Acrylic Acid Acrylonitrile (12.04%) (**PBAN**) as rubber-based binder, Epoxy Curing Agent (1.96%)


- Propellant Density .. 1760 kg/m^3

- Launch Propellant mass ... 502,0 kg

Space Shuttle RSRM Numerical Example (cont'd)



Internal
Grain
Pattern



Solid Propellant Grain Parameters

LENGTH, M	34.57
OUTSIDE DIAMETER, M	3.66
INSIDE DIAMETER, M	1.7
PROPELLANT DENSITY KG/M^3	1760

Solid Propellant Grain Parameters 2

Propellant thickness,M	1.96
Chamber Cross Section Area, M^2	2.2698
PROPELLANT Volume M^3	285.24
Propellant Cross Section Area, M^2	8.25108
PROPELLANT MASS, KG	502022
Chamber Volume, M^3	78.467
PROPELLANT MASS, Mton	502.022
Propellant Burn area, M^2	184.628

Space Shuttle RSRM Numerical Example (cont'd)

Propellant, Saint Robert's Curve Fit

<u>propellant name</u>	<u>n</u>	<u>a (cm/sec-kPaⁿ)</u>
Composite Ammonium Perchlorate, 60F	0.172	0.192

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$

$$\left[\begin{array}{l} A_{burn} = 2\pi R_{chamber} L_{prop} \\ V_c = \pi R_{chamber}^2 L_{prop} \end{array} \right] \rightarrow R_{chamber} = R_{i_{initial}} + \int_0^t \dot{r} dt = R_{i_{initial}} + \int_0^t a P_o^n dt$$

Space Shuttle RSRM Numerical Example (cont'd)

- Use Trapezoidal rule or Runge-Kutta to integrate


$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} \left[\rho_p R_g T_0 - P_0 \right] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$

- Recursive propagation of chamber diameter

$$R_{burn_{k+1}} = R_{i_{initial}} + \int_0^{(k+1)\Delta t} \dot{r} dt = R_{i_{initial}} + \int_0^{(k)\Delta t} \dot{r} dt + \int_{(k)\Delta t}^{(k+1)\Delta t} \dot{r} dt \rightarrow$$

$$R_{burn_{k+1}} = R_{burn_k} + \int_{(k)\Delta t}^{(k+1)\Delta t} \dot{r} dt \approx R_{burn_k} + r \Delta t = R_{burn_k} + a P_o^n \Delta t$$

RSRM Burn Time History




- “Progressive Burn Pattern”




Burn Time: 121 seconds

RSRM Burn Time History (cont'd)




- “Progressive Burn Pattern”



Burn Time: 121 seconds

RSRM Burn Time History (cont'd)




- “Progressive Burn Pattern”



Burn Time: 121 seconds

RSRM Burn Time History (cont'd)




- “Progressive Burn Pattern”

Burn Time: 121 seconds

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$



RSRM Burn Time History (cont'd)



- “Progressive Burn Pattern”
- Quoted “Nominal Thrust” of SRB (11,780 kNt)

So our model is “pretty good”


Burn Area Revisited ₍₁₎



- What happens to the burn area with this pattern?

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$

Burn Area Revisited ₍₂₎




- Burn Area stays relatively constant
- Burn Volume Goes Down
- Ratio of Burn Area to Chamber Volume goes *Down! Fast!*
- *Result is a more shaped burn profile*

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0} \left(\frac{2}{\gamma + 1} \right)^{\frac{\gamma+1}{(\gamma-1)}} \right]$$

SHAPE OF PROPELLANT GRAINS QUENCHED AT DIFFERENT TIMES

Life History of Solid Motor Shown




Start condition


Quenched at 1.5 s

Quenched at 2.5 s


Modified RSRM Burn Time History




Burn Time: 129 seconds




Modified RSRM Burn Time History (cont'd)



Burn Time: 129 seconds



Modified RSRM Burn Time History (cont'd)



- “Neutral Burn Pattern”


$$\int_0^{t_{burn}} F_{thrust}_{SL} dt =$$

$$11.832 \cdot 121 = 1431.7 \text{ MNt-sec}$$

$$\int_0^{t_{burn}} F_{thrust}_{SL} dt =$$

$$6.86627 \cdot 129 = 887.75 \text{ MNt-sec}$$

- Significantly Less delivered impulse



Finally Look at grain pattern






- “*Regressive Grain pattern*” ... Burn surface area actually shrinks As propellant is burned

“Dendrite Grain”




Modified RSRM for Dendrite Grain Pattern



$$\int_0^{t_{burn}} F_{thrust}_{SL} dt = \\ 3.87867 \cdot 142 = 550.77 \text{ MNt-sec}$$
















Burn Time: 142 seconds

SOLID ROCKET MOTOR GRAIN DESIGNS




Source: Köhler, Feststoffraketenantriebe, Vol. 1, p. 122 (1972)

EXAMPLES OF SOLID ROCKET MOTOR UNUSUAL GRAIN DESIGNS



Source: Barrere et al., Raketenantriebe, p. 321, Fig 6.1 (1961)

Solid Rocket Burn Summary





SOLID ROCKET MOTOR GRAIN DESIGN PROGRAMS

- Grain Design Program (**GDP-Light**)
- <http://home.vianetworks.nl/users/aed/gdp/gdp.htm>
- Useful Code to test new and unusual grain shapes to achieve certain thrust profiles or minimize slivers and residual burning.


The “Bates Grain” Geometry

Simple Modification to Cylindrical Port to Give More
Even Burn Pattern



Grain segments burn from
“inside” and along the “ends”

The “Bates Grain” Geometry (2)



Look at Burn evolution
of

$$\frac{A_{burn}}{V_{burn}}$$


$$s_{regression} = \int_t^{\bullet} r \cdot dt$$

$$\rightarrow A_{burn} = 2\pi \cdot \left(\frac{D_0^2 - d^2}{4} \right) + L \cdot \pi \cdot d$$

end of segment interior of grain

*For each
grain segment*

The “Bates Grain” Geometry (3)



Look at Burn evolution
of

$$\frac{A_{burn}}{V_{burn}}$$


*regressing interior
surface diameter +
ends of segment*

$$\begin{aligned} \rightarrow d &= d_0 + 2 \cdot s \\ L &= L_0 - 2 \cdot s \end{aligned}$$

*For each
grain segment*

$$\begin{aligned} A_{burn} &= 2\pi \cdot \left(\frac{{D_0}^2 - d^2}{4} \right) + L \cdot \pi \cdot d = \\ &= \frac{\pi}{2} \cdot \left({D_0}^2 - (d_0 + 2 \cdot s)^2 \right) + \pi \cdot (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \end{aligned}$$

The “Bates Grain” Geometry (4)



Look at Burn evolution
of

$$\frac{A_{burn}}{V_{burn}}$$


*regressing interior
surface diameter +
ends of segment*

$$\begin{aligned} \rightarrow d &= d_0 + 2 \cdot s \\ L &= L_0 - 2 \cdot s \end{aligned}$$

For N grain segments

$$(A_{burn})_{total} = N \cdot \pi \cdot \left[\frac{\left(D_0^2 - (d_0 + 2 \cdot s)^2 \right)}{2} + (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \right]$$

The “Bates Grain” Geometry (5)



Look at Burn evolution
of


$$\frac{A_{burn}}{V_{burn}}$$

Look at total chamber burn volume (empty space) at any time

$$(V_{ol})_{total} = N \cdot \left[\pi \cdot \frac{d^2}{4} \cdot L + \pi \frac{D_0^2}{4} \cdot (2 \cdot s) \right]$$

Port Volume “burn end” volume

The “Bates Grain” Geometry (6)




Look at Burn evolution
of

$$\frac{A_{burn}}{V_{burn}}$$

Allowing for regression from original geometry

$$\begin{aligned}
 (V_{ol})_{total} &= N \cdot \left[\pi \cdot \frac{d^2}{4} \cdot L + \pi \frac{D_0^2}{4} \cdot (2 \cdot s) \right] = \\
 &\frac{N \cdot \pi}{4} \left[(d_0 + 2 \cdot s)^2 \cdot (L_0 - 2 \cdot s) + D_0^2 \cdot (2 \cdot s) \right]
 \end{aligned}$$

The “Bates Grain” Geometry (8)



Look at Burn evolution
of


$$\frac{A_{burn}}{V_{burn}}$$

$$(A_{burn})_{total} = N \cdot \pi \cdot \left[\frac{(D_0^2 - (d_0 + 2 \cdot s)^2)}{2} + (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \right]$$

$$(V_{ol})_{total} = \frac{N \cdot \pi}{4} \left[(d_0 + 2 \cdot s)^2 \cdot (L_0 - 2 \cdot s) + D_0^2 \cdot (2 \cdot s) \right]$$

$$\frac{A_{burn}}{V_{burn}} = \frac{N \cdot \pi \cdot \left[\frac{(D_0^2 - (d_0 + 2 \cdot s)^2)}{2} + (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \right]}{\frac{N \cdot \pi}{4} \left[(d_0 + 2 \cdot s)^2 \cdot (L_0 - 2 \cdot s) + D_0^2 \cdot (2 \cdot s) \right]} = \frac{4 \left[\frac{\left(1 - \left(\frac{d_0 + 2 \cdot s}{D_0} \right)^2 \right)}{2} + \left(1 - 2 \cdot \frac{s}{L_0} \right) \cdot \left(\frac{d_0 + 2 \cdot s}{D_0} \right) \right]}{\left[\left(\frac{d_0 + 2 \cdot s}{D_0} \right)^2 \cdot \left(1 - 2 \cdot \frac{s}{L_0} \right) + \left(2 \cdot \frac{s}{L_0} \right) \right]}$$

The “Bates Grain” Geometry (9)



Summary of Algorithm


$$\begin{aligned} \bullet \quad r &= a \cdot P_o^n \\ s_{regression} &= \int_t^{\bullet} r \cdot dt \end{aligned} \rightarrow$$

$$(A_{burn})_{total} = N \cdot \pi \cdot \left[\frac{\left(D_0^2 - (d_0 + 2 \cdot s)^2 \right)}{2} + (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \right]$$

$$(V_{ol})_{total} = \frac{N \cdot \pi}{4} \left[(d_0 + 2 \cdot s)^2 \cdot (L_0 - 2 \cdot s) + D_0^2 \cdot (2 \cdot s) \right]$$


Comparative Burn Example

Grain Parameters



1.68885 kg
of propellant

Fuel grain shape effect on a small
Solid propelled motor (AMW L777)





First compare 3-grain bates configuration against
Hypothetical 6-grain configuration

Comparative Burn Example (2)


Grain Parameters

D, cm	7.6
d ₀ , cm	3
L ₀ , cm	35
PROPELLANT DENSITY KG/M ³	
	1260
Throat Area, M ²	
	0.0001887
A/A*	
	3.746

1.68885 kg
of propellant




Then compare
more intricate port
patterns





Comparative Burn Example (3)


SNC 4-port cross section




Cylindrical port cross section




Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view





- Initial Grain Patterns
- Propellant Mass:
 1.68885 kg

Comparative Burn Example (4)

SNC 4-port cross section




Cylindrical port cross section




- Grain Geometry after 1-sec burn
- Cross section of clover leaf becoming circular


Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view





Comparative Burn Example (5)

SNC 4-port cross section




Cylindrical port cross section




- Grain Geometry after 2-sec burn
- 4-Port grain completely burned


Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view




Comparative Burn Example (6)

SNC 4-port cross section



Cylindrical port cross section



Cylindrical port


Outer Case

Bates 3-grain port


Bates 6-grain port




Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view




- Grain Geometry after 3-sec burn
- 6-Port grain longitudinal gaps prominent

Comparative Burn Example (7)

SNC 4-port cross section



Cylindrical port cross section



Cylindrical port



Outer Case




Bates 3-grain port




Bates 6-grain port




Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view




- Grain Geometry after 4-sec burn
- Cylindrical cross sections burning equally

Comparative Burn Example (8)

SNC 4-port cross section



Cylindrical port cross section



Cylindrical port



Outer Case




Bates 3-grain port




Bates 6-grain port




Cloverleaf port cross section



Bates 3-grain port side view




Bates 6-grain port side view




- Grain Geometry after 5-sec burn
- Clover Leaf grain essentially consumed

Comparative Burn Example (9)

SNC 4-port cross section



Cylindrical port cross section



Cylindrical port



Outer Case




Bates 3-grain port




Bates 6-grain port




Cloverleaf port cross section



Bates 3-grain port side view







Bates 6-grain port side view





- Grain Geometry after 6-sec burn

- All Cylindrical port propellant consumed

Comparative Burn Example (10)



Comparative Burn Example (11)




Effective Isp, sec

239.046
240.274
251.737
240.289
240.029

Peak Thrust, Nt

1144.35
1159.84
3113.44
780.581
1080.45



Effects of Erosive Burning and Propellant Grain Fracture on Solid Propellants

NASA
SPACE VEHICLE
DESIGN CRITERIA
(CHEMICAL PROPULSION)

NASA SP-8039

SOLID ROCKET MOTOR PERFORMANCE ANALYSIS AND PREDICTION



MAY 1971

<https://ntrs.nasa.gov/search.jsp?R=19720011135> 2018-04-02T19:39:57+00:00

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION


Erosive Burning

- 1) When high velocity or high mass flow hot gas from upstream combustion passes over** a downstream burning surface in a solid rocket motor local, chaotic increase in propellant burning rate results; phenomenon referred to as erosive burning.
- 2) Two types of erosive burning;** velocity-based erosive burning and mass flux-based erosive burning. AP/composite propellants are more sensitive to the effect of the hot gas velocity flowing past burning propellant surface, some propellants (hybrids in particular) are more sensitive to the effect of the mass flux of the hot gas over the burning surface
- 3) Distinct thresholds for core combustion gas velocity and core mass flux** for the onset of velocity-based erosive burning and mass flux-based erosive burning.
- 4) Erosive Burning** is nearly accompanied by a random burn rate element, making for a high variability on trust and total impulse levels for a given class of motors

Erosive Burning ⁽²⁾

... St. Roberts Law strictly only “works” for non-erosive grain burns ... Erosive burns are complex, typically chaotic, and hard to predict / analyze

a) Test 1




b) Test 2

Erosion Properties Highly
Dependent on Chamber Flow Velocity


Eilers/Whitmore, JPC 2007,

AIAA-2007-5349



Erosive Burning ⁽³⁾


... St. Roberts Law only “works”
for non-erosive grain burns



“Plateau effects” are result different surface regression rates --- pressure dependent

-- condensed phase combustion products also "pool" and retard heat transfer to the surface at elevated pressures.

Erosive Burning ⁽⁴⁾




Heat Transfer Mechanisms as a Function of Combustion Gas Velocity

Erosive Burning ⁽⁵⁾

- Most propellants have certain levels of combustion gas velocity (Mach number) that leads to an increased burning rate.
- "Augmentation" of burn rate is referred to as *erosive burning*, chaotic and difficult to predict
- Physical mechanism -- increased convective heat transfer to the propellant surface – resulting from flow turbulence
- For many propellants, a *threshold* Mach number occurs.
- Below this flow level, no augmentation occurs, or a *decrease* in burn rate is experienced (negative erosive burning). (*Slag buildup*)
- *Both Augmented (+) and Suppressed (-) Erosive Burning result in Chaotic Behaviors*

Erosive Burning ⁽⁶⁾



A Simple Erosive Burning Model

.. Mean Regression Rate Augmentation/Suppression

$$\dot{r}_{erosive} = (\dot{r})_{Saint\ Roberts} \cdot \left(\frac{1 + k \cdot \frac{M_{port}}{M_{crit}}}{1 + k} \right) = aP_0^n \cdot \left(\frac{1 + k \cdot \frac{M_{port}}{M_{crit}}}{1 + k} \right)$$


- k ... empirical scale factor
- M_{port} ... Port Mach number based on A_{port}/A^*
- M_{crit} ... critical or thresh hold Mach number

- Port Mach Number Above M_{crit} .. --> Burn rate is augmented
- Port Mach Number Below M_{crit} .. --> Burn rate is suppressed

A Simple Erosive Burning Model (2)

$$\dot{r}_{erosive} = (\dot{r})_{Saint\ Roberts} \cdot \left(\frac{1 + k \cdot \frac{M_{port}}{M_{crit}}}{1 + k} \right) = aP_0^n \cdot \left(\frac{1 + k \cdot \frac{M_{port}}{M_{crit}}}{1 + k} \right)$$


-- Erosive Burning Model



- k ... empirical scale factor
- M_{port} ... Port Mach number based on A_{port}/A^*
- M_{crit} ... critical or thresh hold Mach number

Preventing Erosive Burning


(From C. E. Rogers, “Erosive Burning Design Criteria for High Power and Experimental/Amateur Solid Rocket Motors, High Power Rocketry, Vol. 36, No. 1, Jan. 2005)



- ..Effects of erosive burning can be minimized by designing the motor with a sufficiently large *port-to-throat area ratio* (A_{port}/A^*).
- .. to keep combustor gas velocities below threshold Value

Preventing Erosive Burning (2)

For Any Motor Length (Short or Long), Reducing Core Diameter Increases Propellant Loading, More Propellant Loaded within Fixed Motor Volume. Maximizes Volumetric Loading (Total Impulse Installed within a Fixed Volume). Increased Rocket Flight Performance from Higher Total Impulse Installed within Volume or Length Available for Motor.



How Much Can Motor Core Diameter Be Reduced?

For Velocity-Based Erosive Burning:


- 1) Reduced Core Diameter Reduces Port Area (A_p , the Core Cross-Sectional Area). Port Area Begins to Approach Fixed Throat Area (A_{th}). Port-to-Throat Area Ratio (A_p/A_{th}) Decreases, Core Mach Number Increases.
- 2) Increased Core Mach Number, Increased Velocity-Based Erosive Burning.

For Mass Flux-Based Erosive Burning:

- 1) Reduced Core Diameter Reduces Propellant Surface Area, Reducing Core Mass Flow Rate, but Port Area (Core Cross-Sectional Area) is Reduced at a Greater Rate. Result is an Increase in Core Mass Flux.
- 2) Increased Core Mass Flux, Increased Mass Flux-Based Erosive Burning.


High Length-to-Diameter (L/D) Motors Increase Rocket Flight Performance.

**Maximizes Total Impulse within a Given Frontal Area,
Minimizes Aerodynamic Drag in Minimum Diameter Rockets.**



**Keeping the Core Diameter the Same,
Motor Propellant Grain Length is Increased.**

**How Much Can Motor Length Be Increased
For a Given Motor Diameter?**




For Velocity-Based Erosive Burning:

- 1) Increased Propellant Grain Length Increases Propellant Surface Area.
- 2) For Same K_n , Increased Propellant Surface Area Requires Increase in Throat Area (A_{th}).
- 3) Increased Throat Area Approaches Port Area (A_p , the Core Cross-Sectional Area). Port-to-Throat Area Ratio (A_p/A_{th}) Decreases, Core Mach Number Increases, Increased Velocity-Based Erosive Burning.

For Mass Flux-Based Erosive Burning:


- 1) Increased Propellant Grain Length Increases Propellant Surface Area.
- 2) Increased Propellant Surface Area Increases Mass Flow Rate Down Core.
- 3) With Same Core Diameter, Port Area (Core Cross-Sectional Area) Remains the Same. Increased Core Mass Flow Rate through Same Core Cross-Sectional Area Results in Increased Core Mass Flux, Increased Mass Flux-Based Erosive Burning.

Preventing Erosive Burning (4)



Typical Effect of Combustion Gas Velocity on Burning Rate Augmentation - *Velocity-Based Erosive Burning.*

Preventing Erosive Burning (5)



**Typical Effect of Mass Flux on Burning Rate
Augmentation - *Mass Flux-Based Erosive Burning.***

Rules of Thumb for Preventing Erosive Burning

- Non-Erosive (Safe Zone)

Mach Number

Core Mach Number < 0.50

For $\gamma = 1.2$; $A_{port}/A^ > 1.36$*

Mass Flux

$P_0 = 400\text{-}600 \text{ psia}$; Core Mass Flux < 1.0 lb/sec-in²

$P_0 = 800 \text{ psia}$; Core Mass Flux < 1.75 lb/sec-in²

$P_0 = 1400 \text{ psia}$; Core Mass Flux < 2.0 lb/sec-in²

Rules of Thumb ... (2)

- Maximum Recommended Allowable Parameter at Erosive Burn Threshold: (Tickling Tail of the Dragon)

Mach Number

Core Mach Number < 0.70

For $\gamma = 1.2$; $A_{port}/A^ > 1.10$*

Mass Flux

$P_0 = 400\text{-}600 \text{ psia}$; Core Mass Flux < 2.0 lb/sec-in^2

$P_0 = 800 \text{ psia}$; Core Mass Flux < 2.5 lb/sec-in^2

$P_0 = 1400 \text{ psia}$; Core Mass Flux < 3.0 lb/sec-in^2


Core Mass Flux limits for Max Recommended Erosivity should not be exceeded unless erosive Burning Characterization Tests are performed for propellant.

Fuel Port Core Geometry Design

**These Propellant Burning Surfaces
Do Not Contribute to Core Mass Flux**

**Inhibited Propellant Surfaces
Do Not Contribute to Core Mass Flux**

$$\dot{m}_{total} = (\rho_{fuel} \cdot \dot{r})(2\pi) \cdot \left[\int_0^L r(x) \cdot dx \right]$$



**Core Mass Flux
at Aft End of Core.**

**Commonly Shortened to:
“Core Mass Flux”**

**For Erosive Burning Design Criteria
Core Mass Flux Based On Core Mass Flow Rate
Based On Non-Erosive Propellant Burn Rate**

**Most Important Core Mass Flux Condition is
the Highest Core Mass Flux, Which Occurs
at Aft End of Core at Motor Ignition.**

**Propellant Burning Surfaces Contributing to Core Mass Flux at Aft End
of Core. ... *Core Mass Flux Based on Non-Erosive Burn Rate.***

Combined Core Mach Number/Core Mass Flux Erosive Burning Design Criteria for Motors With Constant Port Diameter

Initial Core Diameter Sized Based On Core Mach Number

Non-Erosive; $M_a = 0.50$
 $\gamma = 1.2; A_p/A_{th} = 1.36$


Max Erosive; $M_a = 0.70$
 $\gamma = 1.2; A_p/A_{th} = 1.10$

Step 1:

Core Mach Number and Core Mass Flux Conditions are at Motor Ignition

Core Mass Flux Values Based on Non-Erosive Propellant Burn Rate

Maintain Constant Core Diameter From Head End to Aft End of Core



Step 2:

Check Core Mass Flux at Aft End of Core

If Core Mass Flux at Aft End of Core Higher Than Design Point Core Mass Flux, Increase Core Diameter to Reduce Core Mass Flux to Design Point Value.

Design Point Core Mass Flux (Recommended Values)

Non-Erosive; $p_c = 400\text{-}600 \text{ psia}$	Core Mass Flux $\leq 1.0 \text{ lb/sec-in}^2$
$p_c = 800 \text{ psia}$	Core Mass Flux $\leq 1.75 \text{ lb/sec-in}^2$
$p_c = 1400 \text{ psia}$	Core Mass Flux $\leq 2.0 \text{ lb/sec-in}^2$


Max Erosive; $p_c = 400 \text{ psia}$	Core Mass Flux $= 2.0 \text{ lb/sec-in}^2$
$p_c = 600 \text{ psia}$	Core Mass Flux $= 2.5 \text{ lb/sec-in}^2$
$p_c \geq 800 \text{ psia}$	Core Mass Flux $= 3.0 \text{ lb/sec-in}^2$

Constant Mass Flux Initial Port Design

Core Mach Number and Core Mass Flux
Design Point Conditions are at Motor Ignition


Core Mass Flux Values Based on
Non-Erosive Propellant Burn Rate

Provides Maximum Motor Length,
Minimum Motor Core Diameter,
Maximum Propellant Loading for
a Given Level (Design Point) of
Erosive Burning



Constant Mass Flux Initial Port Design (2)

- Fix initial port radius until Flux $> G_{max}$ at some critical location x_{cr}
- *Then grow port diameter to give constant massflux*



$$r(x) = r_0 + K \cdot (x - x_{cr})$$

x_{cr}

$$r(x) = r_0$$

• Up to $x_{cr} \rightarrow r_{(x)} = r_0$

Augmented Burn Area

$$\rightarrow A_{burn} = 2\pi \cdot \left\{ \int_{x_{cr}}^L [r_0 + K \cdot (x - x_{cr})] \cdot dx + r_0 \cdot x_{cr} \right\} = 2\pi \cdot \left\{ r_0 \cdot (L - x_{cr}) + \int_{x_{cr}}^L [K \cdot (x - x_{cr})] \cdot dx + r_0 \cdot x_{cr} \right\} =$$


$$2\pi \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (x - x_{cr})^2 \Big|_{x_{cr}}^L \right\} = 2\pi \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (L - x_{cr})^2 \right\}$$

Augmented Massflow @ Exit

$$\rightarrow \dot{m}_{exit} = \rho_{fuel} \cdot \dot{r} \cdot A_{burn} = 2\pi \cdot \rho_{fuel} \cdot \dot{r} \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (L - x_{cr})^2 \right\}$$

Constant Mass Flux Initial Port Design (3)

- Use Allowable G_{max} to find location of x_{cr}




- At $x_{cr} \rightarrow \frac{\dot{m}}{A_c} = G_{max}$ for optimal propellant loading

$$\rightarrow G_{max} = \frac{\rho_{fuel} \cdot \dot{r} \cdot A_{burn}}{\pi \cdot r_0^2} = \frac{2\pi \cdot \rho_{fuel} \cdot \dot{r} \cdot r_0 \cdot x_{cr}}{\pi \cdot r_0^2} = \frac{2 \cdot \rho_{fuel} \cdot \dot{r} \cdot x_{cr}}{r_0}$$

- Solve for x_{cr}

$$\rightarrow x_{cr} = \frac{G_{max} \cdot (r_0 / \dot{r})}{2 \cdot \rho_{fuel}}$$

Constant Mass Flux Initial Port Design (4)




- Apply Max Flux Design Rule @ L

$$(G_{\max})_L \geq \frac{\dot{m}_L}{A_{c_x}} = \frac{2\pi \cdot (\rho_{fuel} \cdot \dot{r}) \cdot \left[r_0 \cdot L + \frac{1}{2} K \cdot (L - x_{cr})^2 \right]}{\pi \cdot r_L^2} = \frac{2\pi \cdot (\rho_{fuel} \cdot \dot{r}) \cdot \left[r_0 \cdot L + \frac{1}{2} K \cdot (L - x_{cr})^2 \right]}{\pi \cdot [r_0 + K \cdot (L - x_{cr})]^2}$$

- Solve for Threshold Value of K @ L

$$K^2 + \left\{ \left(\frac{2r_0}{L - x_{cr}} \right) - \left(\frac{\rho_{fuel} \cdot \dot{r}}{G_{\max}} \right) \right\} \cdot K + \left(\frac{r_0}{L - x_{cr}} \right) \left\{ \left(\frac{r_0}{L - x_{cr}} \right) - 2 \left(\frac{\rho_{fuel} \cdot \dot{r}}{G_{\max}} \right) \cdot \left(\frac{L}{L - x_{cr}} \right) \right\} = 0$$

Constant Mass Flux Initial Port Design (5)



- Solve Quadratic Equation

$$K = \left\{ \left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) - \left(\frac{r_0}{L - x_{cr}} \right) \right\} \pm \sqrt{\left\{ \left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) - \left(\frac{r_0}{L - x_{cr}} \right) \right\}^2 + \left(\frac{r_0}{L - x_{cr}} \right) \left\{ \left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) \cdot \left(\frac{4 \cdot L}{L - x_{cr}} \right) - \left(\frac{r_0}{L - x_{cr}} \right) \right\}}$$

Keep Root with Positive Value

.. K determines our radius growth slope at x_{cr}

Constant Massflux Design Example (6)

- Mean Combustion Pressure (Quasi Steady) of Augmented Grain

$$\frac{\partial P_0}{\partial t} = \frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] - P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right]$$

Quasi-Steady: $\frac{A_{burn} a P_o^n}{V_c} [\rho_p R_g T_0 - P_0] = P_0 \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} \right]$

$$\dot{r} = a P_o^n \rightarrow P_{0_{ss}} \left[\frac{A^*}{V_c} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} + \frac{A_{burn} \dot{r}}{V_c} \right] = \frac{A_{burn} \dot{r}}{V_c} [\rho_p R_g T_0]$$

→ Solve for P_0 →
$$P_{0_{ss}} = \frac{\rho_p R_g T_0}{\left[\frac{A^*}{A_{burn} \dot{r}} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} + 1 \right]}$$

Constant Massflux Design Example (7)

- Mean Combustion Pressure (Quasi Steady), Account for Increased Burn Area due to expanded Port Radius

$$\rightarrow A_{burn} = 2\pi \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (L - x_{cr})^2 \right\}$$

$$P_{0_{ss}} = \frac{\rho_p R_g T_0}{\frac{A^*}{A_{burn} \dot{r}} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}} + 1}} = \frac{\rho_p R_g T_0}{\frac{\dot{A}^*}{\dot{r}} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}} + 1}$$

$$2\pi \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (L - x_{cr})^2 \right\}$$

Constant Massflux Design Example (8)

Pick $(G_{\max})_L$ for given pressure level

→ i.e. $400 - 600 \text{ psia}$ ($2,758 - 4,137 \text{ kPa}$) → $G_{\max} \approx 1.00 \text{ lbm/sec-in}^2$ (70.33 g/sec-cm^2)

→ Assume Starting $(P_0)_{(j)}$, $(\dot{r})_j = a \cdot (P_0^n)_{(j)}$

Calculate $(x_{cr})_{(j)}$

$$\rightarrow (x_{cr})_{(j)} = \frac{G_{\max} \cdot (r_0 / (\dot{r})_j)}{2 \cdot \rho_{fuel}}$$

Calculate $(K)_{(j)}$

$$(K)_{(j)} = \left[\left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{\max}} \right) - \left(\frac{r_0}{L - (x_{cr})_{(j)}} \right) \right] \pm \sqrt{\left[\left(\frac{\rho_{fuel} \cdot (\dot{r})_j}{2 \cdot G_{\max}} \right) - \left(\frac{r_0}{L - (x_{cr})_{(j)}} \right) \right]^2 + \left(\frac{r_0}{L - (x_{cr})_{(j)}} \right) \left[\left(\frac{\rho_{fuel} \cdot (\dot{r})_j}{2 \cdot G_{\max}} \right) \cdot \left(\frac{4 \cdot L}{L - (x_{cr})_{(j)}} \right) - \left(\frac{r_0 \cdot L}{L - (x_{cr})_{(j)}} \right) \right]}$$

Re-calculate P_0, \dot{r}

$$\rightarrow (P_0^n)_{(j+1)} = \frac{\rho_p R_g T_0}{\frac{A^*}{(\dot{r})_j} \sqrt{\gamma R_g T_0 \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{(\gamma-1)}}}} \quad (\dot{r})_{j+1} = a \cdot (P_0^n)_{(j+1)}$$

$$\left[\frac{2\pi \cdot \left(r_0 \cdot L + \left\{ r_0 + (K)_{(j)} \cdot (L - (x_{cr})_{(j+1)})^2 \right\} \right)}{2\pi \cdot \left(r_0 \cdot L + \left\{ r_0 + (K)_{(j)} \cdot (L - (x_{cr})_{(j+1)})^2 \right\} \right)} + 1 \right]$$

- Algorithm, Iterate to convergence

Constant Massflux Design Example (9)

- Initial Erosion Compensated Port Geometry

Port Radius

$$x > x_{cr}$$

$$\rightarrow r(x) = r_0 + K \cdot (x - x_{cr})$$

else

$$\rightarrow r(x) = r_0$$

Burn Area

$$\rightarrow A_{burn} = 2\pi \cdot \left\{ r_0 \cdot L + \frac{1}{2} K (L - x_{cr})^2 \right\}$$

Port Volume

$$V_{port} = \pi \cdot \left(x_{cr} \cdot r_0^2 + \int_{x_{cr}}^L r^2 dx \right) =$$

$$\pi \cdot \left(x_{cr} \cdot r_0^2 + \frac{(L - x_{cr})}{3} \cdot \left\{ (r_0 + K \cdot (L - x_{cr}))^2 + r_0 \cdot (r_0 + K \cdot (L - x_{cr}))^2 + r_0^2 \right\} \right)$$

Example Calculation

Motor Parameters

Geometry		Properties of Propellant Combustion Products		Iteration Array			
Upstream Port Diameter, d0, cm	1	Effective gamma	1.2	rdot, cm/sec	1.07398	rdot, cm/sec	1.07404
Port Length, cm	28	Effective MW	25	mdot, g/sec	155.299	mdot, g/sec	155.35
Throat Diameter, cm	0.85	Idealized Flame Temperature, deg. K	2900	Kscale	0.0192409	Kscale	0.019242
Grain Diameter, cm	3	Start pressure, kPa	3400	Mean Radius, cm	0.577377	Mean Radius, cm	0.57739
Saint Roberts Burn Parameters		Max Number of Iterations*	20	Aburn, cm^2	115.191	Aburn, cm^2	115.195
Burn Multiplier, a cm/sec-kPa^n	0.25	Port mass Flux	70.33	xcrit2, cm	12.9932	xcrit2, cm	12.9924
Burn Exponent, n	0.175	Erosive Burning Threshold g/sec-cm^2	2	P02.kPa	4145.58	P02.kPa	4145.97
		Convergence error	0.00010	Port Volume, cm^3	30.1076	Port Volume, cm^3	30.1091
		Relaxation Factor	0.7500!	EXIT Port Diameter, cm	1.57749	EXIT Port Diameter, cm	1.57755
				Aexit, cm^2	1.95444	Aexit, cm^2	1.95459
				Mdot, xcr, g/sec	55.2371	Mdot, xcr, g/sec	55.2371
				G, xcr, g/sec 2	70.33	G, xcr, g/sec 2	70.33

of iterations

10

35

Example Calculation (2)

Propellant Mass, MassFlow

A 8

Uncompensated
Initial Mass, g

221.671

Compensated
Initial Mass, g

211.442

% mass loss

-4.72328

Uncompensated
Propellant Massflow,
g/sec

155.36

Compensated
Propellant Massflow,
g/sec

155.35

% massflow Loss

-0.00644265

Iteration Array

rdot, cm/sec

1.07398

mdot, g/sec

155.299

Kscale

0.0192409

Mean Radius, cm

0.577377

Abum, cm²

115.191

xcrit2, cm

12.9932

P02.kPa

4145.58

Port Volume, cm³

30.1076

EXIT Port Diameter, cm

1.57749

Aexit, cm²

1.95444

Mdot, xcr, g/sec

55.2371

G, xcr, g/sec 2

70.33

rdot, cm/sec

1.07402

mdot, g/sec

155.334

Kscale

0.0192416

Mean Radius, cm

0.577386

Abum, cm²

115.193

xcrit2, cm

12.9927

P02.kPa

4145.85

Port Volume, cm³

30.1086

EXIT Port Diameter, cm

1.57753

Aexit, cm²

1.95455

Mdot, xcr, g/sec

55.2371

G, xcr, g/sec 2

70.33

rdot, cm/sec

1.07404

mdot, g/sec

155.35

Kscale

0.019242

Mean Radius, cm

0.57739

Abum, cm²

115.195

xcrit2, cm

12.9924

P02.kPa

4145.97

Port Volume, cm³

30.1091

EXIT Port Diameter, cm

1.57755

Aexit, cm²

1.95459

Mdot, xcr, g/sec

55.2371

G, xcr, g/sec 2

70.33

Final Iteration

rdot, cm/sec

1.07404

mdot, g/sec

155.35

Kscale

0.019242

Mean Radius, cm

0.57739

Abum, cm²

115.195

xcrit2, cm

12.9924

P02.kPa

4145.97

Port Volume, cm³

90.1009

EXIT Port Diameter, cm

1.57755

Aexit, cm²

1.95459

Mdot, xcr, g/sec

55.2371

G, xcr, g/sec 2

70.33

Threshold Distance
Xcrit, cm


12.9924

Example Calculation (3)

- Adjusted Port Diameter →

$$K = \left\{ \left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) - \left(\frac{r_0}{L - x_{cr}} \right) \right\} \pm \sqrt{\left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) - \left(\frac{r_0}{L - x_{cr}} \right)^2 + \left(\frac{r_0}{L - x_{cr}} \right) \left(\frac{\rho_{fuel} \cdot \dot{r}}{2 \cdot G_{max}} \right) \cdot \left(\frac{4 \cdot L}{L - x_{cr}} \right) - \left(\frac{r_0}{L - x_{cr}} \right)^2}$$

Motor_Condition 2



Constant Massflux Design Example (4)


- Adjusted Port Diameter →

$$G_{max} = 1.0 \frac{lbm}{in^2 \cdot sec} \left(70.33 \frac{g}{cm^2 \cdot sec} \right)$$

Threshold Distance
Xcrit, cm


12.9924

Massflux vs Length




Example Calculation (5)

Port Mach Number



Exponent Effect on Burn Rate (Pressure Excursion)



- High values of burn exponent (n) make for a propellant whose burn rate is sensitive to chamber pressure
- Solid propellant motors with high burn rate profiles specially susceptible to fuel grain cracks and fractures
- Erosive burning can precipitate grain fracture

Source: Barrere et al.,
Raketenantriebe, Fig 5.1 (1961)

What happens when a solid propellant grain fractures?

- Solid propellant grain fracture events produce detrimental effects on motor performance, and can sometimes be catastrophic
- As crack propagates in the grain or along the grain/case interface, it creates additional burning surfaces
- Augmented burn area produces an excess of hot gas
- Excess mass flow strongly affects the chamber pressure rise and can (depending on the burn exponent) couple with the regression rate to produce a runaway burn and catastrophic failure.


97

What happens when a solid propellant grain fractures? ⁽²⁾


- A classical example of a catastrophic solid rocket failure resulting from propagation of a crack along the grain/case interface is the Titan IV accident August, 1998
- Aerodynamic effects associated with the grain shape near a slot and the interaction between core and cross flows resulted in a dramatic increase in the head end pressure of the motor.
- The crack extended to the propellant case bond and propagated along the interface between the fuel and case.
- This sequence of events eventually led to the choking of the core flow and resulted in the rocket exploding.

<http://www.youtube.com/watch?v=ZFeZkrRE9wI>

What happens when a solid propellant grain fractures? ⁽³⁾




Extremely Complex Fluid/Structural Interaction Problem



Center for Simulation of Advanced Rockets



University of Illinois at Urbana-Champaign



State of the Art Modeling

Project 2

Build Unsteady Model of “Pike” .. Use Integrator of your choice

Calculate:

Chamber pressure profile

Regression rate profile

Massflow rate (compare to choking massflow)

Mass depletion vs time

plot Thrust profile

plot Total Impulse profile

Effective Mean Specific Impulse

Allow:

St. Robert’s Parameter Input

Variable Step Size

Variable Thermodynamic Properties (as inputs to the problem)

Erosive burn model for cylindrical port (Not Bates grain)

Project 2 (2)

Part 1, cylindrical port

Fuel Grain Geometry

$$L_0 = 35 \text{ cm}$$

$$D_0 = 7.6 \text{ cm}$$

$$D_0 = 3 \text{ cm}$$

$$\rho_{\text{propellant}} = 1260 \text{ kg/m}^3$$

Nozzle Geometry

$$A^* = 1.887 \text{ cm}^2$$


$$A_{\text{exit}}/A^* = 4.0$$

$$\theta_{\text{exit}} = 20 \text{ deg.}$$



*Single propellant
segment*

Animal Works™,
L700 Motor Geometry



Assume ends are burn inhibited

Project 2 (3)

Combustion Gas Properties

$$\gamma = 1.18$$

$$M_W = 23 \text{ kg/kg-mol}$$

$$T_0 = 2900 \text{ K}$$

Burn Parameters

$$a = 0.12 \text{ cm}/(\text{sec}\cdot\text{kPa}^n)$$

$$n = 0.16$$

$$M^{crit} = 0.3$$

$$k = 0.2$$

(cylindrical port only)



Project 2 (4)

Part 1, cylindrical port

Fuel Grain Geometry

$$L_0 = 35 \text{ cm}$$

$$D_0 = 7.6 \text{ cm}$$

$$D_0 = 3 \text{ cm}$$


$$\rho_{\text{propellant}} = 1260 \text{ kg/m}^3$$

Nozzle Geometry


$$A^* = 1.887 \text{ cm}^2$$

$$A_{\text{exit}}/A^* = 4.0$$

$$\theta_{\text{exit}} = 20 \text{ deg.}$$



*Animal WorksTM,
L700 Motor Geometry*



*Repeat results
Using bates grain
With 3 segments*

Assume ends are not! burn inhibited

Project 2 (5)

Combustion Gas Properties

$$\gamma = 1.18$$

$$M_W = 23 \text{ kg/kg-mol}$$

$$T_0 = 2900 \text{ K}$$

Burn Parameters


$$a = 0.12 \text{ cm}/(\text{sec}\cdot\text{kPa}^n)$$

$$n = 0.16$$

$$M^{crit} = 0.3$$

$$k = 0.2$$

(cylindrical port only)



Project 2 (6)

Examine sensitivity of calculations to burn rate parameters,
Critical Mach number (for erosion) ... cylindrical port
Only, Assume bates grain does not burn erosivley

What is the effect of Flame temperature (T_0)

Plot Regression rate versus Chamber pressure

Prepare report stating your results and conclusions

State Equation Formulation of Problem

$$\begin{bmatrix} \dot{P}_0 \\ \dot{r} \end{bmatrix} = \begin{bmatrix} \left(\frac{A_{burn} \cdot \dot{r}}{V_c} \right) \cdot (\rho_{propellant} \cdot R_g \cdot T_0 - P_0) - \left(\frac{A^*}{V_c} \right) \cdot P_0 \cdot \sqrt{\gamma \cdot R_g \cdot T_0 \cdot \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{\gamma-1}}} \\ a \cdot P_0^n \end{bmatrix}$$

$$\begin{bmatrix} P_0 \\ r \end{bmatrix}_{t=0} = \begin{bmatrix} P_{ambient} \\ \frac{d_0}{2} \end{bmatrix} \rightarrow \boxed{s(t) = \int_0^t \dot{r} \cdot dt \approx r(t) - \frac{d_0}{2}} \quad \begin{bmatrix} k \equiv \text{Erosion Constant}_{(\text{GRAIN DEPENDENT})} \\ M_{crit} \equiv \text{Critical Port Mach Number} \end{bmatrix}$$

→ State Equations for Erosive Burning :

$$\begin{bmatrix} \dot{P}_0 \\ \dot{r} \end{bmatrix} = \begin{bmatrix} \left(\frac{A_{burn} \cdot \dot{r}}{V_c} \right) \cdot (\rho_{propellant} \cdot R_g \cdot T_0 - P_0) - \left(\frac{A^*}{V_c} \right) \cdot P_0 \cdot \sqrt{\gamma \cdot R_g \cdot T_0 \cdot \left(\frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{\gamma-1}}} \\ \left(1 + k \cdot \frac{M_{port}}{M_{crit}} \right) \cdot a \cdot P_0^n / (1+k) \end{bmatrix}$$

$$\begin{bmatrix} P_0 \\ r \end{bmatrix}_{t=0} = \begin{bmatrix} P_{ambient} \\ \frac{d_0}{2} \end{bmatrix} \rightarrow \boxed{s(t) = \int_0^t \dot{r} \cdot dt \approx r(t) - \frac{d_0}{2}}$$

State Equation Formulation of Problem (2)

→ *Cylindrical Port* :

$$\boxed{A_{burn} = 2 \cdot \pi \cdot r \cdot L_{port} \quad V_c = \pi \cdot r^2 \cdot L_{port}} \rightarrow \begin{cases} r \equiv \text{Port Radius} \\ L_{port} \equiv \text{Port Length} \end{cases}$$

→ *Bates Grain* :

$$A_{burn} = N \cdot \pi \cdot \left\{ \left[\frac{D_0^2 - (d_0 + 2 \cdot s)^2}{2} \right] + (L_0 - 2 \cdot s) \cdot (d_0 + 2 \cdot s) \right\}$$

$$V_c = \frac{N \cdot \pi}{4} \cdot \left\{ (d_0 + 2 \cdot s)^2 \cdot (L_0 - 2 \cdot s) + D_0^2 \cdot 2s \right\}$$

Do NOT! Use Erosive Burning for Bates Grain