TT405 / MS300 — Cut List Guide

This guide describes the cut list (job file) of **TT405 and MS300 machines with B&R PLC**. Both machines use the same file format. Each line defines one part to be cut.

File format

- Each line has **16 fields**, separated by `;`.
- The file has **no header line**; the first line is the first part.
- A file can contain at most **2000 lines** (cuts).
- If a field is empty, keep its position (`;;`); do not shift the following fields to the left.

```
1;806;XXXXXXX12PEN;45;45;1;60;X10MUSTERI;1;1;1;1;906;11;0;XXXXXXXXXX16BAYI
```

Fields

Fields marked **Required** are used by the machine for cutting and must not be empty. The other fields are printed on the label.

No	Field	Required	Max.	Type	Description
1	Cut Number	✔	4 digits	Integer	Cut number, increasing from line to line.
2	Cut Length	✔	5 digits	Decimal	Part length in mm. Can be written as `1200` or `1200.0`; the decimal separator is a point.
3	Profile Code		12 characters	Text	Profile code.
4	Left Angle	✔	2 digits	Integer	Left cutting angle, for example `45` or `90`.
5	Right Angle	✔	2 digits	Integer	Right cutting angle, for example `45` or `90`.
6	Quantity	✔	1 digit	Integer	`1` or `2`.
7	Height		3 digits	Integer	Height information printed on the label.
8	Order No		10 characters	Text	Order number.
9	Position No		3 digits	Integer	Window / position number.
10	Assembly		1 digit	Integer	Side of the part in the frame; see Assembly codes.
11	Trolley No		1 digit	Integer	Trolley the part is placed on.
12	Slot No		3 digits	Integer	Slot number in the trolley.
13	Other Axis		5 digits	Decimal	Length of the other frame axis in mm. Can be written as `1200` or `1200.0`.

No	Field	Required	Max.	Type	Description
14	Color/ Gasket		2 digits	Integer	See Color / gasket codes.
15	Operation		2 digits	Integer	See Operation codes.
16	Dealer Name		16 characters	Text	Dealer / customer name.

Angles are written as a single number. The `90|45` (tilt | pivot) format of TT425 / TT426 files is not used on these machines.

Assembly codes

Code	Side
1	Top (Y)
2	Right (X)
3	Bottom (Y)
4	Left (X)

Color / gasket codes

Code	Gasket	Profile color
01	No gasket	White
02	No gasket	Bottom colored
03	No gasket	Top colored
04	No gasket	Full colored
11	With gasket	White
12	With gasket	Bottom colored
13	With gasket	Top colored
14	With gasket	Full colored

`01` and `1` are the same code.

Operation codes

Code	Operation
0	No operation
1	Water slot

Code	Operation
2	Handle
3	Hinge
4	Double opening
5	Single opening, left
6	Single opening, right
7	Double opening, left
8	Double opening, right
9	V. opening, left
10	Right opening door
11	Left opening door
12	Transom window

Example

No	Length	Profile	Left	Right	Qty	Height	Order	Pos.	Assembly	Trolley	Slot	Other axis	Color/ Gasket	Operati
1	806	XXXXX XX12P EN	45	45	1	60	X10M USTE RI	1	1	1	1	906	11	
2	906	XXXXX XX12P EN	45	45	1	60	X10M USTE RI	1	2	1	2	806	11	
9	1506	XXXXX XX12P EN	90	90	1	60	X10M USTE RI	200	1	2	10	1806	1	

First line: an 806 mm white profile with gasket, cut at 45° on both ends; the top part (assembly 1) of position 1, the other frame side is 906 mm, no operation, placed in slot 1 of trolley 1.

Download the example cut list

Profile, order and dealer values in the example are fictitious.

Before importing

1. Check that every line has 16 fields and the separator is ;.
2. Check that the required fields (cut number, length, left / right angle, quantity) are filled.
3. Check that length and other axis values use a point as the decimal separator.
4. Check that assembly, color / gasket and operation codes are in the tables above.
5. Check that the file does not exceed 2000 lines.
6. Check the file in the CSV File Checker with the **TT405-B&R** option.

Home page