
```
% define system parameters:
c =
       50;
               % kg/s
       10000; % N/m
k =
m =
         331 ; % kg
Y=.05;
v=(65.*1.60934.*1000)./3600;
wb=v.*2.*pi;
% define the time interval and the number of integration steps
  = 100000;
    = zeros(n,1);
tf = 10;
t(1) = 0;
delt = (tf-t(1))/n;
% initializing variables
  = zeros(n,1);
  = zeros(n,1);
% assign initial conditions
x(1) = 0;
v(1) = 0;
% start the integration directly from the second step (with i=2)
for i=2:1:n
   % update the velocity and acceleration for x at step i
   a=(-c./m).*v(i-1)+(-k./m).*x(i-1)+((c.*Y.*wb)./m).*cos(wb.*t(i-1))+((k.*Y)./m).*sin(wb.*t(i-1));
   \% integrate x and v
   x(i) = x(i-1)+v(i-1).*delt;
   v(i) = v(i-1)+a.*delt;
   % integrate time
   t(i)=t(i-1)+delt;
end % end of each integration step
% plot results
figure(20)
clf;
% plot vertical position
subplot(2,1,1)
box on; grid on; hold on;
plot(t,x,'linewidth',2);
ylabel('Position [m]', 'fontsize', 14, 'fontname', 'times');
% plot vertical velocity
subplot(2,1,2)
box on; grid on; hold on;
plot(t,v,'linewidth',2);
xlabel('t [s]', 'fontsize', 14, 'fontname', 'times');
ylabel('Velocity [m/s]', 'fontsize', 14, 'fontname', 'times');
```



Published with MATLAB® R2020a