Schematic for	()
version 1		PORTB5
		PORTB4 ———Alarm
		PORTB3 7-segment pin D4
		PORTB27-segment pin D3
		PORTB17-segment pin D2
		PORTB07-segment pin D1
		PORTD77-segment pin DP
		PORTD67-sengment pin G
Temperature Sensor input—	PORTC0	PORTD57-sengment pin F
Button 2 (decrease values/activate, deactivate alarm)—————	PORTC1	PORTD47-sengment pin E
Button 3 (increase values/display second)—————	PORTC2	PORTD37-sengment pin D
Switch mode (TIME/SET) button——	PORTC3	PORTD27-sengment pin C
	PORTC4	PORTD17-sengment pin B
	PORTC5	PORTD07-segment pin A

