
Machine boundary: all masses and contacts
Optional
Branch mass
d_{12}
d_{23}
m_1
m_2
m_3
F_R, v_R
Loaded receiver
x_1, v_1
x_2, v_2
x_3, v_3