

Preparing a Job for Printing using Colorbyte Design Software (Orange Icon)

1. Open the job using the SO number.
2. Move the material to 0,0 on the screen.
3. Change the blank size to slightly larger than the material.
4. Apply proper color and primer amount.
5. Select only the objects you want to print and click File/Send to Rip.
6. Watch the file rip on the Corel Byte rip software(green icon).
7. Go to the Print Control Software and refresh the queue.



Commonly used Shortcuts

Ctrl-click to select and deselect layers and colors.

Alt-S to see fill.

Alt-K for the alignment tool.