

Colorbyte Design Software (Orange Icon)

To prepare for Rip

1. Open the job using the SO number.
2. Move the material to 0,0 on the screen.
3. Change the text and braille color as needed.
4. Select the items you want to print.
5. Click File/Send to Rip.
6. Check rip software (green icon) to make sure it has passed through the queue.



Commonly used Shortcuts

Hold shift to select multiple items.

Ctrl click to select and deselect layers and colors.

Alt-S to see fill.

Alt-K for the alignment tool.