

Note1: Text in italic placed on a wire doesn't correspond to net name. It just helps to identify rapidly Arduino's signal related to this wire.

Note2: Remove [N/A] on R34, R36, C31, C32, X2 from C.1 to C.2

Note3: Add "default open" on SB48, SB49, SB55 from C.1 to C.2

Note4: Replace "default open" by "default closed" on SB16 & SB50 from C.1 to C.2


Note5: C26's value changed from 2.2uF to 4.7uF from C.2 to C.3


Title: TOP & POWER


Project: NUCLEO-XXXXXXX

Size: A4 Reference: MB1136 Revision: C.3

Date: 6/16/2014 Sheet: 1 of 4 life.augmented







Title: Extension connectors			
Project: NUCLEO-XXXXXXX			
Size: A4	Reference: MB1136	Revision: C.3	
Date: 6/16/2014		Sheet: 4 of 4	life.augmer