## 5.4.5 Device Family SC nnnHE-US

In the following table, you will find the measured values and parameters supported by the SC nnnHE-US device family, which you can access under the Unit IDs = 3-247 (see section 3.4.1 "Unit IDs", page 13). The assignments in section 5.4.1 "Common Addresses of all SMA Devices", page 28 also apply to this table:

ADR (DEC)	Description/Numerical code	CNT (WORD)	Туре	Format	Access
30199	Time until grid connection attempt (s) [TmsRmg]	2	U32	Duration	RO
30211	Recommended action [Prio]: 336 = Contact manufacturer 337 = Contact installer 338 = Invalid	2	U32	ENUM	RO
30217	Grid contactor [GdCtcStt]: 51 = Contactor closed 311 = Contactor open	2	U32	ENUM	RO
30241	Operating state [Mode]: 309 = Operation 455 = Warning 1392 = Error 1470 = Fault	2	U32	ENUM	RO
30243	Error [Error]: 267 = Inverter 1395 = DC section 1396 = AC grid	2	U32	ENUM	RO
30247	Current event number for manufacturer [ErrNoSma]	2	U32	FIXO	RO
30257	DC switch in cabinet [DcSwStt]: 51 = Closed 311 = Open	2	U32	ENUM	RO
30261	AC switch 1 in cabinet [AcSwStt]: 51 = Closed 311 = Open	2	U32	ENUM	RO
30265	AC switch-disconnector in cabinet [DlnErrAcScir]: 51 = Closed 311 = Open	2	U32	ENUM	RO