Overview

This pin detect HID MSD example can become a HID mouse device or a MSD host that supports U-disk. The application prints the operation information when the U-disk is attached or is plugged into the PC host.

System Requirement

Hardware requirements

- · Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower module/base board, and so on) for a specific device
- Personal Computer

Software requirements

• The project files are in:

<MCUXpresso_SDK_Install>/boards/<board>/usb_examples/usb_pin_detect_hid_msd/<rtos>/<toolchain>.

Note

The <rtos> is Bare Metal or FreeRTOS OS.

Getting Started

Hardware Settings

• The Jumper settings:

J14 1-2.

If enable USB Full Speed function, please add jumper on J53.

If enable USB High Speed function, please remove jumper on J53.

to enable usb_pin_detect_hid_mouse example,the R91 need to be soldered with 0 ohm resistor manually.

For detailed instructions, see the appropriate board User's Guide.

Note

The jumpers of the hardware (Tower system/base module) needs to be set to default setting at first.

Prepare the example

- 1. Download the program to the target board.
- 2. Power off the target board and power on again, or press the reset button on your board.

Note

For detailed instructions, see the appropriate board User's Guide.

Run the example

- 1. Connect the board UART to the PC and open the COM port in a terminal tool.
- 2. Run the pin_detect_hid_msd example. The board now acts as an USB device mouse and a USB switch-to-device mode information is displayed.
- 3. Plug in an U-disk to the test board. The board acts as an USB host. The stack switches to host mode and makes some read/write operations of file system. Meanwhile, some attached-device and the related operation information are printed out.

- 4. Unplug the mouse with the cable. The board now acts as a USB device mouse. The mouse is detached and the USB switches to the device mode information.
- 5. Plug in the mouse device into the PC. An HID-compliant mouse is enumerated in the Device Manager.
- 6. The mouse arrow is moving on the PC screen in a rectangular rotation.

The following figures show a pin detect msd information for the pin detect hid msd demo.

Note

Because the printed information is much long, so the U-disk been plugged out in advance.

```
host init done
mass storage device attached:pid=0x5567vid=0x781 address=1
.....fatfs test.....
fatfs mount as logiacal driver 1....success
test f_mkfs.....mass storage device detached
error
.....test done....
host deinit done
USB device HID mouse demo
```

Figure 1: Pin detect hid msd demo