

User Guide - Smart Office Network & IoT devices

Nasrin Younis

1. How to add devices to the network using static IP

- Connect the device to the network using an ethernet cable.
- Open the device and select desktop then select IP configuration.
- Select static
- Enter the:
 - IP address
 - Subnet mask
 - Default gateway
 - DNS server
- Confirm connectivity by using the ping command

2. How to add a device using DHCP

- Connect the device to the network
- Open desktop then select IP configuration
- Select DHCP
- The device will automatically obtain:
 - IP address
 - Subnet mask
 - Default gateway
 - DNS server
- Confirm the assigned address and test the connection using ping

3. How to connect a device using a cable (Wired)

- Connect the Ethernet cable from the device to the network switch
- Configure either:
 - Static IP , DHCP
- Verify network connectivity using ping or tracert

4. How to connect a device wirelessly

- Install a wireless network adapter if required
- Open config and select Wireless0
- Enter the correct SSID
- Select WPA2-PSK security
- Enter the wireless passphrase
- Choose DHCP or configure a static IP
- Test the connection using ping

5. How to set up a device using SSID and passphrase

- Open the wireless settings
- Enter the network SSID:
SmartOffice
- Select WPA2-PSK
- Enter the network password:
Office123
- Save the settings and confirm the device connects successfully

6. How to add and configure an IoT device

- Place the IoT device onto the workspace
- Open the device configuration
- Select remote server
- Enter the IoT server IP address
- Enter the IoT username and password
- Connect the device
- Confirm that the device appears on the IoT server

7. How to operate IoT devices using the IoT management app

- Open the smartphone or any other device and select IoT monitor
- Log in using the IoT account
- Select the required IoT device
- Monitor the device status
- Control the device as you need