

# Desk Dial · knob cheat sheet

Every screen of the knob with its four buttons (1 = left, 4 = right) and what a hold does.  
Turn the knob to browse or set; press a button to act; a lit button marks the knob's current job.

hold 1 (0.6 s) = Home from anywhere

|  |                                                                                                                              |  |                                                                                                                            |
|--|------------------------------------------------------------------------------------------------------------------------------|--|----------------------------------------------------------------------------------------------------------------------------|
|  | <b>Home</b><br>1 Music<br>2 Win<br>3 Lights<br>4 Pause<br>hold 4 (1.0 s) = Knob to lights                                    |  | <b>Music</b><br>1 Home<br>2 Recent<br>3 Tracks<br>4 Pause<br>hold 1 (0.6 s) = Home                                         |
|  | <b>Recently Added</b><br>1 Back<br>2 Full screen<br>3 Playlists<br>4 Play<br>hold 4 (1.0 s) = Queue<br>hold 1 (0.6 s) = Home |  | <b>Playlists</b><br>1 Back<br>2 Full screen<br>3 Recent (lit)<br>4 Play<br>hold 4 (1.0 s) = Queue<br>hold 1 (0.6 s) = Home |
|  | <b>Tracks</b><br>1 Back<br>2 Up next<br>3 Seek<br>4 Play<br>hold 1 (0.6 s) = Home                                            |  | <b>Seek</b><br>1 Cancel<br>2 Up next<br>3 Set (lit)<br>4 Play<br>hold 1 (0.6 s) = Home                                     |
|  | <b>Up next</b><br>1 Back<br>2 Shuffle<br>3 Like<br>4 Play<br>hold 4 (1.0 s) = Play next<br>hold 1 (0.6 s) = Home             |  | <b>Windows</b><br>1 Home<br>2 Snap left<br>3 Snap right<br>4 Switch                                                        |
|  | <b>Lights</b><br>1 Home<br>2 Scenes<br>3 Temp<br>4 All off<br>hold 1 (0.6 s) = Home                                          |  | <b>Colour temperature</b><br>1 Home<br>2 Scenes<br>3 Temp (lit)<br>4 All off<br>hold 1 (0.6 s) = Home                      |
|  | <b>Scenes</b><br>1 Back<br>2 —<br>3 —<br>4 Run<br>hold 1 (0.6 s) = Home                                                      |  | <b>Onshape</b><br>1 Tilt<br>2 Orbit<br>3 Undo<br>4 Pan                                                                     |