Work Instruction - Operations

TRAIN MOVEMENT IN MANUAL AREA WORK INSTRUCTION



Work description: The purpose of this docume The procedure applies to the O&M stage of the	ent is to define the protocol according to which real HRTP project	novements in manual area shall be handled.
Scope: Train Movements in the Manual Area		
References: HNL-09664 Yard Operations Proce	dure	
·		
PPE and precautions	Competencies or qualifications	Licenses or permits required
Nil	Yard Control Bungalow (YCB) Operator, Railcar Leading Technician, Train Operator, Train Controller, Road / Rail Vehicle Operator, Train Operator	Nil
Tools and equipment required		
Handheld Portable Radio		



Warning

The Third Rail Is Always Considered Energized



Warning

The Collector Shoe shall be considered energized even if only one of the collector shoes are on contact with the Third Rail

Manual Area Control

Manual area is identified as the area between the West Yard Lead and East Yard Lead transition platforms. Transition platforms are a part of the Automatic area and the occupancy on transition platform is not visible on the YCB workstation.

Transition platforms are under the control of OCC Operators. If a train shall be positioned on transition platforms the OCC Operator shall confirm that the intended location is energized.

YCB Operator can position a train on transition platform only upon authorization from the OCC.

Train movements without P2R/Niteg are in manual mode.

The YCB Operator is responsible for the overall co-ordination of train movement in manual area. Everyone involved in train movement shall not act without prior consultation with the YCB Operator.

Train Movements in the manual area

Railcar Leading Technician

The Railcar Leading Technician must:

- Assign the YCB Operator
- Define details of train movement

YCB Operator

The YCB Operator must:

- Not leave the TCB Workstation during the movement
- Authorize movements in manual area, specifying origin and destination
- Coordinate with the OCC for energization and de-energization as required
- Supervise train movements in manual area
- Operate the YCB workstation to set the intended route for the train
- Make sure that derailers to be encountered during the movement are in the position that allows train movement
- Instruct the train operator to position the derailers as required
- Make sure that the OSB gates are in the requested position
- Stop the movement if a fault is identified with the YCB Workstation and notify the maintenance team
- Not modify the route when the train movements are taking place

Approved By:	☐ Director, Operations and Maintenance	☐ Department Manager	☐ Manager, HSE (Operations and Maintenance)
Signature:			
Date:			

Document Code	HNL-09528 Train Movement in Manual Area Work Instruction.01	Effective Date:	
File Name	HNL-09528.01.00-0-Train Movement in Manual Area Work Instruction	Rev No. 01	Page 1 of 3

Work Instruction - Operations

HITACHI

TRAIN MOVEMENT IN MANUAL AREA WORK INSTRUCTION

Hitachi Rail Honolulu JV
 HITACHI
 Inspire the Next

	Note Staff involved in the train movement will always be in possession of a handheld portable radio		
Train Operator	The Train Operator must:		
	Move the train in manual mode, in accordance with the YCB Operator instruction		
	Position the derailers in the requested position, before and after train movement		
	 Note Speed Shall not exceed 3mph The Train Operator must not leave the train without Authorization from the YCB Operator 		
Road/Rail Vehicle	The Road/Rail Vehicle Operator must:		
Operator	Open/Close the requested gates		
	Move the road/rail vehicle as per YCB Operator instruction		

Train Moving from Automatic to the Manual Area

Trains must be handed over to a YCB Operator by the Train Controller to move into the Manual Area from the Automatic area.

Train Controller

The Train Controller must:

- Get the name of the assigned YCB Operator
- Move the train to the assigned transition platform
- Inform the YCB Operator when the automatic train movement is complete
- Handover the train to YCB Operator

YCB Operator

The YCB Operator must:

- Accept the train from the Train Controller
- Log in the YCB workstation
- Set the requested route
- Inform maintenance staff about the movement
- Ensure that derailers are in a position that allows train movement over the intended route
- Instruct the train operator to put the derailers in the requested position
- Confirm with the Train Operator and OCC that the vehicle is under YCB control
- Instruct the vehicle operator to open the requested gates
- Authorize train movement from transition platform to the intended location

Train Operator

The Train Operator must:

- Put derailers in the requested position (i.e. to allow train movement)
- Reach Transition platform and inform the YCB Operator when complete
- Board The train
- Enable the emergency driver panel
- Wait for YCB Operator authorization to proceed. Maximum speed 3 mph
- Use the horn prior to moving the train:
 - o Be ready to stop the train in the event YCB Operator commands to do so
 - o Be ready to stop the train before any identified obstruction
 - o Move the train until the leading end is aligned with the end of third rail
 - Wait for YCB Operator confirmation that the yard is de-energized, and the train can be coupled with road/rail vehicle
 - Upon YCB Operator authorization, proceed with the coupling
 - $\circ\$ When the movement resumes, be ready to stop the train as required
- Close the emergency driver panel:
 - o Inform YCB Operator when complete
 - o Upon YCB Operator instruction, put the derailers back in their original position

Document Code	HNL-09528. Train Movement in Manual Area Work Instruction.01	Effective Date:	
File Name	HNL-09528.01.00-0-Train Movement in Manual Area Work Instruction	Rev No. 01	Page 2 of 3

Work Instruction - Operations

TRAIN MOVEMENT IN MANUAL AREA WORK INSTRUCTION



Hitachi Rail Honolulu JV HITACHI Inspire the Next

Road Rail Vehicle Operator

The Road/Rail Vehicle Operator must:

- Upon YCB Operator authorization, move the vehicle towards the assigned location
- Upon YCB Operator authorization, proceed with the coupling
- Upon YCB authorization, resume the movement
- Inform YCB Operator when the movement is complete
- Uncouple the vehicles
- Upon YCB Operator authorization, park the Road/Rail vehicle as required

Train Moving from the Manual Area to the Automatic Area

Trains must be handed over to Train Controller by the YCB Operator to move from the Manual Area to the Automatic area. (Transition Platform)

YCB Operator

The YCB Operator must:

- Advise the Train Controller that a train will be moving to the transition platform
- Ensure that derailers are in a position that allows train movement over the intended route
- Instruct train operator to position the derailers as required
- Make sure that third rail is de-energized
- Set the requested route
- Assign staff to open the requested gate
- Authorize Niteg/P2R movement
- Authorize train shunting until the rear end is aligned with the third rail in the yard
- Authorize uncoupling
- Advise the Tran Controller when this is complete and Co-ordinate for Third Rail energization
- Authorize train movement up to transition platform
- When complete, command closure of gates and make sure that derailers are put back in their original position

Train Controller

The Train Controller must:

- Confirm with the YCB Operator which Transition Platform is required
- Check that the requested transition platform is energized
 - Check that the requested transition platform is free
- Take over the train when requested

Road/Rail Vehicle Operator

The Road/Rail Vehicle Operator must:

- Couple the road rail vehicle with the train
- Wait for YCB Operator authorization for movement
- Move the consist until the rear end of the rear end of the train is aligned with the third rail end in the yard
- Movement has to be announced with the horn
- Uncouple the consist
- Park the rail road vehicle upon YCB Operator authorization

Train Operator

The Tran Operator must:

- Position the derailers in the requested position
- Board the train
- Once the train is uncoupled from road rail vehicle and upon YCB Operator authorization, move the train up to the transition platform. Maximum train speed is 3 mph
- Inform YCB Operator when the train is at the transition platform
- Alight the train only after YCB Operator authorization
- Upon YCB Operator authorization, put derailers in the requested position

Movements from one OSB track to another

These movements are to be treated in the same manner as mentioned above. Thus, same principles, actions and responsibilities apply.

Document Code	HNL-09528. Train Movement in Manual Area Work Instruction.01	Effective Date:	
File Name	HNL-09528.01.00-0-Train Movement in Manual Area Work Instruction	Rev No. 01	Page 3 of 3