



## LASERTUNE & EXTERNAL DETECTOR

## QuickStart: the BLKQCL Control API for LaserTune

- Review overall <u>QuickStart.pdf</u>
- The APIs you will care most about for the tunable laser functionality are
  - GetFactorySettings()

WaveNumberRange, temperature set-point ranges, as well as defaults for UserSettings.

GetUserSettings/SetUserSettings

External pulse control, triggers, Laser temperature set-pointers, pulse width/duration, and much more.

o MoveTune()

The Move operation simply turns the laser on, and on a particular wavenumber.

o StepTune()

A step tune turns the laser on for each step from start to stop (by step size increments).

o SweepTune()

A sweep tune turns and moves it smoothly through a caller-specified range of waveNumbers.

StopLasers()

Aborts any outstanding laser operations, and it turns off the laser.

For more details on the these and other APIs, consider the BLKQCL-SDK-API-Reference.pdf