

Leak-Test — Standard Operating Procedure

Leak-Test — Standard Operating Procedure

- 1. Purpose
- 2. Normal operating envelope
- 3. Idle reasons
- 4. Faults & corrective actions
- 5. Preventive maintenance schedule
- 6. References

Leak-Test — Standard Operating Procedure

Audience: Quality Worker · Maintenance Tech · Line Manager
Applies to: Line-C, station 6, Leak-Test

1. Purpose

Leak-Test is the final station of Line-C. It pressurizes the assembled subassembly and measures decay to detect any leak path that escaped earlier inspection. Reject parts route to the policy in [Quality_Reject_Disposition_Policy.pdf](#).

2. Normal operating envelope

- Ideal cycle time: **25 s**
- Max acceptable cycle time: **32 s**
- Expected reject rate: **≤ 3 %**
- Fault probability per cycle: **0.6 %**
- Input buffer capacity: **5 parts**

3. Idle reasons

idle_reason	Meaning here	First check
Starved	Assembly-Robot (station 5) is not feeding parts.	Verify Assembly-Robot state.
Blocked	Discharge conveyor full.	Verify part-out conveyor.

4. Faults & corrective actions

4.1 Pressure-Sensor

- **Symptoms in telemetry:** `fault_type = "Pressure-Sensor"`. Inconsistent pressure decay readings; reject pattern shifts unpredictably.
- **Likely root cause:** sensor drift, calibration expired, or cable damaged.

- **Corrective action:**
 1. Verify sensor against a master gauge.
 2. If drift > 0.5 %, replace the sensor.
 3. Re-validate the recipe against the master leak.
- **Restart criteria:** test cycle passes the master leak (known leak) and the master pass (sealed) parts.

4.2 Seal-Wear

- **Symptoms in telemetry:** fault_type = "Seal-Wear". False reject rate rises against parts that pass downstream verification.
- **Likely root cause:** fixture face seal hardened or cut after high cycle count.
- **Corrective action:**
 1. LOTO. Replace the fixture seal.
 2. Verify clamp force is to spec.
 3. Confirm zero-leak on the master pass part.
- **Restart criteria:** master pass part shows leak rate at noise floor.

4.3 Valve-Stuck

- **Symptoms in telemetry:** fault_type = "Valve-Stuck". Pressurize or vent step times out.
- **Likely root cause:** solenoid valve coil burned, spool contaminated.
- **Corrective action:**
 1. LOTO. Replace the affected valve.
 2. Flush the air line.
- **Restart criteria:** pressure cycle completes within timing window.

5. Preventive maintenance schedule

- **Daily:** run master pass + master leak set at shift start.
- **Weekly:** inspect fixture seals.
- **Monthly:** sensor calibration verification.
- **Quarterly:** full pneumatic service.

6. References

- Quality_Reject_Disposition_Policy.pdf
- Maintenance_Workflow_Overview.pdf
- Shift_Handover_Checklist.pdf
- Line-C_05_Assembly-Robot_SOP.pdf