






OilPump

L110F Oil pump connector


		1
		2
		3
		4
F18.OUT (Pg.3)	+12V	5
X1.30 (Pg.1)	PWMin	6
	PWMout	7
		8
		9
		10
		11
X93.1	CaseGND	12


 Gnd.1 (Pg.3)


 X93


F18.OUT (Pg.3)


X1.30 (Pg.1)

























MitsuCtrl

Connector numbers are row rev...

	NC	1
	NC	2
	NC	3
	DCSW	4
	CHIN	5
	CANH	6
X112.1	Sense	7
F12.OUT (Pg.3)	IGCT	8
	CP	9
X111.1	GND	10
	NC	11
	CHOT	12
	CANL	13

