






OilPump

L110F Oil pump connector

		1
		2
		3
		4
F13.OUT (Pg.3)	+12V	5
X1.30 (Pg.1)	PWMin	6
	PWMout	7
		8
		9
		10
		11
X93.1	CaseGND	12

Gnd.1 (Pg.3)

X93

F13.OUT (Pg.3)

X1.30 (Pg.1)

