

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A0	IOmux	REF_CLK0_OUT	0x201A0000	[0,3]	1	io -4 0x201A0000 0x000F0001
		GPIO0_A0	0x201A0000	[0,3]	0	io -4 0x201A0000 0x000F0000
	Pull	z	0x201A0300	[0,1]	0	io -4 0x201A0300 0x00030000
		up	0x201A0300	[0,1]	1	io -4 0x201A0300 0x00030001
		down	0x201A0300	[0,1]	2	io -4 0x201A0300 0x00030002
	I/O Mode	input	0x20600008	[0,0]	0	io -4 0x20600008 0x00010000
		output	0x20600008	[0,0]	1	io -4 0x20600008 0x00010001
	Output	low	0x20600000	[0,0]	0	io -4 0x20600000 0x00010000
		high	0x20600000	[0,0]	1	io -4 0x20600000 0x00010001
	Input Ctrl	disable	0x201A0400	[0,0]	0	io -4 0x201A0400 0x00010000
		enable	0x201A0400	[0,0]	1	io -4 0x201A0400 0x00010001
	Schmitt	disable	0x201A0500	[0,0]	0	io -4 0x201A0500 0x00010000
		enable	0x201A0500	[0,0]	1	io -4 0x201A0500 0x00010001
	Drive Strength	level0	0x201A0100	[0,5]	1	io -4 0x201A0100 0x003F0001
		level1	0x201A0100	[0,5]	3	io -4 0x201A0100 0x003F0003
		level2	0x201A0100	[0,5]	7	io -4 0x201A0100 0x003F0007
		level3	0x201A0100	[0,5]	15	io -4 0x201A0100 0x003F000F
		level4	0x201A0100	[0,5]	31	io -4 0x201A0100 0x003F001F
		level5	0x201A0100	[0,5]	63	io -4 0x201A0100 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[0,0]		io -4 0x20600070
GPIO0A1	IOmux	FSPI1_D3_M0	0x201A0000	[4,7]	1	io -4 0x201A0000 0x00F00010
		PWM1_CH1_M0	0x201A0000	[4,7]	2	io -4 0x201A0000 0x00F00020
		TSADC_SHUT	0x201A0000	[4,7]	3	io -4 0x201A0000 0x00F00030
		TSADC_SHUTORG	0x201A0000	[4,7]	4	io -4 0x201A0000 0x00F00040
		GPIO0_A1	0x201A0000	[4,7]	0	io -4 0x201A0000 0x00F00000
	Pull	z	0x201A0300	[2,3]	0	io -4 0x201A0300 0x000C0000
		up	0x201A0300	[2,3]	1	io -4 0x201A0300 0x000C0004
		down	0x201A0300	[2,3]	2	io -4 0x201A0300 0x000C0008
	I/O Mode	input	0x20600008	[1,1]	0	io -4 0x20600008 0x00020000
		output	0x20600008	[1,1]	1	io -4 0x20600008 0x00020002
	Output	low	0x20600000	[1,1]	0	io -4 0x20600000 0x00020000
		high	0x20600000	[1,1]	1	io -4 0x20600000 0x00020002
	Input Ctrl	disable	0x201A0400	[1,1]	0	io -4 0x201A0400 0x00020000
		enable	0x201A0400	[1,1]	1	io -4 0x201A0400 0x00020002
	Schmitt	disable	0x201A0500	[1,1]	0	io -4 0x201A0500 0x00020000
		enable	0x201A0500	[1,1]	1	io -4 0x201A0500 0x00020002
	Drive Strength	level0	0x201A0100	[8,13]	1	io -4 0x201A0100 0x3F000100
		level1	0x201A0100	[8,13]	3	io -4 0x201A0100 0x3F000300
		level2	0x201A0100	[8,13]	7	io -4 0x201A0100 0x3F000700
		level3	0x201A0100	[8,13]	15	io -4 0x201A0100 0x3F000F00
		level4	0x201A0100	[8,13]	31	io -4 0x201A0100 0x3F001F00
		level5	0x201A0100	[8,13]	63	io -4 0x201A0100 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[1,1]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A2	IOMUX	RTC_32K_OUT	0x201A0000	[8,11]	1	io -4 0x201A0000 0x0F000100
		CLK_32K	0x201A0000	[8,11]	2	io -4 0x201A0000 0x0F000200
		PMU_DBG	0x201A0000	[8,11]	3	io -4 0x201A0000 0x0F000300
		GPIO0_A2	0x201A0000	[8,11]	0	io -4 0x201A0000 0x0F000000
	Pull	z	0x201A0300	[4,5]	0	io -4 0x201A0300 0x00300000
		up	0x201A0300	[4,5]	1	io -4 0x201A0300 0x00300010
		down	0x201A0300	[4,5]	2	io -4 0x201A0300 0x00300020
	I/O Mode	input	0x20600008	[2,2]	0	io -4 0x20600008 0x00040000
		output	0x20600008	[2,2]	1	io -4 0x20600008 0x00040004
	Output	low	0x20600000	[2,2]	0	io -4 0x20600000 0x00040000
		high	0x20600000	[2,2]	1	io -4 0x20600000 0x00040004
	Input Ctrl	disable	0x201A0400	[2,2]	0	io -4 0x201A0400 0x00040000
		enable	0x201A0400	[2,2]	1	io -4 0x201A0400 0x00040004
	Schmitt	disable	0x201A0500	[2,2]	0	io -4 0x201A0500 0x00040000
		enable	0x201A0500	[2,2]	1	io -4 0x201A0500 0x00040004
	Drive Strength	level0	0x201A0104	[0,5]	1	io -4 0x201A0104 0x003F0001
		level1	0x201A0104	[0,5]	3	io -4 0x201A0104 0x003F0003
		level2	0x201A0104	[0,5]	7	io -4 0x201A0104 0x003F0007
		level3	0x201A0104	[0,5]	15	io -4 0x201A0104 0x003F000F
		level4	0x201A0104	[0,5]	31	io -4 0x201A0104 0x003F001F
		level5	0x201A0104	[0,5]	63	io -4 0x201A0104 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[2,2]		io -4 0x20600070
GPIO0A3	IOMUX	PWR_CTRL0	0x201A0000	[12,15]	1	io -4 0x201A0000 0xF0001000
		GPIO0_A3	0x201A0000	[12,15]	0	io -4 0x201A0000 0xF0000000
	Pull	z	0x201A0300	[6,7]	0	io -4 0x201A0300 0x00C00000
		up	0x201A0300	[6,7]	1	io -4 0x201A0300 0x00C00040
		down	0x201A0300	[6,7]	2	io -4 0x201A0300 0x00C00080
	I/O Mode	input	0x20600008	[3,3]	0	io -4 0x20600008 0x00080000
		output	0x20600008	[3,3]	1	io -4 0x20600008 0x00080008
	Output	low	0x20600000	[3,3]	0	io -4 0x20600000 0x00080000
		high	0x20600000	[3,3]	1	io -4 0x20600000 0x00080008
	Input Ctrl	disable	0x201A0400	[3,3]	0	io -4 0x201A0400 0x00080000
		enable	0x201A0400	[3,3]	1	io -4 0x201A0400 0x00080008
	Schmitt	disable	0x201A0500	[3,3]	0	io -4 0x201A0500 0x00080000
		enable	0x201A0500	[3,3]	1	io -4 0x201A0500 0x00080008
	Drive Strength	level0	0x201A0104	[8,13]	1	io -4 0x201A0104 0x3F000100
		level1	0x201A0104	[8,13]	3	io -4 0x201A0104 0x3F000300
		level2	0x201A0104	[8,13]	7	io -4 0x201A0104 0x3F000700
		level3	0x201A0104	[8,13]	15	io -4 0x201A0104 0x3F000F00
		level4	0x201A0104	[8,13]	31	io -4 0x201A0104 0x3F001F00
		level5	0x201A0104	[8,13]	63	io -4 0x201A0104 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[3,3]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A4	IOmux	PWR_CTRL1	0x201A0004	[0,3]	1	io -4 0x201A0004 0x000F0001
		GPIO0_A4	0x201A0004	[0,3]	0	io -4 0x201A0004 0x000F0000
	Pull	z	0x201A0300	[8,9]	0	io -4 0x201A0300 0x03000000
		up	0x201A0300	[8,9]	1	io -4 0x201A0300 0x03000100
		down	0x201A0300	[8,9]	2	io -4 0x201A0300 0x03000200
	I/O Mode	input	0x20600008	[4,4]	0	io -4 0x20600008 0x00100000
		output	0x20600008	[4,4]	1	io -4 0x20600008 0x00100010
	Output	low	0x20600000	[4,4]	0	io -4 0x20600000 0x00100000
		high	0x20600000	[4,4]	1	io -4 0x20600000 0x00100010
	Input Ctrl	disable	0x201A0400	[4,4]	0	io -4 0x201A0400 0x00100000
		enable	0x201A0400	[4,4]	1	io -4 0x201A0400 0x00100010
	Schmitt	disable	0x201A0500	[4,4]	0	io -4 0x201A0500 0x00100000
		enable	0x201A0500	[4,4]	1	io -4 0x201A0500 0x00100010
	Drive Strength	level0	0x201A0108	[0,5]	1	io -4 0x201A0108 0x003F0001
		level1	0x201A0108	[0,5]	3	io -4 0x201A0108 0x003F0003
		level2	0x201A0108	[0,5]	7	io -4 0x201A0108 0x003F0007
		level3	0x201A0108	[0,5]	15	io -4 0x201A0108 0x003F000F
		level4	0x201A0108	[0,5]	31	io -4 0x201A0108 0x003F001F
		level5	0x201A0108	[0,5]	63	io -4 0x201A0108 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[4,4]		io -4 0x20600070
GPIO0A5	IOmux	SDMMC0_DET_N	0x201A0004	[4,7]	1	io -4 0x201A0004 0x00F00010
		PWM1_CH0_M0	0x201A0004	[4,7]	2	io -4 0x201A0004 0x00F00020
		GPIO0_A5	0x201A0004	[4,7]	0	io -4 0x201A0004 0x00F00000
	Pull	z	0x201A0300	[10,11]	0	io -4 0x201A0300 0x0C000000
		up	0x201A0300	[10,11]	1	io -4 0x201A0300 0x0C000400
		down	0x201A0300	[10,11]	2	io -4 0x201A0300 0x0C000800
	I/O Mode	input	0x20600008	[5,5]	0	io -4 0x20600008 0x00200000
		output	0x20600008	[5,5]	1	io -4 0x20600008 0x00200020
	Output	low	0x20600000	[5,5]	0	io -4 0x20600000 0x00200000
		high	0x20600000	[5,5]	1	io -4 0x20600000 0x00200020
	Input Ctrl	disable	0x201A0400	[5,5]	0	io -4 0x201A0400 0x00200000
		enable	0x201A0400	[5,5]	1	io -4 0x201A0400 0x00200020
	Schmitt	disable	0x201A0500	[5,5]	0	io -4 0x201A0500 0x00200000
		enable	0x201A0500	[5,5]	1	io -4 0x201A0500 0x00200020
	Drive Strength	level0	0x201A0108	[8,13]	1	io -4 0x201A0108 0x3F000100
		level1	0x201A0108	[8,13]	3	io -4 0x201A0108 0x3F000300
		level2	0x201A0108	[8,13]	7	io -4 0x201A0108 0x3F000700
		level3	0x201A0108	[8,13]	15	io -4 0x201A0108 0x3F000F00
		level4	0x201A0108	[8,13]	31	io -4 0x201A0108 0x3F001F00
		level5	0x201A0108	[8,13]	63	io -4 0x201A0108 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[5,5]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0A6	IOMUX	FSPI1_D2_M0	0x201A0004	[8,11]	1	io -4 0x201A0004 0x0F000100
		SPIO_CSN1_M0	0x201A0004	[8,11]	2	io -4 0x201A0004 0x0F000200
		GPIO0_A6	0x201A0004	[8,11]	0	io -4 0x201A0004 0x0F000000
	Pull	z	0x201A0300	[12,13]	0	io -4 0x201A0300 0x30000000
		up	0x201A0300	[12,13]	1	io -4 0x201A0300 0x30001000
		down	0x201A0300	[12,13]	2	io -4 0x201A0300 0x30002000
	I/O Mode	input	0x20600008	[6,6]	0	io -4 0x20600008 0x00400000
		output	0x20600008	[6,6]	1	io -4 0x20600008 0x00400040
	Output	low	0x20600000	[6,6]	0	io -4 0x20600000 0x00400000
		high	0x20600000	[6,6]	1	io -4 0x20600000 0x00400040
	Input Ctrl	disable	0x201A0400	[6,6]	0	io -4 0x201A0400 0x00400000
		enable	0x201A0400	[6,6]	1	io -4 0x201A0400 0x00400040
	Schmitt	disable	0x201A0500	[6,6]	0	io -4 0x201A0500 0x00400000
		enable	0x201A0500	[6,6]	1	io -4 0x201A0500 0x00400040
	Drive Strength	level0	0x201A010C	[0,5]	1	io -4 0x201A010C 0x003F0001
		level1	0x201A010C	[0,5]	3	io -4 0x201A010C 0x003F0003
		level2	0x201A010C	[0,5]	7	io -4 0x201A010C 0x003F0007
		level3	0x201A010C	[0,5]	15	io -4 0x201A010C 0x003F000F
		level4	0x201A010C	[0,5]	31	io -4 0x201A010C 0x003F001F
		level5	0x201A010C	[0,5]	63	io -4 0x201A010C 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[6,6]		io -4 0x20600070
GPIO0A7	IOMUX	FSPI1_CSN0_M0	0x201A0004	[12,15]	1	io -4 0x201A0004 0xF0001000
		SPIO_CSN0_M0	0x201A0004	[12,15]	2	io -4 0x201A0004 0xF0002000
		GPIO0_A7	0x201A0004	[12,15]	0	io -4 0x201A0004 0xF0000000
	Pull	z	0x201A0300	[14,15]	0	io -4 0x201A0300 0xC0000000
		up	0x201A0300	[14,15]	1	io -4 0x201A0300 0xC0004000
		down	0x201A0300	[14,15]	2	io -4 0x201A0300 0xC0008000
	I/O Mode	input	0x20600008	[7,7]	0	io -4 0x20600008 0x00800000
		output	0x20600008	[7,7]	1	io -4 0x20600008 0x00800080
	Output	low	0x20600000	[7,7]	0	io -4 0x20600000 0x00800000
		high	0x20600000	[7,7]	1	io -4 0x20600000 0x00800080
	Input Ctrl	disable	0x201A0400	[7,7]	0	io -4 0x201A0400 0x00800000
		enable	0x201A0400	[7,7]	1	io -4 0x201A0400 0x00800080
	Schmitt	disable	0x201A0500	[7,7]	0	io -4 0x201A0500 0x00800000
		enable	0x201A0500	[7,7]	1	io -4 0x201A0500 0x00800080
	Drive Strength	level0	0x201A010C	[8,13]	1	io -4 0x201A010C 0x3F000100
		level1	0x201A010C	[8,13]	3	io -4 0x201A010C 0x3F000300
		level2	0x201A010C	[8,13]	7	io -4 0x201A010C 0x3F000700
		level3	0x201A010C	[8,13]	15	io -4 0x201A010C 0x3F000F00
		level4	0x201A010C	[8,13]	31	io -4 0x201A010C 0x3F001F00
		level5	0x201A010C	[8,13]	63	io -4 0x201A010C 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[7,7]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0B0	IOMUX	FSPI1_D0_M0	0x201A0008	[0,3]	1	io -4 0x201A0008 0x000F0001
		SPI0_MOSI_M0	0x201A0008	[0,3]	2	io -4 0x201A0008 0x000F0002
		GPIO0_B0	0x201A0008	[0,3]	0	io -4 0x201A0008 0x000F0000
	Pull	z	0x201A0304	[0,1]	0	io -4 0x201A0304 0x00030000
		up	0x201A0304	[0,1]	1	io -4 0x201A0304 0x00030001
		down	0x201A0304	[0,1]	2	io -4 0x201A0304 0x00030002
	I/O Mode	input	0x20600008	[8,8]	0	io -4 0x20600008 0x01000000
		output	0x20600008	[8,8]	1	io -4 0x20600008 0x01000100
	Output	low	0x20600000	[8,8]	0	io -4 0x20600000 0x01000000
		high	0x20600000	[8,8]	1	io -4 0x20600000 0x01000100
	Input Ctrl	disable	0x201A0404	[0,0]	0	io -4 0x201A0404 0x00010000
		enable	0x201A0404	[0,0]	1	io -4 0x201A0404 0x00010001
	Schmitt	disable	0x201A0504	[0,0]	0	io -4 0x201A0504 0x00010000
		enable	0x201A0504	[0,0]	1	io -4 0x201A0504 0x00010001
	Drive Strength	level0	0x201A0110	[0,5]	1	io -4 0x201A0110 0x003F0001
		level1	0x201A0110	[0,5]	3	io -4 0x201A0110 0x003F0003
		level2	0x201A0110	[0,5]	7	io -4 0x201A0110 0x003F0007
		level3	0x201A0110	[0,5]	15	io -4 0x201A0110 0x003F000F
		level4	0x201A0110	[0,5]	31	io -4 0x201A0110 0x003F001F
		level5	0x201A0110	[0,5]	63	io -4 0x201A0110 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[8,8]		io -4 0x20600070
GPIO0B1	IOMUX	FSPI1_D1_M0	0x201A0008	[4,7]	1	io -4 0x201A0008 0x00F00010
		SPI0_MISO_M0	0x201A0008	[4,7]	2	io -4 0x201A0008 0x00F00020
		GPIO0_B1	0x201A0008	[4,7]	0	io -4 0x201A0008 0x00F00000
	Pull	z	0x201A0304	[2,3]	0	io -4 0x201A0304 0x000C0000
		up	0x201A0304	[2,3]	1	io -4 0x201A0304 0x000C0004
		down	0x201A0304	[2,3]	2	io -4 0x201A0304 0x000C0008
	I/O Mode	input	0x20600008	[9,9]	0	io -4 0x20600008 0x02000000
		output	0x20600008	[9,9]	1	io -4 0x20600008 0x02000200
	Output	low	0x20600000	[9,9]	0	io -4 0x20600000 0x02000000
		high	0x20600000	[9,9]	1	io -4 0x20600000 0x02000200
	Input Ctrl	disable	0x201A0404	[1,1]	0	io -4 0x201A0404 0x00020000
		enable	0x201A0404	[1,1]	1	io -4 0x201A0404 0x00020002
	Schmitt	disable	0x201A0504	[1,1]	0	io -4 0x201A0504 0x00020000
		enable	0x201A0504	[1,1]	1	io -4 0x201A0504 0x00020002
	Drive Strength	level0	0x201A0110	[8,13]	1	io -4 0x201A0110 0x3F000100
		level1	0x201A0110	[8,13]	3	io -4 0x201A0110 0x3F000300
		level2	0x201A0110	[8,13]	7	io -4 0x201A0110 0x3F000700
		level3	0x201A0110	[8,13]	15	io -4 0x201A0110 0x3F000F00
		level4	0x201A0110	[8,13]	31	io -4 0x201A0110 0x3F001F00
		level5	0x201A0110	[8,13]	63	io -4 0x201A0110 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[9,9]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0B2	IOMUX	FSPI1_CLK_M0	0x201A0008	[8,11]	1	io -4 0x201A0008 0x0F000100
		SPIO_CLK_M0	0x201A0008	[8,11]	2	io -4 0x201A0008 0x0F000200
		GPIO0_B2	0x201A0008	[8,11]	0	io -4 0x201A0008 0x0F000000
	Pull	z	0x201A0304	[4,5]	0	io -4 0x201A0304 0x00300000
		up	0x201A0304	[4,5]	1	io -4 0x201A0304 0x00300010
		down	0x201A0304	[4,5]	2	io -4 0x201A0304 0x00300020
	I/O Mode	input	0x20600008	[10,10]	0	io -4 0x20600008 0x04000000
		output	0x20600008	[10,10]	1	io -4 0x20600008 0x04000400
	Output	low	0x20600000	[10,10]	0	io -4 0x20600000 0x04000000
		high	0x20600000	[10,10]	1	io -4 0x20600000 0x04000400
	Input Ctrl	disable	0x201A0404	[2,2]	0	io -4 0x201A0404 0x00040000
		enable	0x201A0404	[2,2]	1	io -4 0x201A0404 0x00040004
	Schmitt	disable	0x201A0504	[2,2]	0	io -4 0x201A0504 0x00040000
		enable	0x201A0504	[2,2]	1	io -4 0x201A0504 0x00040004
	Drive Strength	level0	0x201A0114	[0,5]	1	io -4 0x201A0114 0x003F0001
		level1	0x201A0114	[0,5]	3	io -4 0x201A0114 0x003F0003
		level2	0x201A0114	[0,5]	7	io -4 0x201A0114 0x003F0007
		level3	0x201A0114	[0,5]	15	io -4 0x201A0114 0x003F000F
		level4	0x201A0114	[0,5]	31	io -4 0x201A0114 0x003F001F
		level5	0x201A0114	[0,5]	63	io -4 0x201A0114 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[10,10]		io -4 0x20600070
GPIO0B3	IOMUX	UART0_TX_M2	0x201A0008	[12,15]	1	io -4 0x201A0008 0xF0001000
		PWM1_CH2_M0	0x201A0008	[12,15]	2	io -4 0x201A0008 0xF0002000
		I2C1_SCL_M0	0x201A0008	[12,15]	3	io -4 0x201A0008 0xF0003000
		JTAG_TCK_M0	0x201A0008	[12,15]	4	io -4 0x201A0008 0xF0004000
		PREROLL_DBG	0x201A0008	[12,15]	5	io -4 0x201A0008 0xF0005000
		GPIO0_B3	0x201A0008	[12,15]	0	io -4 0x201A0008 0xF0000000
	Pull	z	0x201A0304	[6,7]	0	io -4 0x201A0304 0x00C00000
		up	0x201A0304	[6,7]	1	io -4 0x201A0304 0x00C00040
		down	0x201A0304	[6,7]	2	io -4 0x201A0304 0x00C00080
	I/O Mode	input	0x20600008	[11,11]	0	io -4 0x20600008 0x08000000
		output	0x20600008	[11,11]	1	io -4 0x20600008 0x08000800
	Output	low	0x20600000	[11,11]	0	io -4 0x20600000 0x08000000
		high	0x20600000	[11,11]	1	io -4 0x20600000 0x08000800
	Input Ctrl	disable	0x201A0404	[3,3]	0	io -4 0x201A0404 0x00080000
		enable	0x201A0404	[3,3]	1	io -4 0x201A0404 0x00080008
	Schmitt	disable	0x201A0504	[3,3]	0	io -4 0x201A0504 0x00080000
		enable	0x201A0504	[3,3]	1	io -4 0x201A0504 0x00080008
	Drive Strength	level0	0x201A0114	[8,13]	1	io -4 0x201A0114 0x3F000100
		level1	0x201A0114	[8,13]	3	io -4 0x201A0114 0x3F000300
		level2	0x201A0114	[8,13]	7	io -4 0x201A0114 0x3F000700
		level3	0x201A0114	[8,13]	15	io -4 0x201A0114 0x3F000F00
		level4	0x201A0114	[8,13]	31	io -4 0x201A0114 0x3F001F00
		level5	0x201A0114	[8,13]	63	io -4 0x201A0114 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[11,11]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0B4	IOMUX	UART0_RX_M2	0x201A000C	[0,3]	1	io -4 0x201A000C 0x000F0001
		PWM1_CH3_M0	0x201A000C	[0,3]	2	io -4 0x201A000C 0x000F0002
		I2C1_SDA_M0	0x201A000C	[0,3]	3	io -4 0x201A000C 0x000F0003
		JTAG_TMS_M0	0x201A000C	[0,3]	4	io -4 0x201A000C 0x000F0004
		GPIO0_B4	0x201A000C	[0,3]	0	io -4 0x201A000C 0x000F0000
	Pull	z	0x201A0304	[8,9]	0	io -4 0x201A0304 0x03000000
		up	0x201A0304	[8,9]	1	io -4 0x201A0304 0x03000100
		down	0x201A0304	[8,9]	2	io -4 0x201A0304 0x03000200
	I/O Mode	input	0x20600008	[12,12]	0	io -4 0x20600008 0x10000000
		output	0x20600008	[12,12]	1	io -4 0x20600008 0x10001000
	Output	low	0x20600000	[12,12]	0	io -4 0x20600000 0x10000000
		high	0x20600000	[12,12]	1	io -4 0x20600000 0x10001000
	Input Ctrl	disable	0x201A0404	[4,4]	0	io -4 0x201A0404 0x00100000
		enable	0x201A0404	[4,4]	1	io -4 0x201A0404 0x00100010
	Schmitt	disable	0x201A0504	[4,4]	0	io -4 0x201A0504 0x00100000
		enable	0x201A0504	[4,4]	1	io -4 0x201A0504 0x00100010
	Drive Strength	level0	0x201A0118	[0,5]	1	io -4 0x201A0118 0x003F0001
		level1	0x201A0118	[0,5]	3	io -4 0x201A0118 0x003F0003
		level2	0x201A0118	[0,5]	7	io -4 0x201A0118 0x003F0007
		level3	0x201A0118	[0,5]	15	io -4 0x201A0118 0x003F000F
		level4	0x201A0118	[0,5]	31	io -4 0x201A0118 0x003F001F
		level5	0x201A0118	[0,5]	63	io -4 0x201A0118 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[12,12]		io -4 0x20600070
GPIO0C0	IOMUX	I2C3_SCL_M0	0x201A8010	[0,3]	1	io -4 0x201A8010 0x000F0001
		PWM0_CH7_M0	0x201A8010	[0,3]	2	io -4 0x201A8010 0x000F0002
		GPIO0_C0	0x201A8010	[0,3]	0	io -4 0x201A8010 0x000F0000
	Pull	z	0x201A8308	[0,1]	0	io -4 0x201A8308 0x00030000
		up	0x201A8308	[0,1]	1	io -4 0x201A8308 0x00030001
		down	0x201A8308	[0,1]	2	io -4 0x201A8308 0x00030002
	I/O Mode	input	0x2060000C	[0,0]	0	io -4 0x2060000C 0x00010000
		output	0x2060000C	[0,0]	1	io -4 0x2060000C 0x00010001
	Output	low	0x20600004	[0,0]	0	io -4 0x20600004 0x00010000
		high	0x20600004	[0,0]	1	io -4 0x20600004 0x00010001
	Input Ctrl	disable	0x201A8408	[0,0]	0	io -4 0x201A8408 0x00010000
		enable	0x201A8408	[0,0]	1	io -4 0x201A8408 0x00010001
	Schmitt	disable	0x201A8508	[0,0]	0	io -4 0x201A8508 0x00010000
		enable	0x201A8508	[0,0]	1	io -4 0x201A8508 0x00010001
	Drive Strength	level0	0x201A8120	[0,5]	1	io -4 0x201A8120 0x003F0001
		level1	0x201A8120	[0,5]	3	io -4 0x201A8120 0x003F0003
		level2	0x201A8120	[0,5]	7	io -4 0x201A8120 0x003F0007
		level3	0x201A8120	[0,5]	15	io -4 0x201A8120 0x003F000F
		level4	0x201A8120	[0,5]	31	io -4 0x201A8120 0x003F001F
		level5	0x201A8120	[0,5]	63	io -4 0x201A8120 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[16,16]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0C1	IOMUX	I2C3_SDA_M0	0x201A8010	[4,7]	1	io -4 0x201A8010 0x00F00010
		PWM0_CH6_M0	0x201A8010	[4,7]	2	io -4 0x201A8010 0x00F00020
		GPIO0_C1	0x201A8010	[4,7]	0	io -4 0x201A8010 0x00F00000
	Pull	z	0x201A8308	[2,3]	0	io -4 0x201A8308 0x000C0000
		up	0x201A8308	[2,3]	1	io -4 0x201A8308 0x000C0004
		down	0x201A8308	[2,3]	2	io -4 0x201A8308 0x000C0008
	I/O Mode	input	0x2060000C	[1,1]	0	io -4 0x2060000C 0x00020000
		output	0x2060000C	[1,1]	1	io -4 0x2060000C 0x00020002
	Output	low	0x20600004	[1,1]	0	io -4 0x20600004 0x00020000
		high	0x20600004	[1,1]	1	io -4 0x20600004 0x00020002
	Input Ctrl	disable	0x201A8408	[1,1]	0	io -4 0x201A8408 0x00020000
		enable	0x201A8408	[1,1]	1	io -4 0x201A8408 0x00020002
	Schmitt	disable	0x201A8508	[1,1]	0	io -4 0x201A8508 0x00020000
		enable	0x201A8508	[1,1]	1	io -4 0x201A8508 0x00020002
	Drive Strength	level0	0x201A8120	[8,13]	1	io -4 0x201A8120 0x3F000100
		level1	0x201A8120	[8,13]	3	io -4 0x201A8120 0x3F000300
		level2	0x201A8120	[8,13]	7	io -4 0x201A8120 0x3F000700
		level3	0x201A8120	[8,13]	15	io -4 0x201A8120 0x3F000F00
		level4	0x201A8120	[8,13]	31	io -4 0x201A8120 0x3F001F00
		level5	0x201A8120	[8,13]	63	io -4 0x201A8120 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[17,17]		io -4 0x20600070
GPIO0C2	IOMUX	SPI2AHB_CSN0	0x201A8010	[8,11]	1	io -4 0x201A8010 0x0F000100
		PWR_CTRL2	0x201A8010	[4,7]	3	io -4 0x201A8010 0x00F00030
		I2C0_SCL_M0	0x201A8010	[8,11]	4	io -4 0x201A8010 0x0F000400
		GPIO0_C2	0x201A8010	[8,11]	0	io -4 0x201A8010 0x0F000000
	Pull	z	0x201A8308	[4,5]	0	io -4 0x201A8308 0x00300000
		up	0x201A8308	[4,5]	1	io -4 0x201A8308 0x00300010
		down	0x201A8308	[4,5]	2	io -4 0x201A8308 0x00300020
	I/O Mode	input	0x2060000C	[2,2]	0	io -4 0x2060000C 0x00040000
		output	0x2060000C	[2,2]	1	io -4 0x2060000C 0x00040004
	Output	low	0x20600004	[2,2]	0	io -4 0x20600004 0x00040000
		high	0x20600004	[2,2]	1	io -4 0x20600004 0x00040004
	Input Ctrl	disable	0x201A8408	[2,2]	0	io -4 0x201A8408 0x00040000
		enable	0x201A8408	[2,2]	1	io -4 0x201A8408 0x00040004
	Schmitt	disable	0x201A8508	[2,2]	0	io -4 0x201A8508 0x00040000
		enable	0x201A8508	[2,2]	1	io -4 0x201A8508 0x00040004
	Drive Strength	level0	0x201A8124	[0,5]	1	io -4 0x201A8124 0x003F0001
		level1	0x201A8124	[0,5]	3	io -4 0x201A8124 0x003F0003
		level2	0x201A8124	[0,5]	7	io -4 0x201A8124 0x003F0007
		level3	0x201A8124	[0,5]	15	io -4 0x201A8124 0x003F000F
		level4	0x201A8124	[0,5]	31	io -4 0x201A8124 0x003F001F
		level5	0x201A8124	[0,5]	63	io -4 0x201A8124 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[18,18]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0C3	IOMUX	SPI2AHB_CLK	0x201A8010	[12,15]	1	io -4 0x201A8010 0xF0001000
		I2C0_SDA_M0	0x201A8010	[12,15]	4	io -4 0x201A8010 0xF0004000
		GPIO0_C3	0x201A8010	[12,15]	0	io -4 0x201A8010 0xF0000000
	Pull	z	0x201A8308	[6,7]	0	io -4 0x201A8308 0x00C00000
		up	0x201A8308	[6,7]	1	io -4 0x201A8308 0x00C00040
		down	0x201A8308	[6,7]	2	io -4 0x201A8308 0x00C00080
	I/O Mode	input	0x2060000C	[3,3]	0	io -4 0x2060000C 0x00080000
		output	0x2060000C	[3,3]	1	io -4 0x2060000C 0x00080008
	Output	low	0x20600004	[3,3]	0	io -4 0x20600004 0x00080000
		high	0x20600004	[3,3]	1	io -4 0x20600004 0x00080008
	Input Ctrl	disable	0x201A8408	[3,3]	0	io -4 0x201A8408 0x00080000
		enable	0x201A8408	[3,3]	1	io -4 0x201A8408 0x00080008
	Schmitt	disable	0x201A8508	[3,3]	0	io -4 0x201A8508 0x00080000
		enable	0x201A8508	[3,3]	1	io -4 0x201A8508 0x00080008
	Drive Strength	level0	0x201A8124	[8,13]	1	io -4 0x201A8124 0x3F000100
		level1	0x201A8124	[8,13]	3	io -4 0x201A8124 0x3F000300
		level2	0x201A8124	[8,13]	7	io -4 0x201A8124 0x3F000700
		level3	0x201A8124	[8,13]	15	io -4 0x201A8124 0x3F000F00
		level4	0x201A8124	[8,13]	31	io -4 0x201A8124 0x3F001F00
		level5	0x201A8124	[8,13]	63	io -4 0x201A8124 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[19,19]		io -4 0x20600070
GPIO0C4	IOMUX	SPI2AHB_D3	0x201A8014	[0,3]	1	io -4 0x201A8014 0x000F0001
		PWM0_CH0_M0	0x201A8014	[0,3]	2	io -4 0x201A8014 0x000F0002
		UART1_TX_M0	0x201A8014	[0,3]	3	io -4 0x201A8014 0x000F0003
		I2C5_SCL_M0	0x201A8014	[0,3]	4	io -4 0x201A8014 0x000F0004
		GPIO0_C4	0x201A8014	[0,3]	0	io -4 0x201A8014 0x000F0000
	Pull	z	0x201A8308	[8,9]	0	io -4 0x201A8308 0x03000000
		up	0x201A8308	[8,9]	1	io -4 0x201A8308 0x03000100
		down	0x201A8308	[8,9]	2	io -4 0x201A8308 0x03000200
	I/O Mode	input	0x2060000C	[4,4]	0	io -4 0x2060000C 0x00100000
		output	0x2060000C	[4,4]	1	io -4 0x2060000C 0x00100010
	Output	low	0x20600004	[4,4]	0	io -4 0x20600004 0x00100000
		high	0x20600004	[4,4]	1	io -4 0x20600004 0x00100010
	Input Ctrl	disable	0x201A8408	[4,4]	0	io -4 0x201A8408 0x00100000
		enable	0x201A8408	[4,4]	1	io -4 0x201A8408 0x00100010
	Schmitt	disable	0x201A8508	[4,4]	0	io -4 0x201A8508 0x00100000
		enable	0x201A8508	[4,4]	1	io -4 0x201A8508 0x00100010
	Drive Strength	level0	0x201A8128	[0,5]	1	io -4 0x201A8128 0x003F0001
		level1	0x201A8128	[0,5]	3	io -4 0x201A8128 0x003F0003
		level2	0x201A8128	[0,5]	7	io -4 0x201A8128 0x003F0007
		level3	0x201A8128	[0,5]	15	io -4 0x201A8128 0x003F000F
		level4	0x201A8128	[0,5]	31	io -4 0x201A8128 0x003F001F
		level5	0x201A8128	[0,5]	63	io -4 0x201A8128 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[20,20]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0C5	IOmux	SPI2AHB_D2	0x201A8014	[4,7]	1	io -4 0x201A8014 0x00F00010
		PWM0_CH1_M0	0x201A8014	[4,7]	2	io -4 0x201A8014 0x00F00020
		UART1_RX_M0	0x201A8014	[4,7]	3	io -4 0x201A8014 0x00F00030
		I2C5_SDA_M0	0x201A8014	[4,7]	4	io -4 0x201A8014 0x00F00040
		GPIO0_C5	0x201A8014	[4,7]	0	io -4 0x201A8014 0x00F00000
	Pull	z	0x201A8308	[10,11]	0	io -4 0x201A8308 0x0C000000
		up	0x201A8308	[10,11]	1	io -4 0x201A8308 0x0C000400
		down	0x201A8308	[10,11]	2	io -4 0x201A8308 0x0C000800
	I/O Mode	input	0x2060000C	[5,5]	0	io -4 0x2060000C 0x00200000
		output	0x2060000C	[5,5]	1	io -4 0x2060000C 0x00200020
	Output	low	0x20600004	[5,5]	0	io -4 0x20600004 0x00200000
		high	0x20600004	[5,5]	1	io -4 0x20600004 0x00200020
	Input Ctrl	disable	0x201A8408	[5,5]	0	io -4 0x201A8408 0x00200000
		enable	0x201A8408	[5,5]	1	io -4 0x201A8408 0x00200020
	Schmitt	disable	0x201A8508	[5,5]	0	io -4 0x201A8508 0x00200000
		enable	0x201A8508	[5,5]	1	io -4 0x201A8508 0x00200020
	Drive Strength	level0	0x201A8128	[8,13]	1	io -4 0x201A8128 0x3F000100
		level1	0x201A8128	[8,13]	3	io -4 0x201A8128 0x3F000300
		level2	0x201A8128	[8,13]	7	io -4 0x201A8128 0x3F000700
		level3	0x201A8128	[8,13]	15	io -4 0x201A8128 0x3F000F00
		level4	0x201A8128	[8,13]	31	io -4 0x201A8128 0x3F001F00
		level5	0x201A8128	[8,13]	63	io -4 0x201A8128 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[21,21]		io -4 0x20600070
GPIO0C6	IOmux	SPI2AHB_D1	0x201A8014	[8,11]	1	io -4 0x201A8014 0x0F000100
		PWM0_CH2_M0	0x201A8014	[8,11]	2	io -4 0x201A8014 0x0F000200
		UART1_RTSN_M0	0x201A8014	[8,11]	3	io -4 0x201A8014 0x0F000300
		GPIO0_C6	0x201A8014	[8,11]	0	io -4 0x201A8014 0x0F000000
	Pull	z	0x201A8308	[12,13]	0	io -4 0x201A8308 0x30000000
		up	0x201A8308	[12,13]	1	io -4 0x201A8308 0x30001000
		down	0x201A8308	[12,13]	2	io -4 0x201A8308 0x30002000
	I/O Mode	input	0x2060000C	[6,6]	0	io -4 0x2060000C 0x00400000
		output	0x2060000C	[6,6]	1	io -4 0x2060000C 0x00400040
	Output	low	0x20600004	[6,6]	0	io -4 0x20600004 0x00400000
		high	0x20600004	[6,6]	1	io -4 0x20600004 0x00400040
	Input Ctrl	disable	0x201A8408	[6,6]	0	io -4 0x201A8408 0x00400000
		enable	0x201A8408	[6,6]	1	io -4 0x201A8408 0x00400040
	Schmitt	disable	0x201A8508	[6,6]	0	io -4 0x201A8508 0x00400000
		enable	0x201A8508	[6,6]	1	io -4 0x201A8508 0x00400040
	Drive Strength	level0	0x201A812C	[0,5]	1	io -4 0x201A812C 0x003F0001
		level1	0x201A812C	[0,5]	3	io -4 0x201A812C 0x003F0003
		level2	0x201A812C	[0,5]	7	io -4 0x201A812C 0x003F0007
		level3	0x201A812C	[0,5]	15	io -4 0x201A812C 0x003F000F
		level4	0x201A812C	[0,5]	31	io -4 0x201A812C 0x003F001F
		level5	0x201A812C	[0,5]	63	io -4 0x201A812C 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[22,22]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0C7	IOMUX	SPI2AHB_D0	0x201A8014	[12,15]	1	io -4 0x201A8014 0xF0001000
		PWM0_CH3_M0	0x201A8014	[12,15]	2	io -4 0x201A8014 0xF0002000
		UART1_CTSN_M0	0x201A8014	[12,15]	3	io -4 0x201A8014 0xF0003000
		GPIO0_C7	0x201A8014	[12,15]	0	io -4 0x201A8014 0xF0000000
	Pull	z	0x201A8308	[14,15]	0	io -4 0x201A8308 0xC0000000
		up	0x201A8308	[14,15]	1	io -4 0x201A8308 0xC0004000
		down	0x201A8308	[14,15]	2	io -4 0x201A8308 0xC0008000
	I/O Mode	input	0x2060000C	[7,7]	0	io -4 0x2060000C 0x00800000
		output	0x2060000C	[7,7]	1	io -4 0x2060000C 0x00800080
	Output	low	0x20600004	[7,7]	0	io -4 0x20600004 0x00800000
		high	0x20600004	[7,7]	1	io -4 0x20600004 0x00800080
	Input Ctrl	disable	0x201A8408	[7,7]	0	io -4 0x201A8408 0x00800000
		enable	0x201A8408	[7,7]	1	io -4 0x201A8408 0x00800080
	Schmitt	disable	0x201A8508	[7,7]	0	io -4 0x201A8508 0x00800000
		enable	0x201A8508	[7,7]	1	io -4 0x201A8508 0x00800080
	Drive Strength	level0	0x201A812C	[8,13]	1	io -4 0x201A812C 0x3F000100
		level1	0x201A812C	[8,13]	3	io -4 0x201A812C 0x3F000300
		level2	0x201A812C	[8,13]	7	io -4 0x201A812C 0x3F000700
		level3	0x201A812C	[8,13]	15	io -4 0x201A812C 0x3F000F00
		level4	0x201A812C	[8,13]	31	io -4 0x201A812C 0x3F001F00
		level5	0x201A812C	[8,13]	63	io -4 0x201A812C 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[23,23]		io -4 0x20600070
GPIO0D0	IOMUX	I2C2_SCL_M0	0x201A8018	[0,3]	1	io -4 0x201A8018 0x000F0001
		PWM0_CH4_M0	0x201A8018	[0,3]	2	io -4 0x201A8018 0x000F0002
		GPIO0_D0	0x201A8018	[0,3]	0	io -4 0x201A8018 0x000F0000
	Pull	z	0x201A830C	[0,1]	0	io -4 0x201A830C 0x00030000
		up	0x201A830C	[0,1]	1	io -4 0x201A830C 0x00030001
		down	0x201A830C	[0,1]	2	io -4 0x201A830C 0x00030002
	I/O Mode	input	0x2060000C	[8,8]	0	io -4 0x2060000C 0x01000000
		output	0x2060000C	[8,8]	1	io -4 0x2060000C 0x01000100
	Output	low	0x20600004	[8,8]	0	io -4 0x20600004 0x01000000
		high	0x20600004	[8,8]	1	io -4 0x20600004 0x01000100
	Input Ctrl	disable	0x201A840C	[0,0]	0	io -4 0x201A840C 0x00010000
		enable	0x201A840C	[0,0]	1	io -4 0x201A840C 0x00010001
	Schmitt	disable	0x201A850C	[0,0]	0	io -4 0x201A850C 0x00010000
		enable	0x201A850C	[0,0]	1	io -4 0x201A850C 0x00010001
	Drive Strength	level0	0x201A8130	[0,5]	1	io -4 0x201A8130 0x003F0001
		level1	0x201A8130	[0,5]	3	io -4 0x201A8130 0x003F0003
		level2	0x201A8130	[0,5]	7	io -4 0x201A8130 0x003F0007
		level3	0x201A8130	[0,5]	15	io -4 0x201A8130 0x003F000F
		level4	0x201A8130	[0,5]	31	io -4 0x201A8130 0x003F001F
		level5	0x201A8130	[0,5]	63	io -4 0x201A8130 0x003F003F
	ExtPort	read gpio data in input	0x20600070	[24,24]		io -4 0x20600070

Name	Config	Description	Register	Position	Value	IO Command
GPIO0D1	IOMUX	I2C2_SDA_M0	0x201A8018	[4,7]	1	io -4 0x201A8018 0x00F00010
		PWM0_CH5_M0	0x201A8018	[4,7]	2	io -4 0x201A8018 0x00F00020
		GPIO0_D1	0x201A8018	[4,7]	0	io -4 0x201A8018 0x00F00000
	Pull	z	0x201A830C	[2,3]	0	io -4 0x201A830C 0x000C0000
		up	0x201A830C	[2,3]	1	io -4 0x201A830C 0x000C0004
		down	0x201A830C	[2,3]	2	io -4 0x201A830C 0x000C0008
	I/O Mode	input	0x2060000C	[9,9]	0	io -4 0x2060000C 0x02000000
		output	0x2060000C	[9,9]	1	io -4 0x2060000C 0x02000200
	Output	low	0x20600004	[9,9]	0	io -4 0x20600004 0x02000000
		high	0x20600004	[9,9]	1	io -4 0x20600004 0x02000200
	Input Ctrl	disable	0x201A840C	[1,1]	0	io -4 0x201A840C 0x00020000
		enable	0x201A840C	[1,1]	1	io -4 0x201A840C 0x00020002
	Schmitt	disable	0x201A850C	[1,1]	0	io -4 0x201A850C 0x00020000
		enable	0x201A850C	[1,1]	1	io -4 0x201A850C 0x00020002
	Drive Strength	level0	0x201A8130	[8,13]	1	io -4 0x201A8130 0x3F000100
		level1	0x201A8130	[8,13]	3	io -4 0x201A8130 0x3F000300
		level2	0x201A8130	[8,13]	7	io -4 0x201A8130 0x3F000700
		level3	0x201A8130	[8,13]	15	io -4 0x201A8130 0x3F000F00
		level4	0x201A8130	[8,13]	31	io -4 0x201A8130 0x3F001F00
		level5	0x201A8130	[8,13]	63	io -4 0x201A8130 0x3F003F00
	ExtPort	read gpio data in input	0x20600070	[25,25]		io -4 0x20600070
GPIO1A0	IOMUX	EMMC_D0	0x201B0020	[0,3]	1	io -4 0x201B0020 0x000F0001
		FSPI1_D0_M1	0x201B0020	[0,3]	2	io -4 0x201B0020 0x000F0002
		PWM3_CH0_M0	0x201B0020	[0,3]	3	io -4 0x201B0020 0x000F0003
		GPIO1_A0	0x201B0020	[0,3]	0	io -4 0x201B0020 0x000F0000
	Pull	z	0x201B0310	[0,1]	0	io -4 0x201B0310 0x00030000
		up	0x201B0310	[0,1]	1	io -4 0x201B0310 0x00030001
		down	0x201B0310	[0,1]	2	io -4 0x201B0310 0x00030002
	I/O Mode	input	0x21300008	[0,0]	0	io -4 0x21300008 0x00010000
		output	0x21300008	[0,0]	1	io -4 0x21300008 0x00010001
	Output	low	0x21300000	[0,0]	0	io -4 0x21300000 0x00010000
		high	0x21300000	[0,0]	1	io -4 0x21300000 0x00010001
	Input Ctrl	disable	0x201B0410	[0,0]	0	io -4 0x201B0410 0x00010000
		enable	0x201B0410	[0,0]	1	io -4 0x201B0410 0x00010001
	Schmitt	disable	0x201B0510	[0,0]	0	io -4 0x201B0510 0x00010000
		enable	0x201B0510	[0,0]	1	io -4 0x201B0510 0x00010001
	Drive Strength	level0	0x201B0140	[0,5]	1	io -4 0x201B0140 0x003F0001
		level1	0x201B0140	[0,5]	3	io -4 0x201B0140 0x003F0003
		level2	0x201B0140	[0,5]	7	io -4 0x201B0140 0x003F0007
		level3	0x201B0140	[0,5]	15	io -4 0x201B0140 0x003F000F
		level4	0x201B0140	[0,5]	31	io -4 0x201B0140 0x003F001F
		level5	0x201B0140	[0,5]	63	io -4 0x201B0140 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[0,0]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A1	IOmux	EMMC_D1	0x201B0020	[4,7]	1	io -4 0x201B0020 0x00F00010
		FSPI1_D1_M1	0x201B0020	[4,7]	2	io -4 0x201B0020 0x00F00020
		PWM3_CH1_M0	0x201B0020	[4,7]	3	io -4 0x201B0020 0x00F00030
		GPIO1_A1	0x201B0020	[4,7]	0	io -4 0x201B0020 0x00F00000
	Pull	z	0x201B0310	[2,3]	0	io -4 0x201B0310 0x000C0000
		up	0x201B0310	[2,3]	1	io -4 0x201B0310 0x000C0004
		down	0x201B0310	[2,3]	2	io -4 0x201B0310 0x000C0008
	I/O Mode	input	0x21300008	[1,1]	0	io -4 0x21300008 0x00020000
		output	0x21300008	[1,1]	1	io -4 0x21300008 0x00020002
	Output	low	0x21300000	[1,1]	0	io -4 0x21300000 0x00020000
		high	0x21300000	[1,1]	1	io -4 0x21300000 0x00020002
	Input Ctrl	disable	0x201B0410	[1,1]	0	io -4 0x201B0410 0x00020000
		enable	0x201B0410	[1,1]	1	io -4 0x201B0410 0x00020002
	Schmitt	disable	0x201B0510	[1,1]	0	io -4 0x201B0510 0x00020000
		enable	0x201B0510	[1,1]	1	io -4 0x201B0510 0x00020002
	Drive Strength	level0	0x201B0140	[8,13]	1	io -4 0x201B0140 0x3F000100
		level1	0x201B0140	[8,13]	3	io -4 0x201B0140 0x3F000300
		level2	0x201B0140	[8,13]	7	io -4 0x201B0140 0x3F000700
		level3	0x201B0140	[8,13]	15	io -4 0x201B0140 0x3F000F00
		level4	0x201B0140	[8,13]	31	io -4 0x201B0140 0x3F001F00
		level5	0x201B0140	[8,13]	63	io -4 0x201B0140 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[1,1]		io -4 0x21300070
GPIO1A2	IOmux	EMMC_D2	0x201B0020	[8,11]	1	io -4 0x201B0020 0x0F000100
		FSPI1_D2_M1	0x201B0020	[8,11]	2	io -4 0x201B0020 0x0F000200
		PWM3_CH2_M0	0x201B0020	[8,11]	3	io -4 0x201B0020 0x0F000300
		GPIO1_A2	0x201B0020	[8,11]	0	io -4 0x201B0020 0x0F000000
	Pull	z	0x201B0310	[4,5]	0	io -4 0x201B0310 0x00300000
		up	0x201B0310	[4,5]	1	io -4 0x201B0310 0x00300010
		down	0x201B0310	[4,5]	2	io -4 0x201B0310 0x00300020
	I/O Mode	input	0x21300008	[2,2]	0	io -4 0x21300008 0x00040000
		output	0x21300008	[2,2]	1	io -4 0x21300008 0x00040004
	Output	low	0x21300000	[2,2]	0	io -4 0x21300000 0x00040000
		high	0x21300000	[2,2]	1	io -4 0x21300000 0x00040004
	Input Ctrl	disable	0x201B0410	[2,2]	0	io -4 0x201B0410 0x00040000
		enable	0x201B0410	[2,2]	1	io -4 0x201B0410 0x00040004
	Schmitt	disable	0x201B0510	[2,2]	0	io -4 0x201B0510 0x00040000
		enable	0x201B0510	[2,2]	1	io -4 0x201B0510 0x00040004
	Drive Strength	level0	0x201B0144	[0,5]	1	io -4 0x201B0144 0x003F0001
		level1	0x201B0144	[0,5]	3	io -4 0x201B0144 0x003F0003
		level2	0x201B0144	[0,5]	7	io -4 0x201B0144 0x003F0007
		level3	0x201B0144	[0,5]	15	io -4 0x201B0144 0x003F000F
		level4	0x201B0144	[0,5]	31	io -4 0x201B0144 0x003F001F
		level5	0x201B0144	[0,5]	63	io -4 0x201B0144 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[2,2]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A3	IOMUX	EMMC_D3	0x201B0020	[12,15]	1	io -4 0x201B0020 0xF0001000
		FSPI1_D3_M1	0x201B0020	[12,15]	2	io -4 0x201B0020 0xF0002000
		PWM3_CH3_M0	0x201B0020	[12,15]	3	io -4 0x201B0020 0xF0003000
		GPIO1_A3	0x201B0020	[12,15]	0	io -4 0x201B0020 0xF0000000
	Pull	z	0x201B0310	[6,7]	0	io -4 0x201B0310 0x00C00000
		up	0x201B0310	[6,7]	1	io -4 0x201B0310 0x00C00040
		down	0x201B0310	[6,7]	2	io -4 0x201B0310 0x00C00080
	I/O Mode	input	0x21300008	[3,3]	0	io -4 0x21300008 0x00080000
		output	0x21300008	[3,3]	1	io -4 0x21300008 0x00080008
	Output	low	0x21300000	[3,3]	0	io -4 0x21300000 0x00080000
		high	0x21300000	[3,3]	1	io -4 0x21300000 0x00080008
	Input Ctrl	disable	0x201B0410	[3,3]	0	io -4 0x201B0410 0x00080000
		enable	0x201B0410	[3,3]	1	io -4 0x201B0410 0x00080008
	Schmitt	disable	0x201B0510	[3,3]	0	io -4 0x201B0510 0x00080000
		enable	0x201B0510	[3,3]	1	io -4 0x201B0510 0x00080008
	Drive Strength	level0	0x201B0144	[8,13]	1	io -4 0x201B0144 0x3F000100
		level1	0x201B0144	[8,13]	3	io -4 0x201B0144 0x3F000300
		level2	0x201B0144	[8,13]	7	io -4 0x201B0144 0x3F000700
		level3	0x201B0144	[8,13]	15	io -4 0x201B0144 0x3F000F00
		level4	0x201B0144	[8,13]	31	io -4 0x201B0144 0x3F001F00
		level5	0x201B0144	[8,13]	63	io -4 0x201B0144 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[3,3]		io -4 0x21300070
GPIO1A4	IOMUX	EMMC_D4	0x201B0024	[0,3]	1	io -4 0x201B0024 0x000F0001
		PWM3_CH4_M0	0x201B0024	[0,3]	3	io -4 0x201B0024 0x000F0003
		GPIO1_A4	0x201B0024	[0,3]	0	io -4 0x201B0024 0x000F0000
	Pull	z	0x201B0310	[8,9]	0	io -4 0x201B0310 0x03000000
		up	0x201B0310	[8,9]	1	io -4 0x201B0310 0x03000100
		down	0x201B0310	[8,9]	2	io -4 0x201B0310 0x03000200
	I/O Mode	input	0x21300008	[4,4]	0	io -4 0x21300008 0x00100000
		output	0x21300008	[4,4]	1	io -4 0x21300008 0x00100010
	Output	low	0x21300000	[4,4]	0	io -4 0x21300000 0x00100000
		high	0x21300000	[4,4]	1	io -4 0x21300000 0x00100010
	Input Ctrl	disable	0x201B0410	[4,4]	0	io -4 0x201B0410 0x00100000
		enable	0x201B0410	[4,4]	1	io -4 0x201B0410 0x00100010
	Schmitt	disable	0x201B0510	[4,4]	0	io -4 0x201B0510 0x00100000
		enable	0x201B0510	[4,4]	1	io -4 0x201B0510 0x00100010
	Drive Strength	level0	0x201B0148	[0,5]	1	io -4 0x201B0148 0x003F0001
		level1	0x201B0148	[0,5]	3	io -4 0x201B0148 0x003F0003
		level2	0x201B0148	[0,5]	7	io -4 0x201B0148 0x003F0007
		level3	0x201B0148	[0,5]	15	io -4 0x201B0148 0x003F000F
		level4	0x201B0148	[0,5]	31	io -4 0x201B0148 0x003F001F
		level5	0x201B0148	[0,5]	63	io -4 0x201B0148 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[4,4]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A5	IOMUX	EMMC_D5	0x201B0024	[4,7]	1	io -4 0x201B0024 0x00F00010
		FSPIO_CSN1	0x201B0024	[4,7]	2	io -4 0x201B0024 0x00F00020
		PWM3_CH5_M0	0x201B0024	[4,7]	3	io -4 0x201B0024 0x00F00030
		GPIO1_A5	0x201B0024	[4,7]	0	io -4 0x201B0024 0x00F00000
	Pull	z	0x201B0310	[10,11]	0	io -4 0x201B0310 0x0C000000
		up	0x201B0310	[10,11]	1	io -4 0x201B0310 0x0C000400
		down	0x201B0310	[10,11]	2	io -4 0x201B0310 0x0C000800
	I/O Mode	input	0x21300008	[5,5]	0	io -4 0x21300008 0x00200000
		output	0x21300008	[5,5]	1	io -4 0x21300008 0x00200020
	Output	low	0x21300000	[5,5]	0	io -4 0x21300000 0x00200000
		high	0x21300000	[5,5]	1	io -4 0x21300000 0x00200020
	Input Ctrl	disable	0x201B0410	[5,5]	0	io -4 0x201B0410 0x00200000
		enable	0x201B0410	[5,5]	1	io -4 0x201B0410 0x00200020
	Schmitt	disable	0x201B0510	[5,5]	0	io -4 0x201B0510 0x00200000
		enable	0x201B0510	[5,5]	1	io -4 0x201B0510 0x00200020
	Drive Strength	level0	0x201B0148	[8,13]	1	io -4 0x201B0148 0x3F000100
		level1	0x201B0148	[8,13]	3	io -4 0x201B0148 0x3F000300
		level2	0x201B0148	[8,13]	7	io -4 0x201B0148 0x3F000700
		level3	0x201B0148	[8,13]	15	io -4 0x201B0148 0x3F000F00
		level4	0x201B0148	[8,13]	31	io -4 0x201B0148 0x3F001F00
		level5	0x201B0148	[8,13]	63	io -4 0x201B0148 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[5,5]		io -4 0x21300070
GPIO1A6	IOMUX	EMMC_D6	0x201B0024	[8,11]	1	io -4 0x201B0024 0x0F000100
		PWM3_CH6_M0	0x201B0024	[8,11]	3	io -4 0x201B0024 0x0F000300
		GPIO1_A6	0x201B0024	[8,11]	0	io -4 0x201B0024 0x0F000000
	Pull	z	0x201B0310	[12,13]	0	io -4 0x201B0310 0x30000000
		up	0x201B0310	[12,13]	1	io -4 0x201B0310 0x30001000
		down	0x201B0310	[12,13]	2	io -4 0x201B0310 0x30002000
	I/O Mode	input	0x21300008	[6,6]	0	io -4 0x21300008 0x00400000
		output	0x21300008	[6,6]	1	io -4 0x21300008 0x00400040
	Output	low	0x21300000	[6,6]	0	io -4 0x21300000 0x00400000
		high	0x21300000	[6,6]	1	io -4 0x21300000 0x00400040
	Input Ctrl	disable	0x201B0410	[6,6]	0	io -4 0x201B0410 0x00400000
		enable	0x201B0410	[6,6]	1	io -4 0x201B0410 0x00400040
	Schmitt	disable	0x201B0510	[6,6]	0	io -4 0x201B0510 0x00400000
		enable	0x201B0510	[6,6]	1	io -4 0x201B0510 0x00400040
	Drive Strength	level0	0x201B014C	[0,5]	1	io -4 0x201B014C 0x003F0001
		level1	0x201B014C	[0,5]	3	io -4 0x201B014C 0x003F0003
		level2	0x201B014C	[0,5]	7	io -4 0x201B014C 0x003F0007
		level3	0x201B014C	[0,5]	15	io -4 0x201B014C 0x003F000F
		level4	0x201B014C	[0,5]	31	io -4 0x201B014C 0x003F001F
		level5	0x201B014C	[0,5]	63	io -4 0x201B014C 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[6,6]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1A7	IOMUX	EMMC_D7	0x201B0024	[12,15]	1	io -4 0x201B0024 0xF0001000
		PWM3_CH7_M0	0x201B0024	[12,15]	3	io -4 0x201B0024 0xF0003000
		GPIO1_A7	0x201B0024	[12,15]	0	io -4 0x201B0024 0xF0000000
	Pull	z	0x201B0310	[14,15]	0	io -4 0x201B0310 0xC0000000
		up	0x201B0310	[14,15]	1	io -4 0x201B0310 0xC0004000
		down	0x201B0310	[14,15]	2	io -4 0x201B0310 0xC0008000
	I/O Mode	input	0x21300008	[7,7]	0	io -4 0x21300008 0x00800000
		output	0x21300008	[7,7]	1	io -4 0x21300008 0x00800080
	Output	low	0x21300000	[7,7]	0	io -4 0x21300000 0x00800000
		high	0x21300000	[7,7]	1	io -4 0x21300000 0x00800080
	Input Ctrl	disable	0x201B0410	[7,7]	0	io -4 0x201B0410 0x00800000
		enable	0x201B0410	[7,7]	1	io -4 0x201B0410 0x00800080
	Schmitt	disable	0x201B0510	[7,7]	0	io -4 0x201B0510 0x00800000
		enable	0x201B0510	[7,7]	1	io -4 0x201B0510 0x00800080
	Drive Strength	level0	0x201B014C	[8,13]	1	io -4 0x201B014C 0x3F000100
		level1	0x201B014C	[8,13]	3	io -4 0x201B014C 0x3F000300
		level2	0x201B014C	[8,13]	7	io -4 0x201B014C 0x3F000700
		level3	0x201B014C	[8,13]	15	io -4 0x201B014C 0x3F000F00
		level4	0x201B014C	[8,13]	31	io -4 0x201B014C 0x3F001F00
		level5	0x201B014C	[8,13]	63	io -4 0x201B014C 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[7,7]		io -4 0x21300070
GPIO1B0	IOMUX	FSPI0_CSNO	0x201B0028	[0,3]	1	io -4 0x201B0028 0x000F0001
		SAI1_MCLK_M0	0x201B0028	[0,3]	2	io -4 0x201B0028 0x000F0002
		GPIO1_B0	0x201B0028	[0,3]	0	io -4 0x201B0028 0x000F0000
	Pull	z	0x201B0314	[0,1]	0	io -4 0x201B0314 0x00030000
		up	0x201B0314	[0,1]	1	io -4 0x201B0314 0x00030001
		down	0x201B0314	[0,1]	2	io -4 0x201B0314 0x00030002
	I/O Mode	input	0x21300008	[8,8]	0	io -4 0x21300008 0x01000000
		output	0x21300008	[8,8]	1	io -4 0x21300008 0x01000100
	Output	low	0x21300000	[8,8]	0	io -4 0x21300000 0x01000000
		high	0x21300000	[8,8]	1	io -4 0x21300000 0x01000100
	Input Ctrl	disable	0x201B0414	[0,0]	0	io -4 0x201B0414 0x00010000
		enable	0x201B0414	[0,0]	1	io -4 0x201B0414 0x00010001
	Schmitt	disable	0x201B0514	[0,0]	0	io -4 0x201B0514 0x00010000
		enable	0x201B0514	[0,0]	1	io -4 0x201B0514 0x00010001
	Drive Strength	level0	0x201B0150	[0,5]	1	io -4 0x201B0150 0x003F0001
		level1	0x201B0150	[0,5]	3	io -4 0x201B0150 0x003F0003
		level2	0x201B0150	[0,5]	7	io -4 0x201B0150 0x003F0007
		level3	0x201B0150	[0,5]	15	io -4 0x201B0150 0x003F000F
		level4	0x201B0150	[0,5]	31	io -4 0x201B0150 0x003F001F
		level5	0x201B0150	[0,5]	63	io -4 0x201B0150 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[8,8]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B1	IOmux	EMMC_CMD	0x201B0028	[4,7]	1	io -4 0x201B0028 0x00F00010
		FSPI1_CSN0_M1	0x201B0028	[4,7]	2	io -4 0x201B0028 0x00F00020
		GPIO1_B1	0x201B0028	[4,7]	0	io -4 0x201B0028 0x00F00000
	Pull	z	0x201B0314	[2,3]	0	io -4 0x201B0314 0x000C0000
		up	0x201B0314	[2,3]	1	io -4 0x201B0314 0x000C0004
		down	0x201B0314	[2,3]	2	io -4 0x201B0314 0x000C0008
	I/O Mode	input	0x21300008	[9,9]	0	io -4 0x21300008 0x02000000
		output	0x21300008	[9,9]	1	io -4 0x21300008 0x02000200
	Output	low	0x21300000	[9,9]	0	io -4 0x21300000 0x02000000
		high	0x21300000	[9,9]	1	io -4 0x21300000 0x02000200
	Input Ctrl	disable	0x201B0414	[1,1]	0	io -4 0x201B0414 0x00020000
		enable	0x201B0414	[1,1]	1	io -4 0x201B0414 0x00020002
	Schmitt	disable	0x201B0514	[1,1]	0	io -4 0x201B0514 0x00020000
		enable	0x201B0514	[1,1]	1	io -4 0x201B0514 0x00020002
	Drive Strength	level0	0x201B0150	[8,13]	1	io -4 0x201B0150 0x3F000100
		level1	0x201B0150	[8,13]	3	io -4 0x201B0150 0x3F000300
		level2	0x201B0150	[8,13]	7	io -4 0x201B0150 0x3F000700
		level3	0x201B0150	[8,13]	15	io -4 0x201B0150 0x3F000F00
		level4	0x201B0150	[8,13]	31	io -4 0x201B0150 0x3F001F00
		level5	0x201B0150	[8,13]	63	io -4 0x201B0150 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[9,9]		io -4 0x21300070
GPIO1B2	IOmux	FSPI0_D2	0x201B0028	[8,11]	1	io -4 0x201B0028 0x0F000100
		SAI1_SDO_M0	0x201B0028	[8,11]	2	io -4 0x201B0028 0x0F000200
		GPIO1_B2	0x201B0028	[8,11]	0	io -4 0x201B0028 0x0F000000
	Pull	z	0x201B0314	[4,5]	0	io -4 0x201B0314 0x00300000
		up	0x201B0314	[4,5]	1	io -4 0x201B0314 0x00300010
		down	0x201B0314	[4,5]	2	io -4 0x201B0314 0x00300020
	I/O Mode	input	0x21300008	[10,10]	0	io -4 0x21300008 0x04000000
		output	0x21300008	[10,10]	1	io -4 0x21300008 0x04000400
	Output	low	0x21300000	[10,10]	0	io -4 0x21300000 0x04000000
		high	0x21300000	[10,10]	1	io -4 0x21300000 0x04000400
	Input Ctrl	disable	0x201B0414	[2,2]	0	io -4 0x201B0414 0x00040000
		enable	0x201B0414	[2,2]	1	io -4 0x201B0414 0x00040004
	Schmitt	disable	0x201B0514	[2,2]	0	io -4 0x201B0514 0x00040000
		enable	0x201B0514	[2,2]	1	io -4 0x201B0514 0x00040004
	Drive Strength	level0	0x201B0154	[0,5]	1	io -4 0x201B0154 0x003F0001
		level1	0x201B0154	[0,5]	3	io -4 0x201B0154 0x003F0003
		level2	0x201B0154	[0,5]	7	io -4 0x201B0154 0x003F0007
		level3	0x201B0154	[0,5]	15	io -4 0x201B0154 0x003F000F
		level4	0x201B0154	[0,5]	31	io -4 0x201B0154 0x003F001F
		level5	0x201B0154	[0,5]	63	io -4 0x201B0154 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[10,10]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B3	IOmux	EMMC_CLK	0x201B0028	[12,15]	1	io -4 0x201B0028 0xF0001000
		FSPI1_CLK_M1	0x201B0028	[12,15]	2	io -4 0x201B0028 0xF0002000
		GPIO1_B3	0x201B0028	[12,15]	0	io -4 0x201B0028 0xF0000000
	Pull	z	0x201B0314	[6,7]	0	io -4 0x201B0314 0x00C00000
		up	0x201B0314	[6,7]	1	io -4 0x201B0314 0x00C00040
		down	0x201B0314	[6,7]	2	io -4 0x201B0314 0x00C00080
	I/O Mode	input	0x21300008	[11,11]	0	io -4 0x21300008 0x08000000
		output	0x21300008	[11,11]	1	io -4 0x21300008 0x08000800
	Output	low	0x21300000	[11,11]	0	io -4 0x21300000 0x08000000
		high	0x21300000	[11,11]	1	io -4 0x21300000 0x08000800
	Input Ctrl	disable	0x201B0414	[3,3]	0	io -4 0x201B0414 0x00080000
		enable	0x201B0414	[3,3]	1	io -4 0x201B0414 0x00080008
	Schmitt	disable	0x201B0514	[3,3]	0	io -4 0x201B0514 0x00080000
		enable	0x201B0514	[3,3]	1	io -4 0x201B0514 0x00080008
	Drive Strength	level0	0x201B0154	[8,13]	1	io -4 0x201B0154 0x3F000100
		level1	0x201B0154	[8,13]	3	io -4 0x201B0154 0x3F000300
		level2	0x201B0154	[8,13]	7	io -4 0x201B0154 0x3F000700
		level3	0x201B0154	[8,13]	15	io -4 0x201B0154 0x3F000F00
		level4	0x201B0154	[8,13]	31	io -4 0x201B0154 0x3F001F00
		level5	0x201B0154	[8,13]	63	io -4 0x201B0154 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[11,11]		io -4 0x21300070
GPIO1B4	IOmux	FSPI0_D0	0x201B002C	[0,3]	1	io -4 0x201B002C 0x000F0001
		SAI1_LRCK_M0	0x201B002C	[0,3]	2	io -4 0x201B002C 0x000F0002
		GPIO1_B4	0x201B002C	[0,3]	0	io -4 0x201B002C 0x000F0000
	Pull	z	0x201B0314	[8,9]	0	io -4 0x201B0314 0x03000000
		up	0x201B0314	[8,9]	1	io -4 0x201B0314 0x03000100
		down	0x201B0314	[8,9]	2	io -4 0x201B0314 0x03000200
	I/O Mode	input	0x21300008	[12,12]	0	io -4 0x21300008 0x10000000
		output	0x21300008	[12,12]	1	io -4 0x21300008 0x10001000
	Output	low	0x21300000	[12,12]	0	io -4 0x21300000 0x10000000
		high	0x21300000	[12,12]	1	io -4 0x21300000 0x10001000
	Input Ctrl	disable	0x201B0414	[4,4]	0	io -4 0x201B0414 0x00100000
		enable	0x201B0414	[4,4]	1	io -4 0x201B0414 0x00100010
	Schmitt	disable	0x201B0514	[4,4]	0	io -4 0x201B0514 0x00100000
		enable	0x201B0514	[4,4]	1	io -4 0x201B0514 0x00100010
	Drive Strength	level0	0x201B0158	[0,5]	1	io -4 0x201B0158 0x003F0001
		level1	0x201B0158	[0,5]	3	io -4 0x201B0158 0x003F0003
		level2	0x201B0158	[0,5]	7	io -4 0x201B0158 0x003F0007
		level3	0x201B0158	[0,5]	15	io -4 0x201B0158 0x003F000F
		level4	0x201B0158	[0,5]	31	io -4 0x201B0158 0x003F001F
		level5	0x201B0158	[0,5]	63	io -4 0x201B0158 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[12,12]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B5	IOMUX	FSPI0_D1	0x201B002C	[4,7]	1	io -4 0x201B002C 0x00F00010
		SAI1_SCLK_M0	0x201B002C	[4,7]	2	io -4 0x201B002C 0x00F00020
		GPIO1_B5	0x201B002C	[4,7]	0	io -4 0x201B002C 0x00F00000
	Pull	z	0x201B0314	[10,11]	0	io -4 0x201B0314 0x0C000000
		up	0x201B0314	[10,11]	1	io -4 0x201B0314 0x0C000400
		down	0x201B0314	[10,11]	2	io -4 0x201B0314 0x0C000800
	I/O Mode	input	0x21300008	[13,13]	0	io -4 0x21300008 0x20000000
		output	0x21300008	[13,13]	1	io -4 0x21300008 0x20002000
	Output	low	0x21300000	[13,13]	0	io -4 0x21300000 0x20000000
		high	0x21300000	[13,13]	1	io -4 0x21300000 0x20002000
	Input Ctrl	disable	0x201B0414	[5,5]	0	io -4 0x201B0414 0x00200000
		enable	0x201B0414	[5,5]	1	io -4 0x201B0414 0x00200020
	Schmitt	disable	0x201B0514	[5,5]	0	io -4 0x201B0514 0x00200000
		enable	0x201B0514	[5,5]	1	io -4 0x201B0514 0x00200020
	Drive Strength	level0	0x201B0158	[8,13]	1	io -4 0x201B0158 0x3F000100
		level1	0x201B0158	[8,13]	3	io -4 0x201B0158 0x3F000300
		level2	0x201B0158	[8,13]	7	io -4 0x201B0158 0x3F000700
		level3	0x201B0158	[8,13]	15	io -4 0x201B0158 0x3F000F00
		level4	0x201B0158	[8,13]	31	io -4 0x201B0158 0x3F001F00
		level5	0x201B0158	[8,13]	63	io -4 0x201B0158 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[13,13]		io -4 0x21300070
GPIO1B6	IOMUX	FSPI0_D3	0x201B002C	[8,11]	1	io -4 0x201B002C 0x0F000100
		SAI1_SDI_M0	0x201B002C	[8,11]	2	io -4 0x201B002C 0x0F000200
		GPIO1_B6	0x201B002C	[8,11]	0	io -4 0x201B002C 0x0F000000
	Pull	z	0x201B0314	[12,13]	0	io -4 0x201B0314 0x30000000
		up	0x201B0314	[12,13]	1	io -4 0x201B0314 0x30001000
		down	0x201B0314	[12,13]	2	io -4 0x201B0314 0x30002000
	I/O Mode	input	0x21300008	[14,14]	0	io -4 0x21300008 0x40000000
		output	0x21300008	[14,14]	1	io -4 0x21300008 0x40004000
	Output	low	0x21300000	[14,14]	0	io -4 0x21300000 0x40000000
		high	0x21300000	[14,14]	1	io -4 0x21300000 0x40004000
	Input Ctrl	disable	0x201B0414	[6,6]	0	io -4 0x201B0414 0x00400000
		enable	0x201B0414	[6,6]	1	io -4 0x201B0414 0x00400040
	Schmitt	disable	0x201B0514	[6,6]	0	io -4 0x201B0514 0x00400000
		enable	0x201B0514	[6,6]	1	io -4 0x201B0514 0x00400040
	Drive Strength	level0	0x201B015C	[0,5]	1	io -4 0x201B015C 0x003F0001
		level1	0x201B015C	[0,5]	3	io -4 0x201B015C 0x003F0003
		level2	0x201B015C	[0,5]	7	io -4 0x201B015C 0x003F0007
		level3	0x201B015C	[0,5]	15	io -4 0x201B015C 0x003F000F
		level4	0x201B015C	[0,5]	31	io -4 0x201B015C 0x003F001F
		level5	0x201B015C	[0,5]	63	io -4 0x201B015C 0x003F003F
	ExtPort	read gpio data in input	0x21300070	[14,14]		io -4 0x21300070

Name	Config	Description	Register	Position	Value	IO Command
GPIO1B7	IOMUX	FSPI0_CLK	0x201B002C	[12,15]	1	io -4 0x201B002C 0xF0001000
		GPIO1_B7	0x201B002C	[12,15]	0	io -4 0x201B002C 0xF0000000
	Pull	z	0x201B0314	[14,15]	0	io -4 0x201B0314 0xC0000000
		up	0x201B0314	[14,15]	1	io -4 0x201B0314 0xC0004000
		down	0x201B0314	[14,15]	2	io -4 0x201B0314 0xC0008000
	I/O Mode	input	0x21300008	[15,15]	0	io -4 0x21300008 0x80000000
		output	0x21300008	[15,15]	1	io -4 0x21300008 0x80008000
	Output	low	0x21300000	[15,15]	0	io -4 0x21300000 0x80000000
		high	0x21300000	[15,15]	1	io -4 0x21300000 0x80008000
	Input Ctrl	disable	0x201B0414	[7,7]	0	io -4 0x201B0414 0x00800000
		enable	0x201B0414	[7,7]	1	io -4 0x201B0414 0x00800080
	Schmitt	disable	0x201B0514	[7,7]	0	io -4 0x201B0514 0x00800000
		enable	0x201B0514	[7,7]	1	io -4 0x201B0514 0x00800080
	Drive Strength	level0	0x201B015C	[8,13]	1	io -4 0x201B015C 0x3F000100
		level1	0x201B015C	[8,13]	3	io -4 0x201B015C 0x3F000300
		level2	0x201B015C	[8,13]	7	io -4 0x201B015C 0x3F000700
		level3	0x201B015C	[8,13]	15	io -4 0x201B015C 0x3F000F00
		level4	0x201B015C	[8,13]	31	io -4 0x201B015C 0x3F001F00
		level5	0x201B015C	[8,13]	63	io -4 0x201B015C 0x3F003F00
	ExtPort	read gpio data in input	0x21300070	[15,15]		io -4 0x21300070
GPIO2A0	IOMUX	SDMMC0_D0	0x201B8040	[0,3]	1	io -4 0x201B8040 0x000F0001
		UART0_RX_M0	0x201B8040	[0,3]	2	io -4 0x201B8040 0x000F0002
		I2C0_SDA_M1	0x201B8040	[0,3]	3	io -4 0x201B8040 0x000F0003
		GPIO2_A0	0x201B8040	[0,3]	0	io -4 0x201B8040 0x000F0000
	Pull	z	0x201B8320	[0,1]	0	io -4 0x201B8320 0x00030000
		up	0x201B8320	[0,1]	1	io -4 0x201B8320 0x00030001
		down	0x201B8320	[0,1]	2	io -4 0x201B8320 0x00030002
	I/O Mode	input	0x21700008	[0,0]	0	io -4 0x21700008 0x00010000
		output	0x21700008	[0,0]	1	io -4 0x21700008 0x00010001
	Output	low	0x21700000	[0,0]	0	io -4 0x21700000 0x00010000
		high	0x21700000	[0,0]	1	io -4 0x21700000 0x00010001
	Input Ctrl	disable	0x201B8420	[0,0]	0	io -4 0x201B8420 0x00010000
		enable	0x201B8420	[0,0]	1	io -4 0x201B8420 0x00010001
	Schmitt	disable	0x201B8520	[0,0]	0	io -4 0x201B8520 0x00010000
		enable	0x201B8520	[0,0]	1	io -4 0x201B8520 0x00010001
	Drive Strength	level0	0x201B8180	[0,5]	1	io -4 0x201B8180 0x003F0001
		level1	0x201B8180	[0,5]	3	io -4 0x201B8180 0x003F0003
		level2	0x201B8180	[0,5]	7	io -4 0x201B8180 0x003F0007
		level3	0x201B8180	[0,5]	15	io -4 0x201B8180 0x003F000F
		level4	0x201B8180	[0,5]	31	io -4 0x201B8180 0x003F001F
		level5	0x201B8180	[0,5]	63	io -4 0x201B8180 0x003F003F
	ExtPort	read gpio data in input	0x21700070	[0,0]		io -4 0x21700070

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A1	IOMUX	SDMMC0_D1	0x201B8040	[4,7]	1	io -4 0x201B8040 0x00F00010
		UART0_TX_M0	0x201B8040	[4,7]	2	io -4 0x201B8040 0x00F00020
		I2C0_SCL_M1	0x201B8040	[4,7]	3	io -4 0x201B8040 0x00F00030
		GPIO2_A1	0x201B8040	[4,7]	0	io -4 0x201B8040 0x00F00000
	Pull	z	0x201B8320	[2,3]	0	io -4 0x201B8320 0x000C0000
		up	0x201B8320	[2,3]	1	io -4 0x201B8320 0x000C0004
		down	0x201B8320	[2,3]	2	io -4 0x201B8320 0x000C0008
	I/O Mode	input	0x21700008	[1,1]	0	io -4 0x21700008 0x00020000
		output	0x21700008	[1,1]	1	io -4 0x21700008 0x00020002
	Output	low	0x21700000	[1,1]	0	io -4 0x21700000 0x00020000
		high	0x21700000	[1,1]	1	io -4 0x21700000 0x00020002
	Input Ctrl	disable	0x201B8420	[1,1]	0	io -4 0x201B8420 0x00020000
		enable	0x201B8420	[1,1]	1	io -4 0x201B8420 0x00020002
	Schmitt	disable	0x201B8520	[1,1]	0	io -4 0x201B8520 0x00020000
		enable	0x201B8520	[1,1]	1	io -4 0x201B8520 0x00020002
	Drive Strength	level0	0x201B8180	[8,13]	1	io -4 0x201B8180 0x3F000100
		level1	0x201B8180	[8,13]	3	io -4 0x201B8180 0x3F000300
		level2	0x201B8180	[8,13]	7	io -4 0x201B8180 0x3F000700
		level3	0x201B8180	[8,13]	15	io -4 0x201B8180 0x3F000F00
		level4	0x201B8180	[8,13]	31	io -4 0x201B8180 0x3F001F00
		level5	0x201B8180	[8,13]	63	io -4 0x201B8180 0x3F003F00
	ExtPort	read gpio data in input	0x21700070	[1,1]		io -4 0x21700070
GPIO2A2	IOMUX	SDMMC0_D2	0x201B8040	[8,11]	1	io -4 0x201B8040 0x0F000100
		UART3_RX_M0	0x201B8040	[8,11]	2	io -4 0x201B8040 0x0F000200
		UART4_RTSN_M3	0x201B8040	[8,11]	3	io -4 0x201B8040 0x0F000300
		JTAG_TCK_M1	0x201B8040	[8,11]	4	io -4 0x201B8040 0x0F000400
		GPIO2_A2	0x201B8040	[8,11]	0	io -4 0x201B8040 0x0F000000
	Pull	z	0x201B8320	[4,5]	0	io -4 0x201B8320 0x00300000
		up	0x201B8320	[4,5]	1	io -4 0x201B8320 0x00300010
		down	0x201B8320	[4,5]	2	io -4 0x201B8320 0x00300020
	I/O Mode	input	0x21700008	[2,2]	0	io -4 0x21700008 0x00040000
		output	0x21700008	[2,2]	1	io -4 0x21700008 0x00040004
	Output	low	0x21700000	[2,2]	0	io -4 0x21700000 0x00040000
		high	0x21700000	[2,2]	1	io -4 0x21700000 0x00040004
	Input Ctrl	disable	0x201B8420	[2,2]	0	io -4 0x201B8420 0x00040000
		enable	0x201B8420	[2,2]	1	io -4 0x201B8420 0x00040004
	Schmitt	disable	0x201B8520	[2,2]	0	io -4 0x201B8520 0x00040000
		enable	0x201B8520	[2,2]	1	io -4 0x201B8520 0x00040004
	Drive Strength	level0	0x201B8184	[0,5]	1	io -4 0x201B8184 0x003F0001
		level1	0x201B8184	[0,5]	3	io -4 0x201B8184 0x003F0003
		level2	0x201B8184	[0,5]	7	io -4 0x201B8184 0x003F0007
		level3	0x201B8184	[0,5]	15	io -4 0x201B8184 0x003F000F
		level4	0x201B8184	[0,5]	31	io -4 0x201B8184 0x003F001F
		level5	0x201B8184	[0,5]	63	io -4 0x201B8184 0x003F003F
	ExtPort	read gpio data in input	0x21700070	[2,2]		io -4 0x21700070

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A3	IOmux	SDMMC0_D3	0x201B8040	[12,15]	1	io -4 0x201B8040 0xF0001000
		UART3_TX_M0	0x201B8040	[12,15]	2	io -4 0x201B8040 0xF0002000
		UART4_CTSN_M3	0x201B8040	[12,15]	3	io -4 0x201B8040 0xF0003000
		JTAG_TMS_M1	0x201B8040	[12,15]	4	io -4 0x201B8040 0xF0004000
		GPIO2_A3	0x201B8040	[12,15]	0	io -4 0x201B8040 0xF0000000
	Pull	z	0x201B8320	[6,7]	0	io -4 0x201B8320 0x00C00000
		up	0x201B8320	[6,7]	1	io -4 0x201B8320 0x00C00040
		down	0x201B8320	[6,7]	2	io -4 0x201B8320 0x00C00080
	I/O Mode	input	0x21700008	[3,3]	0	io -4 0x21700008 0x00080000
		output	0x21700008	[3,3]	1	io -4 0x21700008 0x00080008
	Output	low	0x21700000	[3,3]	0	io -4 0x21700000 0x00080000
		high	0x21700000	[3,3]	1	io -4 0x21700000 0x00080008
	Input Ctrl	disable	0x201B8420	[3,3]	0	io -4 0x201B8420 0x00080000
		enable	0x201B8420	[3,3]	1	io -4 0x201B8420 0x00080008
	Schmitt	disable	0x201B8520	[3,3]	0	io -4 0x201B8520 0x00080000
		enable	0x201B8520	[3,3]	1	io -4 0x201B8520 0x00080008
	Drive Strength	level0	0x201B8184	[8,13]	1	io -4 0x201B8184 0x3F000100
		level1	0x201B8184	[8,13]	3	io -4 0x201B8184 0x3F000300
		level2	0x201B8184	[8,13]	7	io -4 0x201B8184 0x3F000700
		level3	0x201B8184	[8,13]	15	io -4 0x201B8184 0x3F000F00
		level4	0x201B8184	[8,13]	31	io -4 0x201B8184 0x3F001F00
		level5	0x201B8184	[8,13]	63	io -4 0x201B8184 0x3F003F00
	ExtPort	read gpio data in input	0x21700070	[3,3]		io -4 0x21700070
GPIO2A4	IOmux	SDMMC0_CLK	0x201B8044	[0,3]	1	io -4 0x201B8044 0x000F0001
		UART3_RTSN_M0	0x201B8044	[0,3]	2	io -4 0x201B8044 0x000F0002
		UART4_RX_M3	0x201B8044	[0,3]	3	io -4 0x201B8044 0x000F0003
		GPIO2_A4	0x201B8044	[0,3]	0	io -4 0x201B8044 0x000F0000
	Pull	z	0x201B8320	[8,9]	0	io -4 0x201B8320 0x03000000
		up	0x201B8320	[8,9]	1	io -4 0x201B8320 0x03000100
		down	0x201B8320	[8,9]	2	io -4 0x201B8320 0x03000200
	I/O Mode	input	0x21700008	[4,4]	0	io -4 0x21700008 0x00100000
		output	0x21700008	[4,4]	1	io -4 0x21700008 0x00100010
	Output	low	0x21700000	[4,4]	0	io -4 0x21700000 0x00100000
		high	0x21700000	[4,4]	1	io -4 0x21700000 0x00100010
	Input Ctrl	disable	0x201B8420	[4,4]	0	io -4 0x201B8420 0x00100000
		enable	0x201B8420	[4,4]	1	io -4 0x201B8420 0x00100010
	Schmitt	disable	0x201B8520	[4,4]	0	io -4 0x201B8520 0x00100000
		enable	0x201B8520	[4,4]	1	io -4 0x201B8520 0x00100010
	Drive Strength	level0	0x201B8188	[0,5]	1	io -4 0x201B8188 0x003F0001
		level1	0x201B8188	[0,5]	3	io -4 0x201B8188 0x003F0003
		level2	0x201B8188	[0,5]	7	io -4 0x201B8188 0x003F0007
		level3	0x201B8188	[0,5]	15	io -4 0x201B8188 0x003F000F
		level4	0x201B8188	[0,5]	31	io -4 0x201B8188 0x003F001F
		level5	0x201B8188	[0,5]	63	io -4 0x201B8188 0x003F003F
	ExtPort	read gpio data in input	0x21700070	[4,4]		io -4 0x21700070

Name	Config	Description	Register	Position	Value	IO Command
GPIO2A5	IOmux	SDMMC0_CMD	0x201B8044	[4,7]	1	io -4 0x201B8044 0x00F00010
		UART3_CTSN_M0	0x201B8044	[4,7]	2	io -4 0x201B8044 0x00F00020
		UART4_TX_M3	0x201B8044	[4,7]	3	io -4 0x201B8044 0x00F00030
		GPIO2_A5	0x201B8044	[4,7]	0	io -4 0x201B8044 0x00F00000
	Pull	z	0x201B8320	[10,11]	0	io -4 0x201B8320 0x0C000000
		up	0x201B8320	[10,11]	1	io -4 0x201B8320 0x0C000400
		down	0x201B8320	[10,11]	2	io -4 0x201B8320 0x0C000800
	I/O Mode	input	0x21700008	[5,5]	0	io -4 0x21700008 0x00200000
		output	0x21700008	[5,5]	1	io -4 0x21700008 0x00200020
	Output	low	0x21700000	[5,5]	0	io -4 0x21700000 0x00200000
		high	0x21700000	[5,5]	1	io -4 0x21700000 0x00200020
	Input Ctrl	disable	0x201B8420	[5,5]	0	io -4 0x201B8420 0x00200000
		enable	0x201B8420	[5,5]	1	io -4 0x201B8420 0x00200020
	Schmitt	disable	0x201B8520	[5,5]	0	io -4 0x201B8520 0x00200000
		enable	0x201B8520	[5,5]	1	io -4 0x201B8520 0x00200020
	Drive Strength	level0	0x201B8188	[8,13]	1	io -4 0x201B8188 0x3F000100
		level1	0x201B8188	[8,13]	3	io -4 0x201B8188 0x3F000300
		level2	0x201B8188	[8,13]	7	io -4 0x201B8188 0x3F000700
		level3	0x201B8188	[8,13]	15	io -4 0x201B8188 0x3F000F00
		level4	0x201B8188	[8,13]	31	io -4 0x201B8188 0x3F001F00
		level5	0x201B8188	[8,13]	63	io -4 0x201B8188 0x3F003F00
	ExtPort	read gpio data in input	0x21700070	[5,5]		io -4 0x21700070
GPIO3A0	IOmux	SDMMC1_CLK	0x201C0060	[0,3]	1	io -4 0x201C0060 0x000F0001
		GPIO3_A0	0x201C0060	[0,3]	0	io -4 0x201C0060 0x000F0000
	Pull	z	0x201C0330	[0,1]	0	io -4 0x201C0330 0x00030000
		up	0x201C0330	[0,1]	1	io -4 0x201C0330 0x00030001
		down	0x201C0330	[0,1]	2	io -4 0x201C0330 0x00030002
	I/O Mode	input	0x21E00008	[0,0]	0	io -4 0x21E00008 0x00010000
		output	0x21E00008	[0,0]	1	io -4 0x21E00008 0x00010001
	Output	low	0x21E00000	[0,0]	0	io -4 0x21E00000 0x00010000
		high	0x21E00000	[0,0]	1	io -4 0x21E00000 0x00010001
	Input Ctrl	disable	0x201C0430	[0,0]	0	io -4 0x201C0430 0x00010000
		enable	0x201C0430	[0,0]	1	io -4 0x201C0430 0x00010001
	Schmitt	disable	0x201C0530	[0,0]	0	io -4 0x201C0530 0x00010000
		enable	0x201C0530	[0,0]	1	io -4 0x201C0530 0x00010001
	Drive Strength	level0	0x201C01C0	[0,5]	1	io -4 0x201C01C0 0x003F0001
		level1	0x201C01C0	[0,5]	3	io -4 0x201C01C0 0x003F0003
		level2	0x201C01C0	[0,5]	7	io -4 0x201C01C0 0x003F0007
		level3	0x201C01C0	[0,5]	15	io -4 0x201C01C0 0x003F000F
		level4	0x201C01C0	[0,5]	31	io -4 0x201C01C0 0x003F001F
		level5	0x201C01C0	[0,5]	63	io -4 0x201C01C0 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[0,0]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3A1	IOmux	SDMMC1_CMD	0x201C0060	[4,7]	1	io -4 0x201C0060 0x00F00010
		GPIO3_A1	0x201C0060	[4,7]	0	io -4 0x201C0060 0x00F00000
	Pull	z	0x201C0330	[2,3]	0	io -4 0x201C0330 0x000C0000
		up	0x201C0330	[2,3]	1	io -4 0x201C0330 0x000C0004
		down	0x201C0330	[2,3]	2	io -4 0x201C0330 0x000C0008
	I/O Mode	input	0x21E00008	[1,1]	0	io -4 0x21E00008 0x00020000
		output	0x21E00008	[1,1]	1	io -4 0x21E00008 0x00020002
	Output	low	0x21E00000	[1,1]	0	io -4 0x21E00000 0x00020000
		high	0x21E00000	[1,1]	1	io -4 0x21E00000 0x00020002
	Input Ctrl	disable	0x201C0430	[1,1]	0	io -4 0x201C0430 0x00020000
		enable	0x201C0430	[1,1]	1	io -4 0x201C0430 0x00020002
	Schmitt	disable	0x201C0530	[1,1]	0	io -4 0x201C0530 0x00020000
		enable	0x201C0530	[1,1]	1	io -4 0x201C0530 0x00020002
	Drive Strength	level0	0x201C01C0	[8,13]	1	io -4 0x201C01C0 0x3F000100
		level1	0x201C01C0	[8,13]	3	io -4 0x201C01C0 0x3F000300
		level2	0x201C01C0	[8,13]	7	io -4 0x201C01C0 0x3F000700
		level3	0x201C01C0	[8,13]	15	io -4 0x201C01C0 0x3F000F00
		level4	0x201C01C0	[8,13]	31	io -4 0x201C01C0 0x3F001F00
		level5	0x201C01C0	[8,13]	63	io -4 0x201C01C0 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[1,1]		io -4 0x21E00070
GPIO3A2	IOmux	SDMMC1_D0	0x201C0060	[8,11]	1	io -4 0x201C0060 0x0F000100
		I2C1_SCL_M1	0x201C0060	[8,11]	2	io -4 0x201C0060 0x0F000200
		GPIO3_A2	0x201C0060	[8,11]	0	io -4 0x201C0060 0x0F000000
	Pull	z	0x201C0330	[4,5]	0	io -4 0x201C0330 0x00300000
		up	0x201C0330	[4,5]	1	io -4 0x201C0330 0x00300010
		down	0x201C0330	[4,5]	2	io -4 0x201C0330 0x00300020
	I/O Mode	input	0x21E00008	[2,2]	0	io -4 0x21E00008 0x00040000
		output	0x21E00008	[2,2]	1	io -4 0x21E00008 0x00040004
	Output	low	0x21E00000	[2,2]	0	io -4 0x21E00000 0x00040000
		high	0x21E00000	[2,2]	1	io -4 0x21E00000 0x00040004
	Input Ctrl	disable	0x201C0430	[2,2]	0	io -4 0x201C0430 0x00040000
		enable	0x201C0430	[2,2]	1	io -4 0x201C0430 0x00040004
	Schmitt	disable	0x201C0530	[2,2]	0	io -4 0x201C0530 0x00040000
		enable	0x201C0530	[2,2]	1	io -4 0x201C0530 0x00040004
	Drive Strength	level0	0x201C01C4	[0,5]	1	io -4 0x201C01C4 0x003F0001
		level1	0x201C01C4	[0,5]	3	io -4 0x201C01C4 0x003F0003
		level2	0x201C01C4	[0,5]	7	io -4 0x201C01C4 0x003F0007
		level3	0x201C01C4	[0,5]	15	io -4 0x201C01C4 0x003F000F
		level4	0x201C01C4	[0,5]	31	io -4 0x201C01C4 0x003F001F
		level5	0x201C01C4	[0,5]	63	io -4 0x201C01C4 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[2,2]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3A3	IOMUX	SDMMC1_D1	0x201C0060	[12,15]	1	io -4 0x201C0060 0xF0001000
		I2C1_SDA_M1	0x201C0060	[12,15]	2	io -4 0x201C0060 0xF0002000
		GPIO3_A3	0x201C0060	[12,15]	0	io -4 0x201C0060 0xF0000000
	Pull	z	0x201C0330	[6,7]	0	io -4 0x201C0330 0x00C00000
		up	0x201C0330	[6,7]	1	io -4 0x201C0330 0x00C00040
		down	0x201C0330	[6,7]	2	io -4 0x201C0330 0x00C00080
	I/O Mode	input	0x21E00008	[3,3]	0	io -4 0x21E00008 0x00080000
		output	0x21E00008	[3,3]	1	io -4 0x21E00008 0x00080008
	Output	low	0x21E00000	[3,3]	0	io -4 0x21E00000 0x00080000
		high	0x21E00000	[3,3]	1	io -4 0x21E00000 0x00080008
	Input Ctrl	disable	0x201C0430	[3,3]	0	io -4 0x201C0430 0x00080000
		enable	0x201C0430	[3,3]	1	io -4 0x201C0430 0x00080008
	Schmitt	disable	0x201C0530	[3,3]	0	io -4 0x201C0530 0x00080000
		enable	0x201C0530	[3,3]	1	io -4 0x201C0530 0x00080008
	Drive Strength	level0	0x201C01C4	[8,13]	1	io -4 0x201C01C4 0x3F000100
		level1	0x201C01C4	[8,13]	3	io -4 0x201C01C4 0x3F000300
		level2	0x201C01C4	[8,13]	7	io -4 0x201C01C4 0x3F000700
		level3	0x201C01C4	[8,13]	15	io -4 0x201C01C4 0x3F000F00
		level4	0x201C01C4	[8,13]	31	io -4 0x201C01C4 0x3F001F00
		level5	0x201C01C4	[8,13]	63	io -4 0x201C01C4 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[3,3]		io -4 0x21E00070
GPIO3A4	IOMUX	SDMMC1_D2	0x201C0064	[0,3]	1	io -4 0x201C0064 0x000F0001
		GPIO3_A4	0x201C0064	[0,3]	0	io -4 0x201C0064 0x000F0000
	Pull	z	0x201C0330	[8,9]	0	io -4 0x201C0330 0x03000000
		up	0x201C0330	[8,9]	1	io -4 0x201C0330 0x03000100
		down	0x201C0330	[8,9]	2	io -4 0x201C0330 0x03000200
	I/O Mode	input	0x21E00008	[4,4]	0	io -4 0x21E00008 0x00100000
		output	0x21E00008	[4,4]	1	io -4 0x21E00008 0x00100010
	Output	low	0x21E00000	[4,4]	0	io -4 0x21E00000 0x00100000
		high	0x21E00000	[4,4]	1	io -4 0x21E00000 0x00100010
	Input Ctrl	disable	0x201C0430	[4,4]	0	io -4 0x201C0430 0x00100000
		enable	0x201C0430	[4,4]	1	io -4 0x201C0430 0x00100010
	Schmitt	disable	0x201C0530	[4,4]	0	io -4 0x201C0530 0x00100000
		enable	0x201C0530	[4,4]	1	io -4 0x201C0530 0x00100010
	Drive Strength	level0	0x201C01C8	[0,5]	1	io -4 0x201C01C8 0x003F0001
		level1	0x201C01C8	[0,5]	3	io -4 0x201C01C8 0x003F0003
		level2	0x201C01C8	[0,5]	7	io -4 0x201C01C8 0x003F0007
		level3	0x201C01C8	[0,5]	15	io -4 0x201C01C8 0x003F000F
		level4	0x201C01C8	[0,5]	31	io -4 0x201C01C8 0x003F001F
		level5	0x201C01C8	[0,5]	63	io -4 0x201C01C8 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[4,4]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3A5	IOMUX	SDMMC1_D3	0x201C0064	[4,7]	1	io -4 0x201C0064 0x00F00010
		GPIO3_A5	0x201C0064	[4,7]	0	io -4 0x201C0064 0x00F00000
	Pull	z	0x201C0330	[10,11]	0	io -4 0x201C0330 0x0C000000
		up	0x201C0330	[10,11]	1	io -4 0x201C0330 0x0C000400
		down	0x201C0330	[10,11]	2	io -4 0x201C0330 0x0C000800
	I/O Mode	input	0x21E00008	[5,5]	0	io -4 0x21E00008 0x00200000
		output	0x21E00008	[5,5]	1	io -4 0x21E00008 0x00200020
	Output	low	0x21E00000	[5,5]	0	io -4 0x21E00000 0x00200000
		high	0x21E00000	[5,5]	1	io -4 0x21E00000 0x00200020
	Input Ctrl	disable	0x201C0430	[5,5]	0	io -4 0x201C0430 0x00200000
		enable	0x201C0430	[5,5]	1	io -4 0x201C0430 0x00200020
	Schmitt	disable	0x201C0530	[5,5]	0	io -4 0x201C0530 0x00200000
		enable	0x201C0530	[5,5]	1	io -4 0x201C0530 0x00200020
	Drive Strength	level0	0x201C01C8	[8,13]	1	io -4 0x201C01C8 0x3F000100
		level1	0x201C01C8	[8,13]	3	io -4 0x201C01C8 0x3F000300
		level2	0x201C01C8	[8,13]	7	io -4 0x201C01C8 0x3F000700
		level3	0x201C01C8	[8,13]	15	io -4 0x201C01C8 0x3F000F00
		level4	0x201C01C8	[8,13]	31	io -4 0x201C01C8 0x3F001F00
		level5	0x201C01C8	[8,13]	63	io -4 0x201C01C8 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[5,5]		io -4 0x21E00070
GPIO3A6	IOMUX	UART2_RTSN_M0	0x201C0064	[8,11]	4	io -4 0x201C0064 0x0F000400
		GPIO3_A6	0x201C0064	[8,11]	0	io -4 0x201C0064 0x0F000000
	Pull	z	0x201C0330	[12,13]	0	io -4 0x201C0330 0x30000000
		up	0x201C0330	[12,13]	1	io -4 0x201C0330 0x30001000
		down	0x201C0330	[12,13]	2	io -4 0x201C0330 0x30002000
	I/O Mode	input	0x21E00008	[6,6]	0	io -4 0x21E00008 0x00400000
		output	0x21E00008	[6,6]	1	io -4 0x21E00008 0x00400040
	Output	low	0x21E00000	[6,6]	0	io -4 0x21E00000 0x00400000
		high	0x21E00000	[6,6]	1	io -4 0x21E00000 0x00400040
	Input Ctrl	disable	0x201C0430	[6,6]	0	io -4 0x201C0430 0x00400000
		enable	0x201C0430	[6,6]	1	io -4 0x201C0430 0x00400040
	Schmitt	disable	0x201C0530	[6,6]	0	io -4 0x201C0530 0x00400000
		enable	0x201C0530	[6,6]	1	io -4 0x201C0530 0x00400040
	Drive Strength	level0	0x201C01CC	[0,5]	1	io -4 0x201C01CC 0x003F0001
		level1	0x201C01CC	[0,5]	3	io -4 0x201C01CC 0x003F0003
		level2	0x201C01CC	[0,5]	7	io -4 0x201C01CC 0x003F0007
		level3	0x201C01CC	[0,5]	15	io -4 0x201C01CC 0x003F000F
		level4	0x201C01CC	[0,5]	31	io -4 0x201C01CC 0x003F001F
		level5	0x201C01CC	[0,5]	63	io -4 0x201C01CC 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[6,6]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3A7	IOMUX	UART2_CTSN_M0	0x201C0064	[12,15]	4	io -4 0x201C0064 0xF0004000
		GPIO3_A7	0x201C0064	[12,15]	0	io -4 0x201C0064 0xF0000000
	Pull	z	0x201C0330	[14,15]	0	io -4 0x201C0330 0xC0000000
		up	0x201C0330	[14,15]	1	io -4 0x201C0330 0xC0004000
		down	0x201C0330	[14,15]	2	io -4 0x201C0330 0xC0008000
	I/O Mode	input	0x21E00008	[7,7]	0	io -4 0x21E00008 0x00800000
		output	0x21E00008	[7,7]	1	io -4 0x21E00008 0x00800080
	Output	low	0x21E00000	[7,7]	0	io -4 0x21E00000 0x00800000
		high	0x21E00000	[7,7]	1	io -4 0x21E00000 0x00800080
	Input Ctrl	disable	0x201C0430	[7,7]	0	io -4 0x201C0430 0x00800000
		enable	0x201C0430	[7,7]	1	io -4 0x201C0430 0x00800080
	Schmitt	disable	0x201C0530	[7,7]	0	io -4 0x201C0530 0x00800000
		enable	0x201C0530	[7,7]	1	io -4 0x201C0530 0x00800080
	Drive Strength	level0	0x201C01CC	[8,13]	1	io -4 0x201C01CC 0x3F000100
		level1	0x201C01CC	[8,13]	3	io -4 0x201C01CC 0x3F000300
		level2	0x201C01CC	[8,13]	7	io -4 0x201C01CC 0x3F000700
		level3	0x201C01CC	[8,13]	15	io -4 0x201C01CC 0x3F000F00
		level4	0x201C01CC	[8,13]	31	io -4 0x201C01CC 0x3F001F00
		level5	0x201C01CC	[8,13]	63	io -4 0x201C01CC 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[7,7]		io -4 0x21E00070
GPIO3B0	IOMUX	UART2_RX_M0	0x201C0068	[0,3]	4	io -4 0x201C0068 0x000F0004
		GPIO3_B0	0x201C0068	[0,3]	0	io -4 0x201C0068 0x000F0000
	Pull	z	0x201C0334	[0,1]	0	io -4 0x201C0334 0x00030000
		up	0x201C0334	[0,1]	1	io -4 0x201C0334 0x00030001
		down	0x201C0334	[0,1]	2	io -4 0x201C0334 0x00030002
	I/O Mode	input	0x21E00008	[8,8]	0	io -4 0x21E00008 0x01000000
		output	0x21E00008	[8,8]	1	io -4 0x21E00008 0x01000100
	Output	low	0x21E00000	[8,8]	0	io -4 0x21E00000 0x01000000
		high	0x21E00000	[8,8]	1	io -4 0x21E00000 0x01000100
	Input Ctrl	disable	0x201C0434	[0,0]	0	io -4 0x201C0434 0x00010000
		enable	0x201C0434	[0,0]	1	io -4 0x201C0434 0x00010001
	Schmitt	disable	0x201C0534	[0,0]	0	io -4 0x201C0534 0x00010000
		enable	0x201C0534	[0,0]	1	io -4 0x201C0534 0x00010001
	Drive Strength	level0	0x201C01D0	[0,5]	1	io -4 0x201C01D0 0x003F0001
		level1	0x201C01D0	[0,5]	3	io -4 0x201C01D0 0x003F0003
		level2	0x201C01D0	[0,5]	7	io -4 0x201C01D0 0x003F0007
		level3	0x201C01D0	[0,5]	15	io -4 0x201C01D0 0x003F000F
		level4	0x201C01D0	[0,5]	31	io -4 0x201C01D0 0x003F001F
		level5	0x201C01D0	[0,5]	63	io -4 0x201C01D0 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[8,8]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3B1	IOMUX	SAI2_SDI2_M0	0x201C0068	[4,7]	2	io -4 0x201C0068 0x00F00020
		UART2_TX_M0	0x201C0068	[4,7]	4	io -4 0x201C0068 0x00F00040
		GPIO3_B1	0x201C0068	[4,7]	0	io -4 0x201C0068 0x00F00000
	Pull	z	0x201C0334	[2,3]	0	io -4 0x201C0334 0x000C0000
		up	0x201C0334	[2,3]	1	io -4 0x201C0334 0x000C0004
		down	0x201C0334	[2,3]	2	io -4 0x201C0334 0x000C0008
	I/O Mode	input	0x21E00008	[9,9]	0	io -4 0x21E00008 0x02000000
		output	0x21E00008	[9,9]	1	io -4 0x21E00008 0x02000200
	Output	low	0x21E00000	[9,9]	0	io -4 0x21E00000 0x02000000
		high	0x21E00000	[9,9]	1	io -4 0x21E00000 0x02000200
	Input Ctrl	disable	0x201C0434	[1,1]	0	io -4 0x201C0434 0x00020000
		enable	0x201C0434	[1,1]	1	io -4 0x201C0434 0x00020002
	Schmitt	disable	0x201C0534	[1,1]	0	io -4 0x201C0534 0x00020000
		enable	0x201C0534	[1,1]	1	io -4 0x201C0534 0x00020002
	Drive Strength	level0	0x201C01D0	[8,13]	1	io -4 0x201C01D0 0x3F000100
		level1	0x201C01D0	[8,13]	3	io -4 0x201C01D0 0x3F000300
		level2	0x201C01D0	[8,13]	7	io -4 0x201C01D0 0x3F000700
		level3	0x201C01D0	[8,13]	15	io -4 0x201C01D0 0x3F000F00
		level4	0x201C01D0	[8,13]	31	io -4 0x201C01D0 0x3F001F00
		level5	0x201C01D0	[8,13]	63	io -4 0x201C01D0 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[9,9]		io -4 0x21E00070
GPIO3B2	IOMUX	SPI1_MOSI_M1	0x201C0068	[8,11]	1	io -4 0x201C0068 0x0F000100
		SAI2_SDO_M0	0x201C0068	[8,11]	2	io -4 0x201C0068 0x0F000200
		PWM2_CH0_M0	0x201C0068	[8,11]	3	io -4 0x201C0068 0x0F000300
		FLASH_TRIG_OUT	0x201C0068	[8,11]	6	io -4 0x201C0068 0x0F000600
		GPIO3_B2	0x201C0068	[8,11]	0	io -4 0x201C0068 0x0F000000
	Pull	z	0x201C0334	[4,5]	0	io -4 0x201C0334 0x00300000
		up	0x201C0334	[4,5]	1	io -4 0x201C0334 0x00300010
		down	0x201C0334	[4,5]	2	io -4 0x201C0334 0x00300020
	I/O Mode	input	0x21E00008	[10,10]	0	io -4 0x21E00008 0x04000000
		output	0x21E00008	[10,10]	1	io -4 0x21E00008 0x04000400
	Output	low	0x21E00000	[10,10]	0	io -4 0x21E00000 0x04000000
		high	0x21E00000	[10,10]	1	io -4 0x21E00000 0x04000400
	Input Ctrl	disable	0x201C0434	[2,2]	0	io -4 0x201C0434 0x00040000
		enable	0x201C0434	[2,2]	1	io -4 0x201C0434 0x00040004
	Schmitt	disable	0x201C0534	[2,2]	0	io -4 0x201C0534 0x00040000
		enable	0x201C0534	[2,2]	1	io -4 0x201C0534 0x00040004
	Drive Strength	level0	0x201C01D4	[0,5]	1	io -4 0x201C01D4 0x003F0001
		level1	0x201C01D4	[0,5]	3	io -4 0x201C01D4 0x003F0003
		level2	0x201C01D4	[0,5]	7	io -4 0x201C01D4 0x003F0007
		level3	0x201C01D4	[0,5]	15	io -4 0x201C01D4 0x003F000F
		level4	0x201C01D4	[0,5]	31	io -4 0x201C01D4 0x003F001F
		level5	0x201C01D4	[0,5]	63	io -4 0x201C01D4 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[10,10]		io -4 0x21E00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO3B3	IOmux	SPI1_MISO_M1	0x201C0068	[12,15]	1	io -4 0x201C0068 0xF0001000
		SAI2_SDI0_M0	0x201C0068	[12,15]	2	io -4 0x201C0068 0xF0002000
		PWM2_CH1_M0	0x201C0068	[12,15]	3	io -4 0x201C0068 0xF0003000
		PRELIGHT_TRIG_OUT	0x201C0068	[12,15]	6	io -4 0x201C0068 0xF0006000
		GPIO3_B3	0x201C0068	[12,15]	0	io -4 0x201C0068 0xF0000000
	Pull	z	0x201C0334	[6,7]	0	io -4 0x201C0334 0x00C00000
		up	0x201C0334	[6,7]	1	io -4 0x201C0334 0x00C00040
		down	0x201C0334	[6,7]	2	io -4 0x201C0334 0x00C00080
	I/O Mode	input	0x21E00008	[11,11]	0	io -4 0x21E00008 0x08000000
		output	0x21E00008	[11,11]	1	io -4 0x21E00008 0x08000800
	Output	low	0x21E00000	[11,11]	0	io -4 0x21E00000 0x08000000
		high	0x21E00000	[11,11]	1	io -4 0x21E00000 0x08000800
	Input Ctrl	disable	0x201C0434	[3,3]	0	io -4 0x201C0434 0x00080000
		enable	0x201C0434	[3,3]	1	io -4 0x201C0434 0x00080008
	Schmitt	disable	0x201C0534	[3,3]	0	io -4 0x201C0534 0x00080000
		enable	0x201C0534	[3,3]	1	io -4 0x201C0534 0x00080008
	Drive Strength	level0	0x201C01D4	[8,13]	1	io -4 0x201C01D4 0x3F000100
		level1	0x201C01D4	[8,13]	3	io -4 0x201C01D4 0x3F000300
		level2	0x201C01D4	[8,13]	7	io -4 0x201C01D4 0x3F000700
		level3	0x201C01D4	[8,13]	15	io -4 0x201C01D4 0x3F000F00
		level4	0x201C01D4	[8,13]	31	io -4 0x201C01D4 0x3F001F00
		level5	0x201C01D4	[8,13]	63	io -4 0x201C01D4 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[11,11]		io -4 0x21E00070
GPIO3B4	IOmux	SPI1_CLK_M1	0x201C006C	[0,3]	1	io -4 0x201C006C 0x000F0001
		SAI2_SCLK_M0	0x201C006C	[0,3]	2	io -4 0x201C006C 0x000F0002
		PWM2_CH2_M0	0x201C006C	[0,3]	3	io -4 0x201C006C 0x000F0003
		UART1_RTSN_M1	0x201C006C	[0,3]	4	io -4 0x201C006C 0x000F0004
		I2C4_SCL_M0	0x201C006C	[0,3]	5	io -4 0x201C006C 0x000F0005
		FEPHY_LEDLINK_M0	0x201C006C	[0,3]	6	io -4 0x201C006C 0x000F0006
		GPIO3_B4	0x201C006C	[0,3]	0	io -4 0x201C006C 0x000F0000
	Pull	z	0x201C0334	[8,9]	0	io -4 0x201C0334 0x03000000
		up	0x201C0334	[8,9]	1	io -4 0x201C0334 0x03000100
		down	0x201C0334	[8,9]	2	io -4 0x201C0334 0x03000200
	I/O Mode	input	0x21E00008	[12,12]	0	io -4 0x21E00008 0x10000000
		output	0x21E00008	[12,12]	1	io -4 0x21E00008 0x10001000
	Output	low	0x21E00000	[12,12]	0	io -4 0x21E00000 0x10000000
		high	0x21E00000	[12,12]	1	io -4 0x21E00000 0x10001000
	Input Ctrl	disable	0x201C0434	[4,4]	0	io -4 0x201C0434 0x00100000
		enable	0x201C0434	[4,4]	1	io -4 0x201C0434 0x00100010
	Schmitt	disable	0x201C0534	[4,4]	0	io -4 0x201C0534 0x00100000
		enable	0x201C0534	[4,4]	1	io -4 0x201C0534 0x00100010
	Drive Strength	level0	0x201C01D8	[0,5]	1	io -4 0x201C01D8 0x003F0001
		level1	0x201C01D8	[0,5]	3	io -4 0x201C01D8 0x003F0003
		level2	0x201C01D8	[0,5]	7	io -4 0x201C01D8 0x003F0007
		level3	0x201C01D8	[0,5]	15	io -4 0x201C01D8 0x003F000F
		level4	0x201C01D8	[0,5]	31	io -4 0x201C01D8 0x003F001F
		level5	0x201C01D8	[0,5]	63	io -4 0x201C01D8 0x003F003F

Name	Config	Description	Register	Position	Value	IO Command
	ExtPort	read gpio data in input	0x21E00070	[12,12]		io -4 0x21E00070
GPIO3B5	IOmux	SPI1_CSN0_M1	0x201C006C	[4,7]	1	io -4 0x201C006C 0x00F00010
		SAI2_LRCK_M0	0x201C006C	[4,7]	2	io -4 0x201C006C 0x00F00020
		PWM2_CH3_M0	0x201C006C	[4,7]	3	io -4 0x201C006C 0x00F00030
		UART1_CTSN_M1	0x201C006C	[4,7]	4	io -4 0x201C006C 0x00F00040
		I2C4_SDA_M0	0x201C006C	[4,7]	5	io -4 0x201C006C 0x00F00050
		FEPHY_LEDSPD_M0	0x201C006C	[4,7]	6	io -4 0x201C006C 0x00F00060
		GPIO3_B5	0x201C006C	[4,7]	0	io -4 0x201C006C 0x00F00000
	Pull	z	0x201C0334	[10,11]	0	io -4 0x201C0334 0x0C000000
		up	0x201C0334	[10,11]	1	io -4 0x201C0334 0x0C000400
		down	0x201C0334	[10,11]	2	io -4 0x201C0334 0x0C000800
	I/O Mode	input	0x21E00008	[13,13]	0	io -4 0x21E00008 0x20000000
		output	0x21E00008	[13,13]	1	io -4 0x21E00008 0x20002000
	Output	low	0x21E00000	[13,13]	0	io -4 0x21E00000 0x20000000
		high	0x21E00000	[13,13]	1	io -4 0x21E00000 0x20002000
	Input Ctrl	disable	0x201C0434	[5,5]	0	io -4 0x201C0434 0x00200000
		enable	0x201C0434	[5,5]	1	io -4 0x201C0434 0x00200020
	Schmitt	disable	0x201C0534	[5,5]	0	io -4 0x201C0534 0x00200000
		enable	0x201C0534	[5,5]	1	io -4 0x201C0534 0x00200020
	Drive Strength	level0	0x201C01D8	[8,13]	1	io -4 0x201C01D8 0x3F000100
		level1	0x201C01D8	[8,13]	3	io -4 0x201C01D8 0x3F000300
		level2	0x201C01D8	[8,13]	7	io -4 0x201C01D8 0x3F000700
		level3	0x201C01D8	[8,13]	15	io -4 0x201C01D8 0x3F000F00
		level4	0x201C01D8	[8,13]	31	io -4 0x201C01D8 0x3F001F00
		level5	0x201C01D8	[8,13]	63	io -4 0x201C01D8 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[13,13]		io -4 0x21E00070
GPIO3B6	IOmux	SPI1_CSN1_M1	0x201C006C	[8,11]	1	io -4 0x201C006C 0x0F000100
		SAI2_MCLK_M0	0x201C006C	[8,11]	2	io -4 0x201C006C 0x0F000200
		SDMMC1_DET_N	0x201C006C	[8,11]	3	io -4 0x201C006C 0x0F000300
		UART1_TX_M1	0x201C006C	[8,11]	4	io -4 0x201C006C 0x0F000400
		I2C5_SCL_M1	0x201C006C	[8,11]	5	io -4 0x201C006C 0x0F000500
		GPIO3_B6	0x201C006C	[8,11]	0	io -4 0x201C006C 0x0F000000
	Pull	z	0x201C0334	[12,13]	0	io -4 0x201C0334 0x30000000
		up	0x201C0334	[12,13]	1	io -4 0x201C0334 0x30001000
		down	0x201C0334	[12,13]	2	io -4 0x201C0334 0x30002000
	I/O Mode	input	0x21E00008	[14,14]	0	io -4 0x21E00008 0x40000000
		output	0x21E00008	[14,14]	1	io -4 0x21E00008 0x40004000
	Output	low	0x21E00000	[14,14]	0	io -4 0x21E00000 0x40000000
		high	0x21E00000	[14,14]	1	io -4 0x21E00000 0x40004000
	Input Ctrl	disable	0x201C0434	[6,6]	0	io -4 0x201C0434 0x00400000
		enable	0x201C0434	[6,6]	1	io -4 0x201C0434 0x00400040
	Schmitt	disable	0x201C0534	[6,6]	0	io -4 0x201C0534 0x00400000
		enable	0x201C0534	[6,6]	1	io -4 0x201C0534 0x00400040

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C01DC	[0,5]	1	io -4 0x201C01DC 0x003F0001
		level1	0x201C01DC	[0,5]	3	io -4 0x201C01DC 0x003F0003
		level2	0x201C01DC	[0,5]	7	io -4 0x201C01DC 0x003F0007
		level3	0x201C01DC	[0,5]	15	io -4 0x201C01DC 0x003F000F
		level4	0x201C01DC	[0,5]	31	io -4 0x201C01DC 0x003F001F
		level5	0x201C01DC	[0,5]	63	io -4 0x201C01DC 0x003F003F
	ExtPort	read gpio data in input	0x21E00070	[14,14]		io -4 0x21E00070
GPIO3B7	IOMUX	SAI2_SDI1_M0	0x201C006C	[12,15]	2	io -4 0x201C006C 0xF0002000
		UART1_RX_M1	0x201C006C	[12,15]	4	io -4 0x201C006C 0xF0004000
		I2C5_SDA_M1	0x201C006C	[12,15]	5	io -4 0x201C006C 0xF0005000
		GPIO3_B7	0x201C006C	[12,15]	0	io -4 0x201C006C 0xF0000000
	Pull	z	0x201C0334	[14,15]	0	io -4 0x201C0334 0xC0000000
		up	0x201C0334	[14,15]	1	io -4 0x201C0334 0xC0004000
		down	0x201C0334	[14,15]	2	io -4 0x201C0334 0xC0008000
	I/O Mode	input	0x21E00008	[15,15]	0	io -4 0x21E00008 0x80000000
		output	0x21E00008	[15,15]	1	io -4 0x21E00008 0x80008000
	Output	low	0x21E00000	[15,15]	0	io -4 0x21E00000 0x80000000
		high	0x21E00000	[15,15]	1	io -4 0x21E00000 0x80008000
	Input Ctrl	disable	0x201C0434	[7,7]	0	io -4 0x201C0434 0x00800000
		enable	0x201C0434	[7,7]	1	io -4 0x201C0434 0x00800080
	Schmitt	disable	0x201C0534	[7,7]	0	io -4 0x201C0534 0x00800000
		enable	0x201C0534	[7,7]	1	io -4 0x201C0534 0x00800080
	Drive Strength	level0	0x201C01DC	[8,13]	1	io -4 0x201C01DC 0x3F000100
		level1	0x201C01DC	[8,13]	3	io -4 0x201C01DC 0x3F000300
		level2	0x201C01DC	[8,13]	7	io -4 0x201C01DC 0x3F000700
		level3	0x201C01DC	[8,13]	15	io -4 0x201C01DC 0x3F000F00
		level4	0x201C01DC	[8,13]	31	io -4 0x201C01DC 0x3F001F00
		level5	0x201C01DC	[8,13]	63	io -4 0x201C01DC 0x3F003F00
	ExtPort	read gpio data in input	0x21E00070	[15,15]		io -4 0x21E00070
GPIO4A0	IOMUX	CAM_CLK3_OUT	0x201C8080	[0,3]	3	io -4 0x201C8080 0x000F0003
		UART4_RTSN_M0	0x201C8080	[0,3]	5	io -4 0x201C8080 0x000F0005
		I2C1_SDA_M2	0x201C8080	[0,3]	6	io -4 0x201C8080 0x000F0006
		GPIO4_A0	0x201C8080	[0,3]	0	io -4 0x201C8080 0x000F0000
	Pull	z	0x201C8340	[0,1]	0	io -4 0x201C8340 0x00030000
		up	0x201C8340	[0,1]	1	io -4 0x201C8340 0x00030001
		down	0x201C8340	[0,1]	2	io -4 0x201C8340 0x00030002
	I/O Mode	input	0x21800008	[0,0]	0	io -4 0x21800008 0x00010000
		output	0x21800008	[0,0]	1	io -4 0x21800008 0x00010001
	Output	low	0x21800000	[0,0]	0	io -4 0x21800000 0x00010000
		high	0x21800000	[0,0]	1	io -4 0x21800000 0x00010001
	Input Ctrl	disable	0x201C8440	[0,0]	0	io -4 0x201C8440 0x00010000
		enable	0x201C8440	[0,0]	1	io -4 0x201C8440 0x00010001
	Schmitt	disable	0x201C8540	[0,0]	0	io -4 0x201C8540 0x00010000
		enable	0x201C8540	[0,0]	1	io -4 0x201C8540 0x00010001

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C8200	[0,5]	1	io -4 0x201C8200 0x003F0001
		level1	0x201C8200	[0,5]	3	io -4 0x201C8200 0x003F0003
		level2	0x201C8200	[0,5]	7	io -4 0x201C8200 0x003F0007
		level3	0x201C8200	[0,5]	15	io -4 0x201C8200 0x003F000F
		level4	0x201C8200	[0,5]	31	io -4 0x201C8200 0x003F001F
		level5	0x201C8200	[0,5]	63	io -4 0x201C8200 0x003F003F
	ExtPort	read gpio data in input	0x21800070	[0,0]		io -4 0x21800070
GPIO4A1	IOmux	CAM_CLK2_OUT	0x201C8080	[4,7]	3	io -4 0x201C8080 0x00F00030
		UART4_CTSN_M0	0x201C8080	[4,7]	5	io -4 0x201C8080 0x00F00050
		I2C1_SCL_M2	0x201C8080	[4,7]	6	io -4 0x201C8080 0x00F00060
		GPIO4_A1	0x201C8080	[4,7]	0	io -4 0x201C8080 0x00F00000
	Pull	z	0x201C8340	[2,3]	0	io -4 0x201C8340 0x000C0000
		up	0x201C8340	[2,3]	1	io -4 0x201C8340 0x000C0004
		down	0x201C8340	[2,3]	2	io -4 0x201C8340 0x000C0008
	I/O Mode	input	0x21800008	[1,1]	0	io -4 0x21800008 0x00020000
		output	0x21800008	[1,1]	1	io -4 0x21800008 0x00020002
	Output	low	0x21800000	[1,1]	0	io -4 0x21800000 0x00020000
		high	0x21800000	[1,1]	1	io -4 0x21800000 0x00020002
	Input Ctrl	disable	0x201C8440	[1,1]	0	io -4 0x201C8440 0x00020000
		enable	0x201C8440	[1,1]	1	io -4 0x201C8440 0x00020002
	Schmitt	disable	0x201C8540	[1,1]	0	io -4 0x201C8540 0x00020000
		enable	0x201C8540	[1,1]	1	io -4 0x201C8540 0x00020002
	Drive Strength	level0	0x201C8200	[8,13]	1	io -4 0x201C8200 0x3F000100
		level1	0x201C8200	[8,13]	3	io -4 0x201C8200 0x3F000300
		level2	0x201C8200	[8,13]	7	io -4 0x201C8200 0x3F000700
		level3	0x201C8200	[8,13]	15	io -4 0x201C8200 0x3F000F00
		level4	0x201C8200	[8,13]	31	io -4 0x201C8200 0x3F001F00
		level5	0x201C8200	[8,13]	63	io -4 0x201C8200 0x3F003F00
	ExtPort	read gpio data in input	0x21800070	[1,1]		io -4 0x21800070
GPIO4A2	IOmux	PWM0_CH4_M1	0x201C8080	[8,11]	4	io -4 0x201C8080 0x0F000400
		UART4_RX_M0	0x201C8080	[8,11]	5	io -4 0x201C8080 0x0F000500
		GPIO4_A2	0x201C8080	[8,11]	0	io -4 0x201C8080 0x0F000000
	Pull	z	0x201C8340	[4,5]	0	io -4 0x201C8340 0x00300000
		up	0x201C8340	[4,5]	1	io -4 0x201C8340 0x00300010
		down	0x201C8340	[4,5]	2	io -4 0x201C8340 0x00300020
	I/O Mode	input	0x21800008	[2,2]	0	io -4 0x21800008 0x00040000
		output	0x21800008	[2,2]	1	io -4 0x21800008 0x00040004
	Output	low	0x21800000	[2,2]	0	io -4 0x21800000 0x00040000
		high	0x21800000	[2,2]	1	io -4 0x21800000 0x00040004
	Input Ctrl	disable	0x201C8440	[2,2]	0	io -4 0x201C8440 0x00040000
		enable	0x201C8440	[2,2]	1	io -4 0x201C8440 0x00040004
	Schmitt	disable	0x201C8540	[2,2]	0	io -4 0x201C8540 0x00040000
		enable	0x201C8540	[2,2]	1	io -4 0x201C8540 0x00040004

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C8204	[0,5]	1	io -4 0x201C8204 0x003F0001
		level1	0x201C8204	[0,5]	3	io -4 0x201C8204 0x003F0003
		level2	0x201C8204	[0,5]	7	io -4 0x201C8204 0x003F0007
		level3	0x201C8204	[0,5]	15	io -4 0x201C8204 0x003F000F
		level4	0x201C8204	[0,5]	31	io -4 0x201C8204 0x003F001F
		level5	0x201C8204	[0,5]	63	io -4 0x201C8204 0x003F003F
	ExtPort	read gpio data in input	0x21800070	[2,2]		io -4 0x21800070
GPIO4A3	IOmux	SPI0_CSN1_M1	0x201C8080	[12,15]	1	io -4 0x201C8080 0xF0001000
		SAI1_MCLK_M1	0x201C8080	[12,15]	2	io -4 0x201C8080 0xF0002000
		PWM0_CH5_M1	0x201C8080	[12,15]	4	io -4 0x201C8080 0xF0004000
		UART4_TX_M0	0x201C8080	[12,15]	5	io -4 0x201C8080 0xF0005000
		GPIO4_A3	0x201C8080	[12,15]	0	io -4 0x201C8080 0xF0000000
	Pull	z	0x201C8340	[6,7]	0	io -4 0x201C8340 0x00C00000
		up	0x201C8340	[6,7]	1	io -4 0x201C8340 0x00C00040
		down	0x201C8340	[6,7]	2	io -4 0x201C8340 0x00C00080
	I/O Mode	input	0x21800008	[3,3]	0	io -4 0x21800008 0x00080000
		output	0x21800008	[3,3]	1	io -4 0x21800008 0x00080008
	Output	low	0x21800000	[3,3]	0	io -4 0x21800000 0x00080000
		high	0x21800000	[3,3]	1	io -4 0x21800000 0x00080008
	Input Ctrl	disable	0x201C8440	[3,3]	0	io -4 0x201C8440 0x00080000
		enable	0x201C8440	[3,3]	1	io -4 0x201C8440 0x00080008
	Schmitt	disable	0x201C8540	[3,3]	0	io -4 0x201C8540 0x00080000
		enable	0x201C8540	[3,3]	1	io -4 0x201C8540 0x00080008
	Drive Strength	level0	0x201C8204	[8,13]	1	io -4 0x201C8204 0x3F000100
		level1	0x201C8204	[8,13]	3	io -4 0x201C8204 0x3F000300
		level2	0x201C8204	[8,13]	7	io -4 0x201C8204 0x3F000700
		level3	0x201C8204	[8,13]	15	io -4 0x201C8204 0x3F000F00
		level4	0x201C8204	[8,13]	31	io -4 0x201C8204 0x3F001F00
		level5	0x201C8204	[8,13]	63	io -4 0x201C8204 0x3F003F00
	ExtPort	read gpio data in input	0x21800070	[3,3]		io -4 0x21800070
GPIO4A4	IOmux	SPI0_MOSI_M1	0x201C8084	[0,3]	1	io -4 0x201C8084 0x000F0001
		SAI1_SCLK_M1	0x201C8084	[0,3]	2	io -4 0x201C8084 0x000F0002
		I2C3_SCL_M1	0x201C8084	[0,3]	6	io -4 0x201C8084 0x000F0006
		GPIO4_A4	0x201C8084	[0,3]	0	io -4 0x201C8084 0x000F0000
	Pull	z	0x201C8340	[8,9]	0	io -4 0x201C8340 0x03000000
		up	0x201C8340	[8,9]	1	io -4 0x201C8340 0x03000100
		down	0x201C8340	[8,9]	2	io -4 0x201C8340 0x03000200
	I/O Mode	input	0x21800008	[4,4]	0	io -4 0x21800008 0x00100000
		output	0x21800008	[4,4]	1	io -4 0x21800008 0x00100010
	Output	low	0x21800000	[4,4]	0	io -4 0x21800000 0x00100000
		high	0x21800000	[4,4]	1	io -4 0x21800000 0x00100010
	Input Ctrl	disable	0x201C8440	[4,4]	0	io -4 0x201C8440 0x00100000
		enable	0x201C8440	[4,4]	1	io -4 0x201C8440 0x00100010
	Schmitt	disable	0x201C8540	[4,4]	0	io -4 0x201C8540 0x00100000
		enable	0x201C8540	[4,4]	1	io -4 0x201C8540 0x00100010

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C8208	[0,5]	1	io -4 0x201C8208 0x003F0001
		level1	0x201C8208	[0,5]	3	io -4 0x201C8208 0x003F0003
		level2	0x201C8208	[0,5]	7	io -4 0x201C8208 0x003F0007
		level3	0x201C8208	[0,5]	15	io -4 0x201C8208 0x003F000F
		level4	0x201C8208	[0,5]	31	io -4 0x201C8208 0x003F001F
		level5	0x201C8208	[0,5]	63	io -4 0x201C8208 0x003F003F
	ExtPort	read gpio data in input	0x21800070	[4,4]		io -4 0x21800070
GPIO4A5	IOmux	SPI0_MISO_M1	0x201C8084	[4,7]	1	io -4 0x201C8084 0x00F00010
		SAI1_LRCK_M1	0x201C8084	[4,7]	2	io -4 0x201C8084 0x00F00020
		I2C3_SDA_M1	0x201C8084	[4,7]	6	io -4 0x201C8084 0x00F00060
		GPIO4_A5	0x201C8084	[4,7]	0	io -4 0x201C8084 0x00F00000
	Pull	z	0x201C8340	[10,11]	0	io -4 0x201C8340 0x0C000000
		up	0x201C8340	[10,11]	1	io -4 0x201C8340 0x0C000400
		down	0x201C8340	[10,11]	2	io -4 0x201C8340 0x0C000800
	I/O Mode	input	0x21800008	[5,5]	0	io -4 0x21800008 0x00200000
		output	0x21800008	[5,5]	1	io -4 0x21800008 0x00200020
	Output	low	0x21800000	[5,5]	0	io -4 0x21800000 0x00200000
		high	0x21800000	[5,5]	1	io -4 0x21800000 0x00200020
	Input Ctrl	disable	0x201C8440	[5,5]	0	io -4 0x201C8440 0x00200000
		enable	0x201C8440	[5,5]	1	io -4 0x201C8440 0x00200020
	Schmitt	disable	0x201C8540	[5,5]	0	io -4 0x201C8540 0x00200000
		enable	0x201C8540	[5,5]	1	io -4 0x201C8540 0x00200020
	Drive Strength	level0	0x201C8208	[8,13]	1	io -4 0x201C8208 0x3F000100
		level1	0x201C8208	[8,13]	3	io -4 0x201C8208 0x3F000300
		level2	0x201C8208	[8,13]	7	io -4 0x201C8208 0x3F000700
		level3	0x201C8208	[8,13]	15	io -4 0x201C8208 0x3F000F00
		level4	0x201C8208	[8,13]	31	io -4 0x201C8208 0x3F001F00
		level5	0x201C8208	[8,13]	63	io -4 0x201C8208 0x3F003F00
	ExtPort	read gpio data in input	0x21800070	[5,5]		io -4 0x21800070
GPIO4A6	IOmux	SPI0_CSN0_M1	0x201C8084	[8,11]	1	io -4 0x201C8084 0x0F000100
		SAI1_SDI_M1	0x201C8084	[8,11]	2	io -4 0x201C8084 0x0F000200
		PWM0_CH6_M1	0x201C8084	[8,11]	4	io -4 0x201C8084 0x0F000400
		UART5_TX_M0	0x201C8084	[8,11]	5	io -4 0x201C8084 0x0F000500
		I2C4_SDA_M2	0x201C8084	[8,11]	6	io -4 0x201C8084 0x0F000600
		GPIO4_A6	0x201C8084	[8,11]	0	io -4 0x201C8084 0x0F000000
	Pull	z	0x201C8340	[12,13]	0	io -4 0x201C8340 0x30000000
		up	0x201C8340	[12,13]	1	io -4 0x201C8340 0x30001000
		down	0x201C8340	[12,13]	2	io -4 0x201C8340 0x30002000
	I/O Mode	input	0x21800008	[6,6]	0	io -4 0x21800008 0x00400000
		output	0x21800008	[6,6]	1	io -4 0x21800008 0x00400040
	Output	low	0x21800000	[6,6]	0	io -4 0x21800000 0x00400000
		high	0x21800000	[6,6]	1	io -4 0x21800000 0x00400040
	Input Ctrl	disable	0x201C8440	[6,6]	0	io -4 0x201C8440 0x00400000
		enable	0x201C8440	[6,6]	1	io -4 0x201C8440 0x00400040
	Schmitt	disable	0x201C8540	[6,6]	0	io -4 0x201C8540 0x00400000
		enable	0x201C8540	[6,6]	1	io -4 0x201C8540 0x00400040

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C820C	[0,5]	1	io -4 0x201C820C 0x003F0001
		level1	0x201C820C	[0,5]	3	io -4 0x201C820C 0x003F0003
		level2	0x201C820C	[0,5]	7	io -4 0x201C820C 0x003F0007
		level3	0x201C820C	[0,5]	15	io -4 0x201C820C 0x003F000F
		level4	0x201C820C	[0,5]	31	io -4 0x201C820C 0x003F001F
		level5	0x201C820C	[0,5]	63	io -4 0x201C820C 0x003F003F
	ExtPort	read gpio data in input	0x21800070	[6,6]		io -4 0x21800070
GPIO4A7	IOmux	SPI0_CLK_M1	0x201C8084	[12,15]	1	io -4 0x201C8084 0xF0001000
		SAI1_SDO_M1	0x201C8084	[12,15]	2	io -4 0x201C8084 0xF0002000
		PWM0_CH7_M1	0x201C8084	[12,15]	4	io -4 0x201C8084 0xF0004000
		UART5_RX_M0	0x201C8084	[12,15]	5	io -4 0x201C8084 0xF0005000
		I2C4_SCL_M2	0x201C8084	[12,15]	6	io -4 0x201C8084 0xF0006000
		GPIO4_A7	0x201C8084	[12,15]	0	io -4 0x201C8084 0xF0000000
	Pull	z	0x201C8340	[14,15]	0	io -4 0x201C8340 0xC0000000
		up	0x201C8340	[14,15]	1	io -4 0x201C8340 0xC0004000
		down	0x201C8340	[14,15]	2	io -4 0x201C8340 0xC0008000
	I/O Mode	input	0x21800008	[7,7]	0	io -4 0x21800008 0x00800000
		output	0x21800008	[7,7]	1	io -4 0x21800008 0x00800080
	Output	low	0x21800000	[7,7]	0	io -4 0x21800000 0x00800000
		high	0x21800000	[7,7]	1	io -4 0x21800000 0x00800080
	Input Ctrl	disable	0x201C8440	[7,7]	0	io -4 0x201C8440 0x00800000
		enable	0x201C8440	[7,7]	1	io -4 0x201C8440 0x00800080
	Schmitt	disable	0x201C8540	[7,7]	0	io -4 0x201C8540 0x00800000
		enable	0x201C8540	[7,7]	1	io -4 0x201C8540 0x00800080
	Drive Strength	level0	0x201C820C	[8,13]	1	io -4 0x201C820C 0x3F000100
		level1	0x201C820C	[8,13]	3	io -4 0x201C820C 0x3F000300
		level2	0x201C820C	[8,13]	7	io -4 0x201C820C 0x3F000700
		level3	0x201C820C	[8,13]	15	io -4 0x201C820C 0x3F000F00
		level4	0x201C820C	[8,13]	31	io -4 0x201C820C 0x3F001F00
		level5	0x201C820C	[8,13]	63	io -4 0x201C820C 0x3F003F00
	ExtPort	read gpio data in input	0x21800070	[7,7]		io -4 0x21800070
GPIO4B0	IOmux	CAM_CLK1_OUT	0x201C8088	[0,3]	3	io -4 0x201C8088 0x000F0003
		UART5_RTSN_M0	0x201C8088	[0,3]	5	io -4 0x201C8088 0x000F0005
		GPIO4_B0	0x201C8088	[0,3]	0	io -4 0x201C8088 0x000F0000
	Pull	z	0x201C8344	[0,1]	0	io -4 0x201C8344 0x00030000
		up	0x201C8344	[0,1]	1	io -4 0x201C8344 0x00030001
		down	0x201C8344	[0,1]	2	io -4 0x201C8344 0x00030002
	I/O Mode	input	0x21800008	[8,8]	0	io -4 0x21800008 0x01000000
		output	0x21800008	[8,8]	1	io -4 0x21800008 0x01000100
	Output	low	0x21800000	[8,8]	0	io -4 0x21800000 0x01000000
		high	0x21800000	[8,8]	1	io -4 0x21800000 0x01000100
	Input Ctrl	disable	0x201C8444	[0,0]	0	io -4 0x201C8444 0x00010000
		enable	0x201C8444	[0,0]	1	io -4 0x201C8444 0x00010001
	Schmitt	disable	0x201C8544	[0,0]	0	io -4 0x201C8544 0x00010000
		enable	0x201C8544	[0,0]	1	io -4 0x201C8544 0x00010001

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201C8210	[0,5]	1	io -4 0x201C8210 0x003F0001
		level1	0x201C8210	[0,5]	3	io -4 0x201C8210 0x003F0003
		level2	0x201C8210	[0,5]	7	io -4 0x201C8210 0x003F0007
		level3	0x201C8210	[0,5]	15	io -4 0x201C8210 0x003F000F
		level4	0x201C8210	[0,5]	31	io -4 0x201C8210 0x003F001F
		level5	0x201C8210	[0,5]	63	io -4 0x201C8210 0x003F003F
	ExtPort	read gpio data in input	0x21800070	[8,8]		io -4 0x21800070
GPIO4B1	IOmux	CAM_CLK0_OUT	0x201C8088	[4,7]	3	io -4 0x201C8088 0x00F00030
		UART5_CTSN_M0	0x201C8088	[4,7]	5	io -4 0x201C8088 0x00F00050
		GPIO4_B1	0x201C8088	[4,7]	0	io -4 0x201C8088 0x00F00000
	Pull	z	0x201C8344	[2,3]	0	io -4 0x201C8344 0x000C0000
		up	0x201C8344	[2,3]	1	io -4 0x201C8344 0x000C0004
		down	0x201C8344	[2,3]	2	io -4 0x201C8344 0x000C0008
	I/O Mode	input	0x21800008	[9,9]	0	io -4 0x21800008 0x02000000
		output	0x21800008	[9,9]	1	io -4 0x21800008 0x02000200
	Output	low	0x21800000	[9,9]	0	io -4 0x21800000 0x02000000
		high	0x21800000	[9,9]	1	io -4 0x21800000 0x02000200
	Input Ctrl	disable	0x201C8444	[1,1]	0	io -4 0x201C8444 0x00020000
		enable	0x201C8444	[1,1]	1	io -4 0x201C8444 0x00020002
	Schmitt	disable	0x201C8544	[1,1]	0	io -4 0x201C8544 0x00020000
		enable	0x201C8544	[1,1]	1	io -4 0x201C8544 0x00020002
	Drive Strength	level0	0x201C8210	[8,13]	1	io -4 0x201C8210 0x3F000100
		level1	0x201C8210	[8,13]	3	io -4 0x201C8210 0x3F000300
		level2	0x201C8210	[8,13]	7	io -4 0x201C8210 0x3F000700
		level3	0x201C8210	[8,13]	15	io -4 0x201C8210 0x3F000F00
		level4	0x201C8210	[8,13]	31	io -4 0x201C8210 0x3F001F00
		level5	0x201C8210	[8,13]	63	io -4 0x201C8210 0x3F003F00
	ExtPort	read gpio data in input	0x21800070	[9,9]		io -4 0x21800070
GPIO5A0	IOmux	VO_LCDC_D0	0x201D00A0	[0,3]	1	io -4 0x201D00A0 0x000F0001
		ETH_TXD3_M1	0x201D00A0	[0,3]	2	io -4 0x201D00A0 0x000F0002
		VI_CIF_D0_M1	0x201D00A0	[0,3]	3	io -4 0x201D00A0 0x000F0003
		DSMC_CSN1	0x201D00A0	[0,3]	4	io -4 0x201D00A0 0x000F0004
		IR_FPA_SDA0	0x201D00A0	[0,3]	6	io -4 0x201D00A0 0x000F0006
		PWM2_CH4_M0	0x201D00A0	[0,3]	7	io -4 0x201D00A0 0x000F0007
		UART4_RTSN_M1	0x201D00A0	[0,3]	8	io -4 0x201D00A0 0x000F0008
		GPIO5_A0	0x201D00A0	[0,3]	0	io -4 0x201D00A0 0x000F0000
	Pull	z	0x201D0350	[0,1]	0	io -4 0x201D0350 0x00030000
		up	0x201D0350	[0,1]	1	io -4 0x201D0350 0x00030001
		down	0x201D0350	[0,1]	2	io -4 0x201D0350 0x00030002
	I/O Mode	input	0x21900008	[0,0]	0	io -4 0x21900008 0x00010000
		output	0x21900008	[0,0]	1	io -4 0x21900008 0x00010001
	Output	low	0x21900000	[0,0]	0	io -4 0x21900000 0x00010000
		high	0x21900000	[0,0]	1	io -4 0x21900000 0x00010001
	Input Ctrl	disable	0x201D0450	[0,0]	0	io -4 0x201D0450 0x00010000
		enable	0x201D0450	[0,0]	1	io -4 0x201D0450 0x00010001
	Schmitt	disable	0x201D0550	[0,0]	0	io -4 0x201D0550 0x00010000
		enable	0x201D0550	[0,0]	1	io -4 0x201D0550 0x00010001

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D0240	[0,5]	1	io -4 0x201D0240 0x003F0001
		level1	0x201D0240	[0,5]	3	io -4 0x201D0240 0x003F0003
		level2	0x201D0240	[0,5]	7	io -4 0x201D0240 0x003F0007
		level3	0x201D0240	[0,5]	15	io -4 0x201D0240 0x003F000F
		level4	0x201D0240	[0,5]	31	io -4 0x201D0240 0x003F001F
		level5	0x201D0240	[0,5]	63	io -4 0x201D0240 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[0,0]		io -4 0x21900070
GPIO5A1	IOMUX	VO_LCDC_D1	0x201D00A0	[4,7]	1	io -4 0x201D00A0 0x00F00010
		I2C5_SCL_M2	0x201D00A0	[4,7]	2	io -4 0x201D00A0 0x00F00020
		VI_CIF_D1_M1	0x201D00A0	[4,7]	3	io -4 0x201D00A0 0x00F00030
		DSMC_DQS1	0x201D00A0	[4,7]	4	io -4 0x201D00A0 0x00F00040
		SAI2_SDI2_M1	0x201D00A0	[4,7]	5	io -4 0x201D00A0 0x00F00050
		IR_FPA_SDA1	0x201D00A0	[4,7]	6	io -4 0x201D00A0 0x00F00060
		PWM2_CH5_M0	0x201D00A0	[4,7]	7	io -4 0x201D00A0 0x00F00070
		UART4_CTSN_M1	0x201D00A0	[4,7]	8	io -4 0x201D00A0 0x00F00080
		GPIO5_A1	0x201D00A0	[4,7]	0	io -4 0x201D00A0 0x00F00000
	Pull	z	0x201D0350	[2,3]	0	io -4 0x201D0350 0x000C0000
		up	0x201D0350	[2,3]	1	io -4 0x201D0350 0x000C0004
		down	0x201D0350	[2,3]	2	io -4 0x201D0350 0x000C0008
	I/O Mode	input	0x21900008	[1,1]	0	io -4 0x21900008 0x00020000
		output	0x21900008	[1,1]	1	io -4 0x21900008 0x00020002
	Output	low	0x21900000	[1,1]	0	io -4 0x21900000 0x00020000
		high	0x21900000	[1,1]	1	io -4 0x21900000 0x00020002
	Input Ctrl	disable	0x201D0450	[1,1]	0	io -4 0x201D0450 0x00020000
		enable	0x201D0450	[1,1]	1	io -4 0x201D0450 0x00020002
	Schmitt	disable	0x201D0550	[1,1]	0	io -4 0x201D0550 0x00020000
		enable	0x201D0550	[1,1]	1	io -4 0x201D0550 0x00020002
	Drive Strength	level0	0x201D0240	[8,13]	1	io -4 0x201D0240 0x3F000100
		level1	0x201D0240	[8,13]	3	io -4 0x201D0240 0x3F000300
		level2	0x201D0240	[8,13]	7	io -4 0x201D0240 0x3F000700
		level3	0x201D0240	[8,13]	15	io -4 0x201D0240 0x3F000F00
		level4	0x201D0240	[8,13]	31	io -4 0x201D0240 0x3F001F00
		level5	0x201D0240	[8,13]	63	io -4 0x201D0240 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[1,1]		io -4 0x21900070
GPIO5A2	IOMUX	VO_LCDC_D2	0x201D00A0	[8,11]	1	io -4 0x201D00A0 0x0F000100
		ETH_PPSCCLK_M1	0x201D00A0	[8,11]	2	io -4 0x201D00A0 0x0F000200
		VI_CIF_D2_M1	0x201D00A0	[8,11]	3	io -4 0x201D00A0 0x0F000300
		DSMC_D15	0x201D00A0	[8,11]	4	io -4 0x201D00A0 0x0F000400
		SAI2_SDI1_M1	0x201D00A0	[8,11]	5	io -4 0x201D00A0 0x0F000500
		PWM0_CH5_M2	0x201D00A0	[8,11]	7	io -4 0x201D00A0 0x0F000700
		UART4_TX_M1	0x201D00A0	[8,11]	8	io -4 0x201D00A0 0x0F000800
		GPIO5_A2	0x201D00A0	[8,11]	0	io -4 0x201D00A0 0x0F000000
	Pull	z	0x201D0350	[4,5]	0	io -4 0x201D0350 0x00300000
		up	0x201D0350	[4,5]	1	io -4 0x201D0350 0x00300010
		down	0x201D0350	[4,5]	2	io -4 0x201D0350 0x00300020
	I/O Mode	input	0x21900008	[2,2]	0	io -4 0x21900008 0x00040000
		output	0x21900008	[2,2]	1	io -4 0x21900008 0x00040004

Name	Config	Description	Register	Position	Value	IO Command
GPIO5A2	Output	low	0x21900000	[2,2]	0	io -4 0x21900000 0x00040000
		high	0x21900000	[2,2]	1	io -4 0x21900000 0x00040004
	Input Ctrl	disable	0x201D0450	[2,2]	0	io -4 0x201D0450 0x00040000
		enable	0x201D0450	[2,2]	1	io -4 0x201D0450 0x00040004
	Schmitt	disable	0x201D0550	[2,2]	0	io -4 0x201D0550 0x00040000
		enable	0x201D0550	[2,2]	1	io -4 0x201D0550 0x00040004
	Drive Strength	level0	0x201D0244	[0,5]	1	io -4 0x201D0244 0x003F0001
		level1	0x201D0244	[0,5]	3	io -4 0x201D0244 0x003F0003
		level2	0x201D0244	[0,5]	7	io -4 0x201D0244 0x003F0007
		level3	0x201D0244	[0,5]	15	io -4 0x201D0244 0x003F000F
		level4	0x201D0244	[0,5]	31	io -4 0x201D0244 0x003F001F
		level5	0x201D0244	[0,5]	63	io -4 0x201D0244 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[2,2]		io -4 0x21900070
GPIO5A3	IOmux	VO_LCDC_D3	0x201D00A0	[12,15]	1	io -4 0x201D00A0 0xF0001000
		SPI0_CSN0_M2	0x201D00A0	[12,15]	2	io -4 0x201D00A0 0xF0002000
		DSMC_D14	0x201D00A0	[12,15]	4	io -4 0x201D00A0 0xF0004000
		SAI2_MCLK_M1	0x201D00A0	[12,15]	5	io -4 0x201D00A0 0xF0005000
		PWM0_CH4_M2	0x201D00A0	[12,15]	7	io -4 0x201D00A0 0xF0007000
		UART4_RX_M1	0x201D00A0	[12,15]	8	io -4 0x201D00A0 0xF0008000
		GPIO5_A3	0x201D00A0	[12,15]	0	io -4 0x201D00A0 0xF0000000
	Pull	z	0x201D0350	[6,7]	0	io -4 0x201D0350 0x00C00000
		up	0x201D0350	[6,7]	1	io -4 0x201D0350 0x00C00040
		down	0x201D0350	[6,7]	2	io -4 0x201D0350 0x00C00080
	I/O Mode	input	0x21900008	[3,3]	0	io -4 0x21900008 0x00080000
		output	0x21900008	[3,3]	1	io -4 0x21900008 0x00080008
	Output	low	0x21900000	[3,3]	0	io -4 0x21900000 0x00080000
		high	0x21900000	[3,3]	1	io -4 0x21900000 0x00080008
	Input Ctrl	disable	0x201D0450	[3,3]	0	io -4 0x201D0450 0x00080000
		enable	0x201D0450	[3,3]	1	io -4 0x201D0450 0x00080008
	Schmitt	disable	0x201D0550	[3,3]	0	io -4 0x201D0550 0x00080000
		enable	0x201D0550	[3,3]	1	io -4 0x201D0550 0x00080008
	Drive Strength	level0	0x201D0244	[8,13]	1	io -4 0x201D0244 0x3F000100
		level1	0x201D0244	[8,13]	3	io -4 0x201D0244 0x3F000300
		level2	0x201D0244	[8,13]	7	io -4 0x201D0244 0x3F000700
		level3	0x201D0244	[8,13]	15	io -4 0x201D0244 0x3F000F00
		level4	0x201D0244	[8,13]	31	io -4 0x201D0244 0x3F001F00
		level5	0x201D0244	[8,13]	63	io -4 0x201D0244 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[3,3]		io -4 0x21900070
	IOmux	VO_LCDC_D4	0x201D00A4	[0,3]	1	io -4 0x201D00A4 0x000F0001
		SPI0_MOSI_M2	0x201D00A4	[0,3]	2	io -4 0x201D00A4 0x000F0002
		DSMC_D13	0x201D00A4	[0,3]	4	io -4 0x201D00A4 0x000F0004
		SAI2_SDO_M1	0x201D00A4	[0,3]	5	io -4 0x201D00A4 0x000F0005
		PWM0_CH3_M1	0x201D00A4	[0,3]	7	io -4 0x201D00A4 0x000F0007
		UART5_TX_M1	0x201D00A4	[0,3]	8	io -4 0x201D00A4 0x000F0008
		GPIO5_A4	0x201D00A4	[0,3]	0	io -4 0x201D00A4 0x000F0000

Name	Config	Description	Register	Position	Value	IO Command
GPIO5A4	Pull	z	0x201D0350	[8,9]	0	io -4 0x201D0350 0x03000000
		up	0x201D0350	[8,9]	1	io -4 0x201D0350 0x03000100
		down	0x201D0350	[8,9]	2	io -4 0x201D0350 0x03000200
	I/O Mode	input	0x21900008	[4,4]	0	io -4 0x21900008 0x00100000
		output	0x21900008	[4,4]	1	io -4 0x21900008 0x00100010
	Output	low	0x21900000	[4,4]	0	io -4 0x21900000 0x00100000
		high	0x21900000	[4,4]	1	io -4 0x21900000 0x00100010
	Input Ctrl	disable	0x201D0450	[4,4]	0	io -4 0x201D0450 0x00100000
		enable	0x201D0450	[4,4]	1	io -4 0x201D0450 0x00100010
	Schmitt	disable	0x201D0550	[4,4]	0	io -4 0x201D0550 0x00100000
		enable	0x201D0550	[4,4]	1	io -4 0x201D0550 0x00100010
	Drive Strength	level0	0x201D0248	[0,5]	1	io -4 0x201D0248 0x003F0001
		level1	0x201D0248	[0,5]	3	io -4 0x201D0248 0x003F0003
		level2	0x201D0248	[0,5]	7	io -4 0x201D0248 0x003F0007
		level3	0x201D0248	[0,5]	15	io -4 0x201D0248 0x003F000F
		level4	0x201D0248	[0,5]	31	io -4 0x201D0248 0x003F001F
		level5	0x201D0248	[0,5]	63	io -4 0x201D0248 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[4,4]		io -4 0x21900070
GPIO5A5	IOmux	VO_LCDC_D5	0x201D00A4	[4,7]	1	io -4 0x201D00A4 0x00F00010
		SPI0_MISO_M2	0x201D00A4	[4,7]	2	io -4 0x201D00A4 0x00F00020
		DSMC_D12	0x201D00A4	[4,7]	4	io -4 0x201D00A4 0x00F00040
		SAI2_SCLK_M1	0x201D00A4	[4,7]	5	io -4 0x201D00A4 0x00F00050
		PWM0_CH2_M1	0x201D00A4	[4,7]	7	io -4 0x201D00A4 0x00F00070
		UART5_RX_M1	0x201D00A4	[4,7]	8	io -4 0x201D00A4 0x00F00080
		GPIO5_A5	0x201D00A4	[4,7]	0	io -4 0x201D00A4 0x00F00000
	Pull	z	0x201D0350	[10,11]	0	io -4 0x201D0350 0x0C000000
		up	0x201D0350	[10,11]	1	io -4 0x201D0350 0x0C000400
		down	0x201D0350	[10,11]	2	io -4 0x201D0350 0x0C000800
	I/O Mode	input	0x21900008	[5,5]	0	io -4 0x21900008 0x00200000
		output	0x21900008	[5,5]	1	io -4 0x21900008 0x00200020
	Output	low	0x21900000	[5,5]	0	io -4 0x21900000 0x00200000
		high	0x21900000	[5,5]	1	io -4 0x21900000 0x00200020
	Input Ctrl	disable	0x201D0450	[5,5]	0	io -4 0x201D0450 0x00200000
		enable	0x201D0450	[5,5]	1	io -4 0x201D0450 0x00200020
	Schmitt	disable	0x201D0550	[5,5]	0	io -4 0x201D0550 0x00200000
		enable	0x201D0550	[5,5]	1	io -4 0x201D0550 0x00200020
	Drive Strength	level0	0x201D0248	[8,13]	1	io -4 0x201D0248 0x3F000100
		level1	0x201D0248	[8,13]	3	io -4 0x201D0248 0x3F000300
		level2	0x201D0248	[8,13]	7	io -4 0x201D0248 0x3F000700
		level3	0x201D0248	[8,13]	15	io -4 0x201D0248 0x3F000F00
		level4	0x201D0248	[8,13]	31	io -4 0x201D0248 0x3F001F00
		level5	0x201D0248	[8,13]	63	io -4 0x201D0248 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[5,5]		io -4 0x21900070

Name	Config	Description	Register	Position	Value	IO Command
GPIO5A6	IOMUX	VO_LCDC_D6	0x201D00A4	[8,11]	1	io -4 0x201D00A4 0x0F000100
		SPI0_CLK_M2	0x201D00A4	[8,11]	2	io -4 0x201D00A4 0x0F000200
		DSMC_D11	0x201D00A4	[8,11]	4	io -4 0x201D00A4 0x0F000400
		SAI2_SDI0_M1	0x201D00A4	[8,11]	5	io -4 0x201D00A4 0x0F000500
		PWM0_CH1_M1	0x201D00A4	[8,11]	7	io -4 0x201D00A4 0x0F000700
		UART5_RTSN_M1	0x201D00A4	[8,11]	8	io -4 0x201D00A4 0x0F000800
		GPIO5_A6	0x201D00A4	[8,11]	0	io -4 0x201D00A4 0x0F000000
	Pull	z	0x201D0350	[12,13]	0	io -4 0x201D0350 0x30000000
		up	0x201D0350	[12,13]	1	io -4 0x201D0350 0x30001000
		down	0x201D0350	[12,13]	2	io -4 0x201D0350 0x30002000
	I/O Mode	input	0x21900008	[6,6]	0	io -4 0x21900008 0x00400000
		output	0x21900008	[6,6]	1	io -4 0x21900008 0x00400040
	Output	low	0x21900000	[6,6]	0	io -4 0x21900000 0x00400000
		high	0x21900000	[6,6]	1	io -4 0x21900000 0x00400040
	Input Ctrl	disable	0x201D0450	[6,6]	0	io -4 0x201D0450 0x00400000
		enable	0x201D0450	[6,6]	1	io -4 0x201D0450 0x00400040
	Schmitt	disable	0x201D0550	[6,6]	0	io -4 0x201D0550 0x00400000
		enable	0x201D0550	[6,6]	1	io -4 0x201D0550 0x00400040
	Drive Strength	level0	0x201D024C	[0,5]	1	io -4 0x201D024C 0x003F0001
		level1	0x201D024C	[0,5]	3	io -4 0x201D024C 0x003F0003
		level2	0x201D024C	[0,5]	7	io -4 0x201D024C 0x003F0007
		level3	0x201D024C	[0,5]	15	io -4 0x201D024C 0x003F000F
		level4	0x201D024C	[0,5]	31	io -4 0x201D024C 0x003F001F
		level5	0x201D024C	[0,5]	63	io -4 0x201D024C 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[6,6]		io -4 0x21900070
GPIO5A7	IOMUX	VO_LCDC_D7	0x201D00A4	[12,15]	1	io -4 0x201D00A4 0xF0001000
		SPI0_CSN1_M2	0x201D00A4	[12,15]	2	io -4 0x201D00A4 0xF0002000
		VI_CIF_D3_M1	0x201D00A4	[12,15]	3	io -4 0x201D00A4 0xF0003000
		DSMC_D10	0x201D00A4	[12,15]	4	io -4 0x201D00A4 0xF0004000
		SAI2_LRCK_M1	0x201D00A4	[12,15]	5	io -4 0x201D00A4 0xF0005000
		I2C5_SDA_M2	0x201D00A4	[12,15]	6	io -4 0x201D00A4 0xF0006000
		PWM0_CH0_M1	0x201D00A4	[12,15]	7	io -4 0x201D00A4 0xF0007000
		UART5_CTSN_M1	0x201D00A4	[12,15]	8	io -4 0x201D00A4 0xF0008000
		GPIO5_A7	0x201D00A4	[12,15]	0	io -4 0x201D00A4 0xF0000000
	Pull	z	0x201D0350	[14,15]	0	io -4 0x201D0350 0xC0000000
		up	0x201D0350	[14,15]	1	io -4 0x201D0350 0xC0004000
		down	0x201D0350	[14,15]	2	io -4 0x201D0350 0xC0008000
	I/O Mode	input	0x21900008	[7,7]	0	io -4 0x21900008 0x00800000
		output	0x21900008	[7,7]	1	io -4 0x21900008 0x00800080
	Output	low	0x21900000	[7,7]	0	io -4 0x21900000 0x00800000
		high	0x21900000	[7,7]	1	io -4 0x21900000 0x00800080
	Input Ctrl	disable	0x201D0450	[7,7]	0	io -4 0x201D0450 0x00800000
		enable	0x201D0450	[7,7]	1	io -4 0x201D0450 0x00800080
	Schmitt	disable	0x201D0550	[7,7]	0	io -4 0x201D0550 0x00800000
		enable	0x201D0550	[7,7]	1	io -4 0x201D0550 0x00800080

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D024C	[8,13]	1	io -4 0x201D024C 0x3F000100
		level1	0x201D024C	[8,13]	3	io -4 0x201D024C 0x3F000300
		level2	0x201D024C	[8,13]	7	io -4 0x201D024C 0x3F000700
		level3	0x201D024C	[8,13]	15	io -4 0x201D024C 0x3F000F00
		level4	0x201D024C	[8,13]	31	io -4 0x201D024C 0x3F001F00
		level5	0x201D024C	[8,13]	63	io -4 0x201D024C 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[7,7]		io -4 0x21900070
GPIO5B0	IOmux	VO_LCDC_D8	0x201D00A8	[0,3]	1	io -4 0x201D00A8 0x000F0001
		ETH_RXCTL_M1	0x201D00A8	[0,3]	2	io -4 0x201D00A8 0x000F0002
		VI_CIF_D4_M1	0x201D00A8	[0,3]	3	io -4 0x201D00A8 0x000F0003
		DSMC_D9	0x201D00A8	[0,3]	4	io -4 0x201D00A8 0x000F0004
		IR_FPA_SDA2	0x201D00A8	[0,3]	6	io -4 0x201D00A8 0x000F0006
		UART6_TX_M0	0x201D00A8	[0,3]	8	io -4 0x201D00A8 0x000F0008
		GPIO5_B0	0x201D00A8	[0,3]	0	io -4 0x201D00A8 0x000F0000
	Pull	z	0x201D0354	[0,1]	0	io -4 0x201D0354 0x00030000
		up	0x201D0354	[0,1]	1	io -4 0x201D0354 0x00030001
		down	0x201D0354	[0,1]	2	io -4 0x201D0354 0x00030002
	I/O Mode	input	0x21900008	[8,8]	0	io -4 0x21900008 0x01000000
		output	0x21900008	[8,8]	1	io -4 0x21900008 0x01000100
	Output	low	0x21900000	[8,8]	0	io -4 0x21900000 0x01000000
		high	0x21900000	[8,8]	1	io -4 0x21900000 0x01000100
	Input Ctrl	disable	0x201D0454	[0,0]	0	io -4 0x201D0454 0x00010000
		enable	0x201D0454	[0,0]	1	io -4 0x201D0454 0x00010001
	Schmitt	disable	0x201D0554	[0,0]	0	io -4 0x201D0554 0x00010000
		enable	0x201D0554	[0,0]	1	io -4 0x201D0554 0x00010001
	Drive Strength	level0	0x201D0250	[0,5]	1	io -4 0x201D0250 0x003F0001
		level1	0x201D0250	[0,5]	3	io -4 0x201D0250 0x003F0003
		level2	0x201D0250	[0,5]	7	io -4 0x201D0250 0x003F0007
		level3	0x201D0250	[0,5]	15	io -4 0x201D0250 0x003F000F
		level4	0x201D0250	[0,5]	31	io -4 0x201D0250 0x003F001F
		level5	0x201D0250	[0,5]	63	io -4 0x201D0250 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[8,8]		io -4 0x21900070
GPIO5B1	IOmux	VO_LCDC_D9	0x201D00A8	[4,7]	1	io -4 0x201D00A8 0x00F00010
		ETH_RXD0_M1	0x201D00A8	[4,7]	2	io -4 0x201D00A8 0x00F00020
		VI_CIF_D5_M1	0x201D00A8	[4,7]	3	io -4 0x201D00A8 0x00F00030
		DSMC_D8	0x201D00A8	[4,7]	4	io -4 0x201D00A8 0x00F00040
		IR_FPA_SDA3	0x201D00A8	[4,7]	6	io -4 0x201D00A8 0x00F00060
		UART6_RX_M0	0x201D00A8	[4,7]	8	io -4 0x201D00A8 0x00F00080
		GPIO5_B1	0x201D00A8	[4,7]	0	io -4 0x201D00A8 0x00F00000
	Pull	z	0x201D0354	[2,3]	0	io -4 0x201D0354 0x000C0000
		up	0x201D0354	[2,3]	1	io -4 0x201D0354 0x000C0004
		down	0x201D0354	[2,3]	2	io -4 0x201D0354 0x000C0008
	I/O Mode	input	0x21900008	[9,9]	0	io -4 0x21900008 0x02000000
		output	0x21900008	[9,9]	1	io -4 0x21900008 0x02000200
	Output	low	0x21900000	[9,9]	0	io -4 0x21900000 0x02000000
		high	0x21900000	[9,9]	1	io -4 0x21900000 0x02000200

Name	Config	Description	Register	Position	Value	IO Command
	Input Ctrl	disable	0x201D0454	[1,1]	0	io -4 0x201D0454 0x00020000
		enable	0x201D0454	[1,1]	1	io -4 0x201D0454 0x00020002
	Schmitt	disable	0x201D0554	[1,1]	0	io -4 0x201D0554 0x00020000
		enable	0x201D0554	[1,1]	1	io -4 0x201D0554 0x00020002
	Drive Strength	level0	0x201D0250	[8,13]	1	io -4 0x201D0250 0x3F000100
		level1	0x201D0250	[8,13]	3	io -4 0x201D0250 0x3F000300
		level2	0x201D0250	[8,13]	7	io -4 0x201D0250 0x3F000700
		level3	0x201D0250	[8,13]	15	io -4 0x201D0250 0x3F000F00
		level4	0x201D0250	[8,13]	31	io -4 0x201D0250 0x3F001F00
		level5	0x201D0250	[8,13]	63	io -4 0x201D0250 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[9,9]		io -4 0x21900070
GPIO5B2	IOmux	VO_LCDC_D10	0x201D00A8	[8,11]	1	io -4 0x201D00A8 0x0F000100
		ETH_RXD1_M1	0x201D00A8	[8,11]	2	io -4 0x201D00A8 0x0F000200
		VI_CIF_D6_M1	0x201D00A8	[8,11]	3	io -4 0x201D00A8 0x0F000300
		DSMC_RESETN	0x201D00A8	[8,11]	4	io -4 0x201D00A8 0x0F000400
		DSMC_INT1	0x201D00A8	[8,11]	5	io -4 0x201D00A8 0x0F000500
		PWM2_CH0_M1	0x201D00A8	[8,11]	7	io -4 0x201D00A8 0x0F000700
		UART6_RTSN_M0	0x201D00A8	[8,11]	8	io -4 0x201D00A8 0x0F000800
		GPIO5_B2	0x201D00A8	[8,11]	0	io -4 0x201D00A8 0x0F000000
	Pull	z	0x201D0354	[4,5]	0	io -4 0x201D0354 0x00300000
		up	0x201D0354	[4,5]	1	io -4 0x201D0354 0x00300010
		down	0x201D0354	[4,5]	2	io -4 0x201D0354 0x00300020
	I/O Mode	input	0x21900008	[10,10]	0	io -4 0x21900008 0x04000000
		output	0x21900008	[10,10]	1	io -4 0x21900008 0x04000400
	Output	low	0x21900000	[10,10]	0	io -4 0x21900000 0x04000000
		high	0x21900000	[10,10]	1	io -4 0x21900000 0x04000400
	Input Ctrl	disable	0x201D0454	[2,2]	0	io -4 0x201D0454 0x00040000
		enable	0x201D0454	[2,2]	1	io -4 0x201D0454 0x00040004
	Schmitt	disable	0x201D0554	[2,2]	0	io -4 0x201D0554 0x00040000
		enable	0x201D0554	[2,2]	1	io -4 0x201D0554 0x00040004
	Drive Strength	level0	0x201D0254	[0,5]	1	io -4 0x201D0254 0x003F0001
		level1	0x201D0254	[0,5]	3	io -4 0x201D0254 0x003F0003
		level2	0x201D0254	[0,5]	7	io -4 0x201D0254 0x003F0007
		level3	0x201D0254	[0,5]	15	io -4 0x201D0254 0x003F000F
		level4	0x201D0254	[0,5]	31	io -4 0x201D0254 0x003F001F
		level5	0x201D0254	[0,5]	63	io -4 0x201D0254 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[10,10]		io -4 0x21900070

Name	Config	Description	Register	Position	Value	IO Command
GPIO5B3	IOMUX	VO_LCDC_D11	0x201D00A8	[12,15]	1	io -4 0x201D00A8 0xF0001000
		ETH_MCLK_M1	0x201D00A8	[12,15]	2	io -4 0x201D00A8 0xF0002000
		VI_CIF_D7_M1	0x201D00A8	[12,15]	3	io -4 0x201D00A8 0xF0003000
		DSMC_RDYN	0x201D00A8	[12,15]	4	io -4 0x201D00A8 0xF0004000
		PWM2_CH1_M1	0x201D00A8	[12,15]	7	io -4 0x201D00A8 0xF0007000
		UART6_CTSN_M0	0x201D00A8	[12,15]	8	io -4 0x201D00A8 0xF0008000
		GPIO5_B3	0x201D00A8	[12,15]	0	io -4 0x201D00A8 0xF0000000
	Pull	z	0x201D0354	[6,7]	0	io -4 0x201D0354 0x00C00000
		up	0x201D0354	[6,7]	1	io -4 0x201D0354 0x00C00040
		down	0x201D0354	[6,7]	2	io -4 0x201D0354 0x00C00080
	I/O Mode	input	0x21900008	[11,11]	0	io -4 0x21900008 0x08000000
		output	0x21900008	[11,11]	1	io -4 0x21900008 0x08000800
	Output	low	0x21900000	[11,11]	0	io -4 0x21900000 0x08000000
		high	0x21900000	[11,11]	1	io -4 0x21900000 0x08000800
	Input Ctrl	disable	0x201D0454	[3,3]	0	io -4 0x201D0454 0x00080000
		enable	0x201D0454	[3,3]	1	io -4 0x201D0454 0x00080008
	Schmitt	disable	0x201D0554	[3,3]	0	io -4 0x201D0554 0x00080000
		enable	0x201D0554	[3,3]	1	io -4 0x201D0554 0x00080008
	Drive Strength	level0	0x201D0254	[8,13]	1	io -4 0x201D0254 0x3F000100
		level1	0x201D0254	[8,13]	3	io -4 0x201D0254 0x3F000300
		level2	0x201D0254	[8,13]	7	io -4 0x201D0254 0x3F000700
		level3	0x201D0254	[8,13]	15	io -4 0x201D0254 0x3F000F00
		level4	0x201D0254	[8,13]	31	io -4 0x201D0254 0x3F001F00
		level5	0x201D0254	[8,13]	63	io -4 0x201D0254 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[11,11]		io -4 0x21900070
GPIO5B4	IOMUX	VO_LCDC_D12	0x201D00AC	[0,3]	1	io -4 0x201D00AC 0x000F0001
		VI_CIF_D8_M1	0x201D00AC	[0,3]	3	io -4 0x201D00AC 0x000F0003
		DSMC_CSN0	0x201D00AC	[0,3]	4	io -4 0x201D00AC 0x000F0004
		UART7_TX_M0	0x201D00AC	[0,3]	8	io -4 0x201D00AC 0x000F0008
		GPIO5_B4	0x201D00AC	[0,3]	0	io -4 0x201D00AC 0x000F0000
	Pull	z	0x201D0354	[8,9]	0	io -4 0x201D0354 0x03000000
		up	0x201D0354	[8,9]	1	io -4 0x201D0354 0x03000100
		down	0x201D0354	[8,9]	2	io -4 0x201D0354 0x03000200
	I/O Mode	input	0x21900008	[12,12]	0	io -4 0x21900008 0x10000000
		output	0x21900008	[12,12]	1	io -4 0x21900008 0x10001000
	Output	low	0x21900000	[12,12]	0	io -4 0x21900000 0x10000000
		high	0x21900000	[12,12]	1	io -4 0x21900000 0x10001000
	Input Ctrl	disable	0x201D0454	[4,4]	0	io -4 0x201D0454 0x00100000
		enable	0x201D0454	[4,4]	1	io -4 0x201D0454 0x00100010
	Schmitt	disable	0x201D0554	[4,4]	0	io -4 0x201D0554 0x00100000
		enable	0x201D0554	[4,4]	1	io -4 0x201D0554 0x00100010
	Drive Strength	level0	0x201D0258	[0,5]	1	io -4 0x201D0258 0x003F0001
		level1	0x201D0258	[0,5]	3	io -4 0x201D0258 0x003F0003
		level2	0x201D0258	[0,5]	7	io -4 0x201D0258 0x003F0007
		level3	0x201D0258	[0,5]	15	io -4 0x201D0258 0x003F000F
		level4	0x201D0258	[0,5]	31	io -4 0x201D0258 0x003F001F
		level5	0x201D0258	[0,5]	63	io -4 0x201D0258 0x003F003F

Name	Config	Description	Register	Position	Value	IO Command
	ExtPort	read gpio data in input	0x21900070	[12,12]		io -4 0x21900070
GPIO5B5	IOmux	VO_LCDC_D13	0x201D00AC	[4,7]	1	io -4 0x201D00AC 0x00F00010
		ETH_MDIO_M1	0x201D00AC	[4,7]	2	io -4 0x201D00AC 0x00F00020
		VI_CIF_D9_M1	0x201D00AC	[4,7]	3	io -4 0x201D00AC 0x00F00030
		DSMC_DQS0	0x201D00AC	[4,7]	4	io -4 0x201D00AC 0x00F00040
		UART7_RX_M0	0x201D00AC	[4,7]	8	io -4 0x201D00AC 0x00F00080
		GPIO5_B5	0x201D00AC	[4,7]	0	io -4 0x201D00AC 0x00F00000
	Pull	z	0x201D0354	[10,11]	0	io -4 0x201D0354 0x0C000000
		up	0x201D0354	[10,11]	1	io -4 0x201D0354 0x0C000400
		down	0x201D0354	[10,11]	2	io -4 0x201D0354 0x0C000800
	I/O Mode	input	0x21900008	[13,13]	0	io -4 0x21900008 0x20000000
		output	0x21900008	[13,13]	1	io -4 0x21900008 0x20002000
	Output	low	0x21900000	[13,13]	0	io -4 0x21900000 0x20000000
		high	0x21900000	[13,13]	1	io -4 0x21900000 0x20002000
	Input Ctrl	disable	0x201D0454	[5,5]	0	io -4 0x201D0454 0x00200000
		enable	0x201D0454	[5,5]	1	io -4 0x201D0454 0x00200020
	Schmitt	disable	0x201D0554	[5,5]	0	io -4 0x201D0554 0x00200000
		enable	0x201D0554	[5,5]	1	io -4 0x201D0554 0x00200020
	Drive Strength	level0	0x201D0258	[8,13]	1	io -4 0x201D0258 0x3F000100
		level1	0x201D0258	[8,13]	3	io -4 0x201D0258 0x3F000300
		level2	0x201D0258	[8,13]	7	io -4 0x201D0258 0x3F000700
		level3	0x201D0258	[8,13]	15	io -4 0x201D0258 0x3F000F00
		level4	0x201D0258	[8,13]	31	io -4 0x201D0258 0x3F001F00
		level5	0x201D0258	[8,13]	63	io -4 0x201D0258 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[13,13]		io -4 0x21900070
GPIO5B6	IOmux	VO_LCDC_D14	0x201D00AC	[8,11]	1	io -4 0x201D00AC 0x0F000100
		ETH_MDC_M1	0x201D00AC	[8,11]	2	io -4 0x201D00AC 0x0F000200
		VI_CIF_D10_M1	0x201D00AC	[8,11]	3	io -4 0x201D00AC 0x0F000300
		DSMC_CLKN	0x201D00AC	[8,11]	4	io -4 0x201D00AC 0x0F000400
		DSMC_INT0	0x201D00AC	[8,11]	5	io -4 0x201D00AC 0x0F000500
		PWM2_CH2_M1	0x201D00AC	[8,11]	7	io -4 0x201D00AC 0x0F000700
		UART7_RTSN_M0	0x201D00AC	[8,11]	8	io -4 0x201D00AC 0x0F000800
		GPIO5_B6	0x201D00AC	[8,11]	0	io -4 0x201D00AC 0x0F000000
	Pull	z	0x201D0354	[12,13]	0	io -4 0x201D0354 0x30000000
		up	0x201D0354	[12,13]	1	io -4 0x201D0354 0x30001000
		down	0x201D0354	[12,13]	2	io -4 0x201D0354 0x30002000
	I/O Mode	input	0x21900008	[14,14]	0	io -4 0x21900008 0x40000000
		output	0x21900008	[14,14]	1	io -4 0x21900008 0x40004000
	Output	low	0x21900000	[14,14]	0	io -4 0x21900000 0x40000000
		high	0x21900000	[14,14]	1	io -4 0x21900000 0x40004000
	Input Ctrl	disable	0x201D0454	[6,6]	0	io -4 0x201D0454 0x00400000
		enable	0x201D0454	[6,6]	1	io -4 0x201D0454 0x00400040
	Schmitt	disable	0x201D0554	[6,6]	0	io -4 0x201D0554 0x00400000
		enable	0x201D0554	[6,6]	1	io -4 0x201D0554 0x00400040

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D025C	[0,5]	1	io -4 0x201D025C 0x003F0001
		level1	0x201D025C	[0,5]	3	io -4 0x201D025C 0x003F0003
		level2	0x201D025C	[0,5]	7	io -4 0x201D025C 0x003F0007
		level3	0x201D025C	[0,5]	15	io -4 0x201D025C 0x003F000F
		level4	0x201D025C	[0,5]	31	io -4 0x201D025C 0x003F001F
		level5	0x201D025C	[0,5]	63	io -4 0x201D025C 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[14,14]		io -4 0x21900070
GPIO5B7	IOmux	VO_LCDC_D15	0x201D00AC	[12,15]	1	io -4 0x201D00AC 0xF0001000
		ETH_TXD0_M1	0x201D00AC	[12,15]	2	io -4 0x201D00AC 0xF0002000
		VI_CIF_D11_M1	0x201D00AC	[12,15]	3	io -4 0x201D00AC 0xF0003000
		DSMC_CLKP	0x201D00AC	[12,15]	4	io -4 0x201D00AC 0xF0004000
		PWM2_CH3_M1	0x201D00AC	[12,15]	7	io -4 0x201D00AC 0xF0007000
		UART7_CTSN_M0	0x201D00AC	[12,15]	8	io -4 0x201D00AC 0xF0008000
		GPIO5_B7	0x201D00AC	[12,15]	0	io -4 0x201D00AC 0xF0000000
	Pull	z	0x201D0354	[14,15]	0	io -4 0x201D0354 0xC0000000
		up	0x201D0354	[14,15]	1	io -4 0x201D0354 0xC0004000
		down	0x201D0354	[14,15]	2	io -4 0x201D0354 0xC0008000
	I/O Mode	input	0x21900008	[15,15]	0	io -4 0x21900008 0x80000000
		output	0x21900008	[15,15]	1	io -4 0x21900008 0x80008000
	Output	low	0x21900000	[15,15]	0	io -4 0x21900000 0x80000000
		high	0x21900000	[15,15]	1	io -4 0x21900000 0x80008000
	Input Ctrl	disable	0x201D0454	[7,7]	0	io -4 0x201D0454 0x00800000
		enable	0x201D0454	[7,7]	1	io -4 0x201D0454 0x00800080
	Schmitt	disable	0x201D0554	[7,7]	0	io -4 0x201D0554 0x00800000
		enable	0x201D0554	[7,7]	1	io -4 0x201D0554 0x00800080
	Drive Strength	level0	0x201D025C	[8,13]	1	io -4 0x201D025C 0x3F000100
		level1	0x201D025C	[8,13]	3	io -4 0x201D025C 0x3F000300
		level2	0x201D025C	[8,13]	7	io -4 0x201D025C 0x3F000700
		level3	0x201D025C	[8,13]	15	io -4 0x201D025C 0x3F000F00
		level4	0x201D025C	[8,13]	31	io -4 0x201D025C 0x3F001F00
		level5	0x201D025C	[8,13]	63	io -4 0x201D025C 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[15,15]		io -4 0x21900070
GPIO5C0	IOmux	VO_LCDC_D16	0x201D00B0	[0,3]	1	io -4 0x201D00B0 0x000F0001
		ETH_TXD1_M1	0x201D00B0	[0,3]	2	io -4 0x201D00B0 0x000F0002
		VI_CIF_D12_M1	0x201D00B0	[0,3]	3	io -4 0x201D00B0 0x000F0003
		DSMC_D7	0x201D00B0	[0,3]	4	io -4 0x201D00B0 0x000F0004
		IR_FPA_SDA4	0x201D00B0	[0,3]	6	io -4 0x201D00B0 0x000F0006
		PWM3_CH0_M1	0x201D00B0	[0,3]	7	io -4 0x201D00B0 0x000F0007
		GPIO5_C0	0x201D00B0	[0,3]	0	io -4 0x201D00B0 0x000F0000
	Pull	z	0x201D0358	[0,1]	0	io -4 0x201D0358 0x00030000
		up	0x201D0358	[0,1]	1	io -4 0x201D0358 0x00030001
		down	0x201D0358	[0,1]	2	io -4 0x201D0358 0x00030002
	I/O Mode	input	0x2190000C	[0,0]	0	io -4 0x2190000C 0x00010000
		output	0x2190000C	[0,0]	1	io -4 0x2190000C 0x00010001
	Output	low	0x21900004	[0,0]	0	io -4 0x21900004 0x00010000
		high	0x21900004	[0,0]	1	io -4 0x21900004 0x00010001

Name	Config	Description	Register	Position	Value	IO Command
	Input Ctrl	disable	0x201D0458	[0,0]	0	io -4 0x201D0458 0x00010000
		enable	0x201D0458	[0,0]	1	io -4 0x201D0458 0x00010001
	Schmitt	disable	0x201D0558	[0,0]	0	io -4 0x201D0558 0x00010000
		enable	0x201D0558	[0,0]	1	io -4 0x201D0558 0x00010001
	Drive Strength	level0	0x201D0260	[0,5]	1	io -4 0x201D0260 0x003F0001
		level1	0x201D0260	[0,5]	3	io -4 0x201D0260 0x003F0003
		level2	0x201D0260	[0,5]	7	io -4 0x201D0260 0x003F0007
		level3	0x201D0260	[0,5]	15	io -4 0x201D0260 0x003F000F
		level4	0x201D0260	[0,5]	31	io -4 0x201D0260 0x003F001F
		level5	0x201D0260	[0,5]	63	io -4 0x201D0260 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[16,16]		io -4 0x21900070
GPIO5C1	IOmux	VO_LCDC_D17	0x201D00B0	[4,7]	1	io -4 0x201D00B0 0x00F00010
		ETH_CLK_25M_OUT_M1	0x201D00B0	[4,7]	2	io -4 0x201D00B0 0x00F00020
		VI_CIF_D13_M1	0x201D00B0	[4,7]	3	io -4 0x201D00B0 0x00F00030
		DSMC_D6	0x201D00B0	[4,7]	4	io -4 0x201D00B0 0x00F00040
		IR_FPA_SDA5	0x201D00B0	[4,7]	6	io -4 0x201D00B0 0x00F00060
		PWM3_CH1_M1	0x201D00B0	[4,7]	7	io -4 0x201D00B0 0x00F00070
		GPIO5_C1	0x201D00B0	[4,7]	0	io -4 0x201D00B0 0x00F00000
	Pull	z	0x201D0358	[2,3]	0	io -4 0x201D0358 0x000C0000
		up	0x201D0358	[2,3]	1	io -4 0x201D0358 0x000C0004
		down	0x201D0358	[2,3]	2	io -4 0x201D0358 0x000C0008
	I/O Mode	input	0x2190000C	[1,1]	0	io -4 0x2190000C 0x00020000
		output	0x2190000C	[1,1]	1	io -4 0x2190000C 0x00020002
	Output	low	0x21900004	[1,1]	0	io -4 0x21900004 0x00020000
		high	0x21900004	[1,1]	1	io -4 0x21900004 0x00020002
	Input Ctrl	disable	0x201D0458	[1,1]	0	io -4 0x201D0458 0x00020000
		enable	0x201D0458	[1,1]	1	io -4 0x201D0458 0x00020002
	Schmitt	disable	0x201D0558	[1,1]	0	io -4 0x201D0558 0x00020000
		enable	0x201D0558	[1,1]	1	io -4 0x201D0558 0x00020002
	Drive Strength	level0	0x201D0260	[8,13]	1	io -4 0x201D0260 0x3F000100
		level1	0x201D0260	[8,13]	3	io -4 0x201D0260 0x3F000300
		level2	0x201D0260	[8,13]	7	io -4 0x201D0260 0x3F000700
		level3	0x201D0260	[8,13]	15	io -4 0x201D0260 0x3F000F00
		level4	0x201D0260	[8,13]	31	io -4 0x201D0260 0x3F001F00
		level5	0x201D0260	[8,13]	63	io -4 0x201D0260 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[17,17]		io -4 0x21900070
	IOmux	VO_LCDC_D18	0x201D00B0	[8,11]	1	io -4 0x201D00B0 0x0F000100
		ETH_TXCTL_M1	0x201D00B0	[8,11]	2	io -4 0x201D00B0 0x0F000200
		VI_CIF_D14_M1	0x201D00B0	[8,11]	3	io -4 0x201D00B0 0x0F000300
		DSMC_D5	0x201D00B0	[8,11]	4	io -4 0x201D00B0 0x0F000400
		IR_FPA_SDA6	0x201D00B0	[8,11]	6	io -4 0x201D00B0 0x0F000600
		PWM3_CH2_M1	0x201D00B0	[8,11]	7	io -4 0x201D00B0 0x0F000700
		GPIO5_C2	0x201D00B0	[8,11]	0	io -4 0x201D00B0 0x0F000000
	Pull	z	0x201D0358	[4,5]	0	io -4 0x201D0358 0x00300000
		up	0x201D0358	[4,5]	1	io -4 0x201D0358 0x00300010
		down	0x201D0358	[4,5]	2	io -4 0x201D0358 0x00300020

Name	Config	Description	Register	Position	Value	IO Command
GPIO5C2	I/O Mode	input	0x2190000C	[2,2]	0	io -4 0x2190000C 0x00040000
		output	0x2190000C	[2,2]	1	io -4 0x2190000C 0x00040004
	Output	low	0x21900004	[2,2]	0	io -4 0x21900004 0x00040000
		high	0x21900004	[2,2]	1	io -4 0x21900004 0x00040004
	Input Ctrl	disable	0x201D0458	[2,2]	0	io -4 0x201D0458 0x00040000
		enable	0x201D0458	[2,2]	1	io -4 0x201D0458 0x00040004
	Schmitt	disable	0x201D0558	[2,2]	0	io -4 0x201D0558 0x00040000
		enable	0x201D0558	[2,2]	1	io -4 0x201D0558 0x00040004
	Drive Strength	level0	0x201D0264	[0,5]	1	io -4 0x201D0264 0x003F0001
		level1	0x201D0264	[0,5]	3	io -4 0x201D0264 0x003F0003
		level2	0x201D0264	[0,5]	7	io -4 0x201D0264 0x003F0007
		level3	0x201D0264	[0,5]	15	io -4 0x201D0264 0x003F000F
		level4	0x201D0264	[0,5]	31	io -4 0x201D0264 0x003F001F
		level5	0x201D0264	[0,5]	63	io -4 0x201D0264 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[18,18]		io -4 0x21900070
GPIO5C3	IOmux	VO_LCDC_D19	0x201D00B0	[12,15]	1	io -4 0x201D00B0 0xF0001000
		ETH_RXD2_M1	0x201D00B0	[12,15]	2	io -4 0x201D00B0 0xF0002000
		VI_CIF_D15_M1	0x201D00B0	[12,15]	3	io -4 0x201D00B0 0xF0003000
		DSMC_D4	0x201D00B0	[12,15]	4	io -4 0x201D00B0 0xF0004000
		SAI1_MCLK_M2	0x201D00B0	[12,15]	5	io -4 0x201D00B0 0xF0005000
		PWM3_CH3_M1	0x201D00B0	[12,15]	7	io -4 0x201D00B0 0xF0007000
		GPIO5_C3	0x201D00B0	[12,15]	0	io -4 0x201D00B0 0xF0000000
	Pull	z	0x201D0358	[6,7]	0	io -4 0x201D0358 0x00C00000
		up	0x201D0358	[6,7]	1	io -4 0x201D0358 0x00C00040
		down	0x201D0358	[6,7]	2	io -4 0x201D0358 0x00C00080
	I/O Mode	input	0x2190000C	[3,3]	0	io -4 0x2190000C 0x00080000
		output	0x2190000C	[3,3]	1	io -4 0x2190000C 0x00080008
	Output	low	0x21900004	[3,3]	0	io -4 0x21900004 0x00080000
		high	0x21900004	[3,3]	1	io -4 0x21900004 0x00080008
	Input Ctrl	disable	0x201D0458	[3,3]	0	io -4 0x201D0458 0x00080000
		enable	0x201D0458	[3,3]	1	io -4 0x201D0458 0x00080008
	Schmitt	disable	0x201D0558	[3,3]	0	io -4 0x201D0558 0x00080000
		enable	0x201D0558	[3,3]	1	io -4 0x201D0558 0x00080008
	Drive Strength	level0	0x201D0264	[8,13]	1	io -4 0x201D0264 0x3F000100
		level1	0x201D0264	[8,13]	3	io -4 0x201D0264 0x3F000300
		level2	0x201D0264	[8,13]	7	io -4 0x201D0264 0x3F000700
		level3	0x201D0264	[8,13]	15	io -4 0x201D0264 0x3F000F00
		level4	0x201D0264	[8,13]	31	io -4 0x201D0264 0x3F001F00
		level5	0x201D0264	[8,13]	63	io -4 0x201D0264 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[19,19]		io -4 0x21900070

Name	Config	Description	Register	Position	Value	IO Command
GPIO5C4	IOmux	VO_LCDC_D20	0x201D00B4	[0,3]	1	io -4 0x201D00B4 0x000F0001
		ETH_RXD3_M1	0x201D00B4	[0,3]	2	io -4 0x201D00B4 0x000F0002
		VI_CIF_VSYNC_M1	0x201D00B4	[0,3]	3	io -4 0x201D00B4 0x000F0003
		DSMC_D3	0x201D00B4	[0,3]	4	io -4 0x201D00B4 0x000F0004
		SAI1_SDO_M2	0x201D00B4	[0,3]	5	io -4 0x201D00B4 0x000F0005
		PWM3_CH4_M1	0x201D00B4	[0,3]	7	io -4 0x201D00B4 0x000F0007
		GPIO5_C4	0x201D00B4	[0,3]	0	io -4 0x201D00B4 0x000F0000
	Pull	z	0x201D0358	[8,9]	0	io -4 0x201D0358 0x03000000
		up	0x201D0358	[8,9]	1	io -4 0x201D0358 0x03000100
		down	0x201D0358	[8,9]	2	io -4 0x201D0358 0x03000200
	I/O Mode	input	0x2190000C	[4,4]	0	io -4 0x2190000C 0x00100000
		output	0x2190000C	[4,4]	1	io -4 0x2190000C 0x00100010
	Output	low	0x21900004	[4,4]	0	io -4 0x21900004 0x00100000
		high	0x21900004	[4,4]	1	io -4 0x21900004 0x00100010
	Input Ctrl	disable	0x201D0458	[4,4]	0	io -4 0x201D0458 0x00100000
		enable	0x201D0458	[4,4]	1	io -4 0x201D0458 0x00100010
	Schmitt	disable	0x201D0558	[4,4]	0	io -4 0x201D0558 0x00100000
		enable	0x201D0558	[4,4]	1	io -4 0x201D0558 0x00100010
	Drive Strength	level0	0x201D0268	[0,5]	1	io -4 0x201D0268 0x003F0001
		level1	0x201D0268	[0,5]	3	io -4 0x201D0268 0x003F0003
		level2	0x201D0268	[0,5]	7	io -4 0x201D0268 0x003F0007
		level3	0x201D0268	[0,5]	15	io -4 0x201D0268 0x003F000F
		level4	0x201D0268	[0,5]	31	io -4 0x201D0268 0x003F001F
		level5	0x201D0268	[0,5]	63	io -4 0x201D0268 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[20,20]		io -4 0x21900070
GPIO5C5	IOmux	VO_LCDC_D21	0x201D00B4	[4,7]	1	io -4 0x201D00B4 0x00F00010
		ETH_TXD2_M1	0x201D00B4	[4,7]	2	io -4 0x201D00B4 0x00F00020
		VI_CIF_CLKOUT_M1	0x201D00B4	[4,7]	3	io -4 0x201D00B4 0x00F00030
		DSMC_D2	0x201D00B4	[4,7]	4	io -4 0x201D00B4 0x00F00040
		SAI1_SCLK_M2	0x201D00B4	[4,7]	5	io -4 0x201D00B4 0x00F00050
		PWM3_CH5_M1	0x201D00B4	[4,7]	7	io -4 0x201D00B4 0x00F00070
		GPIO5_C5	0x201D00B4	[4,7]	0	io -4 0x201D00B4 0x00F00000
	Pull	z	0x201D0358	[10,11]	0	io -4 0x201D0358 0x0C000000
		up	0x201D0358	[10,11]	1	io -4 0x201D0358 0x0C000400
		down	0x201D0358	[10,11]	2	io -4 0x201D0358 0x0C000800
	I/O Mode	input	0x2190000C	[5,5]	0	io -4 0x2190000C 0x00200000
		output	0x2190000C	[5,5]	1	io -4 0x2190000C 0x00200020
	Output	low	0x21900004	[5,5]	0	io -4 0x21900004 0x00200000
		high	0x21900004	[5,5]	1	io -4 0x21900004 0x00200020
	Input Ctrl	disable	0x201D0458	[5,5]	0	io -4 0x201D0458 0x00200000
		enable	0x201D0458	[5,5]	1	io -4 0x201D0458 0x00200020
	Schmitt	disable	0x201D0558	[5,5]	0	io -4 0x201D0558 0x00200000
		enable	0x201D0558	[5,5]	1	io -4 0x201D0558 0x00200020

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D0268	[8,13]	1	io -4 0x201D0268 0x3F000100
		level1	0x201D0268	[8,13]	3	io -4 0x201D0268 0x3F000300
		level2	0x201D0268	[8,13]	7	io -4 0x201D0268 0x3F000700
		level3	0x201D0268	[8,13]	15	io -4 0x201D0268 0x3F000F00
		level4	0x201D0268	[8,13]	31	io -4 0x201D0268 0x3F001F00
		level5	0x201D0268	[8,13]	63	io -4 0x201D0268 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[21,21]		io -4 0x21900070
GPIO5C6	IOmux	VO_LCDC_D22	0x201D00B4	[8,11]	1	io -4 0x201D00B4 0x0F000100
		ETH_TXCLK_M1	0x201D00B4	[8,11]	2	io -4 0x201D00B4 0x0F000200
		VI_CIF_CLKIN_M1	0x201D00B4	[8,11]	3	io -4 0x201D00B4 0x0F000300
		DSMC_D1	0x201D00B4	[8,11]	4	io -4 0x201D00B4 0x0F000400
		SAI1_LRCK_M2	0x201D00B4	[8,11]	5	io -4 0x201D00B4 0x0F000500
		PWM3_CH6_M1	0x201D00B4	[8,11]	7	io -4 0x201D00B4 0x0F000700
		GPIO5_C6	0x201D00B4	[8,11]	0	io -4 0x201D00B4 0x0F000000
	Pull	z	0x201D0358	[12,13]	0	io -4 0x201D0358 0x30000000
		up	0x201D0358	[12,13]	1	io -4 0x201D0358 0x30001000
		down	0x201D0358	[12,13]	2	io -4 0x201D0358 0x30002000
	I/O Mode	input	0x2190000C	[6,6]	0	io -4 0x2190000C 0x00400000
		output	0x2190000C	[6,6]	1	io -4 0x2190000C 0x00400040
	Output	low	0x21900004	[6,6]	0	io -4 0x21900004 0x00400000
		high	0x21900004	[6,6]	1	io -4 0x21900004 0x00400040
	Input Ctrl	disable	0x201D0458	[6,6]	0	io -4 0x201D0458 0x00400000
		enable	0x201D0458	[6,6]	1	io -4 0x201D0458 0x00400040
	Schmitt	disable	0x201D0558	[6,6]	0	io -4 0x201D0558 0x00400000
		enable	0x201D0558	[6,6]	1	io -4 0x201D0558 0x00400040
	Drive Strength	level0	0x201D026C	[0,5]	1	io -4 0x201D026C 0x003F0001
		level1	0x201D026C	[0,5]	3	io -4 0x201D026C 0x003F0003
		level2	0x201D026C	[0,5]	7	io -4 0x201D026C 0x003F0007
		level3	0x201D026C	[0,5]	15	io -4 0x201D026C 0x003F000F
		level4	0x201D026C	[0,5]	31	io -4 0x201D026C 0x003F001F
		level5	0x201D026C	[0,5]	63	io -4 0x201D026C 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[22,22]		io -4 0x21900070

Name	Config	Description	Register	Position	Value	IO Command
GPIO5C7	IOmux	VO_LCDC_D23	0x201D00B4	[12,15]	1	io -4 0x201D00B4 0xF0001000
		ETH_RXCLK_M1	0x201D00B4	[12,15]	2	io -4 0x201D00B4 0xF0002000
		VI_CIF_HSYNC_M1	0x201D00B4	[12,15]	3	io -4 0x201D00B4 0xF0003000
		DSMC_D0	0x201D00B4	[12,15]	4	io -4 0x201D00B4 0xF0004000
		SAI1_SDI_M2	0x201D00B4	[12,15]	5	io -4 0x201D00B4 0xF0005000
		PWM3_CH7_M1	0x201D00B4	[12,15]	7	io -4 0x201D00B4 0xF0007000
		GPIO5_C7	0x201D00B4	[12,15]	0	io -4 0x201D00B4 0xF0000000
	Pull	z	0x201D0358	[14,15]	0	io -4 0x201D0358 0xC0000000
		up	0x201D0358	[14,15]	1	io -4 0x201D0358 0xC0004000
		down	0x201D0358	[14,15]	2	io -4 0x201D0358 0xC0008000
	I/O Mode	input	0x2190000C	[7,7]	0	io -4 0x2190000C 0x00800000
		output	0x2190000C	[7,7]	1	io -4 0x2190000C 0x00800080
	Output	low	0x21900004	[7,7]	0	io -4 0x21900004 0x00800000
		high	0x21900004	[7,7]	1	io -4 0x21900004 0x00800080
	Input Ctrl	disable	0x201D0458	[7,7]	0	io -4 0x201D0458 0x00800000
		enable	0x201D0458	[7,7]	1	io -4 0x201D0458 0x00800080
	Schmitt	disable	0x201D0558	[7,7]	0	io -4 0x201D0558 0x00800000
		enable	0x201D0558	[7,7]	1	io -4 0x201D0558 0x00800080
	Drive Strength	level0	0x201D026C	[8,13]	1	io -4 0x201D026C 0x3F000100
		level1	0x201D026C	[8,13]	3	io -4 0x201D026C 0x3F000300
		level2	0x201D026C	[8,13]	7	io -4 0x201D026C 0x3F000700
		level3	0x201D026C	[8,13]	15	io -4 0x201D026C 0x3F000F00
		level4	0x201D026C	[8,13]	31	io -4 0x201D026C 0x3F001F00
		level5	0x201D026C	[8,13]	63	io -4 0x201D026C 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[23,23]		io -4 0x21900070
GPIO5D0	IOmux	VO_LCDC_DEN	0x201D00B8	[0,3]	1	io -4 0x201D00B8 0x000F0001
		SPI1_CSN0_M2	0x201D00B8	[0,3]	2	io -4 0x201D00B8 0x000F0002
		ETH_PTP_REFCLK_M1	0x201D00B8	[0,3]	3	io -4 0x201D00B8 0x000F0003
		DSMC_CSN3	0x201D00B8	[0,3]	4	io -4 0x201D00B8 0x000F0004
		I2C3_SCL_M2	0x201D00B8	[0,3]	6	io -4 0x201D00B8 0x000F0006
		PWM0_CH6_M2	0x201D00B8	[0,3]	7	io -4 0x201D00B8 0x000F0007
		GPIO5_D0	0x201D00B8	[0,3]	0	io -4 0x201D00B8 0x000F0000
	Pull	z	0x201D035C	[0,1]	0	io -4 0x201D035C 0x00030000
		up	0x201D035C	[0,1]	1	io -4 0x201D035C 0x00030001
		down	0x201D035C	[0,1]	2	io -4 0x201D035C 0x00030002
	I/O Mode	input	0x2190000C	[8,8]	0	io -4 0x2190000C 0x01000000
		output	0x2190000C	[8,8]	1	io -4 0x2190000C 0x01000100
	Output	low	0x21900004	[8,8]	0	io -4 0x21900004 0x01000000
		high	0x21900004	[8,8]	1	io -4 0x21900004 0x01000100
	Input Ctrl	disable	0x201D045C	[0,0]	0	io -4 0x201D045C 0x00010000
		enable	0x201D045C	[0,0]	1	io -4 0x201D045C 0x00010001
	Schmitt	disable	0x201D055C	[0,0]	0	io -4 0x201D055C 0x00010000
		enable	0x201D055C	[0,0]	1	io -4 0x201D055C 0x00010001

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D0270	[0,5]	1	io -4 0x201D0270 0x003F0001
		level1	0x201D0270	[0,5]	3	io -4 0x201D0270 0x003F0003
		level2	0x201D0270	[0,5]	7	io -4 0x201D0270 0x003F0007
		level3	0x201D0270	[0,5]	15	io -4 0x201D0270 0x003F000F
		level4	0x201D0270	[0,5]	31	io -4 0x201D0270 0x003F001F
		level5	0x201D0270	[0,5]	63	io -4 0x201D0270 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[24,24]		io -4 0x21900070
GPIO5D1	IOmux	VO_LCDC_HSYNC	0x201D00B8	[4,7]	1	io -4 0x201D00B8 0x00F00010
		SPI1_CLK_M2	0x201D00B8	[4,7]	2	io -4 0x201D00B8 0x00F00020
		ETH_PPSTRIG_M1	0x201D00B8	[4,7]	3	io -4 0x201D00B8 0x00F00030
		DSMC_CSN2	0x201D00B8	[4,7]	4	io -4 0x201D00B8 0x00F00040
		I2C3_SDA_M2	0x201D00B8	[4,7]	6	io -4 0x201D00B8 0x00F00060
		PWM1_CH2_M1	0x201D00B8	[4,7]	7	io -4 0x201D00B8 0x00F00070
		GPIO5_D1	0x201D00B8	[4,7]	0	io -4 0x201D00B8 0x00F00000
	Pull	z	0x201D035C	[2,3]	0	io -4 0x201D035C 0x000C0000
		up	0x201D035C	[2,3]	1	io -4 0x201D035C 0x000C0004
		down	0x201D035C	[2,3]	2	io -4 0x201D035C 0x000C0008
	I/O Mode	input	0x2190000C	[9,9]	0	io -4 0x2190000C 0x02000000
		output	0x2190000C	[9,9]	1	io -4 0x2190000C 0x02000200
	Output	low	0x21900004	[9,9]	0	io -4 0x21900004 0x02000000
		high	0x21900004	[9,9]	1	io -4 0x21900004 0x02000200
	Input Ctrl	disable	0x201D045C	[1,1]	0	io -4 0x201D045C 0x00020000
		enable	0x201D045C	[1,1]	1	io -4 0x201D045C 0x00020002
	Schmitt	disable	0x201D055C	[1,1]	0	io -4 0x201D055C 0x00020000
		enable	0x201D055C	[1,1]	1	io -4 0x201D055C 0x00020002
	Drive Strength	level0	0x201D0270	[8,13]	1	io -4 0x201D0270 0x3F000100
		level1	0x201D0270	[8,13]	3	io -4 0x201D0270 0x3F000300
		level2	0x201D0270	[8,13]	7	io -4 0x201D0270 0x3F000700
		level3	0x201D0270	[8,13]	15	io -4 0x201D0270 0x3F000F00
		level4	0x201D0270	[8,13]	31	io -4 0x201D0270 0x3F001F00
		level5	0x201D0270	[8,13]	63	io -4 0x201D0270 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[25,25]		io -4 0x21900070
GPIO5D2	IOmux	VO_LCDC_VSYNC	0x201D00B8	[8,11]	1	io -4 0x201D00B8 0x0F000100
		SPI1_MOSI_M2	0x201D00B8	[8,11]	2	io -4 0x201D00B8 0x0F000200
		DSMC_INT3	0x201D00B8	[8,11]	4	io -4 0x201D00B8 0x0F000400
		PWM1_CH1_M1	0x201D00B8	[8,11]	7	io -4 0x201D00B8 0x0F000700
		UART3_RTSN_M1	0x201D00B8	[8,11]	8	io -4 0x201D00B8 0x0F000800
		GPIO5_D2	0x201D00B8	[8,11]	0	io -4 0x201D00B8 0x0F000000
	Pull	z	0x201D035C	[4,5]	0	io -4 0x201D035C 0x00300000
		up	0x201D035C	[4,5]	1	io -4 0x201D035C 0x00300010
		down	0x201D035C	[4,5]	2	io -4 0x201D035C 0x00300020
	I/O Mode	input	0x2190000C	[10,10]	0	io -4 0x2190000C 0x04000000
		output	0x2190000C	[10,10]	1	io -4 0x2190000C 0x04000400
	Output	low	0x21900004	[10,10]	0	io -4 0x21900004 0x04000000
		high	0x21900004	[10,10]	1	io -4 0x21900004 0x04000400
	Input Ctrl	disable	0x201D045C	[2,2]	0	io -4 0x201D045C 0x00040000
		enable	0x201D045C	[2,2]	1	io -4 0x201D045C 0x00040004

Name	Config	Description	Register	Position	Value	IO Command
	Schmitt	disable	0x201D055C	[2,2]	0	io -4 0x201D055C 0x00040000
		enable	0x201D055C	[2,2]	1	io -4 0x201D055C 0x00040004
	Drive Strength	level0	0x201D0274	[0,5]	1	io -4 0x201D0274 0x003F0001
		level1	0x201D0274	[0,5]	3	io -4 0x201D0274 0x003F0003
		level2	0x201D0274	[0,5]	7	io -4 0x201D0274 0x003F0007
		level3	0x201D0274	[0,5]	15	io -4 0x201D0274 0x003F000F
		level4	0x201D0274	[0,5]	31	io -4 0x201D0274 0x003F001F
		level5	0x201D0274	[0,5]	63	io -4 0x201D0274 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[26,26]		io -4 0x21900070
GPIO5D3	IOmux	VO_LCDC_CLK	0x201D00B8	[12,15]	1	io -4 0x201D00B8 0xF0001000
		SPI1_MISO_M2	0x201D00B8	[12,15]	2	io -4 0x201D00B8 0xF0002000
		DSMC_INT2	0x201D00B8	[12,15]	4	io -4 0x201D00B8 0xF0004000
		PWM1_CH0_M1	0x201D00B8	[12,15]	7	io -4 0x201D00B8 0xF0007000
		UART3_CTSN_M1	0x201D00B8	[12,15]	8	io -4 0x201D00B8 0xF0008000
		GPIO5_D3	0x201D00B8	[12,15]	0	io -4 0x201D00B8 0xF0000000
	Pull	z	0x201D035C	[6,7]	0	io -4 0x201D035C 0x00C00000
		up	0x201D035C	[6,7]	1	io -4 0x201D035C 0x00C00040
		down	0x201D035C	[6,7]	2	io -4 0x201D035C 0x00C00080
	I/O Mode	input	0x2190000C	[11,11]	0	io -4 0x2190000C 0x08000000
		output	0x2190000C	[11,11]	1	io -4 0x2190000C 0x08000800
	Output	low	0x21900004	[11,11]	0	io -4 0x21900004 0x08000000
		high	0x21900004	[11,11]	1	io -4 0x21900004 0x08000800
	Input Ctrl	disable	0x201D045C	[3,3]	0	io -4 0x201D045C 0x00080000
		enable	0x201D045C	[3,3]	1	io -4 0x201D045C 0x00080008
	Schmitt	disable	0x201D055C	[3,3]	0	io -4 0x201D055C 0x00080000
		enable	0x201D055C	[3,3]	1	io -4 0x201D055C 0x00080008
	Drive Strength	level0	0x201D0274	[8,13]	1	io -4 0x201D0274 0x3F000100
		level1	0x201D0274	[8,13]	3	io -4 0x201D0274 0x3F000300
		level2	0x201D0274	[8,13]	7	io -4 0x201D0274 0x3F000700
		level3	0x201D0274	[8,13]	15	io -4 0x201D0274 0x3F000F00
		level4	0x201D0274	[8,13]	31	io -4 0x201D0274 0x3F001F00
		level5	0x201D0274	[8,13]	63	io -4 0x201D0274 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[27,27]		io -4 0x21900070

Name	Config	Description	Register	Position	Value	IO Command
GPIO5D4	IOmux	FEPHY_LEDLINK_M1	0x201D00BC	[0,3]	1	io -4 0x201D00BC 0x000F0001
		SPI1_CSN1_M2	0x201D00BC	[0,3]	2	io -4 0x201D00BC 0x000F0002
		CAN0_RXD_M0	0x201D00BC	[0,3]	3	io -4 0x201D00BC 0x000F0003
		IR_FPA_FSYNC	0x201D00BC	[0,3]	5	io -4 0x201D00BC 0x000F0005
		I2C2_SCL_M1	0x201D00BC	[0,3]	6	io -4 0x201D00BC 0x000F0006
		PWM0_CH7_M2	0x201D00BC	[0,3]	7	io -4 0x201D00BC 0x000F0007
		UART3_TX_M1	0x201D00BC	[0,3]	8	io -4 0x201D00BC 0x000F0008
		GPIO5_D4	0x201D00BC	[0,3]	0	io -4 0x201D00BC 0x000F0000
	Pull	z	0x201D035C	[8,9]	0	io -4 0x201D035C 0x03000000
		up	0x201D035C	[8,9]	1	io -4 0x201D035C 0x03000100
		down	0x201D035C	[8,9]	2	io -4 0x201D035C 0x03000200
	I/O Mode	input	0x2190000C	[12,12]	0	io -4 0x2190000C 0x10000000
		output	0x2190000C	[12,12]	1	io -4 0x2190000C 0x10001000
	Output	low	0x21900004	[12,12]	0	io -4 0x21900004 0x10000000
		high	0x21900004	[12,12]	1	io -4 0x21900004 0x10001000
	Input Ctrl	disable	0x201D045C	[4,4]	0	io -4 0x201D045C 0x00100000
		enable	0x201D045C	[4,4]	1	io -4 0x201D045C 0x00100010
	Schmitt	disable	0x201D055C	[4,4]	0	io -4 0x201D055C 0x00100000
		enable	0x201D055C	[4,4]	1	io -4 0x201D055C 0x00100010
	Drive Strength	level0	0x201D0278	[0,5]	1	io -4 0x201D0278 0x003F0001
		level1	0x201D0278	[0,5]	3	io -4 0x201D0278 0x003F0003
		level2	0x201D0278	[0,5]	7	io -4 0x201D0278 0x003F0007
		level3	0x201D0278	[0,5]	15	io -4 0x201D0278 0x003F000F
		level4	0x201D0278	[0,5]	31	io -4 0x201D0278 0x003F001F
		level5	0x201D0278	[0,5]	63	io -4 0x201D0278 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[28,28]		io -4 0x21900070
GPIO5D5	IOmux	FEPHY_LEDSPD_M1	0x201D00BC	[4,7]	1	io -4 0x201D00BC 0x00F00010
		CAN0_TXD_M0	0x201D00BC	[4,7]	3	io -4 0x201D00BC 0x00F00030
		IR_FPA_MCLK	0x201D00BC	[4,7]	5	io -4 0x201D00BC 0x00F00050
		I2C2_SDA_M1	0x201D00BC	[4,7]	6	io -4 0x201D00BC 0x00F00060
		PWM1_CH3_M1	0x201D00BC	[4,7]	7	io -4 0x201D00BC 0x00F00070
		UART3_RX_M1	0x201D00BC	[4,7]	8	io -4 0x201D00BC 0x00F00080
		GPIO5_D5	0x201D00BC	[4,7]	0	io -4 0x201D00BC 0x00F00000
	Pull	z	0x201D035C	[10,11]	0	io -4 0x201D035C 0x0C000000
		up	0x201D035C	[10,11]	1	io -4 0x201D035C 0x0C000400
		down	0x201D035C	[10,11]	2	io -4 0x201D035C 0x0C000800
	I/O Mode	input	0x2190000C	[13,13]	0	io -4 0x2190000C 0x20000000
		output	0x2190000C	[13,13]	1	io -4 0x2190000C 0x20002000
	Output	low	0x21900004	[13,13]	0	io -4 0x21900004 0x20000000
		high	0x21900004	[13,13]	1	io -4 0x21900004 0x20002000
	Input Ctrl	disable	0x201D045C	[5,5]	0	io -4 0x201D045C 0x00200000
		enable	0x201D045C	[5,5]	1	io -4 0x201D045C 0x00200020
	Schmitt	disable	0x201D055C	[5,5]	0	io -4 0x201D055C 0x00200000
		enable	0x201D055C	[5,5]	1	io -4 0x201D055C 0x00200020

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D0278	[8,13]	1	io -4 0x201D0278 0x3F000100
		level1	0x201D0278	[8,13]	3	io -4 0x201D0278 0x3F000300
		level2	0x201D0278	[8,13]	7	io -4 0x201D0278 0x3F000700
		level3	0x201D0278	[8,13]	15	io -4 0x201D0278 0x3F000F00
		level4	0x201D0278	[8,13]	31	io -4 0x201D0278 0x3F001F00
		level5	0x201D0278	[8,13]	63	io -4 0x201D0278 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[29,29]		io -4 0x21900070
GPIO5D6	IOmux	UART0_TX_M1	0x201D00BC	[8,11]	1	io -4 0x201D00BC 0x0F000100
		JTAG_TCK_M2	0x201D00BC	[8,11]	2	io -4 0x201D00BC 0x0F000200
		CAN1_RXD_M0	0x201D00BC	[8,11]	3	io -4 0x201D00BC 0x0F000300
		PWM2_CH6_M0	0x201D00BC	[8,11]	7	io -4 0x201D00BC 0x0F000700
		GPIO5_D6	0x201D00BC	[8,11]	0	io -4 0x201D00BC 0x0F000000
	Pull	z	0x201D035C	[12,13]	0	io -4 0x201D035C 0x30000000
		up	0x201D035C	[12,13]	1	io -4 0x201D035C 0x30001000
		down	0x201D035C	[12,13]	2	io -4 0x201D035C 0x30002000
	I/O Mode	input	0x2190000C	[14,14]	0	io -4 0x2190000C 0x40000000
		output	0x2190000C	[14,14]	1	io -4 0x2190000C 0x40004000
	Output	low	0x21900004	[14,14]	0	io -4 0x21900004 0x40000000
		high	0x21900004	[14,14]	1	io -4 0x21900004 0x40004000
	Input Ctrl	disable	0x201D045C	[6,6]	0	io -4 0x201D045C 0x00400000
		enable	0x201D045C	[6,6]	1	io -4 0x201D045C 0x00400040
	Schmitt	disable	0x201D055C	[6,6]	0	io -4 0x201D055C 0x00400000
		enable	0x201D055C	[6,6]	1	io -4 0x201D055C 0x00400040
	Drive Strength	level0	0x201D027C	[0,5]	1	io -4 0x201D027C 0x003F0001
		level1	0x201D027C	[0,5]	3	io -4 0x201D027C 0x003F0003
		level2	0x201D027C	[0,5]	7	io -4 0x201D027C 0x003F0007
		level3	0x201D027C	[0,5]	15	io -4 0x201D027C 0x003F000F
		level4	0x201D027C	[0,5]	31	io -4 0x201D027C 0x003F001F
		level5	0x201D027C	[0,5]	63	io -4 0x201D027C 0x003F003F
	ExtPort	read gpio data in input	0x21900070	[30,30]		io -4 0x21900070
GPIO5D7	IOmux	UART0_RX_M1	0x201D00BC	[12,15]	1	io -4 0x201D00BC 0xF0001000
		JTAG_TMS_M2	0x201D00BC	[12,15]	2	io -4 0x201D00BC 0xF0002000
		CAN1_TXD_M0	0x201D00BC	[12,15]	3	io -4 0x201D00BC 0xF0003000
		PWM2_CH7_M0	0x201D00BC	[12,15]	7	io -4 0x201D00BC 0xF0007000
		GPIO5_D7	0x201D00BC	[12,15]	0	io -4 0x201D00BC 0xF0000000
	Pull	z	0x201D035C	[14,15]	0	io -4 0x201D035C 0xC0000000
		up	0x201D035C	[14,15]	1	io -4 0x201D035C 0xC0004000
		down	0x201D035C	[14,15]	2	io -4 0x201D035C 0xC0008000
	I/O Mode	input	0x2190000C	[15,15]	0	io -4 0x2190000C 0x80000000
		output	0x2190000C	[15,15]	1	io -4 0x2190000C 0x80008000
	Output	low	0x21900004	[15,15]	0	io -4 0x21900004 0x80000000
		high	0x21900004	[15,15]	1	io -4 0x21900004 0x80008000
	Input Ctrl	disable	0x201D045C	[7,7]	0	io -4 0x201D045C 0x00800000
		enable	0x201D045C	[7,7]	1	io -4 0x201D045C 0x00800080
	Schmitt	disable	0x201D055C	[7,7]	0	io -4 0x201D055C 0x00800000
		enable	0x201D055C	[7,7]	1	io -4 0x201D055C 0x00800080

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D027C	[8,13]	1	io -4 0x201D027C 0x3F000100
		level1	0x201D027C	[8,13]	3	io -4 0x201D027C 0x3F000300
		level2	0x201D027C	[8,13]	7	io -4 0x201D027C 0x3F000700
		level3	0x201D027C	[8,13]	15	io -4 0x201D027C 0x3F000F00
		level4	0x201D027C	[8,13]	31	io -4 0x201D027C 0x3F001F00
		level5	0x201D027C	[8,13]	63	io -4 0x201D027C 0x3F003F00
	ExtPort	read gpio data in input	0x21900070	[31,31]		io -4 0x21900070
GPIO6A0	IOmux	VI_CIF_D0_M0	0x201D80C0	[0,3]	1	io -4 0x201D80C0 0x000F0001
		ETH_PPSTRIG_M0	0x201D80C0	[0,3]	2	io -4 0x201D80C0 0x000F0002
		CAN0_RXD_M1	0x201D80C0	[0,3]	3	io -4 0x201D80C0 0x000F0003
		SAI0_SCLK_M1	0x201D80C0	[0,3]	4	io -4 0x201D80C0 0x000F0004
		PWM1_CH0_M2	0x201D80C0	[0,3]	5	io -4 0x201D80C0 0x000F0005
		UART4_TX_M2	0x201D80C0	[0,3]	6	io -4 0x201D80C0 0x000F0006
		I2C3_SCL_M3	0x201D80C0	[0,3]	7	io -4 0x201D80C0 0x000F0007
		GPIO6_A0	0x201D80C0	[0,3]	0	io -4 0x201D80C0 0x000F0000
	Pull	z	0x201D8360	[0,1]	0	io -4 0x201D8360 0x00030000
		up	0x201D8360	[0,1]	1	io -4 0x201D8360 0x00030001
		down	0x201D8360	[0,1]	2	io -4 0x201D8360 0x00030002
	I/O Mode	input	0x21A00008	[0,0]	0	io -4 0x21A00008 0x00010000
		output	0x21A00008	[0,0]	1	io -4 0x21A00008 0x00010001
	Output	low	0x21A00000	[0,0]	0	io -4 0x21A00000 0x00010000
		high	0x21A00000	[0,0]	1	io -4 0x21A00000 0x00010001
	Input Ctrl	disable	0x201D8460	[0,0]	0	io -4 0x201D8460 0x00010000
		enable	0x201D8460	[0,0]	1	io -4 0x201D8460 0x00010001
	Schmitt	disable	0x201D8560	[0,0]	0	io -4 0x201D8560 0x00010000
		enable	0x201D8560	[0,0]	1	io -4 0x201D8560 0x00010001
	Drive Strength	level0	0x201D8280	[0,5]	1	io -4 0x201D8280 0x003F0001
		level1	0x201D8280	[0,5]	3	io -4 0x201D8280 0x003F0003
		level2	0x201D8280	[0,5]	7	io -4 0x201D8280 0x003F0007
		level3	0x201D8280	[0,5]	15	io -4 0x201D8280 0x003F000F
		level4	0x201D8280	[0,5]	31	io -4 0x201D8280 0x003F001F
		level5	0x201D8280	[0,5]	63	io -4 0x201D8280 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[0,0]		io -4 0x21A00070
GPIO6A1	IOmux	VI_CIF_D1_M0	0x201D80C0	[4,7]	1	io -4 0x201D80C0 0x00F00010
		ETH_PTP_REFCLK_M0	0x201D80C0	[4,7]	2	io -4 0x201D80C0 0x00F00020
		CAN0_TXD_M1	0x201D80C0	[4,7]	3	io -4 0x201D80C0 0x00F00030
		SAI0_LRCK_M1	0x201D80C0	[4,7]	4	io -4 0x201D80C0 0x00F00040
		PWM1_CH1_M2	0x201D80C0	[4,7]	5	io -4 0x201D80C0 0x00F00050
		UART4_RX_M2	0x201D80C0	[4,7]	6	io -4 0x201D80C0 0x00F00060
		I2C3_SDA_M3	0x201D80C0	[4,7]	7	io -4 0x201D80C0 0x00F00070
		GPIO6_A1	0x201D80C0	[4,7]	0	io -4 0x201D80C0 0x00F00000
	Pull	z	0x201D8360	[2,3]	0	io -4 0x201D8360 0x000C0000
		up	0x201D8360	[2,3]	1	io -4 0x201D8360 0x000C0004
		down	0x201D8360	[2,3]	2	io -4 0x201D8360 0x000C0008
	I/O Mode	input	0x21A00008	[1,1]	0	io -4 0x21A00008 0x00020000
		output	0x21A00008	[1,1]	1	io -4 0x21A00008 0x00020002

Name	Config	Description	Register	Position	Value	IO Command
GPIOA	Output	low	0x21A00000	[1,1]	0	io -4 0x21A00000 0x00020000
		high	0x21A00000	[1,1]	1	io -4 0x21A00000 0x00020002
	Input Ctrl	disable	0x201D8460	[1,1]	0	io -4 0x201D8460 0x00020000
		enable	0x201D8460	[1,1]	1	io -4 0x201D8460 0x00020002
	Schmitt	disable	0x201D8560	[1,1]	0	io -4 0x201D8560 0x00020000
		enable	0x201D8560	[1,1]	1	io -4 0x201D8560 0x00020002
	Drive Strength	level0	0x201D8280	[8,13]	1	io -4 0x201D8280 0x3F000100
		level1	0x201D8280	[8,13]	3	io -4 0x201D8280 0x3F000300
		level2	0x201D8280	[8,13]	7	io -4 0x201D8280 0x3F000700
		level3	0x201D8280	[8,13]	15	io -4 0x201D8280 0x3F000F00
		level4	0x201D8280	[8,13]	31	io -4 0x201D8280 0x3F001F00
		level5	0x201D8280	[8,13]	63	io -4 0x201D8280 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[1,1]		io -4 0x21A00070
GPIO6A2	IOmux	VI_CIF_D2_M0	0x201D80C0	[8,11]	1	io -4 0x201D80C0 0x0F000100
		ETH_PPSCCLK_M0	0x201D80C0	[8,11]	2	io -4 0x201D80C0 0x0F000200
		CAN1_RXD_M1	0x201D80C0	[8,11]	3	io -4 0x201D80C0 0x0F000300
		SAIO_SDO0_M1	0x201D80C0	[8,11]	4	io -4 0x201D80C0 0x0F000400
		PWM1_CH2_M2	0x201D80C0	[8,11]	5	io -4 0x201D80C0 0x0F000500
		UART5_TX_M2	0x201D80C0	[8,11]	6	io -4 0x201D80C0 0x0F000600
		I2C4_SCL_M1	0x201D80C0	[8,11]	7	io -4 0x201D80C0 0x0F000700
		GPIO6_A2	0x201D80C0	[8,11]	0	io -4 0x201D80C0 0x0F000000
	Pull	z	0x201D8360	[4,5]	0	io -4 0x201D8360 0x00300000
		up	0x201D8360	[4,5]	1	io -4 0x201D8360 0x00300010
		down	0x201D8360	[4,5]	2	io -4 0x201D8360 0x00300020
	I/O Mode	input	0x21A00008	[2,2]	0	io -4 0x21A00008 0x00040000
		output	0x21A00008	[2,2]	1	io -4 0x21A00008 0x00040004
	Output	low	0x21A00000	[2,2]	0	io -4 0x21A00000 0x00040000
		high	0x21A00000	[2,2]	1	io -4 0x21A00000 0x00040004
	Input Ctrl	disable	0x201D8460	[2,2]	0	io -4 0x201D8460 0x00040000
		enable	0x201D8460	[2,2]	1	io -4 0x201D8460 0x00040004
	Schmitt	disable	0x201D8560	[2,2]	0	io -4 0x201D8560 0x00040000
		enable	0x201D8560	[2,2]	1	io -4 0x201D8560 0x00040004
	Drive Strength	level0	0x201D8284	[0,5]	1	io -4 0x201D8284 0x003F0001
		level1	0x201D8284	[0,5]	3	io -4 0x201D8284 0x003F0003
		level2	0x201D8284	[0,5]	7	io -4 0x201D8284 0x003F0007
		level3	0x201D8284	[0,5]	15	io -4 0x201D8284 0x003F000F
		level4	0x201D8284	[0,5]	31	io -4 0x201D8284 0x003F001F
		level5	0x201D8284	[0,5]	63	io -4 0x201D8284 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[2,2]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6A3	IOmux	VI_CIF_D3_M0	0x201D80C0	[12,15]	1	io -4 0x201D80C0 0xF0001000
		ETH_RXD2_M0	0x201D80C0	[12,15]	2	io -4 0x201D80C0 0xF0002000
		CAN1_TXD_M1	0x201D80C0	[12,15]	3	io -4 0x201D80C0 0xF0003000
		SAIO_SDI0_M1	0x201D80C0	[12,15]	4	io -4 0x201D80C0 0xF0004000
		PWM1_CH3_M2	0x201D80C0	[12,15]	5	io -4 0x201D80C0 0xF0005000
		UART5_RX_M2	0x201D80C0	[12,15]	6	io -4 0x201D80C0 0xF0006000
		I2C4_SDA_M1	0x201D80C0	[12,15]	7	io -4 0x201D80C0 0xF0007000
		GPIO6_A3	0x201D80C0	[12,15]	0	io -4 0x201D80C0 0xF0000000
	Pull	z	0x201D8360	[6,7]	0	io -4 0x201D8360 0x00C00000
		up	0x201D8360	[6,7]	1	io -4 0x201D8360 0x00C00040
		down	0x201D8360	[6,7]	2	io -4 0x201D8360 0x00C00080
	I/O Mode	input	0x21A00008	[3,3]	0	io -4 0x21A00008 0x00080000
		output	0x21A00008	[3,3]	1	io -4 0x21A00008 0x00080008
	Output	low	0x21A00000	[3,3]	0	io -4 0x21A00000 0x00080000
		high	0x21A00000	[3,3]	1	io -4 0x21A00000 0x00080008
	Input Ctrl	disable	0x201D8460	[3,3]	0	io -4 0x201D8460 0x00080000
		enable	0x201D8460	[3,3]	1	io -4 0x201D8460 0x00080008
	Schmitt	disable	0x201D8560	[3,3]	0	io -4 0x201D8560 0x00080000
		enable	0x201D8560	[3,3]	1	io -4 0x201D8560 0x00080008
	Drive Strength	level0	0x201D8284	[8,13]	1	io -4 0x201D8284 0x3F000100
		level1	0x201D8284	[8,13]	3	io -4 0x201D8284 0x3F000300
		level2	0x201D8284	[8,13]	7	io -4 0x201D8284 0x3F000700
		level3	0x201D8284	[8,13]	15	io -4 0x201D8284 0x3F000F00
		level4	0x201D8284	[8,13]	31	io -4 0x201D8284 0x3F001F00
		level5	0x201D8284	[8,13]	63	io -4 0x201D8284 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[3,3]		io -4 0x21A00070
GPIO6A4	IOmux	VI_CIF_D4_M0	0x201D80C4	[0,3]	1	io -4 0x201D80C4 0x000F0001
		ETH_RXD3_M0	0x201D80C4	[0,3]	2	io -4 0x201D80C4 0x000F0002
		SAIO_MCLK_M1	0x201D80C4	[0,3]	4	io -4 0x201D80C4 0x000F0004
		PWM2_CH0_M2	0x201D80C4	[0,3]	5	io -4 0x201D80C4 0x000F0005
		UART5_RTSN_M2	0x201D80C4	[0,3]	6	io -4 0x201D80C4 0x000F0006
		GPIO6_A4	0x201D80C4	[0,3]	0	io -4 0x201D80C4 0x000F0000
	Pull	z	0x201D8360	[8,9]	0	io -4 0x201D8360 0x03000000
		up	0x201D8360	[8,9]	1	io -4 0x201D8360 0x03000100
		down	0x201D8360	[8,9]	2	io -4 0x201D8360 0x03000200
	I/O Mode	input	0x21A00008	[4,4]	0	io -4 0x21A00008 0x00100000
		output	0x21A00008	[4,4]	1	io -4 0x21A00008 0x00100010
	Output	low	0x21A00000	[4,4]	0	io -4 0x21A00000 0x00100000
		high	0x21A00000	[4,4]	1	io -4 0x21A00000 0x00100010
	Input Ctrl	disable	0x201D8460	[4,4]	0	io -4 0x201D8460 0x00100000
		enable	0x201D8460	[4,4]	1	io -4 0x201D8460 0x00100010
	Schmitt	disable	0x201D8560	[4,4]	0	io -4 0x201D8560 0x00100000
		enable	0x201D8560	[4,4]	1	io -4 0x201D8560 0x00100010

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D8288	[0,5]	1	io -4 0x201D8288 0x003F0001
		level1	0x201D8288	[0,5]	3	io -4 0x201D8288 0x003F0003
		level2	0x201D8288	[0,5]	7	io -4 0x201D8288 0x003F0007
		level3	0x201D8288	[0,5]	15	io -4 0x201D8288 0x003F000F
		level4	0x201D8288	[0,5]	31	io -4 0x201D8288 0x003F001F
		level5	0x201D8288	[0,5]	63	io -4 0x201D8288 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[4,4]		io -4 0x21A00070
GPIO6A5	IOmux	VI_CIF_D5_M0	0x201D80C4	[4,7]	1	io -4 0x201D80C4 0x00F00010
		ETH_TXD2_M0	0x201D80C4	[4,7]	2	io -4 0x201D80C4 0x00F00020
		PWM2_CH1_M2	0x201D80C4	[4,7]	5	io -4 0x201D80C4 0x00F00050
		UART5_CTSN_M2	0x201D80C4	[4,7]	6	io -4 0x201D80C4 0x00F00060
		GPIO6_A5	0x201D80C4	[4,7]	0	io -4 0x201D80C4 0x00F00000
	Pull	z	0x201D8360	[10,11]	0	io -4 0x201D8360 0x0C000000
		up	0x201D8360	[10,11]	1	io -4 0x201D8360 0x0C000400
		down	0x201D8360	[10,11]	2	io -4 0x201D8360 0x0C000800
	I/O Mode	input	0x21A00008	[5,5]	0	io -4 0x21A00008 0x00200000
		output	0x21A00008	[5,5]	1	io -4 0x21A00008 0x00200020
	Output	low	0x21A00000	[5,5]	0	io -4 0x21A00000 0x00200000
		high	0x21A00000	[5,5]	1	io -4 0x21A00000 0x00200020
	Input Ctrl	disable	0x201D8460	[5,5]	0	io -4 0x201D8460 0x00200000
		enable	0x201D8460	[5,5]	1	io -4 0x201D8460 0x00200020
	Schmitt	disable	0x201D8560	[5,5]	0	io -4 0x201D8560 0x00200000
		enable	0x201D8560	[5,5]	1	io -4 0x201D8560 0x00200020
	Drive Strength	level0	0x201D8288	[8,13]	1	io -4 0x201D8288 0x3F000100
		level1	0x201D8288	[8,13]	3	io -4 0x201D8288 0x3F000300
		level2	0x201D8288	[8,13]	7	io -4 0x201D8288 0x3F000700
		level3	0x201D8288	[8,13]	15	io -4 0x201D8288 0x3F000F00
		level4	0x201D8288	[8,13]	31	io -4 0x201D8288 0x3F001F00
		level5	0x201D8288	[8,13]	63	io -4 0x201D8288 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[5,5]		io -4 0x21A00070
GPIO6A6	IOmux	VI_CIF_D6_M0	0x201D80C4	[8,11]	1	io -4 0x201D80C4 0x0F000100
		ETH_TXD3_M0	0x201D80C4	[8,11]	2	io -4 0x201D80C4 0x0F000200
		PWM2_CH2_M2	0x201D80C4	[8,11]	5	io -4 0x201D80C4 0x0F000500
		UART4_RTSN_M2	0x201D80C4	[8,11]	6	io -4 0x201D80C4 0x0F000600
		GPIO6_A6	0x201D80C4	[8,11]	0	io -4 0x201D80C4 0x0F000000
	Pull	z	0x201D8360	[12,13]	0	io -4 0x201D8360 0x30000000
		up	0x201D8360	[12,13]	1	io -4 0x201D8360 0x30001000
		down	0x201D8360	[12,13]	2	io -4 0x201D8360 0x30002000
	I/O Mode	input	0x21A00008	[6,6]	0	io -4 0x21A00008 0x00400000
		output	0x21A00008	[6,6]	1	io -4 0x21A00008 0x00400040
	Output	low	0x21A00000	[6,6]	0	io -4 0x21A00000 0x00400000
		high	0x21A00000	[6,6]	1	io -4 0x21A00000 0x00400040
	Input Ctrl	disable	0x201D8460	[6,6]	0	io -4 0x201D8460 0x00400000
		enable	0x201D8460	[6,6]	1	io -4 0x201D8460 0x00400040
	Schmitt	disable	0x201D8560	[6,6]	0	io -4 0x201D8560 0x00400000
		enable	0x201D8560	[6,6]	1	io -4 0x201D8560 0x00400040

Name	Config	Description	Register	Position	Value	IO Command
	Drive Strength	level0	0x201D828C	[0,5]	1	io -4 0x201D828C 0x003F0001
		level1	0x201D828C	[0,5]	3	io -4 0x201D828C 0x003F0003
		level2	0x201D828C	[0,5]	7	io -4 0x201D828C 0x003F0007
		level3	0x201D828C	[0,5]	15	io -4 0x201D828C 0x003F000F
		level4	0x201D828C	[0,5]	31	io -4 0x201D828C 0x003F001F
		level5	0x201D828C	[0,5]	63	io -4 0x201D828C 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[6,6]		io -4 0x21A00070
GPIO6A7	IOmux	VI_CIF_D7_M0	0x201D80C4	[12,15]	1	io -4 0x201D80C4 0xF0001000
		ETH_TXD0_M0	0x201D80C4	[12,15]	2	io -4 0x201D80C4 0xF0002000
		PWM2_CH3_M2	0x201D80C4	[12,15]	3	io -4 0x201D80C4 0xF0003000
		SAI0_SDI3_M1	0x201D80C4	[12,15]	4	io -4 0x201D80C4 0xF0004000
		SAI0_SDO1_M1	0x201D80C4	[12,15]	5	io -4 0x201D80C4 0xF0005000
		UART4_CTSN_M2	0x201D80C4	[12,15]	6	io -4 0x201D80C4 0xF0006000
		GPIO6_A7	0x201D80C4	[12,15]	0	io -4 0x201D80C4 0xF0000000
	Pull	z	0x201D8360	[14,15]	0	io -4 0x201D8360 0xC0000000
		up	0x201D8360	[14,15]	1	io -4 0x201D8360 0xC0004000
		down	0x201D8360	[14,15]	2	io -4 0x201D8360 0xC0008000
	I/O Mode	input	0x21A00008	[7,7]	0	io -4 0x21A00008 0x00800000
		output	0x21A00008	[7,7]	1	io -4 0x21A00008 0x00800080
	Output	low	0x21A00000	[7,7]	0	io -4 0x21A00000 0x00800000
		high	0x21A00000	[7,7]	1	io -4 0x21A00000 0x00800080
	Input Ctrl	disable	0x201D8460	[7,7]	0	io -4 0x201D8460 0x00800000
		enable	0x201D8460	[7,7]	1	io -4 0x201D8460 0x00800080
	Schmitt	disable	0x201D8560	[7,7]	0	io -4 0x201D8560 0x00800000
		enable	0x201D8560	[7,7]	1	io -4 0x201D8560 0x00800080
	Drive Strength	level0	0x201D828C	[8,13]	1	io -4 0x201D828C 0x3F000100
		level1	0x201D828C	[8,13]	3	io -4 0x201D828C 0x3F000300
		level2	0x201D828C	[8,13]	7	io -4 0x201D828C 0x3F000700
		level3	0x201D828C	[8,13]	15	io -4 0x201D828C 0x3F000F00
		level4	0x201D828C	[8,13]	31	io -4 0x201D828C 0x3F001F00
		level5	0x201D828C	[8,13]	63	io -4 0x201D828C 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[7,7]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6B0	IOMUX	VI_CIF_D8_M0	0x201D80C8	[0,3]	1	io -4 0x201D80C8 0x000F0001
		ETH_TXD1_M0	0x201D80C8	[0,3]	2	io -4 0x201D80C8 0x000F0002
		SPI1_CSN1_M0	0x201D80C8	[0,3]	3	io -4 0x201D80C8 0x000F0003
		SAIO_SDI2_M1	0x201D80C8	[0,3]	4	io -4 0x201D80C8 0x000F0004
		SAIO_SDO2_M1	0x201D80C8	[0,3]	5	io -4 0x201D80C8 0x000F0005
		UART6_TX_M1	0x201D80C8	[0,3]	6	io -4 0x201D80C8 0x000F0006
		GPIO6_B0	0x201D80C8	[0,3]	0	io -4 0x201D80C8 0x000F0000
	Pull	z	0x201D8364	[0,1]	0	io -4 0x201D8364 0x00030000
		up	0x201D8364	[0,1]	1	io -4 0x201D8364 0x00030001
		down	0x201D8364	[0,1]	2	io -4 0x201D8364 0x00030002
	I/O Mode	input	0x21A00008	[8,8]	0	io -4 0x21A00008 0x01000000
		output	0x21A00008	[8,8]	1	io -4 0x21A00008 0x01000100
	Output	low	0x21A00000	[8,8]	0	io -4 0x21A00000 0x01000000
		high	0x21A00000	[8,8]	1	io -4 0x21A00000 0x01000100
	Input Ctrl	disable	0x201D8464	[0,0]	0	io -4 0x201D8464 0x00010000
		enable	0x201D8464	[0,0]	1	io -4 0x201D8464 0x00010001
	Schmitt	disable	0x201D8564	[0,0]	0	io -4 0x201D8564 0x00010000
		enable	0x201D8564	[0,0]	1	io -4 0x201D8564 0x00010001
	Drive Strength	level0	0x201D8290	[0,5]	1	io -4 0x201D8290 0x003F0001
		level1	0x201D8290	[0,5]	3	io -4 0x201D8290 0x003F0003
		level2	0x201D8290	[0,5]	7	io -4 0x201D8290 0x003F0007
		level3	0x201D8290	[0,5]	15	io -4 0x201D8290 0x003F000F
		level4	0x201D8290	[0,5]	31	io -4 0x201D8290 0x003F001F
		level5	0x201D8290	[0,5]	63	io -4 0x201D8290 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[8,8]		io -4 0x21A00070
GPIO6B1	IOMUX	VI_CIF_D9_M0	0x201D80C8	[4,7]	1	io -4 0x201D80C8 0x00F00010
		ETH_TXCTL_M0	0x201D80C8	[4,7]	2	io -4 0x201D80C8 0x00F00020
		SPI1_CSN0_M0	0x201D80C8	[4,7]	3	io -4 0x201D80C8 0x00F00030
		SAIO_SDI1_M1	0x201D80C8	[4,7]	4	io -4 0x201D80C8 0x00F00040
		SAIO_SDO3_M1	0x201D80C8	[4,7]	5	io -4 0x201D80C8 0x00F00050
		UART6_RX_M1	0x201D80C8	[4,7]	6	io -4 0x201D80C8 0x00F00060
		GPIO6_B1	0x201D80C8	[4,7]	0	io -4 0x201D80C8 0x00F00000
	Pull	z	0x201D8364	[2,3]	0	io -4 0x201D8364 0x000C0000
		up	0x201D8364	[2,3]	1	io -4 0x201D8364 0x000C0004
		down	0x201D8364	[2,3]	2	io -4 0x201D8364 0x000C0008
	I/O Mode	input	0x21A00008	[9,9]	0	io -4 0x21A00008 0x02000000
		output	0x21A00008	[9,9]	1	io -4 0x21A00008 0x02000200
	Output	low	0x21A00000	[9,9]	0	io -4 0x21A00000 0x02000000
		high	0x21A00000	[9,9]	1	io -4 0x21A00000 0x02000200
	Input Ctrl	disable	0x201D8464	[1,1]	0	io -4 0x201D8464 0x00020000
		enable	0x201D8464	[1,1]	1	io -4 0x201D8464 0x00020002

Name	Config	Description	Register	Position	Value	IO Command
	Schmitt	disable	0x201D8564	[1,1]	0	io -4 0x201D8564 0x00020000
		enable	0x201D8564	[1,1]	1	io -4 0x201D8564 0x00020002
	Drive Strength	level0	0x201D8290	[8,13]	1	io -4 0x201D8290 0x3F000100
		level1	0x201D8290	[8,13]	3	io -4 0x201D8290 0x3F000300
		level2	0x201D8290	[8,13]	7	io -4 0x201D8290 0x3F000700
		level3	0x201D8290	[8,13]	15	io -4 0x201D8290 0x3F000F00
		level4	0x201D8290	[8,13]	31	io -4 0x201D8290 0x3F001F00
		level5	0x201D8290	[8,13]	63	io -4 0x201D8290 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[9,9]		io -4 0x21A00070
GPIO6B2	IOmux	VI_CIF_D10_M0	0x201D80C8	[8,11]	1	io -4 0x201D80C8 0x0F000100
		ETH_RXD0_M0	0x201D80C8	[8,11]	2	io -4 0x201D80C8 0x0F000200
		SPI1_MOSI_M0	0x201D80C8	[8,11]	3	io -4 0x201D80C8 0x0F000300
		PDM_SDI2_M1	0x201D80C8	[8,11]	5	io -4 0x201D80C8 0x0F000500
		UART6_RTSN_M1	0x201D80C8	[8,11]	6	io -4 0x201D80C8 0x0F000600
		GPIO6_B2	0x201D80C8	[8,11]	0	io -4 0x201D80C8 0x0F000000
	Pull	z	0x201D8364	[4,5]	0	io -4 0x201D8364 0x00300000
		up	0x201D8364	[4,5]	1	io -4 0x201D8364 0x00300010
		down	0x201D8364	[4,5]	2	io -4 0x201D8364 0x00300020
	I/O Mode	input	0x21A00008	[10,10]	0	io -4 0x21A00008 0x04000000
		output	0x21A00008	[10,10]	1	io -4 0x21A00008 0x04000400
	Output	low	0x21A00000	[10,10]	0	io -4 0x21A00000 0x04000000
		high	0x21A00000	[10,10]	1	io -4 0x21A00000 0x04000400
	Input Ctrl	disable	0x201D8464	[2,2]	0	io -4 0x201D8464 0x00040000
		enable	0x201D8464	[2,2]	1	io -4 0x201D8464 0x00040004
	Schmitt	disable	0x201D8564	[2,2]	0	io -4 0x201D8564 0x00040000
		enable	0x201D8564	[2,2]	1	io -4 0x201D8564 0x00040004
	Drive Strength	level0	0x201D8294	[0,5]	1	io -4 0x201D8294 0x003F0001
		level1	0x201D8294	[0,5]	3	io -4 0x201D8294 0x003F0003
		level2	0x201D8294	[0,5]	7	io -4 0x201D8294 0x003F0007
		level3	0x201D8294	[0,5]	15	io -4 0x201D8294 0x003F000F
		level4	0x201D8294	[0,5]	31	io -4 0x201D8294 0x003F001F
		level5	0x201D8294	[0,5]	63	io -4 0x201D8294 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[10,10]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6B3	IOmux	VI_CIF_D11_M0	0x201D80C8	[12,15]	1	io -4 0x201D80C8 0xF0001000
		ETH_RXD1_M0	0x201D80C8	[12,15]	2	io -4 0x201D80C8 0xF0002000
		SPI1_MISO_M0	0x201D80C8	[12,15]	3	io -4 0x201D80C8 0xF0003000
		PDM_SDI3_M1	0x201D80C8	[12,15]	5	io -4 0x201D80C8 0xF0005000
		UART6_CTSN_M1	0x201D80C8	[12,15]	6	io -4 0x201D80C8 0xF0006000
		GPIO6_B3	0x201D80C8	[12,15]	0	io -4 0x201D80C8 0xF0000000
	Pull	z	0x201D8364	[6,7]	0	io -4 0x201D8364 0x00C00000
		up	0x201D8364	[6,7]	1	io -4 0x201D8364 0x00C00040
		down	0x201D8364	[6,7]	2	io -4 0x201D8364 0x00C00080
	I/O Mode	input	0x21A00008	[11,11]	0	io -4 0x21A00008 0x08000000
		output	0x21A00008	[11,11]	1	io -4 0x21A00008 0x08000800
	Output	low	0x21A00000	[11,11]	0	io -4 0x21A00000 0x08000000
		high	0x21A00000	[11,11]	1	io -4 0x21A00000 0x08000800
	Input Ctrl	disable	0x201D8464	[3,3]	0	io -4 0x201D8464 0x00080000
		enable	0x201D8464	[3,3]	1	io -4 0x201D8464 0x00080008
	Schmitt	disable	0x201D8564	[3,3]	0	io -4 0x201D8564 0x00080000
		enable	0x201D8564	[3,3]	1	io -4 0x201D8564 0x00080008
	Drive Strength	level0	0x201D8294	[8,13]	1	io -4 0x201D8294 0x3F000100
		level1	0x201D8294	[8,13]	3	io -4 0x201D8294 0x3F000300
		level2	0x201D8294	[8,13]	7	io -4 0x201D8294 0x3F000700
		level3	0x201D8294	[8,13]	15	io -4 0x201D8294 0x3F000F00
		level4	0x201D8294	[8,13]	31	io -4 0x201D8294 0x3F001F00
		level5	0x201D8294	[8,13]	63	io -4 0x201D8294 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[11,11]		io -4 0x21A00070
GPIO6B4	IOmux	VI_CIF_D12_M0	0x201D80CC	[0,3]	1	io -4 0x201D80CC 0x000F0001
		ETH_MCLK_M0	0x201D80CC	[0,3]	2	io -4 0x201D80CC 0x000F0002
		SPI1_CLK_M0	0x201D80CC	[0,3]	3	io -4 0x201D80CC 0x000F0003
		PDM_CLK0_M1	0x201D80CC	[0,3]	5	io -4 0x201D80CC 0x000F0005
		UART7_TX_M1	0x201D80CC	[0,3]	6	io -4 0x201D80CC 0x000F0006
		GPIO6_B4	0x201D80CC	[0,3]	0	io -4 0x201D80CC 0x000F0000
	Pull	z	0x201D8364	[8,9]	0	io -4 0x201D8364 0x03000000
		up	0x201D8364	[8,9]	1	io -4 0x201D8364 0x03000100
		down	0x201D8364	[8,9]	2	io -4 0x201D8364 0x03000200
	I/O Mode	input	0x21A00008	[12,12]	0	io -4 0x21A00008 0x10000000
		output	0x21A00008	[12,12]	1	io -4 0x21A00008 0x10001000
	Output	low	0x21A00000	[12,12]	0	io -4 0x21A00000 0x10000000
		high	0x21A00000	[12,12]	1	io -4 0x21A00000 0x10001000
	Input Ctrl	disable	0x201D8464	[4,4]	0	io -4 0x201D8464 0x00100000
		enable	0x201D8464	[4,4]	1	io -4 0x201D8464 0x00100010
	Schmitt	disable	0x201D8564	[4,4]	0	io -4 0x201D8564 0x00100000
		enable	0x201D8564	[4,4]	1	io -4 0x201D8564 0x00100010
	Drive Strength	level0	0x201D8298	[0,5]	1	io -4 0x201D8298 0x003F0001
		level1	0x201D8298	[0,5]	3	io -4 0x201D8298 0x003F0003
		level2	0x201D8298	[0,5]	7	io -4 0x201D8298 0x003F0007
		level3	0x201D8298	[0,5]	15	io -4 0x201D8298 0x003F000F
		level4	0x201D8298	[0,5]	31	io -4 0x201D8298 0x003F001F
		level5	0x201D8298	[0,5]	63	io -4 0x201D8298 0x003F003F

Name	Config	Description	Register	Position	Value	IO Command
	ExtPort	read gpio data in input	0x21A00070	[12,12]		io -4 0x21A00070
GPIO6B5	IOMUX	VI_CIF_D13_M0	0x201D80CC	[4,7]	1	io -4 0x201D80CC 0x00F00010
		ETH_RXCTL_M0	0x201D80CC	[4,7]	2	io -4 0x201D80CC 0x00F00020
		PDM_SDI0_M1	0x201D80CC	[4,7]	5	io -4 0x201D80CC 0x00F00050
		UART7_RX_M1	0x201D80CC	[4,7]	6	io -4 0x201D80CC 0x00F00060
		GPIO6_B5	0x201D80CC	[4,7]	0	io -4 0x201D80CC 0x00F00000
	Pull	z	0x201D8364	[10,11]	0	io -4 0x201D8364 0x0C000000
		up	0x201D8364	[10,11]	1	io -4 0x201D8364 0x0C000400
		down	0x201D8364	[10,11]	2	io -4 0x201D8364 0x0C000800
	I/O Mode	input	0x21A00008	[13,13]	0	io -4 0x21A00008 0x20000000
		output	0x21A00008	[13,13]	1	io -4 0x21A00008 0x20002000
	Output	low	0x21A00000	[13,13]	0	io -4 0x21A00000 0x20000000
		high	0x21A00000	[13,13]	1	io -4 0x21A00000 0x20002000
	Input Ctrl	disable	0x201D8464	[5,5]	0	io -4 0x201D8464 0x00200000
		enable	0x201D8464	[5,5]	1	io -4 0x201D8464 0x00200020
	Schmitt	disable	0x201D8564	[5,5]	0	io -4 0x201D8564 0x00200000
		enable	0x201D8564	[5,5]	1	io -4 0x201D8564 0x00200020
	Drive Strength	level0	0x201D8298	[8,13]	1	io -4 0x201D8298 0x3F000100
		level1	0x201D8298	[8,13]	3	io -4 0x201D8298 0x3F000300
		level2	0x201D8298	[8,13]	7	io -4 0x201D8298 0x3F000700
		level3	0x201D8298	[8,13]	15	io -4 0x201D8298 0x3F000F00
		level4	0x201D8298	[8,13]	31	io -4 0x201D8298 0x3F001F00
		level5	0x201D8298	[8,13]	63	io -4 0x201D8298 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[13,13]		io -4 0x21A00070
GPIO6B6	IOMUX	VI_CIF_D14_M0	0x201D80CC	[8,11]	1	io -4 0x201D80CC 0x0F000100
		PDM_SDI1_M1	0x201D80CC	[8,11]	5	io -4 0x201D80CC 0x0F000500
		UART7_RTSN_M1	0x201D80CC	[8,11]	6	io -4 0x201D80CC 0x0F000600
		GPIO6_B6	0x201D80CC	[8,11]	0	io -4 0x201D80CC 0x0F000000
	Pull	z	0x201D8364	[12,13]	0	io -4 0x201D8364 0x30000000
		up	0x201D8364	[12,13]	1	io -4 0x201D8364 0x30001000
		down	0x201D8364	[12,13]	2	io -4 0x201D8364 0x30002000
	I/O Mode	input	0x21A00008	[14,14]	0	io -4 0x21A00008 0x40000000
		output	0x21A00008	[14,14]	1	io -4 0x21A00008 0x40004000
	Output	low	0x21A00000	[14,14]	0	io -4 0x21A00000 0x40000000
		high	0x21A00000	[14,14]	1	io -4 0x21A00000 0x40004000
	Input Ctrl	disable	0x201D8464	[6,6]	0	io -4 0x201D8464 0x00400000
		enable	0x201D8464	[6,6]	1	io -4 0x201D8464 0x00400040
	Schmitt	disable	0x201D8564	[6,6]	0	io -4 0x201D8564 0x00400000
		enable	0x201D8564	[6,6]	1	io -4 0x201D8564 0x00400040
	Drive Strength	level0	0x201D829C	[0,5]	1	io -4 0x201D829C 0x003F0001
		level1	0x201D829C	[0,5]	3	io -4 0x201D829C 0x003F0003
		level2	0x201D829C	[0,5]	7	io -4 0x201D829C 0x003F0007
		level3	0x201D829C	[0,5]	15	io -4 0x201D829C 0x003F000F
		level4	0x201D829C	[0,5]	31	io -4 0x201D829C 0x003F001F
		level5	0x201D829C	[0,5]	63	io -4 0x201D829C 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[14,14]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6B7	IOMUX	VI_CIF_D15_M0	0x201D80CC	[12,15]	1	io -4 0x201D80CC 0xF0001000
		ETH_MDIO_M0	0x201D80CC	[12,15]	2	io -4 0x201D80CC 0xF0002000
		PDM_CLK1_M1	0x201D80CC	[12,15]	5	io -4 0x201D80CC 0xF0005000
		UART7_CTSN_M1	0x201D80CC	[12,15]	6	io -4 0x201D80CC 0xF0006000
		GPIO6_B7	0x201D80CC	[12,15]	0	io -4 0x201D80CC 0xF0000000
	Pull	z	0x201D8364	[14,15]	0	io -4 0x201D8364 0xC0000000
		up	0x201D8364	[14,15]	1	io -4 0x201D8364 0xC0004000
		down	0x201D8364	[14,15]	2	io -4 0x201D8364 0xC0008000
	I/O Mode	input	0x21A00008	[15,15]	0	io -4 0x21A00008 0x80000000
		output	0x21A00008	[15,15]	1	io -4 0x21A00008 0x80008000
	Output	low	0x21A00000	[15,15]	0	io -4 0x21A00000 0x80000000
		high	0x21A00000	[15,15]	1	io -4 0x21A00000 0x80008000
	Input Ctrl	disable	0x201D8464	[7,7]	0	io -4 0x201D8464 0x00800000
		enable	0x201D8464	[7,7]	1	io -4 0x201D8464 0x00800080
	Schmitt	disable	0x201D8564	[7,7]	0	io -4 0x201D8564 0x00800000
		enable	0x201D8564	[7,7]	1	io -4 0x201D8564 0x00800080
	Drive Strength	level0	0x201D829C	[8,13]	1	io -4 0x201D829C 0x3F000100
		level1	0x201D829C	[8,13]	3	io -4 0x201D829C 0x3F000300
		level2	0x201D829C	[8,13]	7	io -4 0x201D829C 0x3F000700
		level3	0x201D829C	[8,13]	15	io -4 0x201D829C 0x3F000F00
		level4	0x201D829C	[8,13]	31	io -4 0x201D829C 0x3F001F00
		level5	0x201D829C	[8,13]	63	io -4 0x201D829C 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[15,15]		io -4 0x21A00070
GPIO6C0	IOMUX	VI_CIF_VSYNC_M0	0x201D80D0	[0,3]	1	io -4 0x201D80D0 0x000F0001
		ETH_MDC_M0	0x201D80D0	[0,3]	2	io -4 0x201D80D0 0x000F0002
		PWM0_CH0_M2	0x201D80D0	[0,3]	5	io -4 0x201D80D0 0x000F0005
		UART3_RTSN_M2	0x201D80D0	[0,3]	6	io -4 0x201D80D0 0x000F0006
		I2C2_SCL_M2	0x201D80D0	[0,3]	7	io -4 0x201D80D0 0x000F0007
		GPIO6_C0	0x201D80D0	[0,3]	0	io -4 0x201D80D0 0x000F0000
	Pull	z	0x201D8368	[0,1]	0	io -4 0x201D8368 0x00030000
		up	0x201D8368	[0,1]	1	io -4 0x201D8368 0x00030001
		down	0x201D8368	[0,1]	2	io -4 0x201D8368 0x00030002
	I/O Mode	input	0x21A0000C	[0,0]	0	io -4 0x21A0000C 0x00010000
		output	0x21A0000C	[0,0]	1	io -4 0x21A0000C 0x00010001
	Output	low	0x21A00004	[0,0]	0	io -4 0x21A00004 0x00010000
		high	0x21A00004	[0,0]	1	io -4 0x21A00004 0x00010001
	Input Ctrl	disable	0x201D8468	[0,0]	0	io -4 0x201D8468 0x00010000
		enable	0x201D8468	[0,0]	1	io -4 0x201D8468 0x00010001
	Schmitt	disable	0x201D8568	[0,0]	0	io -4 0x201D8568 0x00010000
		enable	0x201D8568	[0,0]	1	io -4 0x201D8568 0x00010001
	Drive Strength	level0	0x201D82A0	[0,5]	1	io -4 0x201D82A0 0x003F0001
		level1	0x201D82A0	[0,5]	3	io -4 0x201D82A0 0x003F0003
		level2	0x201D82A0	[0,5]	7	io -4 0x201D82A0 0x003F0007
		level3	0x201D82A0	[0,5]	15	io -4 0x201D82A0 0x003F000F
		level4	0x201D82A0	[0,5]	31	io -4 0x201D82A0 0x003F001F
		level5	0x201D82A0	[0,5]	63	io -4 0x201D82A0 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[16,16]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6C1	IOMUX	VI_CIF_CLKIN_M0	0x201D80D0	[4,7]	1	io -4 0x201D80D0 0x00F00010
		ETH_CLK_25M_OUT_M0	0x201D80D0	[4,7]	2	io -4 0x201D80D0 0x00F00020
		PWM0_CH1_M2	0x201D80D0	[4,7]	5	io -4 0x201D80D0 0x00F00050
		UART3_CTSN_M2	0x201D80D0	[4,7]	6	io -4 0x201D80D0 0x00F00060
		GPIO6_C1	0x201D80D0	[4,7]	0	io -4 0x201D80D0 0x00F00000
	Pull	z	0x201D8368	[2,3]	0	io -4 0x201D8368 0x000C0000
		up	0x201D8368	[2,3]	1	io -4 0x201D8368 0x000C0004
		down	0x201D8368	[2,3]	2	io -4 0x201D8368 0x000C0008
	I/O Mode	input	0x21A0000C	[1,1]	0	io -4 0x21A0000C 0x00020000
		output	0x21A0000C	[1,1]	1	io -4 0x21A0000C 0x00020002
	Output	low	0x21A00004	[1,1]	0	io -4 0x21A00004 0x00020000
		high	0x21A00004	[1,1]	1	io -4 0x21A00004 0x00020002
	Input Ctrl	disable	0x201D8468	[1,1]	0	io -4 0x201D8468 0x00020000
		enable	0x201D8468	[1,1]	1	io -4 0x201D8468 0x00020002
	Schmitt	disable	0x201D8568	[1,1]	0	io -4 0x201D8568 0x00020000
		enable	0x201D8568	[1,1]	1	io -4 0x201D8568 0x00020002
	Drive Strength	level0	0x201D82A0	[8,13]	1	io -4 0x201D82A0 0x3F000100
		level1	0x201D82A0	[8,13]	3	io -4 0x201D82A0 0x3F000300
		level2	0x201D82A0	[8,13]	7	io -4 0x201D82A0 0x3F000700
		level3	0x201D82A0	[8,13]	15	io -4 0x201D82A0 0x3F000F00
		level4	0x201D82A0	[8,13]	31	io -4 0x201D82A0 0x3F001F00
		level5	0x201D82A0	[8,13]	63	io -4 0x201D82A0 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[17,17]		io -4 0x21A00070
GPIO6C2	IOMUX	VI_CIF_CLKOUT_M0	0x201D80D0	[8,11]	1	io -4 0x201D80D0 0x0F000100
		ETH_TXCLK_M0	0x201D80D0	[8,11]	2	io -4 0x201D80D0 0x0F000200
		FEPHY_LEDLINK_M2	0x201D80D0	[8,11]	3	io -4 0x201D80D0 0x0F000300
		PWM0_CH2_M2	0x201D80D0	[8,11]	5	io -4 0x201D80D0 0x0F000500
		UART3_TX_M2	0x201D80D0	[8,11]	6	io -4 0x201D80D0 0x0F000600
		GPIO6_C2	0x201D80D0	[8,11]	0	io -4 0x201D80D0 0x0F000000
	Pull	z	0x201D8368	[4,5]	0	io -4 0x201D8368 0x00300000
		up	0x201D8368	[4,5]	1	io -4 0x201D8368 0x00300010
		down	0x201D8368	[4,5]	2	io -4 0x201D8368 0x00300020
	I/O Mode	input	0x21A0000C	[2,2]	0	io -4 0x21A0000C 0x00040000
		output	0x21A0000C	[2,2]	1	io -4 0x21A0000C 0x00040004
	Output	low	0x21A00004	[2,2]	0	io -4 0x21A00004 0x00040000
		high	0x21A00004	[2,2]	1	io -4 0x21A00004 0x00040004
	Input Ctrl	disable	0x201D8468	[2,2]	0	io -4 0x201D8468 0x00040000
		enable	0x201D8468	[2,2]	1	io -4 0x201D8468 0x00040004
	Schmitt	disable	0x201D8568	[2,2]	0	io -4 0x201D8568 0x00040000
		enable	0x201D8568	[2,2]	1	io -4 0x201D8568 0x00040004
	Drive Strength	level0	0x201D82A4	[0,5]	1	io -4 0x201D82A4 0x003F0001
		level1	0x201D82A4	[0,5]	3	io -4 0x201D82A4 0x003F0003
		level2	0x201D82A4	[0,5]	7	io -4 0x201D82A4 0x003F0007
		level3	0x201D82A4	[0,5]	15	io -4 0x201D82A4 0x003F000F
		level4	0x201D82A4	[0,5]	31	io -4 0x201D82A4 0x003F001F
		level5	0x201D82A4	[0,5]	63	io -4 0x201D82A4 0x003F003F
	ExtPort	read gpio data in input	0x21A00070	[18,18]		io -4 0x21A00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO6C3	IOmux	VI_CIF_HSYNC_M0	0x201D80D0	[12,15]	1	io -4 0x201D80D0 0xF0001000
		ETH_RXCLK_M0	0x201D80D0	[12,15]	2	io -4 0x201D80D0 0xF0002000
		FEPHY_LEDSPD_M2	0x201D80D0	[12,15]	3	io -4 0x201D80D0 0xF0003000
		PWM0_CH3_M2	0x201D80D0	[12,15]	5	io -4 0x201D80D0 0xF0005000
		UART3_RX_M2	0x201D80D0	[12,15]	6	io -4 0x201D80D0 0xF0006000
		I2C2_SDA_M2	0x201D80D0	[12,15]	7	io -4 0x201D80D0 0xF0007000
		GPIO6_C3	0x201D80D0	[12,15]	0	io -4 0x201D80D0 0xF0000000
	Pull	z	0x201D8368	[6,7]	0	io -4 0x201D8368 0x00C00000
		up	0x201D8368	[6,7]	1	io -4 0x201D8368 0x00C00040
		down	0x201D8368	[6,7]	2	io -4 0x201D8368 0x00C00080
	I/O Mode	input	0x21A0000C	[3,3]	0	io -4 0x21A0000C 0x00080000
		output	0x21A0000C	[3,3]	1	io -4 0x21A0000C 0x00080008
	Output	low	0x21A00004	[3,3]	0	io -4 0x21A00004 0x00080000
		high	0x21A00004	[3,3]	1	io -4 0x21A00004 0x00080008
	Input Ctrl	disable	0x201D8468	[3,3]	0	io -4 0x201D8468 0x00080000
		enable	0x201D8468	[3,3]	1	io -4 0x201D8468 0x00080008
	Schmitt	disable	0x201D8568	[3,3]	0	io -4 0x201D8568 0x00080000
		enable	0x201D8568	[3,3]	1	io -4 0x201D8568 0x00080008
	Drive Strength	level0	0x201D82A4	[8,13]	1	io -4 0x201D82A4 0x3F000100
		level1	0x201D82A4	[8,13]	3	io -4 0x201D82A4 0x3F000300
		level2	0x201D82A4	[8,13]	7	io -4 0x201D82A4 0x3F000700
		level3	0x201D82A4	[8,13]	15	io -4 0x201D82A4 0x3F000F00
		level4	0x201D82A4	[8,13]	31	io -4 0x201D82A4 0x3F001F00
		level5	0x201D82A4	[8,13]	63	io -4 0x201D82A4 0x3F003F00
	ExtPort	read gpio data in input	0x21A00070	[19,19]		io -4 0x21A00070
GPIO7A0	IOmux	SAIO_SCLK_M0	0x201E00E0	[0,3]	1	io -4 0x201E00E0 0x000F0001
		PWM2_CH4_M1	0x201E00E0	[0,3]	5	io -4 0x201E00E0 0x000F0005
		GPIO7_A0	0x201E00E0	[0,3]	0	io -4 0x201E00E0 0x000F0000
	Pull	z	0x201E0370	[0,1]	0	io -4 0x201E0370 0x00030000
		up	0x201E0370	[0,1]	1	io -4 0x201E0370 0x00030001
		down	0x201E0370	[0,1]	2	io -4 0x201E0370 0x00030002
	I/O Mode	input	0x21B00008	[0,0]	0	io -4 0x21B00008 0x00010000
		output	0x21B00008	[0,0]	1	io -4 0x21B00008 0x00010001
	Output	low	0x21B00000	[0,0]	0	io -4 0x21B00000 0x00010000
		high	0x21B00000	[0,0]	1	io -4 0x21B00000 0x00010001
	Input Ctrl	disable	0x201E0470	[0,0]	0	io -4 0x201E0470 0x00010000
		enable	0x201E0470	[0,0]	1	io -4 0x201E0470 0x00010001
	Schmitt	disable	0x201E0570	[0,0]	0	io -4 0x201E0570 0x00010000
		enable	0x201E0570	[0,0]	1	io -4 0x201E0570 0x00010001
	Drive Strength	level0	0x201E02C0	[0,5]	1	io -4 0x201E02C0 0x003F0001
		level1	0x201E02C0	[0,5]	3	io -4 0x201E02C0 0x003F0003
		level2	0x201E02C0	[0,5]	7	io -4 0x201E02C0 0x003F0007
		level3	0x201E02C0	[0,5]	15	io -4 0x201E02C0 0x003F000F
		level4	0x201E02C0	[0,5]	31	io -4 0x201E02C0 0x003F001F
		level5	0x201E02C0	[0,5]	63	io -4 0x201E02C0 0x003F003F
	ExtPort	read gpio data in input	0x21B00070	[0,0]		io -4 0x21B00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO7A1	IOmux	PDM_CLK1_M0	0x201E00E0	[4,7]	3	io -4 0x201E00E0 0x00F00030
		PWM2_CH5_M1	0x201E00E0	[4,7]	5	io -4 0x201E00E0 0x00F00050
		GPIO7_A1	0x201E00E0	[4,7]	0	io -4 0x201E00E0 0x00F00000
	Pull	z	0x201E0370	[2,3]	0	io -4 0x201E0370 0x000C0000
		up	0x201E0370	[2,3]	1	io -4 0x201E0370 0x000C0004
		down	0x201E0370	[2,3]	2	io -4 0x201E0370 0x000C0008
	I/O Mode	input	0x21B00008	[1,1]	0	io -4 0x21B00008 0x00020000
		output	0x21B00008	[1,1]	1	io -4 0x21B00008 0x00020002
	Output	low	0x21B00000	[1,1]	0	io -4 0x21B00000 0x00020000
		high	0x21B00000	[1,1]	1	io -4 0x21B00000 0x00020002
	Input Ctrl	disable	0x201E0470	[1,1]	0	io -4 0x201E0470 0x00020000
		enable	0x201E0470	[1,1]	1	io -4 0x201E0470 0x00020002
	Schmitt	disable	0x201E0570	[1,1]	0	io -4 0x201E0570 0x00020000
		enable	0x201E0570	[1,1]	1	io -4 0x201E0570 0x00020002
	Drive Strength	level0	0x201E02C0	[8,13]	1	io -4 0x201E02C0 0x3F000100
		level1	0x201E02C0	[8,13]	3	io -4 0x201E02C0 0x3F000300
		level2	0x201E02C0	[8,13]	7	io -4 0x201E02C0 0x3F000700
		level3	0x201E02C0	[8,13]	15	io -4 0x201E02C0 0x3F000F00
		level4	0x201E02C0	[8,13]	31	io -4 0x201E02C0 0x3F001F00
		level5	0x201E02C0	[8,13]	63	io -4 0x201E02C0 0x3F003F00
	ExtPort	read gpio data in input	0x21B00070	[1,1]		io -4 0x21B00070
GPIO7A2	IOmux	SAIO_MCLK_M0	0x201E00E0	[8,11]	1	io -4 0x201E00E0 0x0F000100
		PWM2_CH6_M1	0x201E00E0	[8,11]	5	io -4 0x201E00E0 0x0F000500
		GPIO7_A2	0x201E00E0	[8,11]	0	io -4 0x201E00E0 0x0F000000
	Pull	z	0x201E0370	[4,5]	0	io -4 0x201E0370 0x00300000
		up	0x201E0370	[4,5]	1	io -4 0x201E0370 0x00300010
		down	0x201E0370	[4,5]	2	io -4 0x201E0370 0x00300020
	I/O Mode	input	0x21B00008	[2,2]	0	io -4 0x21B00008 0x00040000
		output	0x21B00008	[2,2]	1	io -4 0x21B00008 0x00040004
	Output	low	0x21B00000	[2,2]	0	io -4 0x21B00000 0x00040000
		high	0x21B00000	[2,2]	1	io -4 0x21B00000 0x00040004
	Input Ctrl	disable	0x201E0470	[2,2]	0	io -4 0x201E0470 0x00040000
		enable	0x201E0470	[2,2]	1	io -4 0x201E0470 0x00040004
	Schmitt	disable	0x201E0570	[2,2]	0	io -4 0x201E0570 0x00040000
		enable	0x201E0570	[2,2]	1	io -4 0x201E0570 0x00040004
	Drive Strength	level0	0x201E02C4	[0,5]	1	io -4 0x201E02C4 0x003F0001
		level1	0x201E02C4	[0,5]	3	io -4 0x201E02C4 0x003F0003
		level2	0x201E02C4	[0,5]	7	io -4 0x201E02C4 0x003F0007
		level3	0x201E02C4	[0,5]	15	io -4 0x201E02C4 0x003F000F
		level4	0x201E02C4	[0,5]	31	io -4 0x201E02C4 0x003F001F
		level5	0x201E02C4	[0,5]	63	io -4 0x201E02C4 0x003F003F
	ExtPort	read gpio data in input	0x21B00070	[2,2]		io -4 0x21B00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO7A3	IOMUX	SAIO_LRCK_M0	0x201E00E0	[12,15]	1	io -4 0x201E00E0 0xF0001000
		DSM_AUD_LN	0x201E00E0	[12,15]	4	io -4 0x201E00E0 0xF0004000
		PWM2_CH7_M1	0x201E00E0	[12,15]	5	io -4 0x201E00E0 0xF0005000
		GPIO7_A3	0x201E00E0	[12,15]	0	io -4 0x201E00E0 0xF0000000
	Pull	z	0x201E0370	[6,7]	0	io -4 0x201E0370 0x00C00000
		up	0x201E0370	[6,7]	1	io -4 0x201E0370 0x00C00040
		down	0x201E0370	[6,7]	2	io -4 0x201E0370 0x00C00080
	I/O Mode	input	0x21B00008	[3,3]	0	io -4 0x21B00008 0x00080000
		output	0x21B00008	[3,3]	1	io -4 0x21B00008 0x00080008
	Output	low	0x21B00000	[3,3]	0	io -4 0x21B00000 0x00080000
		high	0x21B00000	[3,3]	1	io -4 0x21B00000 0x00080008
	Input Ctrl	disable	0x201E0470	[3,3]	0	io -4 0x201E0470 0x00080000
		enable	0x201E0470	[3,3]	1	io -4 0x201E0470 0x00080008
	Schmitt	disable	0x201E0570	[3,3]	0	io -4 0x201E0570 0x00080000
		enable	0x201E0570	[3,3]	1	io -4 0x201E0570 0x00080008
	Drive Strength	level0	0x201E02C4	[8,13]	1	io -4 0x201E02C4 0x3F000100
		level1	0x201E02C4	[8,13]	3	io -4 0x201E02C4 0x3F000300
		level2	0x201E02C4	[8,13]	7	io -4 0x201E02C4 0x3F000700
		level3	0x201E02C4	[8,13]	15	io -4 0x201E02C4 0x3F000F00
		level4	0x201E02C4	[8,13]	31	io -4 0x201E02C4 0x3F001F00
		level5	0x201E02C4	[8,13]	63	io -4 0x201E02C4 0x3F003F00
	ExtPort	read gpio data in input	0x21B00070	[3,3]		io -4 0x21B00070
GPIO7A4	IOMUX	PDM_CLK0_M0	0x201E00E4	[0,3]	3	io -4 0x201E00E4 0x000F0003
		UART2_CTSN_M1	0x201E00E4	[0,3]	6	io -4 0x201E00E4 0x000F0006
		GPIO7_A4	0x201E00E4	[0,3]	0	io -4 0x201E00E4 0x000F0000
	Pull	z	0x201E0370	[8,9]	0	io -4 0x201E0370 0x03000000
		up	0x201E0370	[8,9]	1	io -4 0x201E0370 0x03000100
		down	0x201E0370	[8,9]	2	io -4 0x201E0370 0x03000200
	I/O Mode	input	0x21B00008	[4,4]	0	io -4 0x21B00008 0x00100000
		output	0x21B00008	[4,4]	1	io -4 0x21B00008 0x00100010
	Output	low	0x21B00000	[4,4]	0	io -4 0x21B00000 0x00100000
		high	0x21B00000	[4,4]	1	io -4 0x21B00000 0x00100010
	Input Ctrl	disable	0x201E0470	[4,4]	0	io -4 0x201E0470 0x00100000
		enable	0x201E0470	[4,4]	1	io -4 0x201E0470 0x00100010
	Schmitt	disable	0x201E0570	[4,4]	0	io -4 0x201E0570 0x00100000
		enable	0x201E0570	[4,4]	1	io -4 0x201E0570 0x00100010
	Drive Strength	level0	0x201E02C8	[0,5]	1	io -4 0x201E02C8 0x003F0001
		level1	0x201E02C8	[0,5]	3	io -4 0x201E02C8 0x003F0003
		level2	0x201E02C8	[0,5]	7	io -4 0x201E02C8 0x003F0007
		level3	0x201E02C8	[0,5]	15	io -4 0x201E02C8 0x003F000F
		level4	0x201E02C8	[0,5]	31	io -4 0x201E02C8 0x003F001F
		level5	0x201E02C8	[0,5]	63	io -4 0x201E02C8 0x003F003F
	ExtPort	read gpio data in input	0x21B00070	[4,4]		io -4 0x21B00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO7A5	IOmux	SAIO_SDO0_M0	0x201E00E4	[4,7]	1	io -4 0x201E00E4 0x00F00010
		DSM_AUD_LP	0x201E00E4	[4,7]	4	io -4 0x201E00E4 0x00F00040
		GPIO7_A5	0x201E00E4	[4,7]	0	io -4 0x201E00E4 0x00F00000
	Pull	z	0x201E0370	[10,11]	0	io -4 0x201E0370 0x0C000000
		up	0x201E0370	[10,11]	1	io -4 0x201E0370 0x0C000400
		down	0x201E0370	[10,11]	2	io -4 0x201E0370 0x0C000800
	I/O Mode	input	0x21B00008	[5,5]	0	io -4 0x21B00008 0x00200000
		output	0x21B00008	[5,5]	1	io -4 0x21B00008 0x00200020
	Output	low	0x21B00000	[5,5]	0	io -4 0x21B00000 0x00200000
		high	0x21B00000	[5,5]	1	io -4 0x21B00000 0x00200020
	Input Ctrl	disable	0x201E0470	[5,5]	0	io -4 0x201E0470 0x00200000
		enable	0x201E0470	[5,5]	1	io -4 0x201E0470 0x00200020
	Schmitt	disable	0x201E0570	[5,5]	0	io -4 0x201E0570 0x00200000
		enable	0x201E0570	[5,5]	1	io -4 0x201E0570 0x00200020
	Drive Strength	level0	0x201E02C8	[8,13]	1	io -4 0x201E02C8 0x3F000100
		level1	0x201E02C8	[8,13]	3	io -4 0x201E02C8 0x3F000300
		level2	0x201E02C8	[8,13]	7	io -4 0x201E02C8 0x3F000700
		level3	0x201E02C8	[8,13]	15	io -4 0x201E02C8 0x3F000F00
		level4	0x201E02C8	[8,13]	31	io -4 0x201E02C8 0x3F001F00
		level5	0x201E02C8	[8,13]	63	io -4 0x201E02C8 0x3F003F00
	ExtPort	read gpio data in input	0x21B00070	[5,5]		io -4 0x21B00070
GPIO7A6	IOmux	SAIO_SDI0_M0	0x201E00E4	[8,11]	1	io -4 0x201E00E4 0x0F000100
		PDM_SDI0_M0	0x201E00E4	[8,11]	3	io -4 0x201E00E4 0x0F000300
		GPIO7_A6	0x201E00E4	[8,11]	0	io -4 0x201E00E4 0x0F000000
	Pull	z	0x201E0370	[12,13]	0	io -4 0x201E0370 0x30000000
		up	0x201E0370	[12,13]	1	io -4 0x201E0370 0x30001000
		down	0x201E0370	[12,13]	2	io -4 0x201E0370 0x30002000
	I/O Mode	input	0x21B00008	[6,6]	0	io -4 0x21B00008 0x00400000
		output	0x21B00008	[6,6]	1	io -4 0x21B00008 0x00400040
	Output	low	0x21B00000	[6,6]	0	io -4 0x21B00000 0x00400000
		high	0x21B00000	[6,6]	1	io -4 0x21B00000 0x00400040
	Input Ctrl	disable	0x201E0470	[6,6]	0	io -4 0x201E0470 0x00400000
		enable	0x201E0470	[6,6]	1	io -4 0x201E0470 0x00400040
	Schmitt	disable	0x201E0570	[6,6]	0	io -4 0x201E0570 0x00400000
		enable	0x201E0570	[6,6]	1	io -4 0x201E0570 0x00400040
	Drive Strength	level0	0x201E02CC	[0,5]	1	io -4 0x201E02CC 0x003F0001
		level1	0x201E02CC	[0,5]	3	io -4 0x201E02CC 0x003F0003
		level2	0x201E02CC	[0,5]	7	io -4 0x201E02CC 0x003F0007
		level3	0x201E02CC	[0,5]	15	io -4 0x201E02CC 0x003F000F
		level4	0x201E02CC	[0,5]	31	io -4 0x201E02CC 0x003F001F
		level5	0x201E02CC	[0,5]	63	io -4 0x201E02CC 0x003F003F
	ExtPort	read gpio data in input	0x21B00070	[6,6]		io -4 0x21B00070
	IOmux	SAIO_SDI3_M0	0x201E00E4	[12,15]	1	io -4 0x201E00E4 0xF0001000
		SAIO_SDO1_M0	0x201E00E4	[12,15]	2	io -4 0x201E00E4 0xF0002000
		PDM_SDI3_M0	0x201E00E4	[12,15]	3	io -4 0x201E00E4 0xF0003000
		UART2_RTSN_M1	0x201E00E4	[12,15]	6	io -4 0x201E00E4 0xF0006000
		GPIO7_A7	0x201E00E4	[12,15]	0	io -4 0x201E00E4 0xF0000000

Name	Config	Description	Register	Position	Value	IO Command
GPIO7A7	Pull	z	0x201E0370	[14,15]	0	io -4 0x201E0370 0xC0000000
		up	0x201E0370	[14,15]	1	io -4 0x201E0370 0xC0004000
		down	0x201E0370	[14,15]	2	io -4 0x201E0370 0xC0008000
	I/O Mode	input	0x21B00008	[7,7]	0	io -4 0x21B00008 0x00800000
		output	0x21B00008	[7,7]	1	io -4 0x21B00008 0x00800080
	Output	low	0x21B00000	[7,7]	0	io -4 0x21B00000 0x00800000
		high	0x21B00000	[7,7]	1	io -4 0x21B00000 0x00800080
	Input Ctrl	disable	0x201E0470	[7,7]	0	io -4 0x201E0470 0x00800000
		enable	0x201E0470	[7,7]	1	io -4 0x201E0470 0x00800080
	Schmitt	disable	0x201E0570	[7,7]	0	io -4 0x201E0570 0x00800000
		enable	0x201E0570	[7,7]	1	io -4 0x201E0570 0x00800080
	Drive Strength	level0	0x201E02CC	[8,13]	1	io -4 0x201E02CC 0x3F000100
		level1	0x201E02CC	[8,13]	3	io -4 0x201E02CC 0x3F000300
		level2	0x201E02CC	[8,13]	7	io -4 0x201E02CC 0x3F000700
		level3	0x201E02CC	[8,13]	15	io -4 0x201E02CC 0x3F000F00
		level4	0x201E02CC	[8,13]	31	io -4 0x201E02CC 0x3F001F00
		level5	0x201E02CC	[8,13]	63	io -4 0x201E02CC 0x3F003F00
	ExtPort	read gpio data in input	0x21B00070	[7,7]		io -4 0x21B00070
GPIO7B0	IOmux	SAI0_SDI2_M0	0x201E00E8	[0,3]	1	io -4 0x201E00E8 0x000F0001
		SAI0_SDO2_M0	0x201E00E8	[0,3]	2	io -4 0x201E00E8 0x000F0002
		PDM_SDI2_M0	0x201E00E8	[0,3]	3	io -4 0x201E00E8 0x000F0003
		DSM_AUD_RN	0x201E00E8	[0,3]	4	io -4 0x201E00E8 0x000F0004
		I2C1_SCL_M3	0x201E00E8	[0,3]	5	io -4 0x201E00E8 0x000F0005
		UART2_RX_M1	0x201E00E8	[0,3]	6	io -4 0x201E00E8 0x000F0006
		GPIO7_B0	0x201E00E8	[0,3]	0	io -4 0x201E00E8 0x000F0000
	Pull	z	0x201E0374	[0,1]	0	io -4 0x201E0374 0x00030000
		up	0x201E0374	[0,1]	1	io -4 0x201E0374 0x00030001
		down	0x201E0374	[0,1]	2	io -4 0x201E0374 0x00030002
	I/O Mode	input	0x21B00008	[8,8]	0	io -4 0x21B00008 0x01000000
		output	0x21B00008	[8,8]	1	io -4 0x21B00008 0x01000100
	Output	low	0x21B00000	[8,8]	0	io -4 0x21B00000 0x01000000
		high	0x21B00000	[8,8]	1	io -4 0x21B00000 0x01000100
	Input Ctrl	disable	0x201E0474	[0,0]	0	io -4 0x201E0474 0x00010000
		enable	0x201E0474	[0,0]	1	io -4 0x201E0474 0x00010001
	Schmitt	disable	0x201E0574	[0,0]	0	io -4 0x201E0574 0x00010000
		enable	0x201E0574	[0,0]	1	io -4 0x201E0574 0x00010001
	Drive Strength	level0	0x201E02D0	[0,5]	1	io -4 0x201E02D0 0x003F0001
		level1	0x201E02D0	[0,5]	3	io -4 0x201E02D0 0x003F0003
		level2	0x201E02D0	[0,5]	7	io -4 0x201E02D0 0x003F0007
		level3	0x201E02D0	[0,5]	15	io -4 0x201E02D0 0x003F000F
		level4	0x201E02D0	[0,5]	31	io -4 0x201E02D0 0x003F001F
		level5	0x201E02D0	[0,5]	63	io -4 0x201E02D0 0x003F003F
	ExtPort	read gpio data in input	0x21B00070	[8,8]		io -4 0x21B00070

Name	Config	Description	Register	Position	Value	IO Command
GPIO7B1	IOmux	SAIO_SDI1_M0	0x201E00E8	[4,7]	1	io -4 0x201E00E8 0x00F00010
		SAIO_SDO3_M0	0x201E00E8	[4,7]	2	io -4 0x201E00E8 0x00F00020
		PDM_SDI1_M0	0x201E00E8	[4,7]	3	io -4 0x201E00E8 0x00F00030
		DSM_AUD_RP	0x201E00E8	[4,7]	4	io -4 0x201E00E8 0x00F00040
		I2C1_SDA_M3	0x201E00E8	[4,7]	5	io -4 0x201E00E8 0x00F00050
		UART2_TX_M1	0x201E00E8	[4,7]	6	io -4 0x201E00E8 0x00F00060
		GPIO7_B1	0x201E00E8	[4,7]	0	io -4 0x201E00E8 0x00F00000
	Pull	z	0x201E0374	[2,3]	0	io -4 0x201E0374 0x000C0000
		up	0x201E0374	[2,3]	1	io -4 0x201E0374 0x000C0004
		down	0x201E0374	[2,3]	2	io -4 0x201E0374 0x000C0008
	I/O Mode	input	0x21B00008	[9,9]	0	io -4 0x21B00008 0x02000000
		output	0x21B00008	[9,9]	1	io -4 0x21B00008 0x02000200
	Output	low	0x21B00000	[9,9]	0	io -4 0x21B00000 0x02000000
		high	0x21B00000	[9,9]	1	io -4 0x21B00000 0x02000200
	Input Ctrl	disable	0x201E0474	[1,1]	0	io -4 0x201E0474 0x00020000
		enable	0x201E0474	[1,1]	1	io -4 0x201E0474 0x00020002
	Schmitt	disable	0x201E0574	[1,1]	0	io -4 0x201E0574 0x00020000
		enable	0x201E0574	[1,1]	1	io -4 0x201E0574 0x00020002
	Drive Strength	level0	0x201E02D0	[8,13]	1	io -4 0x201E02D0 0x3F000100
		level1	0x201E02D0	[8,13]	3	io -4 0x201E02D0 0x3F000300
		level2	0x201E02D0	[8,13]	7	io -4 0x201E02D0 0x3F000700
		level3	0x201E02D0	[8,13]	15	io -4 0x201E02D0 0x3F000F00
		level4	0x201E02D0	[8,13]	31	io -4 0x201E02D0 0x3F001F00
		level5	0x201E02D0	[8,13]	63	io -4 0x201E02D0 0x3F003F00
	ExtPort	read gpio data in input	0x21B00070	[9,9]		io -4 0x21B00070