

# **Virtual Color Wheel Chart**

DMX CHANNEL VALUE	DISPLAY READOUT	RED VALUE	GREEN VALUE	BLUE VALUE	AMBER VALUE	LIME VALUE
000 ⇔ 005		000	000	000	000	000
006 ⇔ 013	R4590-Cal90 Yellow	150	125	002	255	043
014 ⇔ 021	R11-Light Straw	235	108	005	255	076
022 ⇔ 028	R312-Canary	171	036	000	120	255
029 ⇔ 035	R03-Dark B Amber	255	015	017	255	170
036 ⇔ 043	R18-Flame	255	000	010	255	143
044 ⇔ 051	R20-Medium Amber	255	000	003	255	075
052 ⇔ 059	R21-Golden Amber	188	000	002	255	044
060 ⇔ 067	R26-Light Red	255	000	002	021	002
068 ⇔ 075	R27-Medium Red	255	000	002	000	000
076 ⇔ 083	R33-No Color Pink	255	130	025	255	027
084 ⇔ 091	R337-True Pink	255	013	041	235	182
092 ⇔ 099	R38-Light Rose	255	015	027	030	255
100 ⇔ 107	R41-Salmon	255	000	004	115	009
108 ⇔ 115	R42-Deep Salmon	255	000	004	011	800
116 ⇔ 121	R44-Middle Rose	255	000	022	081	039
122 ⇔ 130	R349-Fisher Fuchsia	160	000	025	000	004
131 ⇔ 138	R54-Special Lavender	255	162	043	255	140
139 ⇔ 146	R64-Light Steel Blue	012	255	070	076	115
147 ⇔ 154	R364-Blue Bell	030	187	085	215	255
155 ⇔ 162	R65-Daylight Blue	004	255	062	093	049
163 ⇔ 170	R80-Primary Blue	005	255	190	003	012
171 ⇔ 178	R81-Urban Blue	800	250	145	005	088
179 ⇔ 186	R82-Surprise Blue	005	209	255	015	074
187 ⇔ 194	R382-Congo Blue	005	000	200	013	003
195 ⇔ 202	R83-Medium Blue	007	112	255	005	007
203 ⇔ 210	R383-Sapphire Blue	004	108	255	003	004
211 ⇔ 218	R90-Dk Yellow Green	004	255	000	005	003
219 ⇔ 226	R91-Primary Green	027	255	006	000	020
227 ⇔ 234	R92-Turquoise	007	255	021	070	076
235 ⇔ 242	R93-Blue Green	007	255	031	085	115
<b>243</b> ⇔ <b>250</b>	R393-Emerald Green	002	255	017	002	020
251 ⇔ 255		000	000	000	000	000

# **Color Temperature Chart**

DMX CHANNEL VALUE	DISPLAY READOUT	RED VALUE	GREEN VALUE	BLUE VALUE	AMBER VALUE	LIME VALUE
000 ⇔ 005		000	000	000	000	000
006 ⇔ 025	2800K	255	51	18	255	255
026 ⇔ 050	3200K	179	82	25	185	220
051 ⇔ 075	3500K	255	130	33	255	240
076 ⇔ 100	4000K	255	219	45	198	255
101 ⇔ 125	4500K	140	255	55	255	255
126 ⇔ 150	5000K	107	255	63	200	255
151 ⇔ 175	5600K	82	255	72	190	230
176 ⇔ 200	6000K	74	255	78	167	255
201 ⇔ 225	6500K	65	255	84	140	255
226 ⇔ 255		000	000	000	000	000



# **DMX Values**

### 2-Cell Personalities

### 2-Cell RGBAL FULL 31CH

CHANNEL	FUNCTION	VALUE	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Red Fine 1	000 ⇔ 255	0–100%
5	Green 1	000 ⇔ 255	0–100%
6	Green Fine 1	000 ⇔ 255	0–100%
7	Blue 1	000 ⇔ 255	0–100%
8	Blue Fine 1	000 ⇔ 255	0–100%
9	Amber 1	000 ⇔ 255	0–100%
10	Amber Fine 1	000 ⇔ 255	0–100%
11	Lime 1	000 ⇔ 255	0–100%
12	Lime Fine 1	000 ⇔ 255	0–100%
13	Virtual Color Wheel 1	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
14	Color Temperature 1	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
15	Strobe 1	000 ⇔ 010	No function
		011 ⇔ 255	Strobe, slow to fast
16	Red 2	000 ⇔ 255	0–100%
17	Red Fine 2	000 ⇔ 255	0–100%
18	Green 2	000 ⇔ 255	0–100%
19	Green Fine 2	000 ⇔ 255	0–100%
20	Blue 2	000 ⇔ 255	0–100%
21	Blue Fine 2	000 ⇔ 255	0–100%
22	Amber 2	000 ⇔ 255	0–100%
23	Amber Fine 2	000 ⇔ 255	0–100%
24	Lime 2	000 ⇔ 255	0–100%
25	Lime Fine 2	000 ⇔ 255	0–100%
26	Virtual Color Wheel 2	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
27	Color Temperature 2	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
28	Strobe 2	000 ⇔ 010	No function
20	July 2	011 ⇔ 255	Strobe, slow to fast
29	Strobe All	000 ⇔ 010	No function
23	Sti Obe All	011 ⇔ 255	Strobe, slow to fast
30	Color Macros	000 ⇔ 015	No function
30	COIDI IVIACIOS	016 ⇔ 255	Color macros
		000 ⇔ 051	Preset dimmer speed from display menu
		052 ⇔ 101	Dimmer speed mode off
31	Dimmer Speed	102 ⇔ 152	Dimmer speed mode 1 (fastest)
		153 ⇔ 203	Dimmer speed mode 2
		204 ⇔ 255	Dimmer speed mode 3 (slowest)



### 2-Cell RGBAL Fine 20CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red 1	000 ⇔ 255	0–100%
2	Red Fine 1	000 ⇔ 255	0–100%
3	Green 1	000 ⇔ 255	0–100%
4	Green Fine 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Blue Fine 1	000 ⇔ 255	0–100%
7	Amber 1	000 ⇔ 255	0–100%
8	Amber Fine 1	000 ⇔ 255	0–100%
9	Lime 1	000 ⇔ 255	0–100%
10	Lime Fine 1	000 ⇔ 255	0–100%
11	Red 2	000 ⇔ 255	0–100%
12	Red Fine 2	000 ⇔ 255	0–100%
13	Green 2	000 ⇔ 255	0–100%
14	Green Fine 2	000 ⇔ 255	0–100%
15	Blue 2	000 ⇔ 255	0–100%
16	Blue Fine 2	000 ⇔ 255	0–100%
17	Amber 2	000 ⇔ 255	0–100%
18	Amber Fine 2	000 ⇔ 255	0–100%
19	Lime 2	000 ⇔ 255	0–100%
20	Lime Fine 2	000 ⇔ 255	0–100%

### 2-Cell RGBAL EXT 19CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Green 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Amber 1	000 ⇔ 255	0–100%
7	Lime 1	000 ⇔ 255	0–100%
8	Virtual Color Wheel 1	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
9	Color Temperature 1	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
10	Strobe 1	000 ⇔ 010	No function
10		011 ⇔ 255	Strobe, slow to fast
11	Red 2	000 ⇔ 255	0–100%
12	Green 2	000 ⇔ 255	0–100%
13	Blue 2	000 ⇔ 255	0–100%
14	Amber 2	000 ⇔ 255	0–100%
15	Lime 2	000 ⇔ 255	0–100%
16	Virtual Color Wheel 2	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
17	Color Temperature 2	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
18	Strobe 2	000 ⇔ 010	No function
		011 ⇔ 255	Strobe, slow to fast
19	Strobe All	000 ⇔ 010	No function
.5	Strobe All	011 ⇔ 255	Strobe, slow to fast



### 2-Cell RGBA EXT 17CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Green 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Amber 1	000 ⇔ 255	0–100%
7	Virtual Color Wheel 1	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
8	Color Temperature 1	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇔ 010	No function
3		011 ⇔ 255	Strobe, slow to fast
10	Red 2	000 ⇔ 255	0–100%
11	Green 2	000 ⇔ 255	0–100%
12	Blue 2	000 ⇔ 255	0–100%
13	Amber 2	000 ⇔ 255	0–100%
14	Virtual Color Wheel 2	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
15	Color Temperature 2	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇔ 010	No function
10	Strope 2	011 ⇔ 255	Strobe, slow to fast
17	Strobe All	000 ⇔ 010	No function
17	Strobe All	011 ⇔ 255	Strobe, slow to fast

### 2-Cell RGB EXT 15CH

CHANNEL	Function	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Green 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Virtual Color Wheel 1	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
7	Color Temperature 1	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇔ 010	No function
Ū		011 ⇔ 255	Strobe, slow to fast
9	Red 2	000 ⇔ 255	0–100%
10	Green 2	000 ⇔ 255	0–100%
11	Blue 2	000 ⇔ 255	0–100%
12	Virtual Color Wheel 2	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
13	Color Temperature 2	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
14	14 Strobe 2	000 ⇔ 010	No function
14	Julione Z	011 ⇔ 255	Strobe, slow to fast
15	Strobe All	000 ⇔ 010	No function
13	Strone All	011 ⇔ 255	Strobe, slow to fast



### 2-Cell RGBAL 10CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red 1	000 ⇔ 255	0–100%
2	Green 1	000 ⇔ 255	0–100%
3	Blue 1	000 ⇔ 255	0–100%
4	Amber 1	000 ⇔ 255	0–100%
5	Lime 1	000 ⇔ 255	0–100%
6	Red 2	000 ⇔ 255	0–100%
7	Green 2	000 ⇔ 255	0–100%
8	Blue 2	000 ⇔ 255	0–100%
9	Amber 2	000 ⇔ 255	0–100%
10	Lime 2	000 ⇔ 255	0–100%

### 2-Cell RGBA 8CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red 1	000 ⇔ 255	0–100%
2	Green 1	000 ⇔ 255	0–100%
3	Blue 1	000 ⇔ 255	0–100%
4	Amber 1	000 ⇔ 255	0–100%
5	Red 2	000 ⇔ 255	0–100%
6	Green 2	000 ⇔ 255	0–100%
7	Blue 2	000 ⇔ 255	0–100%
8	Amber 2	000 ⇔ 255	0–100%

### 2-Cell RGB 6CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red 1	000 ⇔ 255	0–100%
2	Green 1	000 ⇔ 255	0–100%
3	Blue 1	000 ⇔ 255	0–100%
4	Red 2	000 ⇔ 255	0–100%
5	Green 2	000 ⇔ 255	0–100%
6	Blue 2	000 ⇔ 255	0–100%



### **1-Cell Personalities**

### 1-Cell RGBAL FULL 17CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Red Fine	000 ⇔ 255	0–100%
5	Green	000 ⇔ 255	0–100%
6	Green Fine	000 ⇔ 255	0–100%
7	Blue	000 ⇔ 255	0–100%
8	Blue Fine	000 ⇔ 255	0–100%
9	Amber	000 ⇔ 255	0–100%
10	Amber Fine	000 ⇔ 255	0–100%
11	Lime	000 ⇔ 255	0–100%
12	Lime Fine	000 ⇔ 255	0–100%
13	Virtual Color Wheel	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
14	Color Temperature	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe	000 ⇔ 010	No function
13	Strobe	011 ⇔ 255	Strobe, slow to fast
16	Color Macros	000 ⇔ 015	No function
10	COIOI WIACIOS	016 ⇔ 255	Color macros
		000 ⇔ 051	Preset dimmer speed from display menu
		052 ⇔ 101	Dimmer speed mode off
17	Dimmer Speed	102 ⇔ 152	Dimmer speed mode 1 (fastest)
		153 ⇔ 203	Dimmer speed mode 2
		204 ⇔ 255	Dimmer speed mode 3 (slowest)

### 1-Cell RGBAL Fine 10CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red	000 ⇔ 255	0–100%
2	Red Fine	000 ⇔ 255	0–100%
3	Green	000 ⇔ 255	0–100%
4	Green Fine	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Blue Fine	000 ⇔ 255	0–100%
7	Amber	000 ⇔ 255	0–100%
8	Amber Fine	000 ⇔ 255	0–100%
9	Lime	000 ⇔ 255	0–100%
10	Lime Fine	000 ⇔ 255	0–100%



### 1-Cell RGBAL EXT 10CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Green	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Amber	000 ⇔ 255	0–100%
7	Lime	000 ⇔ 255	0–100%
8	Virtual Color Wheel	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
9	Color Temperature	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
10	Strobe	000 ⇔ 010 011 ⇔ 255	No function Strobe, slow to fast

### 1-Cell RGBA EXT 9CH

CHANNEL	Function	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Green	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Amber	000 ⇔ 255	0–100%
7	Virtual Color Wheel	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
8	Color Temperature	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe	000 ⇔ 010 011 ⇔ 255	No function Strobe, slow to fast

#### 1-Cell RGB EXT 8CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer Fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Green	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Virtual Color Wheel	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
7	Color Temperature	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values
8	Strobe	000 ⇔ 010 011 ⇔ 255	No function Strobe, slow to fast

### 1-Cell RGBAL 5CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%
4	Amber	000 ⇔ 255	0–100%
5	Lime	000 ⇔ 255	0–100%



### 1-Cell RGBA 4CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%
4	Amber	000 ⇔ 255	0–100%

### 1-Cell RGB 3CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%

### 1-Cell DMX-VCW-CCT 3CH

CHANNEL	FUNCTION	VALUE	PERCENT/SETTING
1	Dimmer	000 ⇔ 255	0–100%
2	Virtual Color Wheel	000 ⇔ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
3	Color Temperature	000 ⇔ 255	Refer to the <u>Color Temperature Chart</u> section for specific values