

DMX Values

10-C

-Cell Per	sonaliti	es		
10-Cell			Value	Percent/Setting
RGBAL		Dimmer	000ó 255	•
FULL		Dimmer Fine	000ó 255	
135CH		Red 1	000ó 255	
133611	4	Red Fine 1	000ó 255	
-	5	Green 1	000ó 255	
-	6	Green Fine 1	000ó 255	0–100%
-	7	Blue 1	000ó 255	0–100%
-	8	Blue Fine 1	000ó 255	0–100%
-	9	Amber 1	000ó 255	0–100%
-	10	Amber Fine 1	000ó 255	0–100%
	11	Lime 1	000ó 255	0–100%
	12	Lime Fine 1	000ó 255	0–100%
	13	Virtual Color Wheel	000ó 255	Refer to the Virtual Color Wheel Chart section
-		1	0000 200	ior specific values
	14	Color Temperature	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-		1		No function
	15	Strobe 1		Strobe, slow to fast
-	16	Red 2	000ó 255	*
-	17	Red Fine 2	0006 255	
-	18	Green 2	0006 255	
-	19	Green Fine 2	000ó 255	
-	20	Blue 2	000ó 255	
-	21	Blue Fine 2	000ó 255	
-	22	Amber 2	000ó 255	
-	23	Amber Fine 2	000ó 255	
-	24	Lime 2	000ó 255	0–100%
-	25	Lime Fine 2	000ó 255	0–100%
-	26	Virtual Color Wheel	000ക് 255	Refer to the <u>Virtual Color Wheel Chart</u> section
_	20	2	0000 233	ror specific values
	27	Color Temperature	000෮ 255	Refer to the Preset Color Temperature Chart
-		2		section for specific values No function
	28	Strobe 2		
-	29	Red 3	000ó 255	Strobe, slow to fast
-	30	Red Fine 3	0000 255	
-	31	Green 3	0000 255	
-	32	Green Fine 3	0000 255	
-	33	Blue 3	000Ó 255	
-	34	Blue Fine 3	000ó 255	
-	35	Amber 3	000Ó 255	
-	36	Amber Fine 3	000ó 255	
-	37	Lime 3	000ó 255	
-	38	Lime Fine 3	000ó 255	
		•	•	•



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL		Virtual Color Wheel		Pefer to the Virtual Color Wheel Chart section
FULL	39	3	000ó 255	for specific values
	40	Color Temperature	000 4 055	Refer to the Preset Color Temperature Chart
135CH	40	3	000ó 255	section for specific values
(cont.)	41	Strobe 3		No function
	71	Strobe 3	0116255	Strobe, slow to fast
	42	Red 4	000ó 255	0–100%
-	43	Red Fine 4	000ó 255	0–100%
-	44	Green 4	000ó 255	
-	45	Green Fine 4	000ó 255	0–100%
-	46	Blue 4	000ó 255	
	47	Blue Fine 4	000ó 255	
-	48	Amber 4	000ó 255	
-	49	Amber Fine 4	000ó 255	
-	50	Lime 4	000ó 255	
-	51	Lime Fine 4	000ó 255	
	52	Virtual Color Wheel	000ó 255	Refer to the Virtual Color Wheel Chart section
-		Color Townserstone		for specific values
	53	Color Temperature	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-		7	000റ് 010	No function
	54	Strobe 4		Strobe, slow to fast
-	55	Red 5	000ó 255	·
-	56	Red Fine 5	000ó 255	
-	57	Green 5	000ó 255	
-	58	Green Fine 5	000ó 255	
-	59	Blue 5	000ó 255	
-	60	Blue Fine 5	000ó 255	0–100%
-	61	Amber 5	000ó 255	0–100%
•	62	Amber Fine 5	000ó 255	0–100%
•	63	Lime 5	000ó 255	0–100%
-	64	Lime Fine 5	000ó 255	0–100%
	65	Virtual Color Wheel 5	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
•	66	Color Temperature 5	0006 255	Refer to the Preset Color Temperature Chart section for specific values
-	67	Strobe E	000ó 010	No function
	67	Strobe 5	011ó 255	Strobe, slow to fast
-	68	Red 6	000ó 255	0–100%
- -	69	Red Fine 6	000ó 255	0–100%
- -	70	Green 6	000ó 255	0–100%
- -	71	Green Fine 6	000ó 255	0–100%
-	72	Blue 6	000෮ 255	0–100%
-	73	Blue Fine 6	0006 255	
-	74	Amber 6	000ó 255	0–100%
	75	Amber Fine 6	0006 255	
	76	Lime 6	0006 255	0–100%



	Channel	Function	Value	Percent/Setting
RGBAL	77	Lime Fine 6	000ക് 255	0-100%
FULL		Virtual Color Wheel		Refer to the <u>Virtual Color Wheel Chart</u> section
	78	6	000ó 255	for specific values
135CH-	79	Color Temperature	000ó 255	Refer to the Preset Color Temperature Chart
(cont.)	19	6	0000 255	section for specific values
•	80	Strobe 6	0006 010	No function
_		Oll obe 0		Strobe, slow to fast
<u>-</u>	81	Red 7	000ó 255	0–100%
_	82	Red Fine 7	000ó 255	
_	83	Green 7	000ó 255	0–100%
_	84	Green Fine 7	000ó 255	0–100%
_	85	Blue 7	000ó 255	0–100%
_	86	Blue Fine 7	000ó 255	0–100%
_	87	Amber 7	000ó 255	0–100%
_	88	Amber Fine 7	000ó 255	0–100%
_	89	Lime 7	000ó 255	0–100%
_	90	Lime Fine 7	000ó 255	0–100%
	91	Virtual Color Wheel	000റ് 255	Refer to the <u>Virtual Color Wheel Chart</u> section
-		7		ror specific values
	92	Color Temperature	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-		1	000ക് 010	No function
	93	Strobe 7		Strobe, slow to fast
-	94	Red 8	000ó 255	-
-	95	Red Fine 8	0000 255	
-	96	Green 8	000Ó 255	
-	97	Green Fine 8	000Ó 255	
-	98	Blue 8	000Ó 255	
-	99	Blue Fine 8	000Ó 255	
-	100	Amber 8	000Ó 255	
-	101	Amber 6	000Ó 255	
=	102	Lime 8	000Ó 255	
=	103	Lime Fine 8	000Ó 255	
-		Virtual Color Wheel		Defends the Mintural Colon Wheel Chart costion
	104	8	000ó 255	for specific values
-	105	Color Temperature	000 4 055	Refer to the Preset Color Temperature Chart
_	105	8	000ó 255	section for specific values
	106	Strobe 8	0006 010	No function
_	100	Silobe 6	011ó 255	Strobe, slow to fast
_	107	Red 9	000෮ 255	
_	108	Red Fine 9	000෮ 255	0–100%
_	109	Green 9	000ර 255	0–100%
_	110	Green Fine 9	000ó 255	0–100%
_	111	Blue 9	000ර 255	0–100%
- -	112	Blue Fine 9	000෮ 255	0–100%
_	113	Amber 9	000෮ 255	
	114	Amber Fine 9	0006 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	115	Lime 9	000ó 255	0–100%
FULL	116	Lime Fine 9	000ó 255	0–100%
135CH	117	Virtual Color Wheel 9	000ó 255	ioi specific values
(cont.)	118	Color Temperature 9	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	119	Strobe 9		No function Strobe, slow to fast
-	120	Red 10	000ó 255	0–100%
-	121	Red Fine 10	000ó 255	0–100%
-	122	Green 10	000ó 255	0–100%
	123	Green Fine 10	000ó 255	0–100%
	124	Blue 10	000ó 255	0–100%
	125	Blue Fine 10	000ó 255	0–100%
_	126	Amber 10	000ó 255	0–100%
_	127	Amber Fine 10	000ó 255	0–100%
<u>-</u>	128	Lime 10	000ó 255	0–100%
<u>-</u>	129	Lime Fine 10	000ó 255	
_	130	Virtual Color Wheel 10	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
_	131	Color Temperature 10	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
_	132	Strobe 10	000ó 010	No function
_	132		011ó 255	Strobe, slow to fast
	133	Strobe All		No function
<u>-</u>	100	Oll ODE All		Strobe, slow to fast
	134	Color Macros		No function
-		00.0		Color macros
				Preset dimmer speed from display menu
				Dimmer speed mode off
	135	Dimmer Speed		Dimmer speed mode 1 (fastest)
				Dimmer speed mode 2
			2046 255	Dimmer speed mode 3 (slowest)

10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Red 1	000ó 255	0–100%
Fine	2	Red Fine 1	000ó 255	0–100%
100CH	3	Green 1	000ó 255	0–100%
	4	Green Fine 1	000ó 255	0–100%
_	5	Blue 1	000ó 255	0–100%
_	6	Blue Fine 1	000ó 255	0–100%
_	7	Amber 1	000ó 255	0–100%
_	8	Amber Fine 1	000ó 255	0–100%
_	9	Lime 1	000ó 255	0–100%
_	10	Lime Fine 1	000ó 255	0–100%
	11	Red 2	000ó 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL		Red Fine 2	000ó 255	
Fine		Green 2	000Ó 255	
		Green Fine 2	000ó 255	
100CH	45	Blue 2	000ó 255	
(cont.)-	16	Blue Fine 2	000ó 255	
-	17	Amber 2	000ó 255	
-	18	Amber Fine 2	0006 255	
-	19	Lime 2	000ó 255	
-	20	Lime Fine 2	000ó 255	0–100%
-	21	Red 3	000ó 255	
-	22	Red Fine 3	000ó 255	0-100%
-	23	Green 3	000ó 255	0-100%
-	24	Green Fine 3	000ó 255	0-100%
-	25	Blue 3	000ó 255	0–100%
-	26	Blue Fine 3	000ó 255	
-	27	Amber 3	000ó 255	0–100%
-	28	Amber Fine 3	000ó 255	0–100%
-	29	Lime 3	000ó 255	0–100%
-	30	Lime Fine 3	000ó 255	0–100%
-	31	Red 4	000ó 255	0–100%
-	32	Red Fine 4	000ó 255	0–100%
-	33	Green 4	000ó 255	0–100%
-	34	Green Fine 4	000ó 255	0–100%
-	35	Blue 4	000ó 255	0–100%
_	36	Blue Fine 4	000ó 255	0–100%
_	37	Amber 4	000ó 255	0–100%
_	38	Amber Fine 4	000ó 255	0–100%
_	39	Lime 4	000ó 255	0–100%
_	40	Lime Fine 4	000ó 255	0–100%
-	41	Red 5	000ó 255	0–100%
-	42	Red Fine 5	000ó 255	
-	43	Green 5	000ó 255	
-	44	Green Fine 5	000ó 255	
-	45	Blue 5	0006 255	
-	46	Blue Fine 5	0006 255	
-	47	Amber 5	0006 255	
-	48	Amber Fine 5	0006 255	
-	49	Lime 5	000ó 255	
-	50	Lime Fine 5	000ó 255	
-	51	Red 6	000ó 255	
-	52	Red Fine 6	000ó 255	
-	53	Green 6	000ó 255	
-	54 55	Green Fine 6 Blue 6	000ó 255	
-			000ó 255	
-	56 57	Blue Fine 6 Amber 6	000ó 255 000ó 255	
	31	AIIIDEI 0	0000 200	JO-100 /0



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL		Amber Fine 6	000ó 255	•
Fine		Lime 6	0006 255	
100CH		Lime Fine 6	000ó 255	
	04	Red 7	000ó 255	
(cont.)	62	Red Fine 7	000ó 255	
•	63	Green 7	000ó 255	
•	64	Green Fine 7	000ó 255	
•	65	Blue 7	000ó 255	
•	66	Blue Fine 7	000ó 255	0–100%
•	67	Amber 7	000ó 255	0-100%
•	68	Amber Fine 7	000ó 255	0-100%
•	69	Lime 7	000ó 255	0-100%
•	70	Lime Fine 7	000ó 255	0–100%
•	71	Red 8	000ó 255	0–100%
•	72	Red Fine 8	000ó 255	0–100%
•	73	Green 8	000ó 255	0–100%
•	74	Green Fine 8	000ó 255	
•	75	Blue 8	000ó 255	0–100%
•	76	Blue Fine 8	000ó 255	0–100%
•	77	Amber 8	000ó 255	0–100%
•	78	Amber Fine 8	000ó 255	0–100%
•	79	Lime 8	000ó 255	0–100%
•	80	Lime Fine 8	000ó 255	0–100%
•	81	Red 9	000ó 255	0–100%
•	82	Red Fine 9	000ó 255	0–100%
•	83	Green 9	000ó 255	0–100%
•	84	Green Fine 9	000ó 255	0–100%
	85	Blue 9	000ó 255	0–100%
	86	Blue Fine 9	000ó 255	0–100%
	87	Amber 9	000ó 255	0–100%
	88	Amber Fine 9	000ó 255	0–100%
	89	Lime 9	000෮ 255	0–100%
	90	Lime Fine 9	000ó 255	0–100%
	91	Red 10	000ó 255	0–100%
	92	Red Fine 10	000ó 255	0–100%
	93	Green 10	000ó 255	
	94	Green Fine 10	000ó 255	
	95	Blue 10	000ó 255	
	96	Blue Fine 10	000෮ 255	
	97	Amber 10	000ó 255	
	98	Amber Fine 10	000ó 255	0–100%
	99	Lime 10	000ó 255	
	100	Lime Fine 10	000ó 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0-100%
83CH	3	Red 1	000ó 255	0–100%
03011	4	Green 1	000ó 255	0–100%
-	5	Blue 1	000ó 255	0–100%
-	6	Amber 1	000ó 255	0–100%
-	7	Lime 1	000ó 255	0–100%
-	8	Virtual Color Wheel 1	000ó 255	ioi specific values
_	9	Color Temperature 1	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	10	Strobe 1	000ó 010	No function
	10	Strobe i	011ó 255	Strobe, slow to fast
-	11	Red 2	000ó 255	0–100%
-	12	Green 2	000ó 255	0–100%
-	13	Blue 2	000ó 255	0–100%
-	14	Amber 2	000ó 255	0–100%
-	15	Lime 2	000ó 255	0–100%
-	16	Virtual Color Wheel 2	000෮ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	17	Color Temperature 2	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	18	Strobe 2	000ó 010	No function
_	10	Strobe 2	011ó 255	Strobe, slow to fast
<u>-</u>	19	Red 3	000ó 255	
_	20	Green 3	000ó 255	0–100%
_	21	Blue 3	000ó 255	
_	22	Amber 3	000ó 255	
_	23	Lime 3	000ó 255	0–100%
	24	Virtual Color Wheel 3	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	25	Color Temperature 3	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	26	Strobe 3		No function
-				Strobe, slow to fast
-	27	Red 4	000ó 255	
-	28	Green 4	000ó 255	
-	29	Blue 4	000ó 255	
-	30	Amber 4	000ó 255	
-	31	Lime 4	000ó 255	0–100%
_	32	Virtual Color Wheel 4		Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
<u>-</u>	33	Color Temperature 4	0000 255	section for specific values
	34	Strobe 4		No function Strobe, slow to fast



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	35	Red 5	000ó 255	<u> </u>
EXT	36	Green 5	000Ó 255	
		Blue 5	000Ó 255	
83CH	20	Amber 5	000Ó 255	
(cont.)	39	Lime 5	0000 255	
•	39	Virtual Color Wheel		Defende the Minterel Colon Mineral Charter estima
	40	5	000ó 255	for specific values
	41	Color Temperature 5	000ర 255	section for specific values
	42	Strobe 5		No function
	42	Red 6		Strobe, slow to fast
	43		000ó 255	
•	44	Green 6	0006 255	
	48	Blue 6	0006 255	
	46	Amber 6	000ó 255	
	47	Lime 6	000ó 255	
	48	Virtual Color Wheel 6	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	49	Color Temperature 6	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	50	Strobe 6		No function Strobe, slow to fast
•	51	Red 7	000ó 255	0–100%
•	52	Green 7	000ó 255	0–100%
•	53	Blue 7	000ó 255	0–100%
•	54	Amber 7	000ó 255	0–100%
•	55	Lime 7	000ó 255	0–100%
•	56	Virtual Color Wheel 7	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
•	57	Color Temperature 7	000෮ 255	Refer to the Preset Color Temperature Chart section for specific values
•	50	04b7	000ó 010	No function
	58	Strobe 7	0116 255	Strobe, slow to fast
•	59	Red 8	000ó 255	0–100%
•	60	Green 8	000ó 255	
•	61	Blue 8	000ó 255	
•	62	Amber 8	000ó 255	
•	63	Lime 8	000ó 255	
•	64	Virtual Color Wheel	0006 255	Pofor to the Virtual Color Wheel Chart costion
	65	Color Temperature 8	000ó 255	Refer to the Preset Color Temperature Chart
•	66	Strobe 8		No function Strobe, slow to fast
	67	Red 9	000ó 255	
	68	Green 9	000ó 255	
	69	Blue 9	000ó 255	JU-100%



10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	70	Amber 9	000ó 255	0–100%
EXT	71	Lime 9	000ó 255	0–100%
83CH	72	Virtual Color Wheel	000ó 255	Refer to the Virtual Color Wheel Chart section
(cont.)		9	0000 255	Tot specific values
(COIII.)	73	Color Temperature 9	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
_	74	Strobe 9	000ó 010	No function
_	74	Strobe 9	011ó 255	Strobe, slow to fast
_	75	Red 10	000ó 255	0–100%
-	76	Green 10	000ó 255	0–100%
-	77	Blue 10	000ó 255	0–100%
-	78	Amber 10	000ó 255	0–100%
-	79	Lime 10	000ó 255	0–100%
·	80	Virtual Color Wheel 10	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	81	Color Temperature 10	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
_	82	Strobe 10	000ó 010	No function
	02	Strope 10	011ó 255	Strobe, slow to fast
-		Strobe All	000ó 010	No function
	83	Strobe All	011ó 255	Strobe, slow to fast
10-Cell	Channel	Function	Value	Percent/Setting
RGBA	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0–100%
73CH	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
-	5	Blue 1	000ó 255	0–100%
-	6	Amber 1	000ó 255	0–100%
·	7	Virtual Color Wheel 1	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	8	Color Temperature 1	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-	9	Strobe 1	000ó 010	No function
_	3	Strobe 1	011ó 255	Strobe, slow to fast
_	10	Red 2	000ó 255	0–100%
_	11	Green 2	000ó 255	0–100%
_	12	Blue 2	000ó 255	0–100%
_	13	Amber 2	000ó 255	
_	14	Virtual Color Wheel 2	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
·	15	Color Temperature 2	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
- -	16	Strobe 2		No function Strobe, slow to fast
-	17	Red 3	000ó 255	0–100%
-	18	Green 3	000ó 255	
			ı	•



10-Cell	Channel	Function	Value	Percent/Setting
RGBA	19	Blue 3	000ó 255	0–100%
EXT	20	Amber 3	000ó 255	0-100%
73CH	21	Virtual Color Wheel 3	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
(cont.)	22	Color Temperature 3	000ර 255	Refer to the Preset Color Temperature Chart section for specific values
·-	23	Strobe 3	000ó 010	No function
_	23	Strope 3	011ó 255	Strobe, slow to fast
_	24	Red 4	000ó 255	0–100%
_	25	Green 4	000ó 255	0–100%
-	26	Blue 4	000ó 255	0–100%
-	27	Amber 4	000ó 255	
_	28	Virtual Color Wheel 4	0000 255	for specific values
_	29	Color Temperature 4	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	30	Strobe 4	000ó 010	No function
-	30	Ollope 4	0116255	Strobe, slow to fast
-	31	Red 5	000ó 255	0–100%
-	32	Green 5	000ó 255	0–100%
-	33	Blue 5	000ó 255	0–100%
-	34	Amber 5	000ó 255	0–100%
-	35	Virtual Color Wheel 5	000ర 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
_	36	Color Temperature 5	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
•	37	Strobe 5		No function
-				Strobe, slow to fast
-	38	Red 6	0006 255	
-	39	Green 6	0006 255	
-	40	Blue 6	000ó 255	
-	41	Amber 6	0006 255	0-100%
-	42	Virtual Color Wheel	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	43	Color Temperature 6		section for specific values
	44	Strobe 6		No function
-				Strobe, slow to fast
-	45	Red 7	0006 255	
-	46	Green 7	0006 255	
- -	47	Blue 7	000ó 255	
	48	Amber 7	0006 255	0-100%
	49	Virtual Color Wheel 7	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	50	Color Temperature 7	000ර 255	Refer to the Preset Color Temperature Chart section for specific values



		I		
10-Cell	Channel	Function	Value	Percent/Setting
RGBA EXT_	51	Strobe 7		No function
				Strobe, slow to fast
73CH	52	Red 8	000ó 255	
(cont.)-	53	Green 8	000ó 255	
(00)	54	Blue 8	000ó 255	0–100%
<u>.</u>	55	Amber 8	000ó 255	
_	56	Virtual Color Wheel 8	000ó 255	Refer to the Virtual Color Wheel Chart section for specific values
	57	Color Temperature 8	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	58	Strobe 8	000ó 010	No function
	30	Strobe 6	011ó 255	Strobe, slow to fast
	59	Red 9	000ó 255	0–100%
-	60	Green 9	000ó 255	0–100%
-	61	Blue 9	000ó 255	0–100%
-	62	Amber 9	000ó 255	0–100%
-	63	Virtual Color Wheel 9	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	64	Color Temperature 9	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-	65	Strobe 9	000ó 010	No function
	65		011ó 255	Strobe, slow to fast
-	66	Red 10	000ó 255	0–100%
-	67	Green 10	000ó 255	0–100%
-	68	Blue 10	000ó 255	0–100%
-	69	Amber 10	000ó 255	0–100%
- - -	70	Virtual Color Wheel 10	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	71	Color Temperature 10	0006 255	Refer to the Preset Color Temperature Chart section for specific values
	72	Strobe 10	000ó 010	No function
	12	SHODE IV	0116255	Strobe, slow to fast
-	72	Strobe All	000ó 010	No function
	73	Strope All	011ó 255	Strobe, slow to fast

10-Cell RGB EXT 63CH

Ш	Channel	Function	Value	Percent/Setting
T	1	Dimmer	000ó 255	0–100%
Н	2	Dimmer Fine	000ó 255	0–100%
-	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
-	5	Blue 1	000ó 255	0–100%
	6	•		Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	7	Color Temperature 1	000ර 255	Refer to the Preset Color Temperature Chart section for specific values
	8	Strobe 1	000ó 010	No function
		Silone i	0116 255	Strobe, slow to fast



10-Cell	Channel	Function	Value	Percent/Setting
RGB EXT	9	Red 2	000ó 255	· ·
63CH	10	Green 2	000ó 255	
		Blue 2	000Ó 255	
(cont.).		Virtual Color Wheel		Refer to the Virtual Color Wheel Chart section
<u>.</u>	12	2	000ó 255	for specific values
<u>-</u>	13	Color Temperature 2	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	14	Strobe 2		No function
-				Strobe, slow to fast
-	15	Red 3	000ó 255	0–100%
.=	16	Green 3	000ó 255	0–100%
_	17	Blue 3	000ó 255	
	18	Virtual Color Wheel 3	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
<u>-</u>	19	Color Temperature 3	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	20	Strobe 3	000ó 010	No function
_		Oli obe o		Strobe, slow to fast
_	21	Red 4	000ó 255	0–100%
_	22	Green 4	000ó 255	0–100%
_	23	Blue 4	000ó 255	0–100%
•	24	Virtual Color Wheel 4	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	25	Color Temperature 4	000෮ 255	Refer to the Preset Color Temperature Chart section for specific values
•	00	Otrolog 4	000ó 010	No function
	26	Strobe 4	011ó 255	Strobe, slow to fast
-	27	Red 5	000ó 255	0–100%
-	28	Green 5	000ó 255	0–100%
-	29	Blue 5	000ó 255	0–100%
-	30	Virtual Color Wheel	000ó 255	Refer to the Virtual Color Wheel Chart section
-		5		for specific values
<u>-</u>	31	Color Temperature 5	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
	32	Strobe 5		No function Strobe, slow to fast
-	33	Red 6	000ó 255	
-	34	Green 6	000Ó 255	
-	35	Blue 6	000ó 255	
-		Virtual Color Wheel		Refer to the Virtual Color Wheel Chart section
-	36	6	0006 255	for specific values
<u>-</u>	37	Color Temperature 6	0006 255	Refer to the Preset Color Temperature Chart section for specific values
	38	Strobe 6		No function
. -	30	Oli Obe 0		Strobe, slow to fast
. -	39	Red 7	000ó 255	
	40	Green 7	000ó 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGB EXT	41	Blue 7	000ó 255	0–100%
63CH (cont.)	44	Virtual Color Wheel 7	000෮ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
(COIII.)	43	Color Temperature 7	000෮ 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	44	Strobe 7	0006 010	No function
		Strobe 7	011ó 255	Strobe, slow to fast
	45	Red 8	000ර 255	0–100%
	46	Green 8	000ó 255	0–100%
•	47	Blue 8	000ó 255	0–100%
	48	Virtual Color Wheel 8	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	49	Color Temperature 8	0006 255	Refer to the Preset Color Temperature Chart section for specific values
•	50	Strobe 8	000ó 010	No function
		Strobe 8	011ó 255	Strobe, slow to fast
	51	Red 9	000ó 255	0–100%
•	52	Green 9	000ó 255	0–100%
•	53	Blue 9	000ó 255	0–100%
•	54	Virtual Color Wheel 9	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	55	Color Temperature 9	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
•	56	Strobe 9	000ó 010	No function
			011ó 255	Strobe, slow to fast
•	57	Red 10	000ó 255	0–100%
•	58	Green 10	000ó 255	0–100%
•	59	Blue 10	000ó 255	0–100%
- -	60	Virtual Color Wheel 10	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	61	Color Temperature 10	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	62	Strobo 10	000ó 010	No function
	62	Strobe 10	0116 255	Strobe, slow to fast
•	62	Ctuche All	0006 010	No function
	63	Strobe All	0116 255	Strobe, slow to fast

10-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Red 1	000ó 255	0–100%
50CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
	4	Amber 1	000ó 255	0–100%
	5	Lime 1	000ó 255	0–100%
	6	Red 2	000ó 255	0–100%
	7	Green 2	000ó 255	0–100%
	8	Blue 2	000ó 255	0–100%
•	9	Amber 2	0006 255	0–100%



10-Cell RGBAL 50CH

Channel	Function	Value	Percent/Setting
10	Lime 2	000ó 255	0–100%
11	Red 3	000ó 255	0–100%
12	Green 3	000ó 255	0–100%
13	Blue 3	000ó 255	0–100%
14	Amber 3	000ó 255	0–100%
15	Lime 3	000ó 255	0–100%
16	Red 4	000ර 255	0–100%
17	Green 4	000ó 255	0–100%
18	Blue 4	000ó 255	0–100%
19	Amber 4	000ó 255	0–100%
20	Lime 4	000෮ 255	0–100%
21	Red 5	000ó 255	
22	Green 5	000෮ 255	0–100%
23	Blue 5	000ó 255	
24	Amber 5	000ó 255	0–100%
25	Lime 5	000ó 255	0–100%
26	Red 6	000ó 255	0–100%
27	Green 6	000ó 255	0–100%
28	Blue 6	000ó 255	0–100%
29	Amber 6	000ó 255	0–100%
30	Lime 6	000ó 255	0–100%
31	Red 7	000ó 255	0–100%
32	Green 7	000ó 255	0–100%
33	Blue 7	000ó 255	0–100%
34	Amber 7	000ó 255	
35	Lime 7	000෮ 255	
36	Red 8	000ó 255	0–100%
37	Green 8	000ó 255	0–100%
38	Blue 8	000ó 255	
39	Amber 8	000ó 255	
40	Lime 8	000ó 255	
41	Red 9	000ó 255	
42	Green 9	000ó 255	
43	Blue 9	000ó 255	
44	Amber 9	000ó 255	
45	Lime 9	000ó 255	
46	Red 10	000ó 255	
47	Green 10	000ó 255	
48	Blue 10	000ó 255	
49	Amber 10	000ó 255	
50	Lime 10	000ó 255	0–100%

10-Cell	Channel	Function	Value	Percent/Setting
RGBA	1	Red 1	000ó 255	0–100%
40CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	0006 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGBA	4	Amber 1	000ó 255	0–100%
40CH (cont.)	5	Red 2	000ó 255	0–100%
	6	Green 2	000ó 255	0–100%
	7	Blue 2	000ó 255	0–100%
	8	Amber 2	000ó 255	0–100%
	9	Red 3	000ó 255	0–100%
	10	Green 3	000ó 255	0–100%
	11	Blue 3	000ó 255	0–100%
	12	Amber 3	000ó 255	0–100%
	13	Red 4	000෮ 255	0–100%
	14	Green 4	000ó 255	0–100%
	15	Blue 4	000ó 255	0–100%
	16	Amber 4	000ó 255	
	17	Red 5	000ó 255	
	18	Green 5	000ó 255	
	19	Blue 5	000ó 255	
	20	Amber 5	000ó 255	
	21	Red 6	000ó 255	
	22	Green 6	000ó 255	
-	23	Blue 6	000ó 255	
•	24	Amber 6	000ó 255	
-	25	Red 7	000ó 255	
•	26	Green 7	000ó 255	
	27	Blue 7	000ó 255	
	28	Amber 7	000ó 255	
	29	Red 8	0006 255	
-	30	Green 8	0006 255	
	31	Blue 8	0006 255	
	32	Amber 8	000ó 255	
- - - -	33	Red 9	0006255	
	34	Green 9	0006 255	
	35	Blue 9	000ó 255	
	36	Amber 9	000ó 255	
	37	Red 10	000ó 255 000ó 255	
•	38 39	Green 10 Blue 10	0000 255 0000 255	
•	39 40			
	40	Amber 10	000ó 255	U-10U%

10-Cell	Channel	Function	Value	Percent/Setting
RGB	1	Red 1	000ó 255	0–100%
30CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
	4	Red 2	000ó 255	0–100%
	5	Green 2	000ó 255	0–100%
	6	Blue 2	000෮ 255	0–100%



10-Cell	Channel	Function	Value	Percent/Setting
RGB 30CH (cont.)	7	Red 3	000ó 255	0–100%
	8	Green 3	000ó 255	0–100%
	9	Blue 3	000ó 255	0–100%
	10	Red 4	000ó 255	0–100%
	11	Green 4	000ó 255	0–100%
	12	Blue 4	000ó 255	0–100%
•	13	Red 5	000ó 255	0–100%
•	14	Green 5	000ó 255	0–100%
	15	Blue 5	000ó 255	0–100%
,	16	Red 6	000ó 255	0–100%
	17	Green 6	000ó 255	0–100%
	18	Blue 6	000ó 255	0–100%
	19	Red 7	0006 255 0-100%	0–100%
	20	Green 7	000ó 255	0–100%
	21	Blue 7	000ó 255	0–100%
	22	Red 8	000ó 255	0–100%
	23	Green 8	000ó 255	0–100%
- - -	24	Blue 8	000ó 255	0–100%
	25	Red 9	000ó 255	0–100%
	26	Green 9	000ó 255	0–100%
	27	Blue 9	000ó 255	0–100%
	28	Red 10	000ó 255	0–100%
· · · · · · · · · · · · · · · · · · ·	29	Green 10	000ó 255	0–100%
•	30	Blue 10	000ó 255	0–100%

5-Cell Personalities

5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
FULL	2	Dimmer Fine	0006 255	0–100%
70CH	3	Red 1	000ó 255	0–100%
	4	Red Fine 1	000ó 255	0–100%
	5	Green 1	000ó 255	0–100%
	6	Green Fine 1	000ó 255	0–100%
	7	Blue 1	000ó 255	0–100%
	8	Blue Fine 1	000ó 255	0–100%
	9	Amber 1	000ó 255	0–100%
-	10	Amber Fine 1	000ó 255	0–100%
	11	Lime 1	000ó 255	0–100%
	12	Lime Fine 1	000ó 255	
•	13	Virtual Color Wheel 1	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	14	Color Temperature 1		Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-	15	Strobe 1	000ó 010	No function
	15	Strobe 1	0116255	Strobe, slow to fast



5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	16	Red 2	000ó 255	0–100%
FULL	17	Red Fine 2	000ó 255	
70CH	18	Green 2	000ó 255	
	19	Green Fine 2	000ó 255	0-100%
(cont.)-	20	Blue 2	000ó 255	0–100%
-	21	Blue Fine 2	000ó 255	0-100%
-	22	Amber 2	000ó 255	0-100%
=	23	Amber Fine 2	000ó 255	
=	24	Lime 2	000෮ 255	0–100%
-	25	Lime Fine 2	000ó 255	0-100%
-	26	Virtual Color Wheel 2	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	27	Color Temperature 2	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
_	28	Strobe 2	000ó 010	No function
	20	Strobe 2	011ó 255	Strobe, slow to fast
_	29	Red 3	000ó 255	0–100%
_	30	Red Fine 3	000ó 255	0–100%
_	31	Green 3	000ó 255	0–100%
_	32	Green Fine 3	000ó 255	0–100%
_	33	Blue 3	000ó 255	0–100%
_	34	Blue Fine 3	000ó 255	0–100%
_	35	Amber 3	000ó 255	0–100%
_	36	Amber Fine 3	000ó 255	0–100%
_	37	Lime 3	000ó 255	0–100%
_	38	Lime Fine 3	000ó 255	0–100%
-	39	Virtual Color Wheel 3	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	40	Color Temperature 3	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
	41	Strobe 3	0006 010	No function
_			011ó 255	Strobe, slow to fast
_	42	Red 4	000ó 255	0–100%
_	43	Red Fine 4	000ó 255	0–100%
_	44	Green 4	000ó 255	0–100%
_	45	Green Fine 4	000ó 255	
_	46	Blue 4	000ó 255	0–100%
_	47	Blue Fine 4	000ó 255	0–100%
_	48	Amber 4	000ó 255	
_	49	Amber Fine 4	000ó 255	
-	50	Lime 4	000ó 255	
-	51	Lime Fine 4	000ó 255	
<u>-</u>	52	Virtual Color Wheel 4	000ó 255	Tot specific values
	53	Color Temperature 4	0006 255	Refer to the Preset Color Temperature Chart section for specific values



5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	54	Strobe 4	000ó 010	No function
FULL	34	Strobe 4	011ó 255	Strobe, slow to fast
70CH	55	Red 5	000ó 255	0–100%
(cont.)	56	Red Fine 5	000ó 255	0–100%
(cont.)	57	Green 5	000ó 255	0–100%
	58	Green Fine 5	000ó 255	0–100%
	59	Blue 5	000ó 255	0–100%
	60	Blue Fine 5	000ó 255	0–100%
	61	Amber 5	000ó 255	0–100%
	62	Amber Fine 5	000ó 255	0–100%
	63	Lime 5	000ó 255	0–100%
	64	Lime Fine 5	000ó 255	0–100%
	65	Virtual Color Wheel 5	0000 255	Refer to the Virtual Color Wheel Chart section
				for specific values
	66	Color Temperature	000ക് 255	Refer to the Preset Color Temperature Chart
		5		section for specific values
	67	Strobe 5 Strobe All		No function
				Strobe, slow to fast
	68			No function
-				Strobe, slow to fast No function
	69	Color Macros		Color macros
				Preset dimmer speed from display menu
				Dimmer speed mode off
	70	Dimmer Speed		•
	70	Diffiller Speed		Dimmer speed mode 1 (fastest)
				Dimmer speed mode 2
			2040 255	Dimmer speed mode 3 (slowest)

5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Red 1	000ó 255	0–100%
Fine	2	Red Fine 1	000ó 255	0–100%
50CH	3	Green 1	000ó 255	0–100%
	4	Green Fine 1	000ó 255	0–100%
-	5	Blue 1	000ó 255	0–100%
_	6	Blue Fine 1	000ó 255	0–100%
-	7	Amber 1	000ó 255	0–100%
_	8	Amber Fine 1	000ó 255	0–100%
_	9	Lime 1	000ó 255	0–100%
-	10	Lime Fine 1	000ó 255	0–100%
	11	Red 2	000ó 255	0–100%
-	12	Red Fine 2	000ó 255	0–100%
-	13	Green 2	000ó 255	0–100%
	14	Green Fine 2	000෮ 255	0–100%
-	15	Blue 2	000෮ 255	0–100%
	16	Blue Fine 2	000ó 255	0–100%
	17	Amber 2	000ó 255	0–100%



5 O U	0 1 1	l=		ln 40.43
	Channel			Percent/Setting
RGBAL	18	Amber Fine 2	0006 255	
Fine_		Lime 2	000ó 255	
50CH		Lime Fine 2	0006 255	
(cont.)-	21	Red 3	000ó 255	
` _	22	Red Fine 3	000ó 255	
_	23	Green 3	000ó 255	
_	24	Green Fine 3	000ó 255	
_	25	Blue 3	000ó 255	0–100%
_	26	Blue Fine 3	000ó 255	0–100%
_	27	Amber 3	000ó 255	0–100%
<u>_</u>	28	Amber Fine 3	000ó 255	0–100%
_	29	Lime 3	000ó 255	0–100%
_	30	Lime Fine 3	000ó 255	0–100%
_	31	Red 4	000ó 255	0–100%
	32	Red Fine 4	000ó 255	0–100%
_	33	Green 4	000ó 255	0–100%
_	34	Green Fine 4	000ó 255	0–100%
_	35	Blue 4	000ó 255	0–100%
_	36	Blue Fine 4	000ó 255	0–100%
_	37	Amber 4	000ó 255	0–100%
_	38	Amber Fine 4	000ó 255	0–100%
_	39	Lime 4	000ó 255	0–100%
_	40	Lime Fine 4	000ó 255	0–100%
_	41	Red 5	000ó 255	0–100%
-	42	Red Fine 5	000ó 255	0–100%
-	43	Green 5	000ó 255	0–100%
_	44	Green Fine 5	000ó 255	0–100%
-	45	Blue 5	000ó 255	0–100%
-	46	Blue Fine 5	000ó 255	0–100%
-	47	Amber 5	000ó 255	0–100%
-	48	Amber Fine 5	000ó 255	0–100%
-	49	Lime 5	000ó 255	0–100%
_	50	Lime Fine 5	000ó 255	0–100%

5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0–100%
43CH	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
	5	Blue 1	000ó 255	0–100%
	6	Amber 1	000ó 255	0–100%
	7	Lime 1	000ó 255	0–100%
	8	I	0000 255	Tot specific values
	9	Color Temperature 1	000ó 255	Refer to the Preset Color Temperature Chart section for specific values



5-Cell Channel		Function	Value	Percent/Setting
	Chamilei	T UTICUOTI		No function
RGBAL	10	Strobe 1		
EXT		Dod 0		Strobe, slow to fast
43CH		Red 2	000ó 255	
(cont.)	12	Green 2	000ó 255	
	13	Blue 2	000ó 255	
	14	Amber 2	000ó 255	
	15	Lime 2	000ó 255	
	16	Virtual Color Wheel 2	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	17	Color Temperature 2	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
-	40	04	000ó 010	No function
	18	Strobe 2	011ó 255	Strobe, slow to fast
•	19	Red 3	000ó 255	0–100%
•	20	Green 3	000ó 255	0–100%
	21	Blue 3	000ó 255	0–100%
•	22	Amber 3	000ó 255	
•	23	Lime 3	000ó 255	0-100%
•	0.4	Virtual Color Wheel		Refer to the Virtual Color Wheel Chart section
	24	3	000ó 255	for specific values
•	25	Color Temperature 3	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
• =			000ó 010	No function
	26	Strobe 3	011ó 255	Strobe, slow to fast
•	27	Red 4	000ó 255	
•	28	Green 4	000ó 255	
•	29	Blue 4	000ó 255	0–100%
•	30	Amber 4	000ó 255	0–100%
•	31	Lime 4	000ó 255	
•	32	Virtual Color Wheel	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	33	Color Temperature	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
		7	000ക് 010	No function
	34	Strobe 4		Strobe, slow to fast
•	35	Red 5	000ó 255	· · · · · · · · · · · · · · · · · · ·
•	36	Green 5	000Ó 255	
•	37	Blue 5	000Ó 255	
•	38	Amber 5	000Ó 255	
•	39	Lime 5	000Ó 255	
•		Virtual Color Wheel		Refer to the Virtual Color Wheel Chart section
	40	5	0006 255	for specific values
	41	Color Temperature 5	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
•	42	Strobe 5	000ර 0 <mark>1</mark> 0	No function
	74	Oli Obe o	0116255	Strobe, slow to fast
•	43	Strobe All	000ó 010	No function
	43	Strope All	0116 255	Strobe, slow to fast



5-Cell RGBA EXT 38CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000ó 255	0–100%
2	Dimmer Fine	000ó 255	0–100%
3	Red 1	000ó 255	0–100%
4	Green 1	000ó 255	0–100%
5	Blue 1	000ó 255	0–100%
6	Amber 1	000ó 255	0–100%
7	Virtual Color Wheel 1	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
8	Color Temperature 1	000ó 255	Refer to the Preset Color Temperature Chart section for specific values
9	Strobe 1		No function Strobe, slow to fast
10	Red 2	000ó 255	0–100%
11	Green 2	000ó 255	0–100%
12	Blue 2	000ó 255	0–100%
13	Amber 2	000ó 255	
14	Virtual Color Wheel 2	000෮ 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
15	Color Temperature 2	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
16	Strobe 2		No function Strobe, slow to fast
17	Red 3	000ó 255	0–100%
18	Green 3	000ó 255	0–100%
19	Blue 3	000ó 255	0–100%
20	Amber 3	000ó 255	0–100%
21	Virtual Color Wheel 3	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
22	Color Temperature 3	000෮ 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
23	Strobe 3		No function Strobe, slow to fast
24	Red 4	000ó 255	
25	Green 4	000ර 255	0–100%
26	Blue 4	000ó 255	0–100%
27	Amber 4	000ó 255	
28	Virtual Color Wheel 4	000ó 255	for specific values
29	Color Temperature 4	000ර 255	section for specific values
30	Strobe 4		No function Strobe, slow to fast
31	Red 5	000ó 255	0–100%
32	Green 5	000ó 255	0–100%
33	Blue 5	000ó 255	0–100%
34	Amber 5	000ó 255	0–100%



5-Cell	Channel	Function	Value	Percent/Setting
RGBA EXT	35	Virtual Color Wheel 5	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
38CH	36	Color Temperature 5	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
(cont.)	37	Strobe 5	0006 010	No function
_			011ó 255	Strobe, slow to fast
	38	Strobe All	000ó 010	No function
	38		011ó 255	Strobe, slow to fast

Value

Percent/Setting

5-Cell Channel Function RGB EXT 1 Dimmer 33CH 2 Dimmer F

Γ	1	Dimmer	000ó 255	0–100%
ł	2	Dimmer Fine	000ó 255	0–100%
	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
	5	Blue 1	000ó 255	0–100%
	6	Virtual Color Wheel 1	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	7	Color Temperature 1	000ර 255	Refer to the Preset Color Temperature Chart section for specific values
	Ctuche 4	000ó 010	No function	
	8	Strobe 1	011ó 255	Strobe, slow to fast
	9	Red 2	000ó 255	0–100%
	10	Green 2	000ó 255	0–100%
	11	Blue 2	000ó 255	0–100%
	12	Virtual Color Wheel 2	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	13	Color Temperature 2	0006 255	Refer to the Preset Color Temperature Chart section for specific values
	14	Strobe 2	000ó 010	No function
	14	Strobe 2	011ó 255	Strobe, slow to fast
	15	Red 3	000ó 255	0–100%
	16	Green 3	000ó 255	0–100%
	17	Blue 3	000ó 255	0–100%
	18	Virtual Color Wheel 3	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	19	Color Temperature 3	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	20	Strobe 3	000ó 010	No function
	20	Strope 3	011ó 255	Strobe, slow to fast
	21	Red 4	000ó 255	0–100%
	22	Green 4	000ó 255	0–100%
	23	Blue 4	000ó 255	0–100%
	24	Virtual Color Wheel 4	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	25	Color Temperature 4	000ó 255	Refer to the Preset Color Temperature Chart section for specific values



5-Cell	Channel	Function	Value	Percent/Setting
RGB EXT	26	Strobe 4	000ó 010	No function
33CH	20	Strobe 4	011ó 255	Strobe, slow to fast
(cont.)	27	Red 5	000ó 255	0–100%
(001111)	28	Green 5	000ó 255	0–100%
	29	Blue 5	000ó 255	0–100%
_	30	Virtual Color Wheel	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-		5		for specific values
	31	Color Temperature	000ó 255	Refer to the Preset Color Temperature Chart
-		5		section for specific values
	32	Strobe 5	000ó 010	No function
_	32		011ó 255	Strobe, slow to fast
	33	Strobe All	000ó 010	No function
	33	Sti obe All	011ó 255	Strobe, slow to fast

5-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Red 1	000ó 255	0–100%
25CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
	4	Amber 1	000ó 255	0–100%
•	5	Lime 1	000ó 255	0–100%
	6	Red 2	000ó 255	0–100%
	7	Green 2	000ó 255	0–100%
	8	Blue 2	000ó 255	0–100%
	9	Amber 2	000ó 255	0–100%
	10	Lime 2	000ó 255	0–100%
	11	Red 3	000ó 255	0–100%
	12	Green 3	000ó 255	0–100%
	13	Blue 3	000ó 255	0–100%
	14	Amber 3	000ó 255	0–100%
	15	Lime 3	000ó 255	0–100%
_	16	Red 4	000ó 255	0–100%
	17	Green 4	000ó 255	0–100%
	18	Blue 4	000ó 255	0–100%
	19	Amber 4	000ó 255	0–100%
	20	Lime 4	000ó 255	0–100%
	21	Red 5	000ó 255	0–100%
	22	Green 5	000෮ 255	0–100%
	23	Blue 5	000ó 255	0–100%
	24	Amber 5	000ó 255	0–100%

5-Cell	Channel	Function	Value	Percent/Setting
RGBA	1	Red 1	000ó 255	0–100%
20CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
-	4	Amber 1	000ó 255	0–100%

000ó 255 0-100%

Lime 5



RGBA 20CH

(cont.

Ш	Channel	Function	Value	Percent/Setting
Н	5	Red 2	000ó 255	0–100%
.)	6	Green 2	000ó 255	0–100%
′	7	Blue 2	000ó 255	0–100%
	8	Amber 2	000ó 255	0–100%
-	9	Red 3	000ó 255	0–100%
	10	Green 3	000ó 255	0–100%
	11	Blue 3	000ó 255	0–100%
	12	Amber 3	000ó 255	0–100%
	13	Red 4	000ó 255	0–100%
	14	Green 4	000ó 255	0–100%
	15	Blue 4	000ó 255	0–100%
	16	Amber 4	000ó 255	0–100%
	17	Red 5	000ó 255	0–100%
	18	Green 5	000ó 255	0–100%
	19	Blue 5	000ó 255	0–100%
-	20	Amber 5	000ó 255	0–100%

5-Cell RGB 15CH

I	Channel	Function	Value	Percent/Setting
3	1	Red 1	000ó 255	0–100%
۱	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
	4	Red 2	000ó 255	0–100%
	5	Green 2	000ó 255	0–100%
	6	Blue 2	000ó 255	0–100%
	7	Red 3	000ó 255	0–100%
	8	Green 3	000ó 255	0–100%
	9	Blue 3	000ó 255	0–100%
	10	Red 4	000ó 255	0–100%
	11	Green 4	000ó 255	0–100%
	12	Blue 4	000ó 255	0–100%
	13	Red 5	000ó 255	0–100%
	14	Green 5	000ó 255	0–100%
	15	Blue 5	000ó 255	0–100%

2-Cell Personalities

RGBAL FULL 31CH

	iuiitics			
2-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
L 31CH	2	Dimmer Fine	000ó 255	0–100%
	3	Red 1	000ó 255	0–100%
	4	Red Fine 1	000ó 255	0–100%
	5	Green 1	000ó 255	0–100%
	6	Green Fine 1	000ó 255	0–100%
•	7	Blue 1	000ó 255	0–100%
•	8	Blue Fine 1	000ó 255	0–100%
•	9	Amber 1	000ó 255	0–100%



2-Cell	Channel	Function	Value	Percent/Setting
RGBAL	10	Amber Fine 1	000ó 255	0–100%
FULL	11	Lime 1	000ó 255	0–100%
31CH	12	Lime Fine 1	000ó 255	0–100%
(cont.)	13	Virtual Color Wheel 1	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	14	Color Temperature 1	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
1	15	Strobe 1	000ó 010	No function
	13	Strobe i	011ó 255	Strobe, slow to fast
-	16	Red 2	000ó 255	0–100%
_	17	Red Fine 2	000ó 255	0–100%
_	18	Green 2	000ó 255	0–100%
_	19	Green Fine 2	000ó 255	0–100%
_	20	Blue 2	000ó 255	0–100%
_	21	Blue Fine 2	000ó 255	0–100%
_	22	Amber 2	000ó 255	0–100%
-	23	Amber Fine 2	000ó 255	0–100%
-	24	Lime 2	000ó 255	0–100%
_	25	Lime Fine 2	000ó 255	0–100%
	26	Virtual Color Wheel 2	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	27	Color Temperature 2	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	28	Strobe 2		No function
_				Strobe, slow to fast
	29	Strobe All		No function
<u>-</u>		Oli ODC All		Strobe, slow to fast
	30	Color Macros		No function
-				Color macros
				Preset dimmer speed from display menu
				Dimmer speed mode off
	31	Dimmer Speed		Dimmer speed mode 1 (fastest)
				Dimmer speed mode 2
			2040 255	Dimmer speed mode 3 (slowest)
0.0-11	Channel	Eunotion	Value	Paraant/Satting

2-Cell	Channel	Function	value	Percent/Setting
RGBAL	1	Red 1	000ó 255	0–100%
Fine	2	Red Fine 1	000ó 255	0–100%
20CH.	3	Green 1	000ó 255	0–100%
	4	Green Fine 1	000ó 255	0–100%
_	5	Blue 1	000ó 255	0–100%
	6	Blue Fine 1	000ó 255	0–100%
_	7	Amber 1	000ó 255	0–100%
	8	Amber Fine 1	000ó 255	0–100%
	9	Lime 1	000ó 255	0–100%
_	10	Lime Fine 1	000ó 255	0–100%



2-Cell	Channel	Function	Value	Percent/Setting
RGBAL	11	Red 2	000ó 255	0–100%
Fine	12	Red Fine 2	000ó 255	0–100%
20CH		Green 2	000ó 255	0–100%
(cont.)	14	Green Fine 2	000ó 255	0–100%
(00111.)-	15	Blue 2	000ó 255	0–100%
	16	Blue Fine 2	000ó 255	0–100%
	17	Amber 2	000ó 255	0–100%
•	18	Amber Fine 2	000ó 255	0–100%
•	19	Lime 2	000ó 255	0–100%
•	20	Lime Fine 2	000ക് 255	0-100%

2-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0–100%
19CH	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
	5	Blue 1	000ó 255	0–100%
	6	Amber 1	000ó 255	0–100%
	7	Lime 1	000෮ 255	0–100%
	8	Virtual Color Wheel 1	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
•	9	Color Temperature 1	000ó 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	10	Strobe 1	000ó 010	No function
			0116 255	Strobe, slow to fast
	11	Red 2	000ó 255	0–100%
	12	Green 2	000ó 255	0–100%
	13	Blue 2	000ó 255	0–100%
	14	Amber 2	000ó 255	0–100%
	15	Lime 2	000ó 255	0–100%
-	16	Virtual Color Wheel 2	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	17	Color Temperature 2	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	18	Strobe 2	000ó 010	No function
	18	Strobe 2	011ó 255	Strobe, slow to fast
•	10	Strobe All	000ó 010	No function
	19	Strobe All	011ó 255	Strobe, slow to fast

2-Cell	Channel	Function	Value	Percent/Setting
RGBA	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0–100%
17CH	3	Red 1	000ó 255	0–100%
	4	Green 1	000ó 255	0–100%
	5	Blue 1	000ó 255	0–100%
-	6	Amber 1	000ó 255	0–100%



2 Call	Channel	Function	Value	Percent/Setting
		Virtual Color Wheel	Value	
RGBA EXT	7	1	000ó 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
17CH	8	Color Temperature	000෮ 255	Refer to the Preset Color Temperature Chart section for specific values
(cont.)	9	Strobe 1		No function
	9	Strobe i	011ó 255	Strobe, slow to fast
-	10	Red 2	000ó 255	0–100%
-	11	Green 2	000ó 255	0–100%
-	12	Blue 2	000ó 255	0–100%
-	13	Amber 2	000ó 255	0–100%
-	14	Virtual Color Wheel 2	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
- -	15	Color Temperature 2	000ර 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
·-	16	Strobe 2	000ó 010	No function
			011ó 255	Strobe, slow to fast
-	47	Ctrobo All	000ó 010	No function
	17	Strobe All	011ó 255	Strobe, slow to fast
2-Cell	Channel	Function	Value	Percent/Setting
RGB EXT	1	Dimmer	000ó 255	0–100%
15CH	2	Dimmer Fine	000ó 255	0–100%
	3	Red 1	000ó 255	0–100%
-	4	Green 1	000ó 255	0–100%
-	5	Blue 1	000ó 255	
-	6	Virtual Color Wheel	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
-	7	Color Temperature	000෮ 255	Refer to the Preset Color Temperature Chart section for specific values
-	8	Strobe 1	000ó 010	No function
			011ó 255	Strobe, slow to fast
-	9	Red 2	000ó 255	
-	10	Green 2	000ó 255	0–100%
-	11	Blue 2	000ó 255	0–100%
-	12	Virtual Color Wheel 2	0006 255	Pefer to the Virtual Color Wheel Chart section
- -	13	Color Temperature 2	000ර 255	Refer to the Preset Color Temperature Chart section for specific values
-	14	Strobe 2		No function Strobe, slow to fast
-	15	Strobe All	0006 010	No function Strobe, slow to fast
2-Call	Channel	Function	Value	Percent/Setting
RGBAL	1	Red 1	000ó 255	9
-		Green 1		
10CH	3	Blue 1	000ó 255 000ó 255	
	-5	I DIUE I	いいいい ノカカ	11 - 11 11 17/6



2-Cell	Channel	Function	Value	Percent/Setting
RGBAL 10CH (cont.)	4	Amber 1	000ó 255	0–100%
	5	Lime 1	000ó 255	0–100%
	6	Red 2	000ó 255	0–100%
	7	Green 2	000ó 255	0–100%
	8	Blue 2	000ó 255	0–100%
_	9	Amber 2	000ó 255	0–100%
_	10	Lime 2	000ó 255	0–100%

2-Cell	Channel	Function	Value	Percent/Setting
RGBA	1	Red 1	000ó 255	0–100%
8CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
_	4	Amber 1	000ó 255	0–100%
_	5	Red 2	000ó 255	0–100%
_	6	Green 2	000ó 255	0–100%
_	7	Blue 2	000ó 255	0–100%
_	8	Amber 2	0006 255	0–100%

2-Cell	Channel	Function	Value	Percent/Setting
RGB	1	Red 1	000ó 255	0–100%
6CH	2	Green 1	000ó 255	0–100%
	3	Blue 1	000ó 255	0–100%
	4	Red 2	000ó 255	0–100%
_	5	Green 2	000ó 255	0–100%
· <u>-</u>	6	Blue 2	000ó 255	0–100%

1-Cell Personalities

1-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Dimmer	000ó 255	0–100%
FULL	2	Dimmer Fine	000ó 255	0–100%
17CH	3	Red	000ó 255	0–100%
_	4	Red Fine	000ó 255	0–100%
-	5	Green	000ó 255	0–100%
	6	Green Fine	000ó 255	0–100%
_	7	Blue	000ó 255	0–100%
_	8	Blue Fine	000ó 255	0–100%
_	9	Amber	000ó 255	0–100%
_	10	Amber Fine	000ó 255	0–100%
_	11	Lime	000ó 255	0–100%
_	12	Lime Fine	000ó 255	
_	13	Virtual Color Wheel	0006 255	Refer to the Virtual Color Wheel Chart section for specific values
_	14	Color Temperature	0006 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values



VATION B-2803FC QRG PROFESSIONAL				
4 0 4 11	Channal	Eunation	Value	Paraont/Catting
-	Channel	Function		Percent/Setting
RGBAL	15	Strobe		No function
FULL.		0000	011ó 255	Strobe, slow to fast
17CH	16	Color Macros	000ó 015	No function
(cont.)-	. •	COIOI Macios	0166 255	Color macros
(00111.)			000ó 051	Preset dimmer speed from display menu
			052ó 101	Dimmer speed mode off
	17	Dimmer Speed	102ó 152	Dimmer speed mode 1 (fastest)
			153ó 203	Dimmer speed mode 2
			204ó 255	Dimmer speed mode 3 (slowest)
			ı	
1-Cell	Channel	Function	Value	Percent/Setting
RGBAL	1	Red	000ó 255	0–100%
Fine	2	Red Fine	000ó 255	0–100%
10CH	3	Green	000ó 255	0–100%
	4	Green Fine	000ó 255	0–100%
-	5	Blue	000ó 255	0–100%
-	6	Blue Fine	000ó 255	0–100%
-	7	Amber	000ó 255	0–100%
-	8	Amber Fine	000ó 255	0–100%
-	9	Lime	000ó 255	0–100%
-	10	Lime Fine	000ó 255	0–100%
		!		•
1-Cell	Channel	Function	Value	Percent/Setting

1-Cell	Channel	Function	Value	Percent/Setting
RGBAL EXT	1	Dimmer	000ó 255	0–100%
	2	Dimmer Fine	000ó 255	0–100%
10CH	3	Red	000ó 255	0–100%
	4	Green	000ó 255	0–100%
_	5	Blue	000ó 255	0–100%
_	6	Amber	000ó 255	0–100%
-	7	Lime	000ó 255	0–100%
-	8	Virtual Color Wheel	いいいへ ノカカ	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values
	9	Color Temperature	いいいへ ソケケ	Refer to the <u>Preset Color Temperature Chart</u> section for specific values
	10	Strobe	000ó 010	No function
			0116 255	Strobe, slow to fast

1-Cell	Channel	Function	value	Percent/Setting
RGBA	1	Dimmer	000ó 255	0–100%
EXT	2	Dimmer Fine	000ó 255	0–100%
9CH	3	Red	000ó 255	0–100%
	4	Green	000ó 255	0–100%
	5	Blue	000ó 255	0–100%
	6	Amber	000ó 255	0–100%
	7	Virtual Color Wheel	000ර 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values



1-Cell	Channel	Function	Value	Percent/Setting			
RGBA EXT 9CH	8	Color Temperature	000෮ 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values			
(cont.)	9	Strobe		No function Strobe, slow to fast			
1-Cell	Channel	Function	Value	Percent/Setting			
RGB EXT	1	Dimmer	000ó 255	0–100%			
8CH	2	Dimmer Fine	000ó 255	0–100%			
	3	Red	000ó 255	0–100%			
	4	Green	000ó 255	0–100%			
•	5	Blue	000ó 255	0–100%			
	6	Virtual Color Wheel	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values			
	7	Color Temperature	000෮ 255	Refer to the <u>Preset Color Temperature Chart</u> section for specific values			
	8	Strobe	000ó 010	No function			
	0	Strobe	011ó 255	Strobe, slow to fast			
1-Cell	Channel	Function	Value	Percent/Setting			
RGBAL	1	Red	000ó 255	0–100%			
5CH	2	Green	000ó 255	0–100%			
	3	Blue	000ó 255	0–100%			
•	4	Amber	000ó 255	0–100%			
•	5	Lime	000ó 255	0–100%			
		•					
1-Cell	Channel	Function	Value	Percent/Setting			
RGBA	1	Red	000ó 255	0–100%			
4CH	2	Green	000ó 255	0–100%			
	3	Blue	000ó 255	0–100%			
	4	Amber	000ó 255	0–100%			
·							
1-Cell	Channel	Function	Value	Percent/Setting			
RGB 3CH	1	Red	000ó 255	0–100%			
	2	Green	000ó 255	0–100%			
	3	Blue	000ó 255	0–100%			
1-Cell	Channel	Function	Value	Percent/Setting			
DMX-	1	Dimmer	000ó 255	0–100%			
VCW-CCT 3CH	2	Virtual Color Wheel	0006 255	Refer to the <u>Virtual Color Wheel Chart</u> section for specific values			
3311	3	Color Temperature	000ó 255	Refer to the Preset Color Temperature Chart section for specific values			