

PowerFactory 2021

Technical Reference

DIgSILENT F21 Distance Polygonal Generic Relay

Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

Copyright © 2021 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

May 6, 2019 PowerFactory 2021 Revision 892

Contents

1	F21	Distance Polygonal	1
	1.1	Intent	1
	1.2	Functionality	1
	1.3	Inputs	1
	1.4	Available Units	1
	1.5	Outputs	2

1 F21 Distance Polygonal

1.1 Intent

To simulate a set of distance phase and ground polygonal elements with overcurrent/voltage restraint overcurrent starting.

1.2 Functionality

The *F21 Distance Polygonal* generic relay models 5 phase polygonal and 5 ground polygonal, a polarizing element, an overcurrent starting element, one distance directional element and one load encroachment element. The starting element can trigger a delayed back up trip. The polarizing method is user configurable; one of the following methods can be used:

- · Self.
- · Cross Quadrature.
- · Cross (Quad L-L).
- · Positive sequence.
- · Self, Ground compensated.

The distance elements can operate a single phase (for phase-ground faults), a double phase (for phase-phase faults) or a 3 phase trip.

The POTT (Permissive Overreach Transfer Trip) and the PUTT (Permissive Underreach Transfer Trip) distance protection schemes are supported.

The *F21 Distance Polygonal Generic* generic relay can be associated to the following generic relays:

- · F50BF Breaker failure.
- F68 OOS/Power Swing.
- · F79 Recloser.

1.3 Inputs

- One 3 phase CT ("Phase Ct" block, [StaCt class]).
- One 3 phase VT ("Phase Vt" block, [StaVt class]).

1.4 Available Units

Measurement

 One 3phase measurement element ("Measurement" block, RMS Calculation enabled, Filter enabled [RelMeasure class]).

Protective elements

- One polarizing element ("Polarizing" block, [RelZpol class]).
- One starting element ("Starting" block, [RelFdetect class]).
- One directional element ("Directional" block, [RelDisdir class]).
- One load encroachment element ("Load encroachment", [RelDisloadenc class]).
- Five 3 phase-phase loop polygonal elements ("Ph-Ph Polygonal 1", "Ph-Ph Polygonal 2", "Ph-Ph Polygonal 3", "Ph-Ph Polygonal 4" and "Ph-Ph Polygonal 5" block, [RelDispoly class]).
- Five 3 phase-ground loop polygonal elements ("Ph-Grnd Polygonal 1", "Ph-Grnd Polygonal 2", "Ph-Grnd Polygonal 3", "Ph-Grnd Polygonal 4" and "Ph-Grnd Polygonal 5" block, [RelDispoly class]).
- Five phase timers ("Phase Polygonal 1 Delay", "Phase Polygonal 2 Delay", "Phase Polygonal 3 Delay", "Phase Polygonal 4 Delay", and "Phase Polygonal 5 Delay" block, [RelTimer class]).
- Five ground timers ("Ground Polygonal 1 Delay", "Ground Polygonal 2 Delay", "Ground Polygonal 3 Delay", "Ground Polygonal 4 Delay", and "Ground Polygonal 5 Delay" block, [RelTimer class]).
- One delayed trip timer triggered by to the starting signal ("Starting Backup trip delay" block , [RelTimer class]).

Output logic

• One output block ("Output logic", RelLogdip class).

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.

1.5 Outputs

- yout associated by default to any protective element trip trigs a 3 phase trip.
- yout_A associated by default to any protective element trip trigs a phase A trip (single phase and two phase trip only).
- yout_B associated by default to any protective element trip trigs a phase B trip (single phase and two phase trip only).
- yout_C associated by default to any protective element trip trigs a phase C trip (single phase and two phase trip only).