

PowerFactory 2021

Technical Reference

Common Result Variables for Terminals and Elements

EMT Simulation

Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

Copyright © 2020 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

December 1, 2020 PowerFactory 2021 Revision 1

Contents

ı	Gen	erai De	escription	ı
	1.1	Termir	nals	1
	1.2	Eleme	ents (single and multiple port)	1
		1.2.1	Currents, Voltages and Powers	1
		1.2.2	Bus Results	2
2	EMT	Γsimul	ation	3
	2.1	Result	t variables for terminals	3
		2.1.1	Phase voltage related variables for terminals	3
		2.1.2	Line to line voltage related variables for terminals	4
		2.1.3	Line to neutral voltage related variables for terminals	5
		2.1.4	Short circuit variables for terminals	6
		2.1.5	$\alpha\beta\gamma$ components and neutral voltage related variables for terminals $\ \ . \ \ . \ \ .$	6
		2.1.6	Neutral short circuit current related variables for terminals	9
		2.1.7	Frequency related variables for terminals	9
	2.2	Result	t variables for elements	10
		2.2.1	Voltage related variables for elements	10
		2.2.2	Current related variables for elements	11
		2.2.3	Miscellaneous variables per phase for elements	11
		2.2.4	Voltage $\alpha\beta\gamma$ components related variables for elements	12
		2.2.5	Current $\alpha\beta\gamma$ components related variables for elements	13
		2.2.6	Power $\alpha\beta\gamma$ components related variables for elements	15
		227	Miscellaneous variables (min/may values) for elements	16

i

1 General Description

This document describes the common variables available for monitoring in *PowerFactory* for the terminals and for the single- and multiple-port elements (primary equipment). These are the parameters which are not specific to a certain element, that can be selected to be displayed in the result boxes, in the flexible data page of the elements or can be plotted in the virtual instruments.

Variables starting with capital letters are expressed in absolute values and variables starting with a lower case letters are expressed in per unit values. However for the EMT simulation there are few exceptions for the frequency related variables.

1.1 Terminals

For the terminals ($\mathit{ElmTerm}$) only the set $\mathit{Currents}$, $\mathit{Voltages}$ and Powers displays common result variables that can be monitored after a calculation. The identification name of a result variable contains the letter m to denominate that it is a common monitoring variable (in opposite to c which stands for calculation variable), a semicolon and the name of the variable. For example, the result variable $\mathit{Positive-Sequence}$ $\mathit{Voltage}$, $\mathit{Magnitude}$ has the following identification name m:u1.

For the unbalanced representation, the phase result variables get a slightly different identification name where the name of the phase is added. For example: m:u:A.

1.2 Elements (single and multiple port)

For the single- and multiple-port elements (ex.: *ElmSym*, *ElmLne*, *ElmTr3*, etc.), there are two sets containing common result variables that can be monitored after a calculation:

- · Currents, Voltages and Powers
- · Bus Results

1.2.1 Currents, Voltages and Powers

The identification name of the variables available in this set is similar to the one used for the terminals with the difference that for the elements also the connection point name is added.

For example $m:i1:_LOCALBUS$ is the magnitude of the positive-sequence current of the connected element. If the result variable is shown for a certain type of an element, the real connection point name is used. For example m:i1:bushv is the magnitude of the positive-sequence current flowing through the HV connection of a transformer and m:i1:busi is the magnitude of the positive-sequence current flowing through the connection busi of a line.

For the unbalanced representation, the phase result variables get a slightly different identification name where the name of the phase is added. For example: m:i1:LOCALBUS:A, m:i1:bushv:A, m:i1:bushv:A, m:i1:bushv:A,

The result variables available for the elements in p.u. values are based on the element (not on the terminal). Due to this, the same variable for a port element and a terminal may have a different value. For example, if the nominal voltage of an element differs from the nominal

voltage of a terminal, the positive sequence voltage magnitude m:u will have a different value compared to m:u of a terminal.

1.2.2 Bus Results

The result variables available in the *Bus Results* set for the terminals are actually the variables from the connected terminal i.e. they are the same as the variables available in the *Currents, Voltages and Powers* set from the terminals.

There are two differences regarding the identification name:

- the letter 'n' is used to denominate that this is a node (terminal) variable
- the connection-point name is also used

The result variables in p.u. values from this set are based on the terminal. Please note that if for example for a certain element n:u1:bus1 and m:u1:bus1 are displayed, the result will be different if the nominal voltage of the element differs from the nominal voltage of the terminal.

2 EMT simulation

Voltages and currents are represented in the EMT simulation by their instantaneous values.

2.1 Result variables for terminals

As described in Section 1.2.2, the result variables from the *Bus Results* set from the port elements are equivalent to the result variables from the *Currents, Voltages and Currents* set for the terminals.

The result variables available for terminals after an EMT simulation are presented in the following sub chapters.

2.1.1 Phase voltage related variables for terminals

The voltage related variables for the terminals are all based on the phase voltages u_A , u_B and u_C resulting from the EMT simulation. The relationship between the absolute and per unit value voltage is $U_A = u_A \cdot U_{base}$ where the base voltage is $U_{base} = \sqrt{2} \cdot uknom/\sqrt{3}$ where uknom is the nominal line to line voltage of the terminal.

Name	Unit	Description
u: A	p.u.	Phase Voltage
u: B	p.u.	Phase Voltage
u: C	p.u.	Phase Voltage
upc:A	%	Phase Voltage
upc: B	%	Phase Voltage
upc: C	%	Phase Voltage
U: A	kV	Phase Voltage
U: B	kV	Phase Voltage
U: C	kV	Phase Voltage

Table 2.1: Phase voltage related variables for terminals

The result variables from Table 2.1 are calculated as follows:

• u:A, u:B, u:C are the results from the EMT simulation:

$$u:A = u_A$$
$$u:B = u_B$$
$$u:C = u_C$$

• *upc:A*, *upc:B*, *upc:C* are obtained as:

$$upc:A = u:A \cdot 100$$

 $upc:B = u:B \cdot 100$
 $upc:C = u:C \cdot 100$

• U:A, U:B, U:C are obtained as:

for AC terminals (120°):

$$U:A = \sqrt{2} \cdot u:A \cdot uknom/\sqrt{3}$$

$$U:B = \sqrt{2} \cdot u:B \cdot uknom/\sqrt{3}$$

$$U:C = \sqrt{2} \cdot u:C \cdot uknom/\sqrt{3}$$

for AC/BI terminals (180°):

$$U:A = \sqrt{2} \cdot u:A \cdot uknom/2$$

$$U:B = \sqrt{2} \cdot u:B \cdot uknom/2$$

$$U:C = \sqrt{2} \cdot u:C \cdot uknom/2$$

where uknom is the nominal voltage of the terminal.

2.1.2 Line to line voltage related variables for terminals

The line to line voltages are calculated as the difference between the two phases: for AC terminals (120°):

$$u_{lA} = (u_A - u_B)/\sqrt{3}$$

$$u_{lB} = (u_B - u_C)/\sqrt{3}$$

$$u_{lC} = (u_C - u_A)/\sqrt{3}$$

for AC/BI terminals (180°):

$$u_{lA} = (u_A - u_B)/2$$

 $u_{lB} = (u_B - u_C)/2$
 $u_{lC} = (u_C - u_A)/2$

For a system containing two phases only the corresponding voltage phase difference is available $(u_{lA} \text{ or } u_{lB} \text{ or } u_{lC})$.

For single phase systems, the line to line voltages are not available (cannot be calculated).

Table 2.2: Line to line voltage related variables for terminals

Name	Unit	Description
ul:A	p.u.	Line to Line Voltage
ul:B	p.u.	Line to Line Voltage
ul:C	p.u.	Line to Line Voltage
ulpc:A	%	Line to Line Voltage
ulpc:B	%	Line to Line Voltage
ulpc:C	%	Line to Line Voltage
Ul:A	kV	Line to Line Voltage
Ul:B	kV	Line to Line Voltage
Ul:C	kV	Line to Line Voltage

The result variables from Table 2.2 are calculated as follows:

• ul:A, ul:B, ul:C are obtained as:

$$ul:A = u_{lA}$$

 $ul:B = u_{lB}$
 $ul:C = u_{lC}$

• *ulpc:A*, *ulpc:B*, *ulpc:C* are obtained as:

$$\begin{split} ulpc: & A = ul: A \cdot 100 \\ ulpc: & B = ul: B \cdot 100 \\ ulpc: & C = ul: C \cdot 100 \end{split}$$

• *Ul:A*, *Ul:B*, *Ul:C* are obtained as:

$$Ul:A = \sqrt{2} \cdot ul:A \cdot uknom$$

$$Ul:B = \sqrt{2} \cdot ul:B \cdot uknom$$

$$Ul:C = \sqrt{2} \cdot ul:C \cdot uknom$$

where uknom is the nominal voltage of the terminal.

2.1.3 Line to neutral voltage related variables for terminals

The line to neutral voltages are calculated as the difference between the phase and neutral voltages:

$$u_{lnA} = u_A - u_n$$
$$u_{lnB} = u_B - u_n$$
$$u_{lnC} = u_C - u_n$$

Table 2.3: Line to neutral voltage related variables for terminals

Name	Unit	Description
uln:A	p.u.	Line-Neutral Voltage
uln:B	p.u.	Line-Neutral Voltage
uln:C	p.u.	Line-Neutral Voltage
Uln:A	kV	Line-Neutral Voltage
Uln:B	kV	Line-Neutral Voltage
Uln:C	kV	Line-Neutral Voltage

If no neutral connection exists the values of the variables from Table 2.3 are set to zero. If neutral connection exists, the result variables are calculated as follows:

• uln:A, uln:B, uln:C are the magnitudes of the line to line voltages:

$$uln:A = u_{lnA}$$

 $uln:B = u_{lnB}$
 $uln:C = u_{lnC}$

• *Uln:A*, *Uln:B*, *Uln:C* are obtained as: for AC terminals with neutral (120°):

$$Uln:A = \sqrt{2} \cdot uln:A \cdot uknom/\sqrt{3}$$

$$Uln:B = \sqrt{2} \cdot uln:B \cdot uknom/\sqrt{3}$$

$$Uln:C = \sqrt{2} \cdot uln:C \cdot uknom/\sqrt{3}$$

for AC/BI terminals with neutral (180°):

$$Uln:A = \sqrt{2} \cdot uln:A \cdot uknom/2$$

$$Uln:B = \sqrt{2} \cdot uln:B \cdot uknom/2$$

$$Uln:C = \sqrt{2} \cdot uln:C \cdot uknom/2$$

where *uknom* is the nominal voltage of the terminal.

2.1.4 Short circuit variables for terminals

If a short circuit event is defined at the terminal, the short circuit currents I_{shcA} , I_{shcB} and I_{shcC} can be monitored by these variables.

Name	Unit	Description
Ishc:A	kA	Short-Circuit Current
Ishc:B	kA	Short-Circuit Current
Ishc:C	kA	Short-Circuit Current
ishc:A	p.u.	Short-Circuit Current
ishc: B	p.u.	Short-Circuit Current
ishc:C	n u	Short-Circuit Current

Table 2.4: Short circuit variables for terminals

The result variables from Table 2.4 are calculated as follows:

• *Ishc:A*, *Ishc:B*, *Ishc:C* are the short circuit currents available from the EMT simulation:

$$Ishc:A = I_{shcA}$$
$$Ishc:B = I_{shcB}$$
$$Ishc:C = I_{shcC}$$

• *ishc:A*, *ishc:B*, *ishc:C* are obtained as:

$$ishc:A = \frac{Ishc:A}{\sqrt{2} \cdot I_{nom_1MVA}}$$

$$ishc:B = \frac{Ishc:B}{\sqrt{2} \cdot I_{nom_1MVA}}$$

$$ishc:C = \frac{Ishc:C}{\sqrt{2} \cdot I_{nom_1MVA}}$$

where $I_{nom_1MVA} = \frac{1}{\sqrt{3} \cdot uknom}$ is the nominal current for 1MVA and uknom is the nominal voltage of the connected terminal.

2.1.5 $\alpha\beta\gamma$ components and neutral voltage related variables for terminals

In addition to the phase, line to line and line to neutral voltage quantities, also $\alpha\beta\gamma$ components are available.

To project the phase quantities to a stationary reference frame the $\alpha\beta\gamma$ transformation is being used. This transformation (also called the Clarke transformation) is used for transferring the three phase instantaneous values available from the EMT simulation to $\alpha\beta\gamma$ components:

$$\begin{bmatrix} u_{\alpha} \\ u_{\beta} \\ u_{\gamma} \end{bmatrix} = \frac{2}{3} \begin{bmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{bmatrix} \begin{bmatrix} u_{A} \\ u_{B} \\ u_{C} \end{bmatrix}$$

For two phase AC/BI systems (180°) (with instantaneous values u_A and u_B) the following is being used:

$$u_{\alpha} = \frac{1}{2}(u_A - u_B)$$

$$u_{\beta} = 0$$

$$u_{\gamma} = \frac{1}{2}(u_A + u_B)$$

For two phase AC systems (120°) (with instantaneous values u_A and u_B) the following is being used:

$$u_{\alpha} = \frac{1}{\sqrt{3}}(u_A - u_B)$$

$$u_{\beta} = 0$$

$$u_{\gamma} = \frac{1}{\sqrt{3}}(u_A + u_B)$$

For single phase systems (with instantaneous values u_A) the following is being used:

$$u_{\alpha} = u_{A}$$
$$u_{\beta} = 0$$
$$u_{\gamma} = 0$$

Table 2.5: $\alpha\beta\gamma$ components and neutral voltage related variables for terminals

Name	Unit	Description
un	p.u.	Neutral-Ground Voltage
Un	kV	Neutral-Ground Voltage
u0	p.u.	Zero-Sequence Voltage
U0	kV	Zero-Sequence Voltage
$U0\times3$	kV	3*U0
u1r	p.u.	Voltage Phasor, Real Part
u1i	p.u.	Voltage Phasor, Imaginary Part
phiu1	deg	Voltage Phasor, Angle
u1	p.u.	Voltage Phasor, Magnitude
u1pc	%	Voltage Phasor, Magnitude
U1	kV	Line-Ground Voltage Phasor, Magnitude
U1l	kV	Line to Line Voltage Phasor, Magnitude

The variables from Table 2.5 are calculated as follows:

ullet un is the neutral voltage available from the EMT simulation:

$$un = u_n$$

 Un is obtained as: for AC terminals (120°):

$$Un = \sqrt{2} \cdot un \cdot uknom/\sqrt{3}$$

for AC/BI terminals (180°):

$$Un = \sqrt{2} \cdot un \cdot uknom/2$$

where *uknom* is the nominal voltage of the terminal.

• u0 is obtained as:

$$u0 = u_{\gamma}$$

 U0 is obtained as: for AC terminals (120°):

$$U0 = \sqrt{2} \cdot u0 \cdot uknom/\sqrt{3}$$

for AC/BI terminals (180°):

$$U0 = \sqrt{2} \cdot u0 \cdot uknom/2$$

where uknom is the nominal voltage of the terminal.

- $U0\times3$ is calculated as $3\cdot U0$ for three phase, as $2\cdot U0$ for two phase and as U0 for single phase systems.
- u1r is the alpha component of the voltage:

$$u1r = u_{\alpha}$$

• *u*1*i* is the beta component of the voltage:

$$u1i = u_{\beta}$$

phiu1 is obtained as:

$$phiu1 = \arctan\left(\frac{u_{\beta}}{u_{\alpha}}\right) \cdot \frac{180}{\pi}$$

• u1 is obtained as the magnitude of $u_{\alpha} + j \cdot u_{\beta}$:

$$u1 = \sqrt{u_{\alpha}^2 + u_{\beta}^2}$$

• u1pc is obtained as:

$$u1pc = u1 \cdot 100$$

 U1 is obtained as: for AC terminals (120°):

$$U1 = u1 \cdot uknom/\sqrt{3}$$

for AC/BI terminals (180°):

$$U1 = u1 \cdot uknom/2$$

where uknom is the nominal voltage of the terminal. Please note that this variable is represented by an effective value (is not multiplied with $\sqrt{2}$).

• *U*1*l* is obtained as: for 2-phase and 3-phase terminals:

$$U1l = u1 \cdot uknom$$

for 1-phase terminals:

$$U1l = U1$$

Please note that this variable is represented by an effective value.

2.1.6 Neutral short circuit current related variables for terminals

If a short circuit event is defined at the terminal, the short circuit current flowing through the neutral can be monitored by these variables.

Table 2.6: Neutral short circuit current related variables for terminals

	Name	Unit	Description		
	Inshc	kA	Neutral Short-Circuit Current, Magnitude		
İ	inshc	p.u.	Neutral Short-Circuit Current, Magnitude		

The variables from Table 2.6 are calculated as follows:

• *Inshc* is the magnitudes of the short circuit currents at the terminal flowing through the short circuit impedance:

$$Inshc = I_N$$

• *inshc* is obtained as:

$$ishc = \frac{Inshc}{\sqrt{2} \cdot I_{nom,1MVA}}$$

where $I_{nom_1MVA} = \frac{1}{\sqrt{3} \cdot uknom}$ is the nominal current for 1MVA and uknom is the nominal voltage of the connected terminal.

2.1.7 Frequency related variables for terminals

The frequency calculation is based on the positive sequence voltage which is transformed from the phase values through the symmetrical components.

Table 2.7: Frequency related variables for terminals

Name	Unit	Description
frnom	Hz	Nominal Frequency
fe	p.u.	Electrical Frequency
fehz	Hz	Electrical Frequency
dfehz	Hz	Deviation of the Electrical Frequency
frdev	Hz	Average frequency

The result variables from Table 2.7 are calculated as follows:

- frnom is the nominal frequency defined in the Grid (ElmNet).
- fe is calculated by measuring the phase variation between the past and present voltage $(\underline{u} = u_{\alpha} + \jmath \cdot u_{\beta})$ with respect to the integration step size.
- dfedt is calculated using the past and present frequency values and the integration step size.
- fehz is calculated as:

$$fehz = fe \cdot frnom$$

• *dfehz* is calculated as:

$$dfehz = fehz - frnom$$

• frdev is the average frequency value calculated using all terminals.

2.2 Result variables for elements

The result variables available for single- and multiple-port elements after an EMT simulation are presented in the following sub chapters.

2.2.1 Voltage related variables for elements

The voltage related variables for the terminals are all based on the instantaneous voltages u_A , u_B , u_C and u_N resulting from the EMT simulation.

For the element based variables, the relationship between the absolute and per unit value voltage is $U_{A} = u_{A} \cdot U_{base}$ where the base voltage is $U_{base} = \sqrt{2} \cdot U_{nom_el}/\sqrt{3}$ where U_{nom_el} is the nominal line to line voltage of the element. Due to the change in base, the per unit values are multiplied with the factor $uknom/U_{nom_el}$.

Table 2.8: Voltage related variables for elements

Name	Unit	Description
u:A	p.u.	Phase Voltage
u:B	p.u.	Phase Voltage
u:C	p.u.	Phase Voltage
u:N	p.u.	Phase Voltage

The result variables from Table 2.8 are calculated as follows:

• u:A, u:B, u:C, u:N are obtained as:

$$\begin{split} u : & A = u_A \cdot \frac{uknom}{U_{nom_el}} \\ u : & B = u_B \cdot \frac{uknom}{U_{nom_el}} \\ u : & C = u_C \cdot \frac{uknom}{U_{nom_el}} \\ u : & N = u_N \cdot \frac{uknom}{U_{nom_el}} \end{split}$$

2.2.2 Current related variables for elements

The current related variables for the elements are all based on the instantaneous currents from the EMT simulation. The relationship between the absolute and per unit value current is $I_A = \sqrt{2} \cdot i_A \cdot I_{nom_el}$ where $I_{nom_el} = \frac{MVA_{el}}{\sqrt{3} \cdot U_{nom_el}}$ is the nominal current of the element.

Name	Unit	Description
I:A	kA	Phase Current
I:B	kA	Phase Current
I:C	kA	Phase Current
I:N	kA	Phase Current
i:A	p.u.	Phase Current
i:B	p.u.	Phase Current
i:C	p.u.	Phase Current
i:N	p.u.	Phase Current

Table 2.9: Current related variables for elements

The result variables from Table 2.9 are calculated as follows:

• I:A, I:B, I:C, I:N are the instantaneous currents available from the EMT Simulation:

$$I:A = I_A$$

 $I:B = I_B$
 $I:C = I_C$
 $I:N = I_N$

• i:A, i:B, i:C, i:N are obtained as:

$$i:A = \frac{I:A}{\sqrt{2} \cdot I_{nom_el}}$$

$$i:B = \frac{I:B}{\sqrt{2} \cdot I_{nom_el}}$$

$$i:C = \frac{I:C}{\sqrt{2} \cdot I_{nom_el}}$$

$$i:N = \frac{I:N}{\sqrt{2} \cdot I_{nom_el}}$$

2.2.3 Miscellaneous variables per phase for elements

Table 2.10: Miscellaneous variables per phase for elements

Name	Unit	Description
TfctPh:A	s	Fault Clearing Time
TfctPh:B	s	Fault Clearing Time
TfctPh:C	s	Fault Clearing Time
TfctPh:N	s	Fault Clearing Time

The result variables from Table 2.10 are calculated as follows:

• TfctPh:A, TfctPh:B, TfctPh:C, TfctPh:N give the fault clearing time of a fuse or a relay located in the local cubicle. If the fuse/relay model is not triggered with the current, a default value of 9999.999s is used.

2.2.4 Voltage $\alpha\beta\gamma$ components related variables for elements

In addition to the phase voltage quantities, also $\alpha\beta\gamma$ components are available.

To project the phase quantities to a stationary reference frame the $\alpha\beta\gamma$ transformation is being used. This transformation (also called the Clarke transformation) is used for transferring the three phase instantaneous values available from the EMT simulation to $\alpha\beta\gamma$ components. The same is valid as in 2.1.5.

Name	Unit	Description
u0	p.u	Zero-Sequence-Voltage
u1r	p.u	Voltage Phasor, Real Part
u1i	p.u	Voltage Phasor, Imaginary Part
phiu1	deg	Voltage Phasor, Angle
u1	p.u	Voltage Phasor, Magnitude
U1	kV	Line-Ground Voltage Phasor, Magnitude
U1l	kV	Line-Line Voltage Phasor, Magnitude

Table 2.11: Voltage $\alpha\beta\gamma$ components related variables for elements

The variables from Table 2.11 are calculated as follows:

• u0 is obtained as:

$$u0 = u_{\gamma} \cdot \frac{uknom}{U_{nom_el}}$$

where uknom is the nominal voltage of the connected terminal and U_{nom_el} is the nominal voltage of the element.

• u1r is the alpha component of the voltage:

$$u1r = u_{\alpha} \cdot \frac{uknom}{U_{nom_el}}$$

• u1i is the beta component of the voltage:

$$u1i = u_{\beta} \cdot \frac{uknom}{U_{nom_el}}$$

phiu1 is obtained as:

$$phiu1 = \arctan\left(\frac{u_\beta}{u_\alpha}\right) \cdot \frac{180}{\pi}$$

• *u*1 is obtained as:

$$u1 = \sqrt{u_{\alpha}^2 + u_{\beta}^2} \cdot \frac{uknom}{U_{nom\ el}}$$

 U1 is obtained as: for AC elements (120°):

$$U1 = \sqrt{2} \cdot u1 \cdot U_{nom_el} / \sqrt{3}$$

for AC/BI elements (180°):

$$U1 = \sqrt{2} \cdot u1 \cdot U_{nom_el} / 2$$

Please note that this variable represents the effective value (is not multiplied with $\sqrt{2}$).

• *U*1*l* is obtained as: for 2-phase and 3-phase elements:

$$U1l = u1 \cdot U_{nom_el}$$

for 1-phase elements:

$$U1l = U1$$

Please note that this variable represents the effective value (is not multiplied with $\sqrt{2}$).

2.2.5 Current $\alpha\beta\gamma$ components related variables for elements

In addition to the phase voltage quantities, also $\alpha\beta\gamma$ components are available.

To project the phase quantities to a stationary reference frame the $\alpha\beta\gamma$ transformation is being used. This transformation (also called the Clarke transformation) is used for transferring the three phase instantaneous values available from the EMT simulation to $\alpha\beta\gamma$ components I_{α} , I_{β} and I_{γ} . The same is valid as in 2.1.5.

Table 2.12: Current $\alpha\beta\gamma$ components related variables for elements

Name	Unit	Description	
<i>I</i> 0	kA	Zero-Sequence Current	
$I0\times3$	kA	3*10	
i0	p.u	Zero-Sequence Current	
i1	p.u	Current Phasor, Magnitude	
i1r	p.u	Current Phasor, Real Part	
i1i	p.u	Current Phasor, Imaginary Part	
phii1	deg	Current Phasor, Angle	
I1	kA	Current Phasor, Magnitude	
i1P	p.u.	Current Phasor, Active Current	
i1Q	p.u.	Current Phasor, Reactive Current	
I1P	kA	Current Phasor, Active Current	
I1Q	kA	Current Phasor, Reactive Current	
phiu1i1	deg	Angle between Voltage and Current Phasor	

The result variables from Table 2.12 are calculated as follows:

• I0 is obtained as:

$$I0 = I_{\gamma}$$

- $I0 \times 3$ is obtained as $3 \cdot I0$ for three phase, as $2 \cdot I0$ for two phase and as I0 for single phase systems.
- i0 is obtained as:

$$i0 = \frac{I_{\gamma}}{\sqrt{2} \cdot I_{nom_el}}$$

where $I_{nom.el}$ is the nominal current of the element.

• i1 is obtained as:

$$i1 = \frac{\sqrt{I_{\alpha}^2 + I_{\beta}^2}}{\sqrt{2} \cdot I_{nom,el}}$$

where I_{nom_el} is the nominal current of the element.

• i1r is the alpha component and is obtained as:

$$i1r = \frac{I_{\alpha}}{\sqrt{2} \cdot I_{nom,el}}$$

where I_{nom_el} is the nominal current of the element.

• *i*1*i* is the beta component and is obtained as:

$$i1i = \frac{I_{\beta}}{\sqrt{2} \cdot I_{nom_el}}$$

where I_{nom_el} is the nominal current of the element.

phii1 is obtained as:

$$phii1 = \arctan\left(\frac{I_{\beta}}{I_{\alpha}}\right) \cdot \frac{180}{\pi}$$

• I1 is obtained as the magnitude of the positive sequence current:

$$I1 = \frac{\sqrt{I_{\alpha}^2 + I_{\beta}^2}}{\sqrt{2}}$$

Please note that this variable represents the effective value (it is divided with $\sqrt{2}$).

• I1P is obtained as:

$$I1P = I1 \cdot \cos(\phi_1)$$

where ϕ_1 is the angle between the active and reactive power sum variables Psum and Qsum as defined in Section 2.2.6.

• I1Q is obtained as:

$$I1Q = I1 \cdot \sin(\phi_1)$$

• *i*1*P* is obtained as:

$$i1P = i1 \cdot \cos(\phi_1) = \frac{I1P}{I_{nom_el}}$$

• i1Q is obtained as:

$$i1Q = i1 \cdot \sin(\phi_1) = \frac{I1Q}{I_{nom_el}}$$

phiu1i1 is obtained as:

$$phiu1i1 = phiu1 - phii1$$

2.2.6 Power $\alpha\beta\gamma$ components related variables for elements

The complex apparent power is calculated for 3-phase elements using the voltage and current alpha and beta components:

$$\underline{S}_{sum} = 3 \cdot (U_{\alpha} + \jmath \cdot U_{\beta}) \cdot (I_{\alpha} + \jmath \cdot I_{\beta})^*$$

Table 2.13: Power $\alpha\beta\gamma$ components related variables for elements

Name	Unit	Description	
Psum	MW	Power-Phasor, Active Power	
Qsum	Mvar	Power-Phasor, Reactive Power	
Ssum	MVA	Power-Phasor, Apparent Power	
cosphi1		Power-Phasor, Power Factor	

The result variables from Table 2.13 are calculated as follows:

 Psum and Qsum is obtained as: for 3-phase elements:

$$\begin{aligned} Psum &= \underline{S}_{sum}.r \\ Qsum &= \underline{S}_{sum}.i \end{aligned}$$

for 2-phase AC/BI elements (180°):

$$P_{sum} = 4 \cdot U_{\alpha} \cdot I_{\alpha}$$
$$Q_{sum} = 0$$

for 2-phase AC elements (120°):

$$P_{sum} = 3 \cdot U_{\alpha} \cdot I_{\alpha}$$
$$Q_{sum} = 0$$

for 1-phase elements:

$$P_{sum} = 2 \cdot U_{\alpha} \cdot I_{\alpha}$$
$$Q_{sum} = 0$$

• Ssum is obtained as:

$$Ssum = \sqrt{Psum^2 + Qsum^2}$$

• cosphi1 is obtained as:

$$cosphi1 = cos(\phi_s)$$

where the angle is defined for 3-phase elements as:

$$\phi_s = \arctan\left(\frac{\underline{S}_{sum}.i}{\underline{S}_{sum}.r}\right)$$

for 1-phase and 2-phase elements is the angle $\phi_s=0^\circ$.

2.2.7 Miscellaneous variables (min/max values) for elements

Table 2.14: Miscellaneous variables (min/max values) for elements

Name	Unit	Description
Tfct	s	Fault Clearing Time

The result variables from Table 2.14 are calculated as follows:

• Tfct is the minimum from the fault clearing times: TfctPh:A, TfctPh:B, TfctPh:C, TfctPh:N.