

PowerFactory 2021

Technical Reference

AC/DC Connector

ElmConnectacdc

Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

Copyright © 2020 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

December 1, 2020 PowerFactory 2021 Revision 1

Contents

1 General Description

1

General Description 1

The AC/DC Connector element in PowerFactory is used for connecting an AC node to a DC node. It is a purely EMT single-phase model.

It is possible to define a resistance and an inductance, in which case the AC/DC connector is equivalent to a series reactor connected between an AC and a DC node.

The equations describing the model are:

$$u_{AC} - u_{DC} = R \cdot i_{AC} + L \cdot \frac{di_{AC}}{dt}$$

$$i_{AC} = -i_{DC}$$
(1)

$$i_{AC} = -i_{DC} \tag{2}$$

where the currents i_{AC} and i_{DC} are both defined positive if entering the AC or DC node.