

# **PowerFactory 2021**

**Technical Reference** 

**DIgSILENT F87T Transformer differential Generic Rela** 

#### Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

## Copyright © 2021 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

May 6, 2019 PowerFactory 2021 Revision 892

# **Contents**

1	F87T Transformer differential			
	1.1	Intent	1	
	1.2	Functionality	1	
	1.3	Inputs	1	
	1.4	Available Units	1	
	1.5	Outputs	2	

## 1 F87T Transformer differential

#### 1.1 Intent

To simulate the magnitude differential feature for transformer protection.

### 1.2 Functionality

The F87T Transformer differential generic relay model simulates a 3 phase (segregated phase) current magnitude differential element with  $2^{nd}$ ,  $4^{th}$ , and  $5^{th}$  harmonic restrain and differential threshold double bias restrain characteristic. An additional not restraint differential trip threshold is also available. The differential trip can be set with a configurable time delay.

The harmonic restrain can be disabled by the user with a check box in the differential element dialog; the restrain can be disabled if the current is greater than a given threshold. A *Phase Interlocking* logic can be enabled/disabled by the user and can be configured to be triggered by a single phase, by 2 out of 3 phases or by the phase average value.

## 1.3 Inputs

• Three 3 phase CTs ("Phase Ct 1", "Phase Ct 2" and "Phase Ct 3" block, StaCt class).

The *iblock\_1* relay input signals can be used to block the differential element trip.

#### 1.4 Available Units

#### Measurement

- Three 3 phase measurement elements ("Measurement 1", "Measurement 2", and "Measurement 3" block, *RMS Calculation* enabled, *Filter FFT [RelMeasure class]*).
- Four 3 phase RMS measurement blocks ancillary to the differential elements ("Differential RMS", "Differential RMS 2nd harmonic", "Differential RMS 3rd harmonic", and "Differential RMS 4th harmonic" block, [RelMeasure class]).

#### **Protective elements**

- Three 3 phase CT adapters ("Adapter 1", ("Adapter 2", and " Adapter 3" block, [emphRelCtadapt class).
- A differential element with Type set equal to 3ph ("Differential" block, [RelBiasidiff class]).

### **Output logic**

• One relay trip element ("Output logic" block, RelLogdip class).

## 1.5 Outputs

- yout associated by default to the differential element trip (any phase).
- y\_s associated by default to the differential element trip (any phase). Its behavior is identical to the *yout* signal and has been added to guarantee compatibility with the *F79 Recloser* generic relay.
- y\_A associated by default to the phase A differential element trip.
- y\_B associated by default to the phase B differential element trip.
- y\_C associated by default to the phase C differential element trip.

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.