

# **PowerFactory 2021**

**Technical Reference** 

**DIGSILENT Library - DSL Macros Documentation** 

# Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

# Copyright © 2021 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

January 21, 2021 PowerFactory 2021 Revision 2

# **Contents**

1	Gener	al Descrip	tion	1
	1.1	General	naming convention for DSL macros	1
2	Chara	cteristics		3
	2.1	Analytica	al Characteristics	3
		2.1.1	a(x-c1)(x-c2)	3
		2.1.2	ax^2 + bx + c	3
		2.1.3	mx + n	4
	2.2	Lookup	Tables	4
		2.2.1	Inverse Lookup array (linear)	4
		2.2.2	Inverse Lookup array object (linear)	4
		2.2.3	Lookup array (linear)	5
		2.2.4	Lookup array (linear_noclipping)	5
		2.2.5	Lookup array (spline)	5
		2.2.6	Lookup array 1x3 (linear_fixed)	6
		2.2.7	Lookup array 1x3 (linear_variable)	6
		2.2.8	Lookup array 1x4 (linear_fixed)	7
		2.2.9	Lookup array 1x4 (linear_variable)	7
		2.2.10	Lookup array object (linear)	7
		2.2.11	Lookup array object (linear_noclipping)	8
		2.2.12	Lookup array object (spline)	8
		2.2.13	Lookup matrix (linear)	8
		2.2.14	Lookup matrix (spline)	9
		2.2.15	Lookup matrix object (linear)	9
		2.2.16	Lookup matrix object (spline)	10
3	Compa	arators		10
	3.1	Basic Co	omparators	10
		3.1.1	yi equals C	10
		3.1.2	yi greater than C	10
		3.1.3	yi greater than or equal C	11

	3.1.4	yi less than C	11
	3.1.5	yi less than or equal C	12
	3.1.6	yi not equals C	12
	3.1.7	yi1 equals yi2	12
	3.1.8	yi1 greater than or equal yi2	12
	3.1.9	yi1 greater than yi2	13
	3.1.10	yi1 less or equal than yi2	13
	3.1.11	yi1 less than yi2	14
	3.1.12	yi1 not equals yi2	14
3.2	Compara	ators with Pick-up/Drop-off	14
	3.2.1	abs(in) greater than C _ip	14
	3.2.2	abs(in) less than C _ip	15
	3.2.3	yi equals C _ip	15
	3.2.4	yi greater than C _ip	15
	3.2.5	yi greater than or equal C _ip	16
	3.2.6	yi less than C _ip	16
	3.2.7	yi less than or equal C _ip	17
	3.2.8	yi1 equals yi2 _ip	17
	3.2.9	yi1 greater than or equal yi2 _ip	17
	3.2.10	yi1 greater than yi2 _ip	18
	3.2.11	yi1 less than or equal yi2 _ip	18
	3.2.12	yi1 less than yi2 _ip	19
3.3	Compara	ators with Threshold	19
	3.3.1	yi greater than C _eps	19
	3.3.2	yi less than C _eps	20
	3.3.3	yi1 greater than yi2 _eps	20
	3.3.4	yi1 less than yi2 _eps	20
Consta	ants		21
4.1	-C		21
4.2	0		21
4.3	1		22

4

	4.4	1/SQRT2	22
	4.5	2PI	22
	4.6	Bias	22
	4.7	C	23
	4.8	C1/C2	23
	4.9	E	23
	4.10	PI	23
	4.11	PI/2	24
	4.12	SQRT(2/3)	24
	4.13	SQRT(3/2)	24
	4.14	SQRT(C1/C2)	24
	4.15	SQRT2	25
	4.16	SQRT3	25
5	DSL S	pecial Functions	25
	5.1	aflipflop	25
	5.2	balanced	25
	5.3	delay	26
	5.4	flipflop	26
	5.5	gradlim_const	26
	5.6	invlapprox	27
	5.7	lapprox	27
	5.8	lapprox2	27
	5.9	lapproxext	27
	5.10	lastvalue	28
	5.11	lim	28
	5.12	lim_const	28
	5.13	movingavg	29
	5.14	picdro	29
	5.15	picdro_const	29
	5.16	rms	30
	5.17	sapprox	30

	5.18	sapprox2	30
	5.19	select	30
	5.20	select_const	31
	5.21	selfix	31
	5.22	selfix_const	31
	5.23	time	32
6	Deadb	ands	32
	6.1	Backlash	32
	6.2	Deadband	33
	6.3	Deadband [p;p] _bypass	33
	6.4	Deadband _bypass	33
	6.5	Deadband discontinuous	34
	6.6	Deadband offset [p;p] _bypass	34
	6.7	Deadband offset _bypass	34
	6.8	Deadband stepped [p;p] _bypass	35
	6.9	Deadband stepped _bypass	35
7	Delays	·	35
	7.1	Ke^-sT_bypass_incforward	35
	7.2	Ke^-sT_incforward	36
	7.3	Pade approximant R12 _incbackward	36
	7.4	Pade approximant R12 _incforward	37
	7.5	e^-s0.01 _incforward	37
	7.6	e^-sT_bypass	38
	7.7	e^-sT_bypass_incbackward	38
	7.8	e^-sT_bypass_incforward	39
	7.9	e^-sT_incbackward	39
	7.10	e^-sT_incforward	40
	7.11	lastvalue	40
	7.12	lastvalue _incbackward	40
	7.13	lastvalue _incforward	41
8	Deriva	tives	41

	8.1	s/(1+sT)		41
	8.2	sK/(1+0.0	01s)	42
	8.3	sK/(1+sT)	)	42
	8.4	sK/(1+sT)	) _fb	43
9	Electric	Power .		43
	9.1	El. Power	r	43
	9.2	PQ Calcu	ılator	44
	9.3	Power_ba	ase	44
10	Filters			44
	10.1	Band Pas	ss Filters	44
		10.1.1	(H0w0/Q)s/(w0^2+sw0/Q+s^2)	44
		10.1.2	s/(w0^2+s^2)	45
	10.2	High Pass	s Filters	45
		10.2.1	-sT/(1+sT)	45
		10.2.2	-sT/(1+sT) _bypass	46
		10.2.3	sKT/(1+sT)	46
		10.2.4	sKTd/(1+sT)	47
		10.2.5	sT/(1+sT) _bypass	47
		10.2.6	sT/(1+sT) _enable	48
		10.2.7	sTb/(1+sTa) _fb	48
		10.2.8	sTld/(1+sTlg) _fb	48
	10.3	Low Pass	Filters	49
		10.3.1	(1-K)/(1+sT)	49
		10.3.2	(1-K)/(1+sT) _bypass	49
		10.3.3	1/(1+sT)	50
		10.3.4	1/(1+sT) (p)	50
		10.3.5	1/(1+sT) (p;p)[p;p]	51
		10.3.6	1/(1+sT) (s)	51
		10.3.7	1/(1+sT) (s;s)	52
		10.3.8	1/(1+sT) [(p;p)]	52
		10.3.9	1/(1+sT) _bypass	52

		10.3.10	1/(1+sT) _enable	53
		10.3.11	1/(1+sT) and $sx$	53
		10.3.12	$1/(1+sT) \ \{p;p\} \ \_fb \ \ldots \ \ldots \ \ldots \ \ldots \ \ldots \ \ldots$	54
		10.3.13	1/(1+sT/2)	54
		10.3.14	1/(K+sT)	55
		10.3.15	1/(K+sT) _bypass	55
		10.3.16	1/K(T1/T2-1)(1/(1+sT2))	55
		10.3.17	1/K/(1+sT) _bypass	56
		10.3.18	K/(1+sT)	56
		10.3.19	K/(1+sT) (p;s) _bypass	57
		10.3.20	K/(1+sT) (s;s) _bypass	57
		10.3.21	K/(1+sT) (sp;sp)	58
		10.3.22	K/(1+sT) [(p;p)] _bypass	58
		10.3.23	K/(1+sT) _bypass	59
		10.3.24	K1 + K2/(1+sT)	59
		10.3.25	KT/(1+sT)	59
	10.4	Moving A	verage Filters	60
		10.4.1	MovingAverage (stateless)	60
		10.4.2	MovingAverage _enable_incforward	60
		10.4.3	MovingAverage _incforward	61
	10.5	Notch Filt	ters	61
		10.5.1	(s^2+wn^2)/(s^2+sBw+wn^2)	61
		10.5.2	(s^2+wn^2)/(s^2+sBw+wn^2) _bypass	61
	10.6	Other Filt	ers	62
		10.6.1	((1+sTz)/(1+sTp)^M)^N	62
11	Gains			63
	11.1	Multiply (	-1)	63
	11.2	Multiply (	-K)	63
	11.3	Multiply (	1-K)	63
	11.4	Multiply (	1-K1-K2)	64
	11.5	Multiply 1		64

	11.6	Multiply 1/K	64
	11.7	Multiply 1/K [p;p]	65
	11.8	Multiply 1/K1K2 [p;p]	65
	11.9	Multiply 1/SQRT2	66
	11.10	Multiply 1/SQRT3	66
	11.11	Multiply K	66
	11.12	Multiply K [p;p]	67
	11.13	Multiply K1 K2	67
	11.14	Multiply K1 K2 / K3	67
	11.15	Multiply K1 K2 K3	68
	11.16	Multiply K1/K2	68
	11.17	Multiply PI	69
	11.18	Multiply SQRT(2/3)	69
	11.19	Multiply SQRT(3/2)	69
	11.20	Multiply SQRT(K1/K2)	70
	11.21	Multiply SQRT2	70
	11.22	Multiply SQRT3	70
12	Higher	Order Transfer Functions	71
	12.1	(1+B1s+B2ss)/(1+A1s+A2ss) _bypass	71
	12.2	(1+KsTc)/((1+sTa)(1+sTb)(1+sTc)) _bypass	71
	12.3	(1+b1s+b2ss)/(1+a1s+a2ss)	72
	12.4	(1+sT3)/(1+sT1+ssT1T2) _bypass	72
	12.5	(1+sT3+ssT4)/(1+sT1+ssT2)	73
	12.6	(1+sTb)(sTa)^2/(1+sTa)^4	73
	12.7	(1+ssT3)/(1+sT1+ssT2) _bypass	73
	12.8	(A0+sA1+ssA2)/(B0+sB1+ssB2) _bypass	74
	12.9	(ss)/(Ass+Bs+1) _bypass	74
	12.10	(ss+ww)/(ss+sB+ww) _bypass	75
	12.11	1/(1+s(2 x zeta)/wc+ ss/(wc x wc))	75
	12.12	1/(1+sT1+ssT2) _bypass	76
	12.13	K(1+sT1)(1+sT2)/(s(1+sT3)) [(p;p)]	76

	12.14 K(1+sTd)	)/((1+sTa)(1+sTb)s) (p;p) _bypass	77
	12.15 e(-sTd)/(	(1+sT1)(1+sT1))	77
	12.16 s^2K/(1+	sT)^2	78
13	Integrators		78
	13.1 with rese	t (to initial value)	78
	13.1.1	1/s (p;p) _reset	78
	13.1.2	1/s (s;s) _enable_reset	79
	13.1.3	1/s [p;p] _reset	79
	13.1.4	1/s [p] _reset	80
	13.1.5	1/s [s;s] _reset	80
	13.1.6	1/s [s] _reset	81
	13.1.7	1/s _enable_reset	81
	13.1.8	1/s _incfreeze _reset	81
	13.1.9	1/s _reset	82
	13.1.10	1/sT _reset	82
	13.1.11	1/sT (p) _reset	83
	13.1.12	1/sT (p) _fb_reset	83
	13.1.13	1/sT (p; _reset	84
	13.1.14	1/sT (p; _fb_reset	84
	13.1.15	1/sT (p;p) _fb_reset	85
	13.1.16	1/sT (p;s) _fb_reset	85
	13.1.17	1/sT (pp;pp) _reset	86
	13.1.18	1/sT (s;p) _fb_reset	86
	13.1.19	1/sT (s;s) _fb_reset	87
	13.1.20	1/sT ;p) _fb_reset	88
	13.1.21	1/sT ;p) _reset	88
	13.1.22	1/sT ;p] _fb_reset	89
	13.1.23	1/sT ;p] _reset	89
	13.1.24	1/sT [p; _fb_reset	90
	13.1.25	1/sT [p; _reset	90
	13.1.26	1/sT _bypass_incfreeze_reset	91

	13.1.27	1/sT _fb_reset	91
	13.1.28	1/sT _incfreeze_reset	92
13.2	with rese	t (to input signal value)	92
	13.2.1	1/s (p;p) _reset_sig	92
	13.2.2	1/s (s;s) _enable_reset_sig	93
	13.2.3	1/s [p;p] _reset_sig	93
	13.2.4	1/s [p] _reset_sig	93
	13.2.5	1/s [s;s] _reset_sig	94
	13.2.6	1/s [s] _reset_sig	94
	13.2.7	1/s _enable_reset_sig	95
	13.2.8	1/s _incfreeze _reset_sig	95
	13.2.9	1/s _reset_sig	96
	13.2.10	1/sT _reset_sig	96
	13.2.11	1/sT (p) _reset_sig	97
	13.2.12	1/sT (p) _fb _reset_sig	97
	13.2.13	1/sT (p; _reset_sig	98
	13.2.14	1/sT (p; _fb_reset_sig	98
	13.2.15	1/sT (p;p) _fb_reset_sig	99
	13.2.16	1/sT (p;s) _fb_reset_sig	99
	13.2.17	1/sT (pp;pp) _reset_sig	100
	13.2.18	1/sT (s;p) _fb_reset_sig	100
	13.2.19	1/sT (s;s) _fb_reset_sig	101
	13.2.20	1/sT ;p) _fb_reset_sig	101
	13.2.21	1/sT ;p) _reset_sig	102
	13.2.22	1/sT ;p] _fb_sig	102
	13.2.23	1/sT ;p] _reset_sig	103
	13.2.24	1/sT [p; _fb_reset_sig	103
	13.2.25	1/sT [p; _reset_sig	104
	13.2.26	1/sT _bypass_incfreeze_reset_sig	104
	13.2.27	1/sT _fb_reset_sig	105
	13.2.28	1/sT _incfreeze_reset_sig	105

14	Lead-la	lag Blocks						
	14.1	(1+ATs)/(1+BTs)	106					
	14.2	(1+sTb)/(1+sTa)	106					
	14.3	(1+sTb)/(1+sTa) [(p;p)] _bypass	107					
	14.4	(1+sTb)/(1+sTa) [(p;p)] _fb	107					
	14.5	(1+sTb)/(1+sTa) [(pp;pp)] _bypass	108					
	14.6	(1+sTb)/(1+sTa) _bypass	108					
	14.7	(1+sTld)/(1+sTlg) and sx	109					
	14.8	(1-ATs)/(1+sAT/2)	109					
	14.9	(1-sT)/(1+sT/2) _bypass	109					
	14.10	(K+sTb)/(1+sTa)	110					
	14.11	(a+sbT)/(1+sT) _bypass	110					
	14.12	K(1+sTb)/(1+sTa)	111					
	14.13	K(1+sTld)/(1+sTlg) _fb	111					
	14.14	K(A1+sT1)/(A2+sT2)	112					
	14.15	$K(A1+sT1)/(A2+sT2) [(p;p)]_fb$	112					
	14.16	K(A1+sT1)/(A2+sT2) _fb	113					
	14.17	a23(1+(a11-a13a21/a23)sTw)/(1+a11sTw)	113					
15	Limiter	S	113					
	15.1	Limit ;p] _eps	114					
	15.2	Limit [p; _eps	114					
	15.3	Limit [p;p]	114					
	15.4	Limit [p;p] _eps	115					
	15.5	Limit [p]	115					
	15.6	Limit [p] (using min/max)	115					
	15.7	Limit [p] _eps	116					
	15.8	Limit [s;s]	116					
	15.9	Limit [s;s] _eps	116					
	15.10	Limit [sp;sp]	117					
	15.11	Limit lower [p;	117					
	15.12	Limit upper ;p]	117					

15.13 R	Rate limit	er ;p}	 118
15.14 R	Rate limit	er base ;p}	 118
15.15 R	Rate limit	er base {p;	 118
15.16 R	Rate limit	er base {p;p}	 119
15.17 R	Rate limit	er base {p}	 119
15.18 R	Rate limit	er {p;	 120
15.19 R	Rate limit	er {p;p}	 120
15.20 R	Rate limit	er {p}	 120
16 Logic Fur	nctions		 120
16.1 B	Basic Log	gic Functions	 121
	16.1.1	AND2	 121
	16.1.2	AND3	 121
	16.1.3	AND4	 122
	16.1.4	EOR	 122
	16.1.5	EQUAL	 122
	16.1.6	NOR	 123
	16.1.7	NOT	 123
	16.1.8	OR2	 124
	16.1.9	OR3	 124
	16.1.10	OR4	 125
16.2 L	.ogic Fur	nctions with Pick-up/Drop-off	 125
	16.2.1	2_out_of_3_ip	 125
	16.2.2	AND2_ip	 125
	16.2.3	AND3_ip	 126
	16.2.4	Invert Logic _ip	 127
	16.2.5	NOT_ip	 127
	16.2.6	OR2_ip	 127
	16.2.7	OR3_ip	 128
16.3 S	Special L	ogic Functions	 128
	16.3.1	Bistable	 128
	16.3.2	Edge detector	 129

	16.	.3.3	Monostable	129
17	Math Functi	ions		130
	17.1 Bas	ic Fur	nctions	130
	17.	.1.1	ABS	130
	17.	.1.2	CEIL	130
	17.	.1.3	EXP	130
	17.	.1.4	FLOOR	131
	17.	.1.5	FRAC	131
	17.	.1.6	LN	131
	17.	.1.7	LOG	132
	17.	.1.8	MAX2	132
	17.	.1.9	MAX3	132
	17.	.1.10	MAX4	132
	17.	.1.11	MIN2	133
	17.	.1.12	MIN3	133
	17.	.1.13	MIN4	133
	17.	.1.14	MODULO	133
	17.	.1.15	RECIPROCAL	134
	17.	.1.16	RECIPROCAL_fb	134
	17.	.1.17	ROUND	134
	17.	.1.18	SIGN	134
	17.	.1.19	SQRT	135
	17.	.1.20	x^2	135
	17.	.1.21	x^p	135
	17.2 Con	nplex	Operations	135
	17.	.2.1	ADD COMPLEX	135
	17.	.2.2	CONJ COMPLEX	136
	17.	.2.3	DIV COMPLEX	136
	17.	.2.4	MAG COMPLEX	136
	17.	.2.5	MUL COMPLEX	137
	17.	.2.6	SUB COMPLEX	137

		17.2.7	TO POLAR COMPLEX	137
		17.2.8	TO RECTANGULAR COMPLEX	137
	17.3	Trigonom	etric Functions	138
		17.3.1	ACOS	138
		17.3.2	ASIN	138
		17.3.3	ATAN	138
		17.3.4	ATAN2	138
		17.3.5	ATAN2D	139
		17.3.6	ATAND	139
		17.3.7	COS	139
		17.3.8	COSD	140
		17.3.9	COSH	140
		17.3.10	COSHD	140
		17.3.11	SIN	140
		17.3.12	SIND	141
		17.3.13	SINH	141
		17.3.14	SINHD	141
		17.3.15	TAN	141
		17.3.16	TAND	142
		17.3.17	TANH	142
		17.3.18	TANHD	142
18 I	Mecha	nical		142
	18.1	1/(2Hs)		143
	18.2	Accelerat	ting Power (simple)	143
	18.3	Accelerat	ting Power IPB	143
	18.4	Gear Box	·	143
	18.5	Mass_J		144
	18.6	P/omg ->	Torque	144
	18.7	Pt/Pturb		144
	18.8	Shaft J-k	and Pin	145
	18.9	Shaft i-J		145

	18.10	Shaft i-J-k	145
	18.11	Shaft i-J-k and Pin	146
	18.12	Spring	146
19	PI(D) C	controllers	146
	19.1	(1+sT)/KsT [p;p]	147
	19.2	$(1+sT)/KsT {p}[(p;p)] \dots \dots$	147
	19.3	(1+sTb)/sTa	148
	19.4	(1+sTp)/sTi ;p)]	148
	19.5	1+K/sT	149
	19.6	Kp(1/Ti+s)/s	149
	19.7	$Kp(1/Ti+s) / s\; (s)\; \ldots \; \ldots$	149
	19.8	Kp+1/sTi	150
	19.9	Kp+1/sTi [(p;p)]	150
	19.10	Kp+Ki/s	151
	19.11	Kp+Ki/s (s)	151
	19.12	Kp+Ki/s [(p;p)]	152
	19.13	Kp+Ki/s [p;p](pv;pv)	152
	19.14	Kp+Ki/s [s;s](sv;sv)	153
	19.15	Kp+Ki/s+sKd/(1+sTd) [(p;p)]	153
20	Signals		154
	20.1	Clock (t>0) _par	154
	20.2	Clock (t>0) _sig	155
	20.3	Clock (t>t0) _par	155
	20.4	Clock (t>t0) _sig	155
	20.5	Clock _par	156
	20.6	Clock _sig	156
	20.7	Pulse	157
	20.8	Sawtooth Wave Generator	157
	20.9	Sawtooth Wave Generator _ip	157
	20.10	Sine Wave Generator	158
	20.11	Sine Wave Generator (t>0)	158

	20.12 Square Wave Generator	158
	20.13 Square Wave Generator_ip	159
	20.14 Time	159
	20.15 Triangle Wave Generator	159
	20.16 Triangle Wave Generator_ip	160
21	Switches / Selectors	160
	21.1 Enable 1 sig	160
	21.2 Enable 1 sig _hold	161
	21.3 Enable 2 sig	161
	21.4 Enable 2 sig _hold	161
	21.5 Enable 3 sig	162
	21.6 Enable 3 sig _hold	162
	21.7 Enable 4 sig	162
	21.8 Enable 4 sig _hold	163
	21.9 Enable 5 sig	163
	21.10 Enable 5 sig _hold	164
	21.11 Enable 6 sig _hold	164
	21.12 Enable 7 sig _hold	164
	21.13 Enable 8 sig _hold	165
	21.14 Enable signal	165
	21.15 Enable signal (fixed)	165
	21.16 Switch par 1->1 by par	166
	21.17 Switch par 1->1 by par (fixed)	166
	21.18 Switch par 1->2 by par	167
	21.19 Switch par 1->2 by sig	167
	21.20 Switch par 2->1 by par	167
	21.21 Switch par 2->1 by sig	168
	21.22 Switch sig 1->1 by sig	168
	21.23 Switch sig 1->1 by sig (fixed)	168
	21.24 Switch sig 1->2 by par	169
	21.25 Switch sig 1->2 by par (bool)	169

	21.26	Switch sig 1->2 by sig	170
	21.27	Switch sig 2->1 (NOT EQ K) by s/p	170
	21.28	Switch sig 2->1 by par	170
	21.29	Switch sig 2->1 by par (bool)	171
	21.30	Switch sig 2->1 by sig	171
	21.31	Switch sig 2->1 by sig (bool)	171
	21.32	Switch sig 2->1 by sig (fixed)	172
	21.33	Switch sig 3->1 by sig	172
	21.34	Switch sig 4->1 by sig	172
	21.35	Switch sw equal C 2s->1s	173
	21.36	Switch sw greater than C 2s->1s	173
	21.37	Switch sw greater than or equal C 2s->1s	173
	21.38	Switch sw not equal C 2s->1s	174
	21.39	Switch sw smaller than C 2s->1s	174
	21.40	Switch sw smaller than or equal C 2s->1s	174
22	Timers		175
	22.1	Timer _reset	175
	22.2	Timer (reset/hold reset/t0) _reset_incfw	175
23	Transfo	rmations	176
	23.1	Clarke transform	176
	23.2	Inverse Clarke transform	176
	23.3	Inverse Park transform (dq)	177
	23.4	Inverse Park transform (dq0)	177
	23.5	Park transform (dq)	177
	23.6	Park transform (dq0)	178
	23.7	RMS value	178
	23.8	RMS value p.u	179
	23.9	U seq/ab0 -> U abc	179
	23.10	abc->dq0 (power invariant – align a->d)	180
	23.11	abc->dq0 (power invariant – align a->q)	180
	23.12	abc->dq0 (power variant – align a->d)	181

	23.13	abc->dq0 (power variant – align a->q)	. 181
	23.14	dq0->abc (power invariant – align a->d)	. 181
	23.15	dq0->abc (power invariant – align a->q)	. 182
	23.16	dq0->abc (power variant – align a->d)	. 182
	23.17	dq0->abc (power variant – align a->q)	. 182
24	Unit Co	onversion	. 183
	24.1	Hz -> p.u	. 183
	24.2	Nm -> p.u	. 183
	24.3	abs -> p.u. (par)	. 183
	24.4	abs -> p.u. (sig)	. 184
	24.5	deg -> rad	. 184
	24.6	p.u> Hz	. 184
	24.7	p.u> abs (par)	. 184
	24.8	p.u> abs (sig)	. 185
	24.9	p.u> rpm	. 185
	24.10	rad -> deg	. 185
	24.11	rad/s -> rpm	. 186
	24.12	rpm -> p.u	. 186
	2/ 12	rpm -> rad/e	196

# 1 General Description

This document describes the *PowerFactory* global library DSL macros.

# 1.1 General naming convention for DSL macros

A general naming convention is adopted for the global library macros in *PowerFactory*. The naming convention of DSL macro objects is as follows:

$$\underbrace{FunctionName}_{\text{function identifier}} \quad \underbrace{\{s \backslash p \backslash v; s \backslash p \backslash v\}[s \backslash p \backslash v; s \backslash p \backslash v](s \backslash p \backslash v; s \backslash p \backslash v)}_{\text{Limits section}} \quad \underbrace{\{s \backslash p \backslash v; s \backslash p \backslash v\}[s \backslash p \backslash v; s \backslash p \backslash v]}_{\text{Options section}} \quad \underbrace{-opt1\_opt2\_opt3...}_{\text{Options section}}$$

In the above, "s" stand for input signals, "p" for parameters and "v" for internal variables. The DSL macro object name (object parameter *loc\_name*) is split in three main parts, as described below:

- the *FunctionName* (mandatory) identifies the main functionality implemented in the macro (e.g. "1/sT").
- the Limits section (optional) contains a compact description of limits existing within the macro (e.g. "[p;p]" refers to an upper and lower output limiter).
- the *Options* section (optional) provides a listing of various macro options or implementation details which have been programmed into the DSL macro (e.g. "\_bypass" refers to a function which contains a parameter bypass implementation).

The syntax for limits applied to output signals uses square brackets, as defined below:

- [s\p\v; limiter, lower side (signal/parameter/internal variable), e.g. "1/s [s;" Integrator macro, lower output limitation with one signal, no upper output limitation;
- ;s\p\v] limiter, upper side (signal/parameter/internal variable), e.g. "1/s ;p]" Integrator macro, upper output limitation with one parameter, no lower output limitation:
- [s\p\v;s\p\v] upper and lower limiter, asymmetrical(i.e. with separate parameters/signals/variables), e.g. "1/s [p;p]" Integrator macro, lower and upper output limitation with two different parameters (asymmetrical);
- [s\p\v] upper and lower limiter (symmetrical i.e. with single parameter/signal/variable) output limitation, e.g. "1/sT [p]" Integrator macro, lower and upper limitation with single parameter (symmetrical)

The syntax for limits applied to state variables (e.g. anti-windup limiters) uses round parantheses, as defined below:

- (s\p\v; state variable, low limit (signal/parameter/internal variable), e.g. "1/s (p;" Integrator macro, state variable low limit with one parameter, no upper state variable limitation;
- ;s\p\v) state variable, upper limit (using signal/parameter/internal variable), e.g. "1/s ;p)" Integrator macro, state variable upper limit with one parameter,no lower state variable limitation;

- (s\p\v;s\p\v) upper and lower state variable limits, asymmetrical(i.e. with separate signals/parameters/internal variables), e.g. "1/s (p;pv)" Integrator macro, state variable low limit depending on a parameter, state variable upper limit depending on parameter and internal variable;
- (s\p\v) upper and lower state variable limit, symmetrical i.e. with a single parameter/signal/variable, e.g. "1/sT (p)" Integrator macro, state variable upper and lower limit with single parameter (symmetrical)

The syntax for gradient limits applied to output signals or state variables uses curly braces, as defined below:

- {s\p\v; gradient upon value decrease (using signal/parameter/internal variable), e.g. "1/s {p;" Integrator macro, gradient function upon value decrease using one slope parameter, no limitation upon value increase;
- ;s\p\v} gradient upon value increase (using signal/parameter/internal variable), e.g. "1/s ;p}" Integrator macro, gradient function upon value increase using one slope parameter, no limitation upon value decrease;
- {s\p\v;s\p\v} gradient upon increase/decrease, asymmetrical(i.e. with separate signals/parameters/variables), e.g. "1/s {p;p}" Integrator macro, gradient function upon value increase/decrease using two gradient parameters;
- {s\p\v} gradient upon increase/decrease, symmetrical i.e. with a single slope signal/parameter/internal variable, e.g. "1/sT {p}" Integrator macro, gradient function upon value increase/decrease using a single gradient parameter;

The DSL macro options are listed below:

- bypass This macro contains a bypass activated by on one of the (input) parameters.
- reset This macro includes a state/internal variable reset (based on an input signal).
- enable This macro includes an enable flag (based either on parameter or signal).
- trigger This macro includes a trigger port (input signal).
- **fb** This macro applies a fallback value to a parameter if condition true.
- \_incforward This macro contains already initialisation statements (of states, inputs or outputs). Initialisation occurs from input to output (forward initialisation).
- \_incbackward This macro contains already initialisation statements (of states, inputs or outputs). Initialisation occurs from output to input (backward initialisation).
- \_incfreeze This macro disables parts of its functionality for the duration of the calculation of initial conditions and a short period afterwards (typically defined by a parameter). This is used to avoid dx/dt<>0 messages.
- eps This macro contains a user defined epsilon parameter for various purposes.
- \_ip This macro uses picdro (instead of select or select\_const) for logic evaluation (or comparator) in order to avoid toggling effects by internally applying interpolation and reevaluation.
- sig This macro is a variant based on an input signal.
- \_par This macro is a variant based on a parameter.

The limits and the options may appear in various combinations within practical DSL macros, for example:

- 1/sT {s}[p] \_bypass Integrator macro with gradient limiter using one signal (symmetrical); lower and upper limitation using one parameter (symmetrical), function implements a bypass
- 1/sT [(p;p)] Integrator macro with lower/upper asymetrical limit on output signal and on state variable, using the same parameter for state variable and the output limit
- 1/sT [p;p] \_bypass\_reset\_trigger Integrator macro, lower and upper output limitation with two parameters (asymmetrical); with bypass, reset and trigger functions
- 1/sT [(p)] Integrator macro, symmetrical limiter on output signal and state variable using a single parameter
- 1/sT {s}[pv; \_bypass Integrator macro, gradient limiter up/down with one signal (symmetrical); lower output limitation depending on one parameter and one internal variable; with bypass function

Transfer functions shown throughout this document are in their standard form (monic numerator/denominator polynomials and an optional gain). In some cases, for easier notation, a more simplified form has been used.

# 2 Characteristics

This section provides a complete listing of the existing DSL macros within the *Characteristics* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 2.1 Analytical Characteristics

# 2.1.1 a(x-c1)(x-c2)

#### Quadratic function (factorial form)

Functionality: Quadratic function (factorial form) This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Analytical Characteristics

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: a,c1,c2

#### $2.1.2 \quad ax^2 + bx + c$

# Quadratic function (general form)

Functionality: Quadratic function (general form)

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Analytical Characteristics

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: a,b,c

# 2.1.3 mx + n

#### Linear function/straight line

Functionality: Computes the linear function/straight line

This macro has a linear behaviour.

Macro location: Macros\Characteristics\Analytical Characteristics

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: m.n

# 2.2 Lookup Tables

# 2.2.1 Inverse Lookup array (linear)

# Inverse lookup internal array, linear approximation

Functionality: Inverse lapprox function based on internal array.

Identifies the corresponding value of argument x of the function y=f(x), where y and x are pro-

vided in the two-column array "array\_K". This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array K

# 2.2.2 Inverse Lookup array object (linear)

# Inverse lookup external array, linear approximation

Functionality: Inverse lapprox function based on external array.

Identifies the corresponding value of argument x of the function y=f(x), where y and x are pro-

vided in the two-column array "oarray\_K".

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: oarray\_K

#### 2.2.3 Lookup array (linear)

#### Lookup internal array, linear approximation

Functionality: Lookup table function based on internal array, linear approximation. When input is outside pre-defined range, output values are kept constant (characteristic clipping). Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column array "array\_K".

Uses the internal common model array definition (refer to lapprox() description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array\_K

# 2.2.4 Lookup array (linear\_noclipping)

#### Lookup internal array, linear approximation and extrapolation outside range

Functionality: Lookup table function based on internal array, linear approximation and extrapolation outside range. When "x" values are outside range of pre-defined characteristic, a linear extrapolation is done based on the last two characteristic points of the upper or lower side, depending on the situation.

Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column array "array\_K".

Uses the internal common model array definition (refer to lapprox() description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array\_K

#### 2.2.5 Lookup array (spline)

# Lookup internal array, spline approximation

Functionality: Lookup table function based on internal array, spline approximation. When input is outside pre-defined range, output values are kept constant (characteristic clipping). Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column array "array K".

Uses the internal common model array definition (refer to sapprox() description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array K

#### 2.2.6 Lookup array 1x3 (linear fixed)

# Lookup table 1x3, linear approximation, fixed characteristic based on parameters

Look-up table size 1 by 3, input data points using parameters

The set of input data points arr\_xn must be monotonically increasing

if vClip is 1 then whenever the input is outside the defined range, the output is set to the last given point

if vClip is 0 then whenever the input is outside the defined range, the output is calculated based on the slope of the last two points in the characteristic

Macro equations

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: arr\_x1,arr\_x2,arr\_x3,arr\_y1,arr\_y2,arr\_y3,vClip

Internal variables: m,n,m1,m2

# 2.2.7 Lookup array 1x3 (linear variable)

# Lookup table 1x3, linear approximation, variable characteristic based on signals

Look-up table size 1 by 3, input data points using variable signals

The set of input data points arr xn must be monotonically increasing

if vClip is 1 then whenever the input is outside the defined range, the output is set to the last given point

if vClip is 0 then whenever the input is outside the defined range, the output is calculated based on the slope of the last two points in the characteristic

Macro equations

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5
Output signals: yo

Input signals: yi,arr\_x1,arr\_x2,arr\_x3,arr\_y1,arr\_y2,arr\_y3

Parameters: vClip

Internal variables: m,n,m1,m2

# 2.2.8 Lookup array 1x4 (linear\_fixed)

# Lookup table 1x4, linear approximation, fixed characteristic based on parameters

Look-up table size 1 by 4, input data points using parameters

The set of input data points arr xn must be monotonically increasing

if vClip is 1 then whenever the input is outside the defined range, the output is set to the last given point

if vClip is 0 then whenever the input is outside the defined range, the output is calculated based on the slope of the last two points in the characteristic

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: arr\_x1,arr\_x2,arr\_x3,arr\_x4,arr\_y1,arr\_y2,arr\_y3,arr\_y4,vClip

Internal variables: m,n,m1,m2,m3

# 2.2.9 Lookup array 1x4 (linear\_variable)

#### Lookup table 1x4, linear approximation, variable characteristic based on signals

Look-up table size 1 by 4, input data points using variable signals

The set of input data points arr xn must be monotonically increasing

if vClip is 1 then whenever the input is outside the defined range, the output is set to the last given point

if vClip is 0 then whenever the input is outside the defined range, the output is calculated based on the slope of the last two points in the characteristic

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo

Input signals: yi,arr\_x1,arr\_x2,arr\_x3,arr\_x4,arr\_y1,arr\_y2,arr\_y3,arr\_y4

Parameters: vClip

Internal variables: m,n,m1,m2,m3

#### 2.2.10 Lookup array object (linear)

# Lookup external array, linear approximation

Functionality: Lookup table function based on external array, linear approximation. When input is outside pre-defined range, output values are kept constant (characteristic clipping). Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column array "oarray K".

Uses the external object IntMat (refer to lapprox description in the User Manual). This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: oarray\_K

# 2.2.11 Lookup array object (linear\_noclipping)

#### Lookup external array, linear approximation with extrapolation outside range

Functionality: Lookup table function based on external array, linear approximation and extrapolation outside range. When "x" values are outside range of pre-defined characteristic, a linear extrapolation is done based on the last two characteristic points of the upper or lower side, depending on the situation.

Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column array "oarray K".

Uses the external object IntMat (refer to lapprox description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: oarray\_K

#### 2.2.12 Lookup array object (spline)

# Lookup external array, spline approximation

Functionality: Lookup table function based on external array, spline approximation. When input is outside pre-defined range, output values are kept constant (characteristic clipping). Identifies the corresponding value of the function y=f(x), where y and x are provided in the two-column external array "oarray K".

Uses the external object IntMat (refer to sapprox description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: oarray\_K

# 2.2.13 Lookup matrix (linear)

# Lookup internal matrix, linear approximation

Functionality: Lookup table functionbased on internal matrix, linear approximation.

Identifies the value of the function z=f(x,y), where x and y are the rows/columns of the internal matrix "matrix\_K" and the matrix values are the corresponding z=f(x,y).

Uses the internal common model matrix definition (refer to lapprox2 description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: matrix\_K

#### 2.2.14 Lookup matrix (spline)

# Lookup internal matrix, spline approximation

Functionality: Lookup table function based on internal matrix, spline approximation.

Identifies the value of the function z=f(x,y), where x and y are the rows/columns of the internal matrix "matrix K" and the matrix values are the corresponding z=f(x,y).

Uses the internal common model matrix definition (refer to sapprox2 description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: matrix\_K

# 2.2.15 Lookup matrix object (linear)

### Lookup external matrix, linear approximation

Functionality: Lookup table function based on external matrix, linear approximation.

Identifies the value of the function z=f(x,y), where x and y are the rows/columns of the external matrix "omatrix K" and the matrix values are the corresponding z=f(x,y).

Uses the external object IntMat (refer to lapprox2 description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: omatrix\_K

# 2.2.16 Lookup matrix object (spline)

#### Lookup external matrix, spline approximation

Functionality: Lookup table function based on external matrix, spline approximation. Identifies the value of the function z=f(x,y), where x and y are the rows/columns of the external matrix "omatrix K" and the matrix values are the corresponding z=f(x,y).

Uses the external object IntMat (refer to sapprox2 description in the User Manual).

This macro has a non-linear behaviour.

Macro location: Macros\Characteristics\Lookup Tables

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: omatrix\_K

# 3 Comparators

This section provides a complete listing of the existing DSL macros within the *Comparators* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 3.1 Basic Comparators

# 3.1.1 yi equals C

# Checks if the input is equal with a constant (real numbers)

Functionality: Checks if the input is equal with a constant (real numbers)

This macro has a non-linear behaviour.

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.2 yi greater than C

# Greater than C (real numbers)

Functionality: Returns 1 if input is greater than parameter C. Returns 0 otherwise.

Function based on select\_const().
This macro has a non-linear behaviour.

#### **Function:**

$$yo = \begin{cases} 1 & \text{if } yi > C \\ 0 & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.3 yi greater than or equal C

# **Greater or equal than C (real numbers)**

Functionality: Returns 1 if input is greater or equal than parameter C. Returns 0 otherwise.

Function based on select\_const().
This macro has a non-linear behaviour.

#### **Function:**

$$yo = \begin{cases} 1 & \text{if } yi >= C \\ 0 & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.4 yi less than C

#### Less than C (real numbers)

Functionality: Returns 1 if input is less than parameter C. Returns 0 otherwise.

Function based on select\_const(). This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} 1 & \text{if } yi < C \\ 0 & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.5 yi less than or equal C

# Less or equal than C (real numbers)

Functionality: Returns 1 if input is less or equal than parameter C. Returns 0 otherwise.

Function based on select\_const(). This macro has a non-linear behaviour.

Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi <= C \\ \mathbf{0} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.6 yi not equals C

# Checks if the input is not equal with a constant (real numbers)

Functionality: Checks if the input is not equal with a constant (real numbers)

This macro has a non-linear behaviour.

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C

# 3.1.7 yi1 equals yi2

# Checks if two real valued inputs are equal (real numbers)

Functionality: Checks if two real numbers are equal

This macro has a non-linear behaviour.

**Macro location:** *Macros\Comparators\Basic Comparators* 

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.1.8 yi1 greater than or equal yi2

# Greater or equal than (real numbers)

Functionality: Returns 1 if first input is greater or equal than the second. Returns 0 otherwise

Function based on select\_const().

This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} 1 & \text{if } yi1 >= yi2 \\ 0 & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.1.9 yi1 greater than yi2

# Greater than (real numbers)

Functionality: Returns 1 if first input is greater than the second. Returns 0 otherwise. Function based on select const().

This macro has a non-linear behaviour.

# **Function:**

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1 > yi2 \\ \mathbf{0} & \text{otherwise} \end{cases}$$

**Macro location:** *Macros\Comparators\Basic Comparators* 

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.1.10 yi1 less or equal than yi2

# Less or equal than (real numbers)

Functionality: Returns 1 if first input is less or equal than the second. Returns 0 otherwise.

Function based on select\_const().
This macro has a non-linear behaviour.

# Function:

$$yo = \begin{cases} 1 & \text{if } yi1 <= yi2 \\ 0 & \text{otherwise} \end{cases}$$

**Macro location:** *Macros\Comparators\Basic Comparators* 

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.1.11 yi1 less than yi2

# Less than (real numbers)

Functionality: Returns 1 if first input is less than the second. Returns 0 otherwise.

Function based on select\_const().
This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1 < yi2 \\ \mathbf{0} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.1.12 yi1 not equals yi2

# Checks if two real valued inputs are not equal (real numbers)

Functionality: Checks if two real numbers are not equal

This macro has a non-linear behaviour.

Macro location: Macros\Comparators\Basic Comparators

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 3.2 Comparators with Pick-up/Drop-off

#### 3.2.1 abs(in) greater than C ip

# Abs lower than C (real numbers, picdro implementation)

Functionality: Returns 1 if absolute value of input is greater than parameter C. Returns 0 otherwise.

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } |yi| > C \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } |yi| <= C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.2 abs(in) less than C ip

# Abs lower than (real numbers, picdro implementation)

Functionality: Returns 1 if absolute value of input is smaller than parameter C. Returns 0 otherwise.

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} 1 & \text{if } |yi| < C \text{ for } T_{pick} \text{ seconds} \\ 0 & \text{if } |yi| >= C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.3 yi equals C\_ip

#### Checks if input is equal to parameter value (real numbers, picdro implementation)

Functionality: Checks if input is equal to parameter value (real numbers)
Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.
This macro has a non-linear behaviour.

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.4 yi greater than C ip

# Larger than C (real numbers, picdro implementation)

Functionality: Returns 1 if input is greater than parameter C. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### **Function:**

$$yo = \begin{cases} 1 & \text{if } yi > C \text{ for } T_{pick} \text{ seconds} \\ 0 & \text{if } yi <= C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.5 yi greater than or equal C \_ip

# Larger or equal than C (real numbers, picdro implementation)

Functionality: Returns 1 if input is greater or equal than parameter C. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi >= C \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi < C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.6 yi less than C\_ip

# Lower than C (real numbers, picdro implementation)

Functionality: Returns 1 if input is smaller than parameter C. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### **Function:**

$$yo = \begin{cases} 1 & \text{if } yi < C \text{ for } T_{pick} \text{ seconds} \\ 0 & \text{if } yi >= C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C,Tpick,Tdrop

# 3.2.7 yi less than or equal C \_ip

#### Lower or equal than C (real numbers, picdro implementation)

Functionality: Returns 1 if input is smaller or equal than parameter C. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi <= C \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi > C \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: C,Tpick,Tdrop

# 3.2.8 yi1 equals yi2 \_ip

# Checks if two real valued inputs are equal (real numbers, picdro implementation)

Functionality: Checks if two real valued inputs are equal

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.

This macro has a non-linear behaviour.

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick,Tdrop

# 3.2.9 yi1 greater than or equal yi2 \_ip

#### Larger or equal than (real numbers, picdro implementation)

Functionality: Returns 1 if first input is greater or equal than the second. Returns 0 otherwise.

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

# Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1>=yi2 \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi1< yi2 \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick, Tdrop

### 3.2.10 yi1 greater than yi2 \_ip

### Larger than (real numbers, picdro implementation)

Functionality: Returns 1 if first input is greater than the second. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1 > yi2 \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi1 <= yi2 \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick, Tdrop

#### 3.2.11 yi1 less than or equal yi2 ip

### Lower or equal than (real numbers, picdro implementation)

Functionality: Returns 1 if first input is smaller or equal than the second. Returns 0 other-

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1 <= yi2 \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi1 > yi2 \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick, Tdrop

# 3.2.12 yi1 less than yi2 ip

#### Lower than (real numbers, picdro implementation)

Functionality: Returns 1 if first input is smaller than the second. Returns 0 otherwise. Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} \mathbf{1} & \text{if } yi1 < yi2 \text{ for } T_{pick} \text{ seconds} \\ \mathbf{0} & \text{if } yi1 >= yi2 \text{ for } T_{drop} \text{ seconds} \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick,Tdrop

# 3.3 Comparators with Threshold

#### 3.3.1 yi greater than C eps

#### Greater than C (real numbers, with threshold)

Functionality: Returns 1 if input is greater than parameter C. Returns 0 otherwise. Function includes a small threshold upon switching around the constant C.

This block avoids toggling behaviour when the input signal value is close to the constant parameter C.

The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is a simple logic function without switching threshold.

This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} 1 & \text{if } yi > (C + eps) \\ 0 & \text{if } yi < (C - eps) \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Threshold

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C,eps Internal variables: set,rst

### 3.3.2 yi less than C eps

### Less than C (real numbers, with threshold)

Functionality: Returns 1 if input is less than parameter C. Returns 0 otherwise. Function includes a small threshold upon switching around the constant C.

This block avoids toggling behaviour when the input signal value is close to the constant parameter C.

The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is a simple logic function without switching threshold.

This macro has a non-linear behaviour.

#### Function:

$$yo = egin{cases} 1 & & \text{if } yi < (C-eps) \\ 0 & & \text{if } yi > (C+eps) \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Threshold

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: C,eps

Internal variables: set,rst

#### 3.3.3 vi1 greater than vi2 eps

#### Greater than (real numbers, with threshold)

Functionality: Logic "greater than" function with threshold This macro has a non-linear behaviour.

#### Function:

$$yo = \begin{cases} 1 & \text{if } yi1 > (yi2 + eps) \\ 0 & \text{if } yi1 < (yi2 - eps) \\ \text{unchanged} & \text{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Threshold

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: eps

Internal variables: set,rst

### 3.3.4 yi1 less than yi2 eps

Less than (real numbers, with threshold)

Functionality: Logic "less than" function with threshold This macro has a non-linear behaviour.

**Function:** 

$$yo = egin{cases} 1 & ext{if } yi1 < (yi2 - eps) \\ 0 & ext{if } yi1 > (yi2 + eps) \\ ext{unchanged} & ext{otherwise} \end{cases}$$

Macro location: Macros\Comparators\Comparators with Threshold

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: eps

Internal variables: set,rst

# 4 Constants

This section provides a complete listing of the existing DSL macros within the *Constants* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

#### 4.1 -C

# Outputs a constant value equal to -C

Functionality: Outputs a constant value equal to -C.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo Parameters: C

#### 4.2 0

### Outputs a constant zero value

Functionality: Outputs a constant zero value.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

### 4.3 1

### **Outputs 1**

Functionality: Outputs 1.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

#### 4.4 1/SQRT2

## **Outputs 1/SQRT2**

Functionality: Outputs 1/SQRT2. This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

### 4.5 2PI

# **Outputs 2\*PI**

Functionality: Outputs 2\*PI.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 4.6 Bias

# Outputs a constant value defined at initialization

Functionality: Outputs a constant value defined by the value of the output at initialisation.

This block requires that the macro's output is initialised externally.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo Internal variables: bias

# 4.7 C

# Outputs a constant (parameter) value

Functionality: Outputs a constant value, defined by parameter C.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo Parameters: C

# 4.8 C1/C2

### Outputs a constant (parameter) value equal to C1/C2

Functionality: Outputs a constant value, defined by parameter C1 and C2, equal to C1/C2.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo Parameters: C1,C2

# 4.9 E

# Outputs e

Functionality: Outputs e, base of the natural logarithm.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 4.10 PI

# **Outputs PI**

Functionality: Outputs PI.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

### 4.11 PI/2

### **Outputs PI/2**

Functionality: Outputs PI/2.

This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 4.12 SQRT(2/3)

# Outputs SQRT(2/3)

Functionality: Outputs SQRT(2/3) This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 4.13 SQRT(3/2)

# Outputs SQRT(3/2)

Functionality: Outputs SQRT(3/2) This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 4.14 SQRT(C1/C2)

# Outputs the constant value SQRT(C1/C2)

Functionality: Outputs SQRT(C1/C2) This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo Parameters: C1,C2

### 4.15 SQRT2

### **Outputs SQRT2**

Functionality: Outputs SQRT2 This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

### 4.16 SQRT3

## **Outputs SQRT3**

Functionality: Outputs SQRT3
This macro has a linear behaviour.

Macro location: Macros\Constants

Macro DSL level: 5 Output signals: yo

# 5 DSL Special Functions

This section provides a complete listing of the existing DSL macros within the *DSL Special Functions* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 5.1 aflipflop

# Function aflipflop(yi,set,rst)

Functionality: Implements the DSL special function aflipflop(), using input signals yi, set and

rst.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi,set,rst

### 5.2 balanced

### Function balanced()

Functionality: Returns the network representation type (balanced=1 or unbalanced=0).

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

# 5.3 delay

### Function delay()

Functionality: Applies a time delay of duration T on the input. The output is the delayed value of

the input.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

# 5.4 flipflop

# Function flipflop(set,rst)

Functionality: Implements the DSL special function flipflop() based on the input signals set

and rst.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: set,rst

# 5.5 gradlim const

### Function gradlim\_const()

Functionality: Implements the DSL special function gradlim\_const().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

**Lower limitation parameters:** gradmin **Upper limitation parameters:** gradmax

# 5.6 invlapprox

### Function invlapprox()

Functionality: Implements the DSL special function invlapprox().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array\_K

# 5.7 lapprox

### Function lapprox()

Functionality: Implements the DSL special function lapprox().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array\_K

# 5.8 lapprox2

# Function lapprox2()

Functionality: Implements the DSL special function lapprox2().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: row,col Parameters: matrix K

# 5.9 lapproxext

# Function lapproxext()

Functionality: Implements the DSL special function lapproxext().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5

Output signals: yo Input signals: yi Parameters: array K

### 5.10 lastvalue

# Function lastvalue()

Functionality: Implements the DSL special function lastvalue().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 5.11 lim

### Function lim(yi,y min,y max)

Functionality: Implements the DSL special function lim(). Limits input yi based on input sig-

nals y\_min and y\_max.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

Input signals: yi,y\_min,y\_max

# 5.12 lim\_const

### Function lim\_const(yi,y\_min,y\_max)

Functionality: Implements the DSL special function lim const(). Limits the input yi based on

the parameters y\_min and y\_max.
This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

# 5.13 movingavg

#### **Function Moving Average**

Functionality: Implements a buffer based moving average filter. The function includes a delay or a buffer based DSL function in the input-output path.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: Tdel, Tlength

# 5.14 picdro

#### Function picdro(condition, Tpick, Tdrop)

Functionality: Implements the DSL special function picdro(). Sets the output yo to HIGH if condition is TRUE for at least Tpick seconds. If the output is HIGH, then it sets the output yo to LOW if condition is FALSE for at least Tdrop seconds. Tpick and Tdrop are input signals.

output can be 1 = HIGH or 0 = LOW if condition >= 0.5 then evaluate to TRUE if condition < 0.5 then evaluate to FALSE This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

Input signals: condition, Tpick, Tdrop

# 5.15 picdro\_const

# Function picdro\_const(condition,Tpick,Tdrop)

Functionality: Implements the DSL special function picdro(). Sets the output yo to HIGH if condition is TRUE for at least Tpick seconds. If the output is HIGH, then it sets the output yo to LOW if condition is FALSE for at least Tdrop seconds. Tpick and Tdrop are parameters.

output can be 1 = HIGH or 0 = LOW if condition >= 0.5 then evaluate to TRUE if condition < 0.5 then evaluate to FALSE This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: condition Parameters: Tpick,Tdrop

#### 5.16 rms

# Function rms()

Functionality: Returns the dynamic simulation type (RMS=1 or EMT=0).

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

# 5.17 sapprox

## Function sapprox()

Functionality: Implements the DSL special function sapprox().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: array\_K

### 5.18 sapprox2

# Function sapprox2()

Functionality: Implements the DSL special function sapprox2().

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo Input signals: row,col Parameters: matrix K

# 5.19 select

### Function select(condition, v true, v false)

Functionality: Implements the DSL special function select(). Sets the output yo to y\_true if condition is TRUE. Sets the output yo to y false if condition is FALSE.

output can be y\_true OR y\_false. Both y\_true and y\_false are input signals.

if condition >= 0.5 then evaluate to TRUE if condition < 0.5 then evaluate to FALSE

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

Input signals: condition,y true,y false

# 5.20 select const

#### Function select const(condition,K true,K false)

Functionality: Implements the DSL special function select\_const(). Sets the output yo to K\_true if condition is TRUE. Sets the output yo to K\_false if condition is FALSE.

output can be K true OR K false. Both K true and K false are parameters.

if condition >= 0.5 then evaluate to TRUE if condition < 0.5 then evaluate to FALSE This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5
Output signals: yo
Input signals: condition
Parameters: K true,K false

#### 5.21 selfix

#### Function selfix(condition,y true,y false)

Functionality: Implements the DSL special function selfix(). Sets the output yo to y\_true if condition is TRUE at initialisation. Sets the output yo to y\_false if condition is FALSE at initialisation.

output can be y true OR y\_false. Both y\_true and y\_false are input signals.

if condition >= 0.5 then evaluate to TRUE if condition < 0.5 then evaluate to FALSE This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

Input signals: condition,y\_true,y\_false

### 5.22 selfix const

# Function selfix\_const(condition,K\_true,K\_false)

Functionality: Implements the DSL special function selfix\_const(). Sets the output yo to K\_true if condition is TRUE at initialisation. Sets the output yo to K\_false if condition is FALSE at initialisation.

output can be K true OR K false. Both K true and K false are parameters.

if condition >= 0.5 then evaluate to TRUE

if condition < 0.5 then evaluate to FALSE This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5
Output signals: yo
Input signals: condition
Parameters: K\_true,K\_false

#### 5.23 time

### Function time()

Functionality: Returns the current simulation time.

This macro has a non-linear behaviour.

Macro location: Macros\DSL Special Functions

Macro DSL level: 5 Output signals: yo

# 6 Deadbands

This section provides a complete listing of the existing DSL macros within the *Deadbands* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

### 6.1 Backlash

#### **Backlash function**

Functionality: This macro implements a backlash function.

Bypass option: if the deadband db is <=0 then yo is constant throughout the simulation.

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: db Internal variables: d

### 6.2 Deadband

#### Continuos deadband

Functionality: This macro implements a continuous deadband block

Returns:

yi-db if yi > db (outside deadband, positive side) yi+db if yi <-db (outside deadband, negative side)

0 if -db < yi < db (within deadband)

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

# 6.3 Deadband [p;p] \_bypass

# Continuous deadband with limits (bypass)

Functionality: This macro implements a continuous deadband with limits and bypass

Bypass option: A bypass function is also included if the deadband db is zero.

yi-db if yi > db (outside deadband, positive side) yi+db if yi <-db (outside deadband, negative side)

0 if -db < yi < db (within deadband)

Output yo is limited between y min and y max

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

# 6.4 Deadband bypass

#### Continuos deadband (bypass)

Functionality: This macro implements a continuous deadband blockwith bypass

Returns:

yi-db if |yi| > db (outside deadband, positive side) yi+db if |yi| <-db (outside deadband, negative side)

0 if -db < yi < db (within deadband)

Bypass option: A bypass function is also included if the deadband db is zero.

if db<=0, then vo=vi

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

## 6.5 Deadband discontinuous

### Discontinuous deadband

Functionality: This macro implements a discontinuous deadband

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

# 6.6 Deadband offset [p;p] \_bypass

# Continuous deadband with offset and limits (bypass)

Functionality: This macro implements a continuous deadband with offset and limits.

Bypass option: A bypass function is also included if the deadband db<=0.

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 6.7 Deadband offset bypass

# Continuous deadband with offset (bypass)

Functionality: This macro implements a continuous deadband with offset. Bypass option: A bypass function is also included if the deadband db<=0.

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5
Output signals: yo
Input signals: yi
Parameters: db

# Deadband stepped [p;p] \_bypass

# Stepped deadband with limits (bypass)

Functionality: This macro implements a stepped deadband with limits. Bypass option: A bypass function is also included if the deadband db<=0.

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

Lower limitation parameters: y min **Upper limitation parameters:** y max

# Deadband stepped bypass

## Stepped deadband (bypass)

Functionality: This macro implements a stepped deadband.

Bypass option: A bypass function is also included if the deadband db<=0.

This macro has a non-linear behaviour.

Macro location: Macros\Deadbands

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: db

# **Delays**

This section provides a complete listing of the existing DSL macros within the *Delays* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 7.1 Ke<sup>-</sup>-sT bypass incforward

#### Transport delay with gain and initial condition for output, T>=0 (bypass)

Functionality: This macro implements a transport delay with gain and initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path. Parameter T must be non-negative. Otherwise a message is printed to the output window. Bypass option: If T<=0 then yo=K\*yi (gain block)

Forward initial condition option: Output is initialised based on the input This macro has a non-linear behaviour.

Function:

$$H(s) = K e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K,T

# 7.2 Ke^-sT incforward

### Transport delay with gain and initial condition for output, T>0

Functionality: This macro implements a transport delay with gain and initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path. Parameter T must be positive. Otherwise a message is printed to the output window. Forward initial condition option: Output is initialised based on the input

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = K e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K, T

# 7.3 Pade approximant R12 incbackward

### Pade Second Order Approximation (one zero, two poles; bacward initialisation yi<-yo)

Functionality: Implements the time continuous Pade approximation for delays, 2nd order (R1,2): one zero, two poles.

Parameters:

Td - time delay in seconds

A time delay Td smaller than 0.1 ms is not allowed, for robust operation.

Backward initial condition option: Initialisation occurs from the output to the input.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 - \frac{Td}{2}s + \frac{Td^2}{12}s^2}{1 + \frac{Td}{2}s + \frac{Td^2}{12}s^2}$$

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: Td

Internal variables: A0,A1,A2,B0,B1,offset

# 7.4 Pade approximant R12 incforward

### Pade Second Order Approximation (one zero, two poles; forward initialisation yi->yo)

Functionality: Implements the time continuous Pade approximation for delays, 2nd order (R1,2): one zero, two poles.

Parameters:

Td - time delay in seconds

A time delay Td smaller than 0.1 ms is not allowed, for robust operation. Forward initial condition option: Output is initialised based on the input.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{1 - \frac{Td}{2}s + \frac{Td^2}{12}s^2}{1 + \frac{Td}{2}s + \frac{Td^2}{12}s^2}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: Td

Internal variables: A0,A1,A2,B0,B1,offset

# 7.5 e^-s0.01 incforward

#### Transport delay of 10 ms with initial condition for output

Functionality: This macro implements a transport delay of 10 ms with initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path.

Forward initial condition option: Output is initialised based on the input.

Note: The delay function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

This macro has a non-linear behaviour.

Function:

$$H(s) = e^{-s0.01}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi

# 7.6 e^-sT bypass

#### Transport delay, T>=0 (bypass)

Functionality: This macro implements a transport delay. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T must be non-negative. Otherwise a message is printed to the output window.

Note: The delay function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

Bypass option: If T<=0 then yo=yi (feedthrough block)

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

# 7.7 e^-sT\_bypass\_incbackward

### Transport delay, T>=0 (with bypass, backward initialisation: yi <- yo)

Functionality: This macro implements a transport delay with initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T must be non-negative. Otherwise a message is printed to the output window.

Note: The delay function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

Bypass option: If T<=0 then yo=yi (feedthrough block)

Backward initial condition option: Input is initialised based on the output.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = e^{-sT}$$

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

# 7.8 e^-sT\_bypass\_incforward

### Transport delay, T>=0 (with bypass, forward initialisation: yi -> yo)

Functionality: This macro implements a transport delay with initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T must be non-negative. Otherwise a message is printed to the output window.

Note: The delay function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

Bypass option: If T<=0 then yo=yi (feedthrough block)

Forward initial condition option: Output is initialised based on the input.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

### 7.9 e^-sT incbackward

### Transport delay, T>0 (backward initialisation: yi <- yo)

Functionality: This macro implements a transport delay with initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T must be positive. Otherwise a message is printed to the output window.

Backward initial condition option: Input is initialised based on the output.

This macro has a non-linear behaviour.

Function:

$$H(s) = e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

# 7.10 e^-sT\_incforward

#### Transport delay, T>0 (forward initialisation: yi -> yo)

Functionality: This macro implements a transport delay with initial condition for output. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T must be positive. Otherwise a message is printed to the output window.

Note: The delay function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

Forward initial condition option: Output is initialised based on the input.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = e^{-sT}$$

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: T

### 7.11 lastvalue

#### Last value function

Functionality: Outputs the value of the input at the previous simulation time step. The function includes a delay or a buffer based DSL function in the input-output path.

Note: The lastvalue function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

This macro has a non-linear behaviour.

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi

# 7.12 lastvalue incbackward

Last value function (backward initialisation: yi <- yo )

Note: The lastvalue function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

Backward initial condition option: Input is initialised based on the output.

This macro has a non-linear behaviour.

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi

# 7.13 lastvalue incforward

# Last value function (forward initialisation: yi -> yo )

Functionality: Outputs the value of the input at the previous simulation time step. The function includes a delay or a buffer based DSL function in the input-output path.

Note: The lastvalue function should be provided with a corresponding initial condition on either its input or output. In the case of forward initialisation, the output should be initialised with the value of the input. In the case of backward initialisation, the input should be initialised based on the value of the output.

This macro has a non-linear behaviour.

Macro location: Macros\Delays

Macro DSL level: 5 Output signals: yo Input signals: yi

# 8 Derivatives

This section provides a complete listing of the existing DSL macros within the *Derivatives* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

## 8.1 s/(1+sT)

#### Derivative with time constant

Functionality: This block implements a first order lag differentiator.

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{s}{1+sT} = \frac{1}{T} \frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Derivatives

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

Internal variables: dx

# 8.2 sK/(1+0.01s)

### Derivative with gain and first order lag (T=0.01)

Functionality: This block implements a derivative with gain and first order lag (time constant

This macro has a linear behaviour.

Function:

$$H(s) = \frac{sK}{1 + s0.01} = \frac{K}{0.01} \frac{s}{\frac{1}{0.01} + s}$$

Macro location: Macros\Derivatives

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K

Internal variables: dx

# 8.3 sK/(1+sT)

### Derivative with gain and time constant

Functionality: This block implements a first order lag differentiator block with gain K and time constant T

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{sK}{1+sT} = \frac{K}{T} \frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Derivatives

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

Internal variables: dx

# $8.4 \text{ sK/(1+sT)}_{fb}$

# Derivative with gain and time constant T (fallback value)

Functionality: This block implements a first order lag differentiator block with gain K and time

constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Fallback option: If T<=0, the use T=0.01 This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{sK}{1+sT} = \frac{K}{T} \frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Derivatives

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T Internal variables: dx

# 9 Electric Power

This section provides a complete listing of the existing DSL macros within the *Electric Power* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

#### 9.1 El. Power

# Output generator electrical power in MVA/MW base (for synchronous generators)

Functionality: This macro outputs the generator electrical power in generator MVA base (IPB=1). or in generator MW base (IPB=0)

This macro has a linear behaviour.

Macro location: Macros\Electric Power

Macro DSL level: 5 Output signals: pelec Input signals: pgt,cosn Parameters: IPB

### 9.2 PQ Calculator

# Calculates P and Q from complex U and I values

Functionality: Computes the active and reactive power of complex current and voltage.

This macro has a linear behaviour.

Macro location: Macros\Electric Power

Macro DSL level: 5 Output signals: P,Q Input signals: ur,ui,ir,ii

# 9.3 Power base

### Conversion of base for power (for synchronous generators)

Functionality: This macro tranforms the p.u. generator electrical power in the base defined

by

parameter PN. If PN =0, then no conversion is performed.

This macro has a linear behaviour.

Macro location: Macros\Electric Power

Macro DSL level: 5
Output signals: pelec
Input signals: pg,sgnn,cosn

Parameters: PN

# 10 Filters

This section provides a complete listing of the existing DSL macros within the *Filters* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

### 10.1 Band Pass Filters

### 10.1.1 $(H0w0/Q)s/(w0^2+sw0/Q+s^2)$

### **Second Order Band Pass Filter**

Functionality: Second order band-pass filter function

Parameters:

Flow - in Hz, lower cut-off frequency Fhigh - in Hz, upper cut-off frequency H0 - circuit gain (at center frequency)

Q - filter selectivity equal to sqrt(Fhigh\*Flow)/(Fhigh-Flow) (e.g. narrow frequency bands lead to high selectivity)

w0 - in rad/s, center frequency equal to 2\*pi()\*sqrt(Fhigh\*Flow)

Forward initialisation: output is initialised based on input This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{H0 \cdot \omega_0}{Q} \frac{s}{\omega_0^2 + \frac{\omega_0}{Q} s + s^2}$$

Macro location: Macros\Filters\Band Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: Flow,Fhigh,H0 Internal variables: w0,Q,F0

10.1.2 s/(w0^2+s^2)

### Resonant Filter with center frequency w0

Functionality: Resonant filter function

Parameters:

f0 - in Hz, filter center frequency

w0 - in rad/s, filter angular frequency, equal to 2\*PI\*f0 Forward initialisation: output is initialised based on input

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{s}{\omega_0^2 + s^2}$$

Macro location: Macros\Filters\Band Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: f0

Internal variables: w0

# 10.2 High Pass Filters

10.2.1 -sT/(1+sT)

### **Negative Derivative with time constant T**

Functionality: This macro implements a first order differentiator with time constant T and gain -1.

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{-sT}{1+sT} = -1\frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

Internal variables: dx

### 10.2.2 -sT/(1+sT) \_bypass

#### **Negative Derivative (bypass)**

Functionality: This macro implements a first order differentiator with time constant T and gain -1

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0, then output is zero.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{-sT}{1+sT} = -1\frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

Internal variables: dx

### 10.2.3 sKT/(1+sT)

## First order lag differentiator with gain and derivative time constant

Functionality: This block implements a first order lag differentiator with gain and derivative time constant

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{sKT}{1+sT} = K\frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5

Output signals: yo Input signals: yi Continuous states: x Parameters: K,T Internal variables: dx

### 10.2.4 sKTd/(1+sT)

#### First order lag differentiator with gain, derivative and lag time constant

Functionality: This block implements a first order lag differentiator with gain, derivative and lag time constant

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{sKT_d}{1+sT} = K\frac{T_d}{T}\frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,Td,T Internal variables: dx

### 10.2.5 sT/(1+sT) bypass

#### First order lag differentiator, time constant T (bypass)

Functionality: This block implements a first order lag differentiator block with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window. Bypass option: if T<=0, then block is a feedthrough (output is equal to input). This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{sT}{1+sT} = \frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

Internal variables: dx

# 10.2.6 sT/(1+sT) \_enable

#### First order lag differentiator, time constant T (with enable)

Functionality: This block implements a first order lag differentiator block with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window. Enable option:

if T>0, then output is enabled (normal transfer function) if T<=0, then output is 0 and state variable is frozen This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{sT}{1+sT} = \frac{s}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T Internal variables: dx

10.2.7 sTb/(1+sTa) \_fb

# First order lag differentiator, time constant Ta (fallback)

Functionality: This block implements a first order lag differentiator, time constant Ta (bypass) Parameter Ta must be non-negative. Otherwise, a message is printed to the output window. Fallback option: if Ta<=0, then assign Ta=0.01

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{s}{\frac{1}{T_a} + s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta Internal variables: dx

#### 10.2.8 sTld/(1+sTlg) \_fb

### First order lag differentiator, time constant Tlg (fallback value)

Functionality: This block implements a first order lag differentiator with time constant Tlg and derivative time constant Tld

Parameter Tlg must be non-negative. Otherwise, a message is printed to the output window. Fallback option: If Tlg<=0, then assign Tlg=0.01

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{sT_{ld}}{1+sT_{lg}} = \frac{T_{ld}}{T_{lg}} \frac{s}{\frac{1}{T_{lg}}+s}$$

Macro location: Macros\Filters\High Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tld,Tlg Internal variables: dx

#### 10.3 Low Pass Filters

#### 10.3.1 (1-K)/(1+sT)

#### First order lag with 1-K gain and time constant T

Functionality: This macro implements a first order lag with 1-K gain and time constant T. Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

## Function:

$$H(s) = \frac{1 - K}{1 + sT} = \frac{1 - K}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K.T

### 10.3.2 (1-K)/(1+sT) \_bypass

# First order lag with 1-K gain and time constant (bypass)

Functionality: This macro implements a first order lag with 1-K gain and time constant. It also includes a bypass function.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0 then block is a gain, yo=(1-K)\*yi

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 - K}{1 + sT} = \frac{1 - K}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

10.3.3 1/(1+sT)

#### First order lag

Functionality: This macro implements a first order lag block with time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{1}{1+sT} = \frac{1}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

10.3.4 1/(1+sT) (p)

### First order lag, anti-windup limiter, symmetrical

Functionality: This macro implements a first order lag, state variable limit, symmetrical Time constant T must be positive for correct operation

Upper limitation y\_max parameter must be non-negative for correct operation. Otherwise, a message is printed to the output window.

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

Function:

$$H(s) = \frac{1}{1+sT} = \frac{1}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

# $10.3.5 \quad 1/(1+sT) (p;p)[p;p]$

# First order lag, state and derivative rate limit

Functionality: This macro implements a first order lag, state and derivative rate limit Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{1+sT} = \frac{1}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

**Lower limitation parameters:** y\_min,r\_min **Upper limitation parameters:** y\_max,r\_max

 $10.3.6 \ 1/(1+sT)$  (s)

# First order lag, state limit, symmetrical

Functionality: This macro implements a first order lag, state limit based on signal, symmetrical

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{1 + sT} = \frac{1}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: y\_max

Continuous states: x

Parameters: T

### $10.3.7 \ 1/(1+sT) (s;s)$

### First order lag, state limit

Functionality: This macro implements a first order lag, state limit based on signals (asymmetri-

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

#### Function:

$$H(s)=\frac{1}{1+sT}=\frac{1}{T}\frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation input signals: y\_min Upper limitation input signals: y max

Continuous states: x

Parameters: T

### $10.3.8 \ 1/(1+sT) [(p;p)]$

### First order lag, state limit based on parameters (asymmetrical)

Functionality: This macro implements a first order lag, state limit based on parameters (asymmetrical)

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{1 + sT} = \frac{1}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

Lower limitation parameters: y\_min Upper limitation parameters: y max

### 10.3.9 1/(1+sT) \_bypass

# First order lag (bypass)

Functionality: This macro implements a first order lag block with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window. Bypass option: if T<=0, block is bypassed (yo=yi)

This macro has a linear behaviour.

Function:

$$H(s)=\frac{1}{1+sT}=\frac{1}{T}\frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: T

10.3.10 1/(1+sT) enable

### First order lag with enable signal

Functionality: This block implements a first order lag block with time constant T and enable signal.

Parameter T must be positive. Otherwise, a message is printed to the output window.

Enable option:

If enable < 0.5 then output and state are frozen

If enable >= 0.5 then filter is enabled. This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{1 + sT} = \frac{1}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: enable

Continuous states: x

Parameters: T

10.3.11 1/(1+sT) and sx

First order delay (PT1)

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{1}{1 + sT} = \frac{1}{T} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo,dx Input signals: yi Continuous states: x Parameters: T

## 10.3.12 1/(1+sT) {p;p} \_fb

#### First order lag with derivative rate limits (bypass)

Functionality: This macro implements a first order lag with derivative rate limits (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if  $T \le 0$  then yo = yi This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{1+sT} = \frac{1}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

Lower limitation parameters: rdown Upper limitation parameters: rup

# 10.3.13 1/(1+sT/2)

## First order lag variant (T/2 time constant)

Functionality: This macro implements a first order lag variant (T/2 time constant) Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

## Function:

$$H(s) = \frac{1}{1 + sT/2} = \frac{2}{T} \frac{1}{\frac{2}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

## 10.3.14 1/(K+sT)

#### First order lag with 1/T gain and T/K time constant

Functionality: This macro implements a first order delay with gain 1/K and time constant T/K Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{K+sT} = \frac{1}{T} \frac{1}{\frac{K}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

# 10.3.15 1/(K+sT) \_bypass

# First order lag with 1/T gain and T/K time constant (bypass)

Functionality: This macro implements a first order delay with gain 1/K and time constant T/K Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0 then yo = yi/K This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{K+sT} = \frac{1}{T}\frac{1}{\frac{K}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

# 10.3.16 1/K(T1/T2-1)(1/(1+sT2))

## First order lag variant, 3 parameters

Functionality: This macro implements a first order lag variant, 3 parameters Parameter T2 must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

## **Function:**

$$H(s) = \frac{\frac{T_1}{T_2} - 1}{K} \frac{1}{1 + sT_2} = \frac{\frac{T_1}{T_2} - 1}{KT_2} \frac{1}{\frac{1}{T_2} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T1,T2

## 10.3.17 1/K/(1+sT) \_bypass

#### First order lag with gain 1/KT (bypass)

Functionality: This macro implements a first order lag with gain 1/K.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Parameter K must be positive. Otherwise, a message is printed to the output window.

Bypass option: If T<=0, block is a gain 1/K

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{K} \frac{1}{1 + sT} = \frac{1}{KT} \frac{1}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K.T

## 10.3.18 K/(1+sT)

## First order lag with gain

Functionality: This macro implements a first order lag block with gain K/T and time constant T

Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

# 10.3.19 K/(1+sT) (p;s) \_bypass

## First order lag with gain, state limited (bypass)

Functionality: This macro implements a state limited first order lag block with gain K/T and time constant T.

Upper limit is an input signal, lower limit a parameter.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0, then block is a gain (yo=K\*yi) with limited output.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: y\_max

Continuous states: x Parameters: K.T

Lower limitation parameters: y\_min

## 10.3.20 K/(1+sT) (s;s) \_bypass

# First order lag with gain, state limited (bypass)

Functionality: This macro implements a state limited first order lag block with gain K/T and time constant T.

Upper and lower limit is an input signal.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0, then block is a gain (yo=K\*yi) with limited output.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation input signals: y\_min Upper limitation input signals: y\_max

Continuous states: x Parameters: K,T

#### 10.3.21 K/(1+sT) (sp;sp)

#### First order lag with gain, state limited, limits proportional to limiter input signal

Functionality: This macro implements a state limited first order lag block with gain K/T and time constant T

Limits are proportional to limiter signal.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: ylim

Continuous states: x Parameters: K,T

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

## 10.3.22 K/(1+sT)[(p;p)]\_bypass

# First order lag with gain, state limited (bypass)

Functionality: This macro implements a state limited first order lag block with bypass and gain. The state variable and the output are limited using parameters "y\_min" and "y\_max". Parameter T must be non-negative. Otherwise, a message is printed to the output window. Bypass option: if T<=0, block is a limited gain yo = K\*yi between y\_min and y\_max limits. This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 6 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 10.3.23 K/(1+sT) \_bypass

## First order lag with gain (bypass)

Functionality: This macro implements a first order lag block with gain K/T and time constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0, then block is a gain (yo=K\*yi) with limited output.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{K}{1+sT} = \frac{K}{T} \frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

## 10.3.24 K1 + K2/(1+sT)

## First order lag in parallel with gain, 3 parameters

Functionality: This block implements a first order lag in parallel with gain.

This block uses 3 parameters: K1, K2 and T.

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### Function:

$$H(s) = K_1 + \frac{K_2}{1 + sT} = K_1 \frac{\frac{K_1 + K_2}{K_1 T} + s}{\frac{1}{T} + s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K1,K2,T

## 10.3.25 KT/(1+sT)

# First order lag with gain KT

Functionality: This block implements a first order lag with gain K\*T.

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{KT}{1+sT} = K\frac{1}{\frac{1}{T}+s}$$

Macro location: Macros\Filters\Low Pass Filters

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

# 10.4 Moving Average Filters

# 10.4.1 MovingAverage (stateless)

## **Function Moving Average**

Functionality: Implements a buffer based moving average filter. The function includes a delay or a buffer based DSL function in the input-output path. This macro has a non-linear behaviour.

Macro location: Macros\Filters\Moving Average Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: Tdel, Tlength

## 10.4.2 MovingAverage \_enable\_incforward

## Moving Average Filter (time continuous implementation, without buffers, with enable)

Moving average filter with Tavg sliding window and enable signal Implemented based on a 2nd order Pade approximation, as below This macro has a linear behaviour.

Macro location: Macros\Filters\Moving Average Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: enable

Continuous states: x1,x2,x3

Parameters: Tavg

Internal variables: x3\_del,tinit

# 10.4.3 MovingAverage incforward

## Moving Average Filter (time continuous implementation, without buffers)

Moving average filter with Tavg sliding window Implemented based on a 2nd order Pade approximation, as below This macro has a linear behaviour.

Macro location: Macros\Filters\Moving Average Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2,x3

Parameters: Tavg

Internal variables: x3\_del,tinit

# 10.5 Notch Filters

# 10.5.1 (s^2+wn^2)/(s^2+sBw+wn^2)

#### **Notch filter**

Functionality: Block that implements a notch filter

Example of initialisation conditions in the main model:

inc(x2)=0

inc(x1) = yi/sqr(wn)

vardef(wn) = 'rad/s';'Notch filter frequency'
vardef(Bw) = 'rad/s';'Notch filter 3db bandwidth'

This macro has a linear behaviour.

Function:

$$H(s) = \frac{w_n^2 + s^2}{w_n^2 + B_w s + s^2}$$

Macro location: Macros\Filters\Notch Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: Bw,wn

Internal variables: dx1,dx2

## 10.5.2 (s^2+wn^2)/(s^2+sBw+wn^2) \_bypass

## Notch filter (bypass)

Functionality: Block that implements a notch filter with bypass for Bw parameter.

Bypass: If Bw <= 0 and wn <= 0 then output = input

Example of initialisation conditions in the main model

inc(x2)=0

 $inc(x1) = selfix(\{abs(Bw) <= 0.0\}.and.\{abs(wn) <= 0.0\}, yi, yi/sqr(wn))$ 

vardef(wn) = 'rad/s';'Notch filter frequency'
vardef(Bw) = 'rad/s';'Notch filter 3db bandwidth'

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{w_n^2 + s^2}{w_n^2 + B_w s + s^2}$$

Macro location: Macros\Filters\Notch Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: Bw,wn

Internal variables: dx1,dx2

## 10.6 Other Filters

# 10.6.1 $((1+sTz)/(1+sTp)^M)^N$

#### Ramp-tracking filter

Functionality: This block implements a transfer function as described in IEEE Std 421.5 Recommended Practice for Excitation System Models For Power System Stability Studies (Models PSS2A/PSS2B/PSS2C).

Parameter Tp must be positive. Otherwise, a message is printed to the output window.

Parameters M and N must have integer values between 0 and 8 (included). If outside range, a message is printed to the output window. Furthermore, the product N\*M must not be greater than 8 (included).

This macro has a linear behaviour.

#### Function:

$$H(s) = \left[\frac{1 + sT_z}{(1 + sT_p)^M}\right]^N$$

Macro location: Macros\Filters\Other Filters

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2,x3,x4,x5,x6,x7,x8,x9,x10,x11,x12,x13,x14,x15,x16

Parameters: Tz,Tp,N,M

Internal variables: yll,nl,yo1,yo2,yo3,yo4,yo5,yo6,yo7,yo8,yo9,yo10,yo11,yo12,yo13,yo14,yo15,yo16,dx1,dx2,dx3,

# 11 Gains

This section provides a complete listing of the existing DSL macros within the *Gains* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 11.1 Multiply (-1)

# Sign invert

Functionality: Multiplies the input by -1. This macro has a linear behaviour.

Function:

$$H(s) = -1$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.2 **Multiply (-K)**

#### Gain -K

Functionality: Multiplies the input by -K. This macro has a linear behaviour.

**Function:** 

$$H(s) = -K$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

# 11.3 Multiply (1-K)

## Gain 1-K

Functionality: Multiplies the input by (1-K).

This macro has a linear behaviour.

**Function:** 

$$H(s) = 1 - K$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

# 11.4 Multiply (1-K1-K2)

#### Gain 1-K1-K2

Functionality: Multiplies the input by (1-K1-K2). This macro has a linear behaviour.

**Function:** 

$$H(s) = 1 - K1 - K2$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2

# 11.5 Multiply 1

# Feedthrough block

Functionality: Feedthrough block, yo=yi. This macro has a linear behaviour.

**Function:** 

$$H(s) = 1$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.6 Multiply 1/K

## **Inverse Gain**

Functionality: Multiplies the input by 1/K. If K=0 then output is zero This macro has a linear behaviour.

Function:

$$H(s) = \frac{1}{K}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

# 11.7 Multiply 1/K [p;p]

#### **Inverted Gain with limits**

Functionality: Multiplies the input by 1/K and limits the output within y\_min and y\_max. If K=0, output is zero (upper/lower limits still applicable on 0). This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{K}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 11.8 Multiply 1/K1K2 [p;p]

## Inverted Gain, 2 parameters, with limits

Functionality: Multiplies the input by 1/(K1\*K2) and limits the output within y\_min and y\_max. This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{K_1 \cdot K_2}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2 **Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 11.9 Multiply 1/SQRT2

## Gain 1 over square root 2

Functionality: Divides the input by sqrt(2). This macro has a linear behaviour.

Function:

$$H(s) = \frac{1}{\sqrt{2}}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.10 Multiply 1/SQRT3

# Gain 1 over square root 3

Functionality: Divides the input by sqrt(3). This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{1}{\sqrt{3}}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.11 Multiply K

## Gain K

Functionality: Multiplies the input by K. This macro has a linear behaviour.

**Function:** 

$$H(s) = K$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

# 11.12 Multiply K [p;p]

## Gain K with limits

Functionality: Multiplies the input by K and limits the output within y\_min and y\_max values. This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = K$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 11.13 Multiply K1 K2

#### Gain K1 \* K2

Functionality: Multiplies the input by K1\*K2.

This macro has a linear behaviour.

**Function:** 

$$H(s) = K_1 \cdot K_2$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2

# 11.14 Multiply K1 K2 / K3

## Gain K1\*K2/K3

Functionality: Multiplies the input by K1\*K2/K3.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{K_1 \cdot K_2}{K_3}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2,K3

# 11.15 Multiply K1 K2 K3

#### Gain K1 \* K2 \* K3

Functionality: Multiplies the input signal with three constant parameters K1, K2 and K3. This macro has a linear behaviour.

**Function:** 

$$H(s) = K_1 \cdot K_2 \cdot K_3$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2,K3

# 11.16 Multiply K1/K2

## Gain K1/K2

Functionality: Multiplies the input by K1/K2.

This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{K_1}{K_2}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2

# 11.17 Multiply PI

#### Gain of PI

Functionality: Multiplies the input by PI. This macro has a linear behaviour.

**Function:** 

$$H(s) = \pi$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.18 **Multiply SQRT(2/3)**

# Gain square root 2 over square root 3

Functionality: Multiplies the input by sqrt(2/3).

This macro has a linear behaviour.

**Function:** 

$$H(s) = \sqrt{\frac{2}{3}}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.19 **Multiply SQRT(3/2)**

## Gain square root 3 over square root 2

Functionality: Multiplies the input by sqrt(3/2).

This macro has a linear behaviour.

**Function:** 

$$H(s) = \sqrt{\frac{3}{2}}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.20 Multiply SQRT(K1/K2)

## Gain square root of K1/K2

Functionality: Multiplies the input by sqrt(K1/K2), where K1 and K2 are constant parameters. This macro has a linear behaviour.

Function:

$$H(s) = \sqrt{\frac{K1}{K2}}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K1,K2

# 11.21 Multiply SQRT2

# Gain square root 2

Functionality: Multiplies the input by sqrt(2).

This macro has a linear behaviour.

**Function:** 

$$H(s) = \sqrt{2}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 11.22 Multiply SQRT3

# Gain square root 3

Functionality: Multiplies the input by sqrt(3).

This macro has a linear behaviour.

**Function:** 

$$H(s) = \sqrt{3}$$

Macro location: Macros\Gains

Macro DSL level: 5 Output signals: yo Input signals: yi

# 12 Higher Order Transfer Functions

This section provides a complete listing of the existing DSL macros within the *Higher Order Transfer Functions* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 12.1 (1+B1s+B2ss)/(1+A1s+A2ss) \_bypass

(1+B1s+B2ss)/(1+A1s+A2ss) (bypass)

Functionality: This block implements H(s)= (1+B1s+B2ss)/(1+A1s+A2ss).

Parameter A2 must be positive. Otherwise, a message is printed to the output window.

Bypasss option: A bypass is included based on parameters A1, A2, B1 and B2.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 + B_1 s + B_2 s^2}{1 + A_1 s + A_2 s^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: A1,A2,B1,B2 Internal variables: triv,dx1,dx2

# 12.2 (1+KsTc)/((1+sTa)(1+sTb)(1+sTc)) \_bypass

(1+KsTc)/((1+sTa)(1+sTb)(1+sTc)) (bypass)

Functionality: This block implements H(s)=(1+KsTc)/((1+sTa)(1+sTb)(1+sTc))

Parameters Ta, Tb and Tc must be positive. Otherwise, a message is printed to the output

window.

Bypass option: A bypass is included based on parameters Ta, Tb and Tc.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 + K \cdot T_c s}{(1 + sT_a)(1 + sT_b)(1 + sT_c)}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: xa,xb,xc Parameters: Ta,Tb,Tc,K Internal variables: dxc,yxa,yxb

# 12.3 (1+b1s+b2ss)/(1+a1s+a2ss)

#### (1+b1s+b2ss)/(1+a1s+a2ss)

Functionality: This block implements H(s)= (1+b1s+b2ss)/(1+a1s+a2ss)

Parameter a2 must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 + b_1 s + b_2 s^2}{1 + a_1 s + a_2 s^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: a1,a2,b1,b2 Internal variables: dx1,dx2

# 12.4 (1+sT3)/(1+sT1+ssT1T2) bypass

# (1+sT3)/(1+sT1+ssT1T2) (bypass)

Functionality: This block implements  $H(s) = \frac{1+sT3}{1+ssT1T2}$ 

Parameters T1 and T2 must be non-negative. Otherwise, a message is printed to the output

window.

Bypass option:

if T1>0 and T2>0 then function is (1+sT3)/(1+sT1+ssT2)

if T1=0 and T2>0 then function is (1+sT3)/(1+ssT2)

if T1>0 and T2=0 then function is 1/(1+sT1)

if T1=0 and T2=0 then function is 1 (yo=yi)

This macro has a linear behaviour.

Function:

$$H(s) = \frac{1 + sT_3}{1 + sT_1 + s^2T_1T_2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: T1,T2,T3 Internal variables: dx1

# 12.5 (1+sT3+ssT4)/(1+sT1+ssT2)

## (1+sT3+ssT4)/(1+sT1+ssT2)

Functionality: This block implements H(s)=(1+sT3+ssT4)/(1+sT1+ssT2)

Parameter T2 must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1 + sT_3 + s^2T_4}{1 + sT_1 + s^2T_2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: T1,T2,T3,T4 Internal variables: dx1,dx2

# 12.6 (1+sTb)(sTa)^2/(1+sTa)^4

# (1+sTb)(sTa) 2/(1+sTa) 4

Functionality: This block implements H(s)=(1+sTb)(sTa)^2/(1+sTa)^4

Parameters Ta and Tb must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

## **Function:**

$$H(s) = \frac{(1 + sT_b)(sT_a)^2}{(1 + sT_a)^4}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2,x3,x4

Parameters: Tb,Ta

Internal variables: yo1,yo2,yo3,dx1,dx2,dx3

# 12.7 (1+ssT3)/(1+sT1+ssT2) bypass

## (1+ssT3)/(1+sT1+ssT2) (bypass)

Functionality: This block implements  $H(s) = \frac{1+ssT3}{1+ssT2}$ 

Parameters T1 and T2 must be non-negative. Otherwise, a message is printed to the output

window. Bypass:

if T1>0 and T2>0 then function is (1+ssT3)/(1+sT1+ssT2)

if T1=0 and T2>0 then function is (1+ssT3)/(1+ssT2) if T1>0 and T2=0 then function is 1/(1+sT1) if T1=0 and T2=0 then function is 1 (yo=yi)

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1 + s^2 T_3}{1 + s T_1 + s^2 T_2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: T1,T2,T3 Internal variables: dx2

# 12.8 (A0+sA1+ssA2)/(B0+sB1+ssB2) \_bypass

# (A0+sA1+ssA2)/(B0+sB1+ssB2) (bypass)

Functionality: This block implements  $H(s) = \frac{A0+sA1+ssA2}{B0+sB1+ssB2}$ .

Parameter B2 must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: A bypass is included on parameter B2.

This macro has a linear behaviour.

# **Function:**

$$H(s) = \frac{A_0 + sA_1 + s^2 A_2}{B_0 + sB_1 + s^2 B_2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: B0,B1,B2,A0,A1,A2 Internal variables: dx1,dx2

# 12.9 (ss)/(Ass+Bs+1) bypass

# (ss)/(Ass+Bs+1) (bypass)

Functionality: This block implements H(s)=(ss)/(Ass+Bs+1).

Parameter A must be positive. Otherwise, a message is printed to the output window.

Bypass option: A bypass is included on parameters A and B.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{s^2}{As^2 + Bs + 1}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: A,B

Internal variables: triv,dx1,dx2

# 12.10 (ss+ww)/(ss+sB+ww) bypass

## (ss+ww)/(ss+sB+ww) (bypass)

Functionality: This block implements H(s)=(ss+ww)/(ss+sB+ww). Bypass option: A bypass is included on parameter B and w.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{\omega^2 + s^2}{s^2 + sB + \omega^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: B,w

Internal variables: triv,dx1,dx2

# 12.11 $1/(1+s(2 \times zeta)/wc+ss/(wc \times wc))$

# Second order low pass filter with cutoff frequency wc and damping factor zeta

Functionality: This block implements second order low pass filter with characteristic frequency

wc and damping factor zeta

vardef(wc)='rad/s';'Cutoff frequency' vardef(zeta)='n/a';'Damping factor' This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{1 + \frac{2\zeta}{\omega_c}s + \frac{1}{\omega_c^2}s^2} = \frac{\omega_c^2}{\omega_c^2 + 2\zeta\omega_c s + s^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5

Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: wc,zeta

# 12.12 1/(1+sT1+ssT2) bypass

## Second order lag (bypass)

Functionality: This block implements H(s)=(1/(1+sT1+ssT2)).

Parameters T1 and T2 must be positive. Otherwise, a message is printed to the output window.

Bypass option: A bypass is included on parameters T1 and T2.

if T1<=0 and T2<=0 -> yo=yi (bypass T2 and T1 parts)

if T1<=0 and T2 >0 -> Block is H(s)=(1/(1+ssT2)) (bypass T1 part) if T1>0 and T2 <=0 -> Block is H(s)=(1/(1+sT1)) (bypass T2 part)

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{1 + sT_1 + s^2T_2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

**Continuous states:** x1,x2 **Parameters:** T1,T2

# 12.13 K(1+sT1)(1+sT2)/(s(1+sT3))[(p;p)]

## K(1+sT1)(1+sT2)/(s(1+sT3))[(p;p)]

Functionality: This block implements H(s)=K(1+sT1)(1+sT2)/(s(1+sT3)). State variable and output limits are applied using the same parameters. This macro has a non-linear behaviour.

## **Function:**

$$H(s) = K \frac{(1 + sT_1)(1 + sT_2)}{s(1 + sT_3)}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

**Continuous states:** x1,x2 **Parameters:** K,T1,T2,T3

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max **Internal variables:** dx1,yo1,yo2

# 12.14 K(1+sTd)/((1+sTa)(1+sTb)s) (p;p) \_bypass

# K(1+sTd)/((1+sTa)(1+sTb)s) (p;p) (bypass)

Functionality: This block implements H(s)=K(1+sTd)/((1+sTa)(1+sTb)s).

State limits by parameters and a bypass function are applied.

Parameters Ta and Tb must be non-negative. Otherwise, a message is printed to the output

window.

Bypass option: A bypass is included on parameters Ta and Tb.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{K(1 + sT_d)}{s(1 + sT_a)(1 + sT_b)}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

**Continuous states:** xa,xb,xc **Parameters:** K,Td,Ta,Tb

Lower limitation parameters: y\_min Upper limitation parameters: y\_max Internal variables: xbout,xaout,dxa

# 12.15 e(-sTd)/((1+sT1)(1+sT1))

# Second order lag with ideal delay

Functionality: This block implements a second order lag with ideal delay. The function includes a delay or a buffer based DSL function in the input-output path.

Parameter T1, T2 and Td must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = \frac{e^{-sT_d}}{(1+sT_1)^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

**Continuous states:** x1,x2 **Parameters:** T1,T2,Td

# 12.16 s<sup>2</sup>K/(1+sT)<sup>2</sup>

## Second order lag differentiator with gain

Functionality: This block implements a second order lag differentiator with gain Parameter T must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

**Function:** 

$$H(s) = \frac{Ks^2}{(1+sT)^2}$$

Macro location: Macros\Higher Order Transfer Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2

Parameters: K,T

Internal variables: dx1,dx2

# 13 Integrators

This section provides a complete listing of the existing DSL macros within the *Integrators* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 13.1 with reset (to initial value)

# 13.1.1 1/s (p;p) \_reset

# Integrator, state limited by parameters and with reset (to initial value)

Functionality: This macro implements an integrator, state limited by parameters.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

nank.

This macro has a non-linear behaviour.

Function:

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Lower limitation parameters: y\_min

**Upper limitation parameters:** y\_max

Internal variables: xinc

## 13.1.2 1/s (s;s) enable reset

# Integrator with signal limits (asymmetrical), hold signal and with reset (to initial value)

Functionality: This macro implements an integrator with signal limits (asymmetrical)

Option enable:

If hold signal >=0.5 then integrator is frozen If hold signal < 0.5 then integrator is unfrozen

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi,hold

**Lower limitation input signals:** y\_min **Upper limitation input signals:** rst,y max

Continuous states: x Internal variables: xinc

## 13.1.3 1/s [p;p] reset

#### Integrator with parameter limits (asymmetrical) and reset (to initial value)

Functionality: This macro implements an integrator with parameter limits (asymmetrical) Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

# Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

Internal variables: xinc

#### 13.1.4 1/s [p] reset

## Integrator with parameter limits (symmetrical) and with reset (to initial value)

Functionality: This macro implements an integrator with parameter limits (symmetrical)

Parameter y\_max must be positive. Otherwise, a message is printed to the output window.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Upper limitation parameters: y max

Internal variables: xinc

#### 13.1.5 1/s [s;s] \_reset

# Integrator with signal limits (asymmetrical) and with reset (to initial value)

Functionality: This macro implements an integrator with signal limits (asymmetrical) Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Lower limitation input signals: y\_min Upper limitation input signals: rst,y max

Continuous states: x Internal variables: xinc

## 13.1.6 1/s [s] reset

## Integrator with signal limits (symmetrical) and with reset (to initial value)

Functionality: This macro implements an integrator with signal limits (symmetrical)

Input signal must always be positive in order to operate correctly.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst,y max

Continuous states: x
Internal variables: xinc

## 13.1.7 1/s enable reset

## Integrator with reset (to initial value)

Functionality: This macro implements a continuous time integrator block.

Option enable:

If hold signal >=0.5 then integrator is frozen
If hold signal < 0.5 then integrator is unfrozen

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,hold

Upper limitation input signals: rst

Continuous states: x Internal variables: xinc

# 13.1.8 1/s \_incfreeze \_reset

# Integrator with delayed start based on parameter Tincfreeze and with reset (to initial value)

Functionality: Integrator with delayed start based on parameter Tincfreeze

Option incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x Parameters: Tincfreeze Internal variables: t0,xinc

#### 13.1.9 1/s reset

# Integrator with reset (to initial value)

Functionality: This macro implements a continuous time integrator block and reset.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a linear behaviour.

# Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x Internal variables: xinc

# 13.1.10 1/sT \_reset

## Integrator, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator block with time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: vi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Internal variables: xinc

## 13.1.11 1/sT (p) reset

# Integrator, state limits, symmetrical, time constant T and with reset (to initial value)

Functionality: This macro implements a state limited integrator with time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: vi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y max

Internal variables: xinc

## 13.1.12 1/sT (p) \_fb\_reset

# Integrator, state limits, symmetrical, time constant T (fallback) and with reset (to initial value)

Functionality: This macro implements a state limited integrator with time constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

**Upper limitation parameters:** y max

Internal variables: xinc

## 13.1.13 1/sT (p; reset

# Integrator, state lower limit, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y min

Internal variables: xinc

## 13.1.14 1/sT (p; \_fb\_reset

# Integrator, state lower limit, time constant T (fallback) and with reset (to initial value)

Functionality: This macro implements a state lower limited integrator with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option \_fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y min

Internal variables: xinc

## 13.1.15 1/sT (p;p) fb reset

## Integrator, state limits, time constant T (fallback) and with reset (to initial value)

Functionality: This macro implements a state limited integrator with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

Internal variables: xinc

# 13.1.16 1/sT (p;s) \_fb\_reset

# Integrator, state limits based on parameter/signal, time constant T (fallback) and with reset

Functionality: This macro implements an integrator, state limits based on parameter/signal, time constant T (bypass)

Lower limits is parameter; upper limit is input signal

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

**Upper limitation input signals:** rst,y\_max

Continuous states: x

Parameters: T

Lower limitation parameters: y min

Internal variables: xinc

## 13.1.17 1/sT (pp;pp) \_reset

# Integrator, parameter scaled limits, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator, parameter scaled limits, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x Parameters: T,K

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

Internal variables: xinc

#### 13.1.18 1/sT (s;p) fb reset

## Integrator, state limits based on signal/parameter, time constant T (fb) and with reset

Functionality: This macro implements an integrator, state limits based on signal/parameter, time constant T (bypass)

Lower limit is a signal; upper limit is a parameter.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option \_fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

**Lower limitation input signals:** y\_min **Upper limitation input signals:** rst

Continuous states: x

Parameters: T

**Upper limitation parameters:** y max

Internal variables: xinc

# 13.1.19 1/sT (s;s) \_fb\_reset

## Integrator, state limits by signals, time constant T (fb) and with reset (to initial value)

Functionality: This macro implements an integrator, state limits by signals, time constant T (bypass)

Lower and upper limits are input signals.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option \_fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to initial value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi

Lower limitation input signals: y\_min Upper limitation input signals: rst,y max

Continuous states: x

Parameters: T

Internal variables: xinc

## 13.1.20 1/sT;p) fb reset

## Integrator, state lower limit, time constant T (fb) and with reset (to initial value)

Functionality: This macro implements an integrator, state lower limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

Internal variables: xinc

## 13.1.21 1/sT;p)\_reset

## Integrator, state lower limit, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

Internal variables: xinc

## 13.1.22 1/sT;p] fb reset

#### Integrator, state upper limit, time constant T (fb) and with reset (to initial value)

Functionality: This macro implements an integrator, state upper limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

Internal variables: xinc

## 13.1.23 1/sT ;p] \_reset

## Integrator, state upper limit, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator, state upper limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

## Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

Internal variables: xinc

## 13.1.24 1/sT [p; fb reset

## Integrator, state lower limit, time constant T (fb) and with reset (to initial value)

Functionality: This macro implements an integrator, state lower limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y\_min

Internal variables: xinc

# 13.1.25 1/sT [p; \_reset

## Integrator, state lower limit, time constant T and with reset (to initial value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a non-linear behaviour.

## Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y\_min

Internal variables: xinc

## 13.1.26 1/sT bypass incfreeze reset

# Integrator with time constant T and delayed start based on parameter Tincfreeze and with reset

Functionality: Integrator with time constant T and delayed start based on parameter Tincfreeze Option bypass: if time constant T<=0 then block is a feedthrough

Option \_incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x Parameters: T,Tincfreeze Internal variables: t0,xinc

#### 13.1.27 1/sT \_fb\_reset

# Integrator, time constant T (fb) and with reset (to initial value)

Functionality: This macro implements an integrator block with time constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, yo keeps its initial value

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising

flank.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Internal variables: xinc

# 13.1.28 1/sT incfreeze reset

# Integrator with time constant T and delayed start based on parameter Tincfreeze and with reset

Functionality: Integrator with time constant T and delayed start based on parameter Tincfreeze Option \_incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option \_reset: The state "x" is reset to its initial value upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to initial value)

Macro DSL level: 6 Output signals: yo Input signals: yi

Upper limitation input signals: rst

Continuous states: x Parameters: T,Tincfreeze Internal variables: t0,xinc

# 13.2 with reset (to input signal value)

#### 13.2.1 1/s (p;p) reset sig

# Integrator, state limited by parameters, with reset (to input signal value)

Functionality: This macro implements an integrator, state limited by parameters.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

#### 13.2.2 1/s (s;s) enable reset sig

## Integrator with signal limits (asymmetrical), hold signal, with reset (to input signal value)

Functionality: This macro implements an integrator with signal limits (asymmetrical)

Option enable:

If hold signal >=0.5 then integrator is frozen If hold signal < 0.5 then integrator is unfrozen

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6
Output signals: yo
Input signals: yi,hold,xrst

Lower limitation input signals: y\_min Upper limitation input signals: rst,y\_max

Continuous states: x

## 13.2.3 1/s [p;p] reset sig

#### Integrator with parameter limits (asymmetrical), with reset (to input signal value)

Functionality: This macro implements an integrator with parameter limits (asymmetrical) Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a non-linear behaviour.

# Function:

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 13.2.4 1/s [p] \_reset\_sig

Integrator with parameter limits (symmetrical), with reset (to input signal value)

Functionality: This macro implements an integrator with parameter limits (symmetrical) Parameter v max must be positive. Otherwise, a message is printed to the output window. Option reset sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

**Upper limitation parameters:** y max

#### 13.2.5 1/s [s;s] reset sig

# Integrator with signal limits (asymmetrical), with reset (to input signal value)

Functionality: This macro implements an integrator with signal limits (asymmetrical) Option reset sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

# Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: vi,xrst

Lower limitation input signals: y min Upper limitation input signals: rst,v max

Continuous states: x

## 13.2.6 1/s [s] \_reset\_sig

# Integrator with signal limits (symmetrical), with reset (to input signal value)

Functionality: This macro implements an integrator with signal limits (symmetrical)

Input signal must always be positive in order to operate correctly.

Option reset sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst,y\_max

Continuous states: x

## 13.2.7 1/s \_enable\_reset\_sig

# Integrator with reset (to input signal value)

Functionality: This macro implements a continuous time integrator block.

Option enable:

If hold signal >=0.5 then integrator is frozen If hold signal < 0.5 then integrator is unfrozen

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6
Output signals: yo
Input signals: yi,hold,xrst

Upper limitation input signals: rst

Continuous states: x

#### 13.2.8 1/s \_incfreeze \_reset\_sig

# Integrator with delayed start based on parameter Tincfreeze, with reset (to input signal value)

Functionality: Integrator with delayed start based on parameter Tincfreeze

Option \_incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = \frac{1}{s}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x Parameters: Tincfreeze Internal variables: t0

## 13.2.9 1/s \_reset\_sig

#### Integrator with reset (to input signal value)

Functionality: This macro implements a continuous time integrator block and reset.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{s}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

# 13.2.10 1/sT \_reset\_sig

#### Integrator, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator block with time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

#### Parameters: T

# 13.2.11 1/sT (p) \_reset\_sig

# Integrator, state limits, symmetrical, time constant T, with reset (to input signal value)

Functionality: This macro implements a state limited integrator with time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6
Output signals: yo
Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y\_max

## 13.2.12 1/sT (p) \_fb \_reset\_sig

# Integrator, state limits, symmetrical, time constant T (fallback), with reset (to input signal valu

Functionality: This macro implements a state limited integrator with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window. Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y max

## 13.2.13 1/sT (p; reset sig

# Integrator, state lower limit, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y\_min

#### 13.2.14 1/sT (p; fb reset sig

## Integrator, state lower limit, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements a state lower limited integrator with time constant T Parameter T must be non-negative. Otherwise, a message is printed to the output window. Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y min

# 13.2.15 1/sT (p;p) fb reset sig

## Integrator, state limits, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements a state limited integrator with time constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option \_fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 13.2.16 1/sT (p;s) \_fb\_reset\_sig

#### Integrator, state limits based on parameter/signal, time constant T (fallback), with reset

Functionality: This macro implements an integrator, state limits based on parameter/signal, time constant T (bypass)

Lower limits is parameter; upper limit is input signal

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst,y max

Continuous states: x

Parameters: T

Lower limitation parameters: y\_min

## 13.2.17 1/sT (pp;pp) reset sig

## Integrator, parameter scaled limits, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator, parameter scaled limits, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x Parameters: T,K

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

## 13.2.18 1/sT (s;p) \_fb\_reset\_sig

# Integrator, state limits based on signal/parameter, time constant T (fallback) , with reset

Functionality: This macro implements an integrator, state limits based on signal/parameter, time constant T (bypass)

Lower limit is a signal; upper limit is a parameter.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option  $\_$ fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Lower limitation input signals: y\_min Upper limitation input signals: rst

Continuous states: x

Parameters: T

**Upper limitation parameters:** y\_max

## 13.2.19 1/sT (s;s) fb reset sig

# Integrator, state limits by signals, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements an integrator, state limits by signals, time constant T (bypass)

Lower and upper limits are input signals.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### **Function:**

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6
Output signals: yo
Input signals: yi,xrst

Lower limitation input signals: y\_min Upper limitation input signals: rst,y max

Continuous states: x

Parameters: T

#### 13.2.20 1/sT ;p) \_fb\_reset\_sig

#### Integrator, state lower limit, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements an integrator, state lower limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window. Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

**Upper limitation parameters:** y\_max

## 13.2.21 1/sT;p) reset sig

## Integrator, state lower limit, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y max

#### 13.2.22 1/sT;p] fb sig

# Integrator, state upper limit, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements an integrator, state upper limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window. Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

**Upper limitation parameters:** y max

## 13.2.23 1/sT;p] reset sig

## Integrator, state upper limit, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator, state upper limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window. Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Upper limitation parameters: y max

#### 13.2.24 1/sT [p; fb reset sig

# Integrator, state lower limit, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements an integrator, state lower limit, time constant T (bypass) Parameter T must be non-negative. Otherwise, a message is printed to the output window. Option fb: if T<=0, then output keeps initial value.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: y min

## 13.2.25 1/sT [p; reset sig

## Integrator, state lower limit, time constant T, with reset (to input signal value)

Functionality: This macro implements an integrator, state lower limit, time constant T Parameter T must be positive. Otherwise, a message is printed to the output window.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

Lower limitation parameters: v min

#### 13.2.26 1/sT bypass incfreeze reset sig

# Integrator with time constant T and delayed start based on parameter Tincfreeze, with reset

Functionality: Integrator with time constant T and delayed start based on parameter Tincfreeze Option bypass: if time constant T<=0 then block is a feedthrough

Option \_incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

**Function:** 

$$H(s) = \frac{1}{sT}$$

Macro location: Macros\Integrators\with reset (to input signal value)

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x Parameters: T,Tincfreeze Internal variables: t0

# 13.2.27 1/sT fb reset sig

# Integrator, time constant T (fallback), with reset (to input signal value)

Functionality: This macro implements an integrator block with time constant T

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Option fb: if T<=0, yo keeps its initial value

Option reset sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing

0.5 on rising flank.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x

Parameters: T

# 13.2.28 1/sT \_incfreeze\_reset\_sig

# Integrator with time constant T and delayed start based on parameter Tincfreeze, with reset

Functionality: Integrator with time constant T and delayed start based on parameter Tincfreeze Option \_incfreeze: blocks integrator at initialization and afterwards for a duration of Tincfreeze seconds.

Option \_reset\_sig: The state "x" is reset to value of "xrst" input signal upon "rst" signal crossing 0.5 on rising flank.

This macro has a non-linear behaviour.

## Function:

$$H(s) = \frac{1}{sT}$$

**Macro location:** *Macros\Integrators\with reset (to input signal value)* 

Macro DSL level: 6 Output signals: yo Input signals: yi,xrst

Upper limitation input signals: rst

Continuous states: x Parameters: T,Tincfreeze Internal variables: t0

# 14 Lead-lag Blocks

This section provides a complete listing of the existing DSL macros within the *Lead-lag Blocks* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 14.1 (1+ATs)/(1+BTs)

## Lead-lag block with three parameters

Functionality: Block that implements a continuous time lead-lag transfer function.

Uses three parameters: A, B and T.

Parameters T and B must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1 + ATs}{1 + BTs} = \frac{A}{B} \frac{\frac{1}{AT} + s}{\frac{1}{BT} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: A,B,T Internal variables: dx

# 14.2 (1+sTb)/(1+sTa)

## Lead-lag block, time constants Ta and Tb

Functionality: This macro implements a lead-lag block using two parameters Ta and Tb. Parameter Ta must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

# **Function:**

$$H(s) = \frac{1 + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{\frac{1}{T_a} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta Internal variables: dx

# 14.3 (1+sTb)/(1+sTa) [(p;p)] \_bypass

## Lead-lag block, anti-windup limits (bypass)

Functionality: This macro implements a state limited lead-lag block with bypass. The state variable and the output are limited using parameters "y\_min" and "y\_max". Parameter Ta must be non-negative. Otherwise, a message is printed to the output window. Bypass option: if Ta<=0 or Ta=Tb, block is a limited feed-through yo = yi between y\_min and y max limits.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1 + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{\frac{1}{T_a} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

Internal variables: dx,yox

# 14.4 $(1+sTb)/(1+sTa)[(p;p)]_fb$

# Lead-lag block, anti-windup limiter, time constant Ta (fallback value)

Functionality: This macro implements a first order lead-lag block with anti-windup limits. Parameter Ta must be non-negative. Otherwise, a message is printed to the output window. Fallback option: If lag time constant Ta<=0 then use Ta=0.01.

This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{1 + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{\frac{1}{T_c} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

Internal variables: dx,yox

# 14.5 (1+sTb)/(1+sTa) [(pp;pp)] \_bypass

# Lead-lag block, anti-windup limiter, K dependent limits (bypass)

Functionality: This macro implements a lead-lag block with anti windup limits dependent on parameters K, y min and y max

Parameter Ta must be non-negative. Otherwise, a message is printed to the output window.

Parameter K must be positive. Otherwise a message is printed to the output window.

Bypass option: if  $Ta \le 0$  Ta = Tb, block is a limited feed-through yo = yi between y\_min/K and y max/K limits.

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = \frac{1 + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{\frac{1}{T_c} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta,K

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

Internal variables: dx,yox

# 14.6 (1+sTb)/(1+sTa) bypass

## Lead-lag block (bypass)

Functionality: This macro implements a lead-lag block with bypass.

Bypass option:

If Ta>0 then block is a lead-lag

If Ta<=0 .or. Ta=Tb then block is bypassed (yo=yi)

Parameter Ta must be non-negative. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{1 + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{\frac{1}{T_a} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta Internal variables: dx

# 14.7 (1+sTld)/(1+sTlg) and sx

# Lead-lag block with lead time constant Tld and lag time constant Tlg

Lead-lag block (variant) Tld - lead time constant Tlg - lag time constant If Tlg=0, then Tlg=0.01

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1 + sT_{ld}}{1 + sT_{lg}} = \frac{T_{ld}}{T_{lg}} \frac{\frac{1}{T_{ld}} + s}{\frac{1}{T_{lg}} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tld,Tlg Internal variables: dx

# 14.8 (1-ATs)/(1+sAT/2)

## Lead-lag block, with gain and time constant

Functionality: This macro implements a lead-lag block with gain and time constant Parameter A and T must be non-negative. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1 + ATs}{1 + A\frac{T}{2}s} = 2\frac{\frac{1}{AT} - s}{\frac{2}{AT} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: A,T

Internal variables: dx,Tz

# 14.9 (1-sT)/(1+sT/2) bypass

Lead-lag block variant, 1 parameter (bypass)

Functionality: This block implements a variant of a lead-lag block based on a single parameter T. it also includes a bypass in case T=0.

Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: If T<=0 then yo=yi (feedthrough block).

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{1 - sT}{1 + sT/2} = 2\frac{\frac{1}{T} - s}{\frac{2}{T} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

# 14.10 (K+sTb)/(1+sTa)

# Lead-lag block variant, 3 parameters

Functionality: This macro implements a variant of a lead-lag using three parameters K, Ta and Tb.

Parameter Ta must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

# **Function:**

$$H(s) = \frac{K + sT_b}{1 + sT_a} = \frac{T_b}{T_a} \frac{\frac{K}{T_b} + s}{\frac{1}{T_c} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,Tb,Ta Internal variables: dx

# 14.11 (a+sbT)/(1+sT) bypass

## Lead-lag block variant, 3 parameters (bypass)

Functionality: This macro implements a lead-lag block using three parameters a, b and T. Parameter T must be non-negative. Otherwise, a message is printed to the output window.

Bypass option: if T<=0, block is a gain yo=a\*yi

This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{a + sbT}{1 + sT} = b\frac{\frac{a}{bT} + s}{\frac{1}{T} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: a,b,T Internal variables: dx

# 14.12 K(1+sTb)/(1+sTa)

## Lead-lag block with gain, time constant Ta

Functionality: This macro implements a lead-lag block with gain, time constant Ta Parameter Ta must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

#### **Function:**

$$H(s) = \frac{K(1 + sT_b)}{1 + sT_a} = \frac{T_a}{KT_b} \frac{\frac{1}{T_b} + s}{\frac{1}{T_a} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,Tb,Ta Internal variables: dx

# 14.13 K(1+sTld)/(1+sTlg) \_fb

## Lead-lag block with gain, time constant Tig (fallback value)

Functionality: This macro implements a lead-lag block with gain, time constant Tlg (fallback value)

Parameter Tlg must be non-negative. Otherwise, a message is printed to the output window.

Fallback option: If Tlg<=0, then use Tlg=0.01

This macro has a linear behaviour.

## **Function:**

$$H(s) = \frac{K(1 + sT_{ld})}{1 + sT_{lg}} = \frac{T_{lg}}{KT_{ld}} \frac{\frac{1}{T_{ld}} + s}{\frac{1}{T_{lg}} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5
Output signals: yo
Input signals: yi
Continuous states: x

**Parameters:** K,Tld,Tlg **Internal variables:** dx

# 14.14 K(A1+sT1)/(A2+sT2)

#### General first order lead-lag block

Functionality: This macro implements a general first order lead-lag block, 5 parameters Parameter T2 must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{K(A_1 + sT_1)}{A_2 + sT_2} = K \frac{T_1}{T_2} \frac{\frac{A_1}{T_1} + s}{\frac{A_2}{T_2} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,A1,T1,A2,T2 Internal variables: dx

# 14.15 K(A1+sT1)/(A2+sT2)[(p;p)] fb

# General first order lead lag block with state and output limits, time constant T2 (fallback value)

Functionality: This macro implements a general first order lead lag block with state limits, time constant T2 (fallback value)

Parameters T1 and T2 must be non-negative. Otherwise, a message is printed to the output window.

Fallback option: if T2<=0 then use T2=0.01 This macro has a non-linear behaviour.

#### Function:

$$H(s) = \frac{K(A_1 + sT_1)}{A_2 + sT_2} = K\frac{T_1}{T_2} \frac{\frac{A_1}{T_1} + s}{\frac{A_2}{T_2} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,A1,T1,A2,T2

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

Internal variables: dx

# 14.16 K(A1+sT1)/(A2+sT2) fb

#### General first order lead-lag block (fallback value)

Functionality: This macro implements a general first order lead-lag block with 5 parameters. Parameter T2 must be non-negative. Otherwise, a message is printed to the output window.

Fallback option: If T2<=0, then use T2=0.01

This macro has a linear behaviour.

#### Function:

$$H(s) = \frac{K(A_1 + sT_1)}{A_2 + sT_2} = K\frac{T_1}{T_2} \frac{\frac{A_1}{T_1} + s}{\frac{A_2}{T_2} + s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5
Output signals: yo
Input signals: yi
Continuous states: x
Parameters: K,A1,T1,A2,T2
Internal variables: dx

# 14.17 a23(1+(a11-a13a21/a23)sTw)/(1+a11sTw)

## a23(1+(a11-a13a21/a23)sTw)/(1+a11sTw)

Functionality: This block implements the first order transfer function H(s)=a23(1+(a11-a13a21/a23)sTw)/(1+a11sTw) Parameter Tw must be positive. Otherwise, a message is printed to the output window. Parameter a11 must be positive. Otherwise, a message is printed to the output window. This macro has a linear behaviour.

#### Function:

$$H(s) = a_{23} \frac{1 + (a_{11} - a_{13}a_{21}/a_{23})T_w s}{1 + a_{11}T_w s}$$

Macro location: Macros\Lead-lag Blocks

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

**Parameters:** a11,a13,a21,a23,Tw **Internal variables:** dx,Ta,Tb

# 15 Limiters

This section provides a complete listing of the existing DSL macros within the *Limiters* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 15.1 Limit ;p] \_eps

#### Limiter (upper) with small threshold

Functionality: This block implements an upper limiter with a small threshold upon switching between the linear and the limitted regions.

This block avoids toggling behaviour when the input signal is at one of the limit values. The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined. If eps=0, then this block is an upper limiter without switching threshold.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: eps

**Upper limitation parameters:** y\_max **Internal variables:** setmax,rstmax,yo max

# 15.2 Limit [p; eps

#### Limiter (lower) with small threshold

Functionality: This block implements a lower limiter with a small threshold upon switching between the linear and the limitted regions.

This block avoids toggling behaviour when the input signal is at one of the limit values.

The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is a lower limiter without switching threshold.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: eps

Lower limitation parameters: y\_min Internal variables: setmin.rstmin.yo min

# 15.3 Limit [p;p]

# Limiter (lower/upper, asymmetric)

Functionality: This block implements an asymmetric limit (upper/lower)

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi **Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

# 15.4 Limit [p;p] eps

#### Limiter (lower/upper,asymmetric) with small threshold

Functionality: This block implements a symmetric limiter with a small threshold upon switching between the linear and the limitted regions.

This block avoids toggling behaviour when the input signal is at one of the limit values.

The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is an asymmetric limiter without switching threshold.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: eps

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

Internal variables: setmin,rstmin,setmax,rstmax,yo\_min,yo\_max

# 15.5 Limit [p]

## Limiter (lower/upper,symmetric)

Functionality: This block implements a symmetric limit.

Parameter y lim must be positive. Otherwise a message is printed to the output window.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation parameters: y\_lim

# 15.6 Limit [p] (using min/max)

# Limiter (lower/upper,symmetric)

Functionality: This block implements a symmetric limiter.

Parameter y\_lim must be positive. Otherwise a message is printed to the output window.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5

Output signals: yo Input signals: yi

Upper limitation parameters: y\_lim

# 15.7 Limit [p] \_eps

## Limiter (lower/upper,symmetric) with small threshold

Functionality: This block implements a symmetric limiter with a small threshold upon switching between the linear and the limitted regions.

This block avoids toggling behaviour when the input signal is at one of the limit values.

The threshold is defined by parameter eps and it is usually set to a small user defined value.

Parameter y\_lim must be positive. Otherwise a message is printed to the output window.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is a symmetric limiter without switching threshold.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: eps

**Upper limitation parameters:** y\_lim

Internal variables: setmin,rstmin,setmax,rstmax,yo\_min,yo\_max

# 15.8 Limit [s;s]

# Limiter (lower/upper, asymmetric with signals)

Functionality: This block implements an asymmetric limiter with signals (upper/lower)

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

**Lower limitation input signals:** y\_min **Upper limitation input signals:** y\_max

## 15.9 Limit [s;s] eps

#### Limiter (lower/upper,asymmetric) with small threshold

Functionality: This block implements a symmetric limiter with a small threshold upon switching between the linear and the limitted regions.

This block avoids toggling behaviour when the input signal is at one of the limit values. The threshold is defined by parameter eps and it is usually set to a small user defined value.

If set=rst=1 (at within deadband condition) then output is undefined.

If eps=0, then this block is an asymmetric limiter without switching threshold. This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

**Lower limitation input signals:** y\_min **Upper limitation input signals:** y\_max

Parameters: eps

Internal variables: setmin,rstmin,setmax,rstmax,yo\_min,yo\_max

# 15.10 Limit [sp;sp]

# Limiter (lower/upper, asymmetric with signals)

Functionality: This block implements an asymmetric limiter with signals (upper/lower) and pa-

rameters (upper/lower).
This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation input signals: yi\_min Upper limitation input signals: yi\_max Lower limitation parameters: y\_min Upper limitation parameters: y\_max

# 15.11 Limit lower [p;

# Limiter (lower)

Functionality: This block implements a lower limit.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation parameters: v min

# 15.12 Limit upper ;p]

## Limiter (upper)

Functionality: This block implements an upper limit.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: vi

**Upper limitation parameters:** y\_max

# 15.13 Rate limiter ;p}

## **Gradient limiter (upper)**

Functionality: This block implements a gradient limiter (upper)

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation parameters: grd up

## 15.14 Rate limiter base ;p}

## Gradient limiter with base (upper)

Functionality: This block implements an upper gradient limiter block

base - the base value of the input signal, this leads to a gradient limitation in pu/s grd\_up - upper gradient parameter, must be positive, in p.u., base value = base Parameter hi must be positive. Otherwise a message is printed to the output window. This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

Upper limitation parameters: grd up

# 15.15 Rate limiter base {p;

# Gradient limiter with base (lower)

Functionality: This block implements a lower gradient limiter block

Parameters:

base - the base value of the input signal, this leads to a gradient limitation in pu/s

grd down - lower gradient parameter, in p.u., base value = base

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

Lower limitation parameters: grd down

# 15.16 Rate limiter base {p;p}

## Gradient limiter with base (lower/upper, asymmetric)

Functionality: This block implements a gradient limiter (asymmetrical) using parameters lo and

hi

Parameters:

base - the base value of the input signal, this leads to a gradient limitation in pu/s

lo - lower gradient parameter in p.u., base value = base

hi - upper gradient parameter in p.u., base value = base, must be positive

Parameter hi must be positive. Otherwise a message is printed to the output window.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

Lower limitation parameters: grd\_down Upper limitation parameters: grd\_up

# 15.17 Rate limiter base {p}

# Gradient limiter with base (lower/upper,symmetric)

Functionality: This block implements a gradient limiter block (upper/lower), symmetric, in perunit

Parameters:

base - the base value of the input signal, this leads to a gradient limitation in pu/s grd - gradient parameter, in p.u., base value = base, must be positive

Parameter grd must be positive. Otherwise a message is printed to the output window.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

Upper limitation parameters: grd

# 15.18 Rate limiter {p;

# **Gradient limiter (lower)**

Functionality: This block implements a gradient limiter (lower)

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation parameters: grd\_down

# 15.19 Rate limiter {p;p}

## Gradient limiter (lower/upper, asymmetric)

Functionality: This block implements a gradient limiter (lower/upper, asymmetric)

Parameter grd up must be positive. Otherwise a message is printed to the output window.

This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Lower limitation parameters: grd\_down Upper limitation parameters: grd\_up

# 15.20 Rate limiter {p}

#### Gradient limiter (lower/upper,symmetric)

Functionality: This block implements a gradient limiter (lower/upper,symmetric)
Parameter grd must be positive. Otherwise a message is printed to the output window.
This macro has a non-linear behaviour.

Macro location: Macros\Limiters

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation parameters: grd

# 16 Logic Functions

This section provides a complete listing of the existing DSL macros within the *Logic Functions* folder. Their functionality is explained along with a list of the input and output signals, state

variables and parameters.

# 16.1 Basic Logic Functions

#### 16.1.1 AND2

# Logic function AND with two inputs (boolean)

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

#### 16.1.2 AND3

## Logic function AND with three inputs (boolean)

```
Functionality: Implements the logic function AND with three inputs. yi1, yi2 and yi3 are assumed to be boolean input values false =(-oo,0.5) true =[0.5, oo)

Truth table
```

```
| yi1 | yi2 | yi3 | yo |

|------|

| false | false | false | false |

| true | false | false | false |

| false | true | false | false |

| true | true | false | false |

| true | false | true | false |

| true | false | true | false |

| false | true | true | false |
```

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3

#### 16.1.3 AND4

## Logic function AND with four inputs (boolean)

Functionality: Implements the logic function AND with four inputs. yi1, yi2, yi3 and yi4 are assumed to be boolean input values This macro has a non-linear behaviour.

**Macro location:** *Macros\Logic Functions\Basic Logic Functions* 

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,yi4

#### 16.1.4 EOR

# Logic function EOR (NOT EQUAL) (boolean)

Functionality: Implements the logic function EOR (NOT EQUAL) with two inputs yi1 and yi2 are assumed to be boolean input values

false =(-00,0.5)true =[0.5, 00)Truth table

| yi1 | yi2 | yo | |------| | false | false | false | | true | false | true | | false | true | true |

true | true | false |

This macro has a non-linear behaviour.

**Macro location:** *Macros\Logic Functions\Basic Logic Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

#### 16.1.5 EQUAL

# Logic function EQUAL (NOT EOR) (boolean)

Functionality: Implements the logic function EQUAL Description: Returns 1 if yi1 is equal with yi2, 0 otherwise

Behaviour identical with negated exclusive OR

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

#### 16.1.6 NOR

# Logic function NOR (boolean)

|-----| | false | false | true | | true | false | false | | false | true | false | | true | true | false |

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 16.1.7 NOT

# Logic function NOT (boolean)

Functionality: Implements the logic function NOT. yi is assumed to be a boolean input value false =(-oo,0.5) true =[0.5, oo)

## Truth table

| yi | yo | |-----| | false | true | | true | false |

This macro has a non-linear behaviour.

**Macro location:** *Macros\Logic Functions\Basic Logic Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi

#### 16.1.8 OR2

## Logic function OR with two inputs (boolean)

Functionality: Implements the logic function OR with two inputs. yi1 and yi2 are assumed to be boolean input values

false =(-00,0.5)true =[0.5, 00)Truth table

| yi1 | yi2 | yo | |------| | false | false | false | | true | false | true | | false | true | true | | true | true | true |

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

# 16.1.9 OR3

# Logic function OR with three inputs (boolean)

Functionality: Implements the logic function OR with three inputs. yi1, yi2 and yi3 are assumed to be boolean input values

false =(-00,0.5)true =[0.5, 00)Truth table

| yi1 | yi2 | yi3 | yo |

|-----| | false | false | false | false |

```
| true | false | false | true |
| false | true | false | true |
| true | true | false | true |
| false | false | true | true |
| true | false | true | true |
| false | true | true |
| true | true | true |
```

This macro has a non-linear behaviour.

**Macro location:** *Macros\Logic Functions\Basic Logic Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3

#### 16.1.10 OR4

# Logic function OR with four inputs (boolean)

Functionality: Implements the logic function OR with four inputs. yi1, yi2, yi3 and yi4 are assumed to be boolean input values This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Basic Logic Functions

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,yi4

# 16.2 Logic Functions with Pick-up/Drop-off

# 16.2.1 2\_out\_of\_3\_ip

# Output equals to 1 if two inputs are true

Functionality: Output equals to 1 if two inputs are true

Logic function that avoids toggling effects but introduces step re-evaluation.

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3 Parameters: Tpick,Tdrop

# 16.2.2 AND2 \_ip

#### Logic AND function applied on two inputs (boolean, picdro implementation)

Functionality: Logic AND function applied on two inputs

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.

yi1 and yi2 are assumed to be boolean input values

false =(-00,0.5)
true =[0.5, 00)
Truth table
------|
yi1 | yi2 | yo |
|------|
| false | false | false |
| true | false | false |
| false | true | false |

| true | true | true |

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick,Tdrop

### 16.2.3 AND3 ip

### Logic function AND applied to three inputs (boolean, picdro implementation)

Functionality: Implements the logic function AND applied to three inputs

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.

yi1, yi2 and yi3 are assumed to be boolean input values

false =(-oo,0.5) true =[0.5, oo) Truth table

-----

| yi1 | yi2 | yi3 | yo | |------| | false | false | false | false | | true | false | false | false | | false | true | false | false | | true | true | false | false | | false | false | true | false | | true | false | true | false | | false | true | true | false |

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3 Parameters: Tpick,Tdrop

## 16.2.4 Invert Logic \_ip

### Invert a logical signal (boolean, picdro implementation)

Functionality: Invert a logical signal

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi

Parameters: Tpick, Tdrop

## 16.2.5 NOT \_ip

### Logic NOT function (boolean, picdro implementation)

Functionality: Implements the logic NOT function

Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.

yi is assumed to be a boolean input value

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1

Parameters: Tpick, Tdrop

### 16.2.6 OR2 ip

## Logic OR function applied on two inputs (boolean, picdro implementation)

Functionality: Implements the logic OR function applied on two inputs (delay)
Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation.
yi1 and yi2 are assumed to be boolean input values

false =(-00,0.5) true =[0.5, 00) Truth table -----| | yi1 | yi2 | yo |

```
| false | false | false |
| true | false | true |
| false | true | true |
| true | true |
```

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: Tpick,Tdrop

### 16.2.7 OR3 ip

### Logic OR function applied on three inputs (boolean, picdro implementation)

Functionality: Implements the logic OR function applied on three inputs Logic function based on picdro() that avoids toggling effects but introduces step re-evaluation. yi1, yi2 and yi3 are assumed to be boolean input values

false =(-00,0.5) true =[0.5, 00) Truth table

-----

```
| yi1 | yi2 | yi3 | yo |

|------|

| false | false | false | false |

| true | false | false | true |

| false | true | false | true |

| true | true | false | true |

| false | false | true | true |

| true | false | true | true |

| true | true | true |
```

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Logic Functions with Pick-up/Drop-off

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3 Parameters: Tpick,Tdrop

## 16.3 Special Logic Functions

### 16.3.1 Bistable

## Prioritized S-R flip-flop (bistable multivibrator)

Functionality: Prioritized S-R flip-flop (bistable multivibrator)

The Bistable macro operates as below:

When S input is true and R input is false, the flip-flop goes to the Set state. This is the first stable state, where Q is true.

When R is true and S is false, the flip-flop goes to the reset state. This is the second stable state, where Q is false.

When both S and R are true, the flip-flop goes to the prioritized state defined by the Select priority parameter.

When both S and R are false, the flip-flop stays in its previous state.

vardef(PRIO)='0/1';'Prioritised state: 1=SET, 0=RESET'

PRIO\_SET=1: If S=R=1 then Q=1
PRIO\_SET=0: If S=R=1 then Q=0
This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Special Logic Functions

Macro DSL level: 6
Output signals: Q,not\_Q
Input signals: S,R
Parameters: PRIO\_SET

### 16.3.2 Edge detector

### Outputs an impulse when input changes

Functionality: The Edge Detector block outputs an impulse (the value of 1 for one time step) when the logical input changes

If EDGE< 0.5 (e.g. EDGE=0 (default value)) then the detection occurs on the rising edge (from FALSE (yi<0.5) to TRUE (yi>=0.5)).

If  $0.5 \le EDGE < 1.5$  (e.g. EDGE=1) then the detection occurs on the falling edge (from TRUE (yi > 0.5) to FALSE (yi < 0.5)).

If EDGE>=1.5 (e.g. EDGE=2) then the detection occurs on either edges.

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Special Logic Functions

Macro DSL level: 6 Output signals: yo Input signals: yi Parameters: EDGE

Internal variables: rise,fall

### 16.3.3 Monostable

### Monostable flip-flop (one-shot multivibrator)

Functionality: Monostable/monoflop (one-shot) - it generates a pulse of pre-defined duration when triggered (output yo is set to 1). When the timer has expired, it returns to its stable state and produces no more output until triggered again.

The output is set to TRUE (yo = 1 i.e. switches on) upon a rising edge of the input (i.e. yi>0.5) if the monostable output at the previous time step was FALSE (yo=0). Upon triggering, the monostable's output is held TRUE (yo = 1) for a time duration of T seconds. The Monostable block ignores any edge occurring when the pulse is TRUE. Upon time period T expiry since triggering, the output is set to FALSE (yo = 0, i.e. switching off).

This macro has a non-linear behaviour.

Macro location: Macros\Logic Functions\Special Logic Functions

Macro DSL level: 6 Output signals: yo Input signals: yi Continuous states: x

Parameters: T

Internal variables: set,rst,t0

## 17 Math Functions

This section provides a complete listing of the existing DSL macros within the *Math Functions* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

### 17.1 Basic Functions

### 17.1.1 ABS

### Absolute value of real input

Functionality: Returns the absolute value of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.2 CEIL

### Round input to upper integer value

Functionality: Returns the ceil() value of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

## 17.1.3 EXP

### **Exponential function**

Functionality: Computes the exponential function of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.4 FLOOR

## Round input to lower integer value

Functionality: Computes the floor function of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.5 FRAC

## Extraction of fractional part of input

Functionality: Retrieves the fractional part of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.6 LN

## Natural logarithm of input

Functionality: Computes the natural logarithm of the input.

The domain of the function is yi>0. This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

### 17.1.7 LOG

### Logarithm to base of 10

Functionality: Computes the base 10 logarithm of the input.

The domain of the function is yi>0. This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.8 MAX2

## Maximum function (of two signals)

Functionality: Computes the maximum between two input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

### 17.1.9 MAX3

## **Maximum function (of three signals)**

Functionality: Computes the maximum between three input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3

### 17.1.10 MAX4

## **Maximum function (of four signals)**

Functionality: Computes the maximum between four input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,yi4

### 17.1.11 MIN2

### Minimum function (of two signals)

Functionality: Computes the minimum between two input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2

### 17.1.12 MIN3

### Minimum function (of three signals)

Functionality: Computes the minimum between three input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,yi3

### 17.1.13 MIN4

### Minimum function (of four signals)

Functionality: Computes the minimum between four input signals.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,yi4

## 17.1.14 MODULO

## Remainder after numerical division of input by parameter n

Functionality: Computes the remainder after numerical division of yi by n

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: n

### 17.1.15 RECIPROCAL

### Reciprocal function: returns the inverse of input u

Functionality: Returns the inverse of input u

This macro has a linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 6 Output signals: yo Input signals: u

### 17.1.16 RECIPROCAL\_fb

### Reciprocal function: returns the inverse of input u (fallback)

Functionality: Returns the inverse of input u

Option \_fb: If abs(u)<0.000001 then output returns 1/0.000001

This macro has a linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 6 Output signals: yo Input signals: u

### 17.1.17 ROUND

## Rounds input to nearest integer value

Functionality: Round input to nearest integer value.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.18 SIGN

## **Determines sign of input**

Functionality: Determines the sign of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

### 17.1.19 SQRT

### Square root of input

Functionality: Computes the square root of the input.

Note: input may not be negative. If input negative then the absolute value is taken in order to

avoid error.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.20 x<sup>2</sup>

### **Square function**

Functionality: Computes the square of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.1.21 x<sup>p</sup>

## Input to the power of p

Functionality: Computes the input to the power of p

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Basic Functions

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: p

## 17.2 Complex Operations

## 17.2.1 ADD COMPLEX

### Addition of two complex quantities

Functionality: Addition of two complex quantities defined by (re1,im1) and (re2,im2). This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: re,im

Input signals: re1,im1,re2,im2

### 17.2.2 CONJ COMPLEX

### Compute the complex conjugate

Functionality: Retrieve the complex conjugate of a complex number (re1,im1).

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5
Output signals: re,im
Input signals: re1,im1

### 17.2.3 DIV COMPLEX

## Division of two complex quantities

Functionality: Division of two complex quantities defined by (re1,im1) and (re2,im2). Returns: real an imaginary components of the complex division (re1,im1)/(re2,im2).

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: re,im

Input signals: re1,im1,re2,im2

Internal variables: var1

### 17.2.4 MAG COMPLEX

## Magnitude of complex quantity

Functionality: Retrieves the magnitude of a complex quantity with real and imaginary com-

ponents 're' and 'im'.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

### 17.2.5 MUL COMPLEX

### Multiplication of two complex quantities

Functionality: Multiplication of two complex quantities defined by (re1,im1) and (re2,im2).

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: re,im

Input signals: re1,im1,re2,im2

### 17.2.6 SUB COMPLEX

### Subtraction of two complex quantities

Functionality: Subtraction of two complex quantities defined by (re1,im1) and (re2,im2).

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: re,im

Input signals: re1,im1,re2,im2

### 17.2.7 TO POLAR COMPLEX

### Compute the polar form of a complex number from rectangular form

Functionality: Compute the polar form of a complex number from rectangular form.

Output phi is in radians.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: mag,phi Input signals: re,im

### 17.2.8 TO RECTANGULAR COMPLEX

### Compute the rectangular form of a complex number from polar form

Functionality: Compute the rectangular form of a complex number from polar form.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Complex Operations

Macro DSL level: 5 Output signals: re,im Input signals: mag,phi

## 17.3 Trigonometric Functions

### 17.3.1 ACOS

## **Arccosine of input**

Functionality: Returns the arccosine of the input.

The output yo is in radians.

This macro has a non-linear behaviour.

**Macro location:** *Macros\Math Functions\Trigonometric Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.2 ASIN

### Arcsine of input

Functionality: Returns the arcsine of the input.

The input yi is in radians.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.3 ATAN

## Arctangent of input

Functionality: Returns the arctangent of the input.

Output yo is expressed in radians

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.4 ATAN2

### Four-quadrant arctangent

Functionality: Returns the principal value of the angle, given in radians, between the Euclidean plane positive x-axis and the ray to the point (re,im) of the complex value defined by inputs "re" and "im".

Output is in radians, ranging between (-pi,pi]. This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: re,im

### 17.3.5 ATAN2D

### Four-quadrant arctangent (degrees)

Functionality: Returns the principal value of the angle, given in degrees, between the Euclidean plane positive x-axis and the ray to the point (re,im) of the complex value defined by inputs "re" and "im".

Output is in degrees, ranging between (-180,180].

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: re,im

### 17.3.6 ATAND

## Arctangent of input (output angle in degrees)

Functionality: Returns the arctangent of the input (input is the tangent of angle).

Output yo is expressed in degrees This macro has a linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 6 Output signals: yo Input signals: yi

### 17.3.7 COS

### Cosine of input

Functionality: Returns the cosine of the input.

Input yi is in radians.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

### 17.3.8 COSD

## Cosine of input (degrees)

Functionality: Computes the cosine of the input (expressed in degrees).

This macro has a linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 6 Output signals: yo Input signals: yi

### 17.3.9 COSH

## Hyperbolic cosine of input

Functionality: Returns the cosine hyperbolic of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

## 17.3.10 COSHD

## Hyperbolic cosine of input (degrees)

Functionality: Returns the cosine hyperbolic of the input.

This macro has a non-linear behaviour.

**Macro location:** *Macros\Math Functions\Trigonometric Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.11 SIN

### Sine of input

Functionality: Computes the sine of the input. This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

### 17.3.12 SIND

### Sine of input (degrees)

Functionality: Computes the sine of the input (expressed in degrees).

This macro has a linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 6 Output signals: yo Input signals: yi

### 17.3.13 SINH

### Hyperbolic sine of input

Functionality: Computes the sine hyperbolic of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

## 17.3.14 SINHD

## Hyperbolic sine of input (degrees)

Functionality: Computes the sine hyperbolic of the input (expressed in degrees).

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.15 TAN

### Tangent of input

Functionality: Computes the tangent of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

### 17.3.16 TAND

## Tangent of angle (input angle in degrees)

Functionality: Returns the tangent of an angle yi. Input yi is expressed in degrees.

This macro has a linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 6 Output signals: yo Input signals: yi

### 17.3.17 TANH

## Hyperbolic tangent of input

Functionality: Computes the tangent hyperbolic of the input.

This macro has a non-linear behaviour.

Macro location: Macros\Math Functions\Trigonometric Functions

Macro DSL level: 5 Output signals: yo Input signals: yi

### 17.3.18 TANHD

### Hyperbolic tangent of input (degrees)

Functionality: Computes the tangent hyperbolic of the input.

Input yi is expressed in degrees.

This macro has a non-linear behaviour.

**Macro location:** *Macros\Math Functions\Trigonometric Functions* 

Macro DSL level: 5 Output signals: yo Input signals: yi

## 18 Mechanical

This section provides a complete listing of the existing DSL macros within the *Mechanical* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

## 18.1 1/(2Hs)

### Inertia H

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x

Parameters: H

## 18.2 Accelerating Power (simple)

### Computation of accelerating power (simple)

Functionality: This macro computes the accelerating power

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: yo

Input signals: speed,xmt,xme

## 18.3 Accelerating Power IPB

## Computation of accelerating power (variant)

Functionality: This macro calculates the accellerating power of a machine in either genera-

tor MVA base

(IPB=1) or in generator MW base (IPB=0)

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: Pa

Input signals: cosn,speed,xmt,xme

Parameters: IPB

### 18.4 Gear Box

## **Gear Box**

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: omega Input signals: speed

Parameters: Nratio, RPM\_syn

#### 18.5 Mass J

### Mass J

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: omega Input signals: M1,M2 Continuous states: xomega

Parameters: J

## 18.6 P/omg -> Torque

### Calculation of torque based on power and speed

Functionality: This macro computes torque based on speed and power.

Speed input 'omega' is expressed in rad/s.

'Power' input is expressed in kW. 'Torque' output is expressed in Nm. This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: Torque Input signals: Power,omega

### 18.7 Pt/Pturb

## Convert p.u. turbine power in generator MW base (for synchronous generators)

Functionality: This block converts the turbine power from the base defined by parameter PN to the generator MW base. If PN=0, no conversion is perfromed

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: pt

Input signals: pturb,sgnn,cosn

Parameters: PN

### 18.8 Shaft J-k and Pin

### Single mass p.u. shaft model with one coupling and input power

Functionality: This block implements a single mass p.u. shaft model with one coupling and

input power

Nominal torque Tnom = Snom/(2\*pi\*fnom)

Initial conditions:

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 6

Output signals: omega\_j,torque\_jk Input signals: omega k,Pin

**Continuous states:** xdtheta\_jk,xomega\_j **Parameters:** K\_jk,D\_jk,D\_jj,H\_j,fnom

Internal variables: T j,Td jj,Td jk,Tin,dtheta jk,dw j,dw jk,o1,o2,o3,yi

### 18.9 Shaft i-J

### Single mass p.u. shaft model with one coupling, no input power

Functionality: This block implements a single mass p.u. shaft model with one coupling, no

input power

Nominal torque Tnom = Snom/(2\*pi\*fnom)

Initial conditions:

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 6
Output signals: torque\_ji
Input signals: omega i

**Continuous states:** xdtheta\_ji,xomega\_j **Parameters:** K\_ji,D\_ji,D\_jj,H\_j,fnom

Internal variables: T,Td\_ji,Td\_jj,dtheta\_ji\_deg,dw\_ji,dwj,fnom\_,o3,omega\_j,twopi,yi

## 18.10 Shaft i-J-k

## Single mass p.u. shaft model with two couplings, no input power

Functionality: This block implements a single mass p.u. shaft model with two couplings, no

input power

Nominal torque Tnom = Snom/(2\*pi\*fnom)

Initial conditions:

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 6

Output signals: omega j,torque jk

**Input signals:** omega\_k,omega\_i,torque\_ij **Continuous states:** xdtheta\_jk,xomega\_j **Parameters:** K jk,D jk,D ij,D jj,H j,fnom

Internal variables: T,T13,Td12,Td2,add,dtheta deg,dw2,dw jk,dw ki,o1,o2,o3,yi

### 18.11 Shaft i-J-k and Pin

## Single mass p.u. shaft model with two couplings and input power

Functionality: This block implements a single mass p.u. shaft model with two couplings and

input power

Nominal torque Tnom = Snom/(2\*pi\*fnom)

Initial conditions:

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5

Output signals: omega\_j,torque\_jk

**Input signals:** omega\_k,omega\_i,torque\_ij,Pin **Continuous states:** xdtheta\_jk,xomega\_j **Parameters:** K\_jk,D\_jk,D\_ji,D\_ji,H\_j,fnom

Internal variables: T,T1,T13,Td12,Td2,add,dtheta\_deg,dw2,dw\_jk,dw\_ki,o1,o2,o3,yi

## **18.12** Spring

### **Spring**

This macro has a linear behaviour.

Macro location: Macros\Mechanical

Macro DSL level: 5 Output signals: M

Input signals: omega1,omega2

Continuous states: xphi

Parameters: K,D

Internal variables: dxphi

## 19 PI(D) Controllers

This section provides a complete listing of the existing DSL macros within the *PI(D) Controllers* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

## 19.1 (1+sT)/KsT [p;p]

### PI controller, limited output

Functionality: This macro implements a PI controller with limited output

Proportional gain is 1/K. Integral gain is 1/(K\*T).

The output is limited using two parameters "y\_min" and "y\_max". Anti-windup limits are in-

cluded.

Parameters T and K must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

### Function:

$$H(s) = \frac{1 + sT}{KsT} = \frac{1}{K} \frac{\frac{1}{T} + s}{s}$$

Macro location: *Macros\PI(D) Controllers* 

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K.T

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

## 19.2 $(1+sT)/KsT \{p\}[(p;p)]$

## PI controller, rate limit (symmetrical) and anti-windup limiter

Functionality: PI controller with a symmetrical rate limiter and an upper/lower output limitation with two parameters (y min and y max)

The rate limiter parameter "ylim" defines the derivative limit.

The upper/lower output limitation is defined using two parameters "y\_min" and "y\_max". Parameters T and K must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

### Function:

$$H(s) = \frac{1+sT}{KsT} = \frac{1}{K} \frac{\frac{1}{T}+s}{s}$$

**Macro location:** *Macros\PI(D) Controllers* 

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

Lower limitation parameters: y\_min Upper limitation parameters: ylim,y\_max

Internal variables: dx

## 19.3 (1+sTb)/sTa

### PI controller (variant)

Functionality: This macro implements a variant of a PI controller, using two parameters Ta and Tb.

Gain: Tb/Ta

Parameter Ta must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

### Function:

$$H(s) = \frac{1 + sT_b}{sT_a} = \frac{T_b}{T_a} \frac{\frac{1}{T_b} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Tb,Ta Internal variables: dx

## 19.4 (1+sTp)/sTi;p)]

### PI controller with upper output limit and upper anti-windup

Functionality: This macro implements a variant of a PI controller, using two parameters Tp and Ti.

and II.

An upper limitation is included

Gain: Tp/Ti

Parameter Ti must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

### **Function:**

$$H(s) = \frac{1 + sTp}{sT_i} = \frac{T_p}{T_i} \frac{\frac{1}{T_p} + s}{s}$$

**Macro location:** *Macros\PI(D) Controllers* 

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Ti.Tp

Upper limitation parameters: y max

Internal variables: dx

### 19.5 1+K/sT

## PI controller with unity proportional gain, integral gain and time constant

Functionality: This macro implements a variant of a PI controller with unity proportional gain, integral gain and time constant

Parameter T must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

### Function:

$$H(s) = 1 + K\frac{1}{sT} = \frac{\frac{K}{T} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: K,T

## 19.6 Kp(1/Ti+s)/s

### PI controller, series variant, gain Kp, time constant Ti

Functionality: This block implements a PI controller, series variant.

Proportional gain: Kp Integral time constant: Ti

This macro has a linear behaviour.

### Function:

$$H(s) = K_p \frac{1/T_i + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ti

## 19.7 Kp(1/Ti+s)/s (s)

### PI controller, series variant, gain Kp, time constant Ti, with anti-windup

Functionality: This block implements a PI controller, series variant with anti-windup.

The anti-windup implementation is based on the backfeed of the saturated output (external signal) and the unsaturated output (internal).

The difference between these two is used as a second term fed to the integrator input.

Proportional gain: Kp

Integral time constant: Ti

Time constant Tt determines how quickly the integrator is reset.

This macro has a non-linear behaviour.

### Function:

$$H(s) = K_p \frac{1/T_i + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: yo\_lim

**Continuous states: x Parameters:** Kp,Ti,Tt

## 19.8 Kp+1/sTi

### PI Controller, parallel variant, proportional gain Kp, integral time constant Ti

Functionality: This macro implements a variant of a PI Controller (parallel variant).

Proportional gain: Kp Integral time constant: Ti

Parameter Ti must be positive. Otherwise, a message is printed to the output window.

This macro has a linear behaviour.

### Function:

$$H(s) = K_p + \frac{1}{sT_i} = K_p \frac{\frac{1}{K_p T_i} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ti

## 19.9 Kp+1/sTi [(p;p)]

### PI controller, parallel variant, with anti-windup limiter and integrator time constant

Functionality: This macro implements a variant of a PI Controller (parallel variant).

Proportional gain: Kp Integral time constant: Ti

Parameter Ti must be positive. Otherwise, a message is printed to the output window.

This macro has a non-linear behaviour.

## Function:

$$H(s) = K_p + \frac{1}{sT_i} = K_p \frac{\frac{1}{K_p T_i} + s}{s}$$

Macro location: *Macros\PI(D) Controllers* 

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ti

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max

## 19.10 Kp+Ki/s

## PI controller, parallel variant, proportional and integral gains

Functionality: This block implements a PI controller, parallel variant.

Proportional gain: Kp Integral gain: Ki

This macro has a linear behaviour.

Function:

$$H(s) = K_p + \frac{K_i}{s} = K_p \frac{\frac{K_i}{K_p} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ki

## 19.11 Kp+Ki/s (s)

## PI controller, parallel variant, proportional and integral gains, ext. signal tracking antiwindup

Functionality: This block implements a PI controller, parallel variant with external signal tracking anti-windup.

The anti-windup implementation is based on the backfeed of the saturated output (external signal) and the unsaturated output (internal).

Note: Signal yo\_lim is the saturated output (not the limit itself) obtained by externally limiting the signal yo.

The difference between these two is used as a second term fed to the integrator input.

Proportional gain: Kp Integral gain: Ki

Time constant Tt determines how quickly the integrator state is frozen.

This macro has a non-linear behaviour.

### Function:

$$H(s) = K_p + \frac{K_i}{s} = K_p \frac{\frac{K_i}{K_p} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: yo\_lim

Continuous states: x Parameters: Kp,Ki,Tt

## 19.12 Kp+Ki/s [(p;p)]

### PI controller, parallel variant, with Kp, Ki gains and anti-windup limits

Functionality: This block implements a Proportional-Integral (PI) block (parallel variant) with

anti-windup limits. Proportional gain: Kp Integral gain: Ki

This macro has a non-linear behaviour.

## **Function:**

$$H(s) = K_p + \frac{K_i}{s} = K_p \frac{\frac{K_i}{K_p} + s}{s}$$

**Macro location:** *Macros\PI(D) Controllers* 

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ki

Lower limitation parameters: y\_min Upper limitation parameters: y\_max

## 19.13 Kp+Ki/s [p;p](pv;pv)

## PI Controller, parallel variant, with anti-windup acc. to IEEE 421.5 (parallel form)

Functionality: This macro implements a PI Controller with anti-windup acc. to IEEE 421.5 (parallel form), in which the integrator state variable is frozen if the output reaches the limits.

Note: Kp = 0 is not supported, due to risk of integrator latching to limit.

vardef(Kp) = 'p.u.';'Proportional gain'
vardef(Ki) = 'p.u.';'Integral gain'

This macro has a non-linear behaviour.

### Function:

$$H(s) = K_p + \frac{K_i}{s} = K_p \frac{\frac{K_i}{K_p} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi Continuous states: x Parameters: Kp,Ki

**Lower limitation parameters:** ymin **Upper limitation parameters:** ymax

## 19.14 Kp+Ki/s [s;s](sv;sv)

# PI Controller, parallel variant, with anti-windup acc. to IEEE 421.5 (parallel form, variable limit)

Functionality: This macro implements a PI Controller with anti-windup acc. to IEEE 421.5 (parallel form), in which the integrator state variable is frozen if the output reaches the limits.

Limits ymin and ymax are variable and provided as input signals.

Note: Kp = 0 is not supported, due to risk of integrator latching to limit.

vardef(Kp) = 'p.u.';'Proportional gain'
vardef(Ki) = 'p.u.';'Integral gain'

This macro has a non-linear behaviour.

### Function:

$$H(s) = K_p + \frac{K_i}{s} = K_p \frac{\frac{K_i}{K_p} + s}{s}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 6 Output signals: yo Input signals: yi

Lower limitation input signals: ymin Upper limitation input signals: ymax

Continuous states: x Parameters: Kp,Ki

## 19.15 Kp+Ki/s+sKd/(1+sTd)[(p;p)]

## PID controller, parallel variant, with anti-windup and limits

Functionality: This block implements a PID controller with anti-windup limit and output limits

based on the same parameters.

Proportional gain: Kp Integral gain: Ki Derivative gain: Kd Derivative term time constant: Td This macro has a non-linear behaviour.

### Function:

$$H(s) = K_p + \frac{sK_d}{1 + sT_d} + \frac{K_i}{s} = (K_p + \frac{K_d}{T_d}) \frac{\frac{K_i}{K_p T_d + K_d} + \frac{K_p + K_i T_d}{K_p T_d + K_d} s + s^2}{\frac{1}{T_d} s + s^2}$$

Macro location: Macros\PI(D) Controllers

Macro DSL level: 5 Output signals: yo Input signals: yi

Continuous states: x1,x2 Parameters: Kp,Ki,Kd,Td

**Lower limitation parameters:** y\_min **Upper limitation parameters:** y\_max **Internal variables:** yk,yis,yd,dx2

## 20 Signals

This section provides a complete listing of the existing DSL macros within the *Signals* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

## 20.1 Clock (t>0) \_par

### Clock signal (square wave) of fixed frequency at t>0

Functionality: Outputs a square wave signal with frequency cFreq [Hz]. The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed via parameter "cFreq".

The waveform is precise if the maximum simulation time step size is below 1/(2\*cFreq).

The clock signal is generated only at time > 0.

vardef(cFreq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = :'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Continuous states: x
Parameters: cFreq
Internal variables: clock

## 20.2 Clock (t>0) \_sig

### Clock signal (square wave) of variable frequency at t>0

Functionality: Outputs a square wave signal with frequency "extfrq" [Hz]. The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed throughout the simulation via input signal "extfrq". The waveform is precise if the maximum simulation time step size is below 1/(2\*extfrq).

The clock signal is generated only at time > 0.

vardef(extfrq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = ;'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Input signals: extfrq
Continuous states: x
Internal variables: clock

## 20.3 Clock (t>t0) \_par

### Clock signal (square wave) of fixed frequency at t>t0

Functionality: Outputs a square wave signal with frequency cFreq [Hz].

The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed via parameter "cFreq".

The waveform is precise if the maximum simulation time step size is below 1/(2\*cFreq). The macro supresses a derivative of state variable being larger than zero at initial condition,

this results in a delay of 1.0 us of the clock signal at simulation start.

vardef(cFreq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = :'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Continuous states: x
Parameters: cFreq

Internal variables: t0,clock

## 20.4 Clock (t>t0) sig

### Clock signal (square wave) of variable frequency at t>t0

Functionality: Outputs a square wave signal with frequency "extfrq" [Hz]. The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed throughout the simulation via input signal "extfrq". The waveform is precise if the maximum simulation time step size is below 1/(2\*extfrq).

The macro supresses a derivative of state variable being larger than zero at initial condition,

this results in a delay of 1.0 us of the clock signal at simulation start.

vardef(extfrq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = ;'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Input signals: extfrq
Continuous states: x
Internal variables: t0.clock

## 20.5 Clock par

## Clock signal (square wave) of fixed frequency

Functionality: Outputs a square wave signal with frequency cFreq [Hz].

The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed via parameter "cFreq".

The waveform is precise if the maximum simulation time step size is below 1/(2\*cFreq).

The macro contains a state variable with a derivative being larger than zero at initial condition.

vardef(cFreq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = :'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Continuous states: x
Parameters: cFreq
Internal variables: clock

### 20.6 Clock sig

### Clock signal (square wave) of variable frequency

Functionality: Outputs a square wave signal with frequency "extfrq" [Hz].

The "on" pulse has the half width of the period of the signal (Ton/Tp = 0.5).

The clock frequency can be changed throughout the simulation via input signal "extfrq".

The waveform is precise if the maximum simulation time step size is below 1/(2\*extfrq).

The macro contains a state variable with a derivative being larger than zero at initial condition.

vardef(extfrq) = 'Hz';'Clock frequency'

vardef(clock) = ;'Clock signal'

vardef(output) = ;'Clock output signal'

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 6
Output signals: output
Input signals: extfrq
Continuous states: x
Internal variables: clock

### 20.7 Pulse

### Creates a pulse for T1 sec, if input is larger than K

Functionality: Creates a pulse for T1 sec, if input is larger than K

This macro has a linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: K,T1

Internal variables: y1,y2

### 20.8 Sawtooth Wave Generator

### Sawtooth Wave Generator

Functionality: Outputs a sawtooth signal with f=freq [Hz]

The block does not generate interruption events.

The waveform is precise only if the simulation time step size (throughout the simulation) is less

than 1/f.

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: f

Internal variables: t0

## 20.9 Sawtooth Wave Generator \_ip

## Sawtooth Wave Generator, precise with interruption events

Functionality: Outputs a sawtooth signal with f=freq [Hz]

The block enforces interruption events at sawtooth wave peaks.

The waveform is precise if the minimum simulation time step size is less than 1/f (maximum

time step can be greater). Simulations using this block ("Sawtooth Wave Generator \_ip") are typically slower than when using the block "Sawtooth Wave Generator".

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: f

Internal variables: t0,trigger

### 20.10 Sine Wave Generator

## Outputs a sinusoidal signal with f=freq [Hz]

Functionality: Outputs a sinusoidal signal with f=freq [Hz]

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: ampl,freq Internal variables: t

## 20.11 Sine Wave Generator (t>0)

### Outputs a sinusoidal signal with f=freq [Hz] at t>0

Functionality: Outputs a sinusoidal signal with f=freq [Hz] at t>0

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5
Output signals: yo
Parameters: ampl,freq
Internal variables: t

## 20.12 Square Wave Generator

### **Square Wave Generator**

Functionality: Outputs a square wave signal with f=freq [Hz]

The block does not generate interruption events.

The waveform is precise only if the simulation time step size (throughout the simulation) is less

than 1/f.

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: f Internal variables: t0

## 20.13 Square Wave Generator\_ip

### Square Wave Generator, precise with interruption events

Functionality: Outputs a square wave signal with f=freq [Hz]

The block enforces interruption events at square wave flanks (rising/falling).

The waveform is precise if the MAXIMUM simulation time step size is below 1/(2f). Simulations using this block ("Square Wave Generator \_ip") are typically slower than when using the block "Square Wave Generator".

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: f

Internal variables: t0

### 20.14 Time

### Outputs the simulation time

Functionality: Outputs the simulation time This macro has a linear behaviour.

This macro has a linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: t

## 20.15 Triangle Wave Generator

## **Triangle Wave Generator**

Functionality: Outputs a triangle signal with f=freq [Hz].

The block does not generate interruption events.

The waveform is precise only if the simulation time step size (throughout the simulation) is less than 1/f.

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5

Output signals: yo Parameters: f

Internal variables: toffset

## 20.16 Triangle Wave Generator\_ip

### Triangle Wave Generator, precise with interruption events

Functionality: Outputs a triangle signal with f=freq [Hz]

Enforces interruption events at top and bottom triangle wave peaks.

The waveform is precise if the minimum simulation time step size is below 1/f. Simulations using this block ("Triangle Wave Generator \_ip") are typically slower than when using the block "Triangle Wave Generator".

This macro has a non-linear behaviour.

Macro location: Macros\Signals

Macro DSL level: 5 Output signals: yo Parameters: f

Internal variables: toffset,trigger

## 21 Switches / Selectors

This section provides a complete listing of the existing DSL macros within the *Switches / Selectors* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

## 21.1 Enable 1 sig

## Enable an input to pass through depending on signal flag

Functionality: Enable an input to pass through depending on signal flag Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 (at inc) then yo = yi (throughout the simulation) Enable < 0.5 (at inc) then yo = yi\_default (throughout the simulation)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: Enable

Parameters: yi default

## 21.2 Enable 1 sig \_hold

### Enable an input to pass through depending on signal flag or hold

Functionality: Enable an input to pass through depending on signal flag Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi

Upper limitation input signals: Enable

Internal variables: yi\_register

## 21.3 Enable 2 sig

## Enable inputs to pass through depending on signal flag

Functionality: Enable inputs to pass through depending on signal flag

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then yo = yi default

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2 Input signals: yi1,yi2

**Upper limitation input signals:** Enable **Parameters:** yi1 default, yi2 default

## 21.4 Enable 2 sig hold

## Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2 Input signals: yi1,yi2

**Upper limitation input signals:** Enable **Internal variables:** yi1\_register,yi2\_register

# 21.5 Enable 3 sig

# Enable inputs to pass through depending on signal flag

Functionality: Enable inputs to pass through depending on signal flag

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then yo = yi default

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2,yo3 Input signals: yi1,yi2,yi3

**Upper limitation input signals:** Enable **Parameters:** yi1 default,yi2 default,yi3 default

# 21.6 Enable 3 sig hold

#### Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

**Macro DSL level:** 5

Output signals: yo1,yo2,yo3 Input signals: yi1,yi2,yi3

Upper limitation input signals: Enable

Internal variables: vi1 register.vi2 register.vi3 register

# 21.7 Enable 4 sig

## Enable inputs to pass through depending on signal flag

Functionality: Enable inputs to pass through depending on signal flag Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then yo = yi default

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4 Input signals: yi1,yi2,yi3,yi4

**Upper limitation input signals:** Enable

Parameters: yi1\_default,yi2\_default,yi3\_default,yi4\_default

# 21.8 Enable 4 sig hold

# Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4 Input signals: yi1,yi2,yi3,yi4

Upper limitation input signals: Enable

Internal variables: yi1 register,yi2 register,yi3 register,yi4 register

# 21.9 Enable 5 sig

#### Enable inputs to pass through depending on signal flag

Functionality: Enable inputs to pass through depending on signal flag

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then yo = yi default

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4,yo5 Input signals: yi1,yi2,yi3,yi4,yi5 Upper limitation input signals: Enable

Parameters: yi1\_default,yi2\_default,yi3\_default,yi4\_default,yi5\_default

# 21.10 Enable 5 sig hold

#### Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4,yo5 Input signals: yi1,yi2,yi3,yi4,yi5 Upper limitation input signals: Enable

Internal variables: yi1\_register,yi2\_register,yi3\_register,yi4\_register,yi5\_register

# 21.11 Enable 6 sig hold

# Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4,yo5,yo6 Input signals: yi1,yi2,yi3,yi4,yi5,yi6 Upper limitation input signals: Enable

Internal variables: yi1\_register,yi2\_register,yi3\_register,yi4\_register,yi5\_register,yi6\_register

# 21.12 Enable 7 sig hold

# Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo1,yo2,yo3,yo4,yo5,yo6,yo7 Input signals: yi1,yi2,yi3,yi4,yi5,yi6,yi7 Upper limitation input signals: Enable

Internal variables: yi1\_register,yi2\_register,yi3\_register,yi4\_register,yi5\_register,yi6\_register,yi7\_register

# 21.13 Enable 8 sig hold

# Enable inputs to pass through depending on signal flag or hold

Functionality: Enable inputs to pass through depending on signal flag or hold otherwise

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi Enable < 0.5 (at inc) then hold output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

**Output signals:** yo1,yo2,yo3,yo4,yo5,yo6,yo7,yo8

Input signals: yi1,yi2,yi3,yi4,yi5,yi6,yi7,yi8 Upper limitation input signals: Enable

Internal variables: yi1\_register,yi2\_register,yi3\_register,yi4\_register,yi5\_register,yi6\_register,yi7\_register,yi8\_regist

# 21.14 Enable signal

# Enable an input to pass through depending on parameter flag

Functionality: Enable an input to pass through depending on parameter flag Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi (throughout the simulation) Enable < 0.5 (at inc) then yo = 0 (throughout the simulation)

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)'

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: Enable

# 21.15 Enable signal (fixed)

Enable an input to pass through depending on parameter flag (fixed)

Enable an input to pass through depending on parameter flag

Note: Switch is fixed throughout the simulation

Output:

Enable  $\geq$  0.5 (at inc) then yo = yi (throughout the simulation) Enable < 0.5 (at inc) then yo = 0 (throughout the simulation)

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)'

This macro has a linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: Enable

# 21.16 Switch par 1->1 by par

## Outputs either the input or a parameter depending on parameter flag

Outputs either the input or a parameter depending on parameter flag

Note: Output can switch during the simulation via parameter events on Enable

Output:

Enable >= 0.5 then yo = yi Enable < 0.5 then yo = p

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)'

vardef(p) = ;'Output value if flag disabled' This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: Enable,p

# 21.17 Switch par 1->1 by par (fixed)

## Outputs either the input or a parameter depending on parameter flag (fixed)

Outputs either the input or a parameter depending on parameter flag

Note: Switch is fixed throughout the simulation

Output:

Enable >= 0.5 (at inc) then yo = yi (throughout the simulation) Enable < 0.5 (at inc) then yo = p (throughout the simulation)

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)'

vardef(p) = ;'Output value if flag disabled'

This macro has a linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5

Output signals: yo Input signals: yi Parameters: Enable,p

# 21.18 Switch par 1->2 by par

#### Parameter switch 1->2 by parameter

Functionality: Parameter switch 1->2 by parameter Note: Switch is fixed throughout the simulation

Operation:

If sw < 0.5 then parameter K is routed to output yo1 (and yo2 is 0) If sw >=0.5 then parameter K is routed to output yo2 (and yo1 is 0)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2 Parameters: sw.K

## 21.19 Switch par 1->2 by sig

## Parameter switch 1->2 by signal

Functionality: Parameter switch 1->2 by signal sw

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw < 0.5 then parameter K is routed to output yo1 (and yo2 is 0) If sw >= 0.5 then parameter K is routed to output yo2 (and yo1 is 0)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2 Input signals: sw Parameters: K

## 21.20 Switch par 2->1 by par

## Parameter switch 2->1 by parameter

Functionality: Parameter switch 2->1 by parameter Note: Switch is fixed throughout the simulation

Operation:

If sw <=0 then K1 is routed to output
If sw > 0 then K2 is routed to output
This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Parameters: sw,K1,K2

# 21.21 Switch par 2->1 by sig

# Signal switch 2->1 by signal

Functionality: Signal switch 2->1 by signal

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw <=0 then parameter K1 is routed to output If sw > 0 then parameter K2 is routed to output

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: sw Parameters: K1,K2

# 21.22 Switch sig 1->1 by sig

#### Outputs either the input or a parameter depending on signal flag

Outputs either the input or a parameter depending on an input signal flag "Enable" Note: Output can switch during the simulation via parameter events on Enable Output:

Enable  $\geq$  0.5 then yo = yi Enable < 0.5 then yo = p

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)' vardef(p) = ;'Output value if flag disabled'

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi,Enable

Parameters: p

# 21.23 Switch sig 1->1 by sig (fixed)

## Outputs either the input or a parameter depending on signal flag (fixed)

Outputs either the input or a parameter depending on an input signal flag "Enable" Note: Switch is fixed throughout the simulation

## Output:

Enable  $\geq$  0.5 (at inc) then yo = yi (throughout the simulation) Enable < 0.5 (at inc) then yo = p (throughout the simulation)

vardef(Enable)='0/1';'Enable flag (0=disable;1=enable)' vardef(p) = ;'Output value if flag disabled' This macro has a linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi,Enable

Parameters: p

# 21.24 Switch sig 1->2 by par

# Signal switch 1->2 by parameter

Functionality: Signal switch 1->2 by parameter Note: Switch is fixed throughout the simulation

Operation:

If sw < 0.5 then input is routed to output yo1 (and yo2 is 0) If sw >=0.5 then input is routed to output yo2 (and yo1 is 0)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2

Input signals: yi
Parameters: sw

# 21.25 Switch sig 1->2 by par (bool)

## Signal switch 1->2 by parameter(variant)

Functionality: Signal switch 1->2 by parameter (variant)

Note: Switch is fixed throughout the simulation

Operation:

If sw< 0.5 then outputs are zero

If 0.5<=sw<=1.5 then input is routed to yo1 (and yo2=0)

If sw> 1.5 then input is routed to yo2 (and yo1=0)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2

Input signals: yi Parameters: sw

# 21.26 Switch sig 1->2 by sig

#### Signal switch 1->2 by signal

Functionality: Signal switch 1->2 by signal sw

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw < 0.5 then input is routed to output yo1 (and yo2 is 0) If sw >=0.5 then input is routed to output yo2 (and yo1 is 0)

This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo1,yo2 Input signals: yi,sw

# 21.27 Switch sig 2->1 (NOT EQ K) by s/p

## Signal switch 2->1 by signal

Functionality: Signal switch 2->1 (NOT EQ K) by signal/parameter

Note: Output can switch during the simulation (via changing signal sw or parameter events on

K)

Operation:

If sw <> K then yi1 is routed to output. Otherwise yi2 is routed to output. This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,sw

Parameters: K

# 21.28 Switch sig 2->1 by par

## Signal switch 2->1 by parameter

Functionality: Signal switch 2->1 by parameter Note: Switch is fixed throughout the simulation

Operation:

If sw <=0 then yi1 is routed to output If sw > 0 then yi2 is routed to output This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: sw

# 21.29 Switch sig 2->1 by par (bool)

# Signal switch 2->1 by parameter

Functionality: Signal switch 2->1 by parameter Note: Switch is fixed throughout the simulation

Operation:

If sw< 0.5 then output is zero

If 0.5<=sw<=1.5 then yi1 is routed to output If sw> 1.5 then yi2 is routed to output This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2 Parameters: sw

# 21.30 Switch sig 2->1 by sig

# Signal switch 2->1 by signal

Functionality: Signal switch 2->1 by signal

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw <=0 then yi1 is routed to output
If sw > 0 then yi2 is routed to output
This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,sw

# 21.31 Switch sig 2->1 by sig (bool)

## Signal switch 2->1 by signal (threshold at 0.5)

Passes through a single input depending on the state of input signal "sw": Note: Output can switch during the simulation (via changing signal sw) pass first input if sw < 0.5 e.g. sw = 0 pass second input if sw > = 0.5 e.g. sw = 1 This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,sw

# 21.32 Switch sig 2->1 by sig (fixed)

## Signal switch 2->1 fixed by signal (threshold at 0.5)

Functionality: Passes through a single input depending on the state of input signal "sw": Note: Switch is fixed throughout the simulation pass first input if sw < 0.5 e.g. sw = 0 pass second input if sw > 0.5 e.g. sw = 1 This macro has a linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,yi2,sw

# 21.33 Switch sig 3->1 by sig

## Signal switch 3->1 by signal

Passes through a single input depending on the state of input signal "sw": Note: Output can switch during the simulation (via changing signal sw) pass first input if sw<0.5 e.g. sw=0 pass second input if 0.5<=sw<1.5 e.g. sw=1 pass third input if 1.5<=sw e.g. sw=2 This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,sw

# 21.34 Switch sig 4->1 by sig

## Signal switch 4->1 by signal

Passes through a single input depending on the state of input signal "sw": Note: Output can switch during the simulation (via changing signal sw) pass first input if sw<0.5 e.g. sw = 0 pass second input if 0.5<=sw<1.5 e.g. sw = 1 pass third input if 1.5<=sw<2.5 e.g. sw = 2 pass fourth input if 2.5<=sw e.g. sw = 3 This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo

Input signals: yi1,yi2,yi3,yi4,sw

# 21.35 Switch sw equal C 2s->1s

#### Switch sw =C 2s->1s

Functionality: Switch sw=C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw =C then yi1 is routed to output
If sw ~=C then yi2 is routed to output
This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

# 21.36 Switch sw greater than C 2s->1s

## Switch sw>C 2s->1s

Functionality: Switch sw>C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw >C then yi1 is routed to output If sw <=C then yi2 is routed to output This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

# 21.37 Switch sw greater than or equal C 2s->1s

## Switch sw>=C 2s->1s

Functionality: Switch sw>=C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw >= C then yi1 is routed to output
If sw < C then yi2 is routed to output
This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

# 21.38 Switch sw not equal C 2s->1s

#### Switch sw =C 2s->1s

Functionality: Switch sw~=C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw ~=C then yi1 is routed to output
If sw =C then yi2 is routed to output
This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

## 21.39 Switch sw smaller than C 2s->1s

#### Switch sw<C 2s->1s

Functionality: Switch sw<C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw <C then yi1 is routed to output If sw >=C then yi2 is routed to output This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

# 21.40 Switch sw smaller than or equal C 2s->1s

#### Switch sw<=C 2s->1s

Functionality: Switch sw<=C 2s->1s

Pass first input if condition is true, otherwise pass third input.

Note: Output can switch during the simulation (via changing signal sw)

Operation:

If sw <=C then yi1 is routed to output

If sw > C then yi2 is routed to output This macro has a non-linear behaviour.

Macro location: Macros\Switches / Selectors

Macro DSL level: 5 Output signals: yo Input signals: yi1,sw,yi2

Parameters: C

# 22 Timers

This section provides a complete listing of the existing DSL macros within the *Timers* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 22.1 Timer reset

# Timer with reset, resets at 0 upon triggering (rising edge of rst)

Functionality: Timer with reset. Starts always at zero. If trigerred via signal rst then it resets to zero.

Reset signal rst expected within range [0,1].

Triggering occurs when 'rst' signal crosses 0.5 on the rising edge.

This macro has a non-linear behaviour.

Macro location: Macros\Timers

Macro DSL level: 6
Output signals: yo
Input signals: rst
Internal variables: dt

# 22.2 Timer (reset/hold reset/t0) reset incfw

# Timer with reset, hold reset, initial timer value and delayed start

Functionality: Timer with reset, hold reset, initial timer value and delayed start.

Reset option: This function includes a state/internal variable reset (based on an input signal)

Forward initial condition option: Output is initialised based on the input.

Reset signal rst expected within range [0,1]

Inputs: rst - reset signal between 0 and 1 (including); when rst input greater/smaller than 0.5

then reset timer

t0 - value of time upon reset

Outputs:

yo - outputs the timer value; initialises to t0, resets to t0

Parameters:

flank - '0/1';'0:rising / 1:falling'

flank = 0 (rising flank) then when rst>0.5 apply timer reset

flank = 1 (falling flank) then when rst<0.5 apply timer reset

t\_start\_delay - Delay in seconds until timer starts: freezes the output for t\_start\_delay seconds upon simulation start and has no influence afterwards.

This macro has a non-linear behaviour.

Macro location: Macros\Timers

Macro DSL level: 5 Output signals: yo Input signals: rst,t0 Continuous states: x

**Parameters:** flank,t\_start\_delay **Internal variables:** tinc,tldf,dir,tx

# 23 Transformations

This section provides a complete listing of the existing DSL macros within the *Transformations* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

#### 23.1 Clarke transform

#### Clarke transform

Functionality: implements the Clarke transform for EMT type signals Transforms instantaneous A/B/C components to alpha/beta/gamma components This macro has a linear behaviour.

# Function:

$$\begin{bmatrix} alpha \\ beta \\ gamma \end{bmatrix} = \begin{bmatrix} \frac{2}{3} & -\frac{1}{3} & -\frac{1}{3} \\ 0 & \frac{\sqrt{3}}{3} & -\frac{\sqrt{3}}{3} \\ \frac{1}{3} & \frac{1}{3} & \frac{1}{3} \end{bmatrix} \begin{bmatrix} a \\ b \\ c \end{bmatrix}$$

Macro location: Macros\Transformations

Macro DSL level: 5

Output signals: alpha,beta,gamma

Input signals: a,b,c

## 23.2 Inverse Clarke transform

#### **Inverse Clarke transform**

Functionality: implements the inverse Clarke transform for EMT type signals Transforms alpha/beta/gamma components to A/B/C instantaneous components This macro has a linear behaviour.

#### **Function:**

$$\begin{bmatrix} a \\ b \\ c \end{bmatrix} = \begin{bmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{bmatrix} \begin{bmatrix} alpha \\ beta \\ gamma \end{bmatrix}$$

Macro location: Macros\Transformations

Macro DSL level: 5 Output signals: a,b,c

Input signals: alpha,beta,gamma

# 23.3 Inverse Park transform (dq)

## Inverse Park transform (dq)

Functionality: This macro implements the inverse Park transform (d/q) This macro has a linear behaviour.

#### Function:

$$\left[\begin{array}{c} alpha \\ beta \end{array}\right] = \left[\begin{array}{cc} cos(\phi) & -sin(\phi) \\ sin(\phi) & cos(\phi) \end{array}\right] \left[\begin{array}{c} d \\ q \end{array}\right]$$

Macro location: Macros\Transformations

Macro DSL level: 5

Output signals: alpha,beta Input signals: d,q,cosphi,sinphi

# 23.4 Inverse Park transform (dq0)

## Inverse Park transform (dq0)

Functionality: This macro implements the inverse Park transform (d/q/0) This macro has a linear behaviour.

## **Function:**

$$\begin{bmatrix} alpha \\ beta \\ gamma \end{bmatrix} = \begin{bmatrix} cos(\phi) & -sin(\phi) & 0 \\ sin(\phi) & cos(\phi) & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} d \\ q \\ zero \end{bmatrix}$$

Macro location: Macros\Transformations

Macro DSL level: 5

Output signals: alpha,beta,gamma Input signals: d,q,zero,cosphi,sinphi

## 23.5 Park transform (dq)

## Park transform (dq)

Functionality: This macro implements the forward Park transform (alpha,beta)->(d,q) This macro has a linear behaviour.

Function:

$$\left[\begin{array}{c} d \\ q \end{array}\right] = \left[\begin{array}{c} \cos(\phi) & \sin(\phi) \\ -\sin(\phi) & \cos(\phi) \end{array}\right] \left[\begin{array}{c} alpha \\ beta \end{array}\right]$$

Macro location: Macros\Transformations

Macro DSL level: 5 Output signals: d,q

Input signals: alpha,beta,cosphi,sinphi

# 23.6 Park transform (dq0)

## Park transform (dq0)

Functionality: This macro implements the forward Park transform (alpha,beta,gamma)->(d,q,0) This macro has a linear behaviour.

**Function:** 

$$\left[ \begin{array}{c} d \\ q \\ zero \end{array} \right] = \left[ \begin{array}{ccc} \cos(\phi) & \sin(\phi) & 0 \\ -\sin(\phi) & \cos(\phi) & 0 \\ 0 & 0 & 1 \end{array} \right] \left[ \begin{array}{c} alpha \\ beta \\ gamma \end{array} \right]$$

**Macro location:** *Macros\Transformations* 

Macro DSL level: 5 Output signals: d,q,zero

Input signals: alpha,beta,gamma,cosphi,sinphi

# 23.7 RMS value

## Calculation of RMS value of a signal in EMT simulation

Functionality: Calculation of RMS value of a signal in EMT simulation

Caution: The RMS value needs one period to settle.

The result is not precise in the first period.

In RMS simulation this block is a simple feed-through (yo = yi).

This macro has a linear behaviour.

**Macro location:** *Macros\Transformations* 

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: fn

# 23.8 RMS value p.u.

## Calculation of RMS value of a signal in p.u. in EMT simulation

Functionality: Calculation of RMS value of a signal in p.u. in EMT simulation

Input signal yi: p.u. base is nominal peak value (1 p.u. = nominal peak value = sqrt(2) \* nominal RMS value).

Outut signal yo: p.u. base is nominal RMS value (1 p.u. = nominal RMS value).

Caution: The RMS value needs one period to settle.

The result is not precise in the first period.

In RMS simulation this block is a simple feed-through (yo = yi).

This macro has a linear behaviour.

**Macro location:** *Macros\Transformations* 

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: fn

# 23.9 U seq/ab0 -> U abc

# Calculation of line-ground and line-line voltage RMS magnitudes in RMS and EMT simulation

Functionality:

In case of RMS simulation: vector transformation from sequence components to phase voltages (line and lini-line)

[ua] [1 1 1] [u1]

 $[ub] = [a^2 a 1] * [u2]$ 

[uc] [a a^2 1] [u0]

with:

a = -1/2 + j\*sqrt(3)/2

 $a^2 = -1/2 - j*sqrt(3)/2$ 

In case of EMT simulation: inverse Clarke transform for instantaneous values with subsequent per phase RMS value calculation.

 $[ua][1\ 0\ 1][ualpha]$  with ualpha = u1r

 $[ub] = [-1/2 + sqrt(3)/2 \ 1] * [ubeta] with ubeta = u1i$ 

[uc] [-1/2 -sqrt(3)/2 1] [u0]

This macro has a linear behaviour.

#### Function for RMS simulation:

$$\begin{bmatrix} \underline{u}_a \\ \underline{u}_b \\ \underline{u}_c \end{bmatrix} = \begin{bmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{bmatrix} \begin{bmatrix} \underline{u}_1 \\ \underline{u}_2 \\ \underline{u}_0 \end{bmatrix}$$

with: 
$$\underline{a} = -\frac{1}{2} + j\frac{\sqrt{3}}{2}$$

$$\begin{bmatrix} ua \\ ub \\ uc \end{bmatrix} = \begin{bmatrix} \|\underline{u}_a\| \\ \|\underline{u}_b\| \\ \|\underline{u}_c\| \end{bmatrix}$$

#### **Function for EMT simulation:**

$$\begin{bmatrix} ua \\ ub \\ uc \end{bmatrix} = \begin{bmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{bmatrix} \begin{bmatrix} u1r \\ u1i \\ u0 \end{bmatrix}$$

Macro location: Macros\Transformations

Macro DSL level: 5

Output signals: ua,ub,uc,uab,ubc,uca Input signals: u1,u1r,u1i,u2r,u2i,u0r,u0i,u0

Parameters: fn

Internal variables: uar,uai,ubr,ubi,ucr,uci,t,t0

# 23.10 abc->dq0 (power invariant – align a->d)

## DQ0 transform - power invariant (abc->dq0, a->d alignment, emt)

Functionality: This macro implements the power invariant forward Park transformatopm (a,b,c)-(d,q,0)

It aligns phase a to d-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

**Macro location:** *Macros\Transformations* 

Macro DSL level: 6 Output signals: d,q,zero Input signals: a,b,c,theta

Internal variables: sqrt2\_3,one\_sqrt2,twopi\_3

# 23.11 abc->dq0 (power invariant – align a->q)

# DQ0 transform - power invariant (abc->dq0, a->q alignment, emt)

Functionality: This macro implements the power invariant forward Park transformatopm (a,b,c)-(d,a,0)

It aligns phase a to the q-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

Macro location: Macros\Transformations

Macro DSL level: 6 Output signals: d,q,zero Input signals: a,b,c,theta

Internal variables: sqrt2\_3,one\_sqrt2,twopi\_3

# 23.12 abc->dq0 (power variant – align a->d)

## DQ0 transform - power variant (abc->dq0, a->d alignment, emt)

Functionality: This macro implements the power variant forward Park transformatopm (a,b,c)-

>(d,q,0)

It aligns phase a to the d-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

Macro location: Macros\Transformations

Macro DSL level: 6 Output signals: d,q,zero Input signals: a,b,c,theta

Internal variables: ratio2 3,twopi 3

# 23.13 abc->dq0 (power variant – align a->q)

## DQ0 transform - power variant (abc->dq0, a->q alignment, emt)

Functionality: This macro implements the power variant forward Park transformatopm (a,b,c)-

>(d,q,0)

It aligns phase a to the q-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

Macro location: Macros\Transformations

Macro DSL level: 6 Output signals: d,q,zero Input signals: a,b,c,theta

Internal variables: ratio2 3,twopi 3

# 23.14 dq0->abc (power invariant – align a->d)

# Inverse DQ0 transform - power invariant (dq0->abc, a->d alignment, emt)

Functionality: This macro implements the power invariant inverse Park transformatopm (d,q,0)-

>(a,b,c)

It aligns phase a to d-axis.

Supports EMT simulation only.

This macro has a non-linear behaviour.

**Macro location**: *Macros\Transformations* 

Macro DSL level: 6
Output signals: a,b,c
Input signals: d,q,zero,theta

Internal variables: sqrt2\_3,one\_sqrt2,twopi\_3

# 23.15 dq0->abc (power invariant – align a->q)

## Inverse DQ0 transform - power invariant (dq0->abc, a->q alignment, emt)

Functionality: This macro implements the power invariant inverse Park transformatopm (d,q,0)-

>(a,b,c)

It aligns phase a to q-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

Macro location: Macros\Transformations

Macro DSL level: 6 Output signals: a,b,c Input signals: d,q,zero,theta

Internal variables: sqrt2\_3,one\_sqrt2,twopi\_3

# 23.16 dq0->abc (power variant – align a->d)

## Inverse DQ0 transform - power invariant (dq0->abc, a->d alignment, emt)

Functionality: This macro implements the power variant inverse Park transformatopm (d,q,0)-

>(a,b,c)

It aligns phase a to d-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

Macro location: Macros\Transformations

Macro DSL level: 6
Output signals: a,b,c

Input signals: d,q,zero,theta Internal variables: twopi\_3

# 23.17 dq0->abc (power variant – align a->q)

## Inverse DQ0 transform - power variant (dq0->abc, a->q alignment, emt)

Functionality: This macro implements the power variant inverse Park transformatopm (d,q,0)-

>(a,b,c)

It aligns phase a to q-axis. Supports EMT simulation only.

This macro has a non-linear behaviour.

**Macro location:** *Macros\Transformations* 

Macro DSL level: 6
Output signals: a,b,c
Input signals: d,q,zero,theta
Internal variables: twopi\_3

# 24 Unit Conversion

This section provides a complete listing of the existing DSL macros within the *Unit Conversion* folder. Their functionality is explained along with a list of the input and output signals, state variables and parameters.

# 24.1 Hz -> p.u.

## Convert speed/frequency from Hz to p.u.

Functionality: This macro converts an input frequency/speed to p.u., with the base frequency equal to parameter freqbase.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: fpu Input signals: Freq Parameters: freqbase

# 24.2 Nm -> p.u.

# Convert torque in Nm to p.u.

Functionality: This macro converts a torque quantity expressed in Nm into pu, with base parameters freqbase, Zp and Pel\_base.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: m Input signals: M

Parameters: freqbase, Zp, Pel\_base

# 24.3 abs -> p.u. (par)

## Divide by base (parameter)

Functionality: This block converts the input quantity to per unit, with the base value defined by the parameter 'base'.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

# 24.4 abs -> p.u. (sig)

# Divide by base (input signal)

Functionality: This block converts the input quantity to per unit, with the base value defined

by the input signal 'base'.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi,base

# 24.5 deg -> rad

# Convert angle from degrees to radians

Functionality: This macro converts the input yi, expressed in degrees, into radians.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi

# 24.6 p.u. -> Hz

## Convert speed/frequency from p.u. to Hz

Functionality: This macro converts the input signal fpu, in p.u., to Hz using the nominal frequency "freqbase".

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: Freq Input signals: fpu Parameters: freqbase

# 24.7 p.u. -> abs (par)

# Multiply by base (parameter)

Functionality: This macro multiplies the input by the parameter "base"

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi Parameters: base

# 24.8 p.u. -> abs (sig)

## Multiply by base (signal)

Functionality: This macro multiplies the input "yi" by the input signal "base"

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi,base

# 24.9 p.u. -> rpm

# Convert speed/frequency from p.u. to rpm

Functionality: This macro converts the input signal fpu, in p.u., to rpm using the nominal frequency "freqbase" and "Zp".

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: n Input signals: speed Parameters: Zp,freqbase

# 24.10 rad -> deg

# Convert angle from radians to degrees

Functionality: This macro converts the input, expressed in radians, into degrees.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: yo Input signals: yi

# 24.11 rad/s -> rpm

## Convert speed/frequency from rad/s to rpm

Functionality: This macro converts the input, expressed in rad/s, into rpm.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: n Input signals: omega

# 24.12 rpm -> p.u.

## Convert speed/frequency from rpm to p.u.

Functionality: This macro converts the input signal "n", expressed in rpm, into p.u. using the parameters "freqbase" and "Zp".

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: speed Input signals: n

Parameters: Zp,freqbase

# 24.13 rpm -> rad/s

# Convert speed/frequency from rpm to rad/s

Functionality: This macro converts the input signal "n", expressed in rpm, into rad/s.

This macro has a linear behaviour.

Macro location: Macros\Unit Conversion

Macro DSL level: 5 Output signals: omega

Input signals: n