



Schweitzer SEL 751
Power Factory
Relay model description



DIgSILENT GmbH Heinrich-Hertz-Strasse 9 D-72810 Gomaringen Tel.: +49 7072 9168 - 0 Fax: +49 7072 9168- 88

http://www.digsilent.de e-mail: mail@digsilent.de

Schweitzer SEL 751

Power Factory Relay model description

Published by DIgSILENT GmbH, Germany

Copyright 2009. All rights reserved. Unauthorised copying or publishing of this or any part of this document is prohibited.

doc.TechRef, Build 513 12 Januar 2021

## **Table of Contents**

1 MODEL GENERAL DESCRIPTION	4
2 RELAY NOT SUPPORTED FEATURES	5



## 1 Model general description

The following functionalities are modelled:

- 2 Inverse time 3 phase overcurrent elements: 2 protective elements ("51P1", "51P2" block)
- 3 Inverse time single phase overcurrent elements: 3 protective elements ("51A", "51B", "51C" block)
- ♦ 2 Inverse time ground overcurrent elements: 2 protective elements ("51G1", "51G2" block)
- ◆ 2 Inverse time neutral overcurrent elements: 2 protective elements ("51N1", "51N2" block)
- ♦ 1 Inverse time negative sequence overcurrent elements: 1 protective elements ("51Q1" block)
- ♦ 4 definite time phase overcurrent elements: 4 protective elements ("50P1", "50P2", "50P3", "50P4" block)
- 4 definite time ground overcurrent elements: 4 protective elements ("50G1", "50G2", "50G3", "50G4" block)
- ◆ 4 definite time neutral overcurrent elements: 4 protective elements ("50N1", "50N2", "50N3", "50N4" block)
- ◆ 4 definite time negative sequence overcurrent elements: 4 protective elements ("50Q1", "50Q2", "50Q3", "50Q4" block)
- ♦ 2 definite time phase overvoltage elements: 4 protective elements (2 sets:"59P1", "59P2" using the phase-ground voltages and "59PP1", "59PP2" using the phase-phase voltages, only a set can be enabled depending upon the VT connections)
- ♦ 2 definite time phase undervoltage elements: 4 protective elements (2 sets: "27P1", "27P2"" using the phaseground voltages and "27PP1", "27PP2" using the phase-phase voltages, only a set can be enabled depending upon the VT connections)
- ◆ 2 definite time ground overvoltage elements: 2 protective elements ("59G1", "59G2")
- 2 definite time negative sequence overvoltage elements: 2 protective elements ("59Q1", "59Q2")
- ♦ 6 over/under frequency elements: 6 protective elements ("81D1", "81D2", "81D3", "81D4", "81D5", "81D6" block)
- ♦ 4 rate of change of frequency elements: 4 protective elements ("81R1", "81R2", "81R3", "81R4" block)
- Reclosing feature: 4 protective elements are available ("Phase reclosing", "Ground reclosing", "Neutral reclosing", "Neg. Sequence reclosing" block). Please configure the "Tab page" of the reclosing blocks to set the reclosing/lockup logic.



## 2 Relay not supported features

The following features are not supported:

- Power factor element
- Synchronism check element
- Power elements
- Loss of potential