

PowerFactory 2021

Technical Reference

DIgSILENT F27 Phase under voltage Generic Relay

Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

Copyright © 2021 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

November 15, 2019 PowerFactory 2021 Revision 924

Contents

1	F27 Phase under voltage			
	1.1	Intent	1	
	1.2	Functionality	1	
	1.3	Inputs	1	
	1.4	Available Units	1	
	1.5	Outputs	2	

1 F27 Phase under voltage

1.1 Intent

To simulate a set of phase and phase ground under voltage protective elements.

1.2 Functionality

The *F27 Phase under voltage* relay model simulates a set of phase-phase and phase-ground under voltage elements. In each group of elements (i.e. the phase-phase elements) one inverse/definite time and 3 definite time elements are available.

1.3 Inputs

• One 3 phase VT ("Phase Vt" block, StaVt class).

The following blocking signals are available:

- iblock 1 blocking "Upn<".
- iblock 2 blocking "Upn<< ".
- iblock_3 blocking "Upn<<<".
- iblock_4 blocking "Upn<<<<".
- iblock 5 blocking "Upp<".
- iblock_6 blocking "Upp<< ".
- iblock 7 blocking "Upp<<<".
- iblock_8 blocking "Upp<<<<".

1.4 Available Units

Measurement

- One 3phase measurement element ("Measurement" block, *RMS Calculation* enabled, *Filter* disabled [RelMeasure class]).
- One 3phase delta measurement element ("Measurement delta" block, *RMS Calculation* enabled, *Filter* disabled [RelMeasure class]).

Protective elements

• One inverse/definite time phase-phase undervoltage element ("Upp<" block [RelChar class]).

- Three definite time phase-phase undervoltage elements ("Upp<< ", "Upp<<<" and "Upp<<<" block [RelUlim class]).
- One inverse/definite time phase-ground undervoltage element ("Upn<" block, RelChar class).
- Three definite time phase-ground undervoltage elements ("Upn<< ", "Upn<<<" and "Upn<<<" block, *RelUlim* class).

Output logic

• One relay trip element ("Output logic" block, RelLogdip class).

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.

1.5 Outputs

- yout associated by default to any protective element trip.
- yout1 associated by default to any phase-phase undervoltage protective element trip.
- yout2 associated by default to any phase-ground undervoltage protective element trip.