Microprocessor Systems

Dr. Gökhan İnce

Topics


- Stack
- Subroutine
- Interrupt

Stack

- Stack is a temporary storage area in memory identified by the programmer
 - Variables are stored temporarily
 - Program addresses are stored temporarily
 - Connection to subroutine
- Last In First Out (LIFO) structure
- The stack normally grows backwards into memory.
 - Programmer defines the bottom address of the stack and the stack grows up into reducing address range.

Stack

- The stack grows from higher addresses to lower so that the top of the stack grows upwards.
- Because of this, the bottom of the stack is often located at the **highest** available memory address.
- It is used in two ways
 - Data is stored in the program
 - By PUSH (PSH) and POP instructions
 - While branching to the subroutine or branching to interrupt service routine the return addresses (PC) and parameters are pushed onto stack



Stack in Educational CPU


- There is a 16-bit Stack Pointer (SP) in the Educational CPU
- Stack pointer points the next available address in the stack
- The accumulator contents can be pushed to stack
- The stack contents can be pulled to the accumulators
- The stack grows from higher addresses to lower

Saving Information on the Stack

Stack pointer is set to a suitable address

- To store data to the stack: PSH A
 - Data of ACC A is stored at the address pointed with SP

 SP is decremented by one to point the next available address in the stack




The POP Instruction

In order to retrieve data from stack:

Increment SP

$$SP \leftarrow SP + 1$$

 Copy the content of the memory location pointed by the SP to accumulator B



Operation of the Stack

- During pushing, the stack operates in a "store then decrement" style.
 - The information is placed on the stack first, then the stack pointer is decremented.
- During popping, the stack operates in an "increment then use" style.
 - The pointer is incremented and then the information is retrieved from the top of the stack
- The SP always points to "the top of the stack".

LIFO


 Push and pop operations must be done in reverse order in order to retrieve information back into its original location.

```
PUSH A
PUSH B
:
POP B
POP A
```

 Push too much without popping and you can overwrite your program! It's your responsibility not to do this.

There is an array of ten elements starting from address \$1000 in memory. They will be stored in reverse order starting at the same address.

START	LDA	SP,\$2000
	LDA	IX,\$1000
	LDA	B,\$0A
BACK	BEQ	NEXT
	LDA	A, <ix+0></ix+0>
	INC	IX
	PSH	A
	DEC	В
	BR	BACK
NEXT	LDA	IX,\$1000
	LDA	B,\$0A
LOOP	BEQ	END
	POP	A
	STA	A, <ix+0></ix+0>
	INC	IX
	DEC	В
	BR	LOOP
END	SWI	



Topics

- Stack
- Subroutine
- Interrupt

Subroutine

- A subroutine is a group of instructions that will be used repeatedly in different locations of the program.
- In Assembly language, a subroutine can exist anywhere in the code.
 - However, it is customary to place subroutines separately from the main program.

Subroutine Instructions

- The instructions that are used for calling subroutine and returning from subroutine in educational CPU:
 - BSR ADDRESS: Calling the subroutine in the ADDRESS.

```
\langle SP \rangle \leftarrow PC(low), SP \leftarrow SP-1
\langle SP \rangle \leftarrow PC(high), SP \leftarrow SP-1
PC \leftarrow ADDRESS
```

BSR STEP: Calling the subroutine that has address of PC+STEP


```
\langle SP \rangle \leftarrow PC(low), SP \leftarrow SP-1
\langle SP \rangle \leftarrow PC(high), SP \leftarrow SP-1
PC \leftarrow PC + STEP
```

RTS: Return back to main program.

$$SP \leftarrow SP + 1$$
, $PC(high) \leftarrow \langle SP \rangle$
 $SP \leftarrow SP + 1$, $PC(low) \leftarrow \langle SP \rangle$

BSR Instruction


- When BSR is executed:
 - Push the address of the instruction immediately following the BSR onto the stack
 - Load the program counter with the 16-bit address supplied with the BSR instruction.






RTS Instruction

- RTS (return from subroutine) returns to the main program
 - Retrieve the return address from the top of the stack
 - Load the program counter with the return address.



Subroutine



You must initialize the stack in any program that calls subroutines. If you don't, return addresses may overwrite other important data, or not be recorded because the memory at the address the SP points to is either ROM or just empty space (i.e., not installed).

Example-2 (Call-by-value)

A program to find the absolute value of numbers.

Compute magnitude (absolute value) of single-byte signed number in A. Return unsigned result in A.

START	LDA LDA	SP,\$FFFF A,\$A9	્	neg
	STA	A,<\$1000>		_
	LDA	A,\$75	왕	pos
	STA	A,<\$100A>		
	BSR	ABSVAL		
	LDA	A,<\$1000>		
	BSR	ABSVAL		
	STA	A,<\$1000>		
FINISH	SWI			
ABSVAL	TST	A,\$80		_
	BEQ	END		
	NEG	A		
END	RTS			

Passing Data to a Subroutine

- In Assembly Language data is passed to a subroutine through registers.
 - The data is stored in one of the registers by the calling program and the subroutine uses the value from the register.
- The other possibility is to use agreed upon memory locations.
 - The calling program stores the data in the memory location and the subroutine retrieves the data from the location and uses it.
- Stack can be used for parameter passing
 - Data are pushed to stack before calling the subroutine.

Call by Reference vs. Call by Value

Call by value: The values of parameters are transferred to the subroutine.

Call by reference: The addresses of the parameters are transferred to the subroutine.

Values of the parameters were transferred to subroutine in Example 2

If the address of a parameter is passed to the subroutine, the contents of this memory location (original value of the parameter) can be modified by the subroutine.



Example-3 (Call-by-reference)

We write the previous example again. This time the address of the number is sent to the subroutine using the IX register. The subroutine writes the result over original value.

START	LDA LDA STA LDA	A,<\$1000>
	STA	A,<\$100A>
	LDA	
	BSR	, ,
		A,<\$1000>
		IX,\$1000
	BSR	ABSVAL
END	SWI	
ABSVAL	PSH	A
	LDA	A, <ix+0></ix+0>
	TST	A,\$80
	BEQ	FNSHD
	NEG	A
	STA	A, <ix+0></ix+0>
FNSHD	POP	A
	RTS	

Call by reference using index register

The role of the stack in subroutine calls

Stack saves the return address for the PC

- Stack can be used for parameter passing
 - The main program writes parameters (value or address) into stack (push) and the subroutine reads these parameters from stack (pull). The stack is a shared memory. The value of SP is known by main and the subroutine.
- Stack can be used to store the register values
- Stack can be used to allocate local variables for the subroutine



Example-4 (Use of stack)

A subroutine to add two numbers. Parameters are passed via stack, using call-by-value technique. Return value is in AccA.

START	LDA	SP,\$FFFF	Al	DDTN	LDA	A, <sp+4></sp+4>
	LDA	A,\$A9			ADD	A, <sp+3></sp+3>
	STA	A,<\$1000>				
	PSH	A				
	LDA	A,\$75				
	STA	A,<\$1005>				
	PSH	A			1	SP→\$FFFB
	BSR	ADDTN —	—			
				ADR-H		
				ADR-L		
				Num-2		
				Num-1	\$FFFF	



Example-4 (Use of stack)

A subroutine to add two numbers. Parameters are passed via stack, using call-by-value technique. Return value is in AccA.

START	LDA LDA STA PSH LDA STA	SP, \$FFFF A, \$A9 A, <\$1000> A A, \$75 A, <\$1005>	Al	DDTN	LDA ADD RTS	A, <sp+4>A,<sp+3></sp+3></sp+4>
	PSH BSR	A ADDTN				
	STA	A,<\$100A>	→	ADR-H		
				ADR-L	←	SP -> \$FFFD
				Num-2		
				Num-1	\$FFFF	




Example-4 (Use of stack)

A subroutine to add two numbers. Parameters are passed via stack, using call-by-value technique. Return value is in AccA.

START	LDA	SP,\$FFFF	ADDTN	LDA	A, <sp+4></sp+4>
	LDA	A,\$A9		ADD	A, <sp+3></sp+3>
	STA	A,<\$1000>		RTS	
	PSH	A			
	LDA	A,\$75			
	STA	A,<\$1005>			
	PSH	A		7	
	BSR	ADDTN		4	
	STA	A,<\$100A>	ADR-H	_	
	POP	A	ADR-L		
	POP	A	Num-2	1	
END	SWI		Num-1	\$FFFF	SP

The addresses of two numbers to be added and the addresses of the result are transferred to the subroutine. In the subroutine (SUMCLR) two numbers are added, these numbers are cleared and the result is put in the destination location.




SUMCLR	PSH	A				_
	PSH	В		→ \$FFF5		0
	T	IX,SP		1	В	1
	CLR	В			Α	2
	LDA	CD, <ix+09></ix+09>	*Num1 address*		^	-
	LDA	A, <cd></cd>	*ACCA <- Num1*		ADR-H	3
	STA	B, <cd></cd>	*Clear Num1*		ADR-L	4
	LDA	CD, <ix+07></ix+07>	*Num2 address*		10	5
	ADD	A, <cd></cd>	*ACCA <- Num1+Num2*		04	6
	STA	B, <cd></cd>	*Clear Num2 *		0A	0
	LDA	CD, <ix+05></ix+05>	*Sum address*		10	7
	STA	A, <cd></cd>	*Sum stored*		05	8
	POP	В			10	9
	POP	A			00	A
	RTS			\$FFFF	00	

Local Variables

 Local variables are kept in stack by the subroutine. The subroutine must allocate and deallocate necessary memory space for local variables.

Example: Swap the high and low bytes of a 16-bit number stored in memory.

```
void swap(short int *number)
{
  char temp;
  temp = *number;
  *number = *(number + 1);
  *(number + 1) = temp;
}
```



START

LDA SP, \$FFFF
LDA IX, \$1000
T AB, IX
PSH B
PSH A
LDA A, \$44
BSR SWAP

SWAP	PSH	A	
	DEC	SP	*place for local variable *
IX ←FFF9	T	IX,SP	
CD ← 1000	LDA	CD, <ix+05></ix+05>	*address for high byte*
A ← 15	LDA	A, <cd></cd>	*ACCA <- High byte*

15 1000 {
08 1001

void swap(short int *number)
{
 char temp;

START

LDA SP, \$FFFF
LDA IX, \$1000
T AB, IX
PSH B
PSH A
LDA A, \$44
BSR SWAP

SWAP	PSH	A	
	DEC	SP	*place for local variable *
IX ←FFF9	T	IX,SP	
CD ← 1000	LDA	CD, <ix+05></ix+05>	*address for high byte*
A ← 15	LDA	A, <cd></cd>	*ACCA <- High byte*
	STA	A, <ix+1></ix+1>	*temp <- High byte *
CD ← 1001	INC	CD	*address for low byte*
A← 08	LDA	A, <cd></cd>	*ACCA <- Low byte*
$CD \leftarrow 1000$	DEC	CD	

```
15 1
A 2
ADR-H 3
ADR-L 4
10 5
00 6
```

START

LDA SP, \$FFFF
LDA IX, \$1000
T AB, IX
PSH B
PSH A
LDA A, \$44
BSR SWAP

	0
15	1
А	2
ADR-H	3
ADR-L	4
10	5
00	6

```
SWAP
           PSH
                 Α
          DEC
                              *place for local variable *
                 SP
                 IX,SP
IX ←FFF9
          LDA
                 CD, <IX+05> *address for high byte*
CD \leftarrow 1000
          LDA
                 A,<CD>
                              *ACCA <- High byte*
A← 15
           STA
                 A,<IX+1>
                              *temp <- High byte *
CD \leftarrow 1001
          INC
                 CD
                              *address for low byte*
A← 08
          LDA
                 A,<CD>
                              *ACCA <- Low byte*
CD \leftarrow 1000 DEC
                 CD
           STA
                 A,<CD>
                              *swap*
A← 15
          LDA
                 A,<IX+1>
                              *ACCA <- temp*
CD \leftarrow 1001 INC
                 CD
```

START	LDA	SP,\$FFFE
	LDA	IX,\$1000
	T	AB,IX
	PSH	В
	PSH	A
	LDA	A,\$44
	BSR	SWAP
	POP	A
	POP	В
END	SWI	

	0
15	1
А	2
ADR-H	3
ADR-L	4
10	5
00	6

```
SWAP
          PSH
                 Α
                             *place for local variable *
          DEC
                 SP
IX ←FFF9
                 IX,SP
          LDA
                 CD, <IX+05> *address for high byte*
CD \leftarrow 1000
          LDA
                              *ACCA <- High byte*
A← 15
                 A, <CD>
          STA
                              *temp <- High byte *
                 A,<IX+1>
CD \leftarrow 1001
                              *address for low byte*
          INC
                 CD
A← 08
          LDA
                 A,<CD>
                              *ACCA <- Low byte*
CD \leftarrow 1000 DEC
                 CD
          STA
                 A,<CD>
                              *swap*
A← 15
          LDA
                 A,<IX+1>
                              *ACCA <- temp*
CD \leftarrow 1001 INC
                 CD
          STA
                              *high byte to <$1001>*
                 A,<CD>
          INC
                             *deallocate temp*
                 SP
          POP
                 Α
          RTS
                       void swap(short int *number)
 80
           1000
                             char temp;
  15
           1001
                             temp = *number;
                             *number = *(number + 1);
                             *(number + 1) = temp;
```

}

Attention!!

- In PUSH and POP instructions, the variables should be in reverse order (LIFO)
- # of PUSH instructions should be equal to the # of POP instructions
 - Otherwise wrong return address is retrieved from stack by RTS instruction. So program gives error.
- It is not recommended to have PUSH and POP within loops
- Return from subroutine with RTS instruction

Topics


- Stack
- Subroutine
- Interrupt

Interrupt

- Interrupt can be considered to be an emergency signal.
 - The Microprocessor should respond to it as soon as possible.
 - When the Microprocessor receives an interrupt signal, it suspends the currently executing program (after executing its current instruction) and jumps to an **Interrupt Service Routine (ISR)** to respond to the incoming interrupt.
 - Each interrupt will most probably have its own ISR.

Interrupt

- Non-maskable interrupt: CPU responses the interrupt
- Maskable interrupt:
 CPU responses the interrupt based on the interrupt bit of status register.
 - I=1: Blocking the interrupt
 - I=0: CPU responds to interrupt request
- Reset: Brings the computer into the startup state.
- Priorities: Reset>NMI>MI



Interrupt

- Responding to an interrupt may be immediate or delayed depending on whether the interrupt is maskable or non-maskable and whether interrupts are being masked or not.
- There are two ways of redirecting the execution to the ISR depending on whether the interrupt is non-vectored or vectored.

If user has to provide address of subroutine using CALL instruction then it is known as non-vectored interrupt.



Interrupt Vector

Vectored interrupt:

- The vector is already known to the Microprocessor
- 2. The device will have to supply the vector to the Microprocessor
- An interrupt vector is a pointer to where the ISR is stored in memory.
- Interrupt Vector Table: A table of interrupt vectors

Maskable Interrupt Routine	\$0020
Non-maskable Interrupt Routine	\$0010
Reset routine	i e
TRESCE TOUGHTE	\$0000

Option 1

Reset	(H)	\$FFFF
Routine	(L)	\$FFFE
Non-maskable	(H)	\$FFFD
Interrupt Routine	(L)	\$FFFC
Software	(H)	\$FFFB
Routine	(L)	\$FFFA
Maskable	(H)	\$FFF9
Interrupt Routine	(L)	\$FFF8


Option 2



Interrupt in Educational CPU


- When a hardware NMI or IRQ is received:
 - Need to understand where the interrupt is coming from using the following methods
 - Polling: Check the PIA and ACIA status bits. Polling order determines the interrupt priority.
 - Interrupt Controller Chip: Configures interrupt priorities and indicates interrupt source
 - Execute the interrupt routine associated with the interrupt source

Polling



- The interrupt line is lowered if there is an interrupt.
- CPU reads status registers of I/Os to determine which interrupt service routine will be executed

Interrupt Controller



- When I/O interrupt occurs, interrupt controller sends interrupt to CPU
- CPU reads the register or interrupt controller to determine which interrupt routine will be executed

Branching to ISR

- Interrupt service routines are like subroutines.
- When the CPU accesses the ISR, it pushes the current value of the program counter (PC) onto stack
- Upon return from the interrupt, the CPU should continue with where it left from with the same register contents
- The interrupt routine returns to the main program with the RTI (Return from Interrupt) instruction

I/O Interrupt Processing

