## 480 半導體元件物理與製程——理論與實務

深寬比值 (aspect ratio) 253

理想二極體方程式 (ideal diode equation) 53, 56, 60

理想因子 (ideality factor) 60

移動率 (mobility) 14-15, 132, 136, 149, 238, 258-259, 265, 267-271

移動離子電荷 (mobile ionic charge) 99, 102, 104

被動元件 (passive device) 330, 334, 336, 338, 341, 432-433, 453, 463-464

袋狀植入 (pocket implant) 243-244

袋植入工程(halo engineering) 243

設計參數 (design parameter) 139

設計邊界 (margin) 459

貫穿 (punch-through) 159, 166, 173-179, 188-189, 423, 427

貫穿電壓 (punch-through voltage) 175-176, 178-179, 427

軟烤 (soft bake) 190-191

通引 (contact) 207, 209, 253-254, 433, 435, 438-439, 441-442, 462, 468

通孔優先 (via first) 253-254

通道(channel) 71, 82, 95, 122-128, 130-134, 136, 138-140, 143, 148-150, 152-153, 158-175, 177, 179, 188-189, 223, 225, 228-231, 233, 236-241, 243-246, 248, 255, 258-259, 261-262, 264, 267-269, 273, 275, 277, 279, 283, 291, 293, 295, 321, 325, 331-332, 340, 343, 353, 364, 367, 371, 373, 376, 394, 415, 421-423, 425-427, 437, 442, 446, 461-462, 468

通道工程 (channel engineering) 228, 230, 255

通道長度調變 (channel length modulation) 123-124, 130-131, 134, 136, 139-140, 152, 158-162, 165-167, 170, 172-173, 175, 177, 179, 189, 231-232, 240, 243, 258-259, 262, 275, 293, 295, 321, 325, 331, 376, 425-426, 446, 461, 468

通道效應(channeling effect) 122, 158, 169, 171, 173, 179, 189, 223, 230-232, 237-239, 241, 243, 246, 262, 264, 367, 423, 461

通道電導 (channel conductance) 138-139

連續方程式 (continuity equation) 19-23, 47, 49

速度飽和 (velocity saturation) 149, 158-159, 162, 164-165, 417

閉鎖 (latch-up) 159, 227-228

雪崩崩潰 (avalanche breakdown) 61-63, 65, 67-68

鳥嘴 (birds beak ) 196, 225

## 十二劃

最終保護層 (passivation layer) 215

場元件 (field device) 147

場氧化層 (field oxide) 147, 149, 225, 227, 348, 368, 375, 431