

IL COX/PW: Poly over diffusion, Without S/D injection ILCOX NWIDE: diff over poly,

With S/D injetion Poly Edge intensive IIL_COX/PE:

IL COX/PW PE: Poly Edge intensive Diff Edge intensive

圖 13-26 不同狀況下的氧化層測試鍵結構示意圖。

Oxide Leakage:

Measure IG with $V_G = 0 \sim -15V$ (P-sub), $V_B = 0V$ (Accumulation)

Oxide Breakdown Voltage:

Search BVG_{OX} = V_G , when $I_G = -1\mu A$




圖 13-27 典型氧化層漏電流與崩潰電壓測試結果。