

圖 13-23 Kelvin 結構接觸窗電阻與接觸窗電阻鏈測試鍵示意圖。

Measure ID with VD = 1V, VS = 0VEx.

$$R_{M} = \frac{V_{F}}{I_{M}} = 88 * R_{CVLA2} + 44 * R_{SM2} + 44 * R_{SM3}$$

$$R_{CVLA2} = (R_{M} - 44 * R_{SM2} - 44 * R_{SM3})/88$$

Kevin Contact Resistance:

$$\begin{aligned} &\text{Measure ID with VD=1V, VS=0V} \\ &R_{C_Kevin} = \frac{\Delta V}{I_F} = \frac{(V_{HIGH} - V_{LOW})}{I_F} \end{aligned}$$