BHT 412-MMS-SAR

Bell MODEL 412

MAINTENANCE MANUAL SUPPLEMENT FOR

SEARCH AND RESCUE CONFIGURATION

(412-570-002)

NOTICE

PURPOSE To provide information and instructions for maintenance of systems/components used in Search and Rescue configured helicopters.

Bell Helicopter TEXTRON
A Subsidiary of Textron Inc.

POST OFFICE BOX 482 • FORT WORTH, TEXAS 76101

BHT 412-MMS-SAR

Bell MODEL 412

MAINTENANCE MANUAL SUPPLEMENT FOR

SEARCH AND RESCUE CONFIGURATION

(412-570-002)

NOTICE

PURPOSE To provide information and instructions for maintenance of systems/components used in Search and Rescue configured helicopters.

COPYRIGHT NOTICE
COPYRIGHT 1993
BELL ® HELICOPTER INC.
AND BELL HELICOPTER TEXTRON.
A DIVISION OF TEXTRON CANADA LTD.
ALL RIGHTS RESERVED

Bell Helicopter TEXTRON
A Subsidiary of Textron Inc.

POST OFFICE BOX 482 • FORT WORTH, TEXAS 76101

1 MARCH 1993

PROPRIETARY RIGHTS NOTICE

These data are proprietary to Bell Helicopter Textron, Inc. Disclosure, reproduction, or use of these data for any purpose other than helicopter operation and/or maintenance is forbidden without prior written authorization from Bell Helicopter Textron, Inc.

Additional copies of this publication may be obtained by contacting:
Commercial Publication Distribution Center
Bell Helicopter Textron
P. O. Box 482
Fort Worth, Texas 76101-0482

LIST OF EFFECTIVE PAGES

On a revised page the portion of the text and illustration affected by the latest revision is indicated by a vertical line.

Basic ..... 0 ..... 1 MARCH 1993

Page No.	Rev. No.
Title	0
A — B	0
i/ii	0
CHAPTER 1	
1/2	0
3 — 6	0
CHAPTER 21	
1/2	0
3 — 6	0
7/8	0
CHAPTER 53	
1/2	0
3 — 4	0
5/6	0
CHAPTER 67	
1 — 2	0
3/4	0
5 — 22	0
23/24	0
25 — 36	0
37/38	0
39 — 50	0
51/52	0
53 — 62	0
CHAPTER 95	
1 — 20	0
CHAPTER 96	
1 — 2	0
3/4	0
5/6	0
7 — 8	0
9/10	0
11/12	0
13 — 18	0
19/20	0
21/22	0
23/24	0
25 — 38	0
39/40	0
41/42	0
43 — 52	0
CHAPTER 97	
1 — 2	0
3/4	0
5 — 14	0
15/16	0
17 — 20	0
21/22	0
23 — 42	0
43/44	0
45/46	0
47/48	0
49/50	0
51/52	0
53/54	0
55/56	0
57/58	0
59/60	0
61/62	0
CHAPTER 98	
1/2	0
3 — 4	0
5/6	0
7/8	0
9/10	0
11/12	0
13/14	0

LIST OF EFFECTIVE PAGES

Page No.	Rev. No.	Page No.	Rev. No.
15/16	0	39/40	0
17/18	0	41/42	0
19/20	0	43/44	0
21/22	0	45/46	0
23/24	0	47/48	0
25/26	0	49/50	0
27/28	0	51/52	0
29/30	0	53/54	0
31/32	0	55/56	0
33/34	0	57/58	0
35/36	0	59 — 116	0
37/38	0	117/118	0

HELP

EVALUATE

LOGISTICS

PUBLICATIONS

Have you found something wrong with this manual — an error, an inconsistency, unclear instructions, etc? Although we strive for accuracy and clarity, we may make errors on occasion. If we do and you discover it, we would appreciate your telling us about it so that we can change whatever is incorrect or unclear. Please be as specific as possible.

Your complaint or suggestion will be acknowledged and we will tell you what we intend to do.

You may use the enclosed Customer Feedback form, as applicable, to inform us where we have erred.

Your assistance is sincerely appreciated.

CUSTOMER FEEDBACK

MANUAL TITLE: _____

MANUAL NUMBER (If Assigned): _____

DATE OF ISSUE: _____

DATE OF LAST REVISION: _____

SECTION, CHAPTER, PARAGRAPH AFFECTED: _____

WHAT IS THE COMPLAINT? _____

_____

_____

_____

NOW READS: _____

_____

_____

_____

SHOULD READ: _____

_____

_____

_____

_____

Your Name _____ **Address** _____

Position _____ **Telephone** _____

Company _____

Reference No. (Your Initials & Date) _____

(Fold in thirds, with address exposed, tape and mail.)

TAPE HERE

From _____

_____

_____

PLACE
POSTAGE
HERE

Bell Helicopter TEXTRON

PRODUCT SUPPORT DIVISION
12,800 RUE DE L'AVENIR
ST. JANVIER, QUEBEC
CANADA JON 1LO

FOLD ON DOTTED LINES AND TAPE.

TAPE HERE

LIST OF CHAPTERS

Chapter	Description	Page
1	Introduction	1-1
21	Air Distribution (Ventilation)	21-1
53	Fuselage	53-1
67	Flight Controls — Digital AFCS (SAR)	67-1
95	Instrument System	95-1
96	Electrical System	96-1
97	Avionics	97-1
98	Wiring Diagrams	98-1