Floors (Mod 6/2027) (Mod S.O.O. 6244) (Mod S.O.O. 6398) – General Data

1. General

The floors consist of nine panels in the cabin compartment, skin panels and a plywood center panel in the flight compartment, and skin panels in the rear baggage/equipment compartment. The coin matting covers the flight compartment and cabin floor.

A. Cabin Floor

The cabin floor panels are each constructed from sandwich panels with upper and lower aluminum facing sheets with an aluminum honeycomb core. Panel edges are sealed with an epoxy-based potting compound. The panels are supported by transverse beams. The top surface of the panels is coated with light olive urethane resin to form a non-skid surface. Transverse joints of the floor panels are secured by stud rails and straps, and longitudinal joints by seat rail and track assemblies.

B. Flight Compartment Floor

The flight compartment floor consists of aluminum alloy skin panels riveted to the floor support structure, and a plywood center panel which is sealed and coated with Interpon epoxy paint.

C. Coin Mat

The coin mat provides a vinyl, nonslip, skid resistant floor covering for the flight compartment and cabin floor panels.

2. Removal/Installation

A. Remove Cabin Floor Panels

1) Remove passenger seats and coin mats as per Para 2.C. Remove panel assemblies around bulkhead at station 110.00 for access to bulkhead assembly. Remove screws and temporarily move bulkhead assembly to gain access for removal of screws attaching right and left-hand seat rail and track assemblies at station 110.00.

2) Remove screws attaching right and left-hand seat rails to floor support structure aft of station 262.00.

3) Lift right and left-hand seat rails complete with aft floor panels sufficiently to disengage center floor panel from seat rails.

Note When lifting seat rails and floor panels, wedge right and left-hand floor panels, if necessary.

4) Remove seat rails and right and left-hand floor panels.

5) Remove screws attaching right and left-hand seat rail and track assemblies to floor support structure forward of station 262.00.

6) Lift seat rails complete with floor panels, wedge right and left-hand floor panels, if necessary, and disengage and remove two center panels from seat rails.

7) Remove seat rails and two right and left-hand floor panels.

B. Install Cabin Floor Panels

1) Check cork packing and sponge rubber strips on floor support structure for condition and adhesion.

2) Position right-hand, center and left-hand stud rails at station 180.75. Assemble two right-hand panels and seat rail and track assembly, and position under angle on right side aircraft structure. Assemble two left-hand panels and seat and track assembly and position under angle on left side aircraft structure.

3) Lift seat rails and floor panels, wedge floor panels if necessary, and engage two center panels in seat rails. Push seat rails and panels downward into position.

4) Install screws securing seat rail and track assemblies to floor support structure.

5) Position right-hand, center and left-hand stud rails at station 262.00. Position right-hand aft floor panel under angle and step plate on right side aircraft structure and install seat rail. Position left-hand aft floor panel under angle and step plate on left side aircraft structure and install seat rail.

6) Lift seat rails and floor panels, wedge floor panels if necessary, and engage center panel in seat rail. Push seat rails and floor panels downward into position.

7) Install screws securing seat rails to floor support structure.

8) Position bulkhead assembly at station 110.00 and install screws. Install coin mats as per Para 2.D and passenger seats.

C. Coin Mat Removal

1) Remove screws and hot air duct fairing assemblies at station 110.0 and station 239.92 left and right side of aircraft.

2) Remove screws and left, center, right straps from stud rails and transverse joints at station 180.75 and 262.0. Remove screws and strap from transverse joint at station 110.0 (cabin to cockpit doorway).

3) Remove screws and step plates at airstair door and emergency exit door.

4) Remove sealant around seat tracks and coin mat track cut outs.

5) Roll cabin coin mat either aft to fwd or fwd to aft.

6) Remove cabin and cockpit coin mats from aircraft.

7) Remove tape from cabin floor and clean any residue.

8) Clean any tape residue from bottom of coin mat with mild methanol solution or Loncare cleaning solution (S.O.O. 6244) or with mild isopropyl solution (S.O.O. 6398).

D. Coin Mat Installation

1) Apply carpet tape to cabin floor, inset from perimeter. Ensure a non-permanent tape is used. Ensure taped area is clean and grease free.

2) Position respective coin mat in cockpit and cabin.

3) Do not remove release liner from tape. Unroll cabin mat ensuring positioning correct along bulkheads and seat rail cutouts, place cockpit mat in cockpit.

4) Once correct cabin coin mat positioning has been confirmed roll coin mat aft to fwd. Remove release liner from tape and unroll cabin mat.

5) Install screws and step plates at airstair door and emergency exit door.

6) Install left, center, right straps and screws to stud rails and transverse joints at station 110.0, 180.75, and 262.0.

7) Install screws and hot air duct fairing assemblies at station 110.0 and 239.92 on left and right sides of aircraft.

3) Lift seat rails and floor panels, wedge floor panels if necessary, and engage two center panels in seat rails. Push seat rails and panels downward into position.

4) Install screws securing seat rail and track assemblies to floor support structure.

5) Position right-hand, center and left-hand stud rails at station 262.00. Position right-hand aft floor panel under angle and step plate on right side aircraft structure and install seat rail. Position left-hand aft floor panel under angle and step plate on left side aircraft structure and install seat rail.

6) Lift seat rails and floor panels, wedge floor panels if necessary, and engage center panel in seat rail. Push seat rails and floor panels downward into position.

7) Install screws securing seat rails to floor support structure.

8) Position bulkhead assembly at station 110.00 and install screws. Install coin mats as per Para 2.D and passenger seats.

C. Coin Mat Removal

1) Remove screws and hot air duct fairing assemblies at station 110.0 and station 239.92 left and right side of aircraft.

2) Remove screws and left, center, right straps from stud rails and transverse joints at station 180.75 and 262.0. Remove screws and strap from transverse joint at station 110.0 (cabin to cockpit doorway).

3) Remove screws and step plates at airstair door and emergency exit door.

4) Remove sealant around seat tracks and coin mat track cut outs.

5) Roll cabin coin mat either aft to fwd or fwd to aft.

6) Remove cabin and cockpit coin mats from aircraft.

7) Remove tape from cabin floor and clean any residue.

8) Clean any tape residue from bottom of coin mat with mild methanol solution or Loncare cleaning solution (S.O.O. 6244) or with mild isopropyl solution (S.O.O. 6398).

D. Coin Mat Installation

1) Apply OT–40N tape to cabin floor, inset from perimeter, gray side down, black side up. Ensure taped area is clean and grease free.

2) Position respective coin mat in cockpit and cabin.

3) Do not remove release liner from tape. Unroll cabin mat ensuring positioning correct along bulkheads and seat rail cutouts, place cockpit mat in cockpit.

4) Once correct cabin coin mat positioning has been confirmed roll coin mat aft to fwd. Remove release liner from tape and unroll cabin mat.

5) Install screws and step plates at airstair door and emergency exit door.

6) Install left, center, right straps and screws to stud rails and transverse joints at station 110.0, 180.75, and 262.0.

7) Install screws and hot air duct fairing assemblies at station 110.0 and 239.92 on left and right sides of aircraft.

DE HAVILLAND AIRCRAFT OF CANADA LIMITED

TEMPORARY REVISION

PSM: 1-64-2 **AIRCRAFT: DHC-6** **SERIES: 400**

PUBLICATION: MAINTENANCE MANUAL **TEMP. REVISION NO.: TR53-5**

Insert in 53-20-00 facing Chapter 54

FLOORS (MOD 6/2027) (MOD S.O.O. 6244) (MOD S.O.O. 6398) - GENERAL DATA

REASON FOR ISSUE:

To clarify tape application of the Coin Mat Installation.

ACTION:

In Chapter 53, Section 53-20-00, ignore existing Page 2 and insert new page as shown on Page 2 of this Temporary Revision.

-Continued overleaf-

RECORDING INSTRUCTIONS:

Record this TEMPORARY REVISION NO. and the relevant information in the appropriate columns of the TEMPORARY REVISION INDEX provided at the front of the manual.