Propeller De-icing without Pitch Latches (S.O.O. 6202) – General Data

1. General

Propeller de-icing system components installed on the propeller are; an electrically heated de-icing boot fitted to each blade, and a slip ring assembly. Each blade boot contains an inner and outer heater element which is connected electrically to the slip ring assembly mounted behind the spinner back plate on the propeller hub. An engine mounted brush block assembly makes contact with the slip ring to provide electrical power to the blade elements. The propeller de-icing system is fully described in Hartzell Propeller Ice Protection System Manual, manual # 180 (30–61–80).

This Page Intentionally Left Blank