Fireseals – General Data

1. General

Two fireseals are fitted to the engine, one fitted forward and the other fitted to the rear of the engine compressor intake. Each fireseal is made of two semicircular sections, which are bolted to the engine fireseal flange and to each other to form a complete fireseal between engine and cowlings. The fireseals also provide location and support for all lines, controls and ducts which pass from one engine fire zone to another.

This Page Intentionally Left Blank