Exit Duct Door – Maintenance Practices

1. Adjustment/Test

   A. Rig Exit Duct Door

      1) Ensure intake deflector is in fully retracted position.

      2) Push exit duct door to closed position and hold.

      3) Thread cable through hole in bolt at exit duct door quadrant on each side.

      4) Tension cables and tighten nuts.

This Page Intentionally Left Blank