
Oil Pressure Indicating System – General Data

1. General

The oil pressure indicating system for each engine consists of a pressure transducer and a low pressure switch. The oil pressure transducer is threaded into the appropriate engine port, with the wiring connected through the DAU to APEX (refer to Figure 1). The DAU does the required logic to trigger the oil pressure warning and caution messages related to engine oil pressure limits. Excitation power of 28 Volt DC for the oil pressure transducers is provided through the OIL PRESSURE L and OIL PRESSURE R circuit breakers on the main circuit breaker panel (refer to 24-30-00, DC Generation – General Data). Oil pressure is valid over the range of 0 – 200 psi.



Oil System
Figure 1