91-04-00

DISCONNECT BRACKET LIST

91-04-00
DISCONNECT BRACKET LIST

Section	Page	Date
EFFECTIVE PAGES		
	1	Nov 14/2025
	2	BLANK
AB0200	1	May 15/2024
AB0300	1	May 15/2024
	2	May 15/2024
AB0400	1	Dec 24/2024
AB0500	1	May 15/2024
AB0700	1	May 15/2024
AB0800	1	May 15/2024
AB1000	1	May 15/2024
AB1100	1	May 15/2024
AC0500	1	May 15/2024
AD0500	1	May 15/2024
AE0100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
AE0200	1	May 15/2024
	2	May 15/2024
AE0300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
AE0300 (cont)		
	4	May 15/2024
	5	May 15/2024
AE0400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
AE0500	1	May 15/2024
AE0600	1	May 15/2024
	2	May 15/2024
AE1100	1	May 15/2024
AF0200	1	May 15/2024
AJ0000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
AL0600	1	May 15/2024
AL0700	1	May 15/2024
AP0600	1	May 15/2024
	2	May 15/2024
AP0700	1	May 15/2024
AP0900	1	May 15/2024
AP1800	1	May 15/2024
AP2800	1	May 15/2024
AS0000	1	May 15/2024
	2	May 15/2024
AW0200	1	May 15/2024
	2	May 15/2024
AW0700	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0237A	**DISCONNECT BRACKET**					**003**	**237/201/L004**	**ALL**
	01	D11160	W5162					ALL
	02	D11158	W5172					ALL
AB0237B	**DISCONNECT BRACKET**					**003**	**241/203/L005**	**ALL**
	01	D11164	W6162					ALL
	02	D11162	W6172					ALL
AB0250A	**DISCONNECT BRACKET-**					**006**	**250/195/L002**	**ALL**
	01	D11134	W5160					ALL
	02	D11132	W6162					ALL
	03	D10169	W6506					ALL
	04	D11130	W5506					ALL
	05	D11128	W5510					ALL
	06	D10167	W5506					ALL
AB0288	**DISCONNECT BRACKET**					**005**	**288/289/0**	**ALL**
	01	D00570	W4256					ALL
	02	D01128	W6242					ALL
	03	D04889J	W3419	D04889P	W2589			ALL
	04	D37001J	W3701	D37001P	W3801			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0310	**DISCONNECT BRACKET**					**004**	**298.8/177/R029**	**ALL**
	1	D04603J	W5363	D04603P	W0121			ALL
	2	D41215J	W5183	D41215P	W0121			ALL
AB0340A	**DISCONNECT BRACKET-LEFT**					**009**	**340/295/L006**	**ALL**
	01	D40054J	W3058	D40054P	W5142			ALL
	02	D40216J	W3158	D40216P	W3144			ALL
	03	D40196J	W3142	D40196P	W2114			ALL
	04	D40170J	W3058	D40170P	W2218			ALL
	05	D40050J	W3058	D40050P	W6242			ALL
	06	D40108J	W3158	D40108P	W3150			ALL
	09	D40102J	W3158	D40102P	W5142			ALL
AB0340B	**DISCONNECT BRACKET-RIGHT**					**009**	**340/295/R006**	**ALL**
	01	D40096J	W4142	D40096P	W3142			ALL
	03	D41838J	W6288	D41838P	W2114			ALL
	04	D40084J	W4258	D40084P	W4250			ALL
	06	D40292J	W4142	D40292P	W5160			ALL
	07	D40296J	W4142	D40296P	W2114			ALL
	09	D40202J	W4258	D40202P	W6242			ALL
AB0358	**DISCONNECT BRACKET**					**009**	**358/296/L003**	**ALL**
	02	D40351J	W3701	D40351P	W3805			ALL
	07	D40357J	W3709	D40357P	W3805			ALL
	08	D40365J	W3710	D40365P	W3805			ALL
	09	D40349J	W3144	D40349P	W3805			ALL
AB0366	**DISCONNECT BRACKET**					**000**	**360/290/L032**	**ALL**
	01	D12897J	W3477					ALL
	02	D45449J	W3477					ALL
	03	D40011J	W3477					ALL
AB0369L	**DISCONNECT BRACKET**					**000**	**369/280/L047**	**ALL**
AB0370R	**DISCONNECT BRACKET**					**000**	**370/280/R045**	**ALL**
	05	D47021J	W3477					ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0372	**DISCONNECT BRACKET-TEST RECEPTACLES**					**003**	**372/184/R050**	**ALL**
		D10175	W5111					ALL
		D11804	W5111					ALL
AB0373	**DISCONNECT BRACKET**					**003**	**373/296/L013**	**ALL**
	01	D12899J	W3477					ALL
	02	D12804J	W3477					ALL
	04	D45485J	W3477					ALL
	05	D12883J	W3477					ALL
	06	D12885J	W3477					ALL
	07	D12889J	W3477					ALL
	08	D12891J	W3477					ALL
	09	D12893J	W3477					ALL
	10	D12657J	W3755					ALL
AB0374L	**DISCONNECT BRACKET**					**000**	**374/280/L047**	**ALL**
AB0376R	**DISCONNECT BRACKET**					**000**	**376/280/R047**	**ALL**
AB0387	**DISCONNECT BRACKET-UPR TCAS ANT**					**004**	**387/298/R010**	**ALL**
	01	D04625J	W4009	D04625P	W4001			ALL
	02	D04627J	W4009	D04627P	W4001			ALL
	03	D04629J	W4009	D04629P	W4001			ALL
	04	D04633J	W4009	D04633P	W4001			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0405B	**DISCONNECT BRACKET**					**002**	**410/288/R040**	**ALL**
	01	D40728J	W6170	D40728P	W4170			ALL
	02	D40730J	W6172	D40730P	W4170			ALL
AB0410	**DISCONNECT BRACKET**					**006**	**410/205/R039**	**ALL**
	01	D40306J	W6588	D40306P	W6210			ALL
	03	D40078J	W6208	D40078P	W6222			ALL
	05	D40441J	W6420	D40441P	W6528			ALL
	08	D40093J	W6586	D40093P	W2218			ALL
	10	D40059J	W5431	D40059P	W3329			ALL
	11	D40079J	W5248	D40079P	W5160			ALL
	13	D40442J	W5112	D40442P	W5568			ALL
	15	D40439J	W6208	D40439P	W6412			ALL
	16	D40375J	W6134	D40375P	W5160			ALL
	17	D40314J	W6732	D40314P	W5156			ALL
	18	D40036J	W5530	D40036P	W5156			ALL
	19	D40211J	W6214	D40211P	W5156			ALL
	20	D40377J	W6230	D40377P	W6412			ALL
AB0420A	**DISCONNECT BRACKET**					**002**	**424/293/L033**	**ALL**
	01	D40734J	W5170	D40734P	W3170			ALL
	02	D40736J	W5172	D40736P	W3170			ALL
AB0488	**DISCONNECT BRACKET - ANTENNA (SB46-1068)**					**000**	**488/304/R09**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0500DL	**DISCONNECT BRACKET-LEFT WING**					**010**	**500I/201/L040**	**ALL**
	01	D41854J	W5568	D41854P	W1128			ALL
	02	D05348J	W5568	D05348P	W1128			ALL
	03	D05346J	W5568	D05346P	W1134			ALL
	04	D40318J	W5530	D40318P	W5222			ALL
	05	D40500J	W5248	D40500P	W6248			ALL
	07	D40312J	W5134	D40312P	W5224			ALL
	09	D40302J	W5526	D40302P	W5222			ALL
	11	D05352J	W5568	D05352P	W1380			ALL
	12	D46606J	W5094	D46606P	W5098			ALL
AB0500DR	**DISCONNECT BRACKET-RIGHT WING**					**010**	**500I/201/R061**	**ALL**
	01	D40406J	W6528	D40406P	W6228			ALL
	02	D40410J	W6528	D40410P	W6122			ALL
	03	D40400J	W6530	D40400P	W6122			ALL
	05	D40404J	W6034	D40404P	W6124			ALL
	06	D40402J	W6032	D40402P	W6124			ALL
	07	D41850J	W6588	D41850P	W1126			ALL
	08	D40416J	W6032	D40416P	W5224			ALL
	09	D05354J	W6588	D05354P	W1382			ALL
	10	D05342J	W6588	D05342P	W1136			ALL
	11	D05350J	W6588	D05350P	W1126			ALL
AB0501DL	**DISCONNECT BRACKET-LEFT WING**					**006**	**500D+7/180/L058**	**ALL**
AB0501DR	**DISCONNECT BRACKET-RIGHT WING**					**006**	**500D+7/180/R058**	**ALL**
AB0536L	**DISCONNECT BRACKET-LEFT AC BAY**					**002**	**541/159/L025**	**ALL**
	01	D04580J	W5102	D04580P	W5526			ALL
	02	D40056J	W5102	D40056P	W5104			ALL
AB0536R	**DISCONNECT BRACKET-RIGHT AC BAY**					**002**	**541/159/R025**	**ALL**
	01	D04582J	W6202	D04582P	W6528			ALL
	02	D40058J	W6202	D40058P	W6230			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0727L	**DISCONNECT BRACKET-AFT CARGO COMPT**					**002**	**727/193/L038**	**ALL**
	01	D42104J	W5032	D42104P	W1022			ALL
AB0727R	**DISCONNECT BRACKET-AFT CARGO COMPT**					**002**	**727/193/R045**	**ALL**
	01	D43104J	W6028	D43104P	W1032			ALL
	02	D46602J	W5124	D46602P	W6124			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB0839L	**RAIL DISCONNECT BRACKET**					**000**	**839/302/L12**	**ALL**
	09	D44719J	W3755	D44719P	W4479			ALL
	10	D47141J	W3755	D47141P	W4479			ALL
	11	D40968J	W3755	D40968P	W4477			ALL
	12	D40975J	W3755	D40975P	W4479			ALL
	13			D40979J	W4479			ALL
	14	D40981J	W3755	D40981P	W4479			ALL
	15	D41042J	W3755	D41042P	W4479			ALL
	16	D40434J	W3477	D40434P	W4479			ALL
AB0857L	**RAIL DISCONNECT BRACKET**					**000**	**857/302/L014**	**ALL**
	13	D40413J	W3477	D40413P	W4477			ALL
	15	D40415J	W3477	D40415P	W4477			ALL
	16	D40985J	W3477	D40985P	W4477			ALL
	17	D40417J	W3477	D40417P	W4477			ALL
	18	D40418J	W4477					ALL
	19	D40419J	W3477	D40419P	W4477			ALL
	20	D40420J	W3477	D40420P	W4477			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB1030A	**DISCONNECT BRACKET-AFT PRESSURE BLKHD.**					**004**	**1030/301/R012**	**ALL**
	01	D04245J	W3555	D04245P	W7061			ALL
	02	D04713J	W3559	D04713P	W7763			ALL
	03	D04227J	W3553	D04227P	W7057			ALL
	04	D04217J	W3557	D04217P	W7761			ALL
AB1030B	**DISCONNECT BRACKET-AFT PRESSURE BLKHD.**					**004**	**1030/301/0000**	**ALL**
AB1030C	**DISCONNECT BRACKET-AFT PRESSURE BLKHD.**					**004**	**1030/301/L011**	**ALL**
	01	D40192J	W6134	D40192P	W8030			ALL
	04	D04826J	W6134					ALL
AB1042L	**DISCONNECT BRACKET -SEC 48 R**					**000**	**1042/297/L008**	**ALL**
AB1050L	**DISCONNECT BRACKET-SEC 48 L**					**005**	**1050/296/L015**	**ALL**
	01	D40842J	W4134	D40842P	W6134			ALL
	02	D43393J	W3393	D43393P	W5301			ALL
	03	D43397J	W3397	D43397P	W3377			ALL
	04	D44381J	W3391	D44381P	W3381			ALL
AB1050R	**DISCONNECT BRACKET-SEC 48 R**					**006**	**1050/297/R008**	**ALL**
	01	D40790J	W4726	D40790P	W5726			ALL
	02	D40876J	W4726	D40876P	W5726			ALL
	03	D40854J	W4724	D40854P	W5726			ALL
	04	D43399J	W3399	D43399P	W3379			ALL
	05	D40836J	W4222	D40836P	W6222			ALL
AB1080	**DISCONNECT BRACKET-STA 1080**					**003**	**1080/299/0**	**ALL**
	01	D40268J	W4134	D40268P	W6136			ALL
	02	D43387J	W3397	D43387P	W3387			ALL
	03	D43389J	W3399	D43389P	W3389			ALL
AB1088	**DISCONNECT BRACKET-STA 1088**					**001**	**1088/ /**	**ALL**
	01	D10912	W4726					ALL
	02	D10436	W4724					ALL
	03	D10434	W4724					ALL
	04	D11118	W4726					ALL
	05	D40060J	W4724	D40060P	W7538			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AB1156L	**DISCONNECT BRACKET-SEC 48 L**					**001**	**1156/ /**	**ALL**
	01	D40188J	W7038	D40188P	W8030			ALL
AB1156R	**DISCONNECT BRACKET SEC 48 R**					**001**	**1156/ /**	**ALL**
	01	D40190J	W8038	D40190P	W8030			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AC0520	**DISCONNECT BRACKET**					**021**	**500I+15/180/L059**	**ALL**
				D39901	W5166			ALL
				D39903	W1188			ALL
				D39921	W5162			ALL
				D39925	W5170			ALL
				D39927	W1178			ALL
				D39929	W5168			ALL
				D39931	W1182			ALL
				D39933	W5164			ALL
				D39935	W1184			ALL
				D39937	W5568			ALL
				D39938	W1180			ALL
				D39955	W5566			ALL
				D39957	W1662			ALL
				D39963	W5562			ALL
				D39965	W1140			ALL
				D39967	W5172			ALL
				D39973	W1190			ALL
AC0538	**DISCONNECT BRACKET**					**000**	**537/199/R055**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AD0520	**DISCONNECT BRACKET**					**022**	**500D+10/194/R067**	**ALL**
				D39902	W6166			ALL
				D39904	W1288			ALL
				D39922	W6162			ALL
				D39926	W6170			ALL
				D39928	W1278			ALL
				D39930	W6168			ALL
				D39932	W1282			ALL
				D39934	W6164			ALL
				D39936	W1284			ALL
				D39939	W6588			ALL
				D39940	W1280			ALL
				D39941	W6586			ALL
				D39942	W6570			ALL
				D39943	W1664			ALL
				D39944	W1138			ALL
				D39946	W6172			ALL
				D39974	W1290			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0100A	**DISCONNECT RAIL - E1-2 & E1-4 SHELF**					**003**	**310/180/R031**	**ALL**
	01	D47901J	W3143	D47901P	W0141			ALL
	02	D47902J	W3609	D47902P	W0141			ALL
	08	D47908J	W3141	D47908P	W0121			ALL
	16	D47916J	W5039	D47916P	W0121			ALL
	19	D45919J	W0121					ALL
	20	D47920J	W3607	D47920P	W0121			ALL
	23	D47923J	W0521	D47923P	W0121			ALL
	24	D47924J	W0521	D47924P	W0121			ALL
	25	D47925J	W6491	D47925P	W0121			ALL
	26	D47926J	W6491	D47926P	W0121			ALL
	27	D47927J	W6491	D47927P	W0121			ALL
	28	D47928J	W2651	D47928P	W0121			ALL
	30	D47930J	W2205	D47930P	W0121			ALL
	32	D47932J	W5721	D47932P	W0121			ALL
	33	D47933J	W5205	D47933P	W0121			ALL
	34	D47934J	W2149	D47934P	W0121			ALL
	36	D47936J	W5723	D47936P	W0121			ALL
	37	D47937J	W2043	D47937P	W0121			ALL
	38	D47938J	W5111	D47938P	W0121			ALL
	39	D47939J	W5111	D47939P	W0121			ALL
	40	D47940J	W5121	D47940P	W0121			ALL
	41	D47941J	W5719	D47941P	W0121			ALL
	42	D47942J	W5719	D47942P	W0121			ALL
	43	D47943J	W2177	D47943P	W0121			ALL
	44	D47944J	W5189	D47944P	W0121			ALL
AE0100B	**DISCONNECT RAIL - E1-4 SHELF**					**003**	**310/172/R028**	**ALL**
	23	D47823J	W0523	D47823P	W0141			ALL
	24	D47824J	W0523	D47824P	W0141			ALL
	25	D47825J	W5463	D47825P	W0141			ALL
	29	D47829J	W5463	D47829P	W0141			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0100B	**DISCONNECT RAIL - E1-4 SHELF (continued)**					**003**	**310/172/R028**	**ALL**
	30	D47830J	W5463	D47830P	W0141			ALL
	31	D47831J	W2510	D47831P	W0141			ALL
	32	D47832J	W2043	D47832P	W0141			ALL
	33	D47833J	W2251	D47833P	W0141			ALL
	34	D47834J	W2103	D47834P	W0141			ALL
	35	D47835J	W5723	D47835P	W0141			ALL
	36	D47836J	W5723	D47836P	W0141			ALL
	37	D47837J	W5121	D47837P	W0141			ALL
	38	D47838J	W5121	D47838P	W0141			ALL
	39	D47839J	W2383	D47839P	W0141			ALL
	40	D47840J	W2465	D47840P	W0141			ALL
	41	D47841J	W5457	D47841P	W0141			ALL
	42	D47842J	W5457	D47842P	W0141			ALL
	43	D47843J	W2465	D47843P	W0141			ALL
	44	D47844J	W3379	D47844P	W0141			ALL
AE0100C	**DISCONNECT RAIL - E1-4 SHELF**					**003**	**310/166/R027**	**ALL**
	25	D47725J	W5526	D47725P	W0141			ALL
	26	D47726J	W5506	D47726P	W0141			ALL
	27	D47727J	W5506	D47727P	W0141			ALL
	28	D47728J	W2508	D47728P	W0141			ALL
	29	D47729J	W2508	D47729P	W0141			ALL
	30	D47730J	W5721	D47730P	W0141			ALL
	31	D47731J	W5721	D47731P	W0141			ALL
	32	D47732J	W5514	D47732P	W0141			ALL
	33	D47733J	W5514	D47733P	W0141			ALL
	35	D47735J	W5375	D47735P	W0141			ALL
	36	D47736J	W5158	D47736P	W0141			ALL
	37	D47737J	W5158	D47737P	W0141			ALL
	38	D47738J	W5191	D47738P	W0141			ALL
	39	D47739J	W5610	D47739P	W0141			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0100C	**DISCONNECT RAIL - E1-4 SHELF (continued)**					**003**	**310/166/R027**	**ALL**
	40	D47740J	W5610	D47740P	W0141			ALL
	41	D47741J	W5510	D47741P	W0141			ALL
	42	D47742J	W5510	D47742P	W0141			ALL
	43	D47743J	W5204	D47743P	W0141			ALL
AE0101A	**DISCONNECT BRACKET - E1-1 SHELF**					**036**	**310/178/L022**	**ALL**
	01	D40458J	W0111	D40458P	W5156			ALL
	02	D40454J	W0111	D40454P	W5156			ALL
	03	D45133J	W0111	D45133P	W5111			ALL
	04	D41145J	W0111	D41145P	W5161			ALL
	05	D40452J	W0111	D40452P	W5156			ALL
	06	D42311J	W0111	D42311P	W5461			ALL
	07	D41159J	W0111	D41159P	W5353			ALL
	08	D04425J	W0111	D04425P	W5301			ALL
	09	D40133J	W0111	D40133P	W2221			ALL
	11	D41153J	W0111	D41153P	W5111			ALL
	12	D40364J	W0111	D40364P	W6110			ALL
	13	D41811J	W0111	D41811P	W2101			ALL
	14	D40120J	W0111	D40120P	W5568			ALL
	15	D40162J	W0111	D40162P	W5032			ALL
	16	D40180J	W0111	D40180P	W6028			ALL
	17	D41121J	W0111	D41121P	W5721			ALL
	18	D40122J	W0111	D40122P	W5166			ALL
	19	D45113J	W0111	D45113P	W5111			ALL
	20	D41155J	W0111	D41155P	W5161			ALL
	21	D43211J	W0111	D43211P	W5461			ALL
	22	D46461J	W0111	D46461P	W5461			ALL
	23	D04075J	W0111	D04075P	W5369			ALL
	24	D41821J	W0111	D41821P	W2175			ALL
	25	D41125J	W0111	D41125P	W5719			ALL
	26	D04083J	W0111	D04083P	W3381			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0101A	**DISCONNECT BRACKET - E1-1 SHELF (continued)**					**036**	**310/178/L022**	**ALL**
	27	D04073J	W0111	D04073P	W5367			ALL
	28	D40510J	W0111	D40510P	W2218			ALL
	29	D04069J	W0111	D04069P	W2363			ALL
	30	D40019J	W0111	D40019P	W2221			ALL
	31	D45203J	W0111	D45203P	W5205			ALL
	32	D04079J	W0111	D04079P	W3377			ALL
	33	D40774J	W0111	D40774P	W6214			ALL
	34	D41023J	W0111	D41023P	W2043			ALL
	35	D45515J	W0111	D45515P	W5463			ALL
AE0101B	**DISCONNECT BRACKET - E1-1 SHELF**					**023**	**310/178/R017**	**ALL**
	01	D41563J	W0111	D41563P	W5463			ALL
	02	D40464J	W0111	D40464P	W5160			ALL
	03	D41161J	W0111	D41161P	W5397			ALL
	04	D40142J	W0111	D40142P	W6166			ALL
	05	D40063J	W0111	D40063P	W5723			ALL
	06	D40948J	W0111	D40948P	W6166			ALL
	07	D40818J	W0111	D40818P	W6208			ALL
	08	D41163J	W0111	D41163P	W5463			ALL
	09	D46023J	W0111	D46023P	W2383			ALL
	10	D43317J	W0111	D43317P	W5723			ALL
	11	D41147J	W0111	D41147P	W5163			ALL
	12	D41157J	W0111	D41157P	W5163			ALL
	13	D46013J	W0111	D46013P	W2103			ALL
	14	D40160J	W0111	D40160P	W6588			ALL
	15	D04611J	W0111	D04611P	W4001			ALL
	16	D04609J	W0111	D04609P	W4001			ALL
	17	D04615J	W0111	D04615P	W4001			ALL
	18	D04613J	W0111	D04613P	W4001			ALL
	19	D04619J	W0111	D04619P	W5001			ALL
	20	D04617J	W0111	D04617P	W5001			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0101B	**DISCONNECT BRACKET - E1-1 SHELF (continued)**					**023**	**310/178/R017**	**ALL**
	21	D04623J	W0111	D04623P	W5001			ALL
	22	D04621J	W0111	D04621P	W5001			ALL
	23	D40064J	W0111	D40064P	W2218			ALL
AE0102A	**DISCONNECT BRACKET - E1-2 SHELF**					**015**	**312/169/R023**	**ALL**
AE0102B	**DISCONNECT BRACKET - E1-2 SHELF**					**008**	**304/178/R036**	**ALL**
AE0103A	**DISCONNECT BRACKET - E1-3 SHELF**					**022**	**312/170/L025**	**ALL**
	01	D04133J	W0131	D04133P	W5413			ALL
	02	D45227J	W0131	D45227P	W3477			ALL
	04	D43048J	W0131	D43048P	W6730			ALL
	05	D41037J	W0131	D41037P	W5156			ALL
	09	D41400J	W0131	D41400P	W2022			ALL
	10	D41033J	W0131	D41033P	W5719			ALL
	11	D04181J	W0131	D04181P	W3311			ALL
	13	D04149J	W0131	D04149P	W2307			ALL
	16	D04123J	W0131	D04123P	W5107			ALL
	17	D43010J	W0131	D43010P	W5234			ALL
	18	D40810J	W0131	D40810P	W6506			ALL
	21	D46051J	W0131	D46051P	W2661			ALL
	22	D41337J	W0131	D41337P	W3307			ALL
	23	D41831J	W0131	D41831P	W2651			ALL
	24	D04195J	W0131	D04195P	W5189			ALL
	25	D40466J	W0131	D40466P	W5160			ALL
	26	D40498J	W0131	D40498P	W5156			ALL
	27	D40344J	W0131	D40344P	W5610			ALL
	28	D41131J	W0131	D41131P	W5723			ALL
	29	D41509J	W0131	D41509P	W5719			ALL
	36	D43040J	W0131	D43040P	W6528			ALL
	38	D40488J	W0137	D40488P	W5158			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0104A	**DISCONNECT BRACKET - E1-4 SHELF**					**030**	**312/160/R023**	**ALL**
AE0104B	**DISCONNECT BRACKET - E1-4 SHELF**					**003**	**320/170/R030**	**ALL**
AE0105A	**DISCONNECT BRACKET - E1-5 SHELF**					**013**	**312/160/L025**	**ALL**
	01	D04125J	W5177	D04125P	W0151			ALL
	02	D04031J	W2151	D04031P	W0151			ALL
	03	D41507J	W5723	D41507P	W0151			ALL
	04	D04197J	W5191	D04197P	W0151			ALL
	06	D04143J	W5107	D04143P	W0151			ALL
	07	D41557J	W5163	D41557P	W0151			ALL
	08	D41517J	W2247	D41517P	W0151			ALL
	09	D45125J	W5121	D45125P	W0151			ALL
	11	D41511J	W5099	D41511P	W0151			ALL
	12	D41515J	W5185	D41515P	W0151			ALL
	13	D04131J	W5411	D04131P	W0151			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0201A	**DISCONNECT BRACKET - E2-1 SHELF**					**023**	**381/185/L036**	**ALL**
	01	D49996J	W0212	D49996P	W5112			ALL
	02	D40934J	W0212	D40934P	W5112			ALL
	03	D40342J	W0212	D40342P	W5112			ALL
	04	D40256J	W0212	D40256P	W5112			ALL
	05	D40564J	W0212	D40564P	W2702			ALL
	06	D40910J	W0212	D40910P	W5726			ALL
	07	D40254J	W0212	D40254P	W5726			ALL
	08	D40428J	W0212	D40428P	W5510			ALL
	09	D40340J	W0212	D40340P	W5110			ALL
	11	D46258J	W0212	D46258P	W2112			ALL
	12	D40260J	W0212	D40260P	W5110			ALL
	13	D40926J	W0212	D40926P	W5726			ALL
	14	D40598J	W0212	D40598P	W2112			ALL
	16	D40372J	W0212	D40372P	W6210			ALL
	18	D40358J	W0212	D40358P	W5612			ALL
	19	D41432J	W0210	D41432P	W2138			ALL
	20	D40070J	W0210	D40070P	W2108			ALL
	21	D40518J	W0210	D40518P	W2112			ALL
	23	D40258J	W0212	D40258P	W5568			ALL
	24	D40132J	W0212	D40132P	W5164			ALL
	25	D40718J	W0212	D40718P	W5164			ALL
AE0202A	**DISCONNECT BRACKET - E2-2 SHELF**					**033**	**381/185/L036**	**ALL**
	01	D43050J	W0220	D43050P	W6730			ALL
	02	D40586J	W0220	D40586P	W5248			ALL
	04	D43060J	W0220	D43060P	W6128			ALL
	05	D40656J	W0220	D40656P	W7592			ALL
	06	D40246J	W0220	D40246P	W5104			ALL
	07	D41012J	W0220	D41012P	W6214			ALL
	09	D42014J	W0220	D42014P	W5088			ALL
	11	D40506J	W0220	D40506P	W2104			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0202A	**DISCONNECT BRACKET - E2-2 SHELF (continued)**					**033**	**381/185/L036**	**ALL**
	12	D40520J	W0220	D40520P	W2112			ALL
	13	D40450J	W0220	D40450P	W5310			ALL
	14	D40118J	W0220	D40118P	W5566			ALL
	15	D40430J	W0220	D40430P	W5506			ALL
	16	D43084J	W0220	D43084P	W5230			ALL
	17	D40360J	W0220	D40360P	W5612			ALL
	18	D40928J	W0220	D40928P	W5726			ALL
	19	D40724J	W0220	D40724P	W5156			ALL
	20	D43008J	W0220	D43008P	W5134			ALL
	21	D40912J	W0220	D40912P	W5726			ALL
	22	D46022J	W0220	D46022P	W2110			ALL
	23	D40946J	W0220	D40946P	W5726			ALL
	24	D40130J	W0220	D40130P	W5162			ALL
	25	D40240J	W0220	D40240P	W6102			ALL
	26	D40380J	W0220	D40380P	W6214			ALL
	27	D40126J	W0220	D40126P	W3170			ALL
	28	D41840J	W0220	D41840P	W5094			ALL
	29	D40646J	W0220	D40646P	W2110			ALL
	30	D43024J	W0220	D43024P	W5728			ALL
	31	D40456J	W0220	D40456P	W5156			ALL
	32	D40348J	W0220	D40348P	W5610			ALL
	33	D40012J	W0220	D40012P	W7594			ALL
	34	D40138J	W0220	D40138P	W5168			ALL
	35	D40773J	W0220	D40773P	W5506			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0301A	**DISCONNECT BRACKET - E3-1 SHELF**					**041**	**381/194/L005**	**ALL**
	01	D47523J	W0313	D47523P	W2043			ALL
	02	D47521J	W0311	D47521P	W2031			ALL
	03	D42049J	W0313	D42049P	W5049			ALL
	05	D42163J	W0311	D42163P	W5273			ALL
	06	D48888J	W0311	D48888P	W3710			ALL
	07	D42026J	W0311	D42026P	W5610			ALL
	08	D04271J	W0311	D04271P	W5189			ALL
	10	D45205J	W0311	D45205P	W5205			ALL
	11	D45131J	W0311	D45131P	W5111			ALL
	12	D46035J	W0313	D46035P	W2169			ALL
	13	D41837J	W0311	D41837P	W2653			ALL
	14	D40448J	W0311	D40448P	W5310			ALL
	16	D40460J	W0311	D40460P	W5156			ALL
	17	D49994J	W0311	D49994P	W3170			ALL
	18	D43145J	W0311	D43145P	W5161			ALL
	19	D43155J	W0311	D43155P	W5161			ALL
	20	D47151J	W0311	D47151P	W5111			ALL
	21	D45111J	W0311	D45111P	W5111			ALL
	22	D45151J	W0311	D45151P	W5111			ALL
	23	D04267J	W0311	D04267P	W2207			ALL
	24	D42005J	W0311	D42005P	W2265			ALL
	25	D04297J	W0313	D04297P	W2237			ALL
	26	D46017J	W0313	D46017P	W2231			ALL
	27	D40516J	W0311	D40516P	W2112			ALL
	28	D42007J	W0313	D42007P	W2267			ALL
	29	D42047J	W0311	D42047P	W5047			ALL
	30	D40544J	W0313	D40544P	W2218			ALL
	31	D43147J	W0313	D43147P	W5163			ALL
	32	D47311J	W0315	D47311P	W2008			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0301A	**DISCONNECT BRACKET - E3-1 SHELF (continued)**					**041**	**381/194/L005**	**ALL**
	33	D47321J	W0317	D47321P	W2228			ALL
	35	D45121J	W0313	D45121P	W5121			ALL
	36	D45141J	W0313	D45141P	W5121			ALL
	37	D40394J	W0313	D40394P	W6412			ALL
	38	D40149J	W0313	D40149P	W6491			ALL
	39	D40732J	W0313	D40732P	W4170			ALL
	40	D43157J	W0313	D43157P	W5163			ALL
	41	D04277J	W0313	D04277P	W5191			ALL
	42	D42165J	W0313	D42165P	W5275			ALL
	46	D42051J	W0313	D42051P	W5049			ALL
	47	D40508J	W0313	D40508P	W2112			ALL
	49	D41039J	W0313	D41039P	W5158			ALL
AE0302A	**DISCONNECT BRACKET - E3-2 SHELF**					**056**	**381/185/L005**	**ALL**
	02	D40053J	W0321	D40053P	W5367			ALL
	03	D49002J	W0321	D49002P	W2043			ALL
	04	D40446J	W0321	D40446P	W5310			ALL
	05	D40362J	W0321	D40362P	W5612			ALL
	06	D40350J	W0321	D40350P	W5610			ALL
	07	D49004J	W0321	D49004P	W5610			ALL
	09	D43718J	W0325	D43718P	W3028			ALL
	10	D49003J	W0321	D49003P	W5111			ALL
	11	D40025J	W0321	D40025P	W3377			ALL
	12	D43203J	W0321	D43203P	W5603			ALL
	13	D43257J	W0321	D43257P	W5257			ALL
	14	D43219J	W0321	D43219P	W2419			ALL
	15	D45207J	W0321	D45207P	W5205			ALL
	16	D40950J	W0321	D40950P	W5506			ALL
	17	D40594J	W0321	D40594P	W5156			ALL
	18	D42718J	W0325	D42718P	W3026			ALL
	19	D40462J	W0321	D40462P	W5156			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0302A	**DISCONNECT BRACKET - E3-2 SHELF (continued)**					**056**	**381/185/L005**	**ALL**
	20	D43022J	W0321	D43022P	W5530			ALL
	21	D42727J	W0321	D42727P	W2231			ALL
	22	D45117J	W0321	D45117P	W5111			ALL
	24	D43054J	W0321	D43054P	W6732			ALL
	28	D40817J	W0321	D40817P	W5158			ALL
	29	D41839J	W0321	D41839P	W2653			ALL
	30	D40710J	W0321	D40710P	W5047			ALL
	32	D42710J	W0325	D42710P	W5382			ALL
	34	D41819J	W0321	D41819P	W2201			ALL
	36	D45102J	W0321	D45102P	W5121			ALL
	37	D46043J	W0321	D46043P	W2169			ALL
	38	D46054J	W0321	D46054P	W6732			ALL
	42	D43726J	W0326	D43726P	W3042			ALL
	43	D42730J	W0321	D42730P	W2112			ALL
	44	D40596J	W0321	D40596P	W2112			ALL
	45	D43046J	W0321	D43046P	W6530			ALL
	46	D42726J	W0326	D42726P	W3040			ALL
	48	D40029J	W0321	D40029P	W3379			ALL
	49	D40951J	W0321	D40951P	W5506			ALL
	50	D40470J	W0321	D40470P	W5160			ALL
	51	D43205J	W0321	D43205P	W5605			ALL
	52	D42712J	W0326	D42712P	W5380			ALL
	53	D40194J	W0321	D40194P	W6134			ALL
	54	D43261J	W0321	D43261P	W5461			ALL
	55	D42261J	W0321	D42261P	W5461			ALL
	56	D40952J	W0321	D40952P	W5160			ALL
	57	D42361J	W0321	D42361P	W5461			ALL
	58	D43263J	W0321	D43263P	W5463			ALL
	59	D40392J	W0321	D40392P	W6412			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0302A	**DISCONNECT BRACKET - E3-2 SHELF (continued)**					**056**	**381/185/L005**	**ALL**
	60	D45127J	W0321	D45127P	W5121			ALL
	61	D49001J	W0321	D49001P	W5049			ALL
	62	D42053J	W0321	D42053P	W5375			ALL
	63	D40276J	W0321	D40276P	W6134			ALL
	64	D43209J	W0321	D43209P	W5409			ALL
	66	D43030J	W0321	D43030P	W6034			ALL
	67	D40908J	W0321	D40908P	W5726			ALL
	68	D42363J	W0321	D42363P	W5463			ALL
	69	D49007J	W0321	D49007P	W5049			ALL
	70	D42720J	W0321	D42720P	W5371			ALL
	71	D43215J	W0321	D43215P	W2805			ALL
	72	D45157J	W0321	D45157P	W5111			ALL
	73	D45137J	W0321	D45137P	W5111			ALL
	74	D46246J	W0321	D46246P	W7189			ALL
	75	D46252J	W0321	D46252P	W7191			ALL
	76	D45147J	W0321	D45147P	W5121			ALL
	77	D40486J	W0321	D40486P	W5158			ALL
AE0303A	**DISCONNECT BRACKET - E3-3 SHELF**					**049**	**384/173/L005**	**ALL**
	01	D43301J	W0335	D43301P	W5415			ALL
	02	D43313J	W0331	D43313P	W2201			ALL
	05	D41822J	W0330	D41822P	W6412			ALL
	07	D43367J	W0331	D43367P	W5107			ALL
	08	D43314J	W0335	D43314P	W5177			ALL
	09	D41032J	W0330	D41032P	W6420			ALL
	10	D43056J	W0330	D43056P	W5047			ALL
	11	D41826J	W0330	D41826P	W2218			ALL
	12	D41818J	W0330	D41818P	W6288			ALL
	13	D43307J	W0331	D43307P	W5111			ALL
	15	D43329J	W0335	D43329P	W2417			ALL
	17	D43345J	W0331	D43345P	W5331			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0303A	**DISCONNECT BRACKET - E3-3 SHELF (continued)**					**049**	**384/173/L005**	**ALL**
	18	D43347J	W0331	D43347P	W5331			ALL
	20	D43321J	W0331	D43321P	W5111			ALL
	21	D41844J	W0330	D41844P	W3170			ALL
	22	D41848J	W0330	D41848P	W5168			ALL
	23	D43306J	W0331	D43306P	W5723			ALL
	24	D43391J	W0335	D43391P	W2417			ALL
	25	D41814J	W0330	D41814P	W6214			ALL
	26	D41802J	W0330	D41802P	W6220			ALL
	27	D41842J	W0330	D41842P	W5526			ALL
	28	D43359J	W0331	D43359P	W5103			ALL
	33	D41836J	W0330	D41836P	W5104			ALL
	34	D41824J	W0330	D41824P	W5156			ALL
	35	D43309J	W0335	D43309P	W2231			ALL
	37	D43139J	W0335	D43139P	W5049			ALL
	38	D43331J	W0335	D43331P	W5191			ALL
	39	D43379J	W0335	D43379P	W5335			ALL
	41	D41812J	W0330	D41812P	W2216			ALL
	42	D41806J	W0330	D41806P	W6230			ALL
	43	D41808J	W0330	D41808P	W6420			ALL
	44	D43355J	W0335	D43355P	W2415			ALL
	45	D43363J	W0331	D43363P	W2413			ALL
	46	D41813J	W0330	D41813P	W2216			ALL
	52	D43323J	W0335	D43323P	W5121			ALL
	54	D41862J	W0330	D41862P	W4170			ALL
	55	D41864J	W0330	D41864P	W6168			ALL
	56	D41868J	W0330	D41868P	W6412			ALL
	58	D43361J	W0335	D43361P	W5105			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0401A	**DISCONNECT BRACKET - E4-1 SHELF**					**052**	**E004-01/ /**	**ALL**
	01	D04115J	W0411	D04115P	W5331			ALL
	02	D40144J	W0410	D40144P	W6168			ALL
	03	D41828J	W0410	D41828P	W6214			ALL
	04	D41830J	W0410	D41830P	W6412			ALL
	05	D04289J	W0411	D04289P	W5191			ALL
	06	D04287J	W0411	D04287P	W5189			ALL
	07	D04155J	W0411	D04155P	W3323			ALL
	08	D04285J	W0411	D04285P	W5191			ALL
	09	D04331J	W0411	D04331P	W3319			ALL
	10	D08123J	W0411	D08123P	W5189			ALL
	11	D04153J	W0411	D04153P	W3327			ALL
	12	D04371J	W0411	D04371P	W5431			ALL
	13	D41804J	W0410	D41804P	W6220			ALL
	14	D41810J	W0410	D41810P	W6420			ALL
	15	D04161J	W0411	D04161P	W5337			ALL
	16	D43018J	W0410	D43018P	W5526			ALL
	17	D04007J	W0411	D04007P	W5335			ALL
	18	D41816J	W0410	D41816P	W6288			ALL
	19	D41101J	W0411	D41101P	W5602			ALL
	20	D43044J	W0410	D43044P	W6528			ALL
	21	D40554J	W0410	D40554P	W2508			ALL
	22	D40530J	W0410	D40530P	W2214			ALL
	23	D40066J	W0410	D40066P	W6204			ALL
	25	D40326J	W0410	D40326P	W6412			ALL
	26	D40330J	W0410	D40330P	W6230			ALL
	27	D40904J	W0410	D40904P	W5726			ALL
	28	D44139J	W0411	D44139P	W3309			ALL
	29	D04157J	W0411	D04157P	W3329			ALL
	30	D40244J	W0410	D40244P	W5104			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0401A	**DISCONNECT BRACKET - E4-1 SHELF (continued)**					**052**	**E004-01/ /**	**ALL**
	31	D40242J	W0410	D40242P	W6102			ALL
	32	D46248J	W0410	D46248P	W5191			ALL
	33	D04116J	W0411	D04116P	W5331			ALL
	34	D04117J	W0411	D04117P	W5331			ALL
	35	D04009J	W0411	D04009P	W5335			ALL
	36	D44161J	W0410	D44161P	W5461			ALL
	37	D43062J	W0410	D43062P	W5230			ALL
	38	D40378J	W0410	D40378P	W6214			ALL
	39	D40562J	W0410	D40562P	W2510			ALL
	40	D40534J	W0410	D40534P	W2216			ALL
	41	D43038J	W0410	D43038P	W6230			ALL
	42	D40156J	W0410	D40156P	W6162			ALL
	43	D40542J	W0410	D40542P	W2218			ALL
	44	D40390J	W0410	D40390P	W6412			ALL
AE0401B	**DISCONNECT BRACKET - E4-1 SHELF**					**002**	**E004-01/ /**	**ALL**
AE0401D	**DISCONNECT BRACKET - E4-1 SHELF**					**010**	**E004-01/ /**	**ALL**
AE0402A	**DISCONNECT BRACKET - E4-2 SHELF**					**041**	**E004-02/ /**	**ALL**
	01	D42111J	W0422	D42111P	W5719			ALL
	02	D40584J	W0422	D40584P	W5248			ALL
	05	D41417J	W0422	D41417P	W5172			ALL
	06	D40432J	W0422	D40432P	W6222			ALL
	07	D43028J	W0422	D43028P	W6032			ALL
	08	D40238J	W0422	D40238P	W6134			ALL
	09	D40714J	W0422	D40714P	W6588			ALL
	10	D40338J	W0422	D40338P	W5110			ALL
	11	D40388J	W0422	D40388P	W6412			ALL
	12	D40382J	W0422	D40382P	W6410			ALL
	13	D40228J	W0422	D40228P	W6208			ALL
	14	D40222J	W0422	D40222P	W6208			ALL
	15	D40164J	W0422	D40164P	W6586			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0401B	**DISCONNECT BRACKET - E4-1 SHELF (continued)**					**002**	**E004-01/ /**	**ALL**
AE0401D	**DISCONNECT BRACKET - E4-1 SHELF (continued)**					**010**	**E004-01/ /**	**ALL**
AE0402A	**DISCONNECT BRACKET - E4-2 SHELF (continued)**					**041**	**E004-02/ /**	**ALL**
	16	D40787J	W0422	D40787P	W5047			ALL
	17	D40789J	W0422	D40789P	W2031			ALL
	18	D40140J	W0422	D40140P	W6164			ALL
	19	D40938J	W0422	D40938P	W6210			ALL
	20	D40484J	W0422	D40484P	W5158			ALL
	21	D40356J	W0422	D40356P	W5612			ALL
	22	D42400J	W0420	D42400P	W6412			ALL
	23	D40930J	W0422	D40930P	W5612			ALL
	24	D40474J	W0422	D40474P	W5160			ALL
	25	D41440J	W0420	D41440P	W2218			ALL
	26	D41421J	W0422	D41421P	W5162			ALL
	27	D40712J	W0422	D40712P	W6412			ALL
	28	D40819J	W0422	D40819P	W5331			ALL
	31	D41718J	W0422	D41718P	W6172			ALL
	32	D40540J	W0422	D40540P	W2218			ALL
	33	D40472J	W0422	D40472P	W5160			ALL
	34	D40068J	W0420	D40068P	W2208			ALL
	35	D40618J	W0422	D40618P	W5158			ALL
	36	D40370J	W0422	D40370P	W6210			ALL
	37	D40827J	W0422	D40827P	W3910			ALL
	39	D48501J	W0422	D48501P	W6128			ALL
	41	D40785J	W0422	D40785P	W5049			ALL
	42	D40783J	W0422	D40783P	W2597			ALL
	43	D06108J	W0421	D06108P	W5602			ALL
	44	D40791J	W0422	D40791P	W2043			ALL
	45	D06110J	W0421	D06110P	W5602			ALL
	46	D41607J	W0421	D41607P	W3120			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0401B	**DISCONNECT BRACKET - E4-1 SHELF (continued)**					**002**	**E004-01/ /**	**ALL**
AE0401D	**DISCONNECT BRACKET - E4-1 SHELF (continued)**					**010**	**E004-01/ /**	**ALL**
AE0402A	**DISCONNECT BRACKET - E4-2 SHELF (continued)**					**041**	**E004-02/ /**	**ALL**
	47	D41604J	W0421	D41604P	W3110			ALL
	48	D06102J	W0421	D06102P	W5602			ALL
	49	D41722J	W0422	D41722P	W6162			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0502A	**DISCONNECT BRACKET - E5-2 SHELF**					**024**	**E005-02/ /**	**ALL**
	01	D45209J	W5205	D45209P	W0521			ALL
	02	D45245J	W5161	D45245P	W0521			ALL
	03	D45255J	W5161	D45255P	W0521			ALL
	04	D45265J	W5161	D45265P	W0521			ALL
	05	D41561J	W5461	D41561P	W0521			ALL
	06	D45261J	W5461	D45261P	W0521			ALL
	07	D45235J	W2035	D45235P	W0521			ALL
	08	D45239J	W5501	D45239P	W0521			ALL
	09	D45225J	W2597	D45225P	W0521			ALL
	10	D05925J	W2889	D05925P	W0521			ALL
	11	D45293J	W2597	D45293P	W0521			ALL
	12	D45211J	W5111	D45211P	W0521			ALL
	13	D45001J	W5602	D45001P	W0521			ALL
	15	D45521J	W3477	D45521P	W0521			ALL
	16	D45204J	W3477					ALL
	17	D40761J	W5047	D40761P	W0521			ALL
	24	D45563J	W5163	D45563P	W0521			ALL
	25	D40767J	W5049	D40767P	W0523			ALL
	26	D45213J	W5121	D45213P	W0523			ALL
	27	D45247J	W5163	D45247P	W0523			ALL
	28	D45257J	W5163	D45257P	W0523			ALL
	29	D45263J	W5463	D45263P	W0523			ALL
	30	D45237J	W2135	D45237P	W0523			ALL
	31	D45067J	W2135	D45067P	W0523			ALL
	32	D08105J	W2873	D08105P	W0523			ALL
	33	D45241J	W5503	D45241P	W0523			ALL
	34	D06063J	W0521					ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0601A	**DISCONNECT BRACKET - E6-1 SHELF**					**000**	**867/195/R050**	**ALL**
	02			D48202P	W3307			ALL
	03	D48204J	W0611	D48204P	W4477			ALL
	04			D17084P	W4477			ALL
AE0601B	**DISCONNECT BRACKET - E6-1 SHELF**					**000**	**867/195/R050**	**ALL**
	01			D17086P	W4477			ALL
	02			D17088P	W4477			ALL
AE0602A	**DISCONNECT BRACKET - E6-2 SHELF**					**012**	**867/195/R050**	**ALL**
	02	D40117J	W0621	D40117P	W5189			ALL
	03	D40121J	W0621	D40121P	W3553			ALL
	04	D40113J	W0621	D40113P	W5103			ALL
	05	D46201J	W0625	D46201P	W5433			ALL
	07	D40115J	W0623	D40115P	W5105			ALL
	08	D40125J	W0623	D40125P	W3555			ALL
	09	D40119J	W0623	D40119P	W5191			ALL
	11	D40127J	W0623	D40127P	W3559			ALL
	12	D40123J	W0621	D40123P	W3557			ALL
	13	D40111J	W0621	D40111P	W2101			ALL
	14	D40831J	W0626	D40831P	W5726			ALL
	15	D40833J	W0626	D40833P	W5726			ALL
	16	D40835J	W0626	D40835P	W5726			ALL
	17	D40847J	W0626	D40847P	W5726			ALL
	18	D40621J	W0623	D40621P	W2103			ALL
	19	D40845J	W0626	D40845P	W5726			ALL
AE0603A	**DISCONNECT BRACKET - E6-3 SHELF**					**000**	**867/195/R050**	**ALL**
	01	D40953J	W0631	D40953P	W4477			ALL
	02	D40973J	W0631	D40973P	W4479			ALL
	05	D40983J	W0631	D40983P	W4479			ALL
	07	D43717J	W0631	D43717P	W4479			ALL
	08	D47145J	W0631	D47145P	W4479			ALL
	09	D40964J	W0631	D40964P	W4479			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE0603B	**DISCONNECT BRACKET - E6-3 SHELF**					**000**	**867/195/R050**	**ALL**
	01	D47056J	W0635	D47056P	W4479			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AE1100A	**DISCONNECT BRACKET - E11 SHELF**					**006**	**212/180/R020**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AF0213A	**DISCONNECT BRACKET-AISLE CONTROL STAND**					**006**	**210/208/0000**	**ALL**
	01	D05148J	W0008	D05148P	W6208			ALL
	02			D11288	W5506			ALL
	03			D11286	W5510			ALL
	03			D11286P	W0008			ALL
	04	D05150J	W0008	D05150P	W6208			ALL
	05	D08313J	W0049	D08313P	W5369			ALL
	06			D10171	W5506			ALL
	06	D10171J	W0049					ALL
AF0222A	**DISCONNECT BRACKET-AISLE CONTROL STAND**					**007**	**210/208/**	**ALL**
	01			D11292	W6506			ALL
	02			D11290	W6510			ALL
	02			D11290P	W0008			ALL
	04	D08315J	W0051	D08315P	W5457			ALL
	05			D00698	W6208			ALL
	06			D10173	W6510			ALL
	06	D10173J	W0051					ALL
	07			D10537	W6208			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0004	**DISCONNECT BRACKET-J4**					**010**	**273/168/R024**	**ALL**
	01	D40781J	W0094	D40781P	W3453			ALL
	02	D40792J	W0094	D40792P	W3381			ALL
	03	D40662J	W0094	D40662P	W6212			ALL
	12	D40612J	W0094	D40612P	W5160			ALL
	13	D40658J	W0094	D40658P	W5160			ALL
	15	D44440J	W0094	D44440P	W3381			ALL
	16	D40614J	W0094	D40614P	W6222			ALL
	17	D40610J	W0094	D40610P	W5160			ALL
	19	D40602J	W0094	D40602P	W6222			ALL
AJ0011	**DISCONNECT BRACKET-J11**					**002**	**J011-00/ /**	**ALL**
	01	D46618J	W0122	D46618P	W5124			ALL
	02	D46616J	W0122	D46616P	W5124			ALL
	03	D46623J	W0122	D46623P	W5433			ALL
	04	D46612J	W0096	D46612P	W2103			ALL
	05	D46604J	W0096	D46604P	W4477			ALL
	06	D46610J	W0096	D46610P	W4477			ALL
	7	D46614J	W0096	D46614P	W5434			ALL
AJ0020	**DISCONNECT BRACKET-J20**					**000**	**J020-0B/ /**	**ALL**
AJ0020A	**DISCONNECT BRACKET-J20-A**					**004**	**J020-0A/ /**	**ALL**
	02	D40884J	W0074	D40884P	W5158			ALL
AJ0020B	**DISCONNECT BRACKET-J20-B**					**007**	**J020-0B/ /**	**ALL**
	01	D40634J	W0072	D40634P	W5158			ALL
	02	D40638J	W0072	D40638P	W5158			ALL
	03	D40640J	W0072	D40640P	W5158			ALL
	04	D40636J	W0072	D40636P	W5156			ALL
	05	D40632J	W0072	D40632P	W5100			ALL
	07	D40642J	W0072	D40642P	W5156			ALL
AJ0020C	**DISCONNECT BRACKET-J20-C**					**003**	**J020-0A/ /**	**ALL**
	02	D40878J	W0074	D40878P	W5156			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0020D	**DISCONNECT BRACKET-J20-D**					**001**	**J020-0D/ /**	**ALL**
	01	D40858J	W0072	D40858P	W5158			ALL
AJ0022	**DISCONNECT BRACKET-J22**					**009**	**J022-00/ /**	**ALL**
	01	D40678J	W0076	D40678P	W5156			ALL
	02	D40672J	W0076	D40672P	W5510			ALL
	03	D40666J	W0076	D40666P	W5156			ALL
	04	D40670J	W0076	D40670P	W5156			ALL
	05	D40676J	W0076	D40676P	W5156			ALL
	06	D40668J	W0076	D40668P	W5100			ALL
	07	D40674J	W0076	D40674P	W5506			ALL
	08	D40680J	W0076	D40680P	W5156			ALL
	09	D40147J	W0076	D40147P	W6491			ALL
AJ0023	**DISCONNECT BRACKET-J23**					**007**	**J023-00/ /**	**ALL**
	02	D40686J	W0078	D40686P	W5506			ALL
	05	D40688J	W0078	D40688P	W5510			ALL
	06	D40779J	W0078	D40779P	W5506			ALL
AJ0023B	**DISCONNECT BRACKET-J23B**					**000**	**J023-0B/ /**	**ALL**
	02	D40788J	W0098	D40788P	W5510			ALL
	05	D40808J	W0098	D40808P	W2112			ALL
	08	D40776J	W0098	D40776P	W5506			ALL
AJ0024	**DISCONNECT BRACKET-J24**					**007**	**J024-00/ /**	**ALL**
	02	D40696J	W0080	D40696P	W6510			ALL
	03	D40698J	W0080	D40698P	W5100			ALL
	04	D40692J	W0080	D40692P	W5158			ALL
	05	D40700J	W0080	D40700P	W5158			ALL
	06	D40702J	W0080	D40702P	W5158			ALL
	07	D40694J	W0080	D40694P	W5160			ALL
AJ0039A	**DISCONNECT BRACKET-J39-A**					**000**	**J039-0A/ /**	**ALL**
	01	D43900J	W0082	D43900P	W5506			ALL
	03	D43904J	W0082	D43904P	W5158			ALL
	04	D43906J	W0082	D43906P	W5160			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0039A	**DISCONNECT BRACKET-J39-A (continued)**					**000**	**J039-0A/ /**	**ALL**
	06	D43902J	W0082	D43902P	W5156			ALL
AJ0039B	**DISCONNECT BRACKET-J39-B**					**000**	**J039-0B/ /**	**ALL**
	02	D43924J	W0084	D43924P	W6212			ALL
	03	D43922J	W0084	D43922P	W3058			ALL
AJ0046A	**DISCONNECT BRACKET - J46A**					**016**	**263/177/R031**	**ALL**
	01	D46130J	W0066	D46130P	W5510			ALL
	04	D46110J	W0066	D46110P	W6208			ALL
	05	D46128J	W0066	D46128P	W5506			ALL
	07	D46144J	W0066	D46144P	W6170			ALL
	08	D46146J	W0066	D46146P	W6172			ALL
	09	D40103J	W0066	D40103P	W2247			ALL
	10	D40539J	W0066	D40539P	W5234			ALL
	11	D46104J	W0066	D46104P	W5514			ALL
	12	D46150J	W0066	D46150P	W6208			ALL
	13	D40445J	W0066	D40445P	W2151			ALL
	14	D40606J	W0066	D40606P	W5610			ALL
	15	D40600J	W0066	D40600P	W5160			ALL
	18	D40451J	W0066	D40451P	W5121			ALL
	19	D46134J	W0066	D46134P	W5514			ALL
	20	D46122J	W0066	D46122P	W5160			ALL
	21	D46116J	W0066	D46116P	W5156			ALL
	22	D46102J	W0066	D46102P	W5160			ALL
	23	D46108J	W0066	D46108P	W2508			ALL
AJ0046B	**DISCONNECT BRACKET - J46B**					**015**	**263/177/R031**	**ALL**
	01	D46124J	W0066	D46124P	W2212			ALL
	02	D46138J	W0066	D46138P	W6242			ALL
	03	D46120J	W0066	D46120P	W5158			ALL
	04	D46132J	W0066	D46132P	W6506			ALL
	05	D46136J	W0066	D46136P	W6528			ALL
	06	D40097J	W0066	D40097P	W5503			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0046B	**DISCONNECT BRACKET - J46B (continued)**					**015**	**263/177/R031**	**ALL**
	07	D46106J	W0066	D46106P	W6506			ALL
	08	D46126J	W0066	D46126P	W2510			ALL
	09	D46118J	W0066	D46118P	W6510			ALL
	10	D46142J	W0066	D46142P	W6414			ALL
	11	D46100J	W0066	D46100P	W5158			ALL
	12	D46112J	W0066	D46112P	W2216			ALL
	13	D40671J	W0066	D40671P	W6412			ALL
	14	D46148J	W0066	D46148P	W2216			ALL
	15	D46114J	W0066	D46114P	W2218			ALL
	16	D40704J	W0066	D40704P	W6162			ALL
	17	D46158J	W0066	D46158P	W2218			ALL
	18	D46140J	W0066	D46140P	W5158			ALL
AJ0048A	**DISCONNECT BRACKET - J48A**					**026**	**263/177/L033**	**ALL**
	01	D48100J	W0088	D48100P	W2104			ALL
	02	D48126J	W0088	D48126P	W5142			ALL
	03	D48122J	W0088	D48122P	W5510			ALL
	04	D40095J	W0088	D40095P	W2149			ALL
	05	D48102J	W0088	D48102P	W2112			ALL
	07	D48110J	W0088	D48110P	W5170			ALL
	08	D40087J	W0088	D40087P	W5501			ALL
	09	D48120J	W0088	D48120P	W5506			ALL
	13	D48116J	W0088	D48116P	W5158			ALL
	15	D48108J	W0088	D48108P	W2532			ALL
	16	D48112J	W0088	D48112P	W5156			ALL
	17	D48114J	W0088	D48114P	W5156			ALL
	18	D48124J	W0088	D48124P	W6110			ALL
	19	D48136J	W0088	D48136P	W5172			ALL
	20	D48104J	W0088	D48104P	W2114			ALL
	21	D40706J	W0088	D40706P	W5461			ALL
	22	D48118J	W0088	D48118P	W5506			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0048A	**DISCONNECT BRACKET - J48A (continued)**					**026**	**263/177/L033**	**ALL**
	23	D48130J	W0088	D48130P	W6510			ALL
	24	D48106J	W0088	D48106P	W2508			ALL
	25	D48138J	W0088	D48138P	W6506			ALL
	26	D48132J	W0088	D48132P	W6506			ALL
	27	D48125J	W0088	D48125P	W5506			ALL
	29	D40748J	W0088	D40748P	W2035			ALL
	30	D40723J	W0088	D40723P	W2597			ALL
	31	D40758J	W0088	D40758P	W5161			ALL
	32	D40771J	W0088	D40771P	W5156			ALL
	33	D43876J	W0088	D43876P	W5610			ALL
	34	D40721J	W0088	D40721P	W5369			ALL
AJ0071A	**DISCONNECT BRACKET - J71A**					**001**	**223/179/L025**	**ALL**
	01	D47177J	W0171	D47177P	W6103			ALL
	02	D47161J	W0171	D47161P	W2151			ALL
	03	D47172J	W0171	D47172P	W6208			ALL
	04	D47274J	W0171	D47274P	W6491			ALL
	06	D47165J	W0171	D47165P	W2413			ALL
	07	D47176J	W0171	D47176P	W6201			ALL
	08	D47173J	W0171	D47173P	W6208			ALL
	09	D47171J	W0171	D47171P	W5506			ALL
	10	D47263J	W0171	D47263P	W2417			ALL
	11	D47170J	W0171	D47170P	W5049			ALL
	12	D47162J	W0171	D47162P	W2265			ALL
	13	D47160J	W0171	D47160P	W2149			ALL
	14	D47168J	W0171	D47168P	W3323			ALL
	15	D47167J	W0171	D47167P	W2889			ALL
	16	D47268J	W0171	D47268P	W6110			ALL
	17	D47267J	W0171	D47267P	W5514			ALL
AJ0072A	**DISCONNECT BRACKET - J72A**					**001**	**223/179/R025**	**ALL**
	01	D47175J	W0172	D47175P	W6510			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AJ0072A	**DISCONNECT BRACKET - J72A (continued)**					**001**	**223/179/R025**	**ALL**
	02	D47261J	W0172	D47261P	W2177			ALL
	03	D47275J	W0172	D47275P	W6201			ALL
	04	D47169J	W0172	D47169P	W3381			ALL
	05	D47260J	W0172	D47260P	W2110			ALL
	06	D47174J	W0172	D47174P	W6506			ALL
	07	D47266J	W0172	D47266P	W5510			ALL
	08	D47264J	W0172	D47264P	W3319			ALL
	09	D47265J	W0172	D47265P	W5160			ALL
	10	D47269J	W0172	D47269P	W6206			ALL
	11	D47270J	W0172	D47270P	W6206			ALL
	12	D47271J	W0172	D47271P	W6206			ALL
	13	D47272J	W0172	D47272P	W6206			ALL
	14	D47273J	W0172	D47273P	W6206			ALL
	15	D47166J	W0172	D47166P	W2873			ALL
	16	D47262J	W0172	D47262P	W2415			ALL
	17	D47276J	W0172	D47276P	W6103			ALL
	18	D47163J	W0172	D47163P	W2267			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AL0675A	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**004**	**676/198/L040**	**ALL**
	04	D46010J	W5224	D46010P	W7122			ALL
AL0675B	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**004**	**675/198/L036**	**ALL**
	01	D46026J	W5728	D46026P	W7026			ALL
	02	D04850J	W5224	D04850P	W7026			ALL
	03	D46030J	W5222	D46030P	W7522			ALL
	04	D46028J	W5530	D46028P	W7230			ALL
AL0675C	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**003**	**675/198/R036**	**ALL**
	01	D46046J	W6124	D46046P	W8122			ALL
	02	D46042J	W6122	D46042P	W8222			ALL
	03	D46038J	W6732	D46038P	W8228			ALL
AL0694L	**DISCONNECT BRACKET-STA 694**					**002**	**/ /**	**ALL**
	01	D46002J	W7230	D46002P	W7022			ALL
	02	D46004J	W7230	D46004P	W7134			ALL
AL0694R	**DISCONNECT BRACKET-STA 694**					**002**	**/ /**	**ALL**
	01	D46012J	W8228	D46012P	W8022			ALL
	02	D46014J	W8228	D46014P	W8234			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AL0706L	**DISCONNECT BRACKET-STA 706**					**001**	**/ /**	**ALL**
	01	D46006J	W7126	D46006P	W7136			ALL
AL0706R	**DISCONNECT BRACKET-STA 706**					**001**	**/ /**	**ALL**
	01	D46016J	W8224	D46016P	W8236			ALL
AL0711L	**DISCONNECT BRACKET-STA 711**					**000**	**/ /**	**ALL**
	01	D46008J	W7126	D46008P	W7024			ALL
AL0711R	**DISCONNECT BRACKET-STA 711**					**001**	**/ /**	**ALL**
	01	D46018J	W8224	D46018P	W8024			ALL
AL0720A	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**004**	**717/200/L032**	**ALL**
	01	D46024J	W5234	D46024P	W7126			ALL
	02	D42102J	W5367	D42102P	W1022			ALL
	03	D42100J	W5375	D42100P	W1022			ALL
AL0720B	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**003**	**717/200/L027**	**ALL**
	02	D46032J	W5222	D46032P	W7128			ALL
	03	D46036J	W5224	D46036P	W7128			ALL
	04	D46020J	W6124	D46020P	W7128			ALL
AL0720C	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**004**	**717/200/R032**	**ALL**
	01	D43100J	W5367	D43100P	W1032			ALL
	02	D40004J	W6122	D40004P	W8224			ALL
	03	D46044J	W6124	D46044P	W8226			ALL
	04	D40006J	W6124	D40006P	W8226			ALL
AL0720D	**DISCONNECT BRACKET-MAIN WHEEL WELL**					**004**	**717/200/R027**	**ALL**
	01	D46040J	W6124	D46040P	W8124			ALL
	02	D43102J	W5375	D43102P	W1032			ALL
	03	D46048J	W6228	D46048P	W8230			ALL
	04	D46050J	W6730	D46050P	W8524			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP0600A	**DISCONNECT BRACKET-P5-P6 INTEGRATION**					**010**	**270/280/R005**	**ALL**
	04	D40444J	W0044	D40444P	W6214			ALL
	05	D40226J	W0044	D40226P	W3058			ALL
	06	D40947J	W0041	D40947P	W2031			ALL
	08	D40528J	W6208	D40528P	W2212			ALL
	09	D40218J	W0044	D40218P	W0018			ALL
AP0600B	**DISCONNECT BRACKET-LOWER P6 PANEL**					**024**	**260/215/R040**	**ALL**
	01	D40067J	W0041					ALL
	02	D40750J	W0044	D40750P	W5158			ALL
	03	D40822J	W0044	D40822P	W5514			ALL
	04	D40708J	W0044	D40708P	W6212			ALL
	05	D41430J	W0044	D41430P	W2138			ALL
	06	D40623J	W0041	D40623P	W2135			ALL
	07	D46052J	W0044	D46052P	W2030			ALL
	08	D40800J	W0044	D40800P	W5506			ALL
	09	D40368J	W0044	D40368P	W6110			ALL
	10	D46067J	W0044	D46067P	W2231			ALL
	11	D41832J	W0044	D41832P	W6412			ALL
	12	D40812J	W0044	D40812P	W6506			ALL
	13	D40625J	W0041	D40625P	W2597			ALL
	14	D40386J	W0044	D40386P	W6412			ALL
	15	D46065J	W0044	D46065P	W2383			ALL
	16	D40352J	W0044	D40352P	W5612			ALL
	17	D40820J	W0044	D40820P	W6208			ALL
	18	D40816J	W0044	D40816P	W6206			ALL
	19	D46063J	W0044	D46063P	W2169			ALL
	20	D46069J	W0044	D46069P	W2661			ALL
	21	D40574J	W0044	D40574P	W6222			ALL
	22	D40396J	W0044	D40396P	W6414			ALL
	23	D46061J	W0044	D46061P	W2103			ALL
	24	D40654J	W0044	D40654P	W6024			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP0600C	**DISCONNECT BRACKET-UPPER P6 PANEL**					**010**	**260/275/R015**	**ALL**
	01	D40502J	W0044	D40502P	W2104			ALL
	02	D40526J	W0044	D40526P	W2212			ALL
	03	D40512J	W0044	D40512P	W2112			ALL
	04	D40532J	W0044	D40532P	W2216			ALL
	05	D40550J	W0044	D40550P	W2508			ALL
	06	D04151J	W0041	D04151P	W3327			ALL
	08	D40558J	W0044	D40558P	W2510			ALL
	09	D40536J	W0044	D40536P	W2218			ALL
	10	D40582J	W0044	D40582P	W2204			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP0700A	DISCONNECT BRACKET-P7 PANEL					002	P007-00/250/L005	ALL
AP0700B	DISCONNECT BRACKET-P7 PANEL					002	P007-00/250/R005	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP0900A	**DISCONNECT BRACKET-P9-FWD INSTR PANEL**					**027**	**190/214/0**	**ALL**
	01	D40914J	W0001	D40914P	W2022			ALL
	02	D40944J	W0001	D40944P	W5202			ALL
	03	D40804J	W0001	D40804P	W5506			ALL
	08	D04221J	W0001	D04221P	W2221			ALL
	09	D04207J	W0001	D04207P	W2207			ALL
	10	D40578J	W0001	D40578P	W5156			ALL
	13	D47111J	W0001	D47111P	W2008			ALL
	15	D41833J	W0001	D41833P	W2651			ALL
	19	D41877J	W0001	D41877P	W2207			ALL
	20	D46033J	W0003	D46033P	W2383			ALL
	21	D40824J	W0003	D40824P	W5514			ALL
	22	D04251J	W0003	D04251P	W2251			ALL
	23	D41874J	W0003	D41874P	W2383			ALL
	24	D47121J	W0003	D47121P	W2228			ALL
	25	D40924J	W0003	D40924P	W2030			ALL
	26	D04237J	W0003	D04237P	W2237			ALL
	30	D40580J	W0003	D40580P	W5160			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP1800A	**DISCONNECT BRACKET-P5-P18 INTEGRATION**					**010**	**270/280/L005**	**ALL**
	01	D40198J	W0018	D40198P	W3150			ALL
	04	D40524J	W0018	D40524P	W2212			ALL
	05	D40538J	W0018	D40538P	W2218			ALL
	06	D40220J	W0018	D40220P	W3144			ALL
	07	D40298J	W0018	D40298P	W4250			ALL
	08	D40504J	W0018	D40504P	W2104			ALL
	09	D40514J	W0018	D40514P	W2112			ALL
	10	D40522J	W0018	D40522P	W2114			ALL
	12	D40687J	W0018	D40687P	W3004			ALL
AP1800B	**DISCONNECT BRACKET-LOWER P18 PANEL**					**009**	**255/215/L040**	**ALL**
	01	D41805J	W0018	D41805P	W2201			ALL
	02	D40576J	W0018	D40576P	W5156			ALL
	03	D41801J	W0018	D41801P	W2101			ALL
	05	D40802J	W0018	D40802P	W5506			ALL
	06	D41803J	W0018	D41803P	W2175			ALL
	07	D40830J	W0018	D40830P	W5514			ALL
	08	D41807J	W0018	D41807P	W2651			ALL
	09	D41809J	W0018	D41809P	W2653			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AP2800A	**DISCONNECT BRACKET-P28 PANEL**					**001**	**724/172/R018**	**ALL**
	01			D48080	W8524			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AS0001	**DISCONNECT BRACKET-FIRE WALL**					**010**	**NS175/ /**	**ALL**
AS0001L	**DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)**					**010**	**NS175/135/L**	**ALL**
	01	D30260	W1168					ALL
	02	D30234	W1164					ALL
	03	D30220	W1166					ALL
	04	D30256	W1166					ALL
	05	D30252	W1170					ALL
	06	D30212	W1170					ALL
	07	D30224	W1172					ALL
AS0001R	**DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)**					**010**	**NS175/135/R**	**ALL**
	01	D30460	W1268					ALL
	02	D30434	W1264					ALL
	03	D30420	W1266					ALL
	04	D30456	W1266					ALL
	05	D30452	W1270					ALL
	06	D30412	W1270					ALL
	07	D30424	W1272					ALL
AS0002	**DISCONNECT BRACKET-LEFT SLEEVE**					**002**	**NR201/136/**	**ALL**
	01			D30008	W1082			ALL
	02			D30002	W1080			ALL
AS0002L	**DISCONNECT BRACKET-T/R LEFT STRUT**					**002**	**NS201/136/L**	**ALL**
	01	D30208	W1168					ALL
	02	D30202	W1172					ALL
AS0002R	**DISCONNECT BRACKET-T/R RIGHT STRUT**					**002**	**NS201/136/R**	**ALL**
	01	D30408	W1268					ALL
	02	D30402	W1272					ALL
AS0003	**DISCONNECT BRACKET RIGHT SLEEVE**					**002**	**NS201/136/**	**ALL**
	01			D30010	W1084			ALL
	02			D30006	W1086			ALL
AS0003L	**DISCONNECT BRACKET T/R LEFT STRUT**					**002**	**NS201/136/L**	**ALL**
	01	D30210	W1168					ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AS0003L	**DISCONNECT BRACKET T/R LEFT STRUT (continued)**					**002**	**NS201/136/L**	**ALL**
	02	D30206	W1172					ALL
AS0003R	**DISCONNECT BRACKET-T/R RIGHT STRUT**					**002**	**NS201/136/R**	**ALL**
	01	D30410	W1268					ALL
	02	D30406	W1272					ALL
AS0004L	**DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)**					**010**	**NS175/135/L**	**ALL**
	01			D30038	W1062			ALL
	01	D30238	W1162					ALL
AS0004R	**DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)**					**010**	**NS175/135/R**	**ALL**
	01	D30438	W1262					ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AW0219L	**DISCONNECT BRACKET-CLOSURE RIB(L-WING)**					**003**	**LES219/ /**	**ALL**
AW0219R	**DISCONNECT BRACKET-CLOSURE RIB(R-WING)**					**003**	**/ /**	**ALL**
AW0254L	**DISCONNECT BRACKET-LEFT WING STA 254**					**002**	**/ /**	**ALL**
	01	D40024J	W1024	D40024P	W1022			ALL
	02	D42714J	W1026	D42714P	W2026			ALL
	03	D42722J	W1040	D42722P	W2040			ALL
AW0254R	**DISCONNECT BRACKET-RIGHT WING STA 254**					**002**	**/ /**	**ALL**
	01	D40034J	W1034	D40034P	W1032			ALL
	02	D43714J	W1028	D43714P	W2028			ALL
	03	D43722J	W1042	D43722P	W2042			ALL
AW0258L	**DISCONNECT BRACKET**					**006**	**IFSS 217/ /**	**ALL**
				D30014	W1184			ALL
				D30016	W1164			ALL
				D30042	W1172			ALL
				D30048	W1178			ALL
				D30052	W1170			ALL
				D30062	W1182			ALL
				D30064	W1166			ALL
				D30068	W1192			ALL
				D30084	W1168			ALL
				D30092	W1190			ALL
	01	D08094J	W1186	D08094P	W1162			ALL
AW0258R	**DISCONNECT BRACKET**					**006**	**IFSS 217/ /**	**ALL**
				D30114	W1284			ALL
				D30116	W1264			ALL
				D30142	W1272			ALL
				D30148	W1278			ALL
				D30152	W1270			ALL
				D30162	W1282			ALL
				D30164	W1266			ALL
				D30168	W1292			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AW0258R	**DISCONNECT BRACKET (continued)**					**006**	**IFSS 217/ /**	**ALL**
				D30184	W1268			ALL
				D30192	W1290			ALL
	01	D08194J	W1286	D08194P	W1262			ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Bracket No.	Descrption					Max Pos	Station / WL / BL	Effectivity
	Position	Receptacle	Bundle	Plug	Bundle			
AW0742L	DISCONNECT BRACKET-LEFT WING STA 742					002	/ /	ALL
AW0742R	DISCONNECT BRACKET-RIGHT WING STA 742					002	/ /	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details