91-21-21

GROUND LIST

Section	Page	Date
EFFECTIVE PAGES		
	1 thru 3	Nov 14/2025
	4	BLANK
GB00000	1	May 15/2024
GB00100	1	May 15/2024
	2	May 15/2024
GB00200	1	May 15/2024
GB00300	1	May 15/2024
GB00400	1	May 15/2024
GB00500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
GB00600	1	May 15/2024
	2	May 15/2024
GB00800	1	May 15/2024
GB01000	1	May 15/2024
GB01100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
GB01100 (cont)		
	5	May 15/2024
	6	May 15/2024
GB01200	1	May 15/2024
	2	May 15/2024
GB01300	1	May 15/2024
GB01400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GB01500	1	May 15/2024
GB01800	1	May 15/2024
GB02100	1	May 15/2024
GB02200	1	May 15/2024
GB03000	1	May 15/2024
GB03100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
GB03200	1	May 15/2024
	2	May 15/2024
GB03300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GB03900	1	May 15/2024
GB04100	1	May 15/2024
	2	May 15/2024
GB04200	1	May 15/2024
GB05800	1	May 15/2024
GB06100	1	May 15/2024
GD00000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
GD00100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
GD00200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD00300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
GD00400	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
GD00400 (cont)		
	2	May 15/2024
	3	May 15/2024
GD00500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
GD00600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
GD00700	1	May 15/2024
GD00800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	Dec 24/2024
GD00900	1	May 15/2024
	2	May 15/2024
GD00900 (cont)		
	3	May 15/2024
GD01000	1	May 15/2024
	2	May 15/2024
GD01100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD01200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD01300	1	May 15/2024
	2	May 15/2024
GD01400	1	May 15/2024
	2	May 15/2024
GD01500	1	May 15/2024
GD01600	1	May 15/2024
GD01700	1	May 15/2024
GD01800	1	May 15/2024
GD01900	1	May 15/2024
GD02000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD02100	1	May 15/2024
	2	May 15/2024
GD02200	1	May 15/2024
GD02300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
GD02500	1	May 15/2024
GD02600	1	May 15/2024
GD02900	1	May 15/2024
GD03000	1	May 15/2024
	2	May 15/2024
GD03100	1	May 15/2024
GD03200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
GD03300	1	May 15/2024
	2	May 15/2024
GD03400	1	May 15/2024
GD03600	1	May 15/2024
GD03700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
GD03800	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
GD03800 (cont)		
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
GD03900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
GD04000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD04100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
GD04200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
GD04300	1	May 15/2024
GD04400	1	May 15/2024
GD04600	1	May 15/2024
GD04800	1	May 15/2024
GD05000	1	May 15/2024
GD05100	1	May 15/2024
	2	May 15/2024
GD05200	1	May 15/2024
	2	May 15/2024
GD05300	1	May 15/2024
GD05500	1	May 15/2024
GD06000	1	May 15/2024
GD06100	1	May 15/2024
GD06200	1	May 15/2024
GD06300	1	May 15/2024
GD06500	1	May 15/2024
GD07000	1	May 15/2024
GD07200	1	May 15/2024
GD07500	1	May 15/2024
GD08000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	Dec 24/2024
GD08100	1	May 15/2024
GD08200	1	May 15/2024
GD08400	1	Dec 24/2024
GD09000	1	May 15/2024
GD09100	1	May 15/2024
GD10000	1	May 15/2024
GD10100	1	May 15/2024
GD11000	1	May 15/2024
GD11100	1	May 15/2024
GD11300	1	May 15/2024
GD11700	1	May 15/2024
GD11800	1	May 15/2024
GD11900	1	May 15/2024
GD23300	1	May 15/2024
GD30100	1	May 15/2024
GD65200	1	May 15/2024
GD90200	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00020		**PARTOFTB0020**				**J020-0B/ /**	**ALL**
ST..	1A	W0072	2001Z			73-21-11	ALL
ST..	1A	W0072	2011Z			31-32-15	ALL
ST..	1A	W0072	2012Z			73-24-12	ALL
ST..	1A	W0072	2013Z			73-24-12	ALL
GB00022		**PARTOFTB0022**				**J022-00/ /**	**ALL**
GB00023		**PARTOFTB0023**				**J023-00/ /**	**ALL**
ST..	1A	W0078	0099	20		73-21-11	ALL
GB00024		**PARTOFTB0024**				**J024-00/ /**	**ALL**
DC..	1A	W0080	0055	20		74-11-11	ALL
DC..	1A	W0080	0059	20		74-11-11	ALL
GB00028		**PARTOFTB0028**				**J020-0A/ /**	**ALL**
GB00032		**PARTOFTB0032**				**J022-00/ /**	**ALL**
GB00033		**PARTOFTB0033**				**J023-00/ /**	**ALL**
GB00034		**PARTOFTB0034**				**J024-00/ /**	**ALL**
ST..	1A	W0080	1301Z			73-22-11	ALL
ST..	1A	W0080	1302Z			73-22-11	ALL
GB00053		**PARTOFTB0053**				**J023-00/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00101		**PARTOFTB0101**				**P001-00/ /**	**ALL**
ST..	1A	W0001	1012Z			26-11-21	ALL
ST..	1A	W0001	1013Z			26-11-21	ALL
ST..	1A	W0001	1014Z			26-11-21	ALL
ST..	1A	W0001	1015Z			26-11-21	ALL
ST..	1A	W0001	1016Z			26-11-21	ALL
ST..	1A	W0001	1017Z			34-61-16	ALL
ST..	1A	W0001	1018Z			34-61-16	ALL
ST..	1A	W0001	1020Z			34-61-16	ALL
ST..	1A	W0001	1021Z			34-61-16	ALL
ST..	1A	W0001	1023Z			34-61-16	ALL
ST..	1A	W0001	1024Z			34-61-16	ALL
ST..	1A	W0001	1100Z			22-14-11	ALL
ST..	1A	W0001	1162Z			34-49-11	ALL
ST..	1A	W0001	1163Z			34-49-11	ALL
ST..	1A	W0001	1164Z			34-49-11	ALL
ST..	1A	W0001	1165Z			34-49-11	ALL
ST..	1A	W0001	1578Z			22-14-11	ALL
ST..	1A	W0001	1579Z			22-14-11	ALL
ST..	1A	W0001	1580Z			22-14-11	ALL
ST..	1A	W0001	1581Z			22-14-11	ALL
ST..	1A	W0001	1582Z			22-14-11	ALL
ST..	1A	W0001	1583Z			22-14-11	ALL
ST..	1A	W0001	1584Z			22-14-11	ALL
ST..	1A	W0001	1585Z			22-14-11	ALL
ST..	1A	W0001	1586Z			22-14-11	ALL
ST..	1A	W0001	1588Z			22-14-11	ALL
ST..	1A	W0001	1597Z			22-14-11	ALL
ST..	1A	W0003	1001Z			34-61-16	ALL
ST..	1A	W0003	1002Z			34-61-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00101		**PARTOFTB0101 (continued)**				**P001-00/ /**	**ALL**
ST..	1A	W0003	1004Z			34-61-16	ALL
ST..	1A	W0003	1514Z			26-11-21	ALL
ST..	1A	W0003	1515Z			26-11-21	ALL
ST..	1A	W0003	1516Z			26-11-21	ALL
ST..	1A	W0003	1600Z			22-14-11	ALL
ST..	1A	W0003	1627Z			34-49-11	ALL
ST..	1A	W0003	1629Z			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00201		**PARTOFTB0201**				**P002-00/ /**	**ALL**
ST..	1A	W0001	1304Z			33-25-11	ALL
ST..	1A	W0001	1756Z			32-31-15	ALL
ST..	1A	W0001	1757Z			32-31-15	ALL
ST..	1A	W0001	1758Z			32-31-15	ALL
ST..	1A	W0001	1765Z			32-31-15	ALL
ST..	1A	W0001	1766Z			32-31-15	ALL
ST..	1A	W0001	1767Z			32-31-15	ALL
ST..	1A	W0001	1768Z			32-31-15	ALL
ST..	1A	W0001	1769Z			32-31-15	ALL
ST..	1A	W0001	1770Z			32-31-15	ALL
ST..	1A	W0003	1701Z			31-31-15	ALL
ST..	1A	W0003	1760Z			32-31-15	ALL
ST..	1A	W0003	1761Z			32-31-15	ALL
ST..	1A	W0003	1762Z			32-31-15	ALL
ST..	1A	W0003	1773Z			32-31-15	ALL
ST..	1A	W0003	1774Z			32-31-15	ALL
ST..	1A	W0003	1775Z			32-31-15	ALL
ST..	1A	W0003	1776Z			32-31-15	ALL
ST..	1A	W0003	1777Z			32-31-15	ALL
ST..	1A	W0003	1778Z			32-31-15	ALL
GB00205		**PARTOFTB0205**				**540/188/R025**	**ALL**
GB00261		**PARTOFTB0261**				**261/282/R005**	**ALL**
ST..	1A	W2112	2601Z			73-21-12	ALL
DC..	1A	W2114	A-AG			33-51-12	ALL
ST..	1A	W2216	2601Z			73-21-12	ALL
ST..	1A	W5172	2610Z			73-21-12	ALL
ST..	1A	W6172	2611Z			73-21-12	ALL
GB00262		**PARTOFTB0262**				**/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00301		**PARTOFTB0301**				**P003-00/ /**	**ALL**
ST..	1A	W0003	1579Z			22-14-11	ALL
ST..	1A	W0003	1580Z			22-14-11	ALL
ST..	1A	W0003	1581Z			22-14-11	ALL
ST..	1A	W0003	1582Z			22-14-11	ALL
ST..	1A	W0003	1583Z			22-14-11	ALL
ST..	1A	W0003	1585Z			22-14-11	ALL
ST..	1A	W0003	1586Z			22-14-11	ALL
ST..	1A	W0003	1587Z			22-14-11	ALL
ST..	1A	W0003	1588Z			22-14-11	ALL
ST..	1A	W0003	1589Z			22-14-11	ALL
ST..	1A	W0003	1590Z			22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00403		**PARTOFTB0403**				**J004-00/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00521		**PARTOFTB0521**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2502Z			34-61-11	ALL
ST..	1A	W0521	2506ZI			34-61-12	ALL
ST..	1A	W0521	2507ZI			34-61-12	ALL
ST..	1A	W0521	2576Z			31-65-15	ALL
ST..	1A	W0521	2628Z			34-61-11	ALL
ST..	1A	W0521	2637Z			34-61-11	ALL
ST..	1A	W0521	2638Z			34-61-11	ALL
ST..	1A	W0521	2803Z			34-58-11	ALL
ST..	1A	W0523	2512Z			34-61-14	ALL
ST..	1A	W0523	2707Z			34-61-14	ALL
ST..	1A	W0523	2712Z			34-61-14	ALL
ST..	1A	W0523	2716Z			34-61-15	ALL
ST..	1A	W0523	2717Z			34-61-18	ALL
ST..	1A	W0523	2724Z			34-21-23	ALL
ST..	1A	W0523	2726Z			34-21-23	ALL
ST..	1A	W0523	2727Z			34-21-23	ALL
ST..	1A	W0523	2728Z			34-21-23	ALL
ST..	1A	W0523	2729Z			34-21-23	ALL
ST..	1A	W0523	2730Z			34-21-23	ALL
ST..	1A	W0523	2733Z			34-21-23	ALL
ST..	1A	W0523	2734Z			34-21-23	ALL
ST..	1A	W0523	2736Z			34-21-23	ALL
ST..	1A	W0523	2737Z			34-21-23	ALL
ST..	1A	W0523	2739Z			34-21-24	ALL
ST..	1A	W0523	2740Z			34-21-24	ALL
ST..	1A	W0523	2742Z			34-21-24	ALL
ST..	1A	W0523	2743Z			34-21-24	ALL
ST..	1A	W0523	2745Z			34-21-24	ALL
ST..	1A	W0523	2747Z			34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00521		**PARTOFTB0521 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0523	2749Z			34-21-24	ALL
ST..	1A	W0523	2756Z			31-65-25	ALL
ST..	1A	W0523	2760Z			34-31-21	ALL
ST..	1A	W0523	2772Z			34-21-23	ALL
ST..	1A	W0523	2784Z			34-58-21	ALL
ST..	1A	W0523	2787Z			34-58-21	ALL
ST..	1A	W0523	2794Z			34-21-24	ALL
ST..	1A	W0523	2799Z			34-61-15	ALL
ST..	1A	W0523	2802Z			34-61-21	ALL
ST..	1A	W0523	2803Z			34-61-21	ALL
ST..	1A	W0523	2820Z			34-21-24	ALL
ST..	1A	W0523	2839Z			34-21-23	ALL
ST..	1A	W0523	2848Z			34-61-15	ALL
ST..	1A	W0523	2856Z			34-21-23	ALL
ST..	1A	W0523	2864Z			34-58-21	ALL
ST..	1A	W0523	2868Z			34-58-21	ALL
ST..	1A	W0523	4001Z			31-65-15	ALL
ST..	1A	W0523	4002Z			31-65-25	ALL
GB00522		**PARTOFTB0522**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2506ZO			34-61-12	ALL
ST..	1A	W0521	2507ZO			34-61-12	ALL
ST..	1A	W0521	2545Z			34-21-13	ALL
ST..	1A	W0521	2566Z			22-11-51	ALL
ST..	1A	W0521	2569Z			28-41-11	ALL
ST..	1A	W0521	2580Z			34-31-11	ALL
ST..	1A	W0521	2582Z			34-51-11	ALL
ST..	1A	W0521	2585Z			22-31-52	ALL
ST..	1A	W0521	2586Z			22-31-52	ALL
ST..	1A	W0521	2587Z			34-55-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00522		**PARTOFTB0522 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2588Z			34-55-11	ALL
ST..	1A	W0521	2589Z			34-55-11	ALL
ST..	1A	W0521	2597Z			22-31-52	ALL
ST..	1A	W0521	2608Z			34-58-11	ALL
ST..	1A	W0521	2614Z			34-58-11	ALL
ST..	1A	W0521	2615Z			34-58-11	ALL
ST..	1A	W0521	2616Z			34-58-11	ALL
ST..	1A	W0521	2726Z			46-13-11	ALL
ST..	1A	W0521	2803Z			34-58-11	ALL
ST..	1A	W0521	2804Z			34-58-11	ALL
ST..	1A	W0521	2808Z			34-58-11	ALL
ST..	1A	W0521	2913Z			34-61-18	ALL
ST..	1A	W0521	2914Z			34-61-18	ALL
ST..	1A	W0521	2915Z			34-61-18	ALL
ST..	1A	W0521	2919Z			34-61-12	ALL
ST..	1A	W0521	2920Z			34-61-12	ALL
ST..	1A	W0523	2702Z			34-61-11	ALL
ST..	1A	W0523	2703Z			34-61-11	ALL
ST..	1A	W0523	2764Z			34-55-21	ALL
ST..	1A	W0523	2765Z			34-55-21	ALL
ST..	1A	W0523	2770Z			34-61-15	ALL
ST..	1A	W0523	2771Z			34-55-21	ALL
ST..	1A	W0523	2828Z			31-32-15	ALL
ST..	1A	W0523	2829Z			31-32-15	ALL
ST..	1A	W0523	2831Z			34-61-18	ALL
ST..	1A	W0523	2833Z			34-61-26	ALL
ST..	1A	W0523	2862Z			34-51-21	ALL
ST..	1A	W0523	3601Z			34-21-22	ALL
ST..	1A	W0523	3602Z			34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00522		**PARTOFTB0522 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0523	3603Z			34-21-22	ALL
GB00523		**PARTOFTB0523**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2501Z			34-61-22	ALL
ST..	1A	W0521	2503Z			34-61-11	ALL
ST..	1A	W0521	2505Z			34-61-14	ALL
ST..	1A	W0521	2506ZI			34-61-12	ALL
ST..	1A	W0521	2507ZI			34-61-12	ALL
ST..	1A	W0521	2509Z			34-61-14	ALL
ST..	1A	W0521	2510Z			34-61-14	ALL
ST..	1A	W0521	2511Z			34-61-14	ALL
ST..	1A	W0521	2512Z			34-61-14	ALL
ST..	1A	W0521	2513Z			34-61-14	ALL
ST..	1A	W0521	2517Z			34-61-22	ALL
ST..	1A	W0521	2518Z			34-61-14	ALL
ST..	1A	W0521	2519Z			34-61-14	ALL
ST..	1A	W0521	2520Z			34-61-14	ALL
ST..	1A	W0521	2522Z			34-61-14	ALL
ST..	1A	W0521	2523Z			34-61-15	ALL
ST..	1A	W0521	2524Z			34-61-15	ALL
ST..	1A	W0521	2525Z			34-61-15	ALL
ST..	1A	W0521	2526Z			34-61-15	ALL
ST..	1A	W0521	2528Z			34-61-14	ALL
ST..	1A	W0521	2544Z			34-21-13	ALL
ST..	1A	W0521	2548Z			34-21-14	ALL
ST..	1A	W0521	2549Z			34-21-14	ALL
ST..	1A	W0521	2550Z			34-21-14	ALL
ST..	1A	W0521	2551Z			34-21-14	ALL
ST..	1A	W0521	2556Z			34-21-14	ALL
ST..	1A	W0521	2557Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00523		**PARTOFTB0523 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2558Z			34-21-14	ALL
ST..	1A	W0521	2559Z			34-21-14	ALL
ST..	1A	W0521	2575Z			31-65-15	ALL
ST..	1A	W0521	2579Z			34-31-11	ALL
ST..	1A	W0521	2581Z			34-51-11	ALL
ST..	1A	W0521	2592Z			34-61-22	ALL
ST..	1A	W0521	2593Z			34-61-14	ALL
ST..	1A	W0521	2594Z			34-61-14	ALL
ST..	1A	W0521	2595Z			34-61-15	ALL
ST..	1A	W0521	2624Z			34-61-21	ALL
ST..	1A	W0521	2625Z			34-61-21	ALL
ST..	1A	W0521	2640Z			34-61-22	ALL
ST..	1A	W0521	2716Z			34-21-14	ALL
ST..	1A	W0521	2725Z			46-13-11	ALL
ST..	1A	W0521	2744Z			34-61-15	ALL
ST..	1A	W0521	4006Z			31-65-15	ALL
ST..	1A	W0521	4007Z			31-65-25	ALL
ST..	1A	W0523	2755Z			31-65-25	ALL
ST..	1A	W0523	2764Z			34-55-21	ALL
GB00524		**PARTOFTB0524**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2504Z			34-61-11	ALL
ST..	1A	W0521	2506ZO			34-61-12	ALL
ST..	1A	W0521	2507ZO			34-61-12	ALL
ST..	1A	W0521	2527Z			34-61-18	ALL
ST..	1A	W0521	2529Z			34-61-15	ALL
ST..	1A	W0521	2533Z			34-21-13	ALL
ST..	1A	W0521	2535Z			34-21-13	ALL
ST..	1A	W0521	2537Z			34-21-13	ALL
ST..	1A	W0521	2538Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00524		**PARTOFTB0524 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2544Z			34-21-13	ALL
ST..	1A	W0521	2545Z			34-21-13	ALL
ST..	1A	W0521	2546Z			34-21-13	ALL
ST..	1A	W0521	2547Z			34-21-13	ALL
ST..	1A	W0521	2567Z			22-11-51	ALL
ST..	1A	W0521	2569Z			28-41-11	ALL
ST..	1A	W0521	2571Z			28-41-11	ALL
ST..	1A	W0521	2611Z			34-58-11	ALL
ST..	1A	W0521	2615Z			34-58-11	ALL
ST..	1A	W0521	2670Z			28-41-11	ALL
ST..	1A	W0521	2680Z			34-21-13	ALL
ST..	1A	W0521	2750Z			34-61-14	ALL
ST..	1A	W0521	2755Z			34-61-14	ALL
ST..	1A	W0521	2758Z			34-61-21	ALL
ST..	1A	W0521	2765Z			34-61-15	ALL
ST..	1A	W0521	2919Z			34-61-12	ALL
ST..	1A	W0521	2920Z			34-61-12	ALL
ST..	1A	W0521	3501Z			34-21-12	ALL
ST..	1A	W0521	3502Z			34-21-12	ALL
ST..	1A	W0521	3503Z			34-21-12	ALL
ST..	1A	W0523	2517Z			34-61-15	ALL
ST..	1A	W0523	2701Z			34-61-11	ALL
ST..	1A	W0523	2705Z			34-61-14	ALL
ST..	1A	W0523	2706Z			34-61-14	ALL
ST..	1A	W0523	2709Z			34-61-14	ALL
ST..	1A	W0523	2710Z			34-61-14	ALL
ST..	1A	W0523	2711Z			34-61-14	ALL
ST..	1A	W0523	2718Z			34-61-14	ALL
ST..	1A	W0523	2759Z			34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00524		**PARTOFTB0524 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0523	2766Z			34-61-11	ALL
ST..	1A	W0523	2767Z			34-61-11	ALL
ST..	1A	W0523	2768Z			34-61-14	ALL
ST..	1A	W0523	2769Z			34-61-14	ALL
ST..	1A	W0523	2832Z			34-61-26	ALL
ST..	1A	W0523	2861Z			34-51-21	ALL
ST..	1A	W0523	2864Z			34-58-21	ALL
GB00525		**PARTOFTB0525**				**E005-02/ /**	**ALL**
ST..	1A	W0523	2501Z			34-61-15	ALL
ST..	1A	W0523	2715Z			34-61-15	ALL
ST..	1A	W0523	2719Z			34-61-23	ALL
ST..	1A	W0523	2732Z			34-21-23	ALL
ST..	1A	W0523	2741Z			34-21-24	ALL
ST..	1A	W0523	2770Z			34-61-15	ALL
ST..	1A	W0523	2783Z			34-58-21	ALL
ST..	1A	W0523	2788Z			34-58-21	ALL
ST..	1A	W0523	2789Z			34-58-21	ALL
ST..	1A	W0523	2806Z			34-61-23	ALL
ST..	1A	W0523	2819Z			34-61-23	ALL
ST..	1A	W0523	2846Z			34-21-24	ALL
ST..	1A	W0523	2855Z			34-21-23	ALL
ST..	1A	W0523	2856Z			34-21-23	ALL
ST..	1A	W0523	2857Z			34-21-24	ALL
ST..	1A	W0523	2858Z			34-21-24	ALL
ST..	1A	W0523	2859Z			34-21-24	ALL
ST..	1A	W0523	2860Z			34-21-24	ALL
ST..	1A	W0523	2863Z			34-61-15	ALL
ST..	1A	W0523	2865Z			34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00526		**PARTOFTB0526**				**E005-02/ /**	**ALL**
GB00527		**PARTOFTB0527**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2536Z			34-21-13	ALL
ST..	1A	W0521	2540Z			34-21-13	ALL
ST..	1A	W0521	2554Z			34-21-14	ALL
ST..	1A	W0521	2630Z			34-61-23	ALL
ST..	1A	W0521	2632Z			23-27-35	ALL
ST..	1A	W0521	2643Z			34-61-22	ALL
ST..	1A	W0521	2651Z			23-27-32	ALL
ST..	1A	W0521	2652Z			23-27-32	ALL
ST..	1A	W0521	2667Z			34-61-23	ALL
ST..	1A	W0521	2669Z			23-15-15	ALL
ST..	1A	W0521	2671Z			23-15-15	ALL
ST..	1A	W0521	2680Z			34-21-13	ALL
ST..	1A	W0521	2688Z			34-21-13	ALL
ST..	1A	W0521	2708Z			34-21-14	ALL
ST..	1A	W0521	2709Z			34-21-13	ALL
ST..	1A	W0521	2716Z			34-21-14	ALL
ST..	1A	W0521	2724Z			46-13-11	ALL
ST..	1A	W0521	2725Z			46-13-11	ALL
ST..	1A	W0521	2726Z			46-13-11	ALL
ST..	1A	W0521	2749Z			34-21-14	ALL
ST..	1A	W0521	2752Z			23-15-15	ALL
ST..	1A	W0521	2811Z			34-61-23	ALL
ST..	1A	W0521	2916Z			34-61-26	ALL
ST..	1A	W0521	2918Z			34-61-22	ALL
GB00529		**PARTOFTB0529**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2516Z			31-32-15	ALL
ST..	1A	W0521	2529Z			34-61-15	ALL
ST..	1A	W0521	2541Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00529		**PARTOFTB0529 (continued)**				**E005-02/ /**	**ALL**
ST..	1A	W0521	2542Z			34-21-13	ALL
ST..	1A	W0521	2552Z			34-21-14	ALL
ST..	1A	W0521	2565Z			34-61-18	ALL
ST..	1A	W0521	2649Z			34-61-15	ALL
ST..	1A	W0521	2657Z			31-32-15	ALL
ST..	1A	W0521	2681Z			31-32-15	ALL
ST..	1A	W0521	2713Z			34-61-15	ALL
ST..	1A	W0521	2720Z			34-21-14	ALL
ST..	1A	W0521	2721Z			34-21-14	ALL
ST..	1A	W0521	2722Z			34-21-14	ALL
ST..	1A	W0521	2723Z			34-21-14	ALL
ST..	1A	W0521	2764Z			34-21-14	ALL
ST..	1A	W0521	2901Z			34-21-13	ALL
ST..	1A	W0521	2911Z			34-61-26	ALL
ST..	1A	W0521	2921Z			34-21-13	ALL
ST..	1A	W0521	2934Z			34-21-14	ALL
ST..	1A	W0521	2939Z			34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GB00606		**PARTOFTB0606**				**J046-00/ /**	**ALL**
ST..	1A	W2216	1301Z			73-21-12	ALL
ST..	1A	W2216	1302Z			73-21-12	ALL
ST..	1A	W2216	1303Z			73-21-12	ALL
ST..	1A	W2510	1201Z			30-21-32	ALL
ST..	1A	W5158	2601Z			78-32-61	ALL
ST..	1A	W5158	2602Z			78-32-61	ALL
ST..	1A	W6162	1201Z			30-21-32	ALL
ST..	1A	W6162	2614Z			78-32-61	ALL
ST..	1A	W6172	2601Z			78-32-61	ALL
GB00608		**PARTOFTB0608**				**J046-00/ /**	**ALL**
GB00610		**PARTOFTB0610**				**P006-00/ /**	**ALL**
ST..	1A	W0041	2504Z			31-32-15	ALL
ST..	1A	W0041	2533Z			31-32-15	ALL
ST..	1A	W0041	2546Z			31-65-26	ALL
ST..	1A	W0044	2011Z			23-42-14	ALL
ST..	1A	W0044	2570Z			31-65-26	ALL
GB00614		**PARTOFTB0614**				**268/175/R028**	**ALL**
ST..	1A	W5158	2501Z			78-32-61	ALL
ST..	1A	W5160	2503Z			78-32-61	ALL
ST..	1A	W6162	2613Z			78-32-61	ALL
ST..	1A	W6172	2615Z			78-32-61	ALL
GB00621		**PARTOFTB0621**				**E006-02/ /**	**ALL**
ST..	1A	W0621	2020ZO			23-22-11	ALL
ST..	1A	W0621	2501ZO			23-11-11	ALL
ST..	1A	W0621	2502ZO			23-11-11	ALL
ST..	1A	W0621	2506Z			23-11-11	ALL
ST..	1A	W0621	2508Z			23-12-41	ALL
ST..	1A	W0621	2509Z			23-12-41	ALL
ST..	1A	W0621	2511Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00621		**PARTOFTB0621 (continued)**				**E006-02/ /**	**ALL**
ST..	1A	W0623	2510Z			23-12-41	ALL
ST..	1A	W0623	2519Z			23-12-41	ALL
ST..	1A	W0623	2529Z			23-12-41	ALL
GB00660		**PARTOFTB0660**				**J046-00/ /**	**ALL**
GB00662		**PARTOFTB0662**				**J046-00/ /**	**ALL**
GB00664		**PARTOFTB0664**				**J046-00/ /**	**ALL**
GB00666		**PARTOFTB0666**				**J046-00/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB00801		**PARTOFTB0801**				**J38/ /**	**ALL**
GB00803		**PARTOFTB0803**				***/*/***	**ALL**
GB00804		**PARTOFTB0804**				***/*/***	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01092		**PARTOFTB1092**				**P001-01/ /**	**ALL**
ST..	1A	W0001	1009Z			33-11-32	ALL
ST..	1A	W0003	1686Z			33-18-21	ALL
ST..	1A	W0003	1687Z			33-18-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01101		**PARTOFTB1101**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2003Z			34-33-21	ALL
ST..	1A	W0111	2004Z			34-33-21	ALL
ST..	1A	W0111	2005Z			34-33-21	ALL
GB01102		**PARTOFTB1102**				**E001-01/ /**	**ALL**
ST..	1A	W0111	1032Z			27-25-11	ALL
ST..	1A	W0111	1033Z			27-25-11	ALL
ST..	1A	W0111	1035Z			27-25-11	ALL
ST..	1A	W0111	1036Z			27-25-11	ALL
GB01103		**PARTOFTB1103**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2038Z			22-12-31	ALL
ST..	1A	W0111	2058Z			34-45-11	ALL
ST..	1A	W0111	2070Z			34-45-21	ALL
ST..	1A	W0111	2071Z			34-45-21	ALL
ST..	1A	W0111	2072Z			34-45-21	ALL
ST..	1A	W0111	2073Z			34-45-21	ALL
ST..	1A	W0111	2175ZO			34-45-21	ALL
ST..	1A	W0111	2229Z			22-12-31	ALL
ST..	1A	W0111	2303Z			22-12-31	ALL
ST..	1A	W0111	2304Z			22-12-31	ALL
ST..	1A	W0111	2305Z			22-12-31	ALL
GB01104		**PARTOFTB1104**				**E001-01/ /**	**ALL**
ST..	1A	W0111	1001Z			22-11-11	ALL
ST..	1A	W0111	1002Z			22-11-11	ALL
ST..	1A	W0111	1014Z			22-12-31	ALL
ST..	1A	W0111	2002Z			34-33-21	ALL
ST..	1A	W0111	2030Z			22-11-51	ALL
ST..	1A	W0111	2031Z			22-11-51	ALL
ST..	1A	W0111	2037Z			22-12-31	ALL
ST..	1A	W0111	2039Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01104		**PARTOFTB1104 (continued)**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2042Z			22-18-11	ALL
ST..	1A	W0111	2078Z			34-55-11	ALL
ST..	1A	W0111	2088Z			22-31-52	ALL
ST..	1A	W0111	2089Z			22-31-52	ALL
ST..	1A	W0111	2090Z			22-31-52	ALL
ST..	1A	W0111	2091Z			22-31-52	ALL
ST..	1A	W0111	2092Z			22-31-52	ALL
ST..	1A	W0111	2093Z			22-31-52	ALL
ST..	1A	W0111	2094Z			22-31-52	ALL
ST..	1A	W0111	2103Z			34-21-13	ALL
ST..	1A	W0111	2108Z			34-21-14	ALL
ST..	1A	W0111	2122Z			34-31-11	ALL
ST..	1A	W0111	2124Z			34-31-21	ALL
ST..	1A	W0111	2126Z			34-51-11	ALL
ST..	1A	W0111	2128Z			31-65-15	ALL
ST..	1A	W0111	2130Z			31-65-25	ALL
ST..	1A	W0111	2219Z			22-11-53	ALL
ST..	1A	W0111	2221Z			31-32-15	ALL
ST..	1A	W0111	2298Z			34-51-11	ALL
ST..	1A	W0111	2299Z			34-51-11	ALL
ST..	1A	W0111	3004Z			22-12-31	ALL
ST..	1A	W0113	1003Z			22-13-11	ALL
GB01105		**PARTOFTB1105**				**E001-01/ /**	**ALL**
ST..	1A	W0111	1021Z			22-11-31	ALL
ST..	1A	W0111	2006Z			22-11-31	ALL
ST..	1A	W0111	2011Z			22-11-31	ALL
ST..	1A	W0111	2013Z			22-11-31	ALL
ST..	1A	W0111	2032Z			22-11-51	ALL
ST..	1A	W0111	2033Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01105		**PARTOFTB1105 (continued)**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2084Z			22-31-31	ALL
ST..	1A	W0111	2085Z			22-31-41	ALL
ST..	1A	W0111	2086Z			22-31-41	ALL
ST..	1A	W0111	2087Z			22-31-41	ALL
ST..	1A	W0111	2116Z			34-21-24	ALL
ST..	1A	W0111	2133Z			73-24-11	ALL
ST..	1A	W0111	2134Z			73-24-11	ALL
ST..	1A	W0111	2135Z			73-24-21	ALL
ST..	1A	W0111	2136Z			73-24-21	ALL
ST..	1A	W0111	2220Z			31-32-15	ALL
ST..	1A	W0111	2221Z			31-32-15	ALL
ST..	1A	W0111	2222Z			31-32-15	ALL
ST..	1A	W0111	2290Z			31-32-15	ALL
ST..	1A	W0111	2296Z			22-11-51	ALL
ST..	1A	W0111	2297Z			22-11-51	ALL
ST..	1A	W0111	2333Z			22-11-51	ALL
ST..	1A	W0111	3001Z			22-11-31	ALL
ST..	1A	W0111	3002Z			22-11-31	ALL
ST..	1A	W0111	3003Z			22-12-31	ALL
GB01106		**PARTOFTB1106**				**E001-01/ /**	**ALL**
ST..	1A	W0111	1017Z			22-11-31	ALL
ST..	1A	W0111	1018Z			22-11-31	ALL
ST..	1A	W0111	1019Z			22-11-31	ALL
ST..	1A	W0111	2015Z			22-11-51	ALL
ST..	1A	W0111	2016Z			22-11-51	ALL
ST..	1A	W0111	2017Z			22-11-51	ALL
ST..	1A	W0111	2018Z			22-11-51	ALL
ST..	1A	W0111	2019Z			22-11-51	ALL
ST..	1A	W0111	2055Z			34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01106		**PARTOFTB1106 (continued)**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2056Z			34-33-11	ALL
ST..	1A	W0111	2057Z			34-33-11	ALL
ST..	1A	W0111	2067Z			34-45-11	ALL
ST..	1A	W0111	2068Z			34-45-11	ALL
ST..	1A	W0111	2069Z			34-45-11	ALL
ST..	1A	W0113	1001Z			22-13-11	ALL
ST..	1A	W0113	1002Z			22-13-11	ALL
ST..	1A	W0113	1003Z			22-13-11	ALL
GB01107		**PARTOFTB1107**				**E001-01/ /**	**ALL**
ST..	1A	W0111	1012Z			22-12-31	ALL
ST..	1A	W0111	1013Z			22-12-31	ALL
ST..	1A	W0111	1015Z			22-12-31	ALL
ST..	1A	W0111	2042Z			22-18-11	ALL
ST..	1A	W0111	2043Z			22-18-11	ALL
ST..	1A	W0111	2044Z			22-18-11	ALL
GB01108		**PARTOFTB1108**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2064Z			34-33-11	ALL
ST..	1A	W0111	2065Z			34-33-11	ALL
ST..	1A	W0111	2066Z			34-33-11	ALL
ST..	1A	W0111	2075Z			34-49-11	ALL
ST..	1A	W0111	2076Z			34-49-11	ALL
ST..	1A	W0111	2077Z			34-49-11	ALL
GB01109		**PARTOFTB1109**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2051Z			27-32-12	ALL
ST..	1A	W0111	2053Z			27-32-12	ALL
ST..	1A	W0111	2054Z			27-32-12	ALL
ST..	1A	W0111	2079Z			22-31-31	ALL
ST..	1A	W0111	2080Z			22-31-31	ALL
ST..	1A	W0111	2081Z			22-31-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01109		**PARTOFTB1109 (continued)**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2111Z			34-21-23	ALL
ST..	1A	W0111	2113Z			34-21-23	ALL
ST..	1A	W0111	2114Z			34-21-23	ALL
ST..	1A	W0111	2115Z			34-21-23	ALL
ST..	1A	W0111	2207Z			34-21-23	ALL
GB01110		**PARTOFTB1110**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2020Z			22-11-51	ALL
ST..	1A	W0111	2021Z			22-11-51	ALL
ST..	1A	W0111	2022Z			22-11-51	ALL
ST..	1A	W0111	2023Z			22-11-51	ALL
ST..	1A	W0111	2024Z			22-11-51	ALL
ST..	1A	W0111	2025Z			22-11-51	ALL
ST..	1A	W0111	2026Z			22-11-51	ALL
ST..	1A	W0111	2028Z			22-11-51	ALL
ST..	1A	W0111	2029Z			22-11-51	ALL
ST..	1A	W0111	2045Z			22-11-51	ALL
ST..	1A	W0111	2046Z			22-11-51	ALL
ST..	1A	W0111	2059Z			22-11-51	ALL
ST..	1A	W0111	2095Z			34-21-13	ALL
ST..	1A	W0111	2097Z			34-21-13	ALL
ST..	1A	W0111	2098Z			34-21-13	ALL
ST..	1A	W0111	2099Z			34-21-13	ALL
ST..	1A	W0111	2101Z			34-21-13	ALL
ST..	1A	W0111	2102Z			34-21-13	ALL
ST..	1A	W0111	2104Z			34-21-14	ALL
ST..	1A	W0111	2105Z			34-21-14	ALL
ST..	1A	W0111	2107Z			34-21-14	ALL
ST..	1A	W0111	2171Z			22-11-51	ALL
ST..	1A	W0111	2230Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01110		**PARTOFTB1110 (continued)**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2287Z			22-11-51	ALL
GB01111		**PARTOFTB1111**				**E001-01/ /**	**ALL**
ST..	1A	W0111	2241Z			21-31-24	ALL
ST..	1A	W0111	2242Z			21-31-24	ALL
ST..	1A	W0111	2243Z			21-31-24	ALL
ST..	1A	W0111	2244Z			21-31-24	ALL
ST..	1A	W0111	2245Z			21-31-24	ALL
ST..	1A	W0111	2246Z			21-31-24	ALL
ST..	1A	W0111	2247Z			21-31-24	ALL
ST..	1A	W0111	2248Z			21-31-24	ALL
ST..	1A	W0111	2253Z			27-32-22	ALL
ST..	1A	W0111	2254Z			27-32-12	ALL
ST..	1A	W0111	2255Z			34-21-14	ALL
ST..	1A	W0111	2256Z			34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01201		**PARTOFTB1201**				**E001-02/ /**	**ALL**
ST..	1A	W0121	2014Z			34-31-11	ALL
ST..	1A	W0121	2015Z			34-31-11	ALL
ST..	1A	W0121	2016Z			34-31-11	ALL
ST..	1A	W0121	2017Z			34-31-11	ALL
ST..	1A	W0121	2018Z			34-31-11	ALL
ST..	1A	W0121	2020Z			34-31-11	ALL
ST..	1A	W0121	2021Z			34-31-11	ALL
ST..	1A	W0121	2036Z			34-31-11	ALL
ST..	1A	W0121	2037Z			34-31-11	ALL
ST..	1A	W0121	2038Z			34-31-11	ALL
ST..	1A	W0121	2085Z			34-31-11	ALL
ST..	1A	W0121	2086Z			34-31-11	ALL
GB01202		**PARTOFTB1202**				**E001-02/ /**	**ALL**
ST..	1A	W0121	2001Z			34-53-11	ALL
ST..	1A	W0121	2004Z			34-45-21	ALL
ST..	1A	W0121	2005Z			34-45-21	ALL
ST..	1A	W0121	2022Z			34-53-11	ALL
ST..	1A	W0121	2042Z			34-58-11	ALL
ST..	1A	W0121	2043Z			34-58-11	ALL
ST..	1A	W0121	2059Z			34-58-11	ALL
ST..	1A	W0121	2062Z			34-45-21	ALL
ST..	1A	W0121	2064Z			34-45-21	ALL
ST..	1A	W0121	2065Z			34-58-11	ALL
ST..	1A	W0121	2090Z			34-58-11	ALL
ST..	1A	W0121	2091Z			34-58-11	ALL
ST..	1A	W0121	2092Z			34-21-14	ALL
ST..	1A	W0121	2095Z			34-21-24	ALL
ST..	1A	W0121	2500Z			34-53-11	ALL
ST..	1A	W0121	2510Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01202		**PARTOFTB1202 (continued)**				**E001-02/ /**	**ALL**
ST..	1A	W0121	2511Z			34-21-13	ALL
ST..	1A	W0121	2514Z			34-61-14	ALL
ST..	1A	W0121	2515Z			34-53-11	ALL
ST..	1A	W0121	2516Z			31-31-13	ALL
ST..	1A	W0121	2518Z			34-53-11	ALL
GB01203		**PARTOFTB1203**				**E001-02/ /**	**ALL**
GB01204		**PARTOFTB1204**				**E001-02/ /**	**ALL**
ST..	1A	W0121	2006Z			34-55-11	ALL
ST..	1A	W0121	2007Z			34-55-11	ALL
ST..	1A	W0121	2008Z			34-55-11	ALL
ST..	1A	W0121	2009ZO			34-55-11	ALL
ST..	1A	W0121	2011Z			34-55-11	ALL
ST..	1A	W0121	2012Z			34-55-11	ALL
ST..	1A	W0121	2013Z			34-55-11	ALL
ST..	1A	W0121	2034Z			34-55-11	ALL
ST..	1A	W0121	2045Z			34-61-14	ALL
ST..	1A	W0121	2089Z			34-51-11	ALL
ST..	1A	W0121	2514Z			34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01301		**PARTOFTB1301**				**E001-03/ /**	**ALL**
ST..	1A	W0131	2502ZO			23-12-11	ALL
ST..	1A	W0131	2503ZO			23-12-11	ALL
ST..	1A	W0131	2504ZO			23-22-11	ALL
ST..	1A	W0131	2519Z			23-12-41	ALL
ST..	1A	W0131	2525Z			23-12-11	ALL
ST..	1A	W0137	2501Z			23-12-41	ALL
GB01302		**PARTOFTB1302**				**E001-03/ /**	**ALL**
GB01303		**PARTOFTB1303**				**E001-03/ /**	**ALL**
ST..	1A	W0131	2060Z			34-21-13	ALL
ST..	1A	W0131	2066Z			34-21-13	ALL
ST..	1A	W0131	2508Z			34-21-13	ALL
ST..	1A	W0131	2509Z			34-21-23	ALL
ST..	1A	W0131	2510Z			32-41-11	ALL
ST..	1A	W0131	2511Z			32-41-11	ALL
ST..	1A	W0131	2512Z			32-41-11	ALL
ST..	1A	W0131	2513Z			32-41-11	ALL
ST..	1A	W0131	2514Z			32-42-11	ALL
GB01304		**PARTOFTB1304**				**E001-03/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01401		**PARTOFTB1401**				**E001-04/ /**	**ALL**
ST..	1A	W0141	0066Z			22-11-31	ALL
ST..	1A	W0141	0067Z			22-11-31	ALL
ST..	1A	W0141	0068Z			22-11-31	ALL
ST..	1A	W0141	0089Z			22-12-41	ALL
ST..	1A	W0141	0090Z			22-12-41	ALL
ST..	1A	W0141	0091Z			22-12-41	ALL
ST..	1A	W0141	0092Z			22-12-41	ALL
ST..	1A	W0141	1012Z			22-11-11	ALL
ST..	1A	W0141	2027Z			22-11-51	ALL
ST..	1A	W0141	2028Z			22-11-51	ALL
ST..	1A	W0141	2033Z			22-12-41	ALL
ST..	1A	W0141	2034Z			22-12-41	ALL
ST..	1A	W0141	2035Z			22-12-41	ALL
ST..	1A	W0141	2036Z			22-12-41	ALL
ST..	1A	W0141	2057Z			34-21-14	ALL
ST..	1A	W0141	2084Z			22-11-51	ALL
ST..	1A	W0141	2085Z			22-11-51	ALL
ST..	1A	W0141	2152Z			34-55-21	ALL
ST..	1A	W0141	2301Z			34-31-11	ALL
ST..	1A	W0141	2362Z			31-65-15	ALL
ST..	1A	W0141	3004Z			22-12-41	ALL
ST..	1A	W0141	3005Z			22-12-41	ALL
ST..	1A	W0149	1001Z			22-13-11	ALL
GB01402		**PARTOFTB1402**				**E001-04/ /**	**ALL**
ST..	1A	W0141	0065Z			22-11-31	ALL
ST..	1A	W0141	0066Z			22-11-31	ALL
ST..	1A	W0141	1011Z			22-11-11	ALL
ST..	1A	W0141	2001Z			22-11-11	ALL
ST..	1A	W0141	2008Z			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01402		**PARTOFTB1402 (continued)**				**E001-04/ /**	**ALL**
ST..	1A	W0141	2014Z			22-11-31	ALL
ST..	1A	W0141	2015Z			22-11-31	ALL
ST..	1A	W0141	2016Z			22-11-51	ALL
ST..	1A	W0141	2020Z			22-11-51	ALL
ST..	1A	W0141	2021Z			22-11-51	ALL
ST..	1A	W0141	2022Z			22-11-51	ALL
ST..	1A	W0141	2023Z			22-11-51	ALL
ST..	1A	W0141	2025Z			22-11-51	ALL
ST..	1A	W0141	2026Z			22-11-51	ALL
ST..	1A	W0141	2039Z			27-32-22	ALL
ST..	1A	W0141	2048Z			31-32-15	ALL
ST..	1A	W0141	2049Z			31-32-15	ALL
ST..	1A	W0141	2050Z			31-32-15	ALL
ST..	1A	W0141	2051Z			22-11-53	ALL
ST..	1A	W0141	2058Z			34-33-11	ALL
ST..	1A	W0141	2101Z			22-31-52	ALL
ST..	1A	W0141	2102Z			34-21-13	ALL
ST..	1A	W0141	2104Z			34-21-24	ALL
ST..	1A	W0141	2304Z			34-31-21	ALL
ST..	1A	W0141	2318Z			34-51-21	ALL
ST..	1A	W0141	2363Z			31-65-25	ALL
ST..	1A	W0141	3001Z			22-11-31	ALL
ST..	1A	W0141	3002Z			22-11-31	ALL
ST..	1A	W0141	3003Z			22-12-41	ALL
GB01403		**PARTOFTB1403**				**E001-04/ /**	**ALL**
ST..	1A	W0141	2304Z			34-31-21	ALL
ST..	1A	W0141	2305Z			34-31-21	ALL
ST..	1A	W0141	2306Z			34-31-21	ALL
ST..	1A	W0141	2307Z			34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01403		**PARTOFTB1403 (continued)**				**E001-04/ /**	**ALL**
ST..	1A	W0141	2308Z			34-31-21	ALL
ST..	1A	W0141	2309Z			34-31-21	ALL
ST..	1A	W0141	2310Z			34-31-21	ALL
ST..	1A	W0141	2311Z			34-31-21	ALL
ST..	1A	W0141	2312Z			34-31-21	ALL
ST..	1A	W0141	2313Z			34-31-21	ALL
ST..	1A	W0141	2318Z			34-51-21	ALL
ST..	1A	W0141	2328Z			34-51-21	ALL
ST..	1A	W0141	2329Z			34-51-21	ALL
GB01404		**PARTOFTB1404**				**E001-04/ /**	**ALL**
ST..	1A	W0141	2017Z			22-11-51	ALL
ST..	1A	W0141	2018Z			22-11-51	ALL
ST..	1A	W0141	2019Z			22-11-51	ALL
ST..	1A	W0141	2024Z			22-11-51	ALL
ST..	1A	W0141	2034Z			22-12-41	ALL
ST..	1A	W0141	2041Z			34-58-21	ALL
ST..	1A	W0141	2043Z			34-58-21	ALL
ST..	1A	W0141	2059Z			22-12-41	ALL
ST..	1A	W0141	2063Z			34-58-21	ALL
ST..	1A	W0141	2074Z			22-11-51	ALL
ST..	1A	W0141	2083Z			34-58-21	ALL
ST..	1A	W0141	2086Z			34-58-21	ALL
ST..	1A	W0141	2087Z			34-58-21	ALL
ST..	1A	W0141	2097Z			22-12-41	ALL
ST..	1A	W0141	2098Z			22-12-41	ALL
ST..	1A	W0141	2099Z			22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01501		**PARTOFTB1501**				**E005-01/ /**	**ALL**
ST..	1A	W0151	2006Z			34-55-21	ALL
ST..	1A	W0151	2007Z			34-55-21	ALL
ST..	1A	W0151	2008Z			34-55-21	ALL
ST..	1A	W0151	2009ZO			34-55-21	ALL
ST..	1A	W0151	2011Z			34-55-21	ALL
ST..	1A	W0151	2012Z			34-55-21	ALL
ST..	1A	W0151	2013Z			34-55-21	ALL
ST..	1A	W0151	2014Z			34-51-21	ALL
ST..	1A	W0151	2015Z			34-55-21	ALL
ST..	1A	W0151	2020Z			34-61-14	ALL
ST..	1A	W0151	2058Z			34-61-14	ALL
GB01502		**PARTOFTB1502**				**E001-05/ /**	**ALL**
GB01503		**PARTOFTB1503**				**E001-05/ /**	**ALL**
GB01504		**PARTOFTB1504**				**E001-05/ /**	**ALL**
ST..	1A	W0151	2001Z			34-53-21	ALL
ST..	1A	W0151	2002Z			34-21-23	ALL
ST..	1A	W0151	2004Z			34-45-21	ALL
ST..	1A	W0151	2005Z			34-45-21	ALL
ST..	1A	W0151	2016Z			34-21-14	ALL
ST..	1A	W0151	2017Z			34-21-24	ALL
ST..	1A	W0151	2018Z			34-21-24	ALL
ST..	1A	W0151	2019Z			34-21-24	ALL
ST..	1A	W0151	2023Z			34-45-21	ALL
ST..	1A	W0151	2024Z			34-45-21	ALL
ST..	1A	W0151	2056Z			22-11-51	ALL
ST..	1A	W0151	2058Z			34-61-14	ALL
ST..	1A	W0151	2059Z			34-53-21	ALL
ST..	1A	W0151	2062Z			34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB01806		**PARTOFTB1806**				**261/ /**	**ALL**
ST..	1A	W2363	1026Z			33-18-51	ALL
GB01808		**PARTOFTB1808**				**261/172/L025**	**ALL**
ST..	1A	W3323	2504ZO			34-41-11	ALL
ST..	1A	W5162	2613Z			78-32-51	ALL
ST..	1A	W5172	2602Z			78-32-51	ALL
ST..	1A	W5510	2601Z			78-32-51	ALL
ST..	1A	W5510	2602Z			78-32-51	ALL
ST..	1A	W6491	2201ZO			34-41-11	ALL
GB01882		**PARTOFTB1882**				**AJ0048A/ /**	**ALL**
ST..	1A	W0088	1001Z			73-21-12	ALL
ST..	1A	W0088	1002Z			73-21-12	ALL
ST..	1A	W0088	1003Z			73-21-12	ALL
GB01884		**PARTOFTB1884**				**AJ0048A/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB02101		**PARTOFTB2101**				**E002-01/ /**	**ALL**
ST..	1A	W0212	2032Z			34-33-11	ALL
ST..	1A	W0212	2033Z			34-33-11	ALL
ST..	1A	W0212	2034Z			34-33-11	ALL
ST..	1A	W0212	2035Z			34-33-11	ALL
ST..	1A	W0212	2036Z			34-33-11	ALL
ST..	1A	W0212	2037Z			34-33-11	ALL
ST..	1A	W0212	2038Z			34-33-11	ALL
ST..	1A	W0212	2401Z			34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB02201		**PARTOFTB2201**				**E002-02/ /**	**ALL**
ST..	1A	W0220	2031Z			73-24-11	ALL
ST..	1A	W0220	2032Z			73-24-11	ALL
ST..	1A	W0220	2033Z			73-24-11	ALL
ST..	1A	W0220	2044Z			73-24-11	ALL
ST..	1A	W0220	2045Z			73-24-11	ALL
ST..	1A	W0220	2046Z			73-24-11	ALL
ST..	1A	W0220	2501Z			36-21-11	ALL
ST..	1A	W0220	2502Z			36-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03044		**PARTOFTB3044**				**420/205/R040**	**ALL**
ST..	1A	W2207	2012Z			28-41-11	ALL
ST..	1A	W5158	2015Z			28-41-11	ALL
ST..	1A	W5501	2504Z			34-61-14	ALL
ST..	1A	W5501	2505Z			28-41-11	ALL
ST..	1A	W5586	2601Z			28-41-11	ALL
ST..	1A	W6572	2601Z			28-41-11	ALL
ST..	1A	W6572	2602Z			34-61-14	ALL
ST..	1A	W6572	2603Z			28-41-11	ALL
GB03046		**PARTOFTB3046**				**427/ /**	**ALL**
GB03092		**PARTOFTB3092**				**P003-01/ /**	**ALL**
ST..	1A	W0001	1249Z			33-18-51	ALL
ST..	1A	W0003	1685Z			33-18-21	ALL
ST..	1A	W0003	1695Z			33-18-22	ALL
ST..	1A	W0003	1696Z			33-18-22	ALL
ST..	1A	W0003	1699Z			33-18-24	ALL
ST..	1A	W0003	1700Z			33-18-24	ALL
ST..	1A	W0003	1702Z			33-18-24	ALL
ST..	1A	W0003	1706Z			33-18-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03101		**PARTOFTB3101**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2002Z			31-65-12	ALL
ST..	1A	W0311	2003Z			31-65-12	ALL
ST..	1A	W0311	2005Z			31-65-12	ALL
ST..	1A	W0311	2006Z			31-65-12	ALL
ST..	1A	W0311	2007Z			31-65-12	ALL
ST..	1A	W0311	2009Z			31-65-12	ALL
ST..	1A	W0311	2010Z			31-65-13	ALL
ST..	1A	W0311	2011Z			31-65-13	ALL
ST..	1A	W0311	2012Z			31-65-13	ALL
ST..	1A	W0311	2014Z			31-65-15	ALL
ST..	1A	W0311	2015Z			31-65-15	ALL
ST..	1A	W0311	2016Z			31-65-15	ALL
ST..	1A	W0311	2017Z			31-65-15	ALL
ST..	1A	W0311	2018Z			31-65-15	ALL
ST..	1A	W0311	2019Z			31-65-15	ALL
ST..	1A	W0311	2020Z			31-65-15	ALL
ST..	1A	W0311	2021Z			31-65-15	ALL
ST..	1A	W0311	2022Z			31-65-15	ALL
ST..	1A	W0311	2026Z			31-65-15	ALL
ST..	1A	W0311	2027Z			31-65-15	ALL
ST..	1A	W0311	2028Z			31-65-15	ALL
ST..	1A	W0311	2029Z			31-65-15	ALL
ST..	1A	W0311	2053Z			28-41-11	ALL
ST..	1A	W0311	2054Z			28-41-11	ALL
ST..	1A	W0311	2055Z			28-41-11	ALL
ST..	1A	W0311	2061Z			28-41-11	ALL
ST..	1A	W0311	2062Z			28-41-11	ALL
ST..	1A	W0311	2081Z			34-57-11	ALL
ST..	1A	W0311	2082Z			34-57-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03101		**PARTOFTB3101 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2083Z			34-57-11	ALL
ST..	1A	W0311	2085Z			31-35-02	ALL
ST..	1A	W0311	2086Z			31-35-02	ALL
ST..	1A	W0311	2087Z			31-35-02	ALL
ST..	1A	W0311	2093Z			34-55-11	ALL
ST..	1A	W0311	2094Z			34-55-11	ALL
ST..	1A	W0311	2095Z			34-55-11	ALL
ST..	1A	W0311	2096Z			34-31-11	ALL
ST..	1A	W0311	2097Z			34-31-11	ALL
ST..	1A	W0311	2099Z			34-31-11	ALL
ST..	1A	W0311	2136Z			34-45-11	ALL
ST..	1A	W0311	2137Z			34-45-11	ALL
ST..	1A	W0311	2138Z			34-45-11	ALL
ST..	1A	W0311	2144Z			34-41-11	ALL
ST..	1A	W0311	2145Z			34-41-11	ALL
ST..	1A	W0311	2155Z			31-35-02	ALL
ST..	1A	W0311	2156Z			27-81-41	ALL
ST..	1A	W0311	2157Z			27-81-41	ALL
ST..	1A	W0311	2159Z			23-27-38	ALL
ST..	1A	W0311	2160Z			23-27-38	ALL
ST..	1A	W0311	2161Z			23-27-38	ALL
ST..	1A	W0311	2181Z			31-65-15	ALL
ST..	1A	W0311	2182Z			34-57-11	ALL
ST..	1A	W0311	2202Z			32-46-11	ALL
ST..	1A	W0311	2203Z			32-46-11	ALL
ST..	1A	W0311	2204Z			32-46-11	ALL
ST..	1A	W0311	2273Z			31-65-15	ALL
ST..	1A	W0311	2706Z			31-65-15	ALL
ST..	1A	W0311	2707Z			31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03101		**PARTOFTB3101 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2708Z			31-65-15	ALL
ST..	1A	W0311	2709Z			31-65-15	ALL
ST..	1A	W0311	2710Z			31-65-15	ALL
ST..	1A	W0311	2713Z			31-65-16	ALL
ST..	1A	W0311	2751Z			31-65-14	ALL
ST..	1A	W0311	2752Z			31-65-14	ALL
ST..	1A	W0311	2753Z			31-65-14	ALL
ST..	1A	W0311	2754Z			32-64-31	ALL
ST..	1A	W0311	2755Z			32-64-31	ALL
ST..	1A	W0311	2756Z			31-65-15	ALL
ST..	1A	W0311	2759Z			31-65-15	ALL
ST..	1A	W0311	2760Z			34-49-11	ALL
ST..	1A	W0311	2761Z			34-49-11	ALL
ST..	1A	W0311	2762Z			34-49-11	ALL
ST..	1A	W0311	2763Z			34-49-11	ALL
ST..	1A	W0311	2764Z			34-49-11	ALL
ST..	1A	W0311	2765Z			34-49-11	ALL
ST..	1A	W0311	2770Z			31-65-15	ALL
ST..	1A	W0311	2773Z			31-65-14	ALL
ST..	1A	W0311	2775Z			32-64-31	ALL
ST..	1A	W0311	2779Z			31-65-15	ALL
ST..	1A	W0311	2781Z			28-41-11	ALL
ST..	1A	W0313	2046Z			31-65-25	ALL
ST..	1A	W0313	2185Z			34-57-21	ALL
ST..	1A	W0313	2501Z			31-65-22	ALL
ST..	1A	W0313	2502Z			31-65-22	ALL
ST..	1A	W0313	2504Z			31-65-22	ALL
ST..	1A	W0313	2505Z			31-65-22	ALL
ST..	1A	W0313	2507Z			31-65-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03101		**PARTOFTB3101 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0313	2508Z			31-65-22	ALL
ST..	1A	W0313	2510Z			31-65-23	ALL
ST..	1A	W0313	2511Z			31-65-23	ALL
ST..	1A	W0313	2512Z			31-65-23	ALL
ST..	1A	W0313	2514Z			31-65-25	ALL
ST..	1A	W0313	2515Z			31-65-25	ALL
ST..	1A	W0313	2516Z			31-65-25	ALL
ST..	1A	W0313	2517Z			31-65-25	ALL
ST..	1A	W0313	2518Z			31-65-25	ALL
ST..	1A	W0313	2521Z			31-65-25	ALL
ST..	1A	W0313	2522Z			31-65-25	ALL
ST..	1A	W0313	2581Z			34-57-21	ALL
ST..	1A	W0313	2582Z			34-57-21	ALL
ST..	1A	W0313	2583Z			34-57-21	ALL
ST..	1A	W0313	2593Z			34-55-21	ALL
ST..	1A	W0313	2594Z			34-55-21	ALL
ST..	1A	W0313	2595Z			34-55-21	ALL
ST..	1A	W0313	2596Z			34-31-21	ALL
ST..	1A	W0313	2598Z			34-31-21	ALL
ST..	1A	W0313	2599Z			34-31-21	ALL
ST..	1A	W0313	2636Z			34-45-11	ALL
ST..	1A	W0313	2637Z			34-45-11	ALL
ST..	1A	W0313	2638Z			34-45-11	ALL
ST..	1A	W0313	2639Z			34-49-11	ALL
ST..	1A	W0313	2640Z			34-49-11	ALL
ST..	1A	W0313	2641Z			34-49-11	ALL
ST..	1A	W0313	2642Z			34-41-11	ALL
ST..	1A	W0313	2643Z			34-41-11	ALL
ST..	1A	W0313	2644Z			34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03101		**PARTOFTB3101 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0313	2645Z			34-41-11	ALL
ST..	1A	W0313	2648Z			22-11-51	ALL
ST..	1A	W0313	2649Z			22-11-51	ALL
ST..	1A	W0313	2650Z			22-11-51	ALL
ST..	1A	W0313	2657Z			27-81-41	ALL
ST..	1A	W0313	2671Z			34-41-11	ALL
ST..	1A	W0313	2709Z			31-65-25	ALL
ST..	1A	W0313	2710Z			31-65-25	ALL
ST..	1A	W0313	2713Z			31-65-26	ALL
ST..	1A	W0313	2714Z			31-65-26	ALL
ST..	1A	W0313	2725Z			34-33-21	ALL
ST..	1A	W0313	2732Z			34-33-21	ALL
ST..	1A	W0313	2733Z			34-33-21	ALL
ST..	1A	W0313	2743Z			34-33-21	ALL
ST..	1A	W0313	2757Z			32-64-31	ALL
ST..	1A	W0313	2768Z			31-65-15	ALL
ST..	1A	W0313	2770Z			34-33-21	ALL
ST..	1A	W0313	2773Z			31-65-25	ALL
GB03102		**PARTOFTB3102**				**E003-01/ /**	**ALL**
ST..	1A	W0311	1001Z			31-65-14	ALL
ST..	1A	W0311	1002Z			31-65-14	ALL
ST..	1A	W0311	1003Z			31-65-14	ALL
ST..	1A	W0311	1004Z			79-31-11	ALL
ST..	1A	W0311	1005Z			79-31-11	ALL
ST..	1A	W0311	1006Z			79-31-11	ALL
ST..	1A	W0311	1007Z			79-31-11	ALL
ST..	1A	W0311	2037Z			49-62-11	ALL
ST..	1A	W0311	2038Z			49-62-11	ALL
ST..	1A	W0311	2039Z			49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03102		**PARTOFTB3102 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2040Z			49-62-11	ALL
ST..	1A	W0311	2041Z			73-24-11	ALL
ST..	1A	W0311	2042Z			73-24-11	ALL
ST..	1A	W0311	2043Z			73-24-11	ALL
ST..	1A	W0311	2044Z			73-24-11	ALL
ST..	1A	W0311	2045Z			73-24-11	ALL
ST..	1A	W0311	2046Z			73-24-11	ALL
ST..	1A	W0311	2049Z			73-24-12	ALL
ST..	1A	W0311	2050Z			73-24-12	ALL
ST..	1A	W0311	2051Z			73-24-12	ALL
ST..	1A	W0311	2052Z			73-24-12	ALL
ST..	1A	W0311	2065Z			77-12-11	ALL
ST..	1A	W0311	2066Z			77-12-11	ALL
ST..	1A	W0311	2067Z			77-12-11	ALL
ST..	1A	W0311	2069Z			77-12-21	ALL
ST..	1A	W0311	2070Z			77-12-21	ALL
ST..	1A	W0311	2071Z			77-12-21	ALL
ST..	1A	W0311	2123Z			79-31-11	ALL
ST..	1A	W0311	2124Z			79-31-11	ALL
ST..	1A	W0311	2125Z			79-31-11	ALL
ST..	1A	W0311	2126Z			79-31-11	ALL
ST..	1A	W0311	2162Z			49-62-11	ALL
ST..	1A	W0311	2729Z			31-65-25	ALL
ST..	1A	W0311	2757Z			32-64-31	ALL
ST..	1A	W0311	2768Z			31-65-25	ALL
ST..	1A	W0311	3001Z			79-31-11	ALL
ST..	1A	W0313	1501Z			31-65-24	ALL
ST..	1A	W0313	1502Z			31-65-24	ALL
ST..	1A	W0313	1503Z			31-65-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03102		**PARTOFTB3102 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0313	1504Z			79-31-11	ALL
ST..	1A	W0313	1505Z			79-31-11	ALL
ST..	1A	W0313	1506Z			79-31-11	ALL
ST..	1A	W0313	1507Z			79-31-11	ALL
ST..	1A	W0313	2181Z			31-65-25	ALL
ST..	1A	W0313	2218Z			31-65-25	ALL
ST..	1A	W0313	2519Z			31-65-25	ALL
ST..	1A	W0313	2541Z			73-24-21	ALL
ST..	1A	W0313	2542Z			73-24-21	ALL
ST..	1A	W0313	2543Z			73-24-21	ALL
ST..	1A	W0313	2544Z			73-24-21	ALL
ST..	1A	W0313	2545Z			73-24-21	ALL
ST..	1A	W0313	2546Z			73-24-21	ALL
ST..	1A	W0313	2547Z			73-24-21	ALL
ST..	1A	W0313	2548Z			73-24-21	ALL
ST..	1A	W0313	2549Z			73-24-12	ALL
ST..	1A	W0313	2550Z			73-24-12	ALL
ST..	1A	W0313	2551Z			73-24-12	ALL
ST..	1A	W0313	2559Z			28-41-11	ALL
ST..	1A	W0313	2565Z			77-12-11	ALL
ST..	1A	W0313	2566Z			77-12-11	ALL
ST..	1A	W0313	2567Z			77-12-11	ALL
ST..	1A	W0313	2569Z			77-12-21	ALL
ST..	1A	W0313	2570Z			77-12-21	ALL
ST..	1A	W0313	2571Z			77-12-21	ALL
ST..	1A	W0313	2623Z			79-31-11	ALL
ST..	1A	W0313	2624Z			79-31-11	ALL
ST..	1A	W0313	2625Z			79-31-11	ALL
ST..	1A	W0313	2626Z			79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03102		**PARTOFTB3102 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0313	2751Z			31-65-24	ALL
ST..	1A	W0313	2752Z			31-65-24	ALL
ST..	1A	W0313	2753Z			31-65-24	ALL
ST..	1A	W0313	2754Z			32-64-31	ALL
ST..	1A	W0313	2755Z			32-64-31	ALL
ST..	1A	W0313	2756Z			31-65-25	ALL
ST..	1A	W0313	2772Z			31-65-24	ALL
ST..	1A	W0313	2775Z			32-64-31	ALL
ST..	1A	W0313	2781Z			28-41-11	ALL
ST..	1A	W0313	2782Z			28-41-11	ALL
ST..	1A	W0313	2783Z			28-41-11	ALL
ST..	1A	W0313	3501Z			79-31-11	ALL
GB03111		**PARTOFTB3111**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2029Z			31-65-15	ALL
ST..	1A	W0311	2030Z			31-65-15	ALL
ST..	1A	W0311	2073Z			31-65-15	ALL
ST..	1A	W0311	2163Z			31-65-15	ALL
ST..	1A	W0311	2165Z			31-65-15	ALL
ST..	1A	W0311	2171Z			31-65-15	ALL
ST..	1A	W0311	2718Z			36-11-14	ALL
ST..	1A	W0311	2719Z			36-11-14	ALL
ST..	1A	W0311	2720Z			36-11-14	ALL
ST..	1A	W0311	2721Z			36-11-14	ALL
ST..	1A	W0311	2770Z			31-65-15	ALL
ST..	1A	W0311	2774Z			31-65-15	ALL
ST..	1A	W0311	2991Z			23-70-11	ALL
ST..	1A	W0313	2669Z			31-65-15	ALL
ST..	1A	W0313	2992Z			23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03112		**PARTOFTB3112**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2031Z			31-65-15	ALL
ST..	1A	W0311	2164Z			31-65-15	ALL
ST..	1A	W0311	2166Z			31-65-15	ALL
ST..	1A	W0311	2771Z			32-42-12	ALL
ST..	1A	W0311	2772Z			32-42-12	ALL
ST..	1A	W0313	2771Z			32-42-12	ALL
GB03113		**PARTOFTB3113**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2726Z			34-33-11	ALL
ST..	1A	W0311	2727Z			34-33-11	ALL
ST..	1A	W0311	2728Z			34-33-11	ALL
ST..	1A	W0311	2730Z			31-65-25	ALL
ST..	1A	W0313	2526Z			31-65-25	ALL
ST..	1A	W0313	2527Z			31-65-25	ALL
ST..	1A	W0313	2529Z			31-65-25	ALL
ST..	1A	W0313	2530Z			31-65-25	ALL
ST..	1A	W0313	2663Z			31-65-25	ALL
ST..	1A	W0313	2670Z			31-65-25	ALL
ST..	1A	W0313	2801Z			31-65-25	ALL
GB03114		**PARTOFTB3114**				**E003-01/ /**	**ALL**
ST..	1A	W0311	2731Z			31-65-25	ALL
ST..	1A	W0313	2531Z			31-65-25	ALL
ST..	1A	W0313	2664Z			31-65-25	ALL
ST..	1A	W0313	2718Z			36-11-24	ALL
ST..	1A	W0313	2719Z			36-11-24	ALL
ST..	1A	W0313	2720Z			36-11-24	ALL
ST..	1A	W0313	2721Z			36-11-24	ALL
ST..	1A	W0313	2723Z			34-33-21	ALL
ST..	1A	W0313	2724Z			34-33-21	ALL
ST..	1A	W0313	2741Z			34-33-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03114		**PARTOFTB3114 (continued)**				**E003-01/ /**	**ALL**
ST..	1A	W0313	2742Z			34-33-21	ALL
ST..	1A	W0313	2773Z			31-65-25	ALL
ST..	1A	W0313	2774Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03201		**PARTOFTB3201**				**E003-02/ /**	**ALL**
ST..	1A	W0321	2001Z			31-31-11	ALL
ST..	1A	W0321	2002Z			31-31-11	ALL
ST..	1A	W0321	2003Z			31-31-11	ALL
ST..	1A	W0321	2016Z			34-61-14	ALL
ST..	1A	W0321	2017Z			34-21-14	ALL
ST..	1A	W0321	2018Z			34-61-14	ALL
ST..	1A	W0321	2025Z			27-32-12	ALL
ST..	1A	W0321	2026Z			27-32-12	ALL
ST..	1A	W0321	2027Z			27-32-22	ALL
ST..	1A	W0321	2028Z			27-32-22	ALL
ST..	1A	W0321	2029Z			34-21-14	ALL
ST..	1A	W0321	2030Z			34-21-14	ALL
ST..	1A	W0321	2031Z			31-33-01	ALL
ST..	1A	W0321	2032Z			31-35-02	ALL
ST..	1A	W0321	2033Z			31-33-01	ALL
ST..	1A	W0321	2034Z			31-33-01	ALL
ST..	1A	W0321	2035Z			31-35-02	ALL
ST..	1A	W0321	2036Z			31-35-02	ALL
ST..	1A	W0321	2064Z			31-33-01	ALL
ST..	1A	W0321	2065Z			31-33-01	ALL
ST..	1A	W0321	2089Z			28-41-11	ALL
ST..	1A	W0321	2101Z			28-41-11	ALL
ST..	1A	W0321	2102Z			28-41-11	ALL
ST..	1A	W0321	2117Z			27-32-22	ALL
ST..	1A	W0321	2130Z			34-51-11	ALL
ST..	1A	W0321	2167Z			34-61-14	ALL
ST..	1A	W0321	2181Z			34-51-11	ALL
ST..	1A	W0321	2221Z			22-23-12	ALL
ST..	1A	W0321	2222Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03201		**PARTOFTB3201 (continued)**				**E003-02/ /**	**ALL**
ST..	1A	W0321	2225Z			22-23-12	ALL
ST..	1A	W0321	2228Z			22-23-12	ALL
ST..	1A	W0321	2247Z			27-32-12	ALL
ST..	1A	W0321	2286Z			34-51-11	ALL
ST..	1A	W0321	2288Z			34-51-11	ALL
ST..	1A	W0321	2289Z			34-51-11	ALL
ST..	1A	W0321	2296Z			27-32-22	ALL
ST..	1A	W0321	2362Z			34-51-11	ALL
ST..	1A	W0321	2363Z			34-51-11	ALL
ST..	1A	W0321	2364Z			34-51-11	ALL
ST..	1A	W0321	2367Z			34-51-11	ALL
ST..	1A	W0321	2368Z			34-51-11	ALL
ST..	1A	W0321	2709Z			22-23-12	ALL
ST..	1A	W0321	2713Z			27-32-12	ALL
ST..	1A	W0321	2714Z			27-32-12	ALL
ST..	1A	W0321	2715Z			27-32-12	ALL
ST..	1A	W0321	2717Z			27-32-12	ALL
ST..	1A	W0321	2719Z			22-23-12	ALL
ST..	1A	W0321	2725Z			27-81-41	ALL
ST..	1A	W0321	2751Z			27-81-41	ALL
ST..	1A	W0321	2752Z			27-81-41	ALL
ST..	1A	W0321	2753Z			27-32-22	ALL
ST..	1A	W0321	2754Z			27-32-22	ALL
ST..	1A	W0321	2755Z			27-32-22	ALL
ST..	1A	W0321	2756Z			27-32-22	ALL
ST..	1A	W0321	2763Z			31-33-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03301		**PARTOFTB3301**				**E003-03/ /**	**ALL**
ST..	1A	W0330	2023Z			21-51-12	ALL
ST..	1A	W0330	2028Z			21-51-22	ALL
ST..	1A	W0330	2029Z			21-51-22	ALL
ST..	1A	W0330	2030Z			21-51-22	ALL
ST..	1A	W0330	2503Z			31-65-24	ALL
ST..	1A	W0330	2522Z			36-11-24	ALL
ST..	1A	W0330	2601Z			31-65-25	ALL
ST..	1A	W0330	2602Z			34-21-14	ALL
ST..	1A	W0331	2587Z			23-12-31	ALL
ST..	1A	W0331	2601Z			23-27-32	ALL
ST..	1A	W0331	2602Z			23-27-32	ALL
ST..	1A	W0331	2603Z			23-27-32	ALL
ST..	1A	W0331	2624Z			23-27-37	ALL
ST..	1A	W0331	2626Z			23-27-37	ALL
ST..	1A	W0331	2640Z			34-61-23	ALL
ST..	1A	W0331	2641Z			34-61-23	ALL
ST..	1A	W0331	2642Z			34-61-23	ALL
ST..	1A	W0331	2668Z			23-11-11	ALL
ST..	1A	W0331	2669Z			23-12-41	ALL
ST..	1A	W0331	2671Z			23-11-11	ALL
ST..	1A	W0331	2673Z			23-11-21	ALL
ST..	1A	W0331	2676Z			23-12-41	ALL
ST..	1A	W0331	2677Z			23-12-11	ALL
ST..	1A	W0331	2678Z			23-12-41	ALL
ST..	1A	W0331	2679Z			23-12-11	ALL
ST..	1A	W0331	2687Z			23-12-41	ALL
ST..	1A	W0331	2688Z			23-12-41	ALL
ST..	1A	W0331	2689Z			23-12-21	ALL
ST..	1A	W0331	2711Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03301		**PARTOFTB3301 (continued)**				**E003-03/ /**	**ALL**
ST..	1A	W0331	2758Z			23-27-37	ALL
ST..	1A	W0331	2845Z			34-21-14	ALL
ST..	1A	W0331	2881Z			23-12-41	ALL
ST..	1A	W0335	2524Z			23-27-37	ALL
ST..	1A	W0335	2541Z			34-61-23	ALL
ST..	1A	W0335	2542Z			34-61-23	ALL
ST..	1A	W0335	2546Z			23-12-31	ALL
ST..	1A	W0335	2558Z			23-12-31	ALL
ST..	1A	W0335	2608Z			23-27-33	ALL
ST..	1A	W0335	2609Z			23-27-33	ALL
ST..	1A	W0335	2657Z			23-11-11	ALL
ST..	1A	W0335	2658Z			23-12-11	ALL
ST..	1A	W0335	2659Z			23-12-41	ALL
ST..	1A	W0335	2667Z			23-11-11	ALL
ST..	1A	W0335	2670Z			23-12-41	ALL
ST..	1A	W0335	2672Z			23-11-21	ALL
ST..	1A	W0335	2674Z			23-11-21	ALL
ST..	1A	W0335	2675Z			23-11-21	ALL
ST..	1A	W0335	2681Z			23-12-41	ALL
ST..	1A	W0335	2682Z			23-12-11	ALL
ST..	1A	W0335	2683Z			23-12-41	ALL
ST..	1A	W0335	2684Z			23-12-21	ALL
ST..	1A	W0335	2685Z			23-12-41	ALL
ST..	1A	W0335	2686Z			23-12-21	ALL
ST..	1A	W0335	2690Z			23-12-21	ALL
ST..	1A	W0335	2691Z			23-12-41	ALL
ST..	1A	W0335	2707Z			23-12-41	ALL
ST..	1A	W0335	2708Z			23-12-41	ALL
ST..	1A	W0335	2709Z			23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03301		**PARTOFTB3301 (continued)**				**E003-03/ /**	**ALL**
ST..	1A	W0335	2714Z			23-12-41	ALL
ST..	1A	W0335	2803Z			34-61-23	ALL
ST..	1A	W0335	2822Z			23-27-33	ALL
ST..	1A	W0335	2858Z			23-12-41	ALL
ST..	1A	W0335	2859Z			23-12-41	ALL
ST..	1A	W0335	2860Z			23-12-41	ALL
ST..	1A	W0335	2861Z			23-12-41	ALL
ST..	1A	W0335	2862Z			23-12-41	ALL
ST..	1A	W0335	2863Z			21-51-22	ALL
ST..	1A	W0335	2864Z			21-51-22	ALL
ST..	1A	W0335	2865Z			21-51-22	ALL
ST..	1A	W0335	2901Z			21-51-12	ALL
ST..	1A	W0335	2902Z			36-11-24	ALL
ST..	1A	W0335	2903Z			31-65-24	ALL
ST..	1A	W0335	2904Z			31-65-25	ALL
GB03302		**PARTOFTB3302**				**E003-03/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB03901		**PARTOFTB3901**				**AJ0039/ /**	**ALL**
GB03902		**PARTOFTB3902**				**BJ0039/ /**	**ALL**
ST..	1A	W0084	FRAB			23-42-14	ALL
ST..	1A	W0084	FRAD			23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB04101		**PARTOFTB4101**				**E004-01/ /**	**ALL**
ST..	1A	W0410	1069Z			36-11-12	ALL
ST..	1A	W0410	1072Z			36-11-12	ALL
ST..	1A	W0410	1570Z			36-11-22	ALL
ST..	1A	W0410	1572Z			36-11-22	ALL
ST..	1A	W0410	1574Z			36-11-12	ALL
ST..	1A	W0410	1575Z			36-11-12	ALL
ST..	1A	W0410	1576Z			36-11-12	ALL
ST..	1A	W0410	1577Z			36-11-12	ALL
ST..	1A	W0410	1578Z			36-11-22	ALL
ST..	1A	W0410	1579Z			36-11-22	ALL
ST..	1A	W0410	1580Z			36-11-22	ALL
ST..	1A	W0410	1581Z			36-11-22	ALL
ST..	1A	W0410	2015Z			34-51-21	ALL
ST..	1A	W0410	2016Z			34-51-21	ALL
ST..	1A	W0410	2017Z			34-51-21	ALL
ST..	1A	W0410	2018ZO			34-51-21	ALL
ST..	1A	W0410	2020Z			34-51-21	ALL
ST..	1A	W0410	2021Z			34-51-21	ALL
ST..	1A	W0410	2022Z			34-51-21	ALL
ST..	1A	W0410	2023Z			34-51-21	ALL
ST..	1A	W0410	2024Z			34-51-21	ALL
ST..	1A	W0410	2025Z			34-51-21	ALL
ST..	1A	W0410	2028ZO			34-45-21	ALL
ST..	1A	W0410	2030ZO			34-32-11	ALL
ST..	1A	W0410	2050Z			34-51-21	ALL
ST..	1A	W0410	2051ZO			34-51-21	ALL
ST..	1A	W0410	2502Z			36-21-11	ALL
ST..	1A	W0410	2503Z			36-21-11	ALL
ST..	1A	W0410	2510ZO			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB04101		**PARTOFTB4101 (continued)**				**E004-01/ /**	**ALL**
ST..	1A	W0411	1014Z			23-41-11	ALL
ST..	1A	W0411	2009ZO			34-32-11	ALL
ST..	1A	W0411	2010ZO			34-51-11	ALL
ST..	1A	W0411	2506ZO			34-32-11	ALL
ST..	1A	W0411	2507ZO			34-51-11	ALL
ST..	1A	W0411	2508ZO			34-51-21	ALL
ST..	1A	W0411	2527ZO			34-45-21	ALL
ST..	1A	W0411	2528ZO			34-45-21	ALL
ST..	1A	W0411	3501Z			23-41-11	ALL
ST..	1A	W0411	3502Z			23-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB04201		**PARTOFTB4201**				**E004-02/ /**	**ALL**
ST..	1A	W0421	2510Z			34-61-23	ALL
ST..	1A	W0422	2028Z			34-61-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB05801		**PARTOFTB5801**				**374/188/L060**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GB06101		**PARTOFTB6101**				**E006-01/ /**	**ALL**
ST..	1A	W0611	2509Z			44-21-20	ALL
ST..	1A	W0611	2511Z			44-21-20	ALL
ST..	1A	W0611	2513Z			44-21-20	ALL
ST..	1A	W0611	2514Z			44-21-20	ALL
ST..	1A	W0611	2516Z			44-21-20	ALL
ST..	1A	W0611	2555Z			44-21-20	ALL
ST..	1A	W0611	2556Z			44-21-20	ALL
ST..	1A	W0611	2557Z			44-21-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00002		**DC**				**645/162/R042**	**ALL**
GD00005		**ST-**				**RUD56.4/ /**	**ALL**
ST..	E	W3389	0015	20		27-24-11	ALL
GD00007		**ST-**				**RUD56.4/ /**	**ALL**
ST..	E	W3387	0014	20		22-23-12	ALL
ST..	E	W3387	0015	20		22-23-12	ALL
GD00008		**AC-**				**375/157/L029**	**ALL**
AC..	F	W5030	0505	10		24-53-11	ALL
GD00010		**AC-**				**378/168/R047**	**ALL**
AC..	F	W6110	0518	08		24-53-11	ALL
GD00012		**BACC50AN16**				**543/159/L026**	**ALL**
ST..	1	W5230	YAAF			29-11-12	ALL
GD00016		**BACC50AN16**				**543/160/R027**	**ALL**
ST..	1	W6128	YAAF			29-11-12	ALL
AC..	1	W6202	1038	20		21-61-13	ALL
ST..	1	W6202	1038Z			21-61-13	ALL
DC..	1	W6202	1040	20		21-61-13	ALL
ST..	1	W6202	1040Z			21-61-13	ALL
AC..	1	W6202	1042	20		21-61-14	ALL
ST..	1	W6202	1042Z			21-61-14	ALL
DC..	1	W6202	1045	20		21-61-14	ALL
ST..	1	W6202	1045Z			21-61-14	ALL
GD00024		**BACC50AN16**				**1085/272/L020**	**ALL**
ST..	1	W3391	1004Z			22-13-11	ALL
ST..	1	W3391	1005Z			22-13-11	ALL
ST..	1	W3391	1010Z			22-13-11	ALL
ST..	1	W3391	1012Z			22-13-11	ALL
ST..	1	W4134	1013Z			31-53-11	ALL
ST..	1	W4134	1014Z			31-53-11	ALL
DC..	1	W4134	A-F			31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00024		**BACC50AN16 (continued)**				**1085/272/L020**	**ALL**
DC..	1	W4134	B-F			31-53-11	ALL
DC..	1	W4134	C-F			31-53-11	ALL
GD00028		**BACC50AN16**				**849/184/L046**	**ALL**
ST..	1	W5112	0510	20		38-41-13	ALL
DC..	1	W6248	5545	20		30-71-11	ALL
DC..	1	W6248	5547	20		30-71-11	ALL
AC..	1	W6248	5549	20		30-71-11	ALL
AC..	1	W6248	5559	20		30-71-11	ALL
AC..	1	W6248	5571	20		30-71-11	ALL
GD00030		**AC-**				**258/196/L033**	**ALL**
AC..	E	W5100	0508	22		32-51-11	ALL
AC..	E	W5156	0650	18		32-64-11	ALL
AC..	E	W5501	0004	20		34-21-12	ALL
GD00032		**ST-**				**258/195/L033**	**ALL**
ST..	E	W5100	0507	22		32-51-11	ALL
ST..	E	W5501	0003	20		34-21-12	ALL
GD00034		**BACC50AN16**				**213/192/R034**	**ALL**
DC..	1	W5158	0301	20		31-31-15	ALL
DC..	1	W5158	0590	20		32-64-12	ALL
DC..	1	W5160	0008	20		52-71-13	ALL
DC..	1	W5160	0032	20		25-51-21	ALL
DC..	1	W5160	0508	20		52-71-13	ALL
GD00036		**BACC50AN16**				**1085/274/L022**	**ALL**
ST..	1	W3391	1021Z			27-41-12	ALL
ST..	1	W3391	1022Z			27-41-12	ALL
ST..	1	W3391	1023Z			27-41-12	ALL
ST..	1	W3391	1024Z			27-41-12	ALL
ST..	1	W3391	1025Z			27-41-12	ALL
AC..	1	W4724	1040	18		33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00036		**BACC50AN16 (continued)**				**1085/274/L022**	**ALL**
ST..	1	W4724	1040Z			33-43-11	ALL
AC..	1	W8030	2501B	18		33-49-11	ALL
ST..	1	W8030	2501R	18		33-49-11	ALL
ST..	1	W8030	2501Z			33-49-11	ALL
GD00038		**AC-**				**227/184/R024**	**ALL**
AC..	H7	W6026	0004	04		24-41-11	ALL
GD00041		**DC-**				**210/207/L022**	**ALL**
DC..	E	W0145	0002	20		27-32-11	ALL
GD00044		**BACC50AN16**				**213/192/R033**	**ALL**
DC..	1	W5156	0653	20		44-21-22	ALL
GD00045		**BACC50AN16**				**1087/230/R018**	**ALL**
AC..	1	W4724	1041	18		33-43-11	ALL
ST..	1	W4724	1041Z			33-43-11	ALL
AC..	1	W4724	1042	18		33-43-11	ALL
ST..	1	W4724	1042Z			33-43-11	ALL
ST..	1	W4724	1043	18		33-43-11	ALL
ST..	1	W4724	1043Z			33-43-11	ALL
GD00046		**BACC50AN16**				**AB1088/230/R017**	**ALL**
ST..	1	W3391	0101	18		27-41-12	ALL
AC..	1	W3391	1026	18		27-41-12	ALL
ST..	1	W3391	1026Z			27-41-12	ALL
ST..	1	W4222	1010	18		27-41-12	ALL
DC..	1	W4222	1011	20		22-13-11	ALL
DC..	1	W4222	1011Z			22-13-11	ALL
AC..	1	W4724	0034	18		33-35-11	ALL
AC..	1	W4724	0036	18		33-35-11	ALL
DC..	1	W4724	1111R	20		26-11-31	ALL
DED		W4724	1111Z			26-11-31	ALL
DC..	1	W4724	1112R	20		26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00046		**BACC50AN16 (continued)**				**AB1088/230/R017**	**ALL**
DED		W4724	1112Z			26-11-31	ALL
GD00053		**DC-**				**210/206/R022**	**ALL**
DC..	E	W0147	0002	20		27-32-21	ALL
GD00061		**ST-**				**P061-00/ /**	**ALL**
ST..	E	W0041	0037	20		34-21-11	ALL
ST..	E	W0041	0041	20		31-32-15	ALL
ST..	E	W0041	0042	20		31-32-15	ALL
ST..	E	W0041	0043	20		31-32-15	ALL
ST..	E	W0044	6100	20		23-42-14	ALL
GD00068		**BACC50AN16**				**520/177/L053**	**ALL**
DC..	1	W5104	0328	20		21-25-11	ALL
DC..	1	W5168	0035	20		73-21-12	ALL
DC..	1	W5168	6002	20		76-21-11	ALL
DC..	1	W5170	0009	20		36-11-12	ALL
DC..	1	W5526	5532	20		21-51-15	ALL
GD00069		**DC**				**RUD56.4/ /**	**ALL**
DC..	E	W6136	0509	20		27-23-11	ALL
DC..	E	W6136	0510	20		27-25-11	ALL
DC..	E	W6136	0511	20		27-25-11	ALL
GD00070		**BACC50AN16**				**947/205/R017**	**ALL**
AC..	1	W5112	0512	20		38-41-13	ALL
DC..	1	W5146	0004	20		38-41-11	ALL
ST..	1	W5146	0005	20		38-41-11	ALL
ST..	1	W5434	0006	20		21-27-51	ALL
AC..	1	W6248	5555	20		30-71-11	ALL
AC..	1	W6248	5561	20		30-71-11	ALL
AC..	1	W6248	5581	20		30-71-11	ALL
AC..	1	W6248	5583	20		30-71-11	ALL
AC..	1	W6248	5585	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00072		**BACC50AN16**				**500I+17/176/R053**	**ALL**
DC..	1	W6168	0035	20		73-21-12	ALL
DC..	1	W6170	0009	20		36-11-22	ALL
DC..	1	W6170	0511	20		78-35-21	ALL
ST..	1	W6230	FRFA			21-51-24	ALL
GD00074		**ST-**				**847/189/L041**	**ALL**
ST..	E	W5230	0518	12		38-32-12	ALL
GD00083		**ST-**				**694/306/R002**	**ALL**
ST..	E	W5273	0001	20		34-57-11	ALL
ST..	E	W5273	0003	20		34-57-11	ALL
ST..	E	W5273	8991Z			34-57-11	ALL
GD00084		**BACC50AN20**				**431/162/R036**	**ALL**
DC..	1A	W5248	0007	20		33-36-11	ALL
DC..	1A	W5248	0156	20		52-71-12	ALL
GD00085		**ST-**				**727A+7/300/R002**	**ALL**
ST..	=	W5275	0001	20		34-57-21	ALL
ST..	=	W5275	0003	20		34-57-21	ALL
ST..	=	W5275	8991Z			34-57-21	ALL
GD00086		**BACC50AN16**				**500/202/L011**	**ALL**
AC..	1	W5248	0014	20		33-36-11	ALL
GD00090		**AC-**				**724/194/L028**	**ALL**
AC..	E	W7026	0513	20		33-32-11	ALL
GD00091		**ST-**				**500I+3/199/R013**	**ALL**
ST..	E	W5208	0006	20		47-30-11	ALL
GD00092		**AC-**				**703/200/R020**	**ALL**
AC..	E	W7026	0514	20		33-32-11	ALL
AC..	E	W8224	A-Y			32-64-12	ALL
GD00095		**ST-**				**540/162/R039**	**ALL**
ST..	N	W7208	0099	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00098		**BACC50AN16**				**1087/232/L017**	**ALL**
AC..	1	W4724	1002	18		33-35-11	ALL
ST..	1	W4724	1002Z			33-35-11	ALL
ST..	1	W4724	1038	18		33-43-11	ALL
ST..	1	W4724	1038Z			33-43-11	ALL
DC..	1	W4726	1104R	18		26-21-11	ALL
ST..	1	W4726	1104Z			26-21-11	ALL
ST..	1	W4726	1106R	18		26-21-11	ALL
DED		W4726	1106Z			26-21-11	ALL
DC..	1	W4726	1107R	18		26-21-11	ALL
ST..	1	W4726	1107Z			26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00100		**ST-**				**321/290/R023**	**ALL**
ST..	D	W0010	0003	20		33-26-21	ALL
ST..	D	W0010	0007	20		33-26-21	ALL
GD00102		**DC-**				**184/240/L017**	**ALL**
DC..	E	W2108	5501	16		30-42-11	ALL
GD00104		**DC-**				**184/238/R017**	**ALL**
DC..	E	W2208	5501	16		30-42-11	ALL
GD00109		**ST-**				**655/164/L042**	**ALL**
ST..	N	W7202	0022	16		47-30-11	ALL
ST..	N	W7202	0023	16		47-30-11	ALL
ST..	N	W7202	0027	16		47-30-11	ALL
ST..	N	W7202	0028	16		47-30-11	ALL
GD00111		**ST-**				**611/163/L055**	**ALL**
ST..	N	W7202	0020	16		47-30-11	ALL
ST..	N	W7202	0026	16		47-30-11	ALL
GD00113		**ST-**				**647/165/L061**	**ALL**
ST..	N	W7202	0029	16		47-30-11	ALL
GD00120		**ST-**				**ORSS/543/**	**ALL**
ST..	E	W1024	2001Z			27-18-11	ALL
ST..	E	W1024	3001Z			27-18-11	ALL
GD00121		**DC-**				**500I+3/200/R012**	**ALL**
DC..	E	W5208	0005	20		47-30-11	ALL
DC..	E	W5208	0021	20		47-30-11	ALL
DC..	E	W5208	0022	20		47-30-11	ALL
DC..	E	W5208	0023	20		47-30-11	ALL
DC..	E	W5208	0024	20		47-30-11	ALL
GD00126		**ST-**				**ORSS 449/ /**	**ALL**
ST..	N	W1024	0513	20		27-52-11	ALL
ST..	N	W1024	1002	18		27-53-21	ALL
ST..	N	W1024	1002Z			27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00129		**ST-**				**573/151/L043**	**ALL**
ST..	N	W7202	0024	16		47-30-11	ALL
GD00130		**ST-**				**ORSS/543/**	**ALL**
ST..	E	W1034	2001Z			27-18-11	ALL
ST..	E	W1034	3001Z			27-18-11	ALL
GD00133		**ST-**				**1039/299/R002**	**ALL**
ST..	E	W5146	0129	12		38-32-12	ALL
GD00136		**ST-**				**ORSS/449/**	**ALL**
ST..	N	W1034	0513	20		27-52-11	ALL
ST..	N	W1034	1002	18		27-53-21	ALL
ST..	N	W1034	1002Z			27-53-21	ALL
GD00138		**DC-**				**726/169/R020**	**ALL**
DC..	E	W8524	6004R	18		26-11-31	ALL
GD00141		**AC-**				**P001-00/ /**	**ALL**
AC..	E	W0001	0190	14		33-11-11	ALL
AC..	E	W0001	0195	14		33-11-11	ALL
AC..	E	W0001	0202	14		33-11-31	ALL
AC..	E	W0001	0215	20		33-11-32	ALL
GD00142		**AC-**				**P003-00/ /**	**ALL**
AC..	E	W0003	0667	16		33-11-21	ALL
AC..	E	W0003	0674	14		33-11-21	ALL
AC..	E	W0003	0711	16		33-11-32	ALL
GD00144		**AC-**				**IFSS 167/ /**	**ALL**
AC..	E	W1280	J-Y			27-81-21	ALL
GD00148		**AC-**				**IFSS 149/ /**	**ALL**
AC..	E	W1280	K-Y			27-81-21	ALL
AC..	E	W1280	L-Y			27-81-21	ALL
GD00154		**AC-**				**P018-00/ /**	**ALL**
AC..	E	W0020	0889	06		24-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00160		**AC-**				**IFSS-149/ /**	**ALL**
AC..	E	W1180	K-Y			27-81-11	ALL
AC..	E	W1180	L-Y			27-81-11	ALL
GD00172		**DC-**				**IRSS 141/ /**	**ALL**
DC..	GW	W1382	1033	20		28-43-11	ALL
GD00179		**BACC50AN20**				**183/222/L006**	**ALL**
AC..	1A	W2205	0011	20		33-11-32	ALL
DC..	1A	W2205	0039	20		34-24-15	ALL
ST..	1A	W2205	0040	20		34-24-15	ALL
GD00180		**ST-**				**665/178/L031**	**ALL**
ST..	E	W7122	0521	20		27-11-11	ALL
ST..	E	W7122	0531	18		32-31-15	ALL
GD00184		**DC-**				**IRSS 149/ /**	**ALL**
DC..	GW	W1380	1013	20		28-43-11	ALL
GD00190		**ST-**				**666/198/R060**	**ALL**
ST..	E	W1134	1302Z			28-43-11	ALL
ST..	GW	W1382	1032Z			28-43-11	ALL
ST..	GW	W1382	3001Z			28-23-11	ALL
ST..	E	W6128	1005	18		28-22-11	ALL
DED		W6128	1005Z			28-22-11	ALL
GD00191		**ST-**				**IFSS 121/ /**	**ALL**
ST..	GW	W1140	001TO			28-41-11	ALL
ST..	GW	W1140	1002Z			28-41-11	ALL
ST..	GW	W1140	1003Z			28-41-11	ALL
GD00193		**ST-**				**IFSS 121/ /**	**ALL**
ST..	GW	W1138	001TO			28-41-11	ALL
ST..	GW	W1138	1002Z			28-41-11	ALL
ST..	GW	W1138	1003Z			28-41-11	ALL
GD00195		**ST-**				**ENG/ /**	**ALL**
ST..	GY	W1062	1002Z			24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00195		**ST- (continued)**				**ENG/ /**	**ALL**
ST..	GY	W1062	1003Z			24-21-11	ALL
GD00199		**ST-**				**ENG/ /**	**ALL**
ST..	GY	W1062	1001Z			24-21-11	ALL
ST..	GY	W1062	1004Z			24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00207		**ST-**				**642/272/R057**	**ALL**
ST..	E	W4246	0036	18		33-21-12	ALL
GD00210		**AC-**				**226/232/R040**	**ALL**
AC..	E	W2204	5534	20		33-14-11	ALL
GD00211		**ST-**				**642/272/L057**	**ALL**
ST..	E	W3246	0036	18		33-21-12	ALL
GD00217		**ST-**				**581/272/R057**	**ALL**
ST..	E	W4246	0026	18		33-21-12	ALL
GD00224		**ST-**				**ORSS 251/ /**	**ALL**
ST..	N	W1022	1002	18		27-53-21	ALL
ST..	N	W1022	1002Z			27-53-21	ALL
GD00226		**ST-**				**726/194/L048**	**ALL**
ST..	N	W1022	1003	18		27-53-21	ALL
ST..	N	W1022	1003Z			27-53-21	ALL
GD00229		**ST-**				**581/272/L057**	**ALL**
ST..	E	W3246	0026	18		33-21-12	ALL
GD00234		**ST-**				**ORSS 251/ /**	**ALL**
ST..	N	W1032	1002	18		27-53-21	ALL
ST..	N	W1032	1002Z			27-53-21	ALL
GD00236		**ST-**				**726/201/R041**	**ALL**
ST..	N	W1032	1003	18		27-53-21	ALL
ST..	N	W1032	1003Z			27-53-21	ALL
GD00237		**DC**				**P1/ /**	**ALL**
DC..	E	W0001	1501	16		31-65-11	ALL
GD00240		**DC-**				**OFSS 367/ /**	**ALL**
DC..	E	W1664	0034	20		28-44-11	ALL
DC..	E	W1664	0036	20		28-44-11	ALL
DC..	E	W1664	0038	20		28-44-11	ALL
GD00243		**DC**				**P1/ /**	**ALL**
DC..	E	W0001	1505	16		31-65-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00246		**ST-**				**724/155/R012**	**ALL**
ST..	E	W8524	0501	18		29-32-11	ALL
ST..	E	W8524	2001Z			29-32-11	ALL
GD00247		**DC**				**P003/ /**	**ALL**
DC..	E	W0003	1401	16		31-65-21	ALL
GD00249		**DC**				**P003/ /**	**ALL**
DC..	E	W0003	1505	16		31-65-21	ALL
GD00258		**DC-**				**P007-00/ /**	**ALL**
DC..	E	W0001	0752	24		31-65-13	ALL
DC..	E	W0001	0753	24		31-65-23	ALL
GD00261		**BACC50AN20**				**261/280/L008**	**ALL**
AC..	1A	W2112	6043	20		28-23-11	ALL
AC..	1A	W2112	6044	20		28-23-11	ALL
AC..	1A	W2112	6045	20		28-23-11	ALL
AC..	1A	W2112	6056	20		28-23-11	ALL
ST..	1A	W2216	5516	20		21-61-11	ALL
AC..	1A	W2216	5517	20		21-61-11	ALL
DC..	1A	W2508	5613	20		33-14-12	ALL
GD00262		**ST-**				**IFSS 129/ /**	**ALL**
ST..	GW	W1664	1019Z			28-44-11	ALL
ST..	GW	W1664	1026Z			28-44-11	ALL
GD00268		**DC-**				**P007-00/ /**	**ALL**
DC..	E	W0003	0752	24		31-65-13	ALL
DC..	E	W0003	0753	24		31-65-23	ALL
GD00270		**ST-**				**363/157/L029**	**ALL**
ST..	E	W2536	0515	14		24-34-11	ALL
ST..	E	W5506	0520	24		24-34-11	ALL
GD00272		**ST-**				**388/167/R047**	**ALL**
ST..	E	W6210	2201B	22		24-23-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00276		**ST-**				**387/173/L053**	**ALL**
ST..	E	W5726	2237B	22		24-23-11	ALL
ST..	E	W5726	2239B	22		24-22-31	ALL
ST..	E	W5726	4102G	20		24-21-31	ALL
GD00278		**ST-**				**IFSS-200/ /**	**ALL**
ST..	GW	W1186	YAAA			24-21-11	ALL
GD00279		**ST-**				**IFSS 200/ /**	**ALL**
ST..	GW	W1286	YAAA			24-21-21	ALL
GD00287		**ST-**				**239/203/L013**	**ALL**
ST..	E	W5369	0035	20		22-11-11	ALL
ST..	E	W5457	0015	20		22-11-11	ALL
GD00289		**ST-**				**211/197/L026**	**ALL**
ST..	E	W5369	0045	20		22-11-11	ALL
GD00298		**DC-**				**199/203/L015**	**ALL**
DC..	E	W5514	5781	22		32-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00302		**AC-**				**726/165/L020**	**ALL**
AC..	E	W7128	0304	16		27-53-12	ALL
GD00304		**ST-**				**706/200/L010**	**ALL**
ST..	E	W7128	0510	20		29-31-11	ALL
GD00308		**DC-**				**726/180/L008**	**ALL**
DC..	N	W7128	0512	16		32-44-11	ALL
DC..	N	W7128	0515	16		32-44-11	ALL
GD00310		**DC-**				**715/200/R031**	**ALL**
DC..	N	W8226	0504	20		27-53-12	ALL
DC..	N	W8226	0506	20		22-23-12	ALL
DC..	N	W8226	0508	20		33-25-11	ALL
DC..	E	W8226	B-AA			27-53-12	ALL
GD00312		**DC-**				**665/191/R015**	**ALL**
DC..	E	W8222	0507	20		29-33-11	ALL
DC..	E	W8222	0508	20		29-11-11	ALL
DC..	E	W8222	0511	20		29-33-11	ALL
GD00314		**DC-**				**664/178/R031**	**ALL**
DC..	E	W1126	1304	20		28-43-11	ALL
DED		W1126	1304Z			28-43-11	ALL
DC..	E	W8122	0504	20		29-25-11	ALL
GD00315		**DC-**				**301/181/R020**	**ALL**
DC..	E	W5205	0009	20		34-51-41	ALL
GD00316		**DC-**				**726/166/L020**	**ALL**
DC..	E	W7128	0405	20		29-35-11	ALL
DC..	E	W7128	0407	18		27-53-11	ALL
DC..	E	W7128	0521	18		27-23-11	ALL
GD00317		**DC-**				**308/178/R022**	**ALL**
DC..	E	W5163	0037	22		34-51-41	ALL
GD00318		**DC-**				**663/165/R004**	**ALL**
DC..	N	W6128	0501	18		29-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00318		**DC- (continued)**				**663/165/R004**	**ALL**
DC..	N	W6128	0508	18		29-34-11	ALL
DC..	E	W7026	0508	18		27-61-43	ALL
DC..	N	W7122	0503	18		29-25-11	ALL
DC..	E	W8122	0507	20		29-23-11	ALL
DC..	E	W8122	0509	20		29-23-11	ALL
GD00320		**DC-**				**665/182/L024**	**ALL**
DC..	E	W1128	1302	20		28-43-11	ALL
DED		W1128	1302Z			28-43-11	ALL
DC..	E	W5367	0012	20		22-11-31	ALL
DC..	E	W5367	0013	20		22-11-31	ALL
DC..	E	W7122	0505	20		27-23-14	ALL
DC..	E	W7122	0512	18		27-23-11	ALL
GD00322		**DC-**				**662/165/L004**	**ALL**
DC..	N	W5230	0501	18		29-11-12	ALL
DC..	E	W5230	0508	18		29-34-11	ALL
DC..	E	W8122	0508	20		29-23-11	ALL
GD00324		**DC-**				**665/182/R054**	**ALL**
DC..	E	W6128	1006	18		28-22-11	ALL
DED		W6128	1006Z			28-22-11	ALL
DC..	E	W8122	0502	20		27-23-14	ALL
DC..	E	W8122	0513	20		27-23-11	ALL
DC..	E	W8122	0544	18		27-61-43	ALL
GD00328		**DC-**				**674/200/R038**	**ALL**
DC..	E	W8224	0505	20		29-23-11	ALL
GD00330		**DC-**				**665/179/L041**	**ALL**
DC..	E	W5375	0002	20		22-11-31	ALL
DC..	E	W5375	0022	20		22-11-31	ALL
DC..	E	W7026	0505	18		49-62-11	ALL
DC..	E	W7522	0503	20		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00330		**DC- (continued)**				**665/179/L041**	**ALL**
DC..	E	W7522	0505	20		29-33-11	ALL
DC..	E	W7522	0507	20		29-33-11	ALL
GD00332		**DC-**				**717/200/R020**	**ALL**
DC..	E	W8124	0504	18		27-53-11	ALL
DC..	N	W8124	0505	20		32-64-21	ALL
DC..	N	W8124	0510	20		32-64-21	ALL
DC..	N	W8124	0514	20		21-51-14	ALL
GD00336		**ST-**				**665/188/R015**	**ALL**
ST..	E	W8222	0509	18		29-32-11	ALL
GD00340		**DC-**				**726/172/L020**	**ALL**
DC..	E	W7128	0402	18		29-31-11	ALL
GD00342		**DC-**				**717/197/L050**	**ALL**
DC..	E	W7592	6010R	20		26-21-11	ALL
DC..	E	W7592	6011R	20		26-21-11	ALL
DC..	E	W7592	6012R	20		26-21-11	ALL
DC..	E	W7592	6013R	20		26-21-11	ALL
DC..	E	W7592	6014R	20		26-21-11	ALL
GD00344		**DC**				**724/197/L050**	**ALL**
DC..	E	W7594	6009R	20		26-21-11	ALL
DC..	E	W7594	6010R	20		26-21-11	ALL
DC..	E	W7594	6011R	20		26-21-11	ALL
DC..	E	W7594	6012R	20		26-21-11	ALL
DC..	E	W7594	6013R	20		26-21-11	ALL
GD00346		**AC-**				**286/184/R017**	**ALL**
AC..	E	W5160	0505	18		32-64-12	ALL
GD00360		**DC**				**217/183/R006**	**ALL**
DC..	E	W6024	0513	22		23-43-11	ALL
GD00374		**DC-**				**644/159/R009**	**ALL**
DC..	GW	W6202	1033	20		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00374		**DC- (continued)**				**644/159/R009**	**ALL**
DC..	GW	W6202	1033Z			21-51-22	ALL
GD00380		**DC-**				**705/200/L037**	**ALL**
DC..	E	W7126	0502	18		31-31-15	ALL
DC..	E	W7126	0504	18		32-41-11	ALL
GD00382		**DC-**				**644/159/L009**	**ALL**
DC..	GW	W5102	1028	20		21-51-12	ALL
DC..	GW	W5102	1028Z			21-51-12	ALL
GD00383		**BACC50AN20**				**198/172/R007**	**ALL**
DC..	1A	W5156	0545	20		32-64-11	ALL
DC..	1A	W5156	0612	22		32-31-11	ALL
DC..	1A	W5156	6002R	20		26-11-31	ALL
DC..	1A	W5158	0671	20		21-27-31	ALL
ST..	1A	W5158	0672	20		21-27-31	ALL
DC..	1A	W5158	0677	20		21-27-31	ALL
GD00396		**AC-**				**217/183/R007**	**ALL**
AC..	E	W6024	0501	20		33-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00408		**BACC50AN20**				**375/170/R047**	**ALL**
DC..	1A	W6414	0011	22		34-21-22	ALL
ST..	1A	W6414	0051	20		25-29-11	ALL
AC..	1A	W6414	0052	20		25-29-11	ALL
DC..	1A	W6414	0519	20		24-51-21	ALL
ST..	1A	W6414	5505	20		21-27-21	ALL
ST..	1A	W6430	5504	20		21-27-31	ALL
GD00412		**AC-**				**286/190/L017**	**ALL**
AC..	E	W5156	0601	18		32-31-11	ALL
AC..	E	W5156	0651	18		32-64-11	ALL
GD00420		**BACC50AN20**				**419/206/L029**	**ALL**
ST..	1A	W5161	0017	20		34-21-12	ALL
GD00426		**BACC50AN16**				**418/203/R033**	**ALL**
GD00428		**BACC50AN16**				**440/204/L012**	**ALL**
ST..	1	W5086	6015	20		26-16-21	ALL
ST..	1	W5163	0017	20		34-21-22	ALL
AC..	1	W5248	0018	20		33-36-11	ALL
GD00430		**BACC50AN16**				**460/202/L011**	**ALL**
ST..	1	W5086	6005	20		26-16-21	ALL
ST..	1	W5086	6031	22		26-16-21	ALL
DC..	1	W5088	6010	22		26-16-21	ALL
DC..	1	W5088	6011	22		26-16-21	ALL
ST..	1	W5088	6012	22		26-16-21	ALL
GD00431		**BACC50AN16**				**907/205/R038**	**ALL**
DC..	1	W5124	0510	20		27-31-11	ALL
DC..	1	W5124	0515	22		27-31-37	ALL
DC..	1	W5124	0570	20		29-25-11	ALL
DC..	1	W5124	0571	20		29-25-11	ALL
AC..	1	W6248	5573	20		30-71-11	ALL
AC..	1	W6248	5575	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00431		**BACC50AN16 (continued)**				**907/205/R038**	**ALL**
AC..	1	W6248	5577	20		30-71-11	ALL
AC..	1	W6248	5579	20		30-71-11	ALL
GD00432		**BACC50AN16**				**460/203/R053**	**ALL**
AC..	1	W5248	0012	20		33-36-11	ALL
DC..	1	W5586	6008	20		28-41-11	ALL
GD00433		**ST-**				**196/192/L029**	**ALL**
ST..	E	W5501	0001	20		34-21-12	ALL
ST..	E	W5501	0007	20		34-21-12	ALL
ST..	E	W5501	0010	22		27-32-11	ALL
GD00434		**ST-**				**196/173/R011**	**ALL**
ST..	E	W5156	5511	20		21-27-21	ALL
ST..	E	W5503	0001	20		34-21-22	ALL
GD00437		**ST-**				**197/198/R030**	**ALL**
ST..	E	W5158	2605Z			31-65-15	ALL
ST..	E	W5158	2608Z			31-65-25	ALL
ST..	E	W5503	0007	20		34-21-22	ALL
ST..	E	W5503	0009	22		27-32-21	ALL
GD00442		**AC-**				**286/189/L017**	**ALL**
AC..	E	W5156	0718	18		32-31-12	ALL
GD00446		**AC-**				**244/180/R038**	**ALL**
AC..	E	W5160	0650	18		32-64-12	ALL
GD00448		**BACC50AN16**				**479/203/L009**	**ALL**
AC..	1	W5248	0020	20		33-36-11	ALL
GD00449		**ST-**				**179/199/L005**	**ALL**
GD00451		**ST-**				**179/198/L005**	**ALL**
GD00458		**ST-**				**660/154/L032**	**ALL**
ST..	E	W5104	0331	20		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00459		**DC-**				**179/197/L005**	**ALL**
GD00460		**ST-**				**660/155/R033**	**ALL**
ST..	E	W6230	0331	20		21-51-24	ALL
GD00462		**ST-**				**OFSS 378/ /**	**ALL**
ST..	E	W1664	1017Z			28-44-11	ALL
ST..	E	W1664	1024Z			28-44-11	ALL
GD00475		**AC-**				**220/203/R015**	**ALL**
AC..	E	W6110	0006	20		33-34-11	ALL
GD00476		**DC-**				**IRSS 215/ /**	**ALL**
DC..	E	W7230	6002	18		28-42-11	ALL
GD00479		**DC-**				**1157/285/R011**	**ALL**
DC..	E	W3393	0011	20		22-18-11	ALL
DC..	E	W3393	0014	20		22-18-11	ALL
DC..	E	W8030	0523	18		27-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00500		**AC-**				**389/173/L053**	**ALL**
AC..	F	W3154	0022	08		24-51-11	ALL
GD00501		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2112	6018	20		74-31-11	ALL
DC..	1A	W2218	0015	20		33-25-11	ALL
DC..	1A	W2218	0016	20		33-25-11	ALL
DC..	1A	W2218	0019	20		33-25-11	ALL
DC..	1A	W2218	0029	20		33-51-11	ALL
DC..	1A	W2218	0032	20		33-51-11	ALL
AC..	1A	W2218	5550	20		36-21-11	ALL
DC..	1A	W2218	6015	20		74-31-11	ALL
DC..	1A	W2218	6020	20		74-31-11	ALL
DC..	1A	W2508	5575	20		33-18-37	ALL
GD00503		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2218	0522	20		24-28-11	ALL
DC..	1A	W2218	0557	20		24-28-11	ALL
DC..	1A	W2218	0558	20		24-28-11	ALL
DC..	1A	W2508	0504	20		24-32-11	ALL
DC..	1A	W2508	0517	20		24-34-11	ALL
DC..	1A	W2508	5528	20		33-18-31	ALL
DC..	1A	W2508	5538	20		33-18-33	ALL
DC..	1A	W2508	5539	20		33-18-33	ALL
DC..	1A	W2508	5543	20		33-18-33	ALL
DC..	1A	W2508	6010	20		28-21-11	ALL
ST..	1A	W2508	6013	20		28-43-11	ALL
DC..	1A	W2508	6027	20		76-21-11	ALL
DC..	1A	W2508	8001	20		34-51-41	ALL
DC..	1A	W2508	8003	20		34-51-41	ALL
DC..	1A	W2508	8006	20		34-21-15	ALL
DC..	1A	W2508	8018	20		34-21-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00506		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2114	5504	20		21-61-51	ALL
DC..	1A	W2114	5505	20		21-61-51	ALL
DC..	1A	W2114	5516	20		30-31-11	ALL
ST..	1A	W2218	2003Z			30-41-12	ALL
DC..	1A	W2218	5502	22		21-27-21	ALL
ST..	1A	W2218	5509	20		21-31-23	ALL
ST..	1A	W2218	5510	20		21-31-23	ALL
DC..	1A	W2218	5516	20		21-51-22	ALL
DC..	1A	W2218	5532	24		30-41-12	ALL
DC..	1A	W2218	5533	24		30-41-12	ALL
DC..	1A	W2218	5565	20		21-61-13	ALL
DC..	1A	W2218	5567	20		21-61-15	ALL
ST..	1A	W2218	5573	20		30-41-12	ALL
ST..	1A	W2218	FRAA			21-31-23	ALL
DC..	1A	W2510	0005	20		30-21-32	ALL
ST..	1A	W2510	0006	20		30-21-32	ALL
GD00508		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2112	6026	20		73-21-12	ALL
ST..	1A	W2112	6027	20		73-21-12	ALL
DC..	1A	W2112	8008	20		27-32-11	ALL
ST..	1A	W2216	6007	20		73-21-12	ALL
DC..	1A	W2216	6008	20		73-21-12	ALL
AC..	1A	W2218	5611	20		33-12-12	ALL
AC..	1A	W2218	5655	20		33-12-12	ALL
AC..	1A	W2218	5812	20		33-12-12	ALL
DC..	1A	W2218	8002	20		27-32-21	ALL
DC..	1A	W2508	5596	20		33-18-42	ALL
DC..	1A	W2508	5602	20		33-18-42	ALL
DC..	1A	W2508	5644	20		35-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00508		**BACC50AN20 (continued)**				**P005-00/ /**	**ALL**
DC..	1A	W2508	5646	20		35-21-11	ALL
DC..	1A	W3327	0005	22		23-51-31	ALL
ST..	1A	W3327	0011	20		23-51-31	ALL
ST..	1A	W3327	0037	22		23-15-13	ALL
GD00509		**BACC50AN20**				**P005-00/ /**	**ALL**
ST..	1A	W2035	0036	20		34-21-11	ALL
DC..	1A	W2035	0039	20		34-16-11	ALL
ST..	1A	W2135	0002	20		34-21-21	ALL
DC..	1A	W2135	0031	20		34-16-21	ALL
AC..	1A	W2218	0102	20		33-12-11	ALL
DC..	1A	W2218	0523	20		27-81-11	ALL
ST..	1A	W2218	0556	20		27-81-11	ALL
AC..	1A	W2218	5734	20		33-12-12	ALL
DC..	1A	W2508	0019	20		31-65-41	ALL
DC..	1A	W2508	5628	20		33-18-42	ALL
DC..	1A	W2508	5655	20		33-18-42	ALL
DC..	1A	W2589	0016	22		23-24-11	ALL
GD00510		**BACC50AN16**				**P005-00/ /**	**ALL**
DC..	1	W2112	5556	18		30-42-11	ALL
DC..	1	W2112	6015	20		74-31-11	ALL
DC..	1	W2112	6020	20		74-31-11	ALL
DC..	1	W2112	6053	20		28-43-11	ALL
AC..	1	W2218	5561	18		33-14-12	ALL
AC..	1	W2218	5563	18		33-14-12	ALL
AC..	1	W2218	5605	20		33-12-12	ALL
AC..	1	W2218	5609	20		33-12-12	ALL
AC..	1	W2218	5716	20		33-12-12	ALL
AC..	1	W2218	5742	20		33-12-12	ALL
DC..	1	W2218	6014	20		74-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00512		**BACC50AN20**				**J004-00/ /**	**ALL**
DC..	1A	W0094	0052	20		27-41-12	ALL
DC..	1A	W0094	0086	22		27-61-45	ALL
DC..	1A	W0094	0165	20		44-21-22	ALL
AC..	1A	W0094	0238	20		33-42-21	ALL
DC..	1A	W0094	0258	20		22-13-11	ALL
DC..	1A	W0094	0260	20		22-11-31	ALL
DC..	1A	W0094	0420	20		44-35-11	ALL
DC..	1A	W0094	0431	20		44-35-11	ALL
DC..	1A	W0094	0437	20		44-35-11	ALL
GD00514		**BACC50AN16**				**J004-00/ /**	**ALL**
AC..	1	W0094	0084	20		33-42-21	ALL
GD00515		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2112	0513	20		24-28-11	ALL
DC..	1A	W2114	5502	22		21-27-31	ALL
DC..	1A	W2114	8002	20		34-41-11	ALL
DC..	1A	W2135	0019	22		31-65-25	ALL
DC..	1A	W2135	0025	20		34-51-41	ALL
DC..	1A	W2135	0026	20		34-51-41	ALL
DC..	1A	W2135	0030	22		31-65-25	ALL
DC..	1A	W2218	0512	20		24-28-11	ALL
ST..	1A	W2218	0513	20		24-28-11	ALL
DC..	1A	W2508	8013	20		34-21-15	ALL
DC..	1A	W2510	0504	20		24-31-12	ALL
DC..	1A	W2510	5703	20		31-52-41	ALL
DC..	1A	W2510	6001	20		28-21-11	ALL
ST..	1A	W2510	6013	20		28-43-11	ALL
DC..	1A	W2510	6016	20		76-21-21	ALL
GD00516		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2112	0530	20		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00516		**BACC50AN20 (continued)**				**P005-00/ /**	**ALL**
ST..	1A	W2112	0537	20		30-21-31	ALL
ST..	1A	W2112	2003Z			30-41-11	ALL
DC..	1A	W2112	5506	22		21-27-21	ALL
DC..	1A	W2112	5512	20		21-31-22	ALL
ST..	1A	W2112	5514	20		21-31-22	ALL
ST..	1A	W2112	5515	20		21-31-22	ALL
DC..	1A	W2112	5531	24		30-41-11	ALL
DC..	1A	W2112	5536	24		30-41-11	ALL
ST..	1A	W2112	5542	20		30-41-11	ALL
ST..	1A	W2112	6087	20		36-21-11	ALL
ST..	1A	W2112	FRAA			21-31-22	ALL
DC..	1A	W2216	5579	20		36-11-12	ALL
DC..	1D	W2218	5575	18		30-42-11	ALL
ST..	1A	W2218	5578	20		36-21-11	ALL
ST..	1A	W2218	5667	20		36-21-11	ALL
GD00517		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2035	0029	22		31-65-15	ALL
DC..	1A	W2035	0038	22		31-65-15	ALL
DC..	1A	W2112	0502	20		24-11-11	ALL
ST..	1A	W2112	0514	20		24-28-11	ALL
DC..	1A	W2112	0515	20		24-28-11	ALL
DC..	1A	W2112	0520	20		27-83-11	ALL
DC..	1A	W2112	8010	20		34-51-41	ALL
DC..	1A	W2112	8017	20		22-23-11	ALL
DC..	1A	W2112	8018	20		22-23-11	ALL
DC..	1A	W2112	8024	20		34-21-15	ALL
DC..	1A	W2212	0512	22		27-23-14	ALL
DC..	1A	W2216	5525	22		21-27-31	ALL
AC..	1A	W2218	0514	20		24-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00517		**BACC50AN20 (continued)**				**P005-00/ /**	**ALL**
AC..	1A	W2218	6002	20		28-42-11	ALL
DC..	1A	W2218	8004	20		34-51-41	ALL
DC..	1A	W2508	1018	20		33-18-41	ALL
GD00518		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2216	5527	20		21-51-12	ALL
DC..	1A	W2216	5550	20		30-31-12	ALL
DC..	1A	W2216	5560	20		21-61-11	ALL
ST..	1A	W2216	5561	20		21-61-11	ALL
DC..	1A	W2216	5564	20		21-61-14	ALL
DC..	1A	W2508	5502	20		21-31-11	ALL
DC..	1A	W2508	5568	20		33-18-36	ALL
DC..	1A	W2508	5603	20		33-18-36	ALL
DC..	1A	W2508	5619	20		21-51-11	ALL
DC..	1A	W2508	5632	20		33-18-35	ALL
DC..	1A	W2508	5745	20		33-18-35	ALL
ST..	1A	W2508	FRAB			21-31-11	ALL
DC..	1A	W2510	5504	20		21-31-23	ALL
DC..	1A	W2510	5506	22		21-43-21	ALL
GD00519		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2114	0074	20		33-18-37	ALL
AC..	1A	W2216	5703	20		33-12-11	ALL
AC..	1A	W2216	5705	20		33-12-11	ALL
AC..	1A	W2216	5707	20		33-12-11	ALL
AC..	1A	W2216	5709	20		33-12-11	ALL
DC..	1A	W2218	0040	24		36-11-31	ALL
DC..	1A	W2218	5668	20		36-11-22	ALL
AC..	1A	W2218	5709	20		33-12-12	ALL
AC..	1A	W2218	5710	20		33-12-12	ALL
AC..	1A	W2218	5713	20		33-12-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00519		**BACC50AN20 (continued)**				**P005-00/ /**	**ALL**
AC..	1A	W2218	5744	20		33-12-11	ALL
DC..	1A	W2508	0025	20		34-24-15	ALL
DC..	1A	W2510	6051	22		24-28-41	ALL
GD00520		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2212	0523	20		29-35-11	ALL
DC..	1A	W2212	0526	20		29-35-11	ALL
AC..	1A	W2216	5605	20		33-12-11	ALL
AC..	1A	W2216	5607	20		33-12-11	ALL
AC..	1A	W2216	5609	20		33-12-11	ALL
AC..	1A	W2216	5611	20		33-12-11	ALL
AC..	1A	W2216	5621	20		33-12-11	ALL
AC..	1A	W2216	5623	20		33-12-11	ALL
AC..	1A	W2216	5653	20		33-12-11	ALL
AC..	1A	W2216	5655	20		33-12-11	ALL
AC..	1A	W2216	5659	20		33-12-11	ALL
AC..	1A	W2216	5663	20		33-12-11	ALL
AC..	1A	W2216	5665	20		33-12-11	ALL
DC..	1A	W2218	0131	22		34-21-21	ALL
AC..	1A	W2218	5705	20		33-12-12	ALL
GD00522		**BACC50AN16**				**J022-00/ /**	**ALL**
DC..	1	W0076	0158	20		23-71-01	ALL
DC..	1	W0076	0159	20		23-71-01	ALL
DC..	1	W0076	0310	18		78-32-51	ALL
DC..	1	W0076	0312	18		78-32-51	ALL
DC..	1	W0076	0413	20		31-31-15	ALL
ST..	1	W0076	2503Z			78-32-51	ALL
ST..	1	W0076	2504Z			78-32-51	ALL
GD00524		**BACC50AN20**				**J024-00/ /**	**ALL**
DC..	1A	W0080	0515	20		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00524		**BACC50AN20 (continued)**				**J024-00/ /**	**ALL**
DC..	1A	W0080	0522	20		32-44-11	ALL
ST..	1A	W0080	2601Z			73-21-11	ALL
DC..	1A	W0080	6008	24		73-22-31	ALL
DC..	1A	W0080	6014	20		76-21-21	ALL
DC..	1A	W0080	6032	20		78-34-21	ALL
DC..	1A	W0080	6088	20		47-30-11	ALL
DC..	1A	W0080	6108	20		47-30-11	ALL
DC..	1A	W0080	6504	22		31-31-11	ALL
DC..	1A	W0080	6510	22		31-31-11	ALL
GD00526		**BACC50AN16**				**J023-00/ /**	**ALL**
DC..	1	W0078	0317	20		35-21-11	ALL
DC..	1	W0078	0325	22		35-21-11	ALL
DC..	1	W0078	0327	20		35-21-11	ALL
GD00528		**BACC50AN20**				**J020-0B/ /**	**ALL**
DC..	1A	W0072	0134	20		21-27-31	ALL
DC..	1A	W0072	0615	22		27-61-43	ALL
DC..	1A	W0072	0617	22		27-61-43	ALL
GD00530		**BACC50AN20**				**J020-0B/ /**	**ALL**
DC..	1A	W0072	0112	20		21-27-31	ALL
GD00532		**BACC50AN20**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0010	20		52-71-13	ALL
DC..	1A	W0076	0018	20		52-71-13	ALL
DC..	1A	W0076	0161	20		26-23-11	ALL
DC..	1A	W0076	0162	22		78-32-51	ALL
DC..	1A	W0076	0218	24		32-41-11	ALL
DC..	1A	W0076	0278	20		34-61-26	ALL
DC..	1A	W0076	0338	20		47-30-11	ALL
DC..	1A	W0076	0341	20		47-30-11	ALL
ST..	1A	W0076	0423	20		73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00532		**BACC50AN20 (continued)**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0461	20		74-11-11	ALL
DC..	1A	W0076	0464	22		78-32-51	ALL
DC..	1A	W0076	0466	22		78-32-51	ALL
GD00534		**BACC50AN20**				**J024-00/ /**	**ALL**
DC..	1A	W0080	0008	20		52-71-14	ALL
DC..	1A	W0080	0009	20		52-71-14	ALL
DC..	1A	W0080	0024	20		23-71-01	ALL
DC..	1D	W0080	0046	18		78-32-61	ALL
DC..	1D	W0080	0048	18		78-32-61	ALL
ST..	1A	W0080	2607Z			78-32-61	ALL
ST..	1A	W0080	2608Z			78-32-61	ALL
DC..	1A	W0080	5539	22		21-27-21	ALL
DC..	1D	W0080	6023	18		78-32-61	ALL
DC..	1D	W0080	6024	18		78-32-61	ALL
DC..	1D	W0080	6025	18		78-32-61	ALL
DC..	1D	W0080	6026	18		78-32-61	ALL
DC..	1A	W0080	6028	22		78-32-61	ALL
DC..	1D	W0080	6029	18		78-32-61	ALL
DC..	1D	W0080	6043	18		78-32-61	ALL
DC..	1D	W0080	6049	18		78-32-61	ALL
GD00541		**AC-**				**191/242/L002**	**ALL**
AC..	E	W2363	1063	20		33-11-31	ALL
DED		W2363	1063Z			33-11-31	ALL
GD00542		**BACC50AN20**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0086	22		34-41-11	ALL
DC..	1A	W0076	0115	20		78-34-11	ALL
DC..	1A	W0076	0125	24		73-22-31	ALL
DC..	1A	W0076	0128	22		31-31-11	ALL
DC..	1A	W0076	0138	20		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00542		**BACC50AN20 (continued)**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0152	22		78-32-51	ALL
DC..	1D	W0076	0155	18		78-32-51	ALL
DC..	1D	W0076	0157	18		78-32-51	ALL
ST..	1D	W0076	0529	18		78-32-51	ALL
DC..	1D	W0076	0530	18		78-32-51	ALL
ST..	1A	W0076	2001Z			73-21-11	ALL
GD00544		**BACC50AN16**				**J024-00/ /**	**ALL**
DC..	1	W0080	5504	20		21-25-11	ALL
DC..	1	W0080	5518	22		21-43-21	ALL
DC..	1	W0080	5521	22		21-43-21	ALL
DC..	1	W0080	5524	22		21-43-21	ALL
DC..	1	W0080	5552	20		21-25-11	ALL
DC..	1	W0080	5558	20		21-25-11	ALL
DC..	1	W0080	5613	20		21-27-21	ALL
DC..	1	W0080	6113	20		31-31-15	ALL
GD00548		**AC-**				**597/158/L007**	**ALL**
AC..	GW	W5502	1007	20		36-11-31	ALL
AC..	GW	W5502	1007Z			36-11-31	ALL
GD00552		**AC-**				**655/156/L039**	**ALL**
AC..	GW	W5102	0014	20		33-33-11	ALL
AC..	GW	W5102	1202	20		33-44-11	ALL
GD00556		**AC-**				**653/156/R009**	**ALL**
AC..	GW	W6202	1032	20		21-51-22	ALL
AC..	GW	W6202	1032Z			21-51-22	ALL
GD00557		**ST**				**/ /**	**ALL**
GD00567		**ST-**				**197/198/R030**	**ALL**
ST..	E	W5156	2607Z			31-65-25	ALL
ST..	E	W5156	2615Z			31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00569		**BACC50AN20**				**345/190/R059**	**ALL**
ST..	1A	W5506	0034	22		26-19-11	ALL
ST..	1A	W5506	0035	22		26-19-11	ALL
ST..	1A	W5506	0036	22		26-19-11	ALL
DC..	1A	W5506	0084	20		26-19-11	ALL
DC..	1A	W5506	0085	22		26-19-11	ALL
ST..	1A	W5506	0086	20		26-19-11	ALL
GD00572		**DC-**				**364/157/L029**	**ALL**
DC..	F	W2536	0513	08		24-34-11	ALL
GD00575		**ST-**				**IRSS 219/ /**	**ALL**
ST..	E	W7230	2220Z			28-42-11	ALL
GD00576		**BACC50AN20**				**J023-0A/ /**	**ALL**
DC..	1A	W0098	0116	22		26-19-11	ALL
DC..	1A	W0098	0117	22		26-19-11	ALL
DC..	1A	W0098	0121	22		26-19-11	ALL
DC..	1A	W0098	0168	22		26-19-11	ALL
DC..	1A	W0098	0169	22		26-19-11	ALL
DC..	1A	W0098	0172	22		26-19-11	ALL
GD00580		**BACC50AN20**				**345/160/L020**	**ALL**
DC..	1A	W0098	0133	22		26-19-11	ALL
DC..	1A	W0098	0138	22		26-19-11	ALL
DC..	1A	W0098	0148	22		26-19-11	ALL
DC..	1A	W0098	0155	22		26-19-11	ALL
DC..	1A	W0098	0160	22		26-19-11	ALL
DC..	1A	W0098	0175	24		21-51-11	ALL
GD00588		**BACC50AN20**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0147	22		23-15-15	ALL
DC..	1A	W0076	0276	20		34-61-26	ALL
DC..	1A	W0076	0366	20		27-33-11	ALL
DC..	1A	W0076	0415	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00588		**BACC50AN20 (continued)**				**J022-00/ /**	**ALL**
DC..	1A	W0076	0416	20		46-13-11	ALL
ST..	1A	W0076	0422	20		73-22-11	ALL
AC..	1A	W0076	0452	20		73-22-11	ALL
AC..	1A	W0076	0457	20		74-11-11	ALL
GD00590		**AC-**				**372/157/L048**	**ALL**
AC..	E	W5142	2428B	18		33-23-11	ALL
AC..	E	W5142	2429B	18		33-23-11	ALL
AC..	E	W5142	2430B	18		33-23-11	ALL
GD00592		**AC-**				**373/157/L030**	**ALL**
AC..	E	W5142	2431B	18		33-23-11	ALL
AC..	E	W5142	2432B	18		33-23-12	ALL
AC..	E	W5142	2433B	18		33-23-12	ALL
GD00594		**AC-**				**374/157/L030**	**ALL**
AC..	E	W5142	2434B	18		33-23-12	ALL
AC..	E	W5142	2435B	18		33-23-12	ALL
AC..	E	W5142	2436B	18		33-23-12	ALL
GD00596		**AC-**				**213/208/L036**	**ALL**
AC..	E	W2102	5518	20		33-11-11	ALL
AC..	E	W2102	5535	20		33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00600		**AC-**				**387/167/R047**	**ALL**
AC..	F	W4256	0022	08		24-51-21	ALL
GD00602		**AC-**				**195/208/L032**	**ALL**
AC..	E	W5501	0006	20		34-21-12	ALL
AC..	E	W5501	0009	22		27-32-11	ALL
AC..	E	W5501	0013	22		30-31-11	ALL
GD00604		**AC-**				**223/267/L015**	**ALL**
AC..	E	W2102	5528	20		33-17-11	ALL
GD00605		**AC-**				**P006-00/ /**	**ALL**
AC..	E	W0044	6221	16		33-11-41	ALL
AC..	E	W0044	6223	16		33-11-41	ALL
GD00606		**AC-**				**195/208/R033**	**ALL**
AC..	E	W5503	0006	20		34-21-22	ALL
AC..	E	W5503	0008	22		27-32-21	ALL
AC..	E	W5503	0011	22		30-31-12	ALL
AC..	E	W5503	0013	22		30-31-12	ALL
GD00608		**AC-**				**P006-00/ /**	**ALL**
AC..	E	W0044	0074	10		33-12-11	ALL
AC..	E	W0044	0084	10		33-12-12	ALL
AC..	E	W0044	0456	20		21-31-25	ALL
GD00610		**AC-**				**223/267/R015**	**ALL**
AC..	E	W2204	5507	18		33-14-12	ALL
AC..	E	W2204	5510	20		33-17-11	ALL
AC..	E	W2204	B-BG			33-17-11	ALL
GD00612		**AC-**				**244/180/R037**	**ALL**
AC..	E	W6024	0503	22		24-41-11	ALL
GD00614		**AC-**				**IFSS-167/ /**	**ALL**
AC..	E	W1180	J-Y			27-81-11	ALL
GD00618		**AC-**				**P006-00/ /**	**ALL**
AC..	E	W0044	A-AG			33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00620		**BACC50AN20**				**P006-00/ /**	**ALL**
DC..	1A	W0044	0022	24		24-31-11	ALL
DC..	1A	W0044	0127	20		33-18-11	ALL
DC..	1A	W0044	0181	20		33-18-36	ALL
DC..	1A	W0044	0564	20		33-29-11	ALL
GD00622		**DC-**				**P006-00/ /**	**ALL**
DC..	E	W0044	0454	22		21-31-23	ALL
GD00624		**BACC50AN16**				**P006-00/ /**	**ALL**
AC..	1	W0041	0011	22		31-32-15	ALL
DC..	1	W0041	0012	22		31-32-15	ALL
DC..	1	W0041	0038	20		31-52-71	ALL
DC..	1	W0041	0055	20		34-58-21	ALL
DC..	1	W0041	0057	20		23-51-31	ALL
DC..	1	W0041	0104	20		34-58-11	ALL
DC..	1	W0041	0106	20		34-58-11	ALL
DC..	1	W0041	0125	20		31-65-21	ALL
ST..	1	W0041	0126	20		31-65-21	ALL
DC..	1	W0041	0129	20		34-58-11	ALL
DC..	1	W0044	0539	20		33-18-62	ALL
GD00626		**BACC50AN20**				**P006-00/ /**	**ALL**
DC..	1A	W0044	0110	20		33-18-11	ALL
DC..	1A	W0044	0111	20		33-18-11	ALL
DC..	1A	W0044	0113	20		33-18-11	ALL
DC..	1A	W0044	0114	20		33-18-11	ALL
DC..	1A	W0044	0120	20		33-18-11	ALL
DC..	1A	W0044	0123	20		33-18-11	ALL
DC..	1A	W0044	0444	20		21-31-11	ALL
DC..	1A	W0044	0450	20		21-31-22	ALL
GD00628		**DC-**				**P006-00/ /**	**ALL**
DC..	E	W0044	A-AB			33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00630		**BACC50AN20**				**P006-00/ /**	**ALL**
AC..	1A	W0044	0367	24		24-32-11	ALL
AC..	1A	W0044	0368	24		24-32-11	ALL
DC..	1A	W0044	0525	24		24-31-12	ALL
GD00632		**BACC50AN20**				**P006-00/ /**	**ALL**
DC..	1A	W0044	0524	24		24-31-12	ALL
DC..	1A	W0044	0526	24		24-31-12	ALL
DC..	1A	W0044	0550	24		24-31-11	ALL
DC..	1A	W0044	0551	24		24-31-11	ALL
GD00634		**AC-**				**P006-00/ /**	**ALL**
AC..	E	W0040	6204	08		24-53-11	ALL
GD00636		**AC-**				**P006-00/ /**	**ALL**
AC..	E	W0040	6207	10		24-53-11	ALL
GD00638		**BACC50AN20**				**P006-00/ /**	**ALL**
DC..	1A	W0044	0252	20		25-29-11	ALL
ST..	1A	W0044	0253	20		25-29-11	ALL
AC..	1A	W0044	0255	20		25-29-11	ALL
ST..	1A	W0044	0256	20		25-29-11	ALL
ST..	1A	W0044	0646	20		28-21-21	ALL
DC..	1A	W0044	0651	20		28-21-21	ALL
DC..	1A	W0044	0655	20		28-21-21	ALL
DC..	1A	W0044	0901	22		52-51-11	ALL
ST..	1A	W0044	0906	22		52-51-11	ALL
DC..	1A	W0044	0907	22		52-51-11	ALL
DC..	1A	W0044	0941	20		28-23-11	ALL
GD00642		**BACC50AN20**				**P006-00/ /**	**ALL**
DC..	1A	W0044	0937	20		28-23-11	ALL
DC..	1A	W0044	0997	20		23-70-11	ALL
GD00644		**ST-**				**P006-00/ /**	**ALL**
ST..	F	W0044	0692	08		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00648		**BACC50AN20**				**J011-0A/ /**	**ALL**
DC..	1A	W0122	0067	22		49-62-11	ALL
DC..	1A	W0122	0071	22		49-62-11	ALL
GD00656		**DC-**				**660/153/L032**	**ALL**
DC..	E	W5104	0334	20		21-51-14	ALL
GD00658		**DC-**				**660/154/R033**	**ALL**
DC..	E	W6230	0334	20		21-51-24	ALL
DC..	GW	W8122	1012	20		27-83-11	ALL
DC..	GW	W8122	1012Z			27-83-11	ALL
GD00662		**BACC50AN20**				**721/204/R035**	**ALL**
ST..	1A	W5204	1001Z			47-30-11	ALL
ST..	1A	W5204	1002Z			47-30-11	ALL
ST..	1A	W5204	1003Z			47-30-11	ALL
ST..	1A	W5204	1004Z			47-30-11	ALL
ST..	1A	W5204	1005Z			47-30-11	ALL
ST..	1A	W5204	1006Z			47-30-11	ALL
ST..	1A	W5204	1007Z			47-30-11	ALL
ST..	1A	W5204	1008Z			47-30-11	ALL
ST..	1A	W5204	1009Z			47-30-11	ALL
ST..	1A	W5204	1010Z			47-30-11	ALL
DC..	1A	W6228	0511	22		32-42-11	ALL
DC..	1A	W6228	0512	22		32-42-11	ALL
DC..	1A	W6228	0592	22		32-41-11	ALL
GD00690		**AC-**				**374/167/R047**	**ALL**
AC..	E	W6242	2428B	18		33-23-21	ALL
AC..	E	W6242	2429B	18		33-23-21	ALL
AC..	E	W6242	2430B	18		33-23-21	ALL
GD00692		**AC-**				**375/168/R047**	**ALL**
AC..	E	W6242	2431B	18		33-23-21	ALL
AC..	E	W6242	2432B	18		33-23-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00692		**AC- (continued)**				**375/168/R047**	**ALL**
AC..	E	W6242	2433B	18		33-23-22	ALL
GD00694		**AC-**				**376/168/R047**	**ALL**
AC..	E	W6242	2434B	18		33-23-22	ALL
AC..	E	W6242	2435B	18		33-23-22	ALL
AC..	E	W6242	2436B	18		33-23-22	ALL
GD00695		**ST**				**P001/ /**	**ALL**
ST..	E	W0001	1501Z			31-65-11	ALL
GD00696		**ST**				**P001/ /**	**ALL**
ST..	E	W0001	1505Z			31-65-11	ALL
GD00697		**ST**				**P001/ /**	**ALL**
ST..	E	W0001	1509Z			31-65-11	ALL
GD00698		**ST**				**P001/ /**	**ALL**
ST..	E	W0001	1514Z			31-65-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00700		**ST**				**P003/ /**	**ALL**
ST..	E	W0003	1401Z			31-65-21	ALL
GD00701		**DC-**				**P007-01/ /**	**ALL**
DC..	E	W0001	1509	20		31-65-11	ALL
GD00703		**DC-**				**P007-02/ /**	**ALL**
DC..	E	W0003	1681	20		31-65-21	ALL
GD00705		**ST**				**P003/ /**	**ALL**
ST..	E	W0003	1505Z			31-65-21	ALL
GD00709		**ST**				**P003/ /**	**ALL**
ST..	E	W0003	1681Z			31-65-21	ALL
GD00710		**ST-**				**IFSS-84/ /**	**ALL**
ST..	E	W5104	0332	20		21-51-14	ALL
GD00712		**DC-**				**IFSS-84/ /**	**ALL**
DC..	E	W5104	0333	20		21-51-14	ALL
GD00714		**ST-**				**520/175/R058**	**ALL**
ST..	E	W6230	0332	20		21-51-24	ALL
GD00716		**DC-**				**520/174/R057**	**ALL**
DC..	E	W6230	0333	20		21-51-24	ALL
GD00748		**AC-**				**365/158/L030**	**ALL**
AC..	F	W2536	0514	12		24-34-11	ALL
GD00752		**DC-**				**367/152/L019**	**ALL**
DC..	F8	W2532	0534	02		24-31-11	ALL
GD00756		**ST-**				**685/157/R007**	**ALL**
ST..	E	W8228	FRAA			78-34-21	ALL
GD00760		**ST-**				**663/155/L016**	**ALL**
ST..	E	W7522	FRAA			78-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00800		**BACC50AN20**				**208/203/R014**	**ALL**
DC..	1A	W5369	0010	20		22-13-11	ALL
ST..	1A	W5369	0022	20		22-13-11	ALL
ST..	1A	W5369	0023	20		22-13-11	ALL
DC..	1A	W5369	0107	22		22-31-51	ALL
DC..	1A	W5506	6011	20		76-21-11	ALL
DC..	1A	W5514	5550	20		21-33-11	ALL
DC..	1A	W6208	0623	20		32-64-21	ALL
DC..	1A	W6208	5507	20		33-18-61	ALL
GD00801		**BACC50AN20**				**P008-00/ /**	**ALL**
DC..	1A	W2149	0011	22		34-51-11	ALL
DC..	1A	W2149	0028	20		34-51-41	ALL
DC..	1A	W2149	0048	22		34-51-11	ALL
DC..	1A	W2149	0056	22		34-51-11	ALL
DC..	1A	W2177	0006	20		34-53-11	ALL
ST..	1A	W2177	0028	20		34-53-11	ALL
ST..	1A	W2413	0001	20		23-12-11	ALL
DC..	1A	W2413	0041	20		23-12-11	ALL
AC..	1A	W6208	0513	20		27-28-11	ALL
AC..	1A	W6208	0515	20		27-28-11	ALL
ST..	1A	W6208	0516	20		27-28-11	ALL
GD00802		**BACC50AN16**				**208/203/R014**	**ALL**
DC..	1	W5503	0017	20		21-33-11	ALL
DC..	1	W5510	6001	20		76-21-11	ALL
AC..	1	W6208	5506	16		33-11-41	ALL
GD00803		**BACC50AN20**				**P008-00/ /**	**ALL**
DC..	1A	W2151	0011	22		34-51-21	ALL
DC..	1A	W2151	0028	20		34-51-41	ALL
DC..	1A	W2151	0048	22		34-51-21	ALL
DC..	1A	W2151	0056	22		34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00803		**BACC50AN20 (continued)**				**P008-00/ /**	**ALL**
DC..	1A	W2247	0006	20		34-53-21	ALL
DC..	1A	W2307	0002	20		23-31-01	ALL
AC..	1A	W2805	0002	20		31-33-01	ALL
ST..	1A	W2805	0003	20		31-33-01	ALL
DC..	1A	W2805	0004	20		31-33-01	ALL
AC..	1A	W2805	0008	20		33-11-41	ALL
DC..	1A	W3323	0005	22		23-51-11	ALL
ST..	1A	W3323	0011	20		23-51-11	ALL
DC..	1A	W5457	0107	22		22-31-51	ALL
GD00805		**BACC50AN20**				**P008-00/ /**	**ALL**
AC..	1A	W2149	0052	20		33-11-33	ALL
AC..	1A	W2151	0052	20		33-11-41	ALL
AC..	1A	W2177	0002	20		33-11-33	ALL
AC..	1A	W2265	0006	20		33-11-33	ALL
AC..	1A	W2415	0038	20		33-11-41	ALL
AC..	1A	W3319	0009	20		33-11-33	ALL
AC..	1A	W3323	0009	20		33-11-33	ALL
ST..	1A	W3323	0037	22		23-15-13	ALL
AC..	1A	W5506	5505	20		33-11-33	ALL
AC..	1A	W6206	5534	20		33-11-41	ALL
AC..	1A	W6208	5502	20		33-11-41	ALL
AC..	1A	W6208	5504	20		33-11-41	ALL
AC..	1A	W6491	0531	20		33-11-41	ALL
GD00807		**BACC50AN20**				**P008-00/ /**	**ALL**
DC..	1A	W2110	6010	20		26-16-21	ALL
DC..	1A	W2110	6011	20		26-16-21	ALL
ST..	1A	W2110	6012	20		26-16-21	ALL
AC..	1A	W2110	6033	20		33-11-33	ALL
ST..	1A	W2415	0001	20		23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00807		**BACC50AN20 (continued)**				**P008-00/ /**	**ALL**
DC..	1A	W2415	0041	20		23-12-21	ALL
ST..	1A	W2417	0001	20		23-12-31	ALL
AC..	1A	W2417	0038	20		33-11-41	ALL
DC..	1A	W2417	0041	20		23-12-31	ALL
AC..	1A	W3709	0002	20		33-11-41	ALL
DC..	1A	W6206	0011	22		52-51-11	ALL
DC..	1A	W6506	6007	20		76-21-21	ALL
GD00809		**BACC50AN20**				**P008-00/*/***	**ALL**
DC..	1A	W3319	0005	22		23-51-21	ALL
ST..	1A	W3319	0011	20		23-51-21	ALL
ST..	1A	W3319	0041	22		23-15-13	ALL
DC..	1A	W5506	5501	24		36-11-12	ALL
DC..	1A	W5506	6026R	22		26-11-11	ALL
DC..	1A	W6506	5501	24		36-11-22	ALL
DC..	1A	W6510	6007	20		76-21-21	ALL
GD00811		**BACC50AN20**				**P008-00/ /**	**ALL**
ST..	1A	W2149	0042	20		34-51-11	ALL
AC..	1A	W2149	0055	20		34-51-11	ALL
AC..	1A	W2177	0004	20		34-53-11	ALL
ST..	1A	W2177	0008	20		34-53-11	ALL
ST..	1A	W2265	0001	20		34-57-11	ALL
AC..	1A	W2265	0004	20		34-57-11	ALL
AC..	1A	W6208	0510	20		27-21-11	ALL
ST..	1A	W6208	0511	20		27-21-11	ALL
AC..	1A	W6208	0564	20		27-11-11	ALL
DC..	1A	W6510	6017	20		76-21-21	ALL
GD00813		**BACC50AN20**				**P008-00/*/***	**ALL**
DC..	1A	W5510	0540	22		31-53-11	ALL
DC..	1A	W5510	0571	22		32-64-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00813		**BACC50AN20 (continued)**				**P008-00/*/***	**ALL**
DC..	1A	W5510	0573	22		32-64-21	ALL
DC..	1A	W5510	6087	22		30-11-11	ALL
DC..	1A	W5510	6089	22		78-32-51	ALL
DC..	1A	W6162	0540	22		31-53-11	ALL
DC..	1A	W6162	0559	22		32-64-21	ALL
DC..	1A	W6162	0560	22		32-64-21	ALL
DC..	1A	W6162	6086	22		30-11-11	ALL
DC..	1A	W6162	6089	20		78-32-61	ALL
DC..	1A	W6491	0014	20		34-41-11	ALL
DC..	1A	W6506	6001R	20		26-11-31	ALL
DC..	1A	W6506	6004R	20		26-11-31	ALL
DC..	1A	W6506	6084R	22		26-11-21	ALL
GD00814		**ST-**				**IFSS 97/ /**	**ALL**
ST..	GW	W1664	2001ZO			28-41-11	ALL
GD00815		**BACC50AN20**				**P008-00/*/***	**ALL**
ST..	1A	W2151	0042	20		34-51-21	ALL
AC..	1A	W2151	0055	20		34-51-21	ALL
AC..	1A	W2247	0004	20		34-53-21	ALL
ST..	1A	W2247	0008	20		34-53-21	ALL
ST..	1A	W2247	0029	20		34-53-21	ALL
ST..	1A	W2267	0001	20		34-57-21	ALL
AC..	1A	W2267	0004	20		34-57-21	ALL
ST..	1A	W5162	6003	20		73-21-21	ALL
ST..	1A	W5172	6002	20		73-21-21	ALL
ST..	1A	W5506	6085	20		78-35-11	ALL
DC..	1A	W5510	6022	20		76-21-11	ALL
ST..	1A	W6162	6003	20		73-21-21	ALL
ST..	1A	W6172	6002	20		73-21-21	ALL
ST..	1A	W6491	0042	20		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00815		**BACC50AN20 (continued)**				**P008-00/*/***	**ALL**
ST..	1A	W6506	6079	20		78-35-21	ALL
GD00817		**BACC50AN16**				**J019-00/ /**	**ALL**
AC..	1	W2413	0038	16		33-11-33	ALL
AC..	1	W6206	5502	16		33-11-33	ALL
AC..	1	W6206	5508	16		33-11-33	ALL
AC..	1	W6206	5529	16		33-11-41	ALL
AC..	1	W6206	5530	16		33-11-41	ALL
AC..	1	W6206	5538	18		33-14-12	ALL
GD00822		**AC-**				**IFSS-118/ /**	**ALL**
AC..	GW	W1662	1024	18		33-42-21	ALL
GD00824		**ST-**				**IFSS-118/ /**	**ALL**
ST..	GW	W1662	0019	18		33-42-21	ALL
ST..	GW	W1662	1024Z			33-42-21	ALL
GD00826		**AC-**				**IFSS 98/ /**	**ALL**
AC..	GW	W1664	1025	18		33-42-21	ALL
GD00828		**ST-**				**IFSS 98/ /**	**ALL**
ST..	GW	W1664	0019	18		33-42-21	ALL
ST..	GW	W1664	1025Z			33-42-21	ALL
GD00830		**BACC50AN20**				**P005-00/ /**	**ALL**
AC..	1A	W2104	0024	20		33-42-21	ALL
AC..	1A	W2104	0025	20		33-42-21	ALL
DC..	1A	W2508	2002B	20		33-14-12	ALL
DC..	1A	W2508	5629	20		33-18-42	ALL
DC..	1A	W2508	5630	20		33-18-42	ALL
DC..	1A	W2508	5631	20		33-18-42	ALL
GD00832		**BACC50AN20**				**P005-00/ /**	**ALL**
DC..	1A	W2112	0170	22		34-21-11	ALL
AC..	1A	W2218	0087	20		33-42-21	ALL
AC..	1A	W2218	0088	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00832		**BACC50AN20 (continued)**				**P005-00/ /**	**ALL**
AC..	1A	W2218	6043	20		28-23-11	ALL
AC..	1A	W2218	6044	20		28-23-11	ALL
AC..	1A	W2218	6045	20		28-23-11	ALL
AC..	1A	W2218	6056	20		28-23-11	ALL
GD00869		**BACC50AN20**				**360/154/R018**	**ALL**
DC..	1A	W5506	0024	20		26-19-11	ALL
DC..	1A	W5506	0025	22		26-19-11	ALL
ST..	1A	W5506	0026	20		26-19-11	ALL
ST..	1A	W5506	0031	22		26-19-11	ALL
ST..	1A	W5506	0032	22		26-19-11	ALL
ST..	1A	W5506	0033	22		26-19-11	ALL
GD00870		**ST-**				**OFSS 373/ /**	**ALL**
ST..	E	W1664	1012Z			28-44-11	ALL
ST..	E	W1664	1013Z			28-44-11	ALL
ST..	E	W1664	1016Z			28-44-11	ALL
ST..	E	W1664	1020Z			28-44-11	ALL
ST..	E	W1664	1021Z			28-44-11	ALL
ST..	E	W1664	1022Z			28-44-11	ALL
ST..	E	W1664	1023Z			28-44-11	ALL
ST..	E	W1664	1026Z			28-44-11	ALL
GD00887		**AC**				**F057/330/L002**	**ALL**
AC..	E	W7057	0004	18		23-11-11	ALL
AC..	E	W7061	0004	18		23-11-21	ALL
GD00889		**DC**				**F057/330/R002**	**ALL**
DC..	E	W7057	0006	18		23-11-11	ALL
DC..	E	W7061	0006	18		23-11-21	ALL
GD00891		**ST-**				**238/202/L014**	**ALL**
ST..	E	W5457	0002	22		22-11-31	ALL
ST..	E	W5457	0025	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD00904		**BACC50AN20**				**1158/283/L014**	**ALL**
ST..	1D	W3397	1002Z			22-11-12	ALL
ST..	1D	W3397	1003Z			22-11-12	ALL
DC..	1A	W3399	0004	20		22-12-41	ALL
DC..	1A	W3399	0005	20		22-12-41	ALL
ST..	1D	W3399	1001Z			22-12-41	ALL
ST..	1D	W3399	1004Z			22-12-41	ALL
ST..	1D	W3399	2006Z			22-12-41	ALL
ST..	1D	W3399	2007Z			22-12-41	ALL
ST..	1D	W3399	3001Z			22-12-41	ALL
GD00906		**BACC50AN16**				**1158/283/R014**	**ALL**
DC..	1	W7030	1003	18		27-31-11	ALL
ST..	1	W7030	1003Z			27-31-11	ALL
GD00912		**AC-**				**366/157/L029**	**ALL**
AC..	F	W2132	0004	08		24-51-11	ALL
GD00918		**DC-**				**388/173/L053**	**ALL**
DC..	E	W5726	0569	20		24-51-11	ALL
GD00920		**AC-**				**377/168/R048**	**ALL**
AC..	F	W6424	0012	08		24-51-21	ALL
GD00922		**DC-**				**389/167/R047**	**ALL**
DC..	E	W6410	0506	20		24-51-21	ALL
GD00947		**ST-**				**666/194/L059**	**ALL**
ST..	E	W1136	1304Z			28-43-11	ALL
ST..	GW	W1380	1012Z			28-43-11	ALL
ST..	GW	W1380	3001Z			28-23-11	ALL
ST..	E	W5375	YAAA			22-11-31	ALL
ST..	E	W7026	0519	20		32-35-11	ALL
ST..	E	W7026	0521	18		32-31-15	ALL
GD00949		**ST-**				**1157/260/L010**	**ALL**
DC..	E	W3397	0002	20		22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00949		**ST- (continued)**				**1157/260/L010**	**ALL**
DC..	E	W3397	0022	20		22-12-31	ALL
ST..	E	W3397	1001Z			22-12-31	ALL
ST..	E	W3397	1004Z			22-12-31	ALL
ST..	E	W3397	2006Z			22-12-31	ALL
ST..	E	W3397	2007Z			22-12-31	ALL
ST..	E	W3397	3001Z			22-12-31	ALL
GD00977		**ST-**				**192/242/L003**	**ALL**
ST..	E	W2108	FRAC			30-41-11	ALL
ST..	E	W2108	YAAD			30-41-11	ALL
ST..	E	W2363	1001Z			22-11-11	ALL
ST..	E	W2363	1002Z			22-11-11	ALL
ST..	E	W2363	1005Z			22-11-11	ALL
ST..	E	W2363	1015Z			22-31-51	ALL
GD00980		**ST-**				**191/242/R002**	**ALL**
ST..	E	W2208	FRAC			30-41-12	ALL
ST..	E	W2208	YAAD			30-41-12	ALL
ST..	E	W2465	1001Z			22-11-11	ALL
ST..	E	W2465	1005Z			22-11-11	ALL
ST..	E	W2465	1047Z			22-11-11	ALL
ST..	E	W2465	1055Z			22-11-11	ALL
GD00981		**DC-**				**192/242/L004**	**ALL**
DC..	E	W2363	1001	20		22-11-11	ALL
DC..	E	W2363	1002	20		22-11-11	ALL
DC..	E	W2363	1005	20		22-11-11	ALL
DC..	E	W2363	1015	22		22-31-51	ALL
GD00985		**DC-**				**191/242/R003**	**ALL**
DC..	E	W2465	1001	20		22-11-11	ALL
DC..	E	W2465	1005	20		22-11-11	ALL
DC..	E	W2465	1047	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00985		**DC- (continued)**				**191/242/R003**	**ALL**
DC..	E	W2465	1055	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01001		**DC-**				**IRSS 150/ /**	**ALL**
DC..	N	W1134	1301	20		28-43-11	ALL
GD01002		**DC-**				**IRSS 158/ /**	**ALL**
DC..	N	W1136	1303	20		28-43-11	ALL
GD01008		**BACC50AN20**				**376/169/R048**	**ALL**
ST..	1A	W5030	5504	20		21-27-31	ALL
DC..	1A	W5158	0002	20		35-11-11	ALL
DC..	1A	W5158	0553	20		21-43-21	ALL
DC..	1A	W5158	0554	20		21-31-24	ALL
ST..	1A	W5158	0556	20		21-43-21	ALL
DC..	1A	W5337	0004	22		34-21-12	ALL
ST..	1A	W6110	5506	20		21-27-21	ALL
GD01018		**AC-**				**259/280/L009**	**ALL**
AC..	E	W2216	5543	16		33-12-11	ALL
GD0101A		**BACC50AN16**				**P001-00/ /**	**ALL**
ST..	1	W0001	0002	16		31-65-11	ALL
ST..	1	W0001	0003	16		31-65-11	ALL
ST..	1	W0001	0004	16		31-65-11	ALL
ST..	1	W0001	0006	16		31-65-11	ALL
ST..	1	W0001	0007	16		31-65-11	ALL
ST..	1	W0001	0008	16		31-65-11	ALL
ST..	1	W0001	0010	20		31-65-11	ALL
ST..	1	W0001	0011	20		31-65-11	ALL
ST..	1	W0001	0012	20		31-65-11	ALL
ST..	1	W0001	0013	20		31-65-11	ALL
GD0101B		**BACC50AN20**				**P001-00/ /**	**ALL**
DC..	1A	W0001	1019	22		34-61-16	ALL
DC..	1A	W0001	1019Z			34-61-16	ALL
DC..	1A	W0001	1166	22		34-49-11	ALL
DC..	1A	W0001	1166Z			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0101B		**BACC50AN20 (continued)**				**P001-00/ /**	**ALL**
DC..	1A	W0001	1589	20		22-14-11	ALL
DC..	1A	W0001	1589Z			22-14-11	ALL
GD0101C		**BACC50AN20**				**P001-00/ /**	**ALL**
DC..	1A	W0001	1554	22		31-65-13	ALL
DC..	1A	W0001	1554Z			31-65-13	ALL
GD0101D		**BACC50AN20**				**P001-00/ /**	**ALL**
DC..	1A	W0003	1554	22		31-65-23	ALL
DC..	1A	W0003	1554Z			31-65-23	ALL
GD01034		**ST-**				**OFSS 257/ /**	**ALL**
ST..	E	W1664	0017	20		30-11-11	ALL
GD01041		**ST-**				**221/198/R026**	**ALL**
ST..	E	W5369	0001	20		22-11-11	ALL
GD01044		**DC-**				**201/205/L012**	**ALL**
DC..	E	W6208	0555	20		27-62-11	ALL
DC..	E	W6208	0557	20		27-62-11	ALL
GD01047		**DC-**				**E005-00/ /**	**ALL**
DC..	E	W0737	0036	22		34-61-19	ALL
DC..	E	W0737	0037	22		34-61-19	ALL
GD01053		**ST-**				**225/199/R024**	**ALL**
ST..	E	W5457	0035	20		22-11-11	ALL
GD01054		**DC-**				**OFSS 374/ /**	**ALL**
DC..	E	W1664	1016	20		28-44-11	ALL
DC..	E	W1664	A-E			28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01100		**ST-**				**OFSS-259/ /**	**ALL**
ST..	E	W1662	0010	20		30-11-11	ALL
GD01102		**BACC50AN20**				**E001-01/ /**	**ALL**
AC..	1A	W0111	0004	22		22-11-11	ALL
DC..	1A	W0111	0005	20		22-11-11	ALL
DC..	1A	W0111	0006	20		22-11-11	ALL
DC..	1A	W0111	0007	20		22-11-11	ALL
ST..	1A	W0111	0008	20		22-11-11	ALL
AC..	1A	W0111	0067	22		34-45-11	ALL
DC..	1A	W0111	0116	22		22-11-75	ALL
AC..	1A	W0111	0118	22		27-51-11	ALL
AC..	1A	W0111	0133	22		22-18-11	ALL
AC..	1A	W0111	0134	22		22-18-11	ALL
DC..	1A	W0111	0218	22		27-81-41	ALL
ST..	1A	W0111	0394	20		34-21-21	ALL
AC..	1A	W0111	0712	22		27-53-21	ALL
AC..	1A	W0111	0713	22		27-53-21	ALL
AC..	1A	W0111	1003	20		27-52-11	ALL
DED		W0111	1003Z			27-52-11	ALL
GD01103		**BACC50AN20**				**E001-01/ /**	**ALL**
DC..	1A	W0111	0031	20		22-11-11	ALL
ST..	1A	W0111	0032	20		22-11-11	ALL
AC..	1A	W0111	0035	20		22-11-11	ALL
DC..	1A	W0111	0225	22		22-11-75	ALL
DC..	1A	W0111	0380	22		34-21-15	ALL
DC..	1A	W0111	0382	22		34-21-15	ALL
DC..	1A	W0111	0571	20		34-21-21	ALL
ST..	1A	W0111	0696	22		27-81-11	ALL
DC..	1A	W0111	0699	22		27-81-11	ALL
DC..	1A	W0111	0701	22		27-81-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01103		**BACC50AN20 (continued)**				**E001-01/ /**	**ALL**
DC..	1A	W0111	0704	22		27-81-11	ALL
DC..	1A	W0111	0717	22		34-61-12	ALL
DC..	1A	W0111	0719	22		34-61-12	ALL
DC..	1A	W0111	0927	24		22-11-75	ALL
GD01104		**S280W555-401**				**E001-01/ /**	**ALL**
DC..	1A	W0111	0068	22		34-45-11	ALL
ST..	1A	W0111	0069	22		34-45-11	ALL
DC..	1A	W0111	0125	22		22-11-75	ALL
DC..	1A	W0111	0219	22		34-21-16	ALL
DC..	1A	W0111	0229	22		34-45-11	ALL
DC..	1A	W0111	0230	22		34-45-11	ALL
DC..	1A	W0111	0454	22		22-13-11	ALL
DC..	1A	W0111	0790	24		22-11-75	ALL
GD01105		**BACC50AN20**				**E001-01/ /**	**ALL**
AC..	1A	W0111	0024	20		22-11-11	ALL
DC..	1A	W0111	0070	22		22-11-14	ALL
DC..	1A	W0111	0081	22		22-11-75	ALL
DC..	1A	W0111	0217	22		27-81-41	ALL
AC..	1A	W0111	0233	22		34-49-11	ALL
DC..	1A	W0111	0234	22		34-49-11	ALL
DC..	1A	W0111	0838	22		27-81-41	ALL
DC..	1A	W0111	0839	22		27-81-41	ALL
DC..	1A	W0111	0948	22		22-11-75	ALL
DC..	1A	W0111	0949	22		22-11-75	ALL
GD01106		**S280W555-401**				**E001-01/ /**	**ALL**
ST..	1A	W0111	0025	20		22-11-11	ALL
DC..	1A	W0111	0062	22		22-11-14	ALL
DC..	1A	W0111	0249	22		22-18-11	ALL
AC..	1A	W0111	0272	22		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01106		**S280W555-401 (continued)**				**E001-01/ /**	**ALL**
AC..	1A	W0111	0274	22		22-11-11	ALL
AC..	1A	W0111	0276	22		22-11-11	ALL
AC..	1A	W0111	0278	22		22-11-11	ALL
AC..	1A	W0111	0399	20		34-21-21	ALL
AC..	1A	W0111	0727	22		22-18-11	ALL
AC..	1A	W0111	0728	22		22-18-11	ALL
DC..	1A	W0111	0777	22		22-31-51	ALL
DC..	1A	W0111	0796	20		21-31-23	ALL
ST..	1A	W0111	0797	20		21-31-23	ALL
DC..	1A	W0111	0798	22		21-31-23	ALL
DC..	1A	W0111	0799	22		21-31-23	ALL
DC..	1A	W0111	0811	22		21-31-23	ALL
GD01111		**DC-**				**313/161/L028**	**ALL**
DC..	E	W2247	0013	20		34-53-31	ALL
DC..	E	W2247	0028	20		34-53-31	ALL
GD01114		**BACC50AN20**				**J011-0A/ /**	**ALL**
DC..	1A	W0096	0077	22		21-27-51	ALL
DC..	1A	W0096	0088	22		21-27-51	ALL
GD01148		**DC-**				**655/165/R040**	**ALL**
DC..	GW	W6202	1029	20		27-83-21	ALL
DC..	GW	W6202	1029Z			27-83-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01201		**S280W555-402**				**E001-02/ /**	**ALL**
ST..	1A	W0121	0036	20		34-31-11	ALL
GD01202		**S280W555-402**				**E001-02/ /**	**ALL**
AC..	1A	W0121	0035	20		34-31-11	ALL
DC..	1A	W0121	0090	22		34-31-11	ALL
DC..	1A	W0121	0091	22		34-31-11	ALL
DC..	1A	W0121	0092	22		34-31-11	ALL
AC..	1A	W0121	0127	20		34-41-11	ALL
DC..	1A	W0121	0128	20		34-41-11	ALL
GD01203		**S280W555-402**				**E001-02/ /**	**ALL**
AC..	1A	W0121	0004	20		34-53-11	ALL
ST..	1A	W0121	0006	20		34-53-11	ALL
DC..	1A	W0121	0008	20		34-53-11	ALL
ST..	1A	W0121	0009	20		34-53-11	ALL
ST..	1A	W0121	0010	20		34-53-11	ALL
ST..	1A	W0121	0018	22		34-55-11	ALL
ST..	1A	W0121	0025	20		34-53-11	ALL
DC..	1A	W0121	0028	22		34-55-11	ALL
ST..	1A	W0121	0029	22		34-55-11	ALL
DC..	%A	W0121	0050	22		34-53-11	ALL
GD01204		**S280W555-402**				**E001-02/ /**	**ALL**
AC..	1A	W0121	0019	22		34-55-11	ALL
GD01207		**BACC50AN20**				**E003-03/ /**	**ALL**
GD01210		**DC-**				**197/170/0**	**ALL**
DC..	E	W5160	0106	18		52-71-12	ALL
DC..	E	W5160	0622	20		32-31-12	ALL
GD01220		**DC-**				**394/186/R047**	**ALL**
DC..	P	W0422	0134	08		24-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01222		**BACC50AN20**				**775/199/R064**	**ALL**
GD01230		**BACC50AN16**				**520/170/L053**	**ALL**
DC..	1	W5162	0001	18		78-32-51	ALL
DC..	1	W5170	0508	20		73-21-12	ALL
DC..	1	W5170	0511	20		78-35-11	ALL
DC..	1	W5172	0009	18		78-32-51	ALL
GD01232		**BACC50AN16**				**500I+14/175/R053**	**ALL**
DC..	1	W6162	0002	18		78-32-61	ALL
DC..	1	W6168	0031	20		30-21-32	ALL
DC..	1	W6168	0032	20		30-21-32	ALL
DC..	1	W6168	0033	20		30-21-32	ALL
DC..	1	W6168	0034	20		30-21-32	ALL
DC..	1	W6168	6002	20		76-21-21	ALL
DC..	1	W6170	0508	20		73-21-12	ALL
DC..	1	W6172	0009	18		78-32-61	ALL
GD01234		**BACC50AN16**				**500I+14/176/L053**	**ALL**
DC..	1	W5166	0001	20		30-11-11	ALL
DC..	1	W5168	0031	20		30-21-31	ALL
DC..	1	W5168	0032	20		30-21-31	ALL
DC..	1	W5168	0033	20		30-21-31	ALL
DC..	1	W5168	0034	20		30-21-31	ALL
DC..	1	W5566	0005	20		30-11-11	ALL
DC..	1	W5566	0006	20		30-11-11	ALL
DC..	1	W5566	0007	20		30-11-11	ALL
GD01240		**BACC50AN16**				**AB1088/232/L018**	**ALL**
DC..	1	W4724	0515	20		49-52-31	ALL
DC..	1	W4724	0517	20		49-52-31	ALL
DC..	1	W4724	0549	20		49-62-12	ALL
DC..	1	W4724	0560	20		49-94-21	ALL
DC..	1	W4724	0563	20		49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01240		**BACC50AN16 (continued)**				**AB1088/232/L018**	**ALL**
DC..	1	W4724	0575	22		49-62-12	ALL
ST..	1	W4724	0587	22		49-62-12	ALL
DC..	1	W4724	0589	20		49-94-21	ALL
ST..	1	W4724	0590	22		49-94-21	ALL
ST..	1	W4724	1010	18		33-44-12	ALL
ST..	1	W4724	1010Z			33-44-12	ALL
GD01252		**DC-**				**394/184/R047**	**ALL**
DC..	P	W0422	0125	08		24-32-11	ALL
GD01254		**AC-**				**E002-02/ /**	**ALL**
GD01256		**DC-**				**393/194/L019**	**ALL**
DC..	P	W0212	0051	08		24-32-11	ALL
GD01258		**ST-**				**/ /**	**ALL**
GD01290		**AC**				**253/236/L049**	**ALL**
AC..	E	W2102	5526	20		30-41-11	ALL
GD01296		**AC**				**252/236/R049**	**ALL**
AC..	E	W2204	5538	20		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01301		**BACC50AN16**				**E001-03/ /**	**ALL**
DC..	1	W0131	0016	18		23-31-01	ALL
DC..	1	W0131	0033	16		23-12-11	ALL
GD01302		**S280W555-401**				**E001-03/ /**	**ALL**
DC..	1A	W0131	0034	22		23-12-11	ALL
DC..	1A	W0131	0039	22		23-12-11	ALL
DC..	1A	W0131	0435	22		23-12-11	ALL
GD01303		**S280W555-401**				**E001-03/ /**	**ALL**
DC..	1A	W0131	0107	22		32-41-11	ALL
ST..	1A	W0131	0108	22		32-41-11	ALL
GD01304		**S280W555-401**				**E001-03/ /**	**ALL**
DC..	1A	W0131	0001	22		32-42-11	ALL
DC..	1A	W0131	0002	22		32-42-11	ALL
ST..	1A	W0131	0003	22		32-41-11	ALL
DC..	1A	W0131	0106	22		32-41-11	ALL
ST..	1A	W0131	0396	22		32-49-11	ALL
DC..	1A	W0131	0402	22		32-46-11	ALL
ST..	1A	W0131	0403	22		32-46-11	ALL
GD01322		**DC-**				**335/159/L029**	**ALL**
DC..	E	W5156	0002	18		52-71-12	ALL
GD01352		**AC-**				**250/228/R049**	**ALL**
AC..	E	W2108	1003	20		30-41-11	ALL
AC..	E	W2108	1003Z			30-41-11	ALL
ST..	E	W2108	YAAC			30-41-11	ALL
AC..	E	W2204	5503	18		33-14-12	ALL
GD01354		**AC-**				**251/228/L049**	**ALL**
AC..	E	W2102	5517	18		33-14-12	ALL
AC..	E	W2208	1003	20		30-41-12	ALL
AC..	E	W2208	1003Z			30-41-12	ALL
ST..	E	W2208	YAAC			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01356		**BACC50AN20**				**500I+8/176/R053**	**ALL**
DC..	1A	W6166	0001	20		30-11-11	ALL
DC..	1A	W6586	0005	20		30-11-11	ALL
DC..	1A	W6586	0006	20		30-11-11	ALL
DC..	1A	W6586	0007	20		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01401		**S280W555-402**				**E001-04/ /**	**ALL**
AC..	1A	W0141	0006	22		22-11-11	ALL
DC..	1A	W0141	0048	22		22-11-14	ALL
DC..	1A	W0141	0049	22		22-11-14	ALL
DC..	1A	W0141	0056	20		22-11-11	ALL
DC..	1A	W0141	0057	20		22-11-11	ALL
DC..	1A	W0141	0058	20		22-11-11	ALL
ST..	1A	W0141	0059	20		22-11-11	ALL
DC..	1A	W0141	0086	22		22-11-75	ALL
DC..	1A	W0141	0087	22		22-11-75	ALL
AC..	1A	W0141	0122	22		22-18-11	ALL
AC..	1A	W0141	0123	22		22-18-11	ALL
DC..	1A	W0141	0146	22		22-11-75	ALL
DC..	1A	W0141	0239	22		22-11-75	ALL
DC..	1A	W0141	0240	22		22-11-75	ALL
GD01402		**S280W555-402**				**E001-04/ /**	**ALL**
AC..	1A	W0141	0133	22		22-11-11	ALL
AC..	1A	W0141	0135	22		22-11-11	ALL
AC..	1A	W0141	0137	22		22-11-11	ALL
AC..	1A	W0141	0139	22		22-11-11	ALL
GD01403		**S280W555-402**				**E001-04/ /**	**ALL**
AC..	1A	W0141	0703	20		34-31-21	ALL
ST..	1A	W0141	0704	20		34-31-21	ALL
DC..	1A	W0141	0731	22		34-31-21	ALL
DC..	1A	W0141	0732	22		34-31-21	ALL
DC..	1A	W0141	0733	22		34-31-21	ALL
GD01404		**S280W555-402**				**E001-04/ /**	**ALL**
ST..	1A	W0141	0416R	20		26-12-11	ALL
DC..	1A	W0141	0417R	20		26-12-11	ALL
AC..	1A	W0141	0418R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01404		**S280W555-402 (continued)**				**E001-04/ /**	**ALL**
AC..	1A	W0141	0419R	20		26-12-11	ALL
DC..	1A	W0141	0450R	20		26-12-11	ALL
DC..	1A	W0141	0452R	20		26-12-11	ALL
GD01444		**AC-**				**226/232/L040**	**ALL**
AC..	E	W2102	5534	20		33-14-11	ALL
GD01450		**ST-**				**E002-01/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01501		**BACC50AN16**				**E001-05/ /**	**ALL**
DC..	1	W0151	0035	16		23-12-21	ALL
GD01502		**S280W555-402**				**E001-05/ /**	**ALL**
ST..	1A	W0151	0018	22		34-55-21	ALL
AC..	1A	W0151	0019	22		34-55-21	ALL
DC..	1A	W0151	0028	22		34-55-21	ALL
ST..	1A	W0151	0029	22		34-55-21	ALL
GD01503		**S280W555-402**				**E001-05/ /**	**ALL**
AC..	1A	W0151	0004	20		34-53-21	ALL
ST..	1A	W0151	0006	20		34-53-21	ALL
DC..	1A	W0151	0008	20		34-53-21	ALL
ST..	1A	W0151	0009	20		34-53-21	ALL
ST..	1A	W0151	0010	20		34-53-21	ALL
DC..	1A	W0151	0036	22		23-12-21	ALL
DC..	1A	W0151	0037	22		23-12-21	ALL
DC..	%A	W0151	0048	22		34-53-21	ALL
DC..	1A	W0151	0072	22		23-12-21	ALL
GD01505		**ST-**				**679/201/L040**	**ALL**
ST..	E	W5375	YAAA			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01637		**DC-**				**266/42/254**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD01753		**DC-**				**196/171/R012**	**ALL**
DC..	E	W5156	5510	20		21-27-21	ALL
GD01788		**AC-**				**1033/298/L011**	**ALL**
AC..	N	W6134	5502	20		30-31-11	ALL
GD01790		**AC-**				**1031/298/L011**	**ALL**
AC..	N	W6134	5505	20		30-31-12	ALL
GD01792		**ST-**				**69 FIN/ /**	**ALL**
ST..	E	W7102	2001Z			30-31-11	ALL
GD01794		**ST-**				**69 FIN/ /**	**ALL**
ST..	E	W7102	2002Z			30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01830		**ST-**				**/ /**	**ALL**
GD01832		**DC-**				**/ /**	**ALL**
GD01835		**ST-**				**237/202/L006**	**ALL**
ST..	E	W5353	0001	22		22-31-31	ALL
ST..	E	W5353	0004	22		22-31-31	ALL
GD01836		**ST-**				**237/201/L006**	**ALL**
ST..	E	W5353	0002	22		22-31-31	ALL
GD01837		**ST-**				**237/201/R006**	**ALL**
ST..	E	W5397	0002	22		22-31-41	ALL
GD01838		**ST-**				**237/202/R006**	**ALL**
ST..	E	W5397	0001	22		22-31-41	ALL
ST..	E	W5397	0004	22		22-31-41	ALL
GD01840		**AC-**				**/ /**	**ALL**
GD01846		**ST-**				**OFSS 388/ /**	**ALL**
ST..	GW	W1664	2001ZO			28-41-11	ALL
GD01850		**DC-**				**P018-00/ /**	**ALL**
DC..	E	W0018	0894	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD01904		**DC-**				*** */*/***	**ALL**
GD01906		**BACC50AN20**				**/ /**	**ALL**
GD01910		**BACC50AN20**				**/ /**	**ALL**
GD01914		**ST**				**285/189/L017**	**ALL**
ST..	E	W6110	5513	20		21-42-11	ALL
GD01916		**BACC50AN20**				**/ /**	**ALL**
GD01946		**AC-**				**/ /**	**ALL**
GD01948		**AC-**				**673/199/L057**	**ALL**
AC..	E	W7026	0515	20		33-32-11	ALL
AC..	E	W7230	A-Y			32-64-11	ALL
GD01950		**AC-**				**701/201/R062**	**ALL**
AC..	E	W7026	0516	20		33-32-11	ALL
AC..	E	W8228	A-Y			32-64-11	ALL
GD01952		**AC-**				**/ /**	**ALL**
GD01962		**AC-**				**665/196/L059**	**ALL**
AC..	E	W7230	0521	18		32-64-11	ALL
AC..	E	W7230	0533	18		32-31-11	ALL
GD01964		**ST-**				**664/166/L055**	**ALL**
ST..	E	W7230	0503	18		29-32-11	ALL
GD01966		**ST-**				**678/200/R036**	**ALL**
ST..	E	W8224	0510	20		29-31-11	ALL
GD01968		**ST-**				**716/197/L007**	**ALL**
ST..	E	W8230	0501	18		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD0201A		**BACC50AN16**				**P002-00/ /**	**ALL**
GD0201B		**BACC50AN20**				**P002-00/ /**	**ALL**
DC..	1A	W0001	0137	22		32-42-11	ALL
DC..	1A	W0001	0145	22		32-42-11	ALL
DC..	1A	W0001	0146	22		32-42-11	ALL
DC..	1A	W0001	0255	22		29-23-11	ALL
DC..	1A	W0001	1311	22		32-41-11	ALL
ST..	1A	W0001	1311Z			32-41-11	ALL
DC..	1A	W0001	1314	22		32-41-11	ALL
DC..	1A	W0001	1314Z			32-41-11	ALL
DC..	1A	W0001	1759	22		32-31-15	ALL
DC..	1A	W0001	1759Z			32-31-15	ALL
DC..	1A	W0001	1771	22		32-31-15	ALL
DC..	1A	W0001	1771Z			32-31-15	ALL
GD0201C		**BACC50AN20**				**P002-00/ /**	**ALL**
GD0201D		**BACC50AN20**				**P002-00/ /**	**ALL**
DC..	1A	W0003	1763	22		32-31-15	ALL
DC..	1A	W0003	1763Z			32-31-15	ALL
DC..	1A	W0003	1779	22		32-31-15	ALL
DC..	1A	W0003	1779Z			32-31-15	ALL
GD02040		**ST-**				**ORSS 295/ /**	**ALL**
ST..	E	W1040	1001	20		27-61-48	ALL
ST..	E	W1040	1001Z			27-61-48	ALL
GD02042		**ST-**				**ORSS 315/ /**	**ALL**
ST..	E	W1040	1002	20		27-61-48	ALL
ST..	E	W1040	1002Z			27-61-48	ALL
GD02044		**ST-**				**311.7/ /**	**ALL**
ST..	E	W1042	1001	20		27-61-48	ALL
ST..	E	W1042	1001Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02046		**ST-**				**395.2/ /**	**ALL**
ST..	E	W1042	1002	20		27-61-48	ALL
ST..	E	W1042	1002Z			27-61-48	ALL
GD02048		**ST-**				**ORSS 410/ /**	**ALL**
ST..	E	W1026	1001	20		27-61-48	ALL
ST..	E	W1026	1001Z			27-61-48	ALL
GD02050		**ST-**				**ORSS 345/ /**	**ALL**
ST..	N	W1024	1003	18		27-53-21	ALL
ST..	N	W1024	1003Z			27-53-21	ALL
ST..	E	W1026	1002	20		27-61-48	ALL
ST..	E	W1026	1002Z			27-61-48	ALL
GD02054		**AC-**				**ORSS 166/ /**	**ALL**
GD02058		**AC-**				**/ /**	**ALL**
GD02064		**AC-**				**IRSS 156/ /**	**ALL**
GD02068		**AC-**				**/ /**	**ALL**
GD02070		**AC-**				**726/196/L034**	**ALL**
AC..	E	W7126	0521	18		32-64-12	ALL
AC..	E	W7126	0533	18		32-31-12	ALL
GD02074		**AC-**				**726/197/L047**	**ALL**
AC..	E	W7126	A-Y			32-64-12	ALL
GD02076		**AC-**				**726/200/R035**	**ALL**
AC..	E	W8224	0523	18		32-64-12	ALL
AC..	E	W8224	0541	18		32-31-12	ALL
GD02080		**AC-**				**726/196/R036**	**ALL**
AC..	E	W8228	0513	18		32-64-11	ALL
AC..	E	W8228	0540	20		32-31-11	ALL
GD02090		**ST-**				**424.9/ /**	**ALL**
ST..	E	W1028	1001	20		27-61-48	ALL
ST..	E	W1028	1001Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02092		**ST-**				**353.4/ /**	**ALL**
ST..	E	W1028	1002	20		27-61-48	ALL
ST..	E	W1028	1002Z			27-61-48	ALL
ST..	N	W1034	1003	18		27-53-21	ALL
ST..	N	W1034	1003Z			27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02102		**BACC50AN20**				**E002-01/ /**	**ALL**
GD02103		**BACC50AN20**				**E002-01/ /**	**ALL**
DC..	1A	W0212	0012	20		24-11-11	ALL
ST..	1A	W0212	0013	20		24-11-11	ALL
AC..	1A	W0212	0085	20		34-33-11	ALL
ST..	1A	W0212	0086	20		34-33-11	ALL
DC..	1A	W0212	0101	22		34-33-11	ALL
DC..	1A	W0212	0102	22		34-33-11	ALL
GD02104		**BACC50AN20**				**E002-01/ /**	**ALL**
AC..	1A	W0210	5504	20		30-41-11	ALL
DC..	1A	W0210	5506	20		30-41-11	ALL
DC..	1A	W0210	5515	20		30-41-11	ALL
DC..	1A	W0212	0026	22		24-22-31	ALL
ST..	1A	W0212	0027	22		24-22-31	ALL
DC..	1A	W0212	0028	22		24-22-31	ALL
DC..	1A	W0212	0068	22		24-23-11	ALL
GD02105		**BACC50AN16**				**E002-01/ /**	**ALL**
AC..	1	W0212	0055	18		24-32-11	ALL
GD02106		**CGH20-22-1**				**E002-01/ /**	**ALL**
ST..	1F	W0210	2004Z			30-41-11	ALL
ST..	1F	W0210	FRAB			30-41-11	ALL
ST..	1F	W0210	FRAC			30-41-11	ALL
ST..	1F	W0210	FRAD			30-41-11	ALL
ST..	1F	W0210	FRAE			30-41-11	ALL
GD02107		**ST-**				**E002-01/ /**	**ALL**
ST..	E	W0210	5511	12		30-41-11	ALL
GD02108		**AC-**				**E002-01/ /**	**ALL**
AC..	E	W0210	5512	12		30-41-11	ALL
AC..	E	W0210	5531	14		30-41-11	ALL
AC..	E	W0210	5536	18		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02109		**S280W555-401**				**E002-01/ /**	**ALL**
ST..	1A	W0212	1001Z			24-11-11	ALL
ST..	1A	W0212	1003Z			24-28-41	ALL
ST..	1A	W0212	2001Z			24-11-11	ALL
ST..	1A	W0212	2002Z			24-21-11	ALL
ST..	1A	W0212	2004Z			24-22-11	ALL
ST..	1A	W0212	2010Z			24-23-11	ALL
ST..	1A	W0212	2020Z			24-22-11	ALL
ST..	1A	W0212	2039Z			24-23-11	ALL
ST..	1A	W0212	3001Z			24-21-11	ALL
ST..	1A	W0212	4001Z			24-21-11	ALL
ST..	1A	W0212	4003Z			24-24-11	ALL
ST..	1A	W0212	4004Z			24-24-11	ALL
GD02110		**S280W555-401**				**E002-01/ /**	**ALL**
ST..	1A	W0212	4006Z			24-24-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02201		**BACC50AN20**				**E002-02/ /**	**ALL**
GD02203		**BACC50AN20**				**E002-02/ /**	**ALL**
ST..	1A	W0220	0052	20		21-31-22	ALL
DC..	1A	W0220	0112	20		49-41-11	ALL
AC..	1A	W0220	0126	22		49-41-11	ALL
DC..	1A	W0220	0127	20		49-41-11	ALL
GD02204		**BACC50AN20**				**E002-02/ /**	**ALL**
DC..	1A	W0220	0051	20		21-31-22	ALL
DC..	1A	W0220	0059	22		21-31-22	ALL
DC..	1A	W0220	0061	22		21-31-22	ALL
DC..	1A	W0220	0238	22		21-31-22	ALL
ST..	1A	W0220	0332R	22		26-11-11	ALL
DC..	1A	W0220	0333R	20		26-11-11	ALL
DC..	1A	W0220	0344R	20		26-11-11	ALL
ST..	1A	W0220	0352R	20		26-11-21	ALL
DC..	1A	W0220	0354R	20		26-11-21	ALL
DC..	1A	W0220	0379R	20		26-11-31	ALL
DC..	1A	W0220	0382R	20		26-11-31	ALL
DC..	1A	W0220	0383R	20		26-11-31	ALL
DC..	1A	W0220	0384R	20		26-11-31	ALL
DC..	1A	W0220	0385R	20		26-11-31	ALL
DC..	1A	W0220	0401R	20		26-11-21	ALL
GD02205		**BACC50AN16**				**E002-02/ /**	**ALL**
ST..	1	W0220	0124	16		49-41-11	ALL
ST..	1	W0220	0125	16		49-41-11	ALL
ST..	1	W0220	0415	20		31-31-13	ALL
GD02207		**BACC50AN20**				**E002-02/ /**	**ALL**
ST..	1A	W0220	2002Z			24-21-31	ALL
ST..	1A	W0220	3001Z			24-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02300		**ST-**				**653/150/L008**	**ALL**
GD02301		**DC-**				**213/208/R036**	**ALL**
DC..	E	W3319	0016	20		23-51-21	ALL
GD02302		**ST-**				**661/156/L016**	**ALL**
ST..	GW	W5102	1013Z			26-12-11	ALL
ST..	GW	W5102	1025Z			26-12-11	ALL
GD02303		**DC-**				**214/208/L038**	**ALL**
DC..	E	W3323	0016	20		23-51-11	ALL
GD02304		**ST-**				**661/164/L026**	**ALL**
ST..	GW	W5230	YAAF			29-11-12	ALL
GD02306		**AC**				**536/158/R027**	**ALL**
AC..	GW	W6202	0010	20		33-33-11	ALL
AC..	GW	W6202	5556	20		30-71-11	ALL
AC..	GW	W6202	5557	20		30-71-11	ALL
GD02308		**ST-**				**579/161/L039**	**ALL**
GD02312		**ST-**				**578.5/153/L039**	**ALL**
GD02314		**ST-**				**570/153/L039**	**ALL**
GD02316		**DC-**				**570/155/L039**	**ALL**
DC..	GW	W5102	1005	20		21-51-15	ALL
DC..	GW	W5102	1034	20		21-51-15	ALL
DC..	GW	W5102	1050	20		21-61-51	ALL
DC..	GW	W5102	1050Z			21-61-51	ALL
GD02318		**ST-**				**543/155/L040**	**ALL**
ST..	GW	W5102	1004Z			33-33-11	ALL
ST..	GW	W5102	1016Z			33-33-11	ALL
ST..	GW	W5102	1017Z			33-33-11	ALL
ST..	GW	W5102	1018Z			33-33-11	ALL
ST..	GW	W5102	1019Z			33-33-11	ALL
ST..	N	W7202	0021	16		47-30-11	ALL
ST..	N	W7202	0025	16		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02320		**ST-**				**537/161/L032**	**ALL**
ST..	GW	W5102	2007Z			36-21-11	ALL
ST..	GW	W5102	5515	22		36-21-11	ALL
GD02322		**AC-**				**537/157/L027**	**ALL**
AC..	GW	W5102	0012	20		33-33-11	ALL
GD02324		**ST-**				**544/154/L008**	**ALL**
ST..	GW	W5502	0006	20		21-61-11	ALL
ST..	GW	W5502	1035Z			21-61-11	ALL
ST..	GW	W5502	1037Z			21-61-11	ALL
ST..	GW	W5502	1038Z			21-61-11	ALL
ST..	GW	W5502	1039Z			21-61-11	ALL
ST..	GW	W5502	2083Z			21-61-11	ALL
ST..	GW	W5502	2084Z			21-61-11	ALL
GD02326		**ST**				**571/163/L007**	**ALL**
GD02328		**ST-**				**577/157/L007**	**ALL**
GD02330		**ST-**				**603/152/L007**	**ALL**
ST..	GW	W5502	0016	20		21-51-12	ALL
ST..	GW	W5502	1010Z			26-12-11	ALL
ST..	GW	W5502	1011Z			26-12-11	ALL
GD02332		**ST-**				**653/151/R008**	**ALL**
GD02334		**ST-**				**661/156/R016**	**ALL**
ST..	GW	W6202	1008Z			26-12-11	ALL
ST..	GW	W6202	1009Z			26-12-11	ALL
GD02336		**ST-**				**661/162/R030**	**ALL**
ST..	GW	W6128	YAAF			29-11-12	ALL
ST..	E	W8122	YAAF			27-81-51	ALL
GD02338		**ST-**				**655/165/R041**	**ALL**
ST..	GW	W6202	1013Z			27-83-21	ALL
ST..	GW	W6202	1029Z			27-83-21	ALL
ST..	GW	W8122	1011Z			27-83-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD02338		**ST- (continued)**				**655/165/R041**	**ALL**
ST..	GW	W8122	1012Z			27-83-11	ALL
GD02340		**ST-**				**580/162/R040**	**ALL**
GD02342		**ST-**				**571/166/R030**	**ALL**
GD02344		**DC-**				**570/156/R040**	**ALL**
DC..	GW	W6202	0014	20		21-51-25	ALL
DC..	GW	W6202	0015	20		21-51-25	ALL
DC..	GW	W6202	0016	20		21-61-51	ALL
DC..	GW	W6202	1027Z			21-51-25	ALL
DC..	GW	W6202	1034Z			21-51-25	ALL
DC..	GW	W6202	1049Z			21-61-51	ALL
DC..	GW	W6202	2079Z			21-51-22	ALL
DC..	GW	W6202	2080Z			21-51-23	ALL
GD02346		**ST-**				**570/156/R039**	**ALL**
GD02348		**ST-**				**551/155/R033**	**ALL**
GD02350		**ST-**				**544/155/R035**	**ALL**
ST..	GW	W6202	1003Z			33-33-11	ALL
ST..	GW	W6202	1014Z			33-33-11	ALL
ST..	GW	W6202	1015Z			33-33-11	ALL
ST..	GW	W6202	1016Z			33-33-11	ALL
ST..	GW	W6202	1017Z			33-33-11	ALL
GD02352		**ST-**				**537/161/R032**	**ALL**
ST..	GW	W6202	2007Z			36-21-11	ALL
ST..	GW	W6202	5515	22		36-21-11	ALL
GD02354		**ST-**				**537/155/R027**	**ALL**
ST..	GW	W6202	1018Z			30-71-11	ALL
ST..	GW	W6202	1038Z			21-61-13	ALL
ST..	GW	W6202	1039Z			21-61-13	ALL
ST..	GW	W6202	1040Z			21-61-13	ALL
ST..	GW	W6202	1041Z			21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02354		**ST- (continued)**				**537/155/R027**	**ALL**
ST..	GW	W6202	2083Z			21-61-13	ALL
ST..	GW	W6202	2084Z			21-61-13	ALL
ST..	GW	W6202	5564	20		21-61-13	ALL
ST..	GW	W6202	5567	20		21-61-14	ALL
GD02358		**ST-**				**578/155/R007**	**ALL**
ST..	GW	W6502	2001Z			21-51-21	ALL
ST..	GW	W6502	2002Z			21-51-21	ALL
ST..	GW	W6502	5501	20		21-61-15	ALL
GD02360		**ST-**				**578/161/R007**	**ALL**
ST..	GW	W6504	1001Z			21-51-21	ALL
ST..	GW	W6504	1002Z			21-42-11	ALL
ST..	GW	W6504	1003Z			21-51-21	ALL
GD02362		**ST-**				**570/153/R040**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02552		**BACC50AN16**				**727+3/155/L011**	**ALL**
DC..	1	W3154	0027	20		25-51-21	ALL
AC..	1	W3154	0028	16		25-51-21	ALL
AC..	1	W3154	0029	16		25-51-21	ALL
ST..	1	W3154	0030	16		25-51-21	ALL
GD02564		**AC-**				**1087/244/L003**	**ALL**
AC..	R	W4722	0004	04		24-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02604		**ST-**				**/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD02994		**ST-**				**RUD56.4/ /**	**ALL**
ST..	E	W6136	0508	20		27-25-11	ALL
ST..	E	W6136	0512	20		27-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03002		**BACC50AN16**				**579/251/L 66**	**ALL**
GD03004		**BACC50AN16**				**560/229/L 69**	**ALL**
GD03014		**BACC50AN16**				**601/259/L 67**	**ALL**
GD03016		**BACC50AN16**				**560/229/R 69**	**ALL**
GD03018		**BACC50AN16**				**578/259/R 67**	**ALL**
GD0301A		**BACC50AN16**				**P003-00/ /**	**ALL**
ST..	1	W0003	0502	16		31-65-21	ALL
ST..	1	W0003	0503	16		31-65-21	ALL
ST..	1	W0003	0504	16		31-65-21	ALL
ST..	1	W0003	0506	16		31-65-21	ALL
ST..	1	W0003	0507	16		31-65-21	ALL
ST..	1	W0003	0508	16		31-65-21	ALL
ST..	1	W0003	0509	20		31-65-21	ALL
ST..	1	W0003	0510	20		31-65-21	ALL
ST..	1	W0003	0511	20		31-65-21	ALL
ST..	1	W0003	0512	20		31-65-21	ALL
GD0301B		**BACC50AN20**				**P003-00/ /**	**ALL**
DC..	1A	W0003	0631	22		34-49-11	ALL
DC..	1A	W0003	0634	22		34-49-11	ALL
DC..	1A	W0003	1003	22		34-61-16	ALL
DC..	1A	W0003	1003Z			34-61-16	ALL
DC..	1A	W0003	1578	20		22-14-11	ALL
DC..	1A	W0003	1578Z			22-14-11	ALL
DC..	1A	W0003	1628	22		34-49-11	ALL
DC..	1A	W0003	1628Z			34-49-11	ALL
GD0301C		**BACC50AN20**				**P003-00/ /**	**ALL**
DC..	1A	W0003	1546	22		31-65-23	ALL
DC..	1A	W0003	1546Z			31-65-23	ALL
GD0301D		**BACC50AN20**				**P003-00/ /**	**ALL**
DC..	1A	W0001	1546	22		31-65-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD0301D		**BACC50AN20 (continued)**				**P003-00/ /**	**ALL**
DC..	1A	W0001	1546Z			31-65-13	ALL
GD03050		**BACC50AN20**				**420/205/R57**	**ALL**
ST..	1A	W5586	6006	20		28-41-11	ALL
ST..	1A	W6572	6001	20		28-41-11	ALL
DC..	1A	W6572	6003	20		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03101		**BACC50AN20**				**E003-01/ /**	**ALL**
GD03102		**BACC50AN20**				**E003-01/ /**	**ALL**
AC..	1A	W0311	0143	20		34-57-11	ALL
ST..	1A	W0311	0144	20		34-57-11	ALL
DC..	1A	W0311	0145	22		34-57-11	ALL
AC..	1A	W0313	1703	20		34-33-21	ALL
ST..	1A	W0313	1704	20		34-33-21	ALL
DC..	1A	W0313	1708	22		34-33-21	ALL
DC..	1A	W0313	1709	22		34-33-21	ALL
GD03103		**BACC50AN16**				**E003-01/ /**	**ALL**
ST..	1	W0311	0010	16		31-65-11	ALL
ST..	1	W0311	0011	16		31-65-11	ALL
DC..	1	W0311	0150	24		31-65-41	ALL
DC..	1	W0311	0171	22		31-65-41	ALL
GD03104		**BACC50AN16**				**E003-01/ /**	**ALL**
DC..	1	W0313	0508	24		31-65-41	ALL
ST..	1	W0313	0510	16		31-65-21	ALL
ST..	1	W0313	0511	16		31-65-21	ALL
DC..	1	W0313	0672	22		31-65-41	ALL
GD03105		**BACC50AN20**				**E003-01/ /**	**ALL**
AC..	1A	W0313	0643	20		34-57-21	ALL
ST..	1A	W0313	0644	20		34-57-21	ALL
DC..	1A	W0313	0645	22		34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03200		**BACC50AN20**				**378/157/L029**	**ALL**
ST..	1A	W5110	0531	20		24-31-12	ALL
ST..	1A	W5110	0539	20		24-31-12	ALL
AC..	1A	W5112	1106	20		24-21-11	ALL
ST..	1A	W5112	1106Z			24-21-11	ALL
AC..	1A	W6110	0050	20		33-34-11	ALL
AC..	1A	W6110	0060	20		33-34-11	ALL
DC..	1A	W6110	0516	20		24-51-11	ALL
ST..	1A	W6210	0521	20		24-31-11	ALL
DC..	1A	W6214	5552	20		21-61-11	ALL
DC..	1A	W6214	5554	20		21-61-51	ALL
GD03201		**BACC50AN20**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0036	22		31-31-14	ALL
AC..	1A	W0321	0043	22		31-31-14	ALL
AC..	1A	W0321	0128	22		27-32-11	ALL
DC..	1A	W0321	0130	22		27-32-11	ALL
DC..	1A	W0321	0148	22		27-32-11	ALL
DC..	1A	W0321	0169	22		22-23-11	ALL
DC..	1A	W0321	0286	22		27-32-21	ALL
DC..	1A	W0321	0377	22		27-32-11	ALL
AC..	1A	W0321	0476	22		31-31-14	ALL
DC..	1A	W0321	0571	22		27-32-11	ALL
DC..	1A	W0321	0593	22		27-32-21	ALL
AC..	1A	W0321	0603	20		22-23-12	ALL
GD03202		**BACC50AN20**				**E003-02/ /**	**ALL**
DC..	1A	W0321	0246	22		22-23-11	ALL
AC..	1A	W0321	0252	22		27-32-21	ALL
AC..	1A	W0321	0255	22		27-32-21	ALL
DC..	1A	W0321	0257	22		27-32-21	ALL
AC..	1A	W0321	0366	24		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03202		**BACC50AN20 (continued)**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0367	24		31-31-14	ALL
DC..	1A	W0321	0493	22		27-32-21	ALL
AC..	1A	W0321	0643	22		31-31-14	ALL
AC..	1A	W0321	0645	22		31-31-14	ALL
AC..	1A	W0321	0647	22		31-31-14	ALL
GD03203		**BACC50AN20**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0046	22		31-31-14	ALL
AC..	1A	W0321	0053	22		31-31-14	ALL
AC..	1A	W0321	0375	22		27-24-11	ALL
AC..	1A	W0321	0606	20		27-24-11	ALL
AC..	1A	W0321	0793	20		34-51-11	ALL
ST..	1A	W0321	0794	20		34-51-11	ALL
GD03204		**BACC50AN20**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0002	22		31-31-11	ALL
DC..	1A	W0321	0003	22		31-31-11	ALL
DC..	1A	W0321	0004	22		31-31-11	ALL
DC..	1A	W0321	0005	22		31-31-11	ALL
DC..	1A	W0321	0006	22		31-31-11	ALL
AC..	1A	W0321	0035	22		31-31-14	ALL
AC..	1A	W0321	0042	22		31-31-14	ALL
AC..	1A	W0321	0045	22		31-31-14	ALL
AC..	1A	W0321	0052	22		31-31-14	ALL
AC..	1A	W0321	0091	24		27-18-11	ALL
AC..	1A	W0321	0127	20		27-32-11	ALL
DC..	1A	W0321	0165	22		31-31-11	ALL
AC..	1A	W0321	0254	20		27-32-21	ALL
AC..	1A	W0321	0475	22		31-31-14	ALL
GD03205		**BACC50AN20**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0131	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03205		**BACC50AN20 (continued)**				**E003-02/ /**	**ALL**
AC..	1A	W0321	0261	22		22-23-12	ALL
GD03207		**CGH20-22-1**				**E003-02/ /**	**ALL**
DC..	1F	W0321	0186	22		27-32-11	ALL
DC..	1F	W0321	0187	22		27-32-11	ALL
ST..	1F	W0321	2025Z			27-32-12	ALL
ST..	1F	W0321	2029Z			34-21-14	ALL
ST..	1F	W0321	2047Z			34-21-23	ALL
ST..	1F	W0321	2167Z			34-61-14	ALL
ST..	1F	W0321	2211Z			22-11-51	ALL
ST..	1F	W0321	2221Z			22-23-12	ALL
ST..	1F	W0321	2222Z			22-23-12	ALL
ST..	1F	W0321	2372Z			34-21-13	ALL
ST..	1F	W0321	2716Z			31-65-15	ALL
GD03209		**CGH20-22-1**				**E003-02/ /**	**ALL**
DC..	1F	W0321	0129	22		27-32-11	ALL
DC..	1F	W0321	0188	22		27-32-11	ALL
ST..	1F	W0321	2062Z			22-23-11	ALL
ST..	1F	W0321	2063Z			22-23-11	ALL
ST..	1F	W0321	2223Z			22-23-12	ALL
ST..	1F	W0321	2505Z			27-32-11	ALL
ST..	1F	W0321	3225Z			22-23-12	ALL
GD03211		**CGH20-22-1**				**E003-02/ /**	**ALL**
DC..	1F	W0321	0190	22		27-32-21	ALL
DC..	1F	W0321	0191	22		27-32-21	ALL
ST..	1F	W0321	2027Z			27-32-22	ALL
ST..	1F	W0321	2048Z			34-21-23	ALL
ST..	1F	W0321	2145Z			34-21-24	ALL
ST..	1F	W0321	2165Z			34-21-13	ALL
ST..	1F	W0321	2168Z			34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03211		**CGH20-22-1 (continued)**				**E003-02/ /**	**ALL**
ST..	1F	W0321	2212Z			22-11-51	ALL
ST..	1F	W0321	2507Z			27-32-21	ALL
ST..	1F	W0321	2709Z			22-23-12	ALL
ST..	1F	W0321	2719Z			22-23-12	ALL
ST..	1F	W0321	2750Z			31-65-25	ALL
GD03213		**CGH20-22-1**				**E003-02/ /**	**ALL**
DC..	1F	W0321	0189	22		27-32-21	ALL
DC..	1F	W0321	0256	22		27-32-21	ALL
ST..	1F	W0321	2062Z			22-23-11	ALL
ST..	1F	W0321	2063Z			22-23-11	ALL
ST..	1F	W0321	2720Z			27-24-11	ALL
ST..	1F	W0321	3721Z			27-24-11	ALL
GD03214		**ST**				**500I+19/163/L039**	**ALL**
ST..	E	W5104	1013Z			21-51-14	ALL
ST..	E	W5104	2006Z			21-51-12	ALL
GD03215		**ST**				**500I+12/176/L053**	**ALL**
ST..	E	W5104	FRFA			21-51-14	ALL
GD03220		**BACC50AN16**				**E003-02/ /**	**ALL**
ST..	1	W0321	0583	20		27-61-41	ALL
DC..	1	W0321	0628	22		27-61-45	ALL
DC..	1	W0321	0630	22		27-61-45	ALL
DC..	1	W0321	0733	22		27-61-49	ALL
DC..	1	W0321	0739	22		27-61-49	ALL
DC..	1	W0321	0829	22		27-62-11	ALL
DC..	1	W0321	0832	22		27-62-11	ALL
DC..	1	W0321	0983	22		27-61-42	ALL
DC..	1	W0321	0985	22		27-61-42	ALL
GD03221		**BACC50AN20**				**E003-02/ /**	**ALL**
ST..	1A	W0321	0581	20		27-61-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03221		**BACC50AN20 (continued)**				**E003-02/ /**	**ALL**
DC..	1A	W0321	0621	22		27-61-45	ALL
DC..	1A	W0321	0625	22		27-61-45	ALL
DC..	1A	W0321	0633	22		27-61-45	ALL
DC..	1A	W0321	0635	22		27-61-45	ALL
DC..	1A	W0321	0734	22		27-61-49	ALL
DC..	1A	W0321	0735	22		27-61-49	ALL
DC..	1A	W0321	0738	22		27-61-49	ALL
DC..	1A	W0321	0740	22		27-61-49	ALL
DC..	1A	W0321	0824	22		27-62-11	ALL
DC..	1A	W0321	0828	22		27-62-11	ALL
DC..	1A	W0321	0831	22		27-62-11	ALL
DC..	1A	W0321	0971	22		27-62-11	ALL
DC..	1A	W0321	0973	22		27-62-11	ALL
DC..	1A	W0325	0737	22		27-61-49	ALL
DC..	1A	W0325	0991	22		27-61-49	ALL
GD03222		**BACC50AN20**				**E003-02/ /**	**ALL**
DC..	1A	W0321	0580	20		27-61-41	ALL
DC..	1A	W0321	0582	20		27-61-41	ALL
DC..	1A	W0321	0736	22		27-61-49	ALL
DC..	1A	W0321	0744	22		27-61-49	ALL
DC..	1A	W0321	0749	22		27-61-49	ALL
DC..	1A	W0321	0751	22		27-61-49	ALL
DC..	1A	W0321	0752	22		27-61-49	ALL
DC..	1A	W0321	0826	22		27-62-11	ALL
DC..	1A	W0321	0830	22		27-62-11	ALL
DC..	1A	W0321	0943	22		27-62-11	ALL
DC..	1A	W0321	0970	22		27-62-11	ALL
DC..	1A	W0321	0972	22		27-62-11	ALL
DC..	1A	W0321	0981	22		27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03222		**BACC50AN20 (continued)**				**E003-02/ /**	**ALL**
DC..	1A	W0325	0745	22		27-61-49	ALL
GD03234		**ST-**				**520/154/R018**	**ALL**
ST..	E	W6230	0328	14		21-25-11	ALL
GD03250		**DC-**				**547/158/L007**	**ALL**
DC..	GW	W5502	0001	20		36-11-31	ALL
DC..	GW	W5502	0009	20		36-11-31	ALL
DC..	GW	W5502	1005Z			36-11-31	ALL
DC..	GW	W5502	1007Z			36-11-31	ALL
DC..	GW	W5502	1008Z			36-11-31	ALL
DC..	GW	W5502	1038	20		21-61-11	ALL
DC..	GW	W5502	1038Z			21-61-11	ALL
DC..	GW	W5502	2005Z			36-11-31	ALL
GD03252		**DC-**				**361/153/L002**	**ALL**
DC..	H8	W2532	0502	*1		24-31-11	ALL
DC..	H8	W2532	0516	*1		49-41-11	ALL
DC..	H	W2532	2201B	20		24-31-11	ALL
GD03254		**BACC50AN20**				**520/154/R017**	**ALL**
DC..	1A	W6230	0327	20		21-25-11	ALL
ST..	1A	W6230	1013Z			21-51-24	ALL
ST..	1A	W6230	2005Z			21-51-22	ALL
DC..	1A	W6528	0309	20		21-51-25	ALL
GD03256		**DC-**				**368/153/L016**	**ALL**
DC..	H8	W2532	0531	*1		24-31-12	ALL
DC..	H	W2532	2202B	20		24-31-12	ALL
GD03258		**ST**				**520/154/L017**	**ALL**
ST..	E	W5104	0327	14		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03301		**BACC50AN20**				**E003-03/ /**	**ALL**
DC..	1A	W0330	0019	22		36-11-13	ALL
DC..	1A	W0330	0021	22		36-11-13	ALL
DC..	1A	W0330	0028	24		36-11-14	ALL
DC..	1A	W0330	0030	24		36-11-14	ALL
DC..	1A	W0330	0070	24		36-11-14	ALL
DC..	1A	W0330	0093	22		36-11-13	ALL
GD03303		**BACC50AN20**				**E003-03/ /**	**ALL**
DC..	1A	W0330	0211	22		21-51-12	ALL
DC..	1A	W0330	0212	24		21-51-11	ALL
DC..	1A	W0330	0213	24		21-51-11	ALL
DC..	1A	W0330	0214	24		21-51-11	ALL
AC..	1A	W0330	0215	22		21-51-22	ALL
DC..	1A	W0330	0240	22		21-51-12	ALL
DC..	1A	W0330	0242	24		21-51-21	ALL
DC..	1A	W0330	0243	24		21-51-21	ALL
DC..	1A	W0330	0244	24		21-51-21	ALL
DC..	1A	W0330	0245	24		21-51-11	ALL
AC..	1A	W0330	0313	22		21-51-12	ALL
DC..	1A	W0330	0316	22		21-51-12	ALL
ST..	1A	W0330	0319	22		21-51-12	ALL
DC..	1A	W0330	0525	24		21-51-21	ALL
DC..	1A	W0330	0527	24		21-51-22	ALL
GD03304		**BACC50AN20**				**E003-03/ /**	**ALL**
AC..	1A	W0330	0349	24		21-51-22	ALL
DC..	1A	W0330	0352	24		21-51-22	ALL
ST..	1A	W0330	0355	24		21-51-22	ALL
GD03305		**BACC50AN16**				**E003-03/ /**	**ALL**
DC..	1	W0330	0040	22		36-11-23	ALL
DC..	1	W0330	0043	22		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03305		**BACC50AN16 (continued)**				**E003-03/ /**	**ALL**
DC..	1	W0330	0051	24		36-11-24	ALL
DC..	1	W0330	0052	24		36-11-24	ALL
DC..	1	W0330	0053	24		36-11-24	ALL
DC..	1	W0330	0094	22		36-11-23	ALL
DC..	1	W0335	0104	16		23-12-31	ALL
DC..	1	W0335	0105	22		23-12-31	ALL
DC..	1	W0335	0106	22		23-12-31	ALL
DC..	1	W0335	0470	22		23-12-31	ALL
GD03308		**DC-**				**368/153/L019**	**ALL**
DC..	F8	W2532	0532	02		24-31-12	ALL
GD03316		**AC-**				**213/208/R036**	**ALL**
AC..	E	W2204	5513	20		33-11-21	ALL
AC..	E	W2204	5535	20		33-17-11	ALL
GD03372		**BACC50AN16**				**847/220/L069**	**ALL**
DC..	1	W3142	0468	20		33-51-22	ALL
DC..	1	W3142	0469	16		33-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03404		**BACC50AN16**				**387/170/R048**	**ALL**
ST..	1	W6210	1003	22		24-41-11	ALL
DED		W6210	1003Z			24-41-11	ALL
AC..	1	W6210	1004	20		24-21-21	ALL
ST..	1	W6210	1004Z			24-21-21	ALL
ST..	1	W6210	4102G	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03602		**ST-**				**/ /**	**ALL**
GD03606		**ST-**				**/ /**	**ALL**
GD03608		**ST-**				**/ /**	**ALL**
GD03630		**ST**				**1223/295/R190**	**ALL**
ST..	E	W8038	0504	12		33-49-11	ALL
GD03632		**ST**				**1223/295/L190**	**ALL**
ST..	E	W7038	0504	12		33-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03702		**BACC50AN16**				**J020-0A/ /**	**ALL**
DC..	1	W0074	0047	22		27-61-43	ALL
DC..	1	W0074	0201	20		21-31-23	ALL
DC..	1	W0074	0227	22		27-61-43	ALL
GD03704		**BACC50AN20**				**J020-0A/ /**	**ALL**
DC..	1A	W0074	0188	22		21-31-22	ALL
DC..	1A	W0074	0189	22		21-31-22	ALL
DC..	1A	W0074	0190	22		21-31-22	ALL
DC..	1A	W0074	0191	20		21-31-22	ALL
DC..	1A	W0074	0198	22		21-31-23	ALL
DC..	1A	W0074	0199	22		21-31-23	ALL
DC..	1A	W0074	0200	22		21-31-23	ALL
DC..	1A	W0074	0207	20		47-30-11	ALL
DC..	1A	W0074	0209	20		28-44-11	ALL
DC..	1A	W0074	0219	22		27-33-11	ALL
GD03728		**BACC50AN16**				**597/295/L031**	**ALL**
DC..	1	W3142	0058	20		33-51-13	ALL
DC..	1	W3142	0273	20		33-51-13	ALL
DC..	1	W3142	0274	16		33-51-13	ALL
DC..	1	W3142	0435	20		52-71-13	ALL
DC..	1	W3142	0439	20		52-71-13	ALL
DC..	1	W3142	0577	16		33-51-13	ALL
AC..	1	W3142	5537	20		21-42-11	ALL
AC..	1	W3166	0105	18		33-22-41	ALL
ST..	1	W3166	0106	18		33-22-41	ALL
AC..	1	W3166	0285	18		33-22-21	ALL
ST..	1	W3166	0286	18		33-22-21	ALL
GD03734		**BACC50AN20**				**359/291/L027**	**ALL**
DC..	1A	W3142	0276	20		33-51-21	ALL
AC..	1A	W3144	0002	20		33-25-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03734		**BACC50AN20 (continued)**				**359/291/L027**	**ALL**
ST..	1A	W3144	1161	20		23-70-11	ALL
ST..	1D	W4258	0412	18		33-26-51	ALL
AC..	1D	W4258	0413	18		33-26-51	ALL
ST..	1D	W4258	0414	18		33-26-51	ALL
GD03736		**BACC50AN16**				**986.5/294/R028**	**ALL**
AC..	1	W3144	0097	20		33-25-22	ALL
GD03738		**BACC50AN16**				**967/181/R008**	**ALL**
ST..	1	W6102	1001Z			21-31-22	ALL
ST..	1	W6102	2001Z			21-31-22	ALL
ST..	1	W6102	2002Z			21-31-22	ALL
ST..	1	W6102	2004Z			21-31-11	ALL
ST..	1	W6102	3002Z			21-31-11	ALL
ST..	1	W6102	5503	20		21-31-22	ALL
ST..	1	W6102	5504	20		21-31-22	ALL
DC..	1	W6102	5505	20		21-31-22	ALL
DC..	1	W6102	5506	20		21-31-22	ALL
ST..	1	W6102	5507	20		21-31-11	ALL
GD03740		**BACC50AN16**				**967/181/R015**	**ALL**
ST..	1	W6204	1001Z			21-31-23	ALL
ST..	1	W6204	2001Z			21-31-23	ALL
ST..	1	W6204	2002Z			21-31-23	ALL
ST..	1	W6204	5503	20		21-31-23	ALL
ST..	1	W6204	5504	20		21-31-23	ALL
DC..	1	W6204	5505	20		21-31-23	ALL
DC..	1	W6204	5506	20		21-31-23	ALL
AC..	1	W6248	5551	20		30-71-11	ALL
AC..	1	W6248	5553	20		30-71-11	ALL
AC..	1	W6248	5565	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03742		**BACC50AN16**				**558/284/L047**	**ALL**
AC..	1	W3166	0055	18		33-22-41	ALL
ST..	1	W3166	0056	18		33-22-41	ALL
AC..	1	W3166	0275	18		33-22-21	ALL
ST..	1	W3166	0276	18		33-22-21	ALL
GD03748		**BACC50AN16**				**616/279/L052**	**ALL**
DC..	1	W3142	0073	20		33-51-21	ALL
DC..	1	W3142	0253	20		33-51-13	ALL
DC..	1	W3142	0255	16		33-51-13	ALL
DC..	1	W3142	0269	16		33-51-12	ALL
DC..	1	W3142	0467	20		52-71-13	ALL
AC..	1	W3142	5535	20		21-42-11	ALL
AC..	1	W3246	0022	18		33-21-12	ALL
ST..	1	W3246	0023	18		33-21-12	ALL
ST..	1	W3246	0025	18		33-21-12	ALL
AC..	1	W3246	0032	18		33-21-12	ALL
ST..	1	W3246	0033	18		33-21-12	ALL
ST..	1	W3246	0035	18		33-21-12	ALL
GD03750		**BACC50AN16**				**558/292/R036**	**ALL**
AC..	1	W4142	0642	20		33-44-11	ALL
ST..	1	W4142	0643	20		33-44-11	ALL
AC..	1	W4166	0055	18		33-22-51	ALL
ST..	1	W4166	0056	18		33-22-51	ALL
AC..	1	W4166	0275	18		33-22-31	ALL
ST..	1	W4166	0276	18		33-22-31	ALL
GD03754		**BACC50AN16**				**664/234/L073**	**ALL**
DC..	1	W3142	0082	20		33-51-22	ALL
DC..	1	W3142	0251	16		33-51-13	ALL
DC..	1	W3142	0461	20		52-71-13	ALL
AC..	1	W3142	5527	20		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03754		**BACC50AN16 (continued)**				**664/234/L073**	**ALL**
AC..	1	W3142	5574	20		21-42-11	ALL
GD03756		**BACC50AN16**				**727D/296/L028**	**ALL**
AC..	1	W3166	0135	18		33-22-41	ALL
ST..	1	W3166	0136	18		33-22-41	ALL
AC..	1	W3166	0575	18		33-22-22	ALL
ST..	1	W3166	0576	18		33-22-22	ALL
GD03760		**BACC50AN16**				**727D+1/204/L022**	**ALL**
AC..	1	W6248	0274	20		33-36-12	ALL
GD03764		**BACC50AN16**				**765/296/L029**	**ALL**
DC..	1	W3142	0448	16		33-51-14	ALL
DC..	1	W3142	0456	20		33-51-14	ALL
AC..	1	W3166	0175	18		33-22-41	ALL
ST..	1	W3166	0176	18		33-22-41	ALL
AC..	1	W3166	0375	18		33-22-22	ALL
ST..	1	W3166	0376	18		33-22-22	ALL
DC..	1	W3419	0032	20		23-24-11	ALL
DC..	1	W3419	0033	20		23-24-11	ALL
DC..	1	W3419	0034	20		23-24-11	ALL
DC..	1	W3419	0035	20		23-24-11	ALL
DC..	1	W3419	0036	20		23-24-11	ALL
GD03770		**BACC50AN16**				**886/296/L028**	**ALL**
DC..	1	W3058	0430	22		33-51-11	ALL
AC..	1	W3166	0515	18		33-22-22	ALL
ST..	1	W3166	0516	18		33-22-22	ALL
AC..	1	W4168	0008	18		33-26-31	ALL
GD03772		**BACC50AN16**				**966/294/R029**	**ALL**
ST..	1	W3144	5503	20		21-42-11	ALL
DC..	1	W4142	0459	20		33-51-14	ALL
AC..	1	W4142	0476	20		33-26-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03774		**ST-**				**665/185/L045**	**ALL**
ST..	GW	W7580	1301ZO			28-41-11	ALL
ST..	GW	W7580	1302Z			28-41-11	ALL
ST..	GW	W7580	1303Z			28-41-11	ALL
GD03778		**BACC50AN16**				**1005/248/L055**	**ALL**
DC..	1	W3142	0451	18		33-51-14	ALL
DC..	1	W3142	0452	20		33-51-22	ALL
AC..	1	W6248	0102	20		52-71-11	ALL
GD03780		**BACC50AN16**				**420/218/L068**	**ALL**
DC..	1	W3142	0078	20		33-51-21	ALL
DC..	1	W3142	0079	16		33-51-21	ALL
GD03782		**BACC50AN16**				**301/222/L060**	**ALL**
DC..	1	W4142	0152	20		33-51-21	ALL
GD03798		**BACC50AN16**				**597/295/R031**	**ALL**
AC..	1	W4166	0065	18		33-22-51	ALL
ST..	1	W4166	0066	18		33-22-51	ALL
AC..	1	W4166	0285	18		33-22-31	ALL
ST..	1	W4166	0286	18		33-22-31	ALL
AC..	1	W4246	0022	18		33-21-12	ALL
ST..	1	W4246	0023	18		33-21-12	ALL
ST..	1	W4246	0025	18		33-21-12	ALL
AC..	1	W4246	0032	18		33-21-12	ALL
ST..	1	W4246	0033	18		33-21-12	ALL
ST..	1	W4246	0035	18		33-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03800		**BACC50AN16**				**616/280/R052**	**ALL**
DC..	1	W4142	0351	20		33-51-21	ALL
DC..	1	W4142	0353	20		33-51-13	ALL
DC..	1	W4142	0354	16		33-51-13	ALL
DC..	1	W4142	0361	16		33-51-12	ALL
DC..	1	W4142	0439	20		52-71-14	ALL
DC..	1	W4142	0443	20		52-71-14	ALL
DC..	1	W4142	0467	20		52-71-14	ALL
DC..	1	W4142	0551	16		33-51-12	ALL
AC..	1	W4142	5533	20		21-42-11	ALL
AC..	1	W4142	5535	20		21-42-11	ALL
AC..	1	W4142	5537	20		21-42-11	ALL
GD03802		**BACC50AN16**				**664/234/R073**	**ALL**
DC..	1	W4142	0252	16		33-51-14	ALL
DC..	1	W4142	0461	20		52-71-14	ALL
AC..	1	W4142	5514	20		21-42-11	ALL
AC..	1	W4142	5527	20		21-42-11	ALL
GD03804		**BACC50AN16**				**685/287/R044**	**ALL**
AC..	1	W4166	0075	18		33-22-51	ALL
ST..	1	W4166	0076	18		33-22-51	ALL
AC..	1	W4166	0435	18		33-22-32	ALL
ST..	1	W4166	0436	18		33-22-32	ALL
GD03806		**BACC50AN16**				**727B/296/R031**	**ALL**
AC..	1	W3453	0028	20		44-35-11	ALL
ST..	1	W3453	0029	20		44-35-11	ALL
AC..	1	W3453	0030	20		44-35-11	ALL
ST..	1	W3453	0031	20		44-35-11	ALL
DC..	1	W4142	0621	20		33-51-14	ALL
DC..	1	W4142	0625	20		33-51-14	ALL
AC..	1	W4166	0345	18		33-22-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03806		**BACC50AN16 (continued)**				**727B/296/R031**	**ALL**
ST..	1	W4166	0346	18		33-22-32	ALL
AC..	1	W4166	0445	18		33-22-32	ALL
ST..	1	W4166	0446	18		33-22-32	ALL
AC..	1	W4166	0615	18		33-22-51	ALL
ST..	1	W4166	0616	18		33-22-51	ALL
GD03808		**BACC50AN16**				**767/296/R031**	**ALL**
DC..	1	W4142	0623	20		33-51-14	ALL
AC..	1	W4166	0165	18		33-22-51	ALL
ST..	1	W4166	0166	18		33-22-51	ALL
AC..	1	W4166	0505	18		33-22-32	ALL
ST..	1	W4166	0506	18		33-22-32	ALL
GD03810		**BACC50AN16**				**1006/248/R056**	**ALL**
DC..	1	W4142	0451	18		33-51-14	ALL
DC..	1	W4142	0452	20		33-51-22	ALL
AC..	1	W6248	0104	20		52-71-11	ALL
GD03814		**BACC50AN16**				**986/292/L030**	**ALL**
DC..	1	W3142	0474	20		33-51-14	ALL
AC..	1	W3142	0476	20		33-26-11	ALL
GD03816		**BACC50AN16**				**867/297/R029**	**ALL**
DC..	1	W4142	0629	20		33-51-14	ALL
AC..	1	W4166	0195	18		33-22-51	ALL
ST..	1	W4166	0196	18		33-22-51	ALL
AC..	1	W4246	0042	18		33-21-12	ALL
ST..	1	W4246	0043	18		33-21-12	ALL
ST..	1	W4246	0044	18		33-21-12	ALL
AC..	1	W4246	0052	18		33-21-12	ALL
ST..	1	W4246	0053	18		33-21-12	ALL
ST..	1	W4246	0054	18		33-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03834		**AC-**				**IFSS-200/ /**	**ALL**
AC..	IA	W1186	0004	04		24-21-11	ALL
GD03836		**BACC50AN16**				**NSTA 161/137/L 1**	**ALL**
DC..	1	W1164	1002	18		24-11-11	ALL
ST..	1	W1164	1002Z			24-11-11	ALL
DC..	1	W1164	1004	20		29-11-11	ALL
ST..	1	W1164	1004Z			29-11-11	ALL
ST..	1	W1166	0001	20		26-11-11	ALL
ST..	1	W1166	0002	20		26-11-11	ALL
ST..	1	W1166	0003	20		30-21-31	ALL
ST..	1	W1166	0004	20		30-21-31	ALL
ST..	1	W1166	0005	20		30-21-31	ALL
ST..	1	W1166	0006	20		30-21-31	ALL
ST..	1	W1166	0008	20		36-11-13	ALL
GD03838		**BACC50AN16**				**NSTA 161/137/R 2**	**ALL**
ST..	1	W1170	0001	20		26-11-11	ALL
ST..	1	W1170	0002	20		26-11-11	ALL
ST..	1	W1170	0003	20		36-11-13	ALL
ST..	1	W1170	0004	20		36-11-13	ALL
ST..	1	W1170	0005	20		36-11-13	ALL
ST..	1	W1170	0007	20		36-11-13	ALL
ST..	1	W1170	0008	20		36-11-13	ALL
GD03840		**BACC50AN16**				**NSTA 161/137/R004**	**ALL**
AC..	1	W1166	1002	18		73-22-11	ALL
ST..	1	W1166	1002ZI			73-22-11	ALL
ST..	1	W1166	1002ZO			73-22-11	ALL
AC..	1	W1166	1004	20		74-11-11	ALL
ST..	1	W1166	1004Z			74-11-11	ALL
AC..	1	W1170	1002	18		73-22-11	ALL
ST..	1	W1170	1002ZI			73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03840		**BACC50AN16 (continued)**				**NSTA 161/137/R004**	**ALL**
ST..	1	W1170	1002ZO			73-22-11	ALL
AC..	1	W1170	1004	20		74-11-11	ALL
ST..	1	W1170	1004Z			74-11-11	ALL
GD03842		**ST-**				**NSTA 188/ /**	**ALL**
ST..	GW	W1166	FRAA			26-12-11	ALL
GD03848		**BACC50AN16**				**727A/296/L028**	**ALL**
DC..	1	W3142	0613	20		33-51-13	ALL
DC..	1	W3142	0615	20		33-51-13	ALL
AC..	1	W3166	0585	18		33-22-22	ALL
ST..	1	W3166	0586	18		33-22-22	ALL
AC..	1	W3166	0615	18		33-22-41	ALL
ST..	1	W3166	0616	18		33-22-41	ALL
GD03850		**BACC50AN16**				**747/297/L028**	**ALL**
GD03858		**BACC50AN20**				**419/294/R028**	**ALL**
AC..	1D	W4246	0002	18		33-21-12	ALL
ST..	1D	W4246	0003	18		33-21-12	ALL
ST..	1D	W4246	0004	18		33-21-12	ALL
AC..	1D	W4246	0012	18		33-21-12	ALL
ST..	1D	W4246	0013	18		33-21-12	ALL
ST..	1D	W4246	0014	18		33-21-12	ALL
AC..	1A	W6288	0004	20		21-61-13	ALL
ST..	1A	W6288	0005	20		21-61-13	ALL
DC..	1A	W6288	0014	20		21-61-51	ALL
GD03862		**BACC50AN16**				**499/295/R030**	**ALL**
AC..	1	W4166	0105	18		33-22-51	ALL
ST..	1	W4166	0106	18		33-22-51	ALL
AC..	1	W4166	0425	18		33-22-31	ALL
ST..	1	W4166	0426	18		33-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03864		**BACC50AN16**				**926/302/L004**	**ALL**
ST..	1	W3144	0301	18		33-26-31	ALL
DC..	1	W3144	0311	20		33-51-22	ALL
DC..	1	W3144	0315	18		35-21-21	ALL
AC..	1	W3144	0328	20		33-25-11	ALL
ST..	1	W3144	0330	18		33-26-31	ALL
AC..	1	W3144	0339	18		33-26-31	ALL
AC..	1	W3144	0340	18		33-26-31	ALL
DC..	1	W5409	0004	20		31-31-11	ALL
AC..	1	W5409	0005	20		31-31-11	ALL
GD03866		**BACC50AN16**				**500/295/L030**	**ALL**
DC..	1	W3142	0068	16		33-51-12	ALL
AC..	1	W3166	0085	18		33-22-41	ALL
ST..	1	W3166	0086	18		33-22-41	ALL
AC..	1	W3166	0415	18		33-22-21	ALL
ST..	1	W3166	0416	18		33-22-21	ALL
GD03868		**BACC50AN16**				**500B/296/R031**	**ALL**
AC..	1	W3755	0004	22		44-35-20	ALL
ST..	1	W3755	0005	22		44-35-20	ALL
DC..	1	W4142	0537	20		33-51-12	ALL
DC..	1	W4142	0538	20		33-51-12	ALL
AC..	1	W4166	0115	18		33-22-51	ALL
ST..	1	W4166	0116	18		33-22-51	ALL
AC..	1	W4166	0245	18		33-22-31	ALL
ST..	1	W4166	0246	18		33-22-31	ALL
DC..	1	W4250	0924	18		33-27-31	ALL
GD03876		**BACC50AN16**				**380/220/L068**	**ALL**
DC..	1	W3142	0151	16		33-51-12	ALL
GD03880		**BACC50AN16**				**344/227/R065**	**ALL**
DC..	1	W4142	0051	18		33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03880		**BACC50AN16 (continued)**				**344/227/R065**	**ALL**
AC..	1	W6412	0005	20		52-71-11	ALL
GD03884		**BACC50AN16**				**398/294/R026**	**ALL**
DC..	1	W4142	0070	20		33-51-12	ALL
AC..	1	W4166	0405	18		33-22-31	ALL
ST..	1	W4166	0406	18		33-22-31	ALL
GD03886		**BACC50AN16**				**420/296/L025**	**ALL**
AC..	1	W3166	0065	18		33-22-41	ALL
ST..	1	W3166	0066	18		33-22-41	ALL
AC..	1	W3246	0002	18		33-21-12	ALL
ST..	1	W3246	0003	18		33-21-12	ALL
ST..	1	W3246	0004	18		33-21-12	ALL
AC..	1	W3246	0012	18		33-21-12	ALL
ST..	1	W3246	0013	18		33-21-12	ALL
ST..	1	W3246	0014	18		33-21-12	ALL
GD03888		**BACC50AN16**				**460/296/L030**	**ALL**
DC..	1	W3142	0637	20		33-51-12	ALL
AC..	1	W3166	0075	18		33-22-41	ALL
ST..	1	W3166	0076	18		33-22-41	ALL
AC..	1	W3166	0425	18		33-22-21	ALL
ST..	1	W3166	0426	18		33-22-21	ALL
GD03890		**BACC50AN16**				**639/279/L53**	**ALL**
DC..	1	W3142	0465	20		52-71-13	ALL
AC..	1	W3142	5516	20		21-42-11	ALL
AC..	1	W3142	5533	20		21-42-11	ALL
GD03892		**ST-**				**OFSS-737/ /**	**ALL**
ST..	N	W1242	0003	20		33-43-11	ALL
ST..	N	W1242	0009	20		33-43-11	ALL
GD03896		**ST-**				**OFSS737/ /**	**ALL**
ST..	N	W1244	0003	20		33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03896		**ST- (continued)**				**OFSS737/ /**	**ALL**
ST..	N	W1244	0009	20		33-43-11	ALL
GD03898		**AC-**				**OFSS-745/ /**	**ALL**
AC..	N	W1242	0002	20		33-43-11	ALL
AC..	N	W1242	0006	20		33-43-11	ALL
AC..	N	W1242	0008	20		33-43-11	ALL
AC..	N	W1242	0022	18		33-44-12	ALL
AC..	N	W1242	0024	18		33-44-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03900		**ST-**				**OFSS-739/ /**	**ALL**
ST..	N	W1242	0023	18		33-44-12	ALL
GD03902		**AC-**				**OFSS 745/ /**	**ALL**
AC..	N	W1244	0002	20		33-43-11	ALL
AC..	N	W1244	0006	20		33-43-11	ALL
AC..	N	W1244	0008	20		33-43-11	ALL
AC..	N	W1244	0022	18		33-44-12	ALL
AC..	N	W1244	0024	18		33-44-12	ALL
GD03904		**ST-**				**OFSS 739/ /**	**ALL**
ST..	N	W1244	0023	18		33-44-12	ALL
GD03907		**ST**				**666/198/R055**	**ALL**
ST..	E	W1134	3601Z			28-23-11	ALL
GD03908		**ST**				**666/195/L058**	**ALL**
ST..	E	W1136	3601Z			28-23-11	ALL
GD03920		**ST-**				**OFSS-260/ /**	**ALL**
ST..	E	W1182	1003Z			26-12-11	ALL
ST..	E	W1188	1014Z			26-12-11	ALL
GD03924		**BACC50AN16**				**328/293/R014**	**ALL**
DC..	1	W4142	0059	20		33-51-12	ALL
DC..	1	W4142	0066	18		35-21-21	ALL
DC..	1	W4142	0078	18		35-21-31	ALL
GD03926		**BACC50AN16**				**328/295/L014**	**ALL**
DC..	1	W3058	0063	20		33-29-11	ALL
AC..	1	W3168	0002	18		33-24-21	ALL
ST..	1	W3168	0003	18		33-24-21	ALL
AC..	1	W3168	0012	18		33-24-21	ALL
ST..	1	W3168	0013	18		33-24-21	ALL
GD03934		**AC-**				**IFSS 200/ /**	**ALL**
AC..	IA	W1286	0004	04		24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03936		**BACC50AN16**				**NSTA 162/137/0**	**ALL**
DC..	1	W1264	1002	18		24-11-21	ALL
ST..	1	W1264	1002Z			24-11-21	ALL
DC..	1	W1264	1004	20		29-11-11	ALL
ST..	1	W1264	1004Z			29-11-11	ALL
ST..	1	W1266	0001	20		26-11-21	ALL
ST..	1	W1266	0002	20		26-11-21	ALL
ST..	1	W1266	0003	20		30-21-32	ALL
ST..	1	W1266	0004	20		30-21-32	ALL
ST..	1	W1266	0005	20		30-21-32	ALL
ST..	1	W1266	0006	20		30-21-32	ALL
ST..	1	W1266	0008	20		36-11-23	ALL
GD03938		**BACC50AN16**				**NSTA 162/137/R001**	**ALL**
ST..	1	W1270	0001	20		26-11-21	ALL
ST..	1	W1270	0002	20		26-11-21	ALL
ST..	1	W1270	0003	20		36-11-23	ALL
ST..	1	W1270	0004	20		36-11-23	ALL
ST..	1	W1270	0005	20		36-11-23	ALL
ST..	1	W1270	0007	20		36-11-23	ALL
ST..	1	W1270	0008	20		36-11-23	ALL
GD03940		**BACC50AN16**				**NSTA/ /**	**ALL**
AC..	1	W1266	1002	18		73-22-11	ALL
ST..	1	W1266	1002ZI			73-22-11	ALL
ST..	1	W1266	1002ZO			73-22-11	ALL
AC..	1	W1266	1004	20		74-11-11	ALL
ST..	1	W1266	1004Z			74-11-11	ALL
AC..	1	W1270	1002	18		73-22-11	ALL
ST..	1	W1270	1002ZI			73-22-11	ALL
ST..	1	W1270	1002ZO			73-22-11	ALL
AC..	1	W1270	1004	20		74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03940		**BACC50AN16 (continued)**				**NSTA/ /**	**ALL**
ST..	1	W1270	1004Z			74-11-11	ALL
GD03942		**ST-**				**NSTA 188/ /**	**ALL**
ST..	GW	W1266	FRAA			26-12-11	ALL
GD03946		**BACC50AN16**				**727D/221/L070**	**ALL**
DC..	1	W3142	0301	16		33-51-11	ALL
ST..	1	W3142	0307	20		33-51-11	ALL
DC..	1	W3142	0394	20		33-51-22	ALL
DC..	1	W3142	0395	16		33-51-22	ALL
GD03948		**BACC50AN16**				**947/300/L007**	**ALL**
DC..	1	W3058	0233	20		38-32-13	ALL
DC..	1	W3058	0255	20		23-42-11	ALL
DC..	1	W3142	0401	16		33-51-11	ALL
ST..	1	W3142	0407	20		33-51-11	ALL
DC..	1	W3311	0004	20		23-31-01	ALL
ST..	1	W3311	0005	20		23-42-12	ALL
DC..	1	W7359	0002	18		35-21-21	ALL
GD03950		**ST-**				**OFSS-267/ /**	**ALL**
ST..	E	W1024	1001Z			28-21-11	ALL
ST..	E	W1178	1009Z			28-21-11	ALL
ST..	E	W1178	1010Z			28-21-11	ALL
ST..	E	W1178	1011Z			28-21-11	ALL
ST..	E	W1178	1012Z			28-21-11	ALL
ST..	E	W1178	1013Z			28-21-11	ALL
ST..	E	W1662	0011	20		30-11-11	ALL
GD03951		**BACC50AN16**				**948/302/L005**	**ALL**
ST..	1	W3311	0045	22		23-31-01	ALL
ST..	1	W5433	0028	22		23-71-01	ALL
DC..	1	W5433	0029	22		23-71-01	ALL
DC..	1	W5433	0033	24		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03951		**BACC50AN16 (continued)**				**948/302/L005**	**ALL**
ST..	1	W5433	0070	20		23-71-01	ALL
ST..	1	W5433	0071	20		23-71-01	ALL
ST..	1	W5433	0072	20		23-71-01	ALL
GD03952		**ST-**				**OFSS 267/ /**	**ALL**
ST..	E	W1034	1001Z			28-21-11	ALL
ST..	E	W1278	1009Z			28-21-11	ALL
ST..	E	W1278	1010Z			28-21-11	ALL
ST..	E	W1278	1011Z			28-21-11	ALL
ST..	E	W1278	1012Z			28-21-11	ALL
ST..	E	W1278	1013Z			28-21-11	ALL
ST..	E	W1664	0018	20		30-11-11	ALL
GD03956		**AC-**				**987/298/R018**	**ALL**
AC..	P	W3154	0010	08		25-31-11	ALL
GD03958		**AC-**				**987/297/R018**	**ALL**
AC..	GY	W3154	0020	10		25-31-11	ALL
GD03960		**AC-**				**295/287/R013**	**ALL**
AC..	GY	W4256	0014	10		25-31-11	ALL
GD03973		**DC-**				**E003-01/ /**	**ALL**
DC..	E	W0311	0003	16		31-65-11	ALL
DC..	E	W0311	0005	16		31-65-11	ALL
GD03974		**ST-**				**/ /**	**ALL**
GD03975		**DC-**				**E003-01/ /**	**ALL**
DC..	E	W0313	0503	16		31-65-21	ALL
DC..	E	W0313	0505	16		31-65-21	ALL
GD03977		**DC-**				**191/228/L020**	**ALL**
GD03979		**DC-**				**191/228/L012**	**ALL**
GD03980		**DC-**				**OFSS-273/ /**	**ALL**
DC..	E	W1178	1011	18		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD03981		**DC-**				**191/226/R003**	**ALL**
GD03982		**ST-**				**OFSS-274/ /**	**ALL**
ST..	E	W1178	1011Z			28-21-11	ALL
ST..	E	W1178	1013	18		28-21-11	ALL
ST..	E	W1178	1013Z			28-21-11	ALL
GD03983		**DC-**				**200/216/L004**	**ALL**
DC..	E	W0001	1514	20		31-65-11	ALL
GD03984		**DC-**				**OFSS 273/ /**	**ALL**
DC..	E	W1278	1011	18		28-21-11	ALL
GD03985		**DC-**				**191/228/R020**	**ALL**
GD03986		**ST-**				**OFSS 274/ /**	**ALL**
ST..	E	W1278	1011Z			28-21-11	ALL
ST..	E	W1278	1013	18		28-21-11	ALL
ST..	E	W1278	1013Z			28-21-11	ALL
GD03987		**DC-**				**190/227/R010**	**ALL**
GD03990		**BACC50AN16**				**826/296/L029**	**ALL**
DC..	1	W3150	0926	18		33-27-22	ALL
AC..	1	W3166	0185	18		33-22-41	ALL
ST..	1	W3166	0186	18		33-22-41	ALL
AC..	1	W3166	0505	18		33-22-22	ALL
ST..	1	W3166	0506	18		33-22-22	ALL
DC..	1	W4479	0002	24		44-35-12	ALL
GD03996		**BACC50AN16**				**639/285/R047**	**ALL**
DC..	1	W4142	0082	20		33-51-22	ALL
DC..	1	W4142	0355	20		33-51-13	ALL
DC..	1	W4142	0356	16		33-51-13	ALL
DC..	1	W4142	0465	20		52-71-14	ALL
AC..	1	W4142	5516	20		21-42-11	ALL
GD03998		**BACC50AN16**				**947.5/294/R030**	**ALL**
DC..	1	W3058	0464	20		33-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD03998		**BACC50AN16 (continued)**				**947.5/294/R030**	**ALL**
DC..	1	W3058	0466	20		33-29-11	ALL
DC..	1	W3058	0476	20		23-42-11	ALL
DC..	1	W4142	0401	16		33-51-11	ALL
ST..	1	W4142	0407	20		33-51-11	ALL
AC..	1	W4168	0002	18		33-24-22	ALL
ST..	1	W4168	0003	18		33-24-22	ALL
AC..	1	W4168	0012	18		33-24-22	ALL
ST..	1	W4168	0013	18		33-24-22	ALL
AC..	1	W4168	0022	18		33-24-22	ALL
ST..	1	W4168	0023	18		33-24-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04002		**BACC50AN16**				**827/296/R031**	**ALL**
AC..	1	W4166	0185	18		33-22-51	ALL
ST..	1	W4166	0186	18		33-22-51	ALL
AC..	1	W4166	0515	18		33-22-32	ALL
ST..	1	W4166	0516	18		33-22-32	ALL
DC..	1	W4250	0926	18		33-27-32	ALL
GD04004		**BACC50AN16**				**705/295/L031**	**ALL**
DC..	1	W3150	0925	18		33-27-22	ALL
AC..	1	W3166	0295	18		33-22-21	ALL
ST..	1	W3166	0296	18		33-22-21	ALL
AC..	1	W3166	0605	18		33-22-41	ALL
ST..	1	W3166	0606	18		33-22-41	ALL
GD04006		**BACC50AN16**				**866/296/L028**	**ALL**
AC..	1	W3246	0042	18		33-21-12	ALL
ST..	1	W3246	0043	18		33-21-12	ALL
ST..	1	W3246	0044	18		33-21-12	ALL
AC..	1	W3246	0052	18		33-21-12	ALL
ST..	1	W3246	0053	18		33-21-12	ALL
ST..	1	W3246	0054	18		33-21-12	ALL
GD04008		**BACC50AN16**				**706/297/R031**	**ALL**
DC..	1	W4250	0925	18		33-27-32	ALL
GD04024		**ST-**				**OFSS 260/ /**	**ALL**
ST..	E	W1282	1003Z			26-12-11	ALL
ST..	E	W1288	1014Z			26-12-11	ALL
GD04048		**ST-**				**IFSS-165/ /**	**ALL**
ST..	E	W1180	2001Z			27-81-11	ALL
GD04050		**ST-**				**IFSS-167/ /**	**ALL**
ST..	E	W1180	2002Z			27-81-11	ALL
GD04052		**ST-**				**IFSS-150/ /**	**ALL**
ST..	GW	W1180	2003Z			27-81-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04052		**ST- (continued)**				**IFSS-150/ /**	**ALL**
ST..	GW	W1180	2004Z			27-81-11	ALL
GD04054		**AC-**				**IFSS-165/ /**	**ALL**
AC..	E	W1180	I-Y			27-81-11	ALL
GD04056		**AC-**				**OFSS-711/ /**	**ALL**
AC..	E	W1188	A-Y			27-81-12	ALL
GD04058		**AC-**				**OFSS-661/ /**	**ALL**
AC..	E	W1188	B-Y			27-81-12	ALL
GD04060		**AC-**				**OFSS-579/ /**	**ALL**
AC..	E	W1188	C-Y			27-81-12	ALL
GD04062		**AC-**				**OFSS-534/ /**	**ALL**
AC..	E	W1188	D-Y			27-81-12	ALL
GD04064		**ST-**				**OFSS-713/ /**	**ALL**
ST..	E	W1188	2005Z			27-81-12	ALL
GD04066		**ST-**				**OFSS-660/ /**	**ALL**
ST..	E	W1188	2006Z			27-81-12	ALL
GD04068		**ST-**				**OFSS-581/ /**	**ALL**
ST..	E	W1188	2007Z			27-81-12	ALL
GD04070		**ST-**				**OFSS-534/ /**	**ALL**
ST..	E	W1188	2008Z			27-81-12	ALL
GD04072		**AC-**				**OFSS-460/ /**	**ALL**
AC..	E	W1188	E-Y			27-81-12	ALL
GD04074		**AC-**				**OFSS-415/ /**	**ALL**
AC..	E	W1188	F-Y			27-81-12	ALL
GD04076		**AC-**				**OFSS-341/ /**	**ALL**
AC..	E	W1188	G-Y			27-81-12	ALL
GD04078		**AC-**				**OFSS-299/ /**	**ALL**
AC..	E	W1188	H-Y			27-81-12	ALL
GD04080		**ST-**				**OFSS-459/ /**	**ALL**
ST..	E	W1188	2009Z			27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04082		**ST-**				**OFSS-415/ /**	**ALL**
ST..	E	W1188	2010Z			27-81-12	ALL
GD04084		**ST-**				**OFSS-341/ /**	**ALL**
ST..	E	W1188	2011Z			27-81-12	ALL
GD04086		**ST-**				**OFSS-299/ /**	**ALL**
ST..	E	W1188	2012Z			27-81-12	ALL
GD04090		**ST-**				**OFSS 459/ /**	**ALL**
ST..	E	W1288	2007Z			27-81-22	ALL
GD04092		**ST-**				**OFSS 415/ /**	**ALL**
ST..	E	W1288	2008Z			27-81-22	ALL
GD04094		**AC-**				**IFSS 165/ /**	**ALL**
AC..	E	W1280	I-Y			27-81-21	ALL
GD04096		**ST-**				**OFSS 341/ /**	**ALL**
ST..	E	W1288	2005Z			27-81-22	ALL
GD04098		**ST-**				**OFSS 299/ /**	**ALL**
ST..	E	W1288	2006Z			27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04100		**BACC50AN16**				**927/296/R029**	**ALL**
ST..	1	W3144	0351	18		33-26-31	ALL
DC..	1	W3144	0365	18		35-21-31	ALL
AC..	1	W3144	0378	20		33-25-11	ALL
ST..	1	W3144	0380	18		33-26-31	ALL
AC..	1	W3144	0389	18		33-26-31	ALL
AC..	1	W3144	0390	18		33-26-31	ALL
GD04102		**BACC50AN20**				**E004-01/ /**	**ALL**
DC..	1A	W0411	0021	22		23-51-51	ALL
DC..	1A	W0411	0022	22		23-51-51	ALL
DC..	1A	W0411	0023	22		23-51-51	ALL
DC..	1A	W0411	0024	22		23-51-51	ALL
DC..	1A	W0411	0025	22		23-51-51	ALL
DC..	1A	W0411	0026	22		23-51-51	ALL
DC..	1A	W0411	0027	22		23-51-51	ALL
DC..	1A	W0411	0043	22		23-31-04	ALL
DC..	1A	W0411	0050	22		23-22-11	ALL
ST..	1A	W0411	0051	22		23-22-11	ALL
DC..	1A	W0411	0054	22		23-22-11	ALL
DC..	1A	W0411	0057	22		23-22-11	ALL
DC..	1A	W0411	0201	22		23-43-11	ALL
DC..	1A	W0411	0202	22		23-43-11	ALL
GD04103		**BACC50AN20**				**E004-01/ /**	**ALL**
AC..	1A	W0410	0122	20		34-51-21	ALL
ST..	1A	W0410	0123	20		34-51-21	ALL
DC..	1A	W0410	0124	22		34-51-21	ALL
ST..	1A	W0410	0351	20		21-51-21	ALL
DC..	1A	W0410	0589	24		36-11-31	ALL
DC..	1A	W0411	0200	22		23-43-11	ALL
DC..	1A	W0411	0203	22		23-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04103		**BACC50AN20 (continued)**				**E004-01/ /**	**ALL**
AC..	1A	W0411	0293	20		23-27-31	ALL
ST..	1A	W0411	0294	20		23-27-31	ALL
DC..	1A	W0411	0297	22		23-27-31	ALL
DC..	1A	W0411	0338	22		23-31-04	ALL
DC..	1A	W0411	0345	22		23-27-38	ALL
DC..	1A	W0411	2003B	24		23-51-11	ALL
DC..	1A	W0411	2006B	24		23-51-21	ALL
GD04104		**BACC50AN16**				**E004-01/ /**	**ALL**
DC..	1	W0410	0354	20		21-51-21	ALL
DC..	1	W0410	0374	20		21-51-24	ALL
DC..	1	W0410	0381	20		21-51-25	ALL
DC..	1	W0410	0490	20		34-61-17	ALL
DC..	1	W0410	0579	20		36-11-22	ALL
GD04105		**BACC50AN20**				**E004-01/ /**	**ALL**
DC..	1A	W0410	0069	20		36-11-12	ALL
ST..	1A	W0410	0309	20		21-51-11	ALL
DC..	1A	W0410	0312	20		21-51-11	ALL
DC..	1A	W0410	0332	20		21-51-14	ALL
DC..	1A	W0410	0341	20		21-51-15	ALL
DC..	1A	W0410	0488	20		34-61-17	ALL
GD04110		**ST-**				**OFSS 713/ /**	**ALL**
ST..	E	W1288	2011Z			27-81-22	ALL
GD04112		**ST-**				**OFSS 660/ /**	**ALL**
ST..	E	W1288	2012Z			27-81-22	ALL
GD04114		**AC-**				**OFSS 341/ /**	**ALL**
AC..	E	W1288	A-Y			27-81-22	ALL
GD04117		**CGH20-22-1**				**E004-01/ /**	**ALL**
ST..	1F	W0410	1069Z			36-11-12	ALL
ST..	1F	W0410	1072Z			36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04117		**CGH20-22-1 (continued)**				**E004-01/ /**	**ALL**
ST..	1F	W0410	1073Z			36-11-12	ALL
ST..	1F	W0410	1455Z			36-11-12	ALL
GD04118		**AC-**				**OFSS 299/ /**	**ALL**
AC..	E	W1288	B-Y			27-81-22	ALL
GD04119		**CGH20-22-1**				**E004-01/ /**	**ALL**
ST..	1F	W0410	1570Z			36-11-22	ALL
ST..	1F	W0410	1571Z			36-11-22	ALL
ST..	1F	W0410	1572Z			36-11-22	ALL
ST..	1F	W0410	1573Z			36-11-22	ALL
GD04120		**AC-**				**OFSS 460/ /**	**ALL**
AC..	E	W1288	C-Y			27-81-22	ALL
GD04122		**AC-**				**OFSS 415/ /**	**ALL**
AC..	E	W1288	D-Y			27-81-22	ALL
GD04124		**AC-**				**OFSS 579/ /**	**ALL**
AC..	E	W1288	E-Y			27-81-22	ALL
GD04126		**AC-**				**OFSS 534/ /**	**ALL**
AC..	E	W1288	F-Y			27-81-22	ALL
GD04128		**AC-**				**OFSS 711/ /**	**ALL**
AC..	E	W1288	G-Y			27-81-22	ALL
GD04130		**AC-**				**OFSS 661/ /**	**ALL**
AC..	E	W1288	H-Y			27-81-22	ALL
GD04132		**ST-**				**OFSS-587/ /**	**ALL**
ST..	E	W1662	2001Z			28-44-11	ALL
GD04140		**ST-**				**/ /**	**ALL**
GD04142		**ST-**				**OFSS 587/ /**	**ALL**
ST..	E	W1664	1018Z			28-44-11	ALL
ST..	E	W1664	1024Z			28-44-11	ALL
GD04148		**ST-**				**OFSS 379/ /**	**ALL**
ST..	E	W1664	0023	16		28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04148		**ST- (continued)**				**OFSS 379/ /**	**ALL**
ST..	E	W1664	0025	16		28-44-11	ALL
ST..	E	W1664	0027	16		28-44-11	ALL
ST..	E	W1664	3002ZO			23-41-11	ALL
GD04164		**BACC50AN16**				**312/293/L020**	**ALL**
DC..	1	W3058	0021	20		24-23-51	ALL
DC..	1	W3058	0172	20		23-42-14	ALL
ST..	1	W3058	0173	20		23-42-14	ALL
ST..	1	W3058	0174	20		23-42-14	ALL
ST..	1	W3058	0175	20		23-42-14	ALL
ST..	1	W3307	0096	22		23-31-01	ALL
GD04168		**BACC50AN16**				**312/294/L017**	**ALL**
AC..	1	W3307	0014	20		23-31-06	ALL
ST..	1	W3307	0015	20		23-31-06	ALL
DC..	1	W3307	0016	20		23-31-06	ALL
DC..	1	W3307	0020	20		44-21-10	ALL
DC..	1	W3307	0098	20		23-31-01	ALL
DC..	1	W4142	0101	16		33-51-11	ALL
ST..	1	W4142	0107	20		33-51-11	ALL
DC..	1	W4142	0159	20		33-51-12	ALL
GD04170		**BACC50AN20**				**328/293/L014**	**ALL**
DC..	1A	W3058	0029	22		52-71-11	ALL
AC..	1A	W3058	0055	20		33-26-11	ALL
DC..	1A	W3058	0364	20		33-51-12	ALL
DC..	1A	W3058	0370	20		23-42-11	ALL
ST..	1A	W3142	0004	20		30-31-11	ALL
AC..	1D	W3168	0022	18		33-24-21	ALL
ST..	1D	W3168	0023	18		33-24-21	ALL
ST..	1D	W3168	0032	18		33-24-21	ALL
AC..	1D	W3168	0033	18		33-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04201		**BACC50AN20**				**E004-02/ /**	**ALL**
DC..	1A	W0422	0083	20		24-11-21	ALL
ST..	1A	W0422	0144	20		24-41-11	ALL
ST..	1A	W0422	0501	20		24-28-41	ALL
GD04202		**BACC50AN20**				**E004-02/ /**	**ALL**
ST..	1A	W0422	0084	20		24-11-21	ALL
DC..	1A	W0422	0142	20		24-41-11	ALL
ST..	1A	W0422	0302	22		46-13-11	ALL
AC..	1A	W0422	0303	22		46-13-11	ALL
DC..	1A	W0422	0304	22		46-13-11	ALL
DC..	1A	W0422	0305	22		46-13-11	ALL
GD04203		**BACC50AN20**				**E004-02/ /**	**ALL**
AC..	1A	W0420	5504	20		30-41-12	ALL
DC..	1A	W0420	5506	20		30-41-12	ALL
DC..	1A	W0420	5515	20		30-41-12	ALL
GD04204		**BACC50AN16**				**E004-02/ /**	**ALL**
DC..	1	W0421	0002	20		23-15-11	ALL
ST..	1	W0421	0003	20		23-15-11	ALL
AC..	1	W0422	0124	18		24-32-11	ALL
AC..	1	W0422	0135	18		24-32-11	ALL
GD04207		**ST-**				**E004-02/ /**	**ALL**
ST..	E	W0420	5511	12		30-41-12	ALL
GD04208		**AC-**				**E004-02/ /**	**ALL**
AC..	E	W0420	5512	12		30-41-12	ALL
AC..	E	W0420	5531	14		30-41-12	ALL
AC..	E	W0420	5536	18		30-41-12	ALL
GD04209		**BACC50AN20**				**E004-02/ /**	**ALL**
ST..	1A	W0422	1009Z			24-28-41	ALL
ST..	1A	W0422	1012Z			24-23-21	ALL
ST..	1A	W0422	1013Z			24-23-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04209		**BACC50AN20 (continued)**				**E004-02/ /**	**ALL**
ST..	1A	W0422	1014Z			24-11-21	ALL
ST..	1A	W0422	2002Z			24-21-21	ALL
ST..	1A	W0422	2003Z			24-22-21	ALL
ST..	1A	W0422	2004Z			24-11-21	ALL
ST..	1A	W0422	2006Z			24-23-21	ALL
ST..	1A	W0422	2429Z			24-22-21	ALL
ST..	1A	W0422	3001Z			24-21-21	ALL
ST..	1A	W0422	4001Z			24-21-21	ALL
ST..	1A	W0422	4002Z			24-24-21	ALL
ST..	1A	W0422	4003Z			24-24-21	ALL
GD04210		**BACC50AN20**				**E004-02/ /**	**ALL**
ST..	1A	W0422	1008Z			24-28-41	ALL
ST..	1A	W0422	1009Z			24-28-41	ALL
ST..	1A	W0422	1010Z			24-41-11	ALL
ST..	1A	W0422	1011Z			24-41-11	ALL
ST..	1A	W0422	1012Z			24-23-21	ALL
ST..	1A	W0422	1013Z			24-23-21	ALL
ST..	1A	W0422	1015Z			24-23-11	ALL
ST..	1A	W0422	1016Z			24-23-11	ALL
ST..	1A	W0422	2005Z			24-23-11	ALL
ST..	1A	W0422	2017Z			24-41-11	ALL
ST..	1A	W0422	2025Z			24-22-11	ALL
ST..	1A	W0422	2429Z			24-22-21	ALL
GD04214		**CGH20-22-1**				**E004-02/ /**	**ALL**
ST..	1F	W0420	1002ZO			30-41-12	ALL
ST..	1F	W0420	1003Z			30-41-12	ALL
ST..	1F	W0420	1004Z			30-41-12	ALL
ST..	1F	W0420	2003ZO			30-41-12	ALL
ST..	1F	W0420	2004Z			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04214		**CGH20-22-1 (continued)**				**E004-02/ /**	**ALL**
ST..	1F	W0420	2006ZO			30-41-12	ALL
ST..	1F	W0420	FRAB			30-41-12	ALL
ST..	1F	W0420	FRAC			30-41-12	ALL
GD04216		**CGH20-22-1**				**E004-02/ /**	**ALL**
GD04223		**BACC50AN16**				**907/296/L028**	**ALL**
DC..	1	W3058	0180	20		23-42-15	ALL
ST..	1	W3058	0181	20		23-42-15	ALL
ST..	1	W3058	0182	20		23-42-15	ALL
ST..	1	W3058	0183	20		23-42-15	ALL
GD04226		**ST**				**IFSS 150/ /**	**ALL**
ST..	GW	W1280	2003Z			27-81-21	ALL
ST..	GW	W1280	2004Z			27-81-21	ALL
GD04228		**ST**				**IFSS 165/ /**	**ALL**
ST..	E	W1280	2001Z			27-81-21	ALL
GD04230		**ST**				**IFSS 167/ /**	**ALL**
ST..	E	W1280	2002Z			27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04300		**ST-**				**OFSS 581/ /**	**ALL**
ST..	E	W1288	2009Z			27-81-22	ALL
GD04302		**ST-**				**OFSS 534/ /**	**ALL**
ST..	E	W1288	2010Z			27-81-22	ALL
GD04308		**ST-**				**655/165/L039**	**ALL**
ST..	GW	W5102	1203	20		33-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04402		**ST-**				**IRSS 142/ /**	**ALL**
ST..	E	W1134	1302Z			28-43-11	ALL
GD04403		**ST-**				**IRSS 151/ /**	**ALL**
ST..	GW	W1382	1032Z			28-43-11	ALL
ST..	GW	W1382	3001Z			28-23-11	ALL
GD04410		**ST**				**IRSS 150/ /**	**ALL**
ST..	GW	W1380	1012Z			28-43-11	ALL
ST..	GW	W1380	3001Z			28-23-11	ALL
GD04411		**ST**				**IRSS 159/ /**	**ALL**
ST..	E	W1136	1304Z			28-43-11	ALL
GD04426		**ST-**				**ORSS 163/ /**	**ALL**
ST..	E	W1134	3601Z			28-23-11	ALL
GD04428		**ST**				**ORSS 160/ /**	**ALL**
ST..	E	W1136	3601Z			28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD04600		**ST-**				**NSTA 567/ /**	**ALL**
ST..	GW	W1166	FRBB			26-12-11	ALL
GD04640		**ST-**				**/ /**	**ALL**
ST..	GW	W1266	FRBB			26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD04809		**ST-**				**1163/273/RBL5**	**ALL**
ST..	E	W3393	1013Z			22-18-11	ALL
ST..	E	W3393	2001Z			22-18-11	ALL
ST..	E	W3393	2006Z			22-18-11	ALL
ST..	E	W3393	2024Z			22-18-11	ALL
ST..	E	W3393	2026Z			22-18-11	ALL
GD04811		**ST-**				**1162/266/RBL6**	**ALL**
ST..	E	W3399	2003Z			22-12-41	ALL
ST..	E	W3399	2005Z			22-12-41	ALL
GD04813		**ST-**				**1087/223/L022**	**ALL**
ST..	E	W4726	1103Z			26-21-11	ALL
ST..	E	W4726	1105Z			26-21-11	ALL
GD04848		**BACC50AN16**				**1046/253/R046**	**ALL**
DC..	1	W4134	1015	20		27-33-11	ALL
DC..	1	W4134	1015Z			27-33-11	ALL
DC..	1	W4134	1017	20		27-33-11	ALL
DC..	1	W4134	1017Z			27-33-11	ALL
DC..	1	W4134	1018	20		27-33-11	ALL
DC..	1	W4134	1018Z			27-33-11	ALL
AC..	1	W4724	1012	18		33-44-12	ALL
ST..	1	W4724	1012Z			33-44-12	ALL
AC..	1	W4724	1022	18		33-35-11	ALL
ST..	1	W4724	1022Z			33-35-11	ALL
AC..	1	W4724	1028	18		33-35-11	ALL
ST..	1	W4724	1028Z			33-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05002		**BACC50AN16**				**807/297/R036**	**ALL**
GD05010		**AC-**				**231/199/L014**	**ALL**
AC..	E	W6110	0005	20		33-34-11	ALL
GD05014		**AC-**				**196/203/R015**	**ALL**
AC..	E	W6110	0007	20		33-34-11	ALL
GD05016		**AC-**				**350/175/L030**	**ALL**
AC..	E	W6110	0073	20		33-34-11	ALL
GD05018		**AC-**				**351/181/R023**	**ALL**
AC..	E	W6110	0070	20		33-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05101		**BACC50AN16**				**540/188/R026**	**ALL**
DC..	1	W5224	0529	20		32-31-15	ALL
DC..	1	W6730	0592	22		32-41-11	ALL
DC..	1	W6732	0592	22		32-41-11	ALL
DC..	1	W6732	1003	20		78-34-21	ALL
ST..	1	W6732	1003Z			78-34-21	ALL
DC..	1	W6732	1006	20		78-34-21	ALL
ST..	1	W6732	1006Z			78-34-21	ALL
GD05108		**BACC50AN16**				**537/193/L025**	**ALL**
DC..	1	W5222	0530	20		78-34-11	ALL
DC..	1	W5222	0533	20		78-34-11	ALL
DC..	1	W5222	0592	20		32-41-11	ALL
DC..	1	W5234	0592	22		32-41-11	ALL
DC..	1	W5728	0512	20		32-35-11	ALL
DC..	1	W5728	0592	22		32-41-11	ALL
DC..	1	W5728	0596	20		32-31-15	ALL
GD05120		**ST**				**655/154/L040**	**ALL**
ST..	GW	W5102	1202Z			33-44-11	ALL
ST..	GW	W5102	2081Z			21-51-13	ALL
ST..	GW	W5102	2090Z			21-51-14	ALL
ST..	GW	W5102	5544	20		21-51-13	ALL
GD05122		**ST-**				**644/151/L008**	**ALL**
ST..	GW	W5102	0015	20		21-51-12	ALL
ST..	GW	W5102	1027Z			21-51-12	ALL
ST..	GW	W5102	1028Z			21-51-12	ALL
ST..	GW	W5102	2076Z			21-51-12	ALL
ST..	GW	W5102	2077Z			21-51-12	ALL
ST..	GW	W5102	2078Z			21-51-12	ALL
GD05124		**AC**				**653/152/L009**	**ALL**
AC..	GW	W5102	1027	20		21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05124		**AC (continued)**				**653/152/L009**	**ALL**
AC..	GW	W5102	1027Z			21-51-12	ALL
GD05126		**ST-**				**581/165/L036**	**ALL**
ST..	GW	W5102	2082Z			21-51-14	ALL
GD05128		**AC**				**578/154/L039**	**ALL**
AC..	GW	W5102	0006	20		33-33-11	ALL
GD05130		**ST-**				**578/151/L040**	**ALL**
ST..	GW	W5102	1001Z			21-51-15	ALL
ST..	GW	W5102	1033Z			21-51-15	ALL
ST..	GW	W5102	1049Z			21-61-51	ALL
ST..	GW	W5102	1050Z			21-61-51	ALL
ST..	GW	W5102	2079Z			21-51-12	ALL
ST..	GW	W5102	2080Z			21-51-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05202		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0523	0313	22		34-21-21	ALL
DC..	E	W0523	0314	22		34-21-21	ALL
DC..	E	W0523	0315	22		34-21-21	ALL
DC..	E	W0523	0334	20		34-21-21	ALL
DC..	E	W0523	0336	20		34-21-21	ALL
DC..	E	W0523	0338	22		34-61-18	ALL
DC..	E	W0523	0339	22		34-21-21	ALL
DC..	E	W0523	0340	22		34-21-21	ALL
DC..	E	W0523	0341	22		34-21-21	ALL
GD05205		**AC-**				**E005-02/ /**	**ALL**
AC..	E	W0523	0305	20		34-61-11	ALL
AC..	E	W0523	0331	20		34-21-21	ALL
AC..	E	W0523	0333	20		34-21-21	ALL
GD05206		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0523	0353	22		34-21-21	ALL
DC..	E	W0523	0354	22		34-21-21	ALL
DC..	E	W0523	0355	22		34-21-21	ALL
DC..	E	W0523	0356	22		34-21-21	ALL
GD05207		**ST-**				******/ /**	**ALL**
ST..	E	W0523	0306	20		34-61-11	ALL
GD05209		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0521	0008	22		34-61-12	ALL
DC..	E	W0521	0012	22		34-61-12	ALL
DC..	E	W0521	0016	22		34-61-12	ALL
DC..	E	W0521	0193	22		34-61-12	ALL
DC..	E	W0521	0195	22		34-61-12	ALL
DC..	E	W0521	0198	22		34-61-12	ALL
DC..	E	W0521	0279	22		34-61-18	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD05210		**ST-**				**E005-02/ /**	**ALL**
ST..	E	W0521	0004	20		34-61-11	ALL
ST..	E	W0521	0142	20		34-21-11	ALL
ST..	E	W0521	0240	20		34-61-22	ALL
ST..	E	W0521	0338	08		34-24-15	ALL
GD05213		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0521	0064	22		34-61-19	ALL
DC..	E	W0521	0065	22		34-61-19	ALL
DC..	E	W0521	0088	22		34-61-19	ALL
DC..	E	W0521	0146	20		34-21-11	ALL
DC..	E	W0521	0336	20		34-24-15	ALL
GD05218		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0521	0241	20		34-61-22	ALL
GD05220		**AC-**				**E005-02/ /**	**ALL**
AC..	E	W0521	0003	20		34-61-11	ALL
AC..	E	W0521	0141	20		34-21-11	ALL
AC..	E	W0521	0145	20		34-21-11	ALL
AC..	E	W0521	0239	20		34-61-22	ALL
GD05221		**DC-**				**E005-02/ /**	**ALL**
DC..	E	W0521	0162	22		34-21-11	ALL
DC..	E	W0521	0163	22		34-21-11	ALL
DC..	E	W0521	0164	22		34-21-11	ALL
DC..	E	W0521	0174	22		34-21-11	ALL
DC..	E	W0521	0175	22		34-21-11	ALL
DC..	E	W0521	0176	22		34-21-11	ALL
DC..	E	W0521	0177	22		34-21-11	ALL
DC..	E	W0521	0235	22		34-21-11	ALL
DC..	E	W0521	0236	22		34-21-11	ALL
DC..	E	W0521	0237	22		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05302		**ST**				**IRSS 150/ /**	**ALL**
GD05304		**ST-**				**IRSS 142/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD05520		**AC-**				**563/159/L007**	**ALL**
AC..	GW	W5502	0003	20		33-33-11	ALL
AC..	GW	W5502	0004	20		33-33-11	ALL
AC..	GW	W5502	1035	20		21-61-11	ALL
AC..	GW	W5502	1035Z			21-61-11	ALL
GD05522		**ST-**				**570/155/L007**	**ALL**
GD05524		**DC-**				**586/157/L007**	**ALL**
DC..	GW	W5502	1004	20		21-51-11	ALL
DC..	GW	W5502	1006	20		21-51-11	ALL
DC..	GW	W5502	1016	20		21-51-11	ALL
GD05526		**ST-**				**570/155/L007**	**ALL**
ST..	GW	W5502	2001Z			21-51-11	ALL
ST..	GW	W5502	2002Z			21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD06032		**ST-**				**528/183/R021**	**ALL**
ST..	E	W5098	6014	20		26-23-11	ALL
ST..	E	W5098	6017	20		26-23-11	ALL
GD06034		**DC-**				**528/183/R014**	**ALL**
DC..	E	W5098	6011	20		26-23-11	ALL
GD06038		**ST-**				**528/183/R014**	**ALL**
ST..	E	W5098	6010	20		26-23-11	ALL
GD06040		**DC-**				**528/183/R021**	**ALL**
DC..	E	W5098	6013	20		26-23-11	ALL
DC..	E	W5098	6016	20		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD06102		**BACC50AN20**				**E006-01/ /**	**ALL**
GD06120		**AC**				**578/154/R039**	**ALL**
AC..	GW	W6202	0011	20		33-33-11	ALL
GD06122		**ST-**				**581/165/R036**	**ALL**
ST..	GW	W6202	2082Z			21-51-24	ALL
GD06124		**ST-**				**645/150/R008**	**ALL**
ST..	GW	W6202	1032Z			21-51-22	ALL
ST..	GW	W6202	1033Z			21-51-22	ALL
ST..	GW	W6202	2076Z			21-51-22	ALL
ST..	GW	W6202	2077Z			21-51-22	ALL
ST..	GW	W6202	2078Z			21-51-22	ALL
ST..	GW	W6202	5552	20		21-51-22	ALL
GD06126		**AC**				**659/162/R040**	**ALL**
AC..	GW	W6202	0013	20		33-33-11	ALL
GD06127		**ST-**				**536/148/L001**	**ALL**
ST..	N	W6230	0045	24		21-51-22	ALL
ST..	E	W6230	2005Z			21-51-22	ALL
GD06128		**ST-**				**653/155/R040**	**ALL**
ST..	GW	W6202	2081Z			21-51-23	ALL
ST..	GW	W6202	2090Z			21-51-24	ALL
ST..	GW	W6202	5553	20		21-51-23	ALL
GD06129		**ST-**				**536/148/R002**	**ALL**
ST..	N	W5104	0019	24		21-51-12	ALL
ST..	E	W5104	2006Z			21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD06201		**BACC50AN16**				**E006-02/ /**	**ALL**
AC..	1	W0621	0008	20		23-11-11	ALL
ST..	1	W0621	0010	20		23-11-11	ALL
DC..	1	W0621	0069	22		23-11-11	ALL
DC..	1	W0621	0129	22		23-11-11	ALL
DC..	1	W0621	0130	22		23-11-11	ALL
GD06202		**BACC50AN16**				**E006-02/ /**	**ALL**
AC..	1	W0623	0149	20		23-11-21	ALL
ST..	1	W0623	0150	20		23-11-21	ALL
DC..	1	W0623	0162	22		23-11-21	ALL
DC..	1	W0623	0163	22		23-11-21	ALL
DC..	1	W0623	0164	22		23-11-21	ALL
GD06203		**BACC50AN16**				**E006-02/ /**	**ALL**
DC..	1	W0626	0031	16		49-62-51	ALL
ST..	1	W0626	0032	16		49-62-51	ALL
ST..	1	W0626	0033	20		49-62-51	ALL
DC..	1	W0626	0048	16		49-52-31	ALL
GD06204		**BACC50AN20**				**E006-02/ /**	**ALL**
AC..	1A	W0625	0001	20		23-71-01	ALL
ST..	1A	W0625	0005	20		23-71-01	ALL
DC..	1A	W0625	0006	20		23-71-01	ALL
DC..	1A	W0625	0017	20		23-71-01	ALL
DC..	1A	W0625	0037	20		23-71-01	ALL
ST..	1A	W0625	0055	20		23-27-35	ALL
ST..	1A	W0625	0060	20		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD06301		**BACC50AN20**				**E006-03/ /**	**ALL**
AC..	1A	W0631	0049	20		44-35-11	ALL
ST..	1A	W0631	0052	20		44-35-11	ALL
GD06302		**BACC50AN20**				**/ /**	**ALL**
DC..	1A	W0631	0026	22		44-35-12	ALL
AC..	1A	W0631	0059	20		44-35-11	ALL
ST..	1A	W0631	0060	20		44-35-11	ALL
GD06310		**BACC50AN16**				**732/169/R009**	**ALL**
ST..	1	W0063	1001Z			47-30-11	ALL
ST..	1	W0063	1002Z			47-30-11	ALL
ST..	1	W0063	1003Z			47-30-11	ALL
ST..	1	W0063	1004Z			47-30-11	ALL
ST..	1	W0063	1005Z			47-30-11	ALL
ST..	1	W0063	1006Z			47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD06522		**AC-**				**588/162/R007**	**ALL**
AC..	GW	W6502	0002	20		33-33-11	ALL
GD06524		**DC-**				**563/158/R007**	**ALL**
DC..	GW	W6502	1006	20		21-51-21	ALL
DC..	GW	W6502	1008	20		21-51-21	ALL
DC..	GW	W6502	1009Z			21-61-15	ALL
DC..	GW	W6502	1013	20		21-51-21	ALL
DC..	GW	W6502	5519	20		21-61-15	ALL
GD06526		**ST-**				**600/159/R007**	**ALL**
ST..	GW	W6502	0014	20		21-51-22	ALL
ST..	GW	W6502	1002Z			26-12-11	ALL
ST..	GW	W6502	1003Z			26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD07004		**BACC50AN16**				**500C/218/L070**	**ALL**
AC..	1	W3142	0061	18		33-41-11	ALL
ST..	1	W3142	0062	18		33-41-11	ALL
DC..	1	W3142	0501	16		33-51-11	ALL
ST..	1	W3142	0507	20		33-51-11	ALL
DC..	1	W3142	0554	20		33-51-21	ALL
DC..	1	W3142	0555	20		33-51-21	ALL
GD07032		**ST-**				**528/183/L013**	**ALL**
ST..	E	W5074	6005	20		26-23-11	ALL
ST..	E	W5074	6008	20		26-23-11	ALL
GD07034		**DC-**				**528/183/L007**	**ALL**
DC..	E	W5074	6002	20		26-23-11	ALL
GD07038		**ST-**				**528/183/L007**	**ALL**
ST..	E	W5074	6001	20		26-23-11	ALL
GD07040		**DC-**				**528/183/L013**	**ALL**
DC..	E	W5074	6004	20		26-23-11	ALL
DC..	E	W5074	6007	20		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD07226		**BACC50AN16**				**727A/295/R031**	**ALL**
AC..	1	W4166	0605	18		33-22-51	ALL
ST..	1	W4166	0606	18		33-22-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD07504		**ST-**				**1156/248/R012**	**ALL**
ST..	E	W4724	0005	20		26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08000		**BACC50AN16**				**559/215/L067**	**ALL**
DC..	1	W3142	0201	16		33-51-11	ALL
ST..	1	W3142	0207	20		33-51-11	ALL
DC..	1	W3142	0227	20		33-51-21	ALL
DC..	1	W3142	0228	20		33-51-21	ALL
DC..	1	W3142	0252	20		33-51-21	ALL
DC..	1	W3142	0437	20		52-71-13	ALL
AC..	1	W3142	5543	20		21-42-11	ALL
AC..	1	W3142	5545	20		21-42-11	ALL
GD08002		**BACC50AN16**				**559/215/R067**	**ALL**
DC..	1	W4142	0086	20		33-51-21	ALL
DC..	1	W4142	0301	16		33-51-11	ALL
ST..	1	W4142	0307	20		33-51-11	ALL
DC..	1	W4142	0441	20		52-71-14	ALL
AC..	1	W4142	5543	20		21-42-11	ALL
AC..	1	W4142	5545	20		21-42-11	ALL
GD08004		**BACC50AN16**				**500C/216/R069**	**ALL**
AC..	1	W4142	0071	18		33-41-11	ALL
ST..	1	W4142	0072	18		33-41-11	ALL
DC..	1	W4142	0501	16		33-51-11	ALL
ST..	1	W4142	0507	20		33-51-11	ALL
GD08006		**BACC50AN16**				**727D/221/R069**	**ALL**
DC..	1	W4142	0201	16		33-51-11	ALL
ST..	1	W4142	0207	20		33-51-11	ALL
GD08008		**AC-**				**343/286/R035**	**ALL**
AC..	P	W4256	0104	08		25-31-11	ALL
GD08010		**BACC50AN16**				**500D/295/L030**	**ALL**
DC..	1	W3142	0066	20		33-51-12	ALL
DC..	1	W3150	0924	18		33-27-21	ALL
AC..	1	W3166	0025	18		33-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08010		**BACC50AN16 (continued)**				**500D/295/L030**	**ALL**
ST..	1	W3166	0026	18		33-22-41	ALL
AC..	1	W3166	0405	18		33-22-21	ALL
ST..	1	W3166	0406	18		33-22-21	ALL
DC..	1	W6288	0002	20		21-61-13	ALL
DC..	1	W6288	0012	20		21-61-51	ALL
GD08012		**BACC50AN16**				**500H/295/L030**	**ALL**
DC..	1	W3142	0579	16		33-51-12	ALL
AC..	1	W3166	0035	18		33-22-41	ALL
ST..	1	W3166	0036	18		33-22-41	ALL
AC..	1	W3166	0045	18		33-22-41	ALL
ST..	1	W3166	0046	18		33-22-41	ALL
AC..	1	W3166	0255	18		33-22-21	ALL
ST..	1	W3166	0256	18		33-22-21	ALL
AC..	1	W3166	0265	18		33-22-21	ALL
ST..	1	W3166	0266	18		33-22-21	ALL
GD08014		**BACC50AN16**				**500F/296/R031**	**ALL**
AC..	1	W4166	0035	18		33-22-51	ALL
ST..	1	W4166	0036	18		33-22-51	ALL
AC..	1	W4166	0255	18		33-22-31	ALL
ST..	1	W4166	0256	18		33-22-31	ALL
GD08016		**BACC50AN16**				**500G/296/R031**	**ALL**
DC..	1	W4142	0555	20		33-51-12	ALL
GD08018		**BACC50AN16**				**500I/296/R031**	**ALL**
AC..	1	W3755	0012	22		44-35-20	ALL
ST..	1	W3755	0013	22		44-35-20	ALL
AC..	1	W4166	0045	18		33-22-51	ALL
ST..	1	W4166	0046	18		33-22-51	ALL
AC..	1	W4166	0265	18		33-22-31	ALL
ST..	1	W4166	0266	18		33-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08018		**BACC50AN16 (continued)**				**500I/296/R031**	**ALL**
DC..	1	W6288	0007	20		21-61-14	ALL
DC..	1	W6288	0018	20		21-61-51	ALL
GD08020		**BACC50AN16**				**727F/296/L028**	**ALL**
DC..	1	W3142	0356	20		33-51-13	ALL
AC..	1	W3166	0145	18		33-22-41	ALL
ST..	1	W3166	0146	18		33-22-41	ALL
AC..	1	W3166	0355	18		33-22-22	ALL
ST..	1	W3166	0356	18		33-22-22	ALL
AC..	1	W3755	0021	22		44-35-20	ALL
ST..	1	W3755	0022	22		44-35-20	ALL
ST..	1	W3755	0036	22		44-35-20	ALL
AC..	1	W3755	0038	22		44-35-20	ALL
GD08022		**BACC50AN16**				**727F/295/R030**	**ALL**
DC..	1	W4142	0627	20		33-51-14	ALL
AC..	1	W4166	0145	18		33-22-51	ALL
ST..	1	W4166	0146	18		33-22-51	ALL
AC..	1	W4166	0355	18		33-22-32	ALL
ST..	1	W4166	0356	18		33-22-32	ALL
GD08024		**BACC50AN16**				**727H/297/L028**	**ALL**
ST..	1	W3755	0040	20		44-35-11	ALL
AC..	1	W3755	0041	20		44-35-11	ALL
AC..	1	W3755	0051	16		44-35-11	ALL
GD08026		**BACC50AN16**				**727H/296/R031**	**ALL**
AC..	1	W4166	0365	18		33-22-32	ALL
ST..	1	W4166	0366	18		33-22-32	ALL
AC..	1	W6288	0009	20		21-61-14	ALL
ST..	1	W6288	0010	20		21-61-14	ALL
DC..	1	W6288	0016	20		21-61-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD08028		**BACC50AN16**				**727J/296/L028**	**ALL**
AC..	1	W3166	0155	18		33-22-41	ALL
ST..	1	W3166	0156	18		33-22-41	ALL
AC..	1	W3166	0365	18		33-22-22	ALL
ST..	1	W3166	0366	18		33-22-22	ALL
GD08030		**BACC50AN16**				**727J/296/R031**	**ALL**
DC..	1	W4142	0408	16		33-51-14	ALL
AC..	1	W4166	0155	18		33-22-51	ALL
ST..	1	W4166	0156	18		33-22-51	ALL
GD08036		**BACC50AN16**				**787/204/L023**	**ALL**
AC..	1	W6248	0268	20		33-36-12	ALL
GD08038		**BACC50AN16**				**727F/204/L023**	**ALL**
DC..	1	W3142	0353	16		33-51-13	ALL
DC..	1	W4142	0097	16		33-51-14	ALL
AC..	1	W6248	0298	20		33-36-12	ALL
GD08040		**BACC50AN16**				**727I/205/L020**	**ALL**
AC..	1	W6248	0220	20		33-36-12	ALL
GD08042		**BACC50AN16**				**500F/203/R004**	**ALL**
ST..	1	W5086	6020	20		26-16-21	ALL
AC..	1	W5248	0054	20		33-36-11	ALL
GD08044		**BACC50AN16**				**500G/202/L011**	**ALL**
AC..	1	W5248	0036	20		33-36-11	ALL
GD08046		**BACC50AN16**				**500B/203/R004**	**ALL**
AC..	1	W5248	0080	20		33-36-11	ALL
GD08048		**BACC50AN16**				**500D/203/L011**	**ALL**
ST..	1	W5086	6010	20		26-16-21	ALL
AC..	1	W5248	0082	20		33-36-11	ALL
GD08050		**BACC50AN16**				**926/219/R063**	**ALL**
ST..	1	W4258	0092	18		25-29-11	ALL
AC..	1	W4258	0093	18		25-29-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08056		**BACC50AN16**				**380/296/R019**	**ALL**
DC..	1	W3477	0057	20		44-35-11	ALL
GD08057		**BACC50AN16**				**380/298/L011**	**ALL**
DC..	1	W3477	0004	20		44-21-12	ALL
AC..	1	W3477	0005	20		44-21-12	ALL
ST..	1	W3477	0006	20		44-21-12	ALL
DC..	1	W3477	0011	20		44-21-12	ALL
AC..	1	W3477	0012	20		44-21-12	ALL
DC..	1	W3477	0038	20		44-21-12	ALL
AC..	1	W3477	0039	20		44-21-12	ALL
ST..	1	W3477	0040	20		44-21-12	ALL
GD08084		**BACC50AN16**				**479/296/R030**	**ALL**
AC..	1	W3910	0097	22		46-13-52	ALL
DC..	1	W3910	0098	22		46-13-52	ALL
ST..	1	W3910	0099	22		46-13-52	ALL
AC..	1	W4166	0095	18		33-22-51	ALL
ST..	1	W4166	0096	18		33-22-51	ALL
AC..	1	W4166	0415	18		33-22-31	ALL
ST..	1	W4166	0416	18		33-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08111		**AC-**				**E8-1 312/184/R014**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08200		**BACC50AN20**				**AJ0039A/ /**	**ALL**
DC..	1A	W0082	0134	20		27-62-11	ALL
DC..	1A	W0082	0143	22		27-61-45	ALL
DC..	1A	W0082	0253	20		22-11-31	ALL
GD08202		**BACC50AN20**				**AJ0039A/ /**	**ALL**
DC..	1A	W0082	0076	20		27-33-11	ALL
DC..	1A	W0082	0080	20		27-33-11	ALL
DC..	1A	W0082	0083	20		27-33-11	ALL
DC..	1A	W0082	0091	20		27-33-11	ALL
DC..	1A	W0082	0094	20		27-33-11	ALL
DC..	1A	W0082	0103	20		27-33-11	ALL
DC..	1A	W0082	0106	20		27-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD08402		**BACC50AN20**				**AJ0039B/ /**	**ALL**
DC..	1A	W0084	0104	22		46-13-52	ALL
DC..	1A	W0084	0111	20		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD0901A		**BACC50AN16**				**P009-00/ /**	**ALL**
GD0901B		**BACC50AN20**				**P009-00/ /**	**ALL**
GD0901C		**BACC50AN16**				**P009-00/ /**	**ALL**
ST..	1	W0001	0015	20		31-65-11	ALL
DC..	1	W2889	0021	20		33-18-61	ALL
AC..	1	W5202	5511	20		33-14-11	ALL
AC..	1	W5202	5533	20		33-14-11	ALL
DC..	1	W5202	5534	20		33-14-11	ALL
DC..	1	W5202	5535	20		33-14-11	ALL
ST..	1	W5202	5536	20		33-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD0911A		**BACC50AN20**				**P009-00/ /**	**ALL**
GD0911B		**BACC50AN20**				**P009-00/ /**	**ALL**
GD0911C		**BACC50AN20**				**P009-00/ /**	**ALL**
AC..	1A	W5202	5502	20		33-14-11	ALL
DC..	1A	W5202	5506	20		33-14-11	ALL
ST..	1A	W5202	5507	20		33-14-11	ALL
DC..	1A	W5202	5523	20		33-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD10086		**BACC50AN16**				**289/217/R057**	**ALL**
DC..	1	W4142	0052	20		33-51-21	ALL
ST..	1	W6242	0051	18		25-29-11	ALL
AC..	1	W6242	0052	18		25-29-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD1010A		**BACC50AN16**				**P001-00/ /**	**ALL**
AC..	1	W0001	0326	20		33-11-31	ALL
GD1010B		**BACC50AN20**				**P001-00/ /**	**ALL**
DC..	1A	W0001	0235	20		33-18-11	ALL
AC..	1A	W0001	0265	20		33-14-11	ALL
DC..	1A	W0003	0689	20		33-18-21	ALL
GD1010C		**BACC50AN20**				**P001-00/ /**	**ALL**
DC..	1A	W0001	0179	20		31-52-11	ALL
AC..	1A	W0001	0222	20		33-11-32	ALL
AC..	1A	W0001	0226	20		33-11-11	ALL
AC..	1A	W0001	0230	20		33-11-32	ALL
AC..	1A	W0001	1010	20		33-11-32	ALL
ST..	1A	W0001	1010Z			33-11-32	ALL
GD10185		**DC-**				**/ /**	**ALL**
GD10189		**DC-**				**/ /**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD11002		**BACC50AN16**				**747/205/L003**	**ALL**
ST..	1	W5096	6025	20		26-16-22	ALL
AC..	1	W6248	0276	20		33-36-12	ALL
GD11004		**BACC50AN16**				**727J/205/L030**	**ALL**
ST..	1	W5096	6010	20		26-16-22	ALL
GD11098		**BACC50AN16**				**986/300/L006**	**ALL**
ST..	1	W4168	0005	18		33-24-22	ALL
AC..	1	W4168	0006	18		33-24-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD11100		**BACC50AN16**				**294/288/L008**	**ALL**
ST..	1	W3058	1003Z			30-31-12	ALL
ST..	1	W3144	0101	18		33-26-31	ALL
DC..	1	W3144	0115	18		35-21-21	ALL
AC..	1	W3144	0128	20		33-25-11	ALL
ST..	1	W3144	0130	18		33-26-31	ALL
AC..	1	W3144	0139	18		33-26-31	ALL
AC..	1	W3144	0140	18		33-26-31	ALL
ST..	1	W3701	0001	20		23-70-11	ALL
GD11104		**BACC50AN16**				**1005/299/L013**	**ALL**
DC..	1	W3377	1009	20		22-23-11	ALL
DC..	1	W3377	1009Z			22-23-11	ALL
DC..	1	W3379	1009	20		27-24-11	ALL
DC..	1	W3379	1009Z			27-24-11	ALL
DC..	1	W5726	0609	16		49-62-11	ALL
ST..	1	W5726	0610	16		49-62-11	ALL
GD11106		**BACC50AN16**				**294/288/R009**	**ALL**
ST..	1	W3058	0320	20		SPARE	ALL
DC..	1	W4142	0701	16		33-51-11	ALL
ST..	1	W4142	0707	20		33-51-11	ALL
AC..	1	W6242	0057	20		33-26-21	ALL
ST..	1	W6242	0058	20		33-26-21	ALL
GD11108		**BACC50AN16**				**360/297/R006**	**ALL**
AC..	1	W3058	0512	18		33-26-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD11306		**BACC50AN16**				**300/263/L051**	**ALL**
AC..	1	W5110	0101	20		52-71-11	ALL
GD11334		**BACC50AN16**				**344/267/R055**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD11728		**BACC50AN16**				**727+18/205/R024**	**ALL**
AC..	1	W6248	0270	20		33-36-12	ALL
GD11730		**BACC50AN16**				**727B/205/L022**	**ALL**
ST..	1	W5096	6020	20		26-16-22	ALL
AC..	1	W6248	0272	20		33-36-12	ALL
GD11732		**BACC50AN16**				**727C/204/L020**	**ALL**
ST..	1	W5096	6005	20		26-16-22	ALL
GD11734		**BACC50AN16**				**847/204/L023**	**ALL**
ST..	1	W5096	6030	20		26-16-22	ALL
GD11794		**BACC50AN16**				**775/199/R064**	**ALL**
DC..	1	W6248	0146	20		52-71-12	ALL
AC..	1	W6248	0280	20		33-36-12	ALL
DC..	1	W6248	0286	20		33-36-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD11830		**BACC50AN16**				**827/204/L030**	**ALL**
ST..	1	W3154	0037	20		25-51-21	ALL
DC..	1	W3154	0038	20		25-51-21	ALL
ST..	1	W5096	6039	22		26-16-22	ALL
DC..	1	W5098	6019	22		26-16-22	ALL
DC..	1	W5098	6020	22		26-16-22	ALL
ST..	1	W5098	6021	22		26-16-22	ALL
AC..	1	W6248	0282	20		33-36-12	ALL
GD11894		**BACC50AN16**				**887/204/L030**	**ALL**
ST..	1	W5096	6015	20		26-16-22	ALL
DC..	1	W5146	0107	18		38-32-12	ALL
ST..	1	W5146	0110	18		38-32-12	ALL
DC..	1	W5146	0113	20		38-32-12	ALL
DC..	1	W5146	0115	20		38-32-12	ALL
DC..	1	W5146	0212	20		38-32-13	ALL
ST..	1	W5146	0213	20		38-32-13	ALL
DC..	1	W5146	0227	20		38-32-13	ALL
AC..	1	W6248	0284	20		33-36-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD11996		**BACC50AN16**				**991/197/L036**	**ALL**
AC..	1	W6248	5501	20		30-71-11	ALL
AC..	1	W6248	5567	20		30-71-11	ALL
AC..	1	W6248	5569	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD23305		**ST-**				**624/156/L011**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No. Term	Type	Part Number Bundle	Wire No.	GA	CO	Station / WL / BL Diagram	Effectivity
GD3010A		**BACC50AN16**				**P003-00/ /**	**ALL**
AC..	1	W0003	0328	20		33-11-21	ALL
ST..	1	W0003	1509Z			33-11-21	ALL
GD3010B		**BACC50AN20**				**P003-00/ /**	**ALL**
DC..	1A	W0003	0697	20		33-18-22	ALL
DC..	1A	W0003	0701	20		33-18-24	ALL
DC..	1A	W0003	0703	20		33-18-24	ALL
GD3010C		**BACC50AN20**				**P003-00/ /**	**ALL**
DC..	1A	W0003	0652	20		31-52-11	ALL
AC..	1A	W0003	0676	20		33-11-21	ALL
AC..	1A	W0003	0680	20		33-11-21	ALL
AC..	1A	W0003	1510	20		33-11-21	ALL
ST..	1A	W0003	1510Z			33-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD65265		**DC-**				**624/156/R015**	**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Ground No.		Part Number				Station / WL / BL	
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD9022A		**BACC50AN20**				**P009-00/ /**	**ALL**
AC..	1A	W2889	0003	20		34-61-11	ALL
DC..	1A	W2889	0004	20		34-61-11	ALL
ST..	1A	W2889	0005	20		34-61-11	ALL
DC..	1A	W2889	0006	20		34-61-11	ALL
AC..	1A	W2889	0023	20		33-11-33	ALL
AC..	1A	W2889	0029	20		33-11-33	ALL
DC..	1A	W5202	5515	20		33-14-11	ALL
ST..	1A	W5202	5516	20		33-14-11	ALL
DC..	1A	W5202	5524	20		33-14-11	ALL
GD9023A		**BACC50AN16**				**P009-00/ /**	**ALL**
ST..	1	W0003	2515B	22		29-32-11	ALL
ST..	1	W0003	2515Z			29-32-11	ALL
ST..	1	W0003	2516B	22		29-32-11	ALL
ST..	1	W0003	2516Z			29-32-11	ALL
AC..	1	W2873	0003	20		34-61-11	ALL
DC..	1	W2873	0004	20		34-61-11	ALL
ST..	1	W2873	0005	20		34-61-11	ALL
DC..	1	W2873	0006	20		34-61-11	ALL
AC..	1	W2873	0017	20		33-11-41	ALL
AC..	1	W2873	0023	20		33-11-41	ALL
DC..	1	W5514	5501	20		31-51-11	ALL
ST..	1	W5514	5574	20		31-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details