91-21-31

SPLICE LIST

91-21-31
SPLICE LIST

Section	Page	Date
EFFECTIVE PAGES		
	1	Nov 14/2025
	2	BLANK
SP00000	1	May 15/2024
	2	May 15/2024
SP00100	1	May 15/2024
	2	May 15/2024
SP00200	1	May 15/2024
	2	May 15/2024
SP00300	1	May 15/2024
SP00400	1	May 15/2024
	2	May 15/2024
SP00500	1	May 15/2024
	2	May 15/2024
SP00600	1	May 15/2024
SP00700	1	May 15/2024
SP00800	1	May 15/2024
	2	May 15/2024
SP00900	1	May 15/2024
SP01000	1	May 15/2024
SP01100	1	May 15/2024
	2	May 15/2024
SP01200	1	May 15/2024
SP01500	1	May 15/2024
SP01700	1	May 15/2024
SP01800	1	May 15/2024
	2	May 15/2024
SP01900	1	May 15/2024
SP02500	1	May 15/2024
SP02800	1	May 15/2024
SP02900	1	May 15/2024
SP03300	1	May 15/2024
SP03400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
SP04100	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00017		**E004-01/ /**					**ALL**
	W0410	0005	22		W	23-51-51	ALL
	W0411	0017	22		W	23-51-51	ALL
	W0411	0356	22		W	23-51-31	ALL
SP00030		**428/296/R020**					**ALL**
	W5726	0598	10		S	49-62-11	ALL
	W6172	6003	10		S	49-62-11	ALL
SP00047		**1040/194/L005**					**ALL**
	W7359	3502R	20		9	23-41-11	ALL
	W7359	3502Z				23-41-11	ALL
	W7359	A-A			9	23-41-11	ALL
SP00049		**1040/194/L005**					**ALL**
	W7359	3502B	20		9	23-41-11	ALL
	W7359	A-B			9	23-41-11	ALL
SP00051		**1040/194/L005**					**ALL**
	W7359	3502Y	20		9	23-41-11	ALL
	W7359	A-C			9	23-41-11	ALL
SP00054		**1085/265/L001**					**ALL**
	W4134	1013	20		9	31-53-11	ALL
	W4134	D-C			9	31-53-11	ALL
SP00056		**1085/265/L001**					**ALL**
	W4134	1014	20		9	31-53-11	ALL
	W4134	A-D			9	31-53-11	ALL
	W4134	B-D			9	31-53-11	ALL
SP00058		**1085/265/L001**					**ALL**
	W4134	C-C			9	31-53-11	ALL
	W4134	D-F			9	31-53-11	ALL
SP00070		**232/271/0**					**ALL**
	W2218	5560	18		S	33-14-12	ALL
	W2218	A-AA			S	33-14-12	ALL
SP00072		**232/271/0**					**ALL**
	W2218	5561	18		S	33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00072		**232/271/0 (continued)**					**ALL**
	W2218	A-AB			S	33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00113		**1085/232/L018**					**ALL**
	W3391	1005	20		9	22-13-11	ALL
	W3391	A-1			9	22-13-11	ALL
SP00115		**1085/232/L018**					**ALL**
	W3391	1010	20		9	22-13-11	ALL
	W3391	A-3			9	22-13-11	ALL
SP00117		**1085/232/L018**					**ALL**
	W3391	1004	20		9	22-13-11	ALL
	W3391	B-1			9	22-13-11	ALL
SP00119		**1085/232/L018**					**ALL**
	W3391	1012	20		9	22-13-11	ALL
	W3391	B-3			9	22-13-11	ALL
SP00152		**1085/265/L014**					**ALL**
	W3391	1022	18		9	27-41-12	ALL
	W3391	A-6			9	27-41-12	ALL
SP00153		**E004-01/ /**					**ALL**
	W0410	0006	22		W	23-51-51	ALL
	W0411	0018	22		W	23-51-51	ALL
	W0411	0354	22		W	23-51-11	ALL
SP00154		**1085/265/L014**					**ALL**
	W3391	1021	18		9	27-41-12	ALL
	W4222	A-E			9	27-41-12	ALL
	W4222	A-F			9	27-41-12	ALL
SP00155		**E004-01/ /**					**ALL**
	W0410	0007	22		W	23-51-51	ALL
	W0411	0019	22		W	23-51-51	ALL
	W0411	0350	22		W	23-51-21	ALL
SP00156		**1085/265/L014**					**ALL**
	W3391	1023	20		9	27-41-12	ALL
	W3391	A-4			9	27-41-12	ALL
SP00158		**1085/265/L014**					**ALL**
	W3391	1025	20		9	27-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00158		**1085/265/L014 (continued)**					**ALL**
	W4222	A-J			9	27-41-12	ALL
SP00160		**1085/265/L014**					**ALL**
	W3391	1024	20		9	27-41-12	ALL
	W4222	A-K			9	27-41-12	ALL
SP00172		**IRSS 219/ /**					**ALL**
	W7230	2220R	20		9	28-42-11	ALL
	W7230	6002	18		9	28-42-11	ALL
	W7230	A-AA			9	28-42-11	ALL
SP00174		**IRSS 219/ /**					**ALL**
	W7230	2220B	20		9	28-42-11	ALL
	W7230	B-BB			9	28-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00210		**990/181/L018**					**ALL**
	W6248	5501	20		9	30-71-11	ALL
	W6248	E-B			9	30-71-11	ALL
SP00212		**990/181/L018**					**ALL**
	W6248	5514	20		9	30-71-11	ALL
	W6248	E-C			9	30-71-11	ALL
SP00226		**858/170/L032**					**ALL**
	W6248	5544	20		9	30-71-11	ALL
	W6248	F-A			9	30-71-11	ALL
SP00228		**858/170/L032**					**ALL**
	W6248	5545	20		9	30-71-11	ALL
	W6248	F-B			9	30-71-11	ALL
SP00230		**915/168/R002**					**ALL**
	W6248	5546	20		9	30-71-11	ALL
	W6248	G-A			9	30-71-11	ALL
SP00232		**915/168/R002**					**ALL**
	W6248	5547	20		9	30-71-11	ALL
	W6248	G-B			9	30-71-11	ALL
SP00238		**959/178/R008**					**ALL**
	W6248	5552	20		9	30-71-11	ALL
	W6248	H-A			9	30-71-11	ALL
SP00240		**959/178/R008**					**ALL**
	W6248	5551	20		9	30-71-11	ALL
	W6248	H-B			9	30-71-11	ALL
SP00242		**959/178/R008**					**ALL**
	W6248	5564	20		9	30-71-11	ALL
	W6248	I-A			9	30-71-11	ALL
SP00244		**959/178/R008**					**ALL**
	W6248	5565	20		9	30-71-11	ALL
	W6248	I-B			9	30-71-11	ALL
SP00260		**599/220/L070**					**ALL**
	W3142	5545	20		9	21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00260		**599/220/L070 (continued)**					**ALL**
	W3142	E-B			9	21-42-11	ALL
SP00270		**599/220/L070**					**ALL**
	W3142	5544	20		9	21-42-11	ALL
	W3142	E-A			9	21-42-11	ALL
SP00272		**233/265/L025**					**ALL**
	W2102	5528	20		S	33-17-11	ALL
	W2102	5530	20		S	33-17-11	ALL
	W2102	B-BG			S	33-17-11	ALL
SP00280		**OFSS 380/ /**					**ALL**
	W1664	1035	20		9	28-44-11	ALL
	W1664	A-D			9	28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00326		**668/167/L025**					**ALL**
	W5230	6011	18		9	28-21-11	ALL
	W7230	6011	18		9	28-21-11	ALL
SP00332		**698/191/L062**					**ALL**
	W7126	2222R	20		9	32-64-12	ALL
	W7126	A-R			9	32-64-12	ALL
SP00334		**698/191/L062**					**ALL**
	W7126	2222B	20		9	32-64-12	ALL
	W7126	A-B			9	32-64-12	ALL
SP00342		**692/192/L062**					**ALL**
	W7230	2222R	20		9	32-64-11	ALL
	W7230	A-R			9	32-64-11	ALL
SP00344		**692/194/L061**					**ALL**
	W7230	2222B	20		9	32-64-11	ALL
	W7230	A-B			9	32-64-11	ALL
SP00352		**698/196/R061**					**ALL**
	W8224	2224R	20		9	32-64-12	ALL
	W8224	A-R			9	32-64-12	ALL
SP00354		**698/196/R061**					**ALL**
	W8224	2224B	20		9	32-64-12	ALL
	W8224	A-B			9	32-64-12	ALL
SP00362		**692/196/R061**					**ALL**
	W8228	2214R	20		9	32-64-11	ALL
	W8228	A-R			9	32-64-11	ALL
SP00364		**692/196/R061**					**ALL**
	W8228	2214B	20		9	32-64-11	ALL
	W8228	A-B			9	32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00421		**OFSS 381/ /**					**ALL**
	W1664	3002R	20		9	23-41-11	ALL
	W1664	3002ZI				23-41-11	ALL
	W1664	A-V			9	23-41-11	ALL
SP00423		**OFSS 381/ /**					**ALL**
	W1664	3002Y	20		9	23-41-11	ALL
	W1664	A-W			9	23-41-11	ALL
SP00425		**OFSS 381/ /**					**ALL**
	W1664	3002B	20		9	23-41-11	ALL
	W1664	A-U			9	23-41-11	ALL
SP00426		**663/165/R008**					**ALL**
	W6128	6011	18		9	28-21-11	ALL
	W8222	6011	18		9	28-21-11	ALL
SP00436		**252/237/L048**					**ALL**
	W2102	5503	18		S	33-14-12	ALL
	W2102	5527	18		S	33-14-12	ALL
	W2102	J-JP			S	33-14-12	ALL
SP00438		**251/238/R048**					**ALL**
	W2204	5502	18		S	33-14-12	ALL
	W2204	5504	18		S	33-14-12	ALL
	W2204	5506	18		S	33-14-12	ALL
	W2204	D-DP			S	33-14-12	ALL
SP00486		**IFSS 149/ /**					**ALL**
	W1280	2003B	20		9	27-81-21	ALL
	W1280	K-B			9	27-81-21	ALL
SP00488		**IFSS 149/ /**					**ALL**
	W1280	2004B	20		9	27-81-21	ALL
	W1280	L-B			9	27-81-21	ALL
SP00490		**IFSS 168/ /**					**ALL**
	W1280	2002B	20		9	27-81-21	ALL
	W1280	J-B			9	27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP00492		**IFSS 165/ /**					**ALL**
	W1280	2001B	20		9	27-81-21	ALL
	W1280	I-B			9	27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00518		**IFSS-168/ /**					**ALL**
	W1180	2002B	20		9	27-81-11	ALL
	W1180	J-B			9	27-81-11	ALL
SP00520		**IFSS-164/ /**					**ALL**
	W1180	2001B	20		9	27-81-11	ALL
	W1180	I-B			9	27-81-11	ALL
SP00522		**IFSS-149/ /**					**ALL**
	W1180	2003B	20		9	27-81-11	ALL
	W1180	K-B			9	27-81-11	ALL
SP00524		**IFSS-149/ /**					**ALL**
	W1180	2004B	20		9	27-81-11	ALL
	W1180	L-B			9	27-81-11	ALL
SP00530		**532/151/R027**					**ALL**
	W6202	1018	20		9	30-71-11	ALL
	W6202	A-AA			9	30-71-11	ALL
SP00533		**347/271/L053**					**ALL**
	W3058	0027	24		9	52-71-11	ALL
	W3058	A-3			9	52-71-11	ALL
SP00537		**347/271/L053**					**ALL**
	W3058	0029	22		9	52-71-11	ALL
	W3058	A-1			9	52-71-11	ALL
SP00554		**IFSS 149/ /**					**ALL**
	W1280	2003R	20		9	27-81-21	ALL
	W1280	K-R			9	27-81-21	ALL
SP00556		**IFSS 149/ /**					**ALL**
	W1280	2004R	20		9	27-81-21	ALL
	W1280	L-R			9	27-81-21	ALL
SP00558		**IFSS 168/ /**					**ALL**
	W1280	2002R	20		9	27-81-21	ALL
	W1280	J-R			9	27-81-21	ALL
SP00560		**IFSS 165/ /**					**ALL**
	W1280	2001R	20		9	27-81-21	ALL
	W1280	I-R			9	27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP00570		**532/151/R027**					**ALL**
	W6202	A-AB			9	30-71-11	ALL
	W6202	A-AC			9	30-71-11	ALL
SP00572		**532/151/R027**					**ALL**
	W6202	5557	20		9	30-71-11	ALL
	W6202	A-AD			9	30-71-11	ALL
SP00586		**IFSS-168/ /**					**ALL**
	W1180	2002R	20		9	27-81-11	ALL
	W1180	J-R			9	27-81-11	ALL
SP00588		**IFSS-164/ /**					**ALL**
	W1180	2001R	20		9	27-81-11	ALL
	W1180	I-R			9	27-81-11	ALL
SP00590		**IFSS-149/ /**					**ALL**
	W1180	2003R	20		9	27-81-11	ALL
	W1180	K-R			9	27-81-11	ALL
SP00592		**IFSS-149/ /**					**ALL**
	W1180	2004R	20		9	27-81-11	ALL
	W1180	L-R			9	27-81-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP00606		**233/265/L025**					**ALL**
	W2102	5505	20		S	33-17-11	ALL
	W2102	B-BP			S	33-17-11	ALL
SP00608		**227/268/R019**					**ALL**
	W2204	5517	20		S	33-17-11	ALL
	W2204	B-BP			S	33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP00702		**636/220/L070**					**ALL**
	W3142	5573	20		9	21-42-11	ALL
	W3142	C-A			9	21-42-11	ALL
SP00704		**636/220/L070**					**ALL**
	W3142	5574	20		9	21-42-11	ALL
	W3142	C-B			9	21-42-11	ALL
SP00708		**599/220/R070**					**ALL**
	W4142	5544	20		9	21-42-11	ALL
	W4142	J-A			9	21-42-11	ALL
SP00710		**599/220/R070**					**ALL**
	W4142	5545	20		9	21-42-11	ALL
	W4142	J-B			9	21-42-11	ALL
SP00724		**637/220/R070**					**ALL**
	W4142	5513	20		9	21-42-11	ALL
	W4142	C-A			9	21-42-11	ALL
SP00726		**637/220/R070**					**ALL**
	W4142	5514	20		9	21-42-11	ALL
	W4142	C-B			9	21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00802		**639/257/L067**					**ALL**
	W3142	0418	20		9	52-71-13	ALL
	W3142	F-A			9	52-71-13	ALL
SP00804		**635/258/L067**					**ALL**
	W3142	0463	20		9	52-71-13	ALL
	W3142	F-B			9	52-71-13	ALL
SP00806		**634/259/L068**					**ALL**
	W3142	0464	20		9	52-71-13	ALL
	W3142	H-A			9	52-71-13	ALL
SP00808		**634/259/L068**					**ALL**
	W3142	0465	20		9	52-71-13	ALL
	W3142	H-B			9	52-71-13	ALL
SP00810		**616/257/L067**					**ALL**
	W3142	0466	20		9	52-71-13	ALL
	W3142	I-A			9	52-71-13	ALL
SP00812		**616/257/L067**					**ALL**
	W3142	0467	20		9	52-71-13	ALL
	W3142	I-B			9	52-71-13	ALL
SP00814		**639/257/L067**					**ALL**
	W3142	0460	20		9	52-71-13	ALL
	W3142	G-A			9	52-71-13	ALL
SP00816		**639/257/L067**					**ALL**
	W3142	0461	20		9	52-71-13	ALL
	W3142	G-B			9	52-71-13	ALL
SP00818		**595/256/L068**					**ALL**
	W3142	0419	20		9	52-71-13	ALL
	W3142	N-A			9	52-71-13	ALL
SP00820		**595/256/L068**					**ALL**
	W3142	0420	20		9	52-71-13	ALL
	W3142	N-B			9	52-71-13	ALL
SP00822		**595/256/L068**					**ALL**
	W3142	0434	20		9	52-71-13	ALL
	W3142	R-A			9	52-71-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00824		**595/256/L068**					**ALL**
	W3142	0435	20		9	52-71-13	ALL
	W3142	R-B			9	52-71-13	ALL
SP00826		**575/258/L067**					**ALL**
	W3142	0436	20		9	52-71-13	ALL
	W3142	P-A			9	52-71-13	ALL
SP00828		**575/258/L067**					**ALL**
	W3142	0437	20		9	52-71-13	ALL
	W3142	P-B			9	52-71-13	ALL
SP00830		**604/258/L067**					**ALL**
	W3142	0438	20		9	52-71-13	ALL
	W3142	Q-A			9	52-71-13	ALL
SP00832		**604/258/L067**					**ALL**
	W3142	0439	20		9	52-71-13	ALL
	W3142	Q-B			9	52-71-13	ALL
SP00888		**OFSS 126/ /**					**ALL**
	W1664	1019	20		9	28-44-11	ALL
	W1664	B-B			9	28-44-11	ALL
SP00893		**400/199/R030**					**ALL**
	W6222	0548	12		9	21-51-24	ALL
	W6230	0042	12		9	21-51-24	ALL
SP00895		**412/200/R032**					**ALL**
	W2216	6013	12		8	21-51-14	ALL
	W5104	0138	12		8	21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00928		**OFSS 375/ /**					**ALL**
	W1664	1012	20		9	28-44-11	ALL
	W1664	1013	18		9	28-44-11	ALL
	W1664	A-B			9	28-44-11	ALL
	W1664	A-C			9	28-44-11	ALL
SP00998		**IFSS 126/ /**					**ALL**
	W1664	1026	20		9	28-44-11	ALL
	W1664	B-A			9	28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP01092		**235/208/L038**					**ALL**
	W2175	0019	10		9	30-42-11	ALL
	W2208	5504	10		9	30-42-11	ALL
SP01094		**235/208/L038**					**ALL**
	W2108	5504	10		9	30-42-11	ALL
	W5156	0116	10		9	30-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01118		**305/266/L050**					**ALL**
	W5110	2419R	20		9	52-71-11	ALL
	W5110	A-A			9	52-71-11	ALL
SP01120		**305/266/L050**					**ALL**
	W5110	0101	20		9	52-71-11	ALL
	W5110	A-C			9	52-71-11	ALL
SP01122		**305/266/L050**					**ALL**
	W5110	2419B	20		9	52-71-11	ALL
	W5110	A-B			9	52-71-11	ALL
SP01124		**993/265/L055**					**ALL**
	W6248	2409R	20		9	52-71-11	ALL
	W6248	B-A			9	52-71-11	ALL
SP01126		**993/265/L055**					**ALL**
	W6248	0102	20		9	52-71-11	ALL
	W6248	B-C			9	52-71-11	ALL
SP01128		**993/265/L055**					**ALL**
	W6248	2409B	20		9	52-71-11	ALL
	W6248	B-B			9	52-71-11	ALL
SP01144		**997/261/R056**					**ALL**
	W6248	2444R	20		9	52-71-11	ALL
	W6248	D-A			9	52-71-11	ALL
SP01146		**997/261/R056**					**ALL**
	W6248	0104	20		9	52-71-11	ALL
	W6248	D-C			9	52-71-11	ALL
SP01148		**997/261/R056**					**ALL**
	W6248	2444B	20		9	52-71-11	ALL
	W6248	D-B			9	52-71-11	ALL
SP01149		**500I/199/L042**					**ALL**
	W5074	6006	22		9	26-23-11	ALL
	W5088	6016	22		9	26-23-11	ALL
SP01150		**500I/199/L042**					**ALL**
	W5074	6009	22		9	26-23-11	ALL
	W5088	6017	22		9	26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01157		**500I/199/L042**					**ALL**
	W5074	6003	22		9	26-23-11	ALL
	W5088	6015	22		9	26-23-11	ALL
SP01158		**332/267/R055**					**ALL**
	W6412	2401R	20		9	52-71-11	ALL
	W6412	C-A			9	52-71-11	ALL
SP01160		**332/267/R055**					**ALL**
	W6412	0005	20		9	52-71-11	ALL
	W6412	C-C			9	52-71-11	ALL
SP01162		**332/267/R055**					**ALL**
	W6412	2401B	20		9	52-71-11	ALL
	W6412	C-B			9	52-71-11	ALL
SP01167		**232/270/000**					**ALL**
	W2216	0018	24		9	21-51-11	ALL
	W2508	5510	24		9	21-51-11	ALL
SP01168		**232/270/000**					**ALL**
	W2216	0019	24		9	21-51-11	ALL
	W2508	5518	24		9	21-51-11	ALL
SP01191		**E004-01/ /**					**ALL**
	W0410	0630	22		W	21-27-51	ALL
	W0411	0588	22		W	21-27-51	ALL
SP01195		**E004-01/ /**					**ALL**
	W0410	0631	22		W	21-27-51	ALL
	W0411	0587	22		W	21-27-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01246		**785/167/R044**					**ALL**
	W6248	0046	20		S	52-71-12	ALL
	W6248	A-A			S	52-71-12	ALL
SP01248		**785/168/R044**					**ALL**
	W6248	0146	20		S	52-71-12	ALL
	W6248	A-B			S	52-71-12	ALL
SP01256		**436/164/R041**					**ALL**
	W5248	0056	20		S	52-71-12	ALL
	W5248	A-A			S	52-71-12	ALL
SP01258		**436/164/R041**					**ALL**
	W5248	0156	20		S	52-71-12	ALL
	W5248	A-B			S	52-71-12	ALL
SP01260		**192/174/R003**					**ALL**
	W5160	0106	18		S	52-71-12	ALL
	W5160	A-A			S	52-71-12	ALL
SP01262		**192/174/R003**					**ALL**
	W5160	0006	18		S	52-71-12	ALL
	W5160	A-B			S	52-71-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP01523		**1206/336/R002**					**ALL**
	W7057	0018	22		9	23-11-11	ALL
	W7061	0018	22		9	23-11-11	ALL
SP01525		**1206/336/R002**					**ALL**
	W7057	0017	22		9	23-11-11	ALL
	W7061	0017	22		9	23-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01732		**OFSS 589/ /**					**ALL**
	W1664	1024	20		9	28-44-11	ALL
	W1664	A-J			9	28-44-11	ALL
SP01734		**OFSS 589/ /**					**ALL**
	W1664	1018	20		9	28-44-11	ALL
	W1664	A-K			9	28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01802		**625/257/R067**					**ALL**
	W4142	0438	20		9	52-71-14	ALL
	W4142	F-A			9	52-71-14	ALL
SP01804		**625/257/R067**					**ALL**
	W4142	0463	20		9	52-71-14	ALL
	W4142	F-B			9	52-71-14	ALL
SP01806		**622/261/R066**					**ALL**
	W4142	0464	20		9	52-71-14	ALL
	W4142	H-A			9	52-71-14	ALL
SP01808		**640/257/R067**					**ALL**
	W4142	0465	20		9	52-71-14	ALL
	W4142	H-B			9	52-71-14	ALL
SP01810		**616/257/R067**					**ALL**
	W4142	0466	20		9	52-71-14	ALL
	W4142	I-A			9	52-71-14	ALL
SP01812		**616/257/R067**					**ALL**
	W4142	0467	20		9	52-71-14	ALL
	W4142	I-B			9	52-71-14	ALL
SP01814		**640/259/R067**					**ALL**
	W4142	0460	20		9	52-71-14	ALL
	W4142	G-A			9	52-71-14	ALL
SP01816		**643/257/R067**					**ALL**
	W4142	0461	20		9	52-71-14	ALL
	W4142	G-B			9	52-71-14	ALL
SP01818		**583/256/R068**					**ALL**
	W4142	0436	20		9	52-71-14	ALL
	W4142	N-A			9	52-71-14	ALL
SP01820		**587/254/R068**					**ALL**
	W4142	0435	20		9	52-71-14	ALL
	W4142	N-B			9	52-71-14	ALL
SP01822		**583/256/R068**					**ALL**
	W4142	0437	20		9	52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01822		**583/256/R068 (continued)**					**ALL**
	W4142	R-A			9	52-71-14	ALL
SP01824		**583/256/R068**					**ALL**
	W4142	0439	20		9	52-71-14	ALL
	W4142	R-B			9	52-71-14	ALL
SP01826		**578/259/R067**					**ALL**
	W4142	0440	20		9	52-71-14	ALL
	W4142	P-A			9	52-71-14	ALL
SP01828		**578/259/R067**					**ALL**
	W4142	0441	20		9	52-71-14	ALL
	W4142	P-B			9	52-71-14	ALL
SP01830		**601/259/R067**					**ALL**
	W4142	0442	20		9	52-71-14	ALL
	W4142	Q-A			9	52-71-14	ALL
SP01832		**601/259/R067**					**ALL**
	W4142	0443	20		9	52-71-14	ALL
	W4142	Q-B			9	52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP01948		**OFSS-712/ /**					**ALL**
	W1188	2005R	20		9	27-81-12	ALL
	W1188	A-R			9	27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02520		**E003-3/ /**					**ALL**
SP02521		**W003-03/ /**					**ALL**
SP02522		**E003-03/ /**					**ALL**

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP02876		**OFSS-712/ /**					**ALL**
	W1188	2005B	20		9	27-81-12	ALL
	W1188	A-B			9	27-81-12	ALL
SP02884		**OFSS-662/ /**					**ALL**
	W1188	2006R	20		9	27-81-12	ALL
	W1188	B-R			9	27-81-12	ALL
SP02886		**OFSS-662/ /**					**ALL**
	W1188	2006B	20		9	27-81-12	ALL
	W1188	B-B			9	27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02936		**OFSS-581/ /**					**ALL**
	W1188	2007R	20		9	27-81-12	ALL
	W1188	C-R			9	27-81-12	ALL
SP02938		**OFSS-581/ /**					**ALL**
	W1188	2007B	20		9	27-81-12	ALL
	W1188	C-B			9	27-81-12	ALL
SP02940		**OFSS-534/ /**					**ALL**
	W1188	2008R	20		9	27-81-12	ALL
	W1188	D-R			9	27-81-12	ALL
SP02942		**OFSS-534/ /**					**ALL**
	W1188	2008B	20		9	27-81-12	ALL
	W1188	D-B			9	27-81-12	ALL
SP02944		**OFSS-459/ /**					**ALL**
	W1188	2009R	20		9	27-81-12	ALL
	W1188	E-R			9	27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP03362		**OFSS-459/ /**					**ALL**
	W1188	2009B	20		9	27-81-12	ALL
	W1188	E-B			9	27-81-12	ALL
SP03380		**OFSS-415/ /**					**ALL**
	W1188	2010R	20		9	27-81-12	ALL
	W1188	F-R			9	27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03422		**OFSS-415/ /**					**ALL**
	W1188	2010B	20		9	27-81-12	ALL
	W1188	F-B			9	27-81-12	ALL
SP03428		**OFSS-341/ /**					**ALL**
	W1188	2011R	20		9	27-81-12	ALL
	W1188	G-R			9	27-81-12	ALL
SP03430		**OFSS-341/ /**					**ALL**
	W1188	2011B	20		9	27-81-12	ALL
	W1188	G-B			9	27-81-12	ALL
SP03432		**OFSS-300/ /**					**ALL**
	W1188	2012R	20		9	27-81-12	ALL
	W1188	H-R			9	27-81-12	ALL
SP03436		**OFSS-300/ /**					**ALL**
	W1188	2012B	20		9	27-81-12	ALL
	W1188	H-B			9	27-81-12	ALL
SP03438		**OFSS 341/ /**					**ALL**
	W1288	2005R	20		9	27-81-22	ALL
	W1288	A-R			9	27-81-22	ALL
SP03440		**OFSS 341/ /**					**ALL**
	W1288	2005B	20		9	27-81-22	ALL
	W1288	A-B			9	27-81-22	ALL
SP03442		**OFSS 300/ /**					**ALL**
	W1288	2006R	20		9	27-81-22	ALL
	W1288	B-R			9	27-81-22	ALL
SP03446		**OFSS 300/ /**					**ALL**
	W1288	2006B	20		9	27-81-22	ALL
	W1288	B-B			9	27-81-22	ALL
SP03448		**OFSS 459/ /**					**ALL**
	W1288	2007R	20		9	27-81-22	ALL
	W1288	C-R			9	27-81-22	ALL
SP03450		**OFSS 459/ /**					**ALL**
	W1288	2007B	20		9	27-81-22	ALL
	W1288	C-B			9	27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03454		**OFSS 415/ /**					**ALL**
	W1288	2008R	20		9	27-81-22	ALL
	W1288	D-R			9	27-81-22	ALL
SP03456		**OFSS 415/ /**					**ALL**
	W1288	2008B	20		9	27-81-22	ALL
	W1288	D-B			9	27-81-22	ALL
SP03458		**OFSS 581/ /**					**ALL**
	W1288	2009R	20		9	27-81-22	ALL
	W1288	E-R			9	27-81-22	ALL
SP03460		**OFSS 581/ /**					**ALL**
	W1288	2009B	20		9	27-81-22	ALL
	W1288	E-B			9	27-81-22	ALL
SP03462		**OFSS 534/ /**					**ALL**
	W1288	2010R	20		9	27-81-22	ALL
	W1288	F-R			9	27-81-22	ALL
SP03466		**OFSS 534/ /**					**ALL**
	W1288	2010B	20		9	27-81-22	ALL
	W1288	F-B			9	27-81-22	ALL
SP03468		**OFSS 712/ /**					**ALL**
	W1288	2011R	20		9	27-81-22	ALL
	W1288	G-R			9	27-81-22	ALL
SP03470		**OFSS 712/ /**					**ALL**
	W1288	2011B	20		9	27-81-22	ALL
	W1288	G-B			9	27-81-22	ALL
SP03472		**OFSS 662/ /**					**ALL**
	W1288	2012R	20		9	27-81-22	ALL
	W1288	H-R			9	27-81-22	ALL
SP03474		**OFSS 662/ /**					**ALL**
	W1288	2012B	20		9	27-81-22	ALL
	W1288	H-B			9	27-81-22	ALL
SP03476		**OFSS-589/ /**					**ALL**
	W1662	2001R	20		9	28-44-11	ALL
	W1662	M-R			9	28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP03478		**OFSS-589/ /**					**ALL**
	W1662	2001B	20		9	28-44-11	ALL
	W1662	M-B			9	28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Splice No.		Station / WL / BL					
	Bundle	Wire No.	GA	CO	Type	Diagram	Effectivity
SP04111		**P007-00/ /**					**ALL**
	W0001	1754	24		S	31-65-13	ALL
	W0003	1753	24		S	31-65-13	ALL
SP04113		**P007-00/ /**					**ALL**
	W0001	1753	24		S	31-65-23	ALL
	W0003	1754	24		S	31-65-23	ALL
SP04115		**P007-00/ /**					**ALL**
	W0001	1754Z			S	31-65-13	ALL
	W0003	1753Z			S	31-65-13	ALL
SP04117		**P007-00/ /**					**ALL**
	W0001	1753Z			S	31-65-23	ALL
	W0003	1754Z			S	31-65-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details