91-21-51

HOOKUP LIST

91-21-51
HOOKUP LIST

Section	Page	Date
EFFECTIVE PAGES		
	1 thru 38	Nov 14/2025
A00000	1	May 15/2024
	2	May 15/2024
C00000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
C00100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
C00200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
C00300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
C00400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
C00500	1	May 15/2024
	2	May 15/2024
C00600	1	May 15/2024
C00700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
C00800	1	May 15/2024
	2	May 15/2024
C00900	1	Apr 23/2025
C01000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
C01100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
C01200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
C01300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
C01400	1	May 15/2024
	2	May 15/2024
C01400 (cont)		
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
C01500	1	May 15/2024
	2	May 15/2024
C01600	1	May 15/2024
	2	May 15/2024
C01900	1	May 15/2024
	2	Dec 24/2024
C02000	1	May 15/2024
C03000	1	May 15/2024
C04000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
C04100	1	Dec 24/2024
D00000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D00100	1	May 15/2024
	2	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D00100 (cont)			D00100 (cont)			D00200 (cont)		
	3	May 15/2024		34	May 15/2024		15	May 15/2024
	4	May 15/2024		35	May 15/2024		16	May 15/2024
	5	May 15/2024		36	May 15/2024		17	May 15/2024
	6	May 15/2024		37	May 15/2024		18	May 15/2024
	7	May 15/2024		38	May 15/2024		19	May 15/2024
	8	May 15/2024		39	May 15/2024		20	May 15/2024
	9	May 15/2024		40	May 15/2024		21	May 15/2024
	10	May 15/2024		41	May 15/2024		22	May 15/2024
	11	May 15/2024		42	May 15/2024		23	May 15/2024
	12	May 15/2024		43	May 15/2024		24	May 15/2024
	13	May 15/2024		44	May 15/2024		25	May 15/2024
	14	May 15/2024		45	May 15/2024		26	May 15/2024
	15	May 15/2024		46	May 15/2024		27	May 15/2024
	16	May 15/2024		47	May 15/2024		28	May 15/2024
	17	May 15/2024		48	May 15/2024			
	18	May 15/2024		49	May 15/2024	**D00300**	1	May 15/2024
	19	May 15/2024					2	May 15/2024
	20	May 15/2024	**D00200**	1	May 15/2024		3	May 15/2024
	21	May 15/2024		2	May 15/2024		4	May 15/2024
	22	May 15/2024		3	May 15/2024		5	May 15/2024
	23	May 15/2024		4	May 15/2024		6	May 15/2024
	24	May 15/2024		5	May 15/2024		7	May 15/2024
	25	May 15/2024		6	May 15/2024		8	May 15/2024
	26	May 15/2024		7	May 15/2024		9	May 15/2024
	27	May 15/2024		8	May 15/2024		10	May 15/2024
	28	May 15/2024		9	May 15/2024		11	May 15/2024
	29	May 15/2024		10	May 15/2024		12	May 15/2024
	30	May 15/2024		11	May 15/2024		13	May 15/2024
	31	May 15/2024		12	May 15/2024		14	May 15/2024
	32	May 15/2024		13	May 15/2024		15	May 15/2024
	33	May 15/2024		14	May 15/2024		16	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D00300 (cont)		
	17	May 15/2024
D00400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
D00500	1	Sep 15/2025
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
D00600	1	May 15/2024
D00600 (cont)		
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
D00600 (cont)		
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
D00700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
D00800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D00800 (cont)		
	6	May 15/2024
	7	May 15/2024
D00900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D01000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
D01100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D01200	1	May 15/2024
	2	May 15/2024
D01300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D01400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D01500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D01600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
D01700	1	May 15/2024
D01800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D01900	1	Apr 23/2025
	2	Apr 23/2025
	3	Apr 23/2025
D02100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
D02200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D02200 (cont)		
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
D02200 (cont)		
	41	May 15/2024
D02300	1	May 15/2024
	2	May 15/2024
D02400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D02500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
D02500 (cont)		
	22	May 15/2024
	23	May 15/2024
D02600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
D02700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
D02800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D02800 (cont)		
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	Dec 24/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
D02900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D03000	1	May 15/2024
	2	May 15/2024
D03100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D03200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
D03200 (cont)		
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
D03300	1	May 15/2024
	2	May 15/2024
D03400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D03500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
D03600	1	May 15/2024
	2	May 15/2024
D03600 (cont)		
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D03600 (cont)		
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
	51	May 15/2024
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
D03700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D03800	1	May 15/2024
D03800 (cont)		
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D03900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D04000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
D04000 (cont)		
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D04100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D04100 (cont)		
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
D04200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
D04200 (cont)		
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
D04300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D04400	1	May 15/2024
	2	May 15/2024
D04500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D04500 (cont)		
	4	May 15/2024
	5	May 15/2024
D04600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D04700	1	May 15/2024
D04800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D05100	1	May 15/2024
	2	May 15/2024
D05300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D05900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D06000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D06100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
D07000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	Dec 24/2024
	6	Dec 24/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
D07100	1	Dec 24/2024
	2	Dec 24/2024
	3	Dec 24/2024
	4	Dec 24/2024
D07200	1	May 15/2024
	2	May 15/2024
D07300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D07400	1	May 15/2024
D07600	1	May 15/2024
D07700	1	May 15/2024
D07900	1	May 15/2024
D08000	1	May 15/2024
D08100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
D08300	1	May 15/2024
	2	May 15/2024
D10000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
D10100	1	May 15/2024
D10100 (cont)	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

EFFECTIVE PAGES

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D10200	1	May 15/2024
D10300	1	May 15/2024
D10400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D10500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D10600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D10700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
D10700 (cont)	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
D10800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D10900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D10900 (cont)		
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
D11000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	Dec 24/2024
	8	May 15/2024
	9	May 15/2024
D11100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024

Section	Page	Date
D11100 (cont)		
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
D11200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D11300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D11400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024

Section	Page	Date
D11400 (cont)		
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D11500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D11500 (cont)		
	23	May 15/2024
D11600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D11700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D11700 (cont)		
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
D11800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
D11900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D12000	1	May 15/2024
	2	May 15/2024
D12000 (cont)		
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D12100	1	May 15/2024
	2	May 15/2024
D12200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D12300	1	May 15/2024
D12400	1	May 15/2024
	2	May 15/2024
D12500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
R **D12600**	1	Nov 14/2025
	2	May 15/2024
D12700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D12700 (cont)			D13700 (cont)			D13700 (cont)		
	8	May 15/2024		2	May 15/2024		33	May 15/2024
	9	May 15/2024		3	May 15/2024		34	May 15/2024
	10	May 15/2024		4	May 15/2024		35	May 15/2024
	11	May 15/2024		5	May 15/2024		36	May 15/2024
	12	May 15/2024		6	May 15/2024		37	May 15/2024
	13	May 15/2024		7	May 15/2024		38	May 15/2024
	14	May 15/2024		8	May 15/2024		39	May 15/2024
	15	May 15/2024		9	May 15/2024		40	May 15/2024
	16	May 15/2024		10	May 15/2024		41	May 15/2024
				11	May 15/2024		42	May 15/2024
D12800	1	May 15/2024		12	May 15/2024		43	May 15/2024
	2	May 15/2024		13	May 15/2024		44	May 15/2024
	3	May 15/2024		14	May 15/2024		45	May 15/2024
	4	May 15/2024		15	May 15/2024		46	May 15/2024
				16	May 15/2024		47	May 15/2024
D12900	1	May 15/2024		17	May 15/2024		48	May 15/2024
	2	May 15/2024		18	May 15/2024		49	May 15/2024
D13000	1	May 15/2024		19	May 15/2024		50	May 15/2024
				20	May 15/2024		51	May 15/2024
D13100	1	May 15/2024		21	May 15/2024		52	May 15/2024
	2	May 15/2024		22	May 15/2024		53	May 15/2024
	3	May 15/2024		23	May 15/2024		54	May 15/2024
D13200	1	May 15/2024		24	May 15/2024		55	May 15/2024
				25	May 15/2024		56	May 15/2024
D13300	1	May 15/2024		26	May 15/2024		57	May 15/2024
	2	May 15/2024		27	May 15/2024		58	May 15/2024
D13400	1	May 15/2024		28	May 15/2024		59	May 15/2024
	2	May 15/2024		29	May 15/2024		60	Dec 24/2024
				30	May 15/2024		61	Dec 24/2024
D13600	1	May 15/2024		31	May 15/2024		62	Dec 24/2024
D13700	1	May 15/2024		32	May 15/2024		63	Dec 24/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D13700 (cont)		
	64	May 15/2024
	65	Dec 24/2024
	66	Dec 24/2024
	67	Dec 24/2024
	68	Dec 24/2024
	69	Dec 24/2024
	70	Dec 24/2024
	71	Dec 24/2024
	72	Dec 24/2024
	73	Dec 24/2024
	74	Dec 24/2024
	75	May 15/2024
	76	May 15/2024
	77	May 15/2024
	78	May 15/2024
	79	May 15/2024
	80	May 15/2024
	81	May 15/2024
	82	May 15/2024
	83	May 15/2024
	84	May 15/2024
	85	May 15/2024
	86	May 15/2024
D13800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D13800 (cont)		
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
D13900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	Dec 24/2024
	9	Dec 24/2024
	10	Dec 24/2024
	11	Dec 24/2024
	12	Dec 24/2024
	13	Dec 24/2024
	14	Dec 24/2024
	15	Dec 24/2024
	16	Dec 24/2024
	17	Dec 24/2024
	18	Dec 24/2024
	19	Dec 24/2024
	20	Dec 24/2024
D14000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D14000 (cont)		
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
D14100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
D14200	1	May 15/2024
D14300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D14300 (cont)		
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
D14400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D14500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D14600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D14700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D14700 (cont)		
	4	May 15/2024
D14800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D14900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D15000	1	May 15/2024
	2	May 15/2024
D15200	1	May 15/2024
	2	May 15/2024
D15300	1	May 15/2024
	2	May 15/2024
D15500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D15600	1	May 15/2024
	2	May 15/2024
D15700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D15800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D15800 (cont)		
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
D15900	1	Apr 23/2025
	2	Apr 23/2025
	3	Apr 23/2025

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D15900 (cont)		
	4	Apr 23/2025
	5	Apr 23/2025
	6	Apr 23/2025
	7	Apr 23/2025
	8	Apr 23/2025
	9	Apr 23/2025
	10	Apr 23/2025
	11	Apr 23/2025
	12	Apr 23/2025
	13	Apr 23/2025
	14	Apr 23/2025
	15	Apr 23/2025
	16	Apr 23/2025
	17	Apr 23/2025
	18	Apr 23/2025
	19	Apr 23/2025
	20	Apr 23/2025
	21	Apr 23/2025
	22	Apr 23/2025
	23	Apr 23/2025
	24	Apr 23/2025
	25	Apr 23/2025
	26	Apr 23/2025
	27	Apr 23/2025
	28	Apr 23/2025
	29	Apr 23/2025
	30	Apr 23/2025
	31	Apr 23/2025
	32	Apr 23/2025
	33	Apr 23/2025
	34	Apr 23/2025
D15900 (cont)		
	35	Apr 23/2025
	36	Apr 23/2025
D16000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D16100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D16200	1	Apr 23/2025
	2	Apr 23/2025
	3	Apr 23/2025
	4	Apr 23/2025
	5	Apr 23/2025
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
D16300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D16300 (cont)		
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
D16400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
D16500	1	May 15/2024
	2	May 15/2024
D16600	1	May 15/2024
D16700	1	May 15/2024
	2	Dec 24/2024
D16800	1	May 15/2024
	2	Dec 24/2024
D17000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D17000 (cont)		
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D17100	1	May 15/2024
D17400	1	May 15/2024
	2	May 15/2024
D17500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024

Section	Page	Date
D17500 (cont)		
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
D17800	1	Dec 24/2024
	2	Dec 24/2024
	3	Dec 24/2024
D30000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024

Section	Page	Date
D30000 (cont)		
	23	May 15/2024
	24	May 15/2024
D30100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
D30200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D30200 (cont)		
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
D30400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
D37000	1	May 15/2024
D39100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D39900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
D39900 (cont)		
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
D39900 (cont)		
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
	51	May 15/2024
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
	57	May 15/2024
	58	May 15/2024
	59	May 15/2024
	60	May 15/2024
	61	May 15/2024
	62	May 15/2024
D40000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40000 (cont)			D40000 (cont)			**D40100**	1	May 15/2024
	6	May 15/2024		37	May 15/2024		2	May 15/2024
	7	May 15/2024		38	May 15/2024		3	May 15/2024
	8	May 15/2024		39	May 15/2024		4	May 15/2024
	9	May 15/2024		40	May 15/2024		5	May 15/2024
	10	May 15/2024		41	May 15/2024		6	May 15/2024
	11	May 15/2024		42	May 15/2024		7	May 15/2024
	12	May 15/2024		43	May 15/2024		8	May 15/2024
	13	May 15/2024		44	May 15/2024		9	May 15/2024
	14	May 15/2024		45	May 15/2024		10	May 15/2024
	15	May 15/2024		46	May 15/2024		11	May 15/2024
	16	May 15/2024		47	May 15/2024		12	May 15/2024
	17	May 15/2024		48	May 15/2024		13	May 15/2024
	18	May 15/2024		49	May 15/2024		14	May 15/2024
	19	May 15/2024		50	May 15/2024		15	May 15/2024
	20	May 15/2024		51	May 15/2024		16	May 15/2024
	21	May 15/2024		52	May 15/2024		17	May 15/2024
	22	May 15/2024		53	May 15/2024		18	May 15/2024
	23	May 15/2024		54	May 15/2024		19	May 15/2024
	24	May 15/2024		55	May 15/2024		20	May 15/2024
	25	May 15/2024		56	May 15/2024		21	May 15/2024
	26	May 15/2024		57	May 15/2024		22	May 15/2024
	27	May 15/2024		58	May 15/2024		23	May 15/2024
	28	May 15/2024		59	May 15/2024		24	May 15/2024
	29	May 15/2024		60	May 15/2024		25	May 15/2024
	30	May 15/2024		61	May 15/2024		26	May 15/2024
	31	May 15/2024		62	May 15/2024		27	May 15/2024
	32	May 15/2024		63	May 15/2024		28	May 15/2024
	33	May 15/2024		64	May 15/2024		29	May 15/2024
	34	May 15/2024		65	May 15/2024		30	May 15/2024
	35	May 15/2024		66	May 15/2024		31	May 15/2024
	36	May 15/2024					32	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40100 (cont)			D40100 (cont)			D40200 (cont)		
	33	May 15/2024		64	May 15/2024		15	May 15/2024
	34	May 15/2024		65	May 15/2024		16	Dec 24/2024
	35	May 15/2024		66	May 15/2024		17	Dec 24/2024
	36	May 15/2024		67	May 15/2024		18	Dec 24/2024
	37	May 15/2024		68	May 15/2024		19	Dec 24/2024
	38	May 15/2024		69	May 15/2024		20	Dec 24/2024
	39	May 15/2024		70	May 15/2024		21	Dec 24/2024
	40	May 15/2024		71	May 15/2024		22	Dec 24/2024
	41	May 15/2024		72	May 15/2024		23	Dec 24/2024
	42	May 15/2024		73	May 15/2024		24	Dec 24/2024
	43	May 15/2024		74	May 15/2024		25	Dec 24/2024
	44	May 15/2024		75	May 15/2024		26	Dec 24/2024
	45	May 15/2024		76	May 15/2024		27	Dec 24/2024
	46	May 15/2024		77	May 15/2024		28	Dec 24/2024
	47	May 15/2024		78	May 15/2024		29	Dec 24/2024
	48	May 15/2024		79	May 15/2024		30	Dec 24/2024
	49	May 15/2024					31	Dec 24/2024
	50	May 15/2024	**D40200**	1	May 15/2024		32	Dec 24/2024
	51	May 15/2024		2	May 15/2024		33	Dec 24/2024
	52	May 15/2024		3	May 15/2024		34	Dec 24/2024
	53	May 15/2024		4	May 15/2024		35	Dec 24/2024
	54	May 15/2024		5	May 15/2024		36	Dec 24/2024
	55	May 15/2024		6	May 15/2024		37	Dec 24/2024
	56	May 15/2024		7	May 15/2024		38	Dec 24/2024
	57	May 15/2024		8	May 15/2024		39	Dec 24/2024
	58	May 15/2024		9	May 15/2024		40	Dec 24/2024
	59	May 15/2024		10	May 15/2024		41	Dec 24/2024
	60	May 15/2024		11	May 15/2024		42	Dec 24/2024
	61	May 15/2024		12	May 15/2024		43	Dec 24/2024
	62	May 15/2024		13	May 15/2024		44	Dec 24/2024
	63	May 15/2024		14	May 15/2024		45	Dec 24/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40200 (cont)			D40300 (cont)			D40300 (cont)		
	46	Dec 24/2024		22	May 15/2024		53	May 15/2024
	47	Dec 24/2024		23	May 15/2024		54	May 15/2024
	48	Dec 24/2024		24	May 15/2024		55	May 15/2024
	49	Dec 24/2024		25	May 15/2024		56	May 15/2024
	50	Dec 24/2024		26	May 15/2024		57	May 15/2024
	51	Dec 24/2024		27	May 15/2024		58	May 15/2024
	52	Dec 24/2024		28	May 15/2024		59	May 15/2024
	53	Dec 24/2024		29	May 15/2024		60	May 15/2024
	54	Dec 24/2024		30	May 15/2024		61	May 15/2024
				31	May 15/2024		62	May 15/2024
D40300	1	May 15/2024		32	May 15/2024		63	May 15/2024
	2	May 15/2024		33	May 15/2024		64	May 15/2024
	3	May 15/2024		34	May 15/2024		65	May 15/2024
	4	May 15/2024		35	May 15/2024		66	May 15/2024
	5	May 15/2024		36	May 15/2024		67	May 15/2024
	6	May 15/2024		37	May 15/2024		68	May 15/2024
	7	May 15/2024		38	May 15/2024		69	May 15/2024
	8	May 15/2024		39	May 15/2024		70	May 15/2024
	9	May 15/2024		40	May 15/2024		71	May 15/2024
	10	May 15/2024		41	May 15/2024		72	May 15/2024
	11	May 15/2024		42	May 15/2024			
	12	May 15/2024		43	May 15/2024	**D40400**	1	May 15/2024
	13	May 15/2024		44	May 15/2024		2	May 15/2024
	14	May 15/2024		45	May 15/2024		3	May 15/2024
	15	May 15/2024		46	May 15/2024		4	May 15/2024
	16	May 15/2024		47	May 15/2024		5	May 15/2024
	17	May 15/2024		48	May 15/2024		6	May 15/2024
	18	May 15/2024		49	May 15/2024		7	May 15/2024
	19	May 15/2024		50	May 15/2024		8	May 15/2024
	20	May 15/2024		51	May 15/2024		9	May 15/2024
	21	May 15/2024		52	May 15/2024		10	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40400 (cont)			D40400 (cont)			D40400 (cont)		
	11	May 15/2024		42	May 15/2024		73	May 15/2024
	12	May 15/2024		43	May 15/2024		74	May 15/2024
	13	May 15/2024		44	May 15/2024		75	May 15/2024
	14	May 15/2024		45	May 15/2024			
	15	May 15/2024		46	May 15/2024	**D40500**	1	May 15/2024
	16	May 15/2024		47	May 15/2024		2	May 15/2024
	17	May 15/2024		48	May 15/2024		3	May 15/2024
	18	May 15/2024		49	May 15/2024		4	May 15/2024
	19	May 15/2024		50	May 15/2024		5	May 15/2024
	20	May 15/2024		51	May 15/2024		6	May 15/2024
	21	May 15/2024		52	May 15/2024		7	May 15/2024
	22	May 15/2024		53	May 15/2024		8	May 15/2024
	23	May 15/2024		54	May 15/2024		9	May 15/2024
	24	May 15/2024		55	May 15/2024		10	May 15/2024
	25	May 15/2024		56	May 15/2024		11	May 15/2024
	26	May 15/2024		57	May 15/2024		12	May 15/2024
	27	May 15/2024		58	May 15/2024		13	May 15/2024
	28	May 15/2024		59	May 15/2024		14	May 15/2024
	29	May 15/2024		60	May 15/2024		15	May 15/2024
	30	May 15/2024		61	May 15/2024		16	May 15/2024
	31	May 15/2024		62	May 15/2024		17	May 15/2024
	32	May 15/2024		63	May 15/2024		18	May 15/2024
	33	May 15/2024		64	May 15/2024		19	May 15/2024
	34	May 15/2024		65	May 15/2024		20	May 15/2024
	35	May 15/2024		66	May 15/2024		21	May 15/2024
	36	May 15/2024		67	May 15/2024		22	May 15/2024
	37	May 15/2024		68	May 15/2024		23	May 15/2024
	38	May 15/2024		69	May 15/2024		24	May 15/2024
	39	May 15/2024		70	May 15/2024		25	May 15/2024
	40	May 15/2024		71	May 15/2024		26	May 15/2024
	41	May 15/2024		72	May 15/2024		27	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40500 (cont)			D40500 (cont)			D40600 (cont)		
	28	May 15/2024		59	May 15/2024		5	May 15/2024
	29	May 15/2024		60	May 15/2024		6	May 15/2024
	30	May 15/2024		61	May 15/2024		7	May 15/2024
	31	May 15/2024		62	May 15/2024		8	May 15/2024
	32	May 15/2024		63	May 15/2024		9	May 15/2024
	33	May 15/2024		64	May 15/2024		10	May 15/2024
	34	May 15/2024		65	May 15/2024		11	May 15/2024
	35	May 15/2024		66	May 15/2024		12	May 15/2024
	36	May 15/2024		67	May 15/2024		13	May 15/2024
	37	May 15/2024		68	May 15/2024		14	May 15/2024
	38	May 15/2024		69	May 15/2024		15	May 15/2024
	39	May 15/2024		70	May 15/2024		16	May 15/2024
	40	May 15/2024		71	May 15/2024		17	May 15/2024
	41	May 15/2024		72	May 15/2024		18	May 15/2024
	42	May 15/2024		73	May 15/2024		19	May 15/2024
	43	May 15/2024		74	May 15/2024		20	May 15/2024
	44	May 15/2024		75	May 15/2024		21	May 15/2024
	45	May 15/2024		76	May 15/2024		22	May 15/2024
	46	May 15/2024		77	May 15/2024		23	May 15/2024
	47	May 15/2024		78	May 15/2024		24	May 15/2024
	48	May 15/2024		79	May 15/2024		25	May 15/2024
	49	May 15/2024		80	May 15/2024		26	May 15/2024
	50	May 15/2024		81	May 15/2024		27	May 15/2024
	51	May 15/2024		82	May 15/2024		28	May 15/2024
	52	May 15/2024		83	May 15/2024		29	May 15/2024
	53	May 15/2024		84	May 15/2024		30	May 15/2024
	54	May 15/2024					31	May 15/2024
	55	May 15/2024	**D40600**	1	May 15/2024		32	May 15/2024
	56	May 15/2024		2	May 15/2024		33	May 15/2024
	57	May 15/2024		3	May 15/2024		34	May 15/2024
	58	May 15/2024		4	May 15/2024		35	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40600 (cont)			D40600 (cont)			D40700 (cont)		
	36	May 15/2024		67	May 15/2024		23	May 15/2024
	37	May 15/2024		68	May 15/2024		24	May 15/2024
	38	May 15/2024		69	May 15/2024		25	May 15/2024
	39	May 15/2024		70	May 15/2024		26	May 15/2024
	40	May 15/2024		71	May 15/2024		27	May 15/2024
	41	May 15/2024		72	May 15/2024		28	May 15/2024
	42	May 15/2024		73	May 15/2024		29	May 15/2024
	43	May 15/2024		74	May 15/2024		30	May 15/2024
	44	May 15/2024					31	May 15/2024
	45	May 15/2024	**D40700**	1	May 15/2024		32	May 15/2024
	46	May 15/2024		2	May 15/2024		33	May 15/2024
	47	May 15/2024		3	May 15/2024		34	May 15/2024
	48	May 15/2024		4	May 15/2024		35	May 15/2024
	49	May 15/2024		5	May 15/2024		36	May 15/2024
	50	May 15/2024		6	May 15/2024		37	May 15/2024
	51	May 15/2024		7	May 15/2024		38	May 15/2024
	52	May 15/2024		8	May 15/2024		39	May 15/2024
	53	May 15/2024		9	May 15/2024		40	May 15/2024
	54	May 15/2024		10	May 15/2024		41	May 15/2024
	55	May 15/2024		11	May 15/2024		42	May 15/2024
	56	May 15/2024		12	May 15/2024		43	May 15/2024
	57	May 15/2024		13	May 15/2024		44	May 15/2024
	58	May 15/2024		14	May 15/2024		45	May 15/2024
	59	May 15/2024		15	May 15/2024		46	May 15/2024
	60	May 15/2024		16	May 15/2024		47	May 15/2024
	61	May 15/2024		17	May 15/2024		48	May 15/2024
	62	May 15/2024		18	May 15/2024		49	May 15/2024
	63	May 15/2024		19	May 15/2024		50	May 15/2024
	64	May 15/2024		20	May 15/2024		51	May 15/2024
	65	May 15/2024		21	May 15/2024		52	May 15/2024
	66	May 15/2024		22	May 15/2024		53	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40700 (cont)			D40700 (cont)			D40800 (cont)		
	54	May 15/2024		85	May 15/2024		21	May 15/2024
	55	May 15/2024		86	May 15/2024		22	May 15/2024
	56	May 15/2024		87	May 15/2024		23	May 15/2024
	57	May 15/2024		88	May 15/2024		24	May 15/2024
	58	May 15/2024		89	May 15/2024		25	May 15/2024
	59	May 15/2024		90	May 15/2024		26	May 15/2024
	60	May 15/2024		91	May 15/2024		27	Dec 24/2024
	61	May 15/2024		92	May 15/2024		28	Dec 24/2024
	62	May 15/2024		93	May 15/2024		29	May 15/2024
	63	May 15/2024		94	May 15/2024		30	May 15/2024
	64	May 15/2024					31	May 15/2024
	65	May 15/2024	**D40800**	1	May 15/2024		32	May 15/2024
	66	May 15/2024		2	May 15/2024		33	May 15/2024
	67	May 15/2024		3	May 15/2024		34	May 15/2024
	68	May 15/2024		4	May 15/2024		35	May 15/2024
	69	May 15/2024		5	May 15/2024		36	May 15/2024
	70	May 15/2024		6	May 15/2024		37	May 15/2024
	71	May 15/2024		7	May 15/2024		38	May 15/2024
	72	May 15/2024		8	May 15/2024		39	May 15/2024
	73	May 15/2024		9	May 15/2024		40	May 15/2024
	74	May 15/2024		10	May 15/2024		41	May 15/2024
	75	May 15/2024		11	May 15/2024		42	May 15/2024
	76	May 15/2024		12	May 15/2024		43	May 15/2024
	77	May 15/2024		13	May 15/2024		44	May 15/2024
	78	May 15/2024		14	May 15/2024		45	May 15/2024
	79	May 15/2024		15	May 15/2024		46	May 15/2024
	80	May 15/2024		16	May 15/2024		47	May 15/2024
	81	May 15/2024		17	May 15/2024		48	May 15/2024
	82	May 15/2024		18	May 15/2024		49	May 15/2024
	83	May 15/2024		19	May 15/2024		50	May 15/2024
	84	May 15/2024		20	May 15/2024		51	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D40800 (cont)		
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
	57	May 15/2024
	58	May 15/2024
	59	May 15/2024
	60	May 15/2024
D40900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
D40900 (cont)		
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
	48	May 15/2024
D41000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D41000 (cont)		
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
D41100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D41100 (cont)		
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
D41200	1	May 15/2024
D41300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D41400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024

Section	Page	Date
D41400 (cont)		
	6	May 15/2024
	7	May 15/2024
D41500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	Sep 15/2025
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D41600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024

Section	Page	Date
D41700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D41800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D41800 (cont)		
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
	51	May 15/2024
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
	57	May 15/2024
	58	May 15/2024
	59	May 15/2024

Section	Page	Date
D41800 (cont)		
	60	May 15/2024
	61	May 15/2024
	62	May 15/2024
	63	May 15/2024
	64	May 15/2024
	65	May 15/2024
	66	May 15/2024
	67	May 15/2024
	68	May 15/2024
	69	May 15/2024
	70	May 15/2024
	71	May 15/2024
	72	May 15/2024
	73	May 15/2024
	74	May 15/2024
	75	May 15/2024
D42000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024

Section	Page	Date
D42000 (cont)		
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
D42100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
D42200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D42300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D42400	1	May 15/2024	D43000 (cont)			D43100 (cont)		
				9	May 15/2024		5	May 15/2024
D42700	1	May 15/2024		10	May 15/2024		6	Dec 24/2024
	2	May 15/2024		11	May 15/2024		7	Dec 24/2024
	3	May 15/2024		12	May 15/2024		8	Dec 24/2024
	4	May 15/2024		13	May 15/2024		9	May 15/2024
	5	May 15/2024		14	May 15/2024		10	May 15/2024
	6	May 15/2024		15	May 15/2024		11	May 15/2024
	7	May 15/2024		16	May 15/2024		12	May 15/2024
	8	May 15/2024		17	May 15/2024		13	May 15/2024
	9	May 15/2024		18	May 15/2024		14	May 15/2024
	10	May 15/2024		19	May 15/2024		15	May 15/2024
	11	May 15/2024		20	May 15/2024		16	May 15/2024
	12	May 15/2024		21	May 15/2024		17	May 15/2024
	13	May 15/2024		22	May 15/2024		18	May 15/2024
	14	May 15/2024		23	May 15/2024		19	May 15/2024
	15	May 15/2024		24	May 15/2024		20	May 15/2024
	16	May 15/2024		25	May 15/2024		21	May 15/2024
	17	May 15/2024		26	May 15/2024		22	May 15/2024
	18	May 15/2024		27	May 15/2024		23	May 15/2024
	19	May 15/2024		28	May 15/2024		24	May 15/2024
	20	May 15/2024		29	May 15/2024		25	May 15/2024
	21	May 15/2024		30	May 15/2024		26	May 15/2024
	22	May 15/2024		31	May 15/2024			
D43000	1	May 15/2024		32	May 15/2024	**D43200**	1	May 15/2024
	2	May 15/2024		33	May 15/2024		2	May 15/2024
	3	May 15/2024		34	May 15/2024		3	May 15/2024
	4	May 15/2024					4	May 15/2024
	5	May 15/2024	**D43100**	1	May 15/2024		5	May 15/2024
	6	May 15/2024		2	May 15/2024		6	May 15/2024
	7	May 15/2024		3	May 15/2024		7	May 15/2024
	8	May 15/2024		4	May 15/2024		8	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D43200 (cont)		
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D43300	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
D43300 (cont)		
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
D43300 (cont)		
	47	May 15/2024
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
	51	May 15/2024
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
	57	May 15/2024
	58	May 15/2024
	59	May 15/2024
	60	May 15/2024
	61	May 15/2024
	62	May 15/2024
	63	May 15/2024
	64	May 15/2024
D43400	1	May 15/2024
	2	May 15/2024
D43700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D43700 (cont)		
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
D43800	1	May 15/2024
	2	May 15/2024
D43900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	Dec 24/2024
	8	Dec 24/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
D44100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
D44300	1	May 15/2024
	2	May 15/2024
D44400	1	May 15/2024
D44500	1	May 15/2024
	2	May 15/2024
D44700	1	May 15/2024
	2	May 15/2024
D45000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
D45100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
D45100 (cont)		
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
D45200	1	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

EFFECTIVE PAGES

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D45200 (cont)		
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
D45200 (cont)		
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024
	44	May 15/2024
	45	May 15/2024
	46	May 15/2024
	47	May 15/2024
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
	51	May 15/2024
	52	May 15/2024
	53	May 15/2024
	54	May 15/2024
	55	May 15/2024
	56	May 15/2024
	57	May 15/2024
	58	May 15/2024
	59	May 15/2024
	60	May 15/2024
	61	May 15/2024
	62	May 15/2024
	63	May 15/2024
D45400	1	May 15/2024
	2	May 15/2024
D45500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
D45900	1	May 15/2024
D46000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D46000 (cont)			D46000 (cont)			D46100 (cont)		
	19	May 15/2024		50	May 15/2024		17	May 15/2024
	20	May 15/2024		51	May 15/2024		18	May 15/2024
	21	May 15/2024		52	May 15/2024		19	May 15/2024
	22	May 15/2024		53	May 15/2024		20	May 15/2024
	23	May 15/2024		54	May 15/2024		21	May 15/2024
	24	May 15/2024		55	May 15/2024		22	May 15/2024
	25	May 15/2024		56	May 15/2024		23	May 15/2024
	26	May 15/2024		57	May 15/2024		24	May 15/2024
	27	May 15/2024		58	May 15/2024		25	May 15/2024
	28	May 15/2024		59	May 15/2024		26	May 15/2024
	29	May 15/2024		60	May 15/2024		27	May 15/2024
	30	May 15/2024		61	May 15/2024		28	May 15/2024
	31	May 15/2024		62	May 15/2024		29	May 15/2024
	32	May 15/2024		63	May 15/2024		30	May 15/2024
	33	May 15/2024					31	May 15/2024
	34	May 15/2024	**D46100**	1	May 15/2024		32	May 15/2024
	35	May 15/2024		2	May 15/2024		33	May 15/2024
	36	May 15/2024		3	May 15/2024		34	May 15/2024
	37	May 15/2024		4	May 15/2024		35	May 15/2024
	38	May 15/2024		5	May 15/2024		36	May 15/2024
	39	May 15/2024		6	May 15/2024		37	May 15/2024
	40	May 15/2024		7	May 15/2024		38	May 15/2024
	41	May 15/2024		8	May 15/2024		39	May 15/2024
	42	May 15/2024		9	May 15/2024		40	May 15/2024
	43	May 15/2024		10	May 15/2024		41	May 15/2024
	44	May 15/2024		11	May 15/2024		42	May 15/2024
	45	May 15/2024		12	May 15/2024		43	May 15/2024
	46	May 15/2024		13	May 15/2024		44	May 15/2024
	47	May 15/2024		14	May 15/2024		45	May 15/2024
	48	May 15/2024		15	May 15/2024		46	May 15/2024
	49	May 15/2024		16	May 15/2024		47	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D46100 (cont)		
	48	May 15/2024
	49	May 15/2024
	50	May 15/2024
D46200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
D46400	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D46600	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
D47000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
D47100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
D47100 (cont)		
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
D47200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D47200 (cont)		
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
D47300	1	May 15/2024
D47500	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
D47700	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024

Section	Page	Date
D47700 (cont)		
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
D47800	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
	12	May 15/2024

Section	Page	Date
D47800 (cont)		
	13	May 15/2024
	14	May 15/2024
	15	May 15/2024
	16	May 15/2024
	17	May 15/2024
	18	May 15/2024
	19	May 15/2024
	20	May 15/2024
	21	May 15/2024
	22	May 15/2024
	23	May 15/2024
	24	May 15/2024
	25	May 15/2024
	26	May 15/2024
	27	May 15/2024
	28	May 15/2024
	29	May 15/2024
	30	May 15/2024
	31	May 15/2024
	32	May 15/2024
	33	May 15/2024
	34	May 15/2024
	35	May 15/2024
	36	May 15/2024
	37	May 15/2024
	38	May 15/2024
	39	May 15/2024
	40	May 15/2024
	41	May 15/2024
	42	May 15/2024
	43	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date	Section	Page	Date	Section	Page	Date
D47900	1	May 15/2024	D47900 (cont)			D48100 (cont)		
	2	May 15/2024		33	May 15/2024		19	May 15/2024
	3	May 15/2024		34	May 15/2024		20	May 15/2024
	4	May 15/2024		35	May 15/2024		21	May 15/2024
	5	May 15/2024		36	May 15/2024		22	May 15/2024
	6	May 15/2024		37	May 15/2024		23	May 15/2024
	7	May 15/2024		38	May 15/2024		24	May 15/2024
	8	May 15/2024		39	May 15/2024		25	May 15/2024
	9	May 15/2024		40	May 15/2024		26	May 15/2024
	10	May 15/2024		41	May 15/2024		27	May 15/2024
	11	May 15/2024		42	May 15/2024		28	May 15/2024
	12	May 15/2024		43	May 15/2024		29	May 15/2024
	13	May 15/2024						
	14	May 15/2024	**D48000**	1	May 15/2024	**D48200**	1	May 15/2024
	15	May 15/2024	**D48100**	1	May 15/2024		2	May 15/2024
	16	May 15/2024		2	May 15/2024		3	May 15/2024
	17	May 15/2024		3	May 15/2024		4	May 15/2024
	18	May 15/2024		4	May 15/2024		5	May 15/2024
	19	May 15/2024		5	May 15/2024		6	May 15/2024
	20	May 15/2024		6	May 15/2024		7	May 15/2024
	21	May 15/2024		7	May 15/2024	**D48500**	1	May 15/2024
	22	May 15/2024		8	May 15/2024		2	May 15/2024
	23	May 15/2024		9	May 15/2024	**D48800**	1	May 15/2024
	24	May 15/2024		10	May 15/2024		2	May 15/2024
	25	May 15/2024		11	May 15/2024			
	26	May 15/2024		12	May 15/2024	**D49000**	1	May 15/2024
	27	May 15/2024		13	May 15/2024		2	May 15/2024
	28	May 15/2024		14	May 15/2024		3	May 15/2024
	29	May 15/2024		15	May 15/2024		4	May 15/2024
	30	May 15/2024		16	May 15/2024		5	May 15/2024
	31	May 15/2024		17	May 15/2024		6	May 15/2024
	32	May 15/2024		18	May 15/2024		7	May 15/2024

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
D49000 (cont)		
	8	May 15/2024
	9	May 15/2024
	10	May 15/2024
	11	May 15/2024
D49900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
D70000	1	May 15/2024
D71100	1	May 15/2024
DA1700	1	Dec 24/2024
	2	Dec 24/2024
DM7700	1	May 15/2024
G00000	1	May 15/2024
GD0000	1	May 15/2024
L00000	1	May 15/2024
L00100	1	May 15/2024
L00200	1	May 15/2024
L00300	1	May 15/2024
	2	May 15/2024
L00400	1	May 15/2024
	2	May 15/2024
L01000	1	May 15/2024
L01100	1	May 15/2024
L01200	1	May 15/2024
L01300	1	May 15/2024
L01400	1	May 15/2024
L01500	1	May 15/2024
L03000	1	May 15/2024
M00000	1	May 15/2024
M00100	1	May 15/2024
M00200	1	May 15/2024
M00300	1	May 15/2024
M00500	1	May 15/2024
M01200	1	May 15/2024
M01400	1	May 15/2024
M01700	1	May 15/2024
M01900	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
	7	May 15/2024
M02100	1	May 15/2024
	2	May 15/2024
M02200	1	May 15/2024
M02500	1	May 15/2024
	2	May 15/2024
M03000	1	May 15/2024
	2	May 15/2024
M03200	1	May 15/2024
R00000	1	May 15/2024
	2	May 15/2024
R00300	1	May 15/2024
R00400	1	May 15/2024
R00600	1	May 15/2024
R00900	1	May 15/2024
	2	May 15/2024
R01100	1	May 15/2024
R01200	1	May 15/2024
S00000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
	6	May 15/2024
S00100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Section	Page	Date
S00200	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
S00300	1	May 15/2024
S00500	1	May 15/2024
S00600	1	Dec 24/2024
S00700	1	May 15/2024
S00800	1	May 15/2024
	2	May 15/2024
S00900	1	May 15/2024
	2	May 15/2024
S01000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
S01100	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
S01200	1	May 15/2024
	2	May 15/2024
T00000	1	May 15/2024
	2	May 15/2024
T00300	1	May 15/2024
T00400	1	May 15/2024
T03000	1	May 15/2024
TB0000	1	May 15/2024
	2	May 15/2024
	3	May 15/2024
	4	May 15/2024
	5	May 15/2024
TB0200	1	May 15/2024
TB0400	1	May 15/2024
TB0500	1	May 15/2024
TB0600	1	May 15/2024
	2	May 15/2024
TB0900	1	May 15/2024
TB1100	1	May 15/2024
TB1300	1	May 15/2024
TB1400	1	May 15/2024
TB2100	1	May 15/2024
TB2200	1	May 15/2024
TB3100	1	May 15/2024
TB4100	1	May 15/2024
	2	May 15/2024
TB4200	1	May 15/2024
TB4600	1	May 15/2024

Section	Page	Date

A = Added, R = Revised, D = Deleted, O = Overflow

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
A00006		**190/246/L002**		**WINDSHIELD-LEFT 1**				**ALL**
	3	E	W2108	1001	18		30-41-11	ALL
	3	E	W2108	1002	18		30-41-11	ALL
	4	E	W2108	1002	18		30-41-11	ALL
	=A	C	W2108	2003B	20		30-41-11	ALL
	=B	C	W2108	2003R	20		30-41-11	ALL
	=C	C	W2108	2002R	20		30-41-11	ALL
	=D	C	W2108	2002B	20		30-41-11	ALL
			W2108	1001Z			30-41-11	ALL
			W2108	2002Z			30-41-11	ALL
			W2108	2003Z			30-41-11	ALL
			W2108	FRAC			30-41-11	ALL
A00009		**207/240/R032**		**WINDOW-RIGHT 2**				**ALL**
	=A	E	W2012	1001	20		30-41-11	ALL
	=B	E	W2012	5501	20		30-41-11	ALL
	=C	C	W2012	5503	20		30-41-11	ALL
	=D	C	W2012	5502	20		30-41-11	ALL
	CAP	Y	W2012	5504	20		30-41-11	ALL
A00010		**190/246/R001**		**WINDOW-RIGHT 1**				**ALL**
	3	E	W2208	1001	18		30-41-12	ALL
	3	E	W2208	1002	18		30-41-12	ALL
	4	E	W2208	1001	18		30-41-12	ALL
	=A	C	W2208	2003B	20		30-41-12	ALL
	=B	C	W2208	2003R	20		30-41-12	ALL
	=C	C	W2208	2002R	20		30-41-12	ALL
	=D	C	W2208	2002B	20		30-41-12	ALL
			W2208	1002Z			30-41-12	ALL
			W2208	2002Z			30-41-12	ALL
			W2208	2003Z			30-41-12	ALL
			W2208	FRAC			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
A00013		**207/245/L032**		**WINDOW-LEFT 2**				**ALL**
	=A	E	W2004	1001	20		30-41-12	ALL
	=B	E	W2004	5501	20		30-41-12	ALL
	=C	C	W2004	5502	20		30-41-12	ALL
	=D	C	W2004	5503	20		30-41-12	ALL
	CAP	Y	W2004	5504	20		30-41-12	ALL
A00021		**245/247/L030**		**WINDOW-LEFT 3**				**ALL**
	=A	E	W2102	5525	20		30-41-11	ALL
	=B	E	W2102	5526	20		30-41-11	ALL
A00022		**254/258/R040**		**WINDOW-RIGHT 3**				**ALL**
	=A	E	W2204	5537	20		30-41-12	ALL
	=B	E	W2204	5538	20		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00023		**P006-04/ /F016**		**CB-DC BUS INDICATION BUS 1**				**ALL**
	=B	D	W0040	6071	10		24-61-22	ALL
	=B	D	W0040	6345	12		24-61-22	ALL
	=L	D	W0044	0034	24		24-33-11	ALL
	=L	D	W0044	0584	24		24-33-13	ALL
C00026		**P006-04/ /F014**		**CB-DC BUS INDICATION BAT**				**ALL**
	=B	D	W0040	6209	18		24-61-32	ALL
	=L	D	W0044	0032	24		24-33-11	ALL
	=L	D	W0044	0585	24		24-33-13	ALL
C00032		**P006-03/ /A003**		**CB-FUEL FUELING CONT**				**ALL**
	=B	D	W0040	ZZDM	02		24-61-51	ALL
	=L	D	W0044	0297	18		28-44-11	ALL
C00033		**P006-04/ /A014**		**CB-AUX POWER UNIT CONT**				**ALL**
	=B	D	W0040	6155	16		24-61-52	ALL
	=L	D	W0044	0500	20		49-62-11	ALL
	=L	D	W0044	0703	10		49-62-11	ALL
	=L	D	W0044	0704	20		49-62-11	ALL
C00054		**P018-03/ /B003**		**CB-ANTI-ICE & RAIN WSHLD WIPER LEFT**				**ALL**
	=B	D	W0020	6048	14		24-61-21	ALL
	=B	D	W0020	6305	14		24-61-21	ALL
	=L	D	W0018	0707	10		30-42-11	ALL
	=L	D	W0018	0727	18		30-42-11	ALL
C00055		**P018-03/ /B001**		**CB-ANTI-ICE & RAIN WSHLD WIPER RIGHT**				**ALL**
	=B	D	W0020	ZZXZ	02		24-61-23	ALL
	=L	D	W0018	0706	10		30-42-11	ALL
	=L	D	W0018	0728	18		30-42-11	ALL
C00058		**P018-02/ /D015**		**CB-COMMUNICATIONS SELCAL**				**ALL**
	=B	D	W0020	6043	14		24-61-21	ALL
	=B	D	W0020	6096	14		24-61-21	ALL
	=L	D	W0018	0033	22		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00072		**P006-04/ /D016**		**CB-AC BUS STBY BUS 115V AC IND**				**ALL**
	=B	D	W0040	ZZDX	02		24-54-11	ALL
	=L	D	W0044	0013	22		24-28-11	ALL
C00073		**P018-03/ /A009**		**CB-PASSENGER CABIN CREW CALL**				**ALL**
	=B	D	W0020	ZZEF	00		24-61-21	ALL
	=B	D	W0020	ZZEG	00		24-61-21	ALL
	=L	D	W0018	0035	22		23-42-11	ALL
C00076		**P006-04/ /D008**		**CB-AIR CONDITIONING TEMP IND**				**ALL**
	=B	D	W0040	6022	14		24-61-24	ALL
	=B	D	W0040	6348	12		24-61-24	ALL
	=L	D	W0044	0474	20		21-61-51	ALL
C00077		**P006-04/ /B005**		**CB-AIR CONDITIONING BLEED AIR PRESS IND**				**ALL**
	=B	D	W0040	6011	14		24-51-24	ALL
	=B	D	W0040	6163	14		24-51-24	ALL
	=L	D	W0044	0484	24		36-21-11	ALL
C00080		**P006-01/ /C009**		**CB-ENTERTAINMENT PA TAPE RPDR AC**				**ALL**
	=B	D	W0040	6115	14		24-51-24	ALL
	=B	D	W0040	6148	14		24-51-24	ALL
	=L	D	W0044	0349	22		23-31-06	ALL
C00082		**P006-01/ /D004**		**CB-COMMUNICATIONS PA AMPL BAT**				**ALL**
	=B	D	W0040	6003	16		24-61-32	ALL
	=B	D	W0040	6299	18		24-61-32	ALL
	=L	D	W0044	0348	18		23-31-01	ALL
C00083		**P006-02/ /D023**		**CB-AUDIO CAPT**				**ALL**
	=B	D	W0044	6004	20		23-51-51	ALL
	=B	D	W0044	A-AE			23-51-51	ALL
	=L	D	W0044	0503	22		23-51-51	ALL
C00084		**P006-02/ /D021**		**CB-INTPH AND WARN**				**ALL**
	=B	D	W0044	6005	20		23-51-51	ALL
	=B	D	W0044	D-AA			23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00084		**P006-02/ /D021**		**CB-INTPH AND WARN (continued)**				**ALL**
	=L	D	W0044	0505	22		23-51-51	ALL
C00085		**P006-02/ /D024**		**CB-AUDIO OBS**				**ALL**
	=B	D	W0044	6004	20		23-51-51	ALL
	=B	D	W0044	C-AA			23-51-51	ALL
	=L	D	W0044	0502	22		23-51-51	ALL
C00086		**P006-02/ /D022**		**CB-AUDIO F/O**				**ALL**
	=B	D	W0044	6005	20		23-51-51	ALL
	=B	D	W0044	B-AA			23-51-51	ALL
	=L	D	W0044	0504	22		23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00104		**P018-03/ /F013**		**CB-LAVATORY WATER HEATER A**				**ALL**
	=B	D	W0020	6080	12		24-51-12	ALL
	=B	D	W0020	ZZAL	00		24-51-12	ALL
	=B	D	W0020	ZZDK	03		24-51-12	ALL
	=L	D	W0018	0361	22		38-21-11	ALL
C00107		**P018-02/ /D007**		**CB-VOICE RCDR**				**ALL**
	=B	D	W0020	6019	16		24-51-23	ALL
	=L	D	W0018	0074	22		23-71-01	ALL
	=L	D	W0018	0076	22		23-71-01	ALL
C00109		**P018-02/ /C009**		**CB-FLIGHT RECORDER AC**				**ALL**
	=B	D	W0020	6118	16		24-51-13	ALL
	=B	D	W0020	6298	16		24-51-13	ALL
	=L	D	W0018	0741	22		31-31-11	ALL
	=L	D	W0018	0742	22		31-31-11	ALL
C00110		**P018-03/ /A014**		**CB-EXTERIOR LIGHTING WING SCAN**				**ALL**
	=B	D	W0020	6065	18		24-52-11	ALL
	=L	D	W0018	0331	18		33-41-11	ALL
C00111		**P018-03/ /B012**		**CB-EXTERIOR LIGHTING ANTI COLLISION RED**				**ALL**
	=B	D	W0020	6012	16		24-51-13	ALL
	=L	D	W0018	0338	20		33-44-11	ALL
C00117		**P006-03/ /F001**		**CB-28V DC SERVICE OUTLETS**				**ALL**
	=B	D	W0040	6104	10		24-61-22	ALL
	=B	D	W0040	6325	10		24-61-22	ALL
	=L	D	W0044	0251	20		25-29-11	ALL
C00120		**P006-01/ /D013**		**CB-WEATHER RADAR RT**				**ALL**
	=B	D	W0040	6147	10		24-51-24	ALL
	=B	D	W0040	ZZXG	02		24-51-24	ALL
	=L	D	W0044	0756	20		34-41-11	ALL
C00129		**P006-03/ /B017**		**CB-LANDING GEAR LATCH & PRESS WARN**				**ALL**
	=B	D	W0040	ZZYH	02		24-61-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00129		**P006-03/ /B017**		**CB-LANDING GEAR LATCH & PRESS WARN (continued)**				**ALL**
	=L	D	W0044	0257	24		32-31-11	ALL
	=L	D	W0044	0459	22		21-33-11	ALL
C00131		**P006-03/ /B013**		**CB-MASTER CAUTION ANNUNCIATOR BAT**				**ALL**
	=B	D	W0040	ZZYF	02		24-61-33	ALL
	=B	D	W0040	ZZYG	02		24-61-33	ALL
	=L	D	W0044	0053	20		31-52-11	ALL
C00132		**P006-03/ /B012**		**CB-MASTER CAUTION ANNUNCIATOR BUS 1**				**ALL**
	=B	D	W0040	6002	14		24-61-22	ALL
	=B	D	W0040	6068	14		24-61-22	ALL
	=L	D	W0044	0054	20		31-52-11	ALL
C00133		**P006-03/ /D011**		**CB-INDICATOR MASTER DIM DIM/TST CONT**				**ALL**
	=B	D	W0040	6056	12		24-61-33	ALL
	=B	D	W0040	6065	12		24-61-33	ALL
	=B	D	W0040	ZZBI	02		24-61-33	ALL
	=L	D	W0044	0104	20		33-18-11	ALL
	=L	D	W0044	0185	20		33-18-37	ALL
C00134		**P006-04/ /E015**		**CB-DC BUS INDICATION HOT BAT**				**ALL**
	=B	D	W0040	ZZYR	02		24-61-51	ALL
	=L	D	W0044	0033	24		24-33-11	ALL
	=L	D	W0044	0586	24		24-33-13	ALL
C00136		**P006-04/ /E018**		**CB-DC BUS INDICATION STBY**				**ALL**
	=B	D	W0040	6087	16		24-61-42	ALL
	=B	D	W0040	6208	16		24-61-42	ALL
	=L	D	W0044	0512	24		24-33-11	ALL
	=L	D	W0044	0588	24		24-33-13	ALL
C00137		**P006-03/ /E001**		**CB-DOOR LOCK**				**ALL**
	=B	D	W0040	6077	14		24-61-24	ALL
	=B	D	W0040	6281	12		24-61-24	ALL
	=L	D	W0044	0900	22		52-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00142		**J009-00/ /A004**		**CB-BATTERY CHARGER**				**ALL**
	=B	CK	W2532	0537	*1		24-31-11	ALL
	=L	F	W2532	0538	02		24-31-11	ALL
C00148		**P018-03/ /A006**		**CB-ANTI-ICE & RAIN ENG 1 & WING CONT**				**ALL**
	=B	D	W0020	6039	18		24-61-31	ALL
	=L	D	W0018	0712	20		30-21-31	ALL
C00151		**P006-02/ /D006**		**CB-ENGINE 2 IGNITION LEFT**				**ALL**
	=B	D	W0040	ZZDV	02		24-51-24	ALL
	=L	D	W0044	0418	20		74-11-11	ALL
C00153		**P018-02/ /A003**		**CB-ENGINE 1 IGNITION LEFT**				**ALL**
	=B	D	W0020	ZZCQ	02		24-51-13	ALL
	=L	D	W0018	0853	20		74-11-11	ALL
C00154		**P006-02/ /C004**		**CB-ENGINE 2 START VALVE**				**ALL**
	=B	D	W0040	ZZAY	00		24-61-32	ALL
	=B	D	W0040	ZZAZ	00		24-61-32	ALL
	=L	D	W0044	0428	20		80-11-11	ALL
C00155		**P006-04/ /E009**		**CB-ENTRY LIGHTS DIM**				**ALL**
	=B	D	W0040	6090	12		24-61-51	ALL
	=B	D	W0040	6092	14		24-61-51	ALL
	=L	D	W0044	0327	24		33-29-11	ALL
C00156		**P018-03/ /F007**		**CB-OXYGEN IND**				**ALL**
	=B	D	W0020	ZZAX	04		24-61-31	ALL
	=B	D	W0020	ZZBA	00		24-61-31	ALL
	=L	D	W0018	0350	22		35-11-11	ALL
	=L	D	W0018	0354	22		35-21-11	ALL
C00161		**P006-03/ /A014**		**CB-CONTROL CABIN LIGHTING STBY COMPASS**				**ALL**
	=B	D	W0040	6058	18		24-61-33	ALL
	=B	D	W0040	ZZBP	02		24-61-33	ALL
	=B	D	W0040	ZZYG	02		24-61-33	ALL
	=L	D	W0044	0097	20		33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00165		**P018-02/ /D011**		**CB-COMMUNICATIONS VHF 1**				**ALL**
	=B	D	W0020	6163	12		24-61-41	ALL
	=B	D	W0020	6164	16		24-61-41	ALL
	=L	D	W0018	0029	16		23-12-11	ALL
C00166		**P006-01/ /C003**		**CB-COMMUNICATIONS VHF 2**				**ALL**
	=B	D	W0040	6253	10		24-61-24	ALL
	=B	D	W0040	ZZYL	02		24-61-24	ALL
	=L	D	W0044	0247	16		23-12-21	ALL
C00170		**P018-02/ /E003**		**CB-MACH WARN SYS-1**				**ALL**
	=B	D	W0020	ZZBV	00		24-61-41	ALL
	=B	D	W0020	ZZCL	00		24-61-41	ALL
	=L	D	W0018	0801	22		34-16-11	ALL
C00186		**P018-01/ /B005**		**CB-ATC 1**				**ALL**
	=B	D	W0020	ZZXJ	02		24-54-11	ALL
	=B	D	W0020	ZZYF	02		24-54-11	ALL
	=L	D	W0018	0815	20		34-53-11	ALL
C00188		**P006-01/ /D014**		**CB-ATC 2**				**ALL**
	=B	D	W0040	6149	14		24-51-24	ALL
	=L	D	W0044	0279	20		34-53-21	ALL
C00190		**P018-01/ /B003**		**CB-RADIO NAVIGATION DME 1**				**ALL**
	=B	D	W0020	ZZXJ	02		24-54-11	ALL
	=L	D	W0018	0063	22		34-55-11	ALL
C00192		**P006-01/ /A014**		**CB-RADIO NAVIGATION DME 2**				**ALL**
	=B	D	W0040	6115	14		24-51-24	ALL
	=L	D	W0044	0281	22		34-55-21	ALL
C00195		**P006-03/ /E018**		**CB-LANDING GEAR ANTISKID OUTBD**				**ALL**
	=B	D	W0040	6066	16		24-61-22	ALL
	=B	D	W0040	ZZYI	02		24-61-22	ALL
	=L	D	W0044	0513	24		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00196		**P006-03/ /E016**		**CB-LANDING GEAR ANTISKID INBD**				**ALL**
	=B	D	W0040	6057	12		24-61-33	ALL
	=B	D	W0040	ZZYD	02		24-61-33	ALL
	=L	D	W0044	0514	24		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00204		**P006-02/ /B012**		**CB-FLIGHT CONTROL SHUTOFF VALVES SPOILER**				**ALL**
	=B	D	W0040	ZZDA	00		24-61-24	ALL
	=B	D	W0040	ZZDD	00		24-61-24	ALL
	=L	D	W0044	0235	20		27-61-43	ALL
C00207		**P006-02/ /B010**		**CB-FLIGHT CONTROL STAB TRIM CONT**				**ALL**
	=B	D	W0040	6499	08		24-61-24	ALL
	=B	D	W0040	ZZDB	00		24-61-24	ALL
	=B	D	W0040	ZZDE	00		24-61-24	ALL
	=L	D	W0044	0229	20		27-41-11	ALL
C00210		**P006-02/ /A007**		**CB-FLIGHT CONTROL FLAP SHUTOFF VALVES**				**ALL**
	=B	D	W0040	ZZCL	00		24-61-22	ALL
	=B	D	W0040	ZZCM	00		24-61-22	ALL
	=L	D	W0044	0230	20		27-53-11	ALL
	=L	D	W0044	0592	20		27-81-51	ALL
C00211		**P006-02/ /A008**		**CB-FLIGHT CONTROL FSEU DC 1**				**ALL**
	=B	D	W0040	6127	10		24-61-22	ALL
	=B	D	W0040	ZZCK	03		24-61-22	ALL
	=B	D	W0040	ZZCL	00		24-61-22	ALL
	=B	D	W0040	ZZYS	02		24-61-22	ALL
	=L	D	W0044	0291	22		27-81-11	ALL
C00213		**P006-02/ /A012**		**CB-FC TE FLAP POS/SKEW SNSR & IND LEFT**				**ALL**
	=B	D	W0040	6108	16		24-53-11	ALL
	=B	D	W0040	ZZAJ	02		24-53-11	ALL
	=L	D	W0044	0288	24		27-52-11	ALL
C00219		**P006-03/ /C009**		**CB-PANEL & INSTR CB PANEL**				**ALL**
	=B	D	W0040	ZZAL	02		24-53-11	ALL
	=B	D	W0040	ZZXW	02		24-53-11	ALL
	=L	D	W0044	0095	18		33-14-12	ALL
C00228		**P006-05/ /B021**		**CB-WINDOW HEAT POWER LEFT FRONT**				**ALL**
	=B	M	W0040	0009	08		24-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00228		**P006-05/ /B021**		**CB-WINDOW HEAT POWER LEFT FRONT (continued)**				**ALL**
	=B	M	W0040	6575	14		24-51-14	ALL
	=L	M	W0044	0491	12		30-41-11	ALL
C00233		**P018-03/ /E005**		**CB-HEATERS DRAIN**				**ALL**
	=B	D	W0020	ZZAM	02		24-51-12	ALL
	=L	D	W0018	0731	20		30-71-11	ALL
C00234		**P018-03/ /E003**		**CB-HEATERS DRAIN MAST GND**				**ALL**
	=B	D	W0020	6029	14		24-53-11	ALL
	=L	D	W0018	0045	20		30-71-11	ALL
C00236		**P018-03/ /C004**		**CB-HEATERS ELEV PITOT LEFT**				**ALL**
	=B	D	W0020	ZZAJ	00		24-51-13	ALL
	=B	D	W0020	ZZAK	00		24-51-13	ALL
	=L	D	W0018	0111	22		30-31-11	ALL
	=L	D	W0018	0157	22		30-31-11	ALL
	=L	D	W0018	0715	22		30-31-11	ALL
C00237		**P018-03/ /D004**		**CB-HEATERS ELEV PITOT RIGHT**				**ALL**
	=B	D	W0020	ZZAQ	02		24-51-23	ALL
	=L	D	W0018	0119	22		30-31-12	ALL
	=L	D	W0018	0165	22		30-31-12	ALL
	=L	D	W0018	0719	22		30-31-12	ALL
C00238		**P018-03/ /C002**		**CB-HEATERS TEMP PROBE**				**ALL**
	=B	D	W0020	6008	16		24-51-13	ALL
	=B	D	W0020	6012	16		24-51-13	ALL
	=L	D	W0018	0155	22		30-31-11	ALL
	=L	D	W0018	0716	22		30-31-11	ALL
C00239		**P006-02/ /C023**		**CB-INTERPHONE POWER CAPT DC 2**				**ALL**
	=B	D	W0040	6501	14		24-61-24	ALL
	=L	D	W0044	A-BE			23-51-51	ALL
C00240		**P006-02/ /C024**		**CB-INTERPHONE POWER CAPT BAT**				**ALL**
	=B	D	W0040	ZZYB	02		24-61-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00240	**P006-02/ /C024**		**CB-INTERPHONE POWER CAPT BAT (continued)**				**ALL**
=L	D	W0044	C-BA			23-51-51	ALL
C00250	**P018-03/ /A011**		**CB-PASS CABIN LIGHTING EMER CHGR FWD**				**ALL**
=B	D	W0020	6047	14		24-61-21	ALL
=B	D	W0020	6262	10		24-61-21	ALL
=B	D	W0020	ZZBL	05		24-61-21	ALL
=B	D	W0020	ZZED	00		24-61-21	ALL
=L	D	W0018	0344	20		33-51-11	ALL
C00259	**P006-04/ /A005**		**CB-AIR CONDITIONING BLEED AIR VALVE ISLN**				**ALL**
=B	D	W0040	0007	14		24-51-14	ALL
=L	D	W0044	0483	24		36-11-31	ALL
C00262	**P006-04/ /C006**		**CB-AIR CONDITIONING PACK CONT VALVES L**				**ALL**
=B	D	W0040	ZZCB	00		24-61-32	ALL
=B	D	W0040	ZZEI	00		24-61-32	ALL
=L	D	W0044	0461	24		21-51-11	ALL
C00263	**P006-04/ /C005**		**CB-AIR CONDITIONING PACK CONT VALVES R**				**ALL**
=B	D	W0040	ZZCB	00		24-61-32	ALL
=B	D	W0040	ZZEH	00		24-61-32	ALL
=L	D	W0044	0466	24		21-51-21	ALL
C00276	**P018-02/ /B005**		**CB-ENGINE 1 THRUST REVERSER CONT**				**ALL**
=B	D	W0020	ZZCA	03		24-61-41	ALL
=B	D	W0020	ZZCD	00		24-61-41	ALL
=L	D	W0018	0860	20		78-34-11	ALL
C00277	**P006-02/ /C007**		**CB-ENGINE 2 THRUST REVERSER CONT**				**ALL**
=B	D	W0040	6054	12		24-61-32	ALL
=B	D	W0040	ZZAV	05		24-61-32	ALL
=B	D	W0040	ZZAW	00		24-61-32	ALL
=B	D	W0040	ZZYZ	02		24-61-32	ALL
=L	D	W0044	0425	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00282		**P006-03/ /A015**		**CB-CONTROL CABIN LIGHTING DOME WHITE**				**ALL**
	=B	D	W0040	ZZBP	02		24-61-33	ALL
	=B	D	W0040	ZZYH	02		24-61-33	ALL
	=L	D	W0044	0092	20		33-14-12	ALL
C00283		**P006-03/ /A008**		**CB-CONTROL CABIN LIGHTING CONT STAND**				**ALL**
	=B	D	W0040	ZZAN	00		24-53-11	ALL
	=B	D	W0040	ZZAO	00		24-53-11	ALL
	=L	D	W0044	0090	18		33-14-12	ALL
C00284		**P006-03/ /C010**		**CB-PANEL & INSTR ELEX PANEL**				**ALL**
	=B	D	W0040	ZZAL	02		24-53-11	ALL
	=B	D	W0040	ZZXX	02		24-53-11	ALL
	=L	D	W0044	0069	16		33-11-33	ALL
C00285		**P018-01/ /C007**		**CB-YAW DAMPER AC**				**ALL**
	=B	D	W0020	6027	14		24-53-11	ALL
	=L	D	W0018	0021	20		22-23-12	ALL
C00286		**P018-01/ /D007**		**CB-YAW DAMPER 1 DC**				**ALL**
	=B	D	W0020	6040	08		24-61-21	ALL
	=B	D	W0020	ZZBB	06		24-61-21	ALL
	=B	D	W0020	ZZBC	00		24-61-21	ALL
	=L	D	W0018	0019	20		22-23-11	ALL
C00296		**P006-02/ /B022**		**CB-FIRE PROTECTION EXTINGUISHERS LEFT**				**ALL**
	=B	D	W0040	ZZDS	00		24-61-51	ALL
	=B	D	W0040	ZZDT	00		24-61-51	ALL
	=L	D	W0044	1009R	22		26-21-11	ALL
C00297		**P006-02/ /B020**		**CB-FIRE PROTECTION EXTINGUISHERS RIGHT**				**ALL**
	=B	D	W0040	6088	12		24-61-51	ALL
	=B	D	W0040	ZZDQ	05		24-61-51	ALL
	=B	D	W0040	ZZDR	00		24-61-51	ALL
	=L	D	W0044	1006R	22		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00306		**P006-02/ /A013**		**CB-HYDRAULIC SYSTEM BRAKE PRESS IND**				**ALL**
	=B	D	W0040	6107	18		24-61-32	ALL
	=L	D	W0044	0538	22		29-32-11	ALL
C00308		**P006-03/ /A009**		**CB-CONTROL CABIN LIGHTING MAP & KIT**				**ALL**
	=B	D	W0040	ZZAO	00		24-53-11	ALL
	=B	D	W0040	ZZAR	00		24-53-11	ALL
	=L	D	W0044	0098	20		33-17-11	ALL
C00309		**P006-03/ /A010**		**CB-CONTROL CABIN LIGHTING OBS READING**				**ALL**
	=B	D	W0040	ZZAM	04		24-53-11	ALL
	=B	D	W0040	ZZAR	00		24-53-11	ALL
	=B	D	W0040	ZZXY	02		24-53-11	ALL
	=L	D	W0044	0101	20		33-17-11	ALL
	=L	D	W0044	0102	20		33-17-11	ALL
C00310		**P006-03/ /D012**		**CB-INDICATOR MASTER DIM BAT**				**ALL**
	=B	D	W0040	6057	12		24-61-33	ALL
	=B	D	W0040	ZZBI	02		24-61-33	ALL
	=L	D	W0044	0130	20		33-18-11	ALL
C00311		**P006-03/ /D013**		**CB-INDICATOR MASTER DIM BUS 1**				**ALL**
	=B	D	W0040	6066	16		24-61-22	ALL
	=B	D	W0040	6067	16		24-61-22	ALL
	=L	D	W0044	0129	20		33-18-11	ALL
C00312		**P006-03/ /D014**		**CB-INDICATOR MASTER DIM BUS 2**				**ALL**
	=B	D	W0040	6077	14		24-61-24	ALL
	=B	D	W0040	ZZCO	02		24-61-24	ALL
	=L	D	W0044	0128	20		33-18-11	ALL
C00313		**P006-03/ /E011**		**CB-INDICATOR MASTER DIM SECT 1**				**ALL**
	=B	D	W0044	0131	20		33-18-11	ALL
	=B	D	W0044	0136	20		33-18-11	ALL
	=L	D	W0044	0172	20		33-18-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00314		**P006-03/ /E012**		**CB-INDICATOR MASTER DIM SECT 2**				**ALL**
	=B	D	W0044	0131	20		33-18-11	ALL
	=L	D	W0044	0152	20		33-18-21	ALL
C00315		**P006-03/ /E013**		**CB-INDICATOR MASTER DIM SECT 3**				**ALL**
	=B	D	W0044	0132	20		33-18-11	ALL
	=B	D	W0044	0135	20		33-18-11	ALL
	=L	D	W0044	0190	20		33-18-61	ALL
	=L	D	W0044	6239	20		33-18-37	ALL
C00316		**P006-03/ /E014**		**CB-INDICATOR MASTER DIM SECT 4**				**ALL**
	=B	D	W0044	0132	20		33-18-11	ALL
	=L	D	W0044	0169	20		33-18-31	ALL
C00317		**P006-03/ /F011**		**CB-INDICATOR MASTER DIM SECT 5**				**ALL**
	=B	D	W0044	0133	20		33-18-11	ALL
	=B	D	W0044	0134	20		33-18-11	ALL
	=L	D	W0044	0167	20		33-18-24	ALL
C00318		**P006-03/ /F012**		**CB-INDICATOR MASTER DIM SECT 6**				**ALL**
	=B	D	W0044	0133	20		33-18-11	ALL
	=L	D	W0044	0164	20		33-18-22	ALL
C00323		**P006-03/ /D009**		**CB-OVERHEAD 28V PRI**				**ALL**
	=B	D	W0040	6042	10		24-53-11	ALL
	=B	D	W0040	ZZXW	02		24-53-11	ALL
	=L	D	W0044	0071	18		33-12-11	ALL
C00325		**P006-03/ /D010**		**CB-OVERHEAD 28V SEC**				**ALL**
	=B	D	W0044	0072	10		33-12-11	ALL
	=L	D	W0044	0073	10		33-12-11	ALL
	=L	D	W0044	0083	10		33-12-12	ALL
C00326		**P006-03/ /E008**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0079	16		33-12-11	ALL
	=L	D	W0044	0076	18		33-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00327		**P006-03/ /F008**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0085	16		33-12-12	ALL
	=L	D	W0044	0086	18		33-12-12	ALL
C00328		**P006-03/ /E010**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0075	16		33-12-11	ALL
	=B	D	W0044	0078	16		33-12-11	ALL
	=L	D	W0044	0070	18		33-12-11	ALL
C00329		**P006-03/ /E009**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0078	16		33-12-11	ALL
	=B	D	W0044	0079	16		33-12-11	ALL
	=L	D	W0044	0077	18		33-12-11	ALL
C00330		**P006-03/ /F009**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0080	16		33-12-12	ALL
	=B	D	W0044	0081	16		33-12-12	ALL
	=L	D	W0044	0082	18		33-12-12	ALL
C00331		**P006-03/ /B009**		**CB-PANEL & INSTR 28V PRI CAPT & CTR**				**ALL**
	=B	D	W0040	6039	14		24-53-11	ALL
	=L	D	W0044	0064	16		33-11-11	ALL
C00335		**P006-03/ /B010**		**CB-PANEL & INSTR 28V PRI F/O**				**ALL**
	=B	D	W0040	ZZXX	02		24-53-11	ALL
	=B	D	W0040	ZZXY	02		24-53-11	ALL
	=L	D	W0044	0065	16		33-11-21	ALL
C00347		**P006-02/ /C019**		**CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 1**				**ALL**
	=B	D	W0040	6055	14		24-61-32	ALL
	=B	D	W0040	ZZAT	02		24-61-32	ALL
	=B	D	W0040	ZZYA	02		24-61-32	ALL
	=L	D	W0044	0240	20		29-11-11	ALL
C00348		**P006-02/ /C018**		**CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 2**				**ALL**
	=B	D	W0040	6050	12		24-61-32	ALL
	=B	D	W0040	6053	12		24-61-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00348		**P006-02/ /C018**		**CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 2 (continued)**				**ALL**
	=B	D	W0040	ZZAT	02		24-61-32	ALL
	=L	D	W0044	0241	20		29-11-11	ALL
C00355		**P006-03/ /A007**		**CB-FUEL TEMP IND**				**ALL**
	=B	D	W0040	ZZAM	04		24-53-11	ALL
	=B	D	W0040	ZZAN	00		24-53-11	ALL
	=L	D	W0044	0296	22		28-42-11	ALL
C00359		**P006-03/ /B004**		**CB-FUEL SPAR VALVE ENG 1**				**ALL**
	=B	D	W0044	6002	20		28-21-21	ALL
	=B	D	W0044	6003	20		28-21-21	ALL
	=L	D	W0044	0292	20		28-21-11	ALL
C00360		**P006-03/ /B003**		**CB-FUEL SPAR VALVE ENG 2**				**ALL**
	=B	D	W0044	6001	20		28-21-21	ALL
	=B	D	W0044	6003	20		28-21-21	ALL
	=L	D	W0044	0294	20		28-21-11	ALL
C00361		**P006-03/ /B007**		**CB-FUEL CROSS FEED VALVE CONT**				**ALL**
	=B	D	W0040	6124	18		24-61-33	ALL
	=B	D	W0040	ZZBY	02		24-61-33	ALL
	=L	D	W0044	0295	20		28-22-11	ALL
C00362		**P006-02/ /C011**		**CB-FLIGHT CONT SHUTOFF VALVES STBY RUD**				**ALL**
	=B	D	W0040	6053	12		24-61-32	ALL
	=B	D	W0040	6054	12		24-61-32	ALL
	=B	D	W0040	6107	18		24-61-32	ALL
	=L	D	W0044	0226	20		27-23-11	ALL
C00363		**P006-02/ /B013**		**CB-FLIGHT CONT SHUTOFF VALVES FLT CONT**				**ALL**
	=B	D	W0040	ZZDC	00		24-61-24	ALL
	=B	D	W0040	ZZDD	00		24-61-24	ALL
	=L	D	W0044	0227	20		27-23-11	ALL
C00374		**P006-02/ /B001**		**CB-AFCS SYS B WARN LIGHT (BAT)**				**ALL**
	=B	D	W0040	6094	16		24-61-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00374		**P006-02/ /B001**		**CB-AFCS SYS B WARN LIGHT (BAT) (continued)**				**ALL**
	=L	D	W0044	0506	20		22-14-11	ALL
C00388		**P006-02/ /A019**		**CB-FIRE PROTECTION DET OVHT WW WING BODY**				**ALL**
	=B	D	W0040	6128	14		24-51-24	ALL
	=L	D	W0044	0286R	22		26-12-11	ALL
C00390		**P006-03/ /F010**		**CB-OVERHEAD 5V SECONDARY**				**ALL**
	=B	D	W0044	0080	16		33-12-12	ALL
	=B	D	W0044	0085	16		33-12-12	ALL
	=L	D	W0044	0087	18		33-12-12	ALL
C00392		**P006-05/ /B009**		**CB-WINDOW HEAT POWER LEFT SIDE**				**ALL**
	=B	M	W0040	6120	12		24-51-24	ALL
	=B	M	W0040	6578	14		24-51-24	ALL
	=L	M	W0044	0495	14		30-41-12	ALL
C00393		**P006-05/ /B020**		**CB-WINDOW HEAT POWER RIGHT SIDE**				**ALL**
	=B	M	W0040	0010	10		24-51-14	ALL
	=B	M	W0040	6544	14		24-51-14	ALL
	=L	M	W0044	0492	14		30-41-11	ALL
C00394		**P006-05/ /B008**		**CB-WINDOW HEAT POWER RIGHT FRONT**				**ALL**
	=B	M	W0040	6119	08		24-51-24	ALL
	=B	M	W0040	6579	14		24-51-24	ALL
	=L	M	W0044	0494	12		30-41-12	ALL
C00396		**P006-02/ /A021**		**CB-FIRE PROT DETECTION MA WRN & CONT**				**ALL**
	=B	D	W0040	6055	14		24-61-32	ALL
	=B	D	W0040	ZZBA	04		24-61-32	ALL
	=B	D	W0040	ZZBB	00		24-61-32	ALL
	=L	D	W0044	1003R	22		26-11-21	ALL
C00397		**P006-03/ /A006**		**CB-FUEL QTY 1**				**ALL**
	=B	D	W0040	6069	12		24-61-22	ALL
	=B	D	W0040	6399	12		24-61-22	ALL
	=L	D	W0044	0409	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00398		**P006-03/ /A005**		**CB-FUEL QTY 2**				**ALL**
	=B	D	W0040	6058	18		24-61-33	ALL
	=L	D	W0044	0408	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00403		**P006-02/ /A023**		**CB-FIRE PROTECTION DETECTION APU**				**ALL**
	=B	D	W0040	ZZBC	00		24-61-32	ALL
	=B	D	W0040	ZZBD	00		24-61-32	ALL
	=L	D	W0044	1004R	20		26-11-31	ALL
C00405		**P006-02/ /A024**		**CB-FIRE PROTECTION DETECTION ENG 1**				**ALL**
	=B	D	W0040	ZZBA	04		24-61-32	ALL
	=B	D	W0040	ZZBD	00		24-61-32	ALL
	=L	D	W0044	1001R	22		26-11-11	ALL
C00407		**P006-02/ /A022**		**CB-FIRE PROTECTION DETECTION ENG 2**				**ALL**
	=B	D	W0040	ZZBB	00		24-61-32	ALL
	=B	D	W0040	ZZBC	00		24-61-32	ALL
	=L	D	W0044	1002R	22		26-11-21	ALL
C00412		**P018-02/ /E002**		**CB-INSTR XFR**				**ALL**
	=B	D	W0020	ZZBT	04		24-61-41	ALL
	=B	D	W0020	ZZCL	00		24-61-41	ALL
	=B	D	W0020	ZZXX	02		24-61-41	ALL
	=L	D	W0018	0517	20		34-21-15	ALL
C00425		**P018-02/ /E008**		**CB-ADIRU LEFT EXC**				**ALL**
	=B	D	W0020	6067	18		24-53-11	ALL
	=L	D	W0018	0803	20		34-21-11	ALL
C00426		**P006-01/ /C015**		**CB-ADIRU RIGHT EXC**				**ALL**
	=B	D	W0040	6040	16		24-53-11	ALL
	=B	D	W0040	6044	16		24-53-11	ALL
	=L	D	W0044	0520	20		34-21-21	ALL
C00440		**P006-02/ /B009**		**CB-FLIGHT CONTROL AUTO SPEED BRAKE**				**ALL**
	=B	D	W0040	ZZDE	00		24-61-24	ALL
	=B	D	W0040	ZZER	00		24-61-24	ALL
	=B	D	W0040	ZZYU	02		24-61-24	ALL
	=L	D	W0044	0236	20		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00442		**P018-03/ /D011**		**CB-PASSENGER CABIN SIGNS PASS SIGN CONT**				**ALL**
	=B	D	W0020	6133	14		24-61-21	ALL
	=B	D	W0020	ZZCP	02		24-61-21	ALL
	=L	D	W0018	0302	24		33-25-11	ALL
C00451		**P006-03/ /D018**		**CB-LANDING GEAR AURAL WARN**				**ALL**
	=B	D	W0040	ZZYC	02		24-61-33	ALL
	=B	D	W0040	ZZYD	02		24-61-33	ALL
	=L	D	W0044	0052	22		31-51-11	ALL
C00452		**P006-02/ /B021**		**CB-FIRE PROTECTION EXTINGUISHERS APU**				**ALL**
	=B	D	W0040	ZZDR	00		24-61-51	ALL
	=B	D	W0040	ZZDS	00		24-61-51	ALL
	=L	D	W0044	1008R	22		26-21-11	ALL
C00456		**P018-01/ /C004**		**CB-AFCS SYS A MACH TRIM AC**				**ALL**
	=B	D	W0020	ZZAB	02		24-51-13	ALL
	=L	D	W0018	0017	20		22-18-11	ALL
C00457		**P018-01/ /D004**		**CB-AFCS SYS A MACH TRIM DC**				**ALL**
	=B	D	W0020	ZZBE	00		24-61-21	ALL
	=B	D	W0020	ZZBF	00		24-61-21	ALL
	=L	D	W0018	0018	20		22-18-11	ALL
C00458		**P018-02/ /A001**		**CB-ENGINE 1 IGNITION RIGHT**				**ALL**
	=B	D	W0020	6035	18		24-54-11	ALL
	=B	D	W0020	6108	18		24-54-11	ALL
	=L	D	W0018	0854	20		74-11-11	ALL
C00459		**P006-02/ /D004**		**CB-ENGINE 2 IGNITION RIGHT**				**ALL**
	=B	D	W0040	6048	18		24-54-11	ALL
	=L	D	W0044	0417	20		74-11-11	ALL
C00468		**P018-02/ /C010**		**CB-FLIGHT RECORDER DC**				**ALL**
	=B	D	W0020	6043	14		24-61-21	ALL
	=B	D	W0020	6085	14		24-61-21	ALL
	=L	D	W0018	0743	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00468		**P018-02/ /C010**		**CB-FLIGHT RECORDER DC (continued)**				**ALL**
	=L	D	W0018	0744	22		31-31-11	ALL
C00471		**P018-02/ /D012**		**CB-COMMUNICATIONS VHF 3**				**ALL**
	=B	D	W0020	6020	12		24-61-23	ALL
	=B	D	W0020	6275	16		24-61-23	ALL
	=L	D	W0018	0505	16		23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00523		**P018-03/ /C001**		**CB-HEATERS CAPT PITOT**				**ALL**
	=B	D	W0020	6139	18		24-54-11	ALL
	=L	D	W0018	0110	22		30-31-11	ALL
	=L	D	W0018	0154	22		30-31-11	ALL
	=L	D	W0018	0717	22		30-31-11	ALL
C00524		**P018-03/ /D006**		**CB-HEATERS AUX PITOT**				**ALL**
	=B	D	W0020	6022	16		24-51-23	ALL
	=L	D	W0018	0117	22		30-31-12	ALL
	=L	D	W0018	0162	22		30-31-12	ALL
	=L	D	W0018	0720	22		30-31-12	ALL
C00525		**P018-03/ /D005**		**CB-HEATERS F/O PITOT**				**ALL**
	=B	D	W0020	6023	16		24-51-23	ALL
	=B	D	W0020	ZZAQ	02		24-51-23	ALL
	=L	D	W0018	0118	22		30-31-12	ALL
	=L	D	W0018	0164	22		30-31-12	ALL
	=L	D	W0018	0721	22		30-31-12	ALL
C00540		**P006-03/ /B005**		**CB-FUEL SPAR VALVE IND**				**ALL**
	=B	D	W0040	6099	16		24-61-52	ALL
	=L	D	W0044	0293	20		28-21-11	ALL
C00544		**P018-02/ /C008**		**CB-FLIGHT RECORDER POSITION SENSOR**				**ALL**
	=B	D	W0020	6028	14		24-53-11	ALL
	=L	D	W0018	0749	22		31-31-14	ALL
C00549		**P006-01/ /B007**		**CB-MACH WARN SYS -2**				**ALL**
	=B	D	W0040	6085	14		24-61-24	ALL
	=B	D	W0040	ZZCX	03		24-61-24	ALL
	=B	D	W0040	ZZCY	00		24-61-24	ALL
	=L	D	W0044	0212	22		34-16-21	ALL
C00555		**P006-04/ /A008**		**CB-AIR CONDITIONING MISC LOADS LEFT**				**ALL**
	=B	D	W0040	6546	14		24-61-22	ALL
	=B	D	W0040	ZZEP	00		24-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00555		**P006-04/ /A008**		**CB-AIR CONDITIONING MISC LOADS LEFT (continued)**				**ALL**
	=B	D	W0040	ZZEU	03		24-61-22	ALL
	=L	D	W0044	0598	24		21-51-14	ALL
C00560		**P006-02/ /C021**		**CB-INTERPHONE POWER F/O DC 2**				**ALL**
	=B	D	W0040	6501	14		24-61-24	ALL
	=B	D	W0040	6550	14		24-61-24	ALL
	=L	D	W0044	B-BB			23-51-51	ALL
C00561		**P006-02/ /C022**		**CB-INTERPHONE POWER F/O BAT**				**ALL**
	=B	D	W0040	ZZYA	02		24-61-32	ALL
	=B	D	W0040	ZZYB	02		24-61-32	ALL
	=L	D	W0044	D-BA			23-51-51	ALL
C00566		**P006-02/ /A006**		**CB-FLIGHT CONTROL FLAP LOAD RELIEF**				**ALL**
	=B	D	W0040	ZZCK	03		24-61-22	ALL
	=B	D	W0040	ZZCM	00		24-61-22	ALL
	=L	D	W0044	0234	22		27-54-11	ALL
C00569		**P006-03/ /F018**		**CB-PROBE INDICATION CAPT**				**ALL**
	=B	D	W0040	ZZYI	02		24-61-22	ALL
	=L	D	W0044	0485	22		30-31-11	ALL
C00570		**P006-03/ /F016**		**CB-PROBE INDICATION F/O**				**ALL**
	=B	D	W0040	6074	12		24-61-24	ALL
	=B	D	W0040	ZZZJ	02		24-61-24	ALL
	=L	D	W0044	0486	22		30-31-12	ALL
C00583		**P006-03/ /A018**		**CB-LANDING GEAR AUTOBRAKE BITE CONT 1**				**ALL**
	=B	D	W0040	6068	14		24-61-22	ALL
	=B	D	W0040	6069	12		24-61-22	ALL
	=L	D	W0044	0262	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C00629		**P018-01/ /B007**		**CB-GND PROX WARN**				**ALL**
	=B	D	W0020	6001	16		24-51-13	ALL
	=B	D	W0020	ZZXH	02		24-51-13	ALL
	=L	D	W0018	0823	22		34-49-11	ALL
C00644		**P018-03/ /A015**		**CB-EXTERIOR LIGHTING LOGO ILLUM**				**ALL**
	=B	D	W0020	6076	16		24-51-12	ALL
	=L	D	W0018	0343	20		33-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00700		**P018-03/ /E004**		**CB-HEATERS DRAIN MAST AIR**				**ALL**
	=B	D	W0020	6078	14		24-51-12	ALL
	=B	D	W0020	ZZAM	02		24-51-12	ALL
	=L	D	W0018	0733	20		30-71-11	ALL
C00701		**P006-03/ /D008**		**CB-EMER PANEL LTG**				**ALL**
	=B	D	W0040	6047	18		24-53-11	ALL
	=L	D	W0044	0066	16		33-11-32	ALL
	=L	D	W0044	0068	20		33-11-33	ALL
C00716		**P006-02/ /B004**		**CB-AFCS SYS B ENGAGE INTLK**				**ALL**
	=B	D	W0040	ZZDI	00		24-61-24	ALL
	=B	D	W0040	ZZDJ	00		24-61-24	ALL
	=L	D	W0044	0352	20		22-11-12	ALL
C00721		**P018-01/ /E001**		**CB-AUTOTHROTTLE DC 1**				**ALL**
	=B	D	W0020	ZZXR	02		24-61-21	ALL
	=L	D	W0018	0024	18		22-31-31	ALL
C00751		**P006-03/ /A011**		**CB-CONT CABIN LIGHTING PANEL FLOOD CONT**				**ALL**
	=B	D	W0040	6117	14		24-51-24	ALL
	=L	D	W0044	0089	20		33-14-11	ALL
C00781		**P006-02/ /C016**		**CB-HYD SYS LDG GR SYS XFR VALVE PRI**				**ALL**
	=B	D	W0040	ZZCD	04		24-61-22	ALL
	=B	D	W0040	ZZCG	00		24-61-22	ALL
	=L	D	W0044	0209	22		29-23-11	ALL
C00783		**P018-03/ /F010**		**CB-OXYGEN PASS LEFT**				**ALL**
	=B	D	W0020	6038	12		24-61-31	ALL
	=B	D	W0020	6039	18		24-61-31	ALL
	=B	D	W0020	ZZAX	04		24-61-31	ALL
	=B	D	W0020	ZZAY	00		24-61-31	ALL
	=L	D	W0018	0351	16		35-21-11	ALL
C00784		**P018-03/ /F009**		**CB-OXYGEN PASS RIGHT**				**ALL**
	=B	D	W0020	ZZAY	00		24-61-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00784		**P018-03/ /F009**		**CB-OXYGEN PASS RIGHT (continued)**				**ALL**
	=B	D	W0020	ZZAZ	00		24-61-31	ALL
	=L	D	W0018	0352	16		35-21-11	ALL
C00785		**P018-03/ /F008**		**CB-OXYGEN MAN CONT**				**ALL**
	=B	D	W0020	ZZAZ	00		24-61-31	ALL
	=B	D	W0020	ZZBA	00		24-61-31	ALL
	=L	D	W0018	0353	22		35-21-11	ALL
C00786		**P006-02/ /D018**		**CB-FLIGHT CONTROL TRIM CONT AIL**				**ALL**
	=B	D	W0040	6126	10		24-51-24	ALL
	=B	D	W0040	6154	08		24-51-24	ALL
	=L	D	W0044	0224	24		27-11-11	ALL
C00787		**P006-02/ /D019**		**CB-FLIGHT CONTROL TRIM CONT RUD**				**ALL**
	=B	D	W0040	6125	08		24-51-24	ALL
	=B	D	W0040	6156	08		24-51-24	ALL
	=L	D	W0044	0225	24		27-21-11	ALL
C00788		**P006-02/ /D016**		**CB-FLIGHT CONTROL TRIM IND RUD**				**ALL**
	=B	D	W0040	6041	16		24-53-11	ALL
	=B	D	W0040	6108	16		24-53-11	ALL
	=L	D	W0044	0287	24		27-28-11	ALL
C00796		**P006-04/ /A007**		**CB-AIR CONDITIONING BLEED AIR VALVES L**				**ALL**
	=B	D	W0040	ZZEP	00		24-61-22	ALL
	=B	D	W0040	ZZFA	00		24-61-22	ALL
	=L	D	W0044	0482	20		36-11-12	ALL
C00797		**P006-04/ /B007**		**CB-AIR CONDITIONING BLEED AIR VALVES R**				**ALL**
	=B	D	W0040	ZZEL	00		24-61-24	ALL
	=B	D	W0040	ZZFB	00		24-61-24	ALL
	=L	D	W0044	0481	20		36-11-22	ALL
C00799		**P006-02/ /C015**		**CB-HYD SYS LDG GR SYS XFR VALVE SEC**				**ALL**
	=B	D	W0040	6436	14		24-61-22	ALL
	=B	D	W0040	ZZCF	00		24-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00799		**P006-02/ /C015**		**CB-HYD SYS LDG GR SYS XFR VALVE SEC (continued)**				**ALL**
	=B	D	W0040	ZZCG	00		24-61-22	ALL
	=L	D	W0044	0210	22		29-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00839		**P018-02/ /E011**		**CB-COMMUNICATIONS HF 1**				**ALL**
	A1	D	W0020	6102	16		24-51-13	ALL
	A1	D	W0020	6118	16		24-51-13	ALL
	A2	D	W0018	3003R	20		23-11-11	ALL
	B1	D	W0020	6103	16		24-51-13	ALL
	B1	D	W0020	6119	16		24-51-13	ALL
	B2	D	W0018	3003Y	20		23-11-11	ALL
	C1	D	W0020	6104	16		24-51-13	ALL
	C1	D	W0020	6120	16		24-51-13	ALL
	C2	D	W0018	3003B	20		23-11-11	ALL
C00840		**P006-02/ /D010**		**CB-FLIGHT CONTROL STAB TRIM ACTUATOR**				**ALL**
	A1	D	W0040	ZZXJ	02		24-51-24	ALL
	A1	D	W0040	ZZXK	02		24-51-24	ALL
	A2	D	W0044	3001R	14		27-41-12	ALL
	B1	D	W0040	ZZXL	02		24-51-24	ALL
	B1	D	W0040	ZZXM	02		24-51-24	ALL
	B2	D	W0044	3001Y	14		27-41-12	ALL
	C1	D	W0040	6128	14		24-51-24	ALL
	C1	D	W0040	ZZXN	02		24-51-24	ALL
	C2	D	W0044	3001B	14		27-41-12	ALL
C00841		**P006-02/ /D013**		**CB-FLIGHT CONTROL ALTN T.E. FLAP DRIVE**				**ALL**
	A1	D	W0040	6156	08		24-51-24	ALL
	A1	D	W0040	ZZXJ	02		24-51-24	ALL
	A2	D	W0044	0231	16		27-53-12	ALL
	B1	D	W0040	6126	10		24-51-24	ALL
	B1	D	W0040	ZZXL	02		24-51-24	ALL
	B2	D	W0044	0232	16		27-53-12	ALL
	C1	D	W0040	6129	08		24-51-24	ALL
	C1	D	W0040	ZZXN	02		24-51-24	ALL
	C2	D	W0044	0233	16		27-53-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00857		**P006-01/ /D002**		**CB-COMMUNICATIONS HF 2**				**ALL**
	A1	D	W0040	6146	10		24-51-24	ALL
	A1	D	W0040	6147	10		24-51-24	ALL
	A2	D	W0044	3215R	20		23-11-21	ALL
	B1	D	W0040	6145	14		24-51-24	ALL
	B1	D	W0040	6148	14		24-51-24	ALL
	B2	D	W0044	3215Y	20		23-11-21	ALL
	C1	D	W0040	6144	14		24-51-24	ALL
	C1	D	W0040	6149	14		24-51-24	ALL
	C2	D	W0044	3215B	20		23-11-21	ALL
C00884		**P006-04/ /E004**		**CB-AC RECIRC RIGHT FAN CABIN AIR**				**ALL**
	A1	D	W0044	0429	14		21-25-11	ALL
	A2	D	W0040	6134	12		24-51-22	ALL
	B1	D	W0044	0430	14		21-25-11	ALL
	B2	D	W0040	6135	12		24-51-22	ALL
	C1	D	W0044	0431	14		21-25-11	ALL
	C2	D	W0040	6136	12		24-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C00911		**P018-03/ /E007**		**CB-A/C RECIRC FAN LEFT CABIN AIR**				**ALL**
	A1	D	W0020	6076	16		24-51-12	ALL
	A1	D	W0020	6077	12		24-51-12	ALL
	A2	D	W0018	0508	14		21-25-11	ALL
	B1	D	W0020	6078	14		24-51-12	ALL
	B1	D	W0020	6079	10		24-51-12	ALL
	B2	D	W0018	0509	14		21-25-11	ALL
	C1	D	W0020	6080	12		24-51-12	ALL
	C1	D	W0020	6081	10		24-51-12	ALL
	C2	D	W0018	0510	14		21-25-11	ALL
C00923		**P018-02/ /A009**		**CB-DATA LOADER (INOP)**				**ALL**
	=B	D	W0020	6120	16		24-51-13	ALL
	=L	*	W0018	0838	20		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01001		**P018-03/ /A007**		**CB-ANTI-ICE & RAIN ENG 1 COWL AI VALVE**				**ALL**
	=B	D	W0020	6048	14		24-61-21	ALL
	=B	D	W0020	ZZBL	05		24-61-21	ALL
	=B	D	W0020	ZZEC	00		24-61-21	ALL
	=L	D	W0018	0711	20		30-21-31	ALL
C01002		**P018-03/ /B007**		**CB-ANTI-ICE & RAIN ENG 2 COWL AI VALVE**				**ALL**
	=B	D	W0020	ZZBR	02		24-61-23	ALL
	=B	D	W0020	ZZXZ	02		24-61-23	ALL
	=L	D	W0018	0713	20		30-21-32	ALL
C01007		**P018-01/ /E007**		**CB-ADIRU LEFT AC**				**ALL**
	=B	D	W0020	6034	14		24-54-11	ALL
	=B	D	W0020	6304	14		24-54-11	ALL
	=L	D	W0018	0804	20		34-21-11	ALL
C01008		**P006-01/ /C014**		**CB-ADIRU RIGHT AC**				**ALL**
	=B	D	W0040	6112	14		24-51-24	ALL
	=B	D	W0040	ZZXH	02		24-51-24	ALL
	=L	D	W0044	0521	20		34-21-21	ALL
C01009		**P018-01/ /E005**		**CB-ADIRU LEFT DC**				**ALL**
	=B	D	W0020	6060	16		24-61-52	ALL
	=B	D	W0020	6062	16		24-61-52	ALL
	=L	D	W0018	0805	16		34-21-11	ALL
C01010		**P006-01/ /C017**		**CB-ADIRU RIGHT DC**				**ALL**
	=B	D	W0040	6093	16		24-61-52	ALL
	=L	D	W0044	0522	16		34-21-21	ALL
C01017		**P018-02/ /A006**		**CB-FMCS CMPTR 1**				**ALL**
	=B	D	W0020	6108	18		24-54-11	ALL
	=B	D	W0020	ZZAC	02		24-54-11	ALL
	=L	D	W0018	0394	20		34-61-11	ALL
C01018		**P018-02/ /A007**		**CB-FMCS CDU 1**				**ALL**
	=B	D	W0020	ZZAC	02		24-54-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01018		**P018-02/ /A007**		**CB-FMCS CDU 1 (continued)**				**ALL**
	=L	D	W0018	0835	20		34-61-11	ALL
C01021		**P006-02/ /B024**		**CB-FIRE PROTECTION EXTINGUISHERS ALTN L**				**ALL**
	=B	D	W0040	ZZDQ	05		24-61-51	ALL
	=B	D	W0040	ZZDU	00		24-61-51	ALL
	=L	D	W0044	1005R	22		26-21-11	ALL
C01022		**P006-02/ /B023**		**CB-FIRE PROTECTION EXTINGUISHERS ALTN R**				**ALL**
	=B	D	W0040	ZZDT	00		24-61-51	ALL
	=B	D	W0040	ZZDU	00		24-61-51	ALL
	=L	D	W0044	1007R	22		26-21-11	ALL
C01023		**P006-04/ /E002**		**CB-A/C RECIRC FAN RIGHT CONT.**				**ALL**
	=B	D	W0040	6017	10		24-61-24	ALL
	=B	D	W0040	6347	12		24-61-24	ALL
	=L	D	W0044	0613	24		21-25-11	ALL
C01027		**P006-03/ /D017**		**CB-LANDING GEAR NOSE GEAR STEER**				**ALL**
	=B	D	W0040	6404	14		24-51-24	ALL
	=L	D	W0044	0273	22		32-51-11	ALL
C01037		**P006-02/ /C001**		**CB-AFCS SYS B MACH TRIM AC**				**ALL**
	=B	D	W0040	ZZAH	02		24-51-24	ALL
	=L	D	W0044	0508	20		22-18-11	ALL
C01041		**P018-01/ /C005**		**CB-AFCS SYS A SNSR EXC AC**				**ALL**
	=B	D	W0020	ZZAB	02		24-51-13	ALL
	=B	D	W0020	ZZXB	02		24-51-13	ALL
	=L	D	W0018	0008	20		22-11-11	ALL
C01042		**P006-02/ /C002**		**CB-AFCS SYS B SNSR EXC AC**				**ALL**
	=B	D	W0040	6123	14		24-51-24	ALL
	=B	D	W0040	ZZAH	02		24-51-24	ALL
	=L	D	W0044	0351	20		22-11-11	ALL
C01044		**P018-01/ /D005**		**CB-AFCS MCP DC 1**				**ALL**
	=B	D	W0020	ZZBD	00		24-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01044		**P018-01/ /D005**		**CB-AFCS MCP DC 1 (continued)**				**ALL**
	=B	D	W0020	ZZBE	00		24-61-21	ALL
	=L	D	W0018	0010	20		22-11-12	ALL
C01045		**P018-01/ /D002**		**CB-AFCS SYS A FCC DC**				**ALL**
	=B	D	W0020	ZZBB	06		24-61-21	ALL
	=B	D	W0020	ZZBG	00		24-61-21	ALL
	=B	D	W0020	ZZXR	02		24-61-21	ALL
	=L	D	W0018	0009	20		22-11-11	ALL
C01046		**P006-02/ /B003**		**CB-AFCS SYS B FCC DC**				**ALL**
	=B	D	W0040	ZZDJ	00		24-61-24	ALL
	=B	D	W0040	ZZDK	00		24-61-24	ALL
	=L	D	W0044	0350	20		22-11-11	ALL
C01047		**P006-02/ /C003**		**CB-AFCS MCP DC 2**				**ALL**
	=B	D	W0040	ZZAV	05		24-61-32	ALL
	=B	D	W0040	ZZAZ	00		24-61-32	ALL
	=L	D	W0044	0353	20		22-11-12	ALL
C01048		**P018-01/ /D003**		**CB-AFCS SYS A ENGAGE INTLK**				**ALL**
	=B	D	W0020	ZZBF	00		24-61-21	ALL
	=B	D	W0020	ZZBG	00		24-61-21	ALL
	=L	D	W0018	0011	20		22-11-12	ALL
C01049		**P018-01/ /D001**		**CB-AFCS SYS A WARN LIGHT (BAT)**				**ALL**
	=B	D	W0020	6062	16		24-61-52	ALL
	=L	D	W0018	0016	20		22-14-11	ALL
C01050		**P006-01/ /D015**		**CB-FMCS CDU 2**				**ALL**
	=B	D	W0040	ZZAC	02		24-51-24	ALL
	=B	D	W0040	ZZXG	02		24-51-24	ALL
	=L	D	W0044	0222	20		34-61-11	ALL
C01064		**P006-02/ /B002**		**CB-AFCS SYS B MACH TRIM DC**				**ALL**
	=B	D	W0040	ZZDH	04		24-61-24	ALL
	=B	D	W0040	ZZDK	00		24-61-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01064		**P006-02/ /B002**		**CB-AFCS SYS B MACH TRIM DC (continued)**				**ALL**
	=B	D	W0040	ZZXF	02		24-61-24	ALL
	=L	D	W0044	0507	20		22-18-11	ALL
C01068		**P006-02/ /C014**		**CB-FLIGHT CONTROL AUTOSLAT DC 1**				**ALL**
	=B	D	W0040	6127	10		24-61-22	ALL
	=B	D	W0040	ZZCE	00		24-61-22	ALL
	=B	D	W0040	ZZCF	00		24-61-22	ALL
	=L	D	W0044	0239	22		27-83-11	ALL
C01070		**P006-02/ /B014**		**CB-FLIGHT CONTROL AUTOSLAT DC 2**				**ALL**
	=B	D	W0040	6550	14		24-61-24	ALL
	=B	D	W0040	ZZDC	00		24-61-24	ALL
	=B	D	W0040	ZZDF	07		24-61-24	ALL
	=L	D	W0044	0413	22		27-83-21	ALL
C01071		**P018-03/ /D003**		**CB-HEATERS ALPHA VANE RIGHT**				**ALL**
	=B	D	W0020	6021	14		24-51-23	ALL
	=B	D	W0020	6301	16		24-51-23	ALL
	=L	D	W0018	0163	22		30-31-12	ALL
	=L	D	W0018	0722	22		30-31-12	ALL
C01072		**P018-03/ /C003**		**CB-HEATERS ALPHA VANE LEFT**				**ALL**
	=B	D	W0020	ZZAI	03		24-51-13	ALL
	=B	D	W0020	ZZAK	00		24-51-13	ALL
	=L	D	W0018	0156	22		30-31-11	ALL
	=L	D	W0018	0718	22		30-31-11	ALL
C01073		**P018-03/ /F014**		**CB-LAVATORY WATER HEATER D**				**ALL**
	=B	D	W0020	ZZAL	00		24-51-12	ALL
	=B	D	W0020	ZZBN	00		24-51-12	ALL
	=L	D	W0018	0362	22		38-21-11	ALL
C01074		**P006-02/ /C013**		**CB-FLIGHT CONT SHUTOFF VALVES FLT CONT**				**ALL**
	=B	D	W0040	6062	10		24-61-22	ALL
	=B	D	W0040	ZZCD	04		24-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01074		**P006-02/ /C013**		**CB-FLIGHT CONT SHUTOFF VALVES FLT CONT (continued)**				**ALL**
	=B	D	W0040	ZZCE	00		24-61-22	ALL
	=L	D	W0044	0228	20		27-23-11	ALL
C01081		**P006-02/ /A015**		**CB-HYDRAULIC SYSTEM PTU VALVE CONT 1**				**ALL**
	=B	D	W0040	ZZCI	02		24-61-22	ALL
	=B	D	W0040	ZZYS	02		24-61-22	ALL
	=L	D	W0044	0208	22		29-25-11	ALL
C01085		**P006-02/ /A016**		**CB-HYDRAULIC SYSTEM PTU VALVE CONT 2**				**ALL**
	=B	D	W0040	ZZCI	02		24-61-22	ALL
	=L	D	W0044	0207	22		29-25-11	ALL
C01094		**P006-03/ /E015**		**CB-LANDING GEAR BRAKE TEMP MONITOR**				**ALL**
	=B	D	W0040	6281	12		24-61-24	ALL
	=B	D	W0040	ZZZJ	02		24-61-24	ALL
	=L	D	W0044	0788	22		32-46-11	ALL
C01096		**P018-03/ /F015**		**CB-LAVATORY WATER HEATER E**				**ALL**
	=B	D	W0020	ZZBN	00		24-51-12	ALL
	=B	D	W0020	ZZDK	03		24-51-12	ALL
	=B	D	W0020	ZZYI	02		24-51-12	ALL
	=L	D	W0018	0202	22		38-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01103		**P018-02/ /B008**		**CB-ENGINE 1 START VALVE**				**ALL**
	=B	D	W0020	6183	18		24-61-31	ALL
	=B	D	W0020	6248	18		24-61-31	ALL
	=L	D	W0018	0863	20		80-11-11	ALL
C01116		**P006-04/ /C012**		**CB-EQPT COOLING SUPPLY FAN CONT-NORMAL**				**ALL**
	=B	D	W0040	6549	14		24-61-24	ALL
	=B	D	W0040	ZZZC	02		24-61-24	ALL
	=L	D	W0044	0642	24		21-27-31	ALL
C01117		**P006-04/ /C013**		**CB-EQPT COOLING SUPPLY FAN CONTROL-ALTN**				**ALL**
	=B	D	W0040	6546	14		24-61-22	ALL
	=B	D	W0040	ZZZD	02		24-61-22	ALL
	=L	D	W0044	0641	24		21-27-31	ALL
C01125		**P018-03/ /E012**		**CB-LAVATORY SMOKE**				**ALL**
	=B	D	W0020	ZZBY	02		24-61-21	ALL
	=B	D	W0020	ZZXU	02		24-61-21	ALL
	=L	D	W0018	0260	22		26-14-11	ALL
C01139		**P006-05/ /C021**		**CB-AFT CARGO LOADER CONT**				**ALL**
	=B	D	W0040	6602	18		24-61-61	ALL
	=L	D	W0044	0566	22		25-51-21	ALL
C01156		**P018-03/ /E009**		**CB-A/C RECIRC FAN LEFT CONT**				**ALL**
	=B	D	W0020	6112	14		24-61-21	ALL
	=L	D	W0018	0511	22		21-25-11	ALL
C01157		**P006-04/ /A001**		**CB-A/C TEMP CONT VALVE CLOSE LEFT**				**ALL**
	=B	D	W0040	6520	14		24-51-14	ALL
	=L	D	W0044	0595	24		21-51-12	ALL
C01158		**P006-04/ /A009**		**CB-AIR CONDITIONING PACK CONTROL LEFT DC**				**ALL**
	=B	D	W0040	6565	16		24-61-41	ALL
	=L	D	W0044	0596	24		21-51-12	ALL
C01159		**P006-04/ /A011**		**CB-AIR CONDITIONING PACK CONTROL LEFT AC**				**ALL**
	=B	D	W0040	0512	14		24-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01159		**P006-04/ /A011**		**CB-AIR CONDITIONING PACK CONTROL LEFT AC (continued)**				**ALL**
	=B	D	W0040	6520	14		24-51-14	ALL
	=L	D	W0044	0597	22		21-51-12	ALL
C01160		**P006-04/ /B001**		**CB-A/C TEMP CONT VALVE CLOSE RIGHT**				**ALL**
	=B	D	W0040	6012	14		24-51-24	ALL
	=L	D	W0044	0608	24		21-51-22	ALL
C01161		**P006-04/ /B009**		**CB-AIR CONDITIONING PACK CONT RIGHT DC**				**ALL**
	=B	D	W0040	6558	16		24-61-42	ALL
	=L	D	W0044	0609	24		21-51-22	ALL
C01162		**P006-04/ /B011**		**CB-AIR CONDITIONING PACK CONT RIGHT AC**				**ALL**
	=B	D	W0040	6010	14		24-51-24	ALL
	=B	D	W0040	6163	14		24-51-24	ALL
	=L	D	W0044	0610	24		21-51-22	ALL
C01163		**P006-04/ /B003**		**CB-A/C ZONE TEMP VALVE/FAN CONT FLT DECK**				**ALL**
	=B	D	W0040	6011	14		24-51-24	ALL
	=B	D	W0040	6012	14		24-51-24	ALL
	=L	D	W0044	0607	24		21-61-11	ALL
C01164		**P006-04/ /C004**		**CB-A/C ZONE TEMP DUCT OVHT FLT DECK**				**ALL**
	=B	D	W0040	ZZEH	00		24-61-32	ALL
	=B	D	W0040	ZZFG	00		24-61-32	ALL
	=L	D	W0044	0606	24		21-61-11	ALL
C01166		**P006-04/ /C003**		**CB-A/C ZONE TEMP DUCT OVHT FWD PASS**				**ALL**
	=B	D	W0040	ZZFF	00		24-61-32	ALL
	=B	D	W0040	ZZFG	00		24-61-32	ALL
	=L	D	W0044	0604	24		21-61-13	ALL
C01167		**P006-04/ /B002**		**CB-A/C ZONE TEMP VALVE/FAN CONT FWD PASS**				**ALL**
	=B	D	W0040	6519	14		24-51-24	ALL
	=L	D	W0044	0605	24		21-61-13	ALL
C01169		**P006-04/ /C002**		**CB-A/C ZONE TEMP DUCT OVHT AFT PASS**				**ALL**
	=B	D	W0040	6013	18		24-61-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01169		**P006-04/ /C002**		**CB-A/C ZONE TEMP DUCT OVHT AFT PASS (continued)**				**ALL**
	=B	D	W0040	ZZEE	07		24-61-32	ALL
	=B	D	W0040	ZZFF	00		24-61-32	ALL
	=L	D	W0044	0601	24		21-61-14	ALL
C01170		**P006-04/ /A003**		**CB-A/C ZONE TEMP VALVE/FAN CONT AFT PASS**				**ALL**
	=B	D	W0040	0511	14		24-51-14	ALL
	=L	D	W0044	0602	24		21-61-14	ALL
C01172		**P006-04/ /D009**		**CB-AIR CONDITIONING TRIM AIR PRESS**				**ALL**
	=B	D	W0044	6080	20		21-61-15	ALL
	=L	D	W0044	0612	20		21-61-15	ALL
C01176		**P006-04/ /C008**		**CB-A/C PACK/ENGINE BLEED AIR OVHT LEFT**				**ALL**
	=B	D	W0040	6014	12		24-61-32	ALL
	=B	D	W0040	ZZEE	07		24-61-32	ALL
	=B	D	W0040	ZZEJ	00		24-61-32	ALL
	=L	D	W0044	0599	24		21-51-15	ALL
C01177		**P006-04/ /C007**		**CB-A/C PACK/ENGINE BLEED AIR OVHT RIGHT**				**ALL**
	=B	D	W0040	6552	18		24-61-32	ALL
	=B	D	W0040	ZZEI	00		24-61-32	ALL
	=B	D	W0040	ZZEJ	00		24-61-32	ALL
	=L	D	W0044	0603	24		21-51-25	ALL
C01178		**P006-04/ /B008**		**CB-AIR CONDITIONING MISC LOADS RIGHT**				**ALL**
	=B	D	W0040	6549	14		24-61-24	ALL
	=B	D	W0040	ZZEK	03		24-61-24	ALL
	=B	D	W0040	ZZEL	00		24-61-24	ALL
	=L	D	W0044	0611	20		21-51-24	ALL
C01179		**P006-03/ /F013**		**CB-INDICATOR MASTER DIM SECT 7**				**ALL**
	=B	D	W0044	0195	20		33-18-62	ALL
	=L	D	W0044	0176	20		33-18-33	ALL
	=L	D	W0044	0547	20		33-18-62	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01180		**P006-03/ /F014**		**CB-INDICATOR MASTER DIM SECT 8**				**ALL**
	=B	D	W0044	0199	20		33-18-62	ALL
	=L	D	W0044	0175	20		33-18-33	ALL
	=L	D	W0044	0178	20		33-18-35	ALL
	=L	D	W0044	0548	20		33-18-62	ALL
C01192		**P018-02/ /B010**		**CB-FMCS BITE DC**				**ALL**
	=B	D	W0020	6085	14		24-61-21	ALL
	=B	D	W0020	6306	14		24-61-21	ALL
	=L	D	W0018	0515	20		34-61-22	ALL
C01194		**P006-01/ /E014**		**CB-ATC ANT SWITCH**				**ALL**
	=B	D	W0040	ZZCV	00		24-61-24	ALL
	=B	D	W0040	ZZCW	00		24-61-24	ALL
	=L	D	W0044	0280	22		34-53-31	ALL
C01195		**P018-01/ /B006**		**CB-TCAS**				**ALL**
	=B	D	W0020	6002	16		24-51-13	ALL
	=L	D	W0018	0821	20		34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01204		**P018-02/ /E005**		**CB-SMYD-1 CMPTR DC**				**ALL**
	=B	D	W0020	ZZBT	04		24-61-41	ALL
	=B	D	W0020	ZZBW	00		24-61-41	ALL
	=L	D	W0018	0702	22		27-32-11	ALL
C01205		**P018-02/ /E006**		**CB-SMYD-1 SNSR EXC AC**				**ALL**
	=B	D	W0020	6033	18		24-53-11	ALL
	=B	D	W0020	6067	18		24-53-11	ALL
	=L	D	W0018	0701	22		27-32-11	ALL
C01206		**P006-01/ /B005**		**CB-SMYD-2 CMPTR DC**				**ALL**
	=B	D	W0040	ZZCX	03		24-61-24	ALL
	=B	D	W0040	ZZCZ	00		24-61-24	ALL
	=B	D	W0040	ZZYL	02		24-61-24	ALL
	=L	D	W0044	0510	22		27-32-21	ALL
C01207		**P006-01/ /B004**		**CB-SMYD-2 SNSR EXC AC**				**ALL**
	=B	D	W0040	6044	16		24-53-11	ALL
	=L	D	W0044	0509	22		27-32-21	ALL
C01208		**P018-02/ /E007**		**CB-STALL WARN ASYM MODE**				**ALL**
	=B	D	W0018	0894	22		27-32-11	ALL
	=L	D	W0018	0704	22		27-32-11	ALL
C01209		**J009-00/ /A003**		**CB-AUX BAT CHARGER**				**ALL**
	=B	CK	W2532	0527	*1		24-31-12	ALL
	=B	F	W2532	0529	24		24-31-12	ALL
	=L	F	W2532	0526	02		24-31-12	ALL
C01210		**J009-00/ /A002**		**CB-AUX BAT DC VOLTMETER**				**ALL**
	=B	D	W2532	0529	24		24-31-12	ALL
	=L	D	W2532	0530	24		24-31-12	ALL
	=L	D	W2532	0533	24		24-33-11	ALL
C01212		**J009-00/ /**		**CB-DUAL BATTERY RCCB**				**ALL**
	3	1A	W5110	0529	24		24-31-12	ALL
	4	1A	W2532	0530	24		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01212		**J009-00/ /**		**CB-DUAL BATTERY RCCB (continued)**				**ALL**
	A2	CK	W2532	0527	*1		24-31-12	ALL
	A2	CK	W2532	0528	*1		24-31-12	ALL
	5A	1A	W5110	0531	20		24-31-12	ALL
C01216		**P006-01/ /E005**		**CB-PRINTER**				**ALL**
	=B	D	W0040	ZZXB	02		24-51-14	ALL
	=L	D	W0044	0615	22		31-33-01	ALL
C01217		**P018-03/ /D010**		**CB-PASS CAB SIGNS LAV OCC SIGN**				**ALL**
	=B	D	W0020	6029	14		24-53-11	ALL
	=B	D	W0020	6193	08		24-53-11	ALL
	=B	D	W0020	6302	14		24-53-11	ALL
	=L	D	W0018	0319	20		33-26-31	ALL
C01262		**P006-01/ /D016**		**CB-FMCS CMPTR 2**				**ALL**
	=B	D	W0040	ZZAC	02		24-51-24	ALL
	=B	D	W0040	ZZXH	02		24-51-24	ALL
	=L	D	W0044	0221	20		34-61-11	ALL
C01263		**P006-01/ /E015**		**CB-FMCS XFR**				**ALL**
	=B	D	W0040	ZZCR	06		24-61-24	ALL
	=B	D	W0040	ZZCW	00		24-61-24	ALL
	=L	D	W0044	0223	20		34-61-12	ALL
C01266		**P018-02/ /B007**		**CB-ENGINE 1 THRUST REVERSER SYNC LOCK**				**ALL**
	=B	D	W0020	6164	16		24-61-41	ALL
	=B	D	W0020	ZZCA	03		24-61-41	ALL
	=B	D	W0020	ZZCB	00		24-61-41	ALL
	=L	D	W0018	0859	18		78-32-51	ALL
C01267		**P006-02/ /C005**		**CB-ENGINE 2 THRUST REVERSER SYNC LOCK**				**ALL**
	=B	D	W0040	ZZAX	00		24-61-32	ALL
	=B	D	W0040	ZZAY	00		24-61-32	ALL
	=L	D	W0044	0424	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01269		**P006-04/ /F006**		**CB-PRESSURIZATION CONTROL MANUAL**				**ALL**
	=B	D	W0040	ZZYJ	02		24-61-32	ALL
	=L	D	W0044	0440	20		21-31-11	ALL
C01270		**P006-04/ /F003**		**CB-PRESSURIZATION CONTROL AUTO 1**				**ALL**
	=B	D	W0040	6064	10		24-61-22	ALL
	=B	D	W0040	6071	10		24-61-22	ALL
	=L	D	W0044	0445	20		21-31-22	ALL
C01271		**P006-04/ /F005**		**CB-PRESSURIZATION CONTROL AUTO 2**				**ALL**
	=B	D	W0040	6017	10		24-61-24	ALL
	=B	D	W0040	6079	10		24-61-24	ALL
	=L	D	W0044	0919	20		21-31-23	ALL
C01272		**P006-04/ /F007**		**CB-PRESSURIZATION CONTROL IND**				**ALL**
	=B	D	W0040	6517	14		24-61-24	ALL
	=L	D	W0044	0452	24		21-31-23	ALL
C01273		**P006-04/ /F001**		**CB-PRESSURIZATION CONTROL LCD LTG**				**ALL**
	=B	D	W0040	6043	16		24-53-11	ALL
	=L	D	W0044	0455	24		21-31-25	ALL
C01274		**P018-03/ /E011**		**CB-AIR CONDITIONING DOOR AREA HEAT CONT**				**ALL**
	=B	D	W0020	6112	14		24-61-21	ALL
	=B	D	W0020	ZZBY	02		24-61-21	ALL
	=L	D	W0018	0007	24		21-42-11	ALL
C01275		**P006-03/ /C011**		**CB-MASTER CAUTION ANNUNCIATOR CONT 1**				**ALL**
	=B	D	W0040	6065	12		24-61-33	ALL
	=B	D	W0040	6124	18		24-61-33	ALL
	=B	D	W0040	ZZBJ	05		24-61-33	ALL
	=B	D	W0040	ZZBK	00		24-61-33	ALL
	=L	D	W0044	0058	20		31-52-25	ALL
C01276		**P006-03/ /C012**		**CB-MASTER CAUTION ANNUNCIATOR CONT 2**				**ALL**
	=B	D	W0040	ZZBK	00		24-61-33	ALL
	=B	D	W0040	ZZBL	00		24-61-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01276		**P006-03/ /C012**		**CB-MASTER CAUTION ANNUNCIATOR CONT 2 (continued)**				**ALL**
	=L	D	W0044	0057	20		31-52-21	ALL
C01277		**P006-03/ /C013**		**CB-MASTER CAUTION ANNUNCIATOR CONT 3**				**ALL**
	=B	D	W0040	ZZBL	00		24-61-33	ALL
	=B	D	W0040	ZZBM	00		24-61-33	ALL
	=B	D	W0040	ZZYF	02		24-61-33	ALL
	=L	D	W0044	0059	20		31-52-51	ALL
C01278		**P006-03/ /C014**		**CB-MASTER CAUTION ANNUNCIATOR CONT 4**				**ALL**
	=B	D	W0040	ZZBM	00		24-61-33	ALL
	=B	D	W0040	ZZBN	00		24-61-33	ALL
	=L	D	W0044	0063	20		31-52-75	ALL
	=L	D	W0044	0516	20		31-52-71	ALL
C01283		**P006-04/ /F010**		**CB-GENERATOR CONT UNIT 1**				**ALL**
	=B	D	W0040	6209	18		24-61-32	ALL
	=B	D	W0040	ZZBQ	03		24-61-32	ALL
	=B	D	W0040	ZZBU	00		24-61-32	ALL
	=L	D	W0044	0001	20		24-11-11	ALL
C01284		**P006-04/ /F011**		**CB-GENERATOR CONT UNIT 2**				**ALL**
	=B	D	W0040	6208	16		24-61-42	ALL
	=B	D	W0040	6558	16		24-61-42	ALL
	=L	D	W0044	0003	20		24-11-21	ALL
C01285		**P006-04/ /F012**		**CB-GENERATOR APU GEN CONT UNIT**				**ALL**
	=B	D	W0040	ZZBW	02		24-61-52	ALL
	=L	D	W0044	0005	20		24-22-31	ALL
C01286		**P006-04/ /F008**		**CB-GENERATOR DISC 1**				**ALL**
	=B	D	W0040	6014	12		24-61-32	ALL
	=B	D	W0040	ZZBQ	03		24-61-32	ALL
	=B	D	W0040	ZZBT	00		24-61-32	ALL
	=B	D	W0040	ZZYJ	02		24-61-32	ALL
	=L	D	W0044	0002	18		24-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01287		**P006-04/ /F009**		**CB-GENERATOR DISC 2**				**ALL**
	=B	D	W0040	6052	12		24-61-32	ALL
	=B	D	W0040	ZZBT	00		24-61-32	ALL
	=B	D	W0040	ZZBU	00		24-61-32	ALL
	=L	D	W0044	0004	18		24-11-21	ALL
C01290		**P006-04/ /F013**		**CB-GENERATOR BUS PWR CONT UNIT**				**ALL**
	=B	D	W0040	6096	12		24-61-52	ALL
	=B	D	W0040	ZZBW	02		24-61-52	ALL
	=B	D	W0040	ZZZB	02		24-61-52	ALL
	=L	D	W0044	0048	20		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01312		**P018-02/ /B003**		**CB-ENGINE 1 RUN/PWR**				**ALL**
	=B	D	W0020	6306	14		24-61-21	ALL
	=L	D	W0018	0852	24		73-22-31	ALL
C01313		**P006-02/ /B005**		**CB-ENGINE 2 RUN/PWR**				**ALL**
	=B	D	W0040	6247	12		24-61-24	ALL
	=B	D	W0040	ZZDH	04		24-61-24	ALL
	=B	D	W0040	ZZDI	00		24-61-24	ALL
	=L	D	W0044	0416	24		73-22-31	ALL
C01316		**P018-02/ /B001**		**CB-ENGINE 1 START LEVER CHAN A**				**ALL**
	=B	D	W0020	ZZBK	02		24-61-31	ALL
	=L	D	W0018	0855	24		76-21-11	ALL
C01317		**P018-02/ /B002**		**CB-ENGINE 1 START LEVER CHAN B**				**ALL**
	=B	D	W0020	6248	18		24-61-31	ALL
	=B	D	W0020	ZZBK	02		24-61-31	ALL
	=L	D	W0018	0856	24		76-21-11	ALL
C01318		**P006-02/ /B006**		**CB-ENGINE 2 START LEVER CHAN A**				**ALL**
	=B	D	W0040	ZZDG	02		24-61-32	ALL
	=L	D	W0044	0580	24		76-21-21	ALL
C01319		**P006-02/ /B007**		**CB-ENGINE 2 START LEVER CHAN B**				**ALL**
	=B	D	W0040	ZZDG	02		24-61-32	ALL
	=B	D	W0040	ZZYZ	02		24-61-32	ALL
	=L	D	W0044	0581	24		76-21-21	ALL
C01320		**P006-03/ /E005**		**CB-ENGINE FUEL ENGINE 1 HPSOV CONT**				**ALL**
	=B	D	W0040	ZZBF	00		24-61-33	ALL
	=B	D	W0040	ZZBG	00		24-61-33	ALL
	=L	D	W0044	0419	20		76-21-11	ALL
C01321		**P006-03/ /E003**		**CB-ENGINE FUEL ENGINE 2 HPSOV CONT**				**ALL**
	=B	D	W0040	ZZBE	04		24-61-33	ALL
	=B	D	W0040	ZZBH	00		24-61-33	ALL
	=L	D	W0044	0421	20		76-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01328		**P006-04/ /E013**		**CB-ELECTRICAL GND SERV CONT**				**ALL**
	=B	D	W0040	ZZDO	03		24-61-51	ALL
	=B	D	W0040	ZZEG	00		24-61-51	ALL
	=B	D	W0040	ZZYR	02		24-61-51	ALL
	=L	D	W0044	0008	22		24-23-51	ALL
C01338		**P006-04/ /F018**		**CB-DC BUS INDICATION BUS 2**				**ALL**
	=B	D	W0040	6075	10		24-61-24	ALL
	=B	D	W0040	6079	10		24-61-24	ALL
	=B	D	W0040	6517	14		24-61-24	ALL
	=L	D	W0044	0035	24		24-33-11	ALL
	=L	D	W0044	0589	24		24-33-13	ALL
C01340		**J009-00/ /A005**		**CB-BATTERY BUS**				**ALL**
	=L	7O	W2534	0505	08		24-31-12	ALL
C01341		**J009-00/ /**		**CB-STATIC INVERTER RCCB**				**ALL**
	3	1A	W5506	0521	24		24-34-11	ALL
	A02	F	W2536	0506	08		24-34-11	ALL
	5A	1A	W5506	0520	24		24-34-11	ALL
C01344		**P006-02/ /B019**		**CB-APU FIRE SW POWER**				**ALL**
	=B	D	W0044	6001	20		28-21-21	ALL
	=L	D	W0044	0501	20		49-62-11	ALL
C01345		**P006-03/ /A016**		**CB-LANDING GEAR AUTOBRAKE BITE CONT 2**				**ALL**
	=B	D	W0040	6078	14		24-61-24	ALL
	=L	D	W0044	0264	24		32-42-11	ALL
C01346		**P006-03/ /B016**		**CB-LANDING GEAR PARKING BRAKE**				**ALL**
	=B	D	W0040	6025	14		24-61-51	ALL
	=B	D	W0040	6091	16		24-61-51	ALL
	=L	D	W0044	0272	24		32-44-11	ALL
C01354		**P018-01/ /D006**		**CB-YAW DAMPER 2 DC**				**ALL**
	=B	D	W0020	ZZBC	00		24-61-21	ALL
	=B	D	W0020	ZZBD	00		24-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01354		**P018-01/ /D006**		**CB-YAW DAMPER 2 DC (continued)**				**ALL**
	=L	D	W0018	0020	20		22-23-11	ALL
C01355		**P006-03/ /C015**		**CB-LANDING GEAR AIR/GND SYS 2**				**ALL**
	=B	D	W0040	ZZBJ	05		24-61-33	ALL
	=B	D	W0040	ZZBN	00		24-61-33	ALL
	=L	D	W0044	6103	22		32-31-12	ALL
C01356		**P006-03/ /C016**		**CB-LANDING GEAR AIR/GND SYS 1**				**ALL**
	=B	D	W0040	6002	14		24-61-22	ALL
	=B	D	W0040	6067	16		24-61-22	ALL
	=L	D	W0044	0258	24		32-31-11	ALL
C01357		**P018-03/ /A010**		**CB-PASS CABIN LIGHTING EMER CHGR L AFT**				**ALL**
	=B	D	W0020	6263	08		24-61-21	ALL
	=B	D	W0020	ZZED	00		24-61-21	ALL
	=B	D	W0020	ZZEF	00		24-61-21	ALL
	=L	D	W0018	0345	20		33-51-11	ALL
C01358		**P018-03/ /B010**		**CB-PASS CABIN LIGHTING EMER CHGR R AFT**				**ALL**
	=B	D	W0020	6134	12		24-61-21	ALL
	=B	D	W0020	6262	10		24-61-21	ALL
	=L	D	W0018	0346	20		33-51-11	ALL
C01374		**P018-01/ /A001**		**CB-RADIO NAVIGATION VOR/MKR BCN 1**				**ALL**
	=B	D	W0020	ZZAW	04		24-54-11	ALL
	=B	D	W0020	ZZCT	00		24-54-11	ALL
	=B	D	W0020	ZZYF	02		24-54-11	ALL
	=L	D	W0018	0880	22		34-51-11	ALL
C01375		**P006-01/ /A012**		**CB-RADIO NAVIGATION VOR 2**				**ALL**
	=B	D	W0040	6112	14		24-51-24	ALL
	=B	D	W0040	ZZEO	02		24-51-24	ALL
	=L	D	W0044	0061	22		34-51-21	ALL
C01376		**P018-01/ /B001**		**CB-RADIO NAVIGATION NAV SNSR DC-1**				**ALL**
	=B	D	W0020	6053	16		24-61-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01376		**P018-01/ /B001**		**CB-RADIO NAVIGATION NAV SNSR DC-1 (continued)**				**ALL**
	=L	D	W0018	0814	22		34-51-41	ALL
C01377		**P006-01/ /A010**		**CB-RADIO NAVIGATION NAV SNSR DC-2**				**ALL**
	=B	D	W0040	6085	14		24-61-24	ALL
	=B	D	W0040	ZZYO	02		24-61-24	ALL
	=L	D	W0044	0523	22		34-51-41	ALL
C01378		**P018-01/ /A003**		**CB-RADIO NAVIGATION NAV CONT PNL 1**				**ALL**
	=B	D	W0020	ZZCH	00		24-54-11	ALL
	=B	D	W0020	ZZCU	00		24-54-11	ALL
	=L	D	W0018	0812	22		34-51-11	ALL
C01379		**P006-01/ /A015**		**CB-RADIO NAVIGATION NAV CONT PNL 2**				**ALL**
	=B	D	W0040	ZZAE	03		24-51-24	ALL
	=B	D	W0040	ZZAF	00		24-51-24	ALL
	=B	D	W0040	ZZZE	02		24-51-24	ALL
	=L	D	W0044	0062	22		34-51-21	ALL
C01382		**P018-01/ /A004**		**CB-RADIO NAVIGATION ADF 1**				**ALL**
	=B	D	W0020	6304	14		24-54-11	ALL
	=B	D	W0020	ZZAW	04		24-54-11	ALL
	=B	D	W0020	ZZCH	00		24-54-11	ALL
	=L	D	W0018	0832	22		34-57-11	ALL
C01383		**P006-01/ /A017**		**CB-RADIO NAVIGATION ADF 2 (INOP)**				**ALL**
	=B	D	W0040	ZZAE	03		24-51-24	ALL
	=B	D	W0040	ZZAG	00		24-51-24	ALL
	=L	D	W0044	0245	22		34-57-21	ALL
C01384		**P018-01/ /B004**		**CB-RADIO NAVIGATION RADIO ALTM 1**				**ALL**
	=B	D	W0020	ZZXB	02		24-51-13	ALL
	=B	D	W0020	ZZXH	02		24-51-13	ALL
	=L	D	W0018	0813	22		34-33-11	ALL
C01385		**P006-01/ /A016**		**CB-RADIO NAVIGATION RADIO ALTM 2**				**ALL**
	=B	D	W0040	ZZAF	00		24-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01385		**P006-01/ /A016**		**CB-RADIO NAVIGATION RADIO ALTM 2 (continued)**				**ALL**
	=B	D	W0040	ZZAG	00		24-51-24	ALL
	=L	D	W0044	0277	22		34-33-21	ALL
C01392		**P018-02/ /E004**		**CB-STICK SHAKER LEFT**				**ALL**
	=B	D	W0020	ZZBV	00		24-61-41	ALL
	=B	D	W0020	ZZBW	00		24-61-41	ALL
	=L	D	W0018	0703	22		27-32-11	ALL
C01393		**P006-01/ /B006**		**CB-STICK SHAKER RIGHT**				**ALL**
	=B	D	W0040	ZZCY	00		24-61-24	ALL
	=B	D	W0040	ZZCZ	00		24-61-24	ALL
	=L	D	W0044	0511	22		27-32-21	ALL
C01395		**P006-03/ /E006**		**CB-ENGINE FUEL ENGINE 1 HPSOV IND**				**ALL**
	=B	D	W0040	6056	12		24-61-33	ALL
	=B	D	W0040	6198	12		24-61-33	ALL
	=B	D	W0040	ZZBE	04		24-61-33	ALL
	=B	D	W0040	ZZBF	00		24-61-33	ALL
	=L	D	W0044	0420	24		76-21-11	ALL
C01396		**P006-03/ /E004**		**CB-ENGINE FUEL ENGINE 2 HPSOV IND**				**ALL**
	=B	D	W0040	ZZBG	00		24-61-33	ALL
	=B	D	W0040	ZZBH	00		24-61-33	ALL
	=L	D	W0044	0422	24		76-21-21	ALL
C01397		**P006-04/ /E011**		**CB-ELECTRICAL TR3 XFR RELAY CONT**				**ALL**
	=B	D	W0040	ZZDO	03		24-61-51	ALL
	=B	D	W0040	ZZEF	00		24-61-51	ALL
	=L	D	W0044	0023	24		24-32-11	ALL
	=L	D	W0044	0024	24		24-32-11	ALL
C01399		**P006-03/ /D001**		**CB-PSEU PRI**				**ALL**
	=B	D	W0040	6327	18		24-61-61	ALL
	=L	D	W0044	0274	24		32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01400		**P006-03/ /D002**		**CB-PSEU ALTN**				**ALL**
	=B	D	W0040	6095	16		24-61-52	ALL
	=B	D	W0040	6099	16		24-61-52	ALL
	=L	D	W0044	0275	22		32-64-12	ALL
C01401		**P006-03/ /D015**		**CB-LANDING GEAR AIR/GND RELAY**				**ALL**
	=B	D	W0040	6400	14		24-61-24	ALL
	=B	D	W0040	ZZCO	02		24-61-24	ALL
	=L	D	W0044	0260	22		32-31-12	ALL
C01403		**P018-03/ /A008**		**CB-PASSENGER CABIN PASS CALL LEFT**				**ALL**
	=B	D	W0020	ZZEC	00		24-61-21	ALL
	=B	D	W0020	ZZEG	00		24-61-21	ALL
	=L	D	W0018	0325	22		33-27-11	ALL
C01404		**P018-03/ /B008**		**CB-PASSENGER CABIN PASS CALL RIGHT**				**ALL**
	=B	D	W0020	6051	12		24-61-23	ALL
	=B	D	W0020	ZZBR	02		24-61-23	ALL
	=L	D	W0018	0321	22		33-27-11	ALL
C01407		**P018-03/ /C011**		**CB-PASS CABIN SIGNS NO SMOKING L (INOP)**				**ALL**
	=B	D	W0020	6302	14		24-53-11	ALL
	=B	D	W0020	ZZYQ	02		24-53-11	ALL
	=L	+	W0018	0060	20		33-25-11	ALL
	=L	+	W0018	0300	20		33-25-11	ALL
C01408		**P018-03/ /C010**		**CB-PASS CABIN SIGNS NO SMOKING R (INOP)**				**ALL**
	=B	D	W0020	6303	14		24-53-11	ALL
	=B	D	W0020	ZZYP	02		24-53-11	ALL
	=L	+	W0018	0061	20		33-25-11	ALL
	=L	+	W0018	0301	20		33-25-11	ALL
C01412		**P018-02/ /B006**		**CB-ENGINE 1 THRUST REVERSER INTLK**				**ALL**
	=B	D	W0020	ZZCB	00		24-61-41	ALL
	=B	D	W0020	ZZCD	00		24-61-41	ALL
	=L	D	W0018	0861	20		78-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01413		**P006-02/ /C006**		**CB-ENGINE 2 THRUST REVERSER INTLK**				**ALL**
	=B	D	W0040	ZZAW	00		24-61-32	ALL
	=B	D	W0040	ZZAX	00		24-61-32	ALL
	=L	D	W0044	0426	20		78-35-21	ALL
C01423		**P018-03/ /D019**		**CB-VACUUM WASTE**				**ALL**
	=B	D	W0020	6057	18		24-61-61	ALL
	=B	D	W0020	ZZBP	02		24-61-61	ALL
	=L	D	W0018	0378	20		38-32-13	ALL
C01425		**P006-03/ /A012**		**CB-CONT CABIN LIGHTING PANEL FLOOD STBY**				**ALL**
	=B	D	W0040	6005	18		24-54-11	ALL
	=L	D	W0044	0544	20		33-14-11	ALL
C01432		**P006-03/ /D016**		**CB-LANDING GEAR ALTN EXTEND SOL**				**ALL**
	=B	D	W0040	ZZYC	02		24-61-33	ALL
	=L	D	W0044	0261	22		32-35-11	ALL
C01433		**P018-03/ /A017**		**CB-EQPT COOLING LOW FLOW DETECT SUPPLY**				**ALL**
	=B	D	W0020	6051	12		24-61-23	ALL
	=B	D	W0020	6136	12		24-61-23	ALL
	=L	D	W0018	0006	22		21-27-31	ALL
C01434		**P018-03/ /A018**		**CB-EQPT COOLING LOW FLOW DETECT EXHAUST**				**ALL**
	=B	D	W0020	6047	14		24-61-21	ALL
	=L	D	W0018	0001	22		21-27-21	ALL
C01435		**P006-04/ /C014**		**CB-EQPT COOLING EXHAUST FAN CONT NORMAL**				**ALL**
	=B	D	W0040	6023	18		24-61-61	ALL
	=L	D	W0044	0637	24		21-27-21	ALL
C01436		**P006-04/ /C015**		**CB-EQPT COOLING EXHAUST FAN CONT ALTN**				**ALL**
	=B	D	W0040	6022	14		24-61-24	ALL
	=B	D	W0040	ZZZC	02		24-61-24	ALL
	=L	D	W0044	0638	24		21-27-21	ALL
C01441		**P006-03/ /A004**		**CB-FUEL FUELING IND**				**ALL**
	=B	D	W0040	6091	16		24-61-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01441		**P006-03/ /A004**		**CB-FUEL FUELING IND (continued)**				**ALL**
	=B	D	W0040	ZZDM	02		24-61-51	ALL
	=L	D	W0044	0410	22		28-41-11	ALL
	=L	D	W0044	0411	22		28-41-11	ALL
C01443		**P006-02/ /A011**		**CB-FC TE FLAP POS/SKEW SNSR & IND RIGHT**				**ALL**
	=B	D	W0040	ZZAJ	02		24-53-11	ALL
	=L	D	W0044	0562	24		27-52-11	ALL
C01444		**P006-04/ /D001**		**CB-A/C OVERBOARD EXHAUST VALVE CONT**				**ALL**
	=B	D	W0040	6013	18		24-61-32	ALL
	=L	D	W0044	0541	24		21-43-21	ALL
	=L	D	W0044	0542	24		21-43-21	ALL
C01445		**P006-04/ /D002**		**CB-A/C OVERBOARD EXH VALVE RECONFIG CONT**				**ALL**
	=B	D	W0044	0542	24		21-43-21	ALL
	=L	D	W0044	0543	24		21-43-21	ALL
C01447		**P006-02/ /C009**		**CB-FLIGHT CONT RUDDER AUTHORITY LIMITER**				**ALL**
	=B	D	W0040	0098	14		24-61-24	ALL
	=B	D	W0040	ZZYP	02		24-61-24	ALL
	=L	D	W0044	0851	20		27-25-11	ALL
C01463		**P018-03/ /D018**		**CB-WASTE/WTR LINE HEATERS**				**ALL**
	=B	D	W0020	ZZBP	02		24-61-61	ALL
	=L	D	W0018	0041	20		30-71-11	ALL
C01464		**P006-02/ /B008**		**CB-FLIGHT CONTROL ELEV TAB VLV RIGHT**				**ALL**
	=B	D	W0040	6247	12		24-61-24	ALL
	=B	D	W0040	ZZDF	07		24-61-24	ALL
	=B	D	W0040	ZZER	00		24-61-24	ALL
	=B	D	W0040	ZZYP	02		24-61-24	ALL
	=L	D	W0044	0643	20		27-31-11	ALL
C01466		**P006-04/ /E016**		**CB-DC BUS INDICATION SW HOT BAT**				**ALL**
	=B	D	W0040	6155	16		24-61-52	ALL
	=B	D	W0040	ZZZB	02		24-61-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01466		**P006-04/ /E016**		**CB-DC BUS INDICATION SW HOT BAT (continued)**				**ALL**
	=L	D	W0044	0587	24		24-33-13	ALL
C01467		**P006-04/ /D013**		**CB-AC BUS XFR BUS 2 115V AC IND**				**ALL**
	=B	D	W0040	6132	14		24-51-24	ALL
	=L	D	W0044	0583	22		24-28-11	ALL
C01468		**P006-02/ /A009**		**CB-FLIGHT CONTROL FSEU DC 2**				**ALL**
	=B	D	W0040	ZZYU	02		24-61-24	ALL
	=L	D	W0044	0591	22		27-81-11	ALL
C01471		**P006-03/ /C004**		**CB-FUEL SHUTOFF VALVES PWR PACK**				**ALL**
	=B	D	W0040	6078	14		24-61-24	ALL
	=B	D	W0040	6401	14		24-61-24	ALL
	=L	D	W0044	0645	20		28-21-21	ALL
C01472		**P006-03/ /C006**		**CB-FUEL SHUTOFF VALVES BUS**				**ALL**
	=B	D	W0040	6025	14		24-61-51	ALL
	=B	D	W0040	6089	12		24-61-51	ALL
	=L	D	W0044	1106	20		28-21-21	ALL
C01473		**P018-03/ /E018**		**CB-HOSE HEATERS**				**ALL**
	=B	D	W0020	ZZYI	02		24-51-12	ALL
	=L	D	W0018	0039	20		30-71-11	ALL
C01479		**P018-01/ /A002**		**CB-RADIO NAVIGATION MMR 1**				**ALL**
	=B	D	W0020	ZZCT	00		24-54-11	ALL
	=B	D	W0020	ZZCU	00		24-54-11	ALL
	=L	D	W0018	0807	22		34-31-11	ALL
C01480		**P006-01/ /A013**		**CB-RADIO NAVIGATION MMR 2**				**ALL**
	=B	D	W0040	ZZEO	02		24-51-24	ALL
	=B	D	W0040	ZZZE	02		24-51-24	ALL
	=L	D	W0044	0561	22		34-31-21	ALL
C01483		**P006-01/ /E008**		**CB-CMU-1 AC**				**ALL**
	=B	D	W0040	6249	14		24-51-14	ALL
	=B	D	W0040	ZZXB	02		24-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01483		**P006-01/ /E008**		**CB-CMU-1 AC (continued)**				**ALL**
	=L	D	W0044	0698	22		23-27-31	ALL
C01495		**P006-03/ /C001**		**CB-ELT INTERFACE UNIT**				**ALL**
	=B	D	W0040	6325	10		24-61-22	ALL
	=B	D	W0040	6398	10		24-61-22	ALL
	=L	D	W0044	0701	24		23-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01500		**P006-01/ /E009**		**CB-CMU/ACARS DC (INOP)**				**ALL**
	=B	D	W0040	6176	16		24-61-22	ALL
	=L	+	W0044	0772	22		23-27-31	ALL
C01514		**P006-02/ /D002**		**CB-OVERWING FLIGHT LOCK-LEFT**				**ALL**
	=B	D	W0040	0097	14		24-61-22	ALL
	=L	D	W0044	0747	20		52-71-13	ALL
C01515		**P006-02/ /D001**		**CB-OVERWING FLIGHT LOCK-RIGHT**				**ALL**
	=B	D	W0040	0098	14		24-61-24	ALL
	=B	D	W0040	6160	14		24-61-24	ALL
	=L	D	W0044	0748	20		52-71-14	ALL
C01518		**P018-03/ /D012**		**CB-EXTERIOR LIGHTING GENERAL LIGHT CONT**				**ALL**
	=B	D	W0020	ZZCP	02		24-61-21	ALL
	=B	D	W0020	ZZXU	02		24-61-21	ALL
	=L	D	W0018	0388	18		33-42-21	ALL
C01522		**P018-03/ /C017**		**CB-CARGO FIRE FWD DET A**				**ALL**
	=B	D	W0020	6133	14		24-61-21	ALL
	=B	D	W0020	ZZYK	02		24-61-21	ALL
	=L	D	W0018	0205	22		26-16-21	ALL
C01523		**P018-03/ /C016**		**CB-CARGO FIRE FWD DET B**				**ALL**
	=B	D	W0020	6281	10		24-61-23	ALL
	=B	D	W0020	ZZYL	02		24-61-23	ALL
	=L	D	W0018	0206	22		26-16-21	ALL
C01524		**P018-03/ /C019**		**CB-CARGO FIRE AFT DET A**				**ALL**
	=B	D	W0020	6134	12		24-61-21	ALL
	=B	D	W0020	ZZYK	02		24-61-21	ALL
	=L	D	W0018	0207	22		26-16-22	ALL
C01525		**P018-03/ /C018**		**CB-CARGO FIRE AFT DET B**				**ALL**
	=B	D	W0020	6136	12		24-61-23	ALL
	=B	D	W0020	ZZYL	02		24-61-23	ALL
	=L	D	W0018	0208	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01526		**P018-03/ /B017**		**CB-CARGO FIRE EXT 1**				**ALL**
	=B	D	W0020	6137	18		24-61-51	ALL
	=B	D	W0020	ZZDO	02		24-61-51	ALL
	=L	D	W0018	0209	22		26-23-11	ALL
C01528		**P018-03/ /B016**		**CB-CARGO FIRE EXT 2**				**ALL**
	=B	D	W0020	ZZDO	02		24-61-51	ALL
	=L	D	W0018	0210	22		26-23-11	ALL
C01537		**P018-02/ /C007**		**CB-VOICE RCDR RELAY**				**ALL**
	=B	D	W0020	6276	16		24-61-23	ALL
	=B	D	W0020	6338	16		24-61-23	ALL
	=L	D	W0018	0075	18		23-71-01	ALL
	=L	D	W0018	0077	20		23-71-01	ALL
	=L	D	W0018	0106	22		23-71-01	ALL
C01551		**P018-02/ /D008**		**CB-ISFD**				**ALL**
	=B	D	W0020	6183	18		24-61-31	ALL
	=B	D	W0020	6186	16		24-61-31	ALL
	=L	D	W0018	0816	20		34-24-15	ALL
C01583		**P006-01/ /C006**		**CB-ENTERTAINMENT PA SYS BAT**				**ALL**
	=B	D	W0040	6299	18		24-61-32	ALL
	=L	D	W0044	0636	20		23-31-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01613	**P006-04/ /D003**		**CB-AIR COND PACK CONT VALVES L ALT**				**ALL**
=B	D	W0040	6345	12		24-61-22	ALL
=B	D	W0040	6346	12		24-61-22	ALL
=L	D	W0044	0824	24		21-51-12	ALL
C01614	**P006-04/ /D004**		**CB-AIR COND PACK CONT VALVES R ALT**				**ALL**
=B	D	W0040	6347	12		24-61-24	ALL
=B	D	W0040	6348	12		24-61-24	ALL
=L	D	W0044	0825	24		21-51-22	ALL
C01627	**P006-05/ /B017**		**CB-CABIN UTIL RLY PWR**				**ALL**
=B	D	W0040	6199	18		24-61-61	ALL
=B	D	W0040	6392	18		24-61-61	ALL
=L	D	W0044	0889	24		24-28-41	ALL
C01628	**P006-02/ /D015**		**CB-FORCE FIGHT MONITOR**				**ALL**
=B	D	W0040	6160	14		24-61-24	ALL
=L	D	W0044	0850	20		27-23-11	ALL
C01631	**P006-02/ /A003**		**CB-AFCS INTLK 2**				**ALL**
=B	D	W0040	ZZXF	02		24-61-24	ALL
=L	D	W0044	0290	20		22-11-12	ALL
C01637	**P006-03/ /C003**		**CB-BOOST PMP CTR TNK L AUTO SHUT OFF-DC**				**ALL**
=B	D	W0040	6398	10		24-61-22	ALL
=B	D	W0040	6399	12		24-61-22	ALL
=L	D	W0044	0935	20		28-23-11	ALL
C01638	**P006-03/ /C007**		**CB-BOOST PMP CTR TNK R AUTO SHUT OFF-DC**				**ALL**
=B	D	W0040	6400	14		24-61-24	ALL
=B	D	W0040	6401	14		24-61-24	ALL
=L	D	W0044	0939	20		28-23-11	ALL
C01648	**P018-03/ /E014**		**CB-LAVATORY MIRROR LIGHT**				**ALL**
=B	D	W0020	6273	18		24-52-11	ALL
=B	D	W0020	6274	18		24-52-11	ALL
=L	D	W0018	0318	20		33-26-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01649		**P006-05/ /B007**		**CB-WINDOW HEAT POWER R3**				**ALL**
	=B	D	W0040	6239	14		24-51-24	ALL
	=L	D	W0044	0335	20		30-41-12	ALL
C01650		**P006-05/ /B019**		**CB-WINDOW HEAT POWER L3**				**ALL**
	=B	D	W0040	6238	14		24-51-14	ALL
	=L	D	W0044	0334	20		30-41-11	ALL
C01657		**P018-03/ /D017**		**CB-NITROGEN GENERATION CONTROL**				**ALL**
	=B	D	W0020	6280	10		24-61-23	ALL
	=B	D	W0020	6308	10		24-61-23	ALL
	=L	D	W0018	0414	16		47-30-11	ALL
C01658		**P006-03/ /E007**		**CB-FUEL AT S-O/UCPO BST PMP CTR TNK R AC**				**ALL**
	=B	D	W0040	6404	14		24-51-24	ALL
	=B	D	W0040	6438	14		24-51-24	ALL
	=L	D	W0044	0938	20		28-23-11	ALL
C01659		**P006-03/ /D007**		**CB-AT S-O/UCPO BST PMP CTR TNK L AC**				**ALL**
	=B	D	W0040	6437	14		24-51-14	ALL
	=L	D	W0044	0934	20		28-23-11	ALL
C01676		**P006-02/ /C010**		**CB-ELEVATOR FEEL LIMIT**				**ALL**
	=B	D	W0040	0097	14		24-61-22	ALL
	=B	D	W0040	6436	14		24-61-22	ALL
	=L	D	W0044	5521	22		27-33-11	ALL
C01680		**P018-03/ /E015**		**CB-NGS ALT PWR**				**ALL**
	=B	D	W0020	6206	16		24-61-41	ALL
	=B	D	W0020	6283	16		24-61-41	ALL
	=L	D	W0018	0096	16		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C01936		**P006-01/ /D012**		**CB-ATTENDANT PANELS**				**ALL**
	=B	D	W0040	6513	18		24-61-61	ALL
	=L	D	W0044	6098	22		23-42-14	ALL
C01945		**P006-01/ /B009**		**CB-IFE AC (INOP)**				**ALL**
	=B	D	W0040	6526	14		24-51-15	ALL
	=B	D	W0040	6606	14		24-51-15	ALL
	=L	+	W0044	0971	20		44-21-10	ALL
C01946		**P018-03/ /D008**		**CB-PROBE AUTO HEAT CAPT**				**ALL**
	=B	D	W0020	6283	16		24-61-41	ALL
	=L	D	W0018	0112	22		30-31-11	ALL
	=L	D	W0018	0158	22		30-31-11	ALL
C01947		**P018-03/ /D009**		**CB-PROBE AUTO HEAT F/O**				**ALL**
	=B	D	W0020	6280	10		24-61-23	ALL
	=B	D	W0020	6281	10		24-61-23	ALL
	=L	D	W0018	0120	22		30-31-12	ALL
	=L	D	W0018	0166	22		30-31-12	ALL
C01948		**P018-02/ /D006**		**CB-VOICE RCDR/RIPS (INOP)**				**ALL**
	=B	D	W0020	6275	16		24-61-23	ALL
	=B	D	W0020	6276	16		24-61-23	ALL
	=L	+	W0018	0107	14		23-71-01	ALL
C01949		**P006-05/ /B018**		**CB-CABIN EMER LIGHTS**				**ALL**
	=B	D	W0040	6515	18		24-61-51	ALL
	=L	D	W0044	6089	22		33-51-11	ALL
C01950		**P006-04/ /A004**		**CB-AIR CONDITIONING RAM AIR MOD LEFT**				**ALL**
	=B	D	W0040	ZZZA	02		24-61-22	ALL
	=L	D	W0044	1023	12		21-51-14	ALL
C01951		**P006-04/ /B004**		**CB-AIR CONDITIONING RAM AIR MOD RIGHT**				**ALL**
	=B	D	W0040	ZZZK	02		24-61-24	ALL
	=L	D	W0044	1024	12		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C01952		**P006-01/ /B010**		**CB-IFE DC (INOP)**				**ALL**
	=B	D	W0040	6608	14		24-61-24	ALL
	=B	D	W0040	ZZYO	02		24-61-24	ALL
	=L	+	W0044	6093	20		44-21-10	ALL
C01958		**P006-05/ /C001**		**CB-NETWORK FILE SERVER**				**ALL**
	=B	D	W0040	6544	14		24-51-14	ALL
	=B	D	W0040	6576	14		24-51-14	ALL
	=L	D	W0044	6143	22		46-13-11	ALL
C01968		**P018-03/ /B014**		**CB-EXTERIOR LIGHTING LTRTL - RIGHT**				**ALL**
	=B	D	W0020	6301	16		24-51-23	ALL
	=L	D	W0018	0193	18		33-42-21	ALL
C01969		**P018-03/ /B015**		**CB-EXTERIOR LIGHTING LTRTL - LEFT**				**ALL**
	=B	D	W0020	6300	16		24-51-13	ALL
	=L	D	W0018	0194	18		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C02029		**P006-04/ /D018**		**CB-AC BUS AC STBY BUS PWR**				**ALL**
	=B	D	W0040	0004	14		24-51-14	ALL
	=B	D	W0040	0007	14		24-51-14	ALL
	=L	D	W0044	0044	20		24-34-11	ALL
C02043		**P006-04/ /D014**		**CB-AC BUS 28V AC XFR BUS 2 SECT 2**				**ALL**
	=B	D	W0040	6010	14		24-51-24	ALL
	=B	D	W0040	6130	14		24-51-24	ALL
	=L	D	W0040	6202	20		24-53-11	ALL
C02046		**P018-03/ /C005**		**CB-28V AC XFR BUS 1 SECT 2**				**ALL**
	=B	D	W0020	6009	12		24-51-13	ALL
	=B	D	W0020	ZZAI	03		24-51-13	ALL
	=B	D	W0020	ZZAJ	00		24-51-13	ALL
	=L	D	W0020	0891	18		24-53-11	ALL
C02047		**P006-04/ /D015**		**CB-AC BUS STBY BUS 28V AC DISTR**				**ALL**
	=B	D	W0040	6049	16		24-54-11	ALL
	=B	D	W0040	ZZDX	02		24-54-11	ALL
	=L	D	W0040	6205	22		24-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C03064		**P006-04/ /D011**		**CB-ELECTRICAL GND SERV DC 1**				**ALL**
	=B	D	W0040	6346	12		24-61-22	ALL
	=B	D	W0040	ZZZD	02		24-61-22	ALL
	=L	D	W0044	6201	18		24-61-61	ALL
C03065		**P006-04/ /E012**		**CB-ELECTRICAL GND SERV DC HOT BAT**				**ALL**
	=B	D	W0040	6092	14		24-61-51	ALL
	=B	D	W0040	ZZEF	00		24-61-51	ALL
	=B	D	W0040	ZZEG	00		24-61-51	ALL
	=L	D	W0044	6203	18		24-61-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C04000		**P006-02/ /B015**		**CB-HYD SYS ENG PUMP DEPRESS VALVE 1**				**ALL**
	=B	D	W0040	6560	16		24-61-42	ALL
	=L	D	W0044	0242	22		29-11-11	ALL
C04001		**P006-02/ /A017**		**CB-HYD SYS ENG PUMP DEPRESS VALVE 2**				**ALL**
	=B	D	W0040	6554	16		24-61-33	ALL
	=L	D	W0044	0243	22		29-11-11	ALL
C04002		**P006-01/ /E012**		**CB-MAINT/BITE PANEL**				**ALL**
	=B	D	W0040	ZZCT	00		24-61-24	ALL
	=B	D	W0040	ZZCU	00		24-61-24	ALL
	=L	D	W0044	0395	20		31-65-21	ALL
C04003		**P018-02/ /D002**		**CB-MULTI FUNCTION PANEL**				**ALL**
	=B	D	W0020	ZZBZ	00		24-61-41	ALL
	=B	D	W0020	ZZCJ	00		24-61-41	ALL
	=L	D	W0018	0810	20		31-65-11	ALL
C04005		**P006-03/ /B006**		**CB-FUEL CROSS FEED VALVE IND**				**ALL**
	=B	D	W0040	ZZBY	02		24-61-33	ALL
	=L	D	W0044	6247	20		28-22-11	ALL
C04007		**P018-02/ /A005**		**CB-ENGINE 1 ALTN PWR CHAN A**				**ALL**
	=B	D	W0020	6298	16		24-51-13	ALL
	=L	D	W0018	0850	20		73-22-11	ALL
C04008		**P018-02/ /A004**		**CB-ENGINE 1 ALTN PWR CHAN B**				**ALL**
	=B	D	W0020	6119	16		24-51-13	ALL
	=B	D	W0020	ZZCQ	02		24-51-13	ALL
	=L	D	W0018	0851	20		73-22-11	ALL
C04009		**P006-02/ /D008**		**CB-ENGINE 2 ALTN PWR CHAN A**				**ALL**
	=B	D	W0040	6123	14		24-51-24	ALL
	=B	D	W0040	ZZXK	02		24-51-24	ALL
	=L	D	W0044	0414	20		73-22-11	ALL
C04010		**P006-02/ /D007**		**CB-ENGINE 2 ALTN PWR CHAN B**				**ALL**
	=B	D	W0040	ZZDV	02		24-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C04010		**P006-02/ /D007**		**CB-ENGINE 2 ALTN PWR CHAN B (continued)**				**ALL**
	=B	D	W0040	ZZXM	02		24-51-24	ALL
	=L	D	W0044	0415	20		73-22-11	ALL
C04011		**P006-05/ /A012**		**CB-APU INLET DOOR**				**ALL**
	=B	D	W0040	6555	16		24-61-52	ALL
	=L	D	W0044	6214	18		49-62-11	ALL
C04012		**P018-03/ /A001**		**CB-ANTI-ICE & RAIN WING ANTI-ICE VALVE**				**ALL**
	=B	D	W0020	6305	14		24-61-21	ALL
	=L	D	W0018	0755	20		30-11-11	ALL
C04013		**P018-03/ /E013**		**CB-EQPT COOL SMOKE DET EXHAUST**				**ALL**
	=B	D	W0020	6307	10		24-61-23	ALL
	=B	D	W0020	6308	10		24-61-23	ALL
	=L	D	W0018	0754	22		26-19-11	ALL
C04014		**P006-05/ /A011**		**CB-EQPT COOL SMOKE DET SUPPLY**				**ALL**
	=B	D	W0040	6557	14		24-61-21	ALL
	=L	D	W0044	6212	22		26-19-11	ALL
C04016		**P006-05/ /E001**		**CB-ENGINE 1 IGNITION PWR CONT**				**ALL**
	=B	D	W0040	6563	16		24-61-42	ALL
	=B	D	W0040	6564	16		24-61-42	ALL
	=L	D	W0044	6251	20		74-11-11	ALL
C04017		**P006-05/ /E002**		**CB-ENGINE 2 IGNITION PWR CONT**				**ALL**
	=B	D	W0040	6562	16		24-61-42	ALL
	=B	D	W0040	6563	16		24-61-42	ALL
	=L	D	W0044	6207	20		74-11-11	ALL
C04018		**P006-05/ /E003**		**CB-ENG 1 STBY ALTN PWR RELAY CHAN A**				**ALL**
	=B	D	W0040	6561	14		24-61-42	ALL
	=B	D	W0040	6562	16		24-61-42	ALL
	=L	D	W0044	6206	20		73-22-11	ALL
C04019		**P006-05/ /E004**		**CB-ENG 1 STBY ALTN PWR CHAN A**				**ALL**
	=B	D	W0040	6545	18		24-54-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04019		**P006-05/ /E004**		**CB-ENG 1 STBY ALTN PWR CHAN A (continued)**				**ALL**
	=L	D	W0044	6205	20		73-22-11	ALL
C04020		**P006-05/ /D018**		**CB-LANDING GEAR CONTROL 1**				**ALL**
	=B	D	W0040	6547	14		24-61-22	ALL
	=B	D	W0040	6548	14		24-61-22	ALL
	=L	D	W0044	6210	22		32-31-15	ALL
C04021		**P006-05/ /D019**		**CB-LANDING GEAR CONTROL 2**				**ALL**
	=B	D	W0040	6444	18		24-61-32	ALL
	=B	D	W0040	6553	16		24-61-32	ALL
	=L	D	W0044	6211	22		32-31-15	ALL
C04022		**P006-01/ /D010**		**CB-DISPLAY DPC 1 HOLDUP**				**ALL**
	=B	D	W0040	6101	12		24-61-51	ALL
	=B	D	W0040	ZZEB	02		24-61-51	ALL
	=L	D	W0044	0888	16		31-65-11	ALL
C04023		**P018-02/ /D005**		**CB-DISPLAY DPC 1 PRI**				**ALL**
	=B	D	W0020	ZZBX	00		24-61-41	ALL
	=B	D	W0020	ZZCO	05		24-61-41	ALL
	=B	D	W0020	ZZXX	02		24-61-41	ALL
	=L	D	W0018	0887	16		31-65-11	ALL
C04024		**P006-01/ /D009**		**CB-DISPLAY DPC 2 HOLDUP**				**ALL**
	=B	D	W0040	ZZEB	02		24-61-51	ALL
	=L	D	W0044	0398	16		31-65-21	ALL
C04025		**P006-01/ /D011**		**CB-DISPLAY DPC 2 PRI**				**ALL**
	=B	D	W0040	6253	10		24-61-24	ALL
	=B	D	W0040	6503	08		24-61-24	ALL
	=L	D	W0044	0397	16		31-65-21	ALL
C04026		**P018-02/ /D003**		**CB-DISPLAY LEFT INBOARD**				**ALL**
	=B	D	W0020	ZZCJ	00		24-61-41	ALL
	=B	D	W0020	ZZCN	00		24-61-41	ALL
	=L	D	W0018	0809	16		31-65-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C04027		**P018-02/ /D004**		**CB-DISPLAY LEFT OUTBOARD**				**ALL**
	=B	D	W0020	6264	10		24-61-41	ALL
	=B	D	W0020	ZZBX	00		24-61-41	ALL
	=B	D	W0020	ZZCN	00		24-61-41	ALL
	=L	D	W0018	0808	16		31-65-11	ALL
C04028		**P006-01/ /E011**		**CB-DISPLAY RIGHT INBOARD**				**ALL**
	=B	D	W0040	6082	08		24-61-24	ALL
	=B	D	W0040	ZZCS	00		24-61-24	ALL
	=B	D	W0040	ZZCT	00		24-61-24	ALL
	=L	D	W0044	0394	16		31-65-21	ALL
C04029		**P006-01/ /E010**		**CB-DISPLAY RIGHT OUTBOARD**				**ALL**
	=B	D	W0040	6503	08		24-61-24	ALL
	=B	D	W0040	ZZCR	06		24-61-24	ALL
	=B	D	W0040	ZZCS	00		24-61-24	ALL
	=L	D	W0044	0393	16		31-65-21	ALL
C04030		**P018-02/ /D001**		**CB-DSP CAPT EFIS CONT PNL**				**ALL**
	=B	D	W0020	6163	12		24-61-41	ALL
	=B	D	W0020	ZZBZ	00		24-61-41	ALL
	=B	D	W0020	ZZCO	05		24-61-41	ALL
	=L	D	W0018	0884	22		31-65-11	ALL
C04031		**P006-01/ /E013**		**CB-DSP F/O EFIS CONT PNL**				**ALL**
	=B	D	W0040	ZZCU	00		24-61-24	ALL
	=B	D	W0040	ZZCV	00		24-61-24	ALL
	=L	D	W0044	0396	22		31-65-21	ALL
C04032		**P006-05/ /C010**		**CB-SPOILER CONTROL ELEC PWR A**				**ALL**
	=B	D	W0040	6548	14		24-61-22	ALL
	=B	D	W0040	6601	14		24-61-22	ALL
	=L	D	W0044	6217	18		27-61-41	ALL
C04033		**P006-05/ /C012**		**CB-SPOILER CONTROL ELEC PWR B**				**ALL**
	=B	D	W0040	6564	16		24-61-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04033		**P006-05/ /C012**		**CB-SPOILER CONTROL ELEC PWR B (continued)**				**ALL**
	=L	D	W0044	6218	18		27-61-41	ALL
C04034		**P006-05/ /D21**		**CB-TIRE PRESSURE INDICATION**				**ALL**
	=B	D	W0040	6199	18		24-61-61	ALL
	=B	D	W0040	6602	18		24-61-61	ALL
	=L	D	W0044	6169	22		32-49-11	ALL
C04035		**P006-04/ /A006**		**AIR COND BLEED AIR CONTROL PRIMARY LEFT**				**ALL**
	=B	D	W0040	ZZEU	03		24-61-22	ALL
	=B	D	W0040	ZZFA	00		24-61-22	ALL
	=B	D	W0040	ZZZA	02		24-61-22	ALL
	=L	D	W0044	6243	20		36-11-13	ALL
C04036		**P006-04/ /B006**		**AIR COND BLEED AIR CONTROL PRIMARY RIGHT**				**ALL**
	=B	D	W0040	ZZEK	03		24-61-24	ALL
	=B	D	W0040	ZZFB	00		24-61-24	ALL
	=B	D	W0040	ZZZK	02		24-61-24	ALL
	=L	D	W0044	6245	20		36-11-23	ALL
C04037		**P006-04/ /D005**		**AIR COND BLEED AIR CONTROL BACKUP LEFT**				**ALL**
	=B	D	W0040	6551	16		24-61-31	ALL
	=L	D	W0044	6244	20		36-11-13	ALL
C04038		**P006-04/ /D006**		**AIR COND BLEED AIR CONTROL BACKUP RIGHT**				**ALL**
	=B	D	W0040	6552	18		24-61-32	ALL
	=L	D	W0044	6246	20		36-11-23	ALL
C04040		**P006-02/ /B011**		**CB-GROUND SPOILER CONTROL**				**ALL**
	=B	D	W0040	ZZDA	00		24-61-24	ALL
	=B	D	W0040	ZZDB	00		24-61-24	ALL
	=L	D	W0044	6213	20		27-61-49	ALL
C04044		**P006-05/ /F001**		**CB-ELEX PANEL LIGHTING, SECTION 1**				**ALL**
	=B	D	W0044	6225	14		33-11-41	ALL
	=L	D	W0044	6230	14		33-11-33	ALL
	=L	D	W0044	6255	16		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
C04044		**P006-05/ /F001**		**CB-ELEX PANEL LIGHTING, SECTION 1 (continued)**				**ALL**
	=L	D	W0044	6260	16		33-11-41	ALL
C04045		**P006-05/ /F002**		**CB-ELEX PANEL LIGHTING, SECTION 2**				**ALL**
	=B	D	W0044	6228	14		33-11-41	ALL
	=L	D	W0044	6229	14		33-11-41	ALL
	=L	D	W0044	6232	14		33-11-33	ALL
C04046		**P006-05/ /F003**		**CB-ELEX PANEL LIGHTING, SECTION 3**				**ALL**
	=B	D	W0044	6224	14		33-11-41	ALL
	=L	D	W0044	6231	16		33-11-33	ALL
	=L	D	W0044	6236	16		33-11-41	ALL
C04047		**P006-05/ /F004**		**CB-ELEX PANEL LIGHTING, SECTION 4**				**ALL**
	=B	D	W0044	6226	14		33-11-41	ALL
	=L	D	W0044	6233	16		33-11-33	ALL
	=L	D	W0044	6237	20		33-11-41	ALL
C04048		**P006-05/ /F005**		**CB-ELEX PANEL LIGHTING, SECTION 5**				**ALL**
	=B	D	W0044	6222	14		33-11-41	ALL
	=L	D	W0044	6235	18		33-11-41	ALL
C04049		**P006-05/ /D002**		**CB-ENGINE 1 EEC FAN BLOWERS (INOP)**				**ALL**
	A1	D	W0040	6574	14		24-51-14	ALL
	A1	D	W0040	6598	14		24-51-14	ALL
	A2	D	W0044	6157	18		73-22-41	ALL
	B1	D	W0040	6575	14		24-51-14	ALL
	B1	D	W0040	6599	14		24-51-14	ALL
	B2	D	W0044	6158	18		73-22-41	ALL
	C1	D	W0040	6576	14		24-51-14	ALL
	C1	D	W0040	6600	14		24-51-14	ALL
	C2	D	W0044	6159	18		73-22-41	ALL
C04050		**P006-05/ /D005**		**CB-ENGINE 2 EEC FAN BLOWERS (INOP)**				**ALL**
	A1	D	W0040	6239	14		24-51-24	ALL
	A1	D	W0040	6577	14		24-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04050		**P006-05/ /D005**		**CB-ENGINE 2 EEC FAN BLOWERS (INOP) (continued)**				**ALL**
	A2	D	W0044	6160	18		73-22-41	ALL
	B1	D	W0040	6578	14		24-51-24	ALL
	B2	D	W0044	6161	18		73-22-41	ALL
	C1	D	W0040	6579	14		24-51-24	ALL
	C2	D	W0044	6162	18		73-22-41	ALL
C04051		**P018-03/ /A013**		**CB-EXTERIOR LIGHTING POSITION LEFT**				**ALL**
	=B	D	W0020	6274	18		24-52-11	ALL
	=B	D	W0020	6311	18		24-52-11	ALL
	=L	D	W0018	0337	20		33-43-11	ALL
C04052		**P018-03/ /A012**		**CB-EXTERIOR LIGHTING POSITION RIGHT**				**ALL**
	=B	D	W0020	6309	18		24-52-11	ALL
	=B	D	W0020	6310	18		24-52-11	ALL
	=L	D	W0018	0336	20		33-43-11	ALL
C04053		**P018-03/ /C012**		**CB-ANTI COLLISION LIGHT-TAIL CONE- WHITE**				**ALL**
	=B	D	W0020	6311	18		24-52-11	ALL
	=L	D	W0018	0339	20		33-44-12	ALL
C04054		**P018-03/ /C013**		**CB-ANTI COLLISION LIGHTS-WINGLET-WHITE**				**ALL**
	=B	D	W0020	6310	18		24-52-11	ALL
	=L	D	W0018	6150	20		33-44-12	ALL
C04060		**P018-02/ /E013**		**CB - SATCOM SDU**				**ALL**
	=B	D	W0020	6338	16		24-61-23	ALL
	=L	D	W0018	0067	20		23-15-11	ALL
	=L	D	W0018	0073	22		23-15-15	ALL
C04063		**P018-03/ /B002**		**ANTI-ICE & RAIN WING ANTI-ICE VALVE-L**				**ALL**
	=B	D	W0018	6120	20		30-11-11	ALL
	=L	D	W0018	6149	20		30-11-11	ALL
C04064		**P018-03/ /B004**		**ANTI-ICE & RAIN WING ANTI-ICE VALVE-R**				**ALL**
	=B	D	W0018	6118	20		30-11-11	ALL
	=L	D	W0018	6119	20		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04065		**P006-05/ /F006**		**CB - IASC EAI INHIBITS OUT L**				**ALL**
	=B	D	W0044	6164	24		36-11-13	ALL
	=L	D	W0044	6163	24		36-11-13	ALL
C04066		**P006-05/ /F007**		**CB - IASC EAI INHIBITS OUT R**				**ALL**
	=B	D	W0044	6166	24		36-11-23	ALL
	=L	D	W0044	6165	24		36-11-23	ALL
C04067		**P006-05/ /C002**		**CB-ONS DATALOAD RLY**				**ALL**
	=B	D	W0040	6596	16		24-61-22	ALL
	=L	D	W0044	6167	22		46-13-11	ALL
C04069		**P006-05/ /D008**		**EQUIPMENT COOLING E6 RACK FAN POWER**				**ALL**
	A1	D	W0040	6238	14		24-51-14	ALL
	A1	D	W0040	6598	14		24-51-14	ALL
	A2	D	W0044	6171	20		21-27-51	ALL
	B1	D	W0040	6599	14		24-51-14	ALL
	B2	D	W0044	6172	20		21-27-51	ALL
	C1	D	W0040	6600	14		24-51-14	ALL
	C2	D	W0044	6173	20		21-27-51	ALL
C04070		**P006-05/ /D010**		**EQUIPMENT COOLING E6 RACK FAN CONTROL**				**ALL**
	=B	D	W0040	6596	16		24-61-22	ALL
	=B	D	W0040	6601	14		24-61-22	ALL
	=L	D	W0044	6174	20		21-27-51	ALL
C04071		**P018-03/ /C009**		**CB-PASS CABIN SIGNS FASTEN SEAT BELT L**				**ALL**
	=B	D	W0020	ZZYQ	02		24-53-11	ALL
	=L	D	W0018	0303	20		33-25-11	ALL
C04072		**P018-03/ /C008**		**CB-PASS CABIN SIGNS FASTEN SEAT BELT R**				**ALL**
	=B	D	W0020	ZZYP	02		24-53-11	ALL
	=L	D	W0018	0304	20		33-25-11	ALL
C04073		**P006-01/ /A008**		**CB-BROADBAND 1**				**ALL**
	=B	D	W0040	6354	14		24-51-15	ALL
	=L	+	W0044	6141	16		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04074		**P006-01/ /A009**		**CB-BROADBAND 2**				**ALL**
	=B	D	W0040	6606	14		24-51-15	ALL
	=L	+	W0044	6140	20		44-35-11	ALL
C04075		**P006-05/ /D012**		**CB-CWAP/SERVER**				**ALL**
	=B	D	W0040	6356	14		24-51-15	ALL
	=L	+	W0044	6136	20		44-35-20	ALL
C04076		**P006-05/ /D013**		**CB-BROADBAND/WIFI CONTROL**				**ALL**
	=B	D	W0040	6608	14		24-61-24	ALL
	=B	D	W0040	6628	14		24-61-24	ALL
	=L	+	W0044	6137	20		44-35-20	ALL
C04078		**J00011/ /**		**CWAP/SERVER MAINTENANCE 2**				**ALL**
	=B	D	W0096	0015	20		44-35-11	ALL
	=L	D	W0096	0012	20		44-35-11	ALL
C04082		**P006-05/ /D011**		**CB-ANTI-ICE & RAIN ENGINE 2 CONTROL**				**ALL**
	=B	D	W0040	6444	18		24-61-32	ALL
	=L	D	W0044	6020	20		30-21-32	ALL
C04084		**J00011/ /**		**BROADBAND MAINTENANCE 2**				**ALL**
	=B	D	W0096	0014	20		44-35-11	ALL
	=L	D	W0096	0011	20		44-35-11	ALL
C04093		**P006-05/ /B002**		**CB-SURVEILLANCE CAMERA DC**				**ALL**
	=B	D	W0040	6628	14		24-61-24	ALL
	=L	D	W0044	0996	20		23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
C04113		**P006-05/ /B012**		**AID PWR C/B**				**ALL**
	=B	D	W0040	6589	14		24-51-22	ALL
	=L	D	W0044	6168	22		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00042	**E002-01/ /**		**PLUG-BATT CHARGER**				**ALL**
1		W6210	0524	24		24-31-11	ALL
2		W6210	0521	20		24-31-11	ALL
3		W6210	0525	24		24-31-11	ALL
4		W6210	3204R	20		24-31-11	ALL
5		W6210	0520	24		24-31-11	ALL
6		W6210	0520	24		24-31-11	ALL
7		W6210	3204B	20		24-31-11	ALL
8		W6210	0514	24		24-31-11	ALL
9		W6210	0519	24		24-31-11	ALL
10		W6210	3204Y	20		24-31-11	ALL
11		W6210	0522	24		24-31-11	ALL
12		W6210	0523	24		24-31-11	ALL
D00044	**390/165/L008**		**PLUG-BATTERY**				**ALL**
+	Q	W2532	0501	*2		49-41-11	ALL
+	Q	W2532	0537	*1		24-31-11	ALL
-	G	W2532	2201R	20		24-31-11	ALL
-	Q	W2532	0502	*1		24-31-11	ALL
D00046	**E002-02/ /**		**PLUG-STATIC INVERT**				**ALL**
1		W2536	0520	12		24-34-11	ALL
2		W2536	0515	14		24-34-11	ALL
3		W2536	0514	12		24-34-11	ALL
4	UNUSED						ALL
D00048	**235/180/R028**		**RECP-EXT PWR AC**				**ALL**
A	H1	W6026	0001	*1		24-41-11	ALL
B	H1	W6026	0002	*1		24-41-11	ALL
C	H1	W6026	0003	*1		24-41-11	ALL
E	E	W3309	2202R	22		24-41-11	ALL
E	E	W6024	0301	22		33-29-11	ALL
F	E	W3309	2202B	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00048		**235/180/R028**		**RECP-EXT PWR AC (continued)**				**ALL**
	N	H	W6026	0004	04		24-41-11	ALL
D00057		**610/143/0**		**PLUG - (C) STRAIGHT**				**ALL**
	=A1		W7193	001CX			34-32-11	ALL
	=C1		W7193	001CO			34-32-11	ALL
D00062		**192/239/L012**		**PLUG-LEFT WINDSHIELD WIPER MOTOR**				**ALL**
	1		W2108	5501	16		30-42-11	ALL
	2	14	W2108	5502	14		30-42-11	ALL
	3		W2108	5503	24		30-42-11	ALL
D00064		**189/239/R012**		**PLUG-RIGHT WINDSHIELD WIPER MOTOR**				**ALL**
	1		W2208	5501	16		30-42-11	ALL
	2	14	W2208	5502	14		30-42-11	ALL
	3		W2208	5503	24		30-42-11	ALL
D00085		**178/237/R002**		**PLUG - (C) ANGLED 90 (OUT-1)**				**ALL**
	=A1		W7159	001CX			34-31-11	ALL
	=C1		W7159	001CO			34-31-11	ALL
D00087		**178/237/L002**		**PLUG - (C) ANGLED 90 (OUT-2)**				**ALL**
	=A1		W8159	001CX			34-31-21	ALL
	=C1		W8159	001CO			34-31-21	ALL
D00089		**1200/578/L001**		**PLUG - (C)**				**ALL**
	=A1		W7153	001CX			34-51-11	ALL
	=C1		W7153	001CO			34-51-11	ALL
D00090		**P005-17/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W2218	5559	20		21-61-51	ALL
	3		W2114	5507	24		21-61-51	ALL
	4		W2114	5504	20		21-61-51	ALL
	5		W2114	5505	20		21-61-51	ALL
	6		W2216	5654	20		33-12-11	ALL
	7		W2216	5655	20		33-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00091	**1200/578/R001**		**PLUG - (C)**				**ALL**
=A1		W8153	001CX			34-51-21	ALL
=C1		W8153	001CO			34-51-21	ALL
D00093	**580.5/144/0**		**PLUG-DME ANT NO.1**				**ALL**
=A1		W5183	001CX			34-55-11	ALL
=C1		W5183	001CO			34-55-11	ALL
D00095	**641/143/0**		**PLUG-DME ANT NO.2**				**ALL**
=A1		W5185	001CX			34-55-21	ALL
=C1		W5185	001CO			34-55-21	ALL
D00096	**P005-10/ /**		**PLUG-**				**ALL**
1		W2216	5662	20		33-12-11	ALL
2		W2216	5663	20		33-12-11	ALL
3		W2112	2012R	24		36-21-11	ALL
4		W2112	2012B	24		36-21-11	ALL
5		W2218	2019R	24		36-21-11	ALL
6		W2218	2019B	24		36-21-11	ALL
7		W2218	5578	20		36-21-11	ALL
8		W2218	5557	24		36-21-11	ALL
9		W2218	5550	20		36-21-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
		W2112	2012Z			36-21-11	ALL
		W2112	6087	20		36-21-11	ALL
		W2218	2019Z			36-21-11	ALL
		W2218	5667	20		36-21-11	ALL
D00099	**355/149/0**		**PLUG**				**ALL**
=A1		W5181	001CX			34-53-31	ALL
=C1		W5181	001CO			34-53-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00102		**E002-01/ /**		**PLUG-T/R UNIT**				**ALL**
	1		W0212	0054	18		24-32-11	ALL
	2		W0212	0053	18		24-32-11	ALL
	3		W0212	0052	18		24-32-11	ALL
	4		W0212	0051	08		24-32-11	ALL
	5		W0212	2014R	22		24-33-11	ALL
	6		W0212	0055	18		24-32-11	ALL
	7		W0212	0050	08		24-32-11	ALL
	8		W0212	2014B	22		24-33-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	DED		W0212	2014Z			24-33-11	ALL
D00104		**E004-02/ /**		**PLUG**				**ALL**
	1		W0422	0129	18		24-32-11	ALL
	2		W0422	0127	18		24-32-11	ALL
	3		W0422	0128	18		24-32-11	ALL
	4		W0422	0125	08		24-32-11	ALL
	5		W0422	2011R	22		24-33-11	ALL
	6		W0422	0124	18		24-32-11	ALL
	7		W0422	0126	08		24-32-11	ALL
	8		W0422	2011B	22		24-33-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	DED		W0422	2011Z			24-33-11	ALL
D00106		**E004-02/ /**		**PLUG**				**ALL**
	1		W0422	0132	18		24-32-11	ALL
	2		W0422	0131	18		24-32-11	ALL
	3		W0422	0130	18		24-32-11	ALL
	4		W0422	0134	08		24-32-11	ALL
	5		W0422	2012R	22		24-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00106	**E004-02/ /**		**PLUG (continued)**				**ALL**
6		W0422	0135	18		24-32-11	ALL
7		W0422	0133	08		24-32-11	ALL
8		W0422	2012B	22		24-33-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
DED		W0422	2012Z			24-33-11	ALL
D00115	**630/305/R005**		**PLUG - 90 DEG, C**				**ALL**
=A1		W5413	001CX			23-12-11	ALL
=C1		W5413	001CO			23-12-11	ALL
D00117	**727D+10/149/0**		**PLUG- VHF COMM NO.2 ANT**				**ALL**
=A1		W5417	001CX			23-12-21	ALL
=C1		W5417	001CO			23-12-21	ALL
D00127	**200/262/L035**		**PLUG-CAPT SPKR**				**ALL**
1		W3323	2001R	24		23-51-11	ALL
2		W3323	2001B	24		23-51-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D00129	**237/268/R013**		**PLUG-FO SPKR**				**ALL**
1		W3319	2001R	24		23-51-21	ALL
2		W3319	2001B	24		23-51-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D00131	**P008-06/ /**		**PLUG AUDIO SEL CAPT**				**ALL**
1		W3323	0017	24		23-22-11	ALL
2		W3323	0018	24		23-22-11	ALL
3		W3323	0019	24		23-22-11	ALL
4		W3323	0020	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00131		**P008-06/ /**		**PLUG AUDIO SEL CAPT (continued)**				**ALL**
	5		W3323	0012	24		23-22-11	ALL
	6		W3323	0023	24		23-43-11	ALL
	7		W3323	0022	24		23-43-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3323	0035	24		23-15-13	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3323	0021	22		23-27-31	ALL
	14		W3323	0036	24		23-15-13	ALL
	15		W3323	0032	20		33-18-62	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3323	0037	22		23-15-13	ALL
	19		W3323	0033	24		23-15-13	ALL
	20		W3323	0034	24		23-15-13	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D00133		**P008-06/ /**		**PLUG-AUD SEL CAPT-**				**ALL**
	A		W3323	2501R	24		23-51-11	ALL
	B		W3323	2501B	24		23-51-11	ALL
	C		W3323	0001	22		23-51-11	ALL
	D		W3323	0002	22		23-51-11	ALL
	E		W3323	0014	22		23-51-11	ALL
	F		W3323	0030	22		23-51-11	ALL
	G		W3323	0030	22		23-51-11	ALL
	H	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00133	**P008-06/ /**		**PLUG-AUD SEL CAPT- (continued)**				**ALL**
J	UNUSED						ALL
K		W3323	0007	20		33-11-33	ALL
L		W3323	0009	20		33-11-33	ALL
M	UNUSED						ALL
N		W3323	0008	20		33-18-62	ALL
P		W3323	0005	22		23-51-11	ALL
R		W3323	0042	24		23-51-11	ALL
S		W3323	0043	24		23-51-11	ALL
T		W3323	0004	22		23-51-11	ALL
U		W3323	0044	24		23-51-11	ALL
V		W3323	0003	22		23-51-11	ALL
		W3323	0011	20		23-51-11	ALL
		W3323	2501Z			23-51-11	ALL
D00135	**P008-07/ /**		**PLUG-AUDIO SEL F/O**				**ALL**
1		W3319	0017	24		23-22-11	ALL
2		W3319	0018	24		23-22-11	ALL
3		W3319	0019	24		23-22-11	ALL
4		W3319	0020	24		23-22-11	ALL
5		W3319	0013	24		23-22-11	ALL
6		W3319	0023	24		23-43-11	ALL
7		W3319	0010	24		23-43-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W3319	0039	24		23-15-13	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W3319	0022	22		23-27-31	ALL
14		W3319	0040	24		23-15-13	ALL
15		W3319	0032	20		33-18-62	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00135		**P008-07/ /**		**PLUG-AUDIO SEL F/O (continued)**				**ALL**
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3319	0041	22		23-15-13	ALL
	19		W3319	0037	24		23-15-13	ALL
	20		W3319	0038	24		23-15-13	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D00137		**P008-7/ /**		**PUG-AUDIO SEL F/O**				**ALL**
	A		W3319	2501R	24		23-51-21	ALL
	B		W3319	2501B	24		23-51-21	ALL
	C		W3319	0001	22		23-51-21	ALL
	D		W3319	0002	22		23-51-21	ALL
	E		W3319	0014	22		23-51-21	ALL
	F	UNUSED						ALL
	G		W3319	0030	22		23-51-21	ALL
	H		W3319	0030	22		23-51-21	ALL
	J	UNUSED						ALL
	K		W3319	0007	20		33-11-33	ALL
	L		W3319	0009	20		33-11-33	ALL
	M	UNUSED						ALL
	N		W3319	0008	20		33-18-62	ALL
	P		W3319	0005	22		23-51-21	ALL
	R		W3319	0042	24		23-51-21	ALL
	S		W3319	0043	24		23-51-21	ALL
	T		W3319	0004	22		23-51-21	ALL
	U		W3319	0044	24		23-51-21	ALL
	V		W3319	0003	22		23-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00137	**P008-7/ /**		**PUG-AUDIO SEL F/O (continued)**				**ALL**
		W3319	0011	20		23-51-21	ALL
		W3319	2501Z			23-51-21	ALL
D00139	**P005-15/ /**		**PLUG-**				**ALL**
A		W3327	2503R	24		23-51-31	ALL
B		W3327	2503B	24		23-51-31	ALL
C		W3327	0001	22		23-51-31	ALL
D		W3327	0002	22		23-51-31	ALL
E		W3327	0027	24		23-51-31	ALL
F		W3327	0030	22		23-51-31	ALL
G		W3327	0030	22		23-51-31	ALL
H	UNUSED						ALL
J	UNUSED						ALL
K		W3327	0007	20		33-12-12	ALL
L		W3327	0013	20		33-12-12	ALL
M	UNUSED						ALL
N		W3327	0012	20		33-18-42	ALL
P		W3327	0005	22		23-51-31	ALL
R	UNUSED						ALL
S	UNUSED						ALL
T		W3327	0004	22		23-51-31	ALL
U	UNUSED						ALL
V		W3327	0003	22		23-51-31	ALL
		W3327	0011	20		23-51-31	ALL
		W3327	2503Z			23-51-31	ALL
D00141	**P005-15/ /**		**PLUG-**				**ALL**
1		W3327	0017	24		23-22-11	ALL
2		W3327	0018	24		23-22-11	ALL
3		W3327	0019	24		23-22-11	ALL
4		W3327	0020	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00141		**P005-15/ /**		**PLUG- (continued)**				**ALL**
	5		W3327	0021	24		23-22-11	ALL
	6		W3327	0006	24		23-43-11	ALL
	7		W3327	0008	24		23-43-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3327	0035	24		23-15-13	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3327	0010	22		23-27-31	ALL
	14		W3327	0036	24		23-15-13	ALL
	15		W3327	0029	20		33-18-42	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3327	0037	22		23-15-13	ALL
	19		W3327	0033	24		23-15-13	ALL
	20		W3327	0034	24		23-15-13	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D00149A		**E001-02/*/***		**PLUG**				**ALL**
	71		W0121	001CX			34-53-31	ALL
	A01	UNUSED						ALL
	A02		W0121	2515R	22		34-53-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0121	2514R	24		34-61-14	ALL
	A07		W0121	2510R	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149A	**E001-02/*/***		**PLUG (continued)**				**ALL**
B01		W0121	0122	24		34-53-11	ALL
B02		W0121	2515B	22		34-53-11	ALL
B03		W0121	0121	24		34-53-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0121	2514B	24		34-61-14	ALL
B07		W0121	2510B	24		22-11-51	ALL
C01	UNUSED						ALL
C02		W0121	2511R	24		34-21-13	ALL
C03		W0121	0069	24		34-53-11	ALL
C04	UNUSED						ALL
C05		W0121	0227	24		34-53-11	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01	UNUSED						ALL
D02		W0121	2511B	24		34-21-13	ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05		W0121	0226	24		34-53-11	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01		W0121	0120	24		34-53-11	ALL
E02		W0121	2500R	24		34-53-11	ALL
E03		W0121	0070	24		34-53-11	ALL
E04	UNUSED						ALL
E05		W0121	2004R	24		34-45-21	ALL
E06	UNUSED						ALL
E07		W0121	2001R	24		34-53-11	ALL
F01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149A		**E001-02/*/***		**PLUG (continued)**				**ALL**
	F02		W0121	2500B	24		34-53-11	ALL
	F03		W0121	0071	24		34-53-11	ALL
	F04	UNUSED						ALL
	F05		W0121	2004B	24		34-45-21	ALL
	F06	UNUSED						ALL
	F07		W0121	2001B	24		34-53-11	ALL
	G01		W0121	0233	24		34-53-11	ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05		W0121	2005R	24		34-45-21	ALL
	G06	UNUSED						ALL
	G07		W0121	0007	24		34-53-11	ALL
	H01		W0121	0123	24		34-53-11	ALL
	H02	UNUSED						ALL
	H03		W0121	0017	24		34-53-11	ALL
	H04	UNUSED						ALL
	H05		W0121	2005B	24		34-45-21	ALL
	H06	UNUSED						ALL
	H07		W0121	2092R	24		34-21-14	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0121	0017	24		34-53-11	ALL
	J04	UNUSED						ALL
	J05		W0121	0015	24		34-53-11	ALL
	J06	UNUSED						ALL
	J07		W0121	2092B	24		34-21-14	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149A		**E001-02/*/***		**PLUG (continued)**				**ALL**
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05		W0121	0011	24		34-53-11	ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0121	001CO			34-53-31	ALL
	DED		W0121	2005Z			34-45-21	ALL
D00149B		*/*/*		**PLUG**				**ALL**
	71		W0121	004CX			34-53-31	ALL
	A01		W0121	0201	24		34-53-11	ALL
	A02		W0121	0211	24		34-53-11	ALL
	A03		W0121	0221	24		34-53-11	ALL
	A04	UNUSED						ALL
	A05		W0121	2095R	24		34-21-24	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0121	0202	24		34-53-11	ALL
	B02		W0121	0212	24		34-53-11	ALL
	B03		W0121	0222	24		34-53-11	ALL
	B04	UNUSED						ALL
	B05		W0121	2095B	24		34-21-24	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	C01		W0121	0203	24		34-53-11	ALL
	C02		W0121	0213	24		34-53-11	ALL
	C03		W0121	0223	24		34-53-11	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149B		***/*/***		**PLUG (continued)**				**ALL**
	C07	UNUSED						ALL
	D01		W0121	0204	24		34-53-11	ALL
	D02		W0121	0214	24		34-53-11	ALL
	D03		W0121	0224	24		34-53-11	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01		W0121	0205	24		34-53-11	ALL
	E02		W0121	0215	24		34-53-11	ALL
	E03		W0121	0225	24		34-53-11	ALL
	E04		W0121	0234	24		34-53-11	ALL
	E05	UNUSED						ALL
	E06		W0121	0016	24		34-53-11	ALL
	E07	UNUSED						ALL
	F01		W0121	0206	24		34-53-11	ALL
	F02		W0121	0216	24		34-53-11	ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01		W0121	0207	24		34-53-11	ALL
	G02		W0121	0217	24		34-53-11	ALL
	G03	UNUSED						ALL
	G04		W0121	0124	24		34-53-11	ALL
	G05		W0121	0050	22		34-53-11	ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149B		*/*/*		**PLUG (continued)**				**ALL**
	H01		W0121	0208	24		34-53-11	ALL
	H02		W0121	0218	24		34-53-11	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06		W0121	0125	24		34-53-11	ALL
	H07	UNUSED						ALL
	J01		W0121	0209	24		34-53-11	ALL
	J02		W0121	0219	24		34-53-11	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0121	0228	24		34-53-11	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	K01		W0121	0210	24		34-53-11	ALL
	K02		W0121	0220	24		34-53-11	ALL
	K03		W0121	0020	24		34-53-11	ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0121	004CO			34-53-31	ALL
D00149C		*/*/*		**PLUG**				**ALL**
	1		W0121	0001	20		34-53-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00149C		***/*/***		**PLUG (continued)**				**ALL**
	7		W0121	0004	20		34-53-11	ALL
	8		W0121	0008	20		34-53-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0121	0006	20		34-53-11	ALL
	12	DN	W0121	002CX			34-53-31	ALL
	13	UNUSED						ALL
	=C12		W0121	002CO			34-53-31	ALL
	=C13	UNUSED						ALL
D00150		**P006-00/ /**		**RCPT-CONT CAB SERVICE OUTLET**				**ALL**
	=G	LD	W0044	0256	20		25-29-11	ALL
	=N	LD	W0044	0255	20		25-29-11	ALL
	=P	LD	W0044	0254	20		25-29-11	ALL
D00152		**359/164/R004**		**RCPT-EQUIP RACK SERVICE OUTLET**				**ALL**
	=G	LD	W6414	0051	20		25-29-11	ALL
	=N	LD	W6414	0052	20		25-29-11	ALL
	=P	LD	W6414	0015	20		25-29-11	ALL
D00154		**P006-00/ /**		**RCPT-CONT CAB SERVICE OUTLET**				**ALL**
	=G	LD	W0044	0253	20		25-29-11	ALL
	=N	LD	W0044	0252	20		25-29-11	ALL
	=P	LD	W0044	0251	20		25-29-11	ALL
D00155A		**307/*/***		**PLUG**				**ALL**
	71		W0151	001CX			34-53-31	ALL
	A01	UNUSED						ALL
	A02		W0151	2059R	22		34-53-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0151	2058R	24		34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00155A	**307/*/***		**PLUG (continued)**				**ALL**
A07		W0151	2056R	24		22-11-51	ALL
B01		W0151	0122	24		34-53-21	ALL
B02		W0151	2059B	22		34-53-21	ALL
B03		W0151	0121	24		34-53-21	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0151	2058B	24		34-61-14	ALL
B07		W0151	2056B	24		22-11-51	ALL
C01	UNUSED						ALL
C02		W0151	2002R	24		34-21-23	ALL
C03		W0151	0069	24		34-53-21	ALL
C04	UNUSED						ALL
C05		W0151	0227	24		34-53-21	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01	UNUSED						ALL
D02		W0151	2002B	24		34-21-23	ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05		W0151	0226	24		34-53-21	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01		W0151	0120	24		34-53-21	ALL
E02		W0151	2062R	24		34-53-21	ALL
E03		W0151	0070	24		34-53-21	ALL
E04	UNUSED						ALL
E05		W0151	2004R	24		34-45-21	ALL
E06	UNUSED						ALL
E07		W0151	2001R	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00155A		**307/*/***		**PLUG (continued)**				**ALL**
	F01	UNUSED						ALL
	F02		W0151	2062B	24		34-53-21	ALL
	F03		W0151	0071	24		34-53-21	ALL
	F04	UNUSED						ALL
	F05		W0151	2004B	24		34-45-21	ALL
	F06	UNUSED						ALL
	F07		W0151	2001B	24		34-53-21	ALL
	G01		W0151	0233	24		34-53-21	ALL
	G02	UNUSED						ALL
	G03		W0151	0017	24		34-53-21	ALL
	G04	UNUSED						ALL
	G05		W0151	2005R	24		34-45-21	ALL
	G06	UNUSED						ALL
	G07		W0151	0007	24		34-53-21	ALL
	H01		W0151	0123	24		34-53-21	ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0151	2005B	24		34-45-21	ALL
	H06	UNUSED						ALL
	H07		W0151	2019R	24		34-21-24	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0151	0017	24		34-53-21	ALL
	J04	UNUSED						ALL
	J05		W0151	0015	24		34-53-21	ALL
	J06	UNUSED						ALL
	J07		W0151	2019B	24		34-21-24	ALL
	K01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00155A		**307/*/***		**PLUG (continued)**				**ALL**
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05		W0151	0011	24		34-53-21	ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0151	001CO			34-53-31	ALL
	DED		W0151	2005Z			34-45-21	ALL
	DED		W0151	2019Z			34-21-24	ALL
D00155B		***/*/***		**PLUG**				**ALL**
	71		W0151	004CX			34-53-31	ALL
	A01		W0151	0201	24		34-53-21	ALL
	A02		W0151	0211	24		34-53-21	ALL
	A03		W0151	0221	24		34-53-21	ALL
	A04	UNUSED						ALL
	A05		W0151	2016R	24		34-21-14	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0151	0202	24		34-53-21	ALL
	B02		W0151	0212	24		34-53-21	ALL
	B03		W0151	0222	24		34-53-21	ALL
	B04	UNUSED						ALL
	B05		W0151	2016B	24		34-21-14	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	C01		W0151	0203	24		34-53-21	ALL
	C02		W0151	0213	24		34-53-21	ALL
	C03		W0151	0223	24		34-53-21	ALL
	C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00155B		***/*/***		**PLUG (continued)**				**ALL**
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	D01		W0151	0204	24		34-53-21	ALL
	D02		W0151	0214	24		34-53-21	ALL
	D03		W0151	0224	24		34-53-21	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01		W0151	0205	24		34-53-21	ALL
	E02		W0151	0215	24		34-53-21	ALL
	E03		W0151	0225	24		34-53-21	ALL
	E04		W0151	0234	24		34-53-21	ALL
	E05	UNUSED						ALL
	E06		W0151	0016	24		34-53-21	ALL
	E07	UNUSED						ALL
	F01		W0151	0206	24		34-53-21	ALL
	F02		W0151	0216	24		34-53-21	ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01		W0151	0207	24		34-53-21	ALL
	G02		W0151	0217	24		34-53-21	ALL
	G03	UNUSED						ALL
	G04		W0151	0124	24		34-53-21	ALL
	G05		W0151	0048	22		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00155B	*/*/*		**PLUG (continued)**				**ALL**
G06	UNUSED						ALL
G07	UNUSED						ALL
H01		W0151	0208	24		34-53-21	ALL
H02		W0151	0218	24		34-53-21	ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06		W0151	0125	24		34-53-21	ALL
H07	UNUSED						ALL
J01		W0151	0209	24		34-53-21	ALL
J02		W0151	0219	24		34-53-21	ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05		W0151	0228	24		34-53-21	ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
K01		W0151	0210	24		34-53-21	ALL
K02		W0151	0220	24		34-53-21	ALL
K03		W0151	0020	24		34-53-21	ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
=C71		W0151	004CO			34-53-31	ALL
D00155C	*/*/*		**PLUG**				**ALL**
1		W0151	0001	20		34-53-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00155C		***/*/***		**PLUG (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0151	0004	20		34-53-21	ALL
	8		W0151	0008	20		34-53-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0151	0006	20		34-53-21	ALL
	12	DN	W0151	002CX			34-53-31	ALL
	13	UNUSED						ALL
	=C12		W0151	002CO			34-53-31	ALL
	=C13	UNUSED						ALL
D00156		**293/221/R054**		**RCPT-FWD VACUUM CLEANER**				**ALL**
	=G	XR	W6242	0051	18		25-29-11	ALL
	=N	XR	W6242	0052	18		25-29-11	ALL
	=P	XR	W6242	0035	18		25-29-11	ALL
D00158		**954/221/R059**		**RCPT-AFT VACUUM CLEANER**				**ALL**
	=G	XR	W4258	0092	18		25-29-11	ALL
	=N	XR	W4258	0093	18		25-29-11	ALL
	=P	XR	W4258	0091	18		25-29-11	ALL
D00160		**370/164/R027**		**PLUG-**				**ALL**
	1		W6110	5503	20		21-27-21	ALL
	2		W6110	5504	20		21-27-21	ALL
	3		W6110	5505	20		21-27-21	ALL
	4	UNUSED						ALL
	5		W6110	5507	22		21-27-21	ALL
	6		W6110	5508	20		21-27-21	ALL
	7		W6110	5506	20		21-27-21	ALL
D00161A		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		*/*/*		**PLUG (continued)**				**ALL**
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		***/*/***		**PLUG (continued)**				**ALL**
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		*/*/*		**PLUG (continued)**				**ALL**
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		***/*/***		**PLUG (continued)**				**ALL**
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		*/*/*		**PLUG (continued)**				**ALL**
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161A		***/*/***		**PLUG (continued)**				**ALL**
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
D00161B		***/*/***		**PLUG**				**ALL**
	71		W0121	006CX			34-55-11	ALL
	A01		W0121	2009R	24		34-55-11	ALL
	A02	UNUSED						ALL
	A03		W0121	2089R	24		34-51-11	ALL
	A04	UNUSED						ALL
	A05		W0121	0029	22		34-55-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0121	2009B	24		34-55-11	ALL
	B02	UNUSED						ALL
	B03		W0121	2089B	24		34-51-11	ALL
	B04	UNUSED						ALL
	B05		W0121	0032	22		34-55-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161B	*/*/*		**PLUG (continued)**				**ALL**
D03		W0121	2006R	24		34-55-11	ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03		W0121	2006B	24		34-55-11	ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
G01		W0121	2011R	24		34-55-11	ALL
G02	UNUSED						ALL
G03		W0121	2008R	24		34-55-11	ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
H01		W0121	2011B	24		34-55-11	ALL
H02	UNUSED						ALL
H03		W0121	2008B	24		34-55-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161B		***/*/***		**PLUG (continued)**				**ALL**
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05		W0121	0026	22		34-55-11	ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0121	006CO			34-55-11	ALL
	DED		W0121	2006Z			34-55-11	ALL
	DED		W0121	2009ZI			34-55-11	ALL
	DED		W0121	2011Z			34-55-11	ALL
D00161C		***/*/***		**PLUG**				**ALL**
	1		W0121	0021	22		34-55-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00161C	***/*/***		**PLUG (continued)**				**ALL**
7		W0121	0019	22		34-55-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0121	0018	22		34-55-11	ALL
12	DN	W0121	005CX			34-55-11	ALL
13	UNUSED						ALL
=C12		W0121	005CO			34-55-11	ALL
=C13	UNUSED						ALL
D00162	**378/163/R027**		**PLUG-**				**ALL**
1		W6414	5502	20		21-27-21	ALL
2		W6414	5503	20		21-27-21	ALL
3		W6414	5504	20		21-27-21	ALL
4	UNUSED						ALL
5		W6414	5506	22		21-27-21	ALL
6		W6414	5507	20		21-27-21	ALL
7		W6414	5505	20		21-27-21	ALL
D00164	**213/191/R025**		**PLUG-LOW FLOW SENSOR**				**ALL**
1		W5156	5508	22		21-27-21	ALL
2	UNUSED						ALL
3		W5156	5510	20		21-27-21	ALL
4		W5156	5511	20		21-27-21	ALL
5	UNUSED						ALL
6		W5156	5531	22		21-27-21	ALL
7		W5156	5512	20		33-18-11	ALL
8		W5156	5513	22		34-21-16	ALL
9		W5156	5514	22		21-27-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00164		**213/191/R025**		**PLUG-LOW FLOW SENSOR (continued)**				**ALL**
	12	UNUSED						ALL
D00169A		**307/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169A		**307/*/***		**PLUG (continued)**				**ALL**
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169A		**307/*/***		**PLUG (continued)**				**ALL**
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169A		**307/*/***		**PLUG (continued)**				**ALL**
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169A		**307/*/***		**PLUG (continued)**				**ALL**
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169A		**307/*/***		**PLUG (continued)**				**ALL**
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
D00169B		***/*/***		**PLUG**				**ALL**
	71		W0151	006CX			34-55-21	ALL
	A01		W0151	2009R	24		34-55-21	ALL
	A02	UNUSED						ALL
	A03		W0151	2014R	24		34-51-21	ALL
	A04	UNUSED						ALL
	A05		W0151	0029	22		34-55-21	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0151	2009B	24		34-55-21	ALL
	B02	UNUSED						ALL
	B03		W0151	2014B	24		34-51-21	ALL
	B04	UNUSED						ALL
	B05		W0151	0022	22		34-55-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169B		***/*/***		**PLUG (continued)**				**ALL**
	C07	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0151	2006R	24		34-55-21	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03		W0151	2006B	24		34-55-21	ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01		W0151	2011R	24		34-55-21	ALL
	G02	UNUSED						ALL
	G03		W0151	2008R	24		34-55-21	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169B	***/*/***		**PLUG (continued)**				**ALL**
H01		W0151	2011B	24		34-55-21	ALL
H02	UNUSED						ALL
H03		W0151	2008B	24		34-55-21	ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05		W0151	0026	22		34-55-21	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
=C71		W0151	006CO			34-55-21	ALL
DED		W0151	2006Z			34-55-21	ALL
DED		W0151	2009ZI			34-55-21	ALL
DED		W0151	2011Z			34-55-21	ALL
D00169C	***/*/***		**PLUG**				**ALL**
1		W0151	0021	22		34-55-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00169C		***/*/***		**PLUG (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0151	0019	22		34-55-21	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0151	0018	22		34-55-21	ALL
	12	DN	W0151	005CX			34-55-21	ALL
	13	UNUSED						ALL
	=C12		W0151	005CO			34-55-21	ALL
	=C13	UNUSED						ALL
D00179		**P005-07/ /**		**PLUG-VOICE REC CONT PNL**				**ALL**
	A		W3329	0014	24		23-71-01	ALL
	B		W3329	0011	24		23-71-01	ALL
	C		W3329	0010	24		23-71-01	ALL
	D		W3329	2007R	24		23-71-01	ALL
	E		W3329	2007B	24		23-71-01	ALL
	F		W3329	0015	20		23-71-01	ALL
	G		W3329	0002	22		23-71-01	ALL
	H		W3329	0001	22		23-71-01	ALL
	J	UNUSED						ALL
	K		W3329	2001B	24		23-71-01	ALL
	L		W3329	2001R	24		23-71-01	ALL
	M	UNUSED						ALL
	N		W3329	0004	22		23-71-01	ALL
	P		W3329	0005	22		23-71-01	ALL
	R	UNUSED						ALL
	S	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00179	**P005-07/ /**		**PLUG-VOICE REC CONT PNL (continued)**				**ALL**
T	UNUSED						ALL
U	UNUSED						ALL
V		W3329	2002B	24		23-71-01	ALL
W		W3329	2002R	24		23-71-01	ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z	UNUSED						ALL
DED		W3329	2001Z			23-71-01	ALL
DED		W3329	2007Z			23-71-01	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-	UNUSED						ALL
F-		W3329	0004	22		23-71-01	ALL
G-		W3329	0005	22		23-71-01	ALL
H-	UNUSED						ALL
I-	UNUSED						ALL
J-	UNUSED						ALL
K-	UNUSED						ALL
M-	UNUSED						ALL
N-	UNUSED						ALL
P-	UNUSED						ALL
Q-		W3329	0003	22		23-71-01	ALL
R-		W3329	0003	22		23-71-01	ALL
S-	UNUSED						ALL
T-	UNUSED						ALL
D00183A	**0923/294/000**		**PLUG-FLT RECORDER**				**ALL**
1		W0767	0007	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00183A		**0923/294/000**		**PLUG-FLT RECORDER (continued)**				**ALL**
	2		W0767	0005	20		31-31-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0767	0004	20		31-31-11	ALL
	7		W0767	2002R	22		31-31-11	ALL
	8		W0767	2002B	22		31-31-11	ALL
	9		W0767	2001R	22		31-31-11	ALL
	10		W0767	2001B	22		31-31-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0767	0001	22		31-31-11	ALL
	22		W0767	0002	22		31-31-11	ALL
	23		W0767	0008	22		31-31-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00183A	**0923/294/000**		**PLUG-FLT RECORDER (continued)**				**ALL**
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
56	UNUSED						ALL
57	UNUSED						ALL
DED		W0767	2001Z			31-31-11	ALL
DED		W0767	2002Z			31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00183B		**0923/295/000**		**PLUG-FLT RECORDER**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00183B	**0923/295/000**		**PLUG-FLT RECORDER (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
56	UNUSED						ALL
57	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00192		**952/186/R035**		**PLUG-**				**ALL**
	1		W5146	0001	22		38-41-11	ALL
	2		W5146	0002	22		38-41-11	ALL
	3		W5146	0003	22		38-41-11	ALL
	4		W5146	0004	20		38-41-11	ALL
	5		W5146	0005	20		38-41-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D00193		**P008-52/ /**		**PLUG**				**ALL**
	A		W6491	0014	20		34-41-11	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D		W6491	0169	24		34-41-11	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G		W6491	0013	22		34-41-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K		W6491	0019	24		34-41-11	ALL
	L		W6491	0020	24		34-41-11	ALL
	M		W6491	0012	24		34-41-11	ALL
	N	UNUSED						ALL
	P		W6491	0530	20		33-11-41	ALL
	R	UNUSED						ALL
	S	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00193		**P008-52/ /**		**PLUG (continued)**				**ALL**
	T	UNUSED						ALL
	U		W6491	0010	24		34-41-11	ALL
	V		W6491	0009	24		34-41-11	ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
			W6491	0042	20		34-41-11	ALL
			W6491	2011Z			34-41-11	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-		W6491	0531	20		33-11-41	ALL
	F-		W6491	0011	24		34-41-11	ALL
	G-	UNUSED						ALL
	H-		W6491	2011R	24		34-41-11	ALL
	J-		W6491	2011B	24		34-41-11	ALL
D00199A		***/*/***		**PLUG - VHF 1**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00199A		***/*/***		**PLUG - VHF 1 (continued)**				**ALL**
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00199A		*/*/*		**PLUG - VHF 1 (continued)**				**ALL**
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D00199B		*/*/*		**PLUG - VHF 1**				**ALL**
	A01		W0131	2502R	24		23-12-11	ALL
	A02		W0131	0039	22		23-12-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0137	2501R	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00199B		***/*/***		**PLUG - VHF 1 (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0131	2519R	24		23-12-41	ALL
	A12	VP	W0131	2531R	24		23-27-37	ALL
	A13		W0131	2504R	24		23-22-11	ALL
	A14	UNUSED						ALL
	A15		W0131	2503R	24		23-12-11	ALL
	B01		W0131	2502B	24		23-12-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0137	2501B	24		23-12-41	ALL
	B08	UNUSED						ALL
	B09		W0131	0059	24		23-12-11	ALL
	B10	UNUSED						ALL
	B11		W0131	2519B	24		23-12-41	ALL
	B12	VP	W0131	2531B	24		23-27-37	ALL
	B13		W0131	2504B	24		23-22-11	ALL
	B14		W0131	0038	24		23-12-11	ALL
	B15		W0131	2503B	24		23-12-11	ALL
	C01		W0131	0035	22		23-12-11	ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00199B	*/*/*		**PLUG - VHF 1 (continued)**				**ALL**
C07	UNUSED						ALL
C08	UNUSED						ALL
C09		W0131	0059	24		23-12-11	ALL
C10	VP	W0131	2532R	24		23-27-37	ALL
C11		W0131	0435	22		23-12-11	ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14		W0131	2525R	24		23-12-11	ALL
C15	UNUSED						ALL
D01		W0131	0057	24		31-31-17	ALL
D02	UNUSED						ALL
D03		W0131	0034	22		23-12-11	ALL
D04	UNUSED						ALL
D05		W0131	0124	22		23-12-11	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	VP	W0131	2532B	24		23-27-37	ALL
D11		W0131	0132	24		23-12-41	ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14		W0131	2525B	24		23-12-11	ALL
D15	UNUSED						ALL
DED		W0131	2502ZI			23-12-11	ALL
DED		W0131	2503ZI			23-12-11	ALL
DED		W0131	2504ZI			23-22-11	ALL
DED		W0131	2531Z			23-27-37	ALL
DED		W0131	2532Z			23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00199C		***/*/***		**PLUG - VHF 1**				**ALL**
	1	DN	W0131	001CX			23-12-11	ALL
	2		W0131	0029	16		23-12-11	ALL
	3	UNUSED						ALL
	4		W0131	0033	16		23-12-11	ALL
	5	UNUSED						ALL
	=C1		W0131	001CO			23-12-11	ALL
	=C5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00201A	*/*/*		**PLUG-VHF-2 TRANSCEIVER**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00201A		***/*/***		**PLUG-VHF-2 TRANSCEIVER (continued)**				**ALL**
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00201A	*/*/*		**PLUG-VHF-2 TRANSCEIVER (continued)**				**ALL**
D14	UNUSED						ALL
D15	UNUSED						ALL
D00201B	*/*/*		**PLUG-VHF-2 TRANSCEIVER**				**ALL**
A01		W0151	2507R	24		23-12-21	ALL
A02		W0151	0037	22		23-12-21	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W0151	2031R	24		23-12-41	ALL
A08	UNUSED						ALL
A09		W0151	0084	24		23-12-21	ALL
A10	UNUSED						ALL
A11		W0151	2034R	24		23-12-41	ALL
A12	VP	W0151	2046R	24		23-27-37	ALL
A13		W0151	2003R	24		23-22-11	ALL
A14	UNUSED						ALL
A15		W0151	2508R	24		23-12-21	ALL
B01		W0151	2507B	24		23-12-21	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0151	2031B	24		23-12-41	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0151	2034B	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00201B		***/*/***		**PLUG-VHF-2 TRANSCEIVER (continued)**				**ALL**
	B12	VP	W0151	2046B	24		23-27-37	ALL
	B13		W0151	2003B	24		23-22-11	ALL
	B14		W0151	0039	24		23-12-21	ALL
	B15		W0151	2508B	24		23-12-21	ALL
	C01		W0151	0049	22		23-12-21	ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09		W0151	0084	24		23-12-21	ALL
	C10	VP	W0151	2050R	24		23-27-37	ALL
	C11		W0151	0072	22		23-12-21	ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14		W0151	2041R	24		23-12-21	ALL
	C15	UNUSED						ALL
	D01		W0151	0052	24		31-31-17	ALL
	D02	UNUSED						ALL
	D03		W0151	0036	22		23-12-21	ALL
	D04	UNUSED						ALL
	D05		W0151	0025	22		23-12-21	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	VP	W0151	2050B	24		23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00201B	***/*/***		**PLUG-VHF-2 TRANSCEIVER (continued)**				**ALL**
D11		W0151	0083	24		23-12-41	ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14		W0151	2041B	24		23-12-21	ALL
D15	UNUSED						ALL
DED		W0151	2003ZI			23-22-11	ALL
DED		W0151	2046Z			23-27-37	ALL
DED		W0151	2050Z			23-27-37	ALL
DED		W0151	2507ZI			23-12-21	ALL
DED		W0151	2508ZI			23-12-21	ALL
PERG	1A	W0151	2003ZO			23-22-11	ALL
PERG	1A	W0151	2031Z			23-12-41	ALL
PERG	1A	W0151	2034Z			23-12-41	ALL
PERG	1A	W0151	2041Z			23-12-21	ALL
PERG	1A	W0151	2507ZO			23-12-21	ALL
PERG	1A	W0151	2508ZO			23-12-21	ALL
D00201C	***/*/***		**PLUG-VHF-2 TRANSCEIVER**				**ALL**
1	DN	W0151	007CX			23-12-21	ALL
2		W0151	0031	16		23-12-21	ALL
3	UNUSED						ALL
4		W0151	0035	16		23-12-21	ALL
5	UNUSED						ALL
=C1		W0151	007CO			23-12-21	ALL
=C5	UNUSED						ALL
D00203	**P008-71/ /**		**PLUG-**				**ALL**
1		W2413	0001	20		23-12-11	ALL
2		W2413	2501R	24		23-12-41	ALL
3		W2413	2501B	24		23-12-41	ALL
4		W2413	0004	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00203		**P008-71/ /**		**PLUG- (continued)**				**ALL**
	5		W2413	2507R	24		23-12-41	ALL
	6		W2413	2507B	24		23-12-41	ALL
	7		W2413	0047	24		23-12-41	ALL
	8		W2413	2505R	24		23-12-41	ALL
	9		W2413	2505B	24		23-12-41	ALL
	10		W2413	0010	22		23-12-11	ALL
	11		W2413	0011	22		23-12-31	ALL
	12		W2413	0012	22		23-12-21	ALL
	13	UNUSED						ALL
	14		W2413	0054	24		23-27-31	ALL
	15	VP	W2413	0055	24		23-27-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	VP	W2413	0059	24		23-27-31	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2413	0030	24		23-12-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W2413	0026	22		23-11-11	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2413	0029	22		23-11-11	ALL
	30		W2413	0030	24		23-12-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00203		**P008-71/ /**		**PLUG- (continued)**				**ALL**
	34	UNUSED						ALL
	35		W2413	0035	20		33-18-62	ALL
	36		W2413	0036	20		33-18-62	ALL
	37	16	W2413	0037	16		33-11-33	ALL
	38	16	W2413	0038	16		33-11-33	ALL
	39	UNUSED						ALL
	40	18	W2413	0040	18		23-12-11	ALL
	41		W2413	0041	20		23-12-11	ALL
	DED		W2413	2501Z			23-12-41	ALL
	DED		W2413	2505Z			23-12-41	ALL
	DED		W2413	2507Z			23-12-41	ALL
D00209		**P008-72/ /**		**PLUG-**				**ALL**
	1		W2415	0001	20		23-12-21	ALL
	2		W2415	2501R	24		23-12-41	ALL
	3		W2415	2501B	24		23-12-41	ALL
	4		W2415	0004	24		23-12-41	ALL
	5		W2415	2505R	24		23-12-41	ALL
	6		W2415	2505B	24		23-12-41	ALL
	7		W2415	0047	24		23-12-41	ALL
	8		W2415	2508R	24		23-12-41	ALL
	9		W2415	2508B	24		23-12-41	ALL
	10		W2415	0010	22		23-12-11	ALL
	11		W2415	0011	22		23-12-31	ALL
	12		W2415	0012	22		23-12-21	ALL
	13	UNUSED						ALL
	14		W2415	0054	24		23-27-31	ALL
	15	VP	W2415	0055	24		23-27-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00209		**P008-72/ /**		**PLUG- (continued)**				**ALL**
	18	UNUSED						ALL
	19	VP	W2415	0059	24		23-27-31	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2415	0023	24		23-12-21	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W2415	0026	22		23-11-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2415	0029	22		23-11-21	ALL
	30	UNUSED						ALL
	31		W2415	0023	24		23-12-21	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W2415	0035	20		33-18-62	ALL
	36		W2415	0036	20		33-18-62	ALL
	37		W2415	0037	20		33-11-41	ALL
	38		W2415	0038	20		33-11-41	ALL
	39	UNUSED						ALL
	40	18	W2415	0040	18		23-12-21	ALL
	41		W2415	0041	20		23-12-21	ALL
	DED		W2415	2501Z			23-12-41	ALL
	DED		W2415	2505Z			23-12-41	ALL
	DED		W2415	2508Z			23-12-41	ALL
D00211		**P008-29/ /**		**PLUG-ATC DUAL CONT**				**ALL**
	1		W2177	0001	20		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00211	**P008-29/ /**		**PLUG-ATC DUAL CONT (continued)**				**ALL**
2		W2177	0002	20		33-11-33	ALL
3		W2177	0003	20		34-53-11	ALL
4		W2177	0004	20		34-53-11	ALL
5	VP	W2177	0005	20		34-53-11	ALL
6		W2177	0006	20		34-53-11	ALL
7		W2177	0007	24		34-53-11	ALL
8		W2177	0008	20		34-53-11	ALL
9	VP	W2177	0009	20		34-53-11	ALL
10	VP	W2177	0010	20		34-53-11	ALL
11		W2177	0011	24		34-53-11	ALL
12		W2177	0012	24		34-53-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2177	0015	24		34-53-11	ALL
16		W2177	0016	24		34-53-11	ALL
17	UNUSED						ALL
18		W2177	0018	20		33-18-61	ALL
19	UNUSED						ALL
20		W2177	0020	24		34-53-11	ALL
21		W2177	0021	20		33-18-61	ALL
22		W2177	2001R	24		34-53-11	ALL
23		W2177	2001B	24		34-53-11	ALL
24		W2177	0024	24		34-53-11	ALL
		W2177	0028	20		34-53-11	ALL
		W2177	2001Z			34-53-11	ALL
D00229	**ORSS/446/**		**PLUG-CONDUCTIVE**				**ALL**
1		W1034	2006R	20		27-52-11	ALL
2		W1034	2006B	20		27-52-11	ALL
3		W1034	2007B	20		27-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00229		**ORSS/446/**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	4		W1034	2004R	20		27-32-11	ALL
	5		W1034	2004B	20		27-32-11	ALL
	6		W1034	3004R	20		27-32-11	ALL
	7		W1034	3004B	20		27-32-11	ALL
	8		W1034	3004Y	20		27-32-11	ALL
	9		W1034	2005R	20		22-11-11	ALL
	10		W1034	2005B	20		22-11-11	ALL
	11		W1034	2007R	20		27-52-11	ALL
	12		W1034	3005R	20		22-12-41	ALL
	13		W1034	3005B	20		22-12-41	ALL
	14		W1034	3005Y	20		22-12-41	ALL
	15		W1034	0513	20		27-52-11	ALL
	16	UNUSED						ALL
	S/R		W1034	2004Z			27-32-11	ALL
	S/R		W1034	2005Z			22-11-11	ALL
	S/R		W1034	2006ZI			27-52-11	ALL
	S/R		W1034	2006ZO			27-52-11	ALL
	S/R		W1034	2007ZI			27-52-11	ALL
	S/R		W1034	2007ZO			27-52-11	ALL
	S/R		W1034	3004Z			27-32-11	ALL
	S/R		W1034	3005Z			22-12-41	ALL
D00235A		***/*/***		**PLUG**				**ALL**
	1		W0111	0399	20		34-21-21	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235A	*/*/*		**PLUG (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235A		***/*/***		**PLUG (continued)**				**ALL**
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W0111	0715	20		34-21-11	ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52		W0111	0386	20		34-21-21	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60		W0111	0374	22		34-21-11	ALL
	61	UNUSED						ALL
	62	UNUSED						ALL
	63	UNUSED						ALL
	64	UNUSED						ALL
	65	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235A	*/*/*		**PLUG (continued)**				**ALL**
66	UNUSED						ALL
67	UNUSED						ALL
68	UNUSED						ALL
69		W0111	0219	22		34-21-16	ALL
70	UNUSED						ALL
71	UNUSED						ALL
72	UNUSED						ALL
73		W0111	0429	22		34-51-41	ALL
74		W0111	0351	22		34-21-16	ALL
75		W0111	0578	22		23-43-11	ALL
76	UNUSED						ALL
77	UNUSED						ALL
78		W0111	0388	20		34-21-21	ALL
79		W0111	0433	22		34-51-41	ALL
80	UNUSED						ALL
81	UNUSED						ALL
82	UNUSED						ALL
83	UNUSED						ALL
84	UNUSED						ALL
85	UNUSED						ALL
86	UNUSED						ALL
87	UNUSED						ALL
88	UNUSED						ALL
89	UNUSED						ALL
90	UNUSED						ALL
91	UNUSED						ALL
92		W0111	0716	22		34-61-12	ALL
93		W0111	0717	22		34-61-12	ALL
94		W0111	0389	20		34-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235A		***/*/***		**PLUG (continued)**				**ALL**
	95	UNUSED						ALL
	96	UNUSED						ALL
	97	UNUSED						ALL
	98	UNUSED						ALL
	99	UNUSED						ALL
	100	UNUSED						ALL
	101	UNUSED						ALL
	102	UNUSED						ALL
	103	UNUSED						ALL
	104	UNUSED						ALL
	105	UNUSED						ALL
	106	UNUSED						ALL
	107	UNUSED						ALL
	108	UNUSED						ALL
	109	UNUSED						ALL
	110	UNUSED						ALL
	111		W0111	0390	20		34-21-21	ALL
	112		W0111	0391	20		34-21-21	ALL
	113	UNUSED						ALL
	114		W0111	0576	22		23-43-11	ALL
	115	UNUSED						ALL
	116	UNUSED						ALL
	117		W0111	0428	22		34-51-41	ALL
	118		W0111	0357	22		34-21-16	ALL
	119	UNUSED						ALL
	120	UNUSED						ALL
	121	UNUSED						ALL
	122	UNUSED						ALL
	123	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235A	***/*/***		**PLUG (continued)**				**ALL**
124	UNUSED						ALL
D00235B	***/*/***		**PLUG**				**ALL**
1		W0111	0571	20		34-21-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0111	0358	22		34-21-16	ALL
10	UNUSED						ALL
11		W0111	0122	20		34-61-22	ALL
12		W0111	0561	22		34-51-41	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0111	0353	22		34-21-16	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235B		***/*/***		**PLUG (continued)**				**ALL**
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W0111	0394	20		34-21-21	ALL
	35	UNUSED						ALL
	36		W0111	2198B	24		34-61-22	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41		W0111	0379	22		34-21-15	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46		W0111	2097R	24		34-21-13	ALL
	47	UNUSED						ALL
	48		W0111	2199B	24		34-61-22	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	56	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235B	*/*/*		**PLUG (continued)**				**ALL**
57		W0111	0382	22		34-21-15	ALL
58	UNUSED						ALL
59	UNUSED						ALL
60		W0111	0356	22		34-21-21	ALL
61	UNUSED						ALL
62	UNUSED						ALL
63		W0111	2197B	24		34-61-22	ALL
64	UNUSED						ALL
65		W0111	0123	20		34-61-22	ALL
66		W0111	2197R	24		34-61-22	ALL
67		W0111	2199R	24		34-61-22	ALL
68		W0111	2198R	24		34-61-22	ALL
69		W0111	0355	22		34-21-16	ALL
70	UNUSED						ALL
71	UNUSED						ALL
72	UNUSED						ALL
73		W0111	0563	22		34-51-41	ALL
74	UNUSED						ALL
75		W0111	0719	22		34-61-12	ALL
76		W0111	0718	22		34-61-12	ALL
77	UNUSED						ALL
78	UNUSED						ALL
79		W0111	0568	22		34-51-41	ALL
80	UNUSED						ALL
81	UNUSED						ALL
82	UNUSED						ALL
83	UNUSED						ALL
84	UNUSED						ALL
85	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235B		***/*/***		**PLUG (continued)**				**ALL**
	86	UNUSED						ALL
	87	UNUSED						ALL
	88	UNUSED						ALL
	89		W0111	2097B	24		34-21-13	ALL
	90	UNUSED						ALL
	91	UNUSED						ALL
	92	UNUSED						ALL
	93	UNUSED						ALL
	94	UNUSED						ALL
	95	UNUSED						ALL
	96	UNUSED						ALL
	97	UNUSED						ALL
	98	UNUSED						ALL
	99		W0111	2110B	22		34-21-15	ALL
	100		W0111	0381	22		34-21-15	ALL
	101	UNUSED						ALL
	102	UNUSED						ALL
	103	UNUSED						ALL
	104	UNUSED						ALL
	105	UNUSED						ALL
	106	UNUSED						ALL
	107	UNUSED						ALL
	108	UNUSED						ALL
	109	UNUSED						ALL
	110	UNUSED						ALL
	111	UNUSED						ALL
	112	UNUSED						ALL
	113	UNUSED						ALL
	114	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00235B	***/*/***		**PLUG (continued)**				**ALL**
115	UNUSED						ALL
116	UNUSED						ALL
117	UNUSED						ALL
118		W0111	0380	22		34-21-15	ALL
119		W0111	2113B	24		34-21-23	ALL
120		W0111	2113R	24		34-21-23	ALL
121		W0111	2110R	22		34-21-15	ALL
122	UNUSED						ALL
123	UNUSED						ALL
124	UNUSED						ALL
DED		W0111	2197Z			34-61-22	ALL
DED		W0111	2198Z			34-61-22	ALL
DED		W0111	2199Z			34-61-22	ALL
		W0111	2097Z			34-21-13	ALL
		W0111	2110Z			34-21-15	ALL
		W0111	2113Z			34-21-23	ALL
D00263	**P008-25/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W2149	0025	22		34-51-41	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2149	0011	22		34-51-11	ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00263		**P008-25/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W2149	0015	22		34-51-41	ALL
	16	UNUSED						ALL
	17	VP	W2149	2004R	24		22-11-51	ALL
	18	VP	W2149	2004B	24		22-11-51	ALL
	19	UNUSED						ALL
	20		W2149	2002R	24		34-51-11	ALL
	21		W2149	2002B	24		34-51-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2149	0028	20		34-51-41	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W2149	0031	22		34-51-41	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W2149	0035	22		34-55-11	ALL
	36		W2149	0056	22		34-51-11	ALL
	37	UNUSED						ALL
	38		W2149	0038	22		34-51-41	ALL
	39	UNUSED						ALL
	40		W2149	0033	22		34-51-41	ALL
	41	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00263	**P008-25/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46		W2149	0032	22		34-51-41	ALL
47	UNUSED						ALL
48		W2149	0048	22		34-51-11	ALL
49	UNUSED						ALL
50	UNUSED						ALL
51		W2149	0051	22		34-51-41	ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W2149	2002Z			34-51-11	ALL
CAP	Y	W2149	0023	22		SPARE	ALL
DED		W2149	2004Z			22-11-51	ALL
D00265	**P008-26/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W2151	0025	22		34-51-41	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2151	0011	22		34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00265		**P008-26/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W2151	0015	22		34-51-41	ALL
	16	UNUSED						ALL
	17	VP	W2151	2004R	24		22-11-51	ALL
	18	VP	W2151	2004B	24		22-11-51	ALL
	19	UNUSED						ALL
	20		W2151	2002R	24		34-51-21	ALL
	21		W2151	2002B	24		34-51-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2151	0028	20		34-51-41	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W2151	0031	22		34-51-41	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W2151	0035	22		34-55-21	ALL
	36		W2151	0056	22		34-51-21	ALL
	37	UNUSED						ALL
	38		W2151	0038	22		34-51-41	ALL
	39	UNUSED						ALL
	40		W2151	0033	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00265		**P008-26/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46		W2151	0032	22		34-51-41	ALL
	47	UNUSED						ALL
	48		W2151	0048	22		34-51-21	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51		W2151	0051	22		34-51-41	ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W2151	2002Z			34-51-21	ALL
	DED		W2151	2004Z			22-11-51	ALL
D00275		**ORSS/446/**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1024	2006R	20		27-52-11	ALL
	2		W1024	2006B	20		27-52-11	ALL
	3		W1024	2007B	20		27-52-11	ALL
	4		W1024	2004R	20		27-32-21	ALL
	5		W1024	2004B	20		27-32-21	ALL
	6		W1024	3004R	20		27-32-21	ALL
	7		W1024	3004B	20		27-32-21	ALL
	8		W1024	3004Y	20		27-32-21	ALL
	9		W1024	2005R	20		22-11-11	ALL
	10		W1024	2005B	20		22-11-11	ALL
	11		W1024	2007R	20		27-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00275		**ORSS/446/**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	12		W1024	3005R	20		22-12-31	ALL
	13		W1024	3005B	20		22-12-31	ALL
	14		W1024	3005Y	20		22-12-31	ALL
	15		W1024	0513	20		27-52-11	ALL
	16	UNUSED						ALL
	S/R		W1024	2004Z			27-32-21	ALL
	S/R		W1024	2005Z			22-11-11	ALL
	S/R		W1024	2006ZI			27-52-11	ALL
	S/R		W1024	2006ZO			27-52-11	ALL
	S/R		W1024	2007ZI			27-52-11	ALL
	S/R		W1024	2007ZO			27-52-11	ALL
	S/R		W1024	3004Z			27-32-21	ALL
	S/R		W1024	3005Z			22-12-31	ALL
D00277		**268/192/L049**		**PLUG - TAT PROBE**				**ALL**
	1		W5501	0008	22		30-31-11	ALL
	2		W5501	2503B	20		34-21-22	ALL
	3		W5501	2502R	20		34-21-12	ALL
	4		W5501	2502B	20		34-21-12	ALL
	5		W5501	2503R	20		34-21-22	ALL
	6		W5501	0004	20		34-21-12	ALL
	7		W5501	0003	20		34-21-12	ALL
	DED		W5501	2502Z			34-21-12	ALL
	DED		W5501	2503Z			34-21-22	ALL
D00281		**210/218/L020**		**PLUG-CONTROL COLUMN SHAKER-CAPT**				**ALL**
	A		W0145	0001	20		27-32-11	ALL
	B		W0145	0002	20		27-32-11	ALL
D00287		**193/205/R029**		**PLUG-AOA SENSOR-RIGHT**				**ALL**
	1		W5503	2001R	22		27-32-21	ALL
	2		W5503	2001B	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00287		**193/205/R029**		**PLUG-AOA SENSOR-RIGHT (continued)**				**ALL**
	3		W5503	3002R	22		27-32-21	ALL
	4		W5503	3002B	22		27-32-21	ALL
	5		W5503	3002Y	22		27-32-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5503	0003	22		30-31-12	ALL
	9		W5503	0004	22		30-31-12	ALL
	10		W5503	0008	22		27-32-21	ALL
	11	UNUSED						ALL
	12		W5503	0009	22		27-32-21	ALL
D00291		**1140/365/R006**		**PLUG**				**ALL**
	1		W3387	1001	20		22-23-11	ALL
	2		W3387	1002	20		22-23-11	ALL
	3		W3387	0014	20		22-23-12	ALL
	4		W3387	3001Y	20		22-23-12	ALL
	5		W3387	4521R	20		22-23-12	ALL
	6		W3387	4521Y	20		22-23-12	ALL
	7		W3387	4521G	20		22-23-12	ALL
	8		W3387	4521B	20		22-23-12	ALL
	9		W3387	2001B	20		22-23-12	ALL
	10		W3387	2001R	20		22-23-12	ALL
	11		W3387	3001B	20		22-23-12	ALL
	12		W3387	3001R	20		22-23-12	ALL
	S/R		W3387	1001Z			22-23-11	ALL
	S/R		W3387	1002Z			22-23-11	ALL
	S/R		W3387	2001Z			22-23-12	ALL
	S/R		W3387	3001Z			22-23-12	ALL
	S/R		W3387	4521Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00299		**P007/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2363	3001B	20		22-11-12	ALL
	4		W2363	1011	20		22-11-31	ALL
	5		W2363	1002	20		22-11-11	ALL
	6		W2363	1014	22		22-11-75	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W2363	1062	20		33-11-31	ALL
	15		W2363	1063	20		33-11-31	ALL
	16		W2363	1010	20		22-12-31	ALL
	17		W2363	2017B	22		22-11-51	ALL
	18		W2363	2017R	22		22-11-51	ALL
	19	UNUSED						ALL
	20		W2363	1007	22		22-14-11	ALL
	21	UNUSED						ALL
	22		W2363	1022	22		22-14-11	ALL
	23		W2363	1023	22		22-11-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2363	2013B	22		22-11-11	ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00299	**P007/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32		W2363	2015B	22		22-11-51	ALL
33		W2363	2015R	22		22-11-51	ALL
34		W2363	1017	22		22-11-11	ALL
35		W2363	0007	20		22-11-11	ALL
36		W2363	0007	20		22-11-11	ALL
37		W2363	1047	22		22-11-11	ALL
38	UNUSED						ALL
39		W2363	3001Y	20		22-11-12	ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W2363	1003	22		22-11-11	ALL
44		W2363	1001	20		22-11-11	ALL
45		W2363	1045	22		22-11-11	ALL
46	UNUSED						ALL
47		W2363	1004	22		22-14-11	ALL
48		W2363	1064	22		22-14-11	ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52		W2363	2013R	22		22-11-11	ALL
53		W2363	1030	22		22-14-11	ALL
54		W2363	3001R	20		22-11-12	ALL
55		W2363	1005	20		22-11-11	ALL
S/R		W2363	1001Z			22-11-11	ALL
S/R		W2363	1002Z			22-11-11	ALL
S/R		W2363	1003Z			22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00299		**P007/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	S/R		W2363	1004Z			22-14-11	ALL
	S/R		W2363	1005Z			22-11-11	ALL
	S/R		W2363	1007Z			22-14-11	ALL
	S/R		W2363	1010Z			22-12-31	ALL
	S/R		W2363	1011Z			22-11-31	ALL
	S/R		W2363	1014Z			22-11-75	ALL
	S/R		W2363	1017Z			22-11-11	ALL
	S/R		W2363	1022Z			22-14-11	ALL
	S/R		W2363	1023Z			22-11-11	ALL
	S/R		W2363	1030Z			22-14-11	ALL
	S/R		W2363	1045Z			22-11-11	ALL
	S/R		W2363	1047Z			22-11-11	ALL
	S/R		W2363	1062Z			33-11-31	ALL
	S/R		W2363	1063Z			33-11-31	ALL
	S/R		W2363	1064Z			22-14-11	ALL
	S/R		W2363	2013Z			22-11-11	ALL
	S/R		W2363	2015Z			22-11-51	ALL
	S/R		W2363	2017Z			22-11-51	ALL
	S/R		W2363	3001Z			22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00301	**P007/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W2363	2003B	22		22-11-51	ALL
2		W2363	2003R	22		22-11-51	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W2363	1026	20		33-18-51	ALL
7		W2363	1008	22		22-31-51	ALL
8		W2363	1006	22		22-31-51	ALL
9	UNUSED						ALL
10		W2363	1015	22		22-31-51	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2363	1009	22		22-31-51	ALL
14	UNUSED						ALL
15		W2363	1016	22		22-14-11	ALL
S/R		W2363	1006Z			22-31-51	ALL
S/R		W2363	1008Z			22-31-51	ALL
S/R		W2363	1009Z			22-31-51	ALL
S/R		W2363	1015Z			22-31-51	ALL
S/R		W2363	1016Z			22-14-11	ALL
S/R		W2363	1026Z			33-18-51	ALL
S/R		W2363	2003Z			22-11-51	ALL
D00303	**P008-25/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2149	0004	22		34-55-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00303		**P008-25/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2149	0012	22		34-51-41	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2149	2003R	24		34-55-11	ALL
	25		W2149	2003B	24		34-55-11	ALL
	26		W2149	0026	22		34-55-11	ALL
	27	UNUSED						ALL
	28		W2149	2001R	24		34-31-11	ALL
	29		W2149	2001B	24		34-31-11	ALL
	30		W2149	0030	22		34-55-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00303	**P008-25/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
36	UNUSED						ALL
37		W2149	0037	22		34-55-11	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W2149	0042	20		34-51-11	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W2149	0045	22		22-11-18	ALL
46		W2149	0046	22		34-55-11	ALL
47	UNUSED						ALL
48	UNUSED						ALL
49		W2149	0049	20		33-18-61	ALL
50		W2149	0050	20		33-11-33	ALL
51	UNUSED						ALL
52		W2149	0052	20		33-11-33	ALL
53		W2149	0053	22		34-55-11	ALL
54		W2149	0054	22		34-51-11	ALL
55		W2149	0055	20		34-51-11	ALL
S/R		W2149	2001Z			34-31-11	ALL
S/R		W2149	2003Z			34-55-11	ALL
CAP	Y	W2149	0027	22		SPARE	ALL
D00305	**P008-26/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2151	0004	22		34-55-21	ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00305		**P008-26/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2151	0012	22		34-51-41	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2151	2003R	24		34-55-21	ALL
	25		W2151	2003B	24		34-55-21	ALL
	26		W2151	0026	22		34-55-21	ALL
	27	UNUSED						ALL
	28		W2151	2001R	24		34-31-21	ALL
	29		W2151	2001B	24		34-31-21	ALL
	30		W2151	0030	22		34-55-21	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00305	**P008-26/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
35	UNUSED						ALL
36	UNUSED						ALL
37		W2151	0037	22		34-55-21	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W2151	0042	20		34-51-21	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W2151	0045	22		22-11-18	ALL
46		W2151	0046	22		34-55-21	ALL
47	UNUSED						ALL
48	UNUSED						ALL
49		W2151	0049	20		33-18-61	ALL
50		W2151	0050	20		33-11-41	ALL
51	UNUSED						ALL
52		W2151	0052	20		33-11-41	ALL
53		W2151	0053	22		34-55-21	ALL
54		W2151	0054	22		34-51-21	ALL
55		W2151	0055	20		34-51-21	ALL
S/R		W2151	2001Z			34-31-21	ALL
S/R		W2151	2003Z			34-55-21	ALL
D00335	**471/149/L000**		**PLUG-**				**ALL**
=A1		W5415	001CX			23-12-31	ALL
=C1		W5415	001CO			23-12-31	ALL
D00337	**F057/350/L04**		**PLUG**				**ALL**
=A1		W7761	001CX			23-11-11	ALL
=C1		W7761	001CO			23-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00341		**F057/350/L004**		**PLUG**				**ALL**
	A		W7057	0016	20		23-11-11	ALL
	B		W7057	0013	20		23-11-11	ALL
	C	UNUSED						ALL
	D	18	W7057	0004	18		23-11-11	ALL
	E	UNUSED						ALL
	F		W7057	0005	22		23-11-11	ALL
	G	18	W7057	0006	18		23-11-11	ALL
	H		W7057	0007	22		23-11-11	ALL
	J	UNUSED						ALL
	K		W7057	0008	22		23-11-11	ALL
	L		W7057	0014	20		23-11-11	ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S		W7057	0011	22		23-11-11	ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X		W7057	0017	22		23-11-11	ALL
	Y		W7057	0018	22		23-11-11	ALL
	Z	UNUSED						ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-		W7057	0012	20		23-11-11	ALL
D00345A		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A		*/*/*		**PLUG (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A		***/*/***		**PLUG (continued)**				**ALL**
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A		*/*/*		**PLUG (continued)**				**ALL**
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A		***/*/***		**PLUG (continued)**				**ALL**
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A	*/*/*		**PLUG (continued)**				**ALL**
H14	UNUSED						ALL
H15	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345A		***/*/***		**PLUG (continued)**				**ALL**
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
D00345B		***/*/***		**PLUG**				**ALL**
	71		W0621	001CX			23-11-11	ALL
	A01		W0621	2502R	24		23-11-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0621	2502B	24		23-11-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0621	0017	22		23-11-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	C01		W0621	0013	22		23-11-11	ALL
	C02	UNUSED						ALL
	C03		W0621	2020R	24		23-22-11	ALL
	C04		W0621	2506R	24		23-11-11	ALL
	C05		W0621	0016	22		23-11-11	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	D01		W0621	2501R	24		23-11-11	ALL
	D02	UNUSED						ALL
	D03		W0621	2020B	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345B		*/*/*		**PLUG (continued)**				**ALL**
	D04		W0621	2506B	24		23-11-11	ALL
	D05		W0621	0069	22		23-11-11	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01		W0621	2501B	24		23-11-11	ALL
	E02		W0621	0085	24		31-31-17	ALL
	E03		W0621	2508R	24		23-12-41	ALL
	E04		W0621	0022	22		23-11-11	ALL
	E05		W0621	0006	22		23-11-11	ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03		W0621	2508B	24		23-12-41	ALL
	F04		W0621	0021	22		23-11-11	ALL
	F05		W0621	0005	22		23-11-11	ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03		W0621	2509R	24		23-12-41	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03		W0621	2509B	24		23-12-41	ALL
	H04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345B		***/*/***		**PLUG (continued)**				**ALL**
	H05		W0621	0015	22		23-11-11	ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0621	0138	24		23-12-41	ALL
	J04		W0621	0023	24		23-11-11	ALL
	J05		W0621	0130	22		23-11-11	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	K01	UNUSED						ALL
	K02		W0621	0129	22		23-11-11	ALL
	K03	UNUSED						ALL
	K04		W0621	0023	24		23-11-11	ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0621	001CO			23-11-11	ALL
	DED		W0621	2020ZI			23-22-11	ALL
	DED		W0621	2501ZI			23-11-11	ALL
	DED		W0621	2502ZI			23-11-11	ALL
D00345C		***/*/***		**PLUG**				**ALL**
	1		W0621	0011	20		23-11-11	ALL
	2		W0621	3001R	20		23-11-11	ALL
	3		W0621	3001Y	20		23-11-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0621	3001B	20		23-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00345C	***/*/***		**PLUG (continued)**				**ALL**
8		W0621	0008	20		23-11-11	ALL
9		W0621	0009	18		23-11-11	ALL
10		W0621	0010	20		23-11-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
=C12	UNUSED						ALL
=C13	UNUSED						ALL
D00365	**193/204/L029**		**PLUG-AOA SENSOR-LEFT**				**ALL**
1		W5501	2001R	22		27-32-11	ALL
2		W5501	2001B	22		27-32-11	ALL
3		W5501	3002R	22		27-32-11	ALL
4		W5501	3002B	22		27-32-11	ALL
5		W5501	3002Y	22		27-32-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5501	0011	22		30-31-11	ALL
9		W5501	0012	22		30-31-11	ALL
10		W5501	0009	22		27-32-11	ALL
11	UNUSED						ALL
12		W5501	0010	22		27-32-11	ALL
D00367	**210/218/R020**		**PLUG-CONTROL COLUMN SHAKER-F/O**				**ALL**
A		W0147	0001	20		27-32-21	ALL
B		W0147	0002	20		27-32-21	ALL
D00381	**1074/235/R004**		**PLUG**				**ALL**
1		W3391	0101	18		27-41-12	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00381		**1074/235/R004**		**PLUG (continued)**				**ALL**
	5	UNUSED						ALL
	6	14	W3391	3002R	14		27-41-12	ALL
	7	14	W3391	3002Y	14		27-41-12	ALL
	8	14	W3391	3002B	14		27-41-12	ALL
	9	UNUSED						ALL
	10		W3391	1021	18		27-41-12	ALL
	11		W3391	1012	20		22-13-11	ALL
	12		W3391	1026	18		27-41-12	ALL
	13		W3391	1010	20		22-13-11	ALL
	14		W3391	1022	18		27-41-12	ALL
	S/R		W3391	1010Z			22-13-11	ALL
	S/R		W3391	1012Z			22-13-11	ALL
	S/R		W3391	1021Z			27-41-12	ALL
	S/R		W3391	1022Z			27-41-12	ALL
	S/R		W3391	1026Z			27-41-12	ALL
	S/R		W3391	3002Z			27-41-12	ALL
D00383		**238/203/L014**		**RCPT**				**ALL**
	1		W5369	2027R	22		22-11-11	ALL
	2		W5369	2029R	22		22-12-31	ALL
	3		W5369	2029B	22		22-12-31	ALL
	4		W5369	2027B	22		22-11-11	ALL
	5		W5369	0035	20		22-11-11	ALL
D00385		**227/202/R027**		**RCPT**				**ALL**
	1		W5369	2001B	22		22-11-11	ALL
	2		W5369	2002R	22		22-12-31	ALL
	3		W5369	2002B	22		22-12-31	ALL
	4		W5369	2001R	22		22-11-11	ALL
	5		W5369	0001	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00397		**206/195/L025**		**RCPT**				**ALL**
	1		W5369	2033B	22		22-11-11	ALL
	2		W5369	2031R	22		22-11-31	ALL
	3		W5369	2031B	22		22-11-31	ALL
	4		W5369	2033R	22		22-11-11	ALL
	5		W5369	0045	20		22-11-11	ALL
	DED		W5369	2031Z			22-11-31	ALL
D00398		**546/166/L001**		**PLUG-**				**ALL**
	1		W5502	2005B	20		36-11-31	ALL
	2		W5502	2005R	20		36-11-31	ALL
	3		W5502	1007	20		36-11-31	ALL
	4		W5502	1005	20		36-11-31	ALL
	5		W5502	0009	20		36-11-31	ALL
	6		W5502	1008	20		36-11-31	ALL
	7		W5502	0001	20		36-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00423		**P001-03/ /**		**PLUG-- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0001	1166	22		34-49-11	ALL
	5		W0001	1164	24		34-49-11	ALL
	6		W0001	1165	24		34-49-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W0001	1242	20		33-18-21	ALL
	29		W0001	1207	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00423		**P001-03/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W0001	0235	20		33-18-11	ALL
	35	UNUSED						ALL
	36		W0001	1251	20		33-18-62	ALL
	37		W0001	1531	20		33-18-11	ALL
	38		W0001	1250	20		33-18-62	ALL
	39		W0001	1530	20		33-18-11	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	S/R		W0001	1164Z			34-49-11	ALL
	S/R		W0001	1165Z			34-49-11	ALL
	S/R		W0001	1166Z			34-49-11	ALL
	S/R		W0001	1207Z			22-13-11	ALL
	S/R		W0001	1242Z			33-18-21	ALL
	S/R		W0001	1250Z			33-18-62	ALL
	S/R		W0001	1251Z			33-18-62	ALL
	S/R		W0001	1530Z			33-18-11	ALL
	S/R		W0001	1531Z			33-18-11	ALL
D00432		**P005-14/ /**		**PLUG-**				**ALL**
	1		W2508	5643	22		35-11-11	ALL
	2		W2508	5644	20		35-11-11	ALL
	3		W2216	5622	20		33-12-11	ALL
	4		W2216	5623	20		33-12-11	ALL
	5	UNUSED						ALL
D00438		**395/167/R007**		**PLUG-**				**ALL**
	1		W5158	0001	22		35-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00438		**395/167/R007**		**PLUG- (continued)**				**ALL**
	2		W5158	0002	20		35-11-11	ALL
	3		W5158	0003	22		35-11-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D00440		**P005-00/ /**		**PLUG-**				**ALL**
	1		W2216	5621	20		33-12-11	ALL
	2		W2216	5620	20		33-12-11	ALL
	3		W2508	5645	22		35-21-11	ALL
	4		W2508	5646	20		35-21-11	ALL
	5		W2112	5587	20		33-18-42	ALL
	6		W2508	5648	20		35-21-11	ALL
	7		W2508	5597	20		33-18-42	ALL
	8		W2508	5596	20		33-18-42	ALL
	9		W2508	5647	22		35-21-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D00458A		***/*/***		**PLUG-AIR COND RELAY NO 1**				**ALL**
	1		W0410	0487	24		34-61-17	ALL
	2		W0410	0488	20		34-61-17	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0410	0396	24		21-61-11	ALL
	8		W0410	0483	24		21-25-11	ALL
	9	UNUSED						ALL
	10		W0410	0482	24		21-25-11	ALL
	11		W0410	0434	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00458A	*/*/*		**PLUG-AIR COND RELAY NO 1 (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0410	0397	24		21-61-11	ALL
18		W0410	0302	24		21-51-11	ALL
19		W0410	0313	24		21-51-11	ALL
20		W0410	0390	24		21-61-11	ALL
21	UNUSED						ALL
22		W0410	0394	24		21-51-12	ALL
23		W0410	0307	24		21-51-11	ALL
24	UNUSED						ALL
25		W0410	0388	24		21-61-11	ALL
26		W0410	0405	24		21-61-11	ALL
27		W0410	0402	24		21-61-11	ALL
28		W0410	0407	24		21-61-11	ALL
29	UNUSED						ALL
30		W0410	0308	24		21-51-11	ALL
31		W0410	0481	24		21-25-11	ALL
32		W0410	0306	24		21-51-11	ALL
33		W0410	0311	24		21-51-11	ALL
34		W0410	0480	24		21-25-11	ALL
35		W0410	0539	24		21-51-14	ALL
36	UNUSED						ALL
37		W0410	0389	24		21-61-11	ALL
38		W0410	0402	24		21-61-11	ALL
39	UNUSED						ALL
40		W0410	0405	24		21-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00458A	***/*/***		**PLUG-AIR COND RELAY NO 1 (continued)**				**ALL**
41		W0410	0403	24		21-61-11	ALL
42		W0410	0404	24		21-61-11	ALL
43		W0410	0305	24		21-51-11	ALL
44		W0410	0303	24		21-51-11	ALL
45		W0410	0312	20		21-51-11	ALL
46		W0410	0316	24		21-51-12	ALL
47		W0410	0542	24		21-51-14	ALL
48		W0410	0616	24		21-51-11	ALL
49	UNUSED						ALL
50		W0410	0321	24		21-51-12	ALL
51		W0410	0444	24		21-61-14	ALL
52		W0410	0443	24		21-61-14	ALL
53		W0410	0436	24		21-61-14	ALL
54		W0410	0435	24		21-61-14	ALL
55		W0410	0310	24		21-51-11	ALL
56		W0410	0318	24		21-51-12	ALL
57		W0410	0395	24		21-61-11	ALL
58		W0410	0317	24		21-51-12	ALL
59		W0410	0324	22		21-51-14	ALL
60	UNUSED						ALL
61		W0410	0533	24		21-51-14	ALL
62	UNUSED						ALL
63		W0410	0323	24		21-51-12	ALL
64		W0410	0322	24		21-51-12	ALL
65		W0410	0319	24		21-51-12	ALL
66		W0410	0320	24		21-51-12	ALL
67		W0410	0445	24		21-61-14	ALL
D00458B	***/*/***		**PLUG-AIR COND RELAY NO 1**				**ALL**
1		W0410	0332	20		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00458B	*/*/*		**PLUG-AIR COND RELAY NO 1 (continued)**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
4		W0410	0309	20		21-51-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0410	0069	20		36-11-12	ALL
8		W0410	0584	24		36-11-23	ALL
9		W0410	1455	20		36-11-12	ALL
10		W0410	0063	24		36-11-12	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0410	0465	24		21-25-11	ALL
15		W0410	0466	24		21-25-11	ALL
16		W0410	0469	24		21-25-11	ALL
17	UNUSED						ALL
18		W0410	0520	24		36-11-13	ALL
19		W0410	0384	24		21-61-11	ALL
20		W0410	0429	24		21-61-14	ALL
21	UNUSED						ALL
22		W0410	0391	24		21-61-11	ALL
23		W0410	0340	24		21-51-15	ALL
24		W0410	0065	24		36-11-12	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28		W0410	0468	24		21-25-11	ALL
29		W0410	0467	24		21-25-11	ALL
30		W0410	0338	24		21-51-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00458B	***/*/***		**PLUG-AIR COND RELAY NO 1 (continued)**				**ALL**
31	UNUSED						ALL
32		W0410	0355	24		21-51-21	ALL
33		W0410	0536	24		21-51-14	ALL
34		W0410	0437	24		21-61-14	ALL
35		W0410	0342	24		21-51-15	ALL
36		W0410	0339	24		21-51-15	ALL
37		W0410	0463	24		36-11-12	ALL
38		W0410	0061	24		36-11-12	ALL
39		W0410	0594	24		36-11-31	ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W0410	0400	24		21-61-11	ALL
44		W0410	0400	24		21-61-11	ALL
45	UNUSED						ALL
46		W0410	1073	20		36-11-12	ALL
47		W0410	1072	20		36-11-12	ALL
48		W0410	0441	24		21-61-14	ALL
49		W0410	0439	24		21-61-14	ALL
50		W0410	1069	20		36-11-12	ALL
51		W0410	0593	24		36-11-31	ALL
52		W0410	0589	24		36-11-31	ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W0410	0610	24		21-25-11	ALL
56		W0410	0611	24		21-25-11	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00458B	***/*/***		**PLUG-AIR COND RELAY NO 1 (continued)**				**ALL**
60		W0410	0341	20		21-51-15	ALL
61		W0410	0399	24		21-61-11	ALL
62		W0410	0393	24		21-61-11	ALL
63		W0410	0066	24		36-11-12	ALL
64		W0410	0062	24		36-11-12	ALL
65		W0410	0064	24		36-11-12	ALL
66		W0410	0071	24		36-11-12	ALL
67		W0410	0588	24		36-11-31	ALL
D00462	**P005-00/ /**		**PLUG-**				**ALL**
1		W2112	5586	22		30-11-11	ALL
2		W2112	6028	22		30-21-31	ALL
3		W2112	0014	22		30-11-11	ALL
4	UNUSED						ALL
5		W2112	0015	22		30-11-11	ALL
6		W2112	0530	20		30-21-31	ALL
7		W2112	0537	20		30-21-31	ALL
8		W2508	5555	20		33-18-34	ALL
9		W2508	0540	24		75-11-11	ALL
10		W2112	6086	24		36-11-13	ALL
11		W2112	6082	22		30-21-32	ALL
12		W2112	1004R	22		26-11-11	ALL
13		W2112	0016	22		30-11-11	ALL
14		W2112	0170	22		34-21-11	ALL
15		W2216	0020	22		36-11-13	ALL
16	UNUSED						ALL
17		W2508	5772	20		31-52-56	ALL
18		W2112	6083	22		30-21-31	ALL
19		W2112	6084	22		30-21-31	ALL
20		W2508	5770	20		31-52-56	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00462		**P005-00/ /**		**PLUG- (continued)**				**ALL**
	21		W2112	0009	22		30-21-31	ALL
	22		W2508	5779	20		33-18-34	ALL
	23		W2112	1201	20		30-21-31	ALL
	24		W2112	6024	22		30-11-11	ALL
	25		W2112	0013	20		30-11-11	ALL
	26		W2112	6066	20		30-11-11	ALL
	27		W2112	6001	20		30-21-31	ALL
	28		W2112	0007	22		30-21-31	ALL
	29		W2508	5771	20		31-52-56	ALL
	30		W2112	6049	20		30-21-31	ALL
	31		W2112	0008	22		30-21-31	ALL
	CAP	Y	W2112	0179	22		34-21-11	ALL
	DED		W2112	1201Z			30-21-31	ALL
D00482		**P005-20/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W2508	0008	20		52-71-13	ALL
	5		W2508	5557	20		33-18-35	ALL
	6		W2508	5558	20		33-18-35	ALL
	7		W2508	5632	20		33-18-35	ALL
	8		W2508	5731	20		31-52-65	ALL
	9		W2508	5732	20		31-52-65	ALL
	10		W2508	5733	20		31-52-65	ALL
	11		W2508	0009	20		52-71-14	ALL
	12		W2508	0003	24		52-71-12	ALL
D00483		**P005-19/ /**		**PLUG-**				**ALL**
	1		W2589	0011	22		23-24-11	ALL
	2		W2112	8004	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00483	**P005-19/ /**		**PLUG- (continued)**				**ALL**
3	UNUSED						ALL
4		W2135	0031	20		34-16-21	ALL
5	UNUSED						ALL
6		W2135	0032	22		34-16-21	ALL
7		W2112	8002	22		31-31-11	ALL
8		W2114	0011	20		33-51-11	ALL
9	UNUSED						ALL
10		W2112	8001	22		31-31-11	ALL
11		W2112	8005	22		31-31-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2035	0039	20		34-16-11	ALL
16		W2035	0030	22		34-16-11	ALL
17	UNUSED						ALL
18		W2112	8003	22		31-31-11	ALL
19		W2112	5607	20		33-18-42	ALL
20		W2112	8006	22		31-31-11	ALL
21		W2589	0010	22		23-24-11	ALL
22		W2508	5600	20		33-18-42	ALL
23		W2508	5602	20		33-18-42	ALL
24		W2508	5647	22		35-21-11	ALL
25		W2589	0006	22		23-24-11	ALL
26		W2508	5736	20		31-52-75	ALL
27		W2112	5501	22		21-27-21	ALL
28	UNUSED						ALL
29		W2508	5734	20		31-52-75	ALL
30		W2508	5735	20		31-52-75	ALL
31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00483		**P005-19/ /**		**PLUG- (continued)**				**ALL**
	32		W2508	0040	22		26-19-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W2508	0035	22		31-65-41	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00519	**P008-29/ /**		**PLUG-ATC 2 DUAL CONTROL**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W2247	0003	20		34-53-21	ALL
4		W2247	0004	20		34-53-21	ALL
5		W2247	0005	22		34-53-31	ALL
6		W2247	0006	20		34-53-21	ALL
7		W2247	0007	24		34-53-21	ALL
8		W2247	0008	20		34-53-21	ALL
9	VP	W2247	0009	20		34-53-21	ALL
10	VP	W2247	0010	20		34-53-21	ALL
11		W2247	0011	24		34-53-21	ALL
12		W2247	0012	24		34-53-21	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2247	0015	24		34-53-21	ALL
16		W2247	0016	24		34-53-21	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W2247	0020	24		34-53-21	ALL
21	UNUSED						ALL
22		W2247	2001R	24		34-53-21	ALL
23		W2247	2001B	24		34-53-21	ALL
24		W2247	0024	22		34-53-21	ALL
		W2247	0029	20		34-53-21	ALL
		W2247	2001Z			34-53-21	ALL
D00532	**581/152/L029**		**PLUG-**				**ALL**
1		W5102	1005	20		21-51-15	ALL
2		W5102	1001	20		21-51-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00532		**581/152/L029**		**PLUG- (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D00538		**578/154/R033**		**PLUG-**				**ALL**
	1		W6202	0014	20		21-51-25	ALL
	2		W6202	1027	20		21-51-25	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D00539A		***/*/***		**PLUG - VHF 3**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00539A	*/*/*		**PLUG - VHF 3 (continued)**				**ALL**
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00539A		***/*/***		**PLUG - VHF 3 (continued)**				**ALL**
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D00539B		***/*/***		**PLUG - VHF 3**				**ALL**
	A01		W0335	2529R	24		23-12-31	ALL
	A02		W0335	0106	22		23-12-31	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0335	2708R	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09		W0335	0273	24		23-12-31	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0335	2527R	24		23-27-37	ALL
	A13		W0335	2507R	24		23-22-11	ALL
	A14	UNUSED						ALL
	A15		W0335	2530R	24		23-12-31	ALL
	B01		W0335	2529B	24		23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00539B	*/*/*		**PLUG - VHF 3 (continued)**				**ALL**
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0335	2708B	24		23-12-41	ALL
B08	UNUSED						ALL
B09		W0335	0274	24		23-12-31	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0335	2527B	24		23-27-37	ALL
B13		W0335	2507B	24		23-22-11	ALL
B14		W0335	0103	24		23-12-31	ALL
B15		W0335	2530B	24		23-12-31	ALL
C01		W0335	0102	22		23-12-31	ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09		W0335	0275	24		23-12-31	ALL
C10		W0335	2535R	24		23-27-37	ALL
C11		W0335	0470	22		23-12-31	ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14		W0335	2558R	24		23-12-31	ALL
C15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00539B		***/*/***		**PLUG - VHF 3 (continued)**				**ALL**
	D01		W0335	0107	22		31-31-17	ALL
	D02	UNUSED						ALL
	D03		W0335	0105	22		23-12-31	ALL
	D04	UNUSED						ALL
	D05		W0335	0268	22		23-12-31	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10		W0335	2535B	24		23-27-37	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14		W0335	2558B	24		23-12-31	ALL
	D15	UNUSED						ALL
	DED		W0335	2507ZI			23-22-11	ALL
	DED		W0335	2529ZI			23-12-31	ALL
	DED		W0335	2530ZI			23-12-31	ALL
	PERG	1A	W0335	2507ZO			23-22-11	ALL
	PERG	1A	W0335	2527Z			23-27-37	ALL
	PERG	1A	W0335	2529ZO			23-12-31	ALL
	PERG	1A	W0335	2530ZO			23-12-31	ALL
	PERG	1A	W0335	2535Z			23-27-37	ALL
	PERG	1A	W0335	2558Z			23-12-31	ALL
	PERG	1A	W0335	2708Z			23-12-41	ALL
D00539C		***/*/***		**PLUG - VHF 3**				**ALL**
	1	DN	W0335	001CX			23-12-31	ALL
	2		W0335	0101	16		23-12-31	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00539C	***/*/***		**PLUG - VHF 3 (continued)**				**ALL**
4		W0335	0104	16		23-12-31	ALL
5	UNUSED						ALL
=C1		W0335	001CO			23-12-31	ALL
=C5	UNUSED						ALL
D00545	**1165/277/R002**		**PLUG**				**ALL**
1		W3393	2001B	22		22-18-11	ALL
2		W3393	2001R	22		22-18-11	ALL
3		W3393	2006B	22		22-18-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W3393	2006R	22		22-18-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W3393	0011	20		22-18-11	ALL
12	UNUSED						ALL
13		W3393	1013	20		22-18-11	ALL
14		W3393	0014	20		22-18-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W3393	2024B	22		22-18-11	ALL
24		W3393	2024R	22		22-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00545		**1165/277/R002**		**PLUG (continued)**				**ALL**
	25		W3393	2026B	22		22-18-11	ALL
	26		W3393	2026R	22		22-18-11	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D00549		**P008-73/ /**		**PLUG-**				**ALL**
	1		W2417	0001	20		23-12-31	ALL
	2		W2417	2501R	24		23-12-41	ALL
	3		W2417	2501B	24		23-12-41	ALL
	4	UNUSED						ALL
	5		W2417	2508R	24		23-12-41	ALL
	6		W2417	2508B	24		23-12-41	ALL
	7		W2417	0047	24		23-12-41	ALL
	8		W2417	2506R	24		23-12-41	ALL
	9		W2417	2506B	24		23-12-41	ALL
	10		W2417	0010	22		23-12-11	ALL
	11		W2417	0011	22		23-12-31	ALL
	12		W2417	0012	22		23-12-21	ALL
	13	UNUSED						ALL
	14		W2417	0054	24		23-27-31	ALL
	15	VP	W2417	0055	24		23-27-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	VP	W2417	0059	24		23-27-31	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00549	**P008-73/ /**		**PLUG- (continued)**				**ALL**
22	UNUSED						ALL
23		W2417	0023	24		23-12-31	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W2417	0030	24		23-12-31	ALL
31		W2417	0031	24		23-12-31	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W2417	0035	20		33-18-62	ALL
36		W2417	0036	20		33-18-62	ALL
37		W2417	0037	20		33-11-41	ALL
38		W2417	0038	20		33-11-41	ALL
39	UNUSED						ALL
40	18	W2417	0040	18		23-12-31	ALL
41		W2417	0041	20		23-12-31	ALL
DED		W2417	2501Z			23-12-41	ALL
DED		W2417	2506Z			23-12-41	ALL
DED		W2417	2508Z			23-12-41	ALL
D00553	**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE**				**ALL**
1		W2216	5702	20		33-12-11	ALL
2		W2216	5703	20		33-12-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00553		**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W2035	0026	24		31-65-15	ALL
	12		W2035	0027	24		31-65-15	ALL
	13		W2035	0028	24		31-65-15	ALL
	14		W2035	0029	22		31-65-15	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W2112	8009	22		34-51-41	ALL
	19		W2112	8010	20		34-51-41	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W2508	8004	22		34-51-41	ALL
	28		W2508	8003	20		34-51-41	ALL
	29		W2508	8001	20		34-51-41	ALL
	30		W2508	8002	22		34-51-41	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W2035	0037	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00553	**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE (continued)**				**ALL**
35		W2035	0038	22		31-65-15	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W2508	8014	22		34-21-15	ALL
41		W2112	8024	20		34-21-15	ALL
42		W2112	8023	22		34-21-15	ALL
43		W2508	8007	22		34-21-15	ALL
44		W2508	8018	20		34-21-15	ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W2114	8002	20		34-41-11	ALL
51		W2114	8001	22		34-41-11	ALL
52	UNUSED						ALL
53		W2508	8015	22		34-21-15	ALL
54		W2112	8027	20		34-21-15	ALL
55	UNUSED						ALL
D00570	**AB0288/ /**		**RCPT-**				**ALL**
A		W4256	0011	10		25-31-11	ALL
B		W4256	0012	10		25-31-11	ALL
C		W4256	0013	10		25-31-11	ALL
D		W4256	0014	10		25-31-11	ALL
D00576	**P008-01/ /**		**PLUG**				**ALL**
1		W5506	6025R	22		26-11-11	ALL
2		W5506	5509	20		33-18-63	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00576		**P008-01/ /**		**PLUG (continued)**				**ALL**
	3		W5506	6063R	22		26-21-11	ALL
	4		W5506	6058R	22		26-21-11	ALL
	5		W5506	6033	20		78-34-11	ALL
	6		W5506	6034	20		78-34-11	ALL
	7		W5506	6062R	22		26-21-11	ALL
	8		W5506	6059R	22		26-21-11	ALL
	9		W5506	5503	24		36-11-12	ALL
	10		W5506	5501	24		36-11-12	ALL
	11	UNUSED						ALL
	12		W5506	6056R	22		26-21-11	ALL
	13		W5506	6065R	22		26-21-11	ALL
	14		W5506	6057R	22		26-21-11	ALL
	15	UNUSED						ALL
	16		W5506	2201B	22		24-22-11	ALL
	17		W5506	2201R	22		24-22-11	ALL
	18		W5506	6064R	22		26-21-11	ALL
	19		W5506	0515	24		29-33-11	ALL
	20		W5506	0516	24		29-33-11	ALL
	21		W5506	6029	20		28-21-11	ALL
	22		W5506	6027	20		28-21-11	ALL
	23		W5506	6028	20		28-21-11	ALL
	24		W5506	0508	20		29-11-11	ALL
	25		W5506	0506	20		29-11-11	ALL
	26		W5506	0507	20		29-11-11	ALL
	27		W5506	6024R	22		26-11-11	ALL
	28		W5506	6026R	22		26-11-11	ALL
	29		W5506	6012	20		76-21-11	ALL
	30		W5506	6006	20		76-21-11	ALL
	31		W5506	6013R	20		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00576	**P008-01/ /**		**PLUG (continued)**				**ALL**
DED		W5506	2201Z			24-22-11	ALL
D00578	**P008-01/ /**		**PLUG**				**ALL**
1		W6506	6040R	22		26-11-21	ALL
2		W6506	5507	20		33-18-63	ALL
3		W6506	6070R	22		26-21-11	ALL
4		W6506	6051R	22		26-21-11	ALL
5		W6506	6014	20		78-34-21	ALL
6		W6506	6015	20		78-34-21	ALL
7		W6506	6071R	22		26-21-11	ALL
8		W6506	6052R	22		26-21-11	ALL
9		W6506	5503	24		36-11-22	ALL
10		W6506	5501	24		36-11-22	ALL
11	UNUSED						ALL
12		W6506	6049R	22		26-21-11	ALL
13		W6506	6072R	22		26-21-11	ALL
14		W6506	6050R	22		26-21-11	ALL
15	UNUSED						ALL
16		W6506	2201R	22		24-22-21	ALL
17		W6506	2201B	22		24-22-21	ALL
18		W6506	6069R	22		26-21-11	ALL
19		W6506	0515	24		29-33-11	ALL
20		W6506	0516	24		29-33-11	ALL
21		W6506	6010	20		28-21-11	ALL
22		W6506	6008	20		28-21-11	ALL
23		W6506	6009	20		28-21-11	ALL
24		W6506	0508	20		29-11-11	ALL
25		W6506	0506	20		29-11-11	ALL
26		W6506	0507	20		29-11-11	ALL
27		W6506	6039R	22		26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00578		**P008-01/ /**		**PLUG (continued)**				**ALL**
	28		W6506	6084R	22		26-11-21	ALL
	29		W6506	6030	20		76-21-21	ALL
	30		W6506	6028	20		76-21-21	ALL
	31		W6506	6029R	20		76-21-21	ALL
D00580		**P008-01/ /**		**PLUG**				**ALL**
	1		W6506	6002R	20		26-11-31	ALL
	2		W6506	5508	20		33-18-63	ALL
	3		W6506	6073R	22		26-21-11	ALL
	4		W6506	0502	20		49-62-11	ALL
	5		W6506	0501	20		49-62-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W6506	6048R	22		26-21-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W6506	6047R	22		26-21-11	ALL
	15	UNUSED						ALL
	16		W6506	2202B	22		24-22-31	ALL
	17		W6506	2202R	22		24-22-31	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00580	**P008-01/ /**		**PLUG (continued)**				**ALL**
25	UNUSED						ALL
26	UNUSED						ALL
27		W6506	6003R	20		26-11-31	ALL
28		W6506	6004R	20		26-11-31	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
DED		W6506	2202Z			24-22-31	ALL
D00582	**708/192/L057**		**CONNECTOR-L.BOTTLE M00194**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W7596	6002R	20		26-21-11	ALL
4		W7596	6008R	20		26-21-11	ALL
5	UNUSED						ALL
6		W7596	6003R	20		26-21-11	ALL
7		W7596	6001R	20		26-21-11	ALL
D00584	**718/191/L055**		**CONNECTOR-R.BOTTLE M00195**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W7598	6002R	20		26-21-11	ALL
4		W7598	6008R	20		26-21-11	ALL
5	UNUSED						ALL
6		W7598	6003R	20		26-21-11	ALL
7		W7598	6001R	20		26-21-11	ALL
D00586	**709/194/L054**		**CONNECTOR-L.BOTTLE M00194**				**ALL**
1		W7596	6011R	20		26-21-11	ALL
2		W7596	6005R	20		26-21-11	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00588		**718/194/L054**		**CONNECTOR-R.BOTTLE M00195**				**ALL**
	1		W7598	6011R	20		26-21-11	ALL
	2		W7598	6005R	20		26-21-11	ALL
	3	UNUSED						ALL
D00594		**1081/227/L024**		**PLUG-SQUIB APU BTL**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W4726	1107R	18		26-21-11	ALL
	4		W4726	1105R	20		26-21-11	ALL
	5		W4726	1106R	18		26-21-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	DED		W4726	1106Z			26-21-11	ALL
	DED		W4726	1107Z			26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00616	**P005-02/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W2218	6001	22		28-42-11	ALL
3		W2218	6003	20		28-42-11	ALL
4		W2218	6004	20		28-42-11	ALL
5		W2218	6002	20		28-42-11	ALL
6		W2216	5704	20		33-12-11	ALL
7		W2216	5705	20		33-12-11	ALL
D00623A	***/*/***		**PLUG**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623A		***/*/***		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623A		*/*/*		**PLUG (continued)**				**ALL**
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623A		***/*/***		**PLUG (continued)**				**ALL**
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623A	*/*/*		**PLUG (continued)**				**ALL**
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623A		***/*/***		**PLUG (continued)**				**ALL**
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
D00623B		***/*/***		**PLUG**				**ALL**
	71		W0623	002CX			23-11-21	ALL
	A01		W0623	2517R	24		23-11-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01		W0623	2517B	24		23-11-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0623	0172	22		23-11-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623B	*/*/*		**PLUG (continued)**				**ALL**
C01		W0623	0175	22		23-11-21	ALL
C02	UNUSED						ALL
C03		W0623	2021R	24		23-22-11	ALL
C04		W0623	2530R	24		23-11-21	ALL
C05		W0623	0171	22		23-11-21	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01		W0623	2516R	24		23-11-21	ALL
D02	UNUSED						ALL
D03		W0623	2021B	24		23-22-11	ALL
D04		W0623	2530B	24		23-11-21	ALL
D05		W0623	0164	22		23-11-21	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01		W0623	2516B	24		23-11-21	ALL
E02		W0623	0086	24		31-31-17	ALL
E03		W0623	2529R	24		23-12-41	ALL
E04		W0623	0182	22		23-11-21	ALL
E05		W0623	0177	22		23-11-21	ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03		W0623	2529B	24		23-12-41	ALL
F04		W0623	0183	22		23-11-21	ALL
F05		W0623	0176	22		23-11-21	ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623B		***/*/***		**PLUG (continued)**				**ALL**
	G02	UNUSED						ALL
	G03		W0623	2519R	24		23-12-41	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03		W0623	2519B	24		23-12-41	ALL
	H04		W0623	0161	24		23-11-21	ALL
	H05		W0623	0170	22		23-11-21	ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0623	0178	24		23-12-41	ALL
	J04	UNUSED						ALL
	J05		W0623	0162	22		23-11-21	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	K01	UNUSED						ALL
	K02		W0623	0163	22		23-11-21	ALL
	K03	UNUSED						ALL
	K04		W0623	0161	24		23-11-21	ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W0623	002CO			23-11-21	ALL
	DED		W0623	2021ZI			23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00623B	***/*/***		**PLUG (continued)**				**ALL**
DED		W0623	2516ZI			23-11-21	ALL
DED		W0623	2517ZI			23-11-21	ALL
PERG	1A	W0623	2021ZO			23-22-11	ALL
PERG	1A	W0623	2516ZO			23-11-21	ALL
PERG	1A	W0623	2517ZO			23-11-21	ALL
PERG	1A	W0623	2519Z			23-12-41	ALL
PERG	1A	W0623	2529Z			23-12-41	ALL
PERG	1A	W0623	2530Z			23-11-21	ALL
D00623C	***/*/***		**PLUG**				**ALL**
1		W0623	0169	20		23-11-21	ALL
2		W0623	3001R	20		23-11-21	ALL
3		W0623	3001Y	20		23-11-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0623	3001B	20		23-11-21	ALL
8		W0623	0149	20		23-11-21	ALL
9		W0623	0168	18		23-11-21	ALL
10		W0623	0150	20		23-11-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
=C12	UNUSED						ALL
=C13	UNUSED						ALL
D00624	**P005-00/ /**		**PLUG-**				**ALL**
1		W2216	5707	20		33-12-11	ALL
2		W2216	5706	20		33-12-11	ALL
3		W2212	0504	20		27-23-11	ALL
4		W2104	0520	20		27-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00624		**P005-00/ /**		**PLUG- (continued)**				**ALL**
	5		W2104	0517	20		27-53-11	ALL
	6		W2112	0518	20		27-53-12	ALL
	7		W2212	0512	22		27-23-14	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W2212	0519	20		27-23-11	ALL
	12		W2212	0503	20		27-23-11	ALL
	13		W2508	5708	20		31-52-25	ALL
	14	UNUSED						ALL
	15		W2104	0518	20		27-53-11	ALL
	16		W2112	0517	20		27-53-12	ALL
	17		W2104	0515	20		27-53-11	ALL
	18		W2212	0511	22		27-23-14	ALL
	19		W2218	0521	20		27-61-43	ALL
	20		W2104	0513	24		29-35-11	ALL
	21		W2212	0522	22		29-22-11	ALL
	22		W2212	0501	20		27-23-11	ALL
	23		W2112	8019	22		22-23-11	ALL
	24		W2104	0514	24		27-23-14	ALL
	25		W2212	0520	20		27-23-11	ALL
	26		W2508	5709	20		31-52-25	ALL
	27		W2508	5710	20		31-52-25	ALL
	28		W2112	0519	22		27-83-11	ALL
	29		W2112	0520	20		27-83-11	ALL
	30		W2104	0516	20		27-53-11	ALL
	31		W2218	0520	20		27-61-43	ALL
	32		W2112	8021	24		31-31-15	ALL
	33		W2104	0511	20		27-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00624	**P005-00/ /**		**PLUG- (continued)**				**ALL**
34	UNUSED						ALL
35	UNUSED						ALL
36		W2135	0028	22		22-18-11	ALL
37		W2212	0526	20		29-35-11	ALL
38		W2135	0033	22		22-13-11	ALL
39	UNUSED						ALL
40		W2212	0502	22		27-23-11	ALL
41		W2216	5619	22		27-61-45	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W2112	8020	20		22-23-11	ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52		W2212	0525	24		29-35-11	ALL
53		W2212	0525	24		29-35-11	ALL
54	UNUSED						ALL
55	UNUSED						ALL
D00625	**F057/350/L004**		**PLUG-**				**ALL**
=A1		W7763	001CX			23-11-21	ALL
=C1		W7763	001CO			23-11-21	ALL
D00626	**P005-02/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W2112	6048	20		28-43-11	ALL
3		W2508	6022	24		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00626		**P005-02/ /**		**PLUG- (continued)**				**ALL**
	4		W2508	5717	20		31-52-41	ALL
	5		W2508	5532	20		33-18-32	ALL
	6		W2112	6053	20		28-43-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2112	6056	20		28-23-11	ALL
	10		W2112	6039	20		28-43-11	ALL
	11	UNUSED						ALL
	12		W2508	6040	24		76-21-11	ALL
	13	UNUSED						ALL
	14		W2508	5534	20		33-18-32	ALL
	15		W2216	5708	20		33-12-11	ALL
	16		W2216	5709	20		33-12-11	ALL
	17	UNUSED						ALL
	18		W2112	6054	20		28-23-11	ALL
	19		W2508	6013	20		28-43-11	ALL
	20	UNUSED						ALL
	21		W2112	6031	24		73-31-11	ALL
	22		W2508	6010	20		28-21-11	ALL
	23		W2508	6007	20		28-21-11	ALL
	24		W2508	6024	20		76-21-11	ALL
	25		W2508	6027	20		76-21-11	ALL
	26		W2112	6047	20		28-43-11	ALL
	27		W2508	6023	20		76-21-11	ALL
	28		W2112	6046	20		28-43-11	ALL
	29		W2508	6008	20		28-21-11	ALL
	30		W2508	6009	20		28-21-11	ALL
	31	UNUSED						ALL
	32		W2508	6006	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00626	**P005-02/ /**		**PLUG- (continued)**				**ALL**
33	UNUSED						ALL
34		W2112	6044	20		28-23-11	ALL
35		W2112	6041	20		28-23-11	ALL
36		W2112	6043	20		28-23-11	ALL
37		W2112	6042	20		28-23-11	ALL
38		W2112	6045	20		28-23-11	ALL
39		W2112	6040	20		28-23-11	ALL
40	UNUSED						ALL
41	UNUSED						ALL
D00628	**P005-02/ /**		**PLUG-**				**ALL**
1		W2218	6023	20		28-22-11	ALL
2		W2218	6027	20		28-43-11	ALL
3		W2510	6015	24		76-21-21	ALL
4		W2510	5701	20		31-52-41	ALL
5		W2510	5513	20		33-18-32	ALL
6		W2218	6024	20		28-22-11	ALL
7		W2218	6025	20		28-22-11	ALL
8		W2510	6007	20		28-22-11	ALL
9		W2218	6056	20		28-23-11	ALL
10		W2218	6005	20		28-43-11	ALL
11	UNUSED						ALL
12		W2510	6052	24		76-21-21	ALL
13	UNUSED						ALL
14		W2508	5718	20		31-52-41	ALL
15	UNUSED						ALL
16		W2510	5703	20		31-52-41	ALL
17	UNUSED						ALL
18		W2218	6054	20		28-23-11	ALL
19		W2510	6013	20		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00628		**P005-02/ /**		**PLUG- (continued)**				**ALL**
	20	UNUSED						ALL
	21		W2218	6012	24		73-31-11	ALL
	22		W2510	6001	20		28-21-11	ALL
	23		W2510	6002	20		28-21-11	ALL
	24		W2510	6019	20		76-21-21	ALL
	25		W2510	6016	20		76-21-21	ALL
	26		W2218	6026	20		28-43-11	ALL
	27		W2510	6017	20		76-21-21	ALL
	28		W2218	6028	20		28-43-11	ALL
	29		W2510	6003	20		28-21-11	ALL
	30		W2510	6004	20		28-21-11	ALL
	31	UNUSED						ALL
	32		W2510	6005	20		28-21-11	ALL
	33		W2510	6031	20		28-22-11	ALL
	34		W2218	6044	20		28-23-11	ALL
	35		W2218	6041	20		28-23-11	ALL
	36		W2218	6045	20		28-23-11	ALL
	37		W2218	6040	20		28-23-11	ALL
	38		W2218	6043	20		28-23-11	ALL
	39		W2218	6042	20		28-23-11	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
D00629		**F057/350/R002**		**PLUG-**				**ALL**
	A		W7061	0016	20		23-11-21	ALL
	B		W7061	0013	20		23-11-21	ALL
	C	UNUSED						ALL
	D	18	W7061	0004	18		23-11-21	ALL
	E	UNUSED						ALL
	F		W7061	0005	22		23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00629	**F057/350/R002**		**PLUG- (continued)**				**ALL**
G	18	W7061	0006	18		23-11-21	ALL
H		W7061	0007	22		23-11-21	ALL
J	UNUSED						ALL
K		W7061	0008	22		23-11-21	ALL
L		W7061	0014	20		23-11-21	ALL
M	UNUSED						ALL
N	UNUSED						ALL
P	UNUSED						ALL
R	UNUSED						ALL
S		W7061	0011	22		23-11-21	ALL
T	UNUSED						ALL
U	UNUSED						ALL
V	UNUSED						ALL
W	UNUSED						ALL
X		W7061	0018	22		23-11-11	ALL
Y		W7061	0017	22		23-11-11	ALL
Z	UNUSED						ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-		W7061	0012	20		23-11-21	ALL
D00630	**P005-00/ /**		**PLUG-**				**ALL**
1		W2035	0042	22		22-13-11	ALL
2		W2035	0035	22		22-18-11	ALL
3		W2218	0519	20		27-61-43	ALL
4		W2112	8011	20		22-23-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2508	5527	20		33-18-31	ALL
8		W2104	0508	24		29-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00630		**P005-00/ /**		**PLUG- (continued)**				**ALL**
	9		W2212	0517	20		27-23-11	ALL
	10		W2112	0521	24		27-23-14	ALL
	11		W2218	0518	20		27-61-43	ALL
	12		W2112	8014	20		22-23-11	ALL
	13	UNUSED						ALL
	14		W2112	8018	20		22-23-11	ALL
	15		W2508	0051	20		31-52-25	ALL
	16		W2508	5528	20		33-18-31	ALL
	17		W2112	8017	20		22-23-11	ALL
	18		W2112	5584	20		33-18-31	ALL
	19		W2112	8012	22		22-23-11	ALL
	20		W2112	0524	22		27-31-37	ALL
	21		W2212	0518	20		27-23-11	ALL
	22		W2212	0521	20		27-23-11	ALL
	23	UNUSED						ALL
	24		W2212	0508	20		27-61-43	ALL
	25	UNUSED						ALL
	26		W2112	8013	20		22-23-11	ALL
	27		W2112	8015	20		22-23-11	ALL
	28	UNUSED						ALL
	29		W2508	5706	20		31-52-25	ALL
	30	UNUSED						ALL
	31		W2510	0519	22		27-83-21	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W2218	5618	22		27-61-45	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W2212	0523	20		29-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00630	**P005-00/ /**		**PLUG- (continued)**				**ALL**
38	UNUSED						ALL
39	UNUSED						ALL
40		W2212	0505	22		27-23-11	ALL
41		W2104	0501	20		27-23-11	ALL
42	UNUSED						ALL
43		W2212	0507	22		27-23-11	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52		W2212	0524	24		29-35-11	ALL
53		W2212	0524	24		29-35-11	ALL
54	UNUSED						ALL
55	UNUSED						ALL
D00634	**P005-04/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W2508	5538	20		33-18-33	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W2702	0504	22		49-62-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2508	5716	20		31-52-35	ALL
10		W2508	5539	20		33-18-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00634		**P005-04/ /**		**PLUG- (continued)**				**ALL**
	11		W2218	2205R	22		24-41-11	ALL
	12	UNUSED						ALL
	13		W2218	3202R	22		24-41-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2702	3201Y	22		24-22-31	ALL
	17		W2702	0501	22		24-22-31	ALL
	18		W2702	0508	22		49-94-21	ALL
	19		W2702	0509	22		49-62-11	ALL
	20	UNUSED						ALL
	21		W2508	5715	20		31-52-35	ALL
	22		W2508	5714	20		31-52-35	ALL
	23		W2508	5540	20		33-18-33	ALL
	24		W2218	2205B	22		24-41-11	ALL
	25		W2218	3202B	22		24-41-11	ALL
	26		W2218	3202Y	22		24-41-11	ALL
	27	UNUSED						ALL
	28		W2702	3201B	22		24-22-31	ALL
	29		W2702	3201R	22		24-22-31	ALL
	30		W2702	0506	22		49-62-11	ALL
	31		W2702	0505	22		49-62-11	ALL
	DED		W2702	3201Z			24-22-31	ALL
D00636		**P005-05/ /**		**PLUG-**				**ALL**
	1		W2218	5712	20		33-12-12	ALL
	2		W2218	5713	20		33-12-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00636	**P005-05/ /**		**PLUG- (continued)**				**ALL**
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2508	5712	20		31-52-31	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W2508	5711	20		31-52-31	ALL
15	UNUSED						ALL
16		W2218	0501	22		24-11-21	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	18	W2510	0515	18		24-11-21	ALL
21	UNUSED						ALL
22		W2508	5741	20		31-52-32	ALL
23		W2508	5742	20		31-52-32	ALL
24		W2508	5713	20		31-52-31	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W2508	5536	20		33-18-33	ALL
28		W2508	5740	20		31-52-32	ALL
29		W2508	5739	20		31-52-32	ALL
30	UNUSED						ALL
31	18	W2510	0516	18		24-11-21	ALL
D00638	**P005-09/ /**		**PLUG-**				**ALL**
1		W2112	5539	24		30-41-11	ALL
2		W2112	5540	24		30-41-11	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00638		**P005-09/ /**		**PLUG- (continued)**				**ALL**
	4		W2112	2003B	24		30-41-11	ALL
	5		W2112	2003R	24		30-41-11	ALL
	6		W2112	5534	24		30-41-11	ALL
	7		W2112	5533	24		30-41-11	ALL
	8		W2112	5535	24		30-41-11	ALL
	9		W2112	5541	24		30-41-11	ALL
	10	UNUSED						ALL
	11		W2508	5552	20		33-18-34	ALL
	12	UNUSED						ALL
	13		W2135	0022	22		34-21-22	ALL
	14	UNUSED						ALL
	15		W2135	0023	22		34-21-22	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W2212	5551	22		30-31-12	ALL
	23		W2212	5553	22		30-31-12	ALL
	24		W2212	5552	22		30-31-12	ALL
	25		W2212	5554	22		30-31-12	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W2112	5550	20		33-18-34	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00638	**P005-09/ /**		**PLUG- (continued)**				**ALL**
33		W2112	5525	22		30-31-12	ALL
34	UNUSED						ALL
35		W2508	5776	20		31-52-56	ALL
36		W2508	5777	20		31-52-56	ALL
37	UNUSED						ALL
38		W2216	5545	22		30-31-12	ALL
39		W2112	5526	22		30-31-12	ALL
40		W2112	5548	22		30-31-12	ALL
41		W2216	5548	22		30-31-12	ALL
42		W2112	5528	22		30-31-12	ALL
43		W2112	5529	22		30-31-12	ALL
44		W2216	5546	22		30-31-12	ALL
45		W2216	5547	22		30-31-12	ALL
46		W2112	5527	22		30-31-12	ALL
47		W2112	5532	24		30-41-11	ALL
48		W2112	5538	24		30-41-11	ALL
49		W2112	5553	20		30-41-11	ALL
50		W2112	5531	24		30-41-11	ALL
51		W2112	5536	24		30-41-11	ALL
52		W2112	5537	20		30-41-11	ALL
53	UNUSED						ALL
54		W2218	5742	20		33-12-12	ALL
55		W2216	5550	20		30-31-12	ALL
56	UNUSED						ALL
57		W2218	5741	20		33-12-12	ALL
58		W2112	5542	20		30-41-11	ALL
59	UNUSED						ALL
60		W2508	5775	20		31-52-56	ALL
61	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00642		**P005-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2508	5560	20		33-18-35	ALL
	4	UNUSED						ALL
	5		W2508	0532	24		29-33-11	ALL
	6		W2104	0510	24		29-34-11	ALL
	7		W2104	0509	24		29-33-11	ALL
	8	UNUSED						ALL
	9		W2212	0513	22		29-11-11	ALL
	10		W2212	0514	22		29-11-11	ALL
	11		W2508	5702	20		31-52-21	ALL
	12		W2508	5704	20		31-52-21	ALL
	13		W2212	0516	22		29-11-12	ALL
	14		W2212	0515	22		29-11-12	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D00644		**P005-09/ /**		**PLUG-**				**ALL**
	1		W2218	5539	24		30-41-12	ALL
	2		W2218	5540	24		30-41-12	ALL
	3	UNUSED						ALL
	4		W2218	2003B	24		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00644	**P005-09/ /**		**PLUG- (continued)**				**ALL**
5		W2218	2003R	24		30-41-12	ALL
6		W2218	5536	24		30-41-12	ALL
7		W2218	5535	24		30-41-12	ALL
8		W2218	5537	24		30-41-12	ALL
9		W2218	5538	24		30-41-12	ALL
10	UNUSED						ALL
11		W2508	5727	20		31-52-55	ALL
12	UNUSED						ALL
13		W2035	0023	22		34-21-12	ALL
14		W2035	0025	22		34-21-12	ALL
15		W2035	0024	22		34-21-12	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W2218	5806	22		30-31-11	ALL
24		W2218	5801	22		30-31-11	ALL
25		W2218	5807	22		30-31-11	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W2508	5549	20		33-18-34	ALL
33		W2218	5558	22		30-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00644		**P005-09/ /**		**PLUG- (continued)**				**ALL**
	34	UNUSED						ALL
	35	UNUSED						ALL
	36		W2218	5808	22		30-31-11	ALL
	37	UNUSED						ALL
	38		W2114	5518	22		30-31-11	ALL
	39		W2114	5514	22		30-31-11	ALL
	40		W2114	5535	22		30-31-11	ALL
	41		W2114	5517	22		30-31-11	ALL
	42		W2114	5513	22		30-31-11	ALL
	43		W2114	5524	22		30-31-11	ALL
	44		W2114	5519	22		30-31-11	ALL
	45		W2114	5520	22		30-31-11	ALL
	46		W2114	5515	22		30-31-11	ALL
	47		W2218	5534	24		30-41-12	ALL
	48		W2218	5541	24		30-41-12	ALL
	49		W2218	5531	20		30-41-12	ALL
	50		W2218	5532	24		30-41-12	ALL
	51		W2218	5533	24		30-41-12	ALL
	52		W2218	5530	20		30-41-12	ALL
	53	UNUSED						ALL
	54		W2508	5725	20		31-52-55	ALL
	55		W2114	5516	20		30-31-11	ALL
	56	UNUSED						ALL
	57		W2508	5726	20		31-52-55	ALL
	58		W2218	5573	20		30-41-12	ALL
	59	UNUSED						ALL
	60		W2508	5770	20		31-52-56	ALL
	61	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00646	**P005-10/ /**		**PLUG-**				**ALL**
1		W2216	5659	20		33-12-11	ALL
2		W2216	5658	20		33-12-11	ALL
3		W2508	5568	20		33-18-36	ALL
4		W2508	5619	20		21-51-11	ALL
5		W2508	5566	20		33-18-36	ALL
6		W2508	5569	20		33-18-36	ALL
7		W2112	5520	24		21-31-22	ALL
8		W2508	1307R	20		26-12-11	ALL
9		W2508	5562	20		33-18-36	ALL
10		W2216	5528	24		21-51-12	ALL
11		W2216	5534	24		36-11-12	ALL
12		W2216	5552	24		21-51-12	ALL
13		W2508	5511	24		21-51-11	ALL
14		W2112	5519	24		21-31-22	ALL
15		W2216	5527	20		21-51-12	ALL
16	UNUSED						ALL
17		W2508	5509	24		21-51-11	ALL
18		W2216	5536	20		36-11-12	ALL
19		W2216	5535	20		36-11-12	ALL
20		W2216	5541	24		36-11-31	ALL
21		W2216	2501R	24		36-11-31	ALL
22		W2216	2501B	24		36-11-31	ALL
23		W2508	5515	24		21-51-11	ALL
24		W2508	5516	24		21-51-11	ALL
25	UNUSED						ALL
26		W2216	5512	24		21-51-12	ALL
27		W2216	5558	24		21-61-12	ALL
28	UNUSED						ALL
29		W2508	5519	24		21-51-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00646		**P005-10/ /**		**PLUG- (continued)**				**ALL**
	30		W2508	5614	24		21-43-21	ALL
	31		W2508	5722	20		31-52-51	ALL
	32	UNUSED						ALL
	33		W2216	5566	20		36-11-12	ALL
	34	UNUSED						ALL
	35		W2508	5517	24		21-51-11	ALL
	36	UNUSED						ALL
	37		W2508	5520	24		21-51-15	ALL
	38		W2216	5579	20		36-11-12	ALL
	39		W2112	6007	24		34-61-17	ALL
	40		W2216	5506	24		21-61-11	ALL
	41		W2508	5513	24		21-51-11	ALL
	42		W2508	5510	24		21-51-11	ALL
	43		W2216	5567	24		36-11-12	ALL
	44		W2216	5538	24		36-11-31	ALL
	45		W2508	5514	24		21-51-11	ALL
	46		W2508	5518	24		21-51-11	ALL
	47		W2216	5505	24		21-61-11	ALL
	48		W2216	5514	24		21-61-12	ALL
	49	UNUSED						ALL
	50		W2216	5556	24		36-11-31	ALL
	51	UNUSED						ALL
	52		W2216	5521	24		21-61-14	ALL
	53		W2508	5512	22		21-25-11	ALL
	54		W2508	5530	22		21-25-11	ALL
	55		W2216	5555	24		21-51-12	ALL
	DED		W2216	5535Z			36-11-12	ALL
	DED		W2216	5536Z			36-11-12	ALL
	DED		W2216	5566Z			36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00646	**P005-10/ /**		**PLUG- (continued)**				**ALL**
DED		W2508	1307Z			26-12-11	ALL
D00648	**P005-11/ /**		**PLUG-**				**ALL**
1		W2216	6016	22		30-11-11	ALL
2		W2216	6015	22		30-21-31	ALL
3		W2112	0011	22		30-11-11	ALL
4		W2508	5553	20		33-18-34	ALL
5		W2510	0006	20		30-21-32	ALL
6		W2510	0005	20		30-21-32	ALL
7		W2510	0020R	22		26-11-21	ALL
8		W2112	5579	20		33-18-34	ALL
9	UNUSED						ALL
10		W2218	5582	24		36-11-23	ALL
11		W2112	0012	22		30-11-11	ALL
12		W2218	5705	20		33-12-12	ALL
13		W2218	5704	20		33-12-12	ALL
14		W2218	6010	22		30-21-32	ALL
15	UNUSED						ALL
16		W2510	0531	24		75-11-11	ALL
17		W2508	5774	20		31-52-56	ALL
18		W2218	5639	22		30-21-32	ALL
19		W2218	5638	22		30-21-32	ALL
20		W2508	5775	20		31-52-56	ALL
21		W2510	0204	22		30-21-32	ALL
22		W2112	5569	20		33-18-34	ALL
23		W2510	1201	20		30-21-32	ALL
24		W2112	6023	22		30-11-11	ALL
25		W2112	0010	20		30-11-11	ALL
26		W2218	0131	22		34-21-21	ALL
27		W2218	6006	20		30-21-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00648	**P005-11/ /**		**PLUG- (continued)**				**ALL**
28		W2510	0202	22		30-21-32	ALL
29		W2508	5773	20		31-52-56	ALL
30		W2218	6022	20		30-21-32	ALL
31		W2510	0203	22		30-21-32	ALL
CAP	Y	W2135	0011	22		34-21-21	ALL
DED		W2510	1201Z			30-21-32	ALL
D00650	**P005-12/ /**		**PLUG-**				**ALL**
1		W2218	5603	20		33-12-12	ALL
2		W2218	5602	20		33-12-12	ALL
3		W2218	0530	24		27-81-12	ALL
4		W2218	0529	24		27-81-12	ALL
5		W2218	0528	24		27-81-12	ALL
6		W2218	0533	24		27-81-12	ALL
7		W2218	0532	24		27-81-12	ALL
8		W2218	0531	24		27-81-12	ALL
9		W2218	0536	24		27-81-12	ALL
10		W2218	0535	24		27-81-12	ALL
11		W2218	0534	24		27-81-12	ALL
12		W2218	0539	24		27-81-12	ALL
13		W2218	0538	24		27-81-12	ALL
14		W2218	0537	24		27-81-12	ALL
15		W2218	0525	24		27-81-11	ALL
16		W2218	0524	24		27-81-11	ALL
17		W2218	0526	24		27-81-11	ALL
18		W2218	0527	24		27-81-11	ALL
19		W2218	0541	24		27-81-21	ALL
20		W2218	0542	24		27-81-21	ALL
21		W2218	0543	24		27-81-21	ALL
22		W2218	0540	24		27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00650	**P005-12/ /**		**PLUG- (continued)**				**ALL**
23		W2218	0544	24		27-81-22	ALL
24		W2218	0545	24		27-81-22	ALL
25		W2218	0546	24		27-81-22	ALL
26		W2218	0547	24		27-81-22	ALL
27		W2218	0548	24		27-81-22	ALL
28		W2218	0549	24		27-81-22	ALL
29		W2218	0550	24		27-81-22	ALL
30		W2218	0551	24		27-81-22	ALL
31		W2218	0552	24		27-81-22	ALL
32		W2218	0553	24		27-81-22	ALL
33		W2218	0554	24		27-81-22	ALL
34		W2218	0555	24		27-81-22	ALL
35		W2508	5592	20		33-18-41	ALL
36		W2508	5591	20		33-18-41	ALL
37		W2218	0523	20		27-81-11	ALL
38		W2218	0556	20		27-81-11	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00650		**P005-12/ /**		**PLUG- (continued)**				**ALL**
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D00652		**P005-13/ /**		**PLUG-**				**ALL**
	1		W2510	0505	24		24-31-12	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W2510	0504	20		24-31-12	ALL
	5		W2112	0063	22		33-22-11	ALL
	6		W2510	6051	22		24-28-41	ALL
	7		W2510	6050	22		24-28-41	ALL
	8		W2508	0531	24		24-31-12	ALL
	9		W2508	0529	24		24-33-11	ALL
	10		W2508	0512	24		24-33-11	ALL
	11		W2508	0513	24		24-33-11	ALL
	12		W2218	2202R	22		24-28-41	ALL
	13		W2218	2202B	22		24-28-41	ALL
	14		W2112	0062	22		33-22-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W2112	0510	24		24-33-11	ALL
	22		W2508	0521	24		24-34-11	ALL
	23		W2508	0514	24		24-33-11	ALL
	24		W2112	0515	20		24-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00652	**P005-13/ /**		**PLUG- (continued)**				**ALL**
25		W2508	0509	24		24-33-11	ALL
26		W2510	0507	24		24-31-12	ALL
27		W2510	0506	24		24-31-12	ALL
28		W2510	0508	24		24-31-12	ALL
29		W2218	2201B	22		24-28-11	ALL
30		W2112	2203B	22		24-28-11	ALL
31		W2112	2202B	22		24-28-11	ALL
32		W2508	2201B	20		24-31-11	ALL
33		W2510	2204R	22		24-33-11	ALL
34		W2510	2203R	22		24-33-11	ALL
35		W2510	2202R	22		24-33-11	ALL
36		W2508	2202B	20		24-31-12	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W2112	0513	20		24-28-11	ALL
40		W2508	5714	20		31-52-35	ALL
41		W2508	5711	20		31-52-31	ALL
42		W2508	0511	24		24-33-11	ALL
43		W2508	0510	24		24-33-11	ALL
44		W2508	0024	24		34-24-15	ALL
45		W2508	0025	20		34-24-15	ALL
46	UNUSED						ALL
47		W2218	2201R	22		24-28-11	ALL
48		W2112	2203R	22		24-28-11	ALL
49		W2112	2202R	22		24-28-11	ALL
50		W2508	2201R	20		24-31-11	ALL
51		W2510	2204B	22		24-33-11	ALL
52		W2510	2203B	22		24-33-11	ALL
53		W2510	2202B	22		24-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00652		**P005-13/ /**		**PLUG- (continued)**				**ALL**
	54		W2508	2202R	20		24-31-12	ALL
	55		W2112	0514	20		24-28-11	ALL
	DED		W2508	2201Z			24-31-11	ALL
	DED		W2508	2202Z			24-31-12	ALL
	DED		W2510	2202Z			24-33-11	ALL
	DED		W2510	2203Z			24-33-11	ALL
	DED		W2510	2204Z			24-33-11	ALL
D00654		**P005-16/ /**		**PLUG-**				**ALL**
	1		W2216	5609	20		33-12-11	ALL
	2		W2216	5608	20		33-12-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W2508	5507	22		21-33-11	ALL
	7		W2508	5508	22		21-33-11	ALL
	8		W2508	0030	22		21-33-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D00660		**669/181/R021**		**PLUG-CONDUCTIVE**				**ALL**
	1		W8222	0509	18		29-32-11	ALL
	2		W8222	1009	18		29-32-11	ALL
	3		W8222	1008	18		29-32-11	ALL
	S/R		W8222	1008Z			29-32-11	ALL
	S/R		W8222	1009Z			29-32-11	ALL
D00662		**668/171/L048**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7230	0503	18		29-32-11	ALL
	2		W7230	1005	18		29-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00662	**668/171/L048**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3		W7230	1004	18		29-32-11	ALL
S/R		W7230	1004Z			29-32-11	ALL
S/R		W7230	1005Z			29-32-11	ALL
D00674	**678/195/R008**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0501	20		29-31-11	ALL
2		W7128	0502	20		29-31-11	ALL
3		W7128	0503	20		29-31-11	ALL
4	UNUSED						ALL
5		W7128	0510	20		29-31-11	ALL
D00678	**718/171/L000**		**PLUG-CONDUCTIVE**				**ALL**
1		W7128	0402	18		29-31-11	ALL
2		W7128	0406	20		29-31-11	ALL
D00680	**P005-10/ /**		**PLUG-**				**ALL**
1		W2218	5514	24		21-51-22	ALL
2		W2218	5551	24		21-51-22	ALL
3	UNUSED						ALL
4		W2218	0040	24		36-11-31	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W2218	0043	24		36-11-31	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2510	5515	24		21-51-25	ALL
12		W2218	5516	20		21-51-22	ALL
13		W2510	5501	24		21-51-21	ALL
14		W2218	5643	20		36-11-22	ALL
15		W2218	5649	20		36-11-22	ALL
16		W2218	5666	20		36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00680		**P005-10/ /**		**PLUG- (continued)**				**ALL**
	17		W2112	5518	24		21-31-22	ALL
	18		W2218	5505	24		21-31-11	ALL
	19		W2218	5669	24		36-11-22	ALL
	20		W2508	5563	20		33-18-36	ALL
	21		W2508	1306R	20		26-12-11	ALL
	22		W2508	5564	20		33-18-36	ALL
	23		W2508	1305R	20		26-12-11	ALL
	24		W2508	5721	20		31-52-51	ALL
	25		W2510	5516	24		21-51-25	ALL
	26		W2218	5519	24		21-51-22	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2510	5510	24		21-51-21	ALL
	30		W2510	5511	24		21-51-21	ALL
	31	UNUSED						ALL
	32		W2218	5521	24		21-61-13	ALL
	33		W2508	1303R	20		26-12-11	ALL
	34		W2508	1304R	20		26-12-11	ALL
	35		W2508	5724	20		31-52-51	ALL
	36		W2508	5617	24		21-43-21	ALL
	37		W2508	5747	20		31-52-51	ALL
	38		W2218	5668	20		36-11-22	ALL
	39		W2216	6006	24		34-61-17	ALL
	40	UNUSED						ALL
	41		W2510	5512	24		21-51-21	ALL
	42		W2218	5508	24		21-51-21	ALL
	43		W2218	5644	24		36-11-22	ALL
	44		W2218	5671	24		36-11-31	ALL
	45		W2510	5509	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00680		**P005-10/ /**		**PLUG- (continued)**				**ALL**
	46		W2508	5611	22		21-25-11	ALL
	47		W2510	5502	22		21-25-11	ALL
	48		W2508	5672	24		21-43-21	ALL
	49	UNUSED						ALL
	50		W2218	5672	24		36-11-31	ALL
	51		W2508	5615	24		21-43-21	ALL
	52		W2508	5672	24		21-43-21	ALL
	53		W2508	5616	24		21-43-21	ALL
	54		W2508	5617	24		21-43-21	ALL
	55		W2218	5515	24		21-51-22	ALL
	DED		W2218	5643Z			36-11-22	ALL
	DED		W2218	5649Z			36-11-22	ALL
	DED		W2218	5666Z			36-11-22	ALL
	DED		W2508	1303Z			26-12-11	ALL
	DED		W2508	1304Z			26-12-11	ALL
	DED		W2508	1305Z			26-12-11	ALL
	DED		W2508	1306Z			26-12-11	ALL
D00698		**AF0222A/ /**		**PLUG-STAB TRIM C/0SW**				**ALL**
	1		W6208	0543	20		27-41-11	ALL
	2		W6208	0006	20		22-13-11	ALL
	3		W6208	0007	20		22-13-11	ALL
	4		W6208	0008	20		22-13-11	ALL
	5		W6208	0520	20		27-41-11	ALL
	6		W6208	0005	20		22-13-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00698		**AF0222A/ /**		**PLUG-STAB TRIM C/0SW (continued)**				**ALL**
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00700	**1072/235/R003**		**PLUG-STAB TRIM ACT**				**ALL**
1	UNUSED						ALL
2		W4222	1011	20		22-13-11	ALL
3	18	W4222	1010	18		27-41-12	ALL
4		W4222	1015	20		27-41-12	ALL
5		W4222	1012	20		22-13-11	ALL
6	UNUSED						ALL
7		W4222	1014	20		22-13-11	ALL
8	UNUSED						ALL
9	18	W4222	1004	18		27-41-12	ALL
10		W4222	1020	20		22-13-11	ALL
11	UNUSED						ALL
12		W4222	1013	20		22-13-11	ALL
S/R		W4222	1004Z			27-41-12	ALL
S/R		W4222	1011Z			22-13-11	ALL
S/R		W4222	1012Z			22-13-11	ALL
S/R		W4222	1013Z			22-13-11	ALL
S/R		W4222	1014Z			22-13-11	ALL
S/R		W4222	1015Z			27-41-12	ALL
S/R		W4222	1020Z			22-13-11	ALL
D00722	**P005-04/ /**		**PLUG-**				**ALL**
1		W2218	5708	20		33-12-12	ALL
2		W2218	5709	20		33-12-12	ALL
3	UNUSED						ALL
4		W2112	0504	22		24-22-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00722		**P005-04/ /**		**PLUG- (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2112	2201R	22		24-23-11	ALL
	13		W2112	2201B	22		24-23-11	ALL
	14	UNUSED						ALL
	15		W2702	2201R	22		24-22-31	ALL
	16		W2702	2201B	22		24-22-31	ALL
	17		W2508	5738	20		31-52-32	ALL
	18		W2508	5737	20		31-52-32	ALL
	19		W2508	5546	20		33-18-33	ALL
	20		W2112	0503	22		24-22-11	ALL
	21		W2112	0505	22		24-22-11	ALL
	22		W2112	3201B	22		24-22-11	ALL
	23		W2112	3201Y	22		24-22-11	ALL
	24		W2112	3201R	22		24-22-11	ALL
	DED		W2112	3201Z			24-22-11	ALL
	DED		W2702	2201Z			24-22-31	ALL
D00728A		***/*/***		**PLUG**				**ALL**
	A01		W0111	0675	24		27-81-12	ALL
	A02		W0111	0674	24		27-81-12	ALL
	A03		W0111	0676	24		27-81-12	ALL
	A04		W0111	0677	24		27-81-21	ALL
	A05		W0111	0680	24		27-81-21	ALL
	A06		W0111	0691	24		27-81-22	ALL
	A07		W0111	0692	24		27-81-22	ALL
	A08		W0111	0690	24		27-81-22	ALL
	A09	UNUSED						ALL
	A10		W0111	0537	24		27-81-31	ALL
	A11		W0111	0120	22		27-81-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728A		*/*/*		**PLUG (continued)**				**ALL**
	A12		W0111	0756	22		27-54-11	ALL
	A13	UNUSED						ALL
	A14		W0111	2179R	24		27-81-12	ALL
	A15		W0111	2179B	24		27-81-12	ALL
	B01		W0111	0672	24		27-81-12	ALL
	B02		W0111	0671	24		27-81-12	ALL
	B03		W0111	0673	24		27-81-12	ALL
	B04		W0111	0679	24		27-81-21	ALL
	B05		W0111	0678	24		27-81-21	ALL
	B06		W0111	0688	24		27-81-22	ALL
	B07		W0111	0689	24		27-81-22	ALL
	B08		W0111	0687	24		27-81-22	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0111	0581	22		31-53-11	ALL
	B13	UNUSED						ALL
	B14		W0111	2180R	24		27-81-12	ALL
	B15		W0111	2180B	24		27-81-12	ALL
	C01		W0111	0669	24		27-81-12	ALL
	C02		W0111	0668	24		27-81-12	ALL
	C03		W0111	0670	24		27-81-12	ALL
	C04		W0111	0709	24		27-81-11	ALL
	C05		W0111	0708	24		27-81-11	ALL
	C06		W0111	0685	24		27-81-22	ALL
	C07		W0111	0686	24		27-81-22	ALL
	C08		W0111	0684	24		27-81-22	ALL
	C09	UNUSED						ALL
	C10		W0111	0080	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728A		***/*/***		**PLUG (continued)**				**ALL**
	C11		W0111	0589	24		21-51-24	ALL
	C12		W0111	1033	22		27-25-11	ALL
	C13	UNUSED						ALL
	C14		W0111	2181R	24		27-81-12	ALL
	C15		W0111	2181B	24		27-81-12	ALL
	D01		W0111	0666	24		27-81-12	ALL
	D02		W0111	0665	24		27-81-12	ALL
	D03		W0111	0667	24		27-81-12	ALL
	D04		W0111	0705	24		27-81-11	ALL
	D05		W0111	0706	24		27-81-11	ALL
	D06		W0111	0682	24		27-81-22	ALL
	D07		W0111	0683	24		27-81-22	ALL
	D08		W0111	0681	24		27-81-22	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11		W0111	0252	22		27-32-11	ALL
	D12		W0111	0119	22		27-81-51	ALL
	D13	UNUSED						ALL
	D14		W0111	2182R	24		27-81-22	ALL
	D15		W0111	2182B	24		27-81-22	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728A	*/*/*		**PLUG (continued)**				**ALL**
E10	UNUSED						ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14		W0111	2201R	24		27-81-22	ALL
E15		W0111	2201B	24		27-81-22	ALL
F01		W0111	0704	22		27-81-11	ALL
F02		W0111	0699	22		27-81-11	ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14		W0111	2202R	24		27-81-22	ALL
F15		W0111	2202B	24		27-81-22	ALL
G01	UNUSED						ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04		W0111	2162B	24		27-81-22	ALL
G05		W0111	2164B	24		27-81-22	ALL
G06		W0111	2160B	24		27-81-22	ALL
G07		W0111	2161B	24		27-81-22	ALL
G08		W0111	2158B	24		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728A		***/*/***		**PLUG (continued)**				**ALL**
	G09		W0111	2159B	24		27-81-22	ALL
	G10		W0111	2156B	24		27-81-22	ALL
	G11		W0111	2157B	24		27-81-22	ALL
	G12		W0111	2153B	24		27-81-21	ALL
	G13		W0111	2152B	24		27-81-21	ALL
	G14		W0111	2154B	24		27-81-21	ALL
	G15		W0111	2155B	24		27-81-21	ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04		W0111	2162R	24		27-81-22	ALL
	H05		W0111	2164R	24		27-81-22	ALL
	H06		W0111	2160R	24		27-81-22	ALL
	H07		W0111	2161R	24		27-81-22	ALL
	H08		W0111	2158R	24		27-81-22	ALL
	H09		W0111	2159R	24		27-81-22	ALL
	H10		W0111	2156R	24		27-81-22	ALL
	H11		W0111	2157R	24		27-81-22	ALL
	H12		W0111	2153R	24		27-81-21	ALL
	H13		W0111	2152R	24		27-81-21	ALL
	H14		W0111	2154R	24		27-81-21	ALL
	H15		W0111	2155R	24		27-81-21	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04		W0111	2144B	24		27-81-12	ALL
	J05		W0111	2145B	24		27-81-12	ALL
	J06		W0111	2146B	24		27-81-12	ALL
	J07		W0111	2147B	24		27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728A	*/*/*		**PLUG (continued)**				**ALL**
J08		W0111	2148B	24		27-81-12	ALL
J09		W0111	2149B	24		27-81-12	ALL
J10		W0111	2150B	24		27-81-12	ALL
J11		W0111	2151B	24		27-81-12	ALL
J12		W0111	2185B	24		27-81-11	ALL
J13		W0111	2184B	24		27-81-11	ALL
J14		W0111	2186B	24		27-81-11	ALL
J15		W0111	2187B	24		27-81-11	ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0111	2144R	24		27-81-12	ALL
K05		W0111	2145R	24		27-81-12	ALL
K06		W0111	2146R	24		27-81-12	ALL
K07		W0111	2147R	24		27-81-12	ALL
K08		W0111	2148R	24		27-81-12	ALL
K09		W0111	2149R	24		27-81-12	ALL
K10		W0111	2150R	24		27-81-12	ALL
K11		W0111	2151R	24		27-81-12	ALL
K12		W0111	2185R	24		27-81-11	ALL
K13		W0111	2184R	24		27-81-11	ALL
K14		W0111	2186R	24		27-81-11	ALL
K15		W0111	2187R	24		27-81-11	ALL
PERG	1A	W0111	1033Z			27-25-11	ALL
D00728B	*/*/*		**PLUG**				**ALL**
A01		W0111	0695	24		27-81-31	ALL
A02		W0111	0655	22		27-53-11	ALL
A03	UNUSED						ALL
A04		W0111	2105R	24		34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B		***/*/***		**PLUG (continued)**				**ALL**
	A05		W0111	2105B	24		34-21-14	ALL
	A06		W0111	2293R	24		31-65-15	ALL
	A07		W0111	2293B	24		31-65-15	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0111	3024R	22		27-51-11	ALL
	A11		W0111	3024B	22		27-51-11	ALL
	A12		W0111	3024Y	22		27-51-11	ALL
	A13		W0111	3023R	22		27-53-21	ALL
	A14		W0111	3023B	22		27-53-21	ALL
	A15		W0111	3023Y	22		27-53-21	ALL
	B01		W0111	0411	22		27-53-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0111	3022R	22		27-53-21	ALL
	B14		W0111	3022B	22		27-53-21	ALL
	B15		W0111	3022Y	22		27-53-21	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B	*/*/*		**PLUG (continued)**				**ALL**
C04		W0111	2165R	24		27-81-41	ALL
C05		W0111	2165B	24		27-81-41	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13		W0111	3021R	22		27-53-21	ALL
C14		W0111	3021B	22		27-53-21	ALL
C15		W0111	3021Y	22		27-53-21	ALL
D01	UNUSED						ALL
D02		W0111	0217	22		27-81-41	ALL
D03	UNUSED						ALL
D04		W0111	2168R	24		27-81-41	ALL
D05		W0111	2168B	24		27-81-41	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13		W0111	3020R	22		27-53-21	ALL
D14		W0111	3020B	22		27-53-21	ALL
D15		W0111	3020Y	22		27-53-21	ALL
E01	UNUSED						ALL
E02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B		***/*/***		**PLUG (continued)**				**ALL**
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11		W0111	1006	24		27-52-11	ALL
	E12	UNUSED						ALL
	E13		W0111	3016R	22		27-53-21	ALL
	E14		W0111	3016B	22		27-53-21	ALL
	E15		W0111	3016Y	22		27-53-21	ALL
	F01	UNUSED						ALL
	F02		W0111	0839	22		27-81-41	ALL
	F03		W0111	0736	24		27-81-31	ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0111	3017R	22		27-53-21	ALL
	F14		W0111	3017B	22		27-53-21	ALL
	F15		W0111	3017Y	22		27-53-21	ALL
	G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B	*/*/*		**PLUG (continued)**				**ALL**
G02		W0111	0838	22		27-81-41	ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05		W0111	0223	22		27-81-11	ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11		W0111	1007	24		27-52-11	ALL
G12	UNUSED						ALL
G13		W0111	3018R	22		27-53-21	ALL
G14		W0111	3018B	22		27-53-21	ALL
G15		W0111	3018Y	22		27-53-21	ALL
H01	UNUSED						ALL
H02		W0111	0218	22		27-81-41	ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13		W0111	3019R	22		27-53-21	ALL
H14		W0111	3019B	22		27-53-21	ALL
H15		W0111	3019Y	22		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B		***/*/***		**PLUG (continued)**				**ALL**
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07		W0111	2189R	24		27-52-11	ALL
	J08		W0111	2189B	24		27-52-11	ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0111	0723	22		27-53-11	ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07		W0111	2192R	24		27-52-11	ALL
	K08		W0111	2192B	24		27-52-11	ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00728B	***/*/***		**PLUG (continued)**				**ALL**
K15	UNUSED						ALL
DED		W0111	1006Z			27-52-11	ALL
DED		W0111	1007Z			27-52-11	ALL
DED		W0111	2189Z			27-52-11	ALL
DED		W0111	2192Z			27-52-11	ALL
PERG	1A	W0111	2105Z			34-21-14	ALL
PERG	1A	W0111	2165Z			27-81-41	ALL
PERG	1A	W0111	2168Z			27-81-41	ALL
PERG	1A	W0111	2293Z			31-65-15	ALL
D00728C	***/*/***		**PLUG**				**ALL**
1	UNUSED						ALL
2		W0111	0701	22		27-81-11	ALL
3		W0111	0642	20		27-53-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0111	0645	20		27-53-11	ALL
8		W0111	0641	20		27-53-11	ALL
9		W0111	0697	22		27-81-11	ALL
10		W0111	0696	22		27-81-11	ALL
11		W0111	0735	22		27-81-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
=C12	UNUSED						ALL
=C13	UNUSED						ALL
D00730	**P005-04/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00730		**P005-04/ /**		**PLUG- (continued)**				**ALL**
	4		W2218	3201R	22		24-22-21	ALL
	5		W2218	0503	22		24-22-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2508	5739	20		31-52-32	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W2508	0506	24		24-32-11	ALL
	12	UNUSED						ALL
	13		W2218	3201Y	22		24-22-21	ALL
	14		W2218	3201B	22		24-22-21	ALL
	15		W2218	0504	22		24-22-21	ALL
	16		W2218	0502	22		24-22-21	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W2508	5740	20		31-52-32	ALL
	20		W2508	5537	20		33-18-33	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2508	0504	20		24-32-11	ALL
	24		W2508	0505	24		24-32-11	ALL
	DED		W2218	3201Z			24-22-21	ALL
D00732		**OFSS-258/ /**		**PLUG**				**ALL**
	1		W1662	2002B	20		30-11-11	ALL
	2		W1662	2002R	20		30-11-11	ALL
	3		W1662	0010	20		30-11-11	ALL
	4		W1662	2003B	20		30-11-11	ALL
	5		W1662	2003R	20		30-11-11	ALL
	S/R		W1662	2002Z			30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00732	**OFSS-258/ /**		**PLUG (continued)**				**ALL**
S/R		W1662	2003Z			30-11-11	ALL
D00734	**OFSS 258/ /**		**PLUG**				**ALL**
1		W1664	2002B	20		30-11-11	ALL
2		W1664	2002R	20		30-11-11	ALL
3		W1664	0017	20		30-11-11	ALL
4		W1664	2003R	20		30-11-11	ALL
5		W1664	2003B	20		30-11-11	ALL
S/R		W1664	2002Z			30-11-11	ALL
S/R		W1664	2003Z			30-11-11	ALL
D00736	**OFSS 266/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1		W1288	1012	20		30-11-11	ALL
2		W1288	1015	20		30-11-11	ALL
S/R		W1288	1012Z			30-11-11	ALL
S/R		W1288	1015Z			30-11-11	ALL
D00738	**OFSS-266/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1		W1188	1012	20		30-11-11	ALL
2		W1188	1015	20		30-11-11	ALL
S/R		W1188	1012Z			30-11-11	ALL
S/R		W1188	1015Z			30-11-11	ALL
D00742	**E001-04/ /**		**PLUG**				**ALL**
1		W0141	0418R	20		26-12-11	ALL
2		W0141	0441R	20		26-12-11	ALL
3		W0141	0421R	22		26-12-11	ALL
4		W0141	0414R	20		26-12-11	ALL
5		W0141	0417R	20		26-12-11	ALL
6		W0141	0416R	20		26-12-11	ALL
7		W0141	0415R	22		26-12-11	ALL
8		W0141	0440R	20		26-12-11	ALL
9		W0141	0430R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00742		**E001-04/ /**		**PLUG (continued)**				**ALL**
	10		W0141	0436R	20		26-12-11	ALL
	11		W0141	0437R	20		26-12-11	ALL
	12		W0141	0443R	20		26-12-11	ALL
	13		W0141	0438R	20		26-12-11	ALL
	14		W0141	0424R	22		26-12-11	ALL
	15		W0141	0428R	22		26-12-11	ALL
	16		W0141	0426R	22		26-12-11	ALL
	17		W0141	0433R	22		26-12-11	ALL
	18		W0141	0434R	22		26-12-11	ALL
	19		W0141	0435R	22		26-12-11	ALL
	20		W0141	0427R	22		26-12-11	ALL
	21		W0141	0422R	20		26-12-11	ALL
	22		W0141	0432R	22		26-12-11	ALL
	23		W0141	0431R	22		26-12-11	ALL
	24		W0141	0423R	20		26-12-11	ALL
	25		W0141	0425R	22		26-12-11	ALL
	26	UNUSED						ALL
	27		W0141	0439R	20		26-12-11	ALL
	28		W0141	0419R	20		26-12-11	ALL
	29		W0141	0429R	20		26-12-11	ALL
	30		W0141	0445R	20		26-12-11	ALL
	31		W0141	0470R	20		26-12-11	ALL
	32		W0141	0447R	20		26-12-11	ALL
	33		W0141	0448R	20		26-12-11	ALL
	34		W0141	0471R	20		26-12-11	ALL
	35		W0141	0446R	20		26-12-11	ALL
	36		W0141	0410R	20		26-12-11	ALL
	37		W0141	0411R	20		26-12-11	ALL
	38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00742	**E001-04/ /**		**PLUG (continued)**				**ALL**
39		W0141	0412R	20		26-12-11	ALL
40		W0141	0413R	20		26-12-11	ALL
41		W0141	0444R	20		26-12-11	ALL
42		W0141	0449R	20		26-12-11	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48		W0141	0450R	20		26-12-11	ALL
49	UNUSED						ALL
50		W0141	0452R	20		26-12-11	ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
56	UNUSED						ALL
57	UNUSED						ALL
D00758	**666/179/R051**		**PLUG-CONDUCTIVE**				**ALL**
1		W8122	0544	18		27-61-43	ALL
2		W8122	0542	18		27-61-43	ALL
3		W8122	0543	18		27-61-43	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D00760	**666/178/L056**		**PLUG-CONDUCTIVE**				**ALL**
1		W7026	0508	18		27-61-43	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00760		**666/178/L056**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2		W7026	0506	18		27-61-43	ALL
	3		W7026	0507	18		27-61-43	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D00762		**673/190/L065**		**PLUG-CONDUCTIVE**				**ALL**
	S/R		W7522	1508Z			31-65-14	ALL
	S/R		W7522	2001Z			29-11-11	ALL
	A		W7522	2001R	18		29-11-11	ALL
	B		W7522	2001B	18		29-11-11	ALL
	C	UNUSED						ALL
	D		W7522	1508	18		31-65-14	ALL
	E		W7522	0503	20		29-11-11	ALL
D00764		**682/189/R073**		**PLUG-**				**ALL**
	S/R		W8222	1513Z			31-65-24	ALL
	S/R		W8222	2002Z			29-11-11	ALL
	A		W8222	2002R	18		29-11-11	ALL
	B		W8222	2002B	18		29-11-11	ALL
	C	UNUSED						ALL
	D		W8222	1513	18		31-65-24	ALL
	E		W8222	0508	20		29-11-11	ALL
D00776		**196/206/R001**		**PLUG-CAB PRESS SW**				**ALL**
	A		W5514	5552	22		21-33-11	ALL
	B		W5514	5550	20		21-33-11	ALL
	C	UNUSED						ALL
D00786		**P005-16/ /**		**PLUG-**				**ALL**
	1		W2216	5604	20		33-12-11	ALL
	2		W2216	5605	20		33-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00786	**P005-16/ /**		**PLUG- (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D00788	**OFSS-271/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W1178	1009	20		28-21-11	ALL
3		W1178	1010	20		28-21-11	ALL
4		W1178	1011	18		28-21-11	ALL
5		W1178	1012	20		28-21-11	ALL
6		W1024	1001	20		28-21-11	ALL
7		W1178	1013	18		28-21-11	ALL
D00790	**OFSS-271/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W1278	1009	20		28-21-11	ALL
3		W1278	1010	20		28-21-11	ALL
4		W1278	1011	18		28-21-11	ALL
5		W1278	1012	20		28-21-11	ALL
6		W1034	1001	20		28-21-11	ALL
7		W1278	1013	18		28-21-11	ALL
D00792	**666/183/R043**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W6128	1004	20		28-22-11	ALL
3		W6128	1003	20		28-22-11	ALL
4		W6128	1006	18		28-22-11	ALL
5		W6128	1007	20		28-22-11	ALL
6	UNUSED						ALL
7		W6128	1005	18		28-22-11	ALL
DED		W6128	1003Z			28-22-11	ALL
DED		W6128	1004Z			28-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00792		**666/183/R043**		**PLUG (continued)**				**ALL**
	DED		W6128	1005Z			28-22-11	ALL
	DED		W6128	1006Z			28-22-11	ALL
	DED		W6128	1007Z			28-22-11	ALL
D00794		**P005-16/ /**		**PLUG-**				**ALL**
	1		W2216	5610	20		33-12-11	ALL
	2		W2216	5611	20		33-12-11	ALL
D00796		**210/217/L031**		**PLUG-MODULE P021-01**				**ALL**
	1		W2102	5509	20		33-11-11	ALL
	2		W2102	5518	20		33-11-11	ALL
	3	UNUSED						ALL
	4		W2102	5508	20		33-17-11	ALL
	5	UNUSED						ALL
	6		W2102	5535	20		33-17-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W2102	5505	20		33-17-11	ALL
	11		W2102	5514	20		33-17-11	ALL
	12		W2102	5529	20		33-17-11	ALL
D00798		**210/217/R031**		**PLUG-MODULE P023-01**				**ALL**
	1		W2204	5512	20		33-11-21	ALL
	2		W2204	5513	20		33-11-21	ALL
	3	UNUSED						ALL
	4		W2204	5509	20		33-17-11	ALL
	5	UNUSED						ALL
	6		W2204	5535	20		33-17-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00798		**210/217/R031**		**PLUG-MODULE P023-01 (continued)**				**ALL**
	10		W2204	5517	20		33-17-11	ALL
	11		W2204	5514	20		33-17-11	ALL
	12		W2204	5511	20		33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00802		**664/182/L020**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1128	3601R	18		28-23-11	ALL
	2		W1128	3601Y	18		28-23-11	ALL
	3		W1128	3601B	18		28-23-11	ALL
	4	UNUSED						ALL
	DED		W1128	3601Z			28-23-11	ALL
D00804		**663/183/R011**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1126	3601R	18		28-23-11	ALL
	2		W1126	3601Y	18		28-23-11	ALL
	3		W1126	3601B	18		28-23-11	ALL
	4	UNUSED						ALL
	DED		W1126	3601Z			28-23-11	ALL
D00812		**727+18/150/R027**		**PLUG-**				**ALL**
	A		W8538	0501	12		29-22-11	ALL
	B		W8538	0502	12		29-22-11	ALL
	C		W8538	0503	12		29-22-11	ALL
	D	UNUSED						ALL
D00814		**666/178/L053**		**PLUG-FLT CNTRL SYS A PRESSURE SW**				**ALL**
	1		W7122	0530	20		31-31-15	ALL
	2		W7122	0505	20		27-23-14	ALL
	3		W7122	0504	20		27-23-14	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D00815		**222/194/L020**		**RCPT-CONT WHEEL POS SENSOR**				**ALL**
	1		W5257	2001B	22		31-31-14	ALL
	2		W5257	3001B	22		31-31-14	ALL
	3		W5257	3001R	22		31-31-14	ALL
	4		W5257	3001Y	22		31-31-14	ALL
	5		W5257	2001R	22		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00816	**666/179/R054**		**PLUG-CONDUCTIVE**				**ALL**
1		W8122	0530	20		31-31-15	ALL
2		W8122	0502	20		27-23-14	ALL
3		W8122	0501	20		27-23-14	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D00817	**230/203/L012**		**RCPT-CONT COLUMN POS SENSOR**				**ALL**
1		W5257	2002B	22		31-31-14	ALL
2		W5257	3002B	22		31-31-14	ALL
3		W5257	3002R	22		31-31-14	ALL
4		W5257	3002Y	22		31-31-14	ALL
5		W5257	2002R	22		31-31-14	ALL
D00818	**666/178/L050**		**PLUG-FLT CONT SYS A SHUTOFF VALVE**				**ALL**
1		W7122	0512	18		27-23-11	ALL
2		W7122	0511	18		27-23-11	ALL
3		W7122	0510	18		27-23-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D00819	**234/202/R27**		**PLUG-RUDDER PEDAL POS SENSOR**				**ALL**
1		W5257	2003B	22		31-31-14	ALL
2		W5257	2003R	22		31-31-14	ALL
3		W5257	3003Y	22		31-31-14	ALL
4		W5257	3003R	22		31-31-14	ALL
5		W5257	3003B	22		31-31-14	ALL
D00820	**666/179/R056**		**PLUG**				**ALL**
1		W8122	0513	20		27-23-11	ALL
2		W8122	0512	20		27-23-11	ALL
3		W8122	0511	20		27-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00820		**666/179/R056**		**PLUG (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D00821		**667/193/R048**		**PLUG-ACCELEROMETER**				**ALL**
	S/R		W5603	2001Z			31-31-14	ALL
	S/R		W5603	2002Z			31-31-14	ALL
	S/R		W5603	2003Z			31-31-14	ALL
	S/R		W5603	2004Z			31-31-14	ALL
	A		W5603	2001R	20		31-31-14	ALL
	B		W5603	2001B	20		31-31-14	ALL
	C		W5603	2002R	20		31-31-14	ALL
	D		W5603	2002B	20		31-31-14	ALL
	E		W5603	2003R	20		31-31-14	ALL
	F		W5603	2003B	20		31-31-14	ALL
	G		W5603	2004R	20		31-31-14	ALL
	H		W5603	2004B	20		31-31-14	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D00822		**724/168/L012**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7128	0521	18		27-23-11	ALL
	2		W7128	0518	18		27-23-11	ALL
	3		W7128	0519	18		27-23-11	ALL
	4		W7128	0520	18		27-23-14	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D00824		**723/163/L001**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00824	**723/163/L001**		**PLUG-CONDUCTIVE (continued)**				**ALL**
2		W7128	0405	20		29-35-11	ALL
3		W7128	0401	20		29-35-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D00832	**544/166/L039**		**PLUG - CONDUCTIVE**				**ALL**
P		W5102	1015R	20		26-12-11	ALL
D00834	**IFSS-220/ /**		**PLUG - CONDUCTIVE**				**ALL**
P		W1182	1009R	20		26-12-11	ALL
D00836	**544/166/R039**		**PLUG - CONDUCTIVE**				**ALL**
P		W6202	1021R	20		26-12-11	ALL
D00838	**IFSS 221/ /**		**PLUG - CONDUCTIVE**				**ALL**
P		W1282	1009R	20		26-12-11	ALL
D00844	**563/159/R039**		**PLUG - CONDUCTIVE**				**ALL**
P		W6202	1010R	20		26-12-11	ALL
D00846	**570/164/R008**		**PLUG - CONDUCTIVE**				**ALL**
P		W6502	1003R	20		26-12-11	ALL
D00848	**540/155/R005**		**PLUG - CONDUCTIVE**				**ALL**
P		W6528	0590R	20		26-12-11	ALL
D00850	**656/147/R005**		**PLUG - CONDUCTIVE**				**ALL**
P		W7500	1302R	20		26-12-11	ALL
D00852	**667/151/R004**		**PLUG - CONDUCTIVE**				**ALL**
P		W7500	1302R	20		26-12-11	ALL
D00854	**722/150/R004**		**PLUG - CONDUCTIVE**				**ALL**
P		W7128	1003R	20		26-12-11	ALL
D00856	**570/164/L008**		**PLUG - CONDUCTIVE**				**ALL**
P		W5502	1010R	20		26-12-11	ALL
D00858	**563/159/L039**		**PLUG-**				**ALL**
P		W5102	1014R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00862		**1016/202/L011**		**PLUG-**				**ALL**
	=1		W6248	0301R	20		26-12-11	ALL
D00864		**1047/203/L011**		**PLUG-**				**ALL**
	=1		W6248	0303R	20		26-12-11	ALL
D00866		**1084/222/R012**		**PLUG-**				**ALL**
	=1		W6248	0304R	20		26-12-11	ALL
	CAP	Y	W6248	0499	20		SPARE	ALL
	CAP	Y	W6248	0500	20		SPARE	ALL
D00876		**667/188/L029**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1128	1302	20		28-43-11	ALL
	3		W1128	1301	20		28-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	DED		W1128	1301Z			28-43-11	ALL
	DED		W1128	1302Z			28-43-11	ALL
D00878		**666/186/R029**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1126	1304	20		28-43-11	ALL
	3		W1126	1303	20		28-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	DED		W1126	1303Z			28-43-11	ALL
	DED		W1126	1304Z			28-43-11	ALL
D00890		**OFSS 373/ /**		**PLUG**				**ALL**
	1		W1664	0027	16		28-44-11	ALL
	2		W1664	0038	20		28-44-11	ALL
	3		W1664	0039	20		28-44-11	ALL
D00892		**OFSS 377/ /**		**PLUG**				**ALL**
	1		W1664	0025	16		28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00892	**OFSS 377/ /**		**PLUG (continued)**				**ALL**
2		W1664	0036	20		28-44-11	ALL
3		W1664	0037	20		28-44-11	ALL
D00894	**OFSS 382/ /**		**PLUG**				**ALL**
1		W1664	0023	16		28-44-11	ALL
2		W1664	0034	20		28-44-11	ALL
3		W1664	0035	20		28-44-11	ALL
D00895	**P001-03/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0003	1690	20		33-18-21	ALL
4	UNUSED						ALL
5		W0003	1518	22		27-62-11	ALL
6		W0003	0689	20		33-18-21	ALL
7		W0003	1517	22		27-62-11	ALL
8		W0003	1686	20		33-18-21	ALL
9		W0003	1685	20		33-18-21	ALL
10		W0003	1707	20		22-13-11	ALL
11		W0003	1691	20		33-18-21	ALL
12		W0003	1072	22		31-53-11	ALL
13		W0003	1070	22		21-33-11	ALL
14		W0003	1687	20		33-18-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00895		**P001-03/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W0003	1070Z			21-33-11	ALL
	S/R		W0003	1072Z			31-53-11	ALL
	S/R		W0003	1517Z			27-62-11	ALL
	S/R		W0003	1518Z			27-62-11	ALL
	S/R		W0003	1685Z			33-18-21	ALL
	S/R		W0003	1686Z			33-18-21	ALL
	S/R		W0003	1687Z			33-18-21	ALL
	S/R		W0003	1690Z			33-18-21	ALL
	S/R		W0003	1691Z			33-18-21	ALL
	S/R		W0003	1707Z			22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00918	**209/256/000**		**PLUG-COMPASS STANDBY INDICATOR**				**ALL**
=A1		W2508	1001	20		33-14-12	ALL
=C1		W2508	1001Z			33-14-12	ALL
D00920	**666/182/L041**		**PLUG-CONDUCTIVE**				**ALL**
1		W7026	0501	18		49-62-11	ALL
2		W7026	0502	18		49-62-11	ALL
3		W7026	0503	18		49-62-11	ALL
4		W7026	0504	18		49-62-11	ALL
5		W7026	0505	18		49-62-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
D00928	**725/191/R003**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0512	16		32-44-11	ALL
2		W7128	1008	16		32-44-11	ALL
3		W7128	1007	16		32-44-11	ALL
4		W7128	3003Y	16		32-44-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W7128	3003R	16		32-44-11	ALL
9		W7128	0515	16		32-44-11	ALL
10		W7128	3003B	16		32-44-11	ALL
S/R		W7128	1007Z			32-44-11	ALL
S/R		W7128	1008Z			32-44-11	ALL
S/R		W7128	3003Z			32-44-11	ALL
D00940	**202/210/R006**		**PLUG-AURAL WARNING BOX**				**ALL**
1	UNUSED						ALL
2		W5514	0556	22		32-64-21	ALL
3		W5514	5551	22		21-33-11	ALL
4		W5514	1001	22		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D00940		**202/210/R006**		**PLUG-AURAL WARNING BOX (continued)**				**ALL**
	5		W5514	5502	22		31-51-11	ALL
	6		W5514	5501	20		31-51-11	ALL
	7		W5514	5557	22		23-42-11	ALL
	8		W5514	5558	22		23-22-11	ALL
	9	UNUSED						ALL
	10		W5514	5554	22		34-16-21	ALL
	11		W5514	5553	22		34-16-21	ALL
	12		W5514	6003R	22		26-11-21	ALL
	13		W5514	6002R	22		26-11-21	ALL
	14	UNUSED						ALL
	15		W5514	5574	20		31-51-11	ALL
	DED		W5514	1001Z			22-14-11	ALL
D00944		**P006-00/ /**		**PLUG**				**ALL**
	A1		W0044	0297	18		28-44-11	ALL
	A2		W0044	0298	18		28-44-11	ALL
	A3	UNUSED						ALL
	B1		W0044	0410	22		28-41-11	ALL
	B2		W0044	0412	22		28-41-11	ALL
	B3		W0044	0409	22		28-41-11	ALL
	C1		W0044	0018	24		24-31-11	ALL
	C2		W0044	0022	24		24-31-11	ALL
	C3	UNUSED						ALL
	D1		W0044	0411	22		28-41-11	ALL
	D2		W0044	0299	20		28-44-11	ALL
	D3	UNUSED						ALL
	X1		W0044	0047	22		24-41-11	ALL
	X2		W0044	0282	22		28-44-11	ALL
D00998		**E002-02/ /**		**RECP-FIRE DET MOD TOP**				**ALL**
	1		W0220	0409R	22		26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D00998	**E002-02/ /**		**RECP-FIRE DET MOD TOP (continued)**				**ALL**
2		W0220	0354R	20		26-11-21	ALL
3		W0220	0366R	22		26-11-21	ALL
4		W0220	0353R	22		26-11-21	ALL
5		W0220	0361R	22		26-11-21	ALL
6		W0220	0359R	22		26-11-21	ALL
7		W0220	0362R	22		26-11-21	ALL
8		W0220	0360R	22		26-11-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0220	0364R	22		26-11-21	ALL
12		W0220	0402R	20		26-11-21	ALL
13		W0220	0351R	22		26-11-21	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0220	0401R	20		26-11-21	ALL
18		W0220	0403R	20		26-11-21	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W0220	0406R	22		26-11-21	ALL
22		W0220	0352R	20		26-11-21	ALL
23		W0220	0404R	20		26-11-21	ALL
24	UNUSED						ALL
25		W0220	0405R	20		26-11-21	ALL
26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01000		**E002-02/ /**		**RECP-FIRE DET MOD MIDDLE**				**ALL**
	1		W0220	0368R	20		26-11-31	ALL
	2		W0220	0383R	20		26-11-31	ALL
	3		W0220	0384R	20		26-11-31	ALL
	4		W0220	0369R	22		26-11-31	ALL
	5	UNUSED						ALL
	6		W0220	0233	22		49-62-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0220	0382R	20		26-11-31	ALL
	10	UNUSED						ALL
	11		W0220	0370R	22		26-11-31	ALL
	12	UNUSED						ALL
	13		W0220	0378R	20		26-11-31	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0220	2050R	24		31-31-13	ALL
	17		W0220	0379R	20		26-11-31	ALL
	18		W0220	0357R	22		26-11-21	ALL
	19	UNUSED						ALL
	20		W0220	0387R	20		26-11-31	ALL
	21		W0220	0380R	20		26-11-31	ALL
	22		W0220	0385R	20		26-11-31	ALL
	23		W0220	2050B	24		31-31-13	ALL
	24	UNUSED						ALL
	25		W0220	0386R	20		26-11-31	ALL
	26	UNUSED						ALL
			W0220	0415	20		31-31-13	ALL
			W0220	2050Z			31-31-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01002	**E002-02/ /**		**RECP-FIRE DET MOD BOTTOM**				**ALL**
1		W0220	0342R	22		26-11-11	ALL
2		W0220	0333R	20		26-11-11	ALL
3		W0220	0343R	22		26-11-11	ALL
4	UNUSED						ALL
5		W0220	0336R	22		26-11-11	ALL
6		W0220	0338R	22		26-11-11	ALL
7		W0220	0335R	22		26-11-11	ALL
8		W0220	0337R	22		26-11-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0220	0339R	22		26-11-11	ALL
12		W0220	0348R	20		26-11-11	ALL
13		W0220	0375R	20		26-11-31	ALL
14	UNUSED						ALL
15		W0220	0334R	22		26-11-11	ALL
16	UNUSED						ALL
17		W0220	0332R	22		26-11-11	ALL
18		W0220	0347R	20		26-11-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W0220	0356R	22		26-11-21	ALL
22		W0220	0344R	20		26-11-11	ALL
23		W0220	0346R	20		26-11-11	ALL
24	UNUSED						ALL
25		W0220	0345R	20		26-11-11	ALL
26	UNUSED						ALL
D01008	**NSTA 202/120/L32**		**PLUG-CONDUCTIVE**				**ALL**
1		W1080	3002R	18		78-32-61	ALL
2		W1080	3002B	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01008	**NSTA 202/120/L32**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3		W1080	3002Y	18		78-32-61	ALL
PERB		W1080	3002Z			78-32-61	ALL
D01010	**723/167/L007**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0407	18		27-53-11	ALL
2		W7128	0404	18		27-53-11	ALL
3		W7128	0403	18		27-53-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D01012	**719/173/L006**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0301	16		27-53-12	ALL
2		W7128	0302	16		27-53-12	ALL
3		W7128	0303	16		27-53-12	ALL
4		W7128	0304	16		27-53-12	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D01014	**723/200/R020**		**PLUG- CONDUCTIVE**				**ALL**
1		W8124	0501	20		27-53-11	ALL
2		W8124	0502	20		27-53-11	ALL
3		W8124	0503	20		27-53-11	ALL
4	UNUSED						ALL
5		W8124	0504	18		27-53-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
D01016	**NSTA 203/68/R015**		**PLUG-CONDUCTIVE**				**ALL**
1		W1084	3003R	18		78-32-61	ALL
2		W1084	3003B	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01016	**NSTA 203/68/R015**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3		W1084	3003Y	18		78-32-61	ALL
PERB		W1084	3003Z			78-32-61	ALL
D01036	**P001-05/ /**		**PLUG-**				**ALL**
1		W0001	0225	20		33-11-11	ALL
2		W0001	0226	20		33-11-11	ALL
3		W0001	0265	20		33-14-11	ALL
4		W0001	0267	20		33-14-11	ALL
5		W0001	0268	20		33-14-11	ALL
6		W0001	0263	20		33-14-11	ALL
7		W0001	0276	20		33-14-11	ALL
8		W0001	0275	20		33-14-11	ALL
9		W0001	0274	20		33-14-11	ALL
10		W0001	0261	20		33-14-11	ALL
11		W0001	0273	20		33-14-11	ALL
12		W0001	0266	20		33-14-11	ALL
D01038	**P003-04/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1		W0003	0675	20		33-11-21	ALL
2		W0003	0676	20		33-11-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0003	3511R	24		31-65-21	ALL
6		W0003	3511B	24		31-65-21	ALL
7		W0003	3511Y	24		31-65-21	ALL
8		W0003	3512R	24		31-65-21	ALL
9		W0003	3513R	24		31-65-21	ALL
10		W0003	3513B	24		31-65-21	ALL
11		W0003	3513Y	24		31-65-21	ALL
12		W0003	3514R	24		31-65-21	ALL
13		W0003	3514B	24		31-65-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01038		**P003-04/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	14		W0003	3514Y	24		31-65-21	ALL
	15		W0003	0661	16		33-11-21	ALL
	16		W0003	3502Y	24		31-65-23	ALL
	17		W0003	3502B	24		31-65-23	ALL
	18		W0003	3502R	24		31-65-23	ALL
	19		W0003	0664	16		33-11-21	ALL
	20		W0003	1546	22		31-65-23	ALL
	21		W0003	3512B	24		31-65-21	ALL
	22		W0003	3512Y	24		31-65-21	ALL
	23		W0003	0674	14		33-11-21	ALL
	24		W0001	3002Y	24		31-65-13	ALL
	25		W0001	3002B	24		31-65-13	ALL
	26		W0001	3002R	24		31-65-13	ALL
	27	UNUSED						ALL
	28		W0001	1546	22		31-65-13	ALL
	S/R		W0001	1546Z			31-65-13	ALL
	S/R		W0001	3002Z			31-65-13	ALL
	S/R		W0003	1546Z			31-65-23	ALL
	S/R		W0003	3502Z			31-65-23	ALL
	S/R		W0003	3511Z			31-65-21	ALL
	S/R		W0003	3512Z			31-65-21	ALL
	S/R		W0003	3513Z			31-65-21	ALL
	S/R		W0003	3514Z			31-65-21	ALL
D01040A		***/*/***		**PLUG - ANTI-SKID**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0131	0070	24		32-42-11	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01040A		*/*/*		**PLUG - ANTI-SKID (continued)**				**ALL**
	A06	UNUSED						ALL
	A07		W0131	0085	24		32-42-11	ALL
	A08		W0137	0116	24		32-42-11	ALL
	A09		W0131	0046	22		27-62-11	ALL
	A10		W0131	2020R	24		32-42-11	ALL
	A11		W0137	0045	22		27-62-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0131	0067	22		32-41-11	ALL
	B01		W0131	0112	24		32-41-11	ALL
	B02	UNUSED						ALL
	B03		W0131	0109	24		32-41-11	ALL
	B04	VP	W0131	2573R	24		31-65-15	ALL
	B05		W0131	2510R	24		32-41-11	ALL
	B06		W0131	2510B	24		32-41-11	ALL
	B07		W0131	2062B	22		27-62-11	ALL
	B08		W0131	0121	24		32-42-11	ALL
	B09	UNUSED						ALL
	B10		W0131	2020B	24		32-42-11	ALL
	B11	UNUSED						ALL
	B12		W0131	2511R	24		32-41-11	ALL
	B13		W0131	2511B	24		32-41-11	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01		W0131	0094	24		32-41-11	ALL
	C02		W0131	0001	22		32-42-11	ALL
	C03	UNUSED						ALL
	C04	VP	W0131	2573B	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01040A		***/*/***		**PLUG - ANTI-SKID (continued)**				**ALL**
	C05	UNUSED						ALL
	C06		W0131	0106	22		32-41-11	ALL
	C07		W0131	2021B	24		32-42-11	ALL
	C08		W0137	0115	24		32-42-11	ALL
	C09		W0131	2514R	24		32-42-11	ALL
	C10	UNUSED						ALL
	C11		W0131	0066	22		32-41-11	ALL
	C12	UNUSED						ALL
	C13		W0131	0003	22		32-41-11	ALL
	C14	VP	W0131	2575R	24		32-42-12	ALL
	C15	VP	W0131	2575B	24		32-42-12	ALL
	D01		W0131	0064	22		32-41-11	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0131	0065	22		32-41-11	ALL
	D06	UNUSED						ALL
	D07		W0131	0081	24		32-42-11	ALL
	D08	UNUSED						ALL
	D09		W0131	2514B	24		32-42-11	ALL
	D10		W0137	0047	22		27-62-11	ALL
	D11		W0131	2508R	24		34-21-13	ALL
	D12		W0131	2508B	24		34-21-13	ALL
	D13		W0131	0044	22		27-62-11	ALL
	D14	UNUSED						ALL
	D15		W0137	0091	24		32-44-11	ALL
	DED		W0131	2573Z			31-65-15	ALL
	DED		W0131	2575Z			32-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01040B	*/*/*		**PLUG - ANTI-SKID**				**ALL**
A01		W0131	0111	24		32-41-11	ALL
A02		W0131	0086	22		32-42-11	ALL
A03		W0131	0110	24		32-41-11	ALL
A04		W0131	0089	24		32-42-11	ALL
A05		W0131	2513R	24		32-41-11	ALL
A06		W0131	2513B	24		32-41-11	ALL
A07		W0131	0090	24		32-42-11	ALL
A08		W0131	0118	24		32-42-11	ALL
A09		W0131	2019B	24		32-42-11	ALL
A10		W0131	2021R	24		32-42-11	ALL
A11		W0131	0069	24		32-42-11	ALL
A12		W0131	2512R	24		32-41-11	ALL
A13		W0131	2512B	24		32-41-11	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	VP	W0137	2574R	24		31-65-25	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0131	0114	24		32-42-11	ALL
B08		W0131	2019R	24		32-42-11	ALL
B09		W0131	0087	22		32-42-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01040B		***/*/***		**PLUG - ANTI-SKID (continued)**				**ALL**
	B15		W0131	0068	22		32-41-11	ALL
	C01		W0137	0060	24		32-41-11	ALL
	C02		W0131	0107	22		32-41-11	ALL
	C03		W0131	0083	24		32-42-11	ALL
	C04	VP	W0137	2574B	24		31-65-25	ALL
	C05		W0137	0062	22		32-41-11	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08		W0131	0117	24		32-42-11	ALL
	C09		W0131	0071	24		32-42-11	ALL
	C10		W0131	0080	24		32-42-11	ALL
	C11		W0131	2062R	22		27-62-11	ALL
	C12	UNUSED						ALL
	C13		W0131	0108	22		32-41-11	ALL
	C14		W0131	0082	22		32-42-11	ALL
	C15		W0131	0002	22		32-42-11	ALL
	D01		W0131	0063	22		32-41-11	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0131	0074	24		32-42-11	ALL
	D05	UNUSED						ALL
	D06		W0131	0084	24		32-42-11	ALL
	D07		W0131	0075	24		32-42-11	ALL
	D08		W0131	0076	24		32-42-11	ALL
	D09		W0131	0078	24		32-42-11	ALL
	D10		W0131	0079	24		32-42-11	ALL
	D11	UNUSED						ALL
	D12		W0131	0077	24		32-42-11	ALL
	D13		W0131	2509R	24		34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01040B	***/*/***		**PLUG - ANTI-SKID (continued)**				**ALL**
D14		W0131	2509B	24		34-21-23	ALL
D15	UNUSED						ALL
DED		W0137	2574Z			31-65-25	ALL
D01040C	***/*/***		**PLUG - ANTI-SKID**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
=C1	UNUSED						ALL
=C5	UNUSED						ALL
D01070	**727/201/L009**		**PLUG-**				**ALL**
=1		W6248	0302R	20		26-12-11	ALL
D01078	**P008-01/ /**		**PLUG**				**ALL**
1		W5506	5505	20		33-11-33	ALL
2		W5506	5504	20		33-11-33	ALL
3		W5506	6060R	22		26-21-11	ALL
4		W5506	6071R	22		26-21-11	ALL
5		W5506	6050R	22		26-11-21	ALL
6		W5506	5507	20		33-18-63	ALL
7		W5506	6003R	20		26-11-31	ALL
8		W5506	6021R	22		26-11-11	ALL
9		W5506	6075R	22		26-21-11	ALL
10		W5506	6024R	22		26-11-11	ALL
11		W5506	6025R	22		26-11-11	ALL
12		W5506	5510	20		31-52-45	ALL
13		W5506	6018R	22		26-11-11	ALL
14		W5506	6005R	20		26-11-31	ALL
15		W5506	6001R	22		26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01078		**P008-01/ /**		**PLUG (continued)**				**ALL**
	16		W5506	6020R	22		26-11-11	ALL
	17		W5506	5508	20		33-18-63	ALL
	18		W5506	6053R	22		26-11-21	ALL
	19		W5506	6019R	22		26-11-11	ALL
	20		W5506	6014R	22		26-12-11	ALL
	21		W5506	6051R	22		26-11-21	ALL
	22		W5506	6070R	22		26-21-11	ALL
	23		W5506	6073R	22		26-21-11	ALL
	24		W5506	6023R	22		26-11-11	ALL
	25		W5506	6022R	22		26-11-11	ALL
	26		W5506	6074R	22		26-21-11	ALL
	27		W5506	6004R	20		26-11-31	ALL
	28		W5506	6002R	20		26-11-31	ALL
	29		W5506	6052R	22		26-11-21	ALL
	30		W5506	6072R	22		26-21-11	ALL
	31		W5506	6017R	22		26-11-11	ALL
D01080		**P008-01/ /**		**PLUG**				**ALL**
	1		W6506	6067R	22		26-21-11	ALL
	2		W6506	6053R	22		26-21-11	ALL
	3		W6506	6068R	22		26-21-11	ALL
	4		W6506	5504	20		33-18-63	ALL
	5	UNUSED						ALL
	6		W6506	5506	20		33-18-63	ALL
	7		W6506	5509	20		31-52-45	ALL
	8		W6506	6043R	22		26-21-11	ALL
	9		W6506	6045R	22		26-21-11	ALL
	10		W6506	5505	20		33-18-63	ALL
	11		W6506	6054R	22		26-21-11	ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01080		**P008-01/ /**		**PLUG (continued)**				**ALL**
	13		W6506	6042R	22		26-21-11	ALL
	14	UNUSED						ALL
	15		W6506	6082R	22		26-21-11	ALL
	16		W6506	6001R	20		26-11-31	ALL
	17		W6506	6034R	22		26-11-21	ALL
	18		W6506	6038R	22		26-11-21	ALL
	19		W6506	6037R	22		26-11-21	ALL
	20		W6506	6039R	22		26-11-21	ALL
	21		W6506	6040R	22		26-11-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W6506	6036R	22		26-11-21	ALL
	25		W6506	6044R	22		26-21-11	ALL
	26	UNUSED						ALL
	27		W6506	6055R	22		26-21-11	ALL
	28		W6506	6035R	22		26-11-21	ALL
	29	UNUSED						ALL
	30		W6506	6066R	22		26-21-11	ALL
	31		W6506	6033R	22		26-11-21	ALL
D01084		**199/205/L006**		**PLUG-SPEED BRAKE HANDLE ACTR**				**ALL**
	1		W6208	0555	20		27-62-11	ALL
	2	UNUSED						ALL
	3		W6208	0592	20		27-62-11	ALL
	4	UNUSED						ALL
	5		W6208	0558	20		27-62-11	ALL
	6		W6208	0557	20		27-62-11	ALL
	7		W6208	0591	20		27-62-11	ALL
D01086		**P005-05/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01086		**P005-05/ /**		**PLUG- (continued)**				**ALL**
	2		W2510	0502	24		24-31-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2508	0515	24		24-34-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2510	0501	24		24-31-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W2508	5545	20		33-18-33	ALL
	19		W2508	5544	20		33-18-33	ALL
	20		W2112	0501	22		24-11-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	18	W2508	0523	18		24-11-11	ALL
	24	UNUSED						ALL
	25		W2508	0516	24		24-34-11	ALL
	26		W2508	0517	20		24-34-11	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01086		**P005-05/ /**		**PLUG- (continued)**				**ALL**
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W2508	0519	24		24-34-11	ALL
	36	UNUSED						ALL
	37		W2112	0502	20		24-11-11	ALL
	38		W2508	5737	20		31-52-32	ALL
	39		W2508	5738	20		31-52-32	ALL
	40	UNUSED						ALL
	41	18	W2508	0524	18		24-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01128		**AB0288/ /**		**RCPT-**				**ALL**
	1		W6242	0026	22		33-26-21	ALL
	2		W6242	0053	22		33-26-21	ALL
	3		W6242	0054	22		33-26-21	ALL
	4	UNUSED						ALL
	5		W6242	0056	22		33-26-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D01153A		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0111	2206W	24		34-49-11	ALL
	A04	UNUSED						ALL
	A05		W0111	2207R	24		34-21-23	ALL
	A06		W0111	2207B	24		34-21-23	ALL
	A07	UNUSED						ALL
	A08		W0111	2003R	24		34-33-21	ALL
	A09		W0111	2131R	24		31-65-25	ALL
	A10		W0111	0506	24		34-49-11	ALL
	A11		W0111	0938	24		34-49-11	ALL
	A12		W0111	0534	24		34-49-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0111	2206B	24		34-49-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0111	2288R	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01153A		*/*/*		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W0111	2003B	24		34-33-21	ALL
	B09		W0111	2131B	24		31-65-25	ALL
	B10		W0111	0937	24		34-49-11	ALL
	B11	UNUSED						ALL
	B12		W0111	0880	24		34-49-11	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01		W0111	2208R	24		34-21-24	ALL
	C02	UNUSED						ALL
	C03		W0111	2204W	24		34-49-11	ALL
	C04	UNUSED						ALL
	C05		W0111	2125R	24		34-31-21	ALL
	C06		W0111	2288B	24		34-49-11	ALL
	C07	UNUSED						ALL
	C08		W0111	2205R	24		34-49-11	ALL
	C09		W0111	2062R	24		27-32-22	ALL
	C10		W0111	0507	24		34-49-11	ALL
	C11		W0111	2210R	24		34-58-21	ALL
	C12		W0111	0514	24		34-49-11	ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0111	2208B	24		34-21-24	ALL
	D02	UNUSED						ALL
	D03		W0111	2204B	24		34-49-11	ALL
	D04		W0111	0535	24		34-49-11	ALL
	D05		W0111	2125B	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01153A		***/*/***		**PLUG (continued)**				**ALL**
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08		W0111	2205B	24		34-49-11	ALL
	D09		W0111	2062B	24		27-32-22	ALL
	D10	UNUSED						ALL
	D11		W0111	2210B	24		34-58-21	ALL
	D12		W0111	0281	24		34-49-11	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	CAP	Y	W0111	0881	24		34-49-11	ALL
	CAP	Y	W0111	0882	24		34-49-11	ALL
	PERG	1A	W0111	2003Z			34-33-21	ALL
	PERG	1A	W0111	2062Z			27-32-22	ALL
	PERG	1A	W0111	2125Z			34-31-21	ALL
	PERG	1A	W0111	2131Z			31-65-25	ALL
	PERG	1A	W0111	2204Z			34-49-11	ALL
	PERG	1A	W0111	2205Z			34-49-11	ALL
	PERG	1A	W0111	2206Z			34-49-11	ALL
	PERG	1A	W0111	2207Z			34-21-23	ALL
	PERG	1A	W0111	2208Z			34-21-24	ALL
	PERG	1A	W0111	2210Z			34-58-21	ALL
	PERG	1A	W0111	2288Z			34-49-11	ALL
D01153B		***/*/***		**PLUG**				**ALL**
	A01		W0111	0288	24		34-49-11	ALL
	A02		W0111	0942	24		34-49-11	ALL
	A03		W0111	0940	24		34-49-11	ALL
	A04		W0111	4002Y	24		46-13-11	ALL
	A05		W0111	4002B	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01153B	*/*/*		**PLUG (continued)**				**ALL**
A06		W0111	2095R	24		34-21-13	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0111	0282	24		34-49-11	ALL
A10		W0111	2129R	24		31-65-15	ALL
A11		W0111	2104R	24		34-21-14	ALL
A12		W0111	2022R	24		22-11-51	ALL
A13		W0111	2064R	24		34-33-11	ALL
A14	UNUSED						ALL
A15		W0111	2290R	22		31-32-15	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W0111	4002R	24		46-13-11	ALL
B05		W0111	4002G	24		46-13-11	ALL
B06		W0111	2095B	24		34-21-13	ALL
B07		W0111	0532	24		34-49-11	ALL
B08	UNUSED						ALL
B09		W0111	0283	24		34-49-11	ALL
B10		W0111	2129B	24		31-65-15	ALL
B11		W0111	2104B	24		34-21-14	ALL
B12		W0111	2022B	24		22-11-51	ALL
B13		W0111	2064B	24		34-33-11	ALL
B14		W0111	0471	24		34-49-11	ALL
B15		W0111	2290B	22		31-32-15	ALL
C01		W0111	2077R	24		34-49-11	ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04		W0111	0945	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01153B		***/*/***		**PLUG (continued)**				**ALL**
	C05	UNUSED						ALL
	C06		W0111	2209R	24		34-58-11	ALL
	C07		W0111	0280	24		34-49-11	ALL
	C08		W0111	0939	24		34-49-11	ALL
	C09		W0111	0268	24		34-49-11	ALL
	C10		W0111	2121R	22		34-61-15	ALL
	C11		W0111	2123R	24		34-31-11	ALL
	C12		W0111	2053R	24		27-32-12	ALL
	C13		W0111	2074R	24		34-49-11	ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0111	2077B	24		34-49-11	ALL
	D02	UNUSED						ALL
	D03		W0111	0508	24		34-49-11	ALL
	D04		W0111	0941	24		34-49-11	ALL
	D05	UNUSED						ALL
	D06		W0111	2209B	24		34-58-11	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0111	0264	24		34-49-11	ALL
	D10		W0111	2121B	22		34-61-15	ALL
	D11		W0111	2123B	24		34-31-11	ALL
	D12		W0111	2053B	24		27-32-12	ALL
	D13		W0111	2074B	24		34-49-11	ALL
	D14		W0111	0943	24		34-49-11	ALL
	D15		W0111	0511	24		34-49-11	ALL
	PERG	1A	W0111	2022Z			22-11-51	ALL
	PERG	1A	W0111	2053Z			27-32-12	ALL
	PERG	1A	W0111	2064Z			34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01153B		*/*/*		**PLUG (continued)**				**ALL**
	PERG	1A	W0111	2074ZI			34-49-11	ALL
	PERG	1A	W0111	2074ZO			34-49-11	ALL
	PERG	1A	W0111	2077Z			34-49-11	ALL
	PERG	1A	W0111	2095Z			34-21-13	ALL
	PERG	1A	W0111	2104Z			34-21-14	ALL
	PERG	1A	W0111	2121Z			34-61-15	ALL
	PERG	1A	W0111	2123Z			34-31-11	ALL
	PERG	1A	W0111	2129Z			31-65-15	ALL
	PERG	1A	W0111	2209Z			34-58-11	ALL
	PERG	1A	W0111	2290Z			31-32-15	ALL
	PERG	1A	W0111	4002Z			46-13-11	ALL
D01153C		*/*/*		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0111	0263	22		34-49-11	ALL
	3		W0111	0233	22		34-49-11	ALL
	4		W0111	0234	22		34-49-11	ALL
	5	UNUSED						ALL
	=C1	UNUSED						ALL
	=C5	UNUSED						ALL
D01172		**202/210/R005**		**PLUG-AURAL WARNING M/W M315**				**ALL**
	1		W5514	5555	22		34-16-11	ALL
	2		W5514	5556	22		34-16-11	ALL
	3		W5514	0015	22		21-33-11	ALL
	4	UNUSED						ALL
	5		W5514	0014	22		21-33-11	ALL
D01176		**1077/229/L022**		**PLUG-DISCH SW APU**				**ALL**
	1		W4726	1104R	18		26-21-11	ALL
	2		W4726	1103R	20		26-21-11	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01176		**1077/229/L022**		**PLUG-DISCH SW APU (continued)**				**ALL**
	DED		W4726	1104Z			26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01205	**P003-07/ /**		**PLUG-**				**ALL**
1		W0003	0680	20		33-11-21	ALL
2		W0003	0679	20		33-11-21	ALL
3		W0003	0634	22		34-49-11	ALL
4		W0003	0633	24		34-49-11	ALL
5		W0003	0630	24		34-49-11	ALL
6		W0003	0631	22		34-49-11	ALL
7		W0003	0632	24		34-49-11	ALL
8		W0003	0635	24		34-49-11	ALL
9		W0003	0636	22		34-49-11	ALL
10		W0003	0743	24		34-49-11	ALL
11		W0003	0693	20		33-18-22	ALL
12		W0003	0692	20		33-18-22	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
CAP	Y	W0003	0750	24		34-49-11	ALL
CAP	Y	W0003	0751	24		34-49-11	ALL
D01218	**350/292/R025**		**RCPT-**				**ALL**
A		W4256	0101	08		25-31-11	ALL
B		W4256	0102	08		25-31-11	ALL
C		W4256	0103	08		25-31-11	ALL
D		W4256	0104	08		25-31-11	ALL
D01249	**1167/265/L06**		**RECP-CONDUCTIVE**				**ALL**
1		W8030	2231B	20		27-48-11	ALL
2		W8030	2231R	20		27-48-11	ALL
3		W8030	3231Y	20		27-48-11	ALL
4		W8030	3231R	20		27-48-11	ALL
5		W8030	3231B	20		27-48-11	ALL
S/R		W8030	2231Z			27-48-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01249		**1167/265/L06**		**RECP-CONDUCTIVE (continued)**				**ALL**
	S/R		W8030	3231Z			27-48-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01322	**713/190/L057**		**CONNECTOR-L.BOTTLE M00194**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W7596	6010R	20		26-21-11	ALL
4		W7596	6007R	20		26-21-11	ALL
5	UNUSED						ALL
6		W7596	6004R	20		26-21-11	ALL
7		W7596	6009R	20		26-21-11	ALL
D01324	**722/190/L056**		**CONNECTOR-R.BOTTLE M00195**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W7598	6010R	20		26-21-11	ALL
4		W7598	6007R	20		26-21-11	ALL
5	UNUSED						ALL
6		W7598	6004R	20		26-21-11	ALL
7		W7598	6009R	20		26-21-11	ALL
D01344	**J019-00/ /**		**PLUG-DIM MODULE**				**ALL**
1		W5514	5506	20		33-18-51	ALL
2		W5514	5516	20		31-52-11	ALL
3		W5514	6001R	22		26-11-21	ALL
4		W5514	5507	20		33-18-51	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W5514	5562	20		22-11-12	ALL
8		W5514	5503	20		33-18-21	ALL
9	UNUSED						ALL
10		W5514	5517	20		31-52-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01344		**J019-00/ /**		**PLUG-DIM MODULE (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01344	**J019-00/ /**		**PLUG-DIM MODULE (continued)**				**ALL**
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
D01346	**J019-00/ /**		**PLUG-DIM MODULE**				**ALL**
1		W5514	5519	20		31-52-11	ALL
2		W5514	5518	20		31-52-11	ALL
3		W5514	5520	20		31-52-11	ALL
4		W5514	5529	20		31-52-31	ALL
5		W5514	5535	20		31-52-45	ALL
6	UNUSED						ALL
7		W5514	5543	20		31-52-65	ALL
8	UNUSED						ALL
9		W5514	5525	20		31-52-21	ALL
10	UNUSED						ALL
11		W5514	5533	20		31-52-41	ALL
12	UNUSED						ALL
13		W5514	5527	20		31-52-25	ALL
14	UNUSED						ALL
15		W5514	5537	20		31-52-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01346		**J019-00/ /**		**PLUG-DIM MODULE (continued)**				**ALL**
	16	UNUSED						ALL
	17		W5514	5548	20		31-52-75	ALL
	18	UNUSED						ALL
	19		W5514	5539	20		31-52-55	ALL
	20	UNUSED						ALL
	21		W5514	5531	20		31-52-35	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W5514	5541	20		31-52-61	ALL
	25		W5514	5545	20		31-52-71	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01346		**J019-00/ /**		**PLUG-DIM MODULE (continued)**				**ALL**
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01406		**P005-20/ /**		**PLUG-**				**ALL**
	1		W2216	0006	24		52-71-12	ALL
	2		W2216	0004	24		52-71-11	ALL
	3		W2216	0005	24		52-71-11	ALL
	4	UNUSED						ALL
	5		W2216	0003	24		52-71-11	ALL
	6		W2216	0008	24		52-71-12	ALL
	7		W2508	0007	20		52-71-14	ALL
	8		W2216	0012	24		52-71-11	ALL
	9	UNUSED						ALL
	10		W2508	0006	20		52-71-13	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D01409		**178/195/L003**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01409	**178/195/L003**		**PLUG (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	16	W8489	2006R	16		34-41-11	ALL
26	UNUSED						ALL
27	16	W8489	2006B	16		34-41-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01409		**178/195/L003**		**PLUG (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W8489	YAAA			34-41-11	ALL
D01411		**178/195/L005**		**PLUG (STA 178)**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01411	**178/195/L005**		**PLUG (STA 178) (continued)**				**ALL**
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	16	W6491	2001R	16		34-41-11	ALL
26	UNUSED						ALL
27	16	W6491	2001B	16		34-41-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01411		**178/195/L005**		**PLUG (STA 178) (continued)**				**ALL**
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W6491	2001Z			34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01507	**LAV A/ /**		**PLUG - FWD LAV ANNOUNCE SELECTOR PNL**				**ALL**
1		W3307	0003	22		23-31-06	ALL
2	UNUSED						ALL
3		W3307	0006	22		23-31-06	ALL
4	UNUSED						ALL
5		W3307	0016	20		23-31-06	ALL
6		W3307	2002R	24		23-31-06	ALL
7		W3307	2002B	24		23-31-06	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W3307	0002	22		23-31-06	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W3307	2001B	24		23-31-06	ALL
18		W3307	2001R	24		23-31-06	ALL
19	UNUSED						ALL
20		W3307	0012	22		23-31-06	ALL
21		W3307	0014	20		23-31-06	ALL
22	UNUSED						ALL
23		W3307	0015	20		23-31-06	ALL
24		W3307	0001	22		23-31-06	ALL
CAP	Y	W3307	0013	22		23-31-06	ALL
CAP	Y	W3307	0027	24		23-31-06	ALL
CAP	Y	W3307	0028	24		23-31-06	ALL
DED		W3307	2001Z			23-31-06	ALL
DED		W3307	2002Z			23-31-06	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01582		**723/199/R047**		**PLUG- CONDUCTIVE**				**ALL**
	1		W8226	0501	18		27-54-11	ALL
	2		W8226	0503	18		27-54-11	ALL
D01598		**P006-00/ /**		**RCPT-MASTER DIM**				**ALL**
	1	UNUSED						ALL
	2		W0044	0054	20		31-52-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0044	0108	20		33-18-11	ALL
	6		W0044	0055	20		31-52-11	ALL
	7		W0044	0107	20		33-18-11	ALL
	8		W0044	0053	20		31-52-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0044	0179	20		33-18-36	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0044	0180	20		33-18-36	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0044	0181	20		33-18-36	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0044	0140	20		33-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01598	**P006-00/ /**		**RCPT-MASTER DIM (continued)**				**ALL**
27		W0044	0106	20		33-18-11	ALL
28		W0044	0139	20		33-18-11	ALL
29		W0044	0105	20		33-18-11	ALL
30		W0044	0142	20		33-18-11	ALL
31	UNUSED						ALL
32		W0044	0141	20		33-18-11	ALL
33	UNUSED						ALL
34		W0044	0138	20		33-18-11	ALL
35	UNUSED						ALL
36		W0044	0137	20		33-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01614		**P006-00/ /**		**SOCKET-MASTER TEST RELAY**				**ALL**
	A1		W0044	0170	20		33-18-31	ALL
	A2		W0044	0111	20		33-18-11	ALL
	A3	UNUSED						ALL
	B1		W0044	0156	20		33-18-21	ALL
	B2		W0044	0114	20		33-18-11	ALL
	B3	UNUSED						ALL
	C1		W0044	0154	20		33-18-21	ALL
	C2		W0044	0113	20		33-18-11	ALL
	C3	UNUSED						ALL
	D1		W0044	0182	20		33-18-36	ALL
	D2		W0044	0112	20		33-18-11	ALL
	D3	UNUSED						ALL
	G1	UNUSED						ALL
	G2		W0044	PA01			33-18-11	ALL
	G3		W0044	PA01			33-18-11	ALL
	X1		W0044	0115	20		33-18-11	ALL
	X2		W0044	0116	20		33-18-11	ALL
D01616		**P006-00/ /**		**SOCKET-MASTER DIM RELAY**				**ALL**
	A1	UNUSED						ALL
	A2		W0044	0151	20		33-18-11	ALL
	A3		W0044	0150	20		33-18-11	ALL
	B1		W0044	0109	20		33-18-11	ALL
	B2		W0044	0149	20		33-18-11	ALL
	B3		W0044	0148	20		33-18-11	ALL
	C1	UNUSED						ALL
	C2		W0044	0147	20		33-18-11	ALL
	C3		W0044	0146	20		33-18-11	ALL
	D1	UNUSED						ALL
	D2		W0044	0120	20		33-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01616		**P006-00/ /**		**SOCKET-MASTER DIM RELAY (continued)**				**ALL**
	D3		W0044	0121	20		33-18-11	ALL
	G1	UNUSED						ALL
	G2		W0044	PA03			33-18-11	ALL
	G3		W0044	PA03			33-18-11	ALL
	X1		W0044	0118	20		33-18-11	ALL
	X2		W0044	0119	20		33-18-11	ALL
D01618		**P006-00/ /**		**SOCKET-AUX MASTER DIM RELAY**				**ALL**
	A1	UNUSED						ALL
	A2		W0044	0158	20		33-18-21	ALL
	A3		W0044	0159	20		33-18-21	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2		W0044	0127	20		33-18-11	ALL
	C3		W0044	0056	20		31-52-11	ALL
	D1	UNUSED						ALL
	D2		W0044	0124	20		33-18-11	ALL
	D3		W0044	0189	20		33-18-51	ALL
	G1	UNUSED						ALL
	G2		W0044	PA04			33-18-11	ALL
	G3		W0044	PA04			33-18-11	ALL
	X1		W0044	0125	20		33-18-11	ALL
	X2		W0044	0126	20		33-18-11	ALL
D01620		**P006-00/ /**		**SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1		W0044	0333	24		33-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01620		**P006-00/ /**		**SOCKET (continued)**				**ALL**
	B2		W0044	0300	24		33-25-11	ALL
	B3	UNUSED						ALL
	C1		W0044	0318	20		33-25-11	ALL
	C2		W0044	0302	20		33-25-11	ALL
	C3	UNUSED						ALL
	D1		W0044	0319	20		33-25-11	ALL
	D2		W0044	0301	20		33-25-11	ALL
	D3	UNUSED						ALL
	X1		W0044	0303	24		33-25-11	ALL
	X2		W0044	0312	24		33-25-11	ALL
D01622		**P006-00/ /**		**SOCKET**				**ALL**
	A1		W0044	0320	20		33-25-11	ALL
	A2		W0044	0308	20		33-25-11	ALL
	A3	UNUSED						ALL
	B1		W0044	0315	24		33-25-11	ALL
	B2		W0044	0307	24		33-25-11	ALL
	B3	UNUSED						ALL
	C1		W0044	0317	20		33-25-11	ALL
	C2		W0044	0309	20		33-25-11	ALL
	C3	UNUSED						ALL
	D1		W0044	0316	20		33-25-11	ALL
	D2		W0044	0310	20		33-25-11	ALL
	D3	UNUSED						ALL
	X1		W0044	0306	24		33-25-11	ALL
	X2		W0044	0314	24		33-25-11	ALL
D01637		**P018-02/ /**		**PLUG-SYSTEM TEST PLUG**				**ALL**
	1		W2419	0002	22		31-31-11	ALL
	2		W2419	0001	22		31-31-11	ALL
	3		W2419	FRAA			31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01637	**P018-02/ /**		**PLUG-SYSTEM TEST PLUG (continued)**				**ALL**
4		W2419	2002R	24		31-31-11	ALL
5		W2419	2002B	24		31-31-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W2419	2001R	24		31-31-11	ALL
9		W2419	2001B	24		31-31-11	ALL
10		W2419	0004	22		31-31-11	ALL
11		W2419	0003	22		31-31-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
		W2419	2001Z			31-31-11	ALL
		W2419	2002Z			31-31-11	ALL
		W2419	FRAA			31-31-11	ALL
D01640	**P006-00/ /**		**SOCKET-EXT PWR SENSING RLY**				**ALL**
A1	UNUSED						ALL
A2	UNUSED						ALL
A3	UNUSED						ALL
B1		W0044	0325	24		33-29-11	ALL
B2		W0044	0326	24		33-29-11	ALL
B3	UNUSED						ALL
C1		W0044	0324	24		33-29-11	ALL
C2		W0044	0323	24		33-29-11	ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0044	0563	24		33-29-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01640		**P006-00/ /**		**SOCKET-EXT PWR SENSING RLY (continued)**				**ALL**
	X2		W0044	0564	20		33-29-11	ALL
D01673		**238/202/L014**		**RCPT-**				**ALL**
	1		W5457	2018R	22		22-11-11	ALL
	2		W5457	2020R	22		22-12-41	ALL
	3		W5457	2020B	22		22-12-41	ALL
	4		W5457	2018B	22		22-11-11	ALL
	5		W5457	0025	20		22-11-11	ALL
D01675		**230/199/R017**		**RCPT**				**ALL**
	1		W5457	2007B	22		22-11-11	ALL
	2		W5457	2009R	22		22-12-41	ALL
	3		W5457	2009B	22		22-12-41	ALL
	4		W5457	2007R	22		22-11-11	ALL
	5		W5457	0035	20		22-11-11	ALL
D01677		**1156/271/R005**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3399	2001B	22		22-12-41	ALL
	2		W3399	2001R	22		22-12-41	ALL
	3	UNUSED						ALL
	4		W3399	3002B	22		22-12-41	ALL
	5		W3399	3002R	22		22-12-41	ALL
	S/R		W3399	2001Z			22-12-41	ALL
	S/R		W3399	3002Z			22-12-41	ALL
D01679		**1156/271/R008**		**RCPT**				**ALL**
	1		W3399	2004B	22		22-12-41	ALL
	2		W3399	2004R	22		22-12-41	ALL
	3		W3399	3003Y	22		22-12-41	ALL
	4		W3399	3003R	22		22-12-41	ALL
	5		W3399	3003B	22		22-12-41	ALL
	S/R		W3399	2004Z			22-12-41	ALL
	S/R		W3399	3003Z			22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01681	**1167/271/L010**		**PLUG**				**ALL**
1		W3397	1001	20		22-12-31	ALL
2		W3397	0002	20		22-12-31	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W3397	2007B	22		22-12-31	ALL
6		W3397	0006	22		22-12-31	ALL
7		W3397	0006	22		22-12-31	ALL
8		W3397	2007R	22		22-12-31	ALL
9		W3397	2006B	22		22-12-31	ALL
10		W3397	2006R	22		22-12-31	ALL
11		W3397	3001R	22		22-12-31	ALL
12		W3397	3001B	22		22-12-31	ALL
13		W3397	3001Y	22		22-12-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W3397	1004	20		22-12-31	ALL
22		W3397	0022	20		22-12-31	ALL
23	UNUSED						ALL
24	UNUSED						ALL
D01687	**1164/287/L009**		**PLUG-**				**ALL**
1		W3399	1001	20		22-12-41	ALL
2		W3399	0004	20		22-12-41	ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01687		**1164/287/L009**		**PLUG- (continued)**				**ALL**
	5		W3399	2007B	22		22-12-41	ALL
	6		W3399	0006	22		22-12-41	ALL
	7		W3399	0006	22		22-12-41	ALL
	8		W3399	2007R	22		22-12-41	ALL
	9		W3399	2006B	22		22-12-41	ALL
	10		W3399	2006R	22		22-12-41	ALL
	11		W3399	3001R	22		22-12-41	ALL
	12		W3399	3001B	22		22-12-41	ALL
	13		W3399	3001Y	22		22-12-41	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W3399	1004	20		22-12-41	ALL
	22		W3399	0005	20		22-12-41	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D01691		**671/190/L053**		**PLUG**				**ALL**
	1		W5375	2007B	20		22-11-31	ALL
	2		W5375	0002	20		22-11-31	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5375	2006R	22		22-11-31	ALL
	6		W5375	0006	22		22-11-31	ALL
	7		W5375	0006	22		22-11-31	ALL
	8		W5375	2006B	22		22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01691	**671/190/L053**		**PLUG (continued)**				**ALL**
9		W5375	2005R	22		22-11-31	ALL
10		W5375	2005B	22		22-11-31	ALL
11		W5375	3004R	22		22-11-31	ALL
12		W5375	3004B	22		22-11-31	ALL
13		W5375	3004Y	22		22-11-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W5375	2007R	20		22-11-31	ALL
22		W5375	0022	20		22-11-31	ALL
23	UNUSED						ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01707		**667/197/L024**		**RCPT**				**ALL**
	1		W5375	2004B	22		22-11-31	ALL
	2		W5375	2004R	22		22-11-31	ALL
	3		W5375	3003Y	22		22-11-31	ALL
	4		W5375	3003R	22		22-11-31	ALL
	5		W5375	3003B	22		22-11-31	ALL
D01709		**667/196/L024**		**RCPT**				**ALL**
	1		W5367	2001B	22		22-11-31	ALL
	2		W5367	2001R	22		22-11-31	ALL
	3		W5367	3001Y	22		22-11-31	ALL
	4		W5367	3001R	22		22-11-31	ALL
	5		W5367	3001B	22		22-11-31	ALL
D01711		**1157/265/R006**		**RCPT**				**ALL**
	1		W3397	2004B	22		22-12-31	ALL
	2		W3397	2004R	22		22-12-31	ALL
	3		W3397	3003Y	22		22-12-31	ALL
	4		W3397	3003R	22		22-12-31	ALL
	5		W3397	3003B	22		22-12-31	ALL
	S/R		W3397	2004Z			22-12-31	ALL
	S/R		W3397	3003Z			22-12-31	ALL
D01713		**225/198/L015**		**RCPT-**				**ALL**
	1		W5457	2014B	22		22-11-11	ALL
	2		W5457	2016R	22		22-11-31	ALL
	3		W5457	2016B	22		22-11-31	ALL
	4		W5457	2014R	22		22-11-11	ALL
	5		W5457	0015	20		22-11-11	ALL
			W5457	0002	22		22-11-31	ALL
			W5457	2016Z			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01805	**J00024/ /**		**SOCKET-**				**ALL**
A1	UNUSED						ALL
A2		W0080	6505	22		31-31-11	ALL
A3		W0080	6504	22		31-31-11	ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
X1		W0080	6506	22		31-31-11	ALL
X2		W0080	6507	22		31-31-11	ALL
D01815	**P0007/ /**		**PLUG**				**ALL**
1		W2465	1001	20		22-11-11	ALL
2	UNUSED						ALL
3		W2465	1003	20		22-11-12	ALL
4		W2465	1004	20		22-11-31	ALL
5		W2465	1005	20		22-11-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2465	1020	22		22-14-11	ALL
16		W2465	1016	20		22-12-41	ALL
17		W2465	2018B	22		22-11-51	ALL
18		W2465	2018R	22		22-11-51	ALL
19	UNUSED						ALL
20		W2465	0007	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01815		**P0007/ /**		**PLUG (continued)**				**ALL**
	21		W2465	0007	20		22-11-11	ALL
	22		W2465	1022	22		22-14-11	ALL
	23		W2465	1023	22		22-11-11	ALL
	24	UNUSED						ALL
	25		W2465	1025	22		22-14-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2465	2052B	22		22-11-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W2465	2033B	22		22-11-51	ALL
	33		W2465	2033R	22		22-11-51	ALL
	34		W2465	1034	22		22-11-11	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W2465	1037	22		22-11-11	ALL
	38	UNUSED						ALL
	39		W2465	1039	20		22-11-12	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43		W2465	1043	22		22-11-11	ALL
	44	UNUSED						ALL
	45		W2465	1045	22		22-11-11	ALL
	46	UNUSED						ALL
	47		W2465	1047	20		22-11-11	ALL
	48	UNUSED						ALL
	49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01815	**P0007/ /**		**PLUG (continued)**				**ALL**
50	UNUSED						ALL
51	UNUSED						ALL
52		W2465	2052R	22		22-11-11	ALL
53		W2465	1002	22		22-11-75	ALL
54		W2465	1054	20		22-11-12	ALL
55		W2465	1055	20		22-11-11	ALL
S/R		W2465	1001Z			22-11-11	ALL
S/R		W2465	1002Z			22-11-75	ALL
S/R		W2465	1003Z			22-11-12	ALL
S/R		W2465	1004Z			22-11-31	ALL
S/R		W2465	1005Z			22-11-11	ALL
S/R		W2465	1016Z			22-12-41	ALL
S/R		W2465	1020Z			22-14-11	ALL
S/R		W2465	1022Z			22-14-11	ALL
S/R		W2465	1023Z			22-11-11	ALL
S/R		W2465	1025Z			22-14-11	ALL
S/R		W2465	1034Z			22-11-11	ALL
S/R		W2465	1037Z			22-11-11	ALL
S/R		W2465	1039Z			22-11-12	ALL
S/R		W2465	1043Z			22-11-11	ALL
S/R		W2465	1045Z			22-11-11	ALL
S/R		W2465	1047Z			22-11-11	ALL
S/R		W2465	1054Z			22-11-12	ALL
S/R		W2465	1055Z			22-11-11	ALL
S/R		W2465	2018Z			22-11-51	ALL
S/R		W2465	2033Z			22-11-51	ALL
S/R		W2465	2052Z			22-11-11	ALL
D01817	**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01817		**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W2035	0059	22		34-61-12	ALL
	8		W2035	0002	22		34-61-12	ALL
	9		W2035	0003	22		34-61-12	ALL
	10		W2035	0004	22		34-61-12	ALL
	11		W2035	0005	22		34-61-12	ALL
	12	UNUSED						ALL
	13		W2135	0027	22		34-51-41	ALL
	14		W2135	0025	20		34-51-41	ALL
	15		W2135	0026	20		34-51-41	ALL
	16		W2135	0024	22		34-51-41	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2218	8004	20		34-51-41	ALL
	25		W2218	8003	22		34-51-41	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01817	**P005-28/ /**		**PLUG - INSTRUMENT SWITCHING MODULE (continued)**				**ALL**
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W2112	8022	22		34-21-15	ALL
36		W2508	8006	20		34-21-15	ALL
37		W2508	8005	22		34-21-15	ALL
38	UNUSED						ALL
39		W2508	8013	20		34-21-15	ALL
40		W2508	8012	22		34-21-15	ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W2135	0016	24		31-65-25	ALL
46		W2135	0017	24		31-65-25	ALL
47		W2135	0018	24		31-65-25	ALL
48		W2135	0019	22		31-65-25	ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53		W2135	0030	22		31-65-25	ALL
54		W2135	0029	24		31-65-25	ALL
55	UNUSED						ALL
D01827	**675/190/L039**		**PLUG**				**ALL**
1		W5367	2008B	20		22-11-31	ALL
2		W5367	0012	20		22-11-31	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01827		**675/190/L039**		**PLUG (continued)**				**ALL**
	4	UNUSED						ALL
	5		W5367	2009R	22		22-11-31	ALL
	6		W5367	0003	22		22-11-31	ALL
	7		W5367	0003	22		22-11-31	ALL
	8		W5367	2009B	22		22-11-31	ALL
	9		W5367	2003R	22		22-11-31	ALL
	10		W5367	2003B	22		22-11-31	ALL
	11		W5367	3004R	22		22-11-31	ALL
	12		W5367	3004B	22		22-11-31	ALL
	13		W5367	3004Y	22		22-11-31	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W5367	2008R	20		22-11-31	ALL
	22		W5367	0013	20		22-11-31	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	DED		W5367	3013Z			SPARE	ALL
D01829		**1156/271/R005**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3397	2001B	22		22-12-31	ALL
	2		W3397	2001R	22		22-12-31	ALL
	3	UNUSED						ALL
	4		W3397	3002B	22		22-12-31	ALL
	5		W3397	3002R	22		22-12-31	ALL
	S/R		W3397	2001Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01829	**1156/271/R005**		**RCPT-CONDUCTIVE (continued)**				**ALL**
S/R		W3397	3002Z			22-12-31	ALL
D01857	**1160/288/L011**		**PLUG**				**ALL**
1		W3399	1002	20		22-11-12	ALL
2		W3399	1003	20		22-11-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
S/R		W3399	1002Z			22-11-12	ALL
S/R		W3399	1003Z			22-11-12	ALL
D01859	**670/193/L046**		**PLUG**				**ALL**
1		W5375	0021	20		22-11-12	ALL
2		W5375	0020	20		22-11-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D01861	**1168/278/L011**		**PLUG**				**ALL**
1		W3397	1002	20		22-11-12	ALL
2		W3397	1003	20		22-11-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D01863	**668/192/L037**		**PLUG**				**ALL**
1		W5367	0032	20		22-11-12	ALL
2		W5367	0034	20		22-11-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01907	**P061-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0041	2501R	22		31-32-15	ALL
9		W0041	2501B	22		31-32-15	ALL
10		W0041	2502R	22		31-32-15	ALL
11		W0041	2502B	22		31-32-15	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0041	FRAA			31-32-15	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0041	0013	22		31-32-15	ALL
20		W0041	0001	22		31-32-15	ALL
21		W0041	0009	22		31-32-15	ALL
22		W0041	0002	22		31-32-15	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D01907	**P061-00/ /**		**RCPT- (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0041	0005	22		31-32-15	ALL
51		W0041	0006	22		31-32-15	ALL
52		W0041	0007	22		31-32-15	ALL
53	UNUSED						ALL
CAP	Y	W0041	2503B	22		31-32-15	ALL
CAP	Y	W0041	2503R	22		31-32-15	ALL
CAP	Y	W0041	FRAC			31-32-15	ALL
		W0041	0041	20		31-32-15	ALL
		W0041	0042	20		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D01907		**P061-00/ /**		**RCPT- (continued)**				**ALL**
			W0041	0043	20		31-32-15	ALL
			W0041	2501Z			31-32-15	ALL
			W0041	2502Z			31-32-15	ALL
			W0041	2503Z			31-32-15	ALL
			W0041	FRAA			31-32-15	ALL
			W0041	FRAC			31-32-15	ALL
D01986		**855/179/L049**		**PLUG-**				**ALL**
	1		W5112	0502	20		38-41-13	ALL
	2		W5112	0503	20		38-41-13	ALL
	3		W5112	0504	20		38-41-13	ALL
	4	UNUSED						ALL
	5		W5112	0510	20		38-41-13	ALL
D01990		**958/204/R002**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5112	0511	20		38-41-13	ALL
	3		W5112	0512	20		38-41-13	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02113		**300/177/R022**		**RCPT - (N) IN-LINE (NC)**				**ALL**
	=A1		W5137	001CX			34-31-11	ALL
	=C1		W5137	001CO			34-31-11	ALL
D02115		**E001-02/ /**		**PLUG- (C) STRAIGNT (IN)**				**ALL**
	=A1		W0121	009CX			34-31-11	ALL
	=C1		W0121	009CO			34-31-11	ALL
D02117		**300/178/R022**		**PLUG - (N) STRAIGHT (NO)**				**ALL**
	=A1		W5837	001CX			34-31-11	ALL
	=C1		W5837	001CO			34-31-11	ALL
D02119		**300/180/R021**		**PLUG**				**ALL**
	A		W5205	0008	22		34-51-41	ALL
	B	UNUSED						ALL
	C		W5205	0009	20		34-51-41	ALL
	D		W5205	0004	22		34-51-41	ALL
	E		W5205	0003	22		34-51-41	ALL
	F	UNUSED						ALL
D02121		**305/180/R21**		**RCPT - (N) STRAIGHT**				**ALL**
	=A1		W5139	001CX			34-31-21	ALL
	=C1		W5139	001CO			34-31-21	ALL
D02123		**306/180/R020**		**PLUG - (C) STRAIGHT (IN)**				**ALL**
	=A1		W0141	001CX			34-31-21	ALL
	=C1		W0141	001CO			34-31-21	ALL
D02125		**305/178/R021**		**PLUG - (N) STRAIGHT (NO)**				**ALL**
	=A1		W5839	001CX			34-31-21	ALL
	=C1		W5839	001CO			34-31-21	ALL
D02127		**305/178/R019**		**PLUG-LOC ANT SWITCH-2 (CONTROL)**				**ALL**
	A		W5163	0036	22		34-51-41	ALL
	B	UNUSED						ALL
	C		W5163	0037	22		34-51-41	ALL
	D		W5163	0032	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02127		**305/178/R019**		**PLUG-LOC ANT SWITCH-2 (CONTROL) (continued)**				**ALL**
	E		W5163	0031	22		34-51-41	ALL
	F	UNUSED						ALL
D02129		**178/187/L010**		**PLUG - (C) ANGLED 90 (OUT-1)**				**ALL**
	=A1		W7157	001CX			34-31-11	ALL
	=C1		W7157	001CO			34-31-11	ALL
D02131		**178/186/L010**		**PLUG - (C) ANGLED 90 (OUT-2)**				**ALL**
	=A1		W8157	001CX			34-31-21	ALL
	=C1		W8157	001CO			34-31-21	ALL
D02169		**P005-70/ /**		**PLUG PLATE ASSY - ISDU - LEFT**				**ALL**
	1		W2218	5662	20		33-12-12	ALL
	2		W2218	5663	20		33-12-12	ALL
	3		W2035	0014	24		34-21-11	ALL
	4		W2035	0015	24		34-21-11	ALL
	5		W2035	0045	22		34-21-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2035	0036	20		34-21-11	ALL
	9		W2035	0011	22		34-21-11	ALL
	10		W2035	0053	24		34-21-11	ALL
	11		W2508	5589	20		33-18-41	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02169	**P005-70/ /**		**PLUG PLATE ASSY - ISDU - LEFT (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W2035	2001R	24		34-21-11	ALL
25		W2035	2001B	24		34-21-11	ALL
26		W2035	2501R	22		34-21-13	ALL
27		W2035	2501B	22		34-21-13	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
DED		W2035	2001Z			34-21-11	ALL
DED		W2035	2501Z			34-21-13	ALL
D02171	**P005-69/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - LEFT**				**ALL**
1		W2218	5660	20		33-12-12	ALL
2		W2218	5661	20		33-12-12	ALL
3		W2508	5586	20		33-18-41	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W2508	5587	20		33-18-41	ALL
11		W2035	0016	24		34-21-11	ALL
12		W2035	0017	22		34-21-11	ALL
13		W2035	0018	22		34-21-11	ALL
14		W2035	0019	22		34-21-11	ALL
15		W2035	0021	22		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02171		**P005-69/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - LEFT (continued)**				**ALL**
	16		W2035	0022	22		34-21-11	ALL
	17		W2035	0020	22		34-21-11	ALL
	18		W2508	5584	20		33-18-41	ALL
	19		W2135	0060	22		34-58-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D02173		**P005-69/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - RIGHT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W2508	5588	20		33-18-41	ALL
	11		W2135	0003	22		34-21-21	ALL
	12		W2135	0004	22		34-21-21	ALL
	13		W2135	0005	22		34-21-21	ALL
	14		W2135	0006	22		34-21-21	ALL
	15		W2135	0007	22		34-21-21	ALL
	16		W2135	0009	22		34-21-21	ALL
	17		W2135	0008	22		34-21-21	ALL
	18		W2508	5585	20		33-18-41	ALL
	19		W2135	0010	22		34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02173	**P005-69/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - RIGHT (continued)**				**ALL**
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W2135	0061	22		34-58-11	ALL
CAP	Y	W2135	0064	22		34-58-11	ALL
D02179A	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1**				**ALL**
A01		W0521	2581R	24		34-51-11	ALL
A02	UNUSED						ALL
A03		W0521	2544R	24		34-21-13	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0521	2592R	24		34-61-22	ALL
A10	UNUSED						ALL
A11		W0521	2595R	22		34-61-15	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0521	2507R	24		34-61-12	ALL
A15		W0521	2725R	24		46-13-11	ALL
B01		W0521	2581B	24		34-51-11	ALL
B02	UNUSED						ALL
B03		W0521	2544B	24		34-21-13	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02179A		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	B08	UNUSED						ALL
	B09		W0521	2592B	24		34-61-22	ALL
	B10	UNUSED						ALL
	B11		W0521	2595B	22		34-61-15	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0521	2507B	24		34-61-12	ALL
	B15		W0521	2725B	24		46-13-11	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0521	2587R	24		34-55-11	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0521	2670R	22		28-41-11	ALL
	D06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179A	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
D07		W0521	2558R	24		34-21-14	ALL
D08	UNUSED						ALL
D09		W0521	2565R	24		34-61-18	ALL
D10	UNUSED						ALL
D11		W0523	2766R	24		34-61-11	ALL
D12		W0521	4006R	24		31-65-15	ALL
D13		W0521	2503R	24		34-61-11	ALL
D14		W0521	4007R	24		31-65-25	ALL
D15	UNUSED						ALL
E01		W0521	2587B	24		34-55-11	ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05		W0521	2670B	22		28-41-11	ALL
E06	UNUSED						ALL
E07		W0521	2558B	24		34-21-14	ALL
E08	UNUSED						ALL
E09		W0521	2565B	24		34-61-18	ALL
E10	UNUSED						ALL
E11		W0523	2766B	24		34-61-11	ALL
E12		W0521	4006B	24		31-65-15	ALL
E13		W0521	2503B	24		34-61-11	ALL
E14		W0521	4007B	24		31-65-25	ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179A		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01		W0521	2579R	24		34-31-11	ALL
	G02	UNUSED						ALL
	G03		W0523	2755R	24		31-65-25	ALL
	G04	UNUSED						ALL
	G05		W0521	2585R	24		22-31-52	ALL
	G06	UNUSED						ALL
	G07		W0521	2567R	24		22-11-51	ALL
	G08	UNUSED						ALL
	G09		W0521	2593R	24		34-61-14	ALL
	G10	UNUSED						ALL
	G11		W0521	2527R	24		34-61-18	ALL
	G12		W0521	4006Y	24		31-65-15	ALL
	G13		W0521	2504R	24		34-61-11	ALL
	G14		W0521	4007Y	24		31-65-25	ALL
	G15		W0521	2575R	24		31-65-15	ALL
	H01		W0521	2579B	24		34-31-11	ALL
	H02	UNUSED						ALL
	H03		W0523	2755B	24		31-65-25	ALL
	H04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179A	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
H05		W0521	2585B	24		22-31-52	ALL
H06	UNUSED						ALL
H07		W0521	2567B	24		22-11-51	ALL
H08	UNUSED						ALL
H09		W0521	2593B	24		34-61-14	ALL
H10	UNUSED						ALL
H11		W0521	2527B	24		34-61-18	ALL
H12		W0521	4006G	24		31-65-15	ALL
H13		W0521	2504B	24		34-61-11	ALL
H14		W0521	4007G	24		31-65-25	ALL
H15		W0521	2575B	24		31-65-15	ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13		W0523	0303	22		34-61-11	ALL
J14		W0521	0296	22		34-61-19	ALL
J15		W0521	0297	22		34-61-19	ALL
K01		W0521	0223	24		34-61-17	ALL
K02	UNUSED						ALL
K03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02179A		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08		W0521	0279	22		34-61-18	ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13		W0521	0029	22		34-61-16	ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	DED		W0521	2558Z			34-21-14	ALL
	DED		W0521	2565Z			34-61-18	ALL
	DED		W0521	2585Z			22-31-52	ALL
	DED		W0521	2587Z			34-55-11	ALL
	DED		W0521	2592Z			34-61-22	ALL
	DED		W0521	2593Z			34-61-14	ALL
	DED		W0521	2595Z			34-61-15	ALL
	DED		W0521	2670Z			28-41-11	ALL
	DED		W0523	2766Z			34-61-11	ALL
D02179B		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1**				**ALL**
	A01		W0521	2615R	24		34-58-11	ALL
	A02	UNUSED						ALL
	A03		W0523	2737R	24		34-21-23	ALL
	A04		W0521	2506R	24		34-61-12	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
A08	UNUSED						ALL
A09		W0521	2624R	24		34-61-21	ALL
A10		W0521	0101	22		34-61-19	ALL
A11		W0521	0139	24		34-61-18	ALL
A12		W0521	0075	22		34-61-19	ALL
A13	UNUSED						ALL
A14		W0521	0045	24		34-61-17	ALL
A15	UNUSED						ALL
B01		W0521	2615B	24		34-58-11	ALL
B02	UNUSED						ALL
B03		W0523	2737B	24		34-21-23	ALL
B04		W0521	2506B	24		34-61-12	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0521	2624B	24		34-61-21	ALL
B10		W0521	0319	22		34-61-19	ALL
B11	UNUSED						ALL
B12		W0521	0068	22		34-61-19	ALL
B13		W0521	0110	22		34-61-19	ALL
B14		W0523	0011	24		34-61-17	ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10		W0521	0102	22		34-61-19	ALL
	C11		W0521	0069	22		34-61-19	ALL
	C12		W0521	0066	22		34-61-19	ALL
	C13		W0521	0318	22		34-61-19	ALL
	C14		W0523	0014	24		34-61-17	ALL
	C15	UNUSED						ALL
	D01		W0523	2861R	24		34-51-21	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0521	2919W	24		34-61-12	ALL
	D05		W0523	2749R	24		34-21-24	ALL
	D06	UNUSED						ALL
	D07		W0521	2594R	24		34-61-14	ALL
	D08	UNUSED						ALL
	D09		W0521	2914R	24		34-61-18	ALL
	D10		W0521	0103	22		34-61-19	ALL
	D11		W0521	0070	22		34-61-19	ALL
	D12		W0521	0067	22		34-61-19	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0523	2861B	24		34-51-21	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0521	2919B	24		34-61-12	ALL
	E05		W0523	2749B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
E06	UNUSED						ALL
E07		W0521	2594B	24		34-61-14	ALL
E08	UNUSED						ALL
E09		W0521	2914B	24		34-61-18	ALL
E10	UNUSED						ALL
E11		W0521	0071	22		34-61-19	ALL
E12		W0521	0203	22		34-61-12	ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06		W0521	0006	22		34-61-11	ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0521	0104	22		34-61-19	ALL
F11		W0521	0072	22		34-61-19	ALL
F12		W0521	0108	22		34-61-19	ALL
F13		W0521	0033	22		30-21-31	ALL
F14		W0521	0099	22		34-61-19	ALL
F15		W0521	0317	22		34-61-19	ALL
G01		W0523	2864R	24		34-58-21	ALL
G02	UNUSED						ALL
G03		W0521	2625R	24		34-61-21	ALL
G04		W0521	2920W	24		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	G05		W0523	2759R	24		34-31-21	ALL
	G06	UNUSED						ALL
	G07		W0523	2764R	24		34-55-21	ALL
	G08	UNUSED						ALL
	G09		W0521	2529R	22		34-61-15	ALL
	G10		W0521	0105	22		34-61-19	ALL
	G11		W0521	0073	22		34-61-19	ALL
	G12		W0521	0202	22		34-61-12	ALL
	G13		W0521	0031	22		30-21-32	ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0523	2864B	24		34-58-21	ALL
	H02	UNUSED						ALL
	H03		W0521	2625B	24		34-61-21	ALL
	H04		W0521	2920B	24		34-61-12	ALL
	H05		W0523	2759B	24		34-31-21	ALL
	H06	UNUSED						ALL
	H07		W0523	2764B	24		34-55-21	ALL
	H08	UNUSED						ALL
	H09		W0521	2529B	22		34-61-15	ALL
	H10		W0521	0106	22		34-61-19	ALL
	H11		W0521	0074	22		34-61-19	ALL
	H12		W0521	0109	22		34-61-19	ALL
	H13		W0521	0037	24		34-61-17	ALL
	H14		W0523	0008	24		34-61-17	ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B	**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0521	0107	22		34-61-19	ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13		W0521	0041	24		34-61-17	ALL
J14		W0521	0035	22		30-11-11	ALL
J15	UNUSED						ALL
K01		W0521	0064	22		34-61-19	ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0521	0049	24		34-61-17	ALL
K05		W0521	0065	22		34-61-19	ALL
K06	UNUSED						ALL
K07		W0521	0027	22		34-61-16	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
DED		W0521	2594Z			34-61-14	ALL
DED		W0521	2914Z			34-61-18	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02179B		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1 (continued)**				**ALL**
	DED		W0523	2737Z			34-21-23	ALL
	DED		W0523	2749Z			34-21-24	ALL
D02179C		**E005-02/ /**		**PLUG PLATE ASSY-FMC NO. 1**				**ALL**
	1		W0521	0001	20		34-61-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0521	0003	20		34-61-11	ALL
	8		W0521	0004	20		34-61-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D02181		**P009-65/ /**		**PLUG - CDU NO.1**				**ALL**
	1	UNUSED						ALL
	2		W2889	2502R	24		34-61-11	ALL
	3		W2889	2502B	24		34-61-11	ALL
	4	UNUSED						ALL
	5		W2889	2511R	24		34-61-26	ALL
	6		W2889	2511B	24		34-61-26	ALL
	7		W2889	0013	24		34-61-26	ALL
	8		W2889	2501R	24		34-61-22	ALL
	9		W2889	2501B	24		34-61-22	ALL
	10		W2889	0012	24		34-61-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02181	**P009-65/ /**		**PLUG - CDU NO.1 (continued)**				**ALL**
11		W2889	0004	20		34-61-11	ALL
12	UNUSED						ALL
13		W2889	0002	22		34-61-11	ALL
14		W2889	2504R	24		23-27-32	ALL
15		W2889	2504B	24		23-27-32	ALL
16		W2889	2503R	24		34-61-23	ALL
17		W2889	2503B	24		34-61-23	ALL
18		W2889	2505R	24		31-35-02	ALL
19		W2889	2505B	24		31-35-02	ALL
20		W2889	2508R	24		23-15-15	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W2889	0011	20		33-18-61	ALL
24		W2889	2508B	24		23-15-15	ALL
25		W2889	0005	20		34-61-11	ALL
26		W2889	0006	20		34-61-11	ALL
27		W2889	0010	20		33-18-61	ALL
28		W2889	0008	20		33-11-33	ALL
29		W2889	0009	20		33-11-33	ALL
30		W2889	0001	20		34-61-11	ALL
31		W2889	0003	20		34-61-11	ALL
DED		W2889	2501Z			34-61-22	ALL
DED		W2889	2502Z			34-61-11	ALL
DED		W2889	2503Z			34-61-23	ALL
DED		W2889	2504Z			23-27-32	ALL
DED		W2889	2505Z			31-35-02	ALL
DED		W2889	2508Z			23-15-15	ALL
DED		W2889	2511Z			34-61-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02183		**P005-70/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - LEFT**				**ALL**
	1		W2218	5664	20		33-12-12	ALL
	2		W2218	5665	20		33-12-12	ALL
	3		W2135	0037	22		34-21-21	ALL
	4		W2135	0040	22		34-21-21	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2135	0002	20		34-21-21	ALL
	9		W2135	0001	22		34-21-21	ALL
	10		W2135	0039	22		34-21-21	ALL
	11		W2508	5590	20		33-18-41	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2135	2501R	24		34-21-21	ALL
	25		W2135	2501B	24		34-21-21	ALL
	26		W2135	2502R	22		34-21-23	ALL
	27		W2135	2502B	22		34-21-23	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02183		**P005-70/ /**		**PLUG PLATE ASSY-MODE SELECT UNIT - LEFT (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	DED		W2135	2501Z			34-21-21	ALL
	DED		W2135	2502Z			34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02205		**1166/267/L006**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3397	2003B	22		22-12-31	ALL
	2		W3397	2003R	22		22-12-31	ALL
	3	UNUSED						ALL
	4		W3397	2005B	22		22-12-31	ALL
	5		W3397	2005R	22		22-12-31	ALL
	S/R		W3397	2003Z			22-12-31	ALL
	S/R		W3397	2005Z			22-12-31	ALL
D02207		**1164/266/R006**		**PLUG**				**ALL**
	1		W3399	2003B	22		22-12-41	ALL
	2		W3399	2003R	22		22-12-41	ALL
	3	UNUSED						ALL
	4		W3399	2005R	20		22-12-41	ALL
	5		W3399	2005B	20		22-12-41	ALL
D02209A		***/*/***		**PLUG**				**ALL**
	1		W0111	0022	22		22-11-11	ALL
	2		W0111	0026	20		22-11-11	ALL
	3	UNUSED						ALL
	4		W0111	0023	20		22-11-11	ALL
	5	UNUSED						ALL
	6		W0111	0024	20		22-11-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209A	*/*/*		**PLUG (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W0111	0025	20		22-11-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W0111	0246	22		22-18-11	ALL
41		W0111	0247	22		22-18-11	ALL
42		W0111	2049R	22		22-18-11	ALL
43		W0111	2049B	22		22-18-11	ALL
44	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209A		***/*/***		**PLUG (continued)**				**ALL**
	45		W0111	0245	22		22-18-11	ALL
	46		W0111	0248	22		22-18-11	ALL
	47		W0111	0176	22		22-14-11	ALL
	48		W0111	0179	20		22-14-11	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	56		W0111	0729	22		22-18-11	ALL
	57		W0111	0249	22		22-18-11	ALL
	58		W0111	2047R	22		22-18-11	ALL
	59		W0111	2047B	22		22-18-11	ALL
	60	UNUSED						ALL
	61		W0111	0726	22		22-18-11	ALL
	62		W0111	0135	20		22-18-11	ALL
	63	UNUSED						ALL
	64		W0111	0586	24		24-32-11	ALL
	65	UNUSED						ALL
	66	UNUSED						ALL
	67	UNUSED						ALL
	68	UNUSED						ALL
	69	UNUSED						ALL
	70	UNUSED						ALL
	71	UNUSED						ALL
	72	UNUSED						ALL
	73	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209A	*/*/*		**PLUG (continued)**				**ALL**
74	UNUSED						ALL
75	UNUSED						ALL
76	UNUSED						ALL
77	UNUSED						ALL
78	UNUSED						ALL
79		W0111	0583	24		24-32-11	ALL
80	UNUSED						ALL
81	UNUSED						ALL
82	UNUSED						ALL
83		W0111	0073	22		22-11-18	ALL
84	UNUSED						ALL
85	UNUSED						ALL
86	UNUSED						ALL
87	UNUSED						ALL
88	UNUSED						ALL
89	UNUSED						ALL
90	UNUSED						ALL
91	UNUSED						ALL
92	UNUSED						ALL
93	UNUSED						ALL
94	UNUSED						ALL
95	UNUSED						ALL
96	UNUSED						ALL
97	UNUSED						ALL
98	UNUSED						ALL
99	UNUSED						ALL
100	UNUSED						ALL
101	UNUSED						ALL
102	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209A		***/*/***		**PLUG (continued)**				**ALL**
	103	UNUSED						ALL
	104	UNUSED						ALL
	105	UNUSED						ALL
	106	UNUSED						ALL
	107		W0111	0041	20		22-11-12	ALL
	108	UNUSED						ALL
	109	UNUSED						ALL
	110	UNUSED						ALL
	111	UNUSED						ALL
	112	UNUSED						ALL
	113	UNUSED						ALL
	114	UNUSED						ALL
	115	UNUSED						ALL
	116	UNUSED						ALL
	117	UNUSED						ALL
	118	UNUSED						ALL
	119	UNUSED						ALL
	120	UNUSED						ALL
	121		W0111	0173	20		22-13-11	ALL
	122	UNUSED						ALL
	123	UNUSED						ALL
	124	UNUSED						ALL
	DED		W0111	2047Z			22-18-11	ALL
D02209B		***/*/***		**PLUG**				**ALL**
	1		W0111	0033	22		22-11-11	ALL
	2		W0111	0030	20		22-11-11	ALL
	3	UNUSED						ALL
	4		W0111	0034	20		22-11-11	ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209B	*/*/*		**PLUG (continued)**				**ALL**
6		W0111	0035	20		22-11-11	ALL
7		W0111	0031	20		22-11-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W0111	0032	20		22-11-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209B		***/*/***		**PLUG (continued)**				**ALL**
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W0111	0139	20		22-18-11	ALL
	40		W0111	0241	22		22-18-11	ALL
	41		W0111	0243	22		22-18-11	ALL
	42		W0111	2048R	22		22-18-11	ALL
	43		W0111	2048B	22		22-18-11	ALL
	44	UNUSED						ALL
	45		W0111	0240	22		22-18-11	ALL
	46		W0111	0242	22		22-18-11	ALL
	47	UNUSED						ALL
	48		W0111	0191	22		22-14-11	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W0111	0244	22		22-18-11	ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61	UNUSED						ALL
	62	UNUSED						ALL
	63	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209B	*/*/*		**PLUG (continued)**				**ALL**
64	UNUSED						ALL
65	UNUSED						ALL
66	UNUSED						ALL
67	UNUSED						ALL
68	UNUSED						ALL
69	UNUSED						ALL
70	UNUSED						ALL
71	UNUSED						ALL
72	UNUSED						ALL
73	UNUSED						ALL
74	UNUSED						ALL
75	UNUSED						ALL
76	UNUSED						ALL
77	UNUSED						ALL
78	UNUSED						ALL
79	UNUSED						ALL
80	UNUSED						ALL
81	UNUSED						ALL
82	UNUSED						ALL
83		W0111	0075	22		22-11-18	ALL
84	UNUSED						ALL
85	UNUSED						ALL
86	UNUSED						ALL
87	UNUSED						ALL
88	UNUSED						ALL
89	UNUSED						ALL
90	UNUSED						ALL
91	UNUSED						ALL
92	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209B		***/*/***		**PLUG (continued)**				**ALL**
	93	UNUSED						ALL
	94	UNUSED						ALL
	95	UNUSED						ALL
	96	UNUSED						ALL
	97	UNUSED						ALL
	98	UNUSED						ALL
	99	UNUSED						ALL
	100	UNUSED						ALL
	101	UNUSED						ALL
	102	UNUSED						ALL
	103	UNUSED						ALL
	104	UNUSED						ALL
	105	UNUSED						ALL
	106	UNUSED						ALL
	107		W0111	0058	20		22-11-12	ALL
	108	UNUSED						ALL
	109	UNUSED						ALL
	110	UNUSED						ALL
	111	UNUSED						ALL
	112	UNUSED						ALL
	113	UNUSED						ALL
	114	UNUSED						ALL
	115	UNUSED						ALL
	116	UNUSED						ALL
	117	UNUSED						ALL
	118	UNUSED						ALL
	119	UNUSED						ALL
	120	UNUSED						ALL
	121	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02209B	***/*/***		**PLUG (continued)**				**ALL**
122	UNUSED						ALL
123	UNUSED						ALL
124	UNUSED						ALL
D02221	**P009-66/ /**		**PLUG - CDU NO.2**				**ALL**
1	UNUSED						ALL
2		W2873	2502R	24		34-61-11	ALL
3		W2873	2502B	24		34-61-11	ALL
4	UNUSED						ALL
5		W2873	2511R	24		34-61-26	ALL
6		W2873	2511B	24		34-61-26	ALL
7		W2873	0013	24		34-61-26	ALL
8		W2873	2501R	24		34-61-11	ALL
9		W2873	2501B	24		34-61-11	ALL
10		W2873	0012	24		34-61-26	ALL
11	UNUSED						ALL
12		W2873	0004	20		34-61-11	ALL
13		W2873	0002	22		34-61-11	ALL
14		W2873	2504R	24		23-27-33	ALL
15		W2873	2504B	24		23-27-33	ALL
16		W2873	2503R	24		34-61-23	ALL
17		W2873	2503B	24		34-61-23	ALL
18		W2873	2505R	24		31-35-02	ALL
19		W2873	2505B	24		31-35-02	ALL
20		W2873	2508R	24		23-15-15	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W2873	0011	20		33-18-61	ALL
24		W2873	2508B	24		23-15-15	ALL
25		W2873	0005	20		34-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02221		**P009-66/ /**		**PLUG - CDU NO.2 (continued)**				**ALL**
	26		W2873	0006	20		34-61-11	ALL
	27		W2873	0010	20		33-18-61	ALL
	28		W2873	0008	20		33-11-41	ALL
	29		W2873	0009	20		33-11-41	ALL
	30		W2873	0001	20		34-61-11	ALL
	31		W2873	0003	20		34-61-11	ALL
	DED		W2873	2501Z			34-61-11	ALL
	DED		W2873	2502Z			34-61-11	ALL
	DED		W2873	2503Z			34-61-23	ALL
	DED		W2873	2504Z			23-27-33	ALL
	DED		W2873	2505Z			31-35-02	ALL
	DED		W2873	2508Z			23-15-15	ALL
	DED		W2873	2511Z			34-61-26	ALL
D02257		**200/203/R013**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W5369	0009	20		22-13-11	ALL
	3		W5369	0014	20		22-13-11	ALL
	4	UNUSED						ALL
	5		W5369	0010	20		22-13-11	ALL
	6		W5369	0008	20		22-13-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5369	0022	20		22-13-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5369	0013	20		22-13-11	ALL
	13		W5369	0012	20		22-13-11	ALL
	14		W5369	0020	20		22-13-11	ALL
	15		W5369	0015	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02257		**200/203/R013**		**PLUG (continued)**				**ALL**
	16		W5369	0018	20		22-13-11	ALL
	17	UNUSED						ALL
	18		W5369	0007	20		22-13-11	ALL
	19	UNUSED						ALL
	20		W5369	0023	20		22-13-11	ALL
	21	UNUSED						ALL
	22		W5369	0017	20		22-13-11	ALL
	23	UNUSED						ALL
	24		W5369	0019	20		22-13-11	ALL
D02269		**P061-01/ /**		**PLUG-MASTER CAUTION UNIT-LEFT**				**ALL**
	1		W0041	2511R	24		34-58-11	ALL
	2		W0041	2511B	24		34-58-11	ALL
	3		W0041	0034	20		31-52-71	ALL
	4		W0041	0038	20		31-52-71	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0041	2512R	24		34-58-11	ALL
	8		W0041	0037	20		34-21-11	ALL
	9		W0041	0035	20		31-52-71	ALL
	10		W0041	2512B	24		34-58-11	ALL
	11		W0041	0106	20		34-58-11	ALL
	12		W0041	0105	22		34-58-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0041	0025	22		34-21-11	ALL
	16		W0041	0026	22		34-21-11	ALL
	17		W0041	0024	22		34-21-11	ALL
	18		W0041	0027	22		34-21-11	ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02269		**P061-01/ /**		**PLUG-MASTER CAUTION UNIT-LEFT (continued)**				**ALL**
	20		W0041	0032	20		33-18-41	ALL
	21		W0041	0033	20		31-52-71	ALL
	22	UNUSED						ALL
	23		W0041	0028	22		34-21-16	ALL
	24	UNUSED						ALL
	CAP	Y	W0041	0129	20		34-58-11	ALL
	DED		W0041	2511Z			34-58-11	ALL
	DED		W0041	2512Z			34-58-11	ALL
D02271		**P061-01/ /**		**PLUG-MASTER CAUTION UNIT-RIGHT**				**ALL**
	1		W0041	2513R	24		34-58-21	ALL
	2		W0041	2513B	24		34-58-21	ALL
	3		W0041	0019	22		34-58-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0041	2514R	24		34-58-21	ALL
	8		W0041	0103	22		34-58-11	ALL
	9		W0041	0104	20		34-58-11	ALL
	10		W0041	2514B	24		34-58-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0041	0022	22		34-21-21	ALL
	16		W0041	0023	22		34-21-21	ALL
	17		W0041	0021	22		34-21-21	ALL
	18		W0041	0020	22		34-21-21	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02271		**P061-01/ /**		**PLUG-MASTER CAUTION UNIT-RIGHT (continued)**				**ALL**
	21		W0041	0055	20		34-58-21	ALL
	22	UNUSED						ALL
	23		W0041	0029	22		34-21-16	ALL
	24	UNUSED						ALL
	CAP	Y	W0041	0128	22		34-58-11	ALL
	DED		W0041	2513Z			34-58-21	ALL
	DED		W0041	2514Z			34-58-21	ALL
D02295A		***/*/***		**PLUG**				**ALL**
	A01		W0321	0093	24		31-31-17	ALL
	A02		W0321	2381R	24		31-65-24	ALL
	A03		W0321	0173	24		24-33-13	ALL
	A04		W0321	2259R	24		31-35-04	ALL
	A05	UNUSED						ALL
	A06		W0321	2748R	24		31-65-25	ALL
	A07		W0321	0958	22		26-19-11	ALL
	A08		W0321	2218R	24		34-58-21	ALL
	A09		W0321	2002R	24		31-31-11	ALL
	A10		W0321	2255R	24		23-12-41	ALL
	A11		W0321	0007	22		31-31-11	ALL
	A12	UNUSED						ALL
	A13		W0321	2045R	24		22-31-52	ALL
	A14		W0321	2130R	24		34-51-11	ALL
	A15		W0321	2012R	24		34-33-11	ALL
	B01		W0321	0098	24		31-31-17	ALL
	B02		W0321	2381B	24		31-65-24	ALL
	B03		W0321	0172	24		24-33-13	ALL
	B04		W0321	2259B	24		31-35-04	ALL
	B05		W0321	0930	22		27-62-11	ALL
	B06		W0321	2748B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A		***/*/***		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W0321	2218B	24		34-58-21	ALL
	B09		W0321	2002B	24		31-31-11	ALL
	B10		W0321	2255B	24		23-12-41	ALL
	B11		W0321	0026	22		31-31-11	ALL
	B12	UNUSED						ALL
	B13		W0321	2045B	24		22-31-52	ALL
	B14		W0321	2130B	24		34-51-11	ALL
	B15		W0321	2012B	24		34-33-11	ALL
	C01		W0321	0099	24		31-31-17	ALL
	C02	UNUSED						ALL
	C03		W0321	0174	24		24-33-13	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06		W0321	2749R	24		31-65-25	ALL
	C07	UNUSED						ALL
	C08		W0321	2254R	24		23-12-41	ALL
	C09		W0321	2220R	24		31-35-09	ALL
	C10		W0321	2234R	24		31-35-09	ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14		W0321	2044R	24		22-11-51	ALL
	C15		W0321	2820R	24		22-11-51	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0321	0175	24		24-33-13	ALL
	D04	UNUSED						ALL
	D05		W0321	2355R	24		31-31-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A	*/*/*		**PLUG (continued)**				**ALL**
D06		W0321	2749B	24		31-65-25	ALL
D07	UNUSED						ALL
D08		W0321	2254B	24		23-12-41	ALL
D09		W0321	2220B	24		31-35-09	ALL
D10		W0321	2234B	24		31-35-09	ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14		W0321	2044B	24		22-11-51	ALL
D15		W0321	2820B	24		22-11-51	ALL
E01	UNUSED						ALL
E02		W0321	2156R	24		34-61-15	ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05		W0321	2355B	24		31-31-13	ALL
E06		W0321	2158R	24		32-64-31	ALL
E07		W0321	0357	22		27-11-11	ALL
E08		W0321	2239R	24		34-41-11	ALL
E09	UNUSED						ALL
E10		W0321	2233R	24		31-35-09	ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13		W0321	2017R	24		34-21-14	ALL
E14		W0321	2123R	24		34-55-21	ALL
E15	UNUSED						ALL
F01		W0321	0178	24		31-31-15	ALL
F02		W0321	2156B	24		34-61-15	ALL
F03		W0321	0080	24		31-31-15	ALL
F04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A		***/*/***		**PLUG (continued)**				**ALL**
	F05	UNUSED						ALL
	F06		W0321	2158B	24		32-64-31	ALL
	F07		W0321	0359	24		27-21-11	ALL
	F08		W0321	2239B	24		34-41-11	ALL
	F09	UNUSED						ALL
	F10		W0321	2233B	24		31-35-09	ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0321	2017B	24		34-21-14	ALL
	F14		W0321	2123B	24		34-55-21	ALL
	F15	UNUSED						ALL
	G01		W0321	0208	24		31-31-15	ALL
	G02		W0321	2345R	24		22-11-51	ALL
	G03		W0321	0054	24		31-31-15	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06		W0321	2149R	24		34-53-21	ALL
	G07		W0321	0170	22		24-28-11	ALL
	G08		W0321	2251R	24		23-12-41	ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13		W0321	2010R	24		31-65-15	ALL
	G14		W0321	2011R	24		31-65-25	ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02		W0321	2345B	24		22-11-51	ALL
	H03		W0321	0056	24		31-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A	*/*/*		**PLUG (continued)**				**ALL**
H04	UNUSED						ALL
H05	UNUSED						ALL
H06		W0321	2149B	24		34-53-21	ALL
H07		W0321	0403	24		26-16-22	ALL
H08		W0321	2251B	24		23-12-41	ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13		W0321	2010B	24		31-65-15	ALL
H14		W0321	2011B	24		31-65-25	ALL
H15	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03		W0321	0082	24		31-31-15	ALL
J04		W0321	2147R	24		22-11-51	ALL
J05		W0321	0012	24		31-35-08	ALL
J06		W0321	2230R	24		34-57-21	ALL
J07	UNUSED						ALL
J08		W0321	2415R	24		36-11-24	ALL
J09		W0321	2004B	24		31-31-11	ALL
J10	UNUSED						ALL
J11		W0321	2005R	24		31-31-11	ALL
J12	UNUSED						ALL
J13		W0321	2500R	24		34-31-21	ALL
J14		W0321	2028R	24		27-32-22	ALL
J15		W0321	0003	22		31-31-11	ALL
K01		W0321	0067	22		31-31-15	ALL
K02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A		***/*/***		**PLUG (continued)**				**ALL**
	K03		W0321	0084	24		31-31-15	ALL
	K04		W0321	2147B	24		22-11-51	ALL
	K05		W0321	0957	22		26-19-11	ALL
	K06		W0321	2230B	24		34-57-21	ALL
	K07	UNUSED						ALL
	K08		W0321	2415B	24		36-11-24	ALL
	K09		W0321	2004R	24		31-31-11	ALL
	K10	UNUSED						ALL
	K11		W0321	2005B	24		31-31-11	ALL
	K12	UNUSED						ALL
	K13		W0321	2500B	24		34-31-21	ALL
	K14		W0321	2028B	24		27-32-22	ALL
	K15		W0321	0004	22		31-31-11	ALL
	PERG	1A	W0321	2002Z			31-31-11	ALL
	PERG	1A	W0321	2004Z			31-31-11	ALL
	PERG	1A	W0321	2005Z			31-31-11	ALL
	PERG	1A	W0321	2010Z			31-65-15	ALL
	PERG	1A	W0321	2011Z			31-65-25	ALL
	PERG	1A	W0321	2012Z			34-33-11	ALL
	PERG	1A	W0321	2017Z			34-21-14	ALL
	PERG	1A	W0321	2028Z			27-32-22	ALL
	PERG	1A	W0321	2044Z			22-11-51	ALL
	PERG	1A	W0321	2045Z			22-31-52	ALL
	PERG	1A	W0321	2123Z			34-55-21	ALL
	PERG	1A	W0321	2130Z			34-51-11	ALL
	PERG	1A	W0321	2147Z			22-11-51	ALL
	PERG	1A	W0321	2149Z			34-53-21	ALL
	PERG	1A	W0321	2156Z			34-61-15	ALL
	PERG	1A	W0321	2158Z			32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295A		*/*/*		**PLUG (continued)**				**ALL**
	PERG	1A	W0321	2218Z			34-58-21	ALL
	PERG	1A	W0321	2220Z			31-35-09	ALL
	PERG	1A	W0321	2230Z			34-57-21	ALL
	PERG	1A	W0321	2233Z			31-35-09	ALL
	PERG	1A	W0321	2234Z			31-35-09	ALL
	PERG	1A	W0321	2239Z			34-41-11	ALL
	PERG	1A	W0321	2251Z			23-12-41	ALL
	PERG	1A	W0321	2254Z			23-12-41	ALL
	PERG	1A	W0321	2255Z			23-12-41	ALL
	PERG	1A	W0321	2259Z			31-35-04	ALL
	PERG	1A	W0321	2345Z			22-11-51	ALL
	PERG	1A	W0321	2355Z			31-31-13	ALL
	PERG	1A	W0321	2381Z			31-65-24	ALL
	PERG	1A	W0321	2415Z			36-11-24	ALL
	PERG	1A	W0321	2500Z			34-31-21	ALL
	PERG	1A	W0321	2748Z			31-65-25	ALL
	PERG	1A	W0321	2749Z			31-65-25	ALL
	PERG	1A	W0321	2820Z			22-11-51	ALL
D02295B		*/*/*		**PLUG**				**ALL**
	A01		W0321	2038R	24		31-31-14	ALL
	A02		W0321	2038B	24		31-31-14	ALL
	A03	UNUSED						ALL
	A04		W0321	2039R	24		31-31-14	ALL
	A05		W0321	2039B	24		31-31-14	ALL
	A06	UNUSED						ALL
	A07		W0321	3001R	24		31-31-14	ALL
	A08		W0321	3001Y	24		31-31-14	ALL
	A09		W0321	3001B	24		31-31-14	ALL
	A10		W0321	3707R	24		27-38-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B		***/*/***		**PLUG (continued)**				**ALL**
	A11		W0321	3707Y	24		27-38-11	ALL
	A12		W0321	3707B	24		27-38-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01		W0321	3701R	24		27-18-11	ALL
	B02		W0321	3701Y	24		27-18-11	ALL
	B03		W0321	3701B	24		27-18-11	ALL
	B04		W0321	2040R	24		31-31-14	ALL
	B05		W0321	2040B	24		31-31-14	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0321	0034	22		31-31-14	ALL
	C05		W0321	0035	22		31-31-14	ALL
	C06		W0321	0037	22		31-31-14	ALL
	C07		W0321	0041	22		31-31-14	ALL
	C08		W0321	0042	22		31-31-14	ALL
	C09		W0321	0039	22		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B		*/*/*		**PLUG (continued)**				**ALL**
	C10		W0321	0432	24		31-35-05	ALL
	C11		W0321	0433	24		31-35-05	ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0321	0474	22		31-31-14	ALL
	D05		W0321	0475	22		31-31-14	ALL
	D06		W0321	0477	22		31-31-14	ALL
	D07		W0321	1073	24		31-31-14	ALL
	D08		W0321	0367	24		31-31-14	ALL
	D09		W0321	0201	24		31-31-14	ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B		***/*/***		**PLUG (continued)**				**ALL**
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07		W0321	2260R	24		31-31-13	ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14		W0321	2037R	24		31-31-14	ALL
	F15		W0321	2037B	24		31-31-14	ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07		W0321	2260B	24		31-31-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B	*/*/*		**PLUG (continued)**				**ALL**
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL
G13	UNUSED						ALL
G14	UNUSED						ALL
G15	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03		W0321	0023	24		31-31-14	ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15	UNUSED						ALL
J01		W0321	0194	24		31-31-17	ALL
J02		W0321	0058	24		31-31-15	ALL
J03		W0321	0092	24		31-31-15	ALL
J04		W0321	0073	22		34-61-12	ALL
J05		W0321	0567	24		23-12-41	ALL
J06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B		***/*/***		**PLUG (continued)**				**ALL**
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0321	0077	24		31-31-15	ALL
	K02		W0321	0075	24		31-31-15	ALL
	K03		W0321	0559	24		31-31-15	ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	PERG	1A	W0321	1073Z			31-31-14	ALL
	PERG	1A	W0321	2037Z			31-31-14	ALL
	PERG	1A	W0321	2038Z			31-31-14	ALL
	PERG	1A	W0321	2039Z			31-31-14	ALL
	PERG	1A	W0321	2040Z			31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295B		***/*/***		**PLUG (continued)**				**ALL**
	PERG	1A	W0321	2260Z			31-31-13	ALL
D02295C		***/*/***		**PLUG**				**ALL**
	1		W0321	0001	22		31-31-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0321	0002	22		31-31-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D02295D		***/*/***		**PLUG**				**ALL**
	A01		W0321	0069	24		31-31-15	ALL
	A02		W0321	2414R	24		36-11-14	ALL
	A03		W0321	0176	24		24-33-13	ALL
	A04		W0321	2146R	24		34-21-24	ALL
	A05		W0321	0086	24		31-31-15	ALL
	A06		W0321	2747R	24		31-65-15	ALL
	A07		W0321	0210	24		31-31-15	ALL
	A08		W0321	2281R	24		31-65-25	ALL
	A09		W0321	0809	24		31-31-16	ALL
	A10		W0321	2380R	24		31-65-14	ALL
	A11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		***/*/***		**PLUG (continued)**				**ALL**
	A12	UNUSED						ALL
	A13		W0321	2016R	24		34-61-14	ALL
	A14		W0321	2026R	24		27-32-12	ALL
	A15		W0321	2180R	24		34-33-21	ALL
	B01		W0321	0094	24		31-31-17	ALL
	B02		W0321	2414B	24		36-11-14	ALL
	B03		W0321	0177	24		24-33-13	ALL
	B04		W0321	2146B	24		34-21-24	ALL
	B05	UNUSED						ALL
	B06		W0321	2747B	24		31-65-15	ALL
	B07		W0321	0959	22		26-19-11	ALL
	B08		W0321	2281B	24		31-65-25	ALL
	B09		W0321	0810	24		31-31-16	ALL
	B10		W0321	2380B	24		31-65-14	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0321	2016B	24		34-61-14	ALL
	B14		W0321	2026B	24		27-32-12	ALL
	B15		W0321	2180B	24		34-33-21	ALL
	C01		W0321	0950	22		31-52-11	ALL
	C02		W0321	2032R	24		31-35-02	ALL
	C03		W0321	0569	24		23-12-41	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06		W0321	2148R	24		22-11-51	ALL
	C07	UNUSED						ALL
	C08		W0321	2253R	24		23-12-41	ALL
	C09		W0321	0811	24		31-31-16	ALL
	C10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		*/*/*		**PLUG (continued)**				**ALL**
	C11	UNUSED						ALL
	C12		W0321	2359R	24		31-31-13	ALL
	C13		W0321	2042R	24		34-49-11	ALL
	C14		W0321	2015R	22		34-61-15	ALL
	C15		W0321	2819R	24		22-11-51	ALL
	D01		W0321	0032	24		31-31-17	ALL
	D02		W0321	2032B	24		31-35-02	ALL
	D03		W0321	0081	24		31-31-15	ALL
	D04	UNUSED						ALL
	D05		W0321	2344R	24		22-11-51	ALL
	D06		W0321	2148B	24		22-11-51	ALL
	D07	UNUSED						ALL
	D08		W0321	2253B	24		23-12-41	ALL
	D09		W0321	0812	24		31-31-16	ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12		W0321	2359B	24		31-31-13	ALL
	D13		W0321	2042B	24		34-49-11	ALL
	D14		W0321	2015B	22		34-61-15	ALL
	D15		W0321	2819B	24		22-11-51	ALL
	E01		W0321	0070	22		34-21-15	ALL
	E02		W0321	2305R	24		34-61-23	ALL
	E03		W0321	0072	24		31-31-15	ALL
	E04		W0321	2157R	24		34-61-15	ALL
	E05		W0321	2344B	24		22-11-51	ALL
	E06		W0321	2159R	24		32-64-31	ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0321	0813	24		31-31-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		***/*/***		**PLUG (continued)**				**ALL**
	E10		W0321	2132R	24		34-55-11	ALL
	E11	UNUSED						ALL
	E12		W0321	2244R	24		31-35-04	ALL
	E13		W0321	2131R	24		34-31-11	ALL
	E14		W0321	2013R	24		31-65-15	ALL
	E15		W0321	2074R	22		32-46-11	ALL
	F01	UNUSED						ALL
	F02		W0321	2305B	24		34-61-23	ALL
	F03		W0321	0076	24		31-31-15	ALL
	F04		W0321	2157B	24		34-61-15	ALL
	F05	UNUSED						ALL
	F06		W0321	2159B	24		32-64-31	ALL
	F07		W0321	0356	22		27-11-11	ALL
	F08	UNUSED						ALL
	F09		W0321	0814	24		31-31-16	ALL
	F10		W0321	2132B	24		34-55-11	ALL
	F11	UNUSED						ALL
	F12		W0321	2244B	24		31-35-04	ALL
	F13		W0321	2131B	24		34-31-11	ALL
	F14		W0321	2013B	24		31-65-15	ALL
	F15		W0321	2074B	22		32-46-11	ALL
	G01	UNUSED						ALL
	G02		W0321	2031R	24		31-33-01	ALL
	G03		W0321	0066	22		31-31-15	ALL
	G04		W0321	2113R	24		34-21-23	ALL
	G05	UNUSED						ALL
	G06		W0321	2229R	24		34-57-11	ALL
	G07		W0321	0358	24		27-21-11	ALL
	G08		W0321	2252R	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		***/*/***		**PLUG (continued)**				**ALL**
	G09	UNUSED						ALL
	G10		W0321	2046R	22		34-21-15	ALL
	G11	UNUSED						ALL
	G12		W0321	2516R	24		31-31-13	ALL
	G13		W0321	2043R	24		22-11-51	ALL
	G14		W0321	2041R	24		34-45-11	ALL
	G15	UNUSED						ALL
	H01		W0321	0209	24		31-31-15	ALL
	H02		W0321	2031B	24		31-33-01	ALL
	H03		W0321	0055	24		31-31-15	ALL
	H04		W0321	2113B	24		34-21-23	ALL
	H05	UNUSED						ALL
	H06		W0321	2229B	24		34-57-11	ALL
	H07		W0321	0171	22		24-28-11	ALL
	H08		W0321	2252B	24		23-12-41	ALL
	H09	UNUSED						ALL
	H10		W0321	2046B	22		34-21-15	ALL
	H11	UNUSED						ALL
	H12		W0321	2516B	24		31-31-13	ALL
	H13		W0321	2043B	24		22-11-51	ALL
	H14		W0321	2041B	24		34-45-11	ALL
	H15		W0321	0017	24		31-35-01	ALL
	J01	UNUSED						ALL
	J02		W0321	2306R	24		34-61-23	ALL
	J03		W0321	0087	24		31-31-15	ALL
	J04		W0321	2746R	24		31-65-15	ALL
	J05		W0321	0011	24		31-35-08	ALL
	J06		W0321	2241R	24		34-58-11	ALL
	J07		W0321	0402	24		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		***/*/***		**PLUG (continued)**				**ALL**
	J08		W0321	2357R	24		31-31-13	ALL
	J09	UNUSED						ALL
	J10		W0321	2014R	24		49-62-11	ALL
	J11		W0321	0815	24		31-31-16	ALL
	J12		W0321	2089R	22		28-41-11	ALL
	J13		W0321	2501R	24		34-51-21	ALL
	J14		W0321	2751R	24		27-81-41	ALL
	J15		W0321	0005	22		31-31-11	ALL
	K01	UNUSED						ALL
	K02		W0321	2306B	24		34-61-23	ALL
	K03		W0321	0089	24		31-31-15	ALL
	K04		W0321	2746B	24		31-65-15	ALL
	K05		W0321	0960	22		26-19-11	ALL
	K06		W0321	2241B	24		34-58-11	ALL
	K07	UNUSED						ALL
	K08		W0321	2357B	24		31-31-13	ALL
	K09	UNUSED						ALL
	K10		W0321	2014B	24		49-62-11	ALL
	K11		W0321	0820	24		31-31-16	ALL
	K12		W0321	2089B	22		28-41-11	ALL
	K13		W0321	2501B	24		34-51-21	ALL
	K14		W0321	2751B	24		27-81-41	ALL
	K15		W0321	0006	22		31-31-11	ALL
	PERG	1A	W0321	2013Z			31-65-15	ALL
	PERG	1A	W0321	2014Z			49-62-11	ALL
	PERG	1A	W0321	2015Z			34-61-15	ALL
	PERG	1A	W0321	2016Z			34-61-14	ALL
	PERG	1A	W0321	2026Z			27-32-12	ALL
	PERG	1A	W0321	2031Z			31-33-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		*/*/*		**PLUG (continued)**				**ALL**
	PERG	1A	W0321	2032Z			31-35-02	ALL
	PERG	1A	W0321	2041Z			34-45-11	ALL
	PERG	1A	W0321	2042Z			34-49-11	ALL
	PERG	1A	W0321	2043Z			22-11-51	ALL
	PERG	1A	W0321	2046Z			34-21-15	ALL
	PERG	1A	W0321	2074Z			32-46-11	ALL
	PERG	1A	W0321	2089Z			28-41-11	ALL
	PERG	1A	W0321	2113Z			34-21-23	ALL
	PERG	1A	W0321	2131Z			34-31-11	ALL
	PERG	1A	W0321	2132Z			34-55-11	ALL
	PERG	1A	W0321	2146Z			34-21-24	ALL
	PERG	1A	W0321	2148Z			22-11-51	ALL
	PERG	1A	W0321	2157Z			34-61-15	ALL
	PERG	1A	W0321	2159Z			32-64-31	ALL
	PERG	1A	W0321	2180Z			34-33-21	ALL
	PERG	1A	W0321	2229Z			34-57-11	ALL
	PERG	1A	W0321	2241Z			34-58-11	ALL
	PERG	1A	W0321	2244Z			31-35-04	ALL
	PERG	1A	W0321	2252Z			23-12-41	ALL
	PERG	1A	W0321	2253Z			23-12-41	ALL
	PERG	1A	W0321	2281Z			31-65-25	ALL
	PERG	1A	W0321	2305Z			34-61-23	ALL
	PERG	1A	W0321	2306Z			34-61-23	ALL
	PERG	1A	W0321	2344Z			22-11-51	ALL
	PERG	1A	W0321	2357Z			31-31-13	ALL
	PERG	1A	W0321	2359Z			31-31-13	ALL
	PERG	1A	W0321	2380Z			31-65-14	ALL
	PERG	1A	W0321	2414Z			36-11-14	ALL
	PERG	1A	W0321	2501Z			34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295D		***/*/***		**PLUG (continued)**				**ALL**
	PERG	1A	W0321	2516Z			31-31-13	ALL
	PERG	1A	W0321	2746Z			31-65-15	ALL
	PERG	1A	W0321	2747Z			31-65-15	ALL
	PERG	1A	W0321	2751Z			27-81-41	ALL
	PERG	1A	W0321	2819Z			22-11-51	ALL
D02295E		***/*/***		**PLUG**				**ALL**
	A01		W0321	3711R	24		27-48-11	ALL
	A02		W0321	3711Y	24		27-48-11	ALL
	A03		W0321	3711B	24		27-48-11	ALL
	A04		W0321	3005R	24		31-31-14	ALL
	A05		W0321	3005Y	24		31-31-14	ALL
	A06		W0321	3005B	24		31-31-14	ALL
	A07		W0321	3006R	24		31-31-14	ALL
	A08		W0321	3006Y	24		31-31-14	ALL
	A09		W0321	3006B	24		31-31-14	ALL
	A10		W0321	3706R	24		27-38-11	ALL
	A11		W0321	3706Y	24		27-38-11	ALL
	A12		W0321	3706B	24		27-38-11	ALL
	A13		W0321	3700R	24		27-18-11	ALL
	A14		W0321	3700Y	24		27-18-11	ALL
	A15		W0321	3700B	24		27-18-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0321	3008R	24		31-31-14	ALL
	B08		W0321	3008Y	24		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295E		*/*/*		**PLUG (continued)**				**ALL**
	B09		W0321	3008B	24		31-31-14	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0321	3705R	24		27-28-11	ALL
	B14		W0321	3705Y	24		27-28-11	ALL
	B15		W0321	3705B	24		27-28-11	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0321	0044	22		31-31-14	ALL
	C05		W0321	0045	22		31-31-14	ALL
	C06		W0321	0047	22		31-31-14	ALL
	C07		W0321	0051	22		31-31-14	ALL
	C08		W0321	0052	22		31-31-14	ALL
	C09		W0321	0049	22		31-31-14	ALL
	C10		W0321	0434	24		31-35-05	ALL
	C11		W0321	0435	24		31-35-05	ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295E		***/*/***		**PLUG (continued)**				**ALL**
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295E		*/*/*		**PLUG (continued)**				**ALL**
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0321	2301R	24		23-27-33	ALL
	H02		W0321	2301B	24		23-27-33	ALL
	H03		W0321	2021R	24		31-35-02	ALL
	H04		W0321	2021B	24		31-35-02	ALL
	H05		W0321	2008R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295E		***/*/***		**PLUG (continued)**				**ALL**
	H06		W0321	2008B	24		31-35-02	ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11		W0321	0015	24		31-35-01	ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0321	0085	24		31-31-15	ALL
	J02		W0321	0068	24		31-31-15	ALL
	J03	UNUSED						ALL
	J04		W0321	0558	24		31-31-15	ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0321	0193	24		31-31-17	ALL
	K02		W0321	0074	24		31-31-15	ALL
	K03		W0321	0071	24		31-31-15	ALL
	K04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295E	***/*/***		**PLUG (continued)**				**ALL**
K05		W0321	0568	24		23-12-41	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
PERG	1A	W0321	2008Z			31-35-02	ALL
PERG	1A	W0321	2021Z			31-35-02	ALL
PERG	1A	W0321	2301Z			23-27-33	ALL
D02295F	***/*/***		**PLUG**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295F		***/*/***		**PLUG (continued)**				**ALL**
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295F		*/*/*		**PLUG (continued)**				**ALL**
	F10	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	=1T		W0321	4000Z			46-13-11	ALL
	=2T	UNUSED						ALL
	1T-1		W0321	4000Y	24		46-13-11	ALL
	1T-2		W0321	4000R	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02295F		***/*/***		**PLUG (continued)**				**ALL**
	1T-3		W0321	4000G	24		46-13-11	ALL
	1T-4		W0321	4000B	24		46-13-11	ALL
	2T-1	UNUSED						ALL
	2T-2	UNUSED						ALL
	2T-3	UNUSED						ALL
	2T-4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02349	**P005-18/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2112	8008	20		27-32-11	ALL
5		W2112	8007	22		27-32-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D02351	**P005-18/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2218	8002	20		27-32-21	ALL
5		W2218	8001	22		27-32-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D02375	**J020-0B/ /**		**RELAY SOCKET**				**ALL**
1		W0072	2004R	24		23-31-06	ALL
2		W0072	2003B	24		23-31-06	ALL
3		W0072	0201	22		23-31-06	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02375		**J020-0B/ /**		**RELAY SOCKET (continued)**				**ALL**
	4		W0072	2005B	24		23-31-06	ALL
	5		W0072	2004B	24		23-31-06	ALL
	6		W0072	2003R	24		23-31-06	ALL
	7		W0072	0202	20		23-31-06	ALL
	8		W0072	2005R	24		23-31-06	ALL
	DED		W0072	2003Z			23-31-06	ALL
	DED		W0072	2004Z			23-31-06	ALL
	DED		W0072	2005Z			23-31-06	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02435	**P001-03/ /**		**PLUG**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0001	1589	20		22-14-11	ALL
4		W0001	1582	22		22-14-11	ALL
5		W0001	1583	22		22-14-11	ALL
6		W0001	1584	22		22-14-11	ALL
7		W0001	1585	22		22-14-11	ALL
8		W0001	1586	22		22-14-11	ALL
9		W0001	1587	22		22-14-11	ALL
10		W0001	1101	22		22-31-51	ALL
11		W0001	1588	22		22-14-11	ALL
12		W0003	1590	22		22-14-11	ALL
13		W0001	1580	22		22-14-11	ALL
14		W0001	1581	22		22-14-11	ALL
15		W0001	1100	22		22-14-11	ALL
S/R		W0001	1100Z			22-14-11	ALL
S/R		W0001	1101Z			22-31-51	ALL
S/R		W0001	1580Z			22-14-11	ALL
S/R		W0001	1581Z			22-14-11	ALL
S/R		W0001	1582Z			22-14-11	ALL
S/R		W0001	1583Z			22-14-11	ALL
S/R		W0001	1584Z			22-14-11	ALL
S/R		W0001	1585Z			22-14-11	ALL
S/R		W0001	1586Z			22-14-11	ALL
S/R		W0001	1587Z			22-14-11	ALL
S/R		W0001	1588Z			22-14-11	ALL
S/R		W0001	1589Z			22-14-11	ALL
S/R		W0003	1590Z			22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02437		**P001-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0001	1019	22		34-61-16	ALL
	4	UNUSED						ALL
	5		W0001	1022	22		34-61-16	ALL
	6		W0001	1578	22		22-14-11	ALL
	7		W0001	1579	22		22-14-11	ALL
	8		W0003	1002	22		34-61-16	ALL
	9		W0001	1020	22		34-61-16	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0001	1017	22		34-61-16	ALL
	15	UNUSED						ALL
	S/R		W0001	1017Z			34-61-16	ALL
	S/R		W0001	1019Z			34-61-16	ALL
	S/R		W0001	1020Z			34-61-16	ALL
	S/R		W0001	1022Z			34-61-16	ALL
	S/R		W0001	1578Z			22-14-11	ALL
	S/R		W0001	1579Z			22-14-11	ALL
	S/R		W0003	1002Z			34-61-16	ALL
D02439		**P003-01/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0003	1578	20		22-14-11	ALL
	4		W0003	1587	22		22-14-11	ALL
	5		W0003	1579	22		22-14-11	ALL
	6		W0003	1580	22		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02439	**P003-01/ /**		**PLUG (continued)**				**ALL**
7		W0003	1582	22		22-14-11	ALL
8		W0003	1581	22		22-14-11	ALL
9		W0003	1584	22		22-14-11	ALL
10		W0003	1601	22		22-31-51	ALL
11		W0001	1597	22		22-14-11	ALL
12		W0003	1583	22		22-14-11	ALL
13		W0003	1585	22		22-14-11	ALL
14		W0003	1586	22		22-14-11	ALL
15		W0003	1600	22		22-14-11	ALL
S/R		W0001	1597Z			22-14-11	ALL
S/R		W0003	1578Z			22-14-11	ALL
S/R		W0003	1579Z			22-14-11	ALL
S/R		W0003	1580Z			22-14-11	ALL
S/R		W0003	1581Z			22-14-11	ALL
S/R		W0003	1582Z			22-14-11	ALL
S/R		W0003	1583Z			22-14-11	ALL
S/R		W0003	1584Z			22-14-11	ALL
S/R		W0003	1585Z			22-14-11	ALL
S/R		W0003	1586Z			22-14-11	ALL
S/R		W0003	1587Z			22-14-11	ALL
S/R		W0003	1600Z			22-14-11	ALL
S/R		W0003	1601Z			22-31-51	ALL
D02441	**P003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0003	1003	22		34-61-16	ALL
4	UNUSED						ALL
5		W0001	1022	22		34-61-16	ALL
6		W0003	1588	22		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02441		**P003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	7		W0003	1589	22		22-14-11	ALL
	8		W0003	1004	22		34-61-16	ALL
	9		W0001	1023	22		34-61-16	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0001	1024	22		34-61-16	ALL
	15	UNUSED						ALL
	S/R		W0001	1022Z			34-61-16	ALL
	S/R		W0001	1023Z			34-61-16	ALL
	S/R		W0001	1024Z			34-61-16	ALL
	S/R		W0003	1003Z			34-61-16	ALL
	S/R		W0003	1004Z			34-61-16	ALL
	S/R		W0003	1588Z			22-14-11	ALL
	S/R		W0003	1589Z			22-14-11	ALL
D02473		**E001-02/ /**		**PLUG-COAX**				**ALL**
	=A1		W0121	003CX			34-53-31	ALL
	=C1		W0121	003CO			34-53-31	ALL
D02475		**E001-02/ /**		**PLUG-COAX**				**ALL**
	=A1		W0121	005CX			34-55-11	ALL
	=C1		W0121	005CO			34-55-11	ALL
D02477		**E001-02/ /**		**PLUG-COAX**				**ALL**
	=A1		W0121	002CX			34-53-31	ALL
	=C1		W0121	002CO			34-53-31	ALL
D02486		**P005-08/ /**		**PLUG-**				**ALL**
	1		W2216	5607	20		33-12-11	ALL
	2		W2216	5606	20		33-12-11	ALL
	3		W2508	5561	20		33-18-35	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02486	**P005-08/ /**		**PLUG- (continued)**				**ALL**
4		W2508	5559	20		33-18-35	ALL
5		W2214	0506	24		29-33-11	ALL
6		W2510	0514	24		29-34-11	ALL
7		W2510	0004	24		29-33-11	ALL
8	UNUSED						ALL
9		W2104	0504	22		29-11-11	ALL
10		W2104	0505	22		29-11-11	ALL
11		W2508	5745	20		33-18-35	ALL
12		W2508	5703	20		31-52-21	ALL
13		W2104	0521	22		29-11-12	ALL
14		W2104	0522	22		29-11-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT**				**ALL**
	A01		W0411	0046	24		23-31-04	ALL
	A02		W0411	2568B	24		23-11-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0411	0204	24		23-43-11	ALL
	A09		W0411	0075	22		23-12-21	ALL
	A10		W0411	2595R	24		23-15-13	ALL
	A11		W0411	0263	24		23-15-12	ALL
	A12		W0411	0029	24		23-51-51	ALL
	A13		W0411	2511R	24		34-55-11	ALL
	A14		W0411	2506B	24		34-32-11	ALL
	A15		W0411	2506R	24		34-32-11	ALL
	B01		W0411	0043	22		23-31-04	ALL
	B02		W0411	2568R	24		23-11-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0411	0202	22		23-43-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0411	2521B	24		23-12-21	ALL
	B10		W0411	2595B	24		23-15-13	ALL
	B11		W0411	2513B	24		34-57-11	ALL
	B12		W0411	2511B	24		34-55-11	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
B15	UNUSED						ALL
C01		W0411	2021R	22		23-31-04	ALL
C02		W0411	0416	24		23-11-21	ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06		W0411	0201	22		23-43-11	ALL
C07	UNUSED						ALL
C08		W0411	0203	22		23-43-11	ALL
C09		W0411	2521R	24		23-12-21	ALL
C10		W0411	0132	22		23-11-11	ALL
C11		W0411	2513R	24		34-57-11	ALL
C12	UNUSED						ALL
C13		W0411	0029	24		23-51-51	ALL
C14	UNUSED						ALL
C15		W0411	2508B	24		34-51-21	ALL
D01		W0411	2022R	22		23-31-04	ALL
D02		W0411	0417	24		23-11-21	ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06		W0411	0198	22		23-43-11	ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09		W0411	0200	22		23-43-11	ALL
D10		W0411	2545B	24		23-11-11	ALL
D11		W0411	2532R	24		34-41-11	ALL
D12		W0411	0032	22		34-51-41	ALL
D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	D14	UNUSED						ALL
	D15		W0411	2508R	24		34-51-21	ALL
	E01		W0411	0045	24		23-31-04	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06		W0411	0205	24		23-43-11	ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0411	0199	22		23-42-11	ALL
	E10		W0411	2545R	24		23-11-11	ALL
	E11		W0411	2504B	24		34-31-11	ALL
	E12		W0411	2504R	24		34-31-11	ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01		W0411	0044	24		23-31-04	ALL
	F02		W0411	0041	24		23-31-02	ALL
	F03		W0411	0360	24		23-11-11	ALL
	F04	UNUSED						ALL
	F05		W0411	0036	24		73-22-31	ALL
	F06		W0411	2519R	24		23-12-11	ALL
	F07		W0411	0088	22		23-12-31	ALL
	F08		W0411	2598R	24		23-15-13	ALL
	F09	UNUSED						ALL
	F10		W0411	0084	22		22-14-11	ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A		*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	F13		W0411	2528B	24		34-45-21	ALL
	F14		W0411	2528R	24		34-45-21	ALL
	F15	UNUSED						ALL
	G01		W0411	0042	24		23-31-04	ALL
	G02		W0411	0040	22		23-31-02	ALL
	G03		W0411	0357	24		23-11-11	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06		W0411	2519B	24		23-12-11	ALL
	G07		W0411	2530B	24		23-12-31	ALL
	G08		W0411	2598B	24		23-15-13	ALL
	G09		W0411	2505B	24		34-31-21	ALL
	G10		W0411	0028	24		23-51-51	ALL
	G11		W0411	0028	24		23-51-51	ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0411	0047	24		23-31-04	ALL
	H02		W0411	2020R	22		23-31-04	ALL
	H03		W0411	2544B	24		23-11-11	ALL
	H04	UNUSED						ALL
	H05		W0411	0039	22		23-31-02	ALL
	H06		W0411	0073	22		23-12-11	ALL
	H07		W0411	2530R	24		23-12-31	ALL
	H08		W0411	0264	24		23-15-12	ALL
	H09		W0411	2505R	24		34-31-21	ALL
	H10	UNUSED						ALL
	H11		W0411	0030	24		23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	H12		W0411	0089	22		23-27-31	ALL
	H13		W0411	0031	22		34-51-41	ALL
	H14	UNUSED						ALL
	H15		W0411	2527R	24		34-45-21	ALL
	J01	UNUSED						ALL
	J02		W0411	0338	22		23-31-04	ALL
	J03		W0411	2544R	24		23-11-11	ALL
	J04	UNUSED						ALL
	J05		W0411	0040	22		23-31-02	ALL
	J06		W0411	2569B	24		23-11-21	ALL
	J07		W0411	0174	22		23-11-21	ALL
	J08		W0411	2532B	24		34-41-11	ALL
	J09		W0411	0027	22		23-51-51	ALL
	J10		W0411	2512B	24		34-55-21	ALL
	J11		W0411	0030	24		23-51-51	ALL
	J12		W0411	0056	22		23-22-11	ALL
	J13		W0411	2507B	24		34-51-11	ALL
	J14	UNUSED						ALL
	J15		W0411	2527B	24		34-45-21	ALL
	K01	UNUSED						ALL
	K02		W0411	0039	22		23-31-02	ALL
	K03		W0411	0037	22		23-31-02	ALL
	K04	UNUSED						ALL
	K05		W0411	0035	24		73-22-31	ALL
	K06		W0411	2569R	24		23-11-21	ALL
	K07		W0411	2514B	24		34-57-21	ALL
	K08		W0411	2514R	24		34-57-21	ALL
	K09	UNUSED						ALL
	K10		W0411	2512R	24		34-55-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
K11	UNUSED						ALL
K12		W0411	0055	22		23-22-11	ALL
K13		W0411	2507R	24		34-51-11	ALL
K14		W0411	2510B	24		34-49-11	ALL
K15		W0411	2510R	24		34-49-11	ALL
PERG	1A	W0411	2504ZI			34-31-11	ALL
PERG	1A	W0411	2504ZO			34-31-11	ALL
PERG	1A	W0411	2505ZI			34-31-21	ALL
PERG	1A	W0411	2505ZO			34-31-21	ALL
PERG	1A	W0411	2506ZI			34-32-11	ALL
PERG	1A	W0411	2506ZO			34-32-11	ALL
PERG	1A	W0411	2507ZI			34-51-11	ALL
PERG	1A	W0411	2507ZO			34-51-11	ALL
PERG	1A	W0411	2508ZI			34-51-21	ALL
PERG	1A	W0411	2508ZO			34-51-21	ALL
PERG	1A	W0411	2510ZI			34-49-11	ALL
PERG	1A	W0411	2510ZO			34-49-11	ALL
PERG	1A	W0411	2511ZI			34-55-11	ALL
PERG	1A	W0411	2511ZO			34-55-11	ALL
PERG	1A	W0411	2512ZI			34-55-21	ALL
PERG	1A	W0411	2512ZO			34-55-21	ALL
PERG	1A	W0411	2513ZI			34-57-11	ALL
PERG	1A	W0411	2513ZO			34-57-11	ALL
PERG	1A	W0411	2514ZI			34-57-21	ALL
PERG	1A	W0411	2514ZO			34-57-21	ALL
PERG	1A	W0411	2519ZI			23-12-11	ALL
PERG	1A	W0411	2519ZO			23-12-11	ALL
PERG	1A	W0411	2521ZI			23-12-21	ALL
PERG	1A	W0411	2521ZO			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501A		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	PERG	1A	W0411	2527ZI			34-45-21	ALL
	PERG	1A	W0411	2527ZO			34-45-21	ALL
	PERG	1A	W0411	2528ZI			34-45-21	ALL
	PERG	1A	W0411	2528ZO			34-45-21	ALL
	PERG	1A	W0411	2530ZI			23-12-31	ALL
	PERG	1A	W0411	2530ZO			23-12-31	ALL
	PERG	1A	W0411	2532ZI			34-41-11	ALL
	PERG	1A	W0411	2532ZO			34-41-11	ALL
	PERG	1A	W0411	2544ZI			23-11-11	ALL
	PERG	1A	W0411	2544ZO			23-11-11	ALL
	PERG	1A	W0411	2545ZI			23-11-11	ALL
	PERG	1A	W0411	2545ZO			23-11-11	ALL
	PERG	1A	W0411	2568ZI			23-11-21	ALL
	PERG	1A	W0411	2568ZO			23-11-21	ALL
	PERG	1A	W0411	2569ZI			23-11-21	ALL
	PERG	1A	W0411	2569ZO			23-11-21	ALL
	PERG	1A	W0411	2595Z			23-15-13	ALL
	PERG	1A	W0411	2598Z			23-15-13	ALL
D02501B		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT**				**ALL**
	A01		W0411	2016R	24		23-31-02	ALL
	A02		W0411	0005	24		23-51-51	ALL
	A03		W0411	2518R	24		23-12-11	ALL
	A04		W0411	2017R	24		23-31-02	ALL
	A05		W0411	2529R	24		23-12-31	ALL
	A06		W0411	2017B	24		23-31-02	ALL
	A07		W0411	0414	24		23-11-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
A11	UNUSED						ALL
A12		W0411	3004R	24		23-51-21	ALL
A13		W0411	3004B	24		23-51-21	ALL
A14	UNUSED						ALL
A15		W0411	0021	22		23-51-51	ALL
B01		W0411	2016B	24		23-31-02	ALL
B02	UNUSED						ALL
B03		W0411	2518B	24		23-12-11	ALL
B04		W0411	2520B	24		23-12-21	ALL
B05		W0411	2529B	24		23-12-31	ALL
B06		W0411	0357	24		23-11-11	ALL
B07		W0411	0416	24		23-11-21	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0411	2001R	24		23-51-11	ALL
B15	UNUSED						ALL
C01		W0411	0026	22		23-51-51	ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04		W0411	2520R	24		23-12-21	ALL
C05		W0411	2018R	24		23-31-02	ALL
C06		W0411	0358	24		23-11-11	ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09		W0411	0005	24		23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	C10	UNUSED						ALL
	C11		W0411	2006R	24		23-51-21	ALL
	C12	UNUSED						ALL
	C13		W0411	4253B	24		23-51-21	ALL
	C14		W0411	0415	24		23-11-21	ALL
	C15		W0411	2001B	24		23-51-11	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0411	2639R	24		23-15-12	ALL
	D05		W0411	2018B	24		23-31-02	ALL
	D06		W0411	1013	24		23-41-11	ALL
	D07		W0411	2027B	24		23-41-11	ALL
	D08		W0411	2003R	24		23-51-11	ALL
	D09		W0411	2007R	24		23-51-31	ALL
	D10		W0411	2007B	24		23-51-31	ALL
	D11		W0411	2004R	24		23-51-21	ALL
	D12		W0411	2004B	24		23-51-21	ALL
	D13		W0411	4253R	24		23-51-21	ALL
	D14		W0411	0359	24		23-11-11	ALL
	D15		W0411	2002R	24		23-51-11	ALL
	E01		W0411	0018	22		23-51-51	ALL
	E02		W0411	0023	22		23-51-51	ALL
	E03	UNUSED						ALL
	E04		W0411	2639B	24		23-15-12	ALL
	E05		W0411	2641B	24		23-15-12	ALL
	E06		W0411	2641R	24		23-15-12	ALL
	E07		W0411	2027R	24		23-41-11	ALL
	E08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
E09	UNUSED						ALL
E10	UNUSED						ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14		W0411	2002B	24		23-51-11	ALL
E15		W0411	4251G	24		23-51-11	ALL
F01		W0411	0019	22		23-51-51	ALL
F02		W0411	0022	22		23-51-51	ALL
F03	UNUSED						ALL
F04		W0411	2523R	24		23-51-51	ALL
F05		W0411	2523B	24		23-51-51	ALL
F06		W0411	3503Y	24		23-41-11	ALL
F07		W0411	3006Y	24		23-42-12	ALL
F08		W0411	2008R	24		23-51-31	ALL
F09		W0411	2008B	24		23-51-31	ALL
F10		W0411	4258R	24		23-51-31	ALL
F11	UNUSED						ALL
F12		W0411	4253Y	24		23-51-21	ALL
F13		W0411	4253G	24		23-51-21	ALL
F14		W0411	4251Y	24		23-51-11	ALL
F15	UNUSED						ALL
G01		W0411	0017	22		23-51-51	ALL
G02		W0411	0024	22		23-51-51	ALL
G03	UNUSED						ALL
G04		W0411	2524R	24		23-51-51	ALL
G05		W0411	2524B	24		23-51-51	ALL
G06		W0411	3503R	24		23-41-11	ALL
G07		W0411	3503B	24		23-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	G08		W0411	3006B	24		23-42-12	ALL
	G09		W0411	3006R	24		23-42-12	ALL
	G10		W0411	4258B	24		23-51-31	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14		W0411	4251B	24		23-51-11	ALL
	G15		W0411	3002B	24		23-51-11	ALL
	H01		W0411	0020	22		23-51-51	ALL
	H02		W0411	0025	22		23-51-51	ALL
	H03	UNUSED						ALL
	H04		W0411	2525R	24		23-51-51	ALL
	H05		W0411	2525B	24		23-51-51	ALL
	H06		W0411	2015R	24		23-31-02	ALL
	H07		W0411	2015B	24		23-31-02	ALL
	H08		W0411	4258Y	24		23-51-31	ALL
	H09		W0411	4258G	24		23-51-31	ALL
	H10		W0411	3005R	24		23-51-31	ALL
	H11		W0411	3005B	24		23-51-31	ALL
	H12		W0411	2005R	24		23-51-21	ALL
	H13		W0411	2005B	24		23-51-21	ALL
	H14		W0411	4251R	24		23-51-11	ALL
	H15		W0411	3002R	24		23-51-11	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04		W0411	3002Y	24		23-51-11	ALL
	J05		W0411	0004	22		23-51-11	ALL
	J06		W0411	3004Y	24		23-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
J07		W0411	0010	22		23-51-21	ALL
J08		W0411	3005Y	24		23-51-31	ALL
J09		W0411	0015	22		23-51-31	ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0411	2501R	24		23-51-11	ALL
K02		W0411	2501B	24		23-51-11	ALL
K03		W0411	0003	22		23-51-11	ALL
K04		W0411	0001	22		23-51-11	ALL
K05		W0411	0002	22		23-51-11	ALL
K06		W0411	2502R	24		23-51-21	ALL
K07		W0411	2502B	24		23-51-21	ALL
K08		W0411	0009	22		23-51-21	ALL
K09		W0411	0007	22		23-51-21	ALL
K10		W0411	0008	22		23-51-21	ALL
K11		W0411	2503R	24		23-51-31	ALL
K12		W0411	2503B	24		23-51-31	ALL
K13		W0411	0014	22		23-51-31	ALL
K14		W0411	0012	22		23-51-31	ALL
K15		W0411	0013	22		23-51-31	ALL
DED		W0411	2001Z			23-51-11	ALL
DED		W0411	2004Z			23-51-21	ALL
DED		W0411	2007Z			23-51-31	ALL
DED		W0411	2027Z			23-41-11	ALL
DED		W0411	2523Z			23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501B		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	DED		W0411	2524Z			23-51-51	ALL
	DED		W0411	2525Z			23-51-51	ALL
	DED		W0411	3004Z			23-51-21	ALL
	PERG	1A	W0411	1013Z			23-41-11	ALL
	PERG	1A	W0411	2002Z			23-51-11	ALL
	PERG	1A	W0411	2005Z			23-51-21	ALL
	PERG	1A	W0411	2008Z			23-51-31	ALL
	PERG	1A	W0411	2501Z			23-51-11	ALL
	PERG	1A	W0411	2502Z			23-51-21	ALL
	PERG	1A	W0411	2503Z			23-51-31	ALL
	PERG	1A	W0411	2518ZI			23-12-11	ALL
	PERG	1A	W0411	2518ZO			23-12-11	ALL
	PERG	1A	W0411	2520ZI			23-12-21	ALL
	PERG	1A	W0411	2520ZO			23-12-21	ALL
	PERG	1A	W0411	2529ZI			23-12-31	ALL
	PERG	1A	W0411	2529ZO			23-12-31	ALL
	PERG	1A	W0411	2639Z			23-15-12	ALL
	PERG	1A	W0411	2641Z			23-15-12	ALL
	PERG	1A	W0411	3002Z			23-51-11	ALL
	PERG	1A	W0411	3005Z			23-51-31	ALL
	PERG	1A	W0411	3006Z			23-42-12	ALL
	PERG	1A	W0411	3503Z			23-41-11	ALL
	PERG	1A	W0411	4251Z			23-51-11	ALL
	PERG	1A	W0411	4253Z			23-51-21	ALL
	PERG	1A	W0411	4258Z			23-51-31	ALL
D02501C		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501C	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501C		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02501C	*/*/*		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02501C		***/*/***		**PLUG-REMOTE ELECTRONIC UNIT (continued)**				**ALL**
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
D02529		**430/305/R005**		**PLUG - ATC TOP ANTENNA**				**ALL**
	=A1		W3895	001CX			34-53-31	ALL
	=C1		W3895	001CO			34-53-31	ALL
D02555A		***/*/***		**PLUG-SELCAL**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02555A	*/*/*		**PLUG-SELCAL (continued)**				**ALL**
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02555A		***/*/***		**PLUG-SELCAL (continued)**				**ALL**
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D02555B		***/*/***		**PLUG-SELCAL**				**ALL**
	A01		W0411	0063	24		23-22-11	ALL
	A02		W0411	0067	24		23-22-11	ALL
	A03		W0411	2517R	24		23-22-11	ALL
	A04		W0411	0054	22		23-22-11	ALL
	A05		W0411	2509R	24		23-22-11	ALL
	A06		W0411	2522R	24		23-22-11	ALL
	A07		W0411	0059	24		23-22-11	ALL
	A08		W0411	0057	22		23-22-11	ALL
	A09	UNUSED						ALL
	A10		W0411	0100	24		23-22-11	ALL
	A11		W0411	0104	24		23-22-11	ALL
	A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02555B	*/*/*		**PLUG-SELCAL (continued)**				**ALL**
A13		W0411	0108	24		23-22-11	ALL
A14	UNUSED						ALL
A15		W0411	0112	24		23-22-11	ALL
B01		W0411	0064	24		23-22-11	ALL
B02		W0411	2516R	24		23-22-11	ALL
B03		W0411	2517B	24		23-22-11	ALL
B04		W0411	0053	22		23-22-11	ALL
B05		W0411	2509B	24		23-22-11	ALL
B06		W0411	2522B	24		23-22-11	ALL
B07		W0411	0060	24		23-22-11	ALL
B08		W0411	2543R	24		23-22-11	ALL
B09		W0411	0118	24		23-22-11	ALL
B10		W0411	0101	24		23-22-11	ALL
B11		W0411	0105	24		23-22-11	ALL
B12	UNUSED						ALL
B13		W0411	0109	24		23-22-11	ALL
B14	UNUSED						ALL
B15		W0411	0113	24		23-22-11	ALL
C01		W0411	0065	24		23-22-11	ALL
C02		W0411	2516B	24		23-22-11	ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07		W0411	0061	24		23-22-11	ALL
C08		W0411	2543B	24		23-22-11	ALL
C09		W0411	0116	24		23-22-11	ALL
C10		W0411	0102	24		23-22-11	ALL
C11		W0411	0106	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02555B		***/*/***		**PLUG-SELCAL (continued)**				**ALL**
	C12	UNUSED						ALL
	C13		W0411	0110	24		23-22-11	ALL
	C14	UNUSED						ALL
	C15		W0411	0114	24		23-22-11	ALL
	D01		W0411	0066	24		23-22-11	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06		W0411	0058	24		23-22-11	ALL
	D07		W0411	0062	24		23-22-11	ALL
	D08	UNUSED						ALL
	D09		W0411	0117	24		23-22-11	ALL
	D10		W0411	0103	24		23-22-11	ALL
	D11		W0411	0107	24		23-22-11	ALL
	D12	UNUSED						ALL
	D13		W0411	0111	24		23-22-11	ALL
	D14	UNUSED						ALL
	D15		W0411	0115	24		23-22-11	ALL
	PERG	1A	W0411	2509ZI			23-22-11	ALL
	PERG	1A	W0411	2509ZO			23-22-11	ALL
	PERG	1A	W0411	2516ZI			23-22-11	ALL
	PERG	1A	W0411	2516ZO			23-22-11	ALL
	PERG	1A	W0411	2517ZI			23-22-11	ALL
	PERG	1A	W0411	2517ZO			23-22-11	ALL
	PERG	1A	W0411	2522ZI			23-22-11	ALL
	PERG	1A	W0411	2522ZO			23-22-11	ALL
	PERG	1A	W0411	2543ZI			23-22-11	ALL
	PERG	1A	W0411	2543ZO			23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02555C	***/*/***		**PLUG-SELCAL**				**ALL**
1	UNUSED						ALL
2		W0411	0049	22		23-22-11	ALL
3		W0411	0050	22		23-22-11	ALL
4		W0411	0051	22		23-22-11	ALL
5	UNUSED						ALL
=C1	UNUSED						ALL
=C5	UNUSED						ALL
D02564	**725/197/L021**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W7126	2203R	20		32-42-11	ALL
3		W7126	2203B	20		32-42-11	ALL
S/R		W7126	2203Z			32-42-11	ALL
D02566	**725/193/L018**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W7126	2204R	20		32-42-11	ALL
3		W7126	2204B	20		32-42-11	ALL
S/R		W7126	2204Z			32-42-11	ALL
D02570	**713/198/L000**		**PLUG- CONDUCTIVE**				**ALL**
1		W8230	2205R	20		32-42-11	ALL
2		W8230	2205B	20		32-42-11	ALL
3		W8230	0501	18		32-42-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
DED		W8230	2205Z			32-42-11	ALL
D02572	**716/199/L004**		**PLUG- CONDUCTIVE**				**ALL**
1		W8230	2202R	20		32-42-11	ALL
2		W8230	2202B	20		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02572		**716/199/L004**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	3		W8230	1001	20		31-31-15	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	DED		W8230	1001Z			31-31-15	ALL
	DED		W8230	2202Z			32-42-11	ALL
D02574		**714/196/L003**		**PLUG- CONDUCTIVE**				**ALL**
	1		W8230	2203R	20		32-42-11	ALL
	2		W8230	2203B	20		32-42-11	ALL
	3	UNUSED						ALL
	DED		W8230	2203Z			32-42-11	ALL
D02576		**712/197/L007**		**PLUG- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W8230	2204R	20		32-42-11	ALL
	3		W8230	2204B	20		32-42-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	DED		W8230	2204Z			32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02621		**178/212/R014**		**RCPT - (TNC) FEED THRU (42 DEG KEY)**				**ALL**
	=A1	UNUSED						ALL
	=C1	UNUSED						ALL
D02623		**178/ /**		**RCPT - (TNC) FEED THRU (42 DEG KEY)**				**ALL**
	=A1	UNUSED						ALL
	=C1	UNUSED						ALL
D02625		**178/212/R010**		**RCPT - (TNC) FEED THRU (102 DEG KEY)**				**ALL**
	=A1	UNUSED						ALL
	=C1	UNUSED						ALL
D02627		**178/ /**		**RCPT - (TNC) FEED THRU (102 DEG KEY)**				**ALL**
	=A1	UNUSED						ALL
	=C1	UNUSED						ALL
D02639A		***/*/***		**PLUG - PA AMP**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02639A		***/*/***		**PLUG - PA AMP (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02639A		*/*/*		**PLUG - PA AMP (continued)**				**ALL**
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D02639B		*/*/*		**PLUG - PA AMP**				**ALL**
	A01		W0131	2024R	24		23-31-01	ALL
	A02		W0131	2023R	24		23-31-01	ALL
	A03	UNUSED						ALL
	A04		W0131	2026R	24		23-31-06	ALL
	A05		W0131	2011R	24		23-31-06	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0131	2004R	24		23-31-02	ALL
	A10		W0131	0017	24		23-31-02	ALL
	A11		W0131	0097	22		33-27-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0131	2008R	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02639B		***/*/***		**PLUG - PA AMP (continued)**				**ALL**
	A15		W0131	2007R	22		23-31-02	ALL
	B01		W0131	2024B	24		23-31-01	ALL
	B02		W0131	2023B	24		23-31-01	ALL
	B03	UNUSED						ALL
	B04		W0131	2026B	24		23-31-06	ALL
	B05		W0131	2011B	24		23-31-06	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0131	2004B	24		23-31-02	ALL
	B10		W0131	0017	24		23-31-02	ALL
	B11		W0131	0043	22		23-42-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0131	2008B	22		23-31-02	ALL
	B15		W0131	2007B	22		23-31-02	ALL
	C01		W0131	0015	24		23-31-01	ALL
	C02		W0131	0021	24		23-31-01	ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09		W0131	0019	22		23-31-02	ALL
	C10	UNUSED						ALL
	C11		W0131	0096	24		33-25-11	ALL
	C12	UNUSED						ALL
	C13		W0131	2005R	24		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02639B	***/*/***		**PLUG - PA AMP (continued)**				**ALL**
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04		W0131	0138	22		23-31-06	ALL
D05		W0131	0027	22		23-31-06	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09		W0131	0392	22		23-31-06	ALL
D10	UNUSED						ALL
D11		W0131	0095	24		33-25-11	ALL
D12	UNUSED						ALL
D13		W0131	2005B	24		23-31-02	ALL
D14	UNUSED						ALL
D15	UNUSED						ALL
DED		W0131	2011Z			23-31-06	ALL
DED		W0131	2026Z			23-31-06	ALL
D02639C	***/*/***		**PLUG - PA AMP**				**ALL**
1	UNUSED						ALL
2		W0131	0013	18		23-31-01	ALL
3	UNUSED						ALL
4		W0131	0016	18		23-31-01	ALL
5	UNUSED						ALL
=C1	UNUSED						ALL
=C5	UNUSED						ALL
D02649	**P008-54/ /**		**PLUG**				**ALL**
A		W2805	2503R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02649		**P008-54/ /**		**PLUG (continued)**				**ALL**
	B		W2805	2503B	24		SPARE	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E		W2805	2501R	24		31-33-01	ALL
	F		W2805	2501B	24		31-33-01	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L		W2805	0004	20		31-33-01	ALL
	M		W2805	0008	20		33-11-41	ALL
	N		W2805	0002	20		31-33-01	ALL
	P	UNUSED						ALL
	R		W2805	0001	22		31-33-01	ALL
	S	UNUSED						ALL
	T		W2805	2505R	24		31-65-16	ALL
	U		W2805	2505B	24		31-65-16	ALL
	V		W2805	2506R	24		31-65-26	ALL
	W		W2805	2506B	24		31-65-26	ALL
	X		W2805	2504B	24		23-27-32	ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
			W2805	0003	20		31-33-01	ALL
			W2805	2501Z			31-33-01	ALL
			W2805	2502Z			31-33-01	ALL
			W2805	2503Z			SPARE	ALL
			W2805	2504Z			23-27-32	ALL
			W2805	2505Z			31-65-16	ALL
			W2805	2506Z			31-65-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02649		**P008-54/ /**		**PLUG (continued)**				**ALL**
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-		W2805	0007	20		33-11-41	ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-		W2805	2502R	24		31-33-01	ALL
	I-		W2805	2502B	24		31-33-01	ALL
	J-		W2805	2504R	24		23-27-32	ALL
	K-	UNUSED						ALL
	M-	UNUSED						ALL
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-	UNUSED						ALL
D02650		**P001-09/ /**		**PLUG-- CONDUCTIVE**				**ALL**
	1		W0001	0221	20		33-11-32	ALL
	2		W0001	0222	20		33-11-32	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0001	3011R	24		31-65-11	ALL
	6		W0001	3011B	24		31-65-11	ALL
	7		W0001	3011Y	24		31-65-11	ALL
	8		W0001	3012R	24		31-65-11	ALL
	9		W0001	3013R	24		31-65-11	ALL
	10		W0001	3013B	24		31-65-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02650		**P001-09/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	11		W0001	3013Y	24		31-65-11	ALL
	12		W0001	3014R	24		31-65-11	ALL
	13		W0001	3014B	24		31-65-11	ALL
	14		W0001	3014Y	24		31-65-11	ALL
	15		W0001	0193	16		33-11-11	ALL
	16		W0003	3508Y	24		31-65-23	ALL
	17		W0003	3508B	24		31-65-23	ALL
	18		W0003	3508R	24		31-65-23	ALL
	19		W0001	0194	14		33-11-11	ALL
	20		W0003	1554	22		31-65-23	ALL
	21		W0001	3012B	24		31-65-11	ALL
	22		W0001	3012Y	24		31-65-11	ALL
	23		W0001	0195	14		33-11-11	ALL
	24		W0001	3008Y	24		31-65-13	ALL
	25		W0001	3008B	24		31-65-13	ALL
	26		W0001	3008R	24		31-65-13	ALL
	27	UNUSED						ALL
	28		W0001	1554	22		31-65-13	ALL
	S/R		W0001	1554Z			31-65-13	ALL
	S/R		W0001	3008Z			31-65-13	ALL
	S/R		W0001	3011Z			31-65-11	ALL
	S/R		W0001	3012Z			31-65-11	ALL
	S/R		W0001	3013Z			31-65-11	ALL
	S/R		W0001	3014Z			31-65-11	ALL
	S/R		W0003	1554Z			31-65-23	ALL
	S/R		W0003	3508Z			31-65-23	ALL
D02664		**671/171/L019**		**PLUG-**				**ALL**
	1	10	W6128	0504	10		29-11-12	ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02664	**671/171/L019**		**PLUG- (continued)**				**ALL**
3	10	W6128	0505	10		29-11-12	ALL
4		W6128	0503	18		29-11-12	ALL
5		W6128	0501	18		29-11-12	ALL
6	10	W6128	0506	10		29-11-12	ALL
7		W6128	0502	18		29-34-11	ALL
8	UNUSED						ALL
D02666	**674/171/R004**		**PLUG-**				**ALL**
1	10	W5230	0504	10		29-11-12	ALL
2	UNUSED						ALL
3	10	W5230	0505	10		29-11-12	ALL
4		W5230	0503	18		29-11-12	ALL
5		W5230	0501	18		29-11-12	ALL
6	10	W5230	0506	10		29-11-12	ALL
7		W5230	0502	18		29-34-11	ALL
8	UNUSED						ALL
D02668	**P092-00/ /**		**PLUG-SYS A ELEC HYD PUMP GND FAULT DET**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02670		**P091-00/ /**		**PLUG-SYS B ELEC HYD PUMP GND FAULT DET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D02674		**678/194/R043**		**PLUG-**				**ALL**
	1		W8224	0502	20		29-31-11	ALL
	2		W8224	0503	20		29-31-11	ALL
	3		W8224	0504	20		29-31-11	ALL
	4		W8224	0505	20		29-23-11	ALL
	5		W8224	0501	20		29-23-11	ALL
	6		W8224	0510	20		29-31-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D02676		**724/162/R010**		**PLUG- CONDUCTIVE**				**ALL**
	1		W8524	0501	18		29-32-11	ALL
	2		W8524	2001B	18		29-32-11	ALL
	3		W8524	2001R	18		29-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02680	**666/171/L043**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W7522	0506	20		29-33-11	ALL
3		W7522	0507	20		29-33-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D02682	**666/181/R022**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W8222	0501	20		29-33-11	ALL
3		W8222	0511	20		29-33-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D02684	**666/170/L047**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W7522	0505	20		29-33-11	ALL
3		W7522	0504	20		29-33-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D02686	**666/181/R027**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W8222	0507	20		29-33-11	ALL
3		W8222	0506	20		29-33-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D02688	**674/165/L010**		**PLUG-**				**ALL**
A		W6128	0508	18		29-34-11	ALL
B		W6128	0507	18		29-34-11	ALL
D02690	**672/159/R007**		**PLUG-**				**ALL**
A		W5230	0508	18		29-34-11	ALL
B		W5230	0507	18		29-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02701		**316/161/L-23**		**PLUG-COAX**				**ALL**
	=A1		W5363	001CX			34-53-31	ALL
	=C1		W5363	001CO			34-53-31	ALL
D02703		**316/162/L023**		**PLUG-COAX**				**ALL**
	=A1		W3895	001CX			34-53-31	ALL
	=C1		W3895	001CO			34-53-31	ALL
D02705		**E001-05/ /**		**PLUG-COAX**				**ALL**
	=A1		W0151	001CX			34-53-31	ALL
	=C1		W0151	001CO			34-53-31	ALL
D02707		**314/161/L-23**		**PLUG-COAX**				**ALL**
	=A1		W5181	001CX			34-53-31	ALL
	=C1		W5181	001CO			34-53-31	ALL
D02709		**314/161/L23**		**PLUG-COAX**				**ALL**
	=A1		W5039	001CX			34-53-31	ALL
	=C1		W5039	001CO			34-53-31	ALL
D02711		**E001-05/ /**		**PLUG-COAX**				**ALL**
	=A1		W0151	004CX			34-53-31	ALL
	=C1		W0151	004CO			34-53-31	ALL
D02743A		***/*/***		**PLUG**				**ALL**
	1		W0111	001CX			34-45-21	ALL
	2		W0111	002CX			34-45-21	ALL
	3		W0111	003CX			34-45-21	ALL
	4		W0111	004CX			34-45-21	ALL
	=C1		W0111	001CO			34-45-21	ALL
	=C2		W0111	002CO			34-45-21	ALL
	=C3		W0111	003CO			34-45-21	ALL
	=C4		W0111	004CO			34-45-21	ALL
D02743B		***/*/***		**PLUG**				**ALL**
	1		W0111	005CX			34-45-21	ALL
	2		W0111	006CX			34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743B		*/*/*		**PLUG (continued)**				**ALL**
	3		W0111	007CX			34-45-21	ALL
	4		W0111	008CX			34-45-21	ALL
	=C1		W0111	005CO			34-45-21	ALL
	=C2		W0111	006CO			34-45-21	ALL
	=C3		W0111	007CO			34-45-21	ALL
	=C4		W0111	008CO			34-45-21	ALL
D02743C		*/*/*		**PLUG**				**ALL**
	1		W0111	0066	20		34-45-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0111	0067	22		34-45-11	ALL
	8		W0111	0068	22		34-45-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0111	0069	22		34-45-11	ALL
	12	DN	W0111	009CX			34-53-31	ALL
	13	UNUSED						ALL
	=C12		W0111	009CO			34-53-31	ALL
	=C13	UNUSED						ALL
D02743D		*/*/*		**PLUG**				**ALL**
	=A	UNUSED						ALL
	=B	UNUSED						ALL
D02743E		*/*/*		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		***/*/***		**PLUG (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0111	2098R	24		34-21-13	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0111	2072R	24		34-45-21	ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0111	2098B	24		34-21-13	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0111	2072B	24		34-45-21	ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		*/*/*		**PLUG (continued)**				**ALL**
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0111	2069R	24		34-45-11	ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14		W0111	0232	24		34-45-11	ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0111	2069B	24		34-45-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		***/*/***		**PLUG (continued)**				**ALL**
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07		W0111	0229	22		34-45-11	ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13		W0111	0231	24		34-45-11	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03		W0111	2175R	24		34-45-21	ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0111	0227	22		34-45-11	ALL
	F14		W0111	2071R	24		34-45-21	ALL
	F15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		*/*/*		**PLUG (continued)**				**ALL**
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03		W0111	2175B	24		34-45-21	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07		W0111	2058R	24		34-45-11	ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14		W0111	2071B	24		34-45-21	ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06		W0111	0254	24		34-45-21	ALL
	H07		W0111	2058B	24		34-45-11	ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13		W0111	2065R	24		34-33-11	ALL
	H14		W0111	2073R	24		34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		***/*/***		**PLUG (continued)**				**ALL**
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06		W0111	0255	24		34-45-21	ALL
	J07		W0111	0230	22		34-45-11	ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13		W0111	2065B	24		34-33-11	ALL
	J14		W0111	2073B	24		34-45-21	ALL
	J15		W0111	2070R	24		34-45-21	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05		W0111	0228	24		34-45-11	ALL
	K06		W0111	0256	24		34-45-21	ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743E		***/*/***		**PLUG (continued)**				**ALL**
	K14	UNUSED						ALL
	K15		W0111	2070B	24		34-45-21	ALL
	DED		W0111	2065Z			34-33-11	ALL
	DED		W0111	2069Z			34-45-11	ALL
	DED		W0111	2098Z			34-21-13	ALL
	DED		W0111	2175ZI			34-45-21	ALL
D02743F		**E001-01/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0111	0235	24		34-45-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0111	0494	24		34-41-11	ALL
	B06	UNUSED						ALL
	B07		W0111	0237	24		34-45-21	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743F		**E001-01/*/***		**PLUG (continued)**				**ALL**
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0111	0236	24		34-45-21	ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0111	2004R	24		34-33-21	ALL
	D04	UNUSED						ALL
	D05		W0111	0472	24		34-49-11	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03		W0111	2004B	24		34-33-21	ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08		W0111	0238	24		34-45-21	ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	F01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02743F		**E001-01/*/***		**PLUG (continued)**				**ALL**
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02743F		**E001-01/*/***		**PLUG (continued)**				**ALL**
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07		W0111	0239	24		34-45-21	ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	DED		W0111	2004Z			34-33-21	ALL
D02745		**387/302/R005**		**PLUG-COAX**				**ALL**
	=A1		W4009	001CX			34-45-21	ALL
	=C1		W4009	001CO			34-45-21	ALL
D02747		**385/302/R005**		**PLUG-COAX**				**ALL**
	=A1		W4009	002CX			34-45-21	ALL
	=C1		W4009	002CO			34-45-21	ALL
D02749		**386/302/R005**		**PLUG-COAX**				**ALL**
	=A1		W4009	003CX			34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02749	**386/302/R005**		**PLUG-COAX (continued)**				**ALL**
=C1		W4009	003CO			34-45-21	ALL
D02751	**385/302/R006**		**PLUG-COAX**				**ALL**
=A1		W4009	004CX			34-45-21	ALL
=C1		W4009	004CO			34-45-21	ALL
D02753	**305/150/R001**		**PLUG-COAX**				**ALL**
=A1		W5001	001CX			34-45-21	ALL
=C1		W5001	001CO			34-45-21	ALL
D02755	**305/150/R002**		**PLUG-COAX**				**ALL**
=A1		W5001	002CX			34-45-21	ALL
=C1		W5001	002CO			34-45-21	ALL
D02757	**305/150/R001**		**PLUG-COAX**				**ALL**
=A1		W5001	003CX			34-45-21	ALL
=C1		W5001	003CO			34-45-21	ALL
D02759	**305/150/L001**		**PLUG-COAX**				**ALL**
=A1		W5001	004CX			34-45-21	ALL
=C1		W5001	004CO			34-45-21	ALL
D02775	**J022-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0076	0053	22		23-22-11	ALL
A2		W0076	0054	22		23-22-11	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
X1		W0076	0051	22		23-22-11	ALL
X2		W0076	0052	22		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02849		**304/156/L6**		**PLUG-COAX**				**ALL**
	=A1		W0151	005CX			34-55-21	ALL
	=C1		W0151	005CO			34-55-21	ALL
D02851		**304/158/L8**		**PLUG-COAX**				**ALL**
	=A1		W0151	003CX			34-53-31	ALL
	=C1		W0151	003CO			34-53-31	ALL
D02853		**304/156/L9**		**PLUG-COAX**				**ALL**
	=A1		W0151	002CX			34-53-31	ALL
	=C1		W0151	002CO			34-53-31	ALL
D02860		**674/158/L002**		**PLUG-CONDUCTIVE**				**ALL**
	1		W8122	1005	20		29-23-11	ALL
	2		W8122	0509	20		29-23-11	ALL
	3		W8122	1006	20		29-23-11	ALL
	4		W8122	0508	20		29-23-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W8122	0507	20		29-23-11	ALL
	10	UNUSED						ALL
	11		W8122	1008	20		29-23-11	ALL
	12	UNUSED						ALL
	S/R		W8122	1005Z			29-23-11	ALL
	S/R		W8122	1006Z			29-23-11	ALL
	S/R		W8122	1008Z			29-23-11	ALL
D02864		**251/203/L035**		**PLUG-NOSE STEERING ACT**				**ALL**
	1		W5100	0507	22		32-51-11	ALL
	2	UNUSED						ALL
	3		W5100	0506	22		32-51-11	ALL
	4		W5100	0509	22		32-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02864	**251/203/L035**		**PLUG-NOSE STEERING ACT (continued)**				**ALL**
5		W5100	0508	22		32-51-11	ALL
D02866	**J019-00/ /**		**PLUG-DIM MODULE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W5514	5515	20		33-18-61	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W5514	0521	24		32-44-11	ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02866		**J019-00/ /**		**PLUG-DIM MODULE (continued)**				**ALL**
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W5514	5512	20		33-18-61	ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46		W5514	5504	20		33-18-21	ALL
	47		W5514	5563	20		22-11-12	ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02870	**703/201/L027**		**PLUG-CONDUCTIVE**				**ALL**
1		W7126	1501	18		31-31-15	ALL
2		W7126	0502	18		31-31-15	ALL
3	UNUSED						ALL
4		W7126	1001	18		32-41-11	ALL
5		W7126	0504	18		32-41-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
S/R		W7126	1001Z			32-41-11	ALL
S/R		W7126	1501Z			31-31-15	ALL
D02872	**688/191/R065**		**PLUG-CONDUCTIVE**				**ALL**
1		W8228	2201R	20		32-41-11	ALL
2		W8228	2201B	20		32-41-11	ALL
S/R		W8228	2201Z			32-41-11	ALL
D02874	**688/191/L066**		**PLUG-CONDUCTIVE**				**ALL**
1		W7026	2201R	18		32-41-11	ALL
2		W7026	2201B	18		32-41-11	ALL
S/R		W7026	2201Z			32-41-11	ALL
D02875	**P061-01/ /**		**PLUG**				**ALL**
1		W0041	2541R	24		31-32-15	ALL
2		W0041	2541B	24		31-32-15	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0041	2542R	24		31-32-15	ALL
9		W0041	2542B	24		31-32-15	ALL
10		W0041	2502R	22		31-32-15	ALL
11		W0041	2502B	22		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02875		**P061-01/ /**		**PLUG (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0041	0012	22		31-32-15	ALL
	19		W0041	0013	22		31-32-15	ALL
	20		W0041	0001	22		31-32-15	ALL
	21		W0041	0009	22		31-32-15	ALL
	22		W0041	0002	22		31-32-15	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02875	**P061-01/ /**		**PLUG (continued)**				**ALL**
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0041	0115	22		31-32-15	ALL
51		W0041	0116	22		31-32-15	ALL
52		W0041	0117	22		31-32-15	ALL
53	UNUSED						ALL
DED		W0041	2502Z			31-32-15	ALL
DED		W0041	2541Z			31-32-15	ALL
DED		W0041	2542Z			31-32-15	ALL
D02877	**P061-01/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W0041	0091	24		34-61-26	ALL
3		W0041	2510R	22		31-32-15	ALL
4	UNUSED						ALL
5		W0041	2510B	22		31-32-15	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02877		**P061-01/ /**		**PLUG- (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0041	0094	24		22-11-53	ALL
	16		W0041	0048	22		23-15-15	ALL
	17	UNUSED						ALL
	18		W0041	0030	24		31-65-15	ALL
	19		W0041	0039	24		23-27-39	ALL
	20		W0041	2516B	24		23-27-39	ALL
	21		W0041	2529B	24		34-61-26	ALL
	22		W0041	2525B	24		34-61-18	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0041	0121	22		27-61-42	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W0041	0095	24		22-11-53	ALL
	32		W0041	2531B	24		22-11-53	ALL
	33		W0041	2520B	22		23-15-15	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W0041	0114	24		34-49-11	ALL
	38		W0041	2540R	24		34-49-11	ALL
	39		W0041	2516R	24		23-27-39	ALL
	40		W0041	2529R	24		34-61-26	ALL
	41		W0041	2525R	24		34-61-18	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02877	**P061-01/ /**		**PLUG- (continued)**				**ALL**
42		W0041	0089	24		34-61-18	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W0041	2543B	24		27-61-47	ALL
46		W0041	2543R	24		27-61-47	ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54		W0041	0093	24		22-11-53	ALL
55		W0041	2531R	24		22-11-53	ALL
56		W0041	2520R	22		23-15-15	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60	UNUSED						ALL
61		W0041	2540B	24		34-49-11	ALL
DED		W0041	2510Z			31-32-15	ALL
DED		W0041	2516Z			23-27-39	ALL
DED		W0041	2520Z			23-15-15	ALL
DED		W0041	2525Z			34-61-18	ALL
DED		W0041	2529Z			34-61-26	ALL
DED		W0041	2531Z			22-11-53	ALL
DED		W0041	2540Z			34-49-11	ALL
DED		W0041	2543Z			27-61-47	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02879	**P061-01/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0041	0047	22		46-13-52	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0041	0096	24		22-11-53	ALL
12	UNUSED						ALL
13		W0041	0011	22		31-32-15	ALL
14		W0041	2504R	22		31-32-15	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0041	0016	24		31-35-01	ALL
20		W0041	0017	24		31-35-01	ALL
21	UNUSED						ALL
22		W0041	2545B	24		27-61-47	ALL
23		W0041	0122	22		27-61-42	ALL
24	UNUSED						ALL
25		W0044	6101	24		23-42-14	ALL
26	UNUSED						ALL
27		W0041	0046	22		31-32-15	ALL
28		W0041	0010	20		31-32-15	ALL
29		W0041	2504B	22		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02879	**P061-01/ /**		**PLUG- (continued)**				**ALL**
30	UNUSED						ALL
31		W0041	2518R	24		SPARE	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W0041	2545R	24		27-61-47	ALL
42		W0044	2012R	24		23-42-14	ALL
43		W0044	2012B	24		23-42-14	ALL
44		W0041	2519R	22		49-62-11	ALL
45		W0041	2519B	22		49-62-11	ALL
46		W0041	2526R	24		34-61-18	ALL
47		W0041	2526B	24		34-61-18	ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0041	2518B	24		SPARE	ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
DED		W0041	2504Z			31-32-15	ALL
DED		W0041	2518Z			SPARE	ALL
DED		W0041	2519Z			49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02879		**P061-01/ /**		**PLUG- (continued)**				**ALL**
	DED		W0041	2526Z			34-61-18	ALL
	DED		W0041	2545Z			27-61-47	ALL
			W0044	2012Z			23-42-14	ALL
			W0044	6100	20		23-42-14	ALL
D02880		**J023-00/ /**		**SOCKET-OXYGEN RELAY R322**				**ALL**
	A1		W0078	0314	16		35-21-11	ALL
	A2		W0078	0307	16		35-21-11	ALL
	A3	UNUSED						ALL
	B1		W0078	0315	16		35-21-11	ALL
	B2		W0078	0308	16		35-21-11	ALL
	B3	UNUSED						ALL
	C1		W0078	0316	22		35-21-11	ALL
	C2		W0078	0309	22		35-21-11	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0078	0310	22		35-21-11	ALL
	X2		W0078	0313	22		35-21-11	ALL
D02882		**J023-00/ /**		**SOCKET-OXYGEN RELAY R323**				**ALL**
	A1		W0078	0323	16		35-21-11	ALL
	A2		W0078	0320	16		35-21-11	ALL
	A3	UNUSED						ALL
	B1		W0078	0322	16		35-21-11	ALL
	B2		W0078	0319	16		35-21-11	ALL
	B3	UNUSED						ALL
	C1		W0078	0321	22		35-21-11	ALL
	C2		W0078	0318	22		35-21-11	ALL
	C3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02882	**J023-00/ /**		**SOCKET-OXYGEN RELAY R323 (continued)**				**ALL**
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0078	0301	22		35-21-11	ALL
X2		W0078	0306	22		35-21-11	ALL
D02884	**J023-00/ /**		**SOCKET-OXYGEN RELAY R324**				**ALL**
A1		W0078	0329	22		35-21-11	ALL
A2		W0078	0324	22		35-21-11	ALL
A3	UNUSED						ALL
B1		W0078	0331	24		33-25-11	ALL
B2		W0078	0325	22		35-21-11	ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2		W0078	0332	20		33-25-11	ALL
C3		W0078	0333	20		33-25-11	ALL
D1		W0078	0326	22		35-21-11	ALL
D2		W0078	0001	22		35-21-11	ALL
D3	UNUSED						ALL
X1		W0078	0330	22		35-21-11	ALL
X2		W0078	0328	22		35-21-11	ALL
D02886	**J023-00/ /**		**PLUG-ALTITUDE PRESSURE SWITCH S813**				**ALL**
1		W0078	0313	22		35-21-11	ALL
2		W0078	0317	20		35-21-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D02889	**P005-80/ /**		**PLUG-ELT CONT PNL**				**ALL**
1	UNUSED						ALL
2		W2589	0002	22		23-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02889		**P005-80/ /**		**PLUG-ELT CONT PNL (continued)**				**ALL**
	3	UNUSED						ALL
	4		W2508	5640	20		33-18-42	ALL
	5		W2589	0005	22		23-24-11	ALL
	6		W2589	0006	22		23-24-11	ALL
	7		W2589	0007	22		23-24-11	ALL
	8		W2589	0008	22		23-24-11	ALL
	9		W2508	5642	20		23-24-11	ALL
	10		W2589	0010	22		23-24-11	ALL
	11		W2589	0011	22		23-24-11	ALL
	12		W2508	5641	20		33-18-42	ALL
	13		W2218	5743	20		33-12-11	ALL
	14		W2218	5744	20		33-12-11	ALL
	15		W2589	0015	22		23-24-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02905	**797/289/L015**		**PLUG-121.5/243 MHZ XMTR**				**ALL**
=A1	UNUSED						ALL
=C1	UNUSED						ALL
D02907	**797/289/L005**		**PLUG-121.5/243 MHZ ELT ANTENNA**				**ALL**
=A1	UNUSED						ALL
=C1	UNUSED						ALL
D02909	**726/187/L022**		**PLUG**				**ALL**
1		W5603	3002R	20		31-31-14	ALL
2		W5603	3002B	20		31-31-14	ALL
3		W5603	3002Y	20		31-31-14	ALL
S/R		W5603	3002Z			31-31-14	ALL
D02911	**725/189/L004**		**PLUG**				**ALL**
1		W5605	3002R	20		31-31-14	ALL
2		W5605	3002B	20		31-31-14	ALL
3		W5605	3002Y	20		31-31-14	ALL
S/R		W5605	3002Z			31-31-14	ALL
D02913	**681/193/L069**		**PLUG**				**ALL**
1		W5603	3001Y	20		31-31-14	ALL
2		W5603	3001R	20		31-31-14	ALL
3		W5603	3001B	20		31-31-14	ALL
S/R		W5603	3001Z			31-31-14	ALL
D02915	**692/192/R068**		**PLUG**				**ALL**
1		W5605	3001Y	20		31-31-14	ALL
2		W5605	3001R	20		31-31-14	ALL
3		W5605	3001B	20		31-31-14	ALL
S/R		W5605	3001Z			31-31-14	ALL
D02921	**P005-81/ /**		**PLUG-**				**ALL**
1		W2114	0071	20		33-18-37	ALL
2		W2114	0072	22		44-21-22	ALL
3		W2114	0073	20		33-18-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D02921		**P005-81/ /**		**PLUG- (continued)**				**ALL**
	4		W2114	0074	20		33-18-37	ALL
	5	UNUSED						ALL
D02928		**666/169/L035**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7122	0520	20		27-11-11	ALL
	2		W7122	0518	20		27-11-11	ALL
	3		W7122	0519	20		27-11-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W7122	0521	20		27-11-11	ALL
D02930		**P008-43/ /**		**PLUG-AILERON TRIM CONT MODULE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W6208	3002Y	20		27-11-11	ALL
	5		W6208	5503	20		33-11-41	ALL
	6		W6208	5504	20		33-11-41	ALL
	7		W6208	3002B	20		27-11-11	ALL
	8		W6208	0564	20		27-11-11	ALL
	9		W6208	0529	22		27-11-11	ALL
	10		W6208	0532	22		27-11-11	ALL
	11		W6208	0502	22		27-11-11	ALL
	12		W6208	3002R	20		27-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02932	**RUD51/ /**		**PLUG-RUDDER TRIM ACTUATOR M1125**				**ALL**
1	UNUSED						ALL
2		W6136	3204Y	20		27-21-11	ALL
3		W6136	3204B	20		27-21-11	ALL
4		W6136	2202B	20		27-28-11	ALL
5		W6136	2202R	20		27-28-11	ALL
6		W6136	2204B	20		27-28-11	ALL
7		W6136	2204R	20		27-28-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W6136	3204R	20		27-21-11	ALL
14	UNUSED						ALL
15		W6136	0512	20		27-21-11	ALL
S/R		W6136	2202Z			27-28-11	ALL
S/R		W6136	2204Z			27-28-11	ALL
S/R		W6136	3204Z			27-21-11	ALL
D02934	**P008-43/ /**		**PLUG-RUDDER TRIM INDICATOR N159**				**ALL**
1		W6208	5501	20		33-11-41	ALL
2		W6208	5502	20		33-11-41	ALL
3		W6208	0534	24		27-28-11	ALL
4		W6208	0515	20		27-28-11	ALL
5	UNUSED						ALL
6		W6208	0516	20		27-28-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W6208	2201R	24		27-28-11	ALL
10		W6208	2201B	24		27-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02934		**P008-43/ /**		**PLUG-RUDDER TRIM INDICATOR N159 (continued)**				**ALL**
	11	UNUSED						ALL
	12	UNUSED						ALL
D02936		**392/162/L004**		**PLUG-BATTERY SENSOR**				**ALL**
	1		W6210	0524	24		24-31-11	ALL
	2	UNUSED						ALL
	3		W6210	0525	24		24-31-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W6210	0522	24		24-31-11	ALL
	12		W6210	0523	24		24-31-11	ALL
D02941		**500A+15/306/L005**		**PLUG - ANGLE 90**				**ALL**
	=A1		W3607	001CX			34-58-11	ALL
	=C1		W3607	001CO			34-58-11	ALL
D02947		**500A+5/306/R005**		**PLUG - ANGLE 90**				**ALL**
	=A1		W3609	001CX			34-58-21	ALL
	=C1		W3609	001CO			34-58-21	ALL
D02952		**P005-68/ /**		**PLUG-**				**ALL**
	1		W2508	5728	20		31-52-61	ALL
	2		W2508	5729	20		31-52-61	ALL
	3		W2508	5730	20		31-52-61	ALL
	4	UNUSED						ALL
	5		W2508	5593	20		33-18-42	ALL
	6		W2112	6025	24		73-21-12	ALL
	7		W2508	5598	20		33-18-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02952	**P005-68/ /**		**PLUG- (continued)**				**ALL**
8		W2112	6014	24		73-32-11	ALL
9		W2508	5631	20		33-18-42	ALL
10		W2112	1301	24		73-21-12	ALL
11		W2112	0089	20		78-36-11	ALL
12	UNUSED						ALL
13		W2112	2601B	24		73-21-12	ALL
14	UNUSED						ALL
15		W2508	5629	20		33-18-42	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W2112	6026	20		73-21-12	ALL
19		W2112	0090	20		78-36-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W2112	2601R	24		73-21-12	ALL
		W2112	1301Z			73-21-12	ALL
		W2112	2601Z			73-21-12	ALL
		W2112	6027	20		73-21-12	ALL
D02968	**317/279/R037**		**PLUG-**				**ALL**
1		W0342	0003	20		33-51-12	ALL
2		W0342	0004	20		33-51-12	ALL
3	UNUSED						ALL
D02970	**269/274/L014**		**RCPT-**				**ALL**
=1		W2114	0022	20		33-51-12	ALL
D02972	**329/285/L030**		**PLUG-**				**ALL**
1		W0352	0003	20		33-51-12	ALL
2		W0352	0004	20		33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D02972		**329/285/L030**		**PLUG- (continued)**				**ALL**
	3	UNUSED						ALL
D02982		**972/279/L037**		**PLUG-**				**ALL**
	1		W0452	0003	20		33-51-14	ALL
	2		W0452	0004	20		33-51-14	ALL
	3	UNUSED						ALL
D02986		**972/286/R044**		**PLUG-**				**ALL**
	1		W0442	0003	20		33-51-14	ALL
	2		W0442	0004	20		33-51-14	ALL
	3	UNUSED						ALL
D02992		**0270/284/L010**		**PART OF ASSY 69-74399**				**ALL**
	=1		W2114	0025	20		33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03001J	**257/195/R011**		**RCPT-INLINE CONNECTOR**				**ALL**
A		W5506	6004R	20		26-11-31	ALL
B		W5506	6005R	20		26-11-31	ALL
C	UNUSED						ALL
D03001P	**255/195/R011**		**PLUG-INLINE CONNECTOR**				**ALL**
A		W6506	6003R	20		26-11-31	ALL
B		W6506	6002R	20		26-11-31	ALL
C	UNUSED						ALL
D03003	**795/289/L010**		**PLUG-**				**ALL**
1		W3419	0001	22		23-24-11	ALL
2		W3419	0002	22		23-24-11	ALL
3		W3419	0003	22		23-24-11	ALL
4	UNUSED						ALL
5		W3419	0005	22		23-24-11	ALL
6		W3419	0006	22		23-24-11	ALL
7		W3419	0007	22		23-24-11	ALL
8		W3419	0005	22		23-24-11	ALL
9		W3419	0009	24		23-24-11	ALL
10		W3419	0004	24		23-24-11	ALL
11		W3419	0011	22		23-24-11	ALL
12		W3419	0008	24		23-24-11	ALL
D03052	**675/152/L012**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W7522	2601B	20		78-34-11	ALL
3		W7522	2603R	20		78-34-11	ALL
4		W7522	2602B	20		78-34-11	ALL
5		W7522	2602R	20		78-34-11	ALL
6		W7522	2603B	20		78-34-11	ALL
7		W7522	2601R	20		78-34-11	ALL
		W7522	2601Z			78-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03052		**675/152/L012**		**PLUG (continued)**				**ALL**
			W7522	2602Z			78-34-11	ALL
			W7522	2603Z			78-34-11	ALL
			W7522	FRAA			78-34-11	ALL
D03056		**675/152/R012**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W8228	2601B	20		78-34-21	ALL
	3		W8228	2603R	20		78-34-21	ALL
	4		W8228	2602B	20		78-34-21	ALL
	5		W8228	2602R	20		78-34-21	ALL
	6		W8228	2603B	20		78-34-21	ALL
	7		W8228	2601R	20		78-34-21	ALL
			W8228	2601Z			78-34-21	ALL
			W8228	2602Z			78-34-21	ALL
			W8228	2603Z			78-34-21	ALL
			W8228	FRAA			78-34-21	ALL
D03072		**P005-00/ /**		**PLUG-**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2		W2218	0022	24		33-25-11	ALL
	B3		W2218	0019	20		33-25-11	ALL
	X1		W2218	0020	24		33-25-11	ALL
	X2		W2218	0021	20		33-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03116	**P008-43/ /**		**PLUG-AILERON/RUDDER TRIM CONT MOD**				**ALL**
1		W6208	0506	24		27-21-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W6208	0500	24		27-21-11	ALL
5		W6208	0510	20		27-21-11	ALL
6		W6208	0511	20		27-21-11	ALL
7		W6208	0501	24		27-21-11	ALL
8		W6208	0509	24		27-21-11	ALL
9	UNUSED						ALL
10		W6208	0507	24		27-21-11	ALL
11	UNUSED						ALL
12		W6208	0508	24		27-21-11	ALL
D03124	**200/198/R013**		**PLUG-F/O COLUMN SWITCHING MODULE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6208	0610	20		27-41-11	ALL
4	UNUSED						ALL
5		W6208	0611	20		27-41-11	ALL
6		W6208	0608	20		27-41-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6208	0612	20		27-41-11	ALL
D03160	**305/290/R003**		**PLUG, RECTANGULAR**				**ALL**
1		W0142	0018	22		SPARE	ALL
2		W0142	0012	22		33-27-11	ALL
3		W0142	0011	22		33-27-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03160		**305/290/R003**		**PLUG, RECTANGULAR (continued)**				**ALL**
	4		W0142	0009	22		23-42-11	ALL
	5		W0142	0017	22		SPARE	ALL
	6		W0142	0010	22		23-42-11	ALL
	7		W0142	0003	20		33-51-12	ALL
	8		W0142	0004	20		33-51-12	ALL
D03172		**P005-68/ /**		**PLUG-**				**ALL**
	1		W2218	5610	20		33-12-12	ALL
	2		W2218	5611	20		33-12-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2508	5594	20		33-18-42	ALL
	6		W2218	6009	24		73-21-12	ALL
	7	UNUSED						ALL
	8		W2218	6013	24		73-32-11	ALL
	9		W2508	5630	20		33-18-42	ALL
	10		W2216	1301	24		73-21-12	ALL
	11		W2218	0093	20		78-36-21	ALL
	12	UNUSED						ALL
	13		W2216	2601B	24		73-21-12	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W2216	6008	20		73-21-12	ALL
	19		W2218	0094	20		78-36-21	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03172		**P005-68/ /**		**PLUG- (continued)**				**ALL**
	24		W2216	2601R	24		73-21-12	ALL
			W2216	1301Z			73-21-12	ALL
			W2216	2601Z			73-21-12	ALL
			W2216	6007	20		73-21-12	ALL
D03188		**642/162/R047**		**PLUG-**				**ALL**
	1		W8122	1011	20		27-83-11	ALL
	2		W8122	1012	20		27-83-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D03190		**642/161/R053**		**PLUG-**				**ALL**
	1		W6202	1013	20		27-83-21	ALL
	2		W6202	1029	20		27-83-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03242		**667/179/R031**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W8122	0504	20		29-25-11	ALL
	3		W8122	1010	20		29-25-11	ALL
	S/R		W8122	1010Z			29-25-11	ALL
D03244		**664/150/L009**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7122	0503	18		29-25-11	ALL
	2		W7122	2003B	18		29-25-11	ALL
	3		W7122	2003R	18		29-25-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W7122	2003Z			29-25-11	ALL
D03254		**J011-00/ /**		**SOCKET-HYD SYS B EDP RLY R353**				**ALL**
	A1		W0122	0016	22		29-25-11	ALL
	A2		W0122	0010	22		29-25-11	ALL
	A3	UNUSED						ALL
	B1		W0122	0015	18		29-25-11	ALL
	B2		W0122	0009	18		29-25-11	ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03254	**J011-00/ /**		**SOCKET-HYD SYS B EDP RLY R353 (continued)**				**ALL**
X1		W0122	0018	20		29-25-11	ALL
X2		W0122	0017	22		29-25-11	ALL
D03261A	**E005-02/ /**		**PLUG FMC NO.2**				**ALL**
A01		W0521	2582R	24		34-51-11	ALL
A02	UNUSED						ALL
A03		W0521	2545R	24		34-21-13	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0521	2517R	24		34-61-22	ALL
A10	UNUSED						ALL
A11		W0523	2770R	22		34-61-15	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0521	2506R	24		34-61-12	ALL
A15		W0521	2726R	24		46-13-11	ALL
B01		W0521	2582B	24		34-51-11	ALL
B02	UNUSED						ALL
B03		W0521	2545B	24		34-21-13	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0521	2517B	24		34-61-22	ALL
B10	UNUSED						ALL
B11		W0523	2770B	22		34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261A		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0521	2506B	24		34-61-12	ALL
	B15		W0521	2726B	24		46-13-11	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0521	2588R	24		34-55-11	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0521	2569R	22		28-41-11	ALL
	D06	UNUSED						ALL
	D07		W0521	2559R	24		34-21-14	ALL
	D08	UNUSED						ALL
	D09		W0523	2831R	24		34-61-18	ALL
	D10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261A	**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
D11		W0523	2767R	24		34-61-11	ALL
D12		W0523	4001R	24		31-65-15	ALL
D13		W0523	2702R	24		34-61-11	ALL
D14		W0523	4002R	24		31-65-25	ALL
D15	UNUSED						ALL
E01		W0521	2588B	24		34-55-11	ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05		W0521	2569B	22		28-41-11	ALL
E06	UNUSED						ALL
E07		W0521	2559B	24		34-21-14	ALL
E08	UNUSED						ALL
E09		W0523	2831B	24		34-61-18	ALL
E10	UNUSED						ALL
E11		W0523	2767B	24		34-61-11	ALL
E12		W0523	4001B	24		31-65-15	ALL
E13		W0523	2702B	24		34-61-11	ALL
E14		W0523	4002B	24		31-65-25	ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261A		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01		W0521	2580R	24		34-31-11	ALL
	G02	UNUSED						ALL
	G03		W0523	2756R	24		31-65-25	ALL
	G04	UNUSED						ALL
	G05		W0521	2597R	24		22-31-52	ALL
	G06	UNUSED						ALL
	G07		W0521	2566R	24		22-11-51	ALL
	G08	UNUSED						ALL
	G09		W0523	2769R	24		34-61-14	ALL
	G10	UNUSED						ALL
	G11		W0523	2717R	24		34-61-18	ALL
	G12		W0523	4001Y	24		31-65-15	ALL
	G13		W0523	2703R	24		34-61-11	ALL
	G14		W0523	4002Y	24		31-65-25	ALL
	G15		W0521	2576R	24		31-65-15	ALL
	H01		W0521	2580B	24		34-31-11	ALL
	H02	UNUSED						ALL
	H03		W0523	2756B	24		31-65-25	ALL
	H04	UNUSED						ALL
	H05		W0521	2597B	24		22-31-52	ALL
	H06	UNUSED						ALL
	H07		W0521	2566B	24		22-11-51	ALL
	H08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261A	**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
H09		W0523	2769B	24		34-61-14	ALL
H10	UNUSED						ALL
H11		W0523	2717B	24		34-61-18	ALL
H12		W0523	4001G	24		31-65-15	ALL
H13		W0523	2703B	24		34-61-11	ALL
H14		W0523	4002G	24		31-65-25	ALL
H15		W0521	2576B	24		31-65-15	ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13		W0523	0304	22		34-61-11	ALL
J14		W0521	0298	22		34-61-19	ALL
J15		W0521	0299	22		34-61-19	ALL
K01		W0521	0060	24		34-61-17	ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261A		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	K08		W0523	0338	22		34-61-18	ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13		W0523	0323	22		34-61-16	ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	DED		W0521	2517Z			34-61-22	ALL
	DED		W0521	2559Z			34-21-14	ALL
	DED		W0521	2588Z			34-55-11	ALL
	DED		W0521	2597Z			22-31-52	ALL
	DED		W0523	2767Z			34-61-11	ALL
	DED		W0523	2769Z			34-61-14	ALL
	DED		W0523	2831Z			34-61-18	ALL
D03261B		**E005-02/ /**		**PLUG FMC NO.2**				**ALL**
	A01		W0521	2803R	24		34-58-11	ALL
	A02	UNUSED						ALL
	A03		W0523	2772R	24		34-21-23	ALL
	A04		W0521	2507R	24		34-61-12	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0523	2802R	24		34-61-21	ALL
	A10		W0521	0114	22		34-61-19	ALL
	A11		W0523	0325	24		34-61-18	ALL
	A12		W0521	0085	22		34-61-19	ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261B	**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
A14		W0521	0052	24		34-61-17	ALL
A15	UNUSED						ALL
B01		W0521	2803B	24		34-58-11	ALL
B02	UNUSED						ALL
B03		W0523	2772B	24		34-21-23	ALL
B04		W0521	2507B	24		34-61-12	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0523	2802B	24		34-61-21	ALL
B10		W0521	0322	22		34-61-19	ALL
B11	UNUSED						ALL
B12		W0521	0078	22		34-61-19	ALL
B13		W0521	0123	22		34-61-19	ALL
B14		W0523	0012	24		34-61-17	ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10		W0521	0115	22		34-61-19	ALL
C11		W0521	0079	22		34-61-19	ALL
C12		W0521	0076	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261B		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	C13		W0521	0321	22		34-61-19	ALL
	C14		W0523	0015	24		34-61-17	ALL
	C15	UNUSED						ALL
	D01		W0523	2862R	24		34-51-21	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0521	2920W	24		34-61-12	ALL
	D05		W0523	2794R	24		34-21-24	ALL
	D06	UNUSED						ALL
	D07		W0523	2768R	24		34-61-14	ALL
	D08	UNUSED						ALL
	D09		W0521	2915R	24		34-61-18	ALL
	D10		W0521	0116	22		34-61-19	ALL
	D11		W0521	0080	22		34-61-19	ALL
	D12		W0521	0077	22		34-61-19	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0523	2862B	24		34-51-21	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0521	2920B	24		34-61-12	ALL
	E05		W0523	2794B	24		34-21-24	ALL
	E06	UNUSED						ALL
	E07		W0523	2768B	24		34-61-14	ALL
	E08	UNUSED						ALL
	E09		W0521	2915B	24		34-61-18	ALL
	E10	UNUSED						ALL
	E11		W0521	0081	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261B	**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
E12		W0521	0201	22		34-61-12	ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06		W0521	0007	22		34-61-11	ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0521	0117	22		34-61-19	ALL
F11		W0521	0082	22		34-61-19	ALL
F12		W0521	0121	22		34-61-19	ALL
F13		W0521	0058	22		30-21-31	ALL
F14		W0521	0112	22		34-61-19	ALL
F15		W0521	0320	22		34-61-19	ALL
G01		W0523	2788R	24		34-58-21	ALL
G02	UNUSED						ALL
G03		W0523	2803R	24		34-61-21	ALL
G04		W0521	2919W	24		34-61-12	ALL
G05		W0523	2760R	24		34-31-21	ALL
G06	UNUSED						ALL
G07		W0523	2771R	24		34-55-21	ALL
G08	UNUSED						ALL
G09		W0523	2716R	22		34-61-15	ALL
G10		W0521	0118	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261B		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	G11		W0521	0083	22		34-61-19	ALL
	G12		W0521	0200	22		34-61-12	ALL
	G13		W0521	0059	22		30-21-32	ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0523	2788B	24		34-58-21	ALL
	H02	UNUSED						ALL
	H03		W0523	2803B	24		34-61-21	ALL
	H04		W0521	2919B	24		34-61-12	ALL
	H05		W0523	2760B	24		34-31-21	ALL
	H06	UNUSED						ALL
	H07		W0523	2771B	24		34-55-21	ALL
	H08	UNUSED						ALL
	H09		W0523	2716B	22		34-61-15	ALL
	H10		W0521	0119	22		34-61-19	ALL
	H11		W0521	0084	22		34-61-19	ALL
	H12		W0521	0122	22		34-61-19	ALL
	H13		W0521	0056	24		34-61-17	ALL
	H14		W0523	0009	24		34-61-17	ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261B	**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
J10		W0521	0120	22		34-61-19	ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13		W0521	0054	24		34-61-17	ALL
J14		W0521	0057	22		30-11-11	ALL
J15	UNUSED						ALL
K01		W0521	0086	22		34-61-19	ALL
K02	UNUSED						ALL
K03		W0521	0087	22		34-61-19	ALL
K04		W0521	0050	24		34-61-17	ALL
K05		W0521	0088	22		34-61-19	ALL
K06	UNUSED						ALL
K07		W0523	0322	22		34-61-16	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
DED		W0521	2915Z			34-61-18	ALL
DED		W0523	2768Z			34-61-14	ALL
DED		W0523	2771Z			34-55-21	ALL
DED		W0523	2772Z			34-21-23	ALL
DED		W0523	2788Z			34-58-21	ALL
DED		W0523	2794Z			34-21-24	ALL
D03261C	**E005-02/ /**		**PLUG FMC NO.2**				**ALL**
1		W0523	0307	20		34-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03261C		**E005-02/ /**		**PLUG FMC NO.2 (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0523	0305	20		34-61-11	ALL
	8		W0523	0306	20		34-61-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D03263		**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1**				**ALL**
	A		W0521	2632R	24		23-27-35	ALL
	B		W0521	2632B	24		23-27-35	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E		W0521	2509R	24		34-61-14	ALL
	F		W0521	2509B	24		34-61-14	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L		W0521	2502R	24		34-61-11	ALL
	M		W0521	2502B	24		34-61-11	ALL
	N		W0523	2704R	24		34-61-11	ALL
	P		W0523	2704B	24		34-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03263	**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1 (continued)**				**ALL**
R		W0521	2524R	22		34-61-15	ALL
S		W0521	2524B	22		34-61-15	ALL
T		W0521	2750R	24		34-61-14	ALL
U		W0521	2750B	24		34-61-14	ALL
V		W0521	2623R	24		34-61-21	ALL
W		W0521	2623B	24		34-61-21	ALL
X		W0521	0024	22		34-61-16	ALL
Y		W0521	0025	22		34-61-16	ALL
Z		W0521	0016	22		34-61-12	ALL
DED		W0521	2502Z			34-61-11	ALL
DED		W0521	2509Z			34-61-14	ALL
DED		W0521	2524Z			34-61-15	ALL
DED		W0521	2623Z			34-61-21	ALL
DED		W0521	2632Z			23-27-35	ALL
DED		W0521	2743Z			34-61-15	ALL
DED		W0521	2750Z			34-61-14	ALL
DED		W0523	2704Z			34-61-11	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-		W0521	0017	22		34-61-12	ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-		W0521	2743R	24		34-61-15	ALL
I-		W0521	2743B	24		34-61-15	ALL
J-	UNUSED						ALL
K-	UNUSED						ALL
M-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03263		**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1 (continued)**				**ALL**
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-		W0521	0015	22		34-61-12	ALL
D03265		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.1**				**ALL**
	A		W0523	2803R	24		34-61-21	ALL
	B		W0523	2803B	24		34-61-21	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E		W0523	2706R	24		34-61-14	ALL
	F		W0523	2706B	24		34-61-14	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L		W0523	2702R	24		34-61-11	ALL
	M		W0523	2702B	24		34-61-11	ALL
	N		W0523	2703R	24		34-61-11	ALL
	P		W0523	2703B	24		34-61-11	ALL
	R		W0523	2715R	22		34-61-15	ALL
	S		W0523	2715B	22		34-61-15	ALL
	T		W0523	2705R	24		34-61-14	ALL
	U		W0523	2705B	24		34-61-14	ALL
	V		W0523	2802R	24		34-61-21	ALL
	W		W0523	2802B	24		34-61-21	ALL
	X		W0523	0323	22		34-61-16	ALL
	Y		W0523	0321	22		34-61-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03265	**E005-02/ /**		**PLUG-FMC XFER RELAY NO.1 (continued)**				**ALL**
Z	UNUSED						ALL
DED		W0523	2702Z			34-61-11	ALL
DED		W0523	2703Z			34-61-11	ALL
DED		W0523	2705Z			34-61-14	ALL
DED		W0523	2706Z			34-61-14	ALL
DED		W0523	2715Z			34-61-15	ALL
DED		W0523	2802Z			34-61-21	ALL
DED		W0523	2803Z			34-61-21	ALL
DED		W0523	2848Z			34-61-15	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-		W0521	0012	22		34-61-12	ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-		W0523	2848R	24		34-61-15	ALL
I-		W0523	2848B	24		34-61-15	ALL
J-	UNUSED						ALL
K-	UNUSED						ALL
M-		W0521	0008	22		34-61-12	ALL
N-		W0521	0011	22		34-61-12	ALL
P-		W0521	0009	22		34-61-12	ALL
Q-		W0521	0010	22		34-61-12	ALL
R-	UNUSED						ALL
S-	UNUSED						ALL
T-	UNUSED						ALL
D03267	**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1**				**ALL**
A		W0521	2625R	24		34-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03267		**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1 (continued)**				**ALL**
	B		W0521	2625B	24		34-61-21	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E		W0521	2511R	24		34-61-14	ALL
	F		W0521	2511B	24		34-61-14	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L		W0521	2503R	24		34-61-11	ALL
	M		W0521	2503B	24		34-61-11	ALL
	N		W0521	2504R	24		34-61-11	ALL
	P		W0521	2504B	24		34-61-11	ALL
	R		W0521	2526R	22		34-61-15	ALL
	S		W0521	2526B	22		34-61-15	ALL
	T		W0521	2510R	24		34-61-14	ALL
	U		W0521	2510B	24		34-61-14	ALL
	V		W0521	2624R	24		34-61-21	ALL
	W		W0521	2624B	24		34-61-21	ALL
	X		W0521	0029	22		34-61-16	ALL
	Y		W0521	0028	22		34-61-16	ALL
	Z		W0521	0014	22		34-61-12	ALL
	DED		W0521	2503Z			34-61-11	ALL
	DED		W0521	2504Z			34-61-11	ALL
	DED		W0521	2510Z			34-61-14	ALL
	DED		W0521	2511Z			34-61-14	ALL
	DED		W0521	2526Z			34-61-15	ALL
	DED		W0521	2624Z			34-61-21	ALL
	DED		W0521	2625Z			34-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03267	**E005-02/ /**		**PLUG-FMCS XFER RELAY NO. 1 (continued)**				**ALL**
DED		W0521	2939Z			34-61-15	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-	UNUSED						ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-		W0521	2939R	24		34-61-15	ALL
I-		W0521	2939B	24		34-61-15	ALL
J-	UNUSED						ALL
K-	UNUSED						ALL
M-	UNUSED						ALL
N-	UNUSED						ALL
P-	UNUSED						ALL
Q-	UNUSED						ALL
R-	UNUSED						ALL
S-	UNUSED						ALL
T-		W0521	0013	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03309		**178/178/L003**		**PLUG - (TNC) ANGLED 90 (42 DEG KEY)**				**ALL**
	=A1		W7159	001CX			34-31-11	ALL
	=C1		W7159	001CO			34-31-11	ALL
D03311		**178/178/L002**		**PLUG - (TNC) ANGLED 90 (102 DEG KEY)**				**ALL**
	=A1		W8159	001CX			34-31-21	ALL
	=C1		W8159	001CO			34-31-21	ALL
D03313		**178/182/L012**		**PLUG - (TNC) ANGLED 90 (42 DEG KEY)**				**ALL**
	=A1		W7157	001CX			34-31-11	ALL
	=C1		W7157	001CO			34-31-11	ALL
D03315		**178/181/L010**		**PLUG - (TNC) ANGLED 90 (102 DEG KEY)**				**ALL**
	=A1		W8157	001CX			34-31-21	ALL
	=C1		W8157	001CO			34-31-21	ALL
D03317		**178/178/L003**		**PLUG - (TNC) ANGLED 90 (42 DEG KEY)**				**ALL**
	=A1		W3141	001CX			34-31-11	ALL
	=C1		W3141	001CO			34-31-11	ALL
D03319		**178/178/L002**		**PLUG - (TNC) ANGLED 90 (102 DEG KEY)**				**ALL**
	=A1		W3143	001CX			34-31-21	ALL
	=C1		W3143	001CO			34-31-21	ALL
D03320		**T454/ /**		**PLUG- BRAKE TEMP SENSOR POS 1 LEFT GEAR**				**ALL**
	1	4L	W7130	4501W	20		32-46-11	ALL
	2	UNUSED						ALL
	3	4H	W7130	4501G	20		32-46-11	ALL
	DED		W7130	4501Z			32-46-11	ALL
D03321		**179/188/L015**		**PLUG - (TNC) STRAIGHT (42 DEG KEY)**				**ALL**
	=A1		W5837	001CX			34-31-11	ALL
	=C1		W5837	001CO			34-31-11	ALL
D03322		**T455/ /**		**PLUG- BRAKE TEMP SENSOR POS 2 LEFT GEAR**				**ALL**
	1	4L	W7132	4501W	20		32-46-11	ALL
	2	UNUSED						ALL
	3	4H	W7132	4501G	20		32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03322		**T455/ /**		**PLUG- BRAKE TEMP SENSOR POS 2 LEFT GEAR (continued)**				**ALL**
	DED		W7132	4501Z			32-46-11	ALL
D03323		**178/191/L014**		**PLUG - (TNC) STRAIGHT (102 DEG KEY)**				**ALL**
	=A1		W5839	001CX			34-31-21	ALL
	=C1		W5839	001CO			34-31-21	ALL
D03324		**T456/ /**		**PLUG- BRAKE TEMP SENSOR POS 3 RIGHT GEAR**				**ALL**
	1	4L	W8240	4501W	20		32-46-11	ALL
	2	UNUSED						ALL
	3	4H	W8240	4501G	20		32-46-11	ALL
	DED		W8240	4501Z			32-46-11	ALL
D03326		**T457/ /**		**PLUG- BRAKE TEMP SENSOR POS 4 RIGHT GEAR**				**ALL**
	1	4L	W8238	4501W	20		32-46-11	ALL
	2	UNUSED						ALL
	3	4H	W8238	4501G	20		32-46-11	ALL
	DED		W8238	4501Z			32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03423		**E005-02/ /**		**PLUG-FMC XFER NO.2**				**ALL**
	A		W0523	2708R	24		34-61-14	ALL
	B		W0523	2708B	24		34-61-14	ALL
	C		W0523	2707R	24		34-61-14	ALL
	D		W0523	2707B	24		34-61-14	ALL
	E		W0521	0196	22		34-61-12	ALL
	F		W0523	0319	22		34-61-16	ALL
	G		W0521	0195	22		34-61-12	ALL
	H	UNUSED						ALL
	J		W0523	2517R	24		34-61-15	ALL
	K		W0523	2517B	24		34-61-15	ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	DED		W0523	2517Z			34-61-15	ALL
	DED		W0523	2707Z			34-61-14	ALL
	DED		W0523	2708Z			34-61-14	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03423		**E005-02/ /**		**PLUG-FMC XFER NO.2 (continued)**				**ALL**
	D-	UNUSED						ALL
	E-	UNUSED						ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-	UNUSED						ALL
	I-	UNUSED						ALL
	J-	UNUSED						ALL
	K-	UNUSED						ALL
	M-	UNUSED						ALL
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-		W0521	0011	22		34-61-12	ALL
D03425		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.2**				**ALL**
	A		W0521	2512R	24		34-61-14	ALL
	B		W0521	2512B	24		34-61-14	ALL
	C		W0521	2513R	24		34-61-14	ALL
	D		W0521	2513B	24		34-61-14	ALL
	E		W0521	0198	22		34-61-12	ALL
	F		W0521	0026	22		34-61-16	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W0521	2649R	24		34-61-15	ALL
	K		W0521	2649B	24		34-61-15	ALL
	L		W0521	2744R	24		34-61-15	ALL
	M		W0521	2744B	24		34-61-15	ALL
	N	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03425		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.2 (continued)**				**ALL**
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	DED		W0521	2512Z			34-61-14	ALL
	DED		W0521	2513Z			34-61-14	ALL
	DED		W0521	2649Z			34-61-15	ALL
	DED		W0521	2744Z			34-61-15	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-	UNUSED						ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-	UNUSED						ALL
	I-	UNUSED						ALL
	J-	UNUSED						ALL
	K-	UNUSED						ALL
	M-		W0521	0193	22		34-61-12	ALL
	N-		W0521	0015	22		34-61-12	ALL
	P-		W0521	0194	22		34-61-12	ALL
	Q-		W0523	0311	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03425		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.2 (continued)**				**ALL**
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-	UNUSED						ALL
D03427		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.2**				**ALL**
	A		W0523	2711R	24		34-61-14	ALL
	B		W0523	2711B	24		34-61-14	ALL
	C		W0523	2710R	24		34-61-14	ALL
	D		W0523	2710B	24		34-61-14	ALL
	E	UNUSED						ALL
	F		W0523	0320	22		34-61-16	ALL
	G		W0521	0199	22		34-61-12	ALL
	H	UNUSED						ALL
	J		W0523	2799R	24		34-61-15	ALL
	K		W0523	2799B	24		34-61-15	ALL
	L		W0523	2863R	24		34-61-15	ALL
	M		W0523	2863B	24		34-61-15	ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	DED		W0523	2710Z			34-61-14	ALL
	DED		W0523	2711Z			34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03427		**E005-02/ /**		**PLUG-FMC XFER RELAY NO.2 (continued)**				**ALL**
	DED		W0523	2799Z			34-61-15	ALL
	DED		W0523	2863Z			34-61-15	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-	UNUSED						ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-	UNUSED						ALL
	I-	UNUSED						ALL
	J-	UNUSED						ALL
	K-	UNUSED						ALL
	M-	UNUSED						ALL
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-		W0521	0197	22		34-61-12	ALL
D03428		**P008-47/ /**		**PLUG-STAB TRIM & CAB DOOR MODULE**				**ALL**
	1		W6206	5534	20		33-11-41	ALL
	2		W6206	5533	20		33-11-41	ALL
	3		W6206	0507	20		27-41-11	ALL
	4		W6206	0506	20		27-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W6206	0015	22		52-51-11	ALL
	8		W6206	5554	20		33-18-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03428	**P008-47/ /**		**PLUG-STAB TRIM & CAB DOOR MODULE (continued)**				**ALL**
9		W6206	0011	22		52-51-11	ALL
10		W6206	0012	22		52-51-11	ALL
11	UNUSED						ALL
12		W6206	5552	20		33-18-61	ALL
13		W6206	0014	22		52-51-11	ALL
14		W6206	0016	22		52-51-11	ALL
15		W6206	0504	20		27-41-11	ALL
16		W6206	0503	20		27-41-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D03432	**P008-50/ /**		**PLUG-FLOOD AND PANEL LIGHTING MODULE**				**ALL**
1		W6206	5530	16		33-11-41	ALL
2		W6206	5532	16		33-11-41	ALL
3	14	W6206	5531	14		33-11-41	ALL
4		W6206	5528	16		33-11-41	ALL
5		W6206	5538	18		33-14-12	ALL
6		W6206	5539	18		33-14-12	ALL
7		W6206	5537	18		33-14-12	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W6206	5529	16		33-11-41	ALL
D03464	**200/189/R020**		**PLUG-LOW FLOW SNSR**				**ALL**
1		W5158	0670	22		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03464		**200/189/R020**		**PLUG-LOW FLOW SNSR (continued)**				**ALL**
	2	UNUSED						ALL
	3		W5158	0671	20		21-27-31	ALL
	4		W5158	0672	20		21-27-31	ALL
	5	UNUSED						ALL
	6		W5158	0673	22		21-27-31	ALL
	7		W5158	0674	20		33-18-11	ALL
	8		W5158	0675	22		34-21-16	ALL
	9		W5158	0676	22		21-27-31	ALL
	10	UNUSED						ALL
	11		W5158	0677	20		21-27-31	ALL
	12	UNUSED						ALL
D03470		**370/191/R050**		**PLUG-**				**ALL**
	1		W6430	5501	20		21-27-31	ALL
	2		W6430	5502	20		21-27-31	ALL
	3		W6430	5503	20		21-27-31	ALL
	4	UNUSED						ALL
	5		W6430	5505	22		21-27-31	ALL
	6		W6430	5506	20		21-27-31	ALL
	7		W6430	5504	20		21-27-31	ALL
D03472		**368/184/R050**		**PLUG-**				**ALL**
	1		W5030	5501	20		21-27-31	ALL
	2		W5030	5502	20		21-27-31	ALL
	3		W5030	5503	20		21-27-31	ALL
	4	UNUSED						ALL
	5		W5030	5505	22		21-27-31	ALL
	6		W5030	5506	20		21-27-31	ALL
	7		W5030	5504	20		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03524	**P008-00/ /**		**RCPT**				**ALL**
1		W0008	0081	20		27-41-11	ALL
2		W0008	0080	20		22-13-11	ALL
3		W0008	0093	20		22-13-11	ALL
4		W0008	0088	20		22-13-11	ALL
5		W0008	0061	20		27-41-11	ALL
6		W0008	0064	20		22-13-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D03527	**J022-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0076	0139	20		78-34-11	ALL
A2		W0076	0164	20		78-34-11	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0076	0468	18		78-32-51	ALL
X2		W0076	0162	22		78-32-51	ALL
D03529	**J00024/ /**		**SOCKET-**				**ALL**
A1		W0080	6052	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03529		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	A2		W0080	6031	20		78-34-21	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	6035	22		78-32-61	ALL
	X2		W0080	6028	22		78-32-61	ALL
D03572		**ORSS/540/**		**PLUG-AILERON POS XMTR LEFT**				**ALL**
	1		W1024	2001B	20		27-18-11	ALL
	2		W1024	2001R	20		27-18-11	ALL
	3		W1024	3001Y	20		27-18-11	ALL
	4		W1024	3001R	20		27-18-11	ALL
	5		W1024	3001B	20		27-18-11	ALL
D03574		**ORSS/540/**		**PLUG-AILERON POS XMTR RIGHT**				**ALL**
	1		W1034	2001B	20		27-18-11	ALL
	2		W1034	2001R	20		27-18-11	ALL
	3		W1034	3001Y	20		27-18-11	ALL
	4		W1034	3001R	20		27-18-11	ALL
	5		W1034	3001B	20		27-18-11	ALL
D03576		**RUD80/ /**		**PLUG-RUDDER POSITION XMTR**				**ALL**
	1		W6136	2203B	20		27-28-11	ALL
	2		W6136	2203R	20		27-28-11	ALL
	3		W6136	3203Y	20		27-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03576	**RUD80/ /**		**PLUG-RUDDER POSITION XMTR (continued)**				**ALL**
4		W6136	3203R	20		27-28-11	ALL
5		W6136	3203B	20		27-28-11	ALL
S/R		W6136	2203Z			27-28-11	ALL
S/R		W6136	3203Z			27-28-11	ALL
D03578	**1168/278/L032**		**PLUG-L ELEV POS XMTR**				**ALL**
1		W7038	2201B	20		27-38-11	ALL
2		W7038	2201R	20		27-38-11	ALL
3		W7038	3201Y	20		27-38-11	ALL
4		W7038	3201R	20		27-38-11	ALL
5		W7038	3201B	20		27-38-11	ALL
S/R		W7038	2201Z			27-38-11	ALL
S/R		W7038	3201Z			27-38-11	ALL
D03580	**1167/278/R032**		**PLUG-R ELEV POS XMTR**				**ALL**
1		W8038	2201B	20		27-38-11	ALL
2		W8038	2201R	20		27-38-11	ALL
3		W8038	3201Y	20		27-38-11	ALL
4		W8038	3201R	20		27-38-11	ALL
5		W8038	3201B	20		27-38-11	ALL
S/R		W8038	2201Z			27-38-11	ALL
S/R		W8038	3201Z			27-38-11	ALL
D03599A	**E006-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0626	0016	22		49-62-11	ALL
A04		W0626	3001Y	22		49-62-12	ALL
A05		W0626	3001R	22		49-62-12	ALL
A06		W0626	3001B	22		49-62-12	ALL
A07		W0626	2005R	22		49-62-12	ALL
A08		W0626	2005B	22		49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599A		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	A09		W0626	2007R	22		49-62-12	ALL
	A10		W0626	2017B	22		49-52-31	ALL
	A11		W0626	2016B	22		49-52-31	ALL
	A12		W0626	2016R	22		49-52-31	ALL
	A13		W0626	3003Y	22		49-52-31	ALL
	A14		W0626	2015B	22		49-52-31	ALL
	A15		W0626	2015R	22		49-52-31	ALL
	B01		W0626	0029	22		49-62-51	ALL
	B02		W0626	0022	22		49-62-11	ALL
	B03		W0626	0021	22		49-62-11	ALL
	B04	UNUSED						ALL
	B05		W0626	2009Z			49-62-12	ALL
	B06		W0626	0030	22		49-62-51	ALL
	B07		W0626	2023R	22		49-62-11	ALL
	B08	UNUSED						ALL
	B09		W0626	2007B	22		49-62-12	ALL
	B10		W0626	2017R	22		49-52-31	ALL
	B11	UNUSED						ALL
	B12		W0626	3003B	22		49-52-31	ALL
	B13		W0626	3003R	22		49-52-31	ALL
	B14		W0626	2014B	22		49-52-31	ALL
	B15		W0626	2014R	22		49-52-31	ALL
	C01		W0626	1001	22		49-62-12	ALL
	C02		W0626	2021R	22		49-94-21	ALL
	C03		W0626	2011R	22		49-71-21	ALL
	C04		W0626	2006R	22		49-62-12	ALL
	C05		W0626	2009R	22		49-62-12	ALL
	C06		W0626	4501W	22		49-71-21	ALL
	C07		W0626	4503W	22		49-71-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599A	**E006-02/ /**		**PLUG- (continued)**				**ALL**
C08		W0626	2019R	22		49-52-31	ALL
C09		W0626	2023B	22		49-62-11	ALL
C10		W0626	0020	22		49-62-11	ALL
C11		W0626	2020R	22		49-52-31	ALL
C12		W0626	0037	22		49-94-21	ALL
C13		W0626	0045	24		49-41-11	ALL
C14		W0626	3002B	22		49-52-31	ALL
C15		W0626	3002Y	22		49-52-31	ALL
D01		W0626	1002	22		49-62-12	ALL
D02		W0626	2021B	22		49-94-21	ALL
D03		W0626	2011B	22		49-71-21	ALL
D04		W0626	2006B	22		49-62-12	ALL
D05		W0626	2009B	22		49-62-12	ALL
D06		W0626	4501G	22		49-71-21	ALL
D07		W0626	4503G	22		49-71-21	ALL
D08		W0626	2019B	22		49-52-31	ALL
D09		W0626	2018R	22		49-52-31	ALL
D10		W0626	2018B	22		49-52-31	ALL
D11		W0626	2020B	22		49-52-31	ALL
D12		W0626	2010R	22		49-62-12	ALL
D13		W0626	2010B	22		49-62-12	ALL
D14	UNUSED						ALL
D15		W0626	3002R	22		49-52-31	ALL
		W0626	1001Z			49-62-12	ALL
		W0626	1002Z			49-62-12	ALL
		W0626	2005Z			49-62-12	ALL
		W0626	2006Z			49-62-12	ALL
		W0626	2007Z			49-62-12	ALL
		W0626	2014Z			49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599A		**E006-02/ /**		**PLUG- (continued)**				**ALL**
			W0626	2015Z			49-52-31	ALL
			W0626	2016Z			49-52-31	ALL
			W0626	2017Z			49-52-31	ALL
			W0626	3001Z			49-62-12	ALL
			W0626	3002Z			49-52-31	ALL
			W0626	3003Z			49-52-31	ALL
			W0626	FRAA			49-52-31	ALL
			W0626	FRAC			49-52-31	ALL
			W0626	FRAG			49-62-12	ALL
			W0626	FRAJ			49-62-12	ALL
	PERG	1A	W0626	2010Z			49-62-12	ALL
	PERG	1A	W0626	2011Z			49-71-21	ALL
	PERG	1A	W0626	2018Z			49-52-31	ALL
	PERG	1A	W0626	2019Z			49-52-31	ALL
	PERG	1A	W0626	2020Z			49-52-31	ALL
	PERG	1A	W0626	2021Z			49-94-21	ALL
	PERG	1A	W0626	4502Z			49-71-21	ALL
	PERG	1A	W0626	4504Z			49-71-21	ALL
	PERG	1A	W0626	FRAA			49-52-31	ALL
	PERG	1A	W0626	FRAC			49-52-31	ALL
	PERG	1A	W0626	FRAG			49-62-12	ALL
	PERG	1A	W0626	FRAJ			49-62-12	ALL
D03599B		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W0626	0047	24		49-52-31	ALL
	A02		W0626	0009	22		49-62-11	ALL
	A03		W0626	0024	22		49-62-11	ALL
	A04		W0626	0019	22		49-62-11	ALL
	A05	UNUSED						ALL
	A06		W0626	0046	24		49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599B	**E006-02/ /**		**PLUG- (continued)**				**ALL**
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0626	1003	22		49-62-12	ALL
A10		W0626	0023	22		49-62-11	ALL
A11		W0626	0035	24		49-62-11	ALL
A12		W0626	0034	22		49-94-21	ALL
A13		W0626	0010	22		49-62-11	ALL
A14		W0626	0013	22		49-62-11	ALL
A15		W0626	0012	22		49-62-11	ALL
B01		W0626	0002	22		49-62-11	ALL
B02		W0626	0006	22		49-62-11	ALL
B03		W0626	0005	22		49-62-11	ALL
B04		W0626	0036	22		49-94-21	ALL
B05		W0626	0052	24		49-52-31	ALL
B06		W0626	0049	24		49-52-31	ALL
B07		W0626	0028	22		49-62-11	ALL
B08		W0626	0025	22		49-62-11	ALL
B09		W0626	0044	24		49-41-11	ALL
B10		W0626	0060	22		49-52-31	ALL
B11		W0626	0011	22		49-62-11	ALL
B12		W0626	0038	24		49-52-31	ALL
B13		W0626	2008R	22		49-62-12	ALL
B14		W0626	2008B	22		49-62-12	ALL
B15		W0626	2008Z			49-62-12	ALL
C01		W0626	0007	22		49-62-11	ALL
C02		W0626	0008	22		49-62-11	ALL
C03		W0626	0050	24		49-52-31	ALL
C04		W0626	0051	24		49-52-31	ALL
C05		W0626	0040	22		49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599B		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	C06		W0626	0039	22		49-94-21	ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09		W0626	0055	22		49-52-31	ALL
	C10		W0626	1004	22		49-62-12	ALL
	C11		W0626	2004R	22		49-62-12	ALL
	C12		W0626	2004B	22		49-62-12	ALL
	C13		W0626	2002R	22		49-62-12	ALL
	C14		W0626	2022R	24		49-62-11	ALL
	C15		W0626	2001R	22		49-62-11	ALL
	D01		W0626	0043	24		49-41-11	ALL
	D02		W0626	0042	24		49-41-11	ALL
	D03		W0626	0041	24		49-41-11	ALL
	D04		W0626	0017	22		49-62-11	ALL
	D05		W0626	0026	22		49-62-11	ALL
	D06	UNUSED						ALL
	D07		W0626	2012R	22		49-41-11	ALL
	D08	UNUSED						ALL
	D09		W0626	0027	22		49-62-11	ALL
	D10		W0626	0018	22		49-62-11	ALL
	D11		W0626	2003R	22		49-62-12	ALL
	D12		W0626	2003B	22		49-62-12	ALL
	D13		W0626	2002B	22		49-62-12	ALL
	D14		W0626	2022B	24		49-62-11	ALL
	D15		W0626	2001B	22		49-62-11	ALL
			W0626	1003Z			49-62-12	ALL
			W0626	1004Z			49-62-12	ALL
			W0626	2002Z			49-62-12	ALL
			W0626	2003Z			49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03599B		**E006-02/ /**		**PLUG- (continued)**				**ALL**
			W0626	2004Z			49-62-12	ALL
			W0626	FRAE			49-62-12	ALL
	PERG	1A	W0626	2001Z			49-62-11	ALL
	PERG	1A	W0626	2012B	22		49-41-11	ALL
	PERG	1A	W0626	2013Z			49-41-11	ALL
	PERG	1A	W0626	2022Z			49-62-11	ALL
	PERG	1A	W0626	FRAE			49-62-12	ALL
D03599C		**E006-02/ /**		**PLUG-**				**ALL**
	1		W0626	0048	16		49-52-31	ALL
	2		W0626	0004	16		49-62-11	ALL
	3		W0626	0031	16		49-62-51	ALL
	4		W0626	0032	16		49-62-51	ALL
	5	UNUSED						ALL
	=C1	UNUSED						ALL
	=C5	UNUSED						ALL
	PERG	1A	W0626	0033	20		49-62-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03651A		**E003-01/ /**		**PLUG - RCVR-ADF 1**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03651A	**E003-01/ /**		**PLUG - RCVR-ADF 1 (continued)**				**ALL**
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03651A		**E003-01/ /**		**PLUG - RCVR-ADF 1 (continued)**				**ALL**
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D03651B		**E003-01/ /**		**PLUG - RCVR-ADF 1**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01		W0311	2130R	24		34-57-11	ALL
	B02		W0311	2130B	24		34-57-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0311	2128R	24		34-57-11	ALL
	B08		W0311	2128B	24		34-57-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03651B	**E003-01/ /**		**PLUG - RCVR-ADF 1 (continued)**				**ALL**
B12	UNUSED						ALL
B13		W0311	2081R	22		34-57-11	ALL
B14		W0311	2081B	22		34-57-11	ALL
B15		W0311	0149	22		34-57-11	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05		W0311	0146	24		34-57-11	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08		W0311	0147	24		34-57-11	ALL
C09		W0311	0148	24		34-57-11	ALL
C10		W0311	2134R	22		34-57-11	ALL
C11		W0311	2134B	22		34-57-11	ALL
C12		W0311	1008	22		34-57-11	ALL
C13		W0311	0145	22		34-57-11	ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01		W0311	2131R	22		34-57-11	ALL
D02		W0311	2131B	22		34-57-11	ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07		W0311	2132R	22		34-57-11	ALL
D08		W0311	2132B	22		34-57-11	ALL
D09	UNUSED						ALL
D10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03651B		**E003-01/ /**		**PLUG - RCVR-ADF 1 (continued)**				**ALL**
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14		W0311	2133R	22		34-57-11	ALL
	D15		W0311	2133B	22		34-57-11	ALL
	DED		W0311	2130ZI			34-57-11	ALL
	PERG	1A	W0311	1008Z			34-57-11	ALL
	PERG	1A	W0311	2081Z			34-57-11	ALL
	PERG	1A	W0311	2128Z			34-57-11	ALL
	PERG	1A	W0311	2130ZO			34-57-11	ALL
	PERG	1A	W0311	2131Z			34-57-11	ALL
	PERG	1A	W0311	2132Z			34-57-11	ALL
	PERG	1A	W0311	2133Z			34-57-11	ALL
	PERG	1A	W0311	2134Z			34-57-11	ALL
D03651C		**E003-01/ /**		**PLUG - RCVR-ADF 1**				**ALL**
	1	UNUSED						ALL
	2		W0311	0142	22		34-57-11	ALL
	3		W0311	0144	20		34-57-11	ALL
	4		W0311	0143	20		34-57-11	ALL
	5	UNUSED						ALL
	=C1	UNUSED						ALL
	=C5	UNUSED						ALL
D03653A		**E003-01/ /**		**PLUG - RCVR-ADF 2**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03653A	**E003-01/ /**		**PLUG - RCVR-ADF 2 (continued)**				**ALL**
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03653A		**E003-01/ /**		**PLUG - RCVR-ADF 2 (continued)**				**ALL**
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D03653B		**E003-01/ /**		**PLUG - RCVR-ADF 2**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03653B	**E003-01/ /**		**PLUG - RCVR-ADF 2 (continued)**				**ALL**
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01		W0313	2630R	24		34-57-21	ALL
B02		W0313	2630B	24		34-57-21	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0313	2628R	24		34-57-21	ALL
B08		W0313	2628B	24		34-57-21	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W0313	2581R	22		34-57-21	ALL
B14		W0313	2581B	22		34-57-21	ALL
B15		W0313	0649	22		34-57-21	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03653B		**E003-01/ /**		**PLUG - RCVR-ADF 2 (continued)**				**ALL**
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05		W0313	0646	24		34-57-21	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08		W0313	0647	24		34-57-21	ALL
	C09		W0313	0648	24		34-57-21	ALL
	C10		W0313	2634R	22		34-57-21	ALL
	C11		W0313	2634B	22		34-57-21	ALL
	C12		W0313	1508	22		34-57-21	ALL
	C13		W0313	0645	22		34-57-21	ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0313	2631R	22		34-57-21	ALL
	D02		W0313	2631B	22		34-57-21	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0313	2632R	22		34-57-21	ALL
	D08		W0313	2632B	22		34-57-21	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14		W0313	2633R	22		34-57-21	ALL
	D15		W0313	2633B	22		34-57-21	ALL
	DED		W0313	2630ZI			34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03653B	**E003-01/ /**		**PLUG - RCVR-ADF 2 (continued)**				**ALL**
PERG	1A	W0313	1508Z			34-57-21	ALL
PERG	1A	W0313	2581Z			34-57-21	ALL
PERG	1A	W0313	2628Z			34-57-21	ALL
PERG	1A	W0313	2630ZO			34-57-21	ALL
PERG	1A	W0313	2631Z			34-57-21	ALL
PERG	1A	W0313	2632Z			34-57-21	ALL
PERG	1A	W0313	2633Z			34-57-21	ALL
PERG	1A	W0313	2634Z			34-57-21	ALL
D03653C	**E003-01/ /**		**PLUG - RCVR-ADF 2**				**ALL**
1	UNUSED						ALL
2		W0313	0642	22		34-57-21	ALL
3		W0313	0644	20		34-57-21	ALL
4		W0313	0643	20		34-57-21	ALL
5	UNUSED						ALL
=C1	UNUSED						ALL
=C5	UNUSED						ALL
D03658	**290/225/R053**		**RCPT-**				**ALL**
=1		W4142	0012	20		33-51-21	ALL
D03659	**P008-00/ /**		**PLUG-**				**ALL**
1		W2265	0005	20		33-11-33	ALL
2		W2265	0006	20		33-11-33	ALL
3	UNUSED						ALL
4		W2265	0007	20		33-18-62	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2265	0001	20		34-57-11	ALL
8		W2265	0004	20		34-57-11	ALL
9		W2265	0003	22		34-57-11	ALL
10		W2265	0002	20		34-57-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03659		**P008-00/ /**		**PLUG- (continued)**				**ALL**
	11	UNUSED						ALL
	12		W2265	2001R	24		34-57-11	ALL
	13		W2265	2001B	24		34-57-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W2265	2001Z			34-57-11	ALL
D03660		**290/225/R052**		**PLUG-**				**ALL**
	=1		W4142	0052	20		33-51-21	ALL
D03661		**P008-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W2267	0007	20		33-18-62	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W2267	0001	20		34-57-21	ALL
	8		W2267	0004	20		34-57-21	ALL
	9		W2267	0003	22		34-57-21	ALL
	10		W2267	0002	20		34-57-21	ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03661	**P008-00/ /**		**PLUG- (continued)**				**ALL**
12		W2267	2001R	24		34-57-21	ALL
13		W2267	2001B	24		34-57-21	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W2267	2001Z			34-57-21	ALL
D03662	**301/226/L048**		**RCPT-**				**ALL**
=1		W4142	0112	20		33-51-21	ALL
D03663	**694/306/R005**		**PLUG**				**ALL**
1		W5273	8991R	24		34-57-11	ALL
2		W5273	8991B	24		34-57-11	ALL
3	UNUSED						ALL
4		W5273	8991Y	24		34-57-11	ALL
5		W5273	8991G	24		34-57-11	ALL
6	UNUSED						ALL
7		W5273	8991V	24		34-57-11	ALL
8		W5273	8991K	24		34-57-11	ALL
9	UNUSED						ALL
10		W5273	8991O	22		34-57-11	ALL
11		W5273	8991N	22		34-57-11	ALL
12		W5273	8991W	20		34-57-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03663		**694/306/R005**		**PLUG (continued)**				**ALL**
	13	UNUSED						ALL
	14		W5273	0003	20		34-57-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
			W5273	0001	20		34-57-11	ALL
			W5273	8991ZA			34-57-11	ALL
			W5273	8991ZB			34-57-11	ALL
			W5273	8991ZC			34-57-11	ALL
D03664		**302/226/L047**		**PLUG-**				**ALL**
	=1		W4142	0152	20		33-51-21	ALL
D03665		**727A+9/305/R005**		**PLUG**				**ALL**
	1		W5275	8991R	24		34-57-21	ALL
	2		W5275	8991B	24		34-57-21	ALL
	3	UNUSED						ALL
	4		W5275	8991Y	24		34-57-21	ALL
	5		W5275	8991G	24		34-57-21	ALL
	6	UNUSED						ALL
	7		W5275	8991V	24		34-57-21	ALL
	8		W5275	8991K	24		34-57-21	ALL
	9	UNUSED						ALL
	10		W5275	8991O	22		34-57-21	ALL
	11		W5275	8991N	22		34-57-21	ALL
	12		W5275	8991W	20		34-57-21	ALL
	13	UNUSED						ALL
	14		W5275	0003	20		34-57-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
			W5275	0001	20		34-57-21	ALL
			W5275	8991ZA			34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03665		**727A+9/305/R005**		**PLUG (continued)**				**ALL**
			W5275	8991ZB			34-57-21	ALL
			W5275	8991ZC			34-57-21	ALL
D03666		**613/224/R072**		**RCPT-**				**ALL**
	=1		W4142	0311	20		33-51-21	ALL
D03668		**614/224/R067**		**PLUG-**				**ALL**
	=1		W4142	0351	20		33-51-21	ALL
D03670		**614/225/L070**		**RCPT-**				**ALL**
	=1	VY	W3142	0072	20		33-51-21	ALL
D03671		**450/150/000**		**PLUG-RADIO ALTM XMTR ANTENNA -1**				**ALL**
	=A1		W5293	001CX			34-33-11	ALL
	=C1		W5293	001CO			34-33-11	ALL
D03672		**614/225/L070**		**PLUG-**				**ALL**
	=1	VG	W3142	0073	20		33-51-21	ALL
D03673		**390/150/000**		**PLUG-RADIO ALTM XMTR ANTENNA -2**				**ALL**
	=A1		W5297	001CX			34-33-21	ALL
	=C1		W5297	001CO			34-33-21	ALL
D03675		**430/150/000**		**PLUG-RADIO ALTM RCVER ANTENNA -1**				**ALL**
	=A1		W5295	001CX			34-33-11	ALL
	=C1		W5295	001CO			34-33-11	ALL
D03677		**410/150/000**		**PLUG-RADIO ALTM RCVR ANTENNA -2**				**ALL**
	=A1		W5299	001CX			34-33-21	ALL
	=C1		W5299	001CO			34-33-21	ALL
D03683A		***/*/***		**PLUG**				**ALL**
	1		W0321	0376	22		27-32-11	ALL
	2		W0321	0377	22		27-32-11	ALL
	3		W0321	0119	22		27-83-11	ALL
	4		W0321	0186	22		27-32-11	ALL
	5		W0321	0279	22		27-83-11	ALL
	6		W0321	0187	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683A		***/*/***		**PLUG (continued)**				**ALL**
	7		W0321	2505R	22		27-32-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W0321	0097	22		27-32-11	ALL
	11	UNUSED						ALL
	12		W0321	0237	22		22-23-11	ALL
	13		W0321	0378	22		27-32-11	ALL
	14		W0321	0130	22		27-32-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0321	0134	22		27-32-11	ALL
	21	UNUSED						ALL
	22		W0321	0221	24		22-11-14	ALL
	23	UNUSED						ALL
	24		W0321	0241	22		22-23-11	ALL
	25		W0321	2063B	22		22-23-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0321	2167R	24		34-61-14	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W0321	0570	22		27-32-11	ALL
	34	UNUSED						ALL
	35		W0321	0602	22		22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683A	*/*/*		**PLUG (continued)**				**ALL**
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W0321	0238	22		22-23-11	ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W0321	2167B	24		34-61-14	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W0321	0342	22		27-32-11	ALL
48		W0321	0702	22		27-32-11	ALL
49	UNUSED						ALL
50		W0321	0117	24		27-81-31	ALL
51		W0321	0167	22		22-23-11	ALL
52	UNUSED						ALL
53		W0321	2221B	24		22-23-12	ALL
54		W0321	2221R	24		22-23-12	ALL
55		W0321	2047R	24		34-21-23	ALL
56	UNUSED						ALL
57		W0321	2222R	24		22-23-12	ALL
58		W0321	2222B	24		22-23-12	ALL
59	UNUSED						ALL
60	UNUSED						ALL
61	UNUSED						ALL
62		W0321	0090	22		27-83-11	ALL
63		W0321	0327	22		32-64-21	ALL
64	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683A		***/*/***		**PLUG (continued)**				**ALL**
	65		W0321	0276	22		27-32-11	ALL
	66	UNUSED						ALL
	67	UNUSED						ALL
	68		W0321	2047B	24		34-21-23	ALL
	69	UNUSED						ALL
	70	UNUSED						ALL
	71	UNUSED						ALL
	72	UNUSED						ALL
	73	UNUSED						ALL
	74		W0321	0138	24		27-32-11	ALL
	75	UNUSED						ALL
	76	UNUSED						ALL
	77	UNUSED						ALL
	78	UNUSED						ALL
	79		W0321	0278	22		27-32-11	ALL
	80	UNUSED						ALL
	81	UNUSED						ALL
	82	UNUSED						ALL
	83	UNUSED						ALL
	84		W0321	0140	22		27-32-11	ALL
	85	UNUSED						ALL
	86	UNUSED						ALL
	87	UNUSED						ALL
	88		W0321	0232	22		22-23-11	ALL
	89	UNUSED						ALL
	90	UNUSED						ALL
	91	UNUSED						ALL
	92		W0321	0242	22		22-23-11	ALL
	93		W0321	0236	22		22-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683A	***/*/***		**PLUG (continued)**				**ALL**
94		W0321	2025B	24		27-32-12	ALL
95		W0321	2025R	24		27-32-12	ALL
96	UNUSED						ALL
97	UNUSED						ALL
98	UNUSED						ALL
99	UNUSED						ALL
100		W0321	0147	22		27-32-11	ALL
101	UNUSED						ALL
102		W0321	0230	22		22-23-11	ALL
103	UNUSED						ALL
104	UNUSED						ALL
105		W0321	2505B	22		27-32-11	ALL
106		W0321	0233	22		22-23-11	ALL
D03683B	***/*/***		**PLUG**				**ALL**
1		W0321	0261	22		22-23-12	ALL
2		W0321	0129	22		27-32-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0321	0229	22		22-23-12	ALL
14		W0321	0188	22		27-32-11	ALL
15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683B		***/*/***		**PLUG (continued)**				**ALL**
	16		W0321	3225B	22		22-23-12	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0321	0137	24		27-32-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0321	3225Y	22		22-23-12	ALL
	30		W0321	3225R	22		22-23-12	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W0321	0145	22		27-32-11	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40		W0321	2223R	22		22-23-12	ALL
	41		W0321	2223B	22		22-23-12	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683B	*/*/*		**PLUG (continued)**				**ALL**
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48		W0321	0146	22		27-32-11	ALL
49		W0321	0144	22		27-32-11	ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53		W0321	2063R	22		22-23-11	ALL
54	UNUSED						ALL
55		W0321	0280	22		27-32-11	ALL
56		W0321	0128	22		27-32-11	ALL
57	UNUSED						ALL
58		W0321	3733Y	22		27-32-11	ALL
59	UNUSED						ALL
60	UNUSED						ALL
61	UNUSED						ALL
62	UNUSED						ALL
63	UNUSED						ALL
64		W0321	2716B	24		31-65-15	ALL
65		W0321	2716R	24		31-65-15	ALL
66		W0321	2211R	24		22-11-51	ALL
67	UNUSED						ALL
68	UNUSED						ALL
69	UNUSED						ALL
70	UNUSED						ALL
71		W0321	3733B	22		27-32-11	ALL
72		W0321	3733R	22		27-32-11	ALL
73	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683B		***/*/***		**PLUG (continued)**				**ALL**
	74		W0321	0142	22		27-32-11	ALL
	75		W0321	0440	22		27-32-11	ALL
	76		W0321	0141	22		27-32-11	ALL
	77	UNUSED						ALL
	78		W0321	0143	22		27-32-11	ALL
	79		W0321	2211B	24		22-11-51	ALL
	80	UNUSED						ALL
	81	UNUSED						ALL
	82	UNUSED						ALL
	83	UNUSED						ALL
	84	UNUSED						ALL
	85	UNUSED						ALL
	86		W0321	2062B	22		22-23-11	ALL
	87	UNUSED						ALL
	88	UNUSED						ALL
	89	UNUSED						ALL
	90	UNUSED						ALL
	91		W0321	2372B	24		34-21-13	ALL
	92	UNUSED						ALL
	93		W0321	2029R	24		34-21-14	ALL
	94		W0321	2062R	22		22-23-11	ALL
	95	UNUSED						ALL
	96	UNUSED						ALL
	97		W0321	3732B	22		27-32-11	ALL
	98		W0321	3732Y	22		27-32-11	ALL
	99		W0321	3732R	22		27-32-11	ALL
	100	UNUSED						ALL
	101	UNUSED						ALL
	102	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03683B	*/*/*		**PLUG (continued)**				**ALL**
103	UNUSED						ALL
104		W0321	2372R	24		34-21-13	ALL
105	UNUSED						ALL
106		W0321	2029B	24		34-21-14	ALL
DED		W0321	3732Z			27-32-11	ALL
DED		W0321	3733Z			27-32-11	ALL
D03685A	*/*/*		**PLUG**				**ALL**
1		W0321	0492	22		27-32-21	ALL
2		W0321	0493	22		27-32-21	ALL
3		W0321	0121	22		27-83-21	ALL
4		W0321	0190	22		27-32-21	ALL
5		W0321	0120	22		27-83-21	ALL
6		W0321	0191	22		27-32-21	ALL
7		W0321	2507R	22		27-32-21	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0321	0250	22		27-32-21	ALL
11	UNUSED						ALL
12		W0321	0244	22		22-23-11	ALL
13		W0321	0491	22		27-32-21	ALL
14		W0321	0257	22		27-32-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0321	0263	22		27-32-21	ALL
21	UNUSED						ALL
22		W0321	0227	24		22-11-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685A		***/*/***		**PLUG (continued)**				**ALL**
	23	UNUSED						ALL
	24		W0321	0245	22		22-23-11	ALL
	25		W0321	2062B	22		22-23-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0321	2168R	24		34-61-14	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W0321	0594	22		27-32-21	ALL
	34	UNUSED						ALL
	35		W0321	0601	22		22-23-12	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W0321	0270	22		27-24-11	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W0321	2168B	24		34-61-14	ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W0321	0260	22		27-32-21	ALL
	48		W0321	0704	22		27-32-21	ALL
	49	UNUSED						ALL
	50		W0321	0118	24		27-81-31	ALL
	51		W0321	0169	22		22-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685A	*/*/*		**PLUG (continued)**				**ALL**
52	UNUSED						ALL
53		W0321	2709B	24		22-23-12	ALL
54		W0321	2709R	24		22-23-12	ALL
55		W0321	2165R	24		34-21-13	ALL
56	UNUSED						ALL
57		W0321	2719R	24		22-23-12	ALL
58		W0321	2719B	24		22-23-12	ALL
59	UNUSED						ALL
60	UNUSED						ALL
61		W0321	0168	22		22-23-11	ALL
62		W0321	0122	22		27-83-21	ALL
63		W0321	0315	22		31-53-11	ALL
64	UNUSED						ALL
65		W0321	0259	22		27-32-21	ALL
66	UNUSED						ALL
67	UNUSED						ALL
68		W0321	2165B	24		34-21-13	ALL
69	UNUSED						ALL
70	UNUSED						ALL
71	UNUSED						ALL
72	UNUSED						ALL
73	UNUSED						ALL
74		W0321	0287	24		27-32-21	ALL
75	UNUSED						ALL
76	UNUSED						ALL
77	UNUSED						ALL
78	UNUSED						ALL
79		W0321	0258	22		27-32-21	ALL
80	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685A		***/*/***		**PLUG (continued)**				**ALL**
	81	UNUSED						ALL
	82	UNUSED						ALL
	83	UNUSED						ALL
	84		W0321	0267	22		27-32-21	ALL
	85	UNUSED						ALL
	86	UNUSED						ALL
	87	UNUSED						ALL
	88		W0321	0240	22		22-23-11	ALL
	89	UNUSED						ALL
	90	UNUSED						ALL
	91	UNUSED						ALL
	92		W0321	0246	22		22-23-11	ALL
	93		W0321	0243	22		22-23-11	ALL
	94		W0321	2027B	24		27-32-22	ALL
	95		W0321	2027R	24		27-32-22	ALL
	96	UNUSED						ALL
	97	UNUSED						ALL
	98	UNUSED						ALL
	99	UNUSED						ALL
	100		W0321	0285	22		27-32-21	ALL
	101	UNUSED						ALL
	102		W0321	0231	22		22-23-11	ALL
	103	UNUSED						ALL
	104	UNUSED						ALL
	105		W0321	2507B	22		27-32-21	ALL
	106		W0321	0242	22		22-23-11	ALL
D03685B		***/*/***		**PLUG**				**ALL**
	1		W0321	0375	22		27-24-11	ALL
	2		W0321	0256	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685B	*/*/*		**PLUG (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0321	0025	22		27-24-11	ALL
14		W0321	0189	22		27-32-21	ALL
15	UNUSED						ALL
16		W0321	3721B	22		27-24-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0321	0265	24		27-32-21	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W0321	3721Y	22		27-24-11	ALL
30		W0321	3721R	22		27-24-11	ALL
31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685B		***/*/***		**PLUG (continued)**				**ALL**
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W0321	0283	22		27-32-21	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40		W0321	2720R	22		27-24-11	ALL
	41		W0321	2720B	22		27-24-11	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W0321	0284	22		27-32-21	ALL
	49		W0321	0282	22		27-32-21	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53		W0321	2062R	22		22-23-11	ALL
	54	UNUSED						ALL
	55		W0321	0248	22		27-32-21	ALL
	56		W0321	0255	22		27-32-21	ALL
	57	UNUSED						ALL
	58		W0321	3713Y	22		27-32-21	ALL
	59	UNUSED						ALL
	60	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03685B	*/*/*		**PLUG (continued)**				**ALL**
61	UNUSED						ALL
62	UNUSED						ALL
63	UNUSED						ALL
64		W0321	2750B	24		31-65-25	ALL
65		W0321	2750R	24		31-65-25	ALL
66		W0321	2212R	24		22-11-51	ALL
67	UNUSED						ALL
68	UNUSED						ALL
69	UNUSED						ALL
70	UNUSED						ALL
71		W0321	3713R	22		27-32-21	ALL
72		W0321	3713B	22		27-32-21	ALL
73	UNUSED						ALL
74		W0321	0269	22		27-32-21	ALL
75		W0321	0480	22		27-32-21	ALL
76		W0321	0268	22		27-32-21	ALL
77	UNUSED						ALL
78		W0321	0281	22		27-32-21	ALL
79		W0321	2212B	24		22-11-51	ALL
80	UNUSED						ALL
81		W0321	3010R	22		27-24-11	ALL
82		W0321	3010B	22		27-24-11	ALL
83	UNUSED						ALL
84	UNUSED						ALL
85	UNUSED						ALL
86		W0321	2063B	22		22-23-11	ALL
87	UNUSED						ALL
88	UNUSED						ALL
89	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03685B		***/*/***		**PLUG (continued)**				**ALL**
	90	UNUSED						ALL
	91		W0321	2048B	24		34-21-23	ALL
	92	UNUSED						ALL
	93		W0321	2145R	24		34-21-24	ALL
	94		W0321	2063R	22		22-23-11	ALL
	95		W0321	3010Y	22		27-24-11	ALL
	96	UNUSED						ALL
	97		W0321	3712B	22		27-32-21	ALL
	98		W0321	3712Y	22		27-32-21	ALL
	99		W0321	3712R	22		27-32-21	ALL
	100	UNUSED						ALL
	101	UNUSED						ALL
	102	UNUSED						ALL
	103	UNUSED						ALL
	104		W0321	2048R	24		34-21-23	ALL
	105	UNUSED						ALL
	106		W0321	2145B	24		34-21-24	ALL
D03687A		**E005-02/ /**		**PLUG - ADIRU LEFT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0521	2552R	24		34-21-14	ALL
	A04	UNUSED						ALL
	A05		W0521	2555R	24		34-21-14	ALL
	A06	UNUSED						ALL
	A07		W0523	2841R	24		34-21-14	ALL
	A08	UNUSED						ALL
	A09		W0521	2551R	24		34-21-14	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687A		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0521	2552B	24		34-21-14	ALL
	B04	UNUSED						ALL
	B05		W0521	2555B	24		34-21-14	ALL
	B06	UNUSED						ALL
	B07		W0523	2841B	24		34-21-14	ALL
	B08	UNUSED						ALL
	B09		W0521	2551B	24		34-21-14	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0521	2722R	24		34-21-14	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09		W0521	0206	22		34-16-11	ALL
	C10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687A		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06		W0521	2539R	24		34-21-13	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0521	2531R	24		34-21-12	ALL
	D10		W0521	2584R	24		34-21-12	ALL
	D11	UNUSED						ALL
	D12		W0521	2722B	24		34-21-14	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0521	0326	22		34-21-11	ALL
	E02		W0521	0325	22		34-21-11	ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06		W0521	2539B	24		34-21-13	ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0521	2531B	24		34-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687A	**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
E10		W0521	2584B	24		34-21-12	ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02		W0521	0340	22		34-21-11	ALL
F03		W0521	0265	22		34-21-12	ALL
F04		W0521	0186	22		34-21-12	ALL
F05		W0521	0205	22		34-16-11	ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09		W0521	0163	22		34-21-11	ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13		W0523	2757R	24		31-65-25	ALL
F14		W0521	0235	22		34-21-11	ALL
F15		W0521	2578R	24		31-65-15	ALL
G01		W0521	0161	22		34-21-11	ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06		W0521	3502R	22		34-21-12	ALL
G07	UNUSED						ALL
G08		W0521	0162	22		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687A		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	G09	UNUSED						ALL
	G10		W0521	0164	22		34-21-11	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13		W0523	2757B	24		31-65-25	ALL
	G14	UNUSED						ALL
	G15		W0521	2578B	24		31-65-15	ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06		W0521	3502B	22		34-21-12	ALL
	H07		W0521	3001B	24		34-21-12	ALL
	H08		W0521	2532R	22		34-21-12	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0521	0184	22		34-21-12	ALL
	J04		W0521	0185	22		34-21-12	ALL
	J05	UNUSED						ALL
	J06		W0521	3502Y	22		34-21-12	ALL
	J07		W0521	3001R	24		34-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687A	**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
J08		W0521	2532B	22		34-21-12	ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0521	0324	22		34-21-11	ALL
K02	UNUSED						ALL
K03		W0521	0165	22		34-21-11	ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07		W0521	3001Y	24		34-21-12	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
DED		W0521	2539Z			34-21-13	ALL
PERG	1A	W0521	2531Z			34-21-12	ALL
PERG	1A	W0521	2532Z			34-21-12	ALL
PERG	1A	W0521	2551Z			34-21-14	ALL
PERG	1A	W0521	2552Z			34-21-14	ALL
PERG	1A	W0521	2555Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03687A		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	PERG	1A	W0521	2578Z			31-65-15	ALL
	PERG	1A	W0521	2584Z			34-21-12	ALL
	PERG	1A	W0521	2722Z			34-21-14	ALL
	PERG	1A	W0521	3502Z			34-21-12	ALL
	PERG	1A	W0523	2757Z			31-65-25	ALL
	PERG	1A	W0523	2841Z			34-21-14	ALL
D03687B		**E005-02/ /**		**PLUG - ADIRU LEFT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0521	0174	22		34-21-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0521	0151	22		34-21-11	ALL
	A07		W0521	0151	22		34-21-11	ALL
	A08		W0521	2505R	24		34-61-14	ALL
	A09		W0521	2505B	24		34-61-14	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0523	2709R	24		34-61-14	ALL
	A14		W0523	2709B	24		34-61-14	ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0521	2754R	24		34-21-13	ALL
	B03		W0521	2754B	24		34-21-13	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687B	**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01		W0523	2867R	24		34-58-21	ALL
C02		W0523	2867B	24		34-58-21	ALL
C03		W0521	0236	22		34-21-11	ALL
C04	UNUSED						ALL
C05		W0521	2751R	24		34-21-11	ALL
C06		W0521	2751B	24		34-21-11	ALL
C07		W0523	2868R	24		34-58-21	ALL
C08		W0523	2868B	24		34-58-21	ALL
C09	UNUSED						ALL
C10		W0521	2535R	24		34-21-13	ALL
C11		W0521	2535B	24		34-21-13	ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01		W0521	0170	24		34-21-11	ALL
D02		W0521	0246	24		34-21-11	ALL
D03		W0521	0173	22		34-21-11	ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687B		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14		W0521	2804R	24		34-58-11	ALL
	D15		W0521	2804B	24		34-58-11	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05		W0521	2538R	24		34-21-13	ALL
	E06		W0521	2538B	24		34-21-13	ALL
	E07		W0521	0175	22		34-21-11	ALL
	E08	UNUSED						ALL
	E09		W0521	0166	22		34-21-11	ALL
	E10		W0521	0155	22		34-21-11	ALL
	E11		W0521	0157	22		34-21-11	ALL
	E12		W0521	0156	22		34-21-11	ALL
	E13		W0521	0180	22		34-21-11	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01		W0521	0178	22		34-21-11	ALL
	F02		W0521	0179	22		34-21-11	ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687B		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07		W0521	2542R	24		34-21-13	ALL
	G08		W0521	2542B	24		34-21-13	ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687B		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0521	0237	22		34-21-11	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14		W0521	2805R	24		34-58-11	ALL
	J15		W0521	2805B	24		34-58-11	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0521	0177	22		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687B	**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
K04		W0521	2549R	24		34-21-14	ALL
K05		W0521	2549B	24		34-21-14	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09		W0521	0176	22		34-21-11	ALL
K10	UNUSED						ALL
K11		W0521	2539R	24		34-21-13	ALL
K12		W0521	2539B	24		34-21-13	ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15		W0521	0150	22		34-21-11	ALL
DED		W0521	2539Z			34-21-13	ALL
PERG	1A	W0521	2505Z			34-61-14	ALL
PERG	1A	W0521	2535Z			34-21-13	ALL
PERG	1A	W0521	2538Z			34-21-13	ALL
PERG	1A	W0521	2542Z			34-21-13	ALL
PERG	1A	W0521	2549Z			34-21-14	ALL
PERG	1A	W0521	2751Z			34-21-11	ALL
PERG	1A	W0521	2754Z			34-21-13	ALL
PERG	1A	W0521	2804Z			34-58-11	ALL
PERG	1A	W0521	2805Z			34-58-11	ALL
PERG	1A	W0523	2709Z			34-61-14	ALL
PERG	1A	W0523	2867Z			34-58-21	ALL
PERG	1A	W0523	2868Z			34-58-21	ALL
D03687C	**E005-02/ /**		**PLUG - ADIRU LEFT**				**ALL**
1		W0521	0140	20		34-21-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03687C		**E005-02/ /**		**PLUG - ADIRU LEFT (continued)**				**ALL**
	4		W0521	0145	20		34-21-11	ALL
	5		W0521	0141	20		34-21-11	ALL
	6	UNUSED						ALL
	7		W0521	0182	16		34-21-11	ALL
	8		W0521	0146	20		34-21-11	ALL
	9	UNUSED						ALL
	10		W0521	0144	20		34-21-11	ALL
	11		W0521	0142	20		34-21-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D03689		**200/177/L14**		**PLUG - AIR DATA MODULE - L - PITOT**				**ALL**
	1		W5501	3501R	22		34-21-12	ALL
	2	UNUSED						ALL
	3		W5501	3501B	22		34-21-12	ALL
	4	UNUSED						ALL
	5		W5501	3501Y	22		34-21-12	ALL
	6	UNUSED						ALL
	7		W5501	2501R	24		34-21-12	ALL
	8		W5501	2501B	24		34-21-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5501	0002	22		34-21-12	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03689	**200/177/L14**		**PLUG - AIR DATA MODULE - L - PITOT (continued)**				**ALL**
17		W5501	0002	22		34-21-12	ALL
18		W5501	0001	20		34-21-12	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
PERB		W5501	2501Z			34-21-12	ALL
PERB		W5501	3501Z			34-21-12	ALL
D03691	**408/205/R002**		**PLUG - AIR DATA MODULE-L - STATIC**				**ALL**
1		W5161	3501R	22		34-21-12	ALL
2	UNUSED						ALL
3		W5161	3501B	22		34-21-12	ALL
4	UNUSED						ALL
5		W5161	3501Y	22		34-21-12	ALL
6	UNUSED						ALL
7		W5161	2527R	24		34-21-12	ALL
8		W5161	2527B	24		34-21-12	ALL
9		W5161	0016	22		34-21-12	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5161	0016	22		34-21-12	ALL
13		W5161	0015	22		34-21-12	ALL
14		W5161	0014	22		34-21-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W5161	0014	22		34-21-12	ALL
18		W5161	0017	20		34-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03691		**408/205/R002**		**PLUG - AIR DATA MODULE-L - STATIC (continued)**				**ALL**
	19	UNUSED						ALL
	20		W5161	0015	22		34-21-12	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	PERB		W5161	2527Z			34-21-12	ALL
	PERB		W5161	3501Z			34-21-12	ALL
D03693A		**E005-02/ /**		**PLUG - ADIRU RIGHT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0523	2741R	24		34-21-24	ALL
	A04	UNUSED						ALL
	A05		W0523	2746R	24		34-21-24	ALL
	A06	UNUSED						ALL
	A07		W0523	2744R	24		34-21-24	ALL
	A08	UNUSED						ALL
	A09		W0523	2743R	24		34-21-24	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0523	2741B	24		34-21-24	ALL
	B04	UNUSED						ALL
	B05		W0523	2746B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693A		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W0523	2744B	24		34-21-24	ALL
	B08	UNUSED						ALL
	B09		W0523	2743B	24		34-21-24	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0523	2859R	24		34-21-24	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09		W0523	0387	22		34-16-21	ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03693A		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	D05	UNUSED						ALL
	D06		W0523	2731R	24		34-21-23	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0523	2722R	24		34-21-22	ALL
	D10		W0523	2721R	24		34-21-22	ALL
	D11	UNUSED						ALL
	D12		W0523	2859B	24		34-21-24	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0523	0401	22		34-21-21	ALL
	E02		W0523	0400	22		34-21-21	ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06		W0523	2731B	24		34-21-23	ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0523	2722B	24		34-21-22	ALL
	E10		W0523	2721B	24		34-21-22	ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02		W0523	0003	22		34-21-21	ALL
	F03		W0523	0266	22		34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693A		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	F04		W0521	0233	22		34-21-22	ALL
	F05		W0523	0386	22		34-16-21	ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09		W0523	0339	22		34-21-21	ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0521	2577R	24		31-65-15	ALL
	F14		W0523	0313	22		34-21-21	ALL
	F15		W0523	2758R	24		31-65-25	ALL
	G01		W0523	0342	22		34-21-21	ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06		W0523	3602R	22		34-21-22	ALL
	G07	UNUSED						ALL
	G08		W0523	0341	22		34-21-21	ALL
	G09	UNUSED						ALL
	G10		W0523	0340	22		34-21-21	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13		W0521	2577B	24		31-65-15	ALL
	G14	UNUSED						ALL
	G15		W0523	2758B	24		31-65-25	ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693A		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06		W0523	3602B	22		34-21-22	ALL
	H07		W0523	3101B	24		34-21-22	ALL
	H08		W0521	2619R	22		34-21-22	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0523	0369	22		34-21-22	ALL
	J04		W0523	0370	22		34-21-22	ALL
	J05	UNUSED						ALL
	J06		W0523	3602Y	22		34-21-22	ALL
	J07		W0523	3101R	24		34-21-22	ALL
	J08		W0521	2619B	22		34-21-22	ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0523	0399	22		34-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693A	**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
K02	UNUSED						ALL
K03		W0523	0343	22		34-21-21	ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07		W0523	3101Y	24		34-21-22	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
DED		W0523	2731Z			34-21-23	ALL
PERG	1A	W0521	2577Z			31-65-15	ALL
PERG	1A	W0521	2619Z			34-21-22	ALL
PERG	1A	W0523	2721Z			34-21-22	ALL
PERG	1A	W0523	2722Z			34-21-22	ALL
PERG	1A	W0523	2741Z			34-21-24	ALL
PERG	1A	W0523	2743Z			34-21-24	ALL
PERG	1A	W0523	2744Z			34-21-24	ALL
PERG	1A	W0523	2746Z			34-21-24	ALL
PERG	1A	W0523	2758Z			31-65-25	ALL
PERG	1A	W0523	2859Z			34-21-24	ALL
PERG	1A	W0523	3602Z			34-21-22	ALL
D03693B	**E005-02/ /**		**PLUG - ADIRU RIGHT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	A03		W0523	0353	22		34-21-21	ALL
	A04	UNUSED						ALL
	A05		W0523	0349	22		34-21-21	ALL
	A06	UNUSED						ALL
	A07		W0523	0349	22		34-21-21	ALL
	A08		W0521	2528R	24		34-61-14	ALL
	A09		W0521	2528B	24		34-61-14	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0523	2718R	24		34-61-14	ALL
	A14		W0523	2718B	24		34-61-14	ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01		W0521	2806R	24		34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	C02		W0521	2806B	24		34-58-11	ALL
	C03		W0523	0315	22		34-21-21	ALL
	C04	UNUSED						ALL
	C05		W0523	2720R	24		34-21-21	ALL
	C06		W0523	2720B	24		34-21-21	ALL
	C07		W0521	2808R	24		34-58-11	ALL
	C08		W0521	2808B	24		34-58-11	ALL
	C09	UNUSED						ALL
	C10		W0523	2726R	24		34-21-23	ALL
	C11		W0523	2726B	24		34-21-23	ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01		W0523	0346	22		34-21-21	ALL
	D02		W0523	0347	22		34-21-21	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14		W0523	2865R	24		34-58-21	ALL
	D15		W0523	2865B	24		34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05		W0523	2729R	24		34-21-23	ALL
	E06		W0523	2729B	24		34-21-23	ALL
	E07		W0523	0354	22		34-21-21	ALL
	E08	UNUSED						ALL
	E09		W0523	0345	22		34-21-21	ALL
	E10		W0523	0360	22		34-21-21	ALL
	E11		W0523	0367	22		34-21-21	ALL
	E12		W0523	0359	22		34-21-21	ALL
	E13		W0523	0352	22		34-21-21	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01		W0523	0350	22		34-21-21	ALL
	F02		W0523	0351	22		34-21-21	ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B	**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
F15	UNUSED						ALL
G01	UNUSED						ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07		W0523	2734R	24		34-21-23	ALL
G08		W0523	2734B	24		34-21-23	ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL
G13	UNUSED						ALL
G14	UNUSED						ALL
G15	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0523	0314	22		34-21-21	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14		W0523	2866R	24		34-58-21	ALL
	J15		W0523	2866B	24		34-58-21	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0523	0356	22		34-21-21	ALL
	K04		W0523	2740R	24		34-21-24	ALL
	K05		W0523	2740B	24		34-21-24	ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09		W0523	0355	22		34-21-21	ALL
	K10	UNUSED						ALL
	K11		W0523	2731R	24		34-21-23	ALL
	K12		W0523	2731B	24		34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693B		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15		W0523	0368	22		34-21-21	ALL
	DED		W0523	2731Z			34-21-23	ALL
	PERG	1A	W0521	2528Z			34-61-14	ALL
	PERG	1A	W0521	2806Z			34-58-11	ALL
	PERG	1A	W0521	2808Z			34-58-11	ALL
	PERG	1A	W0523	2718Z			34-61-14	ALL
	PERG	1A	W0523	2720Z			34-21-21	ALL
	PERG	1A	W0523	2726Z			34-21-23	ALL
	PERG	1A	W0523	2729Z			34-21-23	ALL
	PERG	1A	W0523	2734Z			34-21-23	ALL
	PERG	1A	W0523	2740Z			34-21-24	ALL
	PERG	1A	W0523	2865Z			34-58-21	ALL
	PERG	1A	W0523	2866Z			34-58-21	ALL
D03693C		**E005-02/ /**		**PLUG - ADIRU RIGHT**				**ALL**
	1		W0523	0332	20		34-21-21	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0523	0331	20		34-21-21	ALL
	5		W0523	0333	20		34-21-21	ALL
	6	UNUSED						ALL
	7		W0523	0335	20		34-21-21	ALL
	8		W0523	0336	20		34-21-21	ALL
	9	UNUSED						ALL
	10		W0523	0330	20		34-21-21	ALL
	11		W0523	0334	20		34-21-21	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03693C		**E005-02/ /**		**PLUG - ADIRU RIGHT (continued)**				**ALL**
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D03695		**201/177/R18**		**PLUG - AIR DATA MODULE - R - PITOT**				**ALL**
	1		W5503	3501R	22		34-21-22	ALL
	2	UNUSED						ALL
	3		W5503	3501B	22		34-21-22	ALL
	4	UNUSED						ALL
	5		W5503	3501Y	22		34-21-22	ALL
	6	UNUSED						ALL
	7		W5503	2501R	24		34-21-22	ALL
	8		W5503	2501B	24		34-21-22	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5503	0002	22		34-21-22	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5503	0002	22		34-21-22	ALL
	18		W5503	0001	20		34-21-22	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	PERB		W5503	2501Z			34-21-22	ALL
	PERB		W5503	3501Z			34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03697	**430/205/L002**		**PLUG - AIR DATA MODULE-R - STATIC**				**ALL**
1		W5163	3501R	22		34-21-22	ALL
2	UNUSED						ALL
3		W5163	3501B	22		34-21-22	ALL
4	UNUSED						ALL
5		W5163	3501Y	22		34-21-22	ALL
6	UNUSED						ALL
7		W5163	2526R	24		34-21-22	ALL
8		W5163	2526B	24		34-21-22	ALL
9		W5163	0016	22		34-21-22	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5163	0016	22		34-21-22	ALL
13		W5163	0015	22		34-21-22	ALL
14		W5163	0014	22		34-21-22	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W5163	0014	22		34-21-22	ALL
18		W5163	0017	20		34-21-22	ALL
19	UNUSED						ALL
20		W5163	0015	22		34-21-22	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
PERB		W5163	2526Z			34-21-22	ALL
PERB		W5163	3501Z			34-21-22	ALL
D03699	**302/180/R020**		**PLUG -**				**ALL**
=A1		W7137	001CX			34-51-11	ALL
=C1		W7137	001CO			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03732		**298/288/L010**		**PLUG-LAV A**				**ALL**
	1		W3144	0101	18		33-26-31	ALL
	2		W3144	0102	22		33-27-11	ALL
	3		W3144	0103	20		33-26-31	ALL
	4		W3144	0104	20		33-26-31	ALL
	5	UNUSED						ALL
	6		W3144	0106	20		33-26-31	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3144	2401R	22		23-31-02	ALL
	14		W3144	2401B	22		23-31-02	ALL
	15		W3144	0115	18		35-21-21	ALL
	16	UNUSED						ALL
	17		W3144	0117	22		33-27-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W3144	0122	18		35-21-21	ALL
	23		W3144	0123	22		26-14-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W3144	0127	20		33-25-11	ALL
	28		W3144	0128	20		33-25-11	ALL
	29		W3144	0129	22		33-27-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03732	**298/288/L010**		**PLUG-LAV A (continued)**				**ALL**
30		W3144	0130	18		33-26-31	ALL
31		W3144	0131	18		38-32-12	ALL
32		W3144	0132	20		33-25-21	ALL
33		W3144	0133	20		33-25-21	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W3144	0138	22		38-21-11	ALL
39		W3144	0139	18		33-26-31	ALL
40		W3144	0140	18		33-26-31	ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W3144	0143	20		38-32-12	ALL
CAP	Y	W3144	0015	20		SPARE	ALL
CAP	Y	W3144	0016	20		SPARE	ALL
D03738	**937/289/L018**		**PLUG-LAV D**				**ALL**
1		W3144	0301	18		33-26-31	ALL
2		W3144	0302	22		33-27-22	ALL
3		W3144	0303	20		33-26-31	ALL
4		W3144	0304	20		33-26-31	ALL
5	UNUSED						ALL
6		W3144	0306	20		33-26-31	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W3144	0310	20		33-51-22	ALL
11		W3144	0311	20		33-51-22	ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03738		**937/289/L018**		**PLUG-LAV D (continued)**				**ALL**
	13		W3144	2403R	22		23-31-02	ALL
	14		W3144	2403B	22		23-31-02	ALL
	15		W3144	0315	18		35-21-21	ALL
	16	UNUSED						ALL
	17		W3144	0317	22		33-27-22	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W3144	0322	18		35-21-21	ALL
	23		W3144	0323	22		26-14-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W3144	0327	20		33-25-11	ALL
	28		W3144	0328	20		33-25-11	ALL
	29		W3144	0329	22		33-27-22	ALL
	30		W3144	0330	18		33-26-31	ALL
	31		W3144	0331	18		38-32-12	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38		W3144	0338	22		38-21-11	ALL
	39		W3144	0339	18		33-26-31	ALL
	40		W3144	0340	18		33-26-31	ALL
	41	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03738	**937/289/L018**		**PLUG-LAV D (continued)**				**ALL**
42	UNUSED						ALL
43		W3144	0343	20		38-32-12	ALL
CAP	Y	W3144	0013	20		SPARE	ALL
CAP	Y	W3144	0014	20		SPARE	ALL
D03740	**937/289/R018**		**PLUG-LAV E**				**ALL**
1		W3144	0351	18		33-26-31	ALL
2		W3144	0352	22		33-27-32	ALL
3		W3144	0304	20		33-26-31	ALL
4		W3144	0354	20		33-26-31	ALL
5	UNUSED						ALL
6		W3144	0356	20		33-26-31	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W3144	2404R	22		23-31-03	ALL
14		W3144	2404B	22		23-31-03	ALL
15		W3144	0365	18		35-21-31	ALL
16	UNUSED						ALL
17		W3144	0367	22		33-27-32	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W3144	0372	18		35-21-31	ALL
23		W3144	0373	22		26-14-11	ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03740		**937/289/R018**		**PLUG-LAV E (continued)**				**ALL**
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W3144	0377	20		33-25-11	ALL
	28		W3144	0378	20		33-25-11	ALL
	29		W3144	0379	22		33-27-32	ALL
	30		W3144	0380	18		33-26-31	ALL
	31		W3144	0381	18		38-32-12	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38		W3144	0388	22		38-21-11	ALL
	39		W3144	0389	18		33-26-31	ALL
	40		W3144	0390	18		33-26-31	ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43		W3144	0393	20		38-32-12	ALL
D03768		**245/205/R02**		**RELAY SOCKET**				**ALL**
	A1		W6206	5547	14		33-11-33	ALL
	A2		W6206	5548	14		33-11-33	ALL
	A3		W6206	5546	16		33-11-33	ALL
	B1		W6206	5505	14		33-11-33	ALL
	B2		W6206	5510	16		33-11-33	ALL
	B3		W6206	5504	16		33-11-33	ALL
	C1		W6206	5507	16		33-11-33	ALL
	C2		W6206	5511	16		33-11-33	ALL
	C3		W6206	5506	16		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03768	**245/205/R02**		**RELAY SOCKET (continued)**				**ALL**
D1		W6206	5544	16		33-11-33	ALL
D2		W6206	5545	16		33-11-33	ALL
D3		W6206	5543	16		33-11-33	ALL
X1		W6206	5509	16		33-11-33	ALL
X2		W6206	5508	16		33-11-33	ALL
D03779	**303/178/R020**		**PLUG -**				**ALL**
=A1		W5137	001CX			34-31-11	ALL
=C1		W5137	001CO			34-31-11	ALL
D03781	**309/180/R021**		**PLUG -**				**ALL**
=A1		W7191	001CX			34-51-11	ALL
=C1		W7191	001CO			34-51-11	ALL
D03783	**308/180/R20**		**PLUG -**				**ALL**
=A1		W8137	001CX			34-51-21	ALL
=C1		W8137	001CO			34-51-21	ALL
D03785	**309/178/R020**		**PLUG -**				**ALL**
=A1		W5139	001CX			34-31-21	ALL
=C1		W5139	001CO			34-31-21	ALL
D03787	**302/180/R020**		**PLUG -**				**ALL**
=A1		W8195	001CX			34-51-21	ALL
=C1		W8195	001CO			34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03800		**998/295/R025**		**RCPT-**				**ALL**
	A		W3154	0007	08		25-31-11	ALL
	B		W3154	0008	08		25-31-11	ALL
	C		W3154	0009	08		25-31-11	ALL
	D		W3154	0010	08		25-31-11	ALL
D03802		**1000/295/R024**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W3144	0095	20		33-25-22	ALL
	6		W3144	0096	20		33-25-22	ALL
	7		W3144	0097	20		33-25-22	ALL
D03854		**525/165/R018**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W6230	0323	14		21-25-11	ALL
	3		W6230	0324	14		21-25-11	ALL
	4		W6230	0325	14		21-25-11	ALL
	5		W6230	0327	20		21-25-11	ALL
	6		W6230	0326	22		21-25-11	ALL
	7		W6230	0328	14		21-25-11	ALL
	8	UNUSED						ALL
D03856		**500I+7/165/L018**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5104	0326	14		21-25-11	ALL
	3		W5104	0325	14		21-25-11	ALL
	4		W5104	0324	14		21-25-11	ALL
	5		W5104	0328	20		21-25-11	ALL
	6		W5104	0310	22		21-25-11	ALL
	7		W5104	0327	14		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03856	**500I+7/165/L018**		**PLUG- (continued)**				**ALL**
8	UNUSED						ALL
D03862	**645/146/L013**		**PLUG-**				**ALL**
1		W5102	2078B	20		21-51-12	ALL
2		W5102	2078R	20		21-51-12	ALL
3		W5102	1027	20		21-51-12	ALL
4		W5102	2077B	20		21-51-12	ALL
5		W5102	1028	20		21-51-12	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5102	2076R	20		21-51-12	ALL
11		W5102	2076B	20		21-51-12	ALL
12		W5102	2077R	20		21-51-12	ALL
13		W5102	0015	20		21-51-12	ALL
14	UNUSED						ALL
15	UNUSED						ALL
D03864	**646/154/L035**		**PLUG-**				**ALL**
1		W5102	2081B	20		21-51-13	ALL
2		W5102	5544	20		21-51-13	ALL
3		W5102	2081R	20		21-51-13	ALL
4	UNUSED						ALL
5	UNUSED						ALL
CAP	Y	W5102	2090B	20		21-51-14	ALL
CAP	Y	W5102	2090R	20		21-51-14	ALL
D03866	**573/154/L030**		**PLUG-**				**ALL**
1		W5102	2079B	20		21-51-12	ALL
2		W5102	2079R	20		21-51-12	ALL
3		W5102	2080B	20		21-51-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03866		**573/154/L030**		**PLUG- (continued)**				**ALL**
	4		W5102	2080R	20		21-51-13	ALL
	5	UNUSED						ALL
D03868		**500I+7/192/L003**		**PLUG**				**ALL**
	1		W5104	2001B	20		21-51-12	ALL
	2		W5104	2001R	20		21-51-12	ALL
D03872		**644/148/R013**		**PLUG-**				**ALL**
	1		W6202	2078B	20		21-51-22	ALL
	2		W6202	2078R	20		21-51-22	ALL
	3		W6202	1032	20		21-51-22	ALL
	4		W6202	2077B	20		21-51-22	ALL
	5		W6202	1033	20		21-51-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6202	2076R	20		21-51-22	ALL
	11		W6202	2076B	20		21-51-22	ALL
	12		W6202	2077R	20		21-51-22	ALL
	13		W6202	5552	20		21-51-22	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
D03874		**646/151/R035**		**PLUG-**				**ALL**
	1		W6202	2081B	20		21-51-23	ALL
	2		W6202	5553	20		21-51-23	ALL
	3		W6202	2081R	20		21-51-23	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	CAP	Y	W6202	2090B	20		21-51-24	ALL
	CAP	Y	W6202	2090R	20		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03876	**573/154/R030**		**PLUG-**				**ALL**
1		W6202	2079B	20		21-51-22	ALL
2		W6202	2079R	20		21-51-22	ALL
3		W6202	2080B	20		21-51-23	ALL
4		W6202	2080R	20		21-51-23	ALL
5	UNUSED						ALL
D03878	**500I+7/194/R004**		**PLUG-**				**ALL**
1		W6230	2001R	20		21-51-22	ALL
2		W6230	2001B	20		21-51-22	ALL
D03882	**372/195/L055**		**PLUG-**				**ALL**
1		W6214	2006R	20		21-61-12	ALL
2		W6214	2006B	20		21-61-12	ALL
D03884	**372/196/L057**		**PLUG-**				**ALL**
1		W6214	2005R	20		21-61-11	ALL
2		W6214	2005B	20		21-61-11	ALL
D03886	**542/157/L13**		**PLUG-**				**ALL**
1		W5502	2083B	20		21-61-11	ALL
2		W5502	2083R	20		21-61-11	ALL
3		W5502	1035	20		21-61-11	ALL
4		W5502	2084R	20		21-61-11	ALL
5		W5502	1038	20		21-61-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5502	1037	20		21-61-11	ALL
11		W5502	1039	20		21-61-11	ALL
12		W5502	2084B	20		21-61-11	ALL
13		W5502	0006	20		21-61-11	ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03886		**542/157/L13**		**PLUG- (continued)**				**ALL**
	15	UNUSED						ALL
D03888		**539/152/R012**		**PLUG-**				**ALL**
	1		W6202	2083B	20		21-61-13	ALL
	2		W6202	2083R	20		21-61-13	ALL
	3		W6202	1038	20		21-61-13	ALL
	4		W6202	2084R	20		21-61-13	ALL
	5		W6202	1040	20		21-61-13	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6202	1039	20		21-61-13	ALL
	11		W6202	1041	20		21-61-13	ALL
	12		W6202	2084B	20		21-61-13	ALL
	13		W6202	5564	20		21-61-13	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
D03890		**548/153/R017**		**PLUG-**				**ALL**
	1		W6202	2085B	20		21-61-14	ALL
	2		W6202	2085R	20		21-61-14	ALL
	3		W6202	1042	20		21-61-14	ALL
	4		W6202	2086R	20		21-61-14	ALL
	5		W6202	1045	20		21-61-14	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6202	1043	20		21-61-14	ALL
	11		W6202	1046	20		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03890		**548/153/R017**		**PLUG- (continued)**				**ALL**
	12		W6202	2086B	20		21-61-14	ALL
	13		W6202	5567	20		21-61-14	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	DED		W6202	1042Z			21-61-14	ALL
	DED		W6202	1043Z			21-61-14	ALL
	DED		W6202	1045Z			21-61-14	ALL
	DED		W6202	1046Z			21-61-14	ALL
	DED		W6202	2085Z			21-61-14	ALL
	DED		W6202	2086Z			21-61-14	ALL
D03892		**373/194/L058**		**PLUG-**				**ALL**
	1		W6214	5551	20		21-61-11	ALL
	2		W6214	5552	20		21-61-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03914		**557/147/R014**		**PLUG-**				**ALL**
	1		W6502	1009	20		21-61-15	ALL
	2		W6502	5501	20		21-61-15	ALL
	3		W6502	5519	20		21-61-15	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D03916		**584/162/L032**		**PLUG-**				**ALL**
	1		W5102	2082B	20		21-51-14	ALL
	2		W5102	2082R	20		21-51-14	ALL
D03918		**584/162/R032**		**PLUG-**				**ALL**
	1		W6202	2082B	20		21-51-24	ALL
	2		W6202	2082R	20		21-51-24	ALL
D03924		**371/194/L058**		**PLUG-**				**ALL**
	A		W6214	5554	20		21-61-51	ALL
	B		W6214	5553	20		21-61-51	ALL
D03930		**573/152/L033**		**PLUG-**				**ALL**
	A		W5102	1050	20		21-61-51	ALL
	B		W5102	1049	20		21-61-51	ALL
D03940		**520/166/R027**		**PLUG-**				**ALL**
	1		W5526	5532	20		21-51-15	ALL
	2		W5526	5523	20		21-51-15	ALL
D03942		**521/160/R015**		**PLUG-**				**ALL**
	1		W6528	0309	20		21-51-25	ALL
	2		W6528	0301	20		21-51-25	ALL
D03982		**573/152/R033**		**PLUG-**				**ALL**
	A		W6202	0016	20		21-61-51	ALL
	B		W6202	1049	20		21-61-51	ALL
D03991		**P003-01/ /**		**PLUG-- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03991	**P003-01/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
3		W0003	1696	20		33-18-22	ALL
4		W0003	0697	20		33-18-22	ALL
5		W0003	1695	20		33-18-22	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0003	1519	22		27-62-11	ALL
11		W0003	1629	24		34-49-11	ALL
12		W0003	1627	24		34-49-11	ALL
13		W0003	1628	22		34-49-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W0003	1519Z			27-62-11	ALL
S/R		W0003	1627Z			34-49-11	ALL
S/R		W0003	1628Z			34-49-11	ALL
S/R		W0003	1629Z			34-49-11	ALL
S/R		W0003	1695Z			33-18-22	ALL
S/R		W0003	1696Z			33-18-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D03996		**P005-17/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2508	5567	20		33-18-36	ALL
	4		W2216	3002Y	24		21-61-12	ALL
	5		W2216	3002R	24		21-61-12	ALL
	6		W2216	3002B	24		21-61-12	ALL
	7		W2216	5503	24		21-61-11	ALL
	8		W2216	5553	24		21-61-11	ALL
	9		W2216	3001Y	24		21-61-11	ALL
	10		W2216	3001R	24		21-61-11	ALL
	11		W2216	3001B	24		21-61-11	ALL
	12		W2216	5560	20		21-61-11	ALL
	13		W2114	5525	20		21-61-51	ALL
	14		W2216	3003B	24		21-61-14	ALL
	15		W2216	3003R	24		21-61-14	ALL
	16		W2216	3003Y	24		21-61-14	ALL
	17		W2216	5564	20		21-61-14	ALL
	18		W2216	5563	24		21-61-14	ALL
	19		W2216	5561	20		21-61-11	ALL
	20		W2216	5529	24		21-61-14	ALL
	21		W2216	3004B	24		21-61-14	ALL
	22		W2216	3004R	24		21-61-14	ALL
	23		W2216	3004Y	24		21-61-14	ALL
	24		W2216	5513	24		21-61-51	ALL
D03998		**P005-17/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W2216	5653	20		33-12-11	ALL
	3		W2114	5523	24		21-61-51	ALL
	4		W2218	3002Y	24		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03998	**P005-17/ /**		**PLUG- (continued)**				**ALL**
5		W2218	3002B	24		21-61-13	ALL
6		W2218	3002R	24		21-61-13	ALL
7		W2218	5552	24		21-61-13	ALL
8		W2218	5556	24		21-61-13	ALL
9		W2218	3001Y	24		21-61-13	ALL
10		W2218	3001R	24		21-61-13	ALL
11		W2218	3001B	24		21-61-13	ALL
12		W2218	5565	20		21-61-13	ALL
13		W2218	5566	20		21-61-15	ALL
14		W2218	5567	20		21-61-15	ALL
15		W2218	5568	22		21-61-15	ALL
16		W2218	5569	20		21-61-15	ALL
17		W2114	5522	24		21-61-51	ALL
18		W2114	5521	24		21-61-51	ALL
19		W2216	5511	24		21-61-51	ALL
20		W2114	5507	24		21-61-51	ALL
21		W2508	5570	20		33-18-36	ALL
22		W2508	5603	20		33-18-36	ALL
23		W2216	5652	20		33-12-11	ALL
24		W2216	5510	24		21-61-51	ALL
D03999	**P003-01/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D03999		**P003-01/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W0001	1060	22		21-33-11	ALL
	18	UNUSED						ALL
	19		W0001	1062	22		31-53-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W0001	1060Z			21-33-11	ALL
	S/R		W0001	1062Z			31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04007J	**E004-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0411	2614R	24		23-27-37	ALL
A10	UNUSED						ALL
B01		W0411	0099	22		23-27-31	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0411	2614B	24		23-27-37	ALL
B10	UNUSED						ALL
PERG	1F	W0411	2614Z			23-27-37	ALL
D04007P	**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5335	0001	22		SPARE	ALL
A02		W5335	0003	22		SPARE	ALL
A03		W5335	2561R	24		SPARE	ALL
A04	UNUSED						ALL
A05		W5335	2566ZI			SPARE	ALL
A06		W5335	2566R	24		SPARE	ALL
A07		W5335	2510R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04007P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08		W5335	2501R	24		SPARE	ALL
	A09		W5335	2502R	24		23-27-37	ALL
	A10		W5335	2503R	24		SPARE	ALL
	B01		W5335	0002	22		23-27-31	ALL
	B02		W5335	0004	22		SPARE	ALL
	B03		W5335	2561B	24		SPARE	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5335	2566B	24		SPARE	ALL
	B07		W5335	2510B	24		SPARE	ALL
	B08		W5335	2501B	24		SPARE	ALL
	B09		W5335	2502B	24		23-27-37	ALL
	B10		W5335	2503B	24		SPARE	ALL
	PERG	1F	W5335	2501Z			SPARE	ALL
	PERG	1F	W5335	2502Z			23-27-37	ALL
	PERG	1F	W5335	2503Z			SPARE	ALL
	PERG	1F	W5335	2510Z			SPARE	ALL
	PERG	1F	W5335	2561Z			SPARE	ALL
	PERG	1F	W5335	2566ZO			SPARE	ALL
D04009J		**E004-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0411	2620R	24		34-61-23	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0411	2661R	24		34-45-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04009J		**E004-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A10		W0411	2608R	24		23-27-33	ALL
	B01	UNUSED						ALL
	B02		W0411	2620B	24		34-61-23	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0411	2661B	24		34-45-21	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0411	2608B	24		23-27-33	ALL
	PERG	1F	W0411	2608Z			23-27-33	ALL
	PERG	1F	W0411	2620Z			34-61-23	ALL
	PERG	1F	W0411	2661Z			34-45-21	ALL
D04009P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5335	2504R	24		SPARE	ALL
	A02		W5335	2505R	24		34-61-23	ALL
	A03		W5335	2506R	24		SPARE	ALL
	A04		W5335	2507R	24		SPARE	ALL
	A05		W5335	2508R	24		SPARE	ALL
	A06		W5335	2509R	24		SPARE	ALL
	A07		W5335	2511R	24		34-45-21	ALL
	A08		W5335	2513R	24		SPARE	ALL
	A09		W5335	2567R	24		SPARE	ALL
	A10		W5335	2562R	24		23-27-33	ALL
	B01		W5335	2504B	24		SPARE	ALL
	B02		W5335	2505B	24		34-61-23	ALL
	B03		W5335	2506B	24		SPARE	ALL
	B04		W5335	2507B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04009P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B05		W5335	2508B	24		SPARE	ALL
	B06		W5335	2509B	24		SPARE	ALL
	B07		W5335	2511B	24		34-45-21	ALL
	B08		W5335	2513B	24		SPARE	ALL
	B09		W5335	2567B	24		SPARE	ALL
	B10		W5335	2562B	24		23-27-33	ALL
	PERG	1F	W5335	2504Z			SPARE	ALL
	PERG	1F	W5335	2505Z			34-61-23	ALL
	PERG	1F	W5335	2506Z			SPARE	ALL
	PERG	1F	W5335	2507Z			SPARE	ALL
	PERG	1F	W5335	2508Z			SPARE	ALL
	PERG	1F	W5335	2509Z			SPARE	ALL
	PERG	1F	W5335	2511Z			34-45-21	ALL
	PERG	1F	W5335	2513Z			SPARE	ALL
	PERG	1F	W5335	2562Z			23-27-33	ALL
	PERG	1F	W5335	2567Z			SPARE	ALL
D04031J		**E001-05/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2151	0053	22		34-55-21	ALL
	4		W2151	0004	22		34-55-21	ALL
	5	UNUSED						ALL
	6		W2151	0046	22		34-55-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2151	0012	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04031J	**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
13		W2151	0013	22		34-55-21	ALL
14	UNUSED						ALL
15		W2151	0025	22		34-51-41	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W2151	2002R	24		34-51-21	ALL
21		W2151	2002B	24		34-51-21	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W2151	2003R	24		34-55-21	ALL
25		W2151	2003B	24		34-55-21	ALL
26		W2151	0026	22		34-55-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W2151	0030	22		34-55-21	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W2151	0037	22		34-55-21	ALL
38		W2151	0038	22		34-51-41	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04031J		**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54		W2151	0054	22		34-51-21	ALL
	55	UNUSED						ALL
	S/R		W2151	2002Z			34-51-21	ALL
	S/R		W2151	2003Z			34-55-21	ALL
D04031P		**E001-05/ /**		**PLUG-RECEPTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0151	0028	22		34-55-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0151	0022	22		34-55-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0151	0040	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04031P	**E001-05/ /**		**PLUG-RECEPTIVE (continued)**				**ALL**
13		W0151	0026	22		34-55-21	ALL
14	UNUSED						ALL
15		W0151	0061	22		34-51-41	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0151	2010R	24		34-51-21	ALL
21		W0151	2010B	24		34-51-21	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W0151	2007R	24		34-55-21	ALL
25		W0151	2007B	24		34-55-21	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W0151	0038	22		34-51-41	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04031P		**E001-05/ /**		**PLUG-RECEPTIVE (continued)**				**ALL**
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54		W0151	0041	22		34-51-21	ALL
	55	UNUSED						ALL
	S/R		W0151	2007Z			34-55-21	ALL
	S/R		W0151	2010Z			34-51-21	ALL
D04069J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2001R	22		22-11-11	ALL
	A02		W0111	0009	22		22-11-11	ALL
	A03		W0111	0014	22		22-11-11	ALL
	A04		W0111	0016	22		22-11-11	ALL
	A05		W0111	0038	20		22-11-12	ALL
	A06		W0111	1017	20		22-11-31	ALL
	A07		W0111	2024R	24		22-11-51	ALL
	A08		W0111	2015R	24		22-11-51	ALL
	A09		W0111	2059R	24		22-11-51	ALL
	A10		W0111	0176	22		22-14-11	ALL
	A11		W0111	0178	22		22-14-11	ALL
	A12		W0111	0343	22		22-31-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04069J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A13		W0111	0345	22		22-31-51	ALL
A14		W0111	0181	22		22-14-11	ALL
A15		W0111	0786	24		22-11-75	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0111	2001B	22		22-11-11	ALL
B02		W0111	0010	22		22-11-11	ALL
B03		W0111	0015	22		22-11-11	ALL
B04		W0111	0221	20		22-11-12	ALL
B05		W0111	0039	20		22-11-12	ALL
B06		W0111	1013	20		22-12-31	ALL
B07		W0111	2024B	24		22-11-51	ALL
B08		W0111	2015B	24		22-11-51	ALL
B09		W0111	2059B	24		22-11-51	ALL
B10		W0111	0177	22		22-14-11	ALL
B11	UNUSED						ALL
B12		W0111	0344	22		22-31-51	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20		W0111	0193	22		22-14-11	ALL
PERG	1F	W0111	1013Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04069J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	1017Z			22-11-31	ALL
	PERG	1F	W0111	2015Z			22-11-51	ALL
	PERG	1F	W0111	2024Z			22-11-51	ALL
	PERG	1F	W0111	2059Z			22-11-51	ALL
D04069P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W2363	2013R	22		22-11-11	ALL
	A02		W2363	1045	22		22-11-11	ALL
	A03		W2363	1047	22		22-11-11	ALL
	A04		W2363	1023	22		22-11-11	ALL
	A05		W2363	3001B	20		22-11-12	ALL
	A06		W2363	1011	20		22-11-31	ALL
	A07		W2363	2003R	22		22-11-51	ALL
	A08		W2363	2015R	22		22-11-51	ALL
	A09		W2363	2017R	22		22-11-51	ALL
	A10		W2363	1030	22		22-14-11	ALL
	A11		W2363	1004	22		22-14-11	ALL
	A12		W2363	1006	22		22-31-51	ALL
	A13		W2363	1008	22		22-31-51	ALL
	A14		W2363	1007	22		22-14-11	ALL
	A15		W2363	1014	22		22-11-75	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2363	2013B	22		22-11-11	ALL
	B02		W2363	1017	22		22-11-11	ALL
	B03		W2363	1003	22		22-11-11	ALL
	B04		W2363	3001R	20		22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04069P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B05		W2363	3001Y	20		22-11-12	ALL
	B06		W2363	1010	20		22-12-31	ALL
	B07		W2363	2003B	22		22-11-51	ALL
	B08		W2363	2015B	22		22-11-51	ALL
	B09		W2363	2017B	22		22-11-51	ALL
	B10		W2363	1022	22		22-14-11	ALL
	B11	UNUSED						ALL
	B12		W2363	1009	22		22-31-51	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W2363	1016	22		22-14-11	ALL
			W2363	1004Z			22-14-11	ALL
			W2363	1007Z			22-14-11	ALL
			W2363	1022Z			22-14-11	ALL
			W2363	FRAC			22-14-11	ALL
	PERG	1F	W2363	1003Z			22-11-11	ALL
	PERG	1F	W2363	1006Z			22-31-51	ALL
	PERG	1F	W2363	1008Z			22-31-51	ALL
	PERG	1F	W2363	1009Z			22-31-51	ALL
	PERG	1F	W2363	1010Z			22-12-31	ALL
	PERG	1F	W2363	1011Z			22-11-31	ALL
	PERG	1F	W2363	1014Z			22-11-75	ALL
	PERG	1F	W2363	1016Z			22-14-11	ALL
	PERG	1F	W2363	1017Z			22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04069P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2363	1023Z			22-11-11	ALL
	PERG	1F	W2363	1030Z			22-14-11	ALL
	PERG	1F	W2363	1045Z			22-11-11	ALL
	PERG	1F	W2363	1047Z			22-11-11	ALL
	PERG	1F	W2363	2003Z			22-11-51	ALL
	PERG	1F	W2363	2013Z			22-11-11	ALL
	PERG	1F	W2363	2015Z			22-11-51	ALL
	PERG	1F	W2363	2017Z			22-11-51	ALL
	PERG	1F	W2363	3001Z			22-11-12	ALL
	PERG	1F	W2363	FRAC			22-14-11	ALL
D04073J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0047	20		22-11-12	ALL
	A02		W0111	0042	20		22-11-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0111	2013R	22		22-11-31	ALL
	A09		W0111	2013B	22		22-11-31	ALL
	A10		W0111	0277	22		22-11-11	ALL
	A11		W0111	0278	22		22-11-11	ALL
	A12		W0111	3001R	22		22-11-31	ALL
	A13		W0111	3001B	22		22-11-31	ALL
	A14		W0111	3001Y	22		22-11-31	ALL
	A15		W0111	3002R	22		22-11-31	ALL
	A16		W0111	3002B	22		22-11-31	ALL
	A17		W0111	3002Y	22		22-11-31	ALL
	A18		W0111	3003R	22		22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04073J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A19		W0111	3003B	22		22-12-31	ALL
A20		W0111	3003Y	22		22-12-31	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0111	2011R	22		22-11-31	ALL
B13		W0111	2011B	22		22-11-31	ALL
B14		W0111	2222R	22		31-32-15	ALL
B15		W0111	2222B	22		31-32-15	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W0111	1021	22		22-11-31	ALL
B20		W0111	1019	20		22-11-31	ALL
PERG	1F	W0111	1019Z			22-11-31	ALL
PERG	1F	W0111	1021Z			22-11-31	ALL
PERG	1F	W0111	2011Z			22-11-31	ALL
PERG	1F	W0111	2013Z			22-11-31	ALL
PERG	1F	W0111	2222Z			31-32-15	ALL
PERG	1F	W0111	3001Z			22-11-31	ALL
PERG	1F	W0111	3002Z			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04073J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	3003Z			22-12-31	ALL
D04073P		**E001-01/ /**		**PLUG- CONDUCTIVE**				**ALL**
	A01		W5367	0032	20		22-11-12	ALL
	A02		W5367	0034	20		22-11-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5367	2009R	22		22-11-31	ALL
	A09		W5367	2009B	22		22-11-31	ALL
	A10		W5367	2015R	22		22-11-11	ALL
	A11		W5367	2015B	22		22-11-11	ALL
	A12		W5367	3001R	22		22-11-31	ALL
	A13		W5367	3001B	22		22-11-31	ALL
	A14		W5367	3001Y	22		22-11-31	ALL
	A15		W5367	3004R	22		22-11-31	ALL
	A16		W5367	3004B	22		22-11-31	ALL
	A17		W5367	3004Y	22		22-11-31	ALL
	A18		W5367	3007R	22		22-12-31	ALL
	A19		W5367	3007B	22		22-12-31	ALL
	A20		W5367	3007Y	22		22-12-31	ALL
	B01		W5367	3013R	22		SPARE	ALL
	B02		W5367	3013B	22		SPARE	ALL
	B03		W5367	3013Y	22		SPARE	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04073P		**E001-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W5367	2017R	22		22-11-31	ALL
	B13		W5367	2017B	22		22-11-31	ALL
	B14		W5367	2004R	22		31-32-15	ALL
	B15		W5367	2004B	22		31-32-15	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W5367	2008R	20		22-11-31	ALL
	B20		W5367	2008B	20		22-11-31	ALL
	PERG	1F	W5367	2004Z			31-32-15	ALL
	PERG	1F	W5367	2015Z			22-11-11	ALL
	PERG	1F	W5367	3007Z			22-12-31	ALL
	PERG	1F	W5367	3013Z			SPARE	ALL
D04075J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0275	22		22-11-11	ALL
	A02		W0111	0276	22		22-11-11	ALL
	A03		W0111	0040	20		22-11-12	ALL
	A04		W0111	0044	22		22-11-12	ALL
	A05		W0111	0061	22		22-11-14	ALL
	A06		W0111	0062	22		22-11-14	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0111	0152	20		22-13-11	ALL
	A11		W0111	0153	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04075J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	A12	UNUSED						ALL
	A13		W0111	0155	22		22-13-11	ALL
	A14		W0111	0156	22		22-13-11	ALL
	A15		W0111	0980	22		22-31-51	ALL
	A16		W0111	0158	22		22-13-11	ALL
	A17		W0111	0157	22		22-13-11	ALL
	A18	UNUSED						ALL
	A19		W0111	0095	20		22-13-11	ALL
	A20		W0111	0097	20		22-13-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0111	0963	22		22-31-51	ALL
	B05		W0111	2036R	22		22-12-31	ALL
	B06		W0111	2036B	22		22-12-31	ALL
	B07		W0111	0271	22		22-11-11	ALL
	B08		W0111	0272	22		22-11-11	ALL
	B09		W0111	2035R	22		22-12-31	ALL
	B10		W0111	2035B	22		22-12-31	ALL
	B11		W0111	2006R	22		22-11-31	ALL
	B12		W0111	2006B	22		22-11-31	ALL
	B13		W0111	0273	22		22-11-11	ALL
	B14		W0111	0274	22		22-11-11	ALL
	B15		W0111	0334	22		22-31-51	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04075J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0111	2006Z			22-11-31	ALL
D04075P	**E001-01/ /**		**PLUG- CONDUCTIVE**				**ALL**
A01		W5369	2001R	22		22-11-11	ALL
A02		W5369	2001B	22		22-11-11	ALL
A03		W5369	0003	20		22-11-12	ALL
A04		W5369	0103	20		22-11-12	ALL
A05		W5369	0005	22		22-11-14	ALL
A06		W5369	0006	22		22-11-14	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W5369	0014	20		22-13-11	ALL
A11		W5369	0015	20		22-13-11	ALL
A12	UNUSED						ALL
A13		W5369	0017	20		22-13-11	ALL
A14		W5369	0018	20		22-13-11	ALL
A15		W5369	0106	22		22-31-51	ALL
A16		W5369	0020	20		22-13-11	ALL
A17		W5369	0019	20		22-13-11	ALL
A18	UNUSED						ALL
A19		W5369	0012	20		22-13-11	ALL
A20		W5369	0013	20		22-13-11	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5369	0108	22		22-31-51	ALL
B05		W5369	2002R	22		22-12-31	ALL
B06		W5369	2002B	22		22-12-31	ALL
B07		W5369	2027R	22		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04075P		**E001-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	B08		W5369	2027B	22		22-11-11	ALL
	B09		W5369	2029R	22		22-12-31	ALL
	B10		W5369	2029B	22		22-12-31	ALL
	B11		W5369	2031R	22		22-11-31	ALL
	B12		W5369	2031B	22		22-11-31	ALL
	B13		W5369	2033R	22		22-11-11	ALL
	B14		W5369	2033B	22		22-11-11	ALL
	B15		W5369	0105	22		22-31-51	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5369	2031Z			22-11-31	ALL
D04079J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0052	20		22-11-12	ALL
	A02		W0111	0055	20		22-11-12	ALL
	A03	UNUSED						ALL
	A04		W0111	2303R	22		22-12-31	ALL
	A05		W0111	1014	22		22-12-31	ALL
	A06		W0111	1012	20		22-12-31	ALL
	A07		W0111	2040R	22		22-12-31	ALL
	A08		W0111	2040B	22		22-12-31	ALL
	A09		W0111	2037R	22		22-12-31	ALL
	A10		W0111	2037B	22		22-12-31	ALL
	A11		W0111	2305R	22		22-12-31	ALL
	A12		W0111	3005R	22		22-12-31	ALL
	A13		W0111	3005B	22		22-12-31	ALL
	A14		W0111	3005Y	22		22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04079J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A15		W0111	2304R	22		22-12-31	ALL
A16		W0111	3004R	22		22-12-31	ALL
A17		W0111	3004B	22		22-12-31	ALL
A18		W0111	3004Y	22		22-12-31	ALL
A19		W0111	2229R	22		22-12-31	ALL
A20		W0111	2229B	22		22-12-31	ALL
B01	UNUSED						ALL
B02		W0111	2039R	22		22-12-31	ALL
B03		W0111	2039B	22		22-12-31	ALL
B04		W0111	2303B	22		22-12-31	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0111	2305B	22		22-12-31	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W0111	2304B	22		22-12-31	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0111	1012Z			22-12-31	ALL
PERG	1F	W0111	1014Z			22-12-31	ALL
PERG	1F	W0111	2037Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04079J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	2039Z			22-12-31	ALL
	PERG	1F	W0111	2040Z			22-12-31	ALL
	PERG	1F	W0111	2229Z			22-12-31	ALL
	PERG	1F	W0111	2303Z			22-12-31	ALL
	PERG	1F	W0111	2304Z			22-12-31	ALL
	PERG	1F	W0111	2305Z			22-12-31	ALL
	PERG	1F	W0111	3004Z			22-12-31	ALL
	PERG	1F	W0111	3005Z			22-12-31	ALL
D04079P		**E001-01/ /**		**PLUG- CONDUCTIVE**				**ALL**
	A01		W3377	0011	20		22-11-12	ALL
	A02		W3377	0012	20		22-11-12	ALL
	A03	UNUSED						ALL
	A04		W3377	2004R	22		22-12-31	ALL
	A05		W3377	1012	20		22-12-31	ALL
	A06		W3377	1013	20		22-12-31	ALL
	A07		W3377	2007R	22		22-12-31	ALL
	A08		W3377	2007B	22		22-12-31	ALL
	A09		W3377	2023R	22		22-12-31	ALL
	A10		W3377	2023B	22		22-12-31	ALL
	A11		W3377	2006R	22		22-12-31	ALL
	A12		W3377	3001R	22		22-12-31	ALL
	A13		W3377	3001B	22		22-12-31	ALL
	A14		W3377	3001Y	22		22-12-31	ALL
	A15		W3377	2003R	22		22-12-31	ALL
	A16		W3377	3003R	22		22-12-31	ALL
	A17		W3377	3003B	22		22-12-31	ALL
	A18		W3377	3003Y	22		22-12-31	ALL
	A19		W3377	2002R	22		22-12-31	ALL
	A20		W3377	2002B	22		22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04079P	**E001-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
B01	UNUSED						ALL
B02		W3377	2005R	22		22-12-31	ALL
B03		W3377	2005B	22		22-12-31	ALL
B04		W3377	2004B	22		22-12-31	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W3377	2006B	22		22-12-31	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W3377	2003B	22		22-12-31	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W3377	1012Z			22-12-31	ALL
PERG	1F	W3377	1013Z			22-12-31	ALL
PERG	1F	W3377	2002Z			22-12-31	ALL
PERG	1F	W3377	2003Z			22-12-31	ALL
PERG	1F	W3377	2004Z			22-12-31	ALL
PERG	1F	W3377	2005Z			22-12-31	ALL
PERG	1F	W3377	2006Z			22-12-31	ALL
PERG	1F	W3377	2007Z			22-12-31	ALL
PERG	1F	W3377	2023Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04079P		**E001-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W3377	3001Z			22-12-31	ALL
	PERG	1F	W3377	3003Z			22-12-31	ALL
D04083J		**E001-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0111	0098	20		22-13-11	ALL
	A05		W0111	0096	20		22-13-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04083P	**E001-01/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02		W3381	0006	20		SPARE	ALL
A03	UNUSED						ALL
A04		W3381	0004	20		22-13-11	ALL
A05		W3381	0005	20		22-13-11	ALL
A06	UNUSED						ALL
A07		W3381	0007	20		SPARE	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04115J		**E004-01/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0411	2634R	24		23-27-34	ALL
	A03	UNUSED						ALL
	A04		W0411	2728R	24		46-13-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0411	2604R	24		23-27-32	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0411	2611R	24		23-27-37	ALL
	A13		W0411	2612R	24		23-27-37	ALL
	A14	UNUSED						ALL
	A15		W0411	2618R	24		23-27-39	ALL
	A16	UNUSED						ALL
	A17		W0411	0306	24		23-27-39	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0411	0159	24		23-27-31	ALL
	B01	UNUSED						ALL
	B02		W0411	2634B	24		23-27-34	ALL
	B03	UNUSED						ALL
	B04		W0411	2728B	24		46-13-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0411	2604B	24		23-27-32	ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04115J		**E004-01/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0411	2611B	24		23-27-37	ALL
	B13		W0411	2612B	24		23-27-37	ALL
	B14	UNUSED						ALL
	B15		W0411	2618B	24		23-27-39	ALL
	B16	UNUSED						ALL
	B17		W0411	0292	22		23-27-31	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0411	2604Z			23-27-32	ALL
	PERG	1F	W0411	2611Z			23-27-37	ALL
	PERG	1F	W0411	2612Z			23-27-37	ALL
	PERG	1F	W0411	2618Z			23-27-39	ALL
	PERG	1F	W0411	2634Z			23-27-34	ALL
	PERG	1F	W0411	2728Z			46-13-11	ALL
D04115P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5331	2527R	24		SPARE	ALL
	A02		W5331	2528R	24		23-27-34	ALL
	A03		W5331	2532R	24		SPARE	ALL
	A04		W5331	2507R	24		46-13-11	ALL
	A05		W5331	2506R	24		SPARE	ALL
	A06		W5331	2505R	24		SPARE	ALL
	A07		W5331	2501R	24		SPARE	ALL
	A08		W5331	2502R	24		23-27-32	ALL
	A09		W5331	2503R	24		SPARE	ALL
	A10		W5331	2504R	24		SPARE	ALL
	A11		W5331	2508R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04115P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A12		W5331	2509R	24		23-27-37	ALL
	A13		W5331	2510R	24		23-27-37	ALL
	A14		W5331	2511R	24		SPARE	ALL
	A15		W5331	2513R	24		23-27-39	ALL
	A16		W5331	2524R	24		SPARE	ALL
	A17		W5331	0008	24		23-27-39	ALL
	A18		W5331	2529R	24		SPARE	ALL
	A19		W5331	2530R	24		SPARE	ALL
	A20		W5331	0039	24		23-27-31	ALL
	B01		W5331	2527B	24		SPARE	ALL
	B02		W5331	2528B	24		23-27-34	ALL
	B03		W5331	2532B	24		SPARE	ALL
	B04		W5331	2507B	24		46-13-11	ALL
	B05		W5331	2506B	24		SPARE	ALL
	B06		W5331	2505B	24		SPARE	ALL
	B07		W5331	2501B	24		SPARE	ALL
	B08		W5331	2502B	24		23-27-32	ALL
	B09		W5331	2503B	24		SPARE	ALL
	B10		W5331	2504B	24		SPARE	ALL
	B11		W5331	2508B	24		SPARE	ALL
	B12		W5331	2509B	24		23-27-37	ALL
	B13		W5331	2510B	24		23-27-37	ALL
	B14		W5331	2511B	24		SPARE	ALL
	B15		W5331	2513B	24		23-27-39	ALL
	B16		W5331	2524B	24		SPARE	ALL
	B17		W5331	0001	22		23-27-31	ALL
	B18		W5331	2529B	24		SPARE	ALL
	B19		W5331	2530B	24		SPARE	ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04115P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5331	2501Z			SPARE	ALL
	PERG	1F	W5331	2502Z			23-27-32	ALL
	PERG	1F	W5331	2503Z			SPARE	ALL
	PERG	1F	W5331	2504Z			SPARE	ALL
	PERG	1F	W5331	2505Z			SPARE	ALL
	PERG	1F	W5331	2506Z			SPARE	ALL
	PERG	1F	W5331	2507Z			46-13-11	ALL
	PERG	1F	W5331	2508Z			SPARE	ALL
	PERG	1F	W5331	2509Z			23-27-37	ALL
	PERG	1F	W5331	2510Z			23-27-37	ALL
	PERG	1F	W5331	2511Z			SPARE	ALL
	PERG	1F	W5331	2513Z			23-27-39	ALL
	PERG	1F	W5331	2524Z			SPARE	ALL
	PERG	1F	W5331	2527Z			SPARE	ALL
	PERG	1F	W5331	2528Z			23-27-34	ALL
	PERG	1F	W5331	2529Z			SPARE	ALL
	PERG	1F	W5331	2530Z			SPARE	ALL
	PERG	1F	W5331	2532Z			SPARE	ALL
D04116J		**E004-01/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01		W0411	2617R	24		23-27-38	ALL
	A02		W0411	2619R	24		31-32-15	ALL
	A03		W0411	2621R	24		34-61-23	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0411	2632R	24		34-61-21	ALL
	A08		W0411	2660R	24		34-45-21	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04116J		**E004-01/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B01		W0411	2617B	24		23-27-38	ALL
	B02		W0411	2619B	24		31-32-15	ALL
	B03		W0411	2621B	24		34-61-23	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0411	2632B	24		34-61-21	ALL
	B08		W0411	2660B	24		34-45-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0411	2617Z			23-27-38	ALL
	PERG	1F	W0411	2619Z			31-32-15	ALL
	PERG	1F	W0411	2621Z			34-61-23	ALL
	PERG	1F	W0411	2632Z			34-61-21	ALL
	PERG	1F	W0411	2660Z			34-45-21	ALL
D04116P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5331	2512R	24		23-27-38	ALL
	A02		W5331	2517R	24		31-32-15	ALL
	A03		W5331	2519R	24		34-61-23	ALL
	A04		W5331	2520R	24		SPARE	ALL
	A05		W5331	2521R	24		SPARE	ALL
	A06		W5331	2522R	24		SPARE	ALL
	A07		W5331	2523R	24		34-61-21	ALL
	A08		W5331	2526R	24		34-45-21	ALL
	A09		W5331	2561ZI			SPARE	ALL
	A10		W5331	2561R	24		SPARE	ALL
	B01		W5331	2512B	24		23-27-38	ALL
	B02		W5331	2517B	24		31-32-15	ALL
	B03		W5331	2519B	24		34-61-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04116P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04		W5331	2520B	24		SPARE	ALL
	B05		W5331	2521B	24		SPARE	ALL
	B06		W5331	2522B	24		SPARE	ALL
	B07		W5331	2523B	24		34-61-21	ALL
	B08		W5331	2526B	24		34-45-21	ALL
	B09	UNUSED						ALL
	B10		W5331	2561B	24		SPARE	ALL
	PERG	1F	W5331	2512Z			23-27-38	ALL
	PERG	1F	W5331	2517Z			31-32-15	ALL
	PERG	1F	W5331	2519Z			34-61-23	ALL
	PERG	1F	W5331	2520Z			SPARE	ALL
	PERG	1F	W5331	2521Z			SPARE	ALL
	PERG	1F	W5331	2522Z			SPARE	ALL
	PERG	1F	W5331	2523Z			34-61-21	ALL
	PERG	1F	W5331	2526Z			34-45-21	ALL
	PERG	1F	W5331	2561ZO			SPARE	ALL
D04117J		**E004-01/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01		W0411	0300	22		23-27-38	ALL
	A02		W0411	0302	22		23-27-38	ALL
	A03		W0411	0304	22		23-27-38	ALL
	A04		W0411	2631R	24		34-61-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0411	2601R	24		31-35-02	ALL
	A08		W0411	2602R	24		31-35-02	ALL
	A09		W0411	2599R	24		31-33-01	ALL
	A10	UNUSED						ALL
	B01		W0411	0301	22		23-27-38	ALL
	B02		W0411	0303	22		23-27-38	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04117J		**E004-01/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B03		W0411	0305	22		23-27-38	ALL
	B04		W0411	2631B	24		34-61-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0411	2601B	24		31-35-02	ALL
	B08		W0411	2602B	24		31-35-02	ALL
	B09		W0411	2599B	24		31-33-01	ALL
	B10	UNUSED						ALL
	PERG	1F	W0411	2599Z			31-33-01	ALL
	PERG	1F	W0411	2601Z			31-35-02	ALL
	PERG	1F	W0411	2602Z			31-35-02	ALL
	PERG	1F	W0411	2631Z			34-61-21	ALL
D04117P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5331	0002	22		23-27-38	ALL
	A02		W5331	0004	22		23-27-38	ALL
	A03		W5331	0006	22		23-27-38	ALL
	A04		W5331	2566R	24		34-61-21	ALL
	A05		W5331	0022	24		SPARE	ALL
	A06		W5331	0024	24		SPARE	ALL
	A07		W5331	2515R	24		31-35-02	ALL
	A08		W5331	2514R	24		31-35-02	ALL
	A09		W5331	2518R	24		31-33-01	ALL
	A10		W5331	2516R	24		SPARE	ALL
	B01		W5331	0003	22		23-27-38	ALL
	B02		W5331	0005	22		23-27-38	ALL
	B03		W5331	0007	22		23-27-38	ALL
	B04		W5331	2566B	24		34-61-21	ALL
	B05		W5331	0023	24		SPARE	ALL
	B06		W5331	0025	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04117P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B07		W5331	2515B	24		31-35-02	ALL
	B08		W5331	2514B	24		31-35-02	ALL
	B09		W5331	2518B	24		31-33-01	ALL
	B10		W5331	2516B	24		SPARE	ALL
	PERG	1F	W5331	2514Z			31-35-02	ALL
	PERG	1F	W5331	2515Z			31-35-02	ALL
	PERG	1F	W5331	2516Z			SPARE	ALL
	PERG	1F	W5331	2518Z			31-33-01	ALL
	PERG	1F	W5331	2566Z			34-61-21	ALL
D04123J		**E001-03/ /**		**RCPT**				**ALL**
	A01		W0131	2519R	24		23-12-41	ALL
	A02		W0131	2519Z			23-12-41	ALL
	A03		W0131	2525R	24		23-12-11	ALL
	A04		W0131	2525Z			23-12-11	ALL
	A05	UNUSED						ALL
	A06		W0131	0132	24		23-12-41	ALL
	A07		W0131	0124	22		23-12-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0131	2519B	24		23-12-41	ALL
	B02	UNUSED						ALL
	B03		W0131	2525B	24		23-12-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04123J		**E001-03/ /**		**RCPT (continued)**				**ALL**
	B10	UNUSED						ALL
D04123P		**E001-03/ /**		**PLUG**				**ALL**
	A01		W5107	2501R	24		23-12-41	ALL
	A02		W5107	2501Z			23-12-41	ALL
	A03		W5107	2502R	24		23-12-11	ALL
	A04		W5107	2502Z			23-12-11	ALL
	A05	UNUSED						ALL
	A06		W5107	0003	24		23-12-41	ALL
	A07		W5107	0004	22		23-12-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5107	2501B	24		23-12-41	ALL
	B02	UNUSED						ALL
	B03		W5107	2502B	24		23-12-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D04125J		**E001-05/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1		W5177	2501R	24		23-12-41	ALL
	2		W5177	2501B	24		23-12-41	ALL
	3		W5177	0003	24		23-12-41	ALL
	4		W5177	0004	22		23-12-21	ALL
	5		W5177	2502R	24		23-12-21	ALL
	6		W5177	2502B	24		23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04125J		**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	S/R		W5177	2501Z			23-12-41	ALL
	S/R		W5177	2502Z			23-12-21	ALL
D04125P		**AE0105A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W0151	2034R	24		23-12-41	ALL
	2		W0151	2034B	24		23-12-41	ALL
	3		W0151	0083	24		23-12-41	ALL
	4		W0151	0025	22		23-12-21	ALL
	5		W0151	2041R	24		23-12-21	ALL
	6		W0151	2041B	24		23-12-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	S/R		W0151	2034Z			23-12-41	ALL
	S/R		W0151	2041Z			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04131J		**E001-05/ /**		**JACK**				**ALL**
	=A1		W5411	001CX			23-12-21	ALL
	=C1		W5411	001CO			23-12-21	ALL
D04131P		**E001-05/ /**		**PLUG-COAX**				**ALL**
	=A1		W0151	007CX			23-12-21	ALL
	=C1		W0151	007CO			23-12-21	ALL
D04133J		**E001-03/ /**		**RCPT**				**ALL**
	=A1		W0131	001CX			23-12-11	ALL
	=C1		W0131	001CO			23-12-11	ALL
D04133P		**E001-03/ /**		**PLUG**				**ALL**
	=A1		W5413	001CX			23-12-11	ALL
	=C1		W5413	001CO			23-12-11	ALL
D04137J		**472/154/L004**		**JACK**				**ALL**
	=A1		W5411	001CX			23-12-21	ALL
	=C1		W5411	001CO			23-12-21	ALL
D04137P		**472/154/L004**		**PLUG**				**ALL**
	=A1		W5417	001CX			23-12-21	ALL
	=C1		W5417	001CO			23-12-21	ALL
D04143J		**E001-05/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1		W5107	2503R	24		23-12-41	ALL
	2		W5107	2503B	24		23-12-41	ALL
	3		W5107	2504R	24		34-21-14	ALL
	4		W5107	2504B	24		34-21-14	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04143J	**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W5107	2503Z			23-12-41	ALL
S/R		W5107	2504Z			34-21-14	ALL
D04143P	**AE0105A/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W0151	2031R	24		23-12-41	ALL
2		W0151	2031B	24		23-12-41	ALL
3		W0151	2016R	24		34-21-14	ALL
4		W0151	2016B	24		34-21-14	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04143P		**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W0151	2016Z			34-21-14	ALL
	S/R		W0151	2031Z			23-12-41	ALL
D04149J		**E001-03/ /**		**RCPT**				**ALL**
	A01		W0131	2003R	24		23-31-01	ALL
	A02		W0131	3501R	24		23-42-12	ALL
	A03		W0131	3501Y	24		23-42-12	ALL
	A04		W0131	0014	24		23-31-01	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0131	2003B	24		23-31-01	ALL
	B02		W0131	3501B	24		23-42-12	ALL
	B03		W0131	3501Z			23-42-12	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04149J		**E001-03/ /**		**RCPT (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D04149P		**E001-03/ /**		**PLUG -**				**ALL**
	A01		W2307	2001R	22		23-31-01	ALL
	A02		W2307	3501R	24		23-42-12	ALL
	A03		W2307	3501Y	24		23-42-12	ALL
	A04		W2307	0001	22		23-31-01	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2307	2001B	22		23-31-01	ALL
	B02		W2307	3501B	24		23-42-12	ALL
	B03		W2307	FRAA			23-42-12	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W2307	2001Z			23-31-01	ALL
			W2307	3501Z			23-42-12	ALL
			W2307	FRAA			23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04151J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0041	2001R	22		23-51-31	ALL
	2		W0041	2001B	22		23-51-31	ALL
	3		W0041	2524R	24		23-51-31	ALL
	4		W0041	2524B	24		23-51-31	ALL
	5		W0041	3001R	24		23-51-31	ALL
	6		W0041	3001B	24		23-51-31	ALL
	7		W0041	3001Y	24		23-51-31	ALL
	8		W0041	4004Y	24		23-51-31	ALL
	9		W0041	4004G	24		23-51-31	ALL
	10		W0041	4004R	24		23-51-31	ALL
	11		W0041	4004B	24		23-51-31	ALL
	12		W0041	0056	24		23-51-31	ALL
	13		W0041	0084	22		23-51-31	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04151J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
DED		W0041	2524Z			23-51-31	ALL
D04151P	**P006-00/ /**		**PLUG-**				**ALL**
1		W3327	2501R	24		23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04151P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	2		W3327	2501B	24		23-51-31	ALL
	3		W3327	2502R	24		23-51-31	ALL
	4		W3327	2502B	24		23-51-31	ALL
	5		W3327	3501R	24		23-51-31	ALL
	6		W3327	3501B	24		23-51-31	ALL
	7		W3327	3501Y	24		23-51-31	ALL
	8		W3327	4258Y	24		23-51-31	ALL
	9		W3327	4258G	24		23-51-31	ALL
	10		W3327	4258R	24		23-51-31	ALL
	11		W3327	4258B	24		23-51-31	ALL
	12		W3327	0028	24		23-51-31	ALL
	13		W3327	0032	22		23-51-31	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04151P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
DED		W3327	2501Z			23-51-31	ALL
DED		W3327	2502Z			23-51-31	ALL
DED		W3327	3501Z			23-51-31	ALL
DED		W3327	4258Z			23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04153J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	2503R	24		23-51-31	ALL
	A02		W0411	0012	22		23-51-31	ALL
	A03		W0411	0013	22		23-51-31	ALL
	A04		W0411	0015	22		23-51-31	ALL
	A05		W0411	1014	24		23-41-11	ALL
	A06		W0411	2007R	24		23-51-31	ALL
	A07		W0411	2008R	24		23-51-31	ALL
	A08		W0411	3005R	24		23-51-31	ALL
	A09		W0411	3005Z			23-51-31	ALL
	A10		W0411	0378	24		23-22-11	ALL
	A11	UNUSED						ALL
	A12		W0411	0380	24		23-22-11	ALL
	A13	UNUSED						ALL
	A14		W0411	0185	22		23-27-31	ALL
	A15		W0411	0192	24		23-43-11	ALL
	A16		W0411	0193	24		23-43-11	ALL
	A17		W0411	4258Y	24		23-51-31	ALL
	A18		W0411	4258B	24		23-51-31	ALL
	A19		W0411	4258G	24		23-51-31	ALL
	A20		W0411	0349	24		23-51-31	ALL
	B01		W0411	2503B	24		23-51-31	ALL
	B02		W0411	0356	22		23-51-31	ALL
	B03		W0411	0014	22		23-51-31	ALL
	B04		W0411	1013	24		23-41-11	ALL
	B05		W0411	2008Z			23-51-31	ALL
	B06		W0411	2007B	24		23-51-31	ALL
	B07		W0411	2008B	24		23-51-31	ALL
	B08		W0411	3005B	24		23-51-31	ALL
	B09		W0411	3005Y	24		23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04153J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10		W0411	0269	24		23-15-13	ALL
	B11	UNUSED						ALL
	B12		W0411	0268	24		23-15-13	ALL
	B13		W0411	0120	24		23-22-11	ALL
	B14		W0411	0266	24		23-15-13	ALL
	B15		W0411	0377	24		23-22-11	ALL
	B16		W0411	0267	24		23-15-13	ALL
	B17		W0411	4258R	24		23-51-31	ALL
	B18		W0411	4258Z			23-51-31	ALL
	B19		W0411	0379	24		23-22-11	ALL
	B20		W0411	0349	24		23-51-31	ALL
	PERG	1F	W0411	1013Z			23-41-11	ALL
	PERG	1F	W0411	1014Z			23-41-11	ALL
	PERG	1F	W0411	2007Z			23-51-31	ALL
	PERG	1F	W0411	2503Z			23-51-31	ALL
D04153P		**E004-01/ /**		**PLUG- CONDUCTIVE**				**ALL**
	A01		W3327	2503R	24		23-51-31	ALL
	A02		W3327	0001	22		23-51-31	ALL
	A03		W3327	0002	22		23-51-31	ALL
	A04		W3327	0004	22		23-51-31	ALL
	A05		W3327	2004R	24		23-41-11	ALL
	A06		W3327	2501R	24		23-51-31	ALL
	A07		W3327	2502R	24		23-51-31	ALL
	A08		W3327	3501R	24		23-51-31	ALL
	A09		W3327	3501Z			23-51-31	ALL
	A10		W3327	0018	24		23-22-11	ALL
	A11	UNUSED						ALL
	A12		W3327	0020	24		23-22-11	ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04153P		**E004-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	A14		W3327	0010	22		23-27-31	ALL
	A15		W3327	0006	24		23-43-11	ALL
	A16		W3327	0008	24		23-43-11	ALL
	A17		W3327	4258Y	24		23-51-31	ALL
	A18		W3327	4258B	24		23-51-31	ALL
	A19		W3327	4258G	24		23-51-31	ALL
	A20		W3327	0027	24		23-51-31	ALL
	B01		W3327	2503B	24		23-51-31	ALL
	B02		W3327	0032	22		23-51-31	ALL
	B03		W3327	0003	22		23-51-31	ALL
	B04		W3327	2004B	24		23-41-11	ALL
	B05		W3327	2502Z			23-51-31	ALL
	B06		W3327	2501B	24		23-51-31	ALL
	B07		W3327	2502B	24		23-51-31	ALL
	B08		W3327	3501B	24		23-51-31	ALL
	B09		W3327	3501Y	24		23-51-31	ALL
	B10		W3327	0033	24		23-15-13	ALL
	B11	UNUSED						ALL
	B12		W3327	0035	24		23-15-13	ALL
	B13		W3327	0021	24		23-22-11	ALL
	B14		W3327	0036	24		23-15-13	ALL
	B15		W3327	0017	24		23-22-11	ALL
	B16		W3327	0034	24		23-15-13	ALL
	B17		W3327	4258R	24		23-51-31	ALL
	B18		W3327	4258Z			23-51-31	ALL
	B19		W3327	0019	24		23-22-11	ALL
	B20		W3327	0028	24		23-51-31	ALL
	PERG	1F	W3327	2004Z			23-41-11	ALL
	PERG	1F	W3327	2501Z			23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04153P	**E004-01/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
PERG	1F	W3327	2503Z			23-51-31	ALL
D04155J	**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0411	2501R	24		23-51-11	ALL
A02		W0411	0001	22		23-51-11	ALL
A03		W0411	0002	22		23-51-11	ALL
A04		W0411	0004	22		23-51-11	ALL
A05		W0411	4251B	24		23-51-11	ALL
A06		W0411	2001R	24		23-51-11	ALL
A07		W0411	2002R	24		23-51-11	ALL
A08		W0411	3002R	24		23-51-11	ALL
A09		W0411	2002Z			23-51-11	ALL
A10		W0411	2003R	24		23-51-11	ALL
A11		W0411	2532R	24		34-41-11	ALL
A12		W0411	3002Z			23-51-11	ALL
A13		W0411	0273	24		23-15-13	ALL
A14		W0411	0271	24		23-15-13	ALL
A15		W0411	0381	24		23-22-11	ALL
A16		W0411	0126	24		23-22-11	ALL
A17		W0411	0382	24		23-22-11	ALL
A18		W0411	0383	24		23-22-11	ALL
A19		W0411	4251Z			23-51-11	ALL
A20		W0411	0187	22		23-27-31	ALL
B01		W0411	2501B	24		23-51-11	ALL
B02		W0411	4251G	24		23-51-11	ALL
B03		W0411	0003	22		23-51-11	ALL
B04		W0411	4251R	24		23-51-11	ALL
B05		W0411	4251Y	24		23-51-11	ALL
B06		W0411	2001B	24		23-51-11	ALL
B07		W0411	2002B	24		23-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04155J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B08		W0411	3002B	24		23-51-11	ALL
	B09		W0411	3002Y	24		23-51-11	ALL
	B10		W0411	2003B	24		23-51-11	ALL
	B11		W0411	2532B	24		34-41-11	ALL
	B12		W0411	2532ZI			34-41-11	ALL
	B13		W0411	0068	22		23-51-11	ALL
	B14		W0411	0354	22		23-51-11	ALL
	B15		W0411	0194	24		23-43-11	ALL
	B16		W0411	0195	24		23-43-11	ALL
	B17		W0411	0270	24		23-15-13	ALL
	B18		W0411	0068	22		23-51-11	ALL
	B19		W0411	0384	24		23-22-11	ALL
	B20		W0411	0272	24		23-15-13	ALL
	PERG	1F	W0411	2001Z			23-51-11	ALL
	PERG	1F	W0411	2501Z			23-51-11	ALL
	PERG	1F	W0411	2532ZO			34-41-11	ALL
D04155P		**E004-01/ /**		**PLUG E4-1 SHELF**				**ALL**
	A01		W3323	2501R	24		23-51-11	ALL
	A02		W3323	0001	22		23-51-11	ALL
	A03		W3323	0002	22		23-51-11	ALL
	A04		W3323	0004	22		23-51-11	ALL
	A05		W3323	4251B	24		23-51-11	ALL
	A06		W3323	2502R	24		23-51-11	ALL
	A07		W3323	2503R	24		23-51-11	ALL
	A08		W3323	3501R	24		23-51-11	ALL
	A09		W3323	2503Z			23-51-11	ALL
	A10		W3323	2001R	24		23-51-11	ALL
	A11		W3323	2504R	24		34-41-11	ALL
	A12		W3323	3501Z			23-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04155P	**E004-01/ /**		**PLUG E4-1 SHELF (continued)**				**ALL**
A13		W3323	0036	24		23-15-13	ALL
A14		W3323	0035	24		23-15-13	ALL
A15		W3323	0017	24		23-22-11	ALL
A16		W3323	0018	24		23-22-11	ALL
A17		W3323	0019	24		23-22-11	ALL
A18		W3323	0020	24		23-22-11	ALL
A19		W3323	4251Z			23-51-11	ALL
A20		W3323	0021	22		23-27-31	ALL
B01		W3323	2501B	24		23-51-11	ALL
B02		W3323	4251G	24		23-51-11	ALL
B03		W3323	0003	22		23-51-11	ALL
B04		W3323	4251R	24		23-51-11	ALL
B05		W3323	4251Y	24		23-51-11	ALL
B06		W3323	2502B	24		23-51-11	ALL
B07		W3323	2503B	24		23-51-11	ALL
B08		W3323	3501B	24		23-51-11	ALL
B09		W3323	3501Y	24		23-51-11	ALL
B10		W3323	2001B	24		23-51-11	ALL
B11		W3323	2504B	24		34-41-11	ALL
B12		W3323	2504ZI			34-41-11	ALL
B13		W3323	0015	22		23-51-11	ALL
B14		W3323	0031	22		23-51-11	ALL
B15		W3323	0022	24		23-43-11	ALL
B16		W3323	0023	24		23-43-11	ALL
B17		W3323	0033	24		23-15-13	ALL
B18		W3323	0014	22		23-51-11	ALL
B19		W3323	0012	24		23-22-11	ALL
B20		W3323	0034	24		23-15-13	ALL
PERG	1F	W3323	2501Z			23-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04155P		**E004-01/ /**		**PLUG E4-1 SHELF (continued)**				**ALL**
	PERG	1F	W3323	2502Z			23-51-11	ALL
	PERG	1F	W3323	2504ZO			34-41-11	ALL
D04157J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	0052	22		23-71-01	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D04157P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W3329	0001	22		23-71-01	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04157P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D04161J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	3501R	24		23-41-11	ALL
	A02		W0411	3501B	24		23-41-11	ALL
	A03		W0411	3502Y	24		23-41-11	ALL
	A04		W0411	3503R	24		23-41-11	ALL
	A05		W0411	3503B	24		23-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0411	3501Y	24		23-41-11	ALL
	B02		W0411	3502R	24		23-41-11	ALL
	B03		W0411	3502B	24		23-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04161J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B04		W0411	3503Y	24		23-41-11	ALL
	B05	UNUSED						ALL
	B06		W0411	0353	22		34-21-12	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0411	3501Z			23-41-11	ALL
	PERG	1F	W0411	3502Z			23-41-11	ALL
	PERG	1F	W0411	3503Z			23-41-11	ALL
D04161P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5337	3501R	24		23-41-11	ALL
	A02		W5337	3501B	24		23-41-11	ALL
	A03		W5337	3502Y	22		23-41-11	ALL
	A04		W5337	3503R	22		23-41-11	ALL
	A05		W5337	3503B	22		23-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5337	3501Y	24		23-41-11	ALL
	B02		W5337	3502R	22		23-41-11	ALL
	B03		W5337	3502B	22		23-41-11	ALL
	B04		W5337	3503Y	22		23-41-11	ALL
	B05	UNUSED						ALL
	B06		W5337	0005	22		34-21-12	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04161P	**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5337	3501Z			23-41-11	ALL
PERG	1F	W5337	3502Z			23-41-11	ALL
PERG	1F	W5337	3503Z			23-41-11	ALL
D04181J	**E001-03/ /**		**RCPT**				**ALL**
A01		W0131	3503R	24		23-42-12	ALL
A02		W0131	3503B	24		23-42-12	ALL
A03		W0131	0523	22		23-42-12	ALL
A04		W0131	2002R	24		23-31-01	ALL
A05		W0131	0012	20		23-31-01	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0131	3503Y	24		23-42-12	ALL
B02		W0131	3503Z			23-42-12	ALL
B03	UNUSED						ALL
B04		W0131	2002B	24		23-31-01	ALL
B05		W0131	0051	24		23-31-01	ALL
B06		W0131	0052	24		23-31-01	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D04181P	**E001-03/ /**		**PLUG - ATT HANDSET (AFT)**				**ALL**
A01		W3311	3517R	24		23-42-12	ALL
A02		W3311	3517B	24		23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04181P		**E001-03/ /**		**PLUG - ATT HANDSET (AFT) (continued)**				**ALL**
	A03		W3311	0055	22		23-42-12	ALL
	A04		W3311	2011R	24		23-31-01	ALL
	A05		W3311	0003	20		23-31-01	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W3311	3517Y	24		23-42-12	ALL
	B02		W3311	FRAA			23-42-12	ALL
	B03	UNUSED						ALL
	B04		W3311	2011B	24		23-31-01	ALL
	B05		W3311	0002	24		23-31-01	ALL
	B06		W3311	0022	24		23-31-01	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W3311	2011Z			23-31-01	ALL
			W3311	3517Z			23-42-12	ALL
			W3311	FRAA			23-42-12	ALL
D04195J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0131	2009R	24		23-31-02	ALL
	A02		W0131	2008R	22		23-31-02	ALL
	A03		W0131	2005R	24		23-31-02	ALL
	A04		W0131	2004R	24		23-31-02	ALL
	A05		W0131	2006R	22		23-31-02	ALL
	A06		W0131	2010R	22		23-31-04	ALL
	A07		W0131	0019	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04195J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A08		W0131	0020	24		23-31-04	ALL
A09		W0131	0024	24		23-31-04	ALL
A10		W0131	0525	22		23-42-12	ALL
A11		W0131	2504R	24		23-22-11	ALL
A12	UNUSED						ALL
A13		W0131	2502R	24		23-12-11	ALL
A14		W0131	2502ZO			23-12-11	ALL
A15		W0131	2503R	24		23-12-11	ALL
A16		W0131	2503ZO			23-12-11	ALL
A17		W0131	3504R	24		23-42-12	ALL
A18		W0131	3504Y	24		23-42-12	ALL
A19	UNUSED						ALL
A20		W0131	0036	24		23-12-11	ALL
B01		W0131	2009B	24		23-31-02	ALL
B02		W0131	2008B	22		23-31-02	ALL
B03		W0131	2005B	24		23-31-02	ALL
B04		W0131	2004B	24		23-31-02	ALL
B05		W0131	2006B	22		23-31-02	ALL
B06		W0131	2010B	22		23-31-04	ALL
B07		W0131	0009	24		23-31-02	ALL
B08		W0131	0022	24		23-31-04	ALL
B09		W0131	0023	24		23-31-04	ALL
B10		W0131	0035	22		23-12-11	ALL
B11		W0131	2504B	24		23-22-11	ALL
B12		W0131	2504ZI			23-22-11	ALL
B13		W0131	2502B	24		23-12-11	ALL
B14		W0131	2502ZI			23-12-11	ALL
B15		W0131	2503B	24		23-12-11	ALL
B16		W0131	2503ZI			23-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04195J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B17		W0131	3504B	24		23-42-12	ALL
	B18		W0131	3504Z			23-42-12	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0131	2504ZO			23-22-11	ALL
D04195P		**E001-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5189	2002R	24		23-31-02	ALL
	A02		W5189	2003R	24		23-31-02	ALL
	A03		W5189	2004R	24		23-31-02	ALL
	A04		W5189	2005R	24		23-31-02	ALL
	A05		W5189	2006R	22		23-31-02	ALL
	A06		W5189	2007R	22		23-31-04	ALL
	A07		W5189	0003	22		23-31-02	ALL
	A08		W5189	0005	24		23-31-04	ALL
	A09		W5189	0007	24		23-31-04	ALL
	A10		W5189	0011	22		23-42-12	ALL
	A11		W5189	2503R	24		23-22-11	ALL
	A12	UNUSED						ALL
	A13		W5189	2508R	24		23-12-11	ALL
	A14		W5189	2508ZO			23-12-11	ALL
	A15		W5189	2509R	24		23-12-11	ALL
	A16		W5189	2509ZO			23-12-11	ALL
	A17		W5189	3501R	24		23-42-12	ALL
	A18		W5189	3501Y	24		23-42-12	ALL
	A19	UNUSED						ALL
	A20		W5189	0013	22		23-12-11	ALL
	B01		W5189	2002B	24		23-31-02	ALL
	B02		W5189	2003B	24		23-31-02	ALL
	B03		W5189	2004B	24		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04195P	**E001-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B04		W5189	2005B	24		23-31-02	ALL
B05		W5189	2006B	22		23-31-02	ALL
B06		W5189	2007B	22		23-31-04	ALL
B07		W5189	0004	24		23-31-02	ALL
B08		W5189	0006	24		23-31-04	ALL
B09		W5189	0008	24		23-31-04	ALL
B10		W5189	0012	22		23-12-11	ALL
B11		W5189	2503B	24		23-22-11	ALL
B12		W5189	2503ZI			23-22-11	ALL
B13		W5189	2508B	24		23-12-11	ALL
B14		W5189	2508ZI			23-12-11	ALL
B15		W5189	2509B	24		23-12-11	ALL
B16		W5189	2509ZI			23-12-11	ALL
B17		W5189	3501B	24		23-42-12	ALL
B18		W5189	3501Z			23-42-12	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5189	2503ZO			23-22-11	ALL
D04197J	**E001-05/ /**		**RCPT - CONDUCTIVE**				**ALL**
1		W5191	2507R	24		23-12-21	ALL
2		W5191	2507B	24		23-12-21	ALL
3		W5191	2507ZI			23-12-21	ALL
4		W5191	2508R	24		23-12-21	ALL
5		W5191	2508B	24		23-12-21	ALL
6		W5191	2508ZI			23-12-21	ALL
7		W5191	0002	22		23-12-21	ALL
8		W5191	0003	22		23-12-21	ALL
9		W5191	2503R	24		23-22-11	ALL
10		W5191	2503B	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04197J		**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	11		W5191	2503ZI			23-22-11	ALL
	12		W5191	2501R	24		34-55-21	ALL
	13		W5191	2501B	24		34-55-21	ALL
	14		W5191	2501ZI			34-55-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W5191	0004	22		34-51-21	ALL
	20		W5191	2001R	24		34-51-21	ALL
	21		W5191	2001B	24		34-51-21	ALL
	22		W5191	2002R	24		34-51-21	ALL
	23		W5191	2002B	24		34-51-21	ALL
	24		W5191	2005R	24		23-27-37	ALL
	25		W5191	2005B	24		23-27-37	ALL
	26		W5191	2006R	24		23-27-37	ALL
	27		W5191	2006B	24		23-27-37	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04197J	**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W5191	2001Z			34-51-21	ALL
S/R		W5191	2002Z			34-51-21	ALL
S/R		W5191	2005Z			23-27-37	ALL
S/R		W5191	2006Z			23-27-37	ALL
S/R		W5191	2501ZO			34-55-21	ALL
S/R		W5191	2503ZO			23-22-11	ALL
S/R		W5191	2507ZO			23-12-21	ALL
S/R		W5191	2508ZO			23-12-21	ALL
D04197P	**E001-05/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W0151	2507R	24		23-12-21	ALL
2		W0151	2507B	24		23-12-21	ALL
3		W0151	2507ZI			23-12-21	ALL
4		W0151	2508R	24		23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04197P		**E001-05/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	5		W0151	2508B	24		23-12-21	ALL
	6		W0151	2508ZI			23-12-21	ALL
	7		W0151	0039	24		23-12-21	ALL
	8		W0151	0049	22		23-12-21	ALL
	9		W0151	2003R	24		23-22-11	ALL
	10		W0151	2003B	24		23-22-11	ALL
	11		W0151	2003ZI			23-22-11	ALL
	12		W0151	2009R	24		34-55-21	ALL
	13		W0151	2009B	24		34-55-21	ALL
	14		W0151	2009ZI			34-55-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0151	0041	22		34-51-21	ALL
	20		W0151	2010R	24		34-51-21	ALL
	21		W0151	2010B	24		34-51-21	ALL
	22		W0151	2014R	24		34-51-21	ALL
	23		W0151	2014B	24		34-51-21	ALL
	24		W0151	2046R	24		23-27-37	ALL
	25		W0151	2046B	24		23-27-37	ALL
	26		W0151	2050R	24		23-27-37	ALL
	27		W0151	2050B	24		23-27-37	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04197P	**E001-05/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W0151	2003ZO			23-22-11	ALL
S/R		W0151	2009ZO			34-55-21	ALL
S/R		W0151	2010Z			34-51-21	ALL
S/R		W0151	2014Z			34-51-21	ALL
S/R		W0151	2046Z			23-27-37	ALL
S/R		W0151	2050Z			23-27-37	ALL
S/R		W0151	2507ZO			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04197P		**E001-05/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W0151	2508ZO			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04207J		**P001-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0001	2003R	24		31-65-12	ALL
	A03		W0001	2005R	24		31-65-13	ALL
	A04		W0001	2711R	24		31-65-16	ALL
	A05		W0001	2712R	24		31-65-16	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0001	2003B	24		31-65-12	ALL
	B03		W0001	2005B	24		31-65-13	ALL
	B04		W0001	2711B	24		31-65-16	ALL
	B05		W0001	2712B	24		31-65-16	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04207J		**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0001	2003Z			31-65-12	ALL
	PERG	1F	W0001	2005Z			31-65-13	ALL
	PERG	1F	W0001	2711Z			31-65-16	ALL
	PERG	1F	W0001	2712Z			31-65-16	ALL
D04207P		**P009-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W2207	2002R	24		31-65-12	ALL
	A03		W2207	2005R	24		31-65-13	ALL
	A04		W2207	2711R	24		31-65-16	ALL
	A05		W2207	2712R	24		31-65-16	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04207P		**P009-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2207	2002B	24		31-65-12	ALL
	B03		W2207	2005B	24		31-65-13	ALL
	B04		W2207	2711B	24		31-65-16	ALL
	B05		W2207	2712B	24		31-65-16	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2207	2002Z			31-65-12	ALL
	PERG	1F	W2207	2005Z			31-65-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04207P		**P009-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2207	2711Z			31-65-16	ALL
	PERG	1F	W2207	2712Z			31-65-16	ALL
D04217J		**AB1030A/305/R010**		**JACK-HF-1 COAX**				**ALL**
	=A1		W3557	001CX			23-11-11	ALL
	=C1		W3557	001CO			23-11-11	ALL
D04217P		**AB1030A/305/R010**		**PLUG-HF-1 COAX**				**ALL**
	=A1		W7761	001CX			23-11-11	ALL
	=C1		W7761	001CO			23-11-11	ALL
D04221J		**P009-00/ /**		**RCPT-- CONDUCTIVE**				**ALL**
	1		W0001	1207	20		22-13-11	ALL
	2		W0001	0091	22		22-14-11	ALL
	3	UNUSED						ALL
	4		W0001	0093	22		22-14-11	ALL
	5	UNUSED						ALL
	6		W0001	0094	22		22-14-11	ALL
	7		W0001	0095	22		22-14-11	ALL
	8		W0001	0102	22		22-14-11	ALL
	9		W0001	1101	22		22-31-51	ALL
	10		W0001	1018	22		34-61-16	ALL
	11		W0001	1021	22		34-61-16	ALL
	12		W0001	1162	24		34-49-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0001	1587	22		22-14-11	ALL
	17		W0001	1163	24		34-49-11	ALL
	18		W0003	0750	24		34-49-11	ALL
	19		W0003	0751	24		34-49-11	ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04221J	**P009-00/ /**		**RCPT-- CONDUCTIVE (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W0003	0630	24		34-49-11	ALL
26		W0001	0092	22		22-14-11	ALL
27		W0003	0632	24		34-49-11	ALL
28		W0003	0633	24		34-49-11	ALL
29		W0003	0635	24		34-49-11	ALL
30		W0001	0161	22		34-45-11	ALL
31		W0001	0330	24		23-51-11	ALL
32		W0001	0331	24		23-51-11	ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W0001	1308	22		32-31-11	ALL
39		W0001	2004R	24		31-65-12	ALL
40		W0001	2004B	24		31-65-12	ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W0003	0743	24		34-49-11	ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04221J		**P009-00/ /**		**RCPT-- CONDUCTIVE (continued)**				**ALL**
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W0001	1018Z			34-61-16	ALL
	S/R		W0001	1021Z			34-61-16	ALL
	S/R		W0001	1101Z			22-31-51	ALL
	S/R		W0001	1162Z			34-49-11	ALL
	S/R		W0001	1163Z			34-49-11	ALL
	S/R		W0001	1207Z			22-13-11	ALL
	S/R		W0001	1308Z			32-31-11	ALL
	S/R		W0001	1587Z			22-14-11	ALL
	S/R		W0001	2004Z			31-65-12	ALL
D04221P		**P009-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W2221	0001	22		22-13-11	ALL
	2		W2221	0002	22		22-14-11	ALL
	3	UNUSED						ALL
	4		W2221	0004	22		22-14-11	ALL
	5	UNUSED						ALL
	6		W2221	0006	22		22-14-11	ALL
	7		W2221	0007	22		22-14-11	ALL
	8		W2221	0008	22		22-14-11	ALL
	9		W2221	0009	22		22-31-51	ALL
	10		W2221	0010	22		34-61-16	ALL
	11		W2221	0011	22		34-61-16	ALL
	12		W2221	0111	24		34-49-11	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04221P	**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
14	UNUSED						ALL
15	UNUSED						ALL
16		W2221	0005	22		22-14-11	ALL
17		W2221	0112	24		34-49-11	ALL
18		W2221	0120	24		34-49-11	ALL
19		W2221	0121	24		34-49-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W2221	0113	24		34-49-11	ALL
26		W2221	0003	22		22-14-11	ALL
27		W2221	0114	24		34-49-11	ALL
28		W2221	0115	24		34-49-11	ALL
29		W2221	0116	24		34-49-11	ALL
30		W2221	0211	22		34-45-11	ALL
31		W2221	0031	24		23-51-11	ALL
32		W2221	0032	24		23-51-11	ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W2221	0118	22		32-31-11	ALL
39		W2221	2019R	24		31-65-12	ALL
40		W2221	2019B	24		31-65-12	ALL
41	UNUSED						ALL
42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04221P		**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	43	UNUSED						ALL
	44	UNUSED						ALL
	45		W2221	0012	24		34-49-11	ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W2221	2019Z			31-65-12	ALL
D04227J		**AB1030A/305/R010**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W3553	0005	22		23-11-11	ALL
	6	UNUSED						ALL
	7		W3553	0007	22		23-11-11	ALL
	8		W3553	0008	22		23-11-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W3553	0011	22		23-11-11	ALL
	12		W3553	0012	20		23-11-11	ALL
	13		W3553	0013	20		23-11-11	ALL
	14		W3553	0014	20		23-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04227J	**AB1030A/305/R010**		**RCPT (continued)**				**ALL**
15	UNUSED						ALL
16		W3553	0016	18		23-11-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D04227P	**AB1030A/305/R010**		**PLUG-HF-1 COUPLER**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W7057	0005	22		23-11-11	ALL
6	UNUSED						ALL
7		W7057	0007	22		23-11-11	ALL
8		W7057	0008	22		23-11-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W7057	0011	22		23-11-11	ALL
12		W7057	0012	20		23-11-11	ALL
13		W7057	0013	20		23-11-11	ALL
14		W7057	0014	20		23-11-11	ALL
15	UNUSED						ALL
16		W7057	0016	20		23-11-11	ALL
17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04227P		**AB1030A/305/R010**		**PLUG-HF-1 COUPLER (continued)**				**ALL**
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D04237J		**AP0900A/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0003	2503R	24		31-65-22	ALL
	A03		W0003	2505R	24		31-65-23	ALL
	A04		W0003	2711R	24		31-65-26	ALL
	A05		W0003	2712R	24		31-65-26	ALL
	A06		W0003	0596	24		32-44-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04237J	**AP0900A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B01	UNUSED						ALL
B02		W0003	2503B	24		31-65-22	ALL
B03		W0003	2505B	24		31-65-23	ALL
B04		W0003	2711B	24		31-65-26	ALL
B05		W0003	2712B	24		31-65-26	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0003	2503Z			31-65-22	ALL
PERG	1F	W0003	2505Z			31-65-23	ALL
PERG	1F	W0003	2711Z			31-65-26	ALL
PERG	1F	W0003	2712Z			31-65-26	ALL
D04237P	**P009-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W2237	2001R	24		31-65-22	ALL
A03		W2237	2005R	24		31-65-23	ALL
A04		W2237	2711R	24		31-65-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04237P		**P009-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A05		W2237	2712R	24		31-65-26	ALL
	A06		W2237	0010	22		32-44-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2237	2001B	24		31-65-22	ALL
	B03		W2237	2005B	24		31-65-23	ALL
	B04		W2237	2711B	24		31-65-26	ALL
	B05		W2237	2712B	24		31-65-26	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04237P	**P009-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W2237	2001Z			31-65-22	ALL
PERG	1F	W2237	2005Z			31-65-23	ALL
PERG	1F	W2237	2711Z			31-65-26	ALL
PERG	1F	W2237	2712Z			31-65-26	ALL
D04245J	**AB1030A/305/R010**		**RCPT-HF-2 COUPLER**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W3555	0005	22		23-11-21	ALL
6	UNUSED						ALL
7		W3555	0007	22		23-11-21	ALL
8		W3555	0008	22		23-11-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W3555	0011	22		23-11-21	ALL
12		W3555	0012	20		23-11-21	ALL
13		W3555	0013	20		23-11-21	ALL
14		W3555	0014	20		23-11-21	ALL
15	UNUSED						ALL
16		W3555	0016	18		23-11-21	ALL
17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04245J		**AB1030A/305/R010**		**RCPT-HF-2 COUPLER (continued)**				**ALL**
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D04245P		**AB1030A/305/R010**		**PLUG-HF-2 COUPLER**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W7061	0005	22		23-11-21	ALL
	6	UNUSED						ALL
	7		W7061	0007	22		23-11-21	ALL
	8		W7061	0008	22		23-11-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W7061	0011	22		23-11-21	ALL
	12		W7061	0012	20		23-11-21	ALL
	13		W7061	0013	20		23-11-21	ALL
	14		W7061	0014	20		23-11-21	ALL
	15	UNUSED						ALL
	16		W7061	0016	20		23-11-21	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04245P	**AB1030A/305/R010**		**PLUG-HF-2 COUPLER (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D04251J	**AP0900A/214/0**		**INSERT**				**ALL**
1		W0003	1707	20		22-13-11	ALL
2		W0003	0591	22		22-14-11	ALL
3		W0003	1001	22		34-61-16	ALL
4	UNUSED						ALL
5		W0003	1584	22		22-14-11	ALL
6		W0003	0594	22		22-14-11	ALL
7	UNUSED						ALL
8		W0003	1601	22		22-31-51	ALL
9	UNUSED						ALL
10		W0003	0592	22		22-14-11	ALL
11	UNUSED						ALL
12		W0003	0593	22		22-14-11	ALL
13		W0003	2504R	24		31-65-22	ALL
14		W0003	2504B	24		31-65-22	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0003	0007	24		23-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04251J		**AP0900A/214/0**		**INSERT (continued)**				**ALL**
	24		W0003	0008	24		23-51-21	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	PERS	1A	W0003	1001Z			34-61-16	ALL
	PERS	1A	W0003	1584Z			22-14-11	ALL
	PERS	1A	W0003	1601Z			22-31-51	ALL
	PERS	1A	W0003	1707Z			22-13-11	ALL
	PERS	1A	W0003	2504Z			31-65-22	ALL
D04251P		**P009-00/ /**		**INSERT**				**ALL**
	1		W2251	0001	22		22-13-11	ALL
	2		W2251	0002	22		22-14-11	ALL
	3		W2251	0010	22		34-61-16	ALL
	4	UNUSED						ALL
	5		W2251	0005	22		22-14-11	ALL
	6		W2251	0006	22		22-14-11	ALL
	7	UNUSED						ALL
	8		W2251	0008	22		22-31-51	ALL
	9	UNUSED						ALL
	10		W2251	0004	22		22-14-11	ALL
	11	UNUSED						ALL
	12		W2251	0011	22		22-14-11	ALL
	13		W2251	2001R	24		31-65-22	ALL
	14		W2251	2001B	24		31-65-22	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04251P	**P009-00/ /**		**INSERT (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W2251	0013	24		23-51-21	ALL
24		W2251	0014	24		23-51-21	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
PERS	1A	W2251	2001Z			31-65-22	ALL
D04267J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0311	2002R	24		31-65-12	ALL
A04		W0311	2002B	24		31-65-12	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0311	2010R	24		31-65-13	ALL
A10		W0311	2010B	24		31-65-13	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04267J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0311	2127R	22		SPARE	ALL
	A18		W0311	2127B	22		SPARE	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0311	2053R	22		28-41-11	ALL
	B04		W0311	2053B	22		28-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0311	2711R	24		31-65-16	ALL
	B14		W0311	2711B	24		31-65-16	ALL
	B15		W0311	2712R	24		31-65-16	ALL
	B16		W0311	2712B	24		31-65-16	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2002Z			31-65-12	ALL
	PERG	1F	W0311	2010Z			31-65-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04267J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0311	2053Z			28-41-11	ALL
PERG	1F	W0311	2127Z			SPARE	ALL
PERG	1F	W0311	2711Z			31-65-16	ALL
PERG	1F	W0311	2712Z			31-65-16	ALL
D04267P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W2207	2002R	24		31-65-12	ALL
A04		W2207	2002B	24		31-65-12	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W2207	2005R	24		31-65-13	ALL
A10		W2207	2005B	24		31-65-13	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W2207	2012R	22		28-41-11	ALL
B04		W2207	2012B	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04267P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W2207	2711R	24		31-65-16	ALL
	B14		W2207	2711B	24		31-65-16	ALL
	B15		W2207	2712R	24		31-65-16	ALL
	B16		W2207	2712B	24		31-65-16	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2207	2002Z			31-65-12	ALL
	PERG	1F	W2207	2005Z			31-65-13	ALL
	PERG	1F	W2207	2012Z			28-41-11	ALL
	PERG	1F	W2207	2711Z			31-65-16	ALL
	PERG	1F	W2207	2712Z			31-65-16	ALL
D04271J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	2130R	24		34-57-11	ALL
	A02		W0311	2130ZI			34-57-11	ALL
	A03		W0311	0140	20		SPARE	ALL
	A04		W0311	2139R	24		34-49-11	ALL
	A05		W0311	2139ZI			34-49-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04271J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0311	2708R	24		31-65-15	ALL
	B01		W0311	2130B	24		34-57-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0311	2139B	24		34-49-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0311	2708B	24		31-65-15	ALL
	PERG	1F	W0311	2130ZO			34-57-11	ALL
	PERG	1F	W0311	2139ZO			34-49-11	ALL
	PERG	1F	W0311	2708Z			31-65-15	ALL
D04271P		**E003-01/ /**		**PLUG- E3-1 SHELF**				**ALL**
	A01		W5189	2502R	24		34-57-11	ALL
	A02		W5189	2502ZI			34-57-11	ALL
	A03		W5189	0055	22		SPARE	ALL
	A04		W5189	2511R	24		34-49-11	ALL
	A05		W5189	2511ZI			34-49-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5189	2001R	24		31-65-15	ALL
	B01		W5189	2502B	24		34-57-11	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04271P		**E003-01/ /**		**PLUG- E3-1 SHELF (continued)**				**ALL**
	B03	UNUSED						ALL
	B04		W5189	2511B	24		34-49-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5189	2001B	24		31-65-15	ALL
	PERG	1F	W5189	2001Z			31-65-15	ALL
	PERG	1F	W5189	2502ZO			34-57-11	ALL
	PERG	1F	W5189	2511ZO			34-49-11	ALL
D04277J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2630R	24		34-57-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0313	2758R	22		31-32-15	ALL
	A05	UNUSED						ALL
	A06		W0313	0010	24		31-31-17	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04277J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0313	2630B	24		34-57-21	ALL
B02		W0313	2630ZI			34-57-21	ALL
B03	UNUSED						ALL
B04		W0313	2758B	22		31-32-15	ALL
B05	UNUSED						ALL
B06		W0313	0632	24		31-65-42	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0313	2630ZO			34-57-21	ALL
PERG	1F	W0313	2758Z			31-32-15	ALL
D04277P	**E003-01/ /**		**PLUG-E3-1 SHELF**				**ALL**
A01		W5191	2502R	24		34-57-21	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04277P		**E003-01/ /**		**PLUG-E3-1 SHELF (continued)**				**ALL**
	A04		W5191	2517R	22		31-32-15	ALL
	A05	UNUSED						ALL
	A06		W5191	0020	24		31-31-17	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5191	2502B	24		34-57-21	ALL
	B02		W5191	2502ZI			34-57-21	ALL
	B03	UNUSED						ALL
	B04		W5191	2517B	22		31-32-15	ALL
	B05	UNUSED						ALL
	B06		W5191	0040	24		31-65-42	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04277P		**E003-01/ /**		**PLUG-E3-1 SHELF (continued)**				**ALL**
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5191	2502ZO			34-57-21	ALL
	PERG	1F	W5191	2517Z			31-32-15	ALL
D04285J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	0056	22		23-22-11	ALL
	A02		W0411	0289	22		23-12-21	ALL
	A03		W0411	2512R	24		34-55-21	ALL
	A04		W0411	2514R	24		34-57-21	ALL
	A05	UNUSED						ALL
	A06		W0411	2517R	24		23-22-11	ALL
	A07		W0411	2505R	24		34-31-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0411	2520R	24		23-12-21	ALL
	A11		W0411	2521ZI			23-12-21	ALL
	A12		W0411	2521R	24		23-12-21	ALL
	A13		W0411	0308	22		23-11-21	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0411	0482	24		31-65-42	ALL
	A18		W0411	2568R	24		23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04285J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A19		W0411	2569R	24		23-11-21	ALL
A20		W0411	2569ZI			23-11-21	ALL
B01		W0411	0179	24		23-12-21	ALL
B02		W0411	2512ZI			34-55-21	ALL
B03		W0411	2512B	24		34-55-21	ALL
B04		W0411	2514B	24		34-57-21	ALL
B05		W0411	2514ZI			34-57-21	ALL
B06		W0411	2517B	24		23-22-11	ALL
B07		W0411	2505B	24		34-31-21	ALL
B08		W0411	2505ZI			34-31-21	ALL
B09	UNUSED						ALL
B10		W0411	2520B	24		23-12-21	ALL
B11		W0411	2520ZI			23-12-21	ALL
B12		W0411	2521B	24		23-12-21	ALL
B13		W0411	2517ZI			23-22-11	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16		W0411	2568ZI			23-11-21	ALL
B17	UNUSED						ALL
B18		W0411	2568B	24		23-11-21	ALL
B19		W0411	2569B	24		23-11-21	ALL
B20		W0411	0342	20		23-71-01	ALL
PERG	1F	W0411	2505ZO			34-31-21	ALL
PERG	1F	W0411	2512ZO			34-55-21	ALL
PERG	1F	W0411	2514ZO			34-57-21	ALL
PERG	1F	W0411	2517ZO			23-22-11	ALL
PERG	1F	W0411	2520ZO			23-12-21	ALL
PERG	1F	W0411	2521ZO			23-12-21	ALL
PERG	1F	W0411	2568ZO			23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04285J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0411	2569ZO			23-11-21	ALL
D04285P	**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5191	0001	22		23-22-11	ALL
A02		W5191	0003	22		23-12-21	ALL
A03		W5191	2501R	24		34-55-21	ALL
A04		W5191	2502R	24		34-57-21	ALL
A05	UNUSED						ALL
A06		W5191	2503R	24		23-22-11	ALL
A07		W5191	2505R	24		34-31-21	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W5191	2507R	24		23-12-21	ALL
A11		W5191	2508ZI			23-12-21	ALL
A12		W5191	2508R	24		23-12-21	ALL
A13		W5191	0009	22		23-11-21	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17		W5191	0040	24		31-65-42	ALL
A18		W5191	2518R	24		23-11-21	ALL
A19		W5191	2519R	24		23-11-21	ALL
A20		W5191	2519ZI			23-11-21	ALL
B01		W5191	0002	22		23-12-21	ALL
B02		W5191	2501ZI			34-55-21	ALL
B03		W5191	2501B	24		34-55-21	ALL
B04		W5191	2502B	24		34-57-21	ALL
B05		W5191	2502ZI			34-57-21	ALL
B06		W5191	2503B	24		23-22-11	ALL
B07		W5191	2505B	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04285P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B08		W5191	2505ZI			34-31-21	ALL
	B09	UNUSED						ALL
	B10		W5191	2507B	24		23-12-21	ALL
	B11		W5191	2507ZI			23-12-21	ALL
	B12		W5191	2508B	24		23-12-21	ALL
	B13		W5191	2503ZI			23-22-11	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W5191	2518ZI			23-11-21	ALL
	B17	UNUSED						ALL
	B18		W5191	2518B	24		23-11-21	ALL
	B19		W5191	2519B	24		23-11-21	ALL
	B20		W5191	0025	20		23-71-01	ALL
	PERG	1F	W5191	2501ZO			34-55-21	ALL
	PERG	1F	W5191	2502ZO			34-57-21	ALL
	PERG	1F	W5191	2503ZO			23-22-11	ALL
	PERG	1F	W5191	2505ZO			34-31-21	ALL
	PERG	1F	W5191	2507ZO			23-12-21	ALL
	PERG	1F	W5191	2508ZO			23-12-21	ALL
	PERG	1F	W5191	2518ZO			23-11-21	ALL
	PERG	1F	W5191	2519ZO			23-11-21	ALL
D04287J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	0072	22		23-42-12	ALL
	A02		W0411	0074	24		23-12-11	ALL
	A03		W0411	2510R	24		34-49-11	ALL
	A04		W0411	2511R	24		34-55-11	ALL
	A05		W0411	2513ZI			34-57-11	ALL
	A06		W0411	2513R	24		34-57-11	ALL
	A07		W0411	2516R	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04287J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A08		W0411	2504R	24		34-31-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12		W0411	2518ZI			23-12-11	ALL
A13		W0411	2518R	24		23-12-11	ALL
A14		W0411	2519R	24		23-12-11	ALL
A15	UNUSED						ALL
A16		W0411	3006Z			23-42-12	ALL
A17		W0411	3006R	24		23-42-12	ALL
A18		W0411	3006Y	24		23-42-12	ALL
A19	UNUSED						ALL
A20		W0411	2515R	24		31-65-15	ALL
B01		W0411	0287	22		23-12-11	ALL
B02		W0411	2516ZI			23-22-11	ALL
B03		W0411	2510B	24		34-49-11	ALL
B04		W0411	2511B	24		34-55-11	ALL
B05		W0411	2511ZI			34-55-11	ALL
B06		W0411	2513B	24		34-57-11	ALL
B07		W0411	2516B	24		23-22-11	ALL
B08		W0411	2504B	24		34-31-11	ALL
B09		W0411	2504ZI			34-31-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W0411	2518B	24		23-12-11	ALL
B14		W0411	2519B	24		23-12-11	ALL
B15		W0411	2519ZI			23-12-11	ALL
B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04287J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B17		W0411	3006B	24		23-42-12	ALL
	B18		W0411	2510ZI			34-49-11	ALL
	B19	UNUSED						ALL
	B20		W0411	2515B	24		31-65-15	ALL
	PERG	1F	W0411	2504ZO			34-31-11	ALL
	PERG	1F	W0411	2510ZO			34-49-11	ALL
	PERG	1F	W0411	2511ZO			34-55-11	ALL
	PERG	1F	W0411	2513ZO			34-57-11	ALL
	PERG	1F	W0411	2515Z			31-65-15	ALL
	PERG	1F	W0411	2516ZO			23-22-11	ALL
	PERG	1F	W0411	2518ZO			23-12-11	ALL
	PERG	1F	W0411	2519ZO			23-12-11	ALL
D04287P		**E004-01/ /**		**PLUG- E4-1 SHELF**				**ALL**
	A01		W5189	0011	22		23-42-12	ALL
	A02		W5189	0013	22		23-12-11	ALL
	A03		W5189	2511R	24		34-49-11	ALL
	A04		W5189	2501R	24		34-55-11	ALL
	A05		W5189	2502ZI			34-57-11	ALL
	A06		W5189	2502R	24		34-57-11	ALL
	A07		W5189	2503R	24		23-22-11	ALL
	A08		W5189	2505R	24		34-31-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W5189	2508ZI			23-12-11	ALL
	A13		W5189	2508R	24		23-12-11	ALL
	A14		W5189	2509R	24		23-12-11	ALL
	A15	UNUSED						ALL
	A16		W5189	3501Z			23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04287P	**E004-01/ /**		**PLUG- E4-1 SHELF (continued)**				**ALL**
A17		W5189	3501R	24		23-42-12	ALL
A18		W5189	3501Y	24		23-42-12	ALL
A19	UNUSED						ALL
A20		W5189	2001R	24		31-65-15	ALL
B01		W5189	0012	22		23-12-11	ALL
B02		W5189	2503ZI			23-22-11	ALL
B03		W5189	2511B	24		34-49-11	ALL
B04		W5189	2501B	24		34-55-11	ALL
B05		W5189	2501ZI			34-55-11	ALL
B06		W5189	2502B	24		34-57-11	ALL
B07		W5189	2503B	24		23-22-11	ALL
B08		W5189	2505B	24		34-31-11	ALL
B09		W5189	2505ZI			34-31-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W5189	2508B	24		23-12-11	ALL
B14		W5189	2509B	24		23-12-11	ALL
B15		W5189	2509ZI			23-12-11	ALL
B16	UNUSED						ALL
B17		W5189	3501B	24		23-42-12	ALL
B18		W5189	2511ZI			34-49-11	ALL
B19	UNUSED						ALL
B20		W5189	2001B	24		31-65-15	ALL
PERG	1F	W5189	2001Z			31-65-15	ALL
PERG	1F	W5189	2501ZO			34-55-11	ALL
PERG	1F	W5189	2502ZO			34-57-11	ALL
PERG	1F	W5189	2503ZO			23-22-11	ALL
PERG	1F	W5189	2505ZO			34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04287P		**E004-01/ /**		**PLUG- E4-1 SHELF (continued)**				**ALL**
	PERG	1F	W5189	2508ZO			23-12-11	ALL
	PERG	1F	W5189	2509ZO			23-12-11	ALL
	PERG	1F	W5189	2511ZO			34-49-11	ALL
D04289J		**E004-01/ /**		**RECT-CONDUCTIVE**				**ALL**
	A01		W0411	2610R	24		23-27-37	ALL
	A02		W0411	2509R	24		23-22-11	ALL
	A03		W0411	2529R	24		23-12-31	ALL
	A04		W0411	2529ZI			23-12-31	ALL
	A05		W0411	2530R	24		23-12-31	ALL
	A06	UNUSED						ALL
	A07		W0411	2509ZI			23-22-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0411	2543R	24		23-22-11	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W0411	2613R	24		23-27-37	ALL
	A20	UNUSED						ALL
	B01		W0411	2610B	24		23-27-37	ALL
	B02		W0411	2509B	24		23-22-11	ALL
	B03		W0411	2529B	24		23-12-31	ALL
	B04		W0411	2530ZI			23-12-31	ALL
	B05		W0411	2530B	24		23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04289J	**E004-01/ /**		**RECT-CONDUCTIVE (continued)**				**ALL**
B06	UNUSED						ALL
B07		W0411	0087	24		23-12-31	ALL
B08		W0411	0290	22		23-12-31	ALL
B09		W0411	2543ZI			23-22-11	ALL
B10		W0411	2543B	24		23-22-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W0411	2613B	24		23-27-37	ALL
B20	UNUSED						ALL
PERG	1F	W0411	2509ZO			23-22-11	ALL
PERG	1F	W0411	2529ZO			23-12-31	ALL
PERG	1F	W0411	2530ZO			23-12-31	ALL
PERG	1F	W0411	2543ZO			23-22-11	ALL
PERG	1F	W0411	2610Z			23-27-37	ALL
PERG	1F	W0411	2613Z			23-27-37	ALL
D04289P	**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5191	2007R	24		23-27-37	ALL
A02		W5191	2542R	24		23-22-11	ALL
A03		W5191	2528R	24		23-12-31	ALL
A04		W5191	2528ZI			23-12-31	ALL
A05		W5191	2529R	24		23-12-31	ALL
A06	UNUSED						ALL
A07		W5191	2542ZI			23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04289P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5191	2525R	24		23-22-11	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W5191	2008R	24		23-27-37	ALL
	A20	UNUSED						ALL
	B01		W5191	2007B	24		23-27-37	ALL
	B02		W5191	2542B	24		23-22-11	ALL
	B03		W5191	2528B	24		23-12-31	ALL
	B04		W5191	2529ZI			23-12-31	ALL
	B05		W5191	2529B	24		23-12-31	ALL
	B06	UNUSED						ALL
	B07		W5191	0015	22		23-12-31	ALL
	B08		W5191	0014	22		23-12-31	ALL
	B09		W5191	2525ZI			23-22-11	ALL
	B10		W5191	2525B	24		23-22-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04289P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W5191	2008B	24		23-27-37	ALL
	B20	UNUSED						ALL
	PERG	1F	W5191	2007Z			23-27-37	ALL
	PERG	1F	W5191	2008Z			23-27-37	ALL
	PERG	1F	W5191	2525ZO			23-22-11	ALL
	PERG	1F	W5191	2528ZO			23-12-31	ALL
	PERG	1F	W5191	2529ZO			23-12-31	ALL
	PERG	1F	W5191	2542ZO			23-22-11	ALL
D04297J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2502R	24		31-65-22	ALL
	A02		W0313	2502B	24		31-65-22	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0313	2510R	24		31-65-23	ALL
	A10		W0313	2510B	24		31-65-23	ALL
	A11		W0313	2711R	24		31-65-26	ALL
	A12		W0313	2711B	24		31-65-26	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04297J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0313	0005	22		30-31-12	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0313	2712R	24		31-65-26	ALL
	B14		W0313	2712B	24		31-65-26	ALL
	B15		W0313	0006	22		30-31-12	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2502Z			31-65-22	ALL
	PERG	1F	W0313	2510Z			31-65-23	ALL
	PERG	1F	W0313	2711Z			31-65-26	ALL
	PERG	1F	W0313	2712Z			31-65-26	ALL
D04297P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2237	2001R	24		31-65-22	ALL
	A02		W2237	2001B	24		31-65-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04297P	**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W2237	2005R	24		31-65-23	ALL
A10		W2237	2005B	24		31-65-23	ALL
A11		W2237	2711R	24		31-65-26	ALL
A12		W2237	2711B	24		31-65-26	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W2237	0005	22		30-31-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04297P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B12	UNUSED						ALL
	B13		W2237	2712R	24		31-65-26	ALL
	B14		W2237	2712B	24		31-65-26	ALL
	B15		W2237	0006	22		30-31-11	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2237	2001Z			31-65-22	ALL
	PERG	1F	W2237	2005Z			31-65-23	ALL
	PERG	1F	W2237	2711Z			31-65-26	ALL
	PERG	1F	W2237	2712Z			31-65-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04331J	**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0411	2502R	24		23-51-21	ALL
A02		W0411	0007	22		23-51-21	ALL
A03		W0411	0008	22		23-51-21	ALL
A04		W0411	0010	22		23-51-21	ALL
A05		W0411	4253B	24		23-51-21	ALL
A06		W0411	2004R	24		23-51-21	ALL
A07		W0411	2005R	24		23-51-21	ALL
A08		W0411	3004R	24		23-51-21	ALL
A09		W0411	2005Z			23-51-21	ALL
A10		W0411	2006R	24		23-51-21	ALL
A11		W0411	0350	22		23-51-21	ALL
A12		W0411	0386	24		23-22-11	ALL
A13		W0411	0387	24		23-22-11	ALL
A14		W0411	0388	24		23-22-11	ALL
A15		W0411	0191	24		23-22-11	ALL
A16		W0411	0389	24		23-22-11	ALL
A17		W0411	0069	22		23-51-21	ALL
A18	UNUSED						ALL
A19		W0411	0189	22		23-27-31	ALL
A20		W0411	0482	24		31-65-42	ALL
B01		W0411	2502B	24		23-51-21	ALL
B02		W0411	4253G	24		23-51-21	ALL
B03		W0411	0009	22		23-51-21	ALL
B04		W0411	4253R	24		23-51-21	ALL
B05		W0411	4253Y	24		23-51-21	ALL
B06		W0411	2004B	24		23-51-21	ALL
B07		W0411	2005B	24		23-51-21	ALL
B08		W0411	3004B	24		23-51-21	ALL
B09		W0411	3004Y	24		23-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04331J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10		W0411	2006B	24		23-51-21	ALL
	B11		W0411	3004Z			23-51-21	ALL
	B12		W0411	4253Z			23-51-21	ALL
	B13		W0411	0069	22		23-51-21	ALL
	B14		W0411	0196	24		23-43-11	ALL
	B15		W0411	0197	24		23-43-11	ALL
	B16		W0411	0275	24		23-15-13	ALL
	B17		W0411	0277	24		23-15-13	ALL
	B18		W0411	0276	24		23-15-13	ALL
	B19		W0411	0278	24		23-15-13	ALL
	B20	UNUSED						ALL
	PERG	1F	W0411	2004Z			23-51-21	ALL
	PERG	1F	W0411	2502Z			23-51-21	ALL
D04331P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W3319	2501R	24		23-51-21	ALL
	A02		W3319	0001	22		23-51-21	ALL
	A03		W3319	0002	22		23-51-21	ALL
	A04		W3319	0004	22		23-51-21	ALL
	A05		W3319	4251B	24		23-51-21	ALL
	A06		W3319	2502R	24		23-51-21	ALL
	A07		W3319	2503R	24		23-51-21	ALL
	A08		W3319	3501R	24		23-51-21	ALL
	A09		W3319	2503Z			23-51-21	ALL
	A10		W3319	2001R	24		23-51-21	ALL
	A11		W3319	0031	22		23-51-21	ALL
	A12		W3319	0013	24		23-22-11	ALL
	A13		W3319	0020	24		23-22-11	ALL
	A14		W3319	0019	24		23-22-11	ALL
	A15		W3319	0018	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04331P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A16		W3319	0017	24		23-22-11	ALL
	A17		W3319	0014	22		23-51-21	ALL
	A18	UNUSED						ALL
	A19		W3319	0022	22		23-27-31	ALL
	A20		W3319	0054	24		31-65-42	ALL
	B01		W3319	2501B	24		23-51-21	ALL
	B02		W3319	4251G	24		23-51-21	ALL
	B03		W3319	0003	22		23-51-21	ALL
	B04		W3319	4251R	24		23-51-21	ALL
	B05		W3319	4251Y	24		23-51-21	ALL
	B06		W3319	2502B	24		23-51-21	ALL
	B07		W3319	2503B	24		23-51-21	ALL
	B08		W3319	3501B	24		23-51-21	ALL
	B09		W3319	3501Y	24		23-51-21	ALL
	B10		W3319	2001B	24		23-51-21	ALL
	B11		W3319	3501Z			23-51-21	ALL
	B12		W3319	4251Z			23-51-21	ALL
	B13		W3319	0015	22		23-51-21	ALL
	B14		W3319	0010	24		23-43-11	ALL
	B15		W3319	0023	24		23-43-11	ALL
	B16		W3319	0037	24		23-15-13	ALL
	B17		W3319	0038	24		23-15-13	ALL
	B18		W3319	0039	24		23-15-13	ALL
	B19		W3319	0040	24		23-15-13	ALL
	B20	UNUSED						ALL
	PERG	1F	W3319	2501Z			23-51-21	ALL
	PERG	1F	W3319	2502Z			23-51-21	ALL
D04371J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	0342	20		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04371J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A02		W0411	0048	22		23-71-01	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0411	2515R	24		31-65-15	ALL
	A07		W0411	2523R	24		23-51-51	ALL
	A08	UNUSED						ALL
	A09		W0411	2524R	24		23-51-51	ALL
	A10	UNUSED						ALL
	A11		W0411	2525R	24		23-51-51	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0411	2737R	24		23-27-35	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0411	0587	22		21-27-51	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0411	2515B	24		31-65-15	ALL
	B07		W0411	2523B	24		23-51-51	ALL
	B08		W0411	2523Z			23-51-51	ALL
	B09		W0411	2524B	24		23-51-51	ALL
	B10		W0411	2524Z			23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04371J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B11		W0411	2525B	24		23-51-51	ALL
B12		W0411	2525Z			23-51-51	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W0411	2737B	24		23-27-35	ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20		W0411	0588	22		21-27-51	ALL
PERG	1F	W0411	2515Z			31-65-15	ALL
PERG	1F	W0411	2737Z			23-27-35	ALL
D04371P	**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5431	0002	20		23-71-01	ALL
A02		W5431	0004	22		23-71-01	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W5431	2001R	24		31-65-15	ALL
A07		W5431	2002R	24		23-51-51	ALL
A08	UNUSED						ALL
A09		W5431	2003R	24		23-51-51	ALL
A10	UNUSED						ALL
A11		W5431	2004R	24		23-51-51	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04371P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A17		W5431	2008R	24		23-27-35	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W5431	0029	22		21-27-51	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5431	2001B	24		31-65-15	ALL
	B07		W5431	2002B	24		23-51-51	ALL
	B08		W5431	2002Z			23-51-51	ALL
	B09		W5431	2003B	24		23-51-51	ALL
	B10		W5431	2003Z			23-51-51	ALL
	B11		W5431	2004B	24		23-51-51	ALL
	B12		W5431	2004Z			23-51-51	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5431	2008B	24		23-27-35	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W5431	0030	22		21-27-51	ALL
	PERG	1F	W5431	2001Z			31-65-15	ALL
	PERG	1F	W5431	2008Z			23-27-35	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04425J	**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
A01		W0111	0728	22		22-18-11	ALL
A02		W0111	0729	22		22-18-11	ALL
A03		W0111	2047B	22		22-18-11	ALL
A04		W0111	2047R	22		22-18-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0111	0135	20		22-18-11	ALL
B04	UNUSED						ALL
B05		W0111	2043B	22		22-18-11	ALL
B06		W0111	2043R	22		22-18-11	ALL
B07		W0111	0727	22		22-18-11	ALL
B08		W0111	0726	22		22-18-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0111	2043Z			22-18-11	ALL
PERG	1F	W0111	2047Z			22-18-11	ALL
D04425P	**E001-01/ /**		**PLUG-**				**ALL**
A01		W5301	2001B	22		22-18-11	ALL
A02		W5301	2001R	22		22-18-11	ALL
A03		W5301	2006B	22		22-18-11	ALL
A04		W5301	2006R	22		22-18-11	ALL
A05		W5301	0015	22		SPARE	ALL
A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04425P		**E001-01/ /**		**PLUG- (continued)**				**ALL**
	A07		W5301	0017	22		SPARE	ALL
	A08	UNUSED						ALL
	A09		W5301	0019	22		SPARE	ALL
	A10	UNUSED						ALL
	B01		W5301	0021	22		SPARE	ALL
	B02	UNUSED						ALL
	B03		W5301	0013	20		22-18-11	ALL
	B04	UNUSED						ALL
	B05		W5301	2026B	22		22-18-11	ALL
	B06		W5301	2026R	22		22-18-11	ALL
	B07		W5301	2024B	22		22-18-11	ALL
	B08		W5301	2024R	22		22-18-11	ALL
	B09		W5301	2007R	22		SPARE	ALL
	B10		W5301	2007B	22		SPARE	ALL
D04435J		**MULTI/ /**		**RECP - (C)**				**ALL**
	=A1		W7137	001CX			34-51-11	ALL
	=C1		W7137	001CO			34-51-11	ALL
D04435P		**MULTI/ /**		**PLUG - (C)**				**ALL**
	=A1		W7153	001CX			34-51-11	ALL
	=C1		W7153	001CO			34-51-11	ALL
D04437J		**MULTI/ /**		**RCPT - (C)**				**ALL**
	=A1		W8137	001CX			34-51-21	ALL
	=C1		W8137	001CO			34-51-21	ALL
D04437P		**MULTI/ /**		**PLUG - (C)**				**ALL**
	=A1		W8153	001CX			34-51-21	ALL
	=C1		W8153	001CO			34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04578J	**OFSS 388/ /**		**RECP**				**ALL**
1		W1664	1015	20		28-44-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1664	2001R	20		28-41-11	ALL
5		W1664	2001B	20		28-41-11	ALL
6	UNUSED						ALL
7		W1664	1018	20		28-44-11	ALL
8		W1664	1021	20		28-44-11	ALL
9		W1664	1017	20		28-44-11	ALL
10		W1664	1016	20		28-44-11	ALL
11		W1664	1035	20		28-44-11	ALL
12		W1664	1012	20		28-44-11	ALL
13	UNUSED						ALL
14		W1664	1019	20		28-44-11	ALL
15	UNUSED						ALL
16		W1664	1014	20		28-44-11	ALL
17	UNUSED						ALL
18		W1664	1020	20		28-44-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W1664	1034	20		28-44-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W1664	1012Z			28-44-11	ALL
S/R		W1664	1014Z			28-44-11	ALL
S/R		W1664	1015Z			28-44-11	ALL
S/R		W1664	1016Z			28-44-11	ALL
S/R		W1664	1017Z			28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04578J		**OFSS 388/ /**		**RECP (continued)**				**ALL**
	S/R		W1664	1018Z			28-44-11	ALL
	S/R		W1664	1019Z			28-44-11	ALL
	S/R		W1664	1020Z			28-44-11	ALL
	S/R		W1664	1021Z			28-44-11	ALL
	S/R		W1664	1034Z			28-44-11	ALL
	S/R		W1664	2001ZI			28-41-11	ALL
D04580J		**AB0536L/*/***		**RCPT-CONDUCTIVE**				**ALL**
	1		W5102	1017	20		33-33-11	ALL
	2		W5102	1016	20		33-33-11	ALL
	3		W5102	1019	20		33-33-11	ALL
	4		W5102	1018	20		33-33-11	ALL
	5		W5102	2090R	20		21-51-14	ALL
	6		W5102	1033	20		21-51-15	ALL
	7		W5102	1001	20		21-51-15	ALL
	8		W5102	1013R	20		26-12-11	ALL
	9		W5102	1014R	20		26-12-11	ALL
	10		W5102	1015R	20		26-12-11	ALL
	11		W5102	1025R	20		26-12-11	ALL
	12	UNUSED						ALL
	13		W5102	2007B	22		36-21-11	ALL
	14		W5102	2007R	22		36-21-11	ALL
	15		W5102	2090B	20		21-51-14	ALL
	S/R		W5102	1001Z			21-51-15	ALL
	S/R		W5102	1013Z			26-12-11	ALL
	S/R		W5102	1014Z			26-12-11	ALL
	S/R		W5102	1015Z			26-12-11	ALL
	S/R		W5102	1016Z			33-33-11	ALL
	S/R		W5102	1017Z			33-33-11	ALL
	S/R		W5102	1018Z			33-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04580J		**AB0536L/*/***		**RCPT-CONDUCTIVE (continued)**				**ALL**
	S/R		W5102	1019Z			33-33-11	ALL
	S/R		W5102	1025Z			26-12-11	ALL
	S/R		W5102	1033Z			21-51-15	ALL
	S/R		W5102	2007Z			36-21-11	ALL
	S/R		W5102	2090Z			21-51-14	ALL
D04580P		**AB0536L/*/***		**PLUG-CONDUCTIVE**				**ALL**
	1		W5526	0519	20		33-33-11	ALL
	2		W5526	0518	20		33-33-11	ALL
	3		W5526	0521	20		33-33-11	ALL
	4		W5526	0520	20		33-33-11	ALL
	5		W5526	2090R	24		21-51-14	ALL
	6		W5526	0301	24		21-51-15	ALL
	7		W5526	5508	24		21-51-15	ALL
	8		W5526	6002R	20		26-12-11	ALL
	9		W5526	6003R	20		26-12-11	ALL
	10		W5526	6004R	20		26-12-11	ALL
	11		W5526	6005R	20		26-12-11	ALL
	12	UNUSED						ALL
	13		W5526	2501B	24		36-21-11	ALL
	14		W5526	2501R	24		36-21-11	ALL
	15		W5526	2090B	24		21-51-14	ALL
	S/R		W5526	2090Z			21-51-14	ALL
	S/R		W5526	2501Z			36-21-11	ALL
D04582J		**AB0536R/*/***		**RCPT-CONDUCTIVE**				**ALL**
	1		W6202	1009R	20		26-12-11	ALL
	2		W6202	1008R	20		26-12-11	ALL
	3	UNUSED						ALL
	4		W6202	1017	20		33-33-11	ALL
	5		W6202	1034	20		21-51-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04582J		**AB0536R/*/***		**RCPT-CONDUCTIVE (continued)**				**ALL**
	6		W6202	1010R	20		26-12-11	ALL
	7		W6202	1027	20		21-51-25	ALL
	8		W6202	2083B	20		21-61-13	ALL
	9		W6202	2083R	20		21-61-13	ALL
	10		W6202	1039	20		21-61-13	ALL
	11		W6202	2085B	20		21-61-14	ALL
	12		W6202	2085R	20		21-61-14	ALL
	13		W6202	1043	20		21-61-14	ALL
	14		W6202	1021R	20		26-12-11	ALL
	15	UNUSED						ALL
	S/R		W6202	1008Z			26-12-11	ALL
	S/R		W6202	1009Z			26-12-11	ALL
	S/R		W6202	1010Z			26-12-11	ALL
	S/R		W6202	1017Z			33-33-11	ALL
	S/R		W6202	1021Z			26-12-11	ALL
	S/R		W6202	1027Z			21-51-25	ALL
	S/R		W6202	1034Z			21-51-25	ALL
	S/R		W6202	1039Z			21-61-13	ALL
	S/R		W6202	1043Z			21-61-14	ALL
	S/R		W6202	2083Z			21-61-13	ALL
	S/R		W6202	2085Z			21-61-14	ALL
D04582P		**AB0536R/158/R027**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6528	6004R	20		26-12-11	ALL
	2		W6528	6002R	20		26-12-11	ALL
	3	UNUSED						ALL
	4		W6528	0001	20		33-33-11	ALL
	5		W6528	5510	24		21-51-25	ALL
	6		W6528	6005R	20		26-12-11	ALL
	7		W6528	5511	24		21-51-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04582P		**AB0536R/158/R027**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8		W6528	0302	24		21-61-13	ALL
	9		W6528	0303	24		21-61-13	ALL
	10		W6528	0304	24		21-61-13	ALL
	11		W6528	0305	24		21-61-14	ALL
	12		W6528	0306	24		21-61-14	ALL
	13		W6528	0307	24		21-61-14	ALL
	14		W6528	6006R	20		26-12-11	ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04603J		**AB0310/ /**		**PANEL JACK THREADED (COAX)**				**ALL**
	=A1		W5363	001CX			34-53-31	ALL
	=C1		W5363	001CO			34-53-31	ALL
D04603P		**AB0310/ /**		**PLUG-COAX**				**ALL**
	=A1		W0121	001CX			34-53-31	ALL
	=C1		W0121	001CO			34-53-31	ALL
D04609J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	001CX			34-45-21	ALL
	=C1		W0111	001CO			34-45-21	ALL
D04609P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W4001	001CX			34-45-21	ALL
	=C1		W4001	001CO			34-45-21	ALL
D04611J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	002CX			34-45-21	ALL
	=C1		W0111	002CO			34-45-21	ALL
D04611P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W4001	002CX			34-45-21	ALL
	=C1		W4001	002CO			34-45-21	ALL
D04613J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	003CX			34-45-21	ALL
	=C1		W0111	003CO			34-45-21	ALL
D04613P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W4001	003CX			34-45-21	ALL
	=C1		W4001	003CO			34-45-21	ALL
D04615J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	004CX			34-45-21	ALL
	=C1		W0111	004CO			34-45-21	ALL
D04615P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W4001	004CX			34-45-21	ALL
	=C1		W4001	004CO			34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04617J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	005CX			34-45-21	ALL
	=C1		W0111	005CO			34-45-21	ALL
D04617P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W5001	001CX			34-45-21	ALL
	=C1		W5001	001CO			34-45-21	ALL
D04619J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	006CX			34-45-21	ALL
	=C1		W0111	006CO			34-45-21	ALL
D04619P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W5001	002CX			34-45-21	ALL
	=C1		W5001	002CO			34-45-21	ALL
D04621J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	007CX			34-45-21	ALL
	=C1		W0111	007CO			34-45-21	ALL
D04621P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W5001	003CX			34-45-21	ALL
	=C1		W5001	003CO			34-45-21	ALL
D04623J		**E001-01/ /**		**RECPT-COAX**				**ALL**
	=A1		W0111	008CX			34-45-21	ALL
	=C1		W0111	008CO			34-45-21	ALL
D04623P		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W5001	004CX			34-45-21	ALL
	=C1		W5001	004CO			34-45-21	ALL
D04625J		**AB0387/ /**		**RCPT**				**ALL**
	=A1		W4009	001CX			34-45-21	ALL
	=C1		W4009	001CO			34-45-21	ALL
D04625P		**AB0387/ /**		**PLUG**				**ALL**
	=A1		W4001	001CX			34-45-21	ALL
	=C1		W4001	001CO			34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04627J		**AB0387/ /**		**RCPT**				**ALL**
	=A1		W4009	002CX			34-45-21	ALL
	=C1		W4009	002CO			34-45-21	ALL
D04627P		**AB0387/ /**		**PLUG**				**ALL**
	=A1		W4001	002CX			34-45-21	ALL
	=C1		W4001	002CO			34-45-21	ALL
D04629J		**AB0387/ /**		**RCPT**				**ALL**
	=A1		W4009	003CX			34-45-21	ALL
	=C1		W4009	003CO			34-45-21	ALL
D04629P		**AB0387/ /**		**PLUG**				**ALL**
	=A1		W4001	003CX			34-45-21	ALL
	=C1		W4001	003CO			34-45-21	ALL
D04633J		**AB0387/ /**		**RCPT**				**ALL**
	=A1		W4009	004CX			34-45-21	ALL
	=C1		W4009	004CO			34-45-21	ALL
D04633P		**AB0387/ /**		**PLUG**				**ALL**
	=A1		W4001	004CX			34-45-21	ALL
	=C1		W4001	004CO			34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04713J		**AB1030A/305/R010**		**JACK-HF-2 COAX**				**ALL**
	=A1		W3559	001CX			23-11-21	ALL
	=C1		W3559	001CO			23-11-21	ALL
D04713P		**AB1030A/305/R010**		**PLUG-HF-2 COAX**				**ALL**
	=A1		W7763	001CX			23-11-21	ALL
	=C1		W7763	001CO			23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D04826J		**AB1030C/296/L012**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6134	5501	20		30-31-11	ALL
	2		W6134	5504	20		30-31-12	ALL
	3		W6134	5505	20		30-31-12	ALL
	4		W6134	5502	20		30-31-11	ALL
	5		W6134	2003R	20		31-31-14	ALL
	6		W6134	2003B	20		31-31-14	ALL
	7		W6134	1001	20		31-31-14	ALL
	S/R		W6134	1001Z			31-31-14	ALL
	S/R		W6134	2003Z			31-31-14	ALL
D04826P		**MULTI/ /**		**PLUG-PITOT HTR LEFT**				**ALL**
	1		W7102	2001R	20		30-31-11	ALL
	2		W7102	2002R	20		30-31-12	ALL
	3		W7102	2002B	20		30-31-12	ALL
	4		W7102	2001B	20		30-31-11	ALL
	5		W7102	2003R	20		31-31-14	ALL
	6		W7102	2003B	20		31-31-14	ALL
	7		W7102	1001	20		31-31-14	ALL
	S/R		W7102	1001Z			31-31-14	ALL
	S/R		W7102	2001Z			30-31-11	ALL
	S/R		W7102	2002Z			30-31-12	ALL
	S/R		W7102	2003Z			31-31-14	ALL
D04850J		**AL0675B/ /**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W5224	0506	20		27-61-43	ALL
	2		W5224	0507	20		27-61-43	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04850J	**AL0675B/ /**		**RCPT-CONDUCTIVE CONNECTOR (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
D04850P	**AL0675B/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W7026	0506	18		27-61-43	ALL
2		W7026	0507	18		27-61-43	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04850P		**AL0675B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
D04889J		**AB0288/ /**		**RECPT-**				**ALL**
	1		W3419	0001	22		23-24-11	ALL
	2		W3419	0002	22		23-24-11	ALL
	3		W3419	0003	22		23-24-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W3419	0006	22		23-24-11	ALL
	7		W3419	0007	22		23-24-11	ALL
	8	UNUSED						ALL
	9		W3419	0010	24		23-24-11	ALL
	10	UNUSED						ALL
	11		W3419	0011	22		23-24-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04889J	**AB0288/ /**		**RECPT- (continued)**				**ALL**
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D04889P	**AB0288/ /**		**PLUG-**				**ALL**
1		W2589	0015	22		23-24-11	ALL
2		W2589	0008	22		23-24-11	ALL
3		W2589	0005	22		23-24-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W2589	0002	22		23-24-11	ALL
7		W2589	0007	22		23-24-11	ALL
8	UNUSED						ALL
9		W2589	0012	24		23-24-11	ALL
10	UNUSED						ALL
11		W2589	0017	22		23-24-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D04889P		**AB0288/ /**		**PLUG- (continued)**				**ALL**
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05148J	**P010-00/ /**		**RCPT-P8 AND P10 CONTROL STAND PNLS**				**ALL**
1		W0008	C-RD			33-18-61	ALL
2		W0008	C-GN			33-18-61	ALL
3		W0008	C-BK			33-18-61	ALL
4		W0008	0053	20		33-11-41	ALL
5		W0008	0004	22		32-64-21	ALL
6		W0008	0005	22		32-64-21	ALL
7		W0008	0052	20		33-11-41	ALL
8		W0008	0041	20		27-62-11	ALL
9		W0008	0042	20		27-62-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D05148P	**AF0213A/209/R002**		**PLUG-P8 AND P9 CONTROL STAND PANEL**				**ALL**
1		W6208	5508	20		33-18-61	ALL
2		W6208	5509	20		33-18-61	ALL
3		W6208	5507	20		33-18-61	ALL
4		W6208	5505	16		33-11-41	ALL
5		W6208	0549	22		32-64-21	ALL
6		W6208	0623	20		32-64-21	ALL
7		W6208	5506	16		33-11-41	ALL
8		W6208	0589	20		27-62-11	ALL
9		W6208	0590	20		27-62-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D05150J	**P008-00/ /**		**RCPT-P8 CONTROL STAND PANEL**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D05150J		**P008-00/ /**		**RCPT-P8 CONTROL STAND PANEL (continued)**				**ALL**
	4	UNUSED						ALL
	5		W0008	B-RD			27-81-51	ALL
	6		W0008	B-BL			27-81-51	ALL
	7		W0008	B-YL			27-81-51	ALL
	8		W0008	A-BL			27-54-11	ALL
	9		W0008	A-RD			27-54-11	ALL
	10	UNUSED						ALL
	11		W0008	A-YL			27-54-11	ALL
	12	UNUSED						ALL
D05150P		**AF0213A/208/R002**		**PLUG-P8 AND P9 CONTROL STAND PANEL**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W6208	0586	20		27-81-51	ALL
	6	UNUSED						ALL
	7		W6208	0587	20		27-81-51	ALL
	8	UNUSED						ALL
	9		W6208	0536	22		27-54-11	ALL
	10	UNUSED						ALL
	11		W6208	0541	22		27-54-11	ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05342J	**AB0500DR/ /**		**RCPT**				**ALL**
1	UNUSED						ALL
2		W6588	3601B	20		28-23-11	ALL
3		W6588	3601Y	20		28-23-11	ALL
4		W6588	3601R	20		28-23-11	ALL
5	UNUSED						ALL
6		W6588	1304	22		28-43-11	ALL
7	UNUSED						ALL
DED		W6588	1304Z			28-43-11	ALL
D05342P	**AB0500DR/ /**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W1136	3601B	16		28-23-11	ALL
3		W1136	3601Y	16		28-23-11	ALL
4		W1136	3601R	16		28-23-11	ALL
5	UNUSED						ALL
6		W1136	1304	20		28-43-11	ALL
7	UNUSED						ALL
D05346J	**AB0500DL/ /**		**RECP-**				**ALL**
1	UNUSED						ALL
2		W5568	3603B	20		28-23-11	ALL
3		W5568	3603Y	20		28-23-11	ALL
4		W5568	3603R	20		28-23-11	ALL
5	UNUSED						ALL
6		W5568	1301	22		28-43-11	ALL
7	UNUSED						ALL
DED		W5568	1301Z			28-43-11	ALL
D05346P	**AB0500DL/ /**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W1134	3601B	16		28-23-11	ALL
3		W1134	3601Y	16		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05346P		**AB0500DL/ /**		**PLUG (continued)**				**ALL**
	4		W1134	3601R	16		28-23-11	ALL
	5	UNUSED						ALL
	6		W1134	1302	20		28-43-11	ALL
	7	UNUSED						ALL
D05348J		**AB0500DL/ /**		**RECP-**				**ALL**
	1	UNUSED						ALL
	2		W5568	3602B	18		28-23-11	ALL
	3		W5568	3602Y	18		28-23-11	ALL
	4		W5568	3602R	18		28-23-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D05348P		**AB0500DL/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1128	3601B	18		28-23-11	ALL
	3		W1128	3601Y	18		28-23-11	ALL
	4		W1128	3601R	18		28-23-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	DED		W1128	3601Z			28-23-11	ALL
D05350J		**AB0500DR/ /**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05350J	**AB0500DR/ /**		**RCPT (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W6588	3602R	18		28-23-11	ALL
12		W6588	3602Y	18		28-23-11	ALL
13		W6588	3602B	18		28-23-11	ALL
14	UNUSED						ALL
D05350P	**AB0500DR/ /**		**PLUG**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W1126	3601R	18		28-23-11	ALL
12		W1126	3601Y	18		28-23-11	ALL
13		W1126	3601B	18		28-23-11	ALL
14	UNUSED						ALL
DED		W1126	3601Z			28-23-11	ALL
D05352J	**AB0500DL/ /**		**RECP-**				**ALL**
1	UNUSED						ALL
2		W5568	3601Y	20		28-23-11	ALL
3		W5568	3601B	20		28-23-11	ALL
4	UNUSED						ALL
5		W5568	6003	22		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D05352J		**AB0500DL/ /**		**RECP- (continued)**				**ALL**
	6	UNUSED						ALL
	7		W5568	3601R	20		28-23-11	ALL
D05352P		**AB0500DL/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W1380	3001Y	18		28-23-11	ALL
	3		W1380	3001B	18		28-23-11	ALL
	4	UNUSED						ALL
	5		W1380	1012	20		28-43-11	ALL
	6	UNUSED						ALL
	7		W1380	3001R	18		28-23-11	ALL
D05354J		**AB0500DR/ /**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2		W6588	3603Y	20		28-23-11	ALL
	3		W6588	3603B	20		28-23-11	ALL
	4	UNUSED						ALL
	5		W6588	6001	22		28-43-11	ALL
	6	UNUSED						ALL
	7		W6588	3603R	20		28-23-11	ALL
D05354P		**AB0500DR/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1382	3001Y	18		28-23-11	ALL
	3		W1382	3001B	18		28-23-11	ALL
	4	UNUSED						ALL
	5		W1382	1032	20		28-43-11	ALL
	6	UNUSED						ALL
	7		W1382	3001R	18		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05925J	**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W2889	0001	20		34-61-11	ALL
A02		W2889	0002	22		34-61-11	ALL
A03		W2889	2501R	24		34-61-22	ALL
A04		W2889	2501B	24		34-61-22	ALL
A05		W2889	0012	24		34-61-26	ALL
A06		W2889	2502R	24		34-61-11	ALL
A07		W2889	2502B	24		34-61-11	ALL
A08		W2889	2508R	24		23-15-15	ALL
A09		W2889	2508B	24		23-15-15	ALL
A10	UNUSED						ALL
A11		W2889	2511R	24		34-61-26	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2889	2503R	24		34-61-23	ALL
B02		W2889	2503B	24		34-61-23	ALL
B03		W2889	2504R	24		23-27-32	ALL
B04		W2889	2504B	24		23-27-32	ALL
B05		W2889	2505R	24		31-35-02	ALL
B06		W2889	2505B	24		31-35-02	ALL
B07		W2889	0013	24		34-61-26	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05925J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11		W2889	2511B	24		34-61-26	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2889	2501Z			34-61-22	ALL
	PERG	1F	W2889	2502Z			34-61-11	ALL
	PERG	1F	W2889	2503Z			34-61-23	ALL
	PERG	1F	W2889	2504Z			23-27-32	ALL
	PERG	1F	W2889	2505Z			31-35-02	ALL
	PERG	1F	W2889	2508Z			23-15-15	ALL
	PERG	1F	W2889	2511Z			34-61-26	ALL
D05925P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	0148	20		34-61-11	ALL
	A02		W0521	0005	22		34-61-11	ALL
	A03		W0521	2643R	24		34-61-22	ALL
	A04		W0521	2643B	24		34-61-22	ALL
	A05		W0521	0277	24		34-61-26	ALL
	A06		W0521	2628R	24		34-61-11	ALL
	A07		W0521	2628B	24		34-61-11	ALL
	A08		W0521	2669R	24		23-15-15	ALL
	A09		W0521	2669B	24		23-15-15	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05925P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A11		W0521	2911R	24		34-61-26	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0521	2811R	24		34-61-23	ALL
	B02		W0521	2811B	24		34-61-23	ALL
	B03		W0521	2651R	24		23-27-32	ALL
	B04		W0521	2651B	24		23-27-32	ALL
	B05		W0521	2645R	24		31-35-02	ALL
	B06		W0521	2645B	24		31-35-02	ALL
	B07		W0521	0278	24		34-61-26	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0521	2911B	24		34-61-26	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D05925P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B20	UNUSED						ALL
	PERG	1F	W0521	2628Z			34-61-11	ALL
	PERG	1F	W0521	2643Z			34-61-22	ALL
	PERG	1F	W0521	2645Z			31-35-02	ALL
	PERG	1F	W0521	2651Z			23-27-32	ALL
	PERG	1F	W0521	2669Z			23-15-15	ALL
	PERG	1F	W0521	2811Z			34-61-23	ALL
	PERG	1F	W0521	2911Z			34-61-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D06001		**243/213/L003**		**JACK-CONT STAND MIC**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D06007		**P019-00/ /**		**JACK-HANDSET-EP SERVICE**				**ALL**
	BLK		W0048	B-BK			23-41-11	ALL
	BLU		W0048	B-BL			23-41-11	ALL
	RED		W0048	B-RD			23-41-11	ALL
D06009		**P019-00/ /**		**JACK-HANDSET-EP FLIGHT**				**ALL**
	BLK		W0048	A-BK			23-41-11	ALL
	BLU		W0048	A-BL			23-41-11	ALL
	RED		W0048	A-RD			23-41-11	ALL
D06011		**664/161/L071**		**INTPH JACK - L WHEEL WELL**				**ALL**
	BLK		W5355	A-C			23-41-11	ALL
	BLU		W5355	A-B			23-41-11	ALL
	RED		W5355	A-A			23-41-11	ALL
D06013		**OFSS 380/ /**		**JACK**				**ALL**
	BLK		W1664	A-W			23-41-11	ALL
	BLU		W1664	A-U			23-41-11	ALL
	RED		W1664	A-V			23-41-11	ALL
D06015		**988/289/L000**		**JACK-AFT CABIN**				**ALL**
	BLK		W0152	A-A			23-41-11	ALL
	BLU		W0152	A-C			23-41-11	ALL
	RED		W0152	A-B			23-41-11	ALL
D06017		**1042/175/L042**		**APU SERVICE JACK**				**ALL**
	BLK		W7359	A-C			23-41-11	ALL
	BLU		W7359	A-B			23-41-11	ALL
	RED		W7359	A-A			23-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D06019		**P008-00/ /**		**SERVICE JACK - CONTROL STAND**				**ALL**
	BLK		W2307	A-C			23-42-12	ALL
	BLU		W2307	A-B			23-42-12	ALL
	RED		W2307	A-A			23-42-12	ALL
D06025		**358/165/R006**		**SERVICE INTPH JACK - E/R**				**ALL**
	BLK		W5337	A-C			23-41-11	ALL
	BLU		W5337	A-B			23-41-11	ALL
	RED		W5337	A-A			23-41-11	ALL
D06027		**256/263/L045**		**JACK-BOOM MIC-CAPT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D06029		**243/263/R045**		**JACK-BOOM MIC-FO**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D06031		**240/263/L028**		**JACK-HEAD PHONE-CAPT**				**ALL**
	BLK		W3323	A-AB			23-51-11	ALL
	BLU		W3323	A-AA			23-51-11	ALL
D06033		**243/263/R045**		**JACK-HEAD PHONE-FO**				**ALL**
	BLK		W3319	A-AB			23-51-21	ALL
	BLU		W3319	A-AA			23-51-21	ALL
D06035		**P061-00/ /**		**JACK**				**ALL**
	BLK		W0041	A-AA			23-51-31	ALL
	BLU		W0041	A-AB			23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D06041		**224/223/L041**		**JACK-HAND MIC-CAPT**				**ALL**
	BLK		W3323	C-CB			23-51-11	ALL
	BLU		W3323	C-CC			23-51-11	ALL
	RED		W3323	C-CA			23-51-11	ALL
D06043		**220/238/R045**		**JACK-HAND MIC-FO**				**ALL**
	BLK		W3319	D-DB			23-51-21	ALL
	BLU		W3319	D-DC			23-51-21	ALL
	RED		W3319	D-DA			23-51-21	ALL
D06045		**P061-00/ /**		**JACK**				**ALL**
	BLK		W0041	B-BB			23-51-31	ALL
	BLU		W0041	B-BC			23-51-31	ALL
	RED		W0041	B-BA			23-51-31	ALL
D06049		**230/215/L040**		**JACK-OXY MASK CAPT**				**ALL**
	A		W3323	2503R	24		23-51-11	ALL
	B		W3323	2503B	24		23-51-11	ALL
	C		W3323	2503Z			23-51-11	ALL
	D	UNUSED						ALL
	E		W3323	0015	22		23-51-11	ALL
	F		W3323	0016	20		23-51-11	ALL
D06051		**215/213/R034**		**JACK-OXY MIC-FO**				**ALL**
	A		W3319	2503R	24		23-51-21	ALL
	B		W3319	2503B	24		23-51-21	ALL
	C		W3319	2503Z			23-51-21	ALL
	D	UNUSED						ALL
	E		W3319	0015	22		23-51-21	ALL
	F		W3319	0016	20		23-51-21	ALL
D06053		**P006-00/ /**		**PLUG**				**ALL**
	A		W0041	2524R	24		23-51-31	ALL
	B		W0041	2524B	24		23-51-31	ALL
	C		W0041	2524Z			23-51-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D06053		**P006-00/ /**		**PLUG (continued)**				**ALL**
	D	UNUSED						ALL
	E		W0041	0056	24		23-51-31	ALL
	F		W0041	0057	20		23-51-31	ALL
D06057		**664/161/R072**		**INTPH JACK - R WHEEL WELL**				**ALL**
	BLK		W5357	A-C			23-41-11	ALL
	BLU		W5357	A-B			23-41-11	ALL
	RED		W5357	A-A			23-41-11	ALL
D06063J		**E005-02/ /**		**RCPT-FMCS BITE ACCESS**				**ALL**
	1		W0521	0238	20		34-61-22	ALL
	2		W0521	0239	20		34-61-22	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0521	2644R	24		34-61-22	ALL
	6		W0521	2644B	24		34-61-22	ALL
	7		W0521	0204	20		34-61-22	ALL
	8		W0521	0242	20		34-61-22	ALL
	9		W0521	0240	20		34-61-22	ALL
	10		W0521	0243	20		34-61-22	ALL
	11		W0521	0241	20		34-61-22	ALL
	12		W0521	2638R	24		34-61-11	ALL
	13		W0521	2638B	24		34-61-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06063J	**E005-02/ /**		**RCPT-FMCS BITE ACCESS (continued)**				**ALL**
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
DED		W0521	2638Z			34-61-11	ALL
DED		W0521	2644Z			34-61-22	ALL
D06067J	**264/255/L042**		**RECP,BITE PRINTER**				**ALL**
1		W2035	2503R	24		34-61-11	ALL
2		W2035	2503B	24		34-61-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2035	0050	22		34-61-22	ALL
8		W2035	0051	22		34-61-22	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2035	2502R	24		34-61-22	ALL
12		W2035	2502B	24		34-61-22	ALL
13	UNUSED						ALL
14		W2035	0052	22		34-61-22	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D06067J		**264/255/L042**		**RECP,BITE PRINTER (continued)**				**ALL**
	24	UNUSED						ALL
	DED		W2035	2502Z			34-61-22	ALL
	DED		W2035	2503Z			34-61-11	ALL
D06069		**P061-00/ /**		**BOOM - MIC HEADSET 1ST OBSV.**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06102J	**E004-02/ /**		**RCPT -**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W0421	4001Z			23-15-15	ALL
1-1		W0421	4001R	24		23-15-15	ALL
1-2		W0421	4001Y	24		23-15-15	ALL
1-3		W0421	4001B	24		23-15-15	ALL
1-4		W0421	4001G	24		23-15-15	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
D06102P	**E004-02/ /**		**PLUG -**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W5602	4001Z			23-15-15	ALL
1-1		W5602	4001R	24		23-15-15	ALL
1-2		W5602	4001Y	24		23-15-15	ALL
1-3		W5602	4001B	24		23-15-15	ALL
1-4		W5602	4001G	24		23-15-15	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06102P		**E004-02/ /**		**PLUG - (continued)**				**ALL**
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D06108J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0421	2501R	24		23-27-37	ALL
	A02		W0421	0004	24		31-31-17	ALL
	A03		W0421	2506R	24		23-15-15	ALL
	A04		W0421	2507R	22		31-32-15	ALL
	A05		W0421	2508R	24		23-15-15	ALL
	A06		W0421	2509R	24		34-53-11	ALL
	A07	UNUSED						ALL
	A08		W0421	2511R	24		34-61-23	ALL
	A09		W0421	0016	24		23-15-15	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0421	2501B	24		23-27-37	ALL
	B02		W0421	0005	24		31-31-17	ALL
	B03		W0421	2506B	24		23-15-15	ALL
	B04		W0421	2507B	22		31-32-15	ALL
	B05		W0421	2508B	24		23-15-15	ALL
	B06		W0421	2509B	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06108J	**E004-02/ /**		**RCPT- (continued)**				**ALL**
B07	UNUSED						ALL
B08		W0421	2511B	24		34-61-23	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0421	2501Z			23-27-37	ALL
PERG	1F	W0421	2506Z			23-15-15	ALL
PERG	1F	W0421	2507Z			31-32-15	ALL
PERG	1F	W0421	2508Z			23-15-15	ALL
PERG	1F	W0421	2509Z			34-53-11	ALL
PERG	1F	W0421	2511Z			34-61-23	ALL
D06108P	**E004-02/ /**		**PLUG-**				**ALL**
A01		W5602	2501R	24		23-27-37	ALL
A02		W5602	0004	24		31-31-17	ALL
A03		W5602	2506R	24		23-15-15	ALL
A04		W5602	2507R	22		31-32-15	ALL
A05		W5602	2508R	24		23-15-15	ALL
A06		W5602	2509R	24		34-53-11	ALL
A07	UNUSED						ALL
A08		W5602	2511R	24		34-61-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06108P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	A09		W5602	0016	24		23-15-15	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5602	2501B	24		23-27-37	ALL
	B02		W5602	0005	24		31-31-17	ALL
	B03		W5602	2506B	24		23-15-15	ALL
	B04		W5602	2507B	22		31-32-15	ALL
	B05		W5602	2508B	24		23-15-15	ALL
	B06		W5602	2509B	24		34-53-11	ALL
	B07	UNUSED						ALL
	B08		W5602	2511B	24		34-61-23	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06108P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5602	2501Z			23-27-37	ALL
PERG	1F	W5602	2506Z			23-15-15	ALL
PERG	1F	W5602	2507Z			31-32-15	ALL
PERG	1F	W5602	2508Z			23-15-15	ALL
PERG	1F	W5602	2509Z			34-53-11	ALL
PERG	1F	W5602	2511Z			34-61-23	ALL
D06110J	**E004-02/ /**		**RCPT-**				**ALL**
A01		W0421	0006	24		23-15-12	ALL
A02		W0421	2502R	24		23-15-12	ALL
A03		W0421	2502Z			23-15-12	ALL
A04		W0421	2503R	24		23-15-12	ALL
A05		W0421	0010	24		23-15-13	ALL
A06		W0421	0012	24		23-15-13	ALL
A07		W0421	2504R	24		23-15-13	ALL
A08		W0421	2504Z			23-15-13	ALL
A09		W0421	2505R	24		23-15-13	ALL
A10	UNUSED						ALL
A11		W0421	2512R	24		23-15-15	ALL
A12		W0421	0017	24		23-15-15	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W0421	0019	24		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06110J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	A20	UNUSED						ALL
	B01		W0421	0007	24		23-15-12	ALL
	B02		W0421	2502B	24		23-15-12	ALL
	B03		W0421	2503Z			23-15-12	ALL
	B04		W0421	2503B	24		23-15-12	ALL
	B05		W0421	0011	24		23-15-13	ALL
	B06		W0421	0013	24		23-15-13	ALL
	B07		W0421	2504B	24		23-15-13	ALL
	B08		W0421	2505Z			23-15-13	ALL
	B09		W0421	2505B	24		23-15-13	ALL
	B10	UNUSED						ALL
	B11		W0421	2512B	24		23-15-15	ALL
	B12		W0421	0018	24		23-15-15	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0421	2512Z			23-15-15	ALL
D06110P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5602	0006	24		23-15-12	ALL
	A02		W5602	2502R	24		23-15-12	ALL
	A03		W5602	2502Z			23-15-12	ALL
	A04		W5602	2503R	24		23-15-12	ALL
	A05		W5602	0010	24		23-15-13	ALL
	A06		W5602	0012	24		23-15-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06110P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
A07		W5602	2504R	24		23-15-13	ALL
A08		W5602	2504Z			23-15-13	ALL
A09		W5602	2505R	24		23-15-13	ALL
A10	UNUSED						ALL
A11		W5602	2512R	24		23-15-15	ALL
A12		W5602	0017	24		23-15-15	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W5602	0019	24		23-15-15	ALL
A20	UNUSED						ALL
B01		W5602	0007	24		23-15-12	ALL
B02		W5602	2502B	24		23-15-12	ALL
B03		W5602	2503Z			23-15-12	ALL
B04		W5602	2503B	24		23-15-12	ALL
B05		W5602	0011	24		23-15-13	ALL
B06		W5602	0013	24		23-15-13	ALL
B07		W5602	2504B	24		23-15-13	ALL
B08		W5602	2505Z			23-15-13	ALL
B09		W5602	2505B	24		23-15-13	ALL
B10	UNUSED						ALL
B11		W5602	2512B	24		23-15-15	ALL
B12		W5602	0018	24		23-15-15	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D06110P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5602	2512Z			23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07001	**256/263/L045**		**PLUG -**				**ALL**
=1	VG	W3323	4251G	24		23-51-11	ALL
DED		W3323	4251Z			23-51-11	ALL
D07003	**256/263/L045**		**PLUG -**				**ALL**
=1	VR	W3323	4251B	24		23-51-11	ALL
D07005	**256/263/L045**		**RECPT -**				**ALL**
=1	VY	W3323	4251R	24		23-51-11	ALL
D07007	**256/263/L045**		**RECPT -**				**ALL**
=1	VS	W3323	4251Y	24		23-51-11	ALL
D07015	**P008-00/ /**		**PLUG - HANDSET JACK(CONTROL STAND)**				**ALL**
=1	VR	W2307	0001	22		23-31-01	ALL
D07017	**P008-00/ /**		**RCPT - HANDSET JACK(CONTROL STAND)**				**ALL**
=1	VS	W2307	2001R	22		23-31-01	ALL
DED		W2307	2001Z			23-31-01	ALL
D07019	**P008-00/ /**		**PLUG - HANDSET JACK(CONTROL STAND)**				**ALL**
=1	VG	W2307	2001B	22		23-31-01	ALL
D07021	**P008-00/ /**		**RCPT - HANDSET JACK(CONTROL STAND)**				**ALL**
=1	VY	W2307	0002	20		23-31-01	ALL
D07023	**239/263/R028**		**PLUG-**				**ALL**
=1	VR	W3319	4251B	24		23-51-21	ALL
D07024J	**409/198/L001**		**RCPT**				**ALL**
=1		W3058	0581	24		23-15-15	ALL
D07024P	**410/198/L001**		**PLUG**				**ALL**
=1	VG	W5602	0017	24		23-15-15	ALL
D07026J	**333/289/L016**		**RCPT-**				**ALL**
=1	VY	W2112	5548	22		30-31-12	ALL
D07026P	**333/290/L016**		**PLUG**				**ALL**
=1		W4142	0003	20		30-31-12	ALL
D07030J	**352/291/L018**		**RCPT-**				**ALL**
=1	VY	W2112	0002	20		33-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07030P		**352/290/L018**		**PLUG-**				**ALL**
	=1	VG	W6134	0006	20		33-49-11	ALL
D07031J		**408/198/L033**		**RCPT-**				**ALL**
	A		W2112	6057	20		30-11-11	ALL
	B		W2112	6057Z			30-11-11	ALL
	C	UNUSED						ALL
D07031P		**410/198/L033**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	A		W6134	1007	20		30-11-11	ALL
	B		W6134	1007Z			30-11-11	ALL
	C	UNUSED						ALL
D07035		**239/263/R028**		**PLUG-**				**ALL**
	=1	VG	W3319	4251G	24		23-51-21	ALL
D07036J		**231/198/L014**		**PLUG-**				**ALL**
	=1	VG	W0443	0011R	20		27-41-11	ALL
D07036P		**229/198/L014**		**RCPT-**				**ALL**
	=1	VY	W5374	0001	20		27-41-11	ALL
D07037		**243/263/R045**		**RCPT-**				**ALL**
	=1	VS	W3319	4251Y	24		23-51-21	ALL
	DED		W3319	4251Z			23-51-21	ALL
D07038J		**229/198/R018**		**PLUG-**				**ALL**
	=1	VG	W0445	0031R	20		27-41-11	ALL
D07038P		**229/198/R019**		**RCPT-**				**ALL**
	=1	VY	W5373	0001	20		27-41-11	ALL
D07039		**239/263/R028**		**RCPT-**				**ALL**
	=1	VY	W3319	4251R	24		23-51-21	ALL
D07040J		**252/198/R028**		**RCPT-**				**ALL**
	=1	VY	W6506	0502	20		49-62-11	ALL
D07040P		**252/197/R029**		**PLUG-**				**ALL**
	=1	VG	W6172	0511	20		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07041	**243/263/L030**		**PLUG -**				**ALL**
=1	VR	W3323	0031	22		23-51-11	ALL
D07046J	**247/194/R001**		**RCPT-**				**ALL**
A		W5369	0007	20		22-13-11	ALL
B		W5369	0008	20		22-13-11	ALL
C		W5369	0009	20		22-13-11	ALL
D	UNUSED						ALL
D07046P	**248/194/R001**		**PLUG**				**ALL**
A		W5457	0007	20		22-13-11	ALL
B		W5457	0008	20		22-13-11	ALL
C		W5457	0009	20		22-13-11	ALL
D	UNUSED						ALL
D07047J	**230/208/L036**		**RCPT-**				**ALL**
1		W5514	1001	22		22-14-11	ALL
2		W5514	1001Z			22-14-11	ALL
3	UNUSED						ALL
D07047P	**230/208/L036**		**PLUG-**				**ALL**
1		W2363	1064	22		22-14-11	ALL
2		W2363	1064Z			22-14-11	ALL
3	UNUSED						ALL
D07048J	**254/195/R009**		**RCPT**				**ALL**
=1	VY	W2651	0037	16		23-12-11	ALL
D07048P	**254/195/R009**		**PLUG**				**ALL**
=1	VG	W2413	0040	18		23-12-11	ALL
D07050J	**371/291/L020**		**RCPT**				**ALL**
1		W3144	2401R	22		23-31-02	ALL
2		W3144	2401B	22		23-31-02	ALL
3	UNUSED						ALL
D07050P	**370/291/L020**		**PLUG**				**ALL**
1		W5189	2013R	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07050P		**370/291/L020**		**PLUG (continued)**				**ALL**
	2		W5189	2013B	22		23-31-02	ALL
	3	UNUSED						ALL
D07051		**243/263/R030**		**PLUG-**				**ALL**
	=1	VR	W3319	0031	22		23-51-21	ALL
D07051J		**371/291/L021**		**RCPT**				**ALL**
	1		W3150	2699B	22		23-31-02	ALL
	2		W3150	2699R	22		23-31-02	ALL
	3	UNUSED						ALL
D07051P		**370/291/L021**		**PLUG**				**ALL**
	1		W5189	2014B	22		23-31-02	ALL
	2		W5189	2014R	22		23-31-02	ALL
	3	UNUSED						ALL
D07052J		**332/288/L016**		**RCPT**				**ALL**
	1		W4250	2699B	22		23-31-03	ALL
	2		W4250	2699R	22		23-31-03	ALL
	3	UNUSED						ALL
D07052P		**333/288/L016**		**PLUG**				**ALL**
	1		W5189	2015B	22		23-31-03	ALL
	2		W5189	2015R	22		23-31-03	ALL
	3	UNUSED						ALL
D07054J		**351/290/L020**		**RCPT**				**ALL**
	1		W5160	0230	22		23-42-14	ALL
	2		W5160	0231	22		23-42-14	ALL
	3		W5160	0232	22		23-42-14	ALL
D07054P		**353/290/L020**		**PLUG-**				**ALL**
	1		W3058	0176	22		23-42-14	ALL
	2		W3058	0191	22		23-42-14	ALL
	3		W3058	0187	22		23-42-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07055J	**340/290/L017**		**RCPT-**				**ALL**
1		W3307	0122	22		23-42-14	ALL
2	UNUSED						ALL
3		W3307	0123	22		23-42-14	ALL
D07055P	**341/290/L017**		**PLUG-**				**ALL**
1		W3058	0098	22		23-42-14	ALL
2	UNUSED						ALL
3		W3058	0166	22		23-42-15	ALL
D07056J	**351/294/R013**		**RCPT**				**ALL**
=1		W3058	0540	22		46-13-52	ALL
D07056P	**352/294/R013**		**PLUG**				**ALL**
=1	VG	W3910	0001	22		46-13-52	ALL
D07058J	**234/208/L035**		**RCPT-**				**ALL**
1		W2221	0031	24		23-51-11	ALL
2		W2221	0032	24		23-51-11	ALL
3	UNUSED						ALL
D07058P	**234/208/L035**		**PLUG**				**ALL**
1		W3323	0061	24		23-51-11	ALL
2		W3323	0060	24		23-51-11	ALL
3	UNUSED						ALL
D07059J	**235/208/R035**		**RCPT-**				**ALL**
1		W2251	0013	24		23-51-21	ALL
2		W2251	0014	24		23-51-21	ALL
3	UNUSED						ALL
D07059P	**235/208/R035**		**PLUG**				**ALL**
1		W3319	0061	24		23-51-21	ALL
2		W3319	0060	24		23-51-21	ALL
3	UNUSED						ALL
D07061J	**412/200/L030**		**RECEPTACLE**				**ALL**
=1	VS	W5110	0510	20		29-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07061P		**412/200/L034**		**PLUG-**				**ALL**
	=1	VR	W5230	0503	18		29-11-12	ALL
D07062J		**351/294/R014**		**RCPT**				**ALL**
	=1	VS	W3910	0005	22		46-13-52	ALL
D07062P		**351/294/R014**		**PLUG**				**ALL**
	=1		W3058	0541	22		46-13-52	ALL
D07063J		**363/285/R039**		**RCPT-**				**ALL**
	=1	VY	W6412	0515	22		29-23-11	ALL
D07063P		**363/284/R039**		**PLUG**				**ALL**
	=1	VG	W6122	0513	20		29-23-11	ALL
D07064J		**727B+13/201/L053**		**RCPT**				**ALL**
	=1	VY	W6124	0528	20		27-31-11	ALL
D07064P		**727B+11/201/L053**		**PLUG**				**ALL**
	=1	VG	W5124	0509	20		27-31-11	ALL
D07065J		**405/198/R030**		**PLUG-**				**ALL**
	A		W5156	0121	20		27-61-43	ALL
	B		W5156	0119	20		27-61-43	ALL
	C	UNUSED						ALL
D07065P		**405/198/R032**		**PLUG-**				**ALL**
	A		W2218	0120	20		27-61-43	ALL
	B		W2218	0118	20		27-61-43	ALL
	C	UNUSED						ALL
D07066J		**300/181/R035**		**RCPT-**				**ALL**
	=1	VS	W2597	0033	24		34-24-15	ALL
D07066P		**300/181/R035**		**PLUG-**				**ALL**
	=1	VR	W2508	0024	24		34-24-15	ALL
D07067J		**432/198/R034**		**RCPT**				**ALL**
	A		W6032	0531	20		27-61-43	ALL
	B		W6032	0532	20		27-61-43	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07067P	**432/198/R034**		**PLUG-**				**ALL**
A		W2218	0117	20		27-61-43	ALL
B		W2218	0119	20		27-61-43	ALL
C	UNUSED						ALL
D07069J	**500I+2/168/L046**		**RCPT-**				**ALL**
=1	VS	W5164	0301	20		28-21-11	ALL
D07069P	**500I+2/169/L046**		**PLUG**				**ALL**
=1	VR	W5230	6011	18		28-21-11	ALL
D07070J	**727+3/196/L042**		**RCPT-**				**ALL**
=1	VY	W5530	6011	20		28-21-11	ALL
D07070P	**727+3/196/L041**		**PLUG-**				**ALL**
=1		W5032	6001	20		28-21-11	ALL
D07072J	**500I+10/156/R009**		**RCPT-**				**ALL**
=1	VS	W6164	1301	20		28-21-11	ALL
DED		W6164	1301Z			28-21-11	ALL
D07072P	**500I+12/155/R009**		**PLUG-**				**ALL**
=1		W6128	6011	18		28-21-11	ALL
D07076J	**992/299/L016**		**RCPT-**				**ALL**
=1	VY	W3142	0002	22		30-31-11	ALL
D07076P	**991/299/L016**		**PLUG-**				**ALL**
=1	VR	W6134	5501	20		30-31-11	ALL
D07077J	**210/206/R020**		**RCPT**				**ALL**
=1	VY	W0147	0001	20		27-32-21	ALL
D07077P	**212/206/R020**		**PLUG**				**ALL**
=1		W2231	0016	20		27-32-21	ALL
D07078J	**256/195/R011**		**RCPT-**				**ALL**
1		W5506	0513	22		32-42-11	ALL
2	UNUSED						ALL
3		W5506	0511	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07078P		**256/195/R011**		**PLUG-**				**ALL**
	1		W5160	0234	22		32-42-11	ALL
	2	UNUSED						ALL
	3		W5160	0233	22		32-42-11	ALL
D07079J		**229/208/R036**		**RCPT-**				**ALL**
	=1	VY	W2383	0033	16		33-11-21	ALL
D07079P		**228/208/R036**		**PLUG-**				**ALL**
	=1	VG	W2204	5512	20		33-11-21	ALL
D07080J		**234/208/L037**		**RCPT**				**ALL**
	A		W2363	1062	20		33-11-31	ALL
	B		W2363	1062Z			33-11-31	ALL
	C	UNUSED						ALL
D07080P		**234/208/L037**		**PLUG - CONDUCTIVE**				**ALL**
	A		W2207	1001	18		33-11-31	ALL
	B		W2207	1001Z			33-11-31	ALL
	C	UNUSED						ALL
D07081		**P061-00/ /**		**RCPT-BOOM MIC JACK**				**ALL**
	=1	VS	W0041	4004Y	24		23-51-31	ALL
D07081J		**205/208/L022**		**RCPT -**				**ALL**
	=1	VY	W2207	0007	16		33-11-32	ALL
D07081P		**205/208/L022**		**PLUG-**				**ALL**
	=1	VG	W2205	0010	20		33-11-32	ALL
D07082J		**946/298/L010**		**RCPT-**				**ALL**
	=1		W3058	0287	22		33-26-11	ALL
D07082P		**945/298/L010**		**PLUG-**				**ALL**
	=1		W4142	0475	22		33-26-11	ALL
D07083		**P061-00/ /**		**PLUG-BOOM MIC JACK**				**ALL**
	=1	VG	W0041	4004G	24		23-51-31	ALL
D07083J		**944/299/L016**		**RCPT-**				**ALL**
	=1		W3058	0288	22		33-26-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07083P	**943/299/L016**		**PLUG-**				**ALL**
=1	VR	W3142	0475	22		33-26-11	ALL
D07084J	**352/290/L020**		**RCPT-**				**ALL**
=1	VS	W3150	0008	22		33-27-11	ALL
D07084P	**354/290/L020**		**PLUG-**				**ALL**
=1		W3058	0371	22		33-27-11	ALL
D07085	**P061-00/ /**		**RCPT-BOOM MIC JACK**				**ALL**
=1	VY	W0041	4004R	24		23-51-31	ALL
D07085J	**856/296/L027**		**RCPT-**				**ALL**
A		W3058	0469	22		33-27-22	ALL
B		W3058	0295	20		38-32-13	ALL
C	UNUSED						ALL
D07085P	**857/296/L027**		**PLUG-**				**ALL**
A		W3144	0460	22		33-27-22	ALL
B		W3144	0020	20		38-32-13	ALL
C	UNUSED						ALL
D07087	**P061-00/ /**		**PLUG-BOOM MIC JACK**				**ALL**
=1	VR	W0041	4004B	24		23-51-31	ALL
D07089	**P061-00/ /**		**PLUG-BOOM MIC JACK**				**ALL**
=1	VR	W0041	0084	22		23-51-31	ALL
D07090J	**727A+13/296/L020**		**RECEPTACLE**				**ALL**
=1	VY	W6134	0517	20		29-23-11	ALL
D07090P	**727A+14/296/L020**		**PLUG-**				**ALL**
=1	VG	W5224	0521	20		29-23-11	ALL
D07091J	**727A+14/201/L054**		**RCPT**				**ALL**
1		W6124	0562	24		27-31-37	ALL
2		W6124	0564	24		27-31-37	ALL
3	UNUSED						ALL
D07091P	**727A+12/201/L054**		**PLUG**				**ALL**
1		W5124	0511	24		27-31-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07091P		**727A+12/201/L054**		**PLUG (continued)**				**ALL**
	2		W5124	0514	24		27-31-37	ALL
	3	UNUSED						ALL
D07094J		**362/285/R040**		**RCPT**				**ALL**
	A		W6412	0510	20		29-31-11	ALL
	B		W6412	0509	20		29-31-11	ALL
	C		W6412	0514	20		29-31-11	ALL
D07094P		**362/285/R040**		**PLUG-**				**ALL**
	A		W6122	0509	20		29-31-11	ALL
	B		W6122	0510	20		29-31-11	ALL
	C		W6122	0508	20		29-31-11	ALL
D07096J		**406/199/R055**		**RECEPTACLE**				**ALL**
	=1	VY	W5158	0513	22		34-51-21	ALL
D07096P		**406/199/R055**		**PLUG**				**ALL**
	=1	VG	W6412	0543	22		34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07100J	**446/295/R022**		**RCPT-**				**ALL**
=1	VY	W6172	0511	20		49-62-11	ALL
D07100P	**446/294/R022**		**PLUG-**				**ALL**
=1		W5726	0584	20		49-62-11	ALL
D07101J	**467/295/R022**		**RCPT-**				**ALL**
=1	VY	W6172	6004	18		49-62-11	ALL
D07101P	**466/295/R022**		**PLUG-**				**ALL**
=1	VG	W5726	0611	18		49-62-11	ALL
D07102J	**351/294/R015**		**RCPT**				**ALL**
=1		W3058	0542	22		46-13-52	ALL
D07102P	**352/294/R013**		**PLUG**				**ALL**
=1	VG	W3910	0006	22		46-13-52	ALL
D07115J	**364/174/L050**		**RCPT-**				**ALL**
=1	VY	W2112	0532	22		27-33-11	ALL
D07115P	**364/175/L050**		**PLUG**				**ALL**
=1		W5506	0077	22		27-33-11	ALL
D07116J	**410/198/L036**		**RCPT**				**ALL**
=1		W5506	6096R	22		26-11-21	ALL
D07116P	**409/197/L36**		**PLUG-**				**ALL**
=1	VR	W2510	0020R	22		26-11-21	ALL
D07117J	**304/171/L024**		**RCPT**				**ALL**
=1	VY	W2103	0010	22		23-31-06	ALL
D07117P	**304/171/L024**		**PLUG**				**ALL**
=1	VG	W3307	0012	22		23-31-06	ALL
D07118J	**403/198/L037**		**PLUG-**				**ALL**
=1		W5121	1751	20		73-22-41	ALL
D07118P	**403/198/L037**		**RCPT-**				**ALL**
=1		W5506	0099	20		73-22-41	ALL
D07120J	**406/198/R031**		**PLUG-**				**ALL**
=1	VR	W2218	6057	20		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07120P		**406/198/R030**		**RCPT-**				**ALL**
	=1	VS	W5160	0188	20		73-22-41	ALL
D07121J		**254/184/R019**		**PLUG-**				**ALL**
	=1		W6201	0013	20		76-21-11	ALL
D07121P		**254/186/R019**		**RCPT-**				**ALL**
	=1		W5510	6011R	20		76-21-11	ALL
D07122J		**409/198/L039**		**RCPT-**				**ALL**
	=1	VS	W2112	0531	22		27-31-37	ALL
D07122P		**409/198/L038**		**PLUG-**				**ALL**
	=1	VR	W6134	0511	20		27-31-37	ALL
D07129J		**727+2/201/R049**		**RCPT-**				**ALL**
	=1		W6122	6011	20		28-21-11	ALL
D07129P		**727+2/201/R050**		**PLUG-**				**ALL**
	=1		W6028	6001	20		28-21-11	ALL
D07145J		**239/208/L003**		**RCPT**				**ALL**
	=1	VY	W3709	0003	24		31-65-42	ALL
D07145P		**239/208/L002**		**PLUG**				**ALL**
	=1	VG	W3319	0054	24		31-65-42	ALL
D07162J		**375/293/L023**		**RCPT-**				**ALL**
	=1		W3058	0511	20		33-26-31	ALL
D07162P		**375/293/L023**		**PLUG-**				**ALL**
	=1	VG	W3144	0104	20		33-26-31	ALL
D07164J		**938/299/L011**		**RCPT-**				**ALL**
	=1	VY	W4168	0009	20		33-26-31	ALL
D07164P		**938/299/L011**		**PLUG-**				**ALL**
	=1	VG	W3144	0354	20		33-26-31	ALL
D07166J		**351/294/R011**		**RCPT-**				**ALL**
	=1		W3168	0004	18		33-24-21	ALL
D07166P		**351/294/R011**		**PLUG-**				**ALL**
	=1		W4258	0409	18		33-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07168J	**937/298/R012**		**RCPT-**				**ALL**
=1	VY	W4168	0004	18		33-24-22	ALL
D07168P	**937/298/R012**		**PLUG-**				**ALL**
=1		W4258	0408	18		33-24-11	ALL
D07170J	**323/291/L019**		**RCPT-**				**ALL**
=1	VY	W3144	0079	18		35-21-21	ALL
D07170P	**323/291/L019**		**PLUG-**				**ALL**
=1		W4142	0065	18		35-21-21	ALL
D07172J	**950/297/L014**		**RCPT-**				**ALL**
=1	VY	W3144	0089	18		35-21-21	ALL
D07172P	**950/297/L014**		**PLUG -**				**ALL**
=1	VG	W7359	0001	18		35-21-21	ALL
D07176J	**316/290/L013**		**RCPT-**				**ALL**
=1	VS	W3150	0001	16		35-21-21	ALL
D07176P	**314/290/L013**		**PLUG-**				**ALL**
=1	VR	W3144	0076	18		35-21-21	ALL
D07177J	**412/295/R019**		**RCPT-**				**ALL**
=1	VY	W4246	0005	18		33-21-12	ALL
D07177P	**412/295/R019**		**PLUG-**				**ALL**
=1		W4258	0268	18		33-21-12	ALL
D07178J	**435/297/R023**		**RCPT-**				**ALL**
=1	VY	W3246	0005	18		33-21-12	ALL
D07178P	**435/297/R023**		**PLUG-**				**ALL**
=1		W4258	0269	18		33-21-12	ALL
D07179J	**250/200/R035**		**RCPT - QUICK DISC**				**ALL**
=1		W5506	6088	22		28-41-11	ALL
D07179P	**250/200/R035**		**PLUG - QUICK DISC**				**ALL**
=1		W3309	0007	22		28-41-11	ALL
D07180J	**352/294/R012**		**RCPT-**				**ALL**
=1	VY	W4250	0001	16		35-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07180P		**352/294/R012**		**PLUG-**				**ALL**
	=1		W4142	0077	18		35-21-31	ALL
D07199J		**241/208/R039**		**RCPT-**				**ALL**
	=1	VY	W6206	5567	16		33-11-41	ALL
D07199P		**242/208/R039**		**PLUG**				**ALL**
	=1	VG	W2873	0022	16		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07223J		**257/196/R038**		**RCPT**				**ALL**
	=1	VY	W2383	0051	16		23-12-21	ALL
D07223P		**258/196/R038**		**PLUG**				**ALL**
	=1	VG	W2415	0040	18		23-12-21	ALL
D07224J		**390/293/R018**		**RCPT**				**ALL**
	=1	VY	W3755	0001	20		44-35-20	ALL
D07224P		**390/293/R018**		**PLUG**				**ALL**
	=1	VG	W3453	0034	20		44-35-20	ALL
D07240J		**353/290/L020**		**RCPT-**				**ALL**
	1		W5142	0094	22		33-22-11	ALL
	2	UNUSED						ALL
	3		W5142	0093	22		33-22-11	ALL
D07240P		**352/290/L020**		**PLUG-**				**ALL**
	1		W2112	0063	22		33-22-11	ALL
	2	UNUSED						ALL
	3		W2112	0062	22		33-22-11	ALL
D07244J		**339/290/L020**		**RCPT-**				**ALL**
	=1	VS	W3144	0117	22		33-27-11	ALL
D07244P		**340/290/L020**		**PLUG-**				**ALL**
	=1		W3058	0372	22		33-27-11	ALL
D07248J		**938/300/L010**		**RCPT-**				**ALL**
	=1	VS	W3144	0083	22		33-27-22	ALL
D07248P		**938/300/L010**		**PLUG-**				**ALL**
	=1		W3058	0470	22		33-27-22	ALL
D07260J		**409/198/R030**		**RCPT-**				**ALL**
	A		W5526	0521	20		33-33-11	ALL
	B		W5526	0520	20		33-33-11	ALL
	C	UNUSED						ALL
D07260P		**411/198/R030**		**PLUG-**				**ALL**
	A		W6230	0521	20		33-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07260P		**411/198/R030**		**PLUG- (continued)**				**ALL**
	B		W6230	0522	20		33-33-11	ALL
	C	UNUSED						ALL
D07272J		**996/300/L005**		**RCPT-**				**ALL**
	=1	VS	W3158	0206	18		33-35-11	ALL
D07272P		**996/300/L005**		**PLUG-**				**ALL**
	=1	VR	W5726	0011	18		33-35-11	ALL
D07278J		**332/290/L020**		**RCPT-**				**ALL**
	=1		W4142	0113	20		33-51-12	ALL
D07278P		**334/290/L020**		**PLUG-**				**ALL**
	=1		W3058	0363	20		33-51-12	ALL
D07282J		**932/300/L009**		**RCPT-**				**ALL**
	=1	VY	W3142	0413	20		33-51-14	ALL
D07282P		**932/300/L009**		**PLUG-**				**ALL**
	=1		W3058	0463	20		33-51-14	ALL
D07284J		**944/299/L011**		**RCPT-**				**ALL**
	=1	VS	W3142	0414	20		33-51-22	ALL
D07284P		**944/299/L011**		**PLUG-**				**ALL**
	=1	VR	W3144	0310	20		33-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07325J	**242/278/R006**		**RCPT-**				**ALL**
=1		W2112	0089	20		78-36-11	ALL
D07325P	**242/278/R006**		**PLUG-**				**ALL**
=1	VG	W2218	0070	20		78-36-11	ALL
D07326J	**242/277/R005**		**RCPT-**				**ALL**
=1	VS	W2218	0093	20		78-36-21	ALL
D07326P	**242/277/R005**		**PLUG-**				**ALL**
=1	VR	W2112	0070	20		78-36-21	ALL
D07327J	**404/198/L001**		**RCPT**				**ALL**
=1	VS	W6208	0014	18		27-61-41	ALL
D07327P	**404/198/L001**		**PLUG**				**ALL**
=1	VR	W2201	0046	18		27-61-41	ALL
D07328J	**368/176/L048**		**RCPT-**				**ALL**
=1	VY	W5142	0100	22		21-27-31	ALL
D07328P	**368/176/L048**		**PLUG-**				**ALL**
=1	VG	W5030	5506	20		21-27-31	ALL
D07329J	**240/208/R037**		**RCPT-**				**ALL**
1		W5514	0014	22		21-33-11	ALL
2		W5514	0015	22		21-33-11	ALL
3	UNUSED						ALL
D07329P	**239/208/R034**		**PLUG -**				**ALL**
1		W6414	0009	22		21-33-11	ALL
2		W6414	0010	22		21-33-11	ALL
3	UNUSED						ALL
D07330J	**371/174/R043**		**RCPT-**				**ALL**
=1		W6242	5509	24		21-27-31	ALL
D07330P	**371/174/R043**		**PLUG-**				**ALL**
=1	VG	W6430	5506	20		21-27-31	ALL
D07331J	**237/208/L036**		**RCPT -**				**ALL**
=1	VY	W2207	0006	16		33-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07331P		**237/208/L036**		**PLUG-**				**ALL**
	=1	VG	W2102	5509	20		33-11-11	ALL
D07332J		**412/198/R030**		**SOCKET**				**ALL**
	=1	VY	W5719	0045	22		27-54-11	ALL
D07332P		**414/198/R030**		**PLUG**				**ALL**
	=1	VG	W6032	0521	22		27-54-11	ALL
D07333J		**412/198/R031**		**SOCKET**				**ALL**
	=1	VY	W6208	0541	22		27-54-11	ALL
D07333P		**414/198/R031**		**PLUG**				**ALL**
	=1	VG	W6032	0511	22		27-54-11	ALL
D07334J		**412/198/R030**		**PLUG-**				**ALL**
	=1	VG	W5111	0050	20		22-13-11	ALL
D07334P		**414/198/R028**		**PLUG-**				**ALL**
	=1	VY	W6222	0012	20		22-13-11	ALL
D07335J		**727A+13/298/L021**		**RCPT-**				**ALL**
	=1		W4142	0001	20		30-31-12	ALL
D07335P		**727A+14/296/L021**		**PLUG**				**ALL**
	=1	VG	W6134	5504	20		30-31-12	ALL
D07336J		**408/198/L34**		**RCPT-**				**ALL**
	=1		W2112	6048	20		28-43-11	ALL
D07336P		**407/198/L34**		**PLUG-**				**ALL**
	=1	VR	W5112	0531	22		28-43-11	ALL
D07337J		**412/198/R031**		**PLUG-**				**ALL**
	=1	VR	W2218	6028	20		28-43-11	ALL
D07337P		**413/198/R031**		**RCPT-**				**ALL**
	=1	VS	W6210	0531	22		28-43-11	ALL
D07340J		**293/287/L004**		**RCPT-**				**ALL**
	=1		W3058	1003	22		30-31-12	ALL
D07340P		**293/287/L002**		**PLUG**				**ALL**
	=1		W4142	0002	20		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07345J		**322/289/L018**		**RECEPTACLE**				**ALL**
	1		W3144	1001	22		30-31-11	ALL
	2		W3144	1001Z			30-31-11	ALL
	3	UNUSED						ALL
D07345P		**324/289/L018**		**PLUG**				**ALL**
	1		W3142	1001	22		30-31-11	ALL
	2		W3142	FRAA			30-31-11	ALL
	3	UNUSED						ALL
			W3142	0004	20		30-31-11	ALL
			W3142	1001Z			30-31-11	ALL
			W3142	FRAA			30-31-11	ALL
D07346J		**406/199/R053**		**RECP-**				**ALL**
	=1	VY	W5119	0005	20		22-13-11	ALL
	CAP	Y	W5111	0005	20		SPARE	ALL
D07346P		**404/199/R053**		**PLUG**				**ALL**
	=1	VG	W6208	0007	20		22-13-11	ALL
D07349J		**227/208/L035**		**RCPT-**				**ALL**
	=1	VY	W2889	0133	24		32-41-11	ALL
D07349P		**226/208/L035**		**PLUG**				**ALL**
	=1	VG	W5156	0633	22		32-41-11	ALL
D07350J		**371/172/R044**		**RECEPTACLE**				**ALL**
	=1	VY	W5158	0720	22		21-27-31	ALL
D07350P		**371/172/R044**		**PLUG-**				**ALL**
	=1	VG	W6242	5507	22		21-27-31	ALL
D07351J		**229/208/L037**		**RCPT-**				**ALL**
	1		W2889	1001	22		32-46-11	ALL
	2		W2889	1001Z			32-46-11	ALL
	3		W2889	1002	22		32-49-11	ALL
	4		W2889	1002Z			32-49-11	ALL
	5		W2889	0134	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07351J		**229/208/L037**		**RCPT- (continued)**				**ALL**
	6	UNUSED						ALL
D07351P		**228/208/L037**		**PLUG**				**ALL**
	1		W2022	1002	22		32-46-11	ALL
	2		W2022	1002Z			32-46-11	ALL
	3		W2022	1003	22		32-49-11	ALL
	4		W2022	1003Z			32-49-11	ALL
	5		W2022	0501	24		32-42-11	ALL
	6	UNUSED						ALL
D07356J		**205/209/R009**		**RCPT-**				**ALL**
	=1	VY	W5514	5554	22		34-16-21	ALL
D07356P		**205/209/R009**		**PLUG-**				**ALL**
	=1	VG	W2873	0019	22		34-16-21	ALL
D07357J		**237/207/R003**		**RCPT-**				**ALL**
	=1		W6208	0733	16		33-11-41	ALL
D07357P		**235/207/R003**		**PLUG**				**ALL**
	=1	VG	W2805	0007	20		33-11-41	ALL
D07359J		**240/208/L002**		**RCPT-**				**ALL**
	A		W6206	0530	16		33-11-41	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
D07359P		**240/208/L004**		**PLUG**				**ALL**
	A		W3709	0001	20		33-11-41	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
D07363J		**397/183/L051**		**RCPT-**				**ALL**
	A		W3154	3001B	16		25-51-21	ALL
	B		W3154	3001R	16		25-51-21	ALL
	C		W3154	3001Y	16		25-51-21	ALL
	D		W3154	0026	22		25-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07363P		**397/181/L051**		**PLUG-**				**ALL**
	A		W5726	3001B	16		25-51-21	ALL
	B		W5726	3001R	16		25-51-21	ALL
	C		W5726	3001Y	16		25-51-21	ALL
	D		W5726	0597	22		25-51-21	ALL
D07364J		**855/299/R020**		**RCPT-**				**ALL**
	=1	VY	W4477	0026	22		44-35-12	ALL
D07364P		**854/299/R020**		**PLUG-**				**ALL**
	=1	VG	W3477	0045	22		44-35-12	ALL
D07391J		**727B+08/201/L053**		**RCPT**				**ALL**
	A		W5124	0508	20		27-31-11	ALL
	B		W5124	0512	20		27-31-37	ALL
	C		W5124	0569	18		27-53-11	ALL
	D	UNUSED						ALL
D07391P		**727B+06/201/L053**		**PLUG**				**ALL**
	A		W6124	0527	20		27-31-11	ALL
	B		W6124	0563	20		27-31-37	ALL
	C		W6124	0599	20		27-53-11	ALL
	D	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D07428J		**391/293/R019**		**RCPT**				**ALL**
	=1	VY	W6222	0016	16		44-35-11	ALL
D07428P		**391/293/R019**		**PLUG - QUICK DISC**				**ALL**
	=1	VG	W3453	0042	16		44-35-11	ALL
D07430J		**860/198/R061**		**RCPT-**				**ALL**
	A		W5726	0538	20		49-62-11	ALL
	B		W5726	0540	20		49-62-11	ALL
	C		W5726	0542	20		49-62-11	ALL
	D		W5726	0544	20		49-62-11	ALL
D07430P		**860/198/R061**		**PLUG-**				**ALL**
	A		W5728	0506	20		49-62-11	ALL
	B		W5728	0507	20		49-62-11	ALL
	C		W5728	0508	20		49-62-11	ALL
	D		W5728	0509	20		49-62-11	ALL
D07431J		**245/196/R000**		**RCPT-**				**ALL**
	=1		W5170	6011	20		28-21-11	ALL
D07431P		**246/196/R000**		**PLUG**				**ALL**
	=1		W5506	6086	20		28-21-11	ALL
D07432J		**265/193/R029**		**RCPT-**				**ALL**
	=1		W6170	6011	20		28-21-11	ALL
D07432P		**263/194/R034**		**RCPT-**				**ALL**
	=1		W6506	6058	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07660J		**405/199/R055**		**PLUG-**				**ALL**
	=1	VR	W6410	0510	20		29-11-12	ALL
D07660P		**405/199/R055**		**RCPT-**				**ALL**
	=1	VS	W6128	0503	18		29-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07793J		**237/209/L001**		**RCPT-**				**ALL**
	=1	VS	W6206	0021	16		33-11-33	ALL
D07793P		**237/210/L002**		**PLUG**				**ALL**
	=1	VR	W2413	0037	16		33-11-33	ALL
D07794J		**239/209/L002**		**RCPT-**				**ALL**
	=1	VS	W6206	0019	20		33-11-33	ALL
D07794P		**238/210/L003**		**PLUG**				**ALL**
	=1	VR	W2265	0005	20		33-11-33	ALL
D07795J		**239/209/L001**		**RCPT-**				**ALL**
	=1	VY	W6206	0018	18		33-11-41	ALL
D07795P		**239/210/L002**		**PLUG**				**ALL**
	=1	VG	W2417	0037	20		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D07996J		**239/209/L002**		**RCPT-**				**ALL**
	=1	VY	W6206	0020	20		33-11-33	ALL
D07996P		**238/210/L003**		**PLUG**				**ALL**
	=1	VG	W3323	0007	20		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08094J		**IFSS 215/ /**		**RECP**				**ALL**
	S/R	GW	W1186	YAAA			24-21-11	ALL
	S/R	GW	W1186	YAAB			24-21-11	ALL
	S/R	GW	W1186	YAAC			24-21-11	ALL
	S/R	GW	W1186	YAAD			24-21-11	ALL
	A		W1186	0001	02		24-21-11	ALL
	B		W1186	0002	02		24-21-11	ALL
	C		W1186	0003	02		24-21-11	ALL
	D		W1186	0004	04		24-21-11	ALL
D08094P		**NSTA 245/145/L014**		**PLUG-**				**ALL**
	S/R	GW	W1162	1001Z			24-21-11	ALL
	S/R	GW	W1162	1002Z			24-21-11	ALL
	S/R	GW	W1162	1003Z			24-21-11	ALL
	S/R	GW	W1162	1004Z			24-21-11	ALL
	A		W1162	1001	*1		24-21-11	ALL
	B		W1162	1002	*1		24-21-11	ALL
	C		W1162	1003	*1		24-21-11	ALL
	D	HL	W1162	1004	04		24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08105J	**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W2873	0001	20		34-61-11	ALL
A02		W2873	0002	22		34-61-11	ALL
A03		W2873	2501R	24		34-61-11	ALL
A04		W2873	2501B	24		34-61-11	ALL
A05		W2873	0012	24		34-61-26	ALL
A06		W2873	2502R	24		34-61-11	ALL
A07		W2873	2502B	24		34-61-11	ALL
A08		W2873	2508R	24		23-15-15	ALL
A09		W2873	2508B	24		23-15-15	ALL
A10	UNUSED						ALL
A11		W2873	2511R	24		34-61-26	ALL
A12	UNUSED						ALL
A13		W2873	0019	22		34-16-21	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2873	2503R	24		34-61-23	ALL
B02		W2873	2503B	24		34-61-23	ALL
B03		W2873	2504R	24		23-27-33	ALL
B04		W2873	2504B	24		23-27-33	ALL
B05		W2873	2505R	24		31-35-02	ALL
B06		W2873	2505B	24		31-35-02	ALL
B07		W2873	0013	24		34-61-26	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08105J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11		W2873	2511B	24		34-61-26	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2873	2501Z			34-61-11	ALL
	PERG	1F	W2873	2502Z			34-61-11	ALL
	PERG	1F	W2873	2503Z			34-61-23	ALL
	PERG	1F	W2873	2504Z			23-27-33	ALL
	PERG	1F	W2873	2505Z			31-35-02	ALL
	PERG	1F	W2873	2508Z			23-15-15	ALL
	PERG	1F	W2873	2511Z			34-61-26	ALL
D08105P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0523	0301	20		34-61-11	ALL
	A02		W0523	0302	22		34-61-11	ALL
	A03		W0523	2701R	24		34-61-11	ALL
	A04		W0523	2701B	24		34-61-11	ALL
	A05		W0523	0374	24		34-61-26	ALL
	A06		W0523	2704R	24		34-61-11	ALL
	A07		W0523	2704B	24		34-61-11	ALL
	A08		W0521	2752R	24		23-15-15	ALL
	A09		W0521	2752B	24		23-15-15	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08105P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A11		W0523	2833R	24		34-61-26	ALL
	A12	UNUSED						ALL
	A13		W0523	0386	22		34-16-21	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0523	2819R	24		34-61-23	ALL
	B02		W0523	2819B	24		34-61-23	ALL
	B03		W0523	2738R	24		23-27-33	ALL
	B04		W0523	2738B	24		23-27-33	ALL
	B05		W0523	2750R	24		31-35-02	ALL
	B06		W0523	2750B	24		31-35-02	ALL
	B07		W0523	0375	24		34-61-26	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0523	2833B	24		34-61-26	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08105P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
B20	UNUSED						ALL
PERG	1F	W0521	2752Z			23-15-15	ALL
PERG	1F	W0523	2701Z			34-61-11	ALL
PERG	1F	W0523	2704Z			34-61-11	ALL
PERG	1F	W0523	2738Z			23-27-33	ALL
PERG	1F	W0523	2750Z			31-35-02	ALL
PERG	1F	W0523	2819Z			34-61-23	ALL
PERG	1F	W0523	2833Z			34-61-26	ALL
D08123J	**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0411	0037	22		23-31-02	ALL
A02		W0411	0047	24		23-31-04	ALL
A03		W0411	0042	24		23-31-04	ALL
A04		W0411	2015R	24		23-31-02	ALL
A05		W0411	2016R	24		23-31-02	ALL
A06		W0411	2017R	24		23-31-02	ALL
A07		W0411	2018R	24		23-31-02	ALL
A08		W0411	2019R	22		23-31-02	ALL
A09		W0411	2022R	22		23-31-04	ALL
A10		W0411	2019R	22		23-31-02	ALL
A11		W0411	2544R	24		23-11-11	ALL
A12		W0411	2544ZI			23-11-11	ALL
A13		W0411	2545R	24		23-11-11	ALL
A14		W0411	2522R	24		23-22-11	ALL
A15		W0411	2522ZI			23-22-11	ALL
A16		W0411	0119	24		31-31-17	ALL
A17		W0411	2010R	24		34-51-11	ALL
A18		W0411	2010B	24		34-51-11	ALL
A19		W0411	2010ZI			34-51-11	ALL
A20		W0411	2009R	24		34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08123J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B01		W0411	0038	24		23-31-02	ALL
B02		W0411	0044	24		23-31-04	ALL
B03		W0411	0045	24		23-31-04	ALL
B04		W0411	2015B	24		23-31-02	ALL
B05		W0411	2016B	24		23-31-02	ALL
B06		W0411	2017B	24		23-31-02	ALL
B07		W0411	2018B	24		23-31-02	ALL
B08		W0411	2019B	22		23-31-02	ALL
B09		W0411	2022B	22		23-31-04	ALL
B10		W0411	2019B	22		23-31-02	ALL
B11		W0411	2544B	24		23-11-11	ALL
B12		W0411	2545ZI			23-11-11	ALL
B13		W0411	2545B	24		23-11-11	ALL
B14		W0411	2522B	24		23-22-11	ALL
B15		W0411	0307	22		23-11-11	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W0411	2009ZI			34-32-11	ALL
B20		W0411	2009B	24		34-32-11	ALL
PERG	1F	W0411	2009ZO			34-32-11	ALL
PERG	1F	W0411	2010ZO			34-51-11	ALL
PERG	1F	W0411	2522ZO			23-22-11	ALL
PERG	1F	W0411	2544ZO			23-11-11	ALL
PERG	1F	W0411	2545ZO			23-11-11	ALL
D08123P	**E004-01/ /**		**PLUG-E4-1 SHELF**				**ALL**
A01		W5189	0003	22		23-31-02	ALL
A02		W5189	0005	24		23-31-04	ALL
A03		W5189	0007	24		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08123P		**E004-01/ /**		**PLUG-E4-1 SHELF (continued)**				**ALL**
	A04		W5189	2002R	24		23-31-02	ALL
	A05		W5189	2003R	24		23-31-02	ALL
	A06		W5189	2004R	24		23-31-02	ALL
	A07		W5189	2005R	24		23-31-02	ALL
	A08		W5189	2006R	22		23-31-02	ALL
	A09		W5189	2007R	22		23-31-04	ALL
	A10		W5189	2011R	22		23-31-02	ALL
	A11		W5189	2513R	24		23-11-11	ALL
	A12		W5189	2513ZI			23-11-11	ALL
	A13		W5189	2512R	24		23-11-11	ALL
	A14		W5189	2535R	24		23-22-11	ALL
	A15		W5189	2535ZI			23-22-11	ALL
	A16		W5189	0021	24		31-31-17	ALL
	A17		W5189	2010R	24		34-51-11	ALL
	A18		W5189	2010B	24		34-51-11	ALL
	A19		W5189	2010ZI			34-51-11	ALL
	A20		W5189	2009R	24		34-32-11	ALL
	B01		W5189	0004	24		23-31-02	ALL
	B02		W5189	0006	24		23-31-04	ALL
	B03		W5189	0008	24		23-31-04	ALL
	B04		W5189	2002B	24		23-31-02	ALL
	B05		W5189	2003B	24		23-31-02	ALL
	B06		W5189	2004B	24		23-31-02	ALL
	B07		W5189	2005B	24		23-31-02	ALL
	B08		W5189	2006B	22		23-31-02	ALL
	B09		W5189	2007B	22		23-31-04	ALL
	B10		W5189	2011B	22		23-31-02	ALL
	B11		W5189	2513B	24		23-11-11	ALL
	B12		W5189	2512ZI			23-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08123P	**E004-01/ /**		**PLUG-E4-1 SHELF (continued)**				**ALL**
B13		W5189	2512B	24		23-11-11	ALL
B14		W5189	2535B	24		23-22-11	ALL
B15		W5189	0022	22		23-11-11	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W5189	2009ZI			34-32-11	ALL
B20		W5189	2009B	24		34-32-11	ALL
PERG	1F	W5189	2009ZO			34-32-11	ALL
PERG	1F	W5189	2010ZO			34-51-11	ALL
PERG	1F	W5189	2512ZO			23-11-11	ALL
PERG	1F	W5189	2513ZO			23-11-11	ALL
PERG	1F	W5189	2535ZO			23-22-11	ALL
D08194J	**IFSS 215/ /**		**RECP**				**ALL**
S/R	GW	W1286	YAAA			24-21-21	ALL
S/R	GW	W1286	YAAB			24-21-21	ALL
S/R	GW	W1286	YAAC			24-21-21	ALL
S/R	GW	W1286	YAAD			24-21-21	ALL
A		W1286	0001	02		24-21-21	ALL
B		W1286	0002	02		24-21-21	ALL
C		W1286	0003	02		24-21-21	ALL
D		W1286	0004	04		24-21-21	ALL
D08194P	**NSTA 245/145/L014**		**PLUG-**				**ALL**
S/R	GW	W1262	1001Z			24-21-21	ALL
S/R	GW	W1262	1002Z			24-21-21	ALL
S/R	GW	W1262	1003Z			24-21-21	ALL
S/R	GW	W1262	1004Z			24-21-21	ALL
A		W1262	1001	*1		24-21-21	ALL
B		W1262	1002	*1		24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D08194P		**NSTA 245/145/L014**		**PLUG- (continued)**				**ALL**
	C		W1262	1003	*1		24-21-21	ALL
	D		W1262	1004	04		24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D08313J	**214/209/R1**		**RCPT - THRUST LEVER-1**				**ALL**
1		W0049	0001	22		22-11-14	ALL
2		W0049	0002	22		22-11-14	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0049	0005	22		22-31-51	ALL
6		W0049	0006	22		22-31-51	ALL
7		W0049	0007	22		22-31-51	ALL
8		W0049	0008	22		22-31-51	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0049	0003	22		22-11-14	ALL
12		W0049	0004	22		22-11-14	ALL
D08313P	**AF0213A/209/R001**		**PLUG**				**ALL**
1		W5369	0101	22		22-11-14	ALL
2		W5369	0102	22		22-11-14	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5369	0105	22		22-31-51	ALL
6		W5369	0106	22		22-31-51	ALL
7		W5369	0107	22		22-31-51	ALL
8		W5369	0108	22		22-31-51	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5369	0111	22		22-11-14	ALL
12		W5369	0112	22		22-11-14	ALL
D08315J	**ENG 2/ /**		**RCPT - THRUST LEVER-2**				**ALL**
1		W0051	0001	22		22-11-14	ALL
2		W0051	0002	22		22-11-14	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D08315J		**ENG 2/ /**		**RCPT - THRUST LEVER-2 (continued)**				**ALL**
	4	UNUSED						ALL
	5		W0051	0005	22		22-31-51	ALL
	6		W0051	0006	22		22-31-51	ALL
	7		W0051	0007	22		22-31-51	ALL
	8		W0051	0008	22		22-31-51	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0051	0003	22		22-11-14	ALL
	12		W0051	0004	22		22-11-14	ALL
D08315P		**AF0222A/ /**		**PLUG**				**ALL**
	1		W5457	0101	22		22-11-14	ALL
	2		W5457	0102	22		22-11-14	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5457	0105	22		22-31-51	ALL
	6		W5457	0106	22		22-31-51	ALL
	7		W5457	0107	22		22-31-51	ALL
	8		W5457	0108	22		22-31-51	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5457	0111	22		22-11-14	ALL
	12		W5457	0112	22		22-11-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10002A	*/*/*		**PLUG-AIR COND RELAY NO 2**				**ALL**
1		W0410	0489	24		34-61-17	ALL
2		W0410	0490	20		34-61-17	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0410	0398	24		21-61-11	ALL
8		W0410	0470	24		21-25-11	ALL
9		W0410	0472	24		21-25-11	ALL
10		W0410	0469	24		21-25-11	ALL
11		W0410	0417	24		21-61-13	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0410	0345	24		21-51-21	ALL
19		W0410	0353	24		21-51-21	ALL
20		W0410	0412	24		21-61-12	ALL
21		W0410	0468	24		21-25-11	ALL
22		W0410	0401	24		21-51-22	ALL
23		W0410	0349	24		21-51-21	ALL
24	UNUSED						ALL
25		W0410	0410	24		21-61-12	ALL
26		W0410	0397	24		21-61-11	ALL
27		W0410	0396	24		21-61-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10002A		***/*/***		**PLUG-AIR COND RELAY NO 2 (continued)**				**ALL**
	30		W0410	0350	24		21-51-21	ALL
	31		W0410	0471	24		21-25-11	ALL
	32		W0410	0347	24		21-51-21	ALL
	33		W0410	0352	24		21-51-21	ALL
	34		W0410	0467	24		21-25-11	ALL
	35		W0410	0555	24		21-51-24	ALL
	36	UNUSED						ALL
	37		W0410	0411	24		21-61-12	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43		W0410	0348	24		21-51-21	ALL
	44		W0410	0346	24		21-51-21	ALL
	45		W0410	0354	20		21-51-21	ALL
	46		W0410	0357	24		21-51-22	ALL
	47		W0410	0558	24		21-51-24	ALL
	48		W0410	0619	24		21-51-11	ALL
	49	UNUSED						ALL
	50		W0410	0362	24		21-51-22	ALL
	51		W0410	0427	24		21-61-13	ALL
	52		W0410	0426	24		21-61-13	ALL
	53		W0410	0419	24		21-61-13	ALL
	54		W0410	0418	24		21-61-13	ALL
	55		W0410	0344	24		21-51-21	ALL
	56		W0410	0359	24		21-51-22	ALL
	57	UNUSED						ALL
	58		W0410	0358	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10002A	*/*/*		**PLUG-AIR COND RELAY NO 2 (continued)**				**ALL**
59		W0410	0365	24		21-51-24	ALL
60	UNUSED						ALL
61		W0410	0547	24		21-51-24	ALL
62	UNUSED						ALL
63		W0410	0364	24		21-51-22	ALL
64		W0410	0363	24		21-51-22	ALL
65		W0410	0360	24		21-51-22	ALL
66		W0410	0361	24		21-51-22	ALL
67		W0410	0428	24		21-61-13	ALL
D10002B	*/*/*		**PLUG-AIR COND RELAY NO 2**				**ALL**
1		W0410	0374	20		21-51-24	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0410	0351	20		21-51-21	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0410	0579	20		36-11-22	ALL
8		W0410	0518	24		36-11-13	ALL
9		W0410	1571	20		36-11-22	ALL
10		W0410	0523	24		36-11-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0410	0479	24		21-25-11	ALL
15		W0410	0477	24		21-25-11	ALL
16		W0410	0476	24		21-25-11	ALL
17	UNUSED						ALL
18		W0410	0585	24		36-11-23	ALL
19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10002B		***/*/***		**PLUG-AIR COND RELAY NO 2 (continued)**				**ALL**
	20		W0410	0473	24		21-61-13	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W0410	0380	24		21-51-25	ALL
	24		W0410	0568	24		36-11-22	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W0410	0478	24		21-25-11	ALL
	29		W0410	0480	24		21-25-11	ALL
	30		W0410	0379	24		21-51-25	ALL
	31	UNUSED						ALL
	32		W0410	0314	24		21-51-11	ALL
	33		W0410	0553	24		21-51-24	ALL
	34		W0410	0420	24		21-61-13	ALL
	35		W0410	0383	24		21-51-25	ALL
	36		W0410	0382	24		21-51-25	ALL
	37		W0410	0456	24		36-11-22	ALL
	38		W0410	0521	24		36-11-22	ALL
	39		W0410	0591	24		36-11-31	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46		W0410	1573	20		36-11-22	ALL
	47		W0410	1572	20		36-11-22	ALL
	48		W0410	0424	24		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10002B	***/*/***		**PLUG-AIR COND RELAY NO 2 (continued)**				**ALL**
49		W0410	0422	24		21-61-13	ALL
50		W0410	1570	20		36-11-22	ALL
51		W0410	0592	24		36-11-31	ALL
52		W0410	0590	24		36-11-31	ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W0410	0615	24		21-25-11	ALL
56		W0410	0614	24		21-25-11	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60		W0410	0381	20		21-51-25	ALL
61	UNUSED						ALL
62	UNUSED						ALL
63		W0410	0571	24		36-11-22	ALL
64		W0410	0522	24		36-11-22	ALL
65		W0410	0565	24		36-11-22	ALL
66		W0410	0575	24		36-11-22	ALL
67		W0410	0587	24		36-11-31	ALL
D10013	**RUD76.4/ /**		**PLUG- STANDBY RUDDER PCU**				**ALL**
1		W3389	1001	20		27-24-11	ALL
2		W3389	1002	20		27-24-11	ALL
3	UNUSED						ALL
4		W3389	3001Y	20		27-24-11	ALL
5		W3389	4521R	20		27-24-11	ALL
6		W3389	4521Y	20		27-24-11	ALL
7		W3389	4521G	20		27-24-11	ALL
8		W3389	4521B	20		27-24-11	ALL
9		W3389	2002B	20		27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10013		**RUD76.4/ /**		**PLUG- STANDBY RUDDER PCU (continued)**				**ALL**
	10		W3389	2002R	20		27-24-11	ALL
	11		W3389	3001B	20		27-24-11	ALL
	12		W3389	3001R	20		27-24-11	ALL
	S/R		W3389	1001Z			27-24-11	ALL
	S/R		W3389	1002Z			27-24-11	ALL
	S/R		W3389	2002Z			27-24-11	ALL
	S/R		W3389	3001Z			27-24-11	ALL
	S/R		W3389	4521Z			27-24-11	ALL
D10015		**193/203/L029**		**PLUG-AOA SENSOR-L**				**ALL**
	1		W5501	0005	22		34-21-12	ALL
	2		W5501	0006	20		34-21-12	ALL
	3		W5501	3001R	24		34-21-12	ALL
	4		W5501	3001B	24		34-21-12	ALL
	5		W5501	3001Y	24		34-21-12	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5501	0007	20		34-21-12	ALL
D10017		**193/204/R029**		**PLUG-AOA SENSOR-R**				**ALL**
	1		W5503	0005	22		34-21-22	ALL
	2		W5503	0006	20		34-21-22	ALL
	3		W5503	3001B	24		34-21-22	ALL
	4		W5503	3001R	24		34-21-22	ALL
	5		W5503	3001Y	24		34-21-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10017		**193/204/R029**		**PLUG-AOA SENSOR-R (continued)**				**ALL**
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5503	0007	20		34-21-22	ALL
D10025		**233/198/L007**		**PLUG-SERVO MOTOR**				**ALL**
	1		W5353	0003	22		22-31-31	ALL
	2	UNUSED						ALL
	3		W5353	2001B	22		22-31-31	ALL
	4	UNUSED						ALL
	5		W5353	0003	22		22-31-31	ALL
	6		W5353	2002B	24		22-31-31	ALL
	7		W5353	2501R	24		22-31-31	ALL
	8		W5353	2501B	24		22-31-31	ALL
	9		W5353	2001R	22		22-31-31	ALL
	10		W5353	0002	22		22-31-31	ALL
	11	UNUSED						ALL
	12		W5353	2504R	24		22-31-31	ALL
	13		W5353	2504B	24		22-31-31	ALL
	14		W5353	2002R	24		22-31-31	ALL
	15	UNUSED						ALL
			W5353	0001	22		22-31-31	ALL
			W5353	0004	22		22-31-31	ALL
			W5353	2501Z			22-31-31	ALL
			W5353	2504Z			22-31-31	ALL
D10027		**233/200/R008**		**PLUG-SERVO MOTOR**				**ALL**
	1		W5397	0003	22		22-31-41	ALL
	2	UNUSED						ALL
	3		W5397	2001B	22		22-31-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10027		**233/200/R008**		**PLUG-SERVO MOTOR (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5397	2002B	24		22-31-41	ALL
	7		W5397	2501R	24		22-31-41	ALL
	8		W5397	2501B	24		22-31-41	ALL
	9		W5397	2001R	22		22-31-41	ALL
	10		W5397	0002	22		22-31-41	ALL
	11		W5397	0003	22		22-31-41	ALL
	12		W5397	2504R	24		22-31-41	ALL
	13		W5397	2504B	24		22-31-41	ALL
	14		W5397	2002R	24		22-31-41	ALL
	15	UNUSED						ALL
			W5397	0001	22		22-31-41	ALL
			W5397	0004	22		22-31-41	ALL
			W5397	2501Z			22-31-41	ALL
			W5397	2504Z			22-31-41	ALL
D10046		**P006-03/ /**		**PLUG-AUX DIM/TEST MODULE**				**ALL**
	1		W0044	0196	20		33-18-62	ALL
	2		W0044	0197	20		33-18-62	ALL
	3		W0044	0198	20		33-18-62	ALL
	4		W0044	0162	20		33-18-62	ALL
	5		W0044	0201	20		33-18-62	ALL
	6		W0044	0203	20		33-18-62	ALL
	7		W0044	0195	20		33-18-62	ALL
	8		W0044	0199	20		33-18-62	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0044	0200	20		33-18-62	ALL
	12		W0044	0539	20		33-18-62	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10046	**P006-03/ /**		**PLUG-AUX DIM/TEST MODULE (continued)**				**ALL**
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D10056	**576/157/L036**		**PLUG-**				**ALL**
1		W5102	1034	20		21-51-15	ALL
2		W5102	1033	20		21-51-15	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D10058	**576/160/R032**		**PLUG**				**ALL**
1		W6202	0015	20		21-51-25	ALL
2		W6202	1034	20		21-51-25	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D10064	**E001-01/ /**		**RCPT- - TEST CONNECTOR 1**				**ALL**
1		W0111	0606	24		27-28-11	ALL
2		W0111	2142R	24		27-28-11	ALL
3		W0111	2142B	24		27-28-11	ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10064		**E001-01/ /**		**RCPT- - TEST CONNECTOR 1 (continued)**				**ALL**
	5	UNUSED						ALL
	6		W0111	2404R	24		32-64-31	ALL
	7		W0111	2404B	24		32-64-31	ALL
	8	UNUSED						ALL
	9		W0111	2165R	24		27-81-41	ALL
	10		W0111	2165B	24		27-81-41	ALL
	11	UNUSED						ALL
	12		W0111	2335R	24		22-23-12	ALL
	13		W0111	2335B	24		22-23-12	ALL
	14		W0111	2405R	24		32-64-31	ALL
	15		W0111	2405B	24		32-64-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0111	2139B	20		27-25-11	ALL
	19	UNUSED						ALL
	20		W0111	2139R	20		27-25-11	ALL
	21	UNUSED						ALL
	22		W0111	2334R	24		22-23-12	ALL
	23		W0111	2334B	24		22-23-12	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0111	0501	22		22-23-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10064	**E001-01/ /**		**RCPT- - TEST CONNECTOR 1 (continued)**				**ALL**
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W0111	0610	24		27-28-11	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
DED		W0111	2139Z			27-25-11	ALL
DED		W0111	2165Z			27-81-41	ALL
DED		W0111	2334Z			22-23-12	ALL
DED		W0111	2335Z			22-23-12	ALL
DED		W0111	2404Z			32-64-31	ALL
DED		W0111	2405Z			32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10076		**1000/295/R024**		**RCPT-**				**ALL**
	A		W3154	0017	10		25-31-11	ALL
	B		W3154	0018	10		25-31-11	ALL
	C		W3154	0019	10		25-31-11	ALL
	D		W3154	0020	10		25-31-11	ALL
D10082		**995/247/L051**		**RCPT-**				**ALL**
	=1	VY	W3142	0412	20		33-51-22	ALL
D10084		**995/247/L051**		**PLUG-**				**ALL**
	=1	VG	W3142	0452	20		33-51-22	ALL
D10085		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0148	22		23-15-15	ALL
	A2		W0076	0145	22		23-15-15	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0076	0146	22		23-15-15	ALL
	X2		W0076	0147	22		23-15-15	ALL
D10086		**995/237/R052**		**RCPT-**				**ALL**
	=1		W4142	0412	20		33-51-22	ALL
D10088		**995/236/R052**		**PLUG-**				**ALL**
	=1		W4142	0452	20		33-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10101	**955/301/L008**		**RCPT**				**ALL**
1		W5433	0033	24		23-71-01	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5433	0031	24		23-71-01	ALL
7	UNUSED						ALL
8		W5433	0047	22		23-71-01	ALL
9	UNUSED						ALL
10		W5433	0032	24		23-71-01	ALL
11	UNUSED						ALL
12		W5433	0034	24		23-71-01	ALL
D10135A	***/*/***		**PLUG**				**ALL**
A01	UNUSED						ALL
A02		W0111	2130B	24		31-65-25	ALL
A03	UNUSED						ALL
A04		W0111	2090B	24		22-31-52	ALL
A05	UNUSED						ALL
A06		W0111	2016B	24		22-11-51	ALL
A07		W0111	0444	24		22-11-75	ALL
A08		W0111	0101	24		22-11-75	ALL
A09		W0111	2083R	22		22-31-31	ALL
A10		W0111	2031B	24		22-11-51	ALL
A11		W0111	0559	24		22-11-53	ALL
A12		W0111	2039B	22		22-12-31	ALL
A13		W0111	2039R	22		22-12-31	ALL
A14		W0111	2082R	24		22-31-31	ALL
A15		W0111	2038B	22		22-12-31	ALL
B01		W0111	0019	22		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135A		***/*/***		**PLUG (continued)**				**ALL**
	B02		W0111	2130R	24		31-65-25	ALL
	B03		W0111	0045	22		22-11-12	ALL
	B04		W0111	2090R	24		22-31-52	ALL
	B05		W0111	2133R	24		73-24-11	ALL
	B06		W0111	2016R	24		22-11-51	ALL
	B07		W0111	0116	22		22-11-75	ALL
	B08		W0111	0102	24		22-11-75	ALL
	B09		W0111	2083B	22		22-31-31	ALL
	B10		W0111	2031R	24		22-11-51	ALL
	B11		W0111	0558	24		22-11-53	ALL
	B12	UNUSED						ALL
	B13		W0111	0051	22		22-11-12	ALL
	B14		W0111	2082B	24		22-31-31	ALL
	B15		W0111	2038R	22		22-12-31	ALL
	C01		W0111	0746	22		32-64-21	ALL
	C02		W0111	0817	22		34-51-41	ALL
	C03	UNUSED						ALL
	C04		W0111	2133B	24		73-24-11	ALL
	C05	UNUSED						ALL
	C06		W0111	2084R	24		22-31-31	ALL
	C07	UNUSED						ALL
	C08		W0111	0108	24		22-11-75	ALL
	C09		W0111	0341	22		22-31-51	ALL
	C10		W0111	0554	24		22-11-53	ALL
	C11		W0111	0557	24		22-11-53	ALL
	C12		W0111	2037B	22		22-12-31	ALL
	C13		W0111	0766	24		22-11-75	ALL
	C14		W0111	0948	22		22-11-75	ALL
	C15		W0111	0949	22		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135A		*/*/*		**PLUG (continued)**				**ALL**
	D01		W0111	0566	22		34-51-41	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0111	2118B	24		34-61-14	ALL
	D05		W0111	2084B	24		22-31-31	ALL
	D06		W0111	2219B	24		22-11-53	ALL
	D07	UNUSED						ALL
	D08		W0111	0109	24		22-11-75	ALL
	D09	UNUSED						ALL
	D10		W0111	2030B	24		22-11-51	ALL
	D11		W0111	0345	22		22-31-51	ALL
	D12		W0111	2037R	22		22-12-31	ALL
	D13		W0111	1014	22		22-12-31	ALL
	D14		W0111	0761	24		22-11-75	ALL
	D15		W0111	2040B	22		22-12-31	ALL
	E01		W0111	2036B	22		22-12-31	ALL
	E02		W0111	2036R	22		22-12-31	ALL
	E03	UNUSED						ALL
	E04		W0111	2118R	24		34-61-14	ALL
	E05		W0111	0184	22		22-14-11	ALL
	E06		W0111	2219R	24		22-11-53	ALL
	E07		W0111	0103	24		22-11-75	ALL
	E08		W0111	0110	24		22-11-75	ALL
	E09	UNUSED						ALL
	E10		W0111	2030R	24		22-11-51	ALL
	E11		W0111	0018	22		22-11-11	ALL
	E12	UNUSED						ALL
	E13		W0111	0767	24		22-11-75	ALL
	E14		W0111	0762	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135A		***/*/***		**PLUG (continued)**				**ALL**
	E15		W0111	2040R	22		22-12-31	ALL
	F01		W0111	0021	22		22-11-11	ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04		W0111	0065	22		22-11-14	ALL
	F05	UNUSED						ALL
	F06		W0111	2221B	22		31-32-15	ALL
	F07		W0111	0114	24		22-11-75	ALL
	F08		W0111	0105	24		22-11-75	ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0111	1015	22		22-12-31	ALL
	F14		W0111	0763	24		22-11-75	ALL
	F15		W0111	0765	24		22-11-75	ALL
	G01		W0111	0377	22		34-21-15	ALL
	G02		W0111	2124B	24		34-31-21	ALL
	G03		W0111	0482	22		32-64-21	ALL
	G04		W0111	2054B	24		27-32-12	ALL
	G05	UNUSED						ALL
	G06		W0111	2221R	22		31-32-15	ALL
	G07		W0111	0106	24		22-11-75	ALL
	G08		W0111	0104	24		22-11-75	ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135A		*/*/*		**PLUG (continued)**				**ALL**
	G14	UNUSED						ALL
	G15		W0111	3005B	22		22-12-31	ALL
	H01		W0111	0020	22		22-11-11	ALL
	H02		W0111	2124R	24		34-31-21	ALL
	H03	UNUSED						ALL
	H04		W0111	2054R	24		27-32-12	ALL
	H05	UNUSED						ALL
	H06		W0111	0107	24		22-11-75	ALL
	H07	UNUSED						ALL
	H08		W0111	0115	24		22-11-75	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11		W0111	1002	22		22-11-11	ALL
	H12		W0111	0954	22		22-13-11	ALL
	H13		W0111	3004Y	22		22-12-31	ALL
	H14		W0111	2001B	22		22-11-11	ALL
	H15		W0111	3005Y	22		22-12-31	ALL
	J01		W0111	2135B	24		73-24-21	ALL
	J02		W0111	2135R	24		73-24-21	ALL
	J03		W0111	0594	22		78-34-11	ALL
	J04		W0111	2116B	24		34-21-24	ALL
	J05	UNUSED						ALL
	J06		W0111	2021B	24		22-11-51	ALL
	J07		W0111	0111	24		22-11-75	ALL
	J08		W0111	0112	24		22-11-75	ALL
	J09		W0111	0453	22		22-13-11	ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL
	J12		W0111	0334	22		22-31-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135A		***/*/***		**PLUG (continued)**				**ALL**
	J13		W0111	3004B	22		22-12-31	ALL
	J14	UNUSED						ALL
	J15		W0111	3005R	22		22-12-31	ALL
	K01		W0111	0060	22		22-11-12	ALL
	K02		W0111	2111B	24		34-21-23	ALL
	K03		W0111	2111R	24		34-21-23	ALL
	K04		W0111	2116R	24		34-21-24	ALL
	K05	UNUSED						ALL
	K06		W0111	2021R	24		22-11-51	ALL
	K07		W0111	0344	22		22-31-51	ALL
	K08		W0111	0124	24		22-11-75	ALL
	K09	UNUSED						ALL
	K10		W0111	0962	22		22-11-31	ALL
	K11	UNUSED						ALL
	K12		W0111	0441	22		34-51-41	ALL
	K13		W0111	3004R	22		22-12-31	ALL
	K14		W0111	2001R	22		22-11-11	ALL
	K15	UNUSED						ALL
	DED		W0111	1015Z			22-12-31	ALL
	DED		W0111	2016Z			22-11-51	ALL
	DED		W0111	2021Z			22-11-51	ALL
	DED		W0111	2038Z			22-12-31	ALL
	DED		W0111	2040Z			22-12-31	ALL
	DED		W0111	2054Z			27-32-12	ALL
	DED		W0111	2090Z			22-31-52	ALL
	DED		W0111	2111Z			34-21-23	ALL
	DED		W0111	2118Z			34-61-14	ALL
	DED		W0111	3005Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B		*/*/*		**PLUG**				**ALL**
	A01		W0111	0081	22		22-11-75	ALL
	A02		W0111	2128B	24		31-65-15	ALL
	A03	UNUSED						ALL
	A04		W0111	2056B	24		34-33-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0111	0438	22		34-51-41	ALL
	A08		W0111	2333B	24		22-11-51	ALL
	A09		W0111	2086R	22		22-31-41	ALL
	A10		W0111	2033B	24		22-11-51	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0111	2085R	24		22-31-41	ALL
	A15		W0111	2011B	22		22-11-31	ALL
	B01		W0111	0011	22		22-11-11	ALL
	B02		W0111	2128R	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04		W0111	2056R	24		34-33-11	ALL
	B05		W0111	2134R	24		73-24-11	ALL
	B06	UNUSED						ALL
	B07		W0111	0186	22		22-14-11	ALL
	B08		W0111	2333R	24		22-11-51	ALL
	B09		W0111	2086B	22		22-31-41	ALL
	B10		W0111	2033R	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0111	0048	22		22-11-12	ALL
	B14		W0111	2085B	24		22-31-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B		***/*/***		**PLUG (continued)**				**ALL**
	B15		W0111	2011R	22		22-11-31	ALL
	C01		W0111	0070	22		22-11-14	ALL
	C02		W0111	0816	22		34-51-41	ALL
	C03	UNUSED						ALL
	C04		W0111	2134B	24		73-24-11	ALL
	C05	UNUSED						ALL
	C06		W0111	2087R	24		22-31-41	ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10		W0111	2136R	24		73-24-21	ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13		W0111	0768	24		22-11-75	ALL
	C14		W0111	0787	24		22-11-75	ALL
	C15		W0111	0788	24		22-11-75	ALL
	D01		W0111	0010	22		22-11-11	ALL
	D02		W0111	2297B	24		22-11-51	ALL
	D03		W0111	2297R	24		22-11-51	ALL
	D04		W0111	2108B	24		34-21-14	ALL
	D05		W0111	2087B	24		22-31-41	ALL
	D06	UNUSED						ALL
	D07		W0111	0189	22		22-14-11	ALL
	D08	UNUSED						ALL
	D09		W0111	2136B	24		73-24-21	ALL
	D10		W0111	2032B	24		22-11-51	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13		W0111	1021	22		22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B	*/*/*		**PLUG (continued)**				**ALL**
D14		W0111	0789	24		22-11-75	ALL
D15		W0111	2013B	22		22-11-31	ALL
E01		W0111	2035B	22		22-12-31	ALL
E02		W0111	2035R	22		22-12-31	ALL
E03		W0111	0442	22		34-51-41	ALL
E04		W0111	2108R	24		34-21-14	ALL
E05	UNUSED						ALL
E06		W0111	3003Y	22		22-12-31	ALL
E07		W0111	0433	22		34-51-41	ALL
E08	UNUSED						ALL
E09		W0111	0336	22		22-31-51	ALL
E10		W0111	2032R	24		22-11-51	ALL
E11		W0111	0755	22		22-11-11	ALL
E12	UNUSED						ALL
E13		W0111	0770	24		22-11-75	ALL
E14		W0111	0773	24		22-11-75	ALL
E15		W0111	2013R	22		22-11-31	ALL
F01		W0111	0013	22		22-11-11	ALL
F02	UNUSED						ALL
F03		W0111	0054	22		22-11-12	ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06		W0111	3003B	22		22-12-31	ALL
F07		W0111	0335	22		22-31-51	ALL
F08		W0111	2089B	24		22-31-52	ALL
F09		W0111	2089R	24		22-31-52	ALL
F10		W0111	0777	22		22-31-51	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B		***/*/***		**PLUG (continued)**				**ALL**
	F13		W0111	1018	22		22-11-31	ALL
	F14		W0111	0774	24		22-11-75	ALL
	F15		W0111	0769	24		22-11-75	ALL
	G01		W0111	0378	22		34-21-15	ALL
	G02		W0111	2122B	24		34-31-11	ALL
	G03	UNUSED						ALL
	G04		W0111	2078B	24		34-55-11	ALL
	G05		W0111	0188	22		22-14-11	ALL
	G06		W0111	3003R	22		22-12-31	ALL
	G07		W0111	0960	22		22-11-18	ALL
	G08		W0111	2126B	24		34-51-11	ALL
	G09		W0111	0371	24		22-31-52	ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14		W0111	0771	24		22-11-75	ALL
	G15		W0111	3002B	22		22-11-31	ALL
	H01		W0111	0012	22		22-11-11	ALL
	H02		W0111	2122R	24		34-31-11	ALL
	H03		W0111	2080R	24		22-31-31	ALL
	H04		W0111	2078R	24		34-55-11	ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08		W0111	2126R	24		34-51-11	ALL
	H09		W0111	0009	22		22-11-11	ALL
	H10	UNUSED						ALL
	H11		W0111	1001	22		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B	*/*/*		**PLUG (continued)**				**ALL**
H12	UNUSED						ALL
H13		W0111	3001Y	22		22-11-31	ALL
H14		W0111	0722	22		22-11-11	ALL
H15		W0111	3002Y	22		22-11-31	ALL
J01		W0111	0440	22		34-51-41	ALL
J02		W0111	2080B	24		22-31-31	ALL
J03		W0111	0977	22		78-34-21	ALL
J04		W0111	0181	22		22-14-11	ALL
J05		W0111	0046	22		22-11-12	ALL
J06		W0111	2006B	22		22-11-31	ALL
J07		W0111	0437	22		34-51-41	ALL
J08		W0111	2296B	24		22-11-51	ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11		W0111	2002B	24		34-33-21	ALL
J12	UNUSED						ALL
J13		W0111	3001B	22		22-11-31	ALL
J14	UNUSED						ALL
J15		W0111	3002R	22		22-11-31	ALL
K01		W0111	0059	22		22-11-12	ALL
K02		W0111	2103B	24		34-21-13	ALL
K03		W0111	2103R	24		34-21-13	ALL
K04		W0111	2230B	24		22-11-51	ALL
K05		W0111	2230R	24		22-11-51	ALL
K06		W0111	2006R	22		22-11-31	ALL
K07		W0111	0044	22		22-11-12	ALL
K08		W0111	2296R	24		22-11-51	ALL
K09	UNUSED						ALL
K10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135B		***/*/***		**PLUG (continued)**				**ALL**
	K11		W0111	2002R	24		34-33-21	ALL
	K12	UNUSED						ALL
	K13		W0111	3001R	22		22-11-31	ALL
	K14		W0111	0432	22		34-51-41	ALL
	K15	UNUSED						ALL
	DED		W0111	1018Z			22-11-31	ALL
	DED		W0111	2056Z			34-33-11	ALL
	DED		W0111	2080Z			22-31-31	ALL
	DED		W0111	2089Z			22-31-52	ALL
	DED		W0111	2230Z			22-11-51	ALL
D10135C		***/*/***		**PLUG**				**ALL**
	51		W0111	0001	20		22-11-11	ALL
	52		W0111	0300	18		22-31-31	ALL
	53		W0111	0199	20		22-18-11	ALL
	54		W0111	0180	20		22-14-11	ALL
	55	UNUSED						ALL
	56		W0111	0005	20		22-11-11	ALL
	57		W0111	0006	20		22-11-11	ALL
	58		W0111	0007	20		22-11-11	ALL
	59		W0111	0008	20		22-11-11	ALL
	A01		W0111	2049B	22		22-18-11	ALL
	A02	UNUSED						ALL
	A03		W0111	0164	22		22-13-11	ALL
	A04	UNUSED						ALL
	A05		W0111	0131	22		22-18-11	ALL
	B01		W0111	2049R	22		22-18-11	ALL
	B02		W0111	0156	22		22-13-11	ALL
	B03		W0111	0147	22		22-13-11	ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135C		*/*/*		**PLUG (continued)**				**ALL**
	B05		W0111	0132	22		22-18-11	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W0111	0247	22		22-18-11	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	D01		W0111	0245	22		22-18-11	ALL
	D02		W0111	0159	22		22-13-11	ALL
	D03		W0111	0150	22		22-13-11	ALL
	D04		W0111	2042B	22		22-18-11	ALL
	D05		W0111	0133	22		22-18-11	ALL
	E01		W0111	0772	24		22-11-75	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0111	2042R	22		22-18-11	ALL
	E05		W0111	0134	22		22-18-11	ALL
	F01	UNUSED						ALL
	F02		W0111	0155	22		22-13-11	ALL
	F03		W0111	0248	22		22-18-11	ALL
	F04	UNUSED						ALL
	F05		W0111	0004	22		22-11-11	ALL
	G01	UNUSED						ALL
	G02		W0111	0161	22		22-13-11	ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05		W0111	0022	22		22-11-11	ALL
	H01	UNUSED						ALL
	H02		W0111	0163	22		22-13-11	ALL
	H03		W0113	1003	22		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10135C		***/*/***		**PLUG (continued)**				**ALL**
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	J01	UNUSED						ALL
	J02		W0111	0165	22		22-13-11	ALL
	J03		W0111	0136	22		22-18-11	ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	K01		W0111	0246	22		22-18-11	ALL
	K02		W0111	0195	22		22-14-11	ALL
	K03		W0111	0160	22		22-13-11	ALL
	K04	UNUSED						ALL
	K05		W0111	0073	22		22-11-18	ALL
	CAP	Y	W0111	0162	22		SPARE	ALL
D10137A		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B**				**ALL**
	A01	UNUSED						ALL
	A02		W0141	2362B	24		31-65-15	ALL
	A03	UNUSED						ALL
	A04		W0141	2101B	24		22-31-52	ALL
	A05	UNUSED						ALL
	A06		W0141	2023B	24		22-11-51	ALL
	A07		W0141	0131	24		22-11-75	ALL
	A08		W0141	0069	24		22-11-75	ALL
	A09	UNUSED						ALL
	A10		W0141	2028B	24		22-11-51	ALL
	A11		W0141	0308	24		22-11-53	ALL
	A12		W0141	2035B	22		22-12-41	ALL
	A13		W0141	2035R	22		22-12-41	ALL
	A14	UNUSED						ALL
	A15		W0141	2034B	22		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137A	*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
B01		W0141	0018	22		22-11-11	ALL
B02		W0141	2362R	24		31-65-15	ALL
B03		W0141	0030	22		22-11-12	ALL
B04		W0141	2101R	24		22-31-52	ALL
B05	UNUSED						ALL
B06		W0141	2023R	24		22-11-51	ALL
B07		W0141	0146	22		22-11-75	ALL
B08		W0141	0070	24		22-11-75	ALL
B09	UNUSED						ALL
B10		W0141	2028R	24		22-11-51	ALL
B11		W0141	0309	24		22-11-53	ALL
B12	UNUSED						ALL
B13		W0141	0038	22		22-11-12	ALL
B14	UNUSED						ALL
B15		W0141	2034R	22		22-12-41	ALL
C01		W0141	0612	22		32-64-21	ALL
C02		W0141	0729	22		34-51-41	ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08		W0141	0076	24		22-11-75	ALL
C09	UNUSED						ALL
C10		W0141	0311	24		22-11-53	ALL
C11		W0141	0310	24		22-11-53	ALL
C12		W0141	2033B	22		22-12-41	ALL
C13		W0141	0183	24		22-11-75	ALL
C14		W0141	0239	22		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137A		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	C15		W0141	0240	22		22-11-75	ALL
	D01		W0141	0715	22		34-51-41	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0141	2105B	24		34-61-14	ALL
	D05	UNUSED						ALL
	D06		W0141	2051B	24		22-11-53	ALL
	D07	UNUSED						ALL
	D08		W0141	0077	24		22-11-75	ALL
	D09	UNUSED						ALL
	D10		W0141	2027B	24		22-11-51	ALL
	D11	UNUSED						ALL
	D12		W0141	2033R	22		22-12-41	ALL
	D13		W0141	0089	22		22-12-41	ALL
	D14		W0141	0179	24		22-11-75	ALL
	D15		W0141	2036B	22		22-12-41	ALL
	E01		W0141	2031B	22		22-12-41	ALL
	E02		W0141	2031R	22		22-12-41	ALL
	E03	UNUSED						ALL
	E04		W0141	2105R	24		34-61-14	ALL
	E05		W0141	0111	22		22-14-11	ALL
	E06		W0141	2051R	24		22-11-53	ALL
	E07		W0141	0071	24		22-11-75	ALL
	E08		W0141	0078	24		22-11-75	ALL
	E09	UNUSED						ALL
	E10		W0141	2027R	24		22-11-51	ALL
	E11		W0141	0050	22		22-11-11	ALL
	E12	UNUSED						ALL
	E13		W0141	0186	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137A		*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	E14		W0141	0180	24		22-11-75	ALL
	E15		W0141	2036R	22		22-12-41	ALL
	F01		W0141	0019	22		22-11-11	ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04		W0141	0046	22		22-11-14	ALL
	F05	UNUSED						ALL
	F06		W0141	2049B	22		31-32-15	ALL
	F07		W0141	0082	24		22-11-75	ALL
	F08		W0141	0073	24		22-11-75	ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0141	0090	22		22-12-41	ALL
	F14		W0141	0181	24		22-11-75	ALL
	F15		W0141	0182	24		22-11-75	ALL
	G01		W0141	0212	22		34-21-15	ALL
	G02		W0141	2301B	24		34-31-11	ALL
	G03		W0141	0152	22		32-64-21	ALL
	G04		W0141	2039B	24		27-32-22	ALL
	G05	UNUSED						ALL
	G06		W0141	2049R	22		31-32-15	ALL
	G07		W0141	0074	24		22-11-75	ALL
	G08		W0141	0072	24		22-11-75	ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137A		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15		W0141	3005B	22		22-12-41	ALL
	H01		W0141	0017	22		22-11-11	ALL
	H02		W0141	2301R	24		34-31-11	ALL
	H03	UNUSED						ALL
	H04		W0141	2039R	24		27-32-22	ALL
	H05	UNUSED						ALL
	H06		W0141	0075	24		22-11-75	ALL
	H07	UNUSED						ALL
	H08		W0141	0083	24		22-11-75	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11		W0141	1012	22		22-11-11	ALL
	H12		W0141	0238	22		22-13-11	ALL
	H13		W0141	3004Y	22		22-12-41	ALL
	H14		W0141	2001B	22		22-11-11	ALL
	H15		W0141	3005Y	22		22-12-41	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0141	0357	22		78-34-11	ALL
	J04		W0141	2057B	24		34-21-14	ALL
	J05	UNUSED						ALL
	J06		W0141	2024B	24		22-11-51	ALL
	J07		W0141	0079	24		22-11-75	ALL
	J08		W0141	0080	24		22-11-75	ALL
	J09		W0141	0197	22		22-13-11	ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137A		*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	J12	UNUSED						ALL
	J13		W0141	3004B	22		22-12-41	ALL
	J14	UNUSED						ALL
	J15		W0141	3005R	22		22-12-41	ALL
	K01		W0141	0022	22		22-11-12	ALL
	K02		W0141	2102B	24		34-21-13	ALL
	K03		W0141	2102R	24		34-21-13	ALL
	K04		W0141	2057R	24		34-21-14	ALL
	K05	UNUSED						ALL
	K06		W0141	2024R	24		22-11-51	ALL
	K07	UNUSED						ALL
	K08		W0141	0085	24		22-11-75	ALL
	K09	UNUSED						ALL
	K10		W0141	0242	22		22-11-31	ALL
	K11	UNUSED						ALL
	K12		W0141	0724	22		34-51-41	ALL
	K13		W0141	3004R	22		22-12-41	ALL
	K14		W0141	2001R	22		22-11-11	ALL
	K15	UNUSED						ALL
	DED		W0141	2023Z			22-11-51	ALL
	DED		W0141	2024Z			22-11-51	ALL
	DED		W0141	2049Z			31-32-15	ALL
	DED		W0141	2105Z			34-61-14	ALL
D10137B		*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B**				**ALL**
	A01		W0141	0086	22		22-11-75	ALL
	A02		W0141	2363B	24		31-65-25	ALL
	A03	UNUSED						ALL
	A04		W0141	2151B	24		34-33-21	ALL
	A05		W0141	0087	22		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	A06	UNUSED						ALL
	A07		W0141	0721	22		34-51-41	ALL
	A08		W0141	2040B	24		22-11-51	ALL
	A09	UNUSED						ALL
	A10		W0141	2026B	24		22-11-51	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0141	2014B	22		22-11-31	ALL
	B01		W0141	0011	22		22-11-11	ALL
	B02		W0141	2363R	24		31-65-25	ALL
	B03	UNUSED						ALL
	B04		W0141	2151R	24		34-33-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0141	0106	22		22-14-11	ALL
	B08		W0141	2040R	24		22-11-51	ALL
	B09	UNUSED						ALL
	B10		W0141	2026R	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0141	0035	22		22-11-12	ALL
	B14	UNUSED						ALL
	B15		W0141	2014R	22		22-11-31	ALL
	C01		W0141	0049	22		22-11-14	ALL
	C02		W0141	0727	22		34-51-41	ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B	*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13		W0141	0187	24		22-11-75	ALL
C14		W0141	0194	24		22-11-75	ALL
C15		W0141	0195	24		22-11-75	ALL
D01		W0141	0008	22		22-11-11	ALL
D02		W0141	2085B	24		22-11-51	ALL
D03		W0141	2085R	24		22-11-51	ALL
D04		W0141	2104B	24		34-21-24	ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07		W0141	0104	22		22-14-11	ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10		W0141	2025B	24		22-11-51	ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13		W0141	0065	22		22-11-31	ALL
D14		W0141	0196	24		22-11-75	ALL
D15		W0141	2015B	22		22-11-31	ALL
E01		W0141	2032B	22		22-12-41	ALL
E02		W0141	2032R	22		22-12-41	ALL
E03		W0141	0736	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	E04		W0141	2104R	24		34-21-24	ALL
	E05	UNUSED						ALL
	E06		W0141	3003Y	22		22-12-41	ALL
	E07		W0141	0718	22		34-51-41	ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10		W0141	2025R	24		22-11-51	ALL
	E11		W0141	0002	22		22-11-11	ALL
	E12	UNUSED						ALL
	E13		W0141	0189	24		22-11-75	ALL
	E14		W0141	0192	24		22-11-75	ALL
	E15		W0141	2015R	22		22-11-31	ALL
	F01		W0141	0015	22		22-11-11	ALL
	F02	UNUSED						ALL
	F03		W0141	0042	22		22-11-12	ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06		W0141	3003B	22		22-12-41	ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0141	0066	22		22-11-31	ALL
	F14		W0141	0193	24		22-11-75	ALL
	F15		W0141	0188	24		22-11-75	ALL
	G01		W0141	0213	22		34-21-15	ALL
	G02		W0141	2304B	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B	*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
G03	UNUSED						ALL
G04		W0141	2152B	24		34-55-21	ALL
G05		W0141	0113	22		22-14-11	ALL
G06		W0141	3003R	22		22-12-41	ALL
G07		W0141	0062	22		22-11-18	ALL
G08		W0141	2318B	24		34-51-21	ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL
G13	UNUSED						ALL
G14		W0141	0190	24		22-11-75	ALL
G15		W0141	3002B	22		22-11-31	ALL
H01		W0141	0013	22		22-11-11	ALL
H02		W0141	2304R	24		34-31-21	ALL
H03	UNUSED						ALL
H04		W0141	2152R	24		34-55-21	ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08		W0141	2318R	24		34-51-21	ALL
H09		W0141	0009	22		22-11-11	ALL
H10	UNUSED						ALL
H11		W0141	1011	22		22-11-11	ALL
H12	UNUSED						ALL
H13		W0141	3001Y	22		22-11-31	ALL
H14		W0141	0016	22		22-11-11	ALL
H15		W0141	3002Y	22		22-11-31	ALL
J01		W0141	0723	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	J02	UNUSED						ALL
	J03		W0141	0464	22		78-34-21	ALL
	J04		W0141	0161	22		22-14-11	ALL
	J05		W0141	0031	22		22-11-12	ALL
	J06		W0141	2008B	22		22-11-31	ALL
	J07		W0141	0722	22		34-51-41	ALL
	J08		W0141	2084B	24		22-11-51	ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11		W0141	2058B	24		34-33-11	ALL
	J12	UNUSED						ALL
	J13		W0141	3001B	22		22-11-31	ALL
	J14	UNUSED						ALL
	J15		W0141	3002R	22		22-11-31	ALL
	K01		W0141	0021	22		22-11-12	ALL
	K02		W0141	2103B	24		34-21-23	ALL
	K03		W0141	2103R	24		34-21-23	ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06		W0141	2008R	22		22-11-31	ALL
	K07		W0141	0028	22		22-11-12	ALL
	K08		W0141	2084R	24		22-11-51	ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11		W0141	2058R	24		34-33-11	ALL
	K12	UNUSED						ALL
	K13		W0141	3001R	22		22-11-31	ALL
	K14		W0141	0717	22		34-51-41	ALL
	K15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137B		*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	DED		W0141	2040Z			22-11-51	ALL
	DED		W0141	2103Z			34-21-23	ALL
	DED		W0141	2151Z			34-33-21	ALL
D10137C		*/*/*		**PLUG - FLIGHT CONTROL COMPUTER - B**				**ALL**
	51		W0141	0053	20		22-11-11	ALL
	52	UNUSED						ALL
	53		W0141	0124	20		22-18-11	ALL
	54		W0141	0109	20		22-14-11	ALL
	55	UNUSED						ALL
	56		W0141	0056	20		22-11-11	ALL
	57		W0141	0057	20		22-11-11	ALL
	58		W0141	0058	20		22-11-11	ALL
	59		W0141	0059	20		22-11-11	ALL
	A01		W0141	2038B	22		22-18-11	ALL
	A02	UNUSED						ALL
	A03		W0141	0102	22		22-13-11	ALL
	A04	UNUSED						ALL
	A05		W0141	0118	22		22-18-11	ALL
	B01		W0141	2038R	22		22-18-11	ALL
	B02		W0141	0097	22		22-13-11	ALL
	B03		W0141	0094	22		22-13-11	ALL
	B04	UNUSED						ALL
	B05		W0141	0120	22		22-18-11	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W0141	0128	22		22-18-11	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	D01		W0141	0125	22		22-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137C		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	D02		W0141	0096	22		22-13-11	ALL
	D03		W0141	0093	22		22-13-11	ALL
	D04		W0141	2037B	22		22-18-11	ALL
	D05		W0141	0122	22		22-18-11	ALL
	E01		W0141	0191	24		22-11-75	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0141	2037R	22		22-18-11	ALL
	E05		W0141	0123	22		22-18-11	ALL
	F01	UNUSED						ALL
	F02		W0141	0098	22		22-13-11	ALL
	F03		W0141	0127	22		22-18-11	ALL
	F04	UNUSED						ALL
	F05		W0141	0006	22		22-11-11	ALL
	G01	UNUSED						ALL
	G02		W0141	0100	22		22-13-11	ALL
	G03		W0141	0129	22		22-18-11	ALL
	G04	UNUSED						ALL
	G05		W0141	0007	22		22-11-11	ALL
	H01	UNUSED						ALL
	H02		W0141	0095	22		22-13-11	ALL
	H03		W0149	1001	22		22-13-11	ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	J01	UNUSED						ALL
	J02		W0141	0103	22		22-13-11	ALL
	J03		W0141	0121	22		22-18-11	ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10137C		***/*/***		**PLUG - FLIGHT CONTROL COMPUTER - B (continued)**				**ALL**
	K01		W0141	0126	22		22-18-11	ALL
	K02		W0141	0105	22		22-14-11	ALL
	K03		W0141	0099	22		22-13-11	ALL
	K04	UNUSED						ALL
	K05		W0141	0060	22		22-11-18	ALL
	CAP	Y	W0141	0101	22		SPARE	ALL
D10159		**312/178/R17**		**PLUG-COAX**				**ALL**
	=A1		W5099	001CX			34-53-31	ALL
	=C1		W5099	001CO			34-53-31	ALL
D10161		**E001-01/ /**		**PLUG-COAX**				**ALL**
	=A1		W0111	009CX			34-53-31	ALL
	=C1		W0111	009CO			34-53-31	ALL
D10163		**316/178/R017**		**PLUG-COAX**				**ALL**
	=A1		W0121	003CX			34-53-31	ALL
	=C1		W0121	003CO			34-53-31	ALL
D10167		**AB0250A/195/L002**		**RCPT**				**ALL**
	1		W5506	6085	20		78-35-11	ALL
	2		W5506	6083	20		78-35-11	ALL
	3		W5506	6084	20		78-35-11	ALL
D10169		**AB0250A/ /**		**RCPT-**				**ALL**
	1		W6506	6079	20		78-35-21	ALL
	2		W6506	6077	20		78-35-21	ALL
	3		W6506	6078	20		78-35-21	ALL
D10171		**AF0213A/209/L001**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5506	6042	20		78-34-11	ALL
	5		W5506	6041	20		78-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10171J		**214/209/L001**		**RCPT-**				**ALL**
	1		W0049	0011	22		78-34-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0049	0014	22		78-34-11	ALL
	5		W0049	0015	22		78-34-11	ALL
D10173		**AF0222A/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W6510	6031	20		78-34-21	ALL
	5		W6510	6030	20		78-34-21	ALL
D10173J		**AF0222A/ /**		**RCPT-**				**ALL**
	1		W0051	0031	22		78-34-21	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0051	0034	22		78-34-21	ALL
	5		W0051	0036	22		78-34-21	ALL
D10175		**AB0372/184/R050**		**RCPTTEST CONNECTOR**				**ALL**
	1		W5111	2014R	24		31-65-15	ALL
	2		W5111	2014B	24		31-65-15	ALL
	3		W5111	2729R	24		31-65-25	ALL
	4		W5111	2729B	24		31-65-25	ALL
	5	UNUSED						ALL
	S/R		W5111	2014Z			31-65-15	ALL
	S/R		W5111	2729Z			31-65-25	ALL
D10180		**959/290/R004**		**PLUG, RECTANGULAR**				**ALL**
	1		W0152	0018	22		SPARE	ALL
	2		W0152	0009	22		33-27-22	ALL
	3		W0152	0010	22		33-27-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10180	**959/290/R004**		**PLUG, RECTANGULAR (continued)**				**ALL**
4		W0152	0024	22		23-42-11	ALL
5		W0152	0017	22		SPARE	ALL
6		W0152	0026	22		23-42-11	ALL
7		W0152	0003	20		33-51-14	ALL
8		W0152	0004	20		33-51-14	ALL
D10193	**P006-00/ /**		**PLUG-DATA LOADER CONTROL PANEL**				**ALL**
1		W0041	0098	24		22-11-53	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0041	2505B	22		31-32-15	ALL
5		W0041	0097	24		22-11-53	ALL
6		W0041	2505R	22		31-32-15	ALL
7		W0041	0092	24		34-61-26	ALL
8	UNUSED						ALL
9		W0041	0090	24		34-61-18	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0041	0036	24		31-65-25	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W0041	2530R	24		34-61-26	ALL
22	UNUSED						ALL
23		W0041	0123	22		27-61-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10193		**P006-00/ /**		**PLUG-DATA LOADER CONTROL PANEL (continued)**				**ALL**
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W0041	0099	24		22-11-53	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40		W0041	2530B	24		34-61-26	ALL
	41		W0041	2527B	24		34-61-18	ALL
	42		W0041	2527R	24		34-61-18	ALL
	43		W0041	2544R	24		27-61-47	ALL
	44		W0041	2544B	24		27-61-47	ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10193	**P006-00/ /**		**PLUG-DATA LOADER CONTROL PANEL (continued)**				**ALL**
53	UNUSED						ALL
54		W0041	2532R	24		22-11-53	ALL
55		W0041	2532B	24		22-11-53	ALL
56	UNUSED						ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60	UNUSED						ALL
61	UNUSED						ALL
DED		W0041	2505Z			31-32-15	ALL
DED		W0041	2527Z			34-61-18	ALL
DED		W0041	2530Z			34-61-26	ALL
DED		W0041	2532Z			22-11-53	ALL
DED		W0041	2544Z			27-61-47	ALL
D10197	**RUD66.4/ /**		**PLUG-**				**ALL**
1		W6136	1010	20		27-23-11	ALL
2		W6136	1009	20		27-23-11	ALL
3		W6136	2002R	20		27-25-11	ALL
4		W6136	2002B	20		27-25-11	ALL
5		W6136	0508	20		27-25-11	ALL
6		W6136	0510	20		27-25-11	ALL
7		W6136	0511	20		27-25-11	ALL
8		W6136	0509	20		27-23-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W6136	1002	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10197		**RUD66.4/ /**		**PLUG- (continued)**				**ALL**
	15		W6136	1001	20		27-25-11	ALL
	S/R		W6136	1001Z			27-25-11	ALL
	S/R		W6136	1002Z			27-25-11	ALL
	S/R		W6136	1009Z			27-23-11	ALL
	S/R		W6136	1010Z			27-23-11	ALL
	S/R		W6136	2002Z			27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10204	**316/162/L025**		**PLUG-COAX**				**ALL**
A		W2247	0014	22		34-53-31	ALL
B		W2247	0013	20		34-53-31	ALL
C		W2247	0025	22		34-53-31	ALL
D	UNUSED						ALL
E	UNUSED						ALL
F	UNUSED						ALL
D10206	**316/163/L025**		**PLUG-COAX**				**ALL**
A		W2247	0027	22		34-53-31	ALL
B		W2247	0028	20		34-53-31	ALL
C		W2247	0026	22		34-53-31	ALL
D	UNUSED						ALL
E	UNUSED						ALL
F	UNUSED						ALL
D10254	**J004-00/ /**		**RELAY-SOCKET**				**ALL**
A1		W0094	0237	20		33-42-21	ALL
A2		W0094	0238	20		33-42-21	ALL
A3	UNUSED						ALL
B1		W0094	0083	20		33-42-21	ALL
B2		W0094	0084	20		33-42-21	ALL
B3	UNUSED						ALL
X1		W0094	0081	20		33-42-21	ALL
X2		W0094	0082	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10328		**378/165/L008**		**PLUG-AUX BATTERY**				**ALL**
	+	Q	W2532	0528	*1		24-31-12	ALL
	-	G	W2532	2202R	20		24-31-12	ALL
	-	Q	W2532	0531	*1		24-31-12	ALL
D10330		**378/162/L005**		**PLUG-AUX BATTERY SENSOR**				**ALL**
	1		W5110	0523	24		24-31-12	ALL
	2	UNUSED						ALL
	3		W5110	0521	24		24-31-12	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5110	0526	24		24-31-12	ALL
	12		W5110	0525	24		24-31-12	ALL
D10342		**E003-03/ /**		**PLUG-AUX BATT CHARGER**				**ALL**
	1		W5110	0523	24		24-31-12	ALL
	2		W5110	0539	20		24-31-12	ALL
	3		W5110	0521	24		24-31-12	ALL
	4		W5110	3203Y	20		24-31-12	ALL
	5		W5110	0538	24		24-31-12	ALL
	6		W5110	0538	24		24-31-12	ALL
	7		W5110	3203B	20		24-31-12	ALL
	8		W5110	0530	24		24-31-12	ALL
	9		W5110	0527	24		24-31-12	ALL
	10		W5110	3203R	20		24-31-12	ALL
	11		W5110	0526	24		24-31-12	ALL
	12		W5110	0525	24		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10434	**AB1088/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W4724	0515	20		49-52-31	ALL
2	UNUSED						ALL
3		W4724	1016	20		49-52-31	ALL
4		W4724	0517	20		49-52-31	ALL
5		W4724	1018	20		49-52-31	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W4724	1036	20		49-94-21	ALL
10	UNUSED						ALL
11		W4724	1029	20		49-94-21	ALL
12		W4724	0560	20		49-94-21	ALL
13		W4724	0589	20		49-94-21	ALL
14		W4724	0590	22		49-94-21	ALL
15	UNUSED						ALL
16		W4724	2204B	20		49-41-11	ALL
17		W4724	2204R	20		49-41-11	ALL
18	UNUSED						ALL
19		W4724	0563	20		49-94-21	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W4724	1035	20		49-94-21	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W4724	1218	20		49-62-12	ALL
26		W4724	0575	22		49-62-12	ALL
27		W4724	0587	22		49-62-12	ALL
28	UNUSED						ALL
29		W4724	1033	20		49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10434		**AB1088/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	30	UNUSED						ALL
	31		W4724	2224R	22		49-62-51	ALL
	32	UNUSED						ALL
	33		W4724	2224B	22		49-62-51	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	S/R		W4724	1016Z			49-52-31	ALL
	S/R		W4724	1018Z			49-52-31	ALL
	S/R		W4724	1029Z			49-94-21	ALL
	S/R		W4724	1033Z			49-94-21	ALL
	S/R		W4724	1035Z			49-94-21	ALL
	S/R		W4724	1036Z			49-94-21	ALL
	S/R		W4724	1218Z			49-62-12	ALL
	S/R		W4724	2204Z			49-41-11	ALL
	S/R		W4724	2224Z			49-62-51	ALL
D10436		**AB1088/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W4724	2207R	22		49-52-31	ALL
	2		W4724	3201R	22		49-52-31	ALL
	3		W4724	2217R	22		49-62-12	ALL
	4		W4724	3203R	22		49-62-12	ALL
	5		W4724	2207B	22		49-52-31	ALL
	6		W4724	3202Y	22		49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10436	**AB1088/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
7	UNUSED						ALL
8		W4724	2205R	22		49-52-31	ALL
9		W4724	2206R	22		49-52-31	ALL
10		W4724	3201B	22		49-52-31	ALL
11		W4724	3203B	22		49-62-12	ALL
12		W4724	2219B	22		49-62-12	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W4724	2208B	22		49-52-31	ALL
16		W4724	3202B	22		49-52-31	ALL
17	UNUSED						ALL
18		W4724	1208	20		49-62-12	ALL
19		W4724	2215B	22		49-62-12	ALL
20		W4724	2216B	22		49-62-12	ALL
21		W4724	2205B	22		49-52-31	ALL
22		W4724	2206B	22		49-52-31	ALL
23		W4724	3201Y	22		49-52-31	ALL
24		W4724	2217B	22		49-62-12	ALL
25		W4724	3203Y	22		49-62-12	ALL
26		W4724	2219R	22		49-62-12	ALL
27		W4724	1210	20		49-62-12	ALL
28		W4724	2218R	22		49-62-12	ALL
29		W4724	2218B	22		49-62-12	ALL
30		W4724	2208R	22		49-52-31	ALL
31		W4724	3202R	22		49-52-31	ALL
32		W4724	1209	20		49-62-12	ALL
33		W4724	2214R	22		49-62-12	ALL
34		W4724	2214B	22		49-62-12	ALL
35		W4724	2215R	22		49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10436		**AB1088/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	36		W4724	2216R	22		49-62-12	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W4724	0549	20		49-62-12	ALL
	S/R		W4724	1208Z			49-62-12	ALL
	S/R		W4724	1209Z			49-62-12	ALL
	S/R		W4724	1210Z			49-62-12	ALL
	S/R		W4724	2205Z			49-52-31	ALL
	S/R		W4724	2206Z			49-52-31	ALL
	S/R		W4724	2207Z			49-52-31	ALL
	S/R		W4724	2208Z			49-52-31	ALL
	S/R		W4724	2214Z			49-62-12	ALL
	S/R		W4724	2215Z			49-62-12	ALL
	S/R		W4724	2216Z			49-62-12	ALL
	S/R		W4724	2217Z			49-62-12	ALL
	S/R		W4724	2218Z			49-62-12	ALL
	S/R		W4724	2219Z			49-62-12	ALL
	S/R		W4724	3201Z			49-52-31	ALL
	S/R		W4724	3202Z			49-52-31	ALL
	S/R		W4724	3203Z			49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10529	**1159/288/R008**		**PLUG-RIGHT ELEVATOR TAB SOLENOID**				**ALL**
1		W8030	1001	18		27-31-11	ALL
2		W8030	0523	18		27-31-11	ALL
S/R		W8030	1001Z			27-31-11	ALL
D10531	**1159/292/R008**		**PLUG-LEFT ELEVATOR TAB SOLENOID**				**ALL**
1		W7030	1001	18		27-31-11	ALL
2		W7030	1003	18		27-31-11	ALL
S/R		W7030	1001Z			27-31-11	ALL
S/R		W7030	1003Z			27-31-11	ALL
D10533	**631/162/R65**		**PLUG-CONDUCTIVE**				**ALL**
1		W8122	0515	18		27-81-51	ALL
2		W8122	0516	18		27-81-51	ALL
S/R		W8122	YAAF			27-81-51	ALL
D10535	**702/199/L011**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0409	20		27-81-51	ALL
2		W7128	0410	20		27-81-51	ALL
D10537	**AF0222A/ /**		**PLUG-**				**ALL**
1		W6208	2001B	22		27-51-11	ALL
2		W6208	3001B	22		27-51-11	ALL
3		W6208	3001R	22		27-51-11	ALL
4		W6208	3001Y	22		27-51-11	ALL
5		W6208	2001R	22		27-51-11	ALL
D10553	**200/204/R011**		**PLUG**				**ALL**
1		W5369	2176B	22		31-31-14	ALL
2		W5369	3027B	22		31-31-14	ALL
3		W5369	3027R	22		31-31-14	ALL
4		W5369	3027Y	22		31-31-14	ALL
5		W5369	2176R	22		31-31-14	ALL
D10560	**230/239/R040**		**RCPT-**				**ALL**
1		W2012	5503	20		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10560		**230/239/R040**		**RCPT- (continued)**				**ALL**
	2		W2012	5502	20		30-41-11	ALL
	3		W2012	5501	20		30-41-11	ALL
	4		W2012	1001	20		30-41-11	ALL
	5		W2012	5504	20		30-41-11	ALL
	DED		W2012	1001Z			30-41-11	ALL
D10564		**249/232/R048**		**RCPT-M/W R #2 WINDOW COILED CORD**				**ALL**
	1		W2108	3001R	20		30-41-11	ALL
	2		W2108	3001B	20		30-41-11	ALL
	3		W2108	1003	20		30-41-11	ALL
	4		W2108	1004	20		30-41-11	ALL
	5		W2108	FRAB			30-41-11	ALL
	6		W2108	3001Y	20		30-41-11	ALL
	DED		W2108	YAAB			30-41-11	ALL
			W2108	1003Z			30-41-11	ALL
			W2108	1004Z			30-41-11	ALL
			W2108	3001Z			30-41-11	ALL
			W2108	FRAB			30-41-11	ALL
D10568		**249/232/L048**		**RCPT-M/W L #2 WINDOW COILED CORD**				**ALL**
	1		W2208	3001R	20		30-41-12	ALL
	2		W2208	3001B	20		30-41-12	ALL
	3		W2208	1003	20		30-41-12	ALL
	4		W2208	1004	20		30-41-12	ALL
	5		W2208	FRAB			30-41-12	ALL
	6		W2208	3001Y	20		30-41-12	ALL
	DED		W2208	YAAB			30-41-12	ALL
			W2208	1003Z			30-41-12	ALL
			W2208	1004Z			30-41-12	ALL
			W2208	3001Z			30-41-12	ALL
			W2208	FRAB			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10572	**230/239/L040**		**RCPT-**				**ALL**
1		W2004	5502	20		30-41-12	ALL
2		W2004	5503	20		30-41-12	ALL
3		W2004	5501	20		30-41-12	ALL
4		W2004	1001	20		30-41-12	ALL
5		W2004	5504	20		30-41-12	ALL
DED		W2004	1001Z			30-41-12	ALL
D10583	**797/289/L015**		**PLUG-TPS COAX 150-1120**				**ALL**
=A1	UNUSED						ALL
=C1	UNUSED						ALL
D10585	**797/289/L005**		**PLUG-TNC COAX 150-1122**				**ALL**
=A1	UNUSED						ALL
=C1	UNUSED						ALL
D10589	**OFSS 555/ /**		**PLUG-CODUCTIVE**				**ALL**
1		W1188	2601R	20		27-81-12	ALL
2		W1188	2601B	20		27-81-12	ALL
3	UNUSED						ALL
S/R		W1188	2601Z			27-81-12	ALL
D10591	**OFSS 435/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1188	2602R	20		27-81-12	ALL
2		W1188	2602B	20		27-81-12	ALL
3	UNUSED						ALL
S/R		W1188	2602Z			27-81-12	ALL
D10593	**OFSS 318/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1188	2603R	20		27-81-12	ALL
2		W1188	2603B	20		27-81-12	ALL
3	UNUSED						ALL
S/R		W1188	2603Z			27-81-12	ALL
D10595	**OFSS 318/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1288	2601R	20		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10595		**OFSS 318/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2		W1288	2601B	20		27-81-22	ALL
	3	UNUSED						ALL
	S/R		W1288	2601Z			27-81-22	ALL
D10596		**P005-13/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2218	0512	20		24-28-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2218	0513	20		24-28-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2218	0558	20		24-28-11	ALL
	17		W2218	0557	20		24-28-11	ALL
	18	UNUSED						ALL
	19		W2218	0514	20		24-28-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10596	**P005-13/ /**		**PLUG- (continued)**				**ALL**
26		W2218	5710	20		33-12-12	ALL
27	UNUSED						ALL
28		W2218	0517	22		24-22-11	ALL
29		W2218	0506	22		24-22-21	ALL
30		W2508	0520	24		24-34-11	ALL
31		W2508	0505	24		24-32-11	ALL
32		W2508	0502	24		24-31-11	ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W2218	0508	22		24-28-11	ALL
39	UNUSED						ALL
40		W2508	0536	22		24-28-11	ALL
41		W2218	0509	22		24-28-11	ALL
42	UNUSED						ALL
43		W2218	0507	22		24-28-11	ALL
44		W2218	5711	20		33-12-12	ALL
45		W2508	5541	20		33-18-33	ALL
46		W2218	0522	20		24-28-11	ALL
47		W2508	0519	24		24-34-11	ALL
48		W2508	5543	20		33-18-33	ALL
49		W2508	5741	20		31-52-32	ALL
50		W2508	5742	20		31-52-32	ALL
51		W2508	5542	20		33-18-33	ALL
52		W2508	0528	24		24-31-11	ALL
53		W2508	0537	22		24-28-11	ALL
54	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10596		**P005-13/ /**		**PLUG- (continued)**				**ALL**
	55		W2218	0510	22		24-28-11	ALL
D10597		**OFSS 435/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1288	2602R	20		27-81-22	ALL
	2		W1288	2602B	20		27-81-22	ALL
	3	UNUSED						ALL
	S/R		W1288	2602Z			27-81-22	ALL
D10599		**OFSS 555/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1288	2603R	20		27-81-22	ALL
	2		W1288	2603B	20		27-81-22	ALL
	3	UNUSED						ALL
	S/R		W1288	2603Z			27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10601	**P008-71/ /**		**PLUG-**				**ALL**
1		W2413	2502R	24		23-12-11	ALL
2		W2413	2502B	24		23-12-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2413	2506R	24		23-12-21	ALL
10		W2413	2506B	24		23-12-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2413	2508R	24		23-12-31	ALL
14		W2413	2508B	24		23-12-31	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W2413	2503R	24		23-11-11	ALL
18		W2413	2503B	24		23-11-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2413	2504R	24		23-11-21	ALL
23		W2413	2504B	24		23-11-21	ALL
24	UNUSED						ALL
DED		W2413	2502Z			23-12-11	ALL
DED		W2413	2503Z			23-11-11	ALL
DED		W2413	2504Z			23-11-21	ALL
DED		W2413	2506Z			23-12-21	ALL
DED		W2413	2508Z			23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10603	**P008-72/ /**		**PLUG-**				**ALL**
1		W2415	2506R	24		23-12-11	ALL
2		W2415	2506B	24		23-12-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2415	2502R	24		23-12-21	ALL
10		W2415	2502B	24		23-12-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2415	2507R	24		23-12-31	ALL
14		W2415	2507B	24		23-12-31	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W2415	2503R	24		23-11-11	ALL
18		W2415	2503B	24		23-11-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2415	2504R	24		23-11-21	ALL
23		W2415	2504B	24		23-11-21	ALL
24	UNUSED						ALL
DED		W2415	2502Z			23-12-21	ALL
DED		W2415	2503Z			23-11-11	ALL
DED		W2415	2504Z			23-11-21	ALL
DED		W2415	2506Z			23-12-11	ALL
DED		W2415	2507Z			23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10605	**P008-73/ /**		**PLUG-**				**ALL**
1		W2417	2505R	24		23-12-11	ALL
2		W2417	2505B	24		23-12-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2417	2507R	24		23-12-21	ALL
10		W2417	2507B	24		23-12-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2417	2502R	24		23-12-31	ALL
14		W2417	2502B	24		23-12-31	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W2417	2503R	24		23-11-11	ALL
18		W2417	2503B	24		23-11-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2417	2504R	24		23-11-21	ALL
23		W2417	2504B	24		23-11-21	ALL
24	UNUSED						ALL
DED		W2417	2502Z			23-12-31	ALL
DED		W2417	2503Z			23-11-11	ALL
DED		W2417	2504Z			23-11-21	ALL
DED		W2417	2505Z			23-12-11	ALL
DED		W2417	2507Z			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10715	**790/300/L016**		**PLUG-**				**ALL**
1		W3419	0101	24		23-24-11	ALL
2		W3419	0102	24		23-24-11	ALL
3		W3419	0103	24		23-24-11	ALL
4		W3419	0104	24		23-24-11	ALL
5		W3419	0105	24		23-24-11	ALL
6		W3419	0106	24		23-24-11	ALL
7		W3419	0107	24		23-24-11	ALL
8		W3419	0108	24		23-24-11	ALL
9		W3419	0109	24		23-24-11	ALL
10		W3419	0110	24		23-24-11	ALL
11		W3419	0111	24		23-24-11	ALL
12		W3419	0112	24		23-24-11	ALL
13		W3419	0113	24		23-24-11	ALL
14		W3419	0114	24		23-24-11	ALL
15		W3419	0115	24		23-24-11	ALL
16		W3419	0116	24		23-24-11	ALL
17		W3419	0117	24		23-24-11	ALL
18		W3419	0118	24		23-24-11	ALL
19		W3419	0119	24		23-24-11	ALL
20		W3419	0120	24		23-24-11	ALL
21		W3419	0121	24		23-24-11	ALL
22		W3419	0122	24		23-24-11	ALL
23		W3419	0123	24		23-24-11	ALL
24		W3419	0124	24		23-24-11	ALL
25		W3419	0035	20		23-24-11	ALL
26		W3419	0036	20		23-24-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10715	**790/300/L016**		**PLUG- (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
D10716	**727C+13/212/L068**		**PLUG-**				**ALL**
1	16	W3142	0301	16		33-51-11	ALL
2		W3142	0302	20		33-51-11	ALL
3		W3142	0303	22		33-51-11	ALL
4		W3142	0304	22		33-51-11	ALL
5		W3142	0306	20		33-51-11	ALL
6		W3142	0306	20		33-51-11	ALL
7		W3142	0307	20		33-51-11	ALL
8	UNUSED						ALL
9	16	W3142	0309	16		33-51-13	ALL
10		W3142	0308	20		33-51-22	ALL
11		W3142	0316	20		33-51-13	ALL
12		W3142	0310	20		33-51-22	ALL
13	16	W3142	0311	16		33-51-13	ALL
14		W3142	0315	20		33-51-13	ALL
15	UNUSED						ALL
16	16	W3142	0576	16		33-51-13	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W3142	0324	20		33-51-11	ALL
21	UNUSED						ALL
22		W3142	0322	20		33-51-11	ALL
23	UNUSED						ALL
24		W3142	0324	20		33-51-11	ALL
D10717	**790/300/L015**		**PLUG-**				**ALL**
1		W3419	0010	24		23-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10717		**790/300/L015**		**PLUG- (continued)**				**ALL**
	2		W3419	0004	24		23-24-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W3419	0009	24		23-24-11	ALL
	10		W3419	0008	24		23-24-11	ALL
	11		W3419	0032	20		23-24-11	ALL
	12		W3419	0033	20		23-24-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D10719A		***/*/***		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W0121	011CX			34-58-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	=C1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719A		*/*/*		**PLUG- (continued)**				**ALL**
	=C2		W0121	011CO			34-58-11	ALL
	=C3	UNUSED						ALL
	=C4	UNUSED						ALL
D10719B		*/*/*		**PLUG-**				**ALL**
	A01		W0121	2036R	24		34-31-11	ALL
	A02		W0121	2109R	24		34-58-11	ALL
	A03	UNUSED						ALL
	A04		W0121	0037	22		34-31-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0121	2056R	24		34-58-11	ALL
	A09	VP	W0121	2067R	24		34-51-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	B01		W0121	2036B	24		34-31-11	ALL
	B02		W0121	2109B	24		34-58-11	ALL
	B03	UNUSED						ALL
	B04	VP	W0121	0005	22		34-51-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0121	2056B	24		34-58-11	ALL
	B09	VP	W0121	2067B	24		34-51-11	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0121	2055R	24		34-58-11	ALL
	C03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719B		***/*/***		**PLUG- (continued)**				**ALL**
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0121	2055B	24		34-58-11	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0121	0073	24		34-31-11	ALL
	D06	UNUSED						ALL
	D07		W0121	0090	22		34-31-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	E01	VP	W0121	2078R	24		31-65-15	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0121	2059R	24		34-58-11	ALL
	E10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719B	*/*/*		**PLUG- (continued)**				**ALL**
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	VP	W0121	2078B	24		31-65-15	ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09		W0121	2059B	24		34-58-11	ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15		W0121	0039	22		22-11-18	ALL
G01		W0121	2014R	24		34-31-11	ALL
G02		W0121	2112R	24		34-58-11	ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	VP	W0121	2051R	24		34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719B		***/*/***		**PLUG- (continued)**				**ALL**
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	H01		W0121	2014B	24		34-31-11	ALL
	H02		W0121	2112B	24		34-58-11	ALL
	H03	UNUSED						ALL
	H04		W0121	0074	24		34-31-11	ALL
	H05		W0121	0091	22		34-31-11	ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	VP	W0121	2051B	24		34-32-11	ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	J01		W0121	2039R	24		34-31-11	ALL
	J02		W0121	2057R	24		34-58-11	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0121	0092	22		34-31-11	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10		W0121	2504R	24		34-31-11	ALL
	J11	UNUSED						ALL
	K01		W0121	2039B	24		34-31-11	ALL
	K02		W0121	2057B	24		34-58-11	ALL
	K03	UNUSED						ALL
	K04		W0121	0075	24		34-31-11	ALL
	K05	VP	W0121	0023	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719B	*/*/*		**PLUG- (continued)**				**ALL**
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10		W0121	2504B	24		34-31-11	ALL
K11	UNUSED						ALL
1T	UNUSED						ALL
2T	UNUSED						ALL
1TC	UNUSED						ALL
2TC	UNUSED						ALL
1TR	UNUSED						ALL
2TR	UNUSED						ALL
CAP	Y	W0121	016CX			34-32-11	ALL
CAP	Y	W0121	4001B	24		46-13-11	ALL
CAP	Y	W0121	4001G	24		46-13-11	ALL
CAP	Y	W0121	4001R	24		46-13-11	ALL
CAP	Y	W0121	4001Y	24		46-13-11	ALL
DED		W0121	016CO			34-32-11	ALL
DED		W0121	2051ZI			34-32-11	ALL
DED		W0121	2051ZO			34-32-11	ALL
DED		W0121	2067ZI			34-51-11	ALL
DED		W0121	2067ZO			34-51-11	ALL
DED		W0121	2078Z			31-65-15	ALL
DED		W0121	2504ZI			34-31-11	ALL
DED		W0121	4001Z			46-13-11	ALL
PERG	1A	W0121	2014Z			34-31-11	ALL
PERG	1A	W0121	2036Z			34-31-11	ALL
PERG	1A	W0121	2039Z			34-31-11	ALL
PERG	1A	W0121	2055Z			34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10719B		***/*/***		**PLUG- (continued)**				**ALL**
	PERG	1A	W0121	2056Z			34-58-11	ALL
	PERG	1A	W0121	2057Z			34-58-11	ALL
	PERG	1A	W0121	2059Z			34-58-11	ALL
	PERG	1A	W0121	2109Z			34-58-11	ALL
	PERG	1A	W0121	2112Z			34-58-11	ALL
	PERG	1A	W0121	2504ZO			34-31-11	ALL
D10719C		***/*/***		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0121	0035	20		34-31-11	ALL
	8		W0121	0036	20		34-31-11	ALL
	9		W0121	0034	22		34-31-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	DN	W0121	009CX			34-31-11	ALL
	13	DN	W0121	008CX			34-31-11	ALL
	=C12		W0121	009CO			34-31-11	ALL
	=C13		W0121	008CO			34-31-11	ALL
D10721A		***/*/***		**PLUG - MMR-2**				**ALL**
	1	UNUSED						ALL
	2		W0141	004CX			34-58-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	=C1	UNUSED						ALL
	=C2		W0141	004CO			34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721A		*/*/*		**PLUG - MMR-2 (continued)**				**ALL**
	=C3	UNUSED						ALL
	=C4	UNUSED						ALL
D10721B		*/*/*		**PLUG - MMR-2**				**ALL**
	A01		W0141	2306R	24		34-31-21	ALL
	A02		W0141	2095R	24		34-58-21	ALL
	A03	UNUSED						ALL
	A04		W0141	0706	22		34-31-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0141	2502R	24		34-58-21	ALL
	A09	VP	W0141	2093R	24		34-51-21	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	B01		W0141	2306B	24		34-31-21	ALL
	B02		W0141	2095B	24		34-58-21	ALL
	B03	UNUSED						ALL
	B04	VP	W0141	0737	22		34-51-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0141	2502B	24		34-58-21	ALL
	B09	VP	W0141	2093B	24		34-51-21	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0141	2501R	24		34-58-21	ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721B		***/*/***		**PLUG - MMR-2 (continued)**				**ALL**
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0141	2501B	24		34-58-21	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0141	0142	24		34-31-21	ALL
	D06	UNUSED						ALL
	D07		W0141	0731	22		34-31-21	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	E01	VP	W0141	2094R	24		31-65-25	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09		W0141	2041R	24		34-58-21	ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721B	*/*/*		**PLUG - MMR-2 (continued)**				**ALL**
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	VP	W0141	2094B	24		31-65-25	ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09		W0141	2041B	24		34-58-21	ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15		W0141	0064	22		22-11-18	ALL
G01		W0141	2307R	24		34-31-21	ALL
G02		W0141	2096R	24		34-58-21	ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721B		***/*/***		**PLUG - MMR-2 (continued)**				**ALL**
	G11	UNUSED						ALL
	H01		W0141	2307B	24		34-31-21	ALL
	H02		W0141	2096B	24		34-58-21	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0141	0732	22		34-31-21	ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	J01		W0141	2303R	24		34-31-21	ALL
	J02		W0141	2503R	24		34-58-21	ALL
	J03	UNUSED						ALL
	J04		W0141	0143	24		34-31-21	ALL
	J05		W0141	0733	22		34-31-21	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10		W0141	2302R	24		34-31-21	ALL
	J11	UNUSED						ALL
	K01		W0141	2303B	24		34-31-21	ALL
	K02		W0141	2503B	24		34-58-21	ALL
	K03	UNUSED						ALL
	K04		W0141	0144	24		34-31-21	ALL
	K05	VP	W0141	0738	22		34-51-41	ALL
	K06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721B	*/*/*		**PLUG - MMR-2 (continued)**				**ALL**
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10		W0141	2302B	24		34-31-21	ALL
K11	UNUSED						ALL
1T	UNUSED						ALL
2T	UNUSED						ALL
1TC	UNUSED						ALL
2TC	UNUSED						ALL
1TR	UNUSED						ALL
2TR	UNUSED						ALL
CAP	Y	W0141	4001B	24		46-13-11	ALL
CAP	Y	W0141	4001G	24		46-13-11	ALL
CAP	Y	W0141	4001R	24		46-13-11	ALL
CAP	Y	W0141	4001Y	24		46-13-11	ALL
DED		W0141	2093ZI			34-51-21	ALL
DED		W0141	2093ZO			34-51-21	ALL
DED		W0141	2094Z			31-65-25	ALL
DED		W0141	2302ZI			34-31-21	ALL
DED		W0141	4001Z			46-13-11	ALL
PERG	1A	W0141	2041Z			34-58-21	ALL
PERG	1A	W0141	2095Z			34-58-21	ALL
PERG	1A	W0141	2096Z			34-58-21	ALL
PERG	1A	W0141	2302ZO			34-31-21	ALL
PERG	1A	W0141	2303Z			34-31-21	ALL
PERG	1A	W0141	2306Z			34-31-21	ALL
PERG	1A	W0141	2307Z			34-31-21	ALL
PERG	1A	W0141	2501Z			34-58-21	ALL
PERG	1A	W0141	2502Z			34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10721B		***/*/***		**PLUG - MMR-2 (continued)**				**ALL**
	PERG	1A	W0141	2503Z			34-58-21	ALL
D10721C		***/*/***		**PLUG - MMR-2**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0141	0703	20		34-31-21	ALL
	8		W0141	0704	20		34-31-21	ALL
	9		W0141	0702	22		34-31-21	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	DN	W0141	001CX			34-31-21	ALL
	13	DN	W0141	005CX			34-31-21	ALL
	=C12		W0141	001CO			34-31-21	ALL
	=C13		W0141	005CO			34-31-21	ALL
D10724		**P005-06/ /**		**PLUG-**				**ALL**
	1		W2508	5504	24		21-31-11	ALL
	2		W2112	5518	24		21-31-22	ALL
	3	UNUSED						ALL
	4		W2112	5516	24		21-31-22	ALL
	5		W2112	5517	24		21-31-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2112	2002R	24		21-31-22	ALL
	10	UNUSED						ALL
	11		W2112	5514	20		21-31-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10724	**P005-06/ /**		**PLUG- (continued)**				**ALL**
12		W2112	5515	20		21-31-22	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2508	5501	20		21-31-11	ALL
16		W2510	5503	24		21-31-23	ALL
17	UNUSED						ALL
18		W2508	3001R	24		21-31-11	ALL
19	UNUSED						ALL
20		W2112	2001R	24		21-31-22	ALL
21		W2112	2001B	24		21-31-22	ALL
22		W2112	2002B	24		21-31-22	ALL
23	UNUSED						ALL
24		W2508	2001B	22		21-31-11	ALL
25		W2508	2001R	22		21-31-11	ALL
26		W2112	1002	20		21-31-22	ALL
27		W2112	1001	20		21-31-22	ALL
28		W2508	5502	20		21-31-11	ALL
29		W2510	5504	20		21-31-23	ALL
30		W2508	3001B	24		21-31-11	ALL
31		W2508	3001Y	24		21-31-11	ALL
		W2112	1001Z			21-31-22	ALL
		W2112	1002Z			21-31-22	ALL
		W2112	2001Z			21-31-22	ALL
		W2112	2002Z			21-31-22	ALL
		W2112	FRAA			21-31-22	ALL
		W2508	2001Z			21-31-11	ALL
		W2508	3001Z			21-31-11	ALL
		W2508	FRAB			21-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10726		**P005-06/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2218	5503	24		21-31-11	ALL
	9		W2218	6102	24		21-31-23	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2218	5512	24		21-31-25	ALL
	13		W2216	5665	20		33-12-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2218	2102R	24		21-31-23	ALL
	17		W2218	2102B	24		21-31-23	ALL
	18		W2218	5509	20		21-31-23	ALL
	19		W2218	1004	20		21-31-23	ALL
	20		W2112	5511	20		21-31-22	ALL
	21		W2112	5512	20		21-31-22	ALL
	22		W2508	5571	20		33-18-36	ALL
	23	UNUSED						ALL
	24		W2216	5664	20		33-12-11	ALL
	25	UNUSED						ALL
	26		W2510	5506	22		21-43-21	ALL
	27		W2510	5505	24		21-43-21	ALL
	28		W2218	2101R	24		21-31-23	ALL
	29		W2218	2101B	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10726		**P005-06/ /**		**PLUG- (continued)**				**ALL**
	30		W2218	5510	20		21-31-23	ALL
	31		W2218	1001	20		21-31-23	ALL
			W2218	1001Z			21-31-23	ALL
			W2218	1004Z			21-31-23	ALL
			W2218	2101Z			21-31-23	ALL
			W2218	2102Z			21-31-23	ALL
			W2218	FRAA			21-31-23	ALL
D10727A		***/ /**		**PLUG**				**ALL**
	A01		W0411	2069B	22		23-27-39	ALL
	A02		W0411	2069R	22		23-27-39	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0411	2611R	24		23-27-37	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0411	2614R	24		23-27-37	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0411	0300	22		23-27-38	ALL
	B01		W0411	2070R	22		23-27-39	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0411	2611B	24		23-27-37	ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727A		***/ /**		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0411	2614B	24		23-27-37	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0411	0301	22		23-27-38	ALL
	C01		W0411	3026Y	22		23-27-39	ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15		W0411	0303	22		23-27-38	ALL
	D01		W0411	2068B	22		23-27-39	ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0411	2619R	24		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727A		***/ /**		**PLUG (continued)**				**ALL**
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11		W0411	0159	24		23-27-31	ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0411	3026B	22		23-27-39	ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05		W0411	2619B	24		31-32-15	ALL
	E06		W0411	0306	24		23-27-39	ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	VP	W0411	2601R	24		31-35-02	ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727A		***/ /**		**PLUG (continued)**				**ALL**
	F05	UNUSED						ALL
	F06		W0411	2618R	24		23-27-39	ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	VP	W0411	2601B	24		31-35-02	ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06		W0411	2618B	24		23-27-39	ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	VP	W0411	0089	22		23-27-31	ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15		W0411	0304	22		23-27-38	ALL
	H01		W0411	3026R	22		23-27-39	ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727A	***/ /**		**PLUG (continued)**				**ALL**
H04	UNUSED						ALL
H05	UNUSED						ALL
H06		W0411	2662R	24		23-15-15	ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09		W0411	0099	22		23-27-31	ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13		W0411	2610R	24		23-27-37	ALL
H14	UNUSED						ALL
H15		W0411	0305	22		23-27-38	ALL
J01		W0411	2070B	22		23-27-39	ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06		W0411	2662B	24		23-15-15	ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13		W0411	2610B	24		23-27-37	ALL
J14	UNUSED						ALL
J15		W0411	0302	22		23-27-38	ALL
K01		W0411	2068R	22		23-27-39	ALL
K02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727A		***/ /**		**PLUG (continued)**				**ALL**
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15		W0411	0345	22		23-27-38	ALL
	DED		W0411	2601Z			31-35-02	ALL
	PERG	1A	W0411	2068Z			23-27-39	ALL
	PERG	1A	W0411	2069Z			23-27-39	ALL
	PERG	1A	W0411	2070Z			23-27-39	ALL
	PERG	1A	W0411	2610Z			23-27-37	ALL
	PERG	1A	W0411	2611Z			23-27-37	ALL
	PERG	1A	W0411	2614Z			23-27-37	ALL
	PERG	1A	W0411	2618Z			23-27-39	ALL
	PERG	1A	W0411	2619Z			31-32-15	ALL
	PERG	1A	W0411	2662Z			23-15-15	ALL
	PERG	1A	W0411	3026Z			23-27-39	ALL
D10727B		***/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B	***/ /**		**PLUG (continued)**				**ALL**
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W0411	2661R	24		34-45-21	ALL
A11	UNUSED						ALL
A12		W0411	2612R	24		23-27-37	ALL
A13	UNUSED						ALL
A14		W0411	2621R	24		34-61-23	ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W0411	2661B	24		34-45-21	ALL
B11	UNUSED						ALL
B12		W0411	2612B	24		23-27-37	ALL
B13	UNUSED						ALL
B14		W0411	2621B	24		34-61-23	ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B		***/ /**		**PLUG (continued)**				**ALL**
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0411	2613R	24		23-27-37	ALL
	C08		W0411	2660R	24		34-45-21	ALL
	C09	VP	W0411	0296	22		23-27-31	ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12		W0411	2620R	24		34-61-23	ALL
	C13	UNUSED						ALL
	C14		W0411	2728R	24		46-13-11	ALL
	C15		W0411	2737R	24		23-27-35	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0411	2613B	24		23-27-37	ALL
	D08		W0411	2660B	24		34-45-21	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12		W0411	2620B	24		34-61-23	ALL
	D13	UNUSED						ALL
	D14		W0411	2728B	24		46-13-11	ALL
	D15		W0411	2737B	24		23-27-35	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B	***/ /**		**PLUG (continued)**				**ALL**
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08	UNUSED						ALL
E09	UNUSED						ALL
E10	UNUSED						ALL
E11		W0411	2602R	24		31-35-02	ALL
E12		W0411	2608R	24		23-27-33	ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15		W0411	2604R	24		23-27-32	ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	VP	W0411	0298	22		23-27-31	ALL
F10	UNUSED						ALL
F11		W0411	2602B	24		31-35-02	ALL
F12		W0411	2608B	24		23-27-33	ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15		W0411	2604B	24		23-27-32	ALL
G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B		***/ /**		**PLUG (continued)**				**ALL**
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	VP	W0411	0297	22		23-27-31	ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13		W0411	2631R	24		34-61-21	ALL
	G14	UNUSED						ALL
	G15		W0411	2634R	24		23-27-34	ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13		W0411	2631B	24		34-61-21	ALL
	H14	UNUSED						ALL
	H15		W0411	2634B	24		23-27-34	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B	***/ /**		**PLUG (continued)**				**ALL**
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0411	2617R	24		23-27-38	ALL
J11	UNUSED						ALL
J12		W0411	2599R	24		31-33-01	ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15		W0411	2632R	24		34-61-21	ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10		W0411	2617B	24		23-27-38	ALL
K11	UNUSED						ALL
K12		W0411	2599B	24		31-33-01	ALL
K13	UNUSED						ALL
K14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727B		***/ /**		**PLUG (continued)**				**ALL**
	K15		W0411	2632B	24		34-61-21	ALL
	PERG	1A	W0411	2599Z			31-33-01	ALL
	PERG	1A	W0411	2602Z			31-35-02	ALL
	PERG	1A	W0411	2604Z			23-27-32	ALL
	PERG	1A	W0411	2608Z			23-27-33	ALL
	PERG	1A	W0411	2612Z			23-27-37	ALL
	PERG	1A	W0411	2613Z			23-27-37	ALL
	PERG	1A	W0411	2617Z			23-27-38	ALL
	PERG	1A	W0411	2620Z			34-61-23	ALL
	PERG	1A	W0411	2621Z			34-61-23	ALL
	PERG	1A	W0411	2631Z			34-61-21	ALL
	PERG	1A	W0411	2632Z			34-61-21	ALL
	PERG	1A	W0411	2634Z			23-27-34	ALL
	PERG	1A	W0411	2660Z			34-45-21	ALL
	PERG	1A	W0411	2661Z			34-45-21	ALL
	PERG	1A	W0411	2728Z			46-13-11	ALL
	PERG	1A	W0411	2737Z			23-27-35	ALL
D10727C		**E004-01/ /**		**PLUG**				**ALL**
	1		W0411	0292	22		23-27-31	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0411	0293	20		23-27-31	ALL
	8		W0411	0294	20		23-27-31	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10727C	**E004-01/ /**		**PLUG (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
=C12	UNUSED						ALL
=C13	UNUSED						ALL
D10728	**973/183/R13**		**PLUG-FEEDBACK MODULE (OFV)**				**ALL**
A		W6102	3001Y	24		21-31-22	ALL
B		W6102	3001B	24		21-31-22	ALL
C		W6102	3001R	24		21-31-22	ALL
D		W6102	2003B	24		21-31-22	ALL
E		W6102	2003R	24		21-31-22	ALL
F		W6102	3002R	24		21-31-11	ALL
G		W6102	3002Y	24		21-31-11	ALL
H		W6102	3002B	24		21-31-11	ALL
J		W6102	5503	20		21-31-22	ALL
K	UNUSED						ALL
D10730	**972/190/R15**		**PLUG-MANUAL DC MOTOR (OFC)**				**ALL**
A		W6102	2004R	22		21-31-11	ALL
B		W6102	2004B	22		21-31-11	ALL
C	UNUSED						ALL
D		W6102	5507	20		21-31-11	ALL
E	UNUSED						ALL
F	UNUSED						ALL
D10732	**980/190/R013**		**PLUG-ELECTRONIC ACTUATOR NO.1 (OFV)**				**ALL**
A		W6102	3001Y	24		21-31-22	ALL
B		W6102	3001B	24		21-31-22	ALL
C		W6102	3001R	24		21-31-22	ALL
D	UNUSED						ALL
E		W6102	2003B	24		21-31-22	ALL
F		W6102	2003R	24		21-31-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10732		**980/190/R013**		**PLUG-ELECTRONIC ACTUATOR NO.1 (OFV) (continued)**				**ALL**
	G		W6102	5504	20		21-31-22	ALL
	H	UNUSED						ALL
	J		W6102	5506	20		21-31-22	ALL
	K		W6102	5501	20		21-31-22	ALL
	L		W6102	1001	20		21-31-22	ALL
	M		W6102	2002B	24		21-31-22	ALL
	N		W6102	2002R	24		21-31-22	ALL
	P		W6102	2001B	24		21-31-22	ALL
	R		W6102	2001R	24		21-31-22	ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	A-	UNUSED						ALL
	B-		W6102	5505	20		21-31-22	ALL
	C-		W6102	5502	24		21-31-22	ALL
D10734		**978/190/R14**		**PLUG-ELECTRONIC ACTUATOR NO.2 (OFV)**				**ALL**
	A		W6204	3001Y	24		21-31-23	ALL
	B		W6204	3001B	24		21-31-23	ALL
	C		W6204	3001R	24		21-31-23	ALL
	D	UNUSED						ALL
	E		W6204	2003B	24		21-31-23	ALL
	F		W6204	2003R	24		21-31-23	ALL
	G		W6204	5504	20		21-31-23	ALL
	H	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10734	**978/190/R14**		**PLUG-ELECTRONIC ACTUATOR NO.2 (OFV) (continued)**				**ALL**
J		W6204	5506	20		21-31-23	ALL
K		W6204	5501	20		21-31-23	ALL
L		W6204	1001	20		21-31-23	ALL
M		W6204	2002B	24		21-31-23	ALL
N		W6204	2002R	24		21-31-23	ALL
P		W6204	2001B	24		21-31-23	ALL
R		W6204	2001R	24		21-31-23	ALL
S	UNUSED						ALL
T	UNUSED						ALL
U	UNUSED						ALL
V	UNUSED						ALL
W	UNUSED						ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z	UNUSED						ALL
A-	UNUSED						ALL
B-		W6204	5505	20		21-31-23	ALL
C-		W6204	5502	24		21-31-23	ALL
D10736	**974/185/R12**		**PLUG-FEEDBACK MODULE (OFV)**				**ALL**
A		W6204	3001Y	24		21-31-23	ALL
B		W6204	3001B	24		21-31-23	ALL
C		W6204	3001R	24		21-31-23	ALL
D	UNUSED						ALL
E		W6204	2003B	24		21-31-23	ALL
F		W6204	2003R	24		21-31-23	ALL
G	UNUSED						ALL
H		W6204	5503	20		21-31-23	ALL
J	UNUSED						ALL
K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10736	**974/185/R12**		**PLUG-FEEDBACK MODULE (OFV) (continued)**				**ALL**
L	UNUSED						ALL
M	UNUSED						ALL
D10738A	**E002-02/ /**		**PLUG**				**ALL**
A01		W0220	2009R	24		21-31-22	ALL
A02		W0220	2009B	24		21-31-22	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0220	2201R	24		31-35-04	ALL
A06		W0220	2201B	24		31-35-04	ALL
A07		W0220	2010R	24		21-31-22	ALL
A08		W0220	2010B	24		21-31-22	ALL
A09		W0220	2011R	24		21-31-22	ALL
A10		W0220	2011B	24		21-31-22	ALL
A11		W0220	0056	24		21-31-22	ALL
A12	UNUSED						ALL
A13		W0220	0054	24		21-31-22	ALL
A14	UNUSED						ALL
A15		W0220	0068	24		21-31-24	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10738A		**E002-02/ /**		**PLUG (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0220	0069	24		21-31-24	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10738A		**E002-02/ /**		**PLUG (continued)**				**ALL**
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15		W0220	1003	22		21-31-22	ALL
	PERG	1A	W0220	1003Z			21-31-22	ALL
	PERG	1A	W0220	2009Z			21-31-22	ALL
	PERG	1A	W0220	2010Z			21-31-22	ALL
	PERG	1A	W0220	2011Z			21-31-22	ALL
	PERG	1A	W0220	2201Z			31-35-04	ALL
D10738B		**E002-02/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0220	2015R	24		21-31-24	ALL
	A04		W0220	2015B	24		21-31-24	ALL
	A05		W0220	2014R	24		21-31-24	ALL
	A06		W0220	2014B	24		21-31-24	ALL
	A07		W0220	2008R	24		21-31-22	ALL
	A08		W0220	2008B	24		21-31-22	ALL
	A09		W0220	2013R	24		21-31-24	ALL
	A10		W0220	2013B	24		21-31-24	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0220	2012R	24		21-31-24	ALL
	A14		W0220	2012B	24		21-31-24	ALL
	A15		W0220	0061	22		21-31-22	ALL
	B01		W0220	0072	24		21-31-24	ALL
	B02		W0220	0066	24		21-31-24	ALL
	B03		W0220	0046	24		21-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10738B	**E002-02/ /**		**PLUG (continued)**				**ALL**
B04		W0220	0073	24		21-31-24	ALL
B05		W0220	0058	24		21-31-22	ALL
B06		W0220	0065	24		21-31-24	ALL
B07		W0220	0053	24		21-31-22	ALL
B08	UNUSED						ALL
B09		W0220	0074	24		21-31-24	ALL
B10		W0220	0314	24		21-31-22	ALL
B11	UNUSED						ALL
B12		W0220	0070	24		21-31-24	ALL
B13		W0220	0071	24		21-31-24	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11		W0220	0059	22		21-31-22	ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10738B		**E002-02/ /**		**PLUG (continued)**				**ALL**
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0220	0315	24		21-31-22	ALL
	D08		W0220	0238	22		21-31-22	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	PERG	1A	W0220	2008Z			21-31-22	ALL
	PERG	1A	W0220	2012Z			21-31-24	ALL
	PERG	1A	W0220	2013Z			21-31-24	ALL
	PERG	1A	W0220	2014Z			21-31-24	ALL
	PERG	1A	W0220	2015Z			21-31-24	ALL
D10738C		**E002-02/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0220	0051	20		21-31-22	ALL
	3		W0220	0050	20		21-31-22	ALL
	4		W0220	0052	20		21-31-22	ALL
	5	UNUSED						ALL
	=C1	UNUSED						ALL
	=C5	UNUSED						ALL
D10740A		***/*/***		**PLUG-PLATE ASSY**				**ALL**
	A01		W0111	2250R	24		21-31-23	ALL
	A02		W0111	2250B	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10740A	*/*/*		**PLUG-PLATE ASSY (continued)**				**ALL**
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0111	2284R	24		31-35-04	ALL
A06		W0111	2284B	24		31-35-04	ALL
A07		W0111	2251R	24		21-31-23	ALL
A08		W0111	2251B	24		21-31-23	ALL
A09		W0111	2252R	24		21-31-23	ALL
A10		W0111	2252B	24		21-31-23	ALL
A11		W0111	0803	24		21-31-23	ALL
A12	UNUSED						ALL
A13		W0111	0804	24		21-31-23	ALL
A14	UNUSED						ALL
A15		W0111	0857	24		21-31-24	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10740A		***/*/***		**PLUG-PLATE ASSY (continued)**				**ALL**
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0111	0856	24		21-31-24	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15		W0111	1041	22		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10740A		*/*/*		**PLUG-PLATE ASSY (continued)**				**ALL**
	PERG	1A	W0111	1041Z			21-31-23	ALL
	PERG	1A	W0111	2250Z			21-31-23	ALL
	PERG	1A	W0111	2251Z			21-31-23	ALL
	PERG	1A	W0111	2252Z			21-31-23	ALL
	PERG	1A	W0111	2284Z			31-35-04	ALL
D10740B		*/*/*		**PLUG-PLATE ASSY**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0111	2241R	24		21-31-24	ALL
	A04		W0111	2241B	24		21-31-24	ALL
	A05		W0111	2243R	24		21-31-24	ALL
	A06		W0111	2243B	24		21-31-24	ALL
	A07		W0111	2249R	24		21-31-23	ALL
	A08		W0111	2249B	24		21-31-23	ALL
	A09		W0111	2245R	24		21-31-24	ALL
	A10		W0111	2245B	24		21-31-24	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0111	2247R	24		21-31-24	ALL
	A14		W0111	2247B	24		21-31-24	ALL
	A15	UNUSED						ALL
	B01		W0111	0859	24		21-31-24	ALL
	B02		W0111	0850	24		21-31-24	ALL
	B03		W0111	0805	24		21-31-11	ALL
	B04		W0111	0858	24		21-31-24	ALL
	B05		W0111	0863	24		21-31-23	ALL
	B06		W0111	0851	24		21-31-24	ALL
	B07		W0111	0802	24		21-31-23	ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10740B		***/*/***		**PLUG-PLATE ASSY (continued)**				**ALL**
	B09		W0111	0860	24		21-31-24	ALL
	B10		W0111	0806	24		21-31-23	ALL
	B11	UNUSED						ALL
	B12		W0111	0855	24		21-31-24	ALL
	B13		W0111	0853	24		21-31-24	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11		W0111	0798	22		21-31-23	ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15		W0111	0799	22		21-31-23	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0111	0807	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10740B	***/*/***		**PLUG-PLATE ASSY (continued)**				**ALL**
D08		W0111	0811	22		21-31-23	ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14	UNUSED						ALL
D15	UNUSED						ALL
PERG	1A	W0111	2241Z			21-31-24	ALL
PERG	1A	W0111	2243Z			21-31-24	ALL
PERG	1A	W0111	2245Z			21-31-24	ALL
PERG	1A	W0111	2247Z			21-31-24	ALL
PERG	1A	W0111	2249Z			21-31-23	ALL
D10740C	***/*/***		**PLUG-PLATE ASSY**				**ALL**
1	UNUSED						ALL
2		W0111	0796	20		21-31-23	ALL
3		W0111	0866	20		21-31-23	ALL
4		W0111	0797	20		21-31-23	ALL
5	UNUSED						ALL
=C1	UNUSED						ALL
=C5	UNUSED						ALL
D10744	**952/290/R014**		**PLUG-**				**ALL**
1	16	W4142	0401	16		33-51-11	ALL
2		W4142	0402	20		33-51-11	ALL
3		W4142	0403	22		33-51-11	ALL
4		W4142	0404	22		33-51-11	ALL
5		W4142	0406	20		33-51-11	ALL
6		W4142	0406	20		33-51-11	ALL
7		W4142	0407	20		33-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10744		**952/290/R014**		**PLUG- (continued)**				**ALL**
	8	UNUSED						ALL
	9		W4142	0409	20		33-51-14	ALL
	10		W4142	0412	20		33-51-22	ALL
	11		W4142	0411	20		33-51-14	ALL
	12	UNUSED						ALL
	13	16	W4142	0413	16		33-51-14	ALL
	14		W4142	0628	20		33-51-14	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W4142	0424	20		33-51-11	ALL
	21	UNUSED						ALL
	22		W4142	0422	20		33-51-11	ALL
	23	UNUSED						ALL
	24		W4142	0424	20		33-51-11	ALL
	CAP	Y	W4142	0037	20		SPARE	ALL
	CAP	Y	W4142	0039	20		SPARE	ALL
D10746		**952/290/L014**		**PLUG-**				**ALL**
	1	16	W3142	0401	16		33-51-11	ALL
	2		W3142	0402	20		33-51-11	ALL
	3		W3142	0403	22		33-51-11	ALL
	4		W3142	0404	22		33-51-11	ALL
	5		W3142	0406	20		33-51-11	ALL
	6		W3142	0406	20		33-51-11	ALL
	7		W3142	0407	20		33-51-11	ALL
	8	UNUSED						ALL
	9		W3142	0409	20		33-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10746	**952/290/L014**		**PLUG- (continued)**				**ALL**
10		W3142	0412	20		33-51-22	ALL
11		W3142	0411	20		33-51-14	ALL
12	16	W3142	0091	16		33-51-22	ALL
13		W3142	0413	20		33-51-14	ALL
14		W3142	0414	20		33-51-22	ALL
15	UNUSED						ALL
16		W3142	0416	20		33-51-14	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W3142	0424	20		33-51-11	ALL
21	UNUSED						ALL
22		W3142	0422	20		33-51-11	ALL
23	UNUSED						ALL
24		W3142	0424	20		33-51-11	ALL
CAP	Y	W3142	0038	20		SPARE	ALL
CAP	Y	W3142	0039	20		SPARE	ALL
D10750	**322/291/L007**		**PLUG-**				**ALL**
1	16	W4142	0101	16		33-51-11	ALL
2		W4142	0102	20		33-51-11	ALL
3		W4142	0103	22		33-51-11	ALL
4		W4142	0104	22		33-51-11	ALL
5		W4142	0106	20		33-51-11	ALL
6		W4142	0106	20		33-51-11	ALL
7		W4142	0107	20		33-51-11	ALL
8	UNUSED						ALL
9		W4142	0109	20		33-51-12	ALL
10	UNUSED						ALL
11		W4142	0111	20		33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10750		**322/291/L007**		**PLUG- (continued)**				**ALL**
	12		W4142	0110	20		33-51-21	ALL
	13		W4142	0113	20		33-51-12	ALL
	14		W4142	0114	20		33-51-12	ALL
	15		W4142	0112	20		33-51-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W4142	0124	20		33-51-11	ALL
	21	UNUSED						ALL
	22		W4142	0122	20		33-51-11	ALL
	23	UNUSED						ALL
	24		W4142	0124	20		33-51-11	ALL
D10762		**P006-00/ /**		**PLUG**				**ALL**
	A1	UNUSED						ALL
	A2		W0044	0458	24		21-31-25	ALL
	A3		W0044	0457	24		21-31-25	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0044	0109	20		33-18-11	ALL
	X2		W0044	0110	20		33-18-11	ALL
D10770		**975/297/R010**		**PLUG-**				**ALL**
	1		W3144	5502	22		21-42-11	ALL
	2		W3144	5504	22		21-42-11	ALL
	3		W3144	5501	22		21-42-11	ALL
	4		W3144	5503	20		21-42-11	ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10820		**P006-00/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0044	0444	20		21-31-11	ALL
	3		W0044	0443	24		21-31-11	ALL
	4		W0044	0446	24		21-31-22	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0044	0442	20		21-31-11	ALL
	8	UNUSED						ALL
D10822		**P006-00/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0044	0446	24		21-31-22	ALL
	3		W0044	0450	20		21-31-22	ALL
	4		W0044	0447	24		21-31-22	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0044	0448	24		21-31-22	ALL
	8	UNUSED						ALL
D10824		**P006-00/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0044	0447	24		21-31-22	ALL
	3		W0044	0454	22		21-31-23	ALL
	4		W0044	0449	24		21-31-22	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0044	0920	24		21-31-23	ALL
	8	UNUSED						ALL
D10845		**FIN 73.5/285/L007**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W7102	1001	20		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10845		**FIN 73.5/285/L007**		**RCPT- (continued)**				**ALL**
	3	UNUSED						ALL
	4		W7102	2003B	20		31-31-14	ALL
	5		W7102	2003R	20		31-31-14	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	DED		W7102	1001Z			31-31-14	ALL
	DED		W7102	2003Z			31-31-14	ALL
D10853		**P002-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	S/R		W2205	1001Z			34-24-15	ALL
	S/R		W2205	2011Z			34-21-13	ALL
	S/R		W2205	2013Z			34-31-11	ALL
	A		W2205	2013R	24		34-31-11	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D		W2205	1001	20		34-24-15	ALL
	E		W2205	0039	20		34-24-15	ALL
	F	UNUSED						ALL
	G		W2205	0022	22		34-24-15	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S		W2205	2011B	24		34-21-13	ALL
	T		W2205	2011R	24		34-21-13	ALL
	U	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10853	**P002-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
V	UNUSED						ALL
W		W2205	2013B	24		34-31-11	ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z	UNUSED						ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-		W2205	0023	22		34-24-15	ALL
E-	UNUSED						ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-	UNUSED						ALL
I-		W2205	0011	20		33-11-32	ALL
J-		W2205	0010	20		33-11-32	ALL
K-		W2205	0024	22		34-24-15	ALL
M-	UNUSED						ALL
N-	UNUSED						ALL
P-	UNUSED						ALL
Q-	UNUSED						ALL
R-	UNUSED						ALL
S-	UNUSED						ALL
T-		W2205	0040	20		34-24-15	ALL
D10878	**821/205/L019**		**PLUG-**				**ALL**
1		W3154	0037	20		25-51-21	ALL
2		W3154	0038	20		25-51-21	ALL
3		W3154	0031	22		25-51-21	ALL
4		W3154	0032	22		25-51-21	ALL
5		W3154	0033	22		25-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10878		**821/205/L019**		**PLUG- (continued)**				**ALL**
	6		W3154	0040	22		25-51-21	ALL
	7		W3154	0034	22		25-51-21	ALL
	8		W3154	0035	22		25-51-21	ALL
	9		W3154	0036	22		25-51-21	ALL
	10		W3154	2001B	24		25-51-21	ALL
	11		W3154	2001W	24		25-51-21	ALL
	12		W3154	2001Z			25-51-21	ALL
D10884		**273/190/L022**		**PLUG-**				**ALL**
	1		W6110	5510	20		21-42-11	ALL
	2	UNUSED						ALL
	3		W6110	5509	20		21-42-11	ALL
	4		W6110	5513	20		21-42-11	ALL
	5	UNUSED						ALL
D10890A		**E002-01/ /**		**PLUG-**				**ALL**
	1		W0212	2010R	22		24-23-11	ALL
	2	UNUSED						ALL
	3		W0212	3001R	18		24-21-11	ALL
	4		W0212	3001Y	18		24-21-11	ALL
	5		W0212	3001B	18		24-21-11	ALL
	6	UNUSED						ALL
	7		W0212	4001R	20		24-21-11	ALL
	8	UNUSED						ALL
	9		W0212	0068	22		24-23-11	ALL
	10		W0212	2010B	22		24-23-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0212	4001Y	20		24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10890A	**E002-01/ /**		**PLUG- (continued)**				**ALL**
16		W0212	4001B	20		24-21-11	ALL
17		W0212	4001G	20		24-21-11	ALL
18		W0212	0020	22		24-22-11	ALL
19		W0212	0019	22		24-22-11	ALL
20		W0212	0021	22		24-22-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0212	3003R	20		24-22-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W0212	0067	24		31-65-14	ALL
34	UNUSED						ALL
35		W0212	3003Y	20		24-22-11	ALL
36		W0212	3003B	20		24-22-11	ALL
37	UNUSED						ALL
38		W0212	4004R	22		24-24-11	ALL
39		W0212	4004Y	22		24-24-11	ALL
40	UNUSED						ALL
41		W0212	4003R	22		24-24-11	ALL
42		W0212	4003Y	22		24-24-11	ALL
43		W0212	2004B	22		24-22-11	ALL
44	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10890A		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	45	UNUSED						ALL
	46		W0212	0017	22		24-22-11	ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51		W0212	4004B	22		24-24-11	ALL
	52		W0212	4004G	22		24-24-11	ALL
	53		W0212	4003G	22		24-24-11	ALL
	54		W0212	4003B	22		24-24-11	ALL
	55		W0212	2004R	22		24-22-11	ALL
	56	UNUSED						ALL
	57		W0212	0018	22		24-22-11	ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61		W0212	0010	22		24-11-11	ALL
	62	UNUSED						ALL
	63	UNUSED						ALL
	64	UNUSED						ALL
	65	UNUSED						ALL
	66	UNUSED						ALL
	67	UNUSED						ALL
D10890B		**E002-01/ /**		**PLUG-**				**ALL**
	1		W0212	0013	20		24-11-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0212	0012	20		24-11-11	ALL
	5		W0212	1001	20		24-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10890B	**E002-01/ /**		**PLUG- (continued)**				**ALL**
6		W0212	2005R	22		24-22-11	ALL
7		W0212	2039R	22		24-23-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0212	2005B	22		24-22-11	ALL
15		W0212	2001B	22		24-11-11	ALL
16	UNUSED						ALL
17		W0212	2039B	22		24-23-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W0212	1003	24		24-28-41	ALL
26	UNUSED						ALL
27		W0212	2001R	22		24-11-11	ALL
28	UNUSED						ALL
29		W0212	0024	22		24-22-11	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10890B		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W0212	2020R	22		24-22-11	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W0212	2012R	22		24-28-11	ALL
	48	UNUSED						ALL
	49		W0212	2020B	22		24-22-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53		W0212	3006B	20		24-23-11	ALL
	54		W0212	3006Y	20		24-23-11	ALL
	55		W0212	2002R	20		24-21-11	ALL
	56		W0212	2002B	20		24-21-11	ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60		W0212	2012B	22		24-28-11	ALL
	61	UNUSED						ALL
	62		W0212	3002B	22		24-22-11	ALL
	63		W0212	3002Y	22		24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10890B	**E002-01/ /**		**PLUG- (continued)**				**ALL**
64		W0212	3002R	22		24-22-11	ALL
65	UNUSED						ALL
66		W0212	3006R	20		24-23-11	ALL
67	UNUSED						ALL
D10892A	***/*/***		**PLUG**				**ALL**
1		W0422	2006R	22		24-23-21	ALL
2	UNUSED						ALL
3		W0422	3001R	18		24-21-21	ALL
4		W0422	3001Y	18		24-21-21	ALL
5		W0422	3001B	18		24-21-21	ALL
6	UNUSED						ALL
7		W0422	4001R	20		24-21-21	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0422	2006B	22		24-23-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0422	4001Y	20		24-21-21	ALL
16		W0422	4001B	20		24-21-21	ALL
17		W0422	4001G	20		24-21-21	ALL
18		W0422	0091	22		24-22-21	ALL
19		W0422	0090	22		24-22-21	ALL
20		W0422	0092	22		24-22-21	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0422	3003R	20		24-22-21	ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10892A		***/*/***		**PLUG (continued)**				**ALL**
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W0422	0147	24		31-65-24	ALL
	34	UNUSED						ALL
	35		W0422	3003Y	20		24-22-21	ALL
	36		W0422	3003B	20		24-22-21	ALL
	37	UNUSED						ALL
	38		W0422	4003R	22		24-24-21	ALL
	39		W0422	4003Y	22		24-24-21	ALL
	40	UNUSED						ALL
	41		W0422	4002R	22		24-24-21	ALL
	42		W0422	4002Y	22		24-24-21	ALL
	43		W0422	2003R	22		24-22-21	ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46		W0422	0088	22		24-22-21	ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51		W0422	4003B	22		24-24-21	ALL
	52		W0422	4003G	22		24-24-21	ALL
	53		W0422	4002G	22		24-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10892A	***/*/***		**PLUG (continued)**				**ALL**
54		W0422	4002B	22		24-24-21	ALL
55		W0422	2003B	22		24-22-21	ALL
56	UNUSED						ALL
57		W0422	0089	22		24-22-21	ALL
58	UNUSED						ALL
59	UNUSED						ALL
60	UNUSED						ALL
61		W0422	0081	22		24-11-21	ALL
62	UNUSED						ALL
63	UNUSED						ALL
64	UNUSED						ALL
65	UNUSED						ALL
66	UNUSED						ALL
67	UNUSED						ALL
D10892B	***/*/***		**PLUG**				**ALL**
1		W0422	0084	20		24-11-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0422	0083	20		24-11-21	ALL
5		W0422	1014	20		24-11-21	ALL
6		W0422	2019B	22		24-22-21	ALL
7		W0422	1012	22		24-23-21	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0422	2019R	22		24-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10892B		***/*/***		**PLUG (continued)**				**ALL**
	15		W0422	2004B	22		24-11-21	ALL
	16	UNUSED						ALL
	17		W0422	1013	22		24-23-21	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0422	1009	24		24-28-41	ALL
	26	UNUSED						ALL
	27		W0422	2004R	22		24-11-21	ALL
	28	UNUSED						ALL
	29		W0422	0093	22		24-22-21	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W0422	2429R	22		24-22-21	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10892B	***/*/***		**PLUG (continued)**				**ALL**
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W0422	2008R	22		24-28-11	ALL
48	UNUSED						ALL
49		W0422	2429B	22		24-22-21	ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53		W0422	3004B	20		24-23-21	ALL
54		W0422	3004Y	20		24-23-21	ALL
55		W0422	2002R	20		24-21-21	ALL
56		W0422	2002B	20		24-21-21	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60		W0422	2008B	22		24-28-11	ALL
61	UNUSED						ALL
62		W0422	3002B	22		24-22-21	ALL
63		W0422	3002Y	22		24-22-21	ALL
64		W0422	3002R	22		24-22-21	ALL
65	UNUSED						ALL
66		W0422	3004R	20		24-23-21	ALL
67	UNUSED						ALL
D10896A	**E002-01/ /**		**PLUG**				**ALL**
1		W0212	2008R	22		24-22-31	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10896A		**E002-01/ /**		**PLUG (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0212	4002R	20		24-21-31	ALL
	8		W0212	0016	22		24-21-31	ALL
	9	UNUSED						ALL
	10		W0212	2008B	22		24-22-31	ALL
	11		W0212	0066	22		24-22-31	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0212	4002Y	20		24-21-31	ALL
	16		W0212	4002B	20		24-21-31	ALL
	17		W0212	4002G	20		24-21-31	ALL
	18		W0212	0030	22		24-22-31	ALL
	19	UNUSED						ALL
	20		W0212	0031	22		24-22-31	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W0212	3005R	20		24-22-31	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0212	0079	22		24-22-31	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10896A	**E002-01/ /**		**PLUG (continued)**				**ALL**
34	UNUSED						ALL
35		W0212	3005Y	20		24-22-31	ALL
36		W0212	3005B	20		24-22-31	ALL
37	UNUSED						ALL
38		W0212	4005R	22		24-24-31	ALL
39		W0212	4005Y	22		24-24-31	ALL
40	UNUSED						ALL
41		W0212	4006R	20		24-24-31	ALL
42		W0212	4006Y	20		24-24-31	ALL
43		W0212	2007R	22		24-22-31	ALL
44		W0212	2009R	22		24-22-31	ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51		W0212	4005B	22		24-24-31	ALL
52		W0212	4005G	22		24-24-31	ALL
53		W0212	4006G	20		24-24-31	ALL
54		W0212	4006B	20		24-24-31	ALL
55		W0212	2007B	22		24-22-31	ALL
56		W0212	2009B	22		24-22-31	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59		W0212	0014	22		24-21-31	ALL
60		W0212	0015	22		24-21-31	ALL
61	UNUSED						ALL
62	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10896A		**E002-01/ /**		**PLUG (continued)**				**ALL**
	63	UNUSED						ALL
	64	UNUSED						ALL
	65	UNUSED						ALL
	66	UNUSED						ALL
	67	UNUSED						ALL
	DED		W0212	2007Z			24-22-31	ALL
	DED		W0212	2008Z			24-22-31	ALL
	DED		W0212	3005Z			24-22-31	ALL
D10896B		**E002-01/ /**		**PLUG**				**ALL**
	1		W0212	0027	22		24-22-31	ALL
	2	UNUSED						ALL
	3		W0212	0032	18		24-22-31	ALL
	4		W0212	0026	22		24-22-31	ALL
	5		W0212	0025	20		24-22-31	ALL
	6		W0212	0069	22		24-22-31	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0212	2003B	22		24-21-31	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0212	0069	22		24-22-31	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10896B	**E002-01/ /**		**PLUG (continued)**				**ALL**
21		W0212	2003R	22		24-21-31	ALL
22	UNUSED						ALL
23		W0212	0034	22		24-22-31	ALL
24		W0212	0035	22		24-22-31	ALL
25		W0212	0039	24		24-28-41	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W0212	0028	22		24-22-31	ALL
37		W0212	0036	22		24-22-31	ALL
38		W0212	0033	22		24-22-31	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W0212	2011R	22		24-28-11	ALL
48	UNUSED						ALL
49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10896B		**E002-01/ /**		**PLUG (continued)**				**ALL**
	50		W0212	3004R	22		24-22-31	ALL
	51		W0212	3004Y	22		24-22-31	ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60		W0212	2011B	22		24-28-11	ALL
	61	UNUSED						ALL
	62		W0212	2006B	22		24-22-31	ALL
	63		W0212	3004B	22		24-22-31	ALL
	64		W0212	2006R	22		24-22-31	ALL
	65	UNUSED						ALL
	66	UNUSED						ALL
	67	UNUSED						ALL
	DED		W0212	2003Z			24-21-31	ALL
	DED		W0212	2006Z			24-22-31	ALL
	DED		W0212	3004Z			24-22-31	ALL
D10898A		***/*/***		**PLUG**				**ALL**
	1		W0422	2018R	20		24-41-11	ALL
	2		W0422	2018B	20		24-41-11	ALL
	3		W0422	4004R	22		24-41-11	ALL
	4		W0422	4004Y	22		24-41-11	ALL
	5		W0422	4004B	22		24-41-11	ALL
	6	UNUSED						ALL
	7		W0422	4005R	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10898A	*/*/*		**PLUG (continued)**				**ALL**
8		W0422	0141	22		24-41-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0422	4004G	22		24-41-11	ALL
14	UNUSED						ALL
15		W0422	4005Y	22		24-41-11	ALL
16		W0422	4005B	22		24-41-11	ALL
17		W0422	4005G	22		24-41-11	ALL
18		W0422	0107	22		24-23-21	ALL
19		W0422	0104	22		24-23-11	ALL
20		W0422	0106	22		24-23-21	ALL
21		W0422	0103	22		24-23-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W0422	0085	22		24-22-11	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W0422	0184	22		24-22-31	ALL
30		W0422	1016	22		24-23-11	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W0422	0096	22		24-22-21	ALL
36	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10898A		***/*/***		**PLUG (continued)**				**ALL**
	37	UNUSED						ALL
	38		W0422	2017R	22		24-41-11	ALL
	39		W0422	2017B	22		24-41-11	ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44		W0422	2010R	22		24-28-41	ALL
	45	UNUSED						ALL
	46		W0422	3005B	22		24-41-11	ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49		W0422	0139	22		24-41-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W0422	0097	22		24-22-31	ALL
	56		W0422	1013	22		24-23-21	ALL
	57		W0422	2010B	22		24-28-41	ALL
	58		W0422	3005Y	22		24-41-11	ALL
	59		W0422	3005R	22		24-41-11	ALL
	60	UNUSED						ALL
	61		W0422	0140	22		24-41-11	ALL
	62		W0422	0113	22		24-23-51	ALL
	63	UNUSED						ALL
	64	UNUSED						ALL
	65	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10898A	***/*/***		**PLUG (continued)**				**ALL**
66	UNUSED						ALL
67	UNUSED						ALL
D10898B	***/*/***		**PLUG**				**ALL**
1		W0422	0144	20		24-41-11	ALL
2	UNUSED						ALL
3		W0422	1011	20		24-41-11	ALL
4		W0422	0142	20		24-41-11	ALL
5		W0422	1010	20		24-41-11	ALL
6	UNUSED						ALL
7		W0422	0098	22		24-22-31	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0422	0501	20		24-28-41	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0422	0099	22		24-22-31	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0422	0136	22		24-41-11	ALL
21	UNUSED						ALL
22		W0422	2025R	22		24-22-11	ALL
23		W0422	1015	22		24-23-11	ALL
24		W0422	2025B	22		24-22-11	ALL
25	UNUSED						ALL
26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10898B		***/*/***		**PLUG (continued)**				**ALL**
	27		W0422	0123	24		24-28-41	ALL
	28		W0422	2009B	22		24-28-41	ALL
	29		W0422	2005B	22		24-23-11	ALL
	30	UNUSED						ALL
	31		W0422	0115	22		24-28-41	ALL
	32		W0422	0220	22		24-28-41	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W0422	2429R	22		24-22-21	ALL
	36		W0422	1012	22		24-23-21	ALL
	37		W0422	2429B	22		24-22-21	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41		W0422	2009R	22		24-28-41	ALL
	42		W0422	2005R	22		24-23-11	ALL
	43		W0422	0221	22		24-28-41	ALL
	44		W0422	0112	22		24-23-51	ALL
	45		W0422	0118	22		24-28-41	ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W0422	0100	22		24-22-31	ALL
	49	UNUSED						ALL
	50		W0422	1008	24		24-28-41	ALL
	51	UNUSED						ALL
	52		W0422	0154	20		22-11-11	ALL
	53		W0422	2007B	22		24-23-51	ALL
	54		W0422	2014R	22		24-41-11	ALL
	55	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10898B	*/*/*		**PLUG (continued)**				**ALL**
56		W0422	0222	24		24-28-41	ALL
57		W0422	0223	24		24-28-41	ALL
58	UNUSED						ALL
59	UNUSED						ALL
60	UNUSED						ALL
61		W0422	0121	24		24-28-41	ALL
62	UNUSED						ALL
63		W0422	1009	24		24-28-41	ALL
64	UNUSED						ALL
65		W0422	0157	20		22-11-11	ALL
66		W0422	2007R	22		24-23-51	ALL
67		W0422	2014B	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10912		**AB1088/229/L013**		**RCPT-CONDUCTIVE**				**ALL**
	1	4D	W4726	4502W	20		49-71-21	ALL
	2		W4726	2210R	22		49-52-31	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	4B	W4726	4502G	20		49-71-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W4726	2211R	22		49-52-31	ALL
	9		W4726	2209R	22		49-52-31	ALL
	10		W4726	2210B	22		49-52-31	ALL
	11		W4726	2222R	22		49-62-12	ALL
	12		W4726	2221B	22		49-62-12	ALL
	13		W4726	2227R	22		49-71-21	ALL
	14		W4726	2227B	22		49-71-21	ALL
	15	4D	W4726	4504W	20		49-71-21	ALL
	16	4B	W4726	4504G	20		49-71-21	ALL
	17	UNUSED						ALL
	18		W4726	2220R	22		49-62-12	ALL
	19		W4726	2220B	22		49-62-12	ALL
	20	UNUSED						ALL
	21		W4726	2211B	22		49-52-31	ALL
	22	UNUSED						ALL
	23		W4726	2209B	22		49-52-31	ALL
	24		W4726	2222B	22		49-62-12	ALL
	25	UNUSED						ALL
	26		W4726	2221R	22		49-62-12	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10912	**AB1088/229/L013**		**RCPT-CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W4726	2232R	22		49-94-21	ALL
35	UNUSED						ALL
36		W4726	2232B	22		49-94-21	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
S/R		W4726	2209Z			49-52-31	ALL
S/R		W4726	2210Z			49-52-31	ALL
S/R		W4726	2211Z			49-52-31	ALL
S/R		W4726	2220Z			49-62-12	ALL
S/R		W4726	2221Z			49-62-12	ALL
S/R		W4726	2222Z			49-62-12	ALL
S/R		W4726	2227Z			49-71-21	ALL
S/R		W4726	2232Z			49-94-21	ALL
S/R		W4726	4502Z			49-71-21	ALL
S/R		W4726	4504Z			49-71-21	ALL
D10916	**J00024/ /**		**SOCKET-**				**ALL**
A1		W0080	0010	20		52-71-14	ALL
A2		W0080	6008	24		73-22-31	ALL
A3		W0080	6009	24		73-22-31	ALL
B1	UNUSED						ALL
B2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10916		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	B3	UNUSED						ALL
	C1		W0080	6509	22		31-31-11	ALL
	C2		W0080	6510	22		31-31-11	ALL
	C3	UNUSED						ALL
	D1		W0080	6087	20		47-30-11	ALL
	D2		W0080	6088	20		47-30-11	ALL
	D3		W0080	5622	24		36-11-22	ALL
	X1		W0080	6006	24		73-22-31	ALL
	X2		W0080	0013	24		73-22-31	ALL
D10918		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0124	22		29-23-11	ALL
	A2		W0076	0125	24		73-22-31	ALL
	A3		W0076	0126	24		73-22-31	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1		W0076	0127	22		31-31-11	ALL
	C2		W0076	0128	22		31-31-11	ALL
	C3	UNUSED						ALL
	D1		W0076	0339	20		47-30-11	ALL
	D2		W0076	0338	20		47-30-11	ALL
	D3		W0076	0420	24		36-11-12	ALL
	X1		W0076	0121	24		73-22-31	ALL
	X2		W0076	0122	24		73-22-31	ALL
D10920		**J023-00/ /**		**RELAY SOCKET-**				**ALL**
	A1		W0078	2607R	24		73-21-11	ALL
	A2		W0078	2607B	24		73-21-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10920		**J023-00/ /**		**RELAY SOCKET- (continued)**				**ALL**
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2		W0078	0507	18		24-11-11	ALL
	C3		W0078	0508	18		24-11-11	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0078	6050	24		76-21-11	ALL
	X2		W0078	6009	24		76-21-11	ALL
	Y1		W0078	6051	24		76-21-11	ALL
	Y2		W0078	6008	24		76-21-11	ALL
			W0078	0099	20		73-21-11	ALL
			W0078	2607Z			73-21-11	ALL
D10922		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	2001R	24		73-21-11	ALL
	A2		W0076	2001B	24		73-21-11	ALL
	A3	UNUSED						ALL
	B1		W0076	0136	24		31-31-15	ALL
	B2		W0076	0135	24		31-31-15	ALL
	B3		W0076	0413	20		31-31-15	ALL
	C1	UNUSED						ALL
	C2		W0076	0137	24		76-21-11	ALL
	C3		W0076	0138	20		76-21-11	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0131	24		76-21-11	ALL
	X2		W0076	0132	24		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10922		**J022-00/ /**		**RELAY SOCKET (continued)**				**ALL**
	Y1		W0076	0141	24		76-21-11	ALL
	Y2		W0076	0142	24		76-21-11	ALL
D10924		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1		W0072	2001R	24		73-21-11	ALL
	A2		W0072	2001B	24		73-21-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2		W0072	0105	18		24-11-21	ALL
	C3		W0072	0106	18		24-11-21	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0101	24		76-21-21	ALL
	X2		W0072	0102	24		76-21-21	ALL
	Y1		W0072	0103	24		76-21-21	ALL
	Y2		W0072	0104	24		76-21-21	ALL
D10926		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	2601R	24		73-21-11	ALL
	A2		W0080	2601B	24		73-21-11	ALL
	A3	UNUSED						ALL
	B1		W0080	6502	24		31-31-15	ALL
	B2		W0080	6501	24		31-31-15	ALL
	B3		W0080	6113	20		31-31-15	ALL
	C1	UNUSED						ALL
	C2		W0080	6016	24		76-21-21	ALL
	C3		W0080	6014	20		76-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10926		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	6011	24		76-21-21	ALL
	X2		W0080	6015	24		76-21-21	ALL
	Y1		W0080	6012	24		76-21-21	ALL
	Y2		W0080	6013	24		76-21-21	ALL
D10952		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	1301	20		73-22-11	ALL
	A2		W0080	6002	20		73-22-11	ALL
	A3	UNUSED						ALL
	B1		W0080	1302	20		73-22-11	ALL
	B2		W0080	6001	20		73-22-11	ALL
	B3	UNUSED						ALL
	X1		W0080	6004	24		73-22-11	ALL
	X2		W0080	6003	24		73-22-11	ALL
D10954		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	1001	20		73-22-11	ALL
	A2		W0076	0194	20		73-22-11	ALL
	A3	UNUSED						ALL
	B1		W0076	1002	20		73-22-11	ALL
	B2		W0076	0196	20		73-22-11	ALL
	B3	UNUSED						ALL
	X1		W0076	0191	24		73-22-11	ALL
	X2		W0076	0192	24		73-22-11	ALL
			W0076	0422	20		73-22-11	ALL
			W0076	0423	20		73-22-11	ALL
			W0076	1001Z			73-22-11	ALL
			W0076	1002Z			73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10956		**262/278/L005**		**PLUG-**				**ALL**
	1		W2216	5515	24		21-61-11	ALL
	2		W2216	5517	20		21-61-11	ALL
	3		W2216	5516	20		21-61-11	ALL
D10958		**261/278/L007**		**PLUG-**				**ALL**
	1		W2216	2001B	24		21-61-11	ALL
	2		W2216	2001R	24		21-61-11	ALL
	3		W2216	2002B	24		21-61-12	ALL
	4		W2216	2002R	24		21-61-12	ALL
	5	UNUSED						ALL
D10982		**205/184/R020**		**PLUG-**				**ALL**
	1		W5156	0711	22		32-31-15	ALL
	2		W5156	2206B	20		32-64-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5156	0008	20		52-71-13	ALL
	6		W5156	0708	22		32-31-15	ALL
	7	UNUSED						ALL
	8		W5156	0554	22		32-64-11	ALL
	9		W5156	2206R	20		32-64-11	ALL
	10		W5156	0595	20		22-11-12	ALL
	11		W5156	2213R	22		32-64-11	ALL
	12		W5156	2213B	22		32-64-11	ALL
	13	UNUSED						ALL
	14		W5156	0720	22		27-61-49	ALL
	15		W5156	0582	22		31-53-11	ALL
	16	UNUSED						ALL
	17		W5156	0573	22		32-64-21	ALL
	18	UNUSED						ALL
	19		W5156	2205B	20		32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10982	**205/184/R020**		**PLUG- (continued)**				**ALL**
20		W5156	2205R	20		32-64-11	ALL
21		W5156	0021	20		33-42-21	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5156	0567	22		27-32-11	ALL
25		W5156	0555	22		32-64-11	ALL
26		W5156	0552	22		32-64-11	ALL
27		W5156	0710	22		32-31-15	ALL
28	UNUSED						ALL
29		W5156	0715	22		27-61-49	ALL
30	UNUSED						ALL
31		W5156	0600	22		32-64-21	ALL
32	UNUSED						ALL
33		W5156	2211R	22		32-64-11	ALL
34		W5156	0553	22		32-64-11	ALL
35	UNUSED						ALL
36		W5156	0551	22		32-64-11	ALL
37	UNUSED						ALL
38		W5156	0599	22		32-31-15	ALL
39		W5156	0549	22		29-23-11	ALL
40		W5156	0570	22		32-64-21	ALL
41		W5156	0572	22		32-64-21	ALL
42		W5156	0578	22		31-53-11	ALL
43		W5156	0598	22		32-64-21	ALL
44	UNUSED						ALL
45		W5156	2214R	22		32-64-11	ALL
46		W5156	2214B	22		32-64-11	ALL
47	UNUSED						ALL
48	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10982		**205/184/R020**		**PLUG- (continued)**				**ALL**
	49	UNUSED						ALL
	50		W5156	0499	22		31-53-11	ALL
	51		W5156	0583	22		31-53-11	ALL
	52	UNUSED						ALL
	53		W5156	0576	22		31-53-11	ALL
	54	UNUSED						ALL
	55		W5156	2211B	22		32-64-11	ALL
	56	UNUSED						ALL
	57		W5156	2212B	22		32-64-11	ALL
	58		W5156	2212R	22		32-64-11	ALL
	59		W5156	0556	22		32-64-11	ALL
	60	UNUSED						ALL
	61		W5156	0657	22		32-44-11	ALL
D10984		**205/180/R018**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5160	2213B	20		32-64-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5160	2222R	22		32-64-12	ALL
	6		W5160	0712	22		32-31-15	ALL
	7		W5160	0541	22		32-64-12	ALL
	8		W5160	0544	22		32-64-12	ALL
	9		W5160	2213R	20		32-64-12	ALL
	10		W5160	0596	20		22-11-12	ALL
	11		W5160	2223R	22		32-64-12	ALL
	12		W5160	2223B	22		32-64-12	ALL
	13	UNUSED						ALL
	14		W5160	0714	22		32-31-15	ALL
	15		W5160	2222B	22		32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10984	**205/180/R018**		**PLUG- (continued)**				**ALL**
16		W5160	0546	22		32-64-12	ALL
17		W5160	0559	22		32-64-21	ALL
18	UNUSED						ALL
19		W5160	2205B	20		32-64-12	ALL
20		W5160	2205R	20		32-64-12	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5160	0567	22		27-32-21	ALL
25		W5160	0545	22		32-64-12	ALL
26		W5160	0542	22		32-64-12	ALL
27		W5160	0179	24		52-71-11	ALL
28		W5160	0625	22		32-44-11	ALL
29		W5160	0717	22		27-61-49	ALL
30	UNUSED						ALL
31		W5160	0196	22		27-61-49	ALL
32		W5160	0543	22		32-64-12	ALL
33		W5160	2221R	22		32-64-12	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W5160	0716	22		32-31-15	ALL
39	UNUSED						ALL
40		W5160	0557	22		32-64-21	ALL
41		W5160	0558	22		32-64-21	ALL
42		W5160	0578	22		31-53-11	ALL
43		W5160	0609	22		32-64-21	ALL
44		W5160	0711	22		32-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D10984		**205/180/R018**		**PLUG- (continued)**				**ALL**
	45		W5160	2224R	22		32-64-12	ALL
	46		W5160	2224B	22		32-64-12	ALL
	47	UNUSED						ALL
	48		W5160	0560	22		32-64-21	ALL
	49		W5160	0611	22		32-64-21	ALL
	50	UNUSED						ALL
	51		W5160	0583	22		31-53-11	ALL
	52		W5160	0549	22		32-64-21	ALL
	53		W5160	0556	22		32-64-21	ALL
	54		W5160	0571	20		52-71-14	ALL
	55		W5160	2221B	22		32-64-12	ALL
	56	UNUSED						ALL
	57		W5160	0520	22		29-23-11	ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61	UNUSED						ALL
D10986		**205/182/R020**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5160	0003	22		52-71-12	ALL
	7	UNUSED						ALL
	8		W5160	0007	20		52-71-13	ALL
	9		W5160	0594	22		29-23-11	ALL
	10		W5160	0008	20		52-71-13	ALL
	11		W5160	0508	20		52-71-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10986	**205/182/R020**		**PLUG- (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5160	0539	20		52-71-14	ALL
16	UNUSED						ALL
17		W5160	0617	22		23-27-38	ALL
18		W5160	0614	22		23-27-38	ALL
19		W5160	2409R	22		52-71-11	ALL
20		W5160	0004	20		52-71-13	ALL
21		W5160	0519	22		29-23-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W5160	0597	22		31-53-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W5160	0032	20		25-51-21	ALL
33		W5160	0026	22		52-71-12	ALL
34	UNUSED						ALL
35		W5160	0618	22		23-27-38	ALL
36		W5160	2409B	22		52-71-11	ALL
37		W5160	0005	22		52-71-12	ALL
38	UNUSED						ALL
39		W5160	0518	22		29-23-11	ALL
40		W5160	0034	20		52-71-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10986		**205/182/R020**		**PLUG- (continued)**				**ALL**
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W5160	0566	20		52-71-14	ALL
	48		W5160	0598	22		31-53-11	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52		W5160	0509	20		52-71-13	ALL
	53		W5160	0510	20		52-71-13	ALL
	54		W5160	0619	22		25-51-21	ALL
	55		W5160	0047	20		33-36-12	ALL
	56		W5160	0046	22		52-71-12	ALL
	57		W5160	2444B	22		52-71-11	ALL
	58		W5160	2444R	22		52-71-11	ALL
	59		W5160	0043	22		52-71-11	ALL
	60		W5160	0021	22		52-71-11	ALL
	61		W5160	0019	20		52-71-14	ALL
D10988		**205/178/R018**		**PLUG-**				**ALL**
	1		W5160	0017	20		52-71-14	ALL
	2		W5160	0018	20		52-71-14	ALL
	3	UNUSED						ALL
	4		W5160	0615	22		23-27-38	ALL
	5	UNUSED						ALL
	6	18	W5160	0006	18		52-71-12	ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10988	**205/178/R018**		**PLUG- (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10		W5160	2232B	22		32-31-12	ALL
11	UNUSED						ALL
12		W5160	5503	24		21-31-24	ALL
13		W5160	0140	22		23-42-14	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W5160	0616	22		23-27-38	ALL
19		W5160	2419R	22		52-71-11	ALL
20		W5160	0050	22		52-71-11	ALL
21		W5160	0022	20		52-71-13	ALL
22	UNUSED						ALL
23		W5160	2227B	20		32-31-12	ALL
24		W5160	2232R	22		32-31-12	ALL
25	UNUSED						ALL
26		W5160	6004	24		73-23-11	ALL
27		W5160	5501	24		21-51-24	ALL
28		W5160	0506	22		27-32-21	ALL
29	UNUSED						ALL
30		W5160	0535	20		52-71-14	ALL
31		W5160	0572	20		52-71-14	ALL
32	UNUSED						ALL
33		W5160	0033	22		52-71-12	ALL
34	UNUSED						ALL
35		W5160	0533	20		52-71-13	ALL
36		W5160	2419B	22		52-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D10988	**205/178/R018**		**PLUG- (continued)**				**ALL**
37	UNUSED						ALL
38		W5160	0038	22		SPARE	ALL
39	UNUSED						ALL
40		W5160	2233B	22		32-31-12	ALL
41		W5160	2233R	22		32-31-12	ALL
42		W5160	2227R	20		32-31-12	ALL
43		W5160	0197	22		27-61-49	ALL
44	UNUSED						ALL
45		W5160	0622	20		32-31-12	ALL
46	UNUSED						ALL
47		W5160	2201B	22		24-22-21	ALL
48		W5160	2201R	22		24-22-21	ALL
49		W5160	0722	22		32-46-11	ALL
50		W5160	0180	22		31-53-11	ALL
51		W5160	0612	22		49-52-31	ALL
52		W5160	0536	20		52-71-14	ALL
53		W5160	0553	20		52-71-14	ALL
54		W5160	0629	22		SPARE	ALL
55		W5160	0055	20		33-36-11	ALL
56		W5160	0056	22		52-71-12	ALL
57		W5160	2458B	22		52-71-11	ALL
58		W5160	2458R	22		52-71-11	ALL
59		W5160	0059	22		52-71-11	ALL
60		W5160	2460B	22		SPARE	ALL
61		W5160	2460R	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11002		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0076	0113	20		78-34-11	ALL
	A3		W0076	0115	20		78-34-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2		W0076	0416	20		46-13-11	ALL
	C3		W0076	0417	22		46-13-11	ALL
	D1	UNUSED						ALL
	D2		W0076	0341	20		47-30-11	ALL
	D3		W0076	0340	20		47-30-11	ALL
	X1		W0076	0111	24		32-31-11	ALL
	X2		W0076	0112	24		32-31-11	ALL
D11004		**J00024/ /**		**SOCKET-**				**ALL**
	A1	UNUSED						ALL
	A2		W0080	6033	20		78-34-21	ALL
	A3		W0080	6032	20		78-34-21	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	0511	22		32-31-12	ALL
	X2		W0080	0512	22		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11008		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0076	0093	22		29-25-11	ALL
	A3		W0076	0094	18		29-25-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0091	24		32-31-11	ALL
	X2		W0076	0092	24		32-31-11	ALL
D11010		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1		W0072	0093	22		27-23-11	ALL
	A2		W0072	0094	22		27-23-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0091	24		32-31-12	ALL
	X2		W0072	0092	24		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11012		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0076	0347	22		21-25-11	ALL
	A3		W0076	0345	22		21-25-11	ALL
	B1	UNUSED						ALL
	B2		W0076	0346	22		21-25-11	ALL
	B3		W0076	0344	22		21-25-11	ALL
	C1	UNUSED						ALL
	C2		W0076	0086	22		34-41-11	ALL
	C3		W0076	0064	24		34-41-11	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0081	24		32-31-11	ALL
	X2		W0076	0082	24		32-31-11	ALL
D11014		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0081	24		32-31-12	ALL
	X2		W0072	0082	24		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11016		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0071	24		32-31-12	ALL
	X2		W0072	0072	24		32-31-12	ALL
D11018		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2		W0076	0069	24		21-43-21	ALL
	B3		W0076	0348	24		21-43-21	ALL
	C1	UNUSED						ALL
	C2		W0076	0066	24		21-43-21	ALL
	C3		W0076	0349	24		21-43-21	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0061	24		32-31-11	ALL
	X2		W0076	0062	24		32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11020	**J022-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0076	0073	24		21-42-11	ALL
A2		W0076	0074	24		21-42-11	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2		W0076	0275	24		34-61-26	ALL
B3		W0076	0276	20		34-61-26	ALL
C1	UNUSED						ALL
C2		W0076	0277	24		34-61-26	ALL
C3		W0076	0278	20		34-61-26	ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0076	0071	24		32-31-11	ALL
X2		W0076	0072	24		32-31-11	ALL
D11022	**J022-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0076	0103	20		30-71-11	ALL
A2		W0076	0104	20		30-71-11	ALL
A3		W0076	0105	20		30-71-11	ALL
B1		W0076	0363	22		27-33-11	ALL
B2		W0076	0366	20		27-33-11	ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2		W0076	0365	22		27-33-11	ALL
C3		W0076	0364	22		27-33-11	ALL
D1		W0076	0160	22		26-23-11	ALL
D2		W0076	0161	20		26-23-11	ALL
D3	UNUSED						ALL
X1		W0076	0101	24		32-31-11	ALL
X2		W0076	0102	24		32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11024		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1		W0072	0294	24		21-51-11	ALL
	A2		W0072	0054	24		21-51-11	ALL
	A3	UNUSED						ALL
	B1		W0072	0055	18		29-25-11	ALL
	B2		W0072	0056	22		29-25-11	ALL
	B3		W0072	0057	18		29-25-11	ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0051	24		32-31-12	ALL
	X2		W0072	0052	24		32-31-12	ALL
D11026		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1		W0072	0063	24		32-51-11	ALL
	A2		W0072	0064	24		32-51-11	ALL
	A3		W0072	0065	24		32-51-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1		W0072	0157	20		47-30-11	ALL
	C2		W0072	0194	20		47-30-11	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2		W0072	0006	22		26-16-21	ALL
	D3		W0072	0007	22		26-16-21	ALL
	X1		W0072	0061	24		32-31-12	ALL
	X2		W0072	0062	24		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11028	**J039-0B/ /**		**RELAY SOCKET**				**ALL**
A1	UNUSED						ALL
A2	UNUSED						ALL
A3	UNUSED						ALL
B1		W0084	0090	22		46-13-52	ALL
B2		W0084	0104	22		46-13-52	ALL
B3	UNUSED						ALL
C1		W0084	0110	24		23-15-15	ALL
C2		W0084	0111	20		23-15-15	ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0084	0001	22		32-31-12	ALL
X2		W0084	0002	22		32-31-12	ALL
D11048	**562/295/R030**		**PLUG-**				**ALL**
1		W4142	0641	20		33-44-11	ALL
2		W4142	0642	20		33-44-11	ALL
3		W4142	0643	20		33-44-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
D11050	**649/164/L055**		**PLUG-**				**ALL**
1		W5102	1201	20		33-44-11	ALL
2		W5102	1202	20		33-44-11	ALL
3		W5102	1203	20		33-44-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
S/R		W5102	1201Z			33-44-11	ALL
S/R		W5102	1202Z			33-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11072	**350/222/R067**		**PLUG-**				**ALL**
1		W4142	0030	16		33-51-12	ALL
2		W4142	0051	18		33-51-12	ALL
3	UNUSED						ALL
D11073	**J022-00/ /**		**SOCKET-RELAY**				**ALL**
A1		W0076	0171	20		23-71-01	ALL
A2		W0076	0166	22		23-71-01	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
C1		W0076	0169	22		23-71-01	ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0076	0165	18		23-71-01	ALL
X2		W0076	0158	20		23-71-01	ALL
D11074	**370/221/L069**		**PLUG-**				**ALL**
1		W3142	0111	16		33-51-12	ALL
2		W3142	0151	16		33-51-12	ALL
3	UNUSED						ALL
D11080	**727F+4/175/R053**		**PLUG-**				**ALL**
1		W4142	0089	16		33-51-14	ALL
2		W4142	0097	16		33-51-14	ALL
3	UNUSED						ALL
D11082	**727F+11/174/L052**		**PLUG-**				**ALL**
1		W3142	0331	16		33-51-13	ALL
2		W3142	0353	16		33-51-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11082		**727F+11/174/L052**		**PLUG- (continued)**				**ALL**
	3	UNUSED						ALL
D11084		**997/238/R057**		**PLUG-**				**ALL**
	1		W4142	0444	16		33-51-14	ALL
	2		W4142	0451	18		33-51-14	ALL
	3	UNUSED						ALL
D11086		**996/240/L056**		**PLUG-**				**ALL**
	1		W3142	0444	16		33-51-14	ALL
	2		W3142	0451	18		33-51-14	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11108		**1224/294/R187**		**PLUG-RIGHT LOGO LIGHT**				**ALL**
	1	UNUSED						ALL
	2		W8038	3501Y	20		33-49-11	ALL
	3	UNUSED						ALL
	4		W8038	3501B	20		33-49-11	ALL
	5		W8038	3501R	20		33-49-11	ALL
			W8038	0504	12		33-49-11	ALL
			W8038	3501Z			33-49-11	ALL
D11110		**1222/295/L190**		**PLUG-LEFT LOGO LIGHT**				**ALL**
	1	UNUSED						ALL
	2		W7038	3501Y	20		33-49-11	ALL
	3	UNUSED						ALL
	4		W7038	3501B	20		33-49-11	ALL
	5		W7038	3501R	20		33-49-11	ALL
			W7038	0504	12		33-49-11	ALL
			W7038	3501Z			33-49-11	ALL
D11114A		**E002-02/ /**		**PLUG**				**ALL**
	1		W0220	0504	06		24-21-31	ALL
	2		W0220	0506	06		24-21-31	ALL
	3		W0220	0508	06		24-21-31	ALL
D11114B		**E002-02/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0220	3001R	16		24-21-31	ALL
	6		W0220	3001Y	16		24-21-31	ALL
	7	UNUSED						ALL
	8		W0220	2002R	16		24-21-31	ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11114B	**E002-02/ /**		**PLUG (continued)**				**ALL**
10		W0220	2002B	16		24-21-31	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0220	3001B	16		24-21-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0220	2024B	16		49-41-11	ALL
19	UNUSED						ALL
20		W0220	0124	16		49-41-11	ALL
21		W0220	0125	16		49-41-11	ALL
22	UNUSED						ALL
23		W0220	FRAL			49-41-11	ALL
24		W0220	2025B	16		49-41-11	ALL
25		W0220	2024R	16		49-41-11	ALL
26		W0220	2025R	16		49-41-11	ALL
		W0220	2024Z			49-41-11	ALL
		W0220	2025Z			49-41-11	ALL
		W0220	FRAL			49-41-11	ALL
D11114C	**E002-02/ /**		**PLUG**				**ALL**
1		W0220	2047R	22		49-41-11	ALL
2		W0220	2019R	22		49-41-11	ALL
3		W0220	0245	20		49-41-11	ALL
4		W0220	0112	20		49-41-11	ALL
5	UNUSED						ALL
6		W0220	4001R	20		24-21-31	ALL
7		W0220	0118	24		49-41-11	ALL
8		W0220	3002R	22		49-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11114C		**E002-02/ /**		**PLUG (continued)**				**ALL**
	9		W0220	2047B	22		49-41-11	ALL
	10		W0220	2047Z			49-41-11	ALL
	11		W0220	2019B	22		49-41-11	ALL
	12		W0220	0126	22		49-41-11	ALL
	13		W0220	2001R	22		24-21-31	ALL
	14		W0220	4001Y	20		24-21-31	ALL
	15		W0220	4001G	20		24-21-31	ALL
	16	UNUSED						ALL
	17		W0220	0003	22		24-21-31	ALL
	18		W0220	3002Y	22		49-41-11	ALL
	19		W0220	0114	22		49-41-11	ALL
	20		W0220	3201Y	22		49-41-11	ALL
	21		W0220	3201R	22		49-41-11	ALL
	22		W0220	2023R	22		49-41-11	ALL
	23		W0220	2022R	22		49-41-11	ALL
	24		W0220	0127	20		49-41-11	ALL
	25		W0220	2001B	22		24-21-31	ALL
	26	UNUSED						ALL
	27		W0220	4001B	20		24-21-31	ALL
	28		W0220	0002	22		24-21-31	ALL
	29		W0220	0001	22		24-21-31	ALL
	30		W0220	2020R	22		49-41-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W0220	3201B	22		49-41-11	ALL
	34		W0220	3002B	22		49-41-11	ALL
	35		W0220	2023B	22		49-41-11	ALL
	36		W0220	2022B	22		49-41-11	ALL
	37	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11114C	**E002-02/ /**		**PLUG (continued)**				**ALL**
38		W0220	2029B	24		49-41-11	ALL
39		W0220	2029R	24		49-41-11	ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W0220	2020B	22		49-41-11	ALL
44		W0220	2018B	22		49-41-11	ALL
45		W0220	2021R	22		49-41-11	ALL
46		W0220	2016B	22		49-41-11	ALL
47		W0220	0227	22		49-41-11	ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
56	UNUSED						ALL
57		W0220	2018R	22		49-41-11	ALL
58		W0220	2021B	22		49-41-11	ALL
59		W0220	2016R	22		49-41-11	ALL
60	UNUSED						ALL
61		W0220	0119	24		49-41-11	ALL
62		W0220	0120	24		49-41-11	ALL
63		W0220	0121	24		49-41-11	ALL
64		W0220	0123	24		49-41-11	ALL
65	UNUSED						ALL
66	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11114C		**E002-02/ /**		**PLUG (continued)**				**ALL**
	67	UNUSED						ALL
	DED		W0220	2001Z			24-21-31	ALL
	DED		W0220	4001Z			24-21-31	ALL
D11118		**AB1088/229/R014**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W4726	4103R	20		24-24-31	ALL
	4		W4726	4103G	20		24-24-31	ALL
	5	UNUSED						ALL
	6		W4726	2236R	16		24-21-31	ALL
	7	UNUSED						ALL
	8		W4726	2236B	16		24-21-31	ALL
	9	UNUSED						ALL
	10		W4726	3204B	16		24-21-31	ALL
	11		W4726	3204Z			24-21-31	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W4726	2236Z			24-21-31	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W4726	4103Y	20		24-24-31	ALL
	23		W4726	4103B	20		24-24-31	ALL
	24		W4726	3204Y	16		24-21-31	ALL
	25		W4726	3204R	16		24-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11118		**AB1088/229/R014**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	S/R		W4726	4103Z			24-24-31	ALL
	S/R		W4726	YAAA			24-21-31	ALL
D11120		**707/117/L132**		**PLUG**				**ALL**
	1		W7134	2201R	20		32-41-11	ALL
	2	UNUSED						ALL
	3		W7134	2201B	20		32-41-11	ALL
	DED		W7134	2201Z			32-41-11	ALL
D11122		**707/117/L94**		**PLUG**				**ALL**
	1		W7136	2201R	20		32-41-11	ALL
	2	UNUSED						ALL
	3		W7136	2201B	20		32-41-11	ALL
	DED		W7136	2201Z			32-41-11	ALL
D11124		**707/117/R94**		**PLUG-**				**ALL**
	1		W8236	2201R	20		32-41-11	ALL
	2	UNUSED						ALL
	3		W8236	2201B	20		32-41-11	ALL
	DED		W8236	2201Z			32-41-11	ALL
D11125		**P005-88/ /**		**PLUG-**				**ALL**
	1		W2112	5559	22		23-71-01	ALL
	2	UNUSED						ALL
	3		W2112	5561	22		23-71-01	ALL
	4		W2112	5560	20		23-71-01	ALL
	5		W2112	5562	22		23-71-01	ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11125		**P005-88/ /**		**PLUG- (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2218	5811	20		33-12-12	ALL
	10		W2218	5812	20		33-12-12	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D11126		**707/117/R132**		**PLUG**				**ALL**
	1		W8234	2201R	20		32-41-11	ALL
	2	UNUSED						ALL
	3		W8234	2201B	20		32-41-11	ALL
	DED		W8234	2201Z			32-41-11	ALL
D11128		**AB0250A/195/L003**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W5510	0571	22		32-64-21	ALL
	3		W5510	0570	22		32-64-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	18	W5510	6088	18		78-32-51	ALL
	8		W5510	6089	22		78-32-51	ALL
	9	UNUSED						ALL
	10		W5510	6020	22		30-11-11	ALL
	11		W5510	6087	22		30-11-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	18	W5510	6009	18		78-32-51	ALL
	15	UNUSED						ALL
	16		W5510	0526	22		31-53-11	ALL
	17		W5510	0540	22		31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11128	**AB0250A/195/L003**		**RCPT- (continued)**				**ALL**
18		W5510	0500	22		34-41-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5510	0573	22		32-64-21	ALL
24		W5510	0572	22		32-64-21	ALL
D11130	**AB0250A/195/L005**		**RCPT**				**ALL**
1	UNUSED						ALL
2		W5506	0511	24		32-42-11	ALL
3		W5506	0510	24		32-42-11	ALL
4	UNUSED						ALL
5		W5506	0513	22		32-42-11	ALL
6		W5506	0512	24		32-42-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
D11131	**J022-00/ /**		**SOCKET-RELAY**				**ALL**
A1		W0076	0178	22		23-71-01	ALL
A2		W0076	0180	22		23-71-01	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11131		**J022-00/ /**		**SOCKET-RELAY (continued)**				**ALL**
	B3	UNUSED						ALL
	X1		W0076	0181	18		23-71-01	ALL
	X2		W0076	0179	22		23-71-01	ALL
D11132		**AB0250A/ /**		**RECPT -**				**ALL**
	1	UNUSED						ALL
	2		W6162	0559	22		32-64-21	ALL
	3		W6162	0557	22		32-64-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	18	W6162	6088	18		78-32-61	ALL
	8		W6162	6089	20		78-32-61	ALL
	9	UNUSED						ALL
	10		W6162	6087	22		30-11-11	ALL
	11		W6162	6086	22		30-11-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	18	W6162	6026	18		78-32-61	ALL
	15	UNUSED						ALL
	16		W6162	0526	22		31-53-11	ALL
	17		W6162	0540	22		31-53-11	ALL
	18		W6162	0500	22		34-41-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W6162	0560	22		32-64-21	ALL
	24		W6162	0558	22		32-64-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11134	**AB0250A/197/L005**		**RCPT-**				**ALL**
1	UNUSED						ALL
2		W5160	0702	22		32-42-11	ALL
3		W5160	0700	22		32-42-11	ALL
4	UNUSED						ALL
5		W5160	0704	22		32-42-11	ALL
6		W5160	0703	22		32-42-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
D11138	**205/189/R022**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W5156	0550	22		29-23-11	ALL
3		W5156	0616	22		44-21-22	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W5156	0548	22		29-23-11	ALL
8	UNUSED						ALL
9		W5156	0630	20		52-71-13	ALL
10	UNUSED						ALL
11		W5156	0653	20		44-21-22	ALL
12		W5156	5522	24		21-31-24	ALL
13		W5156	0618	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11138		**205/189/R022**		**PLUG- (continued)**				**ALL**
	14		W5156	6015	22		30-11-11	ALL
	15	UNUSED						ALL
	16		W5156	0520	22		23-12-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W5156	0656	22		32-31-11	ALL
	20		W5156	0605	22		32-31-11	ALL
	21		W5156	0606	22		32-31-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W5156	6007	24		73-23-11	ALL
	27		W5156	5501	24		21-51-14	ALL
	28		W5156	0506	22		27-32-11	ALL
	29		W5156	0541	22		24-33-11	ALL
	30		W5156	0519	20		23-71-01	ALL
	31		W5156	2202R	22		24-28-41	ALL
	32		W5156	2202B	22		24-28-41	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W5156	0607	22		32-31-11	ALL
	36		W5156	0603	22		32-31-11	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W5156	0602	22		32-31-11	ALL
	40		W5156	0302	22		32-31-11	ALL
	41		W5156	0545	20		32-64-11	ALL
	42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11138	**205/189/R022**		**PLUG- (continued)**				**ALL**
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W5156	0512	22		34-45-11	ALL
48		W5156	0508	22		27-32-11	ALL
49	UNUSED						ALL
50		W5156	0719	22		27-61-49	ALL
51		W5156	0518	20		23-71-01	ALL
52	UNUSED						ALL
53		W5156	0517	22		34-21-11	ALL
54		W5156	2201R	22		24-22-11	ALL
55		W5156	2201B	22		24-22-11	ALL
56	UNUSED						ALL
57	UNUSED						ALL
58		W5156	0608	22		32-31-11	ALL
59		W5156	0609	22		32-31-11	ALL
60	UNUSED						ALL
61		W5156	0544	22		32-64-11	ALL
D11140	**205/175/R017**		**PLUG-**				**ALL**
1		W5158	2008R	22		27-62-11	ALL
2		W5158	0519	20		29-23-11	ALL
3		W5158	6001	24		73-23-11	ALL
4	UNUSED						ALL
5		W5158	0509	22		34-31-21	ALL
6		W5158	2008B	22		27-62-11	ALL
7		W5158	0518	22		29-23-11	ALL
8		W5158	0008	22		SPARE	ALL
9		W5158	0585	22		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11140		**205/175/R017**		**PLUG- (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5158	2608R	24		31-65-25	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5158	0513	22		34-51-21	ALL
	16		W5158	0516	22		34-57-21	ALL
	17		W5158	2605B	24		31-65-15	ALL
	18		W5158	2605R	24		31-65-15	ALL
	19	UNUSED						ALL
	20		W5158	0586	22		32-31-12	ALL
	21		W5158	0601	22		32-31-12	ALL
	22		W5158	2607R	24		32-64-31	ALL
	23		W5158	0086	22		32-31-12	ALL
	24		W5158	0581	22		32-31-12	ALL
	25		W5158	0520	22		31-31-15	ALL
	26		W5158	0514	22		34-53-21	ALL
	27		W5158	2608B	24		31-65-25	ALL
	28	UNUSED						ALL
	29		W5158	0505	22		31-31-15	ALL
	30		W5158	0301	20		31-31-15	ALL
	31	UNUSED						ALL
	32		W5158	0515	22		34-55-21	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W5158	2612R	24		32-64-31	ALL
	38		W5158	2612B	24		32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11140	**205/175/R017**		**PLUG- (continued)**				**ALL**
39		W5158	0604	22		32-31-12	ALL
40		W5158	2607B	24		32-64-31	ALL
41		W5158	0589	22		32-64-12	ALL
42		W5158	2607Z			32-64-31	ALL
43		W5158	0588	22		32-31-12	ALL
44		W5158	0584	22		32-31-12	ALL
45		W5158	0653	22		32-31-12	ALL
46		W5158	0501	20		22-11-12	ALL
47		W5158	0502	20		22-11-12	ALL
48		W5158	0560	22		32-42-11	ALL
49		W5158	0561	22		32-42-11	ALL
50	UNUSED						ALL
51		W5158	0504	22		31-31-15	ALL
52	UNUSED						ALL
53		W5158	0517	22		34-21-21	ALL
54		W5158	0503	22		31-31-11	ALL
55		W5158	0510	22		34-33-21	ALL
56	UNUSED						ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60		W5158	2612Z			32-64-31	ALL
61		W5158	0590	20		32-64-12	ALL
D11142	**205/187/R022**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W5156	2615R	24		31-65-15	ALL
3		W5156	6008	24		73-23-11	ALL
4	UNUSED						ALL
5		W5156	0509	22		34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11142		**205/187/R022**		**PLUG- (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5156	2615B	24		31-65-15	ALL
	10		W5156	2607R	24		31-65-25	ALL
	11		W5156	2607B	24		31-65-25	ALL
	12		W5156	0610	22		23-27-38	ALL
	13	UNUSED						ALL
	14		W5156	6016	22		30-11-11	ALL
	15		W5156	0513	22		34-51-11	ALL
	16		W5156	0516	22		34-57-11	ALL
	17	UNUSED						ALL
	18		W5156	2240R	22		32-31-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W5156	2620R	24		32-64-31	ALL
	23		W5156	2620B	24		32-64-31	ALL
	24		W5156	2620Z			32-64-31	ALL
	25		W5156	0521	22		34-61-17	ALL
	26		W5156	0514	22		34-53-11	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W5156	0511	22		34-49-11	ALL
	30	UNUSED						ALL
	31		W5156	2021B	22		27-62-11	ALL
	32		W5156	0515	22		34-55-11	ALL
	33	UNUSED						ALL
	34		W5156	2021R	22		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11142	**205/187/R022**		**PLUG- (continued)**				**ALL**
35		W5156	2240B	22		32-31-11	ALL
36		W5156	2226B	20		32-31-11	ALL
37	UNUSED						ALL
38		W5156	2232R	22		32-31-11	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W5156	2614R	24		32-64-31	ALL
43		W5156	2614B	24		32-64-31	ALL
44		W5156	2614Z			32-64-31	ALL
45	UNUSED						ALL
46		W5156	0501	20		22-11-12	ALL
47		W5156	0502	20		22-11-12	ALL
48		W5156	0560	22		32-42-11	ALL
49		W5156	0561	22		32-42-11	ALL
50		W5156	0615	22		34-21-16	ALL
51		W5156	0542	22		27-53-11	ALL
52	UNUSED						ALL
53		W5156	6001R	20		26-11-31	ALL
54		W5156	6002R	20		26-11-31	ALL
55		W5156	0510	22		34-33-11	ALL
56	UNUSED						ALL
57		W5156	0612	22		32-31-11	ALL
58	UNUSED						ALL
59		W5156	0722	22		32-46-11	ALL
60		W5156	2226R	20		32-31-11	ALL
61		W5156	2232B	22		32-31-11	ALL
D11154	**J00024/ /**		**SOCKET-**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11154		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	2	UNUSED						ALL
	3		W0080	0519	22		32-44-11	ALL
	4		W0080	0520	22		32-44-11	ALL
	5		W0080	0523	22		32-44-11	ALL
	6		W0080	0522	20		32-44-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0080	0521	22		32-44-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D11158		**AB0237A/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W5172	2613B	20		73-21-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5172	2611B	20		73-21-21	ALL
	6	UNUSED						ALL
	7		W5172	2612B	20		73-21-21	ALL
	8		W5172	2612R	20		73-21-21	ALL
	9	UNUSED						ALL
	10		W5172	2613R	20		73-21-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W5172	6002	20		73-21-21	ALL
	14	UNUSED						ALL
	15		W5172	2611R	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11158	**AB0237A/ /**		**RCPT- (continued)**				**ALL**
S/R		W5172	2611Z			73-21-21	ALL
S/R		W5172	2612Z			73-21-21	ALL
S/R		W5172	2613Z			73-21-21	ALL
D11160	**AB0237A/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2		W5162	2607B	20		73-21-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5162	2603B	20		73-21-21	ALL
6	UNUSED						ALL
7		W5162	2608B	20		73-21-21	ALL
8		W5162	2608R	20		73-21-21	ALL
9	UNUSED						ALL
10		W5162	2607R	20		73-21-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5162	6003	20		73-21-21	ALL
14	UNUSED						ALL
15		W5162	2603R	20		73-21-21	ALL
S/R		W5162	2603Z			73-21-21	ALL
S/R		W5162	2607Z			73-21-21	ALL
S/R		W5162	2608Z			73-21-21	ALL
D11162	**AB0237B/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2		W6172	2608B	20		73-21-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W6172	2607B	20		73-21-21	ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11162		**AB0237B/ /**		**RCPT- (continued)**				**ALL**
	7		W6172	2609B	20		73-21-21	ALL
	8		W6172	2609R	20		73-21-21	ALL
	9	UNUSED						ALL
	10		W6172	2608R	20		73-21-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W6172	6002	20		73-21-21	ALL
	14	UNUSED						ALL
	15		W6172	2607R	20		73-21-21	ALL
	S/R		W6172	2607Z			73-21-21	ALL
	S/R		W6172	2608Z			73-21-21	ALL
	S/R		W6172	2609Z			73-21-21	ALL
D11164		**AB0237B/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W6162	2608B	20		73-21-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W6162	2607B	20		73-21-21	ALL
	6	UNUSED						ALL
	7		W6162	2609B	20		73-21-21	ALL
	8		W6162	2609R	20		73-21-21	ALL
	9	UNUSED						ALL
	10		W6162	2608R	20		73-21-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W6162	6003	20		73-21-21	ALL
	14	UNUSED						ALL
	15		W6162	2607R	20		73-21-21	ALL
	S/R		W6162	2607Z			73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11164		**AB0237B/ /**		**RCPT- (continued)**				**ALL**
	S/R		W6162	2608Z			73-21-21	ALL
	S/R		W6162	2609Z			73-21-21	ALL
D11173		**917/291/R018**		**PLUG**				**ALL**
	1		W3311	3502R	24		23-42-12	ALL
	2		W3311	3502Y	24		23-42-12	ALL
	3		W3311	3502B	24		23-42-12	ALL
	4		W3311	0006	22		23-42-12	ALL
	5		W3311	0007	22		23-42-12	ALL
	DED		W3311	3502Z			23-42-12	ALL
D11179		**J011-00/ /**		**SOCKET 30 SEC DELAY RELAY**				**ALL**
	1	UNUSED						ALL
	2		W0122	0029	24		27-31-37	ALL
	3		W0122	0030	20		27-31-37	ALL
	4	UNUSED						ALL
	5		W0122	0031	24		27-31-37	ALL
	6	UNUSED						ALL
	7		W0122	0032	20		27-31-37	ALL
	8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11284		**727+4/172/L015**		**RCPT-**				**ALL**
	1		W3154	2001B	24		25-51-21	ALL
	2		W3154	2001W	24		25-51-21	ALL
	3		W3154	0031	22		25-51-21	ALL
	4		W3154	0032	22		25-51-21	ALL
	5		W3154	0033	22		25-51-21	ALL
	6		W3154	0039	22		25-51-21	ALL
	7		W3154	0034	22		25-51-21	ALL
	8		W3154	0035	22		25-51-21	ALL
	9		W3154	0036	22		25-51-21	ALL
	10		W3154	0026	22		25-51-21	ALL
	11		W3154	2001Z			25-51-21	ALL
	12		W3154	0027	20		25-51-21	ALL
	13	UNUSED						ALL
	14		W3154	0028	16		25-51-21	ALL
	15	UNUSED						ALL
	16		W3154	0029	16		25-51-21	ALL
	17	UNUSED						ALL
	18		W3154	0030	16		25-51-21	ALL
	19	UNUSED						ALL
	20		W3154	3001B	16		25-51-21	ALL
	21	UNUSED						ALL
	22		W3154	3001R	16		25-51-21	ALL
	23	UNUSED						ALL
	24		W3154	3001Y	16		25-51-21	ALL
	25	UNUSED						ALL
D11286		**AF0213A/210/L001**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W5510	6022	20		76-21-11	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11286	**AF0213A/210/L001**		**PLUG-CONDUCTIVE (continued)**				**ALL**
4		W5510	6003	24		76-21-11	ALL
5		W5510	6002	24		76-21-11	ALL
6	UNUSED						ALL
7		W5510	6006	20		76-21-11	ALL
8		W5510	6005	20		76-21-11	ALL
9		W5510	6011R	20		76-21-11	ALL
10	UNUSED						ALL
11		W5510	6004	20		74-11-11	ALL
12		W5510	1301	20		74-11-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5510	6001	20		76-21-11	ALL
S/R		W5510	1301Z			74-11-11	ALL
D11286P	**P008-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W0008	0097	22		76-21-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11288		**AF0213A/210/R001**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5506	6010	24		76-21-11	ALL
	5		W5506	6009	24		76-21-11	ALL
	6	UNUSED						ALL
	7		W5506	6030	20		28-21-11	ALL
	8		W5506	6031	20		28-21-11	ALL
	9		W5506	6028	20		28-21-11	ALL
	10		W5506	5522	20		33-18-63	ALL
	11		W5506	0111	20		74-11-11	ALL
	12		W5506	1303	20		74-11-11	ALL
	13	UNUSED						ALL
	14		W5506	6097R	22		26-11-11	ALL
	15		W5506	6011	20		76-21-11	ALL
	S/R		W5506	1303Z			74-11-11	ALL
D11290		**AF0222A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W6510	6017	20		76-21-21	ALL
	3	UNUSED						ALL
	4		W6510	6006	24		76-21-21	ALL
	5		W6510	6005	24		76-21-21	ALL
	6	UNUSED						ALL
	7		W6510	6003	20		76-21-21	ALL
	8		W6510	6004	20		76-21-21	ALL
	9		W6510	6002	20		76-21-21	ALL
	10	UNUSED						ALL
	11		W6510	6016	20		74-11-11	ALL
	12		W6510	1301	20		74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11290	**AF0222A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
13	UNUSED						ALL
14	UNUSED						ALL
15		W6510	6007	20		76-21-21	ALL
S/R		W6510	1301Z			74-11-11	ALL
D11290P	**P008-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W0008	0095	22		76-21-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
D11292	**AF0222A/*/***		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W6506	6006	24		76-21-21	ALL
5		W6506	6005	24		76-21-21	ALL
6	UNUSED						ALL
7		W6506	6011	20		28-21-11	ALL
8		W6506	6012	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11292		**AF0222A/*/***		**PLUG-CONDUCTIVE (continued)**				**ALL**
	9		W6506	6009	20		28-21-11	ALL
	10		W6506	5511	20		33-18-63	ALL
	11		W6506	6016	20		74-11-11	ALL
	12		W6506	1303	20		74-11-11	ALL
	13	UNUSED						ALL
	14		W6506	6057R	20		26-11-21	ALL
	15		W6506	6007	20		76-21-21	ALL
	S/R		W6506	1303Z			74-11-11	ALL
D11294		**192/225/L32**		**PLUG-LEFT PITOT HEATER**				**ALL**
	=A		W5501	0014	22		30-31-11	ALL
	=B		W5501	0013	22		30-31-11	ALL
D11296		**1071/388/L007**		**PLUG-LEFT ELEVATOR PITOT HEATER**				**ALL**
	=A		W7102	2001R	20		30-31-11	ALL
	=B		W7102	2001B	20		30-31-11	ALL
D11298		**193/214/R033**		**PLUG-LWR RIGHT PITOT HEATER**				**ALL**
	=A		W5503	0012	22		30-31-12	ALL
	=B		W5503	0013	22		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11300	**193/226/R033**		**PLUG-UPPER RIGHT PITOT HEATER**				**ALL**
=A		W5503	0010	22		30-31-12	ALL
=B		W5503	0011	22		30-31-12	ALL
D11302	**1071/388/R007**		**PLUG-RIGHT ELEVATOR PITOT HEATER**				**ALL**
=A		W7102	2002R	20		30-31-12	ALL
=B		W7102	2002B	20		30-31-12	ALL
D11316	**666/185/L043**		**PLUG**				**ALL**
1		W7580	1301	20		28-41-11	ALL
2		W7580	1303	20		28-41-11	ALL
3		W7580	1302	20		28-41-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
=C1		W7580	1301ZI			28-41-11	ALL
D11366	**317/286/L027**		**PLUG-**				**ALL**
1		W0352	0005	18		35-21-21	ALL
2		W0352	0006	18		35-21-21	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11368		**962/291/L025**		**PLUG-**				**ALL**
	1		W0152	0031	18		35-21-21	ALL
	2		W0152	0032	18		35-21-21	ALL
	3	UNUSED						ALL
D11370		**J011-00/ /**		**SOCKET-STANDBY SHUTOFF VLV IND RLY R625**				**ALL**
	A1		W0122	0020	18		29-25-11	ALL
	A2		W0122	0007	18		29-25-11	ALL
	A3		W0122	0019	18		29-25-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0122	0004	20		29-25-11	ALL
	X2		W0122	0011	22		29-25-11	ALL
D11396		**321/292/R023**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B		W0010	A-D			33-26-21	ALL
	C		W0010	A-C			33-26-21	ALL
	D		W0010	0004	22		33-26-21	ALL
	E		W0010	0001	20		33-26-21	ALL
	F		W0010	0006	22		33-26-21	ALL
	G		W0010	0002	20		33-26-21	ALL
	H		W0010	0007	20		33-26-21	ALL
	J		W0010	A-A			33-26-21	ALL
	K		W0010	A-B			33-26-21	ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
D11398		**324/291/R023**		**PLUG-**				**ALL**
	1		W6242	0053	22		33-26-21	ALL
	2		W6242	0057	20		33-26-21	ALL
	3		W6242	0058	20		33-26-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11398		**324/291/R023**		**PLUG- (continued)**				**ALL**
	4		W6242	0054	22		33-26-21	ALL
	5	UNUSED						ALL
	6		W6242	0056	22		33-26-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11400		**324/292/R024**		**RCPT-**				**ALL**
	1		W0010	0001	20		33-26-21	ALL
	2		W0010	0002	20		33-26-21	ALL
	3		W0010	0003	20		33-26-21	ALL
	4		W0010	0004	22		33-26-21	ALL
	5	UNUSED						ALL
	6		W0010	0006	22		33-26-21	ALL
D11402		**J00024/ /**		**SOCKET-**				**ALL**
	1		W0080	0527	22		27-62-11	ALL
	2	UNUSED						ALL
	3		W0080	0515	20		32-41-11	ALL
	4	UNUSED						ALL
	5		W0080	0516	22		32-41-11	ALL
	6		W0080	0518	22		32-41-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0080	0517	22		32-41-11	ALL
	13		W0080	0501	22		27-62-11	ALL
	14	UNUSED						ALL
D11404		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0076	0205	24		32-41-11	ALL
	4	UNUSED						ALL
	5		W0076	0204	24		32-41-11	ALL
	6		W0076	0201	24		32-41-11	ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11404	**J022-00/ /**		**RELAY SOCKET (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0076	0202	24		32-41-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
D11406	**J022-00/ /**		**RELAY SOCKET**				**ALL**
1		W0076	0419	22		27-62-11	ALL
2	UNUSED						ALL
3		W0076	0218	24		32-41-11	ALL
4	UNUSED						ALL
5		W0076	0215	24		32-41-11	ALL
6		W0076	0211	24		32-41-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0076	0212	24		32-41-11	ALL
13		W0076	0418	22		27-62-11	ALL
14	UNUSED						ALL
D11409	**1083/266/L029**		**PLUG**				**ALL**
1		W3397	2012R	20		27-32-31	ALL
2		W3397	2012B	20		27-32-31	ALL
3		W3399	2011R	20		27-32-31	ALL
4		W3399	2011B	20		27-32-31	ALL
5	UNUSED						ALL
S/R		W3397	2012Z			27-32-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11409		**1083/266/L029**		**PLUG (continued)**				**ALL**
	S/R		W3399	2011Z			27-32-31	ALL
D11412		**378/179/L043**		**PLUG-**				**ALL**
	A		W2134	0501	10		24-51-13	ALL
	B		W2134	0502	10		24-51-13	ALL
	C		W2134	0503	10		24-51-13	ALL
	D		W2134	0506	10		24-51-12	ALL
	E		W2134	0505	10		24-51-12	ALL
	F	UNUSED						ALL
	G		W2134	0504	10		24-51-12	ALL
D11414		**378/179/L046**		**PLUG-**				**ALL**
	A		W2132	0001	08		24-51-14	ALL
	B		W2132	0002	08		24-51-14	ALL
	C		W2132	0003	08		24-51-14	ALL
	D		W2132	0007	08		24-51-15	ALL
	E		W2132	0004	08		24-51-11	ALL
	F		W2132	0005	08		24-51-15	ALL
	G		W2132	0006	08		24-51-15	ALL
D11416		**P091-00/ /**		**PLUG-**				**ALL**
	1		W5142	0089	18		33-22-11	ALL
	2	18	W5142	0091	18		33-22-11	ALL
	3		W5142	0090	22		33-22-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5142	0102	22		21-42-11	ALL
	8		W5142	0101	22		21-27-31	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11416	**P091-00/ /**		**PLUG- (continued)**				**ALL**
12		W5142	0094	22		33-22-11	ALL
13		W5142	0093	22		33-22-11	ALL
14		W5142	0059	22		33-22-11	ALL
15		W5142	2435R	18		33-23-12	ALL
16		W5142	5516	22		21-42-11	ALL
17		W5142	5517	22		21-42-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W5142	0021	22		38-41-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W5142	0026	22		33-26-11	ALL
27		W5142	2436R	18		33-23-12	ALL
28		W5142	2428R	18		33-23-11	ALL
29		W5142	2429R	18		33-23-11	ALL
30		W5142	2430R	18		33-23-11	ALL
31		W5142	2431R	18		33-23-11	ALL
32		W5142	2432R	18		33-23-12	ALL
33		W5142	2433R	18		33-23-12	ALL
34		W5142	2434R	18		33-23-12	ALL
35		W5142	0051	18		33-22-11	ALL
36		W5142	0052	18		33-22-11	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W5142	0040	18		33-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11416		**P091-00/ /**		**PLUG- (continued)**				**ALL**
	41		W5142	0103	18		24-52-11	ALL
	42		W5142	0104	18		24-52-11	ALL
	43		W5142	0105	18		24-52-11	ALL
	CAP	Y	W5142	0054	20		SPARE	ALL
	CAP	Y	W5142	0055	20		SPARE	ALL
	CAP	Y	W5142	0056	20		SPARE	ALL
D11418		**378/176/L043**		**PLUG-**				**ALL**
	1		W6110	5515	20		21-42-11	ALL
	2	UNUSED						ALL
	3		W6110	0033	22		25-51-21	ALL
	4		W6110	5514	24		21-42-11	ALL
	5		W6110	5516	20		21-42-11	ALL
	6		W6110	0009	20		33-34-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6110	0503	24		24-32-11	ALL
	11		W6110	5502	22		21-27-21	ALL
	12		W6110	0512	22		29-11-12	ALL
	13		W6110	0513	22		24-23-51	ALL
	14		W6110	0014	22		25-51-21	ALL
	15		W6110	5501	22		21-27-21	ALL
	16		W6110	0516	20		24-51-11	ALL
	17		W6110	0509	22		24-28-11	ALL
	18		W6110	0505	20		24-32-11	ALL
	19		W6110	0508	22		24-28-11	ALL
	20	UNUSED						ALL
	21		W6110	0501	22		24-22-11	ALL
	22		W6110	0511	22		29-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11418	**378/176/L043**		**PLUG- (continued)**				**ALL**
23	UNUSED						ALL
24		W6110	0504	24		24-32-11	ALL
D11420	**378/177/L047**		**PLUG-**				**ALL**
A		W5030	0501	12		24-52-11	ALL
B		W5030	0502	12		24-52-11	ALL
C		W5030	0503	12		24-52-11	ALL
D		W5030	0504	10		24-53-11	ALL
E	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
I	UNUSED						ALL
D11422	**378/177/L045**		**PLUG-**				**ALL**
1		W6110	0506	18		24-32-11	ALL
2		W6110	5503	20		21-27-21	ALL
3		W6110	5504	20		21-27-21	ALL
4		W6110	5505	20		21-27-21	ALL
5		W6110	0507	18		24-32-11	ALL
6		W6110	0510	18		24-32-11	ALL
7		W6110	5507	22		21-27-21	ALL
D11424	**378/174/L043**		**PLUG-**				**ALL**
A		W2136	0001	08		24-61-21	ALL
B	UNUSED						ALL
C		W2136	0002	10		24-61-22	ALL
D	UNUSED						ALL
E		W2136	0003	08		24-34-11	ALL
F	UNUSED						ALL
G	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11426		**P091-00/ /**		**PLUG-**				**ALL**
	A		W5036	0501	08		24-32-11	ALL
	B	UNUSED						ALL
	C		W5036	0502	08		24-32-11	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
D11428		**P091-00/ /**		**PLUG-**				**ALL**
	A		W5230	0510	12		49-41-11	ALL
	B		W5230	0511	12		49-41-11	ALL
	C		W5230	0512	12		49-41-11	ALL
	D		W5230	0504	10		29-11-12	ALL
	E		W5230	0505	10		29-11-12	ALL
	F		W5230	0506	10		29-11-12	ALL
	G		W5230	0515	12		38-32-12	ALL
	H		W5230	0516	12		38-32-12	ALL
	I		W5230	0517	12		38-32-12	ALL
D11430		**P091-00/ /**		**PLUG-**				**ALL**
	A		W3154	0001	08		25-31-11	ALL
	B		W3154	0002	08		25-31-11	ALL
	C		W3154	0003	08		25-31-11	ALL
	D		W3154	0013	10		25-31-11	ALL
	E		W3154	0012	10		25-31-11	ALL
	F		W3154	0011	10		25-31-11	ALL
	G		W3154	0022	08		24-51-11	ALL
D11432		**P091-00/ /**		**PLUG-**				**ALL**
	1		W5110	0501	22		24-23-51	ALL
	2	UNUSED						ALL
	3		W5110	0510	20		29-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11432	**P091-00/ /**		**PLUG- (continued)**				**ALL**
4		W5110	0503	22		24-28-41	ALL
5		W5110	0502	22		24-28-41	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5110	5501	22		21-27-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5110	0513	22		24-22-11	ALL
14		W5110	0519	22		24-22-21	ALL
15		W5110	0508	22		24-23-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W5110	0537	20		38-41-13	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5110	3203Y	20		24-31-12	ALL
25	UNUSED						ALL
26		W5110	4101Y	22		24-24-11	ALL
27		W5110	4101G	22		24-24-11	ALL
28	UNUSED						ALL
29		W5110	0507	22		24-23-11	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W5110	0532	22		24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11432		**P091-00/ /**		**PLUG- (continued)**				**ALL**
	33		W5110	0533	22		24-22-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W5110	0536	20		38-41-13	ALL
	40		W5110	0535	20		38-41-13	ALL
	41		W5110	0534	20		38-41-13	ALL
	42	UNUSED						ALL
	43		W5110	3203R	20		24-31-12	ALL
	44		W5110	3203B	20		24-31-12	ALL
	45	UNUSED						ALL
	46		W5110	4101R	22		24-24-11	ALL
	47		W5110	4101B	22		24-24-11	ALL
	48		W5110	3202B	20		24-23-11	ALL
	49		W5110	3202R	20		24-23-11	ALL
	50		W5110	0509	22		24-22-11	ALL
	51		W5110	3202Y	20		24-23-11	ALL
	52	UNUSED						ALL
	53		W5110	3201Y	20		24-22-11	ALL
	54	UNUSED						ALL
	55		W5110	3201R	20		24-22-11	ALL
	56		W5110	3201B	20		24-22-11	ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11432	**P091-00/ /**		**PLUG- (continued)**				**ALL**
S/R		W5110	4101Z			24-24-11	ALL
D11434	**P091-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5112	0501	20		24-53-11	ALL
2		W5112	0513	20		28-23-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5112	5501	22		21-27-31	ALL
9		W5112	3201R	20		28-23-11	ALL
10		W5112	3201Y	20		28-23-11	ALL
11		W5112	3201B	20		28-23-11	ALL
12		W5112	0515	20		28-23-11	ALL
13		W5112	0514	20		28-23-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5112	3206R	20		24-21-11	ALL
17		W5112	3206Y	20		24-21-11	ALL
18		W5112	3206B	20		24-21-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W5112	1001	20		24-41-11	ALL
22	UNUSED						ALL
23		W5112	0517	20		38-32-12	ALL
24		W5112	3203R	20		28-23-11	ALL
25		W5112	3203Y	20		28-23-11	ALL
26		W5112	3203B	20		28-23-11	ALL
27		W5112	0506	18		24-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11434		**P091-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	28		W5112	0507	18		24-32-11	ALL
	29		W5112	0508	18		24-32-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W5112	0516	18		38-32-12	ALL
	40	UNUSED						ALL
	41		W5112	3202R	18		28-23-11	ALL
	42		W5112	3202Y	18		28-23-11	ALL
	43		W5112	3202B	18		28-23-11	ALL
	S/R		W5112	1001Z			24-41-11	ALL
	S/R		W5112	3206Z			24-21-11	ALL
D11436		**P091-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5726	0569	20		24-51-11	ALL
	3	UNUSED						ALL
	4		W5726	4101B	20		24-21-31	ALL
	5		W5726	4101G	20		24-21-31	ALL
	6		W5726	4104G	22		24-24-31	ALL
	7		W5726	4104B	22		24-24-31	ALL
	8	UNUSED						ALL
	9		W5726	0572	22		24-22-31	ALL
	10		W5726	2238B	24		49-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11436	**P091-00/ /**		**PLUG- (continued)**				**ALL**
11		W5726	2238R	24		49-41-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W5726	4101Y	20		24-21-31	ALL
15		W5726	4101R	20		24-21-31	ALL
16	UNUSED						ALL
17		W5726	4104R	22		24-24-31	ALL
18		W5726	4104Y	22		24-24-31	ALL
19	UNUSED						ALL
20		W5726	3205R	20		24-22-31	ALL
21		W5726	3205Y	20		24-22-31	ALL
22	UNUSED						ALL
23		W5726	3205B	20		24-22-31	ALL
24		W5726	0571	22		24-22-31	ALL
D11438	**P091-00/ /**		**PLUG-**				**ALL**
1		W5726	4102R	20		24-21-31	ALL
2		W5726	3001B	16		25-51-21	ALL
3		W5726	3001R	16		25-51-21	ALL
4		W5726	3001Y	16		25-51-21	ALL
5		W5726	4102Y	20		24-21-31	ALL
6		W5726	4102B	20		24-21-31	ALL
7		W5726	0597	22		25-51-21	ALL
8		W5726	2237R	22		24-23-11	ALL
9	UNUSED						ALL
10		W5726	2239R	22		24-22-31	ALL
DED		W5726	2237Z			24-23-11	ALL
DED		W5726	2239Z			24-22-31	ALL
D11440	**P092/ /**		**PLUG-**				**ALL**
A		W6424	0001	08		24-61-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11440		**P092/ /**		**PLUG- (continued)**				**ALL**
	B	UNUSED						ALL
	C		W6424	0002	10		24-61-23	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
D11442		**P092/ /**		**PLUG-**				**ALL**
	A		W6424	0003	08		24-51-24	ALL
	B		W6424	0004	08		24-51-24	ALL
	C		W6424	0005	08		24-51-24	ALL
	D		W6424	0008	10		24-51-22	ALL
	E		W6424	0007	10		24-51-22	ALL
	F	UNUSED						ALL
	G		W6424	0006	10		24-51-22	ALL
D11444		**P092/ /**		**PLUG-**				**ALL**
	A		W6424	0009	10		24-51-23	ALL
	B		W6424	0010	10		24-51-23	ALL
	C		W6424	0011	10		24-51-23	ALL
	D		W6424	0018	08		24-51-25	ALL
	E		W6424	0017	08		24-51-25	ALL
	F		W6424	0016	08		24-51-25	ALL
	G		W6424	0012	08		24-51-21	ALL
D11446		**378/177/R42**		**PLUG-**				**ALL**
	1		W5030	0501	12		24-52-11	ALL
	2		W5030	0502	12		24-52-11	ALL
	3		W5030	0503	12		24-52-11	ALL
	4	UNUSED						ALL
D11448		**P092/176/R039**		**PLUG-**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11448	**P092/176/R039**		**PLUG- (continued)**				**ALL**
2		W6414	0002	20		33-32-11	ALL
3		W6414	0507	20		24-32-11	ALL
4		W6414	0502	24		SPARE	ALL
5		W6414	0504	24		24-32-11	ALL
6		W6414	0006	20		33-36-11	ALL
7		W6414	5506	22		21-27-21	ALL
8	UNUSED						ALL
9		W6414	0519	20		24-51-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6414	0510	22		24-28-11	ALL
13		W6414	0509	22		24-28-11	ALL
14		W6414	0014	20		25-29-11	ALL
15		W6414	0015	20		25-29-11	ALL
16		W6414	0501	22		24-41-11	ALL
17		W6414	0017	20		33-36-12	ALL
18		W6414	0503	24		24-32-11	ALL
19	UNUSED						ALL
20		W6414	0506	22		24-23-51	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W6414	0523	22		24-22-21	ALL
24	UNUSED						ALL
25		W6414	0514	22		29-22-11	ALL
26		W6414	5501	24		21-27-21	ALL
27		W6414	5502	20		21-27-21	ALL
28		W6414	5503	20		21-27-21	ALL
29		W6414	5504	20		21-27-21	ALL
30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11448		**P092/176/R039**		**PLUG- (continued)**				**ALL**
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W6414	5508	18		SPARE	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
D11450		**378/177/R044**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B		W6110	0507	18		24-32-11	ALL
	C		W6110	0510	18		24-32-11	ALL
	D		W6110	0517	10		24-53-11	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	I		W6110	0506	18		24-32-11	ALL
D11452		**P092-00/174/R039**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	18	W6242	0003	18		33-21-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11452	**P092-00/174/R039**		**PLUG- (continued)**				**ALL**
6	UNUSED						ALL
7		W6242	5507	22		21-27-31	ALL
8		W6242	5508	22		21-27-31	ALL
9		W6242	0509	22		29-11-12	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	18	W6242	0013	18		33-21-11	ALL
14		W6242	0014	22		33-21-11	ALL
15		W6242	2435R	18		33-23-22	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	18	W6242	0034	18		33-24-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W6242	0523	22		29-11-12	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W6242	0026	22		33-26-21	ALL
27		W6242	2436R	18		33-23-22	ALL
28		W6242	2428R	18		33-23-21	ALL
29		W6242	2429R	18		33-23-21	ALL
30		W6242	2430R	18		33-23-21	ALL
31		W6242	2431R	18		33-23-21	ALL
32		W6242	2432R	18		33-23-22	ALL
33		W6242	2433R	18		33-23-22	ALL
34		W6242	2434R	18		33-23-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11452		**P092-00/174/R039**		**PLUG- (continued)**				**ALL**
	35		W6242	0035	18		25-29-11	ALL
	36		W6242	0036	18		25-29-11	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	CAP	Y	W6242	0059	20		SPARE	ALL
	CAP	Y	W6242	0060	20		SPARE	ALL
D11454		**P092-00/179/R039**		**PLUG**				**ALL**
	1		W6410	2201B	20		24-41-11	ALL
	2	UNUSED						ALL
	3		W6410	0510	20		29-11-12	ALL
	4		W6410	0503	22		24-28-41	ALL
	5		W6410	0504	22		24-28-41	ALL
	6		W6410	0501	22		24-23-51	ALL
	7		W6410	0506	20		24-51-21	ALL
	8		W6410	5501	22		21-27-31	ALL
	9		W6410	0009	20		33-36-12	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W6410	0505	22		24-22-31	ALL
	13		W6410	0520	22		24-22-11	ALL
	14		W6410	0519	22		24-22-21	ALL
	15		W6410	0515	22		24-23-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11454	**P092-00/179/R039**		**PLUG (continued)**				**ALL**
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W6410	0021	20		33-36-11	ALL
22	UNUSED						ALL
23		W6410	0023	20		33-36-12	ALL
24		W6410	4102G	22		24-41-11	ALL
25		W6410	4102Y	22		24-41-11	ALL
26		W6410	4101Y	22		24-24-21	ALL
27		W6410	4101G	22		24-24-21	ALL
28	UNUSED						ALL
29		W6410	0514	22		24-23-21	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W6410	0517	22		24-22-21	ALL
33		W6410	0518	22		24-22-21	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W6410	0039	20		33-36-11	ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W6410	0042	20		33-33-11	ALL
43	UNUSED						ALL
44		W6410	4102B	22		24-41-11	ALL
45		W6410	4102R	22		24-41-11	ALL
46		W6410	4101R	22		24-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11454		**P092-00/179/R039**		**PLUG (continued)**				**ALL**
	47		W6410	4101B	22		24-24-21	ALL
	48		W6410	3202B	20		24-23-21	ALL
	49		W6410	3202R	20		24-23-21	ALL
	50		W6410	0516	22		24-22-21	ALL
	51		W6410	3202Y	20		24-23-21	ALL
	52	UNUSED						ALL
	53		W6410	3201Y	20		24-22-21	ALL
	54	UNUSED						ALL
	55		W6410	3201R	20		24-22-21	ALL
	56		W6410	3201B	20		24-22-21	ALL
	57	UNUSED						ALL
	58		W6410	2201R	20		24-41-11	ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61	UNUSED						ALL
	S/R		W6410	4101Z			24-24-21	ALL
D11456		**P092-00/ /**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D		W6128	0504	10		29-11-12	ALL
	E		W6128	0505	10		29-11-12	ALL
	F		W6128	0506	10		29-11-12	ALL
	G		W6128	0007	18		24-32-11	ALL
	H		W6128	0008	18		24-32-11	ALL
	I		W6128	0009	18		24-32-11	ALL
D11458		**P0092-00/179/R039**		**PLUG-**				**ALL**
	A		W4256	0101	08		25-31-11	ALL
	B		W4256	0102	08		25-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11458	**P0092-00/179/R039**		**PLUG- (continued)**				**ALL**
C		W4256	0103	08		25-31-11	ALL
D		W4256	0013	10		25-31-11	ALL
E		W4256	0012	10		25-31-11	ALL
F		W4256	0011	10		25-31-11	ALL
G		W4256	0022	08		24-51-21	ALL
D11470	**868/179/L043**		**PLUG-**				**ALL**
1		W6248	5548	20		30-71-11	ALL
2		W6248	5549	20		30-71-11	ALL
3	UNUSED						ALL
D11478A	**E002-02/ /**		**PLUG**				**ALL**
1		W0220	3201Y	22		49-41-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0220	3201R	22		49-41-11	ALL
9		W0220	3201B	22		49-41-11	ALL
10		W0220	2016R	22		49-41-11	ALL
11		W0220	2016B	22		49-41-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0220	2047R	22		49-41-11	ALL
15	UNUSED						ALL
16		W0220	2018R	22		49-41-11	ALL
17		W0220	2018B	22		49-41-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11478A		**E002-02/ /**		**PLUG (continued)**				**ALL**
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W0220	2020R	22		49-41-11	ALL
	25		W0220	2020B	22		49-41-11	ALL
	26	UNUSED						ALL
	27		W0220	2047B	22		49-41-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0220	2022R	22		49-41-11	ALL
	31		W0220	2022B	22		49-41-11	ALL
	32	UNUSED						ALL
	33		W0220	3002R	22		49-41-11	ALL
	34		W0220	3002B	22		49-41-11	ALL
	35		W0220	3002Y	22		49-41-11	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43		W0220	2021R	22		49-41-11	ALL
	44		W0220	2021B	22		49-41-11	ALL
	45	UNUSED						ALL
	46		W0220	0114	22		49-41-11	ALL
	47		W0220	0227	22		49-41-11	ALL
	48	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11478A	**E002-02/ /**		**PLUG (continued)**				**ALL**
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W0220	2023R	22		49-41-11	ALL
56		W0220	2023B	22		49-41-11	ALL
57	UNUSED						ALL
58	UNUSED						ALL
59	UNUSED						ALL
60	UNUSED						ALL
61	UNUSED						ALL
62		W0220	2019R	22		49-41-11	ALL
63		W0220	2019B	22		49-41-11	ALL
64	UNUSED						ALL
65	UNUSED						ALL
66	UNUSED						ALL
67	UNUSED						ALL
DED		W0220	2047Z			49-41-11	ALL
D11478B	**E002-02/ /**		**PLUG**				**ALL**
1		W0220	2024R	16		49-41-11	ALL
2		W0220	2025R	16		49-41-11	ALL
3		W0220	2024B	16		49-41-11	ALL
4		W0220	2025B	16		49-41-11	ALL
5		W0220	0115	12		49-41-11	ALL
6		W0220	0116	12		49-41-11	ALL
7		W0220	0117	12		49-41-11	ALL
8		W0220	FRAK			49-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11478B		**E002-02/ /**		**PLUG (continued)**				**ALL**
			W0220	2024Z			49-41-11	ALL
			W0220	2025Z			49-41-11	ALL
			W0220	FRAK			49-41-11	ALL
D11480		**962/291/R026**		**PLUG-**				**ALL**
	1		W0152	0011	18		35-21-21	ALL
	2		W0152	0012	18		35-21-21	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11500	**367/272/L055**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0491W	20		33-25-21	ALL
2		W3150	0492WV	22		33-27-21	ALL
3		W3150	0493WG	22		33-27-21	ALL
4		W3150	0494WO	22		33-27-21	ALL
5		W3150	0495V	22		33-27-21	ALL
6		W3150	0496N	18		33-23-11	ALL
7		W3150	0497W	20		33-25-21	ALL
8		W3150	0498O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0500K	18		33-27-21	ALL
11		W3150	0499A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2001R	22		23-31-02	ALL
14		W3150	2001B	22		23-31-02	ALL
D11502	**374/272/L056**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0501W	20		33-25-21	ALL
2		W3150	0502WV	22		33-27-21	ALL
3		W3150	0503WG	22		33-27-21	ALL
4		W3150	0504WO	22		33-27-21	ALL
5		W3150	0505V	22		33-27-21	ALL
6		W3150	0506N	18		33-23-11	ALL
7		W3150	0507W	20		33-25-21	ALL
8		W3150	0508O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0510K	18		33-27-21	ALL
11		W3150	0509A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2011R	22		23-31-02	ALL
14		W3150	2011B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11504		**402/278/L050**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0511W	20		33-25-21	ALL
	2		W3150	0512WV	22		33-27-21	ALL
	3		W3150	0513WG	22		33-27-21	ALL
	4		W3150	0514WO	22		33-27-21	ALL
	5		W3150	0515V	22		33-27-21	ALL
	6		W3150	0516N	18		33-23-11	ALL
	7		W3150	0517W	20		33-25-21	ALL
	8		W3150	0518O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0520K	18		33-27-21	ALL
	11		W3150	0519A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2021R	22		23-31-02	ALL
	14		W3150	2021B	22		23-31-02	ALL
D11506		**430/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0521W	20		33-25-21	ALL
	2		W3150	0522WV	22		33-27-21	ALL
	3		W3150	0523WG	22		33-27-21	ALL
	4		W3150	0524WO	22		33-27-21	ALL
	5		W3150	0525V	22		33-27-21	ALL
	6		W3150	0526N	18		33-23-11	ALL
	7		W3150	0527W	20		33-25-21	ALL
	8		W3150	0528O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0530K	18		33-27-21	ALL
	11		W3150	0529A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2031R	22		23-31-02	ALL
	14		W3150	2031B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11508	**450/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0531W	20		33-25-21	ALL
2		W3150	0532WV	22		33-27-21	ALL
3		W3150	0533WG	22		33-27-21	ALL
4		W3150	0534WO	22		33-27-21	ALL
5		W3150	0535V	22		33-27-21	ALL
6		W3150	0536N	18		33-23-11	ALL
7		W3150	0537W	20		33-25-21	ALL
8		W3150	0538O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0540K	18		33-27-21	ALL
11		W3150	0539A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2041R	22		23-31-02	ALL
14		W3150	2041B	22		23-31-02	ALL
D11510	**470/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0541W	20		33-25-21	ALL
2		W3150	0542WV	22		33-27-21	ALL
3		W3150	0543WG	22		33-27-21	ALL
4		W3150	0544WO	22		33-27-21	ALL
5		W3150	0545V	22		33-27-21	ALL
6		W3150	0546N	18		33-23-11	ALL
7		W3150	0547W	20		33-25-21	ALL
8		W3150	0548O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0550K	18		33-27-21	ALL
11		W3150	0549A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2051R	22		23-31-02	ALL
14		W3150	2051B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11512		**490/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0551W	20		33-25-21	ALL
	2		W3150	0552WV	22		33-27-21	ALL
	3		W3150	0553WG	22		33-27-21	ALL
	4		W3150	0554WO	22		33-27-21	ALL
	5		W3150	0555V	22		33-27-21	ALL
	6		W3150	0556N	18		33-23-11	ALL
	7		W3150	0557W	20		33-25-21	ALL
	8		W3150	0558O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0560K	18		33-27-21	ALL
	11		W3150	0559A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2061R	22		23-31-02	ALL
	14		W3150	2061B	22		23-31-02	ALL
D11514		**500+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0561W	20		33-25-21	ALL
	2		W3150	0562WV	22		33-27-21	ALL
	3		W3150	0563WG	22		33-27-21	ALL
	4		W3150	0564WO	22		33-27-21	ALL
	5		W3150	0565V	22		33-27-21	ALL
	6		W3150	0566N	18		33-23-11	ALL
	7		W3150	0567W	20		33-25-21	ALL
	8		W3150	0568O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0570K	18		33-27-21	ALL
	11		W3150	0569A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2071R	22		23-31-02	ALL
	14		W3150	2071B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11516	**500A+12/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0571W	20		33-25-21	ALL
2		W3150	0572WV	22		33-27-21	ALL
3		W3150	0573WG	22		33-27-21	ALL
4		W3150	0574WO	22		33-27-21	ALL
5		W3150	0575V	22		33-27-21	ALL
6		W3150	0576N	18		33-23-11	ALL
7		W3150	0577W	20		33-25-21	ALL
8		W3150	0578O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0580K	18		33-27-21	ALL
11		W3150	0579A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2081R	22		23-31-02	ALL
14		W3150	2081B	22		23-31-02	ALL
D11518	**500B+12/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0581W	20		33-25-21	ALL
2		W3150	0582WV	22		33-27-21	ALL
3		W3150	0583WG	22		33-27-21	ALL
4		W3150	0584WO	22		33-27-21	ALL
5		W3150	0585V	22		33-27-21	ALL
6		W3150	0586N	18		33-23-11	ALL
7		W3150	0587W	20		33-25-21	ALL
8		W3150	0588O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0590K	18		33-27-21	ALL
11		W3150	0589A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2091R	22		23-31-02	ALL
14		W3150	2091B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11520		**500C+12/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0591W	20		33-25-21	ALL
	2		W3150	0592WV	22		33-27-21	ALL
	3		W3150	0593WG	22		33-27-21	ALL
	4		W3150	0594WO	22		33-27-21	ALL
	5		W3150	0595V	22		33-27-21	ALL
	6		W3150	0596N	18		33-23-11	ALL
	7		W3150	0597W	20		33-25-21	ALL
	8		W3150	0598O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0600K	18		33-27-21	ALL
	11		W3150	0599A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2201R	22		23-31-02	ALL
	14		W3150	2201B	22		23-31-02	ALL
D11522		**500D+12/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0601W	20		33-25-21	ALL
	2		W3150	0602WV	22		33-27-21	ALL
	3		W3150	0603WG	22		33-27-21	ALL
	4		W3150	0604WO	22		33-27-21	ALL
	5		W3150	0605V	22		33-27-21	ALL
	6		W3150	0606N	18		33-23-11	ALL
	7		W3150	0607W	20		33-25-21	ALL
	8		W3150	0608O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0610K	18		33-27-21	ALL
	11		W3150	0609A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2211R	22		23-31-02	ALL
	14		W3150	2211B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11524	**500E+16/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0611W	20		33-25-21	ALL
2		W3150	0612WV	22		33-27-21	ALL
3		W3150	0613WG	22		33-27-21	ALL
4		W3150	0614WO	22		33-27-21	ALL
5		W3150	0615V	22		33-27-21	ALL
6		W3150	0616N	18		33-23-11	ALL
7		W3150	0617W	20		33-25-21	ALL
8		W3150	0618O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0620K	18		33-27-21	ALL
11		W3150	0619A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2221R	22		23-31-02	ALL
14		W3150	2221B	22		23-31-02	ALL
D11526	**500F+14/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0621W	20		33-25-21	ALL
2		W3150	0622WV	22		33-27-21	ALL
3		W3150	0623WG	22		33-27-21	ALL
4		W3150	0624WO	22		33-27-21	ALL
5		W3150	0625V	22		33-27-21	ALL
6		W3150	0626N	18		33-23-11	ALL
7		W3150	0627W	20		33-25-21	ALL
8		W3150	0628O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0630K	18		33-27-21	ALL
11		W3150	0629A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2231R	22		23-31-02	ALL
14		W3150	2231B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11528		**500G+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0631W	20		33-25-21	ALL
	2		W3150	0632WV	22		33-27-21	ALL
	3		W3150	0633WG	22		33-27-21	ALL
	4		W3150	0634WO	22		33-27-21	ALL
	5		W3150	0635V	22		33-27-21	ALL
	6		W3150	0636N	18		33-23-11	ALL
	7		W3150	0637W	20		33-25-21	ALL
	8		W3150	0638O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0640K	18		33-27-21	ALL
	11		W3150	0639A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2241R	22		23-31-02	ALL
	14		W3150	2241B	22		23-31-02	ALL
D11530		**500H+6/274/L052**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0641W	20		33-25-21	ALL
	2		W3150	0642WV	22		33-27-21	ALL
	3		W3150	0643WG	22		33-27-21	ALL
	4		W3150	0644WO	22		33-27-21	ALL
	5		W3150	0645V	22		33-27-21	ALL
	6		W3150	0646N	18		33-23-11	ALL
	7		W3150	0647W	20		33-25-21	ALL
	8		W3150	0648O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0650K	18		33-27-21	ALL
	11		W3150	0649A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2251R	22		23-31-02	ALL
	14		W3150	2251B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11532	**500I+16/273/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0651W	20		33-25-21	ALL
2		W3150	0652WV	22		33-27-21	ALL
3		W3150	0653WG	22		33-27-21	ALL
4		W3150	0654WO	22		33-27-21	ALL
5		W3150	0655V	22		33-27-21	ALL
6		W3150	0656N	18		33-23-11	ALL
7		W3150	0657W	20		33-25-21	ALL
8		W3150	0658O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0660K	18		33-27-21	ALL
11		W3150	0659A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2261R	22		23-31-02	ALL
14		W3150	2261B	22		23-31-02	ALL
D11534	**531/273/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0661W	20		33-25-21	ALL
2		W3150	0662WV	22		33-27-21	ALL
3		W3150	0663WG	22		33-27-21	ALL
4		W3150	0664WO	22		33-27-21	ALL
5		W3150	0665V	22		33-27-21	ALL
6		W3150	0666N	18		33-23-11	ALL
7		W3150	0667W	20		33-25-21	ALL
8		W3150	0668O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0670K	18		33-27-21	ALL
11		W3150	0669A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2271R	22		23-31-02	ALL
14		W3150	2271B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11536		**565/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0671W	20		33-25-21	ALL
	2		W3150	0672WV	22		33-27-21	ALL
	3		W3150	0673WG	22		33-27-21	ALL
	4		W3150	0674WO	22		33-27-21	ALL
	5		W3150	0675V	22		33-27-21	ALL
	6		W3150	0676N	18		33-23-11	ALL
	7		W3150	0677W	20		33-25-21	ALL
	8		W3150	0678O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0680K	18		33-27-21	ALL
	11		W3150	0679A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2281R	22		23-31-02	ALL
	14		W3150	2281B	22		23-31-02	ALL
D11538		**588/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0681W	20		33-25-21	ALL
	2		W3150	0682WV	22		33-27-21	ALL
	3		W3150	0683WG	22		33-27-21	ALL
	4		W3150	0684WO	22		33-27-21	ALL
	5		W3150	0685V	22		33-27-21	ALL
	6		W3150	0686N	18		33-23-11	ALL
	7		W3150	0687W	20		33-25-21	ALL
	8		W3150	0688O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0690K	18		33-27-21	ALL
	11		W3150	0689A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2291R	22		23-31-02	ALL
	14		W3150	2291B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11540	**611/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0691W	20		33-25-21	ALL
2		W3150	0692WV	22		33-27-21	ALL
3		W3150	0693WG	22		33-27-21	ALL
4		W3150	0694WO	22		33-27-21	ALL
5		W3150	0695V	22		33-27-21	ALL
6		W3150	0696N	18		33-23-11	ALL
7		W3150	0697W	20		33-25-21	ALL
8		W3150	0698O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0700K	18		33-27-21	ALL
11		W3150	0699A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2401R	22		23-31-02	ALL
14		W3150	2401B	22		23-31-02	ALL
D11542	**630/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0701W	20		33-25-21	ALL
2		W3150	0702WV	22		33-27-21	ALL
3		W3150	0703WG	22		33-27-21	ALL
4		W3150	0704WO	22		33-27-21	ALL
5		W3150	0705V	22		33-27-21	ALL
6		W3150	0706N	18		33-23-11	ALL
7		W3150	0707W	20		33-25-21	ALL
8		W3150	0708O	18		33-23-11	ALL
9	UNUSED						ALL
10		W3150	0710K	18		33-27-21	ALL
11		W3150	0709A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2411R	22		23-31-02	ALL
14		W3150	2411B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11544		**660/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0711W	20		33-25-21	ALL
	2		W3150	0712WV	22		33-27-21	ALL
	3		W3150	0713WG	22		33-27-21	ALL
	4		W3150	0714WO	22		33-27-21	ALL
	5		W3150	0715V	22		33-27-21	ALL
	6		W3150	0716N	18		33-23-11	ALL
	7		W3150	0717W	20		33-25-21	ALL
	8		W3150	0718O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0720K	18		33-27-21	ALL
	11		W3150	0719A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2421R	22		23-31-02	ALL
	14		W3150	2421B	22		23-31-02	ALL
D11546		**680/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0721W	20		33-25-21	ALL
	2		W3150	0722WV	22		33-27-21	ALL
	3		W3150	0723WG	22		33-27-21	ALL
	4		W3150	0724WO	22		33-27-21	ALL
	5		W3150	0725V	22		33-27-21	ALL
	6		W3150	0726N	18		33-23-11	ALL
	7		W3150	0727W	20		33-25-21	ALL
	8		W3150	0728O	18		33-23-11	ALL
	9	UNUSED						ALL
	10		W3150	0730K	18		33-27-21	ALL
	11		W3150	0729A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2431R	22		23-31-02	ALL
	14		W3150	2431B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11548	**700/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0731W	20		33-25-22	ALL
2		W3150	0732WV	22		33-27-22	ALL
3		W3150	0733WG	22		33-27-22	ALL
4		W3150	0734WO	22		33-27-22	ALL
5		W3150	0735V	22		33-27-22	ALL
6		W3150	0736N	18		33-23-12	ALL
7		W3150	0737W	20		33-25-22	ALL
8		W3150	0738O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0740K	18		33-27-22	ALL
11		W3150	0739A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2441R	22		23-31-02	ALL
14		W3150	2441B	22		23-31-02	ALL
D11550	**726/272/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0741W	20		33-25-22	ALL
2		W3150	0742WV	22		33-27-22	ALL
3		W3150	0743WG	22		33-27-22	ALL
4		W3150	0744WO	22		33-27-22	ALL
5		W3150	0745V	22		33-27-22	ALL
6		W3150	0746N	18		33-23-12	ALL
7		W3150	0747W	20		33-25-22	ALL
8		W3150	0748O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0750K	18		33-27-22	ALL
11		W3150	0749A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2451R	22		23-31-02	ALL
14		W3150	2451B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11552		**727+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0751W	20		33-25-22	ALL
	2		W3150	0752WV	22		33-27-22	ALL
	3		W3150	0753WG	22		33-27-22	ALL
	4		W3150	0754WO	22		33-27-22	ALL
	5		W3150	0755V	22		33-27-22	ALL
	6		W3150	0756N	18		33-23-12	ALL
	7		W3150	0757W	20		33-25-22	ALL
	8		W3150	0758O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0760K	18		33-27-22	ALL
	11		W3150	0759A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2461R	22		23-31-02	ALL
	14		W3150	2461B	22		23-31-02	ALL
D11554		**727A+16/272/L054**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0761W	20		33-25-22	ALL
	2		W3150	0762WV	22		33-27-22	ALL
	3		W3150	0763WG	22		33-27-22	ALL
	4		W3150	0764WO	22		33-27-22	ALL
	5		W3150	0765V	22		33-27-22	ALL
	6		W3150	0766N	18		33-23-12	ALL
	7		W3150	0767W	20		33-25-22	ALL
	8		W3150	0768O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0770K	18		33-27-22	ALL
	11		W3150	0769A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2471R	22		23-31-02	ALL
	14		W3150	2471B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11556	**727B+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0771W	20		33-25-22	ALL
2		W3150	0772WV	22		33-27-22	ALL
3		W3150	0773WG	22		33-27-22	ALL
4		W3150	0774WO	22		33-27-22	ALL
5		W3150	0775V	22		33-27-22	ALL
6		W3150	0776N	18		33-23-12	ALL
7		W3150	0777W	20		33-25-22	ALL
8		W3150	0778O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0780K	18		33-27-22	ALL
11		W3150	0779A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2481R	22		23-31-02	ALL
14		W3150	2481B	22		23-31-02	ALL
D11558	**727C+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0781W	20		33-25-22	ALL
2		W3150	0782WV	22		33-27-22	ALL
3		W3150	0783WG	22		33-27-22	ALL
4		W3150	0784WO	22		33-27-22	ALL
5		W3150	0785V	22		33-27-22	ALL
6		W3150	0786N	18		33-23-12	ALL
7		W3150	0787W	20		33-25-22	ALL
8		W3150	0788O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0790K	18		33-27-22	ALL
11		W3150	0789A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2491R	22		23-31-02	ALL
14		W3150	2491B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11560		**727D+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0791W	20		33-25-22	ALL
	2		W3150	0792WV	22		33-27-22	ALL
	3		W3150	0793WG	22		33-27-22	ALL
	4		W3150	0794WO	22		33-27-22	ALL
	5		W3150	0795V	22		33-27-22	ALL
	6		W3150	0796N	18		33-23-12	ALL
	7		W3150	0797W	20		33-25-22	ALL
	8		W3150	0798O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0800K	18		33-27-22	ALL
	11		W3150	0799A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2601R	22		23-31-02	ALL
	14		W3150	2601B	22		23-31-02	ALL
D11562		**727E+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0801W	20		33-25-22	ALL
	2		W3150	0802WV	22		33-27-22	ALL
	3		W3150	0803WG	22		33-27-22	ALL
	4		W3150	0804WO	22		33-27-22	ALL
	5		W3150	0805V	22		33-27-22	ALL
	6		W3150	0806N	18		33-23-12	ALL
	7		W3150	0807W	20		33-25-22	ALL
	8		W3150	0808O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0810K	18		33-27-22	ALL
	11		W3150	0809A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2611R	22		23-31-02	ALL
	14		W3150	2611B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11564	**727F+10/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0811W	20		33-25-22	ALL
2		W3150	0812WV	22		33-27-22	ALL
3		W3150	0813WG	22		33-27-22	ALL
4		W3150	0814WO	22		33-27-22	ALL
5		W3150	0815V	22		33-27-22	ALL
6		W3150	0816N	18		33-23-12	ALL
7		W3150	0817W	20		33-25-22	ALL
8		W3150	0818O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0820K	18		33-27-22	ALL
11		W3150	0819A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2621R	22		23-31-02	ALL
14		W3150	2621B	22		23-31-02	ALL
D11566	**727G+12/272/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0821W	20		33-25-22	ALL
2		W3150	0822WV	22		33-27-22	ALL
3		W3150	0823WG	22		33-27-22	ALL
4		W3150	0824WO	22		33-27-22	ALL
5		W3150	0825V	22		33-27-22	ALL
6		W3150	0826N	18		33-23-12	ALL
7		W3150	0827W	20		33-25-22	ALL
8		W3150	0828O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0830K	18		33-27-22	ALL
11		W3150	0829A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2631R	22		23-31-02	ALL
14		W3150	2631B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11568		**727H+8/272/L054**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0831W	20		33-25-22	ALL
	2		W3150	0832WV	22		33-27-22	ALL
	3		W3150	0833WG	22		33-27-22	ALL
	4		W3150	0834WO	22		33-27-22	ALL
	5		W3150	0835V	22		33-27-22	ALL
	6		W3150	0836N	18		33-23-12	ALL
	7		W3150	0837W	20		33-25-22	ALL
	8		W3150	0838O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0840K	18		33-27-22	ALL
	11		W3150	0839A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2641R	22		23-31-02	ALL
	14		W3150	2641B	22		23-31-02	ALL
D11570		**727I+16/272/L054**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0841W	20		33-25-22	ALL
	2		W3150	0842WV	22		33-27-22	ALL
	3		W3150	0843WG	22		33-27-22	ALL
	4		W3150	0844WO	22		33-27-22	ALL
	5		W3150	0845V	22		33-27-22	ALL
	6		W3150	0846N	18		33-23-12	ALL
	7		W3150	0847W	20		33-25-22	ALL
	8		W3150	0848O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0850K	18		33-27-22	ALL
	11		W3150	0849A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2651R	22		23-31-02	ALL
	14		W3150	2651B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11572	**727J+8/272/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0851W	20		33-25-22	ALL
2		W3150	0852WV	22		33-27-22	ALL
3		W3150	0853WG	22		33-27-22	ALL
4		W3150	0854WO	22		33-27-22	ALL
5		W3150	0855V	22		33-27-22	ALL
6		W3150	0856N	18		33-23-12	ALL
7		W3150	0857W	20		33-25-22	ALL
8		W3150	0858O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0860K	18		33-27-22	ALL
11		W3150	0859A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2661R	22		23-31-02	ALL
14		W3150	2661B	22		23-31-02	ALL
D11574	**763/272/L054**		**RCPT-PSU LEFT**				**ALL**
1		W3150	0861W	20		33-25-22	ALL
2		W3150	0862WV	22		33-27-22	ALL
3		W3150	0863WG	22		33-27-22	ALL
4		W3150	0864WO	22		33-27-22	ALL
5		W3150	0865V	22		33-27-22	ALL
6		W3150	0866N	18		33-23-12	ALL
7		W3150	0867W	20		33-25-22	ALL
8		W3150	0868O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	0870K	18		33-27-22	ALL
11		W3150	0869A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2671R	22		23-31-02	ALL
14		W3150	2671B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11576		**775/272/L054**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0871W	20		33-25-22	ALL
	2		W3150	0872WV	22		33-27-22	ALL
	3		W3150	0873WG	22		33-27-22	ALL
	4		W3150	0874WO	22		33-27-22	ALL
	5		W3150	0875V	22		33-27-22	ALL
	6		W3150	0876N	18		33-23-12	ALL
	7		W3150	0877W	20		33-25-22	ALL
	8		W3150	0878O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0880K	18		33-27-22	ALL
	11		W3150	0879A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2681R	22		23-31-02	ALL
	14		W3150	2681B	22		23-31-02	ALL
D11578		**802/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	0881W	20		33-25-22	ALL
	2		W3150	0882WV	22		33-27-22	ALL
	3		W3150	0883WG	22		33-27-22	ALL
	4		W3150	0884WO	22		33-27-22	ALL
	5		W3150	0885V	22		33-27-22	ALL
	6		W3150	0886N	18		33-23-12	ALL
	7		W3150	0887W	20		33-25-22	ALL
	8		W3150	0888O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	0890K	18		33-27-22	ALL
	11		W3150	0889A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2691R	22		23-31-02	ALL
	14		W3150	2691B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11580	**822/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	5601W	20		33-25-22	ALL
2		W3150	5602WV	22		33-27-22	ALL
3		W3150	5603WG	22		33-27-22	ALL
4		W3150	5604WO	22		33-27-22	ALL
5		W3150	5605V	22		33-27-22	ALL
6		W3150	5606N	18		33-23-12	ALL
7		W3150	5607W	20		33-25-22	ALL
8		W3150	5608O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	5610K	18		33-27-22	ALL
11		W3150	5609A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2701R	22		23-31-02	ALL
14		W3150	2701B	22		23-31-02	ALL
D11582	**842/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	5611W	20		33-25-22	ALL
2		W3150	5612WV	22		33-27-22	ALL
3		W3150	5613WG	22		33-27-22	ALL
4		W3150	5614WO	22		33-27-22	ALL
5		W3150	5615V	22		33-27-22	ALL
6		W3150	5616N	18		33-23-12	ALL
7		W3150	5617W	20		33-25-22	ALL
8		W3150	5618O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	5620K	18		33-27-22	ALL
11		W3150	5619A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2711R	22		23-31-02	ALL
14		W3150	2711B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11584		**865/274/L051**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	5621W	20		33-25-22	ALL
	2		W3150	5622WV	22		33-27-22	ALL
	3		W3150	5623WG	22		33-27-22	ALL
	4		W3150	5624WO	22		33-27-22	ALL
	5		W3150	5625V	22		33-27-22	ALL
	6		W3150	5626N	18		33-23-12	ALL
	7		W3150	5627W	20		33-25-22	ALL
	8		W3150	5628O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	5630K	18		33-27-22	ALL
	11		W3150	5629A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2721R	22		23-31-02	ALL
	14		W3150	2721B	22		23-31-02	ALL
D11586		**898/274/L056**		**RCPT-PSU LEFT**				**ALL**
	1		W3150	5631W	20		33-25-22	ALL
	2		W3150	5632WV	22		33-27-22	ALL
	3		W3150	5633WG	22		33-27-22	ALL
	4		W3150	5634WO	22		33-27-22	ALL
	5		W3150	5635V	22		33-27-22	ALL
	6		W3150	5636N	18		33-23-12	ALL
	7		W3150	5637W	20		33-25-22	ALL
	8		W3150	5638O	18		33-23-12	ALL
	9	UNUSED						ALL
	10		W3150	5640K	18		33-27-22	ALL
	11		W3150	5639A	16		35-21-21	ALL
	12	UNUSED						ALL
	13		W3150	2731R	22		23-31-02	ALL
	14		W3150	2731B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11588	**924/274/L051**		**RCPT-PSU LEFT**				**ALL**
1		W3150	5641W	20		33-25-22	ALL
2		W3150	5642WV	22		33-27-22	ALL
3		W3150	5643WG	22		33-27-22	ALL
4		W3150	5644WO	22		33-27-22	ALL
5		W3150	5645V	22		33-27-22	ALL
6		W3150	5646N	18		33-23-12	ALL
7		W3150	5647W	20		33-25-22	ALL
8		W3150	5648O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	5650K	18		33-27-22	ALL
11		W3150	5649A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2741R	22		23-31-02	ALL
14		W3150	2741B	22		23-31-02	ALL
D11590	**943/277/L050**		**RCPT-PSU LEFT**				**ALL**
1		W3150	5651W	20		33-25-22	ALL
2		W3150	5652WV	22		33-27-22	ALL
3		W3150	5653WG	22		33-27-22	ALL
4		W3150	5654WO	22		33-27-22	ALL
5		W3150	5655V	22		33-27-22	ALL
6		W3150	5656N	18		33-23-12	ALL
7		W3150	5657W	20		33-25-22	ALL
8		W3150	5658O	18		33-23-12	ALL
9	UNUSED						ALL
10		W3150	5660K	18		33-27-22	ALL
11		W3150	5659A	16		35-21-21	ALL
12	UNUSED						ALL
13		W3150	2751R	22		23-31-02	ALL
14		W3150	2751B	22		23-31-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11600		**360/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0491W	20		33-25-31	ALL
	2		W4250	0492WV	22		33-27-31	ALL
	3		W4250	0493WG	22		33-27-31	ALL
	4		W4250	0494WO	22		33-27-31	ALL
	5		W4250	0495V	22		33-27-31	ALL
	6		W4250	0496N	18		33-23-21	ALL
	7		W4250	0497W	20		33-25-31	ALL
	8		W4250	0498O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0500K	18		33-27-31	ALL
	11		W4250	0499A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2001R	22		23-31-03	ALL
	14		W4250	2001B	22		23-31-03	ALL
D11602		**391/273/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0501W	20		33-25-31	ALL
	2		W4250	0502WV	22		33-27-31	ALL
	3		W4250	0503WG	22		33-27-31	ALL
	4		W4250	0504WO	22		33-27-31	ALL
	5		W4250	0505V	22		33-27-31	ALL
	6		W4250	0506N	18		33-23-21	ALL
	7		W4250	0507W	20		33-25-31	ALL
	8		W4250	0508O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0510K	18		33-27-31	ALL
	11		W4250	0509A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2011R	22		23-31-03	ALL
	14		W4250	2011B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11604	**410/273/R052**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0511W	20		33-25-31	ALL
2		W4250	0512WV	22		33-27-31	ALL
3		W4250	0513WG	22		33-27-31	ALL
4		W4250	0514WO	22		33-27-31	ALL
5		W4250	0515V	22		33-27-31	ALL
6		W4250	0516N	18		33-23-21	ALL
7		W4250	0517W	20		33-25-31	ALL
8		W4250	0518O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0520K	18		33-27-31	ALL
11		W4250	0519A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2021R	22		23-31-03	ALL
14		W4250	2021B	22		23-31-03	ALL
D11606	**431/273/R052**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0521W	20		33-25-31	ALL
2		W4250	0522WV	22		33-27-31	ALL
3		W4250	0523WG	22		33-27-31	ALL
4		W4250	0524WO	22		33-27-31	ALL
5		W4250	0525V	22		33-27-31	ALL
6		W4250	0526N	18		33-23-21	ALL
7		W4250	0527W	20		33-25-31	ALL
8		W4250	0528O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0530K	18		33-27-31	ALL
11		W4250	0529A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2031R	22		23-31-03	ALL
14		W4250	2031B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11608		**450/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0531W	20		33-25-31	ALL
	2		W4250	0532WV	22		33-27-31	ALL
	3		W4250	0533WG	22		33-27-31	ALL
	4		W4250	0534WO	22		33-27-31	ALL
	5		W4250	0535V	22		33-27-31	ALL
	6		W4250	0536N	18		33-23-21	ALL
	7		W4250	0537W	20		33-25-31	ALL
	8		W4250	0538O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0540K	18		33-27-31	ALL
	11		W4250	0539A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2041R	22		23-31-03	ALL
	14		W4250	2041B	22		23-31-03	ALL
D11610		**470/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0541W	20		33-25-31	ALL
	2		W4250	0542WV	22		33-27-31	ALL
	3		W4250	0543WG	22		33-27-31	ALL
	4		W4250	0544WO	22		33-27-31	ALL
	5		W4250	0545V	22		33-27-31	ALL
	6		W4250	0546N	18		33-23-21	ALL
	7		W4250	0547W	20		33-25-31	ALL
	8		W4250	0548O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0550K	18		33-27-31	ALL
	11		W4250	0549A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2051R	22		23-31-03	ALL
	14		W4250	2051B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11612	**490/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0551W	20		33-25-31	ALL
2		W4250	0552WV	22		33-27-31	ALL
3		W4250	0553WG	22		33-27-31	ALL
4		W4250	0554WO	22		33-27-31	ALL
5		W4250	0555V	22		33-27-31	ALL
6		W4250	0556N	18		33-23-21	ALL
7		W4250	0557W	20		33-25-31	ALL
8		W4250	0558O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0560K	18		33-27-31	ALL
11		W4250	0559A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2061R	22		23-31-03	ALL
14		W4250	2061B	22		23-31-03	ALL
D11614	**500+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0561W	20		33-25-31	ALL
2		W4250	0562WV	22		33-27-31	ALL
3		W4250	0563WG	22		33-27-31	ALL
4		W4250	0564WO	22		33-27-31	ALL
5		W4250	0565V	22		33-27-31	ALL
6		W4250	0566N	18		33-23-21	ALL
7		W4250	0567W	20		33-25-31	ALL
8		W4250	0568O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0570K	18		33-27-31	ALL
11		W4250	0569A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2071R	22		23-31-03	ALL
14		W4250	2071B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11616		**500A+12/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0571W	20		33-25-31	ALL
	2		W4250	0572WV	22		33-27-31	ALL
	3		W4250	0573WG	22		33-27-31	ALL
	4		W4250	0574WO	22		33-27-31	ALL
	5		W4250	0575V	22		33-27-31	ALL
	6		W4250	0576N	18		33-23-21	ALL
	7		W4250	0577W	20		33-25-31	ALL
	8		W4250	0578O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0580K	18		33-27-31	ALL
	11		W4250	0579A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2081R	22		23-31-03	ALL
	14		W4250	2081B	22		23-31-03	ALL
D11618		**500B+12/273/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0581W	20		33-25-31	ALL
	2		W4250	0582WV	22		33-27-31	ALL
	3		W4250	0583WG	22		33-27-31	ALL
	4		W4250	0584WO	22		33-27-31	ALL
	5		W4250	0585V	22		33-27-31	ALL
	6		W4250	0586N	18		33-23-21	ALL
	7		W4250	0587W	20		33-25-31	ALL
	8		W4250	0588O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0590K	18		33-27-31	ALL
	11		W4250	0589A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2091R	22		23-31-03	ALL
	14		W4250	2091B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11620	**500C+12/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0591W	20		33-25-31	ALL
2		W4250	0592WV	22		33-27-31	ALL
3		W4250	0593WG	22		33-27-31	ALL
4		W4250	0594WO	22		33-27-31	ALL
5		W4250	0595V	22		33-27-31	ALL
6		W4250	0596N	18		33-23-21	ALL
7		W4250	0597W	20		33-25-31	ALL
8		W4250	0598O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0600K	18		33-27-31	ALL
11		W4250	0599A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2201R	22		23-31-03	ALL
14		W4250	2201B	22		23-31-03	ALL
D11622	**500D+12/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0601W	20		33-25-31	ALL
2		W4250	0602WV	22		33-27-31	ALL
3		W4250	0603WG	22		33-27-31	ALL
4		W4250	0604WO	22		33-27-31	ALL
5		W4250	0605V	22		33-27-31	ALL
6		W4250	0606N	18		33-23-21	ALL
7		W4250	0607W	20		33-25-31	ALL
8		W4250	0608O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0610K	18		33-27-31	ALL
11		W4250	0609A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2211R	22		23-31-03	ALL
14		W4250	2211B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11624		**500E+16/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0611W	20		33-25-31	ALL
	2		W4250	0612WV	22		33-27-31	ALL
	3		W4250	0613WG	22		33-27-31	ALL
	4		W4250	0614WO	22		33-27-31	ALL
	5		W4250	0615V	22		33-27-31	ALL
	6		W4250	0616N	18		33-23-21	ALL
	7		W4250	0617W	20		33-25-31	ALL
	8		W4250	0618O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0620K	18		33-27-31	ALL
	11		W4250	0619A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2221R	22		23-31-03	ALL
	14		W4250	2221B	22		23-31-03	ALL
D11626		**500F+14/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0621W	20		33-25-31	ALL
	2		W4250	0622WV	22		33-27-31	ALL
	3		W4250	0623WG	22		33-27-31	ALL
	4		W4250	0624WO	22		33-27-31	ALL
	5		W4250	0625V	22		33-27-31	ALL
	6		W4250	0626N	18		33-23-21	ALL
	7		W4250	0627W	20		33-25-31	ALL
	8		W4250	0628O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0630K	18		33-27-31	ALL
	11		W4250	0629A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2231R	22		23-31-03	ALL
	14		W4250	2231B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11628	**500G+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0631W	20		33-25-31	ALL
2		W4250	0632WV	22		33-27-31	ALL
3		W4250	0633WG	22		33-27-31	ALL
4		W4250	0634WO	22		33-27-31	ALL
5		W4250	0635V	22		33-27-31	ALL
6		W4250	0636N	18		33-23-21	ALL
7		W4250	0637W	20		33-25-31	ALL
8		W4250	0638O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0640K	18		33-27-31	ALL
11		W4250	0639A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2241R	22		23-31-03	ALL
14		W4250	2241B	22		23-31-03	ALL
D11630	**500H+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0641W	20		33-25-31	ALL
2		W4250	0642WV	22		33-27-31	ALL
3		W4250	0643WG	22		33-27-31	ALL
4		W4250	0644WO	22		33-27-31	ALL
5		W4250	0645V	22		33-27-31	ALL
6		W4250	0646N	18		33-23-21	ALL
7		W4250	0647W	20		33-25-31	ALL
8		W4250	0648O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0650K	18		33-27-31	ALL
11		W4250	0649A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2251R	22		23-31-03	ALL
14		W4250	2251B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11632		**500I+16/273/R054**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0651W	20		33-25-31	ALL
	2		W4250	0652WV	22		33-27-31	ALL
	3		W4250	0653WG	22		33-27-31	ALL
	4		W4250	0654WO	22		33-27-31	ALL
	5		W4250	0655V	22		33-27-31	ALL
	6		W4250	0656N	18		33-23-21	ALL
	7		W4250	0657W	20		33-25-31	ALL
	8		W4250	0658O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0660K	18		33-27-31	ALL
	11		W4250	0659A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2261R	22		23-31-03	ALL
	14		W4250	2261B	22		23-31-03	ALL
D11634		**545/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0661W	20		33-25-31	ALL
	2		W4250	0662WV	22		33-27-31	ALL
	3		W4250	0663WG	22		33-27-31	ALL
	4		W4250	0664WO	22		33-27-31	ALL
	5		W4250	0665V	22		33-27-31	ALL
	6		W4250	0666N	18		33-23-21	ALL
	7		W4250	0667W	20		33-25-31	ALL
	8		W4250	0668O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0670K	18		33-27-31	ALL
	11		W4250	0669A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2271R	22		23-31-03	ALL
	14		W4250	2271B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11636	**565/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0671W	20		33-25-31	ALL
2		W4250	0672WV	22		33-27-31	ALL
3		W4250	0673WG	22		33-27-31	ALL
4		W4250	0674WO	22		33-27-31	ALL
5		W4250	0675V	22		33-27-31	ALL
6		W4250	0676N	18		33-23-21	ALL
7		W4250	0677W	20		33-25-31	ALL
8		W4250	0678O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0680K	18		33-27-31	ALL
11		W4250	0679A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2281R	22		23-31-03	ALL
14		W4250	2281B	22		23-31-03	ALL
D11638	**588/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0681W	20		33-25-31	ALL
2		W4250	0682WV	22		33-27-31	ALL
3		W4250	0683WG	22		33-27-31	ALL
4		W4250	0684WO	22		33-27-31	ALL
5		W4250	0685V	22		33-27-31	ALL
6		W4250	0686N	18		33-23-21	ALL
7		W4250	0687W	20		33-25-31	ALL
8		W4250	0688O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0690K	18		33-27-31	ALL
11		W4250	0689A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2291R	22		23-31-03	ALL
14		W4250	2291B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11640		**611/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0691W	20		33-25-31	ALL
	2		W4250	0692WV	22		33-27-31	ALL
	3		W4250	0693WG	22		33-27-31	ALL
	4		W4250	0694WO	22		33-27-31	ALL
	5		W4250	0695V	22		33-27-31	ALL
	6		W4250	0696N	18		33-23-21	ALL
	7		W4250	0697W	20		33-25-31	ALL
	8		W4250	0698O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0700K	18		33-27-31	ALL
	11		W4250	0699A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2401R	22		23-31-03	ALL
	14		W4250	2401B	22		23-31-03	ALL
D11642		**630/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0701W	20		33-25-31	ALL
	2		W4250	0702WV	22		33-27-31	ALL
	3		W4250	0703WG	22		33-27-31	ALL
	4		W4250	0704WO	22		33-27-31	ALL
	5		W4250	0705V	22		33-27-31	ALL
	6		W4250	0706N	18		33-23-21	ALL
	7		W4250	0707W	20		33-25-31	ALL
	8		W4250	0708O	18		33-23-21	ALL
	9	UNUSED						ALL
	10		W4250	0710K	18		33-27-31	ALL
	11		W4250	0709A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2411R	22		23-31-03	ALL
	14		W4250	2411B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11644	**660/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0711W	20		33-25-31	ALL
2		W4250	0712WV	22		33-27-31	ALL
3		W4250	0713WG	22		33-27-31	ALL
4		W4250	0714WO	22		33-27-31	ALL
5		W4250	0715V	22		33-27-31	ALL
6		W4250	0716N	18		33-23-21	ALL
7		W4250	0717W	20		33-25-31	ALL
8		W4250	0718O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0720K	18		33-27-31	ALL
11		W4250	0719A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2421R	22		23-31-03	ALL
14		W4250	2421B	22		23-31-03	ALL
D11646	**680/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0721W	20		33-25-31	ALL
2		W4250	0722WV	22		33-27-31	ALL
3		W4250	0723WG	22		33-27-31	ALL
4		W4250	0724WO	22		33-27-31	ALL
5		W4250	0725V	22		33-27-31	ALL
6		W4250	0726N	18		33-23-21	ALL
7		W4250	0727W	20		33-25-31	ALL
8		W4250	0728O	18		33-23-21	ALL
9	UNUSED						ALL
10		W4250	0730K	18		33-27-31	ALL
11		W4250	0729A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2431R	22		23-31-03	ALL
14		W4250	2431B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11648		**700/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0731W	20		33-25-32	ALL
	2		W4250	0732WV	22		33-27-32	ALL
	3		W4250	0733WG	22		33-27-32	ALL
	4		W4250	0734WO	22		33-27-32	ALL
	5		W4250	0735V	22		33-27-32	ALL
	6		W4250	0736N	18		33-23-22	ALL
	7		W4250	0737W	20		33-25-32	ALL
	8		W4250	0738O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0740K	18		33-27-32	ALL
	11		W4250	0739A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2441R	22		23-31-03	ALL
	14		W4250	2441B	22		23-31-03	ALL
D11650		**726/273/R054**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0741W	20		33-25-32	ALL
	2		W4250	0742WV	22		33-27-32	ALL
	3		W4250	0743WG	22		33-27-32	ALL
	4		W4250	0744WO	22		33-27-32	ALL
	5		W4250	0745V	22		33-27-32	ALL
	6		W4250	0746N	18		33-23-22	ALL
	7		W4250	0747W	20		33-25-32	ALL
	8		W4250	0748O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0750K	18		33-27-32	ALL
	11		W4250	0749A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2451R	22		23-31-03	ALL
	14		W4250	2451B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11652	**727+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0751W	20		33-25-32	ALL
2		W4250	0752WV	22		33-27-32	ALL
3		W4250	0753WG	22		33-27-32	ALL
4		W4250	0754WO	22		33-27-32	ALL
5		W4250	0755V	22		33-27-32	ALL
6		W4250	0756N	18		33-23-22	ALL
7		W4250	0757W	20		33-25-32	ALL
8		W4250	0758O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0760K	18		33-27-32	ALL
11		W4250	0759A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2461R	22		23-31-03	ALL
14		W4250	2461B	22		23-31-03	ALL
D11654	**727A+16/272/R054**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0761W	20		33-25-32	ALL
2		W4250	0762WV	22		33-27-32	ALL
3		W4250	0763WG	22		33-27-32	ALL
4		W4250	0764WO	22		33-27-32	ALL
5		W4250	0765V	22		33-27-32	ALL
6		W4250	0766N	18		33-23-22	ALL
7		W4250	0767W	20		33-25-32	ALL
8		W4250	0768O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0770K	18		33-27-32	ALL
11		W4250	0769A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2471R	22		23-31-03	ALL
14		W4250	2471B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11656		**727B+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0771W	20		33-25-32	ALL
	2		W4250	0772WV	22		33-27-32	ALL
	3		W4250	0773WG	22		33-27-32	ALL
	4		W4250	0774WO	22		33-27-32	ALL
	5		W4250	0775V	22		33-27-32	ALL
	6		W4250	0776N	18		33-23-22	ALL
	7		W4250	0777W	20		33-25-32	ALL
	8		W4250	0778O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0780K	18		33-27-32	ALL
	11		W4250	0779A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2481R	22		23-31-03	ALL
	14		W4250	2481B	22		23-31-03	ALL
D11658		**727C+18/272/R054**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0781W	20		33-25-32	ALL
	2		W4250	0782WV	22		33-27-32	ALL
	3		W4250	0783WG	22		33-27-32	ALL
	4		W4250	0784WO	22		33-27-32	ALL
	5		W4250	0785V	22		33-27-32	ALL
	6		W4250	0786N	18		33-23-22	ALL
	7		W4250	0787W	20		33-25-32	ALL
	8		W4250	0788O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0790K	18		33-27-32	ALL
	11		W4250	0789A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2491R	22		23-31-03	ALL
	14		W4250	2491B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11660	**727D+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0791W	20		33-25-32	ALL
2		W4250	0792WV	22		33-27-32	ALL
3		W4250	0793WG	22		33-27-32	ALL
4		W4250	0794WO	22		33-27-32	ALL
5		W4250	0795V	22		33-27-32	ALL
6		W4250	0796N	18		33-23-22	ALL
7		W4250	0797W	20		33-25-32	ALL
8		W4250	0798O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0800K	18		33-27-32	ALL
11		W4250	0799A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2601R	22		23-31-03	ALL
14		W4250	2601B	22		23-31-03	ALL
D11662	**727E+18/272/R054**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0801W	20		33-25-32	ALL
2		W4250	0802WV	22		33-27-32	ALL
3		W4250	0803WG	22		33-27-32	ALL
4		W4250	0804WO	22		33-27-32	ALL
5		W4250	0805V	22		33-27-32	ALL
6		W4250	0806N	18		33-23-22	ALL
7		W4250	0807W	20		33-25-32	ALL
8		W4250	0808O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0810K	18		33-27-32	ALL
11		W4250	0809A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2611R	22		23-31-03	ALL
14		W4250	2611B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11664		**727F+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0811W	20		33-25-32	ALL
	2		W4250	0812WV	22		33-27-32	ALL
	3		W4250	0813WG	22		33-27-32	ALL
	4		W4250	0814WO	22		33-27-32	ALL
	5		W4250	0815V	22		33-27-32	ALL
	6		W4250	0816N	18		33-23-22	ALL
	7		W4250	0817W	20		33-25-32	ALL
	8		W4250	0818O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0820K	18		33-27-32	ALL
	11		W4250	0819A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2621R	22		23-31-03	ALL
	14		W4250	2621B	22		23-31-03	ALL
D11666		**727G+18/272/R054**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0821W	20		33-25-32	ALL
	2		W4250	0822WV	22		33-27-32	ALL
	3		W4250	0823WG	22		33-27-32	ALL
	4		W4250	0824WO	22		33-27-32	ALL
	5		W4250	0825V	22		33-27-32	ALL
	6		W4250	0826N	18		33-23-22	ALL
	7		W4250	0827W	20		33-25-32	ALL
	8		W4250	0828O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0830K	18		33-27-32	ALL
	11		W4250	0829A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2631R	22		23-31-03	ALL
	14		W4250	2631B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11668	**727H+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0831W	20		33-25-32	ALL
2		W4250	0832WV	22		33-27-32	ALL
3		W4250	0833WG	22		33-27-32	ALL
4		W4250	0834WO	22		33-27-32	ALL
5		W4250	0835V	22		33-27-32	ALL
6		W4250	0836N	18		33-23-22	ALL
7		W4250	0837W	20		33-25-32	ALL
8		W4250	0838O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0840K	18		33-27-32	ALL
11		W4250	0839A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2641R	22		23-31-03	ALL
14		W4250	2641B	22		23-31-03	ALL
D11670	**727I+16/272/R054**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0841W	20		33-25-32	ALL
2		W4250	0842WV	22		33-27-32	ALL
3		W4250	0843WG	22		33-27-32	ALL
4		W4250	0844WO	22		33-27-32	ALL
5		W4250	0845V	22		33-27-32	ALL
6		W4250	0846N	18		33-23-22	ALL
7		W4250	0847W	20		33-25-32	ALL
8		W4250	0848O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0850K	18		33-27-32	ALL
11		W4250	0849A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2651R	22		23-31-03	ALL
14		W4250	2651B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11672		**727J+10/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0851W	20		33-25-32	ALL
	2		W4250	0852WV	22		33-27-32	ALL
	3		W4250	0853WG	22		33-27-32	ALL
	4		W4250	0854WO	22		33-27-32	ALL
	5		W4250	0855V	22		33-27-32	ALL
	6		W4250	0856N	18		33-23-22	ALL
	7		W4250	0857W	20		33-25-32	ALL
	8		W4250	0858O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0860K	18		33-27-32	ALL
	11		W4250	0859A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2661R	22		23-31-03	ALL
	14		W4250	2661B	22		23-31-03	ALL
D11674		**763/272/R054**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	0861W	20		33-25-32	ALL
	2		W4250	0862WV	22		33-27-32	ALL
	3		W4250	0863WG	22		33-27-32	ALL
	4		W4250	0864WO	22		33-27-32	ALL
	5		W4250	0865V	22		33-27-32	ALL
	6		W4250	0866N	18		33-23-22	ALL
	7		W4250	0867W	20		33-25-32	ALL
	8		W4250	0868O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	0870K	18		33-27-32	ALL
	11		W4250	0869A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2671R	22		23-31-03	ALL
	14		W4250	2671B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11676	**785/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0871W	20		33-25-32	ALL
2		W4250	0872WV	22		33-27-32	ALL
3		W4250	0873WG	22		33-27-32	ALL
4		W4250	0874WO	22		33-27-32	ALL
5		W4250	0875V	22		33-27-32	ALL
6		W4250	0876N	18		33-23-22	ALL
7		W4250	0877W	20		33-25-32	ALL
8		W4250	0878O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0880K	18		33-27-32	ALL
11		W4250	0879A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2681R	22		23-31-03	ALL
14		W4250	2681B	22		23-31-03	ALL
D11678	**802/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	0881W	20		33-25-32	ALL
2		W4250	0882WV	22		33-27-32	ALL
3		W4250	0883WG	22		33-27-32	ALL
4		W4250	0884WO	22		33-27-32	ALL
5		W4250	0885V	22		33-27-32	ALL
6		W4250	0886N	18		33-23-22	ALL
7		W4250	0887W	20		33-25-32	ALL
8		W4250	0888O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	0890K	18		33-27-32	ALL
11		W4250	0889A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2691R	22		23-31-03	ALL
14		W4250	2691B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11680		**822/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	5601W	20		33-25-32	ALL
	2		W4250	5602WV	22		33-27-32	ALL
	3		W4250	5603WG	22		33-27-32	ALL
	4		W4250	5604WO	22		33-27-32	ALL
	5		W4250	5605V	22		33-27-32	ALL
	6		W4250	5606N	18		33-23-22	ALL
	7		W4250	5607W	20		33-25-32	ALL
	8		W4250	5608O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	5610K	18		33-27-32	ALL
	11		W4250	5609A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2701R	22		23-31-03	ALL
	14		W4250	2701B	22		23-31-03	ALL
D11682		**842/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	5611W	20		33-25-32	ALL
	2		W4250	5612WV	22		33-27-32	ALL
	3		W4250	5613WG	22		33-27-32	ALL
	4		W4250	5614WO	22		33-27-32	ALL
	5		W4250	5615V	22		33-27-32	ALL
	6		W4250	5616N	18		33-23-22	ALL
	7		W4250	5617W	20		33-25-32	ALL
	8		W4250	5618O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	5620K	18		33-27-32	ALL
	11		W4250	5619A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2711R	22		23-31-03	ALL
	14		W4250	2711B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11684	**865/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	5621W	20		33-25-32	ALL
2		W4250	5622WV	22		33-27-32	ALL
3		W4250	5623WG	22		33-27-32	ALL
4		W4250	5624WO	22		33-27-32	ALL
5		W4250	5625V	22		33-27-32	ALL
6		W4250	5626N	18		33-23-22	ALL
7		W4250	5627W	20		33-25-32	ALL
8		W4250	5628O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	5630K	18		33-27-32	ALL
11		W4250	5629A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2721R	22		23-31-03	ALL
14		W4250	2721B	22		23-31-03	ALL
D11686	**890/274/R051**		**RCPT-PSU RIGHT**				**ALL**
1		W4250	5631W	20		33-25-32	ALL
2		W4250	5632WV	22		33-27-32	ALL
3		W4250	5633WG	22		33-27-32	ALL
4		W4250	5634WO	22		33-27-32	ALL
5		W4250	5635V	22		33-27-32	ALL
6		W4250	5636N	18		33-23-22	ALL
7		W4250	5637W	20		33-25-32	ALL
8		W4250	5638O	18		33-23-22	ALL
9	UNUSED						ALL
10		W4250	5640K	18		33-27-32	ALL
11		W4250	5639A	16		35-21-31	ALL
12	UNUSED						ALL
13		W4250	2731R	22		23-31-03	ALL
14		W4250	2731B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11688		**924/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	5641W	20		33-25-32	ALL
	2		W4250	5642WV	22		33-27-32	ALL
	3		W4250	5643WG	22		33-27-32	ALL
	4		W4250	5644WO	22		33-27-32	ALL
	5		W4250	5645V	22		33-27-32	ALL
	6		W4250	5646N	18		33-23-22	ALL
	7		W4250	5647W	20		33-25-32	ALL
	8		W4250	5648O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	5650K	18		33-27-32	ALL
	11		W4250	5649A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2741R	22		23-31-03	ALL
	14		W4250	2741B	22		23-31-03	ALL
D11690		**937/274/R051**		**RCPT-PSU RIGHT**				**ALL**
	1		W4250	5651W	20		33-25-32	ALL
	2		W4250	5652WV	22		33-27-32	ALL
	3		W4250	5653WG	22		33-27-32	ALL
	4		W4250	5654WO	22		33-27-32	ALL
	5		W4250	5655V	22		33-27-32	ALL
	6		W4250	5656N	18		33-23-22	ALL
	7		W4250	5657W	20		33-25-32	ALL
	8		W4250	5658O	18		33-23-22	ALL
	9	UNUSED						ALL
	10		W4250	5660K	18		33-27-32	ALL
	11		W4250	5659A	16		35-21-31	ALL
	12	UNUSED						ALL
	13		W4250	2751R	22		23-31-03	ALL
	14		W4250	2751B	22		23-31-03	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11701A	**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT**				**ALL**
A01		W0131	0395	22		32-49-11	ALL
A02	UNUSED						ALL
A03		W0131	0401	22		32-46-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	63	W0131	4504W	22		32-46-11	ALL
A08	62	W0131	4504G	22		32-46-11	ALL
A09	UNUSED						ALL
A10		W0131	2037R	22		32-49-11	ALL
A11		W0131	2036R	22		32-49-11	ALL
A12		W0131	2035R	22		32-49-11	ALL
A13		W0131	2034R	22		32-49-11	ALL
A14		W0131	2068R	22		32-49-11	ALL
A15		W0131	2069R	22		32-49-11	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	63	W0131	4503W	22		32-46-11	ALL
B08	62	W0131	4503G	22		32-46-11	ALL
B09	UNUSED						ALL
B10		W0131	2037B	22		32-49-11	ALL
B11		W0131	2036B	22		32-49-11	ALL
B12		W0131	2035B	22		32-49-11	ALL
B13		W0131	2034B	22		32-49-11	ALL
B14		W0131	2068B	22		32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11701A		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT (continued)**				**ALL**
	B15		W0131	2069B	22		32-49-11	ALL
	C01		W0131	0396	22		32-49-11	ALL
	C02	UNUSED						ALL
	C03		W0131	0402	22		32-46-11	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	63	W0131	4502W	22		32-46-11	ALL
	C08	62	W0131	4502G	22		32-46-11	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0131	0403	22		32-46-11	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	63	W0131	4501W	22		32-46-11	ALL
	D08	62	W0131	4501G	22		32-46-11	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11701A		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT (continued)**				**ALL**
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	PERG	1A	W0131	2034Z			32-49-11	ALL
	PERG	1A	W0131	2035Z			32-49-11	ALL
	PERG	1A	W0131	2036Z			32-49-11	ALL
	PERG	1A	W0131	2037Z			32-49-11	ALL
	PERG	1A	W0131	2068Z			32-49-11	ALL
	PERG	1A	W0131	2069Z			32-49-11	ALL
	PERG	1A	W0131	4501Z			32-46-11	ALL
	PERG	1A	W0131	4502Z			32-46-11	ALL
	PERG	1A	W0131	4503Z			32-46-11	ALL
	PERG	1A	W0131	4504Z			32-46-11	ALL
D11701B		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT**				**ALL**
	A01		W0131	0398	22		32-46-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0131	2066R	24		34-21-13	ALL
	A07		W0131	2066B	24		34-21-13	ALL
	A08	UNUSED						ALL
	A09		W0131	2565R	24		31-65-15	ALL
	A10		W0131	2565B	24		31-65-15	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11701B		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT (continued)**				**ALL**
	B02		W0131	1003	22		32-49-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0131	2031R	22		32-46-11	ALL
	B10		W0131	2031B	22		32-46-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01		W0131	0399	22		32-46-11	ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11701B		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT (continued)**				**ALL**
	D01	UNUSED						ALL
	D02		W0131	1001	22		32-46-11	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06		W0131	2032R	22		32-46-11	ALL
	D07		W0131	2032B	22		32-46-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	PERG	1A	W0131	1001Z			32-46-11	ALL
	PERG	1A	W0131	1003Z			32-49-11	ALL
	PERG	1A	W0131	2031Z			32-46-11	ALL
	PERG	1A	W0131	2032Z			32-46-11	ALL
	PERG	1A	W0131	2066Z			34-21-13	ALL
	PERG	1A	W0131	2565Z			31-65-15	ALL
D11701C		**/*/***		**PLUG - BRAKE TEMP MONITOR UNIT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	=C1	UNUSED						ALL
	=C5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11702	**862/198/L019**		**PLUG-**				**ALL**
1	18	W5146	0101	18		38-32-12	ALL
2	18	W5146	0122	18		38-32-12	ALL
3		W5146	0203	20		38-32-13	ALL
4		W5146	0224	20		38-32-13	ALL
5		W5146	0105	20		38-32-13	ALL
6	UNUSED						ALL
7	18	W5146	0107	18		38-32-12	ALL
8		W5146	0228	20		38-32-13	ALL
9		W5146	0229	22		38-32-13	ALL
10	18	W5146	0110	18		38-32-12	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5146	0113	20		38-32-12	ALL
14	UNUSED						ALL
15		W5146	0115	20		38-32-12	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W5146	0218	22		38-32-13	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D11703	**683/196/L054**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W7026	2203R	20		32-31-15	ALL
3		W7026	2202B	20		32-31-15	ALL
4		W7026	0521	18		32-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11703	**683/196/L054**		**PLUG (continued)**				**ALL**
5		W7026	2203B	20		32-31-15	ALL
6		W7026	2202R	20		32-31-15	ALL
7	UNUSED						ALL
S/R		W7026	2202Z			32-31-15	ALL
S/R		W7026	2203Z			32-31-15	ALL
D11712A	**P006-00/ /**		**MATING CONNECTOR**				**ALL**
1		W0044	0037	12		24-34-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0040	6213	12		24-61-31	ALL
5		W0040	6210	12		24-54-11	ALL
6	UNUSED						ALL
7		W0040	6219	12		24-61-33	ALL
8		W0040	6214	12		24-61-32	ALL
D11712B	**P006-00/ /**		**MATING CONNECTOR**				**ALL**
1		W0044	0019	24		24-31-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0044	0552	24		24-31-12	ALL
5		W0044	0029	24		24-32-11	ALL
6	UNUSED						ALL
7		W0044	0036	24		24-33-11	ALL
8	UNUSED						ALL
9		W0044	0549	24		24-31-11	ALL
A1		W0040	6215	10		24-61-42	ALL
A2	UNUSED						ALL
A3		W0044	0026	08		24-32-11	ALL
A4		W0040	6212	10		24-61-41	ALL
A5		W0044	0692	08		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11712B		**P006-00/ /**		**MATING CONNECTOR (continued)**				**ALL**
	A6	UNUSED						ALL
	A7		W0044	0039	08		24-34-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0044	0018	24		24-31-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0044	0550	24		24-31-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
D11714A		**P006-00/ /**		**MATING CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0044	0528	24		24-31-12	ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11714A	**P006-00/ /**		**MATING CONNECTOR (continued)**				**ALL**
7		W0044	0532	24		24-31-12	ALL
8	UNUSED						ALL
9	UNUSED						ALL
A1		W0040	6216	10		24-61-52	ALL
A2	UNUSED						ALL
A3		W0040	6218	12		24-61-51	ALL
A4		W0040	6217	10		24-61-52	ALL
A5	UNUSED						ALL
A6	UNUSED						ALL
A7		W0044	0527	08		24-31-12	ALL
10		W0044	0038	24		24-34-11	ALL
11	UNUSED						ALL
12		W0044	0041	24		24-34-11	ALL
13		W0044	0040	24		24-34-11	ALL
14		W0044	0043	24		24-34-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0044	0529	24		24-31-12	ALL
19	UNUSED						ALL
20		W0044	0530	24		24-31-12	ALL
21		W0044	0531	24		24-31-12	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W0044	0526	24		24-31-12	ALL
25		W0044	0042	24		24-34-11	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11714A		**P006-00/ /**		**MATING CONNECTOR (continued)**				**ALL**
	29	UNUSED						ALL
D11714B		**P006-00/ /**		**MATING CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0044	0368	24		24-32-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W0044	0367	24		24-32-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W0044	0044	20		24-34-11	ALL
	23	UNUSED						ALL
	24		W0044	0030	20		24-32-11	ALL
	25	UNUSED						ALL
	26		W0044	0014	22		24-28-11	ALL
	27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11714B	**P006-00/ /**		**MATING CONNECTOR (continued)**				**ALL**
28	UNUSED						ALL
29	UNUSED						ALL
30		W0044	0553	24		24-31-12	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W0044	0028	20		24-32-11	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0044	0027	24		24-32-11	ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W0044	0551	24		24-31-11	ALL
56	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11714B		**P006-00/ /**		**MATING CONNECTOR (continued)**				**ALL**
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60		W0044	0524	24		24-31-12	ALL
	61	UNUSED						ALL
	62	UNUSED						ALL
	63	UNUSED						ALL
	64	UNUSED						ALL
	65		W0044	0025	24		24-32-11	ALL
	66	UNUSED						ALL
	67		W0044	0525	24		24-31-12	ALL
D11716		**868/178/L040**		**RCPT-**				**ALL**
	1		W5146	0126	20		38-32-12	ALL
	2		W5146	0132	20		38-32-12	ALL
	3	UNUSED						ALL
D11718		**856/190/L043**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5230	0515	12		38-32-12	ALL
	3		W5230	0516	12		38-32-12	ALL
	4		W5230	0517	12		38-32-12	ALL
	5		W5230	0513	18		38-32-12	ALL
	6		W5230	0519	20		38-32-12	ALL
	7		W5230	0518	12		38-32-12	ALL
	8	UNUSED						ALL
D11722		**352/279/L030**		**PLUG-**				**ALL**
	1		W3144	0001	20		33-25-21	ALL
	2		W3144	0002	20		33-25-21	ALL
	3		W3144	0003	20		33-25-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11724	**352/279/L030**		**RCPT-**				**ALL**
1		W0026	0001	20		33-25-21	ALL
2		W0026	0002	18		33-25-21	ALL
3		W0026	0003	18		33-25-21	ALL
D11732	**P002-01/ /**		**PLUG-**				**ALL**
1		W0001	0229	20		33-11-32	ALL
2		W0001	0230	20		33-11-32	ALL
3	UNUSED						ALL
4		W0003	0626	24		32-64-12	ALL
5		W0003	0701	20		33-18-24	ALL
6		W0001	0254	22		29-23-11	ALL
7		W0001	0255	22		29-23-11	ALL
8		W0003	0703	20		33-18-24	ALL
9		W0001	0154	24		32-64-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0003	0624	24		32-64-12	ALL
14		W0003	1700	20		33-18-24	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0001	0159	24		32-64-11	ALL
20		W0003	1702	20		33-18-24	ALL
21		W0003	1704	20		33-18-24	ALL
22		W0001	0155	24		32-64-11	ALL
23		W0001	0156	24		32-64-11	ALL
24	UNUSED						ALL
25		W0003	0625	24		32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11732		**P002-01/ /**		**PLUG- (continued)**				**ALL**
	26		W0003	1699	20		33-18-24	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0001	0157	24		32-64-11	ALL
	31		W0001	0158	24		32-64-11	ALL
	S/R		W0003	1699Z			33-18-24	ALL
	S/R		W0003	1700Z			33-18-24	ALL
	S/R		W0003	1702Z			33-18-24	ALL
	S/R		W0003	1704Z			33-18-24	ALL
D11736		**P92 388/ /**		**PLUG-**				**ALL**
	A		W5036	0506	08		24-32-11	ALL
	B		W5036	0505	08		24-32-11	ALL
	C		W5036	0501	08		24-32-11	ALL
D11738		**P92 388/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W6210	3203Y	20		28-23-11	ALL
	3		W6210	3203B	20		28-23-11	ALL
	4		W6210	4102R	22		24-41-11	ALL
	5		W6210	4102Y	22		24-41-11	ALL
	6		W6210	4102B	22		24-41-11	ALL
	7		W6210	0517	20		28-23-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6210	0518	20		28-23-11	ALL
	11		W6210	3203R	20		28-23-11	ALL
	12		W6210	3201R	20		28-23-11	ALL
	13		W6210	3201Y	20		28-23-11	ALL
	14		W6210	3201B	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11738	**P92 388/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
15	UNUSED						ALL
16		W6210	3204Y	20		24-31-11	ALL
17		W6210	3204B	20		24-31-11	ALL
18		W6210	3204R	20		24-31-11	ALL
19	UNUSED						ALL
20		W6210	2201R	22		24-23-21	ALL
21		W6210	1002	22		24-41-11	ALL
22	UNUSED						ALL
23		W6210	0515	20		24-22-31	ALL
24	UNUSED						ALL
25		W6210	5510	22		21-27-21	ALL
26		W6210	0516	20		28-23-11	ALL
27		W6210	0504	18		24-32-11	ALL
28		W6210	0506	18		24-32-11	ALL
29		W6210	0505	18		24-32-11	ALL
30		W6210	0530	18		24-53-11	ALL
31		W6210	3202R	18		28-23-11	ALL
32		W6210	3202Y	18		28-23-11	ALL
33		W6210	3202B	18		28-23-11	ALL
34	UNUSED						ALL
35		W6210	3206R	20		24-21-21	ALL
36		W6210	3206Y	20		24-21-21	ALL
37		W6210	3206B	20		24-21-21	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11738		**P92 388/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W6210	1002Z			24-41-11	ALL
	S/R		W6210	3206Z			24-21-21	ALL
	DED		W6210	2201Z			24-23-21	ALL
D11740		**388/176/R039**		**PLUG-**				**ALL**
	A		W8538	0501	12		29-22-11	ALL
	B		W8538	0502	12		29-22-11	ALL
	C		W8538	0503	12		29-22-11	ALL
D11756		**P006-00/ /**		**CONNECTOR**				**ALL**
	A1		W0044	6203	18		24-61-61	ALL
	A2		W0044	6202	18		24-61-61	ALL
	A3		W0044	6201	18		24-61-61	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0044	0010	22		24-23-51	ALL
	X2		W0044	0011	22		24-23-51	ALL
D11786		**1038/231/L045**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5146	0126	20		38-32-12	ALL
	3		W5146	0127	20		38-32-12	ALL
	4		W5146	0128	20		38-32-12	ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11788		**852/172/L034**		**PLUG-**				**ALL**
	1		W5146	0211	22		38-32-13	ALL
	2		W5146	0212	20		38-32-13	ALL
	3		W5146	0213	20		38-32-13	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D11798		**E002-02/ /**		**PLUG-APU START POWER UNIT**				**ALL**
	+	Q	W2532	0501	*2		49-41-11	ALL
	-	Q	W2532	0516	*1		49-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11800		**P91 378/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5030	5501	20		21-27-31	ALL
	3		W5030	5502	20		21-27-31	ALL
	4		W5030	5503	20		21-27-31	ALL
	5	UNUSED						ALL
	6		W5030	5505	22		21-27-31	ALL
	7	UNUSED						ALL
D11802		**P0092/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W6430	5501	20		21-27-31	ALL
	3		W6430	5502	20		21-27-31	ALL
	4		W6430	5503	20		21-27-31	ALL
	5	UNUSED						ALL
	6		W6430	5505	22		21-27-31	ALL
	7	UNUSED						ALL
D11804		**AB0372/184/R050**		**RCPTNE TEST CONNECTOR**				**ALL**
	1		W5111	2018R	24		31-65-15	ALL
	2		W5111	2018B	24		31-65-15	ALL
	3		W5111	2730R	24		31-65-25	ALL
	4		W5111	2730B	24		31-65-25	ALL
	5		W5111	2019R	24		31-65-15	ALL
	6		W5111	2019B	24		31-65-15	ALL
	7		W5111	2731R	24		31-65-25	ALL
	8		W5111	2731B	24		31-65-25	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W5111	2018Z			31-65-15	ALL
	S/R		W5111	2019Z			31-65-15	ALL
	S/R		W5111	2730Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11804	**AB0372/184/R050**		**RCPTNE TEST CONNECTOR (continued)**				**ALL**
S/R		W5111	2731Z			31-65-25	ALL
D11810	**P041-00/ /**		**PLUG-**				**ALL**
1		W0001	0214	20		33-11-32	ALL
2		W0001	0215	20		33-11-32	ALL
3	UNUSED						ALL
4		W0001	0211	16		33-11-32	ALL
5	14	W0001	0194	14		33-11-11	ALL
6		W0001	0257	16		33-11-32	ALL
7	14	W0001	0190	14		33-11-11	ALL
8		W0001	0212	16		33-11-32	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0001	0290	16		33-11-32	ALL
12		W0001	0216	16		33-11-32	ALL
13	UNUSED						ALL
14		W0001	0189	16		33-11-11	ALL
D11812	**P041-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W0001	0324	16		33-11-31	ALL
3	UNUSED						ALL
4		W0001	0201	18		33-11-31	ALL
5	UNUSED						ALL
6	14	W0001	0202	14		33-11-31	ALL
7	UNUSED						ALL
D11813	**E004-01/ /**		**PLUG**				**ALL**
1		W0411	3026R	22		23-27-39	ALL
2		W0411	3026B	22		23-27-39	ALL
3		W0411	3026Y	22		23-27-39	ALL
4		W0411	2068R	22		23-27-39	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11813		**E004-01/ /**		**PLUG (continued)**				**ALL**
	5		W0411	2068B	22		23-27-39	ALL
	6		W0411	2069R	22		23-27-39	ALL
	7		W0411	2069B	22		23-27-39	ALL
	8		W0411	2070R	22		23-27-39	ALL
	9		W0411	2070B	22		23-27-39	ALL
			W0411	2068Z			23-27-39	ALL
			W0411	2069Z			23-27-39	ALL
			W0411	2070Z			23-27-39	ALL
			W0411	3026Z			23-27-39	ALL
D11814		**ORSS/439/**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1024	2008B	20		27-53-21	ALL
	2		W1024	2008R	20		27-53-21	ALL
	3		W1024	3006Y	20		27-53-21	ALL
	4		W1024	3006R	20		27-53-21	ALL
	5		W1024	3006B	20		27-53-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1024	1002	18		27-53-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W1024	1002Z			27-53-21	ALL
	S/R		W1024	2008Z			27-53-21	ALL
	S/R		W1024	3006Z			27-53-21	ALL
D11815		**917/292/L035**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W3311	3510R	24		23-42-12	ALL
	3		W3311	3510Y	24		23-42-12	ALL
	4		W3311	3510B	24		23-42-12	ALL
	5		W3311	0045	22		23-31-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11815		**917/292/L035**		**PLUG (continued)**				**ALL**
	6		W3311	3501Y	24		23-42-12	ALL
	7		W3311	3501R	24		23-42-12	ALL
	8		W3311	0044	22		23-31-01	ALL
	9	UNUSED						ALL
	10		W3311	0046	22		23-31-01	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3311	3501B	24		23-42-12	ALL
	DED		W3311	3501Z			23-42-12	ALL
	DED		W3311	3510Z			23-42-12	ALL
D11816		**ORSS/330/**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1024	2009B	20		27-53-21	ALL
	2		W1024	2009R	20		27-53-21	ALL
	3		W1024	3007Y	20		27-53-21	ALL
	4		W1024	3007R	20		27-53-21	ALL
	5		W1024	3007B	20		27-53-21	ALL
	6		W1024	2008R	20		27-53-21	ALL
	7		W1024	2008B	20		27-53-21	ALL
	8		W1024	1003	18		27-53-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W1024	1003Z			27-53-21	ALL
	S/R		W1024	2008Z			27-53-21	ALL
	S/R		W1024	2009Z			27-53-21	ALL
	S/R		W1024	3007Z			27-53-21	ALL
D11818		**ORSS/235/**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1022	2008B	20		27-53-21	ALL
	2		W1022	2008R	20		27-53-21	ALL
	3		W1022	3008Y	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11818		**ORSS/235/**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	4		W1022	3008R	20		27-53-21	ALL
	5		W1022	3008B	20		27-53-21	ALL
	6		W1022	2009R	20		27-53-21	ALL
	7		W1022	2009B	20		27-53-21	ALL
	8		W1022	1002	18		27-53-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W1022	1002Z			27-53-21	ALL
	S/R		W1022	2008Z			27-53-21	ALL
	S/R		W1022	2009Z			27-53-21	ALL
	S/R		W1022	3008Z			27-53-21	ALL
D11820		**721/173/L062**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1022	2010B	20		27-53-21	ALL
	2		W1022	2010R	20		27-53-21	ALL
	3		W1022	3009Y	20		27-53-21	ALL
	4		W1022	3009R	20		27-53-21	ALL
	5		W1022	3009B	20		27-53-21	ALL
	6		W1022	2008R	20		27-53-21	ALL
	7		W1022	2008B	20		27-53-21	ALL
	8		W1022	1003	18		27-53-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	S/R		W1022	1003Z			27-53-21	ALL
	S/R		W1022	2008Z			27-53-21	ALL
	S/R		W1022	2010Z			27-53-21	ALL
	S/R		W1022	3009Z			27-53-21	ALL
D11822		**721/173/R063**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1032	2010B	20		27-53-21	ALL
	2		W1032	2010R	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11822	**721/173/R063**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3		W1032	3009Y	20		27-53-21	ALL
4		W1032	3009R	20		27-53-21	ALL
5		W1032	3009B	20		27-53-21	ALL
6		W1032	2008R	20		27-53-21	ALL
7		W1032	2008B	20		27-53-21	ALL
8		W1032	1003	18		27-53-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
S/R		W1032	1003Z			27-53-21	ALL
S/R		W1032	2008Z			27-53-21	ALL
S/R		W1032	2010Z			27-53-21	ALL
S/R		W1032	3009Z			27-53-21	ALL
D11824	**ORSS/244/**		**PLUG-CONDUCTIVE**				**ALL**
1		W1032	2008B	20		27-53-21	ALL
2		W1032	2008R	20		27-53-21	ALL
3		W1032	3008Y	20		27-53-21	ALL
4		W1032	3008R	20		27-53-21	ALL
5		W1032	3008B	20		27-53-21	ALL
6		W1032	2009R	20		27-53-21	ALL
7		W1032	2009B	20		27-53-21	ALL
8		W1032	1002	18		27-53-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
S/R		W1032	1002Z			27-53-21	ALL
S/R		W1032	2008Z			27-53-21	ALL
S/R		W1032	2009Z			27-53-21	ALL
S/R		W1032	3008Z			27-53-21	ALL
D11826	**ORSS/330/**		**PLUG-CONDUCTIVE**				**ALL**
1		W1034	2009B	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11826	**ORSS/330/**		**PLUG-CONDUCTIVE (continued)**				**ALL**
2		W1034	2009R	20		27-53-21	ALL
3		W1034	3007Y	20		27-53-21	ALL
4		W1034	3007R	20		27-53-21	ALL
5		W1034	3007B	20		27-53-21	ALL
6		W1034	2008R	20		27-53-21	ALL
7		W1034	2008B	20		27-53-21	ALL
8		W1034	1003	18		27-53-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
S/R		W1034	1003Z			27-53-21	ALL
S/R		W1034	2008Z			27-53-21	ALL
S/R		W1034	2009Z			27-53-21	ALL
S/R		W1034	3007Z			27-53-21	ALL
D11828	**ORSS/432/**		**PLUG-CONDUCTIVE**				**ALL**
1		W1034	2008B	20		27-53-21	ALL
2		W1034	2008R	20		27-53-21	ALL
3		W1034	3006Y	20		27-53-21	ALL
4		W1034	3006R	20		27-53-21	ALL
5		W1034	3006B	20		27-53-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1034	1002	18		27-53-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
S/R		W1034	1002Z			27-53-21	ALL
S/R		W1034	2008Z			27-53-21	ALL
S/R		W1034	3006Z			27-53-21	ALL
D11830	**500F+7/298/L012**		**PLUG-**				**ALL**
1		W6288	2001B	20		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11830	**500F+7/298/L012**		**PLUG- (continued)**				**ALL**
2		W6288	2001R	20		21-61-13	ALL
D11832	**500F+9/300/L012**		**PLUG-**				**ALL**
A		W6288	0012	20		21-61-51	ALL
B		W6288	0011	20		21-61-51	ALL
D11834	**500F+10/298/L014**		**PLUG-**				**ALL**
1		W6288	0001	20		21-61-13	ALL
2		W6288	0002	20		21-61-13	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D11836	**536/298/R12**		**PLUG-**				**ALL**
1		W6288	0006	20		21-61-14	ALL
2		W6288	0007	20		21-61-14	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
D11838	**535/299/R012**		**PLUG-**				**ALL**
A		W6288	0018	20		21-61-51	ALL
B		W6288	0017	20		21-61-51	ALL
D11840	**537/299/R012**		**PLUG-**				**ALL**
1		W6288	2004B	20		21-61-14	ALL
2		W6288	2004R	20		21-61-14	ALL
D11842	**P042-00/ /**		**PLUG-**				**ALL**
1		W0003	0667	16		33-11-21	ALL
2		W0003	0664	16		33-11-21	ALL
3		W0003	0666	16		33-11-21	ALL
4		W0003	0665	16		33-11-21	ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11842		**P042-00/ /**		**PLUG- (continued)**				**ALL**
	7	UNUSED						ALL
D11844		**P042-00/ /**		**PLUG-**				**ALL**
	1		W0003	0712	16		33-11-32	ALL
	2	UNUSED						ALL
	3		W0001	0290	16		33-11-32	ALL
	4		W0001	0216	16		33-11-32	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0003	0711	16		33-11-32	ALL
D11866		**J00024/ /**		**SOCKET-**				**ALL**
	1		W0080	5623	24		21-43-21	ALL
	1		W0080	5630	24		21-43-21	ALL
	2		W0080	0579	24		21-25-11	ALL
	2		W0080	5628	24		21-25-11	ALL
	3	UNUSED						ALL
	4		W0080	5602	24		21-43-21	ALL
	5		W0080	5595	24		21-43-21	ALL
	6		W0080	5513	24		21-43-21	ALL
	6		W0080	5629	24		21-43-21	ALL
	7		W0080	5526	24		21-43-21	ALL
	8	UNUSED						ALL
	9		W0080	5502	22		21-25-11	ALL
	10	UNUSED						ALL
	11		W0080	5503	22		21-25-11	ALL
	12		W0080	5504	20		21-25-11	ALL
	13		W0080	5628	24		21-25-11	ALL
	14		W0080	5601	24		21-43-21	ALL
D11868		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11868		**J020-0B/ /**		**RELAY SOCKET (continued)**				**ALL**
	A2		W0072	0113	24		21-27-31	ALL
	A3		W0072	0114	22		21-27-31	ALL
	B1	UNUSED						ALL
	B2		W0072	0116	22		21-27-31	ALL
	B3		W0072	0117	22		21-27-31	ALL
	C1		W0072	0118	22		21-27-31	ALL
	C2		W0072	0119	22		21-27-31	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2		W0072	0120	24		21-27-31	ALL
	D3		W0072	0121	22		21-27-31	ALL
	X1		W0072	0111	24		21-27-31	ALL
	X2		W0072	0112	20		21-27-31	ALL
D11874		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	5501	22		21-25-11	ALL
	A2		W0080	5502	22		21-25-11	ALL
	A3	UNUSED						ALL
	B1		W0080	5530	24		21-43-21	ALL
	B1		W0080	5595	24		21-43-21	ALL
	B2		W0080	5572	24		21-43-21	ALL
	B3	UNUSED						ALL
	C1		W0080	5526	24		21-43-21	ALL
	C2		W0080	5515	24		21-43-21	ALL
	C3	UNUSED						ALL
	D1		W0080	5573	24		21-43-21	ALL
	D2		W0080	5516	24		21-43-21	ALL
	D3	UNUSED						ALL
	X1		W0080	5573	24		21-43-21	ALL
	X1		W0080	5574	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11874		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	X2		W0080	5518	22		21-43-21	ALL
D11876		**J00024/ /**		**SOCKET-**				**ALL**
	A1	UNUSED						ALL
	A2		W0080	5577	24		21-43-21	ALL
	A3		W0080	5611	24		21-43-21	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1		W0080	5523	24		21-43-21	ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	5577	24		21-43-21	ALL
	X1		W0080	5578	24		21-43-21	ALL
	X2		W0080	5524	22		21-43-21	ALL
D11878		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	5621	24		21-43-21	ALL
	A2		W0080	5530	24		21-43-21	ALL
	A3	UNUSED						ALL
	B1		W0080	5576	24		21-43-21	ALL
	B2		W0080	5575	24		21-43-21	ALL
	B3		W0080	5528	24		21-43-21	ALL
	X1		W0080	5520	24		21-43-21	ALL
	X2		W0080	5521	22		21-43-21	ALL
D11880		**368/154/R005**		**PLUG-**				**ALL**
	1		W5158	0551	22		21-43-21	ALL
	2		W5158	0552	22		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11880		**368/154/R005**		**PLUG- (continued)**				**ALL**
	3		W5158	0553	20		21-43-21	ALL
	4		W5158	0554	20		21-31-24	ALL
	5	UNUSED						ALL
	6		W5158	0556	20		21-43-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5158	0555	22		21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11922		**P007-00/ /**		**RCPT- AFCS FLOODLIGHT**				**ALL**
	=1		W0104	5517	20		33-14-11	ALL
D11924		**P007-00/ /**		**PLUG- AFCS FLOODLIGHT**				**ALL**
	=1		W0104	5518	20		33-14-11	ALL
D11926		**P007-00/ /**		**RCPT- CENTER PANEL FLOODLIGHT**				**ALL**
	=1		W0204	5517	20		33-14-11	ALL
D11928		**P007-00/ /**		**PLUG- CENTER PANEL FLOODLIGHT**				**ALL**
	=1		W0204	5518	20		33-14-11	ALL
D11930		**P009 196/222/L006**		**PLUG-**				**ALL**
	1		W5202	5514	20		33-14-11	ALL
	2		W5202	5518	20		33-14-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5202	5512	20		33-14-11	ALL
	6		W5202	5513	20		33-14-11	ALL
	7		W5202	5516	20		33-14-11	ALL
	8		W5202	5517	20		33-14-11	ALL
	9	UNUSED						ALL
	10		W5202	5515	20		33-14-11	ALL
	11		W5202	5510	20		33-14-11	ALL
	12		W5202	5511	20		33-14-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5202	5524	20		33-14-11	ALL
	21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11930	**P009 196/222/L006**		**PLUG- (continued)**				**ALL**
22	UNUSED						ALL
23		W5202	5522	20		33-14-11	ALL
24		W5202	5520	20		33-14-11	ALL
D11932	**P009 196/222/R005**		**PLUG-**				**ALL**
1		W5202	5505	20		33-14-11	ALL
2		W5202	5509	20		33-14-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5202	5503	20		33-14-11	ALL
6		W5202	5504	20		33-14-11	ALL
7		W5202	5507	20		33-14-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5202	5506	20		33-14-11	ALL
11		W5202	5501	20		33-14-11	ALL
12		W5202	5502	20		33-14-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5202	5523	20		33-14-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5202	5508	20		33-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D11936		**P007-00/ /**		**RCPT- MOUNTED FLOODLIGHT**				**ALL**
	=1		W0104	5519	20		33-14-11	ALL
D11938		**P007-00/ /**		**PLUG- MOUNTED FLOODLIGHT**				**ALL**
	=1		W0104	5520	20		33-14-11	ALL
D11939		**P006-00/ /**		**RCPT-RPL CONTROL SYS A HYD**				**ALL**
	A1		W0044	0853	20		27-25-11	ALL
	A2		W0044	0852	20		27-25-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0044	0854	20		27-25-11	ALL
	X2		W0044	0855	20		27-25-11	ALL
D11940		**P007-00/ /**		**RCPT- MOUNT FLOODLIGHT**				**ALL**
	=1		W0204	5519	20		33-14-11	ALL
D11941		**P006-00/ /**		**RCPT-RPL CONTROL SYS B HYD**				**ALL**
	A1		W0044	0857	20		27-25-11	ALL
	A2		W0044	0856	20		27-25-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0044	0858	20		27-25-11	ALL
	X2		W0044	0859	20		27-25-11	ALL
D11942		**P007-00/ /**		**PLUG- MOUNT FLOODLIGHT**				**ALL**
	=1		W0204	5520	20		33-14-11	ALL
D11988		**P005-04/ /**		**PLUG-LEFT WINDSHIELD WIPER SWITCH**				**ALL**
	1		W2218	5715	20		33-12-12	ALL
	2		W2218	5716	20		33-12-12	ALL
	3		W2112	5555	24		30-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D11988		**P005-04/ /**		**PLUG-LEFT WINDSHIELD WIPER SWITCH (continued)**				**ALL**
	4		W2112	5556	18		30-42-11	ALL
	5		W2104	5505	18		30-42-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D11995		**725/170/L016**		**PLUG- CONDUCTIVE**				**ALL**
	1		W7128	3001Y	20		31-31-14	ALL
	2		W7128	3001R	20		31-31-14	ALL
	3		W7128	3001B	20		31-31-14	ALL
	S/R		W7128	3001Z			31-31-14	ALL
D11997		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0094	0162	22		44-21-22	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0094	0164	22		44-21-22	ALL
	7		W0094	0119	20		44-21-22	ALL
	8		W0094	0165	20		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12002		**500C+6/212/R067**		**PLUG-**				**ALL**
	1	16	W4142	0501	16		33-51-11	ALL
	2		W4142	0502	20		33-51-11	ALL
	3		W4142	0503	22		33-51-11	ALL
	4		W4142	0504	22		33-51-11	ALL
	5		W4142	0506	20		33-51-11	ALL
	6		W4142	0506	20		33-51-11	ALL
	7		W4142	0507	20		33-51-11	ALL
	8	UNUSED						ALL
	9	16	W4142	0509	16		33-51-12	ALL
	10	UNUSED						ALL
	11		W4142	0515	20		33-51-12	ALL
	12	UNUSED						ALL
	13		W4142	0513	20		33-51-12	ALL
	14		W4142	0514	20		33-51-12	ALL
	15	UNUSED						ALL
	16		W4142	0516	20		33-51-12	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W4142	0524	20		33-51-11	ALL
	21	UNUSED						ALL
	22		W4142	0522	20		33-51-11	ALL
	23	UNUSED						ALL
	24		W4142	0524	20		33-51-11	ALL
D12004		**727C+14/212/R067**		**PLUG-**				**ALL**
	1	16	W4142	0201	16		33-51-11	ALL
	2		W4142	0202	20		33-51-11	ALL
	3		W4142	0203	22		33-51-11	ALL
	4		W4142	0204	22		33-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12004	**727C+14/212/R067**		**PLUG- (continued)**				**ALL**
5		W4142	0206	20		33-51-11	ALL
6		W4142	0206	20		33-51-11	ALL
7		W4142	0207	20		33-51-11	ALL
8	UNUSED						ALL
9	16	W4142	0212	16		33-51-14	ALL
10		W4142	0209	20		33-51-22	ALL
11	16	W4142	0211	16		33-51-14	ALL
12	UNUSED						ALL
13		W4142	0620	20		33-51-14	ALL
14		W4142	0624	20		33-51-14	ALL
15		W4142	0622	20		33-51-14	ALL
16		W4142	0626	20		33-51-14	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W4142	0224	20		33-51-11	ALL
21	UNUSED						ALL
22		W4142	0222	20		33-51-11	ALL
23	UNUSED						ALL
24		W4142	0224	20		33-51-11	ALL
D12006	**P006-00/ /**		**PLUG-**				**ALL**
1		W0044	0654	20		28-21-21	ALL
2		W0044	0654	20		28-21-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0044	0645	20		28-21-21	ALL
6		W0044	0651	20		28-21-21	ALL
7		W0044	0655	20		28-21-21	ALL
8		W0044	0646	20		28-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12006		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0044	1107	20		28-21-21	ALL
	12		W0044	0649	20		28-21-21	ALL
	DED		W0044	1107Z			28-21-21	ALL
D12008		**565/213/L068**		**PLUG-**				**ALL**
	1	16	W3142	0201	16		33-51-11	ALL
	2		W3142	0202	20		33-51-11	ALL
	3		W3142	0203	22		33-51-11	ALL
	4		W3142	0204	22		33-51-11	ALL
	5		W3142	0206	20		33-51-11	ALL
	6		W3142	0206	20		33-51-11	ALL
	7		W3142	0207	20		33-51-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W3142	0211	20		33-51-21	ALL
	12		W3142	0212	20		33-51-21	ALL
	13		W3142	0213	20		33-51-13	ALL
	14		W3142	0237	20		33-51-13	ALL
	15		W3142	0215	20		33-51-13	ALL
	16		W3142	0236	20		33-51-13	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W3142	0224	20		33-51-11	ALL
	21	UNUSED						ALL
	22		W3142	0222	20		33-51-11	ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12008	**565/213/L068**		**PLUG- (continued)**				**ALL**
24		W3142	0224	20		33-51-11	ALL
D12010	**565/213/R068**		**PLUG-**				**ALL**
1	16	W4142	0301	16		33-51-11	ALL
2		W4142	0302	20		33-51-11	ALL
3		W4142	0303	22		33-51-11	ALL
4		W4142	0304	22		33-51-11	ALL
5		W4142	0306	20		33-51-11	ALL
6		W4142	0306	20		33-51-11	ALL
7		W4142	0307	20		33-51-11	ALL
8	UNUSED						ALL
9		W4142	0309	20		33-51-13	ALL
10	UNUSED						ALL
11		W4142	0311	20		33-51-21	ALL
12		W4142	0312	20		33-51-21	ALL
13		W4142	0313	20		33-51-13	ALL
14		W4142	0334	20		33-51-13	ALL
15		W4142	0315	20		33-51-13	ALL
16		W4142	0336	20		33-51-13	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W4142	0324	20		33-51-11	ALL
21	UNUSED						ALL
22		W4142	0322	20		33-51-11	ALL
23	UNUSED						ALL
24		W4142	0324	20		33-51-11	ALL
D12018	**653/229/R071**		**PLUG-**				**ALL**
1		W4142	0231	16		33-51-14	ALL
2		W4142	0252	16		33-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12018		**653/229/R071**		**PLUG- (continued)**				**ALL**
	3	UNUSED						ALL
D12032		**608/227/L074**		**PLUG-**				**ALL**
	1		W3142	0509	16		33-51-12	ALL
	2		W3142	0269	16		33-51-12	ALL
	3	UNUSED						ALL
D12036		**653/227/L074**		**PLUG-**				**ALL**
	1		W3142	0309	16		33-51-13	ALL
	2		W3142	0251	16		33-51-13	ALL
	3	UNUSED						ALL
D12050		**608/227/R074**		**PLUG-**				**ALL**
	1		W4142	0509	16		33-51-12	ALL
	2		W4142	0551	16		33-51-12	ALL
	3	UNUSED						ALL
D12052		**430/208/L068**		**RCPT-**				**ALL**
	1		W3142	0051	20		33-51-21	ALL
	2		W3142	0077	20		33-51-21	ALL
	3	UNUSED						ALL
	4		W3142	0078	20		33-51-21	ALL
	5	16	W3142	0079	16		33-51-21	ALL
D12064		**573/225/R070**		**RCPT-**				**ALL**
	=1		W4142	0084	20		33-51-21	ALL
D12066		**573/226/R070**		**PLUG-**				**ALL**
	=1		W4142	0086	20		33-51-21	ALL
D12068		**576/234/L062**		**RCPT-**				**ALL**
	=1	VY	W3142	0211	20		33-51-21	ALL
D12072		**576/234/L062**		**PLUG-**				**ALL**
	=1	VG	W3142	0252	20		33-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12106	**P021-01/ /**		**RCPT-**				**ALL**
=1		W2102	5533	20		33-14-11	ALL
D12108	**P021-01/ /**		**PLUG-**				**ALL**
=1		W2102	5534	20		33-14-11	ALL
D12110	**P023-01/ /**		**RCPT-**				**ALL**
=1		W2204	5533	20		33-14-11	ALL
D12112	**P023-01/ /**		**PLUG-**				**ALL**
=1		W2204	5534	20		33-14-11	ALL
D12156	**228/202/L011**		**PLUG-CAPTAIN COLUMN SWITCHING MODULE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6208	0626	20		27-41-11	ALL
4	UNUSED						ALL
5		W6208	0627	20		27-41-11	ALL
6		W6208	0624	20		27-41-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6208	0625	20		27-41-11	ALL
D12180	**915/168/L001**		**RCPT-**				**ALL**
=1	VS	W6248	5550	20		30-71-11	ALL
D12182	**915/168/L001**		**PLUG-**				**ALL**
=1	VR	W6248	5559	20		30-71-11	ALL
D12184	**958/177/L001**		**RCPT-**				**ALL**
=1	VS	W6248	5554	20		30-71-11	ALL
D12186	**958/178/L001**		**PLUG-**				**ALL**
=1	VR	W6248	5553	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12188		**958/204/R023**		**RCPT-**				**ALL**
	=1	VS	W6248	5560	20		30-71-11	ALL
D12190		**958/204/R023**		**PLUG-**				**ALL**
	=1	VR	W6248	5555	20		30-71-11	ALL
D12192		**996/200/R038**		**RCPT-**				**ALL**
	=1	VS	W6248	5556	20		30-71-11	ALL
D12194		**996/200/R038**		**PLUG-**				**ALL**
	=1	VR	W6248	5561	20		30-71-11	ALL
D12196		**1003/203/L40**		**RCPT-**				**ALL**
	=1	VS	W6248	5566	20		30-71-11	ALL
D12198		**1003/203/L40**		**PLUG-**				**ALL**
	=1	VR	W6248	5567	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12200	**961/203/R024**		**RCPT-**				**ALL**
=1	VS	W6248	5580	20		30-71-11	ALL
D12202	**961/203/R024**		**PLUG-**				**ALL**
=1	VR	W6248	5581	20		30-71-11	ALL
D12204	**910/204/R052**		**RCPT-**				**ALL**
=1	VS	W6248	5572	20		30-71-11	ALL
D12206	**910/204/R052**		**PLUG-**				**ALL**
=1	VR	W6248	5573	20		30-71-11	ALL
D12208	**909/203/R039**		**RCPT-**				**ALL**
=1	VS	W6248	5574	20		30-71-11	ALL
D12210	**909/203/R039**		**PLUG-**				**ALL**
=1	VR	W6248	5575	20		30-71-11	ALL
D12212	**909/204/R050**		**RCPT-**				**ALL**
=1	VS	W6248	5576	20		30-71-11	ALL
D12214	**909/204/R050**		**PLUG-**				**ALL**
=1	VR	W6248	5577	20		30-71-11	ALL
D12216	**902/201/R054**		**RCPT-**				**ALL**
=1	VS	W6248	5578	20		30-71-11	ALL
D12218	**902/201/R054**		**PLUG-**				**ALL**
=1	VR	W6248	5579	20		30-71-11	ALL
D12220	**963/201/R026**		**RCPT-**				**ALL**
=1	VS	W6248	5582	20		30-71-11	ALL
D12222	**963/201/R026**		**PLUG-**				**ALL**
=1	VR	W6248	5583	20		30-71-11	ALL
D12224	**942/203/L042**		**RCPT-**				**ALL**
=1	VS	W6248	5568	20		30-71-11	ALL
D12225	**J00024/ /**		**SOCKET-**				**ALL**
1		W0080	5552	20		21-25-11	ALL
2		W0080	5553	22		21-25-11	ALL
3		W0080	5551	22		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12225		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	4	UNUSED						ALL
	5		W0080	5501	22		21-25-11	ALL
	6		W0080	5555	22		21-25-11	ALL
	7		W0080	5602	24		21-43-21	ALL
	8		W0080	5625	24		21-43-21	ALL
	9		W0080	5605	24		21-43-21	ALL
	10	UNUSED						ALL
	11		W0080	5601	24		21-43-21	ALL
	12		W0080	5554	22		21-25-11	ALL
	13	UNUSED						ALL
	14		W0080	5603	24		21-43-21	ALL
D12226		**942/203/L042**		**PLUG-**				**ALL**
	=1	VR	W6248	5569	20		30-71-11	ALL
D12227		**J00024/ /**		**SOCKET-**				**ALL**
	1		W0080	5558	20		21-25-11	ALL
	2		W0080	5560	22		21-25-11	ALL
	3		W0080	5556	22		21-25-11	ALL
	4	UNUSED						ALL
	5		W0080	5551	22		21-25-11	ALL
	6		W0080	5557	22		21-25-11	ALL
	7		W0080	5603	24		21-43-21	ALL
	8		W0080	5627	20		21-43-21	ALL
	9		W0080	5608	24		21-43-21	ALL
	10	UNUSED						ALL
	11		W0080	5605	24		21-43-21	ALL
	12		W0080	5561	22		21-25-11	ALL
	13	UNUSED						ALL
	14		W0080	5614	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12228		**948/202/R045**		**RCPT-**				**ALL**
	=1	VS	W6248	5584	20		30-71-11	ALL
D12229		**J00024/ /**		**SOCKET-**				**ALL**
	A1	UNUSED						ALL
	A2		W0080	5565	22		21-27-21	ALL
	A3		W0080	5510	22		21-27-21	ALL
	B1	UNUSED						ALL
	B2		W0080	5569	22		21-27-21	ALL
	B3		W0080	5570	22		21-27-21	ALL
	C1		W0080	5567	22		21-27-21	ALL
	C2		W0080	5568	22		21-27-21	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2		W0080	5564	22		21-27-21	ALL
	D3		W0080	5508	24		21-27-21	ALL
	X1		W0080	5634	22		21-27-21	ALL
	X2		W0080	5613	20		21-27-21	ALL
D12230		**948/202/R045**		**PLUG-**				**ALL**
	=1	VR	W6248	5585	20		30-71-11	ALL
D12232		**897/204/L047**		**RCPT-**				**ALL**
	=1	VS	W6248	5570	20		30-71-11	ALL
D12234		**897/204/L047**		**PLUG-**				**ALL**
	=1	VR	W6248	5571	20		30-71-11	ALL
D12237		**P008/ /**		**PLUG**				**ALL**
	1		W3709	0001	20		33-11-41	ALL
	2		W3709	0002	20		33-11-41	ALL
	3		W3709	3501R	24		23-70-11	ALL
	4	UNUSED						ALL
	5		W3709	3501Y	24		23-70-11	ALL
	6		W3709	3501B	24		23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12237		**P008/ /**		**PLUG (continued)**				**ALL**
	7		W3709	2501R	24		23-70-11	ALL
	8		W3709	2501B	24		23-70-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3709	2501Z			23-70-11	ALL
	S/R		W3709	3501Z			23-70-11	ALL
D12248		**J00024/ /**		**SOCKET-**				**ALL**
	1	UNUSED						ALL
	2		W0080	5563	24		21-27-21	ALL
	3		W0080	5538	24		21-27-21	ALL
	4		W0080	5539	22		21-27-21	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0080	5537	24		21-27-21	ALL
	8	UNUSED						ALL
D12250		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	1	UNUSED						ALL
	2		W0072	0132	24		21-27-31	ALL
	3		W0072	0133	22		21-27-31	ALL
	4		W0072	0134	20		21-27-31	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0072	0137	22		21-27-31	ALL
	8	UNUSED						ALL
D12289		**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0082	0095	22		27-33-11	ALL
	A2		W0082	0076	20		27-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12289	**J039-0A/ /**		**RELAY-SOCKET (continued)**				**ALL**
A3		W0082	0098	22		27-33-11	ALL
B1	UNUSED						ALL
B2		W0082	0075	22		27-33-11	ALL
B3		W0082	0101	22		27-33-11	ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0082	0077	22		27-33-11	ALL
X2		W0082	0078	22		27-33-11	ALL
D12291	**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
A1		W0082	0107	22		27-33-11	ALL
A2		W0082	0097	22		27-33-11	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2		W0082	0095	22		27-33-11	ALL
B3		W0082	0108	22		27-33-11	ALL
C1	UNUSED						ALL
C2		W0082	0099	22		27-33-11	ALL
C3		W0082	1102	22		27-33-11	ALL
D1	UNUSED						ALL
D2		W0082	0102	22		27-33-11	ALL
D3		W0082	1101	22		27-33-11	ALL
X1		W0082	0093	22		27-33-11	ALL
X2		W0082	0094	20		27-33-11	ALL
		W0082	0103	20		27-33-11	ALL
		W0082	0106	20		27-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12291		**J039-0A/ /**		**RELAY-SOCKET (continued)**				**ALL**
			W0082	1101Z			27-33-11	ALL
			W0082	1102Z			27-33-11	ALL
D12293		**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0082	0088	22		27-33-11	ALL
	A2		W0082	0091	20		27-33-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0082	0085	22		27-33-11	ALL
	X2		W0082	0092	22		27-33-11	ALL
D12297		**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0082	0080	20		27-33-11	ALL
	A3		W0082	0087	22		27-33-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12297		**J039-0A/ /**		**RELAY-SOCKET (continued)**				**ALL**
	D3	UNUSED						ALL
	X1		W0082	0082	22		27-33-11	ALL
	X2		W0082	0083	20		27-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12303		**1082/266/R018**		**PLUG-ELEVATOR FEEL COMPUTER**				**ALL**
	1		W4134	1020	20		27-33-11	ALL
	2		W4134	1018	20		27-33-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W4134	1019	20		27-33-11	ALL
	6		W4134	1010	20		27-31-37	ALL
	7		W4134	1011	20		27-31-37	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W4134	1010Z			27-31-37	ALL
	S/R		W4134	1011Z			27-31-37	ALL
	S/R		W4134	1018Z			27-33-11	ALL
	S/R		W4134	1019Z			27-33-11	ALL
	S/R		W4134	1020Z			27-33-11	ALL
D12346		**915/165/R010**		**RCPT-WTR PRESS PROX SW**				**ALL**
	=1	VY	W5112	0518	20		38-41-13	ALL
D12348		**915/165/R010**		**PLUG-WTR PRESS PROX SW**				**ALL**
	=1	VG	W5112	0511	20		38-41-13	ALL
D12350		**360/284/L031**		**PLUG-**				**ALL**
	1		W3142	0275	20		33-51-21	ALL
	2		W3142	0276	20		33-51-21	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12430	**642/224/R062**		**RCPT-**				**ALL**
=1		W4142	0209	20		33-51-22	ALL
D12432	**642/224/R062**		**PLUG-**				**ALL**
=1		W4142	0082	20		33-51-22	ALL
D12434	**642/224/L062**		**RCPT-**				**ALL**
=1	VY	W3142	0308	20		33-51-22	ALL
D12436	**642/224/L062**		**PLUG-**				**ALL**
=1	VG	W3142	0082	20		33-51-22	ALL
D12442	**590/270/L060**		**RCPT-**				**ALL**
=1	VY	W3142	0233	16		33-51-13	ALL
D12444	**590/270/L060**		**PLUG-**				**ALL**
=1	VG	W3142	0274	16		33-51-13	ALL
D12448	**628/270/L060**		**RCPT-**				**ALL**
=1	VY	W3142	0238	16		33-51-13	ALL
D12450	**628/270/L060**		**PLUG-**				**ALL**
=1	VG	W3142	0255	16		33-51-13	ALL
D12454	**590/270/R060**		**RCPT-**				**ALL**
=1		W4142	0330	16		33-51-13	ALL
D12456	**590/270/R060**		**PLUG-**				**ALL**
=1		W4142	0354	16		33-51-13	ALL
D12460	**628/270/R060**		**RCPT-**				**ALL**
=1		W4142	0335	16		33-51-13	ALL
D12462	**628/270/R060**		**PLUG-**				**ALL**
=1		W4142	0356	16		33-51-13	ALL
D12466	**J020-0B/ /**		**RELAY SOCKET**				**ALL**
1		W0072	2011B	24		31-32-15	ALL
2		W0072	2012R	24		73-24-12	ALL
3		W0072	0230	22		31-32-15	ALL
4		W0072	2013R	24		73-24-12	ALL
5		W0072	2011R	24		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12466		**J020-0B/ /**		**RELAY SOCKET (continued)**				**ALL**
	6		W0072	2012B	24		73-24-12	ALL
	7		W0072	0231	20		49-62-11	ALL
	8		W0072	2013B	24		73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12538		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0019	20		52-71-13	ALL
	A2		W0076	0010	20		52-71-13	ALL
	A3	UNUSED						ALL
	B1		W0076	0020	20		52-71-13	ALL
	B2		W0076	0018	20		52-71-13	ALL
	B3	UNUSED						ALL
	C1		W0076	0168	22		23-71-01	ALL
	C2		W0076	0159	20		23-71-01	ALL
	C3		W0076	0180	22		23-71-01	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0028	24		73-22-31	ALL
	X2		W0076	0029	24		73-22-31	ALL
D12540		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	0007	20		52-71-14	ALL
	A2		W0080	0009	20		52-71-14	ALL
	A3	UNUSED						ALL
	B1		W0080	0006	20		52-71-14	ALL
	B2		W0080	0008	20		52-71-14	ALL
	B3	UNUSED						ALL
	C1		W0080	0023	22		23-71-01	ALL
	C2		W0080	0024	20		23-71-01	ALL
	C3		W0080	0025	22		23-71-01	ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	0011	24		73-22-31	ALL
	X2		W0080	0012	24		73-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12544		**617/251/R066**		**RCPT-**				**ALL**
	=1		W4142	5530	20		21-42-11	ALL
D12546		**617/251/R066**		**PLUG-**				**ALL**
	=1		W4142	5531	20		21-42-11	ALL
D12552		**617/251/L066**		**RCPT-**				**ALL**
	=1	VS	W3142	5530	20		21-42-11	ALL
D12554		**617/251/L066**		**PLUG-**				**ALL**
	=1	VG	W3142	5531	20		21-42-11	ALL
D12560		**579/251/R066**		**RCPT-**				**ALL**
	=1		W4142	5540	20		21-42-11	ALL
D12562		**579/251/R066**		**PLUG-**				**ALL**
	=1		W4142	5541	20		21-42-11	ALL
D12576		**579/251/L066**		**RCPT-**				**ALL**
	=1	VS	W3142	5540	20		21-42-11	ALL
D12578		**579/251/L066**		**PLUG-**				**ALL**
	=1	VG	W3142	5541	20		21-42-11	ALL
D12592		**P009 196/222/L008**		**PLUG-**				**ALL**
	1		W5202	5530	20		33-14-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5202	5532	20		33-14-11	ALL
	6		W5202	5531	20		33-14-11	ALL
	7		W5202	5536	20		33-14-11	ALL
	8	UNUSED						ALL
	9		W5202	5519	20		33-14-11	ALL
	10		W5202	5535	20		33-14-11	ALL
	11		W5202	5529	20		33-14-11	ALL
	12		W5202	5533	20		33-14-11	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12592		**P009 196/222/L008**		**PLUG- (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W5202	5521	20		33-14-11	ALL
	19	UNUSED						ALL
	20		W5202	5534	20		33-14-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12606		**328/281/R034**		**PLUG-**				**ALL**
	1		W0342	0001	18		35-21-31	ALL
	2		W0342	0002	18		35-21-31	ALL
	3	UNUSED						ALL
D12652		**638/251/R066**		**RCPT-**				**ALL**
	=1		W4142	5528	20		21-42-11	ALL
D12654		**638/251/R066**		**PLUG-**				**ALL**
	=1		W4142	5529	20		21-42-11	ALL
D12656		**614/229/R069**		**RCPT-**				**ALL**
	=1		W4142	5532	20		21-42-11	ALL
D12657J		**AB0373/ /**		**RCPT**				**ALL**
	A-1		W3755	4014R	24		44-35-12	ALL
	A-2		W3755	4014Y	24		44-35-12	ALL
	A-3		W3755	4014B	24		44-35-12	ALL
	A-4		W3755	4014G	24		44-35-12	ALL
	B-1	UNUSED						ALL
	B-2	UNUSED						ALL
	B-3	UNUSED						ALL
	B-4	UNUSED						ALL
	=CA		W3755	4014Z			44-35-12	ALL
	=CB	UNUSED						ALL
D12658		**614/229/R069**		**PLUG-**				**ALL**
	=1		W4142	5533	20		21-42-11	ALL
D12660		**640/229/R069**		**RCPT-**				**ALL**
	=1		W4142	5526	20		21-42-11	ALL
D12662		**640/229/R069**		**PLUG-**				**ALL**
	=1		W4142	5527	20		21-42-11	ALL
D12664		**638/251/L066**		**RCPT-**				**ALL**
	=1	VS	W3142	5528	20		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12666		**638/251/L066**		**PLUG-**				**ALL**
	=1	VG	W3142	5529	20		21-42-11	ALL
D12668		**613/229/L069**		**RCPT-**				**ALL**
	=1	VS	W3142	5532	20		21-42-11	ALL
D12670		**613/229/L069**		**PLUG-**				**ALL**
	=1	VG	W3142	5533	20		21-42-11	ALL
D12672		**639/229/L069**		**RCPT-**				**ALL**
	=1	VS	W3142	5526	20		21-42-11	ALL
D12674		**639/229/L069**		**PLUG-**				**ALL**
	=1	VG	W3142	5527	20		21-42-11	ALL
D12676		**600/251/R066**		**RCPT-**				**ALL**
	=1		W4142	5538	20		21-42-11	ALL
D12678		**600/251/R066**		**PLUG-**				**ALL**
	=1		W4142	5539	20		21-42-11	ALL
D12680		**570/229/R069**		**RCPT-**				**ALL**
	=1		W4142	5542	20		21-42-11	ALL
D12682		**570/229/R069**		**PLUG-**				**ALL**
	=1		W4142	5543	20		21-42-11	ALL
D12684		**607/223/R070**		**RCPT-**				**ALL**
	=1		W4142	5534	20		21-42-11	ALL
D12686		**607/223/R070**		**PLUG-**				**ALL**
	=1		W4142	5535	20		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12700		**600/251/L066**		**RCPT-**				**ALL**
	=1	VS	W3142	5538	20		21-42-11	ALL
D12702		**600/251/L066**		**PLUG-**				**ALL**
	=1	VG	W3142	5539	20		21-42-11	ALL
D12704		**575/224/L069**		**RCPT-**				**ALL**
	=1	VS	W3142	5542	20		21-42-11	ALL
D12706		**575/224/L069**		**PLUG-**				**ALL**
	=1	VG	W3142	5543	20		21-42-11	ALL
D12708		**604/222/L070**		**RCPT-**				**ALL**
	=1	VS	W3142	5534	20		21-42-11	ALL
D12710		**604/222/L070**		**PLUG-**				**ALL**
	=1	VG	W3142	5535	20		21-42-11	ALL
D12756		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0009	20		52-71-13	ALL
	A2		W0076	0005	20		52-71-13	ALL
	A3	UNUSED						ALL
	B1		W0076	0518	20		52-71-13	ALL
	B2		W0076	0523	20		52-71-13	ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0006	20		52-71-13	ALL
	X2		W0076	0008	20		52-71-13	ALL
D12758		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	0005	20		52-71-14	ALL
	A2		W0080	0001	20		52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12758	**J00024/ /**		**SOCKET- (continued)**				**ALL**
A3	UNUSED						ALL
B1		W0080	0015	20		52-71-14	ALL
B2		W0080	0014	20		52-71-14	ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0080	0003	20		52-71-14	ALL
X2		W0080	0004	20		52-71-14	ALL
D12760	**P008-75/ /**		**CONNECTOR**				**ALL**
1		W2110	6033	20		33-11-33	ALL
2		W2110	6032	20		33-11-33	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2110	6012	20		26-16-21	ALL
8		W2110	6018	22		26-16-22	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W2110	6037	22		26-23-11	ALL
13	UNUSED						ALL
14		W2110	6005	22		26-16-21	ALL
15		W2110	6004	22		26-16-21	ALL
16		W2110	6043	22		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12760	**P008-75/ /**		**CONNECTOR (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19		W2110	6019	22		26-16-22	ALL
20		W2110	6015	22		26-16-22	ALL
21		W2110	6016	22		26-16-22	ALL
22		W2110	6017	22		26-16-22	ALL
23		W2110	6038	22		26-23-11	ALL
24		W2110	6042	22		26-23-11	ALL
25	UNUSED						ALL
26		W2110	6041	22		26-23-11	ALL
27	UNUSED						ALL
28		W2110	6040	22		26-23-11	ALL
29		W2110	6007	22		26-16-21	ALL
30		W2110	6006	22		26-16-21	ALL
31		W2110	6008	22		26-16-21	ALL
32		W2110	6003	22		26-16-21	ALL
33		W2110	6030	20		33-18-64	ALL
34		W2110	6036	22		26-11-31	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W2110	6020	22		26-16-22	ALL
38		W2110	6021	22		26-16-22	ALL
39	UNUSED						ALL
40		W2110	6013	22		26-16-22	ALL
41		W2110	6011	20		26-16-21	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W2110	6039	22		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12760	**P008-75/ /**		**CONNECTOR (continued)**				**ALL**
46	UNUSED						ALL
47	UNUSED						ALL
48		W2110	6022	22		26-23-11	ALL
49		W2110	6034	22		26-16-21	ALL
50		W2110	6045	24		26-16-22	ALL
51		W2110	6002	22		26-16-21	ALL
52		W2110	6010	20		26-16-21	ALL
53		W2110	6001	22		26-16-21	ALL
54		W2110	6009	22		26-16-21	ALL
55	UNUSED						ALL
56		W2110	6035	22		26-11-21	ALL
57	UNUSED						ALL
58		W2110	6044	24		26-16-21	ALL
59	UNUSED						ALL
60		W2110	6029	20		33-18-64	ALL
61		W2110	6014	22		26-16-22	ALL
D12762	**450/204/L030**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W5088	6011	22		26-16-21	ALL
3		W5088	6012	22		26-16-21	ALL
4		W5088	6010	22		26-16-21	ALL
5		W5088	6001	22		26-16-21	ALL
6		W5088	6007	22		26-16-21	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W5088	6008	22		26-16-21	ALL
10	UNUSED						ALL
11		W5088	6009	22		26-16-21	ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12762		**450/204/L030**		**CONNECTOR (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5088	6013	22		26-16-21	ALL
	21		W5088	6014	22		26-16-21	ALL
	22	UNUSED						ALL
	23		W5088	6003	22		26-16-21	ALL
	24		W5088	6004	22		26-16-21	ALL
	25		W5088	6014	22		26-16-21	ALL
	26		W5088	6005	22		26-16-21	ALL
	27	UNUSED						ALL
	28		W5088	6006	22		26-16-21	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W5088	6002	22		26-16-21	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W5088	6013	22		26-16-21	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
D12764		**450/204/L028**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12764	**450/204/L028**		**CONNECTOR (continued)**				**ALL**
4	UNUSED						ALL
5		W5086	6004	22		26-16-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5086	6016	22		26-16-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5086	6013	22		26-16-21	ALL
12		W5086	6009	22		26-16-21	ALL
13		W5086	6011	22		26-16-21	ALL
14		W5086	6022	22		26-16-21	ALL
15	UNUSED						ALL
16		W5086	6003	22		26-16-21	ALL
17	UNUSED						ALL
18		W5086	6018	22		26-16-21	ALL
19	UNUSED						ALL
20		W5086	6021	22		26-16-21	ALL
21	UNUSED						ALL
22		W5086	6008	22		26-16-21	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W5086	6006	22		26-16-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W5086	6023	22		26-16-21	ALL
30		W5086	6026	22		26-16-21	ALL
31		W5086	6017	22		26-16-21	ALL
32	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12764		**450/204/L028**		**CONNECTOR (continued)**				**ALL**
	33		W5086	6012	22		26-16-21	ALL
	34	UNUSED						ALL
	35		W5086	6025	22		26-16-21	ALL
	36		W5086	6029	22		26-16-21	ALL
	37		W5086	6001	22		26-16-21	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45		W5086	6014	22		26-16-21	ALL
	46		W5086	6024	22		26-16-21	ALL
	47		W5086	6024	22		26-16-21	ALL
	48		W5086	6025	22		26-16-21	ALL
	49		W5086	6028	22		26-16-21	ALL
	50		W5086	6027	22		26-16-21	ALL
	51		W5086	6030	22		26-16-21	ALL
	52		W5086	6026	22		26-16-21	ALL
	53		W5086	6019	22		26-16-21	ALL
	54		W5086	6023	22		26-16-21	ALL
	55		W5086	6030	22		26-16-21	ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58		W5086	6029	22		26-16-21	ALL
	59		W5086	6028	22		26-16-21	ALL
	60		W5086	6022	22		26-16-21	ALL
	61		W5086	6007	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12764	**450/204/L028**		**CONNECTOR (continued)**				**ALL**
62	UNUSED						ALL
63		W5086	6031	22		26-16-21	ALL
64		W5086	6027	22		26-16-21	ALL
65		W5086	6021	22		26-16-21	ALL
66		W5086	6002	22		26-16-21	ALL
D12766	**470/203/L015**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5086	6001	22		26-16-21	ALL
5		W5086	6003	22		26-16-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5086	6005	20		26-16-21	ALL
11		W5086	6004	22		26-16-21	ALL
12		W5086	6002	22		26-16-21	ALL
D12768	**500C+10/203/L012**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5086	6006	22		26-16-21	ALL
5		W5086	6008	22		26-16-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5086	6010	20		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12768		**500C+10/203/L012**		**CONNECTOR (continued)**				**ALL**
	11		W5086	6009	22		26-16-21	ALL
	12		W5086	6007	22		26-16-21	ALL
D12770		**430/203/R012**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5086	6011	22		26-16-21	ALL
	5		W5086	6013	22		26-16-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5086	6015	20		26-16-21	ALL
	11		W5086	6014	22		26-16-21	ALL
	12		W5086	6012	22		26-16-21	ALL
D12772		**500E+10/203/R015**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5086	6016	22		26-16-21	ALL
	5		W5086	6018	22		26-16-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5086	6020	20		26-16-21	ALL
	11		W5086	6019	22		26-16-21	ALL
	12		W5086	6017	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12774	**817/206/L030**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W5098	6020	22		26-16-22	ALL
3		W5098	6021	22		26-16-22	ALL
4		W5098	6019	22		26-16-22	ALL
5		W5098	6001	22		26-16-22	ALL
6		W5098	6007	22		26-16-22	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W5098	6008	22		26-16-22	ALL
10	UNUSED						ALL
11		W5098	6009	22		26-16-22	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5098	6022	22		26-16-22	ALL
21		W5098	6023	22		26-16-22	ALL
22	UNUSED						ALL
23		W5098	6003	22		26-16-22	ALL
24		W5098	6004	22		26-16-22	ALL
25		W5098	6023	22		26-16-22	ALL
26		W5098	6005	22		26-16-22	ALL
27	UNUSED						ALL
28		W5098	6006	22		26-16-22	ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12774		**817/206/L030**		**CONNECTOR (continued)**				**ALL**
	30	UNUSED						ALL
	31		W5098	6002	22		26-16-22	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W5098	6022	22		26-16-22	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
D12776		**817/206/L030**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5096	6004	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5096	6021	22		26-16-22	ALL
	9		W5096	6028	22		26-16-22	ALL
	10	UNUSED						ALL
	11		W5096	6018	22		26-16-22	ALL
	12		W5096	6009	22		26-16-22	ALL
	13		W5096	6016	22		26-16-22	ALL
	14		W5096	6031	22		26-16-22	ALL
	15	UNUSED						ALL
	16		W5096	6003	22		26-16-22	ALL
	17	UNUSED						ALL
	18		W5096	6023	22		26-16-22	ALL
	19	UNUSED						ALL
	20		W5096	6014	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12776	**817/206/L030**		**CONNECTOR (continued)**				**ALL**
21	UNUSED						ALL
22		W5096	6008	22		26-16-22	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W5096	6026	22		26-16-22	ALL
26		W5096	6006	22		26-16-22	ALL
27		W5096	6011	22		26-16-22	ALL
28	UNUSED						ALL
29		W5096	6032	22		26-16-22	ALL
30		W5096	6027	22		26-16-22	ALL
31		W5096	6022	22		26-16-22	ALL
32	UNUSED						ALL
33		W5096	6017	22		26-16-22	ALL
34	UNUSED						ALL
35		W5096	6034	22		26-16-22	ALL
36		W5096	6037	22		26-16-22	ALL
37		W5096	6001	22		26-16-22	ALL
38		W5096	6013	22		26-16-22	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W5096	6019	22		26-16-22	ALL
46		W5096	6033	22		26-16-22	ALL
47		W5096	6033	22		26-16-22	ALL
48		W5096	6034	22		26-16-22	ALL
49		W5096	6036	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12776		**817/206/L030**		**CONNECTOR (continued)**				**ALL**
	50		W5096	6035	22		26-16-22	ALL
	51		W5096	6038	22		26-16-22	ALL
	52		W5096	6029	22		26-16-22	ALL
	53		W5096	6024	22		26-16-22	ALL
	54		W5096	6032	22		26-16-22	ALL
	55		W5096	6038	22		26-16-22	ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58		W5096	6037	22		26-16-22	ALL
	59		W5096	6036	22		26-16-22	ALL
	60		W5096	6031	22		26-16-22	ALL
	61		W5096	6007	22		26-16-22	ALL
	62	UNUSED						ALL
	63		W5096	6039	22		26-16-22	ALL
	64		W5096	6035	22		26-16-22	ALL
	65		W5096	6012	22		26-16-22	ALL
	66		W5096	6002	22		26-16-22	ALL
D12778		**727C+10/205/L011**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5096	6001	22		26-16-22	ALL
	5		W5096	6003	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5096	6005	20		26-16-22	ALL
	11		W5096	6004	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12778	**727C+10/205/L011**		**CONNECTOR (continued)**				**ALL**
12		W5096	6002	22		26-16-22	ALL
D12780	**727I+11/205/L009**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5096	6006	22		26-16-22	ALL
5		W5096	6008	22		26-16-22	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5096	6010	20		26-16-22	ALL
11		W5096	6009	22		26-16-22	ALL
12		W5096	6007	22		26-16-22	ALL
D12782	**877/205/L009**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5096	6011	22		26-16-22	ALL
5		W5096	6013	22		26-16-22	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5096	6015	20		26-16-22	ALL
11		W5096	6014	22		26-16-22	ALL
12		W5096	6012	22		26-16-22	ALL
D12784	**727B+10/205/R010**		**CONNECTOR**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12784		**727B+10/205/R010**		**CONNECTOR (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5096	6016	22		26-16-22	ALL
	5		W5096	6018	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5096	6020	20		26-16-22	ALL
	11		W5096	6019	22		26-16-22	ALL
	12		W5096	6017	22		26-16-22	ALL
D12786		**727J+11/205/R009**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5096	6021	22		26-16-22	ALL
	5		W5096	6023	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5096	6025	20		26-16-22	ALL
	11		W5096	6024	22		26-16-22	ALL
	12		W5096	6022	22		26-16-22	ALL
D12788		**857/205/R009**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5096	6026	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12788		**857/205/R009**		**CONNECTOR (continued)**				**ALL**
	5		W5096	6028	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5096	6030	20		26-16-22	ALL
	11		W5096	6029	22		26-16-22	ALL
	12		W5096	6027	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12802		**500C+10/210/L070**		**RCPT-**				**ALL**
	1		W3142	0551	20		33-51-21	ALL
	2		W3142	0552	20		33-51-21	ALL
	3	UNUSED						ALL
	4		W3142	0554	20		33-51-21	ALL
	5		W3142	0555	20		33-51-21	ALL
D12804J		**AB0373/ /**		**RCPT**				**ALL**
	1		W3477	0009	20		44-21-12	ALL
	2	UNUSED						ALL
	3		W3477	0011	20		44-21-12	ALL
	4	UNUSED						ALL
	5		W3477	0010	20		44-21-12	ALL
	6		W3477	0012	20		44-21-12	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D12828		**570/210/L075**		**RCPT-**				**ALL**
	1		W3142	0225	20		33-51-21	ALL
	2		W3142	0226	20		33-51-21	ALL
	3	UNUSED						ALL
	4		W3142	0227	20		33-51-21	ALL
	5		W3142	0228	20		33-51-21	ALL
D12883J		**AB0373/ /**		**RCPT**				**ALL**
	A-1		W3477	4001Y	24		44-21-12	ALL
	A-2		W3477	4001R	24		44-21-12	ALL
	A-3		W3477	4001G	24		44-21-12	ALL
	A-4		W3477	4001B	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12883J	**AB0373/ /**		**RCPT (continued)**				**ALL**
B-1		W3477	4002Y	24		44-21-12	ALL
B-2		W3477	4002R	24		44-21-12	ALL
B-3		W3477	4002G	24		44-21-12	ALL
B-4		W3477	4002B	24		44-21-12	ALL
=CA		W3477	4001Z			44-21-12	ALL
=CB		W3477	4002Z			44-21-12	ALL
D12885J	**AB0373/ /**		**RCPT**				**ALL**
A-1		W3477	4003R	24		44-21-12	ALL
A-2		W3477	4003Y	24		44-21-12	ALL
A-3		W3477	4003B	24		44-21-12	ALL
A-4		W3477	4003G	24		44-21-12	ALL
B-1		W3477	4004R	24		44-21-12	ALL
B-2		W3477	4004Y	24		44-21-12	ALL
B-3		W3477	4004B	24		44-21-12	ALL
B-4		W3477	4004G	24		44-21-12	ALL
=CA		W3477	4003Z			44-21-12	ALL
=CB		W3477	4004Z			44-21-12	ALL
D12889J	**AB0373/ /**		**RCPT**				**ALL**
A-1		W3477	4005R	24		44-21-12	ALL
A-2		W3477	4005Y	24		44-21-12	ALL
A-3		W3477	4005B	24		44-21-12	ALL
A-4		W3477	4005G	24		44-21-12	ALL
B-1		W3477	4006R	24		44-21-12	ALL
B-2		W3477	4006Y	24		44-21-12	ALL
B-3		W3477	4006B	24		44-21-12	ALL
B-4		W3477	4006G	24		44-21-12	ALL
=CA		W3477	4005Z			44-21-12	ALL
=CB		W3477	4006Z			44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12891J		**AB0373/ /**		**RCPT**				**ALL**
	A-1		W3477	4007R	24		44-21-12	ALL
	A-2		W3477	4007Y	24		44-21-12	ALL
	A-3		W3477	4007B	24		44-21-12	ALL
	A-4		W3477	4007G	24		44-21-12	ALL
	B-1		W3477	4008R	24		44-21-12	ALL
	B-2		W3477	4008Y	24		44-21-12	ALL
	B-3		W3477	4008B	24		44-21-12	ALL
	B-4		W3477	4008G	24		44-21-12	ALL
	=CA		W3477	4007Z			44-21-12	ALL
	=CB		W3477	4008Z			44-21-12	ALL
D12893J		**AB0373/ /**		**RCPT**				**ALL**
	A-1		W3477	4009R	24		44-21-12	ALL
	A-2		W3477	4009Y	24		44-21-12	ALL
	A-3		W3477	4009B	24		44-21-12	ALL
	A-4		W3477	4009G	24		44-21-12	ALL
	B-1		W3477	4010R	24		44-21-12	ALL
	B-2		W3477	4010Y	24		44-21-12	ALL
	B-3		W3477	4010B	24		44-21-12	ALL
	B-4		W3477	4010G	24		44-21-12	ALL
	=CA		W3477	4009Z			44-21-12	ALL
	=CB		W3477	4010Z			44-21-12	ALL
D12897J		**AB0366/ /**		**RCPT**				**ALL**
	A-1		W3477	4005Y	24		44-21-12	ALL
	A-2		W3477	4005R	24		44-21-12	ALL
	A-3		W3477	4005G	24		44-21-12	ALL
	A-4		W3477	4005B	24		44-21-12	ALL
	B-1		W3477	4006Y	24		44-21-12	ALL
	B-2		W3477	4006R	24		44-21-12	ALL
	B-3		W3477	4006G	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12897J		**AB0366/ /**		**RCPT (continued)**				**ALL**
	B-4		W3477	4006B	24		44-21-12	ALL
	=CA		W3477	4005Z			44-21-12	ALL
	=CB		W3477	4006Z			44-21-12	ALL
D12899J		**AB0373/ /**		**RCPT**				**ALL**
	1		W3477	0019	22		44-21-12	ALL
	2		W3477	0004	20		44-21-12	ALL
	3		W3477	0005	20		44-21-12	ALL
	4		W3477	0006	20		44-21-12	ALL
	5		W3477	0008	20		44-21-12	ALL
	6	UNUSED						ALL
	7		W3477	0009	20		44-21-12	ALL
	8		W3477	2001R	22		44-35-02	ALL
	9		W3477	2001B	22		44-35-02	ALL
	10		W3477	0007	20		44-21-12	ALL
	11		W3477	0122	20		44-35-11	ALL
	12		W3477	0125	20		44-35-11	ALL
	PERB		W3477	2001Z			44-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D12945		**J039-0B/ /**		**RELAY SOCKET**				**ALL**
	A1		W0084	2004R	24		23-42-14	ALL
	A2		W0084	2002R	24		23-42-14	ALL
	A3	UNUSED						ALL
	B1		W0084	2004B	24		23-42-14	ALL
	B2		W0084	2002B	24		23-42-14	ALL
	B3	UNUSED						ALL
	C1		W0084	2003R	24		23-42-14	ALL
	C2		W0084	2001R	24		23-42-14	ALL
	C3	UNUSED						ALL
	D1		W0084	2003B	24		23-42-14	ALL
	D2		W0084	2001B	24		23-42-14	ALL
	D3	UNUSED						ALL
	X1		W0084	0060	24		23-42-14	ALL
	X2		W0084	0059	24		23-42-14	ALL
			W0084	2001Z			23-42-14	ALL
			W0084	2002Z			23-42-14	ALL
			W0084	2003Z			23-42-14	ALL
			W0084	2004Z			23-42-14	ALL
			W0084	FRAB			23-42-14	ALL
			W0084	FRAD			23-42-14	ALL
D12968		**J011-00/ /**		**SOCKET**				**ALL**
	A1		W0122	0022	20		27-31-11	ALL
	A2		W0122	0027	20		27-31-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D12968		**J011-00/ /**		**SOCKET (continued)**				**ALL**
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0122	0023	20		27-31-11	ALL
	X2		W0122	0028	20		27-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13018	**500C+7/213/L067**		**PLUG-**				**ALL**
1	16	W3142	0501	16		33-51-11	ALL
2		W3142	0502	20		33-51-11	ALL
3		W3142	0503	22		33-51-11	ALL
4		W3142	0504	22		33-51-11	ALL
5		W3142	0506	20		33-51-11	ALL
6		W3142	0506	20		33-51-11	ALL
7		W3142	0507	20		33-51-11	ALL
8	UNUSED						ALL
9	16	W3142	0509	16		33-51-12	ALL
10	UNUSED						ALL
11		W3142	0511	20		33-51-12	ALL
12		W3142	0510	20		33-51-21	ALL
13		W3142	0636	20		33-51-12	ALL
14		W3142	0514	20		33-51-12	ALL
15	UNUSED						ALL
16		W3142	0578	20		33-51-12	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W3142	0524	20		33-51-11	ALL
21	UNUSED						ALL
22		W3142	0522	20		33-51-11	ALL
23	UNUSED						ALL
24		W3142	0524	20		33-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13124	**855/210/L068**		**RCPT-**				**ALL**
1		W3142	0471	20		33-51-22	ALL
2		W3142	0472	20		33-51-22	ALL
3	UNUSED						ALL
4	16	W3142	0469	16		33-51-22	ALL
5		W3142	0468	20		33-51-22	ALL
D13130	**J022-00/ /**		**RELAY SOCKET**				**ALL**
A1	UNUSED						ALL
A2	UNUSED						ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2		W0076	0414	22		44-21-22	ALL
B3		W0076	0415	22		44-21-22	ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0076	0200	24		73-22-31	ALL
X2		W0076	0199	24		73-22-31	ALL
D13132	**J00024/ /**		**SOCKET-**				**ALL**
A1	UNUSED						ALL
A2	UNUSED						ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2		W0080	6114	22		44-21-22	ALL
B3		W0080	6115	22		44-21-22	ALL
C1	UNUSED						ALL
C2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13132		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	0028	24		73-22-31	ALL
	X2		W0080	0029	24		73-22-31	ALL
D13185		**947/293/L005**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W5433	0028	22		23-71-01	ALL
	4	VP	W5433	0050	22		23-71-01	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5433	0030	22		23-71-01	ALL
	9	UNUSED						ALL
	10		W5433	0026	24		23-71-01	ALL
	11		W5433	0025	24		23-71-01	ALL
	12		W5433	0031	24		23-71-01	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W5433	0029	22		23-71-01	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5433	0032	24		23-71-01	ALL
	21		W5433	0027	22		23-71-01	ALL
	22		W5433	0027	22		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13187		**J011-00/ /**		**SOCKET RELAY - CVR DISPATCH**				**ALL**
	1	UNUSED						ALL
	2		W0122	0123	24		23-71-01	ALL
	3		W0122	0125	22		23-71-01	ALL
	4	UNUSED						ALL
	5		W0122	0122	24		23-71-01	ALL
	6	UNUSED						ALL
	7		W0122	0124	22		23-71-01	ALL
	8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13258		**727C+10/210/L068**		**RCPT-**				**ALL**
	1		W3142	0391	20		33-51-22	ALL
	2		W3142	0392	20		33-51-22	ALL
	3	UNUSED						ALL
	4		W3142	0394	20		33-51-22	ALL
	5	16	W3142	0395	16		33-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13308	**J020-0A/ /**		**RELAY SOCKET**				**ALL**
A1	UNUSED						ALL
A2	UNUSED						ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
C1		W0074	0216	22		27-33-11	ALL
C2		W0074	0219	22		27-33-11	ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2		W0074	0218	22		27-33-11	ALL
D3		W0074	0217	22		27-33-11	ALL
X1		W0074	0290	22		32-31-12	ALL
X2		W0074	0291	22		32-31-12	ALL
D13363	**347/299/R10**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W3307	3507R	24		23-42-12	ALL
3		W3307	3507Y	24		23-42-12	ALL
4		W3307	3507B	24		23-42-12	ALL
5		W3307	0096	22		23-31-01	ALL
6		W3307	3501Y	24		23-42-12	ALL
7		W3307	3501R	24		23-42-12	ALL
8		W3307	0095	22		23-31-01	ALL
9	UNUSED						ALL
10		W3307	0094	22		23-31-01	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W3307	3501B	24		23-42-12	ALL
DED		W3307	3501Z			23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13363		**347/299/R10**		**PLUG (continued)**				**ALL**
	DED		W3307	3507Z			23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13423		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0094	0531	20		44-35-20	ALL
	A2		W0094	0535	20		44-35-20	ALL
	A3	UNUSED						ALL
	B1		W0094	0474	20		44-35-20	ALL
	B2		W0094	0473	20		44-35-20	ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	X1		W0094	0454	20		44-35-20	ALL
	X2		W0094	0456	20		44-35-20	ALL
D13425		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0094	0446	16		44-35-11	ALL
	A2		W0094	0441	16		44-35-11	ALL
	A3	UNUSED						ALL
	B1		W0094	0449	20		44-35-11	ALL
	B2		W0094	0430	20		44-35-11	ALL
	B3	UNUSED						ALL
	C1		W0094	0437	20		44-35-11	ALL
	C2		W0094	0436	20		44-35-11	ALL
	C3	UNUSED						ALL
	X1		W0094	0412	20		44-35-11	ALL
	X2		W0094	0413	20		44-35-11	ALL
D13427		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0094	0419	20		44-35-11	ALL
	A3		W0094	0417	20		44-35-11	ALL
	B1		W0094	0420	20		44-35-11	ALL
	B2		W0094	0421	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13427		**J004-00/ /**		**RELAY SOCKET (continued)**				**ALL**
	B3	UNUSED						ALL
	C1		W0094	0431	20		44-35-11	ALL
	C2		W0094	0434	20		44-35-11	ALL
	C3	UNUSED						ALL
	D1		W0094	0464	20		44-35-11	ALL
	D2		W0094	0471	20		44-35-11	ALL
	D3	UNUSED						ALL
	X1		W0094	0422	20		44-35-11	ALL
	X2		W0094	0463	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13688		**J020-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0074	0191	20		21-31-22	ALL
	A2		W0074	0185	20		21-31-22	ALL
	A3	UNUSED						ALL
	B1		W0074	0190	22		21-31-22	ALL
	B2		W0074	0184	24		21-31-22	ALL
	B3		W0074	0189	22		21-31-22	ALL
	C1		W0074	0188	22		21-31-22	ALL
	C2		W0074	0183	24		21-31-22	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0074	0192	20		21-31-22	ALL
	X2		W0074	0186	20		21-31-22	ALL
D13690		**J020-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0074	0201	20		21-31-23	ALL
	A2		W0074	0195	20		21-31-23	ALL
	A3	UNUSED						ALL
	B1		W0074	0200	22		21-31-23	ALL
	B2		W0074	0194	24		21-31-23	ALL
	B3		W0074	0199	22		21-31-23	ALL
	C1		W0074	0198	22		21-31-23	ALL
	C2		W0074	0193	24		21-31-23	ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0074	0202	20		21-31-23	ALL
	X2		W0074	0196	20		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13712		**P006-00/ /**		**SOCKET - IFE/PASS SEAT CONTROL RELAY**				**ALL**
	A1		W0044	0891	24		24-28-41	ALL
	A2		W0044	0896	24		24-28-41	ALL
	A3	UNUSED						ALL
	B1		W0044	0893	24		24-28-41	ALL
	B2		W0044	0897	24		24-28-41	ALL
	B3	UNUSED						ALL
	C1		W0044	0883	20		44-35-20	ALL
	C2		W0044	6137	20		44-35-20	ALL
	C3	UNUSED						ALL
	D1		W0044	0973	20		44-21-10	ALL
	D2		W0044	6093	20		44-21-10	ALL
	D3	UNUSED						ALL
	X1		W0044	0894	24		24-28-41	ALL
	X2		W0044	0944	22		24-28-41	ALL
D13730		**279/284/R010**		**PLUG-- DOOR POST ASSY INTERFACE**				**ALL**
	1		W0044	0900	22		52-51-11	ALL
	2		W0044	0901	22		52-51-11	ALL
	3		W0044	0902	22		52-51-11	ALL
	4		W0044	0903	22		52-51-11	ALL
	5		W0044	0904	22		52-51-11	ALL
	6		W0044	0905	22		52-51-11	ALL
	7		W0044	0906	22		52-51-11	ALL
	8		W0044	0907	22		52-51-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13730	**279/284/R010**		**PLUG-- DOOR POST ASSY INTERFACE (continued)**				**ALL**
15	UNUSED						ALL
D13741	**P001-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
A		W0001	2003R	24		31-65-12	ALL
B		W0001	2003B	24		31-65-12	ALL
C	UNUSED						ALL
D	UNUSED						ALL
E	UNUSED						ALL
F	UNUSED						ALL
G		W0001	2001R	24		31-65-11	ALL
H		W0001	2001B	24		31-65-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M	UNUSED						ALL
N	UNUSED						ALL
P	UNUSED						ALL
R	UNUSED						ALL
S	UNUSED						ALL
T	UNUSED						ALL
U	UNUSED						ALL
V	UNUSED						ALL
W	UNUSED						ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z	UNUSED						ALL
AA	UNUSED						ALL
BB		W0001	3012B	24		31-65-11	ALL
CC		W0001	3012R	24		31-65-11	ALL
DD		W0001	0002	16		31-65-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13741		**P001-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	EE		W0001	1001	16		31-65-11	ALL
	FF		W0001	1501	16		31-65-11	ALL
	GG		W0001	3011R	24		31-65-11	ALL
	HH		W0001	3011Y	24		31-65-11	ALL
	JJ		W0001	0003	16		31-65-11	ALL
	KK		W0001	3012Y	24		31-65-11	ALL
	LL		W0001	0004	16		31-65-11	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-	UNUSED						ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-		W0001	3001B	24		31-65-11	ALL
	K-		W0001	3001R	24		31-65-11	ALL
	M-		W0001	3001Y	24		31-65-11	ALL
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-	UNUSED						ALL
	U-	UNUSED						ALL
	V-	UNUSED						ALL
	W-	UNUSED						ALL
	X-		W0001	3011B	24		31-65-11	ALL
	Y-	UNUSED						ALL
	Z-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13741		**P001-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERB		W0001	1001Z			31-65-11	ALL
	PERB		W0001	1501Z			31-65-11	ALL
	PERB		W0001	2001Z			31-65-11	ALL
	PERB		W0001	2003Z			31-65-12	ALL
	PERB		W0001	3001Z			31-65-11	ALL
	PERB		W0001	3011Z			31-65-11	ALL
	PERB		W0001	3012Z			31-65-11	ALL
D13743		**P001-00/ /**		**PLUG - FIBER OPTIC**				**ALL**
	A		W0001	0001FO	16		31-65-12	ALL
	B		W0003	0004FO	16		31-65-22	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D13745		**P001-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A		W0001	2004R	24		31-65-12	ALL
	B		W0001	2004B	24		31-65-12	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13745		**P001-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	AA	UNUSED						ALL
	BB		W0001	3014B	24		31-65-11	ALL
	CC		W0001	3014R	24		31-65-11	ALL
	DD		W0001	0006	16		31-65-11	ALL
	EE		W0001	1002	16		31-65-11	ALL
	FF		W0001	1505	16		31-65-11	ALL
	GG		W0001	3013R	24		31-65-11	ALL
	HH		W0001	3013Y	24		31-65-11	ALL
	JJ		W0001	0007	16		31-65-11	ALL
	KK		W0001	3014Y	24		31-65-11	ALL
	LL		W0001	0008	16		31-65-11	ALL
	A-	UNUSED						ALL
	B-	UNUSED						ALL
	C-	UNUSED						ALL
	D-	UNUSED						ALL
	E-	UNUSED						ALL
	F-	UNUSED						ALL
	G-	UNUSED						ALL
	H-	UNUSED						ALL
	K-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13745		**P001-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	M-	UNUSED						ALL
	N-	UNUSED						ALL
	P-	UNUSED						ALL
	Q-	UNUSED						ALL
	R-	UNUSED						ALL
	S-	UNUSED						ALL
	T-	UNUSED						ALL
	U-	UNUSED						ALL
	V-	UNUSED						ALL
	W-	UNUSED						ALL
	X-		W0001	3013B	24		31-65-11	ALL
	Y-	UNUSED						ALL
	Z-	UNUSED						ALL
	PERB		W0001	1002Z			31-65-11	ALL
	PERB		W0001	1505Z			31-65-11	ALL
	PERB		W0001	2004Z			31-65-12	ALL
	PERB		W0001	3013Z			31-65-11	ALL
	PERB		W0001	3014Z			31-65-11	ALL
D13747		**P001-00/ /**		**PLUG - FIBER OPTIC**				**ALL**
	A		W0001	0002FO	16		31-65-12	ALL
	B		W0003	0003FO	16		31-65-22	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D13749		**P003-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A		W0003	2503R	24		31-65-22	ALL
	B		W0003	2503B	24		31-65-22	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13749		**P003-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G		W0003	2501R	24		31-65-21	ALL
	H		W0003	2501B	24		31-65-21	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL
	W	UNUSED						ALL
	X	UNUSED						ALL
	Y	UNUSED						ALL
	Z	UNUSED						ALL
	AA	UNUSED						ALL
	BB		W0003	3512B	24		31-65-21	ALL
	CC		W0003	3512R	24		31-65-21	ALL
	DD		W0003	0502	16		31-65-21	ALL
	EE		W0003	1501	16		31-65-21	ALL
	FF		W0003	1401	16		31-65-21	ALL
	GG		W0003	3511R	24		31-65-21	ALL
	HH		W0003	3511Y	24		31-65-21	ALL
	JJ		W0003	0503	16		31-65-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13749	**P003-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
KK		W0003	3512Y	24		31-65-21	ALL
LL		W0003	0504	16		31-65-21	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-	UNUSED						ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-		W0003	3501B	24		31-65-21	ALL
K-		W0003	3501R	24		31-65-21	ALL
M-		W0003	3501Y	24		31-65-21	ALL
N-	UNUSED						ALL
P-	UNUSED						ALL
Q-	UNUSED						ALL
R-	UNUSED						ALL
S-	UNUSED						ALL
T-	UNUSED						ALL
U-	UNUSED						ALL
V-	UNUSED						ALL
W-	UNUSED						ALL
X-		W0003	3511B	24		31-65-21	ALL
Y-	UNUSED						ALL
Z-	UNUSED						ALL
PERB		W0003	1401Z			31-65-21	ALL
PERB		W0003	1501Z			31-65-21	ALL
PERB		W0003	2501Z			31-65-21	ALL
PERB		W0003	2503Z			31-65-22	ALL
PERB		W0003	3501Z			31-65-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13749		**P003-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERB		W0003	3511Z			31-65-21	ALL
	PERB		W0003	3512Z			31-65-21	ALL
D13751		**P003-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A		W0003	0001FO	16		31-65-22	ALL
	B		W0001	0004FO	16		31-65-12	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D13753		**P003-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A		W0003	2504R	24		31-65-22	ALL
	B		W0003	2504B	24		31-65-22	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
	V	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13753	**P003-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
W	UNUSED						ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z	UNUSED						ALL
AA	UNUSED						ALL
BB		W0003	3514B	24		31-65-21	ALL
CC		W0003	3514R	24		31-65-21	ALL
DD		W0003	0506	16		31-65-21	ALL
EE		W0003	1502	16		31-65-21	ALL
FF		W0003	1505	16		31-65-21	ALL
GG		W0003	3513R	24		31-65-21	ALL
HH		W0003	3513Y	24		31-65-21	ALL
JJ		W0003	0507	16		31-65-21	ALL
KK		W0003	3514Y	24		31-65-21	ALL
LL		W0003	0508	16		31-65-21	ALL
A-	UNUSED						ALL
B-	UNUSED						ALL
C-	UNUSED						ALL
D-	UNUSED						ALL
E-	UNUSED						ALL
F-	UNUSED						ALL
G-	UNUSED						ALL
H-	UNUSED						ALL
K-	UNUSED						ALL
M-	UNUSED						ALL
N-	UNUSED						ALL
P-	UNUSED						ALL
Q-	UNUSED						ALL
R-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13753		**P003-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	S-	UNUSED						ALL
	T-	UNUSED						ALL
	U-	UNUSED						ALL
	V-	UNUSED						ALL
	W-	UNUSED						ALL
	X-		W0003	3513B	24		31-65-21	ALL
	Y-	UNUSED						ALL
	Z-	UNUSED						ALL
	PERB		W0003	1502Z			31-65-21	ALL
	PERB		W0003	1505Z			31-65-21	ALL
	PERB		W0003	2504Z			31-65-22	ALL
	PERB		W0003	3513Z			31-65-21	ALL
	PERB		W0003	3514Z			31-65-21	ALL
D13755		**P003-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A		W0003	0002FO	16		31-65-22	ALL
	B		W0001	0003FO	16		31-65-12	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D13757A		**E003-01/ /**		**PLUG - DPC 1**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0311	2144W	24		34-41-11	ALL
	A04		W0311	2144B	24		34-41-11	ALL
	A05	UNUSED						ALL
	A06		W0313	0625	24		22-31-52	ALL
	A07		W0311	2123R	24		79-31-11	ALL
	A08		W0311	2123B	24		79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0311	1006	24		79-31-11	ALL
A14		W0311	1004	24		79-31-11	ALL
A15	UNUSED						ALL
B01		W0311	2124R	24		79-31-11	ALL
B02		W0311	2124B	24		79-31-11	ALL
B03		W0311	2005R	24		31-65-12	ALL
B04		W0311	2005B	24		31-65-12	ALL
B05		W0311	2043R	24		73-24-11	ALL
B06		W0311	2043B	24		73-24-11	ALL
B07		W0311	2030R	24		31-65-15	ALL
B08		W0311	2030B	24		31-65-15	ALL
B09		W0311	2054R	22		28-41-11	ALL
B10		W0311	2054B	22		28-41-11	ALL
B11		W0311	0171	22		31-65-41	ALL
B12	UNUSED						ALL
B13		W0311	2097R	24		34-31-11	ALL
B14		W0311	2097B	24		34-31-11	ALL
B15	UNUSED						ALL
C01		W0311	2089R	24		22-11-51	ALL
C02		W0311	2089B	24		22-11-51	ALL
C03		W0311	2751R	24		31-65-14	ALL
C04		W0311	2751B	24		31-65-14	ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	C08		W0311	0021	24		31-65-15	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0311	2101R	24		34-51-11	ALL
	D04		W0311	2101B	24		34-51-11	ALL
	D05		W0311	1774	24		27-81-31	ALL
	D06		W0311	0083	24		80-11-11	ALL
	D07		W0311	0028	24		74-31-11	ALL
	D08		W0311	0013	22		30-21-31	ALL
	D09	UNUSED						ALL
	D10		W0311	0056	22		30-11-11	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0311	2754R	24		32-64-31	ALL
	E02		W0311	2754B	24		32-64-31	ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05		W0311	0059	24		73-21-12	ALL
	E06		W0311	1753	24		73-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
E07		W0311	0031	24		74-31-11	ALL
E08		W0313	2640R	24		34-49-11	ALL
E09		W0313	2640B	24		34-49-11	ALL
E10	UNUSED						ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01		W0311	2092R	24		27-32-12	ALL
F02		W0311	2092B	24		27-32-12	ALL
F03		W0311	2026R	24		31-65-15	ALL
F04		W0311	2026B	24		31-65-15	ALL
F05		W0311	0062	24		73-22-11	ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0311	0037	24		76-21-11	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01		W0311	2160R	24		23-27-38	ALL
G02		W0311	2160B	24		23-27-38	ALL
G03		W0311	2726R	24		34-33-11	ALL
G04		W0311	2726B	24		34-33-11	ALL
G05		W0311	1002	22		31-65-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10		W0311	0074	24		73-23-11	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0311	2023R	24		31-65-15	ALL
	H02		W0311	2023B	24		31-65-15	ALL
	H03		W0311	2711R	24		31-65-16	ALL
	H04		W0311	2711B	24		31-65-16	ALL
	H05		W0311	0065	24		73-22-31	ALL
	H06	UNUSED						ALL
	H07		W0311	0131	22		34-21-15	ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10		W0311	0220	24		31-65-41	ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0311	2011R	24		31-65-13	ALL
	J02		W0311	2011B	24		31-65-13	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
J05		W0311	1759	24		76-21-11	ALL
J06		W0311	0112	22		34-51-41	ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0311	0627	22		34-41-11	ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0311	2118R	24		34-21-14	ALL
K02		W0311	2118B	24		34-21-14	ALL
K03		W0311	2761W	24		34-49-11	ALL
K04		W0311	2761B	24		34-49-11	ALL
K05		W0311	0034	24		74-31-11	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08		W0311	2066R	24		77-12-11	ALL
K09		W0311	2066B	24		77-12-11	ALL
K10		W0311	0089	22		49-62-11	ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
DED		W0311	2144Z			34-41-11	ALL
PERG	1A	W0311	1002Z			31-65-14	ALL
PERG	1A	W0311	1004Z			79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757A		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	PERG	1A	W0311	1006Z			79-31-11	ALL
	PERG	1A	W0311	2005Z			31-65-12	ALL
	PERG	1A	W0311	2011Z			31-65-13	ALL
	PERG	1A	W0311	2023Z			31-65-15	ALL
	PERG	1A	W0311	2026Z			31-65-15	ALL
	PERG	1A	W0311	2030Z			31-65-15	ALL
	PERG	1A	W0311	2043Z			73-24-11	ALL
	PERG	1A	W0311	2054Z			28-41-11	ALL
	PERG	1A	W0311	2066Z			77-12-11	ALL
	PERG	1A	W0311	2089Z			22-11-51	ALL
	PERG	1A	W0311	2092Z			27-32-12	ALL
	PERG	1A	W0311	2097Z			34-31-11	ALL
	PERG	1A	W0311	2101Z			34-51-11	ALL
	PERG	1A	W0311	2118Z			34-21-14	ALL
	PERG	1A	W0311	2123Z			79-31-11	ALL
	PERG	1A	W0311	2124Z			79-31-11	ALL
	PERG	1A	W0311	2160Z			23-27-38	ALL
	PERG	1A	W0311	2711Z			31-65-16	ALL
	PERG	1A	W0311	2726Z			34-33-11	ALL
	PERG	1A	W0311	2751Z			31-65-14	ALL
	PERG	1A	W0311	2754Z			32-64-31	ALL
	PERG	1A	W0311	2761Z			34-49-11	ALL
	PERG	1A	W0313	2640Z			34-49-11	ALL
D13757B		**E003-01/ /**		**PLUG - DPC 1**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0311	2094R	24		34-55-11	ALL
	A04		W0311	2094B	24		34-55-11	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757B	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
A06		W0311	0120	22		34-61-12	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0313	2613R	24		22-31-52	ALL
A10		W0313	2613B	24		22-31-52	ALL
A11		W0311	0018	24		31-65-15	ALL
B01		W0311	2070R	24		77-12-21	ALL
B02		W0311	2070B	24		77-12-21	ALL
B03		W0313	2524R	24		31-65-25	ALL
B04		W0313	2524B	24		31-65-25	ALL
B05		W0311	2137R	24		34-45-11	ALL
B06		W0311	2137B	24		34-45-11	ALL
B07		W0311	2115R	24		34-21-13	ALL
B08		W0311	2115B	24		34-21-13	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0311	2716R	24		31-31-13	ALL
C04		W0311	2716B	24		31-31-13	ALL
C05		W0313	1775	24		75-11-11	ALL
C06	UNUSED						ALL
C07		W0311	0079	24		73-32-11	ALL
C08		W0311	0052	24		73-21-31	ALL
C09		W0311	2273R	24		31-65-15	ALL
C10		W0311	2273B	24		31-65-15	ALL
C11		W0311	1762	22		78-36-11	ALL
D01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757B		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	D02	UNUSED						ALL
	D03		W0311	2702R	24		34-58-11	ALL
	D04		W0311	2702B	24		34-58-11	ALL
	D05		W0311	0073	22		30-21-31	ALL
	D06		W0311	0192	24		31-65-14	ALL
	D07		W0311	0105	24		29-32-11	ALL
	D08		W0311	0106	24		29-32-11	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11		W0311	0019	24		31-65-15	ALL
	E01		W0311	2718R	24		36-11-14	ALL
	E02		W0311	2718B	24		36-11-14	ALL
	E03		W0311	2082R	24		34-57-11	ALL
	E04		W0311	2082B	24		34-57-11	ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15		W0311	2990W	24		23-70-11	ALL
	F01		W0311	2706R	24		31-65-15	ALL
	F02		W0311	2706B	24		31-65-15	ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757B	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
F05	UNUSED						ALL
F06	UNUSED						ALL
F07		W0311	0015	24		31-65-14	ALL
F08		W0311	0076	24		73-31-11	ALL
F09		W0311	0020	24		31-65-15	ALL
F10		W0311	0038	24		76-21-11	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15		W0311	2990B	24		23-70-11	ALL
G01		W0311	2149R	24		22-11-51	ALL
G02		W0311	2149B	24		22-11-51	ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05		W0311	0115	22		34-51-41	ALL
G06		W0311	0199	22		30-21-31	ALL
G07	UNUSED						ALL
G08		W0311	0099	24		29-31-11	ALL
G09		W0311	0094	24		29-31-11	ALL
G10		W0311	0072	24		73-23-11	ALL
G11	UNUSED						ALL
H01		W0311	0102	24		29-31-11	ALL
H02		W0311	0095	24		29-31-11	ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05		W0311	0053	24		73-21-31	ALL
H06		W0311	0006	22		30-31-12	ALL
H07		W0311	1767	22		80-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757B		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	H08		W0311	2157R	24		27-81-41	ALL
	H09		W0311	2157B	24		27-81-41	ALL
	H10		W0311	0150	24		31-65-41	ALL
	H11	UNUSED						ALL
	J01		W0311	2061R	22		28-41-11	ALL
	J02		W0311	2061B	22		28-41-11	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0311	0107	22		21-27-31	ALL
	J06		W0311	1772	22		73-22-41	ALL
	J07		W0311	2666R	24		31-33-01	ALL
	J08		W0311	2666B	24		31-33-01	ALL
	J09		W0311	0101	24		29-31-11	ALL
	J10		W0311	0093	24		29-31-11	ALL
	J11		W0311	0160	24		34-45-11	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0311	2006R	24		31-65-12	ALL
	K04		W0311	2006B	24		31-65-12	ALL
	K05		W0311	2044R	24		73-24-11	ALL
	K06		W0311	2044B	24		73-24-11	ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	=C1T	UNUSED						ALL
	=C2T		W0311	4001Z			31-65-15	ALL
	1T-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757B	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
1T-2	UNUSED						ALL
1T-3	UNUSED						ALL
1T-4	UNUSED						ALL
2T-1	J5	W0311	4001Y	24		31-65-15	ALL
2T-2	J5	W0311	4001R	24		31-65-15	ALL
2T-3	J5	W0311	4001G	24		31-65-15	ALL
2T-4	J5	W0311	4001B	24		31-65-15	ALL
PERG	1A	W0311	2006Z			31-65-12	ALL
PERG	1A	W0311	2044Z			73-24-11	ALL
PERG	1A	W0311	2061Z			28-41-11	ALL
PERG	1A	W0311	2070Z			77-12-21	ALL
PERG	1A	W0311	2082Z			34-57-11	ALL
PERG	1A	W0311	2094Z			34-55-11	ALL
PERG	1A	W0311	2115Z			34-21-13	ALL
PERG	1A	W0311	2137Z			34-45-11	ALL
PERG	1A	W0311	2149Z			22-11-51	ALL
PERG	1A	W0311	2157Z			27-81-41	ALL
PERG	1A	W0311	2273Z			31-65-15	ALL
PERG	1A	W0311	2666Z			31-33-01	ALL
PERG	1A	W0311	2702Z			34-58-11	ALL
PERG	1A	W0311	2706Z			31-65-15	ALL
PERG	1A	W0311	2716Z			31-31-13	ALL
PERG	1A	W0311	2718Z			36-11-14	ALL
PERG	1A	W0311	2990Z			23-70-11	ALL
PERG	1A	W0313	2524Z			31-65-25	ALL
PERG	1A	W0313	2613Z			22-31-52	ALL
D13757C	**E003-01/ /**		**PLUG - DPC 1**				**ALL**
1	UNUSED						ALL
2		W0315	0005FO	16		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757C		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0315	0001FO	16		31-65-12	ALL
	6		W0315	0002FO	16		31-65-12	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0311	0003	16		31-65-11	ALL
	14		W0311	0010	16		31-65-11	ALL
	15		W0311	0002	16		31-65-11	ALL
	16	UNUSED						ALL
	=17		W0311	4003Z			46-13-11	ALL
	16-1	UNUSED						ALL
	16-2	UNUSED						ALL
	16-3	UNUSED						ALL
	16-4	UNUSED						ALL
	17-1	J5	W0311	4003Y	24		46-13-11	ALL
	17-2	J5	W0311	4003R	24		46-13-11	ALL
	17-3	J5	W0311	4003G	24		46-13-11	ALL
	17-4	J5	W0311	4003B	24		46-13-11	ALL
D13757D		**E003-01/ /**		**PLUG - DPC 1**				**ALL**
	A01		W0311	0128	22		34-21-15	ALL
	A02	UNUSED						ALL
	A03		W0313	2507R	24		31-65-22	ALL
	A04		W0313	2507B	24		31-65-22	ALL
	A05		W0313	2545R	24		73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
A06		W0313	2545B	24		73-24-21	ALL
A07		W0313	2623R	24		79-31-11	ALL
A08		W0313	2623B	24		79-31-11	ALL
A09		W0313	2599R	24		34-31-21	ALL
A10		W0313	2599B	24		34-31-21	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0313	1506	24		79-31-11	ALL
A14		W0313	1504	24		79-31-11	ALL
A15		W0313	0669	22		34-41-11	ALL
B01		W0313	2624R	24		79-31-11	ALL
B02		W0313	2624B	24		79-31-11	ALL
B03		W0313	0577	24		73-31-11	ALL
B04		W0313	0559	24		73-22-31	ALL
B05		W0313	2782R	22		28-41-11	ALL
B06		W0313	2782B	22		28-41-11	ALL
B07		W0311	2031R	24		31-65-15	ALL
B08		W0311	2031B	24		31-65-15	ALL
B09	UNUSED						ALL
B10		W0311	2145W	24		34-41-11	ALL
B11		W0311	2145B	24		34-41-11	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01		W0313	0516	24		31-65-24	ALL
C02	UNUSED						ALL
C03		W0313	0553	24		73-21-12	ALL
C04		W0311	0123	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0313	2753R	24		31-65-24	ALL
	C08		W0313	2753B	24		31-65-24	ALL
	C09		W0311	2203R	22		32-46-11	ALL
	C10		W0311	2203B	22		32-46-11	ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0313	0556	24		73-22-11	ALL
	D03		W0313	1503	22		31-65-24	ALL
	D04		W0313	0008	24		73-21-31	ALL
	D05		W0313	2591R	24		27-32-22	ALL
	D06		W0313	2591B	24		27-32-22	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0311	2014R	24		31-65-15	ALL
	D10		W0311	2014B	24		31-65-15	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0311	2757R	24		32-64-31	ALL
	E02		W0311	2757B	24		32-64-31	ALL
	E03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07		W0313	2594R	24		34-55-21	ALL
E08		W0313	2594B	24		34-55-21	ALL
E09		W0311	2713R	24		31-65-16	ALL
E10		W0311	2713B	24		31-65-16	ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01		W0313	0532	24		74-31-11	ALL
F02		W0313	0522	24		31-65-15	ALL
F03		W0313	0585	24		80-11-11	ALL
F04		W0313	0700	22		30-21-32	ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07		W0311	2762W	24		34-49-11	ALL
F08		W0311	2762B	24		34-49-11	ALL
F09		W0311	0133	24		31-65-15	ALL
F10		W0313	0537	24		76-21-21	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01	UNUSED						ALL
G02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	G03	UNUSED						ALL
	G04		W0311	2025R	24		31-65-15	ALL
	G05		W0311	2025B	24		31-65-15	ALL
	G06		W0311	2712R	24		31-65-16	ALL
	G07		W0311	2712B	24		31-65-16	ALL
	G08		W0311	2039R	22		49-62-11	ALL
	G09		W0311	2039B	22		49-62-11	ALL
	G10		W0313	0566	24		73-23-11	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03		W0313	0535	24		74-31-11	ALL
	H04		W0313	2601R	24		34-51-21	ALL
	H05		W0313	2601B	24		34-51-21	ALL
	H06		W0313	2511R	24		31-65-23	ALL
	H07		W0313	2511B	24		31-65-23	ALL
	H08		W0311	2086R	24		31-35-02	ALL
	H09		W0311	2086B	24		31-35-02	ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0311	2049R	24		73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
J02		W0311	2049B	24		73-24-12	ALL
J03		W0313	1757	24		76-21-21	ALL
J04		W0313	2582R	24		34-57-21	ALL
J05		W0313	2582B	24		34-57-21	ALL
J06		W0313	2589R	24		22-11-51	ALL
J07		W0313	2589B	24		22-11-51	ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0311	0054	24		73-21-31	ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0313	2637R	24		34-45-11	ALL
K05		W0313	2637B	24		34-45-11	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08		W0313	2566R	24		77-12-11	ALL
K09		W0313	2566B	24		77-12-11	ALL
K10		W0313	0701	24		34-41-11	ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14		W0313	2622R	24		34-21-24	ALL
K15		W0313	2622B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	DED		W0311	2145Z			34-41-11	ALL
	PERG	1A	W0311	2014Z			31-65-15	ALL
	PERG	1A	W0311	2025Z			31-65-15	ALL
	PERG	1A	W0311	2031Z			31-65-15	ALL
	PERG	1A	W0311	2039Z			49-62-11	ALL
	PERG	1A	W0311	2049Z			73-24-12	ALL
	PERG	1A	W0311	2086Z			31-35-02	ALL
	PERG	1A	W0311	2203Z			32-46-11	ALL
	PERG	1A	W0311	2712Z			31-65-16	ALL
	PERG	1A	W0311	2713Z			31-65-16	ALL
	PERG	1A	W0311	2757Z			32-64-31	ALL
	PERG	1A	W0311	2762Z			34-49-11	ALL
	PERG	1A	W0313	1503Z			31-65-24	ALL
	PERG	1A	W0313	1504Z			79-31-11	ALL
	PERG	1A	W0313	1506Z			79-31-11	ALL
	PERG	1A	W0313	2507Z			31-65-22	ALL
	PERG	1A	W0313	2511Z			31-65-23	ALL
	PERG	1A	W0313	2545Z			73-24-21	ALL
	PERG	1A	W0313	2566Z			77-12-11	ALL
	PERG	1A	W0313	2582Z			34-57-21	ALL
	PERG	1A	W0313	2589Z			22-11-51	ALL
	PERG	1A	W0313	2591Z			27-32-22	ALL
	PERG	1A	W0313	2594Z			34-55-21	ALL
	PERG	1A	W0313	2599Z			34-31-21	ALL
	PERG	1A	W0313	2601Z			34-51-21	ALL
	PERG	1A	W0313	2622Z			34-21-24	ALL
	PERG	1A	W0313	2623Z			79-31-11	ALL
	PERG	1A	W0313	2624Z			79-31-11	ALL
	PERG	1A	W0313	2637Z			34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757D		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	PERG	1A	W0313	2753Z			31-65-24	ALL
	PERG	1A	W0313	2782Z			28-41-11	ALL
D13757E		**E003-01/ /**		**PLUG - DPC 1**				**ALL**
	A01	UNUSED						ALL
	A02		W0311	1768	22		80-11-11	ALL
	A03		W0313	0567	22		30-21-32	ALL
	A04	UNUSED						ALL
	A05		W0313	2732R	24		34-33-21	ALL
	A06		W0313	2732B	24		34-33-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	B01		W0313	2570R	24		77-12-21	ALL
	B02		W0313	2570B	24		77-12-21	ALL
	B03	UNUSED						ALL
	B04		W0311	0007	22		30-31-12	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0313	2615R	24		34-21-23	ALL
	B08		W0313	2615B	24		34-21-23	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0313	1792	24		75-11-11	ALL
	C03	UNUSED						ALL
	C04		W0313	0612	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757E		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0311	2717R	24		31-31-13	ALL
	C08		W0311	2717B	24		31-31-13	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	D01		W0311	0181	24		31-65-41	ALL
	D02		W0313	0549	24		73-21-31	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0313	0670	22		34-41-11	ALL
	D10		W0311	1764	22		78-36-21	ALL
	D11	UNUSED						ALL
	E01	UNUSED						ALL
	E02		W0313	0514	22		30-21-32	ALL
	E03		W0313	0615	22		34-51-41	ALL
	E04		W0313	0580	24		73-32-11	ALL
	E05		W0311	2024R	24		31-65-15	ALL
	E06		W0311	2024B	24		31-65-15	ALL
	E07		W0313	2718R	24		36-11-24	ALL
	E08		W0313	2718B	24		36-11-24	ALL
	E09		W0313	1763	22		78-36-21	ALL
	E10		W0313	1759	22		78-36-11	ALL
	E11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757E	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02		W0311	1771	22		73-22-41	ALL
F03		W0313	0550	24		73-21-31	ALL
F04		W0313	2703R	24		34-58-21	ALL
F05		W0313	2703B	24		34-58-21	ALL
F06		W0313	2649R	24		22-11-51	ALL
F07		W0313	2649B	24		22-11-51	ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0313	0538	24		76-21-21	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01		W0311	0178	24		31-65-42	ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08		W0313	0599	24		29-31-11	ALL
G09		W0313	0594	24		29-31-11	ALL
G10		W0313	0568	24		73-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757E		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	G11	UNUSED						ALL
	H01		W0313	0602	24		29-31-11	ALL
	H02		W0313	0595	24		29-31-11	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0313	2523R	24		31-65-25	ALL
	H06		W0313	2523B	24		31-65-25	ALL
	H07		W0311	2017R	24		31-65-15	ALL
	H08		W0311	2017B	24		31-65-15	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	J01		W0313	0529	24		74-31-11	ALL
	J02		W0313	0693	24		31-65-24	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0313	2508R	24		31-65-22	ALL
	J06		W0313	2508B	24		31-65-22	ALL
	J07		W0311	2776R	24		31-65-16	ALL
	J08		W0311	2776B	24		31-65-16	ALL
	J09		W0313	0601	24		29-31-11	ALL
	J10		W0313	0593	24		29-31-11	ALL
	J11	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757E	**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
K07		W0313	2546R	24		73-24-21	ALL
K08		W0313	2546B	24		73-24-21	ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
=C1T		W0313	4002Z			31-65-15	ALL
=C2T	UNUSED						ALL
CAP	Y	W0311	2771B	24		32-42-12	ALL
CAP	Y	W0311	2771R	24		32-42-12	ALL
DED		W0311	2771Z			32-42-12	ALL
1T-1	J5	W0313	4002Y	24		31-65-15	ALL
1T-2	J5	W0313	4002R	24		31-65-15	ALL
1T-3	J5	W0313	4002G	24		31-65-15	ALL
1T-4	J5	W0313	4002B	24		31-65-15	ALL
2T-1	UNUSED						ALL
2T-2	UNUSED						ALL
2T-3	UNUSED						ALL
2T-4	UNUSED						ALL
PERG	1A	W0311	2017Z			31-65-15	ALL
PERG	1A	W0311	2024Z			31-65-15	ALL
PERG	1A	W0311	2717Z			31-31-13	ALL
PERG	1A	W0311	2776Z			31-65-16	ALL
PERG	1A	W0313	2508Z			31-65-22	ALL
PERG	1A	W0313	2523Z			31-65-25	ALL
PERG	1A	W0313	2546Z			73-24-21	ALL
PERG	1A	W0313	2570Z			77-12-21	ALL
PERG	1A	W0313	2615Z			34-21-23	ALL
PERG	1A	W0313	2649Z			22-11-51	ALL
PERG	1A	W0313	2703Z			34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13757E		**E003-01/ /**		**PLUG - DPC 1 (continued)**				**ALL**
	PERG	1A	W0313	2718Z			36-11-24	ALL
	PERG	1A	W0313	2732Z			34-33-21	ALL
D13757F		**E003-01/ /**		**PLUG - DPC 1**				**ALL**
	1	UNUSED						ALL
	2		W0317	0005FO	16		31-65-25	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0315	0003FO	16		31-65-12	ALL
	6		W0315	0004FO	16		31-65-12	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0311	0005	16		31-65-11	ALL
	14		W0311	0011	16		31-65-11	ALL
	15		W0313	0694	16		31-65-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	16-1	UNUSED						ALL
	16-2	UNUSED						ALL
	16-3	UNUSED						ALL
	16-4	UNUSED						ALL
	17-1	UNUSED						ALL
	17-2	UNUSED						ALL
	17-3	UNUSED						ALL
	17-4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A	**E003-01/ /**		**PLUG - DPC 2**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0313	2644W	24		34-41-11	ALL
A04		W0313	2644B	24		34-41-11	ALL
A05	UNUSED						ALL
A06		W0313	0626	24		22-31-52	ALL
A07		W0311	2125R	24		79-31-11	ALL
A08		W0311	2125B	24		79-31-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0311	1007	24		79-31-11	ALL
A14		W0311	1005	24		79-31-11	ALL
A15	UNUSED						ALL
B01		W0311	2126R	24		79-31-11	ALL
B02		W0311	2126B	24		79-31-11	ALL
B03		W0311	2007R	24		31-65-12	ALL
B04		W0311	2007B	24		31-65-12	ALL
B05		W0311	2045R	24		73-24-11	ALL
B06		W0311	2045B	24		73-24-11	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0311	2055R	22		28-41-11	ALL
B10		W0311	2055B	22		28-41-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W0311	2099R	24		34-31-11	ALL
B14		W0311	2099B	24		34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	B15	UNUSED						ALL
	C01		W0311	2090R	24		22-11-51	ALL
	C02		W0311	2090B	24		22-11-51	ALL
	C03		W0311	2753R	24		31-65-14	ALL
	C04		W0311	2753B	24		31-65-14	ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08		W0311	0022	24		31-65-25	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0311	2102R	24		34-51-11	ALL
	D04		W0311	2102B	24		34-51-11	ALL
	D05		W0311	1775	24		27-81-31	ALL
	D06		W0311	0085	24		80-11-11	ALL
	D07		W0311	0029	24		74-31-11	ALL
	D08		W0311	0014	22		30-21-31	ALL
	D09	UNUSED						ALL
	D10		W0311	0047	22		30-11-11	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
D14	UNUSED						ALL
D15	UNUSED						ALL
E01		W0313	2757R	24		32-64-31	ALL
E02		W0313	2757B	24		32-64-31	ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05		W0311	0058	24		73-21-12	ALL
E06		W0311	1752	24		73-21-31	ALL
E07		W0311	0032	24		74-31-11	ALL
E08		W0313	2641R	24		34-49-11	ALL
E09		W0313	2641B	24		34-49-11	ALL
E10	UNUSED						ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01		W0311	2091R	24		27-32-12	ALL
F02		W0311	2091B	24		27-32-12	ALL
F03		W0313	2526R	24		31-65-25	ALL
F04		W0313	2526B	24		31-65-25	ALL
F05		W0311	0061	24		73-22-11	ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0311	0039	24		76-21-11	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01		W0311	2161R	24		23-27-38	ALL
	G02		W0311	2161B	24		23-27-38	ALL
	G03		W0311	2728R	24		34-33-11	ALL
	G04		W0311	2728B	24		34-33-11	ALL
	G05		W0311	1003	22		31-65-14	ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10		W0311	0071	24		73-23-11	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0313	2523R	24		31-65-25	ALL
	H02		W0313	2523B	24		31-65-25	ALL
	H03		W0313	2711R	24		31-65-26	ALL
	H04		W0313	2711B	24		31-65-26	ALL
	H05		W0311	0064	24		73-22-31	ALL
	H06	UNUSED						ALL
	H07		W0311	0132	22		34-21-15	ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10		W0313	0570	24		31-65-41	ALL
	H11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0311	2012R	24		31-65-13	ALL
	J02		W0311	2012B	24		31-65-13	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0311	1758	24		76-21-11	ALL
	J06		W0311	0113	22		34-51-41	ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10		W0311	0628	22		34-41-11	ALL
	J11	UNUSED						ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0311	2121R	24		34-21-14	ALL
	K02		W0311	2121B	24		34-21-14	ALL
	K03		W0311	2763W	24		34-49-11	ALL
	K04		W0311	2763B	24		34-49-11	ALL
	K05		W0311	0035	24		74-31-11	ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08		W0311	2067R	24		77-12-11	ALL
	K09		W0311	2067B	24		77-12-11	ALL
	K10		W0311	0088	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	DED		W0313	2644Z			34-41-11	ALL
	PERG	1A	W0311	1003Z			31-65-14	ALL
	PERG	1A	W0311	1005Z			79-31-11	ALL
	PERG	1A	W0311	1007Z			79-31-11	ALL
	PERG	1A	W0311	2007Z			31-65-12	ALL
	PERG	1A	W0311	2012Z			31-65-13	ALL
	PERG	1A	W0311	2045Z			73-24-11	ALL
	PERG	1A	W0311	2055Z			28-41-11	ALL
	PERG	1A	W0311	2067Z			77-12-11	ALL
	PERG	1A	W0311	2090Z			22-11-51	ALL
	PERG	1A	W0311	2091Z			27-32-12	ALL
	PERG	1A	W0311	2099Z			34-31-11	ALL
	PERG	1A	W0311	2102Z			34-51-11	ALL
	PERG	1A	W0311	2121Z			34-21-14	ALL
	PERG	1A	W0311	2125Z			79-31-11	ALL
	PERG	1A	W0311	2126Z			79-31-11	ALL
	PERG	1A	W0311	2161Z			23-27-38	ALL
	PERG	1A	W0311	2728Z			34-33-11	ALL
	PERG	1A	W0311	2753Z			31-65-14	ALL
	PERG	1A	W0311	2763Z			34-49-11	ALL
	PERG	1A	W0313	2523Z			31-65-25	ALL
	PERG	1A	W0313	2526Z			31-65-25	ALL
	PERG	1A	W0313	2641Z			34-49-11	ALL
	PERG	1A	W0313	2711Z			31-65-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759A	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
PERG	1A	W0313	2757Z			32-64-31	ALL
D13759B	**E003-01/ /**		**PLUG - DPC 2**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0311	2095R	24		34-55-11	ALL
A04		W0311	2095B	24		34-55-11	ALL
A05	UNUSED						ALL
A06		W0311	0121	22		34-61-12	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0313	2614R	24		22-31-52	ALL
A10		W0313	2614B	24		22-31-52	ALL
A11		W0313	0518	24		31-65-25	ALL
B01		W0311	2071R	24		77-12-21	ALL
B02		W0311	2071B	24		77-12-21	ALL
B03		W0311	2024R	24		31-65-15	ALL
B04		W0311	2024B	24		31-65-15	ALL
B05		W0311	2138R	24		34-45-11	ALL
B06		W0311	2138B	24		34-45-11	ALL
B07		W0311	2116R	24		34-21-13	ALL
B08		W0311	2116B	24		34-21-13	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0313	2717R	24		31-31-13	ALL
C04		W0313	2717B	24		31-31-13	ALL
C05		W0313	1754	24		75-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759B		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	C06	UNUSED						ALL
	C07		W0311	0080	24		73-32-11	ALL
	C08		W0311	0051	24		73-21-31	ALL
	C09		W0313	2218R	24		31-65-25	ALL
	C10		W0313	2218B	24		31-65-25	ALL
	C11		W0311	1761	22		78-36-11	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0311	2703R	24		34-58-11	ALL
	D04		W0311	2703B	24		34-58-11	ALL
	D05		W0311	0069	22		30-21-31	ALL
	D06		W0311	0193	24		31-65-14	ALL
	D07		W0313	0605	24		29-32-11	ALL
	D08		W0313	0606	24		29-32-11	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11		W0313	0519	24		31-65-25	ALL
	E01		W0311	2720R	24		36-11-14	ALL
	E02		W0311	2720B	24		36-11-14	ALL
	E03		W0311	2083R	24		34-57-11	ALL
	E04		W0311	2083B	24		34-57-11	ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759B	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
E13	UNUSED						ALL
E14	UNUSED						ALL
E15		W0313	2992W	24		23-70-11	ALL
F01		W0313	2707R	24		31-65-25	ALL
F02		W0313	2707B	24		31-65-25	ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07		W0311	0016	24		31-65-14	ALL
F08		W0311	0077	24		73-31-11	ALL
F09		W0313	0520	24		31-65-25	ALL
F10		W0311	0040	24		76-21-11	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15		W0313	2992B	24		23-70-11	ALL
G01		W0311	2150R	24		22-11-51	ALL
G02		W0311	2150B	24		22-11-51	ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05		W0311	0116	22		34-51-41	ALL
G06		W0311	0200	22		30-21-31	ALL
G07	UNUSED						ALL
G08		W0311	0100	24		29-31-11	ALL
G09		W0311	0097	24		29-31-11	ALL
G10		W0311	0070	24		73-23-11	ALL
G11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759B		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	H01		W0311	0104	24		29-31-11	ALL
	H02		W0311	0098	24		29-31-11	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0311	0050	24		73-21-31	ALL
	H06		W0313	0004	22		30-31-12	ALL
	H07		W0313	1766	22		80-11-11	ALL
	H08		W0313	2657R	24		27-81-41	ALL
	H09		W0313	2657B	24		27-81-41	ALL
	H10		W0313	0508	24		31-65-41	ALL
	H11	UNUSED						ALL
	J01		W0311	2062R	22		28-41-11	ALL
	J02		W0311	2062B	22		28-41-11	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0313	0506	22		21-27-21	ALL
	J06		W0313	1771	22		73-22-41	ALL
	J07		W0313	2818R	24		31-33-01	ALL
	J08		W0313	2818B	24		31-33-01	ALL
	J09		W0311	0103	24		29-31-11	ALL
	J10		W0311	0096	24		29-31-11	ALL
	J11		W0313	0660	24		34-45-11	ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0311	2009R	24		31-65-12	ALL
	K04		W0311	2009B	24		31-65-12	ALL
	K05		W0311	2046R	24		73-24-11	ALL
	K06		W0311	2046B	24		73-24-11	ALL
	K07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759B	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
K08	UNUSED						ALL
K09		W0313	2530R	24		31-65-25	ALL
K10		W0313	2530B	24		31-65-25	ALL
K11	UNUSED						ALL
=C1T	UNUSED						ALL
=C2T		W0311	4002Z			31-65-25	ALL
1T-1	UNUSED						ALL
1T-2	UNUSED						ALL
1T-3	UNUSED						ALL
1T-4	UNUSED						ALL
2T-1	J5	W0311	4002Y	24		31-65-25	ALL
2T-2	J5	W0311	4002R	24		31-65-25	ALL
2T-3	J5	W0311	4002G	24		31-65-25	ALL
2T-4	J5	W0311	4002B	24		31-65-25	ALL
PERG	1A	W0311	2009Z			31-65-12	ALL
PERG	1A	W0311	2024Z			31-65-15	ALL
PERG	1A	W0311	2046Z			73-24-11	ALL
PERG	1A	W0311	2062Z			28-41-11	ALL
PERG	1A	W0311	2071Z			77-12-21	ALL
PERG	1A	W0311	2083Z			34-57-11	ALL
PERG	1A	W0311	2095Z			34-55-11	ALL
PERG	1A	W0311	2116Z			34-21-13	ALL
PERG	1A	W0311	2138Z			34-45-11	ALL
PERG	1A	W0311	2150Z			22-11-51	ALL
PERG	1A	W0311	2703Z			34-58-11	ALL
PERG	1A	W0311	2720Z			36-11-14	ALL
PERG	1A	W0313	2218Z			31-65-25	ALL
PERG	1A	W0313	2530Z			31-65-25	ALL
PERG	1A	W0313	2614Z			22-31-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759B		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	PERG	1A	W0313	2657Z			27-81-41	ALL
	PERG	1A	W0313	2707Z			31-65-25	ALL
	PERG	1A	W0313	2717Z			31-31-13	ALL
	PERG	1A	W0313	2818Z			31-33-01	ALL
	PERG	1A	W0313	2992Z			23-70-11	ALL
D13759C		**E003-01/ /**		**PLUG - DPC 2**				**ALL**
	1	UNUSED						ALL
	2		W0317	0005FO	16		31-65-25	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0317	0004FO	16		31-65-22	ALL
	6		W0317	0003FO	16		31-65-22	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0313	0503	16		31-65-21	ALL
	14		W0313	0510	16		31-65-21	ALL
	15		W0313	0502	16		31-65-21	ALL
	16	UNUSED						ALL
	=17		W0313	4003Z			46-13-11	ALL
	16-1	UNUSED						ALL
	16-2	UNUSED						ALL
	16-3	UNUSED						ALL
	16-4	UNUSED						ALL
	17-1	J5	W0313	4003Y	24		46-13-11	ALL
	17-2	J5	W0313	4003R	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759C		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	17-3	J5	W0313	4003G	24		46-13-11	ALL
	17-4	J5	W0313	4003B	24		46-13-11	ALL
D13759D		**E003-01/ /**		**PLUG - DPC 2**				**ALL**
	A01		W0311	0129	22		34-21-15	ALL
	A02	UNUSED						ALL
	A03		W0313	2505R	24		31-65-22	ALL
	A04		W0313	2505B	24		31-65-22	ALL
	A05		W0313	2543R	24		73-24-21	ALL
	A06		W0313	2543B	24		73-24-21	ALL
	A07		W0313	2625R	24		79-31-11	ALL
	A08		W0313	2625B	24		79-31-11	ALL
	A09		W0313	2598R	24		34-31-21	ALL
	A10		W0313	2598B	24		34-31-21	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0313	1507	24		79-31-11	ALL
	A14		W0313	1505	24		79-31-11	ALL
	A15		W0313	0663	22		34-41-11	ALL
	B01		W0313	2626R	24		79-31-11	ALL
	B02		W0313	2626B	24		79-31-11	ALL
	B03		W0313	0576	24		73-31-11	ALL
	B04		W0313	0558	24		73-22-31	ALL
	B05		W0313	2783R	22		28-41-11	ALL
	B06		W0313	2783B	22		28-41-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0313	2645W	24		34-41-11	ALL
	B11		W0313	2645B	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01		W0313	0515	24		31-65-24	ALL
	C02	UNUSED						ALL
	C03		W0313	0552	24		73-21-12	ALL
	C04		W0311	0124	22		34-61-12	ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0313	2751R	24		31-65-24	ALL
	C08		W0313	2751B	24		31-65-24	ALL
	C09		W0311	2204R	22		32-46-11	ALL
	C10		W0311	2204B	22		32-46-11	ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0313	0555	24		73-22-11	ALL
	D03		W0313	1502	22		31-65-24	ALL
	D04		W0313	0007	24		73-21-31	ALL
	D05		W0313	2592R	24		27-32-22	ALL
	D06		W0313	2592B	24		27-32-22	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0313	2514R	24		31-65-25	ALL
	D10		W0313	2514B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14	UNUSED						ALL
D15	UNUSED						ALL
E01		W0313	2754R	24		32-64-31	ALL
E02		W0313	2754B	24		32-64-31	ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07		W0313	2595R	24		34-55-21	ALL
E08		W0313	2595B	24		34-55-21	ALL
E09		W0313	2713R	24		31-65-26	ALL
E10		W0313	2713B	24		31-65-26	ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01		W0313	0531	24		74-31-11	ALL
F02		W0313	0521	24		31-65-25	ALL
F03		W0313	0583	24		80-11-11	ALL
F04		W0313	0699	22		30-21-32	ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07		W0311	2764W	24		34-49-11	ALL
F08		W0311	2764B	24		34-49-11	ALL
F09		W0313	0633	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	F10		W0313	0539	24		76-21-21	ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04		W0313	2525R	24		31-65-25	ALL
	G05		W0313	2525B	24		31-65-25	ALL
	G06		W0313	2712R	24		31-65-26	ALL
	G07		W0313	2712B	24		31-65-26	ALL
	G08		W0311	2038R	22		49-62-11	ALL
	G09		W0311	2038B	22		49-62-11	ALL
	G10		W0313	0565	24		73-23-11	ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03		W0313	0534	24		74-31-11	ALL
	H04		W0313	2602R	24		34-51-21	ALL
	H05		W0313	2602B	24		34-51-21	ALL
	H06		W0313	2512R	24		31-65-23	ALL
	H07		W0313	2512B	24		31-65-23	ALL
	H08		W0311	2087R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
H09		W0311	2087B	24		31-35-02	ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15	UNUSED						ALL
J01		W0313	2549R	24		73-24-12	ALL
J02		W0313	2549B	24		73-24-12	ALL
J03		W0313	1756	24		76-21-21	ALL
J04		W0313	2583R	24		34-57-21	ALL
J05		W0313	2583B	24		34-57-21	ALL
J06		W0313	2590R	24		22-11-51	ALL
J07		W0313	2590B	24		22-11-51	ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0311	0049	24		73-21-31	ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0313	2638R	24		34-45-11	ALL
K05		W0313	2638B	24		34-45-11	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	K08		W0313	2567R	24		77-12-11	ALL
	K09		W0313	2567B	24		77-12-11	ALL
	K10		W0313	0703	24		34-41-11	ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14		W0313	2619R	24		34-21-24	ALL
	K15		W0313	2619B	24		34-21-24	ALL
	DED		W0313	2645Z			34-41-11	ALL
	PERG	1A	W0311	2038Z			49-62-11	ALL
	PERG	1A	W0311	2087Z			31-35-02	ALL
	PERG	1A	W0311	2204Z			32-46-11	ALL
	PERG	1A	W0311	2764Z			34-49-11	ALL
	PERG	1A	W0313	1502Z			31-65-24	ALL
	PERG	1A	W0313	1505Z			79-31-11	ALL
	PERG	1A	W0313	1507Z			79-31-11	ALL
	PERG	1A	W0313	2505Z			31-65-22	ALL
	PERG	1A	W0313	2512Z			31-65-23	ALL
	PERG	1A	W0313	2514Z			31-65-25	ALL
	PERG	1A	W0313	2525Z			31-65-25	ALL
	PERG	1A	W0313	2543Z			73-24-21	ALL
	PERG	1A	W0313	2549Z			73-24-12	ALL
	PERG	1A	W0313	2567Z			77-12-11	ALL
	PERG	1A	W0313	2583Z			34-57-21	ALL
	PERG	1A	W0313	2590Z			22-11-51	ALL
	PERG	1A	W0313	2592Z			27-32-22	ALL
	PERG	1A	W0313	2595Z			34-55-21	ALL
	PERG	1A	W0313	2598Z			34-31-21	ALL
	PERG	1A	W0313	2602Z			34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759D	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
PERG	1A	W0313	2619Z			34-21-24	ALL
PERG	1A	W0313	2625Z			79-31-11	ALL
PERG	1A	W0313	2626Z			79-31-11	ALL
PERG	1A	W0313	2638Z			34-45-11	ALL
PERG	1A	W0313	2712Z			31-65-26	ALL
PERG	1A	W0313	2713Z			31-65-26	ALL
PERG	1A	W0313	2751Z			31-65-24	ALL
PERG	1A	W0313	2754Z			32-64-31	ALL
PERG	1A	W0313	2783Z			28-41-11	ALL
D13759E	**E003-01/ /**		**PLUG - DPC 2**				**ALL**
A01	UNUSED						ALL
A02		W0313	1765	22		80-11-11	ALL
A03		W0313	0563	22		30-21-32	ALL
A04	UNUSED						ALL
A05		W0313	2733R	24		34-33-21	ALL
A06		W0313	2733B	24		34-33-21	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
B01		W0313	2571R	24		77-12-21	ALL
B02		W0313	2571B	24		77-12-21	ALL
B03	UNUSED						ALL
B04		W0313	0003	22		30-31-12	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0313	2616R	24		34-21-23	ALL
B08		W0313	2616B	24		34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759E		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0313	1753	24		75-11-11	ALL
	C03	UNUSED						ALL
	C04		W0313	0613	22		34-51-41	ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0313	2716R	24		31-31-13	ALL
	C08		W0313	2716B	24		31-31-13	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	D01		W0313	0716	24		31-65-41	ALL
	D02		W0313	0546	24		73-21-31	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09		W0313	0664	22		34-41-11	ALL
	D10		W0311	1765	22		78-36-21	ALL
	D11	UNUSED						ALL
	E01	UNUSED						ALL
	E02		W0313	0513	22		30-21-32	ALL
	E03		W0313	0616	22		34-51-41	ALL
	E04		W0313	0579	24		73-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759E	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
E05		W0313	2524R	24		31-65-25	ALL
E06		W0313	2524B	24		31-65-25	ALL
E07		W0313	2720R	24		36-11-24	ALL
E08		W0313	2720B	24		36-11-24	ALL
E09		W0313	1762	22		78-36-21	ALL
E10		W0313	1760	22		78-36-11	ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02		W0313	1769	22		73-22-41	ALL
F03		W0313	0545	24		73-21-31	ALL
F04		W0313	2704R	24		34-58-21	ALL
F05		W0313	2704B	24		34-58-21	ALL
F06		W0313	2650R	24		22-11-51	ALL
F07		W0313	2650B	24		22-11-51	ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10		W0313	0540	24		76-21-21	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01		W0313	0631	24		31-65-42	ALL
G02	UNUSED						ALL
G03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759E		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08		W0313	0600	24		29-31-11	ALL
	G09		W0313	0597	24		29-31-11	ALL
	G10		W0313	0564	24		73-23-11	ALL
	G11	UNUSED						ALL
	H01		W0313	0604	24		29-31-11	ALL
	H02		W0313	0598	24		29-31-11	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0311	2023R	24		31-65-15	ALL
	H06		W0311	2023B	24		31-65-15	ALL
	H07		W0313	2517R	24		31-65-25	ALL
	H08		W0313	2517B	24		31-65-25	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	J01		W0313	0528	24		74-31-11	ALL
	J02		W0313	0692	24		31-65-24	ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05		W0313	2504R	24		31-65-22	ALL
	J06		W0313	2504B	24		31-65-22	ALL
	J07		W0313	2776R	24		31-65-26	ALL
	J08		W0313	2776B	24		31-65-26	ALL
	J09		W0313	0603	24		29-31-11	ALL
	J10		W0313	0596	24		29-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759E	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
J11	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05		W0313	2531R	24		31-65-25	ALL
K06		W0313	2531B	24		31-65-25	ALL
K07		W0313	2544R	24		73-24-21	ALL
K08		W0313	2544B	24		73-24-21	ALL
K09	UNUSED						ALL
K10		W0313	0672	22		31-65-41	ALL
K11	UNUSED						ALL
=C1T		W0313	4001Z			31-65-25	ALL
=C2T	UNUSED						ALL
CAP	Y	W0313	2771B	24		32-42-12	ALL
CAP	Y	W0313	2771R	24		32-42-12	ALL
DED		W0313	2771Z			32-42-12	ALL
1T-1	J5	W0313	4001Y	24		31-65-25	ALL
1T-2	J5	W0313	4001R	24		31-65-25	ALL
1T-3	J5	W0313	4001G	24		31-65-25	ALL
1T-4	J5	W0313	4001B	24		31-65-25	ALL
2T-1	UNUSED						ALL
2T-2	UNUSED						ALL
2T-3	UNUSED						ALL
2T-4	UNUSED						ALL
PERG	1A	W0311	2023Z			31-65-15	ALL
PERG	1A	W0313	2504Z			31-65-22	ALL
PERG	1A	W0313	2517Z			31-65-25	ALL
PERG	1A	W0313	2524Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759E		**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
	PERG	1A	W0313	2531Z			31-65-25	ALL
	PERG	1A	W0313	2544Z			73-24-21	ALL
	PERG	1A	W0313	2571Z			77-12-21	ALL
	PERG	1A	W0313	2616Z			34-21-23	ALL
	PERG	1A	W0313	2650Z			22-11-51	ALL
	PERG	1A	W0313	2704Z			34-58-21	ALL
	PERG	1A	W0313	2716Z			31-31-13	ALL
	PERG	1A	W0313	2720Z			36-11-24	ALL
	PERG	1A	W0313	2733Z			34-33-21	ALL
	PERG	1A	W0313	2776Z			31-65-26	ALL
D13759F		**E003-01/ /**		**PLUG - DPC 2**				**ALL**
	1	UNUSED						ALL
	2		W0315	0005FO	16		31-65-15	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0317	0002FO	16		31-65-22	ALL
	6		W0317	0001FO	16		31-65-22	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0313	0505	16		31-65-21	ALL
	14		W0313	0511	16		31-65-21	ALL
	15		W0313	0504	16		31-65-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	16-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13759F	**E003-01/ /**		**PLUG - DPC 2 (continued)**				**ALL**
16-2	UNUSED						ALL
16-3	UNUSED						ALL
16-4	UNUSED						ALL
17-1	UNUSED						ALL
17-2	UNUSED						ALL
17-3	UNUSED						ALL
17-4	UNUSED						ALL
D13761A	**E004-02/ /**		**PLUG - NFS**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
CC	UNUSED						ALL
FF	UNUSED						ALL
=AA		W0422	4018Z			46-13-52	ALL
=BB		W0422	4006Z			46-13-11	ALL
=DD		W0422	4019Z			46-13-52	ALL
=EE		W0422	4007Z			46-13-11	ALL
=GG		W0422	4016Z			46-13-11	ALL
=HH		W0422	4017Z			46-13-11	ALL
AA-1		W0422	4018R	24		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761A		**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
	AA-2		W0422	4018Y	24		46-13-52	ALL
	AA-3		W0422	4018B	24		46-13-52	ALL
	AA-4		W0422	4018G	24		46-13-52	ALL
	BB-1		W0422	4006R	24		46-13-11	ALL
	BB-2		W0422	4006Y	24		46-13-11	ALL
	BB-3	J5	W0422	4006B	24		46-13-11	ALL
	BB-4		W0422	4006G	24		46-13-11	ALL
	CC-1	UNUSED						ALL
	CC-2	UNUSED						ALL
	CC-3	UNUSED						ALL
	CC-4	UNUSED						ALL
	DD-1		W0422	4019R	24		46-13-52	ALL
	DD-2		W0422	4019Y	24		46-13-52	ALL
	DD-3		W0422	4019B	24		46-13-52	ALL
	DD-4		W0422	4019G	24		46-13-52	ALL
	EE-1		W0422	4007R	24		46-13-11	ALL
	EE-2		W0422	4007Y	24		46-13-11	ALL
	EE-3	J5	W0422	4007B	24		46-13-11	ALL
	EE-4		W0422	4007G	24		46-13-11	ALL
	FF-1	UNUSED						ALL
	FF-2	UNUSED						ALL
	FF-3	UNUSED						ALL
	FF-4	UNUSED						ALL
	GG-1		W0422	4016R	24		46-13-11	ALL
	GG-2		W0422	4016Y	24		46-13-11	ALL
	GG-3	J5	W0422	4016B	24		46-13-11	ALL
	GG-4		W0422	4016G	24		46-13-11	ALL
	HH-1		W0422	4017R	24		46-13-11	ALL
	HH-2		W0422	4017Y	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761A		**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
	HH-3	J5	W0422	4017B	24		46-13-11	ALL
	HH-4		W0422	4017G	24		46-13-11	ALL
D13761B		**E004-02/ /**		**PLUG - NFS**				**ALL**
	HH	UNUSED						ALL
	JJ	UNUSED						ALL
	LL	UNUSED						ALL
	=AA		W0422	4009Z			46-13-11	ALL
	=BB		W0422	4010Z			46-13-11	ALL
	=CC		W0422	4011Z			46-13-11	ALL
	=DD		W0422	4012Z			46-13-11	ALL
	=EE		W0422	4013Z			46-13-11	ALL
	=FF		W0422	4014Z			46-13-11	ALL
	=GG		W0422	4015Z			46-13-11	ALL
	=KK		W0422	4008Z			46-13-11	ALL
	AA-1		W0422	4009R	24		46-13-11	ALL
	AA-2		W0422	4009Y	24		46-13-11	ALL
	AA-3	J5	W0422	4009B	24		46-13-11	ALL
	AA-4		W0422	4009G	24		46-13-11	ALL
	BB-1		W0422	4010R	24		46-13-11	ALL
	BB-2		W0422	4010Y	24		46-13-11	ALL
	BB-3	J5	W0422	4010B	24		46-13-11	ALL
	BB-4		W0422	4010G	24		46-13-11	ALL
	CC-1		W0422	4011R	24		46-13-11	ALL
	CC-2		W0422	4011Y	24		46-13-11	ALL
	CC-3	J5	W0422	4011B	24		46-13-11	ALL
	CC-4		W0422	4011G	24		46-13-11	ALL
	DD-1		W0422	4012R	24		46-13-11	ALL
	DD-2		W0422	4012Y	24		46-13-11	ALL
	DD-3	J5	W0422	4012B	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761B		**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
	DD-4		W0422	4012G	24		46-13-11	ALL
	EE-1		W0422	4013R	24		46-13-11	ALL
	EE-2		W0422	4013Y	24		46-13-11	ALL
	EE-3	J5	W0422	4013B	24		46-13-11	ALL
	EE-4		W0422	4013G	24		46-13-11	ALL
	FF-1		W0422	4014R	24		46-13-11	ALL
	FF-2		W0422	4014Y	24		46-13-11	ALL
	FF-3	J5	W0422	4014B	24		46-13-11	ALL
	FF-4		W0422	4014G	24		46-13-11	ALL
	GG-1		W0422	4015R	24		46-13-11	ALL
	GG-2		W0422	4015Y	24		46-13-11	ALL
	GG-3	J5	W0422	4015B	24		46-13-11	ALL
	GG-4		W0422	4015G	24		46-13-11	ALL
	HH-1	UNUSED						ALL
	HH-2	UNUSED						ALL
	HH-3	UNUSED						ALL
	HH-4	UNUSED						ALL
	JJ-1	UNUSED						ALL
	JJ-2	UNUSED						ALL
	JJ-3	UNUSED						ALL
	JJ-4	UNUSED						ALL
	KK-1		W0422	4008R	24		46-13-11	ALL
	KK-2		W0422	4008Y	24		46-13-11	ALL
	KK-3	J5	W0422	4008B	24		46-13-11	ALL
	KK-4		W0422	4008G	24		46-13-11	ALL
	LL-1	UNUSED						ALL
	LL-2	UNUSED						ALL
	LL-3	UNUSED						ALL
	LL-4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761C	**E004-02/ /**		**PLUG - NFS**				**ALL**
1		W0422	0303	22		46-13-11	ALL
2		W0422	0301	22		46-13-11	ALL
3		W0422	0302	22		46-13-11	ALL
4		W0422	0304	22		46-13-11	ALL
5		W0422	0305	22		46-13-11	ALL
A01		W0422	2610R	24		31-32-15	ALL
A02	UNUSED						ALL
A03		W0422	2424R	24		34-61-14	ALL
A04		W0422	2425R	24		34-61-15	ALL
A05		W0422	2422R	24		34-21-14	ALL
A06		W0422	2421R	24		34-21-13	ALL
A07		W0422	2427R	24		31-65-15	ALL
A08		W0422	2428R	24		31-65-25	ALL
B01		W0422	2610B	24		31-32-15	ALL
B02	UNUSED						ALL
B03		W0422	2424B	24		34-61-14	ALL
B04		W0422	2425B	24		34-61-15	ALL
B05		W0422	2422B	24		34-21-14	ALL
B06		W0422	2421B	24		34-21-13	ALL
B07		W0422	2427B	24		31-65-15	ALL
B08		W0422	2428B	24		31-65-25	ALL
C01		W0422	2614R	24		23-27-34	ALL
C02	UNUSED						ALL
C03		W0422	2426R	24		34-58-11	ALL
C04		W0422	2423R	24		34-53-11	ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761C		**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
	D01		W0422	2614B	24		23-27-34	ALL
	D02	UNUSED						ALL
	D03		W0422	2426B	24		34-58-11	ALL
	D04		W0422	2423B	24		34-53-11	ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	E01		W0422	2611R	24		31-32-15	ALL
	E02		W0422	2472R	24		46-13-11	ALL
	E03	UNUSED						ALL
	E04		W0422	2613R	24		46-13-11	ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	F01		W0422	2611B	24		31-32-15	ALL
	F02		W0422	2472B	24		46-13-11	ALL
	F03	UNUSED						ALL
	F04		W0422	2613B	24		46-13-11	ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	G01	UNUSED						ALL
	G02		W0422	0540	24		31-32-15	ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05		W0422	2612R	24		31-35-09	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761C	**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
G06		W0422	2029R	24		31-35-09	ALL
G07		W0422	2030R	24		31-35-09	ALL
G08	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05		W0422	2612B	24		31-35-09	ALL
H06		W0422	2029B	24		31-35-09	ALL
H07		W0422	2030B	24		31-35-09	ALL
H08	UNUSED						ALL
J01		W0422	0538	24		31-32-15	ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
K01		W0422	0539	24		31-32-15	ALL
K02		W0422	0306	22		46-13-11	ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05		W0422	0307	22		46-13-11	ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
PERG	1A	W0422	2029Z			31-35-09	ALL
PERG	1A	W0422	2030Z			31-35-09	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13761C		**E004-02/ /**		**PLUG - NFS (continued)**				**ALL**
	PERG	1A	W0422	2421Z			34-21-13	ALL
	PERG	1A	W0422	2422Z			34-21-14	ALL
	PERG	1A	W0422	2423Z			34-53-11	ALL
	PERG	1A	W0422	2424Z			34-61-14	ALL
	PERG	1A	W0422	2425Z			34-61-15	ALL
	PERG	1A	W0422	2426Z			34-58-11	ALL
	PERG	1A	W0422	2427Z			31-65-15	ALL
	PERG	1A	W0422	2428Z			31-65-25	ALL
	PERG	1A	W0422	2472Z			46-13-11	ALL
	PERG	1A	W0422	2610Z			31-32-15	ALL
	PERG	1A	W0422	2611Z			31-32-15	ALL
	PERG	1A	W0422	2612Z			31-35-09	ALL
	PERG	1A	W0422	2613Z			46-13-11	ALL
	PERG	1A	W0422	2614Z			23-27-34	ALL
D13763		**P002-03/ /**		**PLUG-- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0001	1304	24		33-25-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0001	1764	22		32-31-15	ALL
	7		W0001	1765	22		32-31-15	ALL
	8		W0001	1768	22		32-31-15	ALL
	9		W0001	1311	22		32-41-11	ALL
	10		W0001	1771	22		32-31-15	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13763	**P002-03/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0001	1757	22		32-31-15	ALL
19	UNUSED						ALL
20		W0001	1758	22		32-31-15	ALL
21		W0001	1759	22		32-31-15	ALL
22	UNUSED						ALL
23		W0001	1313	24		32-41-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
S/R		W0001	1304Z			33-25-11	ALL
S/R		W0001	1311Z			32-41-11	ALL
S/R		W0001	1313Z			32-41-11	ALL
S/R		W0001	1757Z			32-31-15	ALL
S/R		W0001	1758Z			32-31-15	ALL
S/R		W0001	1759Z			32-31-15	ALL
S/R		W0001	1764Z			32-31-15	ALL
S/R		W0001	1765Z			32-31-15	ALL
S/R		W0001	1768Z			32-31-15	ALL
S/R		W0001	1771Z			32-31-15	ALL
D13781	**P007-01/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1		W0001	1009	20		33-11-32	ALL
2		W0001	1010	20		33-11-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13781		**P007-01/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	3		W0001	1004	22		31-65-11	ALL
	4		W0001	1509	20		31-65-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0001	0010	20		31-65-11	ALL
	17	UNUSED						ALL
	18		W0001	1752	24		31-65-13	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0001	1754	24		31-65-13	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0001	0011	20		31-65-11	ALL
	31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13781	**P007-01/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W0001	0012	20		31-65-11	ALL
41		W0001	3002Y	24		31-65-13	ALL
42		W0001	3002B	24		31-65-13	ALL
43		W0001	3002R	24		31-65-13	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46		W0001	0013	20		31-65-11	ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0001	3008R	24		31-65-13	ALL
51		W0001	3008B	24		31-65-13	ALL
52		W0001	3008Y	24		31-65-13	ALL
53	UNUSED						ALL
54		W0001	2005R	24		31-65-13	ALL
55		W0001	2005B	24		31-65-13	ALL
S/R		W0001	1004Z			31-65-11	ALL
S/R		W0001	1009Z			33-11-32	ALL
S/R		W0001	1010Z			33-11-32	ALL
S/R		W0001	1509Z			31-65-11	ALL
S/R		W0001	1752Z			31-65-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13781		**P007-01/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	S/R		W0001	1754Z			31-65-13	ALL
	S/R		W0001	2005Z			31-65-13	ALL
	S/R		W0001	3002Z			31-65-13	ALL
	S/R		W0001	3008Z			31-65-13	ALL
D13783		**P007-02/ /**		**PLUG- CONDUCTIVE**				**ALL**
	1		W0003	1509	20		33-11-21	ALL
	2		W0003	1510	20		33-11-21	ALL
	3		W0003	1504	22		31-65-21	ALL
	4		W0003	1681	20		31-65-21	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0003	0509	20		31-65-21	ALL
	17	UNUSED						ALL
	18		W0003	1754	24		31-65-23	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13783	**P007-02/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
25	UNUSED						ALL
26		W0003	1752	24		31-65-23	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W0003	0510	20		31-65-21	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W0003	0511	20		31-65-21	ALL
41		W0003	3502Y	24		31-65-23	ALL
42		W0003	3502B	24		31-65-23	ALL
43		W0003	3502R	24		31-65-23	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46		W0003	0512	20		31-65-21	ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50		W0003	3508R	24		31-65-23	ALL
51		W0003	3508B	24		31-65-23	ALL
52		W0003	3508Y	24		31-65-23	ALL
53	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13783		**P007-02/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	54		W0003	2505R	24		31-65-23	ALL
	55		W0003	2505B	24		31-65-23	ALL
	S/R		W0003	1504Z			31-65-21	ALL
	S/R		W0003	1509Z			33-11-21	ALL
	S/R		W0003	1510Z			33-11-21	ALL
	S/R		W0003	1681Z			31-65-21	ALL
	S/R		W0003	1752Z			31-65-23	ALL
	S/R		W0003	1754Z			31-65-23	ALL
	S/R		W0003	2505Z			31-65-23	ALL
	S/R		W0003	3502Z			31-65-23	ALL
	S/R		W0003	3508Z			31-65-23	ALL
D13789		**P009-82/ /**		**PLUG-- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W0001	2711R	24		31-65-16	ALL
	3		W0001	2711B	24		31-65-16	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0001	1003	20		31-65-11	ALL
	7		W0001	1514	20		31-65-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0001	2712B	24		31-65-16	ALL
	16		W0001	2712R	24		31-65-16	ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13789	**P009-82/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
18	UNUSED						ALL
19	UNUSED						ALL
20		W0001	0015	20		31-65-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W0001	0144	24		32-42-11	ALL
25		W0001	0136	24		32-42-11	ALL
26		W0001	0135	22		32-42-11	ALL
27	UNUSED						ALL
28		W0001	0148	24		32-42-11	ALL
29		W0001	0146	22		32-42-11	ALL
30		W0001	0147	22		32-42-11	ALL
31		W0001	0145	22		32-42-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
S/R		W0001	1003Z			31-65-11	ALL
S/R		W0001	1514Z			31-65-11	ALL
S/R		W0001	2711Z			31-65-16	ALL
S/R		W0001	2712Z			31-65-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13790		**P061-08/ /**		**PLUG- S1 TEST SWITCH - LEFT**				**ALL**
	1		W0044	0937	20		28-23-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0044	0936	20		28-23-11	ALL
D13791		**P009-82/ /**		**PLUG- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0003	2712B	24		31-65-26	ALL
	10		W0003	2712R	24		31-65-26	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13791	**P009-82/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
14		W0003	2711R	24		31-65-26	ALL
15		W0003	2711B	24		31-65-26	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W0001	0138	24		32-42-11	ALL
33		W0001	0139	24		32-42-11	ALL
34		W0001	0141	24		32-42-11	ALL
35		W0001	0142	24		32-42-11	ALL
36		W0001	0140	24		32-42-11	ALL
37		W0001	0143	24		32-42-11	ALL
38		W0001	0137	22		32-42-11	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13791		**P009-82/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W0003	2711Z			31-65-26	ALL
	S/R		W0003	2712Z			31-65-26	ALL
D13792		**P061-08/ /**		**PLUG- S2 TEST SWITCH - RIGHT**				**ALL**
	1		W0044	0941	20		28-23-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13792	**P061-08/ /**		**PLUG- S2 TEST SWITCH - RIGHT (continued)**				**ALL**
14		W0044	0940	20		28-23-11	ALL
15	UNUSED						ALL
D13793	**P009-82/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W2889	0016	20		33-11-33	ALL
2		W2889	0017	20		33-11-33	ALL
3		W2889	0018	20		33-18-61	ALL
4		W2889	0020	20		33-18-61	ALL
5	UNUSED						ALL
6		W2889	0019	20		33-18-61	ALL
7		W2889	0021	20		33-18-61	ALL
8		W2889	0133	24		32-41-11	ALL
9		W2889	0134	24		32-42-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W2889	1001	22		32-46-11	ALL
15		W2889	1002	22		32-49-11	ALL
S/R		W2889	1001Z			32-46-11	ALL
S/R		W2889	1002Z			32-49-11	ALL
D13794	**J020-00/ /**		**RELAY SOCKET**				**ALL**
A1	UNUSED						ALL
A2		W0072	0610	20		28-23-11	ALL
A3		W0072	0609	20		28-23-11	ALL
B1	UNUSED						ALL
B2		W0072	0612	20		28-23-11	ALL
B3		W0072	0613	20		28-23-11	ALL
C1	UNUSED						ALL
C2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13794		**J020-00/ /**		**RELAY SOCKET (continued)**				**ALL**
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0072	0605	20		28-23-11	ALL
	X2		W0072	0607	20		28-23-11	ALL
D13795A		***/*/***		**PLUG**				**ALL**
	=A	UNUSED						ALL
	=B	UNUSED						ALL
D13795B		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0121	0148	24		34-41-11	ALL
	A04		W0121	0149	24		34-41-11	ALL
	A05		W0121	2105R	24		34-41-11	ALL
	A06		W0121	2105B	24		34-41-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0121	2110R	24		31-65-15	ALL
	B04		W0121	2110B	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B	*/*/*		**PLUG (continued)**				**ALL**
B05	UNUSED						ALL
B06		W0121	0130	24		34-41-11	ALL
B07		W0121	2097R	24		34-41-11	ALL
B08		W0121	2097B	24		34-41-11	ALL
B09		W0121	0153	22		34-41-11	ALL
B10		W0121	0154	22		34-41-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0121	0152	22		34-41-11	ALL
B15	UNUSED						ALL
C01		W0121	2104R	24		34-41-11	ALL
C02		W0121	2104B	24		34-41-11	ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06		W0121	0131	24		34-41-11	ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01		W0121	0155	24		34-41-11	ALL
D02		W0121	2101W	24		34-41-11	ALL
D03		W0121	2101B	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B		***/*/***		**PLUG (continued)**				**ALL**
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06		W0121	0132	24		34-41-11	ALL
	D07		W0121	0133	24		34-41-11	ALL
	D08		W0121	0109	24		34-41-11	ALL
	D09		W0121	0142	24		34-41-11	ALL
	D10		W0121	0147	24		34-41-11	ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01		W0121	0144	24		34-41-11	ALL
	E02		W0121	0151	22		34-41-11	ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06		W0121	0134	24		34-41-11	ALL
	E07		W0121	0135	24		34-41-11	ALL
	E08	UNUSED						ALL
	E09		W0121	0143	24		34-41-11	ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01		W0121	0156	24		34-49-11	ALL
	F02		W0121	0140	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B	*/*/*		**PLUG (continued)**				**ALL**
F03		W0121	0146	24		34-41-11	ALL
F04		W0121	0136	24		34-41-11	ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07		W0121	0141	24		34-41-11	ALL
F08	UNUSED						ALL
F09	UNUSED						ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14		W0121	0139	22		34-41-11	ALL
F15		W0121	0138	22		34-41-11	ALL
G01		W0121	0145	24		34-41-11	ALL
G02		W0121	2102W	24		34-41-11	ALL
G03		W0121	2102B	24		34-41-11	ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12		W0121	2094R	24		34-21-23	ALL
G13		W0121	2094B	24		34-21-23	ALL
G14		W0121	0129	22		34-41-11	ALL
G15	UNUSED						ALL
H01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B		***/*/***		**PLUG (continued)**				**ALL**
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0121	2103R	24		34-41-11	ALL
	J02	UNUSED						ALL
	J03		W0121	2111R	24		31-65-25	ALL
	J04		W0121	2111B	24		31-65-25	ALL
	J05		W0121	2108R	24		34-49-11	ALL
	J06		W0121	2108B	24		34-49-11	ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09		W0121	2096R	24		34-21-24	ALL
	J10		W0121	2096B	24		34-21-24	ALL
	J11		W0121	2521R	24		34-21-13	ALL
	J12		W0121	2521B	24		34-21-13	ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15		W0121	0157	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B	*/*/*		**PLUG (continued)**				**ALL**
K01		W0121	2103B	24		34-41-11	ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08		W0121	2106R	24		34-41-11	ALL
K09		W0121	2106B	24		34-41-11	ALL
K10		W0121	0137	24		34-41-11	ALL
K11		W0121	2093R	24		34-21-14	ALL
K12		W0121	2093B	24		34-21-14	ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15		W0121	0157	24		34-41-11	ALL
DED		W0121	2106ZI			34-41-11	ALL
PERG	1A	W0121	2093Z			34-21-14	ALL
PERG	1A	W0121	2094Z			34-21-23	ALL
PERG	1A	W0121	2096Z			34-21-24	ALL
PERG	1A	W0121	2097Z			34-41-11	ALL
PERG	1A	W0121	2101Z			34-41-11	ALL
PERG	1A	W0121	2102Z			34-41-11	ALL
PERG	1A	W0121	2103Z			34-41-11	ALL
PERG	1A	W0121	2104Z			34-41-11	ALL
PERG	1A	W0121	2105Z			34-41-11	ALL
PERG	1A	W0121	2106ZO			34-41-11	ALL
PERG	1A	W0121	2108Z			34-49-11	ALL
PERG	1A	W0121	2110Z			31-65-15	ALL
PERG	1A	W0121	2111Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13795B		***/*/***		**PLUG (continued)**				**ALL**
	PERG	1A	W0121	2521Z			34-21-13	ALL
D13795C		***/*/***		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W0121	0126	20		34-41-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0121	0127	20		34-41-11	ALL
	8		W0121	0128	20		34-41-11	ALL
	9	UNUSED						ALL
	10		W0121	2098R	16		34-41-11	ALL
	11		W0121	2098B	16		34-41-11	ALL
	13	UNUSED						ALL
	=12		W0121	4002Z			34-41-11	ALL
	12-1		W0121	4002R	24		34-41-11	ALL
	12-2		W0121	4002Y	24		34-41-11	ALL
	12-3		W0121	4002B	24		34-41-11	ALL
	12-4		W0121	4002G	24		34-41-11	ALL
	13-1	UNUSED						ALL
	13-2	UNUSED						ALL
	13-3	UNUSED						ALL
	13-4	UNUSED						ALL
	PERG	1A	W0121	2098Z			34-41-11	ALL
D13796		**J020-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0072	0605	20		28-23-11	ALL
	A2		W0072	0602	20		28-23-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13796		**J020-00/ /**		**RELAY SOCKET (continued)**				**ALL**
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0072	0611	20		28-23-11	ALL
	X2		W0072	0604	20		28-23-11	ALL
D13798		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0094	0506	20		28-23-11	ALL
	A3		W0094	0509	20		28-23-11	ALL
	B1	UNUSED						ALL
	B2		W0094	0512	20		28-23-11	ALL
	B3		W0094	0513	20		28-23-11	ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0094	0505	20		28-23-11	ALL
	X2		W0094	0507	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13800		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0094	0505	20		28-23-11	ALL
	A2		W0094	0502	20		28-23-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0094	0511	20		28-23-11	ALL
	X2		W0094	0504	20		28-23-11	ALL
D13802		**P006-00/ /**		**SOCKET - IFE/PASS SEAT CONTROL RELAY 2**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1		W0044	0994	20		23-70-11	ALL
	D2		W0044	0996	20		23-70-11	ALL
	D3	UNUSED						ALL
	X1		W0044	0942	24		24-28-41	ALL
	X2		W0044	0943	22		24-28-41	ALL
D13804		**500I+11/201/R012**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5208	2006R	20		47-30-11	ALL
	3		W5208	2006B	20		47-30-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13804	**500I+11/201/R012**		**PLUG- (continued)**				**ALL**
6	UNUSED						ALL
7		W5208	2005R	20		47-30-11	ALL
8		W5208	2005B	20		47-30-11	ALL
9	UNUSED						ALL
10		W5208	2003B	20		47-30-11	ALL
11		W5208	2004B	20		47-30-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5208	4001Y	20		47-30-11	ALL
16		W5208	4001B	20		47-30-11	ALL
17		W5208	4001G	20		47-30-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5208	2003R	20		47-30-11	ALL
24		W5208	2004R	20		47-30-11	ALL
25		W5208	2002R	20		47-30-11	ALL
26		W5208	2002B	20		47-30-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W5208	0003	20		47-30-11	ALL
30		W5208	0002	20		47-30-11	ALL
31		W5208	2001B	20		47-30-11	ALL
32		W5208	3001R	20		47-30-11	ALL
33	UNUSED						ALL
34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13804		**500I+11/201/R012**		**PLUG- (continued)**				**ALL**
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W5208	1522	20		47-30-11	ALL
	43	UNUSED						ALL
	44		W5208	1521	20		47-30-11	ALL
	45	UNUSED						ALL
	46		W5208	0004	20		47-30-11	ALL
	47		W5208	0001	20		47-30-11	ALL
	48		W5208	3001Y	20		47-30-11	ALL
	49		W5208	2001R	20		47-30-11	ALL
	50		W5208	4001R	20		47-30-11	ALL
	51		W5208	3001B	20		47-30-11	ALL
	52		W5208	1501	20		47-30-11	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W5208	1501Z			47-30-11	ALL
	PERB		W5208	1521Z			47-30-11	ALL
	PERB		W5208	1522Z			47-30-11	ALL
	PERB		W5208	2001Z			47-30-11	ALL
	PERB		W5208	2002Z			47-30-11	ALL
	PERB		W5208	2003Z			47-30-11	ALL
	PERB		W5208	2004Z			47-30-11	ALL
	PERB		W5208	2005Z			47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13804	**500I+11/201/R012**		**PLUG- (continued)**				**ALL**
PERB		W5208	2006Z			47-30-11	ALL
PERB		W5208	3001Z			47-30-11	ALL
PERB		W5208	4001Z			47-30-11	ALL
D13806	**500I+6/201/R012**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W5208	1511	20		47-30-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5208	1523	20		47-30-11	ALL
7	UNUSED						ALL
8		W5208	1513	20		47-30-11	ALL
9		W5208	1502	20		47-30-11	ALL
10	UNUSED						ALL
11		W5208	4002B	20		47-30-11	ALL
12		W5208	1509	20		47-30-11	ALL
13	UNUSED						ALL
14		W5208	1524	20		47-30-11	ALL
15		W5208	1520	20		47-30-11	ALL
16		W5208	1504	20		47-30-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5208	1505	20		47-30-11	ALL
24		W5208	4002R	20		47-30-11	ALL
25		W5208	4002Y	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13806		**500I+6/201/R012**		**PLUG- (continued)**				**ALL**
	26	UNUSED						ALL
	27		W5208	1512	20		47-30-11	ALL
	28		W5208	1516	20		47-30-11	ALL
	29		W5208	0021	20		47-30-11	ALL
	30		W5208	1519	20		47-30-11	ALL
	31		W5208	1518	20		47-30-11	ALL
	32	UNUSED						ALL
	33		W5208	1507	20		47-30-11	ALL
	34		W5208	2007B	20		47-30-11	ALL
	35		W5208	2007R	20		47-30-11	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40		W5208	1508	20		47-30-11	ALL
	41		W5208	1506	20		47-30-11	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44		W5208	4002G	20		47-30-11	ALL
	45		W5208	0006	20		47-30-11	ALL
	46		W5208	1515	20		47-30-11	ALL
	47		W5208	0022	20		47-30-11	ALL
	48		W5208	0023	20		47-30-11	ALL
	49		W5208	0024	20		47-30-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52		W5208	1503	20		47-30-11	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13806	**500I+6/201/R012**		**PLUG- (continued)**				**ALL**
55	UNUSED						ALL
PERB		W5208	1502Z			47-30-11	ALL
PERB		W5208	1503Z			47-30-11	ALL
PERB		W5208	1504Z			47-30-11	ALL
PERB		W5208	1505Z			47-30-11	ALL
PERB		W5208	1506Z			47-30-11	ALL
PERB		W5208	1507Z			47-30-11	ALL
PERB		W5208	1508Z			47-30-11	ALL
PERB		W5208	1509Z			47-30-11	ALL
PERB		W5208	1511Z			47-30-11	ALL
PERB		W5208	1512Z			47-30-11	ALL
PERB		W5208	1513Z			47-30-11	ALL
PERB		W5208	1515Z			47-30-11	ALL
PERB		W5208	1516Z			47-30-11	ALL
PERB		W5208	1518Z			47-30-11	ALL
PERB		W5208	1519Z			47-30-11	ALL
PERB		W5208	1520Z			47-30-11	ALL
PERB		W5208	1523Z			47-30-11	ALL
PERB		W5208	1524Z			47-30-11	ALL
PERB		W5208	2007Z			47-30-11	ALL
PERB		W5208	4002Z			47-30-11	ALL
D13808	**543/157/R038**		**PLUG-**				**ALL**
1		W7208	4001R	20		47-30-11	ALL
2		W7208	4001G	20		47-30-11	ALL
3		W7208	4001B	20		47-30-11	ALL
4		W7208	0099	20		47-30-11	ALL
5	UNUSED						ALL
6		W7208	3001Y	20		47-30-11	ALL
7		W7208	1001	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13808		**543/157/R038**		**PLUG- (continued)**				**ALL**
	8		W7208	3001R	20		47-30-11	ALL
	9		W7208	4001Y	20		47-30-11	ALL
	10		W7208	2001B	20		47-30-11	ALL
	11		W7208	2001R	20		47-30-11	ALL
	12		W7208	3001B	20		47-30-11	ALL
	PERB		W7208	1001Z			47-30-11	ALL
	PERB		W7208	2001Z			47-30-11	ALL
	PERB		W7208	3001Z			47-30-11	ALL
	PERB		W7208	4001Z			47-30-11	ALL
D13810		**543/162/L032**		**PLUG-**				**ALL**
	A		W7202	1203	20		47-30-11	ALL
	B		W7202	1204	20		47-30-11	ALL
	C	UNUSED						ALL
	D		W7202	0011	22		47-30-11	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	PERB		W7202	1203Z			47-30-11	ALL
	PERB		W7202	1204Z			47-30-11	ALL
D13812		**644/160/L054**		**PLUG-**				**ALL**
	A		W7202	2506R	20		47-30-11	ALL
	B		W7202	2506B	20		47-30-11	ALL
	C		W7202	0019	22		47-30-11	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	PERB		W7202	2506Z			47-30-11	ALL
D13814		**642/163/L048**		**PLUG-**				**ALL**
	A		W7202	2507B	20		47-30-11	ALL
	B		W7202	2507R	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13814	**642/163/L048**		**PLUG- (continued)**				**ALL**
C	UNUSED						ALL
PERB		W7202	2507Z			47-30-11	ALL
D13816	**654/161/L066**		**PLUG-**				**ALL**
A		W7202	1206	20		47-30-11	ALL
B		W7202	1207	20		47-30-11	ALL
C		W7202	0012	22		47-30-11	ALL
PERB		W7202	1206Z			47-30-11	ALL
PERB		W7202	1207Z			47-30-11	ALL
D13818	**656/158/L047**		**PLUG-**				**ALL**
1		W7202	2510B	22		47-30-11	ALL
2	UNUSED						ALL
3		W7202	2510R	22		47-30-11	ALL
4	UNUSED						ALL
5		W7202	0017	22		47-30-11	ALL
6	UNUSED						ALL
PERB		W7202	2510Z			47-30-11	ALL
D13820	**605/162/L059**		**PLUG-**				**ALL**
1		W7202	1202	20		47-30-11	ALL
2		W7202	1201	20		47-30-11	ALL
3		W7202	0010	22		47-30-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
PERB		W7202	1201Z			47-30-11	ALL
PERB		W7202	1202Z			47-30-11	ALL
D13824	**602/161/L060**		**PLUG-**				**ALL**
1		W7202	2509B	22		47-30-11	ALL
2	UNUSED						ALL
3		W7202	2509R	22		47-30-11	ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13824		**602/161/L060**		**PLUG- (continued)**				**ALL**
	5		W7202	0016	22		47-30-11	ALL
	6	UNUSED						ALL
	PERB		W7202	2509Z			47-30-11	ALL
D13826		**653/162/L061**		**PLUG-**				**ALL**
	A		W7202	1207	20		47-30-11	ALL
	B		W7202	0013	22		47-30-11	ALL
	C		W7202	1208	20		47-30-11	ALL
	PERB		W7202	1207Z			47-30-11	ALL
	PERB		W7202	1208Z			47-30-11	ALL
D13828		**657/161/L066**		**PLUG-**				**ALL**
	A		W7202	2504B	20		47-30-11	ALL
	B		W7202	2505B	20		47-30-11	ALL
	C		W7202	2505R	20		47-30-11	ALL
	D		W7202	2504R	20		47-30-11	ALL
	E		W7202	0018	22		47-30-11	ALL
	F	UNUSED						ALL
	PERB		W7202	2504Z			47-30-11	ALL
	PERB		W7202	2505Z			47-30-11	ALL
D13830		**539/167/L034**		**PLUG-**				**ALL**
	1		W7202	2508B	22		47-30-11	ALL
	2	UNUSED						ALL
	3		W7202	2508R	22		47-30-11	ALL
	4	UNUSED						ALL
	5		W7202	0015	22		47-30-11	ALL
	6	UNUSED						ALL
	PERB		W7202	2508Z			47-30-11	ALL
D13832		**538/197/L041**		**PLUG-**				**ALL**
	1		W5208	1509	20		47-30-11	ALL
	2		W5208	4002R	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13832	**538/197/L041**		**PLUG- (continued)**				**ALL**
3		W5208	4002G	20		47-30-11	ALL
4	UNUSED						ALL
5		W5208	4002Y	20		47-30-11	ALL
6		W5208	1508	20		47-30-11	ALL
7		W5208	4002B	20		47-30-11	ALL
8	UNUSED						ALL
9		W5208	1507	20		47-30-11	ALL
10		W5208	0011R	20		26-12-11	ALL
11		W5208	1505	20		47-30-11	ALL
12		W5208	0012R	20		26-12-11	ALL
13		W5208	1504	20		47-30-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5208	1514	20		47-30-11	ALL
17		W5208	1506	20		47-30-11	ALL
18	UNUSED						ALL
19		W5208	1503	20		47-30-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W5208	1510	20		47-30-11	ALL
23	UNUSED						ALL
24		W5208	1502	20		47-30-11	ALL
PERB		W5208	1502Z			47-30-11	ALL
PERB		W5208	1503Z			47-30-11	ALL
PERB		W5208	1504Z			47-30-11	ALL
PERB		W5208	1505Z			47-30-11	ALL
PERB		W5208	1506Z			47-30-11	ALL
PERB		W5208	1507Z			47-30-11	ALL
PERB		W5208	1508Z			47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13832		**538/197/L041**		**PLUG- (continued)**				**ALL**
	PERB		W5208	1509Z			47-30-11	ALL
	PERB		W5208	1510Z			47-30-11	ALL
	PERB		W5208	1514Z			47-30-11	ALL
	PERB		W5208	4002Z			47-30-11	ALL
D13837		**P061-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A	UNUSED						ALL
	B		W0041	2546R	24		31-65-26	ALL
	C		W0041	2546B	24		31-65-26	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F		W0041	0124	20		31-65-21	ALL
	G		W0041	0125	20		31-65-21	ALL
	H		W0041	0126	20		31-65-21	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERB		W0041	2546Z			31-65-26	ALL
D13838		**723/166/R010**		**PLUG**				**ALL**
	1		W5204	1002	20		47-30-11	ALL
	2		W5204	1003	20		47-30-11	ALL
	3		W5204	1004	20		47-30-11	ALL
	4	UNUSED						ALL
	5		W5204	1001	20		47-30-11	ALL
	PERB		W5204	1001Z			47-30-11	ALL
	PERB		W5204	1002Z			47-30-11	ALL
	PERB		W5204	1003Z			47-30-11	ALL
	PERB		W5204	1004Z			47-30-11	ALL
D13840		**P006-00/ /**		**SOCKET - IVS POWER RELAY**				**ALL**
	A1		W0044	0971	20		44-21-10	ALL
	A2		W0044	0988	20		44-21-10	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13840	**P006-00/ /**		**SOCKET - IVS POWER RELAY (continued)**				**ALL**
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1		W0044	0967	20		44-21-10	ALL
D2		W0044	0968	20		44-21-10	ALL
D3	UNUSED						ALL
X1		W0044	0985	20		44-21-10	ALL
X2		W0044	0986	20		44-21-10	ALL
D13842	**J020-00/ /**		**RELAY SOCKET**				**ALL**
1	UNUSED						ALL
2		W0074	0206	20		47-30-11	ALL
3		W0074	0209	20		28-44-11	ALL
4	UNUSED						ALL
5		W0074	0207	20		47-30-11	ALL
6	UNUSED						ALL
7		W0074	0208	20		28-44-11	ALL
8	UNUSED						ALL
D13844	**MULTI/ /**		**CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5054	0001	22		26-16-22	ALL
5		W5054	0003	22		26-16-22	ALL
6	UNUSED						ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13844		**MULTI/ /**		**CONNECTOR (continued)**				**ALL**
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5054	0005	20		26-16-22	ALL
	11		W5054	0004	22		26-16-22	ALL
	12		W5054	0002	22		26-16-22	ALL
D13846		**MULTI/ /**		**CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5054	0001	22		26-16-22	ALL
	5		W5054	0003	22		26-16-22	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5054	0005	20		26-16-22	ALL
	11		W5054	0004	22		26-16-22	ALL
	12		W5054	0002	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13928	**537/197/L041**		**RCPT - NGS INTERFACE**				**ALL**
1		W5204	0009	20		47-30-11	ALL
2		W5204	1009	20		47-30-11	ALL
3		W5204	1007	20		47-30-11	ALL
4	UNUSED						ALL
5		W5204	1010	20		47-30-11	ALL
6	UNUSED						ALL
7		W5204	1008	20		47-30-11	ALL
8	UNUSED						ALL
9		W5204	0006	20		47-30-11	ALL
10		W5204	0011R	20		26-12-11	ALL
11		W5204	0007	20		47-30-11	ALL
12		W5204	0012R	20		26-12-11	ALL
13		W5204	0003	20		47-30-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5204	0001	20		47-30-11	ALL
17		W5204	0002	20		SPARE	ALL
18	UNUSED						ALL
19		W5204	0008	20		47-30-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W5204	0005	20		47-30-11	ALL
23	UNUSED						ALL
24		W5204	0004	20		47-30-11	ALL
PERB		W5204	1007Z			47-30-11	ALL
PERB		W5204	1008Z			47-30-11	ALL
PERB		W5204	1009Z			47-30-11	ALL
PERB		W5204	1010Z			47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13932		**536/164/L036**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W7202	2501B	20		47-30-11	ALL
	5	UNUSED						ALL
	6		W7202	1205	20		47-30-11	ALL
	7	UNUSED						ALL
	8		W7202	2507B	20		47-30-11	ALL
	9	UNUSED						ALL
	10		W7202	1001R	20		26-12-11	ALL
	11	UNUSED						ALL
	12		W7202	1002R	20		26-12-11	ALL
	13		W7202	2501R	20		47-30-11	ALL
	14	UNUSED						ALL
	15		W7202	1212	20		47-30-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W7202	2507R	20		47-30-11	ALL
	19		W7202	1201	20		47-30-11	ALL
	20		W7202	2506R	20		47-30-11	ALL
	21		W7202	2506B	20		47-30-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W7202	1210	20		47-30-11	ALL
	25	UNUSED						ALL
	26		W7202	2504B	20		47-30-11	ALL
	27		W7202	2504R	20		47-30-11	ALL
	28		W7202	2505B	20		47-30-11	ALL
	29		W7202	2505R	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13932	**536/164/L036**		**PLUG- (continued)**				**ALL**
30		W7202	2502B	20		47-30-11	ALL
31		W7202	2502R	20		47-30-11	ALL
32		W7202	2503B	20		47-30-11	ALL
33		W7202	2503R	20		47-30-11	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W7202	1211	20		47-30-11	ALL
37	UNUSED						ALL
38		W7202	1208	20		47-30-11	ALL
39		W7202	1204	20		47-30-11	ALL
PERB		W7202	1001Z			26-12-11	ALL
PERB		W7202	1002Z			26-12-11	ALL
PERB		W7202	1201Z			47-30-11	ALL
PERB		W7202	1204Z			47-30-11	ALL
PERB		W7202	1205Z			47-30-11	ALL
PERB		W7202	1208Z			47-30-11	ALL
PERB		W7202	1210Z			47-30-11	ALL
PERB		W7202	1211Z			47-30-11	ALL
PERB		W7202	1212Z			47-30-11	ALL
PERB		W7202	2501Z			47-30-11	ALL
PERB		W7202	2502Z			47-30-11	ALL
PERB		W7202	2503Z			47-30-11	ALL
PERB		W7202	2504Z			47-30-11	ALL
PERB		W7202	2505Z			47-30-11	ALL
PERB		W7202	2506Z			47-30-11	ALL
PERB		W7202	2507Z			47-30-11	ALL
D13934	**536/164/L036**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13934		**536/164/L036**		**PLUG- (continued)**				**ALL**
	3	UNUSED						ALL
	4		W5208	2002B	20		47-30-11	ALL
	5	UNUSED						ALL
	6		W5208	1517	20		47-30-11	ALL
	7	UNUSED						ALL
	8		W5208	1523	20		47-30-11	ALL
	9	UNUSED						ALL
	10		W5208	0011R	20		26-12-11	ALL
	11	UNUSED						ALL
	12		W5208	0012R	20		26-12-11	ALL
	13		W5208	2002R	20		47-30-11	ALL
	14	UNUSED						ALL
	15		W5208	1522	20		47-30-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W5208	0005	20		47-30-11	ALL
	19		W5208	1524	20		47-30-11	ALL
	20		W5208	2007R	20		47-30-11	ALL
	21		W5208	2007B	20		47-30-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W5208	1520	20		47-30-11	ALL
	25	UNUSED						ALL
	26		W5208	2005B	20		47-30-11	ALL
	27		W5208	2005R	20		47-30-11	ALL
	28		W5208	2006B	20		47-30-11	ALL
	29		W5208	2006R	20		47-30-11	ALL
	30		W5208	2003B	20		47-30-11	ALL
	31		W5208	2003R	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13934	**536/164/L036**		**PLUG- (continued)**				**ALL**
32		W5208	2004B	20		47-30-11	ALL
33		W5208	2004R	20		47-30-11	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W5208	1521	20		47-30-11	ALL
37	UNUSED						ALL
38		W5208	1519	20		47-30-11	ALL
39		W5208	1518	20		47-30-11	ALL
PERB		W5208	1517Z			47-30-11	ALL
PERB		W5208	1518Z			47-30-11	ALL
PERB		W5208	1519Z			47-30-11	ALL
PERB		W5208	1520Z			47-30-11	ALL
PERB		W5208	1521Z			47-30-11	ALL
PERB		W5208	1522Z			47-30-11	ALL
PERB		W5208	1523Z			47-30-11	ALL
PERB		W5208	1524Z			47-30-11	ALL
PERB		W5208	2002Z			47-30-11	ALL
PERB		W5208	2003Z			47-30-11	ALL
PERB		W5208	2004Z			47-30-11	ALL
PERB		W5208	2005Z			47-30-11	ALL
PERB		W5208	2006Z			47-30-11	ALL
PERB		W5208	2007Z			47-30-11	ALL
D13970	**536/166/R037**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5208	1501	20		47-30-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13970		**536/166/R037**		**PLUG- (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5208	2001R	20		47-30-11	ALL
	21	UNUSED						ALL
	22		W5208	4001B	20		47-30-11	ALL
	23	UNUSED						ALL
	24		W5208	4001G	20		47-30-11	ALL
	25	UNUSED						ALL
	26		W5208	4001R	20		47-30-11	ALL
	27	UNUSED						ALL
	28		W5208	4001Y	20		47-30-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W5208	3001Y	20		47-30-11	ALL
	33	UNUSED						ALL
	34		W5208	3001R	20		47-30-11	ALL
	35	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13970	**536/166/R037**		**PLUG- (continued)**				**ALL**
36		W5208	3001B	20		47-30-11	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W5208	2001B	20		47-30-11	ALL
PERB		W5208	1501Z			47-30-11	ALL
PERB		W5208	2001Z			47-30-11	ALL
PERB		W5208	3001Z			47-30-11	ALL
PERB		W5208	4001Z			47-30-11	ALL
D13972	**536/166/R037**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W7208	1001	20		47-30-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W7208	2001R	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13972		**536/166/R037**		**PLUG- (continued)**				**ALL**
	21	UNUSED						ALL
	22		W7208	4001B	20		47-30-11	ALL
	23	UNUSED						ALL
	24		W7208	4001G	20		47-30-11	ALL
	25	UNUSED						ALL
	26		W7208	4001R	20		47-30-11	ALL
	27	UNUSED						ALL
	28		W7208	4001Y	20		47-30-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W7208	3001Y	20		47-30-11	ALL
	33	UNUSED						ALL
	34		W7208	3001R	20		47-30-11	ALL
	35	UNUSED						ALL
	36		W7208	3001B	20		47-30-11	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39		W7208	2001B	20		47-30-11	ALL
	PERB		W7208	1001Z			47-30-11	ALL
	PERB		W7208	2001Z			47-30-11	ALL
	PERB		W7208	3001Z			47-30-11	ALL
	PERB		W7208	4001Z			47-30-11	ALL
D13993A		**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
	71		W5295	001CX			34-33-11	ALL
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13993A	**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13993A		**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13993A	**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
J07	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
=C71		W5295	001CO			34-33-11	ALL
D13993B	**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
71		W5293	001CX			34-33-11	ALL
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
B01	UNUSED						ALL
B02		W0212	2032R	24		34-33-11	ALL
B03		W0212	2032B	24		34-33-11	ALL
B04	UNUSED						ALL
B05		W0212	0099	24		34-33-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13993B		**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	C05		W0212	0099	24		34-33-11	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03		W0212	0057	24		34-33-11	ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02		W0212	0057	24		34-33-11	ALL
	F03	UNUSED						ALL
	F04		W0212	0007	22		34-33-11	ALL
	F05		W0212	0101	22		34-33-11	ALL
	F06		W0212	0102	22		34-33-11	ALL
	F07	UNUSED						ALL
	G01	UNUSED						ALL
	G02		W0212	2035R	22		34-33-11	ALL
	G03		W0212	2035B	22		34-33-11	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13993B	**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
G06	UNUSED						ALL
G07	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
J01	UNUSED						ALL
J02		W0212	0098	24		34-33-11	ALL
J03	UNUSED						ALL
J04		W0212	0098	24		34-33-11	ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06		W0212	0094	22		22-11-18	ALL
K07	UNUSED						ALL
=C71		W5293	001CO			34-33-11	ALL
DED		W0212	2032Z			34-33-11	ALL
PERG	1A	W0212	2035Z			34-33-11	ALL
D13993C	**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
1	UNUSED						ALL
2		W0212	0086	20		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D13993C		**E002-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	3		W0212	0085	20		34-33-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0212	0006	22		34-33-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL
D13995A		**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
	71		W5299	001CX			34-33-21	ALL
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995A	**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995A		**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	=C71		W5299	001CO			34-33-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995B	**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
71		W5297	001CX			34-33-21	ALL
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
B01	UNUSED						ALL
B02		W0313	2723R	24		34-33-21	ALL
B03		W0313	2723B	24		34-33-21	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0313	1707	24		34-33-21	ALL
B07	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05		W0313	1707	24		34-33-21	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995B		**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03		W0313	1706	24		34-33-21	ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02		W0313	1706	24		34-33-21	ALL
	F03	UNUSED						ALL
	F04		W0313	1710	22		34-33-21	ALL
	F05		W0313	1708	22		34-33-21	ALL
	F06		W0313	1709	22		34-33-21	ALL
	F07	UNUSED						ALL
	G01	UNUSED						ALL
	G02		W0313	2770R	24		34-33-21	ALL
	G03		W0313	2770B	24		34-33-21	ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	J01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995B	**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
J02		W0313	1705	24		34-33-21	ALL
J03	UNUSED						ALL
J04		W0313	1705	24		34-33-21	ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06		W0313	0501	22		22-11-18	ALL
K07	UNUSED						ALL
=C71		W5297	001CO			34-33-21	ALL
PERG	1A	W0313	2723Z			34-33-21	ALL
PERG	1A	W0313	2770Z			34-33-21	ALL
D13995C	**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1**				**ALL**
1	UNUSED						ALL
2		W0313	1704	20		34-33-21	ALL
3		W0313	1703	20		34-33-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0313	1702	22		34-33-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D13995C		**E003-01/ /**		**PLUG - XCVR-RADIO ALTM-1 (continued)**				**ALL**
	13	UNUSED						ALL
	=C12	UNUSED						ALL
	=C13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14045	**P002-03/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0001	1316	24		32-41-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W0003	1772	22		32-31-15	ALL
7		W0003	1774	22		32-31-15	ALL
8		W0003	1776	22		32-31-15	ALL
9	UNUSED						ALL
10		W0001	1314	22		32-41-11	ALL
11		W0003	1779	22		32-31-15	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0003	1761	22		32-31-15	ALL
19	UNUSED						ALL
20		W0003	1762	22		32-31-15	ALL
21		W0003	1763	22		32-31-15	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W0003	1038	24		31-31-15	ALL
26		W0003	1701	24		31-31-15	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W0001	1309	22		32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14045		**P002-03/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	30		W0001	1308	22		32-31-11	ALL
	S/R		W0001	1308Z			32-31-11	ALL
	S/R		W0001	1309Z			32-31-11	ALL
	S/R		W0001	1314Z			32-41-11	ALL
	S/R		W0001	1316Z			32-41-11	ALL
	S/R		W0003	1038Z			31-31-15	ALL
	S/R		W0003	1701Z			31-31-15	ALL
	S/R		W0003	1761Z			32-31-15	ALL
	S/R		W0003	1762Z			32-31-15	ALL
	S/R		W0003	1763Z			32-31-15	ALL
	S/R		W0003	1772Z			32-31-15	ALL
	S/R		W0003	1774Z			32-31-15	ALL
	S/R		W0003	1776Z			32-31-15	ALL
	S/R		W0003	1779Z			32-31-15	ALL
D14047		**679/196/L54**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W7122	2002R	20		32-31-15	ALL
	3		W7122	2001B	20		32-31-15	ALL
	4		W7122	0531	18		32-31-15	ALL
	5		W7122	2002B	20		32-31-15	ALL
	6		W7122	2001R	20		32-31-15	ALL
	7	UNUSED						ALL
	S/R		W7122	2001Z			32-31-15	ALL
	S/R		W7122	2002Z			32-31-15	ALL
D14049		**676/199/L053**		**PLUG**				**ALL**
	1		W7026	2501B	20		32-35-11	ALL
	2		W7026	2501R	20		32-35-11	ALL
	3		W7026	0519	20		32-35-11	ALL
	S/R		W7026	2501Z			32-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14057	**J023-0B/ /**		**SOCKET-EE COOL SMOKE DETECT PURGE MODE**				**ALL**
1	UNUSED						ALL
2		W0098	0124	22		26-19-11	ALL
3		W0098	0150	22		26-19-11	ALL
4		W0098	0149	22		26-19-11	ALL
5	UNUSED						ALL
6		W0098	0185	22		26-19-11	ALL
7		W0098	0154	22		26-19-11	ALL
8		W0098	0186	22		26-19-11	ALL
D14059	**J023-0B/ /**		**SOCKET-EE COOL SMK DETECT RECONFIGURATIO**				**ALL**
1		W0098	0175	24		21-51-11	ALL
2		W0098	0176	24		21-51-11	ALL
3	UNUSED						ALL
4		W0098	0182	24		21-25-11	ALL
5		W0098	0181	24		21-25-11	ALL
6		W0098	0166	22		26-19-11	ALL
7		W0098	0179	24		21-51-21	ALL
8		W0098	0180	24		21-51-21	ALL
9	UNUSED						ALL
10		W0098	0178	24		21-51-11	ALL
11		W0098	0177	24		21-51-11	ALL
12		W0098	0173	22		26-19-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
D14061	**J023-0B/ /**		**SOCKET-EE COOL SMK DETECT RECONF TIMEOUT**				**ALL**
A1		W0098	0174	22		26-19-11	ALL
A2		W0098	0170	22		26-19-11	ALL
A3	UNUSED						ALL
B1		W0098	0173	22		26-19-11	ALL
B2		W0098	0169	22		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14061		**J023-0B/ /**		**SOCKET-EE COOL SMK DETECT RECONF TIMEOUT (continued)**				**ALL**
	B3	UNUSED						ALL
	C1		W0098	0171	22		26-19-11	ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0098	0119	22		26-19-11	ALL
	X2		W0098	0172	22		26-19-11	ALL
D14063		**J023-0B/ /**		**SOCKET-EE COOL SMOKE DETECT PURGE SETUP**				**ALL**
	1		W0098	0150	22		26-19-11	ALL
	2	UNUSED						ALL
	3		W0098	0152	22		26-19-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0098	0151	22		26-19-11	ALL
	7		W0098	0153	22		26-19-11	ALL
	8	UNUSED						ALL
D14065		**J023-0B/ /**		**SOCKET-EE COOL SMOKE DETECT PURGE ENABLE**				**ALL**
	1	UNUSED						ALL
	2		W0098	0157	22		26-19-11	ALL
	3		W0098	0155	22		26-19-11	ALL
	4		W0098	0154	22		26-19-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0098	0156	22		26-19-11	ALL
	8	UNUSED						ALL
D14067		**J023-0B/ /**		**SOCKET-EE COOL SMOKE DETECT TEST RELAY**				**ALL**
	1		W0098	0163	22		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14067	**J023-0B/ /**		**SOCKET-EE COOL SMOKE DETECT TEST RELAY (continued)**				**ALL**
2		W0098	0160	22		26-19-11	ALL
3	UNUSED						ALL
4		W0098	0131	22		26-19-11	ALL
5		W0098	0164	22		26-19-11	ALL
6		W0098	0161	22		26-19-11	ALL
7		W0098	0165	22		26-19-11	ALL
8		W0098	0132	22		26-19-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0098	0134	22		26-19-11	ALL
13		W0098	0159	22		26-19-11	ALL
14	UNUSED						ALL
D14069A	**E004-02/ /**		**PLUG- SDU**				**ALL**
71	UNUSED						ALL
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069A		**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	G01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069A	**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
=C71	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069B		**E004-02/ /**		**PLUG- SDU**				**ALL**
	A01		W0421	2510R	24		34-61-23	ALL
	A02	UNUSED						ALL
	A03		W0421	2501R	24		23-27-37	ALL
	A04		W0421	2503R	24		23-15-12	ALL
	A05		W0421	2504R	24		23-15-13	ALL
	A06	UNUSED						ALL
	A07		W0421	2509R	24		34-53-11	ALL
	A08	UNUSED						ALL
	A09		W0421	2507R	22		31-32-15	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	B01		W0421	2510B	24		34-61-23	ALL
	B02	UNUSED						ALL
	B03		W0421	2501B	24		23-27-37	ALL
	B04		W0421	2503B	24		23-15-12	ALL
	B05		W0421	2504B	24		23-15-13	ALL
	B06	UNUSED						ALL
	B07		W0421	2509B	24		34-53-11	ALL
	B08	UNUSED						ALL
	B09		W0421	2507B	22		31-32-15	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	C01		W0421	0012	24		23-15-13	ALL
	C02		W0421	0014	24		23-15-15	ALL
	C03		W0421	0010	24		23-15-13	ALL
	C04		W0421	0009	24		23-15-12	ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069B	**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
D01		W0421	0018	24		23-15-15	ALL
D02		W0421	0019	24		23-15-15	ALL
D03		W0421	4001R	24		23-15-15	ALL
D04		W0421	4001B	24		23-15-15	ALL
D05		W0421	4001Y	24		23-15-15	ALL
D06		W0421	4001G	24		23-15-15	ALL
D07		W0421	0017	24		23-15-15	ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08		W0421	0016	24		23-15-15	ALL
E09	UNUSED						ALL
E10	UNUSED						ALL
E11	UNUSED						ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069B		**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	H01		W0421	0011	24		23-15-13	ALL
	H02		W0421	0015	24		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069B	**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
H03		W0421	0013	24		23-15-13	ALL
H04		W0421	0008	24		23-15-12	ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
J01		W0421	2511R	24		34-61-23	ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04		W0421	2502R	24		23-15-12	ALL
J05		W0421	2505R	24		23-15-13	ALL
J06	UNUSED						ALL
J07		W0421	2512R	24		23-15-15	ALL
J08	UNUSED						ALL
J09		W0421	2506R	24		23-15-15	ALL
J10		W0421	2508R	24		23-15-15	ALL
J11	UNUSED						ALL
K01		W0421	2511B	24		34-61-23	ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0421	2502B	24		23-15-12	ALL
K05		W0421	2505B	24		23-15-13	ALL
K06	UNUSED						ALL
K07		W0421	2512B	24		23-15-15	ALL
K08	UNUSED						ALL
K09		W0421	2506B	24		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069B		**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
	K10		W0421	2508B	24		23-15-15	ALL
	K11	UNUSED						ALL
	=C1T	UNUSED						ALL
	=C2T	UNUSED						ALL
	DED		W0421	2502Z			23-15-12	ALL
	DED		W0421	2503Z			23-15-12	ALL
	DED		W0421	2504Z			23-15-13	ALL
	DED		W0421	2505Z			23-15-13	ALL
	1T-1	UNUSED						ALL
	1T-2	UNUSED						ALL
	1T-3	UNUSED						ALL
	1T-4	UNUSED						ALL
	2T-1	UNUSED						ALL
	2T-2	UNUSED						ALL
	2T-3	UNUSED						ALL
	2T-4	UNUSED						ALL
	PERG	1A	W0421	2501Z			23-27-37	ALL
	PERG	1A	W0421	2506Z			23-15-15	ALL
	PERG	1A	W0421	2507Z			31-32-15	ALL
	PERG	1A	W0421	2508Z			23-15-15	ALL
	PERG	1A	W0421	2509Z			34-53-11	ALL
	PERG	1A	W0421	2510Z			34-61-23	ALL
	PERG	1A	W0421	2511Z			34-61-23	ALL
	PERG	1A	W0421	2512Z			23-15-15	ALL
	PERG	1A	W0421	4001Z			23-15-15	ALL
D14069C		**E004-02/ /**		**PLUG- SDU**				**ALL**
	1	UNUSED						ALL
	2		W0421	0001	22		23-15-11	ALL
	3		W0421	0003	20		23-15-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14069C	**E004-02/ /**		**PLUG- SDU (continued)**				**ALL**
4		W0421	0002	20		23-15-11	ALL
5	UNUSED						ALL
6		W0421	001CX			23-15-12	ALL
7		W0421	002CX			23-15-12	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
=C6		W0421	001CO			23-15-12	ALL
=C7		W0421	002CO			23-15-12	ALL
D14071	**354/174/R36**		**PLUG**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5602	4001B	24		23-15-15	ALL
6		W5602	4001Y	24		23-15-15	ALL
7	UNUSED						ALL
8		W5602	0018	24		23-15-15	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5602	4001R	24		23-15-15	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W5602	4001G	24		23-15-15	ALL
15		W5602	0019	24		23-15-15	ALL
PERB		W5602	4001Z			23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14073		**450/305/L005**		**PLUG-**				**ALL**
	=A1		W3110	001CX			23-15-12	ALL
	=C1		W3110	001CO			23-15-12	ALL
D14075		**450/305/L005**		**PLUG-**				**ALL**
	=A1		W3120	001CX			23-15-12	ALL
	=C1		W3120	001CO			23-15-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14107		**J004-00/ /**		**RELAY SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2		W0094	0261	20		44-21-10	ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0094	0261	20		44-21-10	ALL
	X2	UNUSED						ALL
D14112		**723/166/R010**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0063	1002	20		47-30-11	ALL
	2		W0063	1003	20		47-30-11	ALL
	3		W0063	1004	20		47-30-11	ALL
	4	UNUSED						ALL
	5		W0063	1001	20		47-30-11	ALL
	PERB		W0063	1001Z			47-30-11	ALL
	PERB		W0063	1002Z			47-30-11	ALL
	PERB		W0063	1003Z			47-30-11	ALL
	PERB		W0063	1004Z			47-30-11	ALL
D14114		**P007-00/ /**		**RCPT W/ SOCKET CONTACTS (170362-3)**				**ALL**
	1		W0104	1002	20		31-52-11	ALL
	2		W0104	1003	20		31-52-11	ALL
	3		W0104	1001	20		31-52-11	ALL
	4		W0104	1004	20		31-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14114		**P007-00/ /**		**RCPT W/ SOCKET CONTACTS (170362-3) (continued)**				**ALL**
	DED		W0104	1001Z			31-52-11	ALL
	DED		W0104	1002Z			31-52-11	ALL
	DED		W0104	1003Z			31-52-11	ALL
	DED		W0104	1004Z			31-52-11	ALL
D14116		**P007-00/ /**		**RCPT W/ SOCKET CONTACTS (170362-3)**				**ALL**
	1		W0204	1002	20		31-52-11	ALL
	2		W0204	1003	20		31-52-11	ALL
	3		W0204	1001	20		31-52-11	ALL
	4		W0204	1004	20		31-52-11	ALL
	DED		W0204	1001Z			31-52-11	ALL
	DED		W0204	1002Z			31-52-11	ALL
	DED		W0204	1003Z			31-52-11	ALL
	DED		W0204	1004Z			31-52-11	ALL
D14117		**P061-00/ /**		**PLUG**				**ALL**
	A-1		W0041	4001R	24		46-13-11	ALL
	A-2		W0041	4001Y	24		46-13-11	ALL
	A-3		W0041	4001B	24		46-13-11	ALL
	A-4		W0041	4001G	24		46-13-11	ALL
	B-1		W0041	4002R	24		46-13-11	ALL
	B-2		W0041	4002Y	24		46-13-11	ALL
	B-3		W0041	4002B	24		46-13-11	ALL
	B-4		W0041	4002G	24		46-13-11	ALL
	=CA		W0041	4001Z			46-13-11	ALL
	=CB		W0041	4002Z			46-13-11	ALL
D14118		**P007-00/ /**		**RCPT W/ SOCKET CONTACTS (170362-3)**				**ALL**
	1		W0104	5521R	20		33-18-51	ALL
	2		W0104	5516R	22		26-11-21	ALL
	3		W0104	5515R	22		26-11-21	ALL
	4		W0104	5514R	22		26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14120	**P007-00/ /**		**RCPT W/ SOCKET CONTACTS (170362-3)**				**ALL**
1		W0204	5521R	20		33-18-51	ALL
2		W0204	5516R	22		26-11-21	ALL
3		W0204	5515R	22		26-11-21	ALL
4		W0204	5514R	22		26-11-21	ALL
D14122	**1082/266/R18**		**PLUG-**				**ALL**
1		W4134	1016	20		27-33-11	ALL
2		W4134	1015	20		27-33-11	ALL
3	UNUSED						ALL
4		W4134	1009	20		27-31-37	ALL
5	UNUSED						ALL
6		W4134	1017	20		27-33-11	ALL
7		W4134	1012	20		27-31-37	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W4134	1009Z			27-31-37	ALL
S/R		W4134	1012Z			27-31-37	ALL
S/R		W4134	1015Z			27-33-11	ALL
S/R		W4134	1016Z			27-33-11	ALL
S/R		W4134	1017Z			27-33-11	ALL
D14139	**J011-00/ /**		**SOCKET-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W0096	0075	22		21-27-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14139		**J011-00/ /**		**SOCKET- (continued)**				**ALL**
	7		W0096	0074	22		21-27-51	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0096	0076	22		21-27-51	ALL
	13	UNUSED						ALL
	14		W0096	0084	22		21-27-51	ALL
D14141		**J011-00/ /**		**SOCKET-**				**ALL**
	1	UNUSED						ALL
	2		W0096	0077	22		21-27-51	ALL
	3		W0096	0088	22		21-27-51	ALL
	4	UNUSED						ALL
	5		W0096	0076	22		21-27-51	ALL
	6	UNUSED						ALL
	7		W0096	0078	22		21-27-51	ALL
	8	UNUSED						ALL
D14143		**J011-00/ /**		**SOCKET-FAN CONTROL**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1		W0096	0083	22		21-27-51	ALL
	B2		W0096	0055	22		21-27-51	ALL
	B3	UNUSED						ALL
	C1		W0096	0082	22		21-27-51	ALL
	C2		W0096	0054	22		21-27-51	ALL
	C3	UNUSED						ALL
	D1		W0096	0081	22		21-27-51	ALL
	D2		W0096	0053	22		21-27-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14143	**J011-00/ /**		**SOCKET-FAN CONTROL (continued)**				**ALL**
D3	UNUSED						ALL
X1		W0096	0085	22		21-27-51	ALL
X2		W0096	0074	22		21-27-51	ALL
D14145	**8 950/191/R034**		**PLUG-**				**ALL**
1		W5434	0001	20		21-27-51	ALL
2		W5434	0002	20		21-27-51	ALL
3		W5434	0003	20		21-27-51	ALL
4	UNUSED						ALL
5		W5434	0004	20		21-27-51	ALL
6		W5434	0005	20		21-27-51	ALL
7		W5434	0006	20		21-27-51	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14145		**8 950/191/R034**		**PLUG- (continued)**				**ALL**
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D14151		**J00024/ /**		**SOCKET-RELAY**				**ALL**
	1	UNUSED						ALL
	2		W0080	5631	22		21-43-21	ALL
	3		W0080	5635	24		21-43-21	ALL
	4	UNUSED						ALL
	5		W0080	5632	22		21-43-21	ALL
	6	UNUSED						ALL
	7		W0080	5629	24		21-43-21	ALL
	8	UNUSED						ALL
D14156		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	6106	20		47-30-11	ALL
	A2		W0080	6105	20		47-30-11	ALL
	A3		W0080	6104	20		47-30-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0080	6107	20		47-30-11	ALL
	X2		W0080	6108	20		47-30-11	ALL
D14169		**E006-02/ /**		**PLUG-VOICE RECORDER**				**ALL**
	1	UNUSED						ALL
	2		W0625	0002	20		23-71-01	ALL
	3		W0625	0001	20		23-71-01	ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14169	**E006-02/ /**		**PLUG-VOICE RECORDER (continued)**				**ALL**
5		W0625	2006B	24		23-71-01	ALL
6		W0625	2006R	24		23-71-01	ALL
7		W0625	0007	24		23-71-01	ALL
8		W0625	0007	24		23-71-01	ALL
9	VP	W0625	0030	22		23-71-01	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0625	0012	24		23-71-01	ALL
13		W0625	0013	24		23-71-01	ALL
14		W0625	0014	24		23-71-01	ALL
15		W0625	2010R	24		23-71-01	ALL
16		W0625	2010B	24		23-71-01	ALL
17		W0625	0006	20		23-71-01	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0625	0034	24		23-71-01	ALL
24	UNUSED						ALL
25		W0625	2001B	24		31-65-15	ALL
26		W0625	2001R	24		31-65-15	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W0625	2002B	24		23-51-51	ALL
31		W0625	0036	22		23-71-01	ALL
32		W0625	2002R	24		23-51-51	ALL
33		W0625	2008B	24		23-27-35	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14169		**E006-02/ /**		**PLUG-VOICE RECORDER (continued)**				**ALL**
	34		W0625	2008R	24		23-27-35	ALL
	35		W0625	2003B	24		23-51-51	ALL
	36	UNUSED						ALL
	37		W0625	2003R	24		23-51-51	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41		W0625	2004B	24		23-51-51	ALL
	42	UNUSED						ALL
	43		W0625	2004R	24		23-51-51	ALL
	44	UNUSED						ALL
	45		W0625	2005B	24		23-71-01	ALL
	46	UNUSED						ALL
	47		W0625	2005R	24		23-71-01	ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W0625	0003	22		23-71-01	ALL
	56		W0625	0037	20		23-71-01	ALL
	57		W0625	0004	22		23-71-01	ALL
			W0625	0005	20		23-71-01	ALL
			W0625	0055	20		23-27-35	ALL
			W0625	0060	20		23-71-01	ALL
			W0625	2001Z			31-65-15	ALL
			W0625	2002Z			23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14169	**E006-02/ /**		**PLUG-VOICE RECORDER (continued)**				**ALL**
		W0625	2003Z			23-51-51	ALL
		W0625	2004Z			23-51-51	ALL
		W0625	2005Z			23-71-01	ALL
		W0625	2008Z			23-27-35	ALL
		W0625	2010Z			23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14200		**577/155/L044**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B	UNUSED						ALL
	C		W7202	0014	22		47-30-11	ALL
	D		W7202	1212	20		47-30-11	ALL
	E		W7202	1211	20		47-30-11	ALL
	F		W7202	1209	20		47-30-11	ALL
	G		W7202	1210	20		47-30-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERB		W7202	1209Z			47-30-11	ALL
	PERB		W7202	1210Z			47-30-11	ALL
	PERB		W7202	1211Z			47-30-11	ALL
	PERB		W7202	1212Z			47-30-11	ALL
D14284		**196/208/0.46**		**PLUG-CAB PRESS SW**				**ALL**
	A		W5503	0018	22		21-33-11	ALL
	B		W5503	0017	20		21-33-11	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14360	**716/194/R055**		**CONNECTOR PLUG - SOCKET**				**ALL**
A		W8124	0512	20		27-23-11	ALL
B	UNUSED						ALL
C		W8124	0513	20		27-23-11	ALL
D		W8124	0514	20		21-51-14	ALL
E	UNUSED						ALL
F		W8124	0515	20		21-51-14	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M	UNUSED						ALL
N		W8124	0516	20		27-31-11	ALL
P	UNUSED						ALL
R		W8124	0517	20		27-31-11	ALL
S		W8124	0518	20		29-25-11	ALL
T		W8124	0519	20		29-25-11	ALL
U		W8124	0520	20		29-25-11	ALL
D14362	**714/195/R057**		**CONNECTOR PLUG - SOCKET**				**ALL**
A		W8226	0504	20		27-53-12	ALL
B	UNUSED						ALL
C		W8226	0505	20		27-53-12	ALL
D		W8226	0506	20		22-23-12	ALL
E		W8226	0507	20		22-23-12	ALL
F	UNUSED						ALL
G		W8226	0508	20		33-25-11	ALL
H		W8226	0509	20		33-25-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14362		**714/195/R057**		**CONNECTOR PLUG - SOCKET (continued)**				**ALL**
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	U	UNUSED						ALL
D14364		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL)**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3058	0174	20		23-42-14	ALL
	11		W3058	0175	20		23-42-14	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3058	2218R	22		24-23-51	ALL
	19		W3058	2218B	22		24-23-51	ALL
	20		W3058	0020	22		24-23-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14364	**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
21		W3058	0021	20		24-23-51	ALL
22		W3058	0056	22		33-26-11	ALL
23		W3058	0064	22		33-26-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14364		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D14366		**305/290/L015**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL)**				**ALL**
	1		W3307	0097	20		23-31-01	ALL
	2		W3307	0004	20		23-31-01	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W3307	0021	20		44-21-10	ALL
	12		W3307	0011	20		44-21-10	ALL
	13		W3307	0020	20		44-21-10	ALL
	14		W3307	3507B	24		23-42-12	ALL
	15		W3307	3507Y	24		23-42-12	ALL
	16		W3307	3507R	24		23-42-12	ALL
	17		W3307	2509R	24		23-31-01	ALL
	18		W3307	2509B	24		23-31-01	ALL
	19		W3307	0005	24		23-31-01	ALL
	20		W3307	2501R	24		23-31-01	ALL
	21		W3307	2501B	24		23-31-01	ALL
	22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14366	**305/290/L015**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
23		W3307	2507R	24		23-31-01	ALL
24		W3307	2507B	24		23-31-01	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40		W3307	0008	24		SPARE	ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14366		**305/290/L015**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	DED		W3307	2501Z			23-31-01	ALL
	DED		W3307	2507Z			23-31-01	ALL
	DED		W3307	2509Z			23-31-01	ALL
	DED		W3307	3507Z			23-42-12	ALL
D14368		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL)**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14368	**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W3058	0139	22		23-42-11	ALL
40	UNUSED						ALL
41		W3058	0141	22		23-42-11	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44		W3058	0144	22		23-42-11	ALL
45	UNUSED						ALL
46		W3058	0146	22		23-42-11	ALL
47		W3058	0147	22		23-42-11	ALL
48		W3058	0148	22		23-42-11	ALL
49		W3058	0149	22		23-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14368		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANT CTRL PNL) (continued)**				**ALL**
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54		W3058	0154	22		23-42-11	ALL
	55	UNUSED						ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61		W3058	0161	22		23-42-11	ALL
D14370		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANTS CTRL PNL)**				**ALL**
	1		W3058	0171	22		23-42-14	ALL
	2		W3058	0172	20		23-42-14	ALL
	3		W3058	0173	20		23-42-14	ALL
	4		W3058	2007W	24		33-24-21	ALL
	5		W3058	2007B	24		33-24-21	ALL
	6		W3058	2007Z			33-24-21	ALL
	7		W3058	2008R	24		33-24-21	ALL
	8		W3058	2008B	24		33-24-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W3058	2005W	24		33-22-41	ALL
	12		W3058	2005B	24		33-22-41	ALL
	13		W3058	2005Z			33-22-41	ALL
	14		W3058	2006R	24		33-22-41	ALL
	15		W3058	2006B	24		33-22-41	ALL
	16		W3058	2003W	24		33-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14370	**305/290/L014**		**PLUG-LAV A (FWD ATTENDANTS CTRL PNL) (continued)**				**ALL**
17		W3058	2003B	24		33-22-31	ALL
18		W3058	2003Z			33-22-31	ALL
19		W3058	2004R	24		33-22-31	ALL
20		W3058	2004B	24		33-22-31	ALL
21		W3058	2001W	24		33-21-12	ALL
22		W3058	2001B	24		33-21-12	ALL
23		W3058	2001Z			33-21-12	ALL
24		W3058	2002R	24		33-21-12	ALL
25		W3058	2002B	24		33-21-12	ALL
26		W3058	2019W	24		23-42-14	ALL
27		W3058	2019B	24		23-42-14	ALL
28		W3058	2019Z			23-42-14	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W3058	2021R	24		23-42-14	ALL
32		W3058	2021B	24		23-42-14	ALL
33		W3058	2022R	24		23-42-14	ALL
34		W3058	2022B	24		23-42-14	ALL
35		W3058	FRAA			23-42-14	ALL
36		W3058	0189	24		23-42-14	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14370		**305/290/L014**		**PLUG-LAV A (FWD ATTENDANTS CTRL PNL) (continued)**				**ALL**
	46	UNUSED						ALL
	47		W3058	0245	22		23-42-14	ALL
	48		W3058	0537	20		44-35-20	ALL
	49	UNUSED						ALL
	50		W3058	0246	22		23-42-14	ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
			W3058	2021Z			23-42-14	ALL
			W3058	2022Z			23-42-14	ALL
			W3058	FRAA			23-42-14	ALL
D14372		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL)**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3058	0182	20		23-42-15	ALL
	11		W3058	0183	20		23-42-15	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14372	**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W3058	0069	22		33-26-11	ALL
23		W3058	0067	22		33-26-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28		W3058	0428	22		33-51-11	ALL
29		W3058	0429	22		33-51-11	ALL
30		W3058	0430	22		33-51-11	ALL
31		W3058	0188	22		33-51-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14372		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D14374		**938/292/L019**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL)**				**ALL**
	1		W3311	0034	20		23-31-01	ALL
	2		W3311	0035	20		23-31-01	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W3311	3510B	24		23-42-12	ALL
	15		W3311	3510Y	24		23-42-12	ALL
	16		W3311	3510R	24		23-42-12	ALL
	17		W3311	2004R	24		23-31-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14374	**938/292/L019**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
18		W3311	2004B	24		23-31-01	ALL
19		W3311	0002	24		23-31-01	ALL
20		W3311	2001R	24		23-31-01	ALL
21		W3311	2001B	24		23-31-01	ALL
22		W3311	0022	24		23-31-01	ALL
23		W3311	2003R	24		23-31-01	ALL
24		W3311	2003B	24		23-31-01	ALL
25	UNUSED						ALL
26		W3311	3502R	24		23-42-12	ALL
27		W3311	3502Y	24		23-42-12	ALL
28		W3311	3502B	24		23-42-12	ALL
29		W3311	0006	22		23-42-12	ALL
30		W3311	0007	22		23-42-12	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14374		**938/292/L019**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	DED		W3311	2001Z			23-31-01	ALL
	DED		W3311	2003Z			23-31-01	ALL
	DED		W3311	2004Z			23-31-01	ALL
	DED		W3311	3510Z			23-42-12	ALL
			W3311	0005	20		23-42-12	ALL
			W3311	3502Z			23-42-12	ALL
D14376		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL)**				**ALL**
	1		W3058	0240	22		38-41-11	ALL
	2		W3058	0243	22		38-41-11	ALL
	3		W3058	0234	22		38-41-11	ALL
	4		W3058	0233	20		38-32-13	ALL
	5		W3058	0228	22		38-32-13	ALL
	6		W3058	0229	22		38-32-13	ALL
	7	UNUSED						ALL
	8		W3058	0227	20		38-32-13	ALL
	9		W3058	0231	20		38-32-13	ALL
	10	UNUSED						ALL
	11		W3058	0232	22		38-32-13	ALL
	12		W3058	0230	20		38-32-13	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14376	**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W3058	0239	22		23-42-11	ALL
40	UNUSED						ALL
41		W3058	0241	22		23-42-11	ALL
42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14376		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
	43	UNUSED						ALL
	44		W3058	0244	22		23-42-11	ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W3058	0248	22		23-42-11	ALL
	49		W3058	0149	22		23-42-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54		W3058	0154	22		23-42-11	ALL
	55	UNUSED						ALL
	56		W3058	0255	20		23-42-11	ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59	UNUSED						ALL
	60	UNUSED						ALL
	61		W3058	0261	22		23-42-11	ALL
D14378		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL)**				**ALL**
	1		W3058	0177	22		23-42-15	ALL
	2		W3058	0180	20		23-42-15	ALL
	3		W3058	0181	20		23-42-15	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14378	**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W3058	2019W	24		23-42-14	ALL
27		W3058	2019B	24		23-42-14	ALL
28		W3058	2019Z			23-42-14	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14378		**941/292/L020**		**PLUG-LAV D (AFT ATTENDANT CTRL PNL) (continued)**				**ALL**
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W3058	0249	22		23-42-15	ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50		W3058	0266	22		23-42-15	ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D14386		**500I+14/171/L060**		**PLUG-**				**ALL**
	1		W5104	1006	24		21-51-14	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5104	1021	20		21-51-14	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5104	1009	24		21-51-14	ALL
	9		W5104	1007	24		21-51-14	ALL
	10		W5104	1008	24		21-51-14	ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14386	**500I+14/171/L060**		**PLUG- (continued)**				**ALL**
12		W5104	1010	24		21-51-14	ALL
13		W5104	1012	24		21-51-14	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5104	0333	20		21-51-14	ALL
17		W5104	2003B	20		21-51-14	ALL
18		W5104	2003R	20		21-51-14	ALL
19		W5104	1005	24		21-51-14	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W5104	0339	24		21-51-14	ALL
23		W5104	0339	24		21-51-14	ALL
24		W5104	0332	20		21-51-14	ALL
PERB		W5104	1005Z			21-51-14	ALL
PERB		W5104	1006Z			21-51-14	ALL
PERB		W5104	1007Z			21-51-14	ALL
PERB		W5104	1008Z			21-51-14	ALL
PERB		W5104	1009Z			21-51-14	ALL
PERB		W5104	1010Z			21-51-14	ALL
PERB		W5104	1012Z			21-51-14	ALL
PERB		W5104	1021Z			21-51-14	ALL
PERB		W5104	2003Z			21-51-14	ALL
D14388	**500I+17/171/L061**		**PLUG-**				**ALL**
1		W5104	2004B	22		21-51-14	ALL
2		W5104	2004W	22		21-51-14	ALL
3		W5104	1002	22		21-51-14	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14388		**500I+17/171/L061**		**PLUG- (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	PERB		W5104	1002Z			21-51-14	ALL
	PERB		W5104	2004Z			21-51-14	ALL
D14390		**657/152/L32**		**RECP-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5104	1020	20		21-51-14	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W5104	0334	20		21-51-14	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5104	0335	24		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14390	**657/152/L32**		**RECP- (continued)**				**ALL**
21		W5104	0336	24		21-51-14	ALL
22		W5104	0337	24		21-51-14	ALL
23		W5104	0338	24		21-51-14	ALL
24		W5104	0331	20		21-51-14	ALL
PERB		W5104	1020Z			21-51-14	ALL
D14392	**656/151/L32**		**PLUG-**				**ALL**
1		W5104	2004B	22		21-51-14	ALL
2		W5104	2004W	22		21-51-14	ALL
3		W5104	1002	22		21-51-14	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
PERB		W5104	1002Z			21-51-14	ALL
PERB		W5104	2004Z			21-51-14	ALL
D14394	**500I+15/172/R059**		**RECP-**				**ALL**
1		W6230	1006	24		21-51-24	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W6230	1021	20		21-51-24	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6230	1009	24		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14394		**500I+15/172/R059**		**RECP- (continued)**				**ALL**
	9		W6230	1007	24		21-51-24	ALL
	10		W6230	1008	24		21-51-24	ALL
	11	UNUSED						ALL
	12		W6230	1010	24		21-51-24	ALL
	13		W6230	1012	24		21-51-24	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W6230	0333	20		21-51-24	ALL
	17		W6230	2003B	20		21-51-24	ALL
	18		W6230	2003R	20		21-51-24	ALL
	19		W6230	1005	24		21-51-24	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W6230	0339	24		21-51-24	ALL
	23		W6230	0339	24		21-51-24	ALL
	24		W6230	0332	20		21-51-24	ALL
	PERB		W6230	1005Z			21-51-24	ALL
	PERB		W6230	1006Z			21-51-24	ALL
	PERB		W6230	1007Z			21-51-24	ALL
	PERB		W6230	1008Z			21-51-24	ALL
	PERB		W6230	1009Z			21-51-24	ALL
	PERB		W6230	1010Z			21-51-24	ALL
	PERB		W6230	1012Z			21-51-24	ALL
	PERB		W6230	1021Z			21-51-24	ALL
	PERB		W6230	2003Z			21-51-24	ALL
D14396		**500I+18/172/R60**		**PLUG-**				**ALL**
	1		W6230	2004B	22		21-51-24	ALL
	2		W6230	2004W	22		21-51-24	ALL
	3		W6230	1002	20		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14396		**500I+18/172/R60**		**PLUG- (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	PERB		W6230	1002Z			21-51-24	ALL
	PERB		W6230	2004Z			21-51-24	ALL
D14398		**658/148/R33**		**RECP-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W6230	1020	20		21-51-24	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W6230	0334	20		21-51-24	ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14398		**658/148/R33**		**RECP- (continued)**				**ALL**
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W6230	0335	24		21-51-24	ALL
	21		W6230	0336	24		21-51-24	ALL
	22		W6230	0337	24		21-51-24	ALL
	23		W6230	0338	24		21-51-24	ALL
	24		W6230	0331	20		21-51-24	ALL
	PERB		W6230	1020Z			21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14400	**656/147/R33**		**PLUG-**				**ALL**
1		W6230	2004B	22		21-51-24	ALL
2		W6230	2004W	22		21-51-24	ALL
3		W6230	1002	20		21-51-24	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
PERB		W6230	1002Z			21-51-24	ALL
PERB		W6230	2004Z			21-51-24	ALL
D14407J	**931/298/L013**		**RCPT**				**ALL**
1		W3311	2008R	24		23-31-01	ALL
2		W3311	2008B	24		23-31-01	ALL
3		W3311	2008Z			23-31-01	ALL
4		W3311	3501Y	24		23-42-12	ALL
5		W3311	3501R	24		23-42-12	ALL
6		W3311	3501B	24		23-42-12	ALL
7		W3311	3501Z			23-42-12	ALL
D14407P	**931/298/L013**		**PLUG**				**ALL**
1		W3377	2015R	24		23-31-01	ALL
2		W3377	2015B	24		23-31-01	ALL
3		W3377	2015Z			23-31-01	ALL
4		W3377	3501Y	24		23-42-12	ALL
5		W3377	3501R	24		23-42-12	ALL
6		W3377	3501B	24		23-42-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14407P		**931/298/L013**		**PLUG (continued)**				**ALL**
	7		W3377	3501Z			23-42-12	ALL
D14409J		**388/292/L021**		**RCPT**				**ALL**
	1		W3311	2011R	24		23-31-01	ALL
	2		W3311	2011B	24		23-31-01	ALL
	3		W3311	2011Z			23-31-01	ALL
	4		W3311	3517Y	24		23-42-12	ALL
	5		W3311	3517R	24		23-42-12	ALL
	6		W3311	3517B	24		23-42-12	ALL
	7		W3311	3517Z			23-42-12	ALL
D14409P		**388/290/L021**		**PLUG**				**ALL**
	1		W3377	2015R	24		23-31-01	ALL
	2		W3377	2015B	24		23-31-01	ALL
	3		W3377	2015Z			23-31-01	ALL
	4		W3377	3501Y	24		23-42-12	ALL
	5		W3377	3501R	24		23-42-12	ALL
	6		W3377	3501B	24		23-42-12	ALL
	7		W3377	3501Z			23-42-12	ALL
D14460		**461/296/L027**		**PLUG-**				**ALL**
	A		W3166	0076	18		33-22-41	ALL
	B		W3166	0074	18		33-22-41	ALL
	C		W3166	0075	18		33-22-41	ALL
D14464		**500+18/296/L027**		**PLUG-**				**ALL**
	A		W3166	0086	18		33-22-41	ALL
	B		W3166	0084	18		33-22-41	ALL
	C		W3166	0085	18		33-22-41	ALL
D14468		**768/296/L027**		**PLUG-**				**ALL**
	A		W3166	0176	18		33-22-41	ALL
	B		W3166	0174	18		33-22-41	ALL
	C		W3166	0175	18		33-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14474	**319/292/L002**		**RCPT-**				**ALL**
1		W0156	2001W	24		33-24-21	ALL
2		W0156	2001B	24		33-24-21	ALL
3		W0156	2002R	24		33-24-21	ALL
4		W0156	2002B	24		33-24-21	ALL
5		W0156	2001Z			33-24-21	ALL
D14478	**356/290/L011**		**PLUG-**				**ALL**
1		W0156	2001W	24		33-24-21	ALL
2		W0156	2001B	24		33-24-21	ALL
3		W0156	2002R	24		33-24-21	ALL
4		W0156	2002B	24		33-24-21	ALL
5		W0156	2001Z			33-24-21	ALL
D14492	**819/296/L027**		**PLUG-**				**ALL**
A		W3166	0506	18		33-22-22	ALL
B		W3166	0504	18		33-22-22	ALL
C		W3166	0505	18		33-22-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14540		**914/290/R010**		**RCPT-**				**ALL**
	1		W0158	2001W	24		33-24-22	ALL
	2		W0158	2001B	24		33-24-22	ALL
	3		W0158	2002R	24		33-24-22	ALL
	4		W0158	2002B	24		33-24-22	ALL
	5		W0158	2001Z			33-24-22	ALL
D14544		**931/290/L015**		**PLUG-**				**ALL**
	1		W0158	2001W	24		33-24-22	ALL
	2		W0158	2001B	24		33-24-22	ALL
	3		W0158	2002R	24		33-24-22	ALL
	4		W0158	2002B	24		33-24-22	ALL
	5		W0158	2001Z			33-24-22	ALL
D14546		**1122/291/R010**		**RCPT-**				**ALL**
	A	UNUSED						ALL
	B		W0158	0005	18		33-24-22	ALL
	C	UNUSED						ALL
D14550		**1121/291/R010**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B		W0160	0004	18		33-24-22	ALL
	C	UNUSED						ALL
D14552		**979/290/L007**		**PLUG-**				**ALL**
	1		W0160	2001W	24		33-24-22	ALL
	2		W0160	2001B	24		33-24-22	ALL
	3		W0160	2002R	24		33-24-22	ALL
	4		W0160	2002B	24		33-24-22	ALL
	5		W0160	2001Z			33-24-22	ALL
D14556		**979/290/L005**		**RCPT-**				**ALL**
	1		W0160	2003W	24		33-24-22	ALL
	2		W0160	2003B	24		33-24-22	ALL
	3		W0160	2004R	24		33-24-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14556	**979/290/L005**		**RCPT- (continued)**				**ALL**
4		W0160	2004B	24		33-24-22	ALL
5		W0160	2003Z			33-24-22	ALL
D14560	**979/290/R007**		**PLUG-**				**ALL**
1		W0160	2003W	24		33-24-22	ALL
2		W0160	2003B	24		33-24-22	ALL
3		W0160	2004R	24		33-24-22	ALL
4		W0160	2004B	24		33-24-22	ALL
5		W0160	2003Z			33-24-22	ALL
D14564	**979/290/R008**		**RCPT-**				**ALL**
1		W0160	2005W	24		33-24-22	ALL
2		W0160	2005B	24		33-24-22	ALL
3		W0160	2006R	24		33-24-22	ALL
4		W0160	2006B	24		33-24-22	ALL
5		W0160	2005Z			33-24-22	ALL
D14568	**931/290/R015**		**PLUG-**				**ALL**
1		W0158	2003W	24		33-24-22	ALL
2		W0158	2003B	24		33-24-22	ALL
3		W0158	2004R	24		33-24-22	ALL
4		W0158	2004B	24		33-24-22	ALL
5		W0158	2003Z			33-24-22	ALL
D14578	**419/269/L059**		**PLUG-**				**ALL**
A		W3246	0003	18		33-21-12	ALL
B		W3246	0001	18		33-21-12	ALL
C		W3246	0002	18		33-21-12	ALL
D		W3246	0004	18		33-21-12	ALL
D14580	**419/269/L059**		**PLUG-**				**ALL**
A		W3246	0013	18		33-21-12	ALL
B		W3246	0011	18		33-21-12	ALL
C		W3246	0012	18		33-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14580		**419/269/L059**		**PLUG- (continued)**				**ALL**
	D		W3246	0014	18		33-21-12	ALL
D14582		**590/269/L059**		**PLUG-**				**ALL**
	A		W3246	0023	18		33-21-12	ALL
	B		W3246	0021	18		33-21-12	ALL
	C		W3246	0022	18		33-21-12	ALL
	D		W3246	0024	18		33-21-12	ALL
D14584		**628/269/L059**		**PLUG-**				**ALL**
	A		W3246	0033	18		33-21-12	ALL
	B		W3246	0031	18		33-21-12	ALL
	C		W3246	0032	18		33-21-12	ALL
	D		W3246	0034	18		33-21-12	ALL
D14586		**866/269/L059**		**PLUG-**				**ALL**
	A		W3246	0043	18		33-21-12	ALL
	B		W3246	0041	18		33-21-12	ALL
	C		W3246	0042	18		33-21-12	ALL
	D		W3246	0044	18		33-21-12	ALL
D14588		**866/269/L059**		**PLUG-**				**ALL**
	A		W3246	0053	18		33-21-12	ALL
	B		W3246	0051	18		33-21-12	ALL
	C		W3246	0052	18		33-21-12	ALL
	D		W3246	0054	18		33-21-12	ALL
D14590		**419/269/L059**		**PLUG-**				**ALL**
	1		W3246	2001W	24		33-21-12	ALL
	2		W3246	2001B	24		33-21-12	ALL
	3		W3246	2002R	24		33-21-12	ALL
	4		W3246	2002B	24		33-21-12	ALL
	5		W3246	2001Z			33-21-12	ALL
D14594		**419/269/R059**		**PLUG-**				**ALL**
	A		W4246	0003	18		33-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14594		**419/269/R059**		**PLUG- (continued)**				**ALL**
	B		W4246	0001	18		33-21-12	ALL
	C		W4246	0002	18		33-21-12	ALL
	D		W4246	0004	18		33-21-12	ALL
D14596		**419/269/R059**		**PLUG-**				**ALL**
	A		W4246	0013	18		33-21-12	ALL
	B		W4246	0011	18		33-21-12	ALL
	C		W4246	0012	18		33-21-12	ALL
	D		W4246	0014	18		33-21-12	ALL
D14598		**590/269/R059**		**PLUG-**				**ALL**
	A		W4246	0023	18		33-21-12	ALL
	B		W4246	0021	18		33-21-12	ALL
	C		W4246	0022	18		33-21-12	ALL
	D		W4246	0024	18		33-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14600		**628/269/R059**		**PLUG-**				**ALL**
	A		W4246	0033	18		33-21-12	ALL
	B		W4246	0031	18		33-21-12	ALL
	C		W4246	0032	18		33-21-12	ALL
	D		W4246	0034	18		33-21-12	ALL
D14602		**866/269/R059**		**PLUG-**				**ALL**
	A		W4246	0043	18		33-21-12	ALL
	B		W4246	0041	18		33-21-12	ALL
	C		W4246	0042	18		33-21-12	ALL
	D		W4246	0044	18		33-21-12	ALL
D14604		**866/269/R059**		**PLUG-**				**ALL**
	A		W4246	0053	18		33-21-12	ALL
	B		W4246	0051	18		33-21-12	ALL
	C		W4246	0052	18		33-21-12	ALL
	D		W4246	0054	18		33-21-12	ALL
D14606		**419/269/R059**		**PLUG-**				**ALL**
	1		W4246	2001W	24		33-21-12	ALL
	2		W4246	2001B	24		33-21-12	ALL
	3		W4246	2002R	24		33-21-12	ALL
	4		W4246	2002B	24		33-21-12	ALL
	5		W4246	2001Z			33-21-12	ALL
D14608		**866/269/R059**		**RCPT-**				**ALL**
	1		W4246	2003W	24		33-24-22	ALL
	2		W4246	2003B	24		33-24-22	ALL
	3		W4246	2004R	24		33-24-22	ALL
	4		W4246	2004B	24		33-24-22	ALL
	5		W4246	2003Z			33-24-22	ALL
D14610		**318/292/L004**		**PLUG-**				**ALL**
	A		W0156	0003	18		33-24-21	ALL
	B		W0156	0001	18		33-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14610	**318/292/L004**		**PLUG- (continued)**				**ALL**
C		W0156	0002	18		33-24-21	ALL
D14612	**319/292/L004**		**PLUG-**				**ALL**
1		W3058	2007W	24		33-24-21	ALL
2		W3058	2007B	24		33-24-21	ALL
3		W3058	2008R	24		33-24-21	ALL
4		W3058	2008B	24		33-24-21	ALL
5		W3058	2007Z			33-24-21	ALL
D14614	**931/290/L014**		**PLUG-**				**ALL**
A		W0158	0013	18		33-24-22	ALL
B		W0158	0011	18		33-24-22	ALL
C		W0158	0012	18		33-24-22	ALL
D14618	**979/290/L008**		**PLUG-**				**ALL**
A		W0160	0003	18		33-24-22	ALL
B		W0160	0001	18		33-24-22	ALL
C		W0160	0002	18		33-24-22	ALL
D14622	**979/290/R007**		**PLUG-**				**ALL**
A		W0160	0013	18		33-24-22	ALL
B		W0160	0011	18		33-24-22	ALL
C		W0160	0012	18		33-24-22	ALL
D14626	**931/290/R014**		**PLUG-**				**ALL**
A		W0158	0023	18		33-24-22	ALL
B		W0158	0021	18		33-24-22	ALL
C		W0158	0022	18		33-24-22	ALL
D14630	**356/290/L008**		**PLUG-**				**ALL**
A		W0156	0023	18		33-24-21	ALL
B		W0156	0021	18		33-24-21	ALL
C		W0156	0022	18		33-24-21	ALL
D14634	**356/290/L009**		**PLUG-**				**ALL**
A		W0156	0013	18		33-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14634		**356/290/L009**		**PLUG- (continued)**				**ALL**
	B		W0156	0011	18		33-24-21	ALL
	C		W0156	0012	18		33-24-21	ALL
D14650		**356/290/R012**		**PLUG-**				**ALL**
	A		W0156	0033	18		33-24-21	ALL
	B		W0156	0031	18		33-24-21	ALL
	C		W0156	0032	18		33-24-21	ALL
D14654		**916/290/L010**		**PLUG-**				**ALL**
	A		W0158	0003	18		33-24-22	ALL
	B		W0158	0001	18		33-24-22	ALL
	C		W0158	0002	18		33-24-22	ALL
D14656		**916/290/L010**		**PLUG-**				**ALL**
	1		W4246	2003W	24		33-24-22	ALL
	2		W4246	2003B	24		33-24-22	ALL
	3		W4246	2004R	24		33-24-22	ALL
	4		W4246	2004B	24		33-24-22	ALL
	5		W4246	2003Z			33-24-22	ALL
D14668		**357/290/L001**		**RCPT-**				**ALL**
	1		W3246	2501W	24		33-24-21	ALL
	2		W3246	2501B	24		33-24-21	ALL
	3		W3246	2011R	24		33-24-21	ALL
	4		W3246	2011B	24		33-24-21	ALL
	5		W3246	2501Z			33-24-21	ALL
D14690		**403/289/R006**		**PLUG-**				**ALL**
	A		W4142	0064	20		33-51-12	ALL
	B		W4142	0070	20		33-51-12	ALL
	C	UNUSED						ALL
D14692		**460/298/L010**		**PLUG-**				**ALL**
	A		W3142	0636	20		33-51-12	ALL
	B		W3142	0637	20		33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14692		**460/298/L010**		**PLUG- (continued)**				**ALL**
	C	UNUSED						ALL
D14694		**461/295/L025**		**PLUG-**				**ALL**
	A		W3142	0514	20		33-51-12	ALL
	B		W3142	0068	16		33-51-12	ALL
	C	UNUSED						ALL
D14698		**500I+1/295/L025**		**PLUG-**				**ALL**
	A		W3142	0578	20		33-51-12	ALL
	B		W3142	0579	16		33-51-12	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14700		**617/295/R023**		**PLUG-**				**ALL**
	A		W4142	0333	16		33-51-12	ALL
	B		W4142	0361	16		33-51-12	ALL
	C	UNUSED						ALL
D14702		**649/296/L027**		**PLUG-**				**ALL**
	A		W3142	0576	16		33-51-13	ALL
	B		W3142	0577	16		33-51-13	ALL
	C	UNUSED						ALL
D14706		**698/289/R006**		**PLUG-**				**ALL**
	A		W4142	0620	20		33-51-14	ALL
	B		W4142	0621	20		33-51-14	ALL
	C	UNUSED						ALL
D14708		**727+10/295/R023**		**PLUG-**				**ALL**
	A		W4142	0624	20		33-51-14	ALL
	B		W4142	0625	20		33-51-14	ALL
	C	UNUSED						ALL
D14710		**727A+10/289/L006**		**PLUG-**				**ALL**
	A		W3142	0612	20		33-51-13	ALL
	B		W3142	0613	20		33-51-13	ALL
	C	UNUSED						ALL
D14712		**727B+2/289/L018**		**PLUG-**				**ALL**
	A		W3142	0614	20		33-51-13	ALL
	B		W3142	0615	20		33-51-13	ALL
	C	UNUSED						ALL
D14714		**727D+8/289/R006**		**PLUG-**				**ALL**
	A		W4142	0622	20		33-51-14	ALL
	B		W4142	0623	20		33-51-14	ALL
	C	UNUSED						ALL
D14720		**815/289/L006**		**PLUG-**				**ALL**
	A		W3142	0440	20		33-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14720		**815/289/L006**		**PLUG- (continued)**				**ALL**
	B		W3142	0456	20		33-51-14	ALL
	C	UNUSED						ALL
D14722		**877/289/R006**		**PLUG-**				**ALL**
	A		W4142	0628	20		33-51-14	ALL
	B		W4142	0629	20		33-51-14	ALL
	C	UNUSED						ALL
D14724		**628/270/R060**		**PLUG-**				**ALL**
	A		W4142	0336	20		33-51-13	ALL
	B		W4142	0355	20		33-51-13	ALL
	C	UNUSED						ALL
D14726		**628/270/L060**		**PLUG-**				**ALL**
	A		W3142	0236	20		33-51-13	ALL
	B		W3142	0253	20		33-51-13	ALL
	C	UNUSED						ALL
D14730		**714/196/R052**		**CONNECTOR PLUG - SOCKET**				**ALL**
	A		W8124	0505	20		32-64-21	ALL
	B	UNUSED						ALL
	C		W8124	0506	20		32-64-21	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14730		**714/196/R052**		**CONNECTOR PLUG - SOCKET (continued)**				**ALL**
	R	UNUSED						ALL
	S		W8124	0510	20		32-64-21	ALL
	T	UNUSED						ALL
	U		W8124	0511	20		32-64-21	ALL
D14738		**500+16/296/L027**		**PLUG-**				**ALL**
	A		W3166	0416	18		33-22-21	ALL
	B		W3166	0414	18		33-22-21	ALL
	C		W3166	0415	18		33-22-21	ALL
D14752		**768/296/R027**		**PLUG-**				**ALL**
	A		W4166	0506	18		33-22-32	ALL
	B		W4166	0504	18		33-22-32	ALL
	C		W4166	0505	18		33-22-32	ALL
D14758		**819/296/R027**		**PLUG-**				**ALL**
	A		W4166	0186	18		33-22-51	ALL
	B		W4166	0184	18		33-22-51	ALL
	C		W4166	0185	18		33-22-51	ALL
D14760		**500C+10/296/R027**		**PLUG-**				**ALL**
	A		W4166	0116	18		33-22-51	ALL
	B		W4166	0114	18		33-22-51	ALL
	C		W4166	0115	18		33-22-51	ALL
D14762		**500+16/296/R027**		**PLUG-**				**ALL**
	A		W4166	0106	18		33-22-51	ALL
	B		W4166	0104	18		33-22-51	ALL
	C		W4166	0105	18		33-22-51	ALL
D14774		**314/293/L004**		**PLUG-**				**ALL**
	A		W0142	0005	24		33-29-11	ALL
	B		W0142	0006	24		33-29-11	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14776	**978/292/R007**		**PLUG-**				**ALL**
A		W0152	0005	24		33-29-11	ALL
B		W0152	0006	24		33-29-11	ALL
C	UNUSED						ALL
D14780	**461/296/R027**		**PLUG-**				**ALL**
A		W4166	0416	18		33-22-31	ALL
B		W4166	0414	18		33-22-31	ALL
C		W4166	0415	18		33-22-31	ALL
D14784	**500+18/296/R027**		**PLUG-**				**ALL**
A		W4166	0426	18		33-22-31	ALL
B		W4166	0424	18		33-22-31	ALL
C		W4166	0425	18		33-22-31	ALL
D14788	**942/292/L010**		**RCPT-**				**ALL**
1		W0160	2001W	24		33-24-22	ALL
2		W0160	2001B	24		33-24-22	ALL
3		W0160	2002R	24		33-24-22	ALL
4		W0160	2002B	24		33-24-22	ALL
5		W0160	2001Z			33-24-22	ALL
D14790	**1121/291/R008**		**PLUG-**				**ALL**
1		W0160	2005W	24		33-24-22	ALL
2		W0160	2005B	24		33-24-22	ALL
3		W0160	2006R	24		33-24-22	ALL
4		W0160	2006B	24		33-24-22	ALL
5		W0160	2005Z			33-24-22	ALL
D14792	**1121/291/R008**		**RCPT-**				**ALL**
1		W0158	2003W	24		33-24-22	ALL
2		W0158	2003B	24		33-24-22	ALL
3		W0158	2004R	24		33-24-22	ALL
4		W0158	2004B	24		33-24-22	ALL
5		W0158	2003Z			33-24-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14810		**500C+10/296/L027**		**PLUG-**				**ALL**
	A		W3166	0406	18		33-22-21	ALL
	B		W3166	0404	18		33-22-21	ALL
	C		W3166	0405	18		33-22-21	ALL
D14812		**310/290/R006**		**PLUG-**				**ALL**
	1	16	W4142	0701	16		33-51-11	ALL
	2		W4142	0702	20		33-51-11	ALL
	3		W4142	0703	22		33-51-11	ALL
	4		W4142	0704	22		33-51-11	ALL
	5		W4142	0706	20		33-51-11	ALL
	6		W4142	0706	20		33-51-11	ALL
	7		W4142	0707	20		33-51-11	ALL
	8	UNUSED						ALL
	9		W4142	0009	20		33-51-12	ALL
	10	UNUSED						ALL
	11		W4142	0011	20		33-51-12	ALL
	12	16	W4142	0010	16		33-51-21	ALL
	13	UNUSED						ALL
	14		W4142	0064	20		33-51-12	ALL
	15		W4142	0012	20		33-51-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W4142	0724	20		33-51-11	ALL
	21	UNUSED						ALL
	22		W4142	0722	20		33-51-11	ALL
	23	UNUSED						ALL
	24		W4142	0724	20		33-51-11	ALL
	CAP	Y	W4142	0036	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D14812	**310/290/R006**		**PLUG- (continued)**				**ALL**
CAP	Y	W4142	0038	20		SPARE	ALL
D14814	**D41078TI/ /**		**PLUG-**				**ALL**
A		W0132	0001	20		33-51-12	ALL
B		W0132	0002	20		33-51-12	ALL
C	UNUSED						ALL
D14816	**MULTI/ /**		**RCPT-**				**ALL**
A		W0132	0001	20		33-51-12	ALL
B		W0132	0002	20		33-51-12	ALL
C	UNUSED						ALL
D14824	**500+18/298/R007**		**PLUG-**				**ALL**
A		W4142	0513	20		33-51-12	ALL
B		W4142	0538	20		33-51-12	ALL
C	UNUSED						ALL
D14826	**500C+10/295/R024**		**PLUG-**				**ALL**
A		W4142	0514	20		33-51-12	ALL
B		W4142	0537	20		33-51-12	ALL
C	UNUSED						ALL
D14828	**500C+14/295/L025**		**PLUG-**				**ALL**
A		W3142	0511	20		33-51-12	ALL
B		W3142	0066	20		33-51-12	ALL
C	UNUSED						ALL
D14830	**500H+20/295/R023**		**PLUG-**				**ALL**
A		W4142	0515	20		33-51-12	ALL
B		W4142	0555	20		33-51-12	ALL
C	UNUSED						ALL
D14832	**727F+5/295/R023**		**PLUG-**				**ALL**
A		W4142	0626	20		33-51-14	ALL
B		W4142	0627	20		33-51-14	ALL
C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14834		**727G+14/296/L027**		**PLUG-**				**ALL**
	A		W3142	0316	20		33-51-13	ALL
	B		W3142	0356	20		33-51-13	ALL
	C	UNUSED						ALL
D14836		**765/295/R023**		**PLUG-**				**ALL**
	A		W4142	0413	16		33-51-14	ALL
	B		W4142	0408	16		33-51-14	ALL
	C	UNUSED						ALL
D14838		**768/294/L023**		**PLUG-**				**ALL**
	A		W3142	0441	20		33-51-14	ALL
	B		W3142	0448	16		33-51-14	ALL
	C	UNUSED						ALL
D14840		**590/270/R060**		**PLUG-**				**ALL**
	A		W4142	0334	20		33-51-13	ALL
	B		W4142	0353	20		33-51-13	ALL
	C	UNUSED						ALL
D14842		**590/270/L060**		**PLUG-**				**ALL**
	A		W3142	0237	20		33-51-13	ALL
	B		W3142	0273	20		33-51-13	ALL
	C	UNUSED						ALL
D14856		**766/296/L027**		**PLUG-**				**ALL**
	A		W3166	0376	18		33-22-22	ALL
	B		W3166	0374	18		33-22-22	ALL
	C		W3166	0375	18		33-22-22	ALL
D14858		**727H+21/296/L027**		**PLUG-**				**ALL**
	A		W3166	0366	18		33-22-22	ALL
	B		W3166	0364	18		33-22-22	ALL
	C		W3166	0365	18		33-22-22	ALL
D14860		**727F+5/296/L027**		**PLUG-**				**ALL**
	A		W3166	0356	18		33-22-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14860		**727F+5/296/L027**		**PLUG- (continued)**				**ALL**
	B		W3166	0354	18		33-22-22	ALL
	C		W3166	0355	18		33-22-22	ALL
D14876		**678/296/L027**		**PLUG-**				**ALL**
	A		W3166	0296	18		33-22-21	ALL
	B		W3166	0294	18		33-22-21	ALL
	C		W3166	0295	18		33-22-21	ALL
D14878		**618/296/L027**		**PLUG-**				**ALL**
	A		W3166	0286	18		33-22-21	ALL
	B		W3166	0284	18		33-22-21	ALL
	C		W3166	0285	18		33-22-21	ALL
D14880		**558/296/L027**		**PLUG-**				**ALL**
	A		W3166	0276	18		33-22-21	ALL
	B		W3166	0274	18		33-22-21	ALL
	C		W3166	0275	18		33-22-21	ALL
D14882		**500H+20/296/L027**		**PLUG-**				**ALL**
	A		W3166	0266	18		33-22-21	ALL
	B		W3166	0264	18		33-22-21	ALL
	C		W3166	0265	18		33-22-21	ALL
D14884		**500F+4/296/L027**		**PLUG-**				**ALL**
	A		W3166	0256	18		33-22-21	ALL
	B		W3166	0254	18		33-22-21	ALL
	C		W3166	0255	18		33-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14916		**500C+12/296/R027**		**PLUG-**				**ALL**
	A		W4166	0246	18		33-22-31	ALL
	B		W4166	0244	18		33-22-31	ALL
	C		W4166	0245	18		33-22-31	ALL
D14918		**500F+6/296/R027**		**PLUG-**				**ALL**
	A		W4166	0256	18		33-22-31	ALL
	B		W4166	0254	18		33-22-31	ALL
	C		W4166	0255	18		33-22-31	ALL
D14920		**500I/296/R027**		**PLUG-**				**ALL**
	A		W4166	0266	18		33-22-31	ALL
	B		W4166	0264	18		33-22-31	ALL
	C		W4166	0265	18		33-22-31	ALL
D14922		**560/296/R027**		**PLUG-**				**ALL**
	A		W4166	0276	18		33-22-31	ALL
	B		W4166	0274	18		33-22-31	ALL
	C		W4166	0275	18		33-22-31	ALL
D14924		**620/296/R027**		**PLUG-**				**ALL**
	A		W4166	0286	18		33-22-31	ALL
	B		W4166	0284	18		33-22-31	ALL
	C		W4166	0285	18		33-22-31	ALL
D14940		**727C+13/296/R027**		**PLUG-**				**ALL**
	A		W4166	0346	18		33-22-32	ALL
	B		W4166	0344	18		33-22-32	ALL
	C		W4166	0345	18		33-22-32	ALL
D14942		**727F+7/296/R027**		**PLUG-**				**ALL**
	A		W4166	0356	18		33-22-32	ALL
	B		W4166	0354	18		33-22-32	ALL
	C		W4166	0355	18		33-22-32	ALL
D14944		**727I+1/296/R027**		**PLUG-**				**ALL**
	A		W4166	0366	18		33-22-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14944		**727I+1/296/R027**		**PLUG- (continued)**				**ALL**
	B		W4166	0364	18		33-22-32	ALL
	C		W4166	0365	18		33-22-32	ALL
D14960		**500C+12/296/L027**		**PLUG-**				**ALL**
	A		W3166	0026	18		33-22-41	ALL
	B		W3166	0024	18		33-22-41	ALL
	C		W3166	0025	18		33-22-41	ALL
D14962		**500F+6/296/L027**		**PLUG-**				**ALL**
	A		W3166	0036	18		33-22-41	ALL
	B		W3166	0034	18		33-22-41	ALL
	C		W3166	0035	18		33-22-41	ALL
D14964		**500H+22/296/L027**		**PLUG-**				**ALL**
	A		W3166	0046	18		33-22-41	ALL
	B		W3166	0044	18		33-22-41	ALL
	C		W3166	0045	18		33-22-41	ALL
D14966		**560/296/L027**		**PLUG-**				**ALL**
	A		W3166	0056	18		33-22-41	ALL
	B		W3166	0054	18		33-22-41	ALL
	C		W3166	0055	18		33-22-41	ALL
D14968		**620/296/L027**		**PLUG-**				**ALL**
	A		W3166	0106	18		33-22-41	ALL
	B		W3166	0104	18		33-22-41	ALL
	C		W3166	0105	18		33-22-41	ALL
D14978		**727C+13/296/L027**		**PLUG-**				**ALL**
	A		W3166	0136	18		33-22-41	ALL
	B		W3166	0134	18		33-22-41	ALL
	C		W3166	0135	18		33-22-41	ALL
D14980		**727F+7/296/L027**		**PLUG-**				**ALL**
	A		W3166	0146	18		33-22-41	ALL
	B		W3166	0144	18		33-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D14980		**727F+7/296/L027**		**PLUG- (continued)**				**ALL**
	C		W3166	0145	18		33-22-41	ALL
D14982		**727I+1/296/L027**		**PLUG-**				**ALL**
	A		W3166	0156	18		33-22-41	ALL
	B		W3166	0154	18		33-22-41	ALL
	C		W3166	0155	18		33-22-41	ALL
D14990		**766/296/R027**		**PLUG-**				**ALL**
	A		W4166	0166	18		33-22-51	ALL
	B		W4166	0164	18		33-22-51	ALL
	C		W4166	0165	18		33-22-51	ALL
D14992		**727H+21/296/R027**		**PLUG-**				**ALL**
	A		W4166	0156	18		33-22-51	ALL
	B		W4166	0154	18		33-22-51	ALL
	C		W4166	0155	18		33-22-51	ALL
D14994		**727F+4/296/R027**		**PLUG-**				**ALL**
	A		W4166	0146	18		33-22-51	ALL
	B		W4166	0144	18		33-22-51	ALL
	C		W4166	0145	18		33-22-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15004	**678/296/R027**		**PLUG-**				**ALL**
A		W4166	0076	18		33-22-51	ALL
B		W4166	0074	18		33-22-51	ALL
C		W4166	0075	18		33-22-51	ALL
D15006	**618/296/R027**		**PLUG-**				**ALL**
A		W4166	0066	18		33-22-51	ALL
B		W4166	0064	18		33-22-51	ALL
C		W4166	0065	18		33-22-51	ALL
D15008	**558/296/R027**		**PLUG-**				**ALL**
A		W4166	0056	18		33-22-51	ALL
B		W4166	0054	18		33-22-51	ALL
C		W4166	0055	18		33-22-51	ALL
D15010	**500H+20/296/R027**		**PLUG-**				**ALL**
A		W4166	0046	18		33-22-51	ALL
B		W4166	0044	18		33-22-51	ALL
C		W4166	0045	18		33-22-51	ALL
D15012	**500F+4/296/R027**		**PLUG-**				**ALL**
A		W4166	0036	18		33-22-51	ALL
B		W4166	0034	18		33-22-51	ALL
C		W4166	0035	18		33-22-51	ALL
D15016	**410/274/R044**		**PLUG-**				**ALL**
1		W4116	2001B	24		21-61-13	ALL
2		W4116	2001R	24		21-61-13	ALL
3		W4116	2002R	24		21-61-13	ALL
4		W4116	2002B	24		21-61-13	ALL
5	UNUSED						ALL
D15018	**410/274/R044**		**PLUG-**				**ALL**
A		W4116	0004	20		21-61-51	ALL
B		W4116	0005	20		21-61-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15020		**410/274/R044**		**PLUG-**				**ALL**
	1		W4116	0001	24		21-61-13	ALL
	2		W4116	0002	20		21-61-13	ALL
	3		W4116	0003	20		21-61-13	ALL
D15022		**727G+11/274/R044**		**PLUG-**				**ALL**
	1		W4118	2001B	24		21-61-14	ALL
	2		W4118	2001R	24		21-61-14	ALL
	3		W4118	2002R	24		21-61-14	ALL
	4		W4118	2002B	24		21-61-14	ALL
	5	UNUSED						ALL
D15024		**727G+11/274/R044**		**PLUG-**				**ALL**
	A		W4118	0004	20		21-61-51	ALL
	B		W4118	0005	20		21-61-51	ALL
D15026		**727G+11/274/R044**		**PLUG-**				**ALL**
	1		W4118	0001	24		21-61-14	ALL
	2		W4118	0002	20		21-61-14	ALL
	3		W4118	0003	20		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15242	**620/288/L000**		**PLUG-**				**ALL**
1		W3142	0057	20		33-51-13	ALL
2		W3142	0058	20		33-51-13	ALL
3	UNUSED						ALL
D15282	**876/296/L027**		**PLUG-**				**ALL**
A		W3166	0516	18		33-22-22	ALL
B		W3166	0514	18		33-22-22	ALL
C		W3166	0515	18		33-22-22	ALL
D15284	**727C+11/296/L027**		**PLUG-**				**ALL**
A		W3166	0576	18		33-22-22	ALL
B		W3166	0574	18		33-22-22	ALL
C		W3166	0575	18		33-22-22	ALL
D15286	**727+11/296/L027**		**PLUG-**				**ALL**
A		W3166	0586	18		33-22-22	ALL
B		W3166	0584	18		33-22-22	ALL
C		W3166	0585	18		33-22-22	ALL
D15288	**458/296/L027**		**PLUG-**				**ALL**
A		W3166	0426	18		33-22-21	ALL
B		W3166	0424	18		33-22-21	ALL
C		W3166	0425	18		33-22-21	ALL
D15290	**405/296/R027**		**PLUG-**				**ALL**
A		W4166	0406	18		33-22-31	ALL
B		W4166	0404	18		33-22-31	ALL
C		W4166	0405	18		33-22-31	ALL
D15292	**680/296/R027**		**PLUG-**				**ALL**
A		W4166	0436	18		33-22-32	ALL
B		W4166	0434	18		33-22-32	ALL
C		W4166	0435	18		33-22-32	ALL
D15294	**727+13/296/R027**		**PLUG-**				**ALL**
A		W4166	0446	18		33-22-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15294		**727+13/296/R027**		**PLUG- (continued)**				**ALL**
	B		W4166	0444	18		33-22-32	ALL
	C		W4166	0445	18		33-22-32	ALL
D15296		**821/296/R027**		**PLUG-**				**ALL**
	A		W4166	0516	18		33-22-32	ALL
	B		W4166	0514	18		33-22-32	ALL
	C		W4166	0515	18		33-22-32	ALL
D15298		**405/296/L027**		**PLUG-**				**ALL**
	A		W3166	0066	18		33-22-41	ALL
	B		W3166	0064	18		33-22-41	ALL
	C		W3166	0065	18		33-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15300	**680/296/L027**		**PLUG-**				**ALL**
A		W3166	0606	18		33-22-41	ALL
B		W3166	0604	18		33-22-41	ALL
C		W3166	0605	18		33-22-41	ALL
D15302	**727+13/296/L027**		**PLUG-**				**ALL**
A		W3166	0616	18		33-22-41	ALL
B		W3166	0614	18		33-22-41	ALL
C		W3166	0615	18		33-22-41	ALL
D15304	**821/296/L027**		**PLUG-**				**ALL**
A		W3166	0186	18		33-22-41	ALL
B		W3166	0184	18		33-22-41	ALL
C		W3166	0185	18		33-22-41	ALL
D15306	**876/296/R027**		**PLUG-**				**ALL**
A		W4166	0196	18		33-22-51	ALL
B		W4166	0194	18		33-22-51	ALL
C		W4166	0195	18		33-22-51	ALL
D15308	**727C+11/296/R027**		**PLUG-**				**ALL**
A		W4166	0616	18		33-22-51	ALL
B		W4166	0614	18		33-22-51	ALL
C		W4166	0615	18		33-22-51	ALL
D15310	**727+11/296/R027**		**PLUG-**				**ALL**
A		W4166	0606	18		33-22-51	ALL
B		W4166	0604	18		33-22-51	ALL
C		W4166	0605	18		33-22-51	ALL
D15312	**458/296/R027**		**PLUG-**				**ALL**
A		W4166	0096	18		33-22-51	ALL
B		W4166	0094	18		33-22-51	ALL
C		W4166	0095	18		33-22-51	ALL
D15314	**405/296/R027**		**PLUG-**				**ALL**
1		W4166	2003W	24		33-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15314		**405/296/R027**		**PLUG- (continued)**				**ALL**
	2		W4166	2003B	24		33-22-31	ALL
	3		W4166	2004R	24		33-22-31	ALL
	4		W4166	2004B	24		33-22-31	ALL
	5		W4166	2003Z			33-22-31	ALL
D15316		**405/296/L027**		**PLUG-**				**ALL**
	1		W3166	2001W	24		33-22-41	ALL
	2		W3166	2001B	24		33-22-41	ALL
	3		W3166	2002R	24		33-22-41	ALL
	4		W3166	2002B	24		33-22-41	ALL
	5		W3166	2001Z			33-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15501	**P018-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0018	0113	22		30-31-11	ALL
A2		W0018	0110	22		30-31-11	ALL
A3	UNUSED						ALL
B1		W0018	0116	22		30-31-11	ALL
B2		W0018	0111	22		30-31-11	ALL
B3	UNUSED						ALL
X1		W0018	0112	22		30-31-11	ALL
X2		W0018	0114	22		30-31-11	ALL
D15502	**P018-00/ /**		**RELAY SOCKET**				**ALL**
A1		W0018	0121	22		30-31-12	ALL
A2		W0018	0117	22		30-31-12	ALL
A3	UNUSED						ALL
B1		W0018	0123	22		30-31-12	ALL
B2		W0018	0118	22		30-31-12	ALL
B3	UNUSED						ALL
C1		W0018	0125	22		30-31-12	ALL
C2		W0018	0119	22		30-31-12	ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0018	0120	22		30-31-12	ALL
X2		W0018	0122	22		30-31-12	ALL
D15510	**247/206/R013**		**PLUG**				**ALL**
A		W5506	0523	20		32-35-11	ALL
B		W5506	0524	20		32-35-11	ALL
C	UNUSED						ALL
D15512	**P018-00/ /**		**SOCKET-RELAY**				**ALL**
A1		W0018	0148	22		30-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15512		**P018-00/ /**		**SOCKET-RELAY (continued)**				**ALL**
	A2		W0018	0155	22		30-31-11	ALL
	A3	UNUSED						ALL
	B1		W0018	0115	22		30-31-11	ALL
	B2		W0018	0154	22		30-31-11	ALL
	B3	UNUSED						ALL
	C1		W0018	0151	22		30-31-11	ALL
	C2		W0018	0156	22		30-31-11	ALL
	C3	UNUSED						ALL
	D1		W0018	0152	22		30-31-11	ALL
	D2		W0018	0157	22		30-31-11	ALL
	D3	UNUSED						ALL
	E1	UNUSED						ALL
	E2	UNUSED						ALL
	E3	UNUSED						ALL
	F1	UNUSED						ALL
	F2	UNUSED						ALL
	F3	UNUSED						ALL
	X1		W0018	0158	22		30-31-11	ALL
	X2		W0018	0153	22		30-31-11	ALL
D15514		**P018-00/ /**		**SOCKET-RELAY**				**ALL**
	A1		W0018	0124	22		30-31-12	ALL
	A2		W0018	0162	22		30-31-12	ALL
	A3	UNUSED						ALL
	B1		W0018	0173	22		30-31-12	ALL
	B2		W0018	0164	22		30-31-12	ALL
	B3	UNUSED						ALL
	C1		W0018	0172	22		30-31-12	ALL
	C2		W0018	0163	22		30-31-12	ALL
	C3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15514		**P018-00/ /**		**SOCKET-RELAY (continued)**				**ALL**
	D1		W0018	0174	22		30-31-12	ALL
	D2		W0018	0165	22		30-31-12	ALL
	D3	UNUSED						ALL
	X1		W0018	0166	22		30-31-12	ALL
	X2		W0018	0175	22		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15642		**366/164/R018**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W5506	1002	22		26-19-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5506	0024	20		26-19-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5506	0025	22		26-19-11	ALL
	9		W5506	1003	22		26-19-11	ALL
	10		W5506	0026	20		26-19-11	ALL
	11	UNUSED						ALL
	12		W5506	1004	22		26-19-11	ALL
			W5506	0031	22		26-19-11	ALL
			W5506	0032	22		26-19-11	ALL
			W5506	0033	22		26-19-11	ALL
			W5506	1002Z			26-19-11	ALL
			W5506	1003Z			26-19-11	ALL
			W5506	1004Z			26-19-11	ALL
D15644		**349/192/R055**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W5506	1005	22		26-19-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5506	0084	20		26-19-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5506	0085	22		26-19-11	ALL
	9		W5506	1006	22		26-19-11	ALL
	10		W5506	0086	20		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15644		**349/192/R055**		**PLUG (continued)**				**ALL**
	11	UNUSED						ALL
	12		W5506	1007	22		26-19-11	ALL
			W5506	0034	22		26-19-11	ALL
			W5506	0035	22		26-19-11	ALL
			W5506	0036	22		26-19-11	ALL
			W5506	1005Z			26-19-11	ALL
			W5506	1006Z			26-19-11	ALL
			W5506	1007Z			26-19-11	ALL
D15646		**0FSS 258/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1664	2004B	20		30-11-11	ALL
	2		W1664	2004R	20		30-11-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1664	0018	20		30-11-11	ALL
	S/R		W1664	2004Z			30-11-11	ALL
D15648		**OFSS 270/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1662	2004B	20		30-11-11	ALL
	2		W1662	2004R	20		30-11-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1662	0011	20		30-11-11	ALL
	S/R		W1662	2004Z			30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15708		**205/195/R020**		**RCPT**				**ALL**
	1		W5382	3701Y	22		27-61-44	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5382	3701R	22		27-61-44	ALL
	6		W5382	3701B	22		27-61-44	ALL
	7	UNUSED						ALL
	8		W5382	2701B	22		27-61-44	ALL
	9		W5382	2701R	22		27-61-44	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W5382	2701Z			27-61-44	ALL
	S/R		W5382	3701Z			27-61-44	ALL
D15710		**205/195/R017**		**RCPT**				**ALL**
	1		W5380	3701Y	22		27-61-44	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5380	3701R	22		27-61-44	ALL
	6		W5380	3701B	22		27-61-44	ALL
	7	UNUSED						ALL
	8		W5380	2701B	22		27-61-44	ALL
	9		W5380	2701R	22		27-61-44	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W5380	2701Z			27-61-44	ALL
	S/R		W5380	3701Z			27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15712	**205/196/R022**		**RCPT**				**ALL**
1		W5371	3701Y	22		27-61-44	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5371	3701R	22		27-61-44	ALL
6		W5371	3701B	22		27-61-44	ALL
7	UNUSED						ALL
8		W5371	2701B	22		27-61-44	ALL
9		W5371	2701R	22		27-61-44	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W5371	2701Z			27-61-44	ALL
S/R		W5371	3701Z			27-61-44	ALL
D15714	**196/204/R009**		**RCPT**				**ALL**
1		W5382	3702Y	22		27-61-44	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5382	3702R	22		27-61-44	ALL
6		W5382	3702B	22		27-61-44	ALL
7	UNUSED						ALL
8		W5382	2702B	22		27-61-44	ALL
9		W5382	2702R	22		27-61-44	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W5382	2702Z			27-61-44	ALL
S/R		W5382	3702Z			27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15716		**200/204/R005**		**RCPT**				**ALL**
	1		W5380	3702Y	22		27-61-44	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5380	3702R	22		27-61-44	ALL
	6		W5380	3702B	22		27-61-44	ALL
	7	UNUSED						ALL
	8		W5380	2702B	22		27-61-44	ALL
	9		W5380	2702R	22		27-61-44	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W5380	2702Z			27-61-44	ALL
	S/R		W5380	3702Z			27-61-44	ALL
D15718		**196/204/R007**		**RCPT**				**ALL**
	1		W5371	3702Y	22		27-61-44	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5371	3702R	22		27-61-44	ALL
	6		W5371	3702B	22		27-61-44	ALL
	7	UNUSED						ALL
	8		W5371	2702B	22		27-61-44	ALL
	9		W5371	2702R	22		27-61-44	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W5371	2702Z			27-61-44	ALL
	S/R		W5371	3702Z			27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15818	**581/158/LB09**		**PLUG-**				**ALL**
1		W5502	2001B	20		21-51-11	ALL
2		W5502	2001R	20		21-51-11	ALL
3		W5502	1004	20		21-51-11	ALL
D15820	**579/158/R015**		**PLUG-**				**ALL**
1		W6502	2001B	20		21-51-21	ALL
2		W6502	2001R	20		21-51-21	ALL
3		W6502	1006	20		21-51-21	ALL
D15822	**624/156/L011**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W5502	2004R	20		21-51-12	ALL
3	UNUSED						ALL
4		W5502	2004B	20		21-51-12	ALL
5		W5502	2003B	20		21-51-12	ALL
6	UNUSED						ALL
7		W5502	2003R	20		21-51-12	ALL
8		W5502	3001Y	20		21-51-12	ALL
9		W5502	3001B	20		21-51-12	ALL
10	UNUSED						ALL
11		W5502	3001R	20		21-51-12	ALL
12		W5502	0016	20		21-51-12	ALL
S/R		W5502	FRGH			21-51-12	ALL
		W5502	2003Z			21-51-12	ALL
		W5502	2004Z			21-51-12	ALL
		W5502	3001Z			21-51-12	ALL
		W5502	FRGH			21-51-12	ALL
D15824	**624/156/R012**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W6502	2004R	20		21-51-22	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15824		**624/156/R012**		**PLUG (continued)**				**ALL**
	4		W6502	2004B	20		21-51-22	ALL
	5		W6502	2003B	20		21-51-22	ALL
	6	UNUSED						ALL
	7		W6502	2003R	20		21-51-22	ALL
	8		W6502	3001Y	20		21-51-22	ALL
	9		W6502	3001B	20		21-51-22	ALL
	10	UNUSED						ALL
	11		W6502	3001R	20		21-51-22	ALL
	12		W6502	0014	20		21-51-22	ALL
	S/R		W6502	FRGH			21-51-22	ALL
			W6502	2003Z			21-51-22	ALL
			W6502	2004Z			21-51-22	ALL
			W6502	3001Z			21-51-22	ALL
			W6502	FRGH			21-51-22	ALL
D15826		**537/152/R002**		**PLUG-**				**ALL**
	1		W5104	2006B	24		21-51-12	ALL
	2	UNUSED						ALL
	3		W5104	2006R	24		21-51-12	ALL
	4	UNUSED						ALL
	5		W5104	0019	24		21-51-12	ALL
	6	UNUSED						ALL
D15828		**537/150/L002**		**PLUG-**				**ALL**
	1		W6230	2005B	24		21-51-22	ALL
	2	UNUSED						ALL
	3		W6230	2005R	24		21-51-22	ALL
	4	UNUSED						ALL
	5		W6230	0045	24		21-51-22	ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15830	**581/158/L009**		**PLUG-**				**ALL**
1		W5502	2002B	20		21-51-11	ALL
2	UNUSED						ALL
3		W5502	1006	20		21-51-11	ALL
4	UNUSED						ALL
5		W5502	2002R	20		21-51-11	ALL
D15832	**582/163/L014**		**PLUG-**				**ALL**
1		W5504	1001	20		21-51-11	ALL
2		W5504	1002	20		21-42-11	ALL
3		W5504	1003	20		21-51-11	ALL
DED		W5504	1001Z			21-51-11	ALL
DED		W5504	1002Z			21-42-11	ALL
DED		W5504	1003Z			21-51-11	ALL
D15834	**579/158/R013**		**PLUG-**				**ALL**
1		W6502	2002B	20		21-51-21	ALL
2	UNUSED						ALL
3		W6502	1008	20		21-51-21	ALL
4	UNUSED						ALL
5		W6502	2002R	20		21-51-21	ALL
D15836	**582/164/R010**		**PLUG-**				**ALL**
1		W6504	1001	20		21-51-21	ALL
2		W6504	1002	20		21-42-11	ALL
3		W6504	1003	20		21-51-21	ALL
D15838A	**E003-03/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0330	2506B	22		36-11-13	ALL
A06		W0330	2506R	22		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	A07		W0330	2509B	22		36-11-13	ALL
	A08		W0330	2509R	22		36-11-13	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0330	2529R	24		36-21-11	ALL
	A13		W0330	2529B	24		36-21-11	ALL
	A14	UNUSED						ALL
	A15		W0330	2508B	22		36-11-13	ALL
	B01		W0330	2504R	22		36-11-13	ALL
	B02		W0330	2504B	22		36-11-13	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0330	2508R	22		36-11-13	ALL
	C01		W0330	2505R	22		36-11-13	ALL
	C02		W0330	2505B	22		36-11-13	ALL
	C03	UNUSED						ALL
	C04		W0330	0030	24		36-11-14	ALL
	C05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11		W0330	2501R	24		31-65-15	ALL
	C12		W0330	2501B	24		31-65-15	ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15		W0330	2528B	24		36-21-11	ALL
	D01		W0330	2510R	22		36-11-13	ALL
	D02		W0330	2510B	22		36-11-13	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05		W0330	0028	24		36-11-14	ALL
	D06	UNUSED						ALL
	D07		W0330	0070	24		36-11-14	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12		W0330	2512R	24		36-11-14	ALL
	D13		W0330	2512B	24		36-11-14	ALL
	D14	UNUSED						ALL
	D15		W0330	2528R	24		36-21-11	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0330	0055	24		36-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	E05		W0330	0054	24		36-11-31	ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10		W0330	2524R	24		36-11-24	ALL
	E11		W0330	2524B	24		36-11-24	ALL
	E12		W0330	2525R	24		36-11-24	ALL
	E13		W0330	2525B	24		36-11-24	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01		W0330	0093	22		36-11-13	ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04		W0330	0011	24		36-11-12	ALL
	F05		W0330	0015	24		36-11-12	ALL
	F06	UNUSED						ALL
	F07		W0330	0027	24		36-11-13	ALL
	F08		W0330	0056	24		36-11-31	ALL
	F09	UNUSED						ALL
	F10		W0330	2513R	24		36-11-14	ALL
	F11		W0330	2513B	24		36-11-14	ALL
	F12		W0330	2514R	24		36-11-14	ALL
	F13		W0330	2514B	24		36-11-14	ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A	**E003-03/ /**		**PLUG- (continued)**				**ALL**
G04		W0330	3501R	22		36-11-13	ALL
G05		W0330	3501Y	22		36-11-13	ALL
G06		W0330	3501B	22		36-11-13	ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL
G13	UNUSED						ALL
G14	UNUSED						ALL
G15	UNUSED						ALL
H01		W0330	0019	22		36-11-13	ALL
H02	UNUSED						ALL
H03		W0330	0090	22		36-11-13	ALL
H04		W0330	0077	22		30-21-31	ALL
H05		W0330	2530R	22		36-11-13	ALL
H06		W0330	2530B	22		36-11-13	ALL
H07		W0330	2507R	22		36-11-13	ALL
H08		W0330	2507B	22		36-11-13	ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12	UNUSED						ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15		W0330	0021	22		36-11-13	ALL
J01	UNUSED						ALL
J02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	J03		W0330	0013	24		36-11-12	ALL
	J04		W0330	0012	24		36-11-12	ALL
	J05		W0330	0010	24		36-11-12	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10		W0330	2511R	24		36-11-14	ALL
	J11		W0330	2511B	24		36-11-14	ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01		W0330	0018	22		36-11-13	ALL
	K02	UNUSED						ALL
	K03		W0330	0014	24		36-11-12	ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06		W0330	0025	24		36-11-13	ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09		W0330	0017	24		36-11-12	ALL
	K10		W0330	0076	22		30-21-31	ALL
	K11		W0330	0016	24		36-11-12	ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15		W0330	0020	22		36-11-13	ALL
	PERG	1A	W0330	2501Z			31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838A		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	PERG	1A	W0330	2504Z			36-11-13	ALL
	PERG	1A	W0330	2505Z			36-11-13	ALL
	PERG	1A	W0330	2506Z			36-11-13	ALL
	PERG	1A	W0330	2507Z			36-11-13	ALL
	PERG	1A	W0330	2508Z			36-11-13	ALL
	PERG	1A	W0330	2509Z			36-11-13	ALL
	PERG	1A	W0330	2510Z			36-11-13	ALL
	PERG	1A	W0330	2511Z			36-11-14	ALL
	PERG	1A	W0330	2512Z			36-11-14	ALL
	PERG	1A	W0330	2513Z			36-11-14	ALL
	PERG	1A	W0330	2514Z			36-11-14	ALL
	PERG	1A	W0330	2524Z			36-11-24	ALL
	PERG	1A	W0330	2525Z			36-11-24	ALL
	PERG	1A	W0330	2528Z			36-21-11	ALL
	PERG	1A	W0330	2529Z			36-21-11	ALL
	PERG	1A	W0330	2530Z			36-11-13	ALL
	PERG	1A	W0330	3501Z			36-11-13	ALL
D15838B		**E003-03/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0330	0207	24		21-51-12	ALL
	A04	UNUSED						ALL
	A05		W0330	0454	24		21-61-14	ALL
	A06		W0330	0453	24		21-61-14	ALL
	A07	UNUSED						ALL
	A08		W0330	0520	24		21-51-12	ALL
	A09		W0330	0521	24		21-51-12	ALL
	A10	UNUSED						ALL
	A11		W0330	2031R	24		21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	A12		W0330	3001B	24		21-51-12	ALL
	A13	UNUSED						ALL
	A14		W0330	2024B	24		21-51-12	ALL
	A15		W0330	2024R	24		21-51-12	ALL
	B01		W0330	0208	24		21-51-12	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0330	0314	24		21-51-12	ALL
	B06		W0330	0315	24		21-51-12	ALL
	B07	UNUSED						ALL
	B08		W0330	2011B	24		21-61-14	ALL
	B09		W0330	2011R	24		21-61-14	ALL
	B10		W0330	2031B	24		21-51-12	ALL
	B11		W0330	3001R	24		21-51-12	ALL
	B12		W0330	3001Y	24		21-51-12	ALL
	B13	UNUSED						ALL
	B14		W0330	2026B	24		21-51-22	ALL
	B15		W0330	2026R	24		21-51-22	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W0330	0240	22		21-51-12	ALL
	C04	UNUSED						ALL
	C05		W0330	0393	24		21-61-11	ALL
	C06		W0330	0392	24		21-61-11	ALL
	C07	UNUSED						ALL
	C08		W0330	2010B	24		21-61-14	ALL
	C09		W0330	2010R	24		21-61-14	ALL
	C10		W0330	3010B	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	C11		W0330	3010Y	24		21-61-14	ALL
	C12		W0330	3010R	24		21-61-14	ALL
	C13	UNUSED						ALL
	C14		W0330	2021R	24		21-51-12	ALL
	C15		W0330	2021B	24		21-51-12	ALL
	D01		W0330	2032R	24		21-51-12	ALL
	D02		W0330	2032B	24		21-51-12	ALL
	D03	UNUSED						ALL
	D04		W0330	0214	24		21-51-11	ALL
	D05		W0330	0213	24		21-51-11	ALL
	D06	UNUSED						ALL
	D07		W0330	0212	24		21-51-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10		W0330	3004Y	24		21-61-12	ALL
	D11		W0330	3004B	24		21-61-12	ALL
	D12		W0330	3004R	24		21-61-12	ALL
	D13	UNUSED						ALL
	D14		W0330	2023R	24		21-51-12	ALL
	D15		W0330	2023B	24		21-51-12	ALL
	E01		W0330	0209	24		21-61-11	ALL
	E02		W0330	0210	24		21-61-11	ALL
	E03	UNUSED						ALL
	E04		W0330	0203	24		21-51-11	ALL
	E05		W0330	0202	24		21-51-12	ALL
	E06		W0330	0201	24		21-51-11	ALL
	E07		W0330	0206	24		21-51-12	ALL
	E08	UNUSED						ALL
	E09		W0330	2006R	24		21-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	E10		W0330	2006B	24		21-61-12	ALL
	E11		W0330	2005B	24		21-61-12	ALL
	E12		W0330	2005R	24		21-61-12	ALL
	E13	UNUSED						ALL
	E14		W0330	2027B	24		21-51-22	ALL
	E15		W0330	2027R	24		21-51-22	ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05		W0330	0379	24		21-61-11	ALL
	F06		W0330	0445	24		21-61-14	ALL
	F07		W0330	0224	24		21-51-12	ALL
	F08		W0330	0223	24		21-51-12	ALL
	F09		W0330	2001B	24		21-51-12	ALL
	F10		W0330	2001R	24		21-51-12	ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14		W0330	2025B	24		21-51-12	ALL
	F15		W0330	2025R	24		21-51-12	ALL
	G01		W0330	0401	24		21-61-12	ALL
	G02		W0330	0402	24		21-61-12	ALL
	G03		W0330	0334	24		21-51-14	ALL
	G04	UNUSED						ALL
	G05		W0330	0335	24		21-51-14	ALL
	G06		W0330	0336	24		21-51-14	ALL
	G07		W0330	0337	24		21-51-14	ALL
	G08		W0330	0338	24		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0330	0306	24		21-51-12	ALL
	H02		W0330	0444	24		21-61-14	ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05		W0330	0404	24		21-61-12	ALL
	H06		W0330	0446	24		21-61-14	ALL
	H07		W0330	0414	24		21-61-13	ALL
	H08		W0330	0467	22		21-61-15	ALL
	H09		W0330	0532	24		21-51-14	ALL
	H10		W0330	0533	24		21-51-14	ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14		W0330	2020R	24		21-51-12	ALL
	H15		W0330	2020B	24		21-51-12	ALL
	J01		W0330	0307	24		21-51-12	ALL
	J02		W0330	0348	24		21-51-22	ALL
	J03		W0330	0325	24		21-51-13	ALL
	J04	UNUSED						ALL
	J05		W0330	0333	24		21-51-14	ALL
	J06		W0330	0303	24		21-51-12	ALL
	J07		W0330	0342	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	J08		W0330	0363	24		21-51-23	ALL
	J09		W0330	0317	24		21-51-12	ALL
	J10		W0330	0318	24		21-51-12	ALL
	J11	UNUSED						ALL
	J12		W0330	2502R	24		31-65-14	ALL
	J13		W0330	2502B	24		31-65-14	ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0330	0326	24		21-51-13	ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06		W0330	0245	24		21-51-11	ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09		W0330	0364	24		21-51-23	ALL
	K10	UNUSED						ALL
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	PERG	1A	W0330	2020Z			21-51-12	ALL
	PERG	1A	W0330	2021Z			21-51-12	ALL
	PERG	1A	W0330	2023Z			21-51-12	ALL
	PERG	1A	W0330	2024Z			21-51-12	ALL
	PERG	1A	W0330	2025Z			21-51-12	ALL
	PERG	1A	W0330	2026Z			21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838B	**E003-03/ /**		**PLUG- (continued)**				**ALL**
PERG	1A	W0330	2027Z			21-51-22	ALL
PERG	1A	W0330	2031Z			21-51-12	ALL
PERG	1A	W0330	2032Z			21-51-12	ALL
PERG	1A	W0330	2502Z			31-65-14	ALL
PERG	1A	W0330	3001Z			21-51-12	ALL
D15838C	**E003-03/ /**		**PLUG-**				**ALL**
1		W0330	0422	24		21-61-14	ALL
2		W0330	0301	24		21-51-12	ALL
3	UNUSED						ALL
4		W0330	2007R	24		21-61-13	ALL
5		W0330	0322	24		21-51-13	ALL
6		W0330	0368	24		21-51-23	ALL
7		W0330	0423	24		21-61-14	ALL
8		W0330	0302	24		21-51-12	ALL
9	UNUSED						ALL
10		W0330	2007B	24		21-61-13	ALL
11		W0330	0360	24		21-51-23	ALL
12		W0330	0367	24		21-51-23	ALL
13		W0330	0400	24		21-61-12	ALL
14		W0330	0399	24		21-61-12	ALL
15	UNUSED						ALL
16		W0330	0366	24		21-51-23	ALL
17		W0330	3007R	24		21-61-13	ALL
18		W0330	3007B	24		21-61-13	ALL
19		W0330	0309	24		21-51-12	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W0330	0365	24		21-51-23	ALL
23		W0330	3007Y	24		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15838C		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	24		W0330	0308	24		21-51-12	ALL
	25		W0330	0313	22		21-51-12	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0330	0316	22		21-51-12	ALL
	30		W0330	0319	22		21-51-12	ALL
	31		W0330	0211	22		21-51-12	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
D15840A		**E003-03/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0330	2517B	22		36-11-23	ALL
	A06		W0330	2517R	22		36-11-23	ALL
	A07		W0330	2520B	22		36-11-23	ALL
	A08		W0330	2520R	22		36-11-23	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0330	2526R	24		36-21-11	ALL
	A13		W0330	2526B	24		36-21-11	ALL
	A14	UNUSED						ALL
	A15		W0330	2519B	22		36-11-23	ALL
	B01		W0330	2515R	22		36-11-23	ALL
	B02		W0330	2515B	22		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A	**E003-03/ /**		**PLUG (continued)**				**ALL**
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W0330	2519R	22		36-11-23	ALL
C01		W0330	2516R	22		36-11-23	ALL
C02		W0330	2516B	22		36-11-23	ALL
C03	UNUSED						ALL
C04		W0330	0053	24		36-11-24	ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11		W0330	2601R	24		31-65-25	ALL
C12		W0330	2601B	24		31-65-25	ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15		W0330	2527B	24		36-21-11	ALL
D01		W0330	2521R	22		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A		**E003-03/ /**		**PLUG (continued)**				**ALL**
	D02		W0330	2521B	22		36-11-23	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06		W0330	0051	24		36-11-24	ALL
	D07		W0330	0052	24		36-11-24	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12		W0330	2523R	24		36-11-24	ALL
	D13		W0330	2523B	24		36-11-24	ALL
	D14	UNUSED						ALL
	D15		W0330	2527R	24		36-21-11	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0330	0058	24		36-11-31	ALL
	E05		W0330	0059	24		36-11-31	ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10		W0330	2513R	24		36-11-14	ALL
	E11		W0330	2513B	24		36-11-14	ALL
	E12		W0330	2514R	24		36-11-14	ALL
	E13		W0330	2514B	24		36-11-14	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A		**E003-03/ /**		**PLUG (continued)**				**ALL**
	F01		W0330	0094	22		36-11-23	ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04		W0330	0032	24		36-11-22	ALL
	F05		W0330	0036	24		36-11-22	ALL
	F06	UNUSED						ALL
	F07		W0330	0048	24		36-11-23	ALL
	F08		W0330	0057	24		36-11-31	ALL
	F09	UNUSED						ALL
	F10		W0330	2524R	24		36-11-24	ALL
	F11		W0330	2524B	24		36-11-24	ALL
	F12		W0330	2525R	24		36-11-24	ALL
	F13		W0330	2525B	24		36-11-24	ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04		W0330	3502R	22		36-11-23	ALL
	G05		W0330	3502Y	22		36-11-23	ALL
	G06		W0330	3502B	22		36-11-23	ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A		**E003-03/ /**		**PLUG (continued)**				**ALL**
	G15	UNUSED						ALL
	H01		W0330	0040	22		36-11-23	ALL
	H02	UNUSED						ALL
	H03		W0330	0092	22		36-11-23	ALL
	H04		W0330	0513	22		30-21-32	ALL
	H05		W0330	2531R	22		36-11-23	ALL
	H06		W0330	2531B	22		36-11-23	ALL
	H07		W0330	2518R	22		36-11-23	ALL
	H08		W0330	2518B	22		36-11-23	ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15		W0330	0043	22		36-11-23	ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03		W0330	0034	24		36-11-22	ALL
	J04		W0330	0033	24		36-11-22	ALL
	J05		W0330	0031	24		36-11-22	ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10		W0330	2522R	24		36-11-24	ALL
	J11		W0330	2522B	24		36-11-24	ALL
	J12	UNUSED						ALL
	J13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A	**E003-03/ /**		**PLUG (continued)**				**ALL**
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0330	0049	22		36-11-23	ALL
K02	UNUSED						ALL
K03		W0330	0035	24		36-11-22	ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06		W0330	0046	24		36-11-23	ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09		W0330	0038	24		36-11-22	ALL
K10		W0330	0512	22		30-21-32	ALL
K11		W0330	0037	24		36-11-22	ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15		W0330	0042	22		36-11-23	ALL
PERG	1A	W0330	2513Z			36-11-14	ALL
PERG	1A	W0330	2514Z			36-11-14	ALL
PERG	1A	W0330	2515Z			36-11-23	ALL
PERG	1A	W0330	2516Z			36-11-23	ALL
PERG	1A	W0330	2517Z			36-11-23	ALL
PERG	1A	W0330	2518Z			36-11-23	ALL
PERG	1A	W0330	2519Z			36-11-23	ALL
PERG	1A	W0330	2520Z			36-11-23	ALL
PERG	1A	W0330	2521Z			36-11-23	ALL
PERG	1A	W0330	2522Z			36-11-24	ALL
PERG	1A	W0330	2523Z			36-11-24	ALL
PERG	1A	W0330	2524Z			36-11-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840A		**E003-03/ /**		**PLUG (continued)**				**ALL**
	PERG	1A	W0330	2525Z			36-11-24	ALL
	PERG	1A	W0330	2526Z			36-21-11	ALL
	PERG	1A	W0330	2527Z			36-21-11	ALL
	PERG	1A	W0330	2531Z			36-11-23	ALL
	PERG	1A	W0330	2601Z			31-65-25	ALL
	PERG	1A	W0330	3502Z			36-11-23	ALL
D15840B		**E003-03/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0330	0508	24		21-51-21	ALL
	A04	UNUSED						ALL
	A05		W0330	0419	24		21-61-13	ALL
	A06		W0330	0418	24		21-61-13	ALL
	A07	UNUSED						ALL
	A08		W0330	0080	24		21-51-22	ALL
	A09		W0330	0081	24		21-51-22	ALL
	A10	UNUSED						ALL
	A11		W0330	2033R	24		21-51-22	ALL
	A12		W0330	3002B	24		21-51-22	ALL
	A13	UNUSED						ALL
	A14		W0330	2026B	24		21-51-22	ALL
	A15		W0330	2026R	24		21-51-22	ALL
	B01		W0330	0510	24		21-51-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0330	0350	24		21-51-22	ALL
	B06		W0330	0351	24		21-51-22	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840B	**E003-03/ /**		**PLUG- (continued)**				**ALL**
B08		W0330	2009B	24		21-61-13	ALL
B09		W0330	2009R	24		21-61-13	ALL
B10		W0330	2033B	24		21-51-22	ALL
B11		W0330	3002R	24		21-51-22	ALL
B12		W0330	3002Y	24		21-51-22	ALL
B13	UNUSED						ALL
B14		W0330	2024B	24		21-51-12	ALL
B15		W0330	2024R	24		21-51-12	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04		W0330	0527	24		21-51-22	ALL
C05		W0330	0396	24		21-61-11	ALL
C06		W0330	0395	24		21-61-11	ALL
C07	UNUSED						ALL
C08		W0330	2008R	24		21-61-13	ALL
C09		W0330	2008B	24		21-61-13	ALL
C10		W0330	3008Y	24		21-61-13	ALL
C11		W0330	3008B	24		21-61-13	ALL
C12		W0330	3008R	24		21-61-13	ALL
C13	UNUSED						ALL
C14		W0330	2029R	24		21-51-22	ALL
C15		W0330	2029B	24		21-51-22	ALL
D01		W0330	2034R	24		21-51-22	ALL
D02		W0330	2034B	24		21-51-22	ALL
D03	UNUSED						ALL
D04		W0330	0244	24		21-51-21	ALL
D05		W0330	0243	24		21-51-21	ALL
D06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	D07		W0330	0242	24		21-51-21	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10		W0330	3003Y	24		21-61-11	ALL
	D11		W0330	3003B	24		21-61-11	ALL
	D12		W0330	3003R	24		21-61-11	ALL
	D13	UNUSED						ALL
	D14		W0330	2030R	24		21-51-22	ALL
	D15		W0330	2030B	24		21-51-22	ALL
	E01		W0330	0505	24		21-51-21	ALL
	E02		W0330	0506	24		21-51-21	ALL
	E03	UNUSED						ALL
	E04		W0330	0509	24		21-51-21	ALL
	E05		W0330	0511	24		21-51-21	ALL
	E06		W0330	0204	24		21-51-11	ALL
	E07		W0330	0507	24		21-51-21	ALL
	E08	UNUSED						ALL
	E09		W0330	2004R	24		21-61-11	ALL
	E10		W0330	2004B	24		21-61-11	ALL
	E11		W0330	2003B	24		21-61-11	ALL
	E12		W0330	2003R	24		21-61-11	ALL
	E13	UNUSED						ALL
	E14		W0330	2025B	24		21-51-12	ALL
	E15		W0330	2025R	24		21-51-12	ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05		W0330	0462	24		21-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840B	**E003-03/ /**		**PLUG- (continued)**				**ALL**
F06		W0330	0410	24		21-61-13	ALL
F07		W0330	0232	24		21-51-22	ALL
F08		W0330	0233	24		21-51-22	ALL
F09		W0330	2002R	24		21-51-22	ALL
F10		W0330	2002B	24		21-51-22	ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14		W0330	2027B	24		21-51-22	ALL
F15		W0330	2027R	24		21-51-22	ALL
G01		W0330	0380	24		21-61-11	ALL
G02		W0330	0386	24		21-61-11	ALL
G03		W0330	0372	24		21-51-24	ALL
G04	UNUSED						ALL
G05		W0330	0373	24		21-51-24	ALL
G06		W0330	0374	24		21-51-24	ALL
G07		W0330	0375	24		21-51-24	ALL
G08		W0330	0376	24		21-51-24	ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL
G13	UNUSED						ALL
G14	UNUSED						ALL
G15	UNUSED						ALL
H01		W0330	0343	24		21-51-22	ALL
H02		W0330	0409	24		21-61-13	ALL
H03	UNUSED						ALL
H04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840B		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	H05		W0330	0385	24		21-61-11	ALL
	H06		W0330	0411	24		21-61-13	ALL
	H07		W0330	0449	24		21-61-14	ALL
	H08		W0330	0466	22		21-61-15	ALL
	H09		W0330	0534	24		21-51-24	ALL
	H10		W0330	0535	24		21-51-24	ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14		W0330	2028R	24		21-51-22	ALL
	H15		W0330	2028B	24		21-51-22	ALL
	J01		W0330	0344	24		21-51-22	ALL
	J02		W0330	0312	24		21-51-12	ALL
	J03		W0330	0363	24		21-51-23	ALL
	J04	UNUSED						ALL
	J05		W0330	0371	24		21-51-24	ALL
	J06		W0330	0340	24		21-51-22	ALL
	J07		W0330	0305	24		21-51-12	ALL
	J08		W0330	0325	24		21-51-13	ALL
	J09		W0330	0353	24		21-51-22	ALL
	J10		W0330	0354	24		21-51-22	ALL
	J11	UNUSED						ALL
	J12		W0330	2503R	24		31-65-24	ALL
	J13		W0330	2503B	24		31-65-24	ALL
	J14	UNUSED						ALL
	J15	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0330	0364	24		21-51-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840B	**E003-03/ /**		**PLUG- (continued)**				**ALL**
K04	UNUSED						ALL
K05	UNUSED						ALL
K06		W0330	0525	24		21-51-21	ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09		W0330	0326	24		21-51-13	ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
PERG	1A	W0330	2024Z			21-51-12	ALL
PERG	1A	W0330	2025Z			21-51-12	ALL
PERG	1A	W0330	2026Z			21-51-22	ALL
PERG	1A	W0330	2027Z			21-51-22	ALL
PERG	1A	W0330	2028Z			21-51-22	ALL
PERG	1A	W0330	2029Z			21-51-22	ALL
PERG	1A	W0330	2030Z			21-51-22	ALL
PERG	1A	W0330	2033Z			21-51-22	ALL
PERG	1A	W0330	2034Z			21-51-22	ALL
PERG	1A	W0330	2503Z			31-65-24	ALL
PERG	1A	W0330	3002Z			21-51-22	ALL
D15840C	**E003-03/ /**		**PLUG-**				**ALL**
1		W0330	0407	24		21-61-13	ALL
2		W0330	0461	24		21-51-22	ALL
3	UNUSED						ALL
4		W0330	2012R	24		21-61-14	ALL
5		W0330	0360	24		21-51-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15840C		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	6		W0330	0330	24		21-51-13	ALL
	7		W0330	0408	24		21-61-13	ALL
	8		W0330	0339	24		21-51-22	ALL
	9	UNUSED						ALL
	10		W0330	2012B	24		21-61-14	ALL
	11		W0330	0322	24		21-51-13	ALL
	12		W0330	0329	24		21-51-13	ALL
	13		W0330	0382	24		21-61-11	ALL
	14		W0330	0381	24		21-61-11	ALL
	15	UNUSED						ALL
	16		W0330	0328	24		21-51-13	ALL
	17		W0330	3009Y	24		21-61-14	ALL
	18		W0330	3009R	24		21-61-14	ALL
	19		W0330	0346	22		21-51-22	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W0330	0327	24		21-51-13	ALL
	23		W0330	3009B	24		21-61-14	ALL
	24		W0330	0345	24		21-51-22	ALL
	25		W0330	0349	24		21-51-22	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0330	0352	24		21-51-22	ALL
	30		W0330	0355	24		21-51-22	ALL
	31		W0330	0215	22		21-51-22	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15854	**537/ /**		**PLUG-**				**ALL**
1		W5102	2007B	22		36-21-11	ALL
2	UNUSED						ALL
3		W5102	2007R	22		36-21-11	ALL
4	UNUSED						ALL
5		W5102	5515	22		36-21-11	ALL
6	UNUSED						ALL
D15856	**538/165/R030**		**PLUG-CONDUCTIVE**				**ALL**
1		W6202	2007B	22		36-21-11	ALL
2	UNUSED						ALL
3		W6202	2007R	22		36-21-11	ALL
4	UNUSED						ALL
5		W6202	5515	22		36-21-11	ALL
6	UNUSED						ALL
D15866	**NSTA 262/146/R013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1170	2012R	20		36-11-13	ALL
2		W1170	2012B	20		36-11-13	ALL
3		W1170	0007	20		36-11-13	ALL
4	UNUSED						ALL
5	UNUSED						ALL
PERB		W1170	2012Z			36-11-13	ALL
D15868	**NSTA 262/146/R013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1270	2012R	20		36-11-23	ALL
2		W1270	2012B	20		36-11-23	ALL
3		W1270	0007	20		36-11-23	ALL
4	UNUSED						ALL
5	UNUSED						ALL
PERB		W1270	2012Z			36-11-23	ALL
D15870	**NSTA 262/146/R013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1170	2007R	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15870		**NSTA 262/146/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2		W1170	2007B	20		36-11-13	ALL
	3		W1170	2008R	20		36-11-13	ALL
	4		W1170	2008B	20		36-11-13	ALL
	5		W1170	0008	20		36-11-13	ALL
	6	UNUSED						ALL
	PERB		W1170	2007Z			36-11-13	ALL
	PERB		W1170	2008Z			36-11-13	ALL
D15872		**NSTA 262/146/R013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1270	2007R	20		36-11-23	ALL
	2		W1270	2007B	20		36-11-23	ALL
	3		W1270	2008R	20		36-11-23	ALL
	4		W1270	2008B	20		36-11-23	ALL
	5		W1270	0008	20		36-11-23	ALL
	6	UNUSED						ALL
	PERB		W1270	2007Z			36-11-23	ALL
	PERB		W1270	2008Z			36-11-23	ALL
D15874		**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1198	0008	20		36-11-13	ALL
	2		W1198	3004Y	20		36-11-13	ALL
	3	UNUSED						ALL
	4		W1198	2012B	20		36-11-13	ALL
	5	UNUSED						ALL
	6		W1198	2011R	20		36-11-13	ALL
	7		W1198	2011B	20		36-11-13	ALL
	8		W1198	3004B	20		36-11-13	ALL
	9		W1198	3004R	20		36-11-13	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W1198	2012R	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15874	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
PERB		W1198	2011Z			36-11-13	ALL
PERB		W1198	2012Z			36-11-13	ALL
PERB		W1198	3004Z			36-11-13	ALL
D15876	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1		W1298	0008	20		36-11-23	ALL
2		W1298	3004Y	20		36-11-23	ALL
3	UNUSED						ALL
4		W1298	2012B	20		36-11-23	ALL
5	UNUSED						ALL
6		W1298	2011R	20		36-11-23	ALL
7		W1298	2011B	20		36-11-23	ALL
8		W1298	3004B	20		36-11-23	ALL
9		W1298	3004R	20		36-11-23	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W1298	2012R	20		36-11-23	ALL
PERB		W1298	2011Z			36-11-23	ALL
PERB		W1298	2012Z			36-11-23	ALL
PERB		W1298	3004Z			36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15906		**P006-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0041	2539R	24		31-32-15	ALL
	A2		W0041	2541R	24		31-32-15	ALL
	A3	UNUSED						ALL
	B1		W0041	2539B	24		31-32-15	ALL
	B2		W0041	2541B	24		31-32-15	ALL
	B3	UNUSED						ALL
	X1		W0041	0119	22		46-13-11	ALL
	X2		W0041	0120	22		46-13-11	ALL
	CAP	Y	W0041	2503B	22		31-32-15	ALL
	CAP	Y	W0041	2503R	22		31-32-15	ALL
	DED		W0041	2503Z			31-32-15	ALL
	DED		W0041	2539Z			31-32-15	ALL
	DED		W0041	2541Z			31-32-15	ALL
D15934		**528/200/**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W1664	1029	20		33-42-21	ALL
	3	UNUSED						ALL
	4		W1664	1027	18		33-42-21	ALL
	5	UNUSED						ALL
	6		W1664	1028	20		33-42-21	ALL
	7		W1664	1025	18		33-42-21	ALL
	8		W1664	1036	20		33-42-21	ALL
	9		W1664	1037	20		33-42-21	ALL
	10		W1664	0019	18		33-42-21	ALL
	11		W1664	1030	20		33-42-21	ALL
	12		W1664	1031	20		33-42-21	ALL
	S/R		W1664	1025Z			33-42-21	ALL
	S/R		W1664	1027Z			33-42-21	ALL
	S/R		W1664	1028Z			33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15934	**528/200/**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W1664	1029Z			33-42-21	ALL
S/R		W1664	1030Z			33-42-21	ALL
S/R		W1664	1031Z			33-42-21	ALL
S/R		W1664	1036Z			33-42-21	ALL
S/R		W1664	1037Z			33-42-21	ALL
D15948	**528/200/L084**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W1662	1021	20		33-42-21	ALL
3	UNUSED						ALL
4		W1662	1023	18		33-42-21	ALL
5	UNUSED						ALL
6		W1662	1022	20		33-42-21	ALL
7		W1662	1024	18		33-42-21	ALL
8		W1662	1018	20		33-42-21	ALL
9		W1662	1017	20		33-42-21	ALL
10		W1662	0019	18		33-42-21	ALL
11		W1662	1020	20		33-42-21	ALL
12		W1662	1019	20		33-42-21	ALL
S/R		W1662	1017Z			33-42-21	ALL
S/R		W1662	1018Z			33-42-21	ALL
S/R		W1662	1019Z			33-42-21	ALL
S/R		W1662	1020Z			33-42-21	ALL
S/R		W1662	1021Z			33-42-21	ALL
S/R		W1662	1022Z			33-42-21	ALL
S/R		W1662	1023Z			33-42-21	ALL
S/R		W1662	1024Z			33-42-21	ALL
D15962	**P009-00/ /**		**PLUG-- CONDUCTIVE**				**ALL**
1		W2873	0016	20		33-11-41	ALL
2		W2873	0017	20		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D15962		**P009-00/ /**		**PLUG-- CONDUCTIVE (continued)**				**ALL**
	3		W0003	0610	22		29-32-11	ALL
	4		W0003	2516B	22		29-32-11	ALL
	5		W0003	2516R	22		29-32-11	ALL
	S/R		W0003	2516Z			29-32-11	ALL
D15964		**OFSS758/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1244	1105	20		33-43-11	ALL
	2		W1244	0006	20		33-43-11	ALL
	3	UNUSED						ALL
	S/R		W1244	1105Z			33-43-11	ALL
D15966		**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	1		W0244	2501R	20		33-43-11	ALL
	2		W0244	2501B	20		33-43-11	ALL
	3		W0244	1001	20		33-43-11	ALL
	S/R		W0244	1001Z			33-43-11	ALL
	S/R		W0244	2501ZI			33-43-11	ALL
	S/R		W0244	2501ZO			33-43-11	ALL
D15968		**OFSS758/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1242	1105	20		33-43-11	ALL
	2		W1242	0006	20		33-43-11	ALL
	3	UNUSED						ALL
	S/R		W1242	1105Z			33-43-11	ALL
D15970		**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	1		W0242	2501R	20		33-43-11	ALL
	2		W0242	2501B	20		33-43-11	ALL
	3		W0242	1001	20		33-43-11	ALL
	S/R		W0242	1001Z			33-43-11	ALL
	S/R		W0242	2501ZI			33-43-11	ALL
	S/R		W0242	2501ZO			33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15972	**OFSS745/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1		W1664	1010	20		33-43-11	ALL
2		W1244	0003	20		33-43-11	ALL
3		W1244	1101	20		33-43-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1244	0002	20		33-43-11	ALL
S/R		W1244	1101Z			33-43-11	ALL
S/R		W1664	1010Z			33-43-11	ALL
D15974	**OFSS745/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1		W1662	1010	20		33-43-11	ALL
2		W1242	0003	20		33-43-11	ALL
3		W1242	1101	20		33-43-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1242	0002	20		33-43-11	ALL
S/R		W1242	1101Z			33-43-11	ALL
S/R		W1662	1010Z			33-43-11	ALL
D15976	**1226/277/R15**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W7152	3502Y	18		33-44-12	ALL
3		W7152	3502R	18		33-43-11	ALL
4	UNUSED						ALL
5		W7152	3502B	18		33-43-11	ALL
6		W7152	1002	18		33-43-11	ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15976		**1226/277/R15**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	S/R		W7152	1002Z			33-43-11	ALL
	S/R		W7152	3502ZI			33-43-11	ALL
	S/R		W7152	3502ZO			33-43-11	ALL
D15978		**1226/277/L15**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2		W7152	3501Y	18		33-44-12	ALL
	3		W7152	3501R	18		33-43-11	ALL
	4	UNUSED						ALL
	5		W7152	3501B	18		33-43-11	ALL
	6		W7152	1003	18		33-43-11	ALL
	7	UNUSED						ALL
	S/R		W7152	1003Z			33-43-11	ALL
	S/R		W7152	3501ZI			33-43-11	ALL
	S/R		W7152	3501ZO			33-43-11	ALL
D15980		**1082/272/L030**		**PLUG-CONDUCTIVE**				**ALL**
	1		W4724	1037	20		33-43-11	ALL
	2		W4724	1038	18		33-43-11	ALL
	3		W4724	1039	18		33-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W4724	1040	18		33-43-11	ALL
	S/R		W4724	1037Z			33-43-11	ALL
	S/R		W4724	1038Z			33-43-11	ALL
	S/R		W4724	1039Z			33-43-11	ALL
	S/R		W4724	1040Z			33-43-11	ALL
D15982		**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	1		W0264	2501R	18		33-44-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15982	**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR (continued)**				**ALL**
2		W0264	2501B	18		33-44-12	ALL
3	UNUSED						ALL
S/R		W0264	2501ZI			33-44-12	ALL
S/R		W0264	2501ZO			33-44-12	ALL
D15984	**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
1		W0262	2501R	18		33-44-12	ALL
2		W0262	2501B	18		33-44-12	ALL
3	UNUSED						ALL
S/R		W0262	2501ZI			33-44-12	ALL
S/R		W0262	2501ZO			33-44-12	ALL
D15986	**OFSS740/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1664	1011	20		33-44-12	ALL
2		W1244	0023	18		33-44-12	ALL
3		W1244	1121	18		33-44-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1244	0022	18		33-44-12	ALL
S/R		W1244	1121Z			33-44-12	ALL
S/R		W1664	1011Z			33-44-12	ALL
D15988	**OFSS740/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1662	1011	20		33-44-12	ALL
2		W1242	0023	18		33-44-12	ALL
3		W1242	1121	18		33-44-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15988		**OFSS740/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8		W1242	0022	18		33-44-12	ALL
	S/R		W1242	1121Z			33-44-12	ALL
	S/R		W1662	1011Z			33-44-12	ALL
D15990		**1082/272/L033**		**PLUG-CONDUCTIVE**				**ALL**
	1		W4724	1009	20		33-44-12	ALL
	2		W4724	1010	18		33-44-12	ALL
	3		W4724	1011	18		33-44-12	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W4724	1012	18		33-44-12	ALL
	S/R		W4724	1009Z			33-44-12	ALL
	S/R		W4724	1010Z			33-44-12	ALL
	S/R		W4724	1011Z			33-44-12	ALL
	S/R		W4724	1012Z			33-44-12	ALL
D15998A		***/*/***		**PLUG**				**ALL**
	A01		W0321	2408R	24		22-11-51	ALL
	A02		W0321	2408B	24		22-11-51	ALL
	A03	UNUSED						ALL
	A04		W0325	2263B	22		27-61-48	ALL
	A05		W0325	3026R	22		27-61-48	ALL
	A06		W0325	2267B	22		27-61-48	ALL
	A07		W0325	3028R	22		27-61-48	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0325	2307B	22		27-61-44	ALL
	A12		W0325	3100R	22		27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A		*/*/*		**PLUG (continued)**				**ALL**
	A13	UNUSED						ALL
	A14		W0325	2310B	22		27-61-44	ALL
	A15		W0325	3103R	22		27-61-44	ALL
	B01		W0321	2358R	24		31-31-13	ALL
	B02		W0321	2358B	24		31-31-13	ALL
	B03	UNUSED						ALL
	B04		W0325	2263R	22		27-61-48	ALL
	B05		W0325	3026B	22		27-61-48	ALL
	B06		W0325	2267R	22		27-61-48	ALL
	B07		W0325	3028B	22		27-61-48	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0325	2307R	22		27-61-44	ALL
	B12		W0325	3100B	22		27-61-44	ALL
	B13	UNUSED						ALL
	B14		W0325	2310R	22		27-61-44	ALL
	B15		W0325	3103B	22		27-61-44	ALL
	C01		W0321	2313R	24		27-61-47	ALL
	C02		W0321	2313B	24		27-61-47	ALL
	C03	UNUSED						ALL
	C04		W0325	2264B	22		27-61-48	ALL
	C05		W0325	3026Y	22		27-61-48	ALL
	C06		W0325	2268B	22		27-61-48	ALL
	C07		W0325	3028Y	22		27-61-48	ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A		***/*/***		**PLUG (continued)**				**ALL**
	C12		W0325	3100Y	22		27-61-44	ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15		W0325	3103Y	22		27-61-44	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0325	2264R	22		27-61-48	ALL
	D05	UNUSED						ALL
	D06		W0325	2268R	22		27-61-48	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A		*/*/*		**PLUG (continued)**				**ALL**
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08		W0321	0751	22		27-61-49	ALL
	F09		W0321	0971	22		27-62-11	ALL
	F10		W0321	0972	22		27-62-11	ALL
	F11		W0321	0970	22		27-62-11	ALL
	F12		W0321	0628	22		27-61-45	ALL
	F13		W0321	0752	22		27-61-49	ALL
	F14	UNUSED						ALL
	F15		W0321	0621	22		27-61-45	ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04		W0321	0614	22		27-61-42	ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A		***/*/***		**PLUG (continued)**				**ALL**
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08		W0321	0741	22		27-61-49	ALL
	H09		W0321	0936	22		27-62-11	ALL
	H10		W0321	0947	22		27-62-11	ALL
	H11		W0325	0589	22		27-62-11	ALL
	H12		W0321	0627	22		27-61-45	ALL
	H13		W0321	0754	22		27-61-49	ALL
	H14	UNUSED						ALL
	H15		W0321	0623	22		27-61-45	ALL
	J01		W0321	2373R	24		34-21-13	ALL
	J02		W0321	2374R	24		34-21-14	ALL
	J03		W0321	2407R	24		22-11-51	ALL
	J04		W0321	2283R	24		34-33-11	ALL
	J05		W0321	2247R	24		27-32-12	ALL
	J06		W0321	2249R	24		31-65-15	ALL
	J07		W0321	2369R	22		31-32-15	ALL
	J08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A	*/*/*		**PLUG (continued)**				**ALL**
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0321	2373B	24		34-21-13	ALL
K02		W0321	2374B	24		34-21-14	ALL
K03		W0321	2407B	24		22-11-51	ALL
K04		W0321	2283B	24		34-33-11	ALL
K05		W0321	2247B	24		27-32-12	ALL
K06		W0321	2249B	24		31-65-15	ALL
K07		W0321	2369B	22		31-32-15	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12		W0321	0610	22		27-61-42	ALL
K13		W0321	0611	22		27-61-42	ALL
K14		W0321	0935	22		27-62-11	ALL
K15		W0321	0980	22		27-61-49	ALL
PERG	1A	W0321	2247Z			27-32-12	ALL
PERG	1A	W0321	2249Z			31-65-15	ALL
PERG	1A	W0321	2283Z			34-33-11	ALL
PERG	1A	W0321	2313Z			27-61-47	ALL
PERG	1A	W0321	2358Z			31-31-13	ALL
PERG	1A	W0321	2369Z			31-32-15	ALL
PERG	1A	W0321	2373Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998A		***/*/***		**PLUG (continued)**				**ALL**
	PERG	1A	W0321	2374Z			34-21-14	ALL
	PERG	1A	W0321	2407Z			22-11-51	ALL
	PERG	1A	W0321	2408Z			22-11-51	ALL
	PERG	1A	W0325	2263Z			27-61-48	ALL
	PERG	1A	W0325	2264Z			27-61-48	ALL
	PERG	1A	W0325	2267Z			27-61-48	ALL
	PERG	1A	W0325	2268Z			27-61-48	ALL
	PERG	1A	W0325	2307Z			27-61-44	ALL
	PERG	1A	W0325	2310Z			27-61-44	ALL
	PERG	1A	W0325	3026Z			27-61-48	ALL
	PERG	1A	W0325	3028Z			27-61-48	ALL
	PERG	1A	W0325	3100Z			27-61-44	ALL
	PERG	1A	W0325	3103Z			27-61-44	ALL
D15998B		***/*/***		**PLUG**				**ALL**
	A01		W0321	2410R	24		22-11-51	ALL
	A02		W0321	2410B	24		22-11-51	ALL
	A03	UNUSED						ALL
	A04		W0326	2271B	22		27-61-48	ALL
	A05		W0326	3030R	22		27-61-48	ALL
	A06		W0326	2275B	22		27-61-48	ALL
	A07		W0326	3032R	22		27-61-48	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0326	2308B	22		27-61-44	ALL
	A12		W0326	3101R	22		27-61-44	ALL
	A13	UNUSED						ALL
	A14		W0326	2311B	22		27-61-44	ALL
	A15		W0326	3104R	22		27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B	*/*/*		**PLUG (continued)**				**ALL**
B01		W0321	2356R	24		31-31-13	ALL
B02		W0321	2356B	24		31-31-13	ALL
B03	UNUSED						ALL
B04		W0326	2271R	22		27-61-48	ALL
B05		W0326	3030B	22		27-61-48	ALL
B06		W0326	2275R	22		27-61-48	ALL
B07		W0326	3032B	22		27-61-48	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0326	2308R	22		27-61-44	ALL
B12		W0326	3101B	22		27-61-44	ALL
B13	UNUSED						ALL
B14		W0326	2311R	22		27-61-44	ALL
B15		W0326	3104B	22		27-61-44	ALL
C01		W0321	2315R	24		27-61-47	ALL
C02		W0321	2315B	24		27-61-47	ALL
C03	UNUSED						ALL
C04		W0326	2272B	22		27-61-48	ALL
C05		W0326	3030Y	22		27-61-48	ALL
C06		W0326	2276B	22		27-61-48	ALL
C07		W0326	3032Y	22		27-61-48	ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12		W0326	3101Y	22		27-61-44	ALL
C13	UNUSED						ALL
C14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B		***/*/***		**PLUG (continued)**				**ALL**
	C15		W0326	3104Y	22		27-61-44	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0326	2272R	22		27-61-48	ALL
	D05	UNUSED						ALL
	D06		W0326	2276R	22		27-61-48	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL
	E08	UNUSED						ALL
	E09	UNUSED						ALL
	E10	UNUSED						ALL
	E11	UNUSED						ALL
	E12	UNUSED						ALL
	E13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B	*/*/*		**PLUG (continued)**				**ALL**
E14	UNUSED						ALL
E15	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08		W0321	0973	22		27-62-11	ALL
F09		W0321	0832	22		27-62-11	ALL
F10		W0321	0831	22		27-62-11	ALL
F11		W0321	0630	22		27-61-45	ALL
F12		W0321	2285B	22		27-62-11	ALL
F13		W0321	0749	22		27-61-49	ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01	UNUSED						ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04		W0321	0615	22		27-61-42	ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL
G08	UNUSED						ALL
G09	UNUSED						ALL
G10	UNUSED						ALL
G11	UNUSED						ALL
G12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B		***/*/***		**PLUG (continued)**				**ALL**
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08		W0321	0940	22		27-62-11	ALL
	H09		W0321	0585	22		27-62-11	ALL
	H10		W0321	0588	22		27-62-11	ALL
	H11		W0321	0629	22		27-61-45	ALL
	H12		W0321	2285R	22		27-62-11	ALL
	H13		W0321	0750	22		27-61-49	ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01		W0321	2376R	24		34-21-23	ALL
	J02		W0321	2377R	24		34-21-24	ALL
	J03		W0321	2409R	24		22-11-51	ALL
	J04		W0321	2284R	24		34-33-21	ALL
	J05		W0321	2296R	24		27-32-22	ALL
	J06		W0321	2282R	24		31-65-25	ALL
	J07		W0321	2009R	22		31-32-15	ALL
	J08	UNUSED						ALL
	J09	UNUSED						ALL
	J10	UNUSED						ALL
	J11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B	*/*/*		**PLUG (continued)**				**ALL**
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01		W0321	2376B	24		34-21-23	ALL
K02		W0321	2377B	24		34-21-24	ALL
K03		W0321	2409B	24		22-11-51	ALL
K04		W0321	2284B	24		34-33-21	ALL
K05		W0321	2296B	24		27-32-22	ALL
K06		W0321	2282B	24		31-65-25	ALL
K07		W0321	2009B	22		31-32-15	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL
K11	UNUSED						ALL
K12		W0321	0612	22		27-61-42	ALL
K13		W0321	0613	22		27-61-42	ALL
K14	UNUSED						ALL
K15	UNUSED						ALL
PERG	1A	W0321	2009Z			31-32-15	ALL
PERG	1A	W0321	2282Z			31-65-25	ALL
PERG	1A	W0321	2284Z			34-33-21	ALL
PERG	1A	W0321	2296Z			27-32-22	ALL
PERG	1A	W0321	2315Z			27-61-47	ALL
PERG	1A	W0321	2356Z			31-31-13	ALL
PERG	1A	W0321	2376Z			34-21-23	ALL
PERG	1A	W0321	2377Z			34-21-24	ALL
PERG	1A	W0321	2409Z			22-11-51	ALL
PERG	1A	W0321	2410Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998B		***/*/***		**PLUG (continued)**				**ALL**
	PERG	1A	W0326	2271Z			27-61-48	ALL
	PERG	1A	W0326	2272Z			27-61-48	ALL
	PERG	1A	W0326	2275Z			27-61-48	ALL
	PERG	1A	W0326	2276Z			27-61-48	ALL
	PERG	1A	W0326	2308Z			27-61-44	ALL
	PERG	1A	W0326	2311Z			27-61-44	ALL
	PERG	1A	W0326	3030Z			27-61-48	ALL
	PERG	1A	W0326	3032Z			27-61-48	ALL
	PERG	1A	W0326	3101Z			27-61-44	ALL
	PERG	1A	W0326	3104Z			27-61-44	ALL
D15998C		***/*/***		**PLUG**				**ALL**
	1		W0321	0577	20		27-61-41	ALL
	2		W0321	0578	20		27-61-41	ALL
	3		W0321	0582	20		27-61-41	ALL
	4	UNUSED						ALL
	5		W0321	0583	20		27-61-41	ALL
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998C	*/*/*		**PLUG (continued)**				**ALL**
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0321	0933	22		27-62-11	ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998C		***/*/***		**PLUG (continued)**				**ALL**
	F03		W0321	0932	22		27-62-11	ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	H01		W0321	0379	22		27-61-49	ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	J01	UNUSED						ALL
	J02		W0321	0619	22		27-61-42	ALL
	J03	UNUSED						ALL
	J04		W0321	0620	22		27-61-42	ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998C		***/*/***		**PLUG (continued)**				**ALL**
	J08	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03		W0321	0617	22		27-61-42	ALL
	K04		W0321	0618	22		27-61-42	ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
D15998D		**/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0321	2348R	22		31-32-15	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0321	0381	22		27-61-49	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0321	0587	22		27-62-11	ALL
	A13		W0325	0990	22		27-61-49	ALL
	A14		W0321	2050R	22		27-61-43	ALL
	A15		W0321	2050B	22		27-61-43	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998D		/ /		**PLUG (continued)**				**ALL**
	B05		W0321	2348B	22		31-32-15	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08		W0325	0758	22		27-61-49	ALL
	C09		W0321	0964	22		27-61-49	ALL
	C10		W0321	0941	22		27-62-11	ALL
	C11		W0321	0632	22		27-61-45	ALL
	C12		W0321	0743	22		27-61-49	ALL
	C13	UNUSED						ALL
	C14		W0321	0988	22		27-61-49	ALL
	C15		W0321	0963	22		27-61-49	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998D	**/ /**		**PLUG (continued)**				**ALL**
D04		W0321	0616	22		27-61-42	ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14	UNUSED						ALL
D15	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08		W0325	0745	22		27-61-49	ALL
E09		W0321	0733	22		27-61-49	ALL
E10		W0321	0943	22		27-62-11	ALL
E11		W0321	0633	22		27-61-45	ALL
E12		W0321	0744	22		27-61-49	ALL
E13	UNUSED						ALL
E14		W0321	0735	22		27-61-49	ALL
E15		W0321	0734	22		27-61-49	ALL
F01	UNUSED						ALL
F02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998D		**/ /**		**PLUG (continued)**				**ALL**
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04		W0325	2266R	22		27-61-48	ALL
	G05	UNUSED						ALL
	G06		W0325	2270R	22		27-61-48	ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01		W0321	2314R	24		27-61-47	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998D	**/ /**		**PLUG (continued)**				**ALL**
H02		W0321	2314B	24		27-61-47	ALL
H03	UNUSED						ALL
H04		W0325	2266B	22		27-61-48	ALL
H05		W0325	3027Y	22		27-61-48	ALL
H06		W0325	2270B	22		27-61-48	ALL
H07		W0325	3029Y	22		27-61-48	ALL
H08	UNUSED						ALL
H09	UNUSED						ALL
H10	UNUSED						ALL
H11	UNUSED						ALL
H12		W0321	3102Y	22		27-61-44	ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15		W0321	3105Y	22		27-61-44	ALL
J01		W0321	2354R	24		31-31-13	ALL
J02		W0321	2354B	24		31-31-13	ALL
J03	UNUSED						ALL
J04		W0325	2265R	22		27-61-48	ALL
J05		W0325	3027B	22		27-61-48	ALL
J06		W0325	2269R	22		27-61-48	ALL
J07		W0325	3029B	22		27-61-48	ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11		W0321	2309R	22		27-61-44	ALL
J12		W0321	3102B	22		27-61-44	ALL
J13	UNUSED						ALL
J14		W0321	2312R	22		27-61-44	ALL
J15		W0321	3105B	22		27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998D		/ /		**PLUG (continued)**				**ALL**
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04		W0325	2265B	22		27-61-48	ALL
	K05		W0325	3027R	22		27-61-48	ALL
	K06		W0325	2269B	22		27-61-48	ALL
	K07		W0325	3029R	22		27-61-48	ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11		W0321	2309B	22		27-61-44	ALL
	K12		W0321	3102R	22		27-61-44	ALL
	K13	UNUSED						ALL
	K14		W0321	2312B	22		27-61-44	ALL
	K15		W0321	3105R	22		27-61-44	ALL
	PERG	1A	W0321	2309Z			27-61-44	ALL
	PERG	1A	W0321	2312Z			27-61-44	ALL
	PERG	1A	W0321	2314Z			27-61-47	ALL
	PERG	1A	W0321	2348Z			31-32-15	ALL
	PERG	1A	W0321	2354Z			31-31-13	ALL
	PERG	1A	W0321	3102Z			27-61-44	ALL
	PERG	1A	W0321	3105Z			27-61-44	ALL
	PERG	1A	W0325	2265Z			27-61-48	ALL
	PERG	1A	W0325	2266Z			27-61-48	ALL
	PERG	1A	W0325	2269Z			27-61-48	ALL
	PERG	1A	W0325	2270Z			27-61-48	ALL
	PERG	1A	W0325	3027Z			27-61-48	ALL
	PERG	1A	W0325	3029Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E	**/ /**		**PLUG**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W0321	0748	22		27-61-49	ALL
A07		W0321	0982	22		27-61-42	ALL
A08		W0321	0948	22		27-62-11	ALL
A09		W0321	2290R	22		27-62-11	ALL
A10	UNUSED						ALL
A11		W0321	2049R	22		27-61-43	ALL
A12		W0321	0609	22		27-61-42	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15		W0321	0380	22		27-61-49	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0321	0984	22		27-61-42	ALL
B08		W0321	0949	22		27-62-11	ALL
B09		W0321	2290B	22		27-62-11	ALL
B10		W0321	0974	22		27-62-11	ALL
B11		W0321	2049B	22		27-61-43	ALL
B12		W0321	0825	22		27-62-11	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E		**/ /**		**PLUG (continued)**				**ALL**
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0321	0635	22		27-61-45	ALL
	C05		W0321	0738	22		27-61-49	ALL
	C06	UNUSED						ALL
	C07		W0321	0625	22		27-61-45	ALL
	C08		W0321	0740	22		27-61-49	ALL
	C09		W0321	0830	22		27-62-11	ALL
	C10		W0325	0737	22		27-61-49	ALL
	C11		W0321	0829	22		27-62-11	ALL
	C12		W0321	2300B	22		27-62-11	ALL
	C13		W0321	0739	22		27-61-49	ALL
	C14	UNUSED						ALL
	C15		W0321	0828	22		27-62-11	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E		**/ /**		**PLUG (continued)**				**ALL**
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04		W0321	0634	22		27-61-45	ALL
	E05		W0321	0965	22		27-61-49	ALL
	E06	UNUSED						ALL
	E07		W0321	0624	22		27-61-45	ALL
	E08		W0321	0987	22		27-61-49	ALL
	E09		W0321	0938	22		27-62-11	ALL
	E10		W0325	0756	22		27-61-49	ALL
	E11		W0321	0584	22		27-62-11	ALL
	E12		W0321	2300R	22		27-62-11	ALL
	E13		W0321	0966	22		27-61-49	ALL
	E14	UNUSED						ALL
	E15		W0321	0946	22		27-62-11	ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09	UNUSED						ALL
	F10	UNUSED						ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E		**/ /**		**PLUG (continued)**				**ALL**
	F13	UNUSED						ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04		W0326	2274R	22		27-61-48	ALL
	G05	UNUSED						ALL
	G06		W0326	2278R	22		27-61-48	ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04		W0326	2274B	22		27-61-48	ALL
	H05		W0326	3031Y	22		27-61-48	ALL
	H06		W0326	2278B	22		27-61-48	ALL
	H07		W0326	3033Y	22		27-61-48	ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E	**/ /**		**PLUG (continued)**				**ALL**
H12	UNUSED						ALL
H13	UNUSED						ALL
H14	UNUSED						ALL
H15	UNUSED						ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04		W0326	2273R	22		27-61-48	ALL
J05		W0326	3031B	22		27-61-48	ALL
J06		W0326	2277R	22		27-61-48	ALL
J07		W0326	3033B	22		27-61-48	ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11	UNUSED						ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04		W0326	2273B	22		27-61-48	ALL
K05		W0326	3031R	22		27-61-48	ALL
K06		W0326	2277B	22		27-61-48	ALL
K07		W0326	3033R	22		27-61-48	ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998E		/ /		**PLUG (continued)**				**ALL**
	K11	UNUSED						ALL
	K12	UNUSED						ALL
	K13	UNUSED						ALL
	K14	UNUSED						ALL
	K15	UNUSED						ALL
	PERG	1A	W0326	2273Z			27-61-48	ALL
	PERG	1A	W0326	2274Z			27-61-48	ALL
	PERG	1A	W0326	2277Z			27-61-48	ALL
	PERG	1A	W0326	2278Z			27-61-48	ALL
	PERG	1A	W0326	3031Z			27-61-48	ALL
	PERG	1A	W0326	3033Z			27-61-48	ALL
D15998F		/ /		**PLUG**				**ALL**
	1		W0321	0581	20		27-61-41	ALL
	2	UNUSED						ALL
	3		W0321	0580	20		27-61-41	ALL
	4		W0321	0574	20		27-61-41	ALL
	5		W0321	0575	20		27-61-41	ALL
	A01		W0321	2291R	22		27-62-11	ALL
	A02		W0321	2291B	22		27-62-11	ALL
	A03		W0321	0821	22		27-62-11	ALL
	A04		W0321	0822	22		27-62-11	ALL
	A05		W0321	0823	22		27-62-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	B01		W0321	0382	22		27-61-49	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998F	**/ /**		**PLUG (continued)**				**ALL**
B05		W0321	0934	22		27-62-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08	UNUSED						ALL
F01		W0321	0755	22		27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998F		**/ /**		**PLUG (continued)**				**ALL**
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D15998F		**/ /**		**PLUG (continued)**				**ALL**
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16006		**J023-0B/ /**		**SOCKET-EE COOL SMOKE TIME ON DELAY RELAY**				**ALL**
	1	UNUSED						ALL
	2		W0098	0148	22		26-19-11	ALL
	3		W0098	0125	22		26-19-11	ALL
	4	UNUSED						ALL
	5		W0098	0114	22		26-19-11	ALL
	6	UNUSED						ALL
	7		W0098	0109	22		26-19-11	ALL
	8	UNUSED						ALL
D16008		**J023-0B/ /**		**SOCKET-EE COOL SMOKE TIMEOFF DELAY RELAY**				**ALL**
	A1		W0098	0115	22		26-19-11	ALL
	A2		W0098	0121	22		26-19-11	ALL
	A3		W0098	0174	22		26-19-11	ALL
	B1		W0098	0116	22		26-19-11	ALL
	B2		W0098	0123	22		26-19-11	ALL
	B3		W0098	0122	22		26-19-11	ALL
	C1		W0098	0114	22		26-19-11	ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0098	0162	22		26-19-11	ALL
	X2		W0098	0117	22		26-19-11	ALL
D16010		**J023-0B/ /**		**SOCKET-EE COOL SMOKE INIHIBIT RELAY**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16010	**J023-0B/ /**		**SOCKET-EE COOL SMOKE INIHIBIT RELAY (continued)**				**ALL**
6		W0098	0147	22		26-19-11	ALL
7		W0098	0141	22		26-19-11	ALL
8		W0098	0139	22		26-19-11	ALL
9		W0098	0167	22		26-19-11	ALL
10	UNUSED						ALL
11		W0098	0140	22		26-19-11	ALL
12		W0098	0168	22		26-19-11	ALL
13	UNUSED						ALL
14		W0098	0123	22		26-19-11	ALL
D16012	**J023-0B/ /**		**SOCKET-EE COOL SMOKE TEST RELAY**				**ALL**
A1		W0098	0119	22		26-19-11	ALL
A2		W0098	0120	22		26-19-11	ALL
A3	UNUSED						ALL
B1		W0098	0162	22		26-19-11	ALL
B2		W0098	0137	22		26-19-11	ALL
B3	UNUSED						ALL
C1	UNUSED						ALL
C2	UNUSED						ALL
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0098	0127	22		26-19-11	ALL
X2		W0098	0138	22		26-19-11	ALL
D16014	**J00024/ /**		**RELAY SOCKET**				**ALL**
A1		W0080	0053	20		74-11-11	ALL
A2		W0080	0051	20		74-11-11	ALL
A3		W0080	0052	20		74-11-11	ALL
B1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16014		**J00024/ /**		**RELAY SOCKET (continued)**				**ALL**
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0080	0054	20		74-11-11	ALL
	X2		W0080	0055	20		74-11-11	ALL
D16016		**J00024/ /**		**RELAY SOCKET**				**ALL**
	A1		W0080	0056	20		74-11-11	ALL
	A2		W0080	0057	20		74-11-11	ALL
	A3		W0080	0052	20		74-11-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0080	0058	20		74-11-11	ALL
	X2		W0080	0059	20		74-11-11	ALL
D16018		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0458	20		74-11-11	ALL
	A2		W0076	0459	20		74-11-11	ALL
	A3		W0076	0454	20		74-11-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0076	0460	20		74-11-11	ALL
	X2		W0076	0461	20		74-11-11	ALL
D16020		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0455	20		74-11-11	ALL
	A2		W0076	0453	20		74-11-11	ALL
	A3		W0076	0454	20		74-11-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16020		**J022-00/ /**		**RELAY SOCKET (continued)**				**ALL**
	X1		W0076	0456	20		74-11-11	ALL
	X2		W0076	0457	20		74-11-11	ALL
D16022		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	0448	20		73-22-11	ALL
	A2		W0076	0443	20		73-22-11	ALL
	A3		W0076	0447	20		73-22-11	ALL
	B1		W0076	0446	20		73-22-11	ALL
	B2		W0076	0443	20		73-22-11	ALL
	B3		W0076	0444	20		73-22-11	ALL
	X1		W0076	0450	20		73-22-11	ALL
	X2		W0076	0452	20		73-22-11	ALL
D16046		**J022-00/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0076	0153	18		78-32-51	ALL
	A2		W0076	0315	18		78-32-51	ALL
	A3		W0076	0155	18		78-32-51	ALL
	B1		W0076	0156	18		78-32-51	ALL
	B2		W0076	0316	18		78-32-51	ALL
	B3		W0076	0157	18		78-32-51	ALL
	C1		W0076	0467	18		78-32-51	ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0076	0306	18		78-32-51	ALL
	X2		W0076	0152	22		78-32-51	ALL
D16048		**J00024/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0080	6019	18		78-32-61	ALL
	A2		W0080	6040	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16048		**J00024/ /**		**RELAY-SOCKET (continued)**				**ALL**
	A3		W0080	6023	18		78-32-61	ALL
	B1		W0080	6018	18		78-32-61	ALL
	B2		W0080	6046	18		78-32-61	ALL
	B3		W0080	6024	18		78-32-61	ALL
	C1		W0080	0043	18		78-32-61	ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	D1	UNUSED						ALL
	D2	UNUSED						ALL
	D3	UNUSED						ALL
	X1		W0080	6037	18		78-32-61	ALL
	X2		W0080	6025	18		78-32-61	ALL
D16050		**J022-00/ /**		**RELAY SOCKET**				**ALL**
	A1		W0076	2504B	20		78-32-51	ALL
	A2		W0076	2504R	20		78-32-51	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0076	0463	18		78-32-51	ALL
	X2		W0076	0464	22		78-32-51	ALL
D16052		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	2607B	20		78-32-61	ALL
	A2		W0080	2607R	20		78-32-61	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0080	0045	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16052		**J00024/ /**		**SOCKET- (continued)**				**ALL**
	X2		W0080	0046	18		78-32-61	ALL
D16054		**J022-00/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0076	2503B	20		78-32-51	ALL
	A2		W0076	2503R	20		78-32-51	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0076	0465	18		78-32-51	ALL
	X2		W0076	0466	22		78-32-51	ALL
D16056		**J00024/ /**		**SOCKET-**				**ALL**
	A1		W0080	2608B	20		78-32-61	ALL
	A2		W0080	2608R	20		78-32-61	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	X1		W0080	0047	18		78-32-61	ALL
	X2		W0080	0048	18		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16180		**ORSS 412/ /**		**SPOILER SOCKET**				**ALL**
	1		W1026	2001B	20		27-61-48	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1026	2001R	20		27-61-48	ALL
	6	UNUSED						ALL
	7		W1026	3001R	20		27-61-48	ALL
	8		W1026	3001Y	20		27-61-48	ALL
	9		W1026	3001B	20		27-61-48	ALL
	10		W1026	1001	20		27-61-48	ALL
	11		W1026	2002R	20		27-61-48	ALL
	12		W1026	2002B	20		27-61-48	ALL
	PERB		W1026	1001Z			27-61-48	ALL
	PERB		W1026	2001Z			27-61-48	ALL
	PERB		W1026	2002Z			27-61-48	ALL
	PERB		W1026	3001Z			27-61-48	ALL
D16182		**ORSS 383/ /**		**PLUG**				**ALL**
	1		W1040	2003B	20		27-61-48	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1040	2003R	20		27-61-48	ALL
	6	UNUSED						ALL
	7		W1040	3002R	20		27-61-48	ALL
	8		W1040	3002Y	20		27-61-48	ALL
	9		W1040	3002B	20		27-61-48	ALL
	10		W1040	1002	20		27-61-48	ALL
	11		W1040	2004R	20		27-61-48	ALL
	12		W1040	2004B	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16182	**ORSS 383/ /**		**PLUG (continued)**				**ALL**
PERB		W1040	1002Z			27-61-48	ALL
PERB		W1040	2003Z			27-61-48	ALL
PERB		W1040	2004Z			27-61-48	ALL
PERB		W1040	3002Z			27-61-48	ALL
D16184	**ORSS 342/ /**		**SPOILER SOCKET**				**ALL**
1		W1026	2003B	20		27-61-48	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1026	2003R	20		27-61-48	ALL
6	UNUSED						ALL
7		W1026	3002R	20		27-61-48	ALL
8		W1026	3002Y	20		27-61-48	ALL
9		W1026	3002B	20		27-61-48	ALL
10		W1026	1002	20		27-61-48	ALL
11		W1026	2004R	20		27-61-48	ALL
12		W1026	2004B	20		27-61-48	ALL
PERB		W1026	1002Z			27-61-48	ALL
PERB		W1026	2003Z			27-61-48	ALL
PERB		W1026	2004Z			27-61-48	ALL
PERB		W1026	3002Z			27-61-48	ALL
D16186	**ORSS 300/ /**		**PLUG**				**ALL**
1		W1040	2001B	20		27-61-48	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1040	2001R	20		27-61-48	ALL
6	UNUSED						ALL
7		W1040	3001R	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16186		**ORSS 300/ /**		**PLUG (continued)**				**ALL**
	8		W1040	3001Y	20		27-61-48	ALL
	9		W1040	3001B	20		27-61-48	ALL
	10		W1040	1001	20		27-61-48	ALL
	11		W1040	2002R	20		27-61-48	ALL
	12		W1040	2002B	20		27-61-48	ALL
	PERB		W1040	1001Z			27-61-48	ALL
	PERB		W1040	2001Z			27-61-48	ALL
	PERB		W1040	2002Z			27-61-48	ALL
	PERB		W1040	3001Z			27-61-48	ALL
D16188		**ORSS317/ /**		**SPOILER SOCKET**				**ALL**
	1		W1042	2001B	20		27-61-48	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1042	2001R	20		27-61-48	ALL
	6	UNUSED						ALL
	7		W1042	3001R	20		27-61-48	ALL
	8		W1042	3001Y	20		27-61-48	ALL
	9		W1042	3001B	20		27-61-48	ALL
	10		W1042	1001	20		27-61-48	ALL
	11		W1042	2002R	20		27-61-48	ALL
	12		W1042	2002B	20		27-61-48	ALL
	PERB		W1042	1001Z			27-61-48	ALL
	PERB		W1042	2001Z			27-61-48	ALL
	PERB		W1042	2002Z			27-61-48	ALL
	PERB		W1042	3001Z			27-61-48	ALL
D16190		**ORSS358/ /**		**SPOILER SOCKET**				**ALL**
	1		W1028	2003B	20		27-61-48	ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16190	**ORSS358/ /**		**SPOILER SOCKET (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5		W1028	2003R	20		27-61-48	ALL
6	UNUSED						ALL
7		W1028	3002R	20		27-61-48	ALL
8		W1028	3002Y	20		27-61-48	ALL
9		W1028	3002B	20		27-61-48	ALL
10		W1028	1002	20		27-61-48	ALL
11		W1028	2004R	20		27-61-48	ALL
12		W1028	2004B	20		27-61-48	ALL
PERB		W1028	1002Z			27-61-48	ALL
PERB		W1028	2003Z			27-61-48	ALL
PERB		W1028	2004Z			27-61-48	ALL
PERB		W1028	3002Z			27-61-48	ALL
D16192	**ORSS400/ /**		**SPOILER SOCKET**				**ALL**
1		W1042	2003B	20		27-61-48	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1042	2003R	20		27-61-48	ALL
6	UNUSED						ALL
7		W1042	3002R	20		27-61-48	ALL
8		W1042	3002Y	20		27-61-48	ALL
9		W1042	3002B	20		27-61-48	ALL
10		W1042	1002	20		27-61-48	ALL
11		W1042	2004R	20		27-61-48	ALL
12		W1042	2004B	20		27-61-48	ALL
PERB		W1042	1002Z			27-61-48	ALL
PERB		W1042	2003Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16192		**ORSS400/ /**		**SPOILER SOCKET (continued)**				**ALL**
	PERB		W1042	2004Z			27-61-48	ALL
	PERB		W1042	3002Z			27-61-48	ALL
D16194		**ORSS423/ /**		**SPOILER SOCKET**				**ALL**
	1		W1028	2001B	20		27-61-48	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1028	2001R	20		27-61-48	ALL
	6	UNUSED						ALL
	7		W1028	3001R	20		27-61-48	ALL
	8		W1028	3001Y	20		27-61-48	ALL
	9		W1028	3001B	20		27-61-48	ALL
	10		W1028	1001	20		27-61-48	ALL
	11		W1028	2002R	20		27-61-48	ALL
	12		W1028	2002B	20		27-61-48	ALL
	PERB		W1028	1001Z			27-61-48	ALL
	PERB		W1028	2001Z			27-61-48	ALL
	PERB		W1028	2002Z			27-61-48	ALL
	PERB		W1028	3001Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16230	**E002-01/ /**		**PLUG-**				**ALL**
1		W0210	1002	18		30-41-11	ALL
2		W0210	5536	18		30-41-11	ALL
3		W0210	1001	20		30-41-11	ALL
4		W0210	5503	16		30-41-11	ALL
5	UNUSED						ALL
6		W0210	0004	24		31-35-08	ALL
7		W0210	5504	20		30-41-11	ALL
8		W0210	2004R	24		30-41-11	ALL
9		W0210	5506	20		30-41-11	ALL
A1		W0210	1003	12		30-41-11	ALL
A2		W0210	1004	14		30-41-11	ALL
A3		W0210	5512	12		30-41-11	ALL
A4		W0210	5511	12		30-41-11	ALL
10		W0210	5517	24		30-41-11	ALL
11		W0210	5516	24		30-41-11	ALL
12		W0210	5518	24		30-41-11	ALL
13		W0210	5514	24		30-41-11	ALL
14		W0210	5509	24		30-41-11	ALL
15		W0210	5507	24		30-41-11	ALL
16		W0210	3001Y	20		30-41-11	ALL
17		W0210	3001R	20		30-41-11	ALL
18		W0210	3001B	20		30-41-11	ALL
19		W0210	2003R	20		30-41-11	ALL
20		W0210	5505	24		30-41-11	ALL
21		W0210	5508	24		30-41-11	ALL
22		W0210	2004B	24		30-41-11	ALL
23	UNUSED						ALL
24		W0210	5515	20		30-41-11	ALL
25		W0210	2003B	20		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16230		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	26		W0210	2006R	20		30-41-11	ALL
	27		W0210	2006B	20		30-41-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
			W0210	1001ZI			30-41-11	ALL
			W0210	1001ZO			30-41-11	ALL
			W0210	1002ZI			30-41-11	ALL
			W0210	1002ZO			30-41-11	ALL
			W0210	1003Z			30-41-11	ALL
			W0210	1004Z			30-41-11	ALL
			W0210	2003ZI			30-41-11	ALL
			W0210	2003ZO			30-41-11	ALL
			W0210	2006ZI			30-41-11	ALL
			W0210	2006ZO			30-41-11	ALL
			W0210	3001ZI			30-41-11	ALL
			W0210	3001ZO			30-41-11	ALL
			W0210	FRAB			30-41-11	ALL
			W0210	FRAC			30-41-11	ALL
			W0210	FRAD			30-41-11	ALL
			W0210	FRAE			30-41-11	ALL
D16232		**E004-02/ /**		**PLUG-**				**ALL**
	1		W0420	1002	18		30-41-12	ALL
	2		W0420	5536	18		30-41-12	ALL
	3		W0420	1001	20		30-41-12	ALL
	4		W0420	5503	16		30-41-12	ALL
	5	UNUSED						ALL
	6		W0420	0001	24		31-35-08	ALL
	7		W0420	5504	20		30-41-12	ALL
	8		W0420	2004R	24		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16232	**E004-02/ /**		**PLUG- (continued)**				**ALL**
9		W0420	5506	20		30-41-12	ALL
A1		W0420	1004	12		30-41-12	ALL
A2		W0420	1003	14		30-41-12	ALL
A3		W0420	5512	12		30-41-12	ALL
A4		W0420	5511	12		30-41-12	ALL
10		W0420	5517	24		30-41-12	ALL
11		W0420	5516	24		30-41-12	ALL
12		W0420	5518	24		30-41-12	ALL
13		W0420	5514	24		30-41-12	ALL
14		W0420	5509	24		30-41-12	ALL
15		W0420	5507	24		30-41-12	ALL
16		W0420	3001Y	20		30-41-12	ALL
17		W0420	3001R	20		30-41-12	ALL
18		W0420	3001B	20		30-41-12	ALL
19		W0420	2003R	20		30-41-12	ALL
20		W0420	5505	24		30-41-12	ALL
21		W0420	5508	24		30-41-12	ALL
22		W0420	2004B	24		30-41-12	ALL
23	UNUSED						ALL
24		W0420	5515	20		30-41-12	ALL
25		W0420	2003B	20		30-41-12	ALL
26		W0420	2006R	20		30-41-12	ALL
27		W0420	2006B	20		30-41-12	ALL
28	UNUSED						ALL
29	UNUSED						ALL
		W0420	1001ZI			30-41-12	ALL
		W0420	1001ZO			30-41-12	ALL
		W0420	1002ZI			30-41-12	ALL
		W0420	2003ZI			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16232		**E004-02/ /**		**PLUG- (continued)**				**ALL**
			W0420	2006ZI			30-41-12	ALL
			W0420	3001ZI			30-41-12	ALL
			W0420	3001ZO			30-41-12	ALL
			W0420	FRAB			30-41-12	ALL
			W0420	FRAC			30-41-12	ALL
D16234		**228/177/L004**		**PLUG-CONNECTOR**				**ALL**
	1		W6024	0502	20		33-32-11	ALL
	2		W6024	0501	20		33-32-11	ALL
	3	UNUSED						ALL
D16236		**725/194/L033**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W7026	1005	20		33-32-11	ALL
	2		W7026	0513	20		33-32-11	ALL
	3	UNUSED						ALL
	S/R		W7026	1005Z			33-32-11	ALL
D16238		**698/200/R018**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W7026	1007	20		33-32-11	ALL
	2		W7026	0514	20		33-32-11	ALL
	3	UNUSED						ALL
	S/R		W7026	1007Z			33-32-11	ALL
D16240		**666/182/L072**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W7026	1006	20		33-32-11	ALL
	2		W7026	0515	20		33-32-11	ALL
	3	UNUSED						ALL
	S/R		W7026	1006Z			33-32-11	ALL
D16242		**667/182/R072**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W7026	1008	20		33-32-11	ALL
	2		W7026	0516	20		33-32-11	ALL
	3	UNUSED						ALL
	S/R		W7026	1008Z			33-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16244	**533/151/R23**		**PLUG-**				**ALL**
1		W6202	1023	20		33-33-11	ALL
2		W6202	0010	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W6202	1023Z			33-33-11	ALL
D16246	**579/154/R38**		**PLUG-**				**ALL**
1		W6202	1051	20		33-33-11	ALL
2		W6202	0011	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W6202	1051Z			33-33-11	ALL
D16248	**654/151/R38**		**PLUG-**				**ALL**
1		W6202	1055	20		33-33-11	ALL
2		W6202	0013	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W6202	1055Z			33-33-11	ALL
D16250	**588/160/R9**		**PLUG-**				**ALL**
1		W6502	1022	20		33-33-11	ALL
2		W6502	0002	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W6502	1022Z			33-33-11	ALL
D16252	**554/158/L7**		**PLUG-**				**ALL**
1		W5502	1042	20		33-33-11	ALL
2		W5502	0003	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W5502	1042Z			33-33-11	ALL
D16254	**538/152/L38**		**PLUG-**				**ALL**
1		W5102	1012	20		33-33-11	ALL
2		W5102	0012	20		33-33-11	ALL
3	UNUSED						ALL
S/R		W5102	1012Z			33-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16256		**579/155/L38**		**PLUG-**				**ALL**
	1		W5102	1040	20		33-33-11	ALL
	2		W5102	0006	20		33-33-11	ALL
	3	UNUSED						ALL
	S/R		W5102	1040Z			33-33-11	ALL
D16258		**658/150/L39**		**PLUG-**				**ALL**
	1		W5102	1011	20		33-33-11	ALL
	2		W5102	0014	20		33-33-11	ALL
	3	UNUSED						ALL
	S/R		W5102	1011Z			33-33-11	ALL
D16260		**588/158/L9**		**PLUG-**				**ALL**
	1		W5502	1040	20		33-33-11	ALL
	2		W5502	0004	20		33-33-11	ALL
	3	UNUSED						ALL
	S/R		W5502	1040Z			33-33-11	ALL
D16262		**218/206/L005**		**PLUG- IN-LINE CONNECTOR**				**ALL**
	A		W6110	0021	20		33-34-11	ALL
	B		W6110	0005	20		33-34-11	ALL
	C	UNUSED						ALL
D16264		**218/206/R005**		**PLUG- IN-LINE CONNECTOR**				**ALL**
	A		W6110	0004	20		33-34-11	ALL
	B		W6110	0006	20		33-34-11	ALL
	C	UNUSED						ALL
D16266		**201/204/R008**		**PLUG- IN-LINE CONNECTOR**				**ALL**
	A		W6110	0003	20		33-34-11	ALL
	B		W6110	0007	20		33-34-11	ALL
	C	UNUSED						ALL
D16268		**354/200/L020**		**PLUG- IN-LINE CONNECTOR**				**ALL**
	A		W6110	0051	20		33-34-11	ALL
	B		W6110	0050	20		33-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16268	**354/200/L020**		**PLUG- IN-LINE CONNECTOR (continued)**				**ALL**
C	UNUSED						ALL
D16270	**354/200/R014**		**PLUG- IN-LINE CONNECTOR**				**ALL**
A		W6110	0030	20		33-34-11	ALL
B		W6110	0060	20		33-34-11	ALL
C	UNUSED						ALL
D16272	**353/174/R020**		**PLUG- IN-LINE CONNECTOR**				**ALL**
A		W6110	0071	20		33-34-11	ALL
B		W6110	0070	20		33-34-11	ALL
C	UNUSED						ALL
D16274	**350/178/L028**		**PLUG- IN-LINE CONNECTOR**				**ALL**
A		W6110	0072	20		33-34-11	ALL
B		W6110	0073	20		33-34-11	ALL
C	UNUSED						ALL
D16276	**1064/285/L036**		**PLUG-**				**ALL**
1	18	W4724	1021	18		33-35-11	ALL
2	18	W4724	1022	18		33-35-11	ALL
3	UNUSED						ALL
S/R		W4724	1021Z			33-35-11	ALL
S/R		W4724	1022Z			33-35-11	ALL
D16278	**1040/285/R038**		**PLUG-**				**ALL**
1	18	W4724	1025	18		33-35-11	ALL
2	18	W4724	1028	18		33-35-11	ALL
3	UNUSED						ALL
S/R		W4724	1025Z			33-35-11	ALL
S/R		W4724	1028Z			33-35-11	ALL
D16280	**500B+13/203/R010**		**PLUG-**				**ALL**
A		W5248	0070	20		33-36-11	ALL
B		W5248	0080	20		33-36-11	ALL
C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16282		**500D+15/203/L010**		**PLUG-**				**ALL**
	A		W5248	0072	20		33-36-11	ALL
	B		W5248	0082	20		33-36-11	ALL
	C	UNUSED						ALL
D16284		**500F+15/203/R010**		**PLUG-**				**ALL**
	A		W5248	0044	20		33-36-11	ALL
	B		W5248	0054	20		33-36-11	ALL
	C	UNUSED						ALL
D16286		**500G+15/203/L010**		**PLUG-**				**ALL**
	A		W5248	0026	20		33-36-11	ALL
	B		W5248	0036	20		33-36-11	ALL
	C	UNUSED						ALL
D16288		**433/203/L010**		**PLUG-**				**ALL**
	A		W5248	0008	20		33-36-11	ALL
	B		W5248	0018	20		33-36-11	ALL
	C	UNUSED						ALL
D16290		**473/203/L005**		**PLUG-**				**ALL**
	A		W5248	0010	20		33-36-11	ALL
	B		W5248	0020	20		33-36-11	ALL
	C	UNUSED						ALL
D16294		**513/203/L010**		**PLUG-**				**ALL**
	A		W5248	0004	20		33-36-11	ALL
	B		W5248	0014	20		33-36-11	ALL
	C	UNUSED						ALL
D16296		**727A+10/205/R019**		**PLUG-**				**ALL**
	A		W6248	0170	20		33-36-12	ALL
	B		W6248	0270	20		33-36-12	ALL
	C	UNUSED						ALL
D16298		**727B+7/205/L011**		**PLUG-**				**ALL**
	A		W6248	0172	20		33-36-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16298		**727B+7/205/L011**		**PLUG- (continued)**				**ALL**
	B		W6248	0272	20		33-36-12	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16300		**727D+7/205/R011**		**PLUG-**				**ALL**
	A		W6248	0174	20		33-36-12	ALL
	B		W6248	0274	20		33-36-12	ALL
	C	UNUSED						ALL
D16302		**754/205/L010**		**PLUG-**				**ALL**
	A		W6248	0176	20		33-36-12	ALL
	B		W6248	0276	20		33-36-12	ALL
	C	UNUSED						ALL
D16304		**791/202/R009**		**PLUG-**				**ALL**
	A		W6248	0168	20		33-36-12	ALL
	B		W6248	0268	20		33-36-12	ALL
	C	UNUSED						ALL
D16306		**727F+7/205/L010**		**PLUG-**				**ALL**
	A		W6248	0198	20		33-36-12	ALL
	B		W6248	0298	20		33-36-12	ALL
	C	UNUSED						ALL
D16308		**727H+7/205/R010**		**PLUG-**				**ALL**
	A		W6248	0120	20		33-36-12	ALL
	B		W6248	0220	20		33-36-12	ALL
	C	UNUSED						ALL
D16312		**823/202/L007**		**PLUG-**				**ALL**
	A		W6248	0182	20		33-36-12	ALL
	B		W6248	0282	20		33-36-12	ALL
	C	UNUSED						ALL
D16314		**894/205/R010**		**PLUG-**				**ALL**
	A		W6248	0184	20		33-36-12	ALL
	B		W6248	0284	20		33-36-12	ALL
	C	UNUSED						ALL
D16322		**427/206/R056**		**PLUG**				**ALL**
	1		W6570	6001	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16322	**427/206/R056**		**PLUG (continued)**				**ALL**
2		W6570	6002	22		28-41-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W6570	FRAA			28-41-11	ALL
8		W6570	1301	20		28-41-11	ALL
9		W6570	FRAB			28-41-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W6570	1302	20		28-41-11	ALL
18		W6570	6003	22		28-41-11	ALL
19		W6570	6004	22		28-41-11	ALL
20		W6570	6005	22		28-41-11	ALL
21		W6570	1303	20		28-41-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W6570	1301ZO			28-41-11	ALL
S/R		W6570	1302Z			28-41-11	ALL
S/R		W6570	1303Z			28-41-11	ALL
CAP	Y	W6570	6001	22		28-41-11	ALL
CAP	Y	W6570	6002	22		28-41-11	ALL
CAP	Y	W6570	6003	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16322		**427/206/R056**		**PLUG (continued)**				**ALL**
	CAP	Y	W6570	6004	22		28-41-11	ALL
	CAP	Y	W6570	6005	22		28-41-11	ALL
			W6570	1301ZI			28-41-11	ALL
			W6570	FRAA			28-41-11	ALL
			W6570	FRAB			28-41-11	ALL
D16324		**427/206/R054**		**PLUG-**				**ALL**
	1		W5562	6001	22		28-41-11	ALL
	2		W5562	6002	22		28-41-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5562	FRAA			28-41-11	ALL
	8		W5562	1301	20		28-41-11	ALL
	9		W5562	FRAB			28-41-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5562	1302	20		28-41-11	ALL
	18		W5562	6003	22		28-41-11	ALL
	19		W5562	6004	22		28-41-11	ALL
	20		W5562	6012	22		28-41-11	ALL
	21		W5562	1303	20		28-41-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16324	**427/206/R054**		**PLUG- (continued)**				**ALL**
24	UNUSED						ALL
S/R		W5562	1301ZO			28-41-11	ALL
S/R		W5562	1302Z			28-41-11	ALL
S/R		W5562	1303Z			28-41-11	ALL
CAP	Y	W5562	6001	22		28-41-11	ALL
CAP	Y	W5562	6002	22		28-41-11	ALL
CAP	Y	W5562	6003	22		28-41-11	ALL
CAP	Y	W5562	6004	22		28-41-11	ALL
CAP	Y	W5562	6012	22		28-41-11	ALL
		W5562	1301ZI			28-41-11	ALL
		W5562	FRAA			28-41-11	ALL
		W5562	FRAB			28-41-11	ALL
D16326	**427/202/R056**		**PLUG**				**ALL**
1		W5580	6001	22		28-41-11	ALL
2		W5580	6002	22		28-41-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W5580	FRAB			28-41-11	ALL
8		W5580	1301	20		28-41-11	ALL
9		W5580	FRAA			28-41-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16326		**427/202/R056**		**PLUG (continued)**				**ALL**
	17		W5580	1302	20		28-41-11	ALL
	18		W5580	6003	22		28-41-11	ALL
	19		W5580	6004	22		28-41-11	ALL
	20		W5580	6010	22		28-41-11	ALL
	21		W5580	1303	20		28-41-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W5580	1301ZO			28-41-11	ALL
	S/R		W5580	1302Z			28-41-11	ALL
	S/R		W5580	1303Z			28-41-11	ALL
	CAP	Y	W5580	6001	22		28-41-11	ALL
	CAP	Y	W5580	6002	22		28-41-11	ALL
	CAP	Y	W5580	6003	22		28-41-11	ALL
	CAP	Y	W5580	6004	22		28-41-11	ALL
	CAP	Y	W5580	6010	22		28-41-11	ALL
			W5580	1301ZI			28-41-11	ALL
			W5580	FRAA			28-41-11	ALL
			W5580	FRAB			28-41-11	ALL
D16330		**427/205/R057**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W6034	2003B	22		28-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W6034	0110	22		28-41-11	ALL
	8		W6034	0110	22		28-41-11	ALL
	9		W6034	0111	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16330	**427/205/R057**		**PLUG (continued)**				**ALL**
10		W6034	0111	22		28-41-11	ALL
11	UNUSED						ALL
12		W6034	2003R	22		28-41-11	ALL
S/R		W6034	2003Z			28-41-11	ALL
D16332	**427/205/R059**		**PLUG**				**ALL**
1		W5586	2601B	22		28-41-11	ALL
2	UNUSED						ALL
3		W5586	2601R	22		28-41-11	ALL
4		W5586	6007	22		28-41-11	ALL
5		W5586	6006	20		28-41-11	ALL
6	UNUSED						ALL
7		W5586	6005	22		28-41-11	ALL
8		W5586	6005	22		28-41-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5586	6008	20		28-41-11	ALL
S/R		W5586	2601Z			28-41-11	ALL
D16334	**427/202/R057**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W6572	2603R	22		28-41-11	ALL
3	UNUSED						ALL
4		W6572	6002	22		28-41-11	ALL
5		W6572	6001	20		28-41-11	ALL
6		W6572	2601R	22		28-41-11	ALL
7		W6572	2601B	22		28-41-11	ALL
8		W6572	2603B	22		28-41-11	ALL
9		W6572	2602R	22		34-61-14	ALL
10		W6572	2602B	22		34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16334		**427/202/R057**		**PLUG (continued)**				**ALL**
	11	UNUSED						ALL
	12		W6572	6003	20		28-41-11	ALL
	S/R		W6572	2601Z			28-41-11	ALL
	S/R		W6572	2602Z			34-61-14	ALL
	S/R		W6572	2603Z			28-41-11	ALL
D16336		**IRSS 160/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1136	3601R	16		28-23-11	ALL
	2		W1136	3601Y	16		28-23-11	ALL
	3		W1136	3601B	16		28-23-11	ALL
	4	UNUSED						ALL
D16338		**IFSS 121/ /**		**PLUG**				**ALL**
	1		W1380	3001R	18		28-23-11	ALL
	2		W1380	3001Y	18		28-23-11	ALL
	3		W1380	3001B	18		28-23-11	ALL
	4	UNUSED						ALL
D16340		**IRSS 145/ /**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1134	3601R	16		28-23-11	ALL
	2		W1134	3601Y	16		28-23-11	ALL
	3		W1134	3601B	16		28-23-11	ALL
	4	UNUSED						ALL
D16342		**668/185/R084**		**PLUG**				**ALL**
	1		W1382	3001R	18		28-23-11	ALL
	2		W1382	3001Y	18		28-23-11	ALL
	3		W1382	3001B	18		28-23-11	ALL
	4	UNUSED						ALL
D16344		**IRSS160/189/L085**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1136	1303	20		28-43-11	ALL
	3		W1136	1304	20		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16344		**IRSS160/189/L085**		**PLUG (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
D16346		**IFSS-118/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1380	1013	20		28-43-11	ALL
	3		W1380	1012	20		28-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16348		**ORSS 148/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W1134	1301	20		28-43-11	ALL
	3		W1134	1302	20		28-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16350		**IFSS 117/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2		W1382	1033	20		28-43-11	ALL
	3		W1382	1032	20		28-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16352		**545/181/L084**		**PLUG**				**ALL**
	1		W1140	001TX	20		28-41-11	ALL
	2		W1140	1003	20		28-41-11	ALL
	3		W1140	1002	20		28-41-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16352		**545/181/L084**		**PLUG (continued)**				**ALL**
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	=C1		W1140	001TI			28-41-11	ALL
D16354		**545/181/R073**		**PLUG**				**ALL**
	1		W1138	001TX	20		28-41-11	ALL
	2		W1138	1003	20		28-41-11	ALL
	3		W1138	1002	20		28-41-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	=C1		W1138	001TI			28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16364	**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0082	0252	22		22-11-31	ALL
4	UNUSED						ALL
5		W0082	0253	20		22-11-31	ALL
6		W0082	0144	22		27-61-45	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0082	0142	22		27-61-45	ALL
10	UNUSED						ALL
11		W0082	0143	22		27-61-45	ALL
12		W0082	0145	22		27-61-45	ALL
13	UNUSED						ALL
14	UNUSED						ALL
D16366	**J004-00/ /**		**RELAY-SOCKET**				**ALL**
1		W0094	0086	22		27-61-45	ALL
2	UNUSED						ALL
3		W0094	0259	22		22-11-31	ALL
4	UNUSED						ALL
5		W0094	0260	20		22-11-31	ALL
6		W0094	0088	22		27-61-45	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0094	0085	22		27-61-45	ALL
13		W0094	0087	22		27-61-45	ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16368		**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
	1		W0082	0148	22		27-23-11	ALL
	2	UNUSED						ALL
	3		W0082	0132	20		27-62-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0082	0149	22		27-23-11	ALL
	7		W0082	0147	20		27-23-11	ALL
	8	UNUSED						ALL
D16370		**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0082	0135	20		27-62-11	ALL
	A2		W0082	0139	20		27-62-11	ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	X1		W0082	0138	20		27-62-11	ALL
	X2		W0082	0137	20		27-62-11	ALL
	11		W0082	0133	20		27-62-11	ALL
	12		W0082	0134	20		27-62-11	ALL
	13	UNUSED						ALL
D16372		**270/168/L023**		**RELAY-SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2	UNUSED						ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2		W0072	0223	20		27-62-11	ALL
	B3		W0072	0220	22		27-62-11	ALL
	C1		W0072	0221	20		27-62-11	ALL
	C2		W0072	0222	20		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16372	**270/168/L023**		**RELAY-SOCKET (continued)**				**ALL**
C3	UNUSED						ALL
D1	UNUSED						ALL
D2	UNUSED						ALL
D3	UNUSED						ALL
X1		W0072	0224	20		27-62-11	ALL
X2		W0072	0226	20		27-62-11	ALL
D16374	**J039-0A/ /**		**RELAY-SOCKET**				**ALL**
1		W0082	0123	20		27-61-49	ALL
2		W0082	0130	22		27-61-49	ALL
3	UNUSED						ALL
4		W0082	0131	22		27-61-49	ALL
5		W0082	0122	22		27-61-49	ALL
6		W0082	0126	20		27-61-49	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0082	0129	22		27-61-49	ALL
11		W0082	0125	20		27-61-49	ALL
12		W0082	0128	20		27-61-49	ALL
13	UNUSED						ALL
14	UNUSED						ALL
D16380	**J011-00/ /**		**RELAY-SOCKET**				**ALL**
A1		W0122	0068	18		49-62-11	ALL
A2		W0122	0065	18		49-62-11	ALL
A3	UNUSED						ALL
B1	UNUSED						ALL
B2	UNUSED						ALL
B3	UNUSED						ALL
C1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16380		**J011-00/ /**		**RELAY-SOCKET (continued)**				**ALL**
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	X1		W0122	0066	22		49-62-11	ALL
	X2		W0122	0067	22		49-62-11	ALL
D16382		**J011-00/ /**		**RELAY-SOCKET**				**ALL**
	A1		W0122	0073	18		49-62-11	ALL
	A2		W0122	0072	18		49-62-11	ALL
	A3	UNUSED						ALL
	B1	UNUSED						ALL
	B2	UNUSED						ALL
	B3	UNUSED						ALL
	C1	UNUSED						ALL
	C2	UNUSED						ALL
	C3	UNUSED						ALL
	X1		W0122	0069	22		49-62-11	ALL
	X2		W0122	0071	22		49-62-11	ALL
D16390		**578/ /**		**PLUG-**				**ALL**
	1		W7140	2202R	20		32-49-11	ALL
	2		W7140	2202B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W7140	2202ZI			32-49-11	ALL
	DED		W7140	2202ZO			32-49-11	ALL
D16392		**578/ /**		**PLUG-**				**ALL**
	1		W7142	2202R	20		32-49-11	ALL
	2		W7142	2202B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W7142	2202ZI			32-49-11	ALL
	DED		W7142	2202ZO			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16394		**578/ /**		**PLUG**				**ALL**
	1		W8250	2202R	20		32-49-11	ALL
	2		W8250	2202B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W8250	2202ZI			32-49-11	ALL
	DED		W8250	2202ZO			32-49-11	ALL
D16396		**578/ /**		**PLUG**				**ALL**
	1		W8248	2202R	20		32-49-11	ALL
	2		W8248	2202B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W8248	2202ZI			32-49-11	ALL
	DED		W8248	2202ZO			32-49-11	ALL
D16398		**344/ /**		**PLUG**				**ALL**
	1		W7144	2101R	20		32-49-11	ALL
	2		W7144	2101B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W7144	2101ZI			32-49-11	ALL
	DED		W7144	2101ZO			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16400		**344/ /**		**PLUG**				**ALL**
	1		W7144	2102R	20		32-49-11	ALL
	2		W7144	2102B	20		32-49-11	ALL
	3	UNUSED						ALL
	DED		W7144	2102ZI			32-49-11	ALL
	DED		W7144	2102ZO			32-49-11	ALL
D16402		**374/284/L030**		**PLUG-**				**ALL**
	A		W0058	0002	18		33-26-51	ALL
	B		W0058	0001	18		33-26-51	ALL
	C		W0058	0003	18		33-26-51	ALL
	D		W0058	0004	18		33-26-51	ALL
D16404		**348/284/L030**		**PLUG-**				**ALL**
	1		W0058	2502W	24		33-26-51	ALL
	2		W0058	2502B	24		33-26-51	ALL
	3		W0058	2002R	24		33-26-51	ALL
	4		W0058	2002B	24		33-26-51	ALL
	5		W0058	2502Z			33-26-51	ALL
D16406		**346/213/L051**		**RCPT-**				**ALL**
	1		W0058	2501W	24		33-26-51	ALL
	2		W0058	2501B	24		33-26-51	ALL
	3		W0058	2001R	24		33-26-51	ALL
	4		W0058	2001B	24		33-26-51	ALL
	5		W0058	2501Z			33-26-51	ALL
D16408		**354/284/L025**		**PLUG-**				**ALL**
	1		W0058	2501W	24		33-26-51	ALL
	2		W0058	2501B	24		33-26-51	ALL
	3		W0058	2001R	24		33-26-51	ALL
	4		W0058	2001B	24		33-26-51	ALL
	5		W0058	2501Z			33-26-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16410	**354/284/L025**		**RCPT-**				**ALL**
1		W3246	2001W	24		33-21-12	ALL
2		W3246	2001B	24		33-21-12	ALL
3		W3246	2002R	24		33-21-12	ALL
4		W3246	2002B	24		33-21-12	ALL
5		W3246	2001Z			33-21-12	ALL
D16420	***/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1172	2006R	20		78-36-11	ALL
2		W1172	2006B	20		78-36-11	ALL
3	UNUSED						ALL
PERB		W1172	2006Z			78-36-11	ALL
D16422	***/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1272	2006R	20		78-36-21	ALL
2		W1272	2006B	20		78-36-21	ALL
3	UNUSED						ALL
PERB		W1272	2006Z			78-36-21	ALL
D16424	**669/195/R036**		**PLUG**				**ALL**
1		W8122	2001R	20		27-61-49	ALL
2	UNUSED						ALL
3		W8122	2001B	20		27-61-49	ALL
4	UNUSED						ALL
5	UNUSED						ALL
PERB		W8122	2001Z			27-61-49	ALL
D16426	**669/195/R36**		**PLUG**				**ALL**
1		W7230	2235R	20		27-61-49	ALL
2		W7230	2235B	20		27-61-49	ALL
3	UNUSED						ALL
PERB		W7230	2235Z			27-61-49	ALL
D16428	**669/195/R36**		**PLUG**				**ALL**
1		W8122	2002R	20		27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16428		**669/195/R36**		**PLUG (continued)**				**ALL**
	2		W8122	2002B	20		27-61-49	ALL
	3	UNUSED						ALL
	PERB		W8122	2002Z			27-61-49	ALL
D16430		**J020-0B/ /**		**RELAY SOCKET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0072	0616	22		27-61-43	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0072	2002R	22		27-61-43	ALL
	10		W0072	2002B	22		27-61-43	ALL
	11		W0072	0615	22		27-61-43	ALL
	12		W0072	0617	22		27-61-43	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D16432		**J020-00/ /**		**RELAY SOCKET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0074	0053	22		27-61-43	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0074	2001R	22		27-61-43	ALL
	10		W0074	2001B	22		27-61-43	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16432	**J020-00/ /**		**RELAY SOCKET (continued)**				**ALL**
11		W0074	0047	22		27-61-43	ALL
12		W0074	0227	22		27-61-43	ALL
13	UNUSED						ALL
14	UNUSED						ALL
D16440	**356/284/L025**		**RCPT-**				**ALL**
1		W0058	2502W	24		33-26-51	ALL
2		W0058	2502B	24		33-26-51	ALL
3		W0058	2002R	24		33-26-51	ALL
4		W0058	2002B	24		33-26-51	ALL
5		W0058	2502Z			33-26-51	ALL
D16442	**356/284/L025**		**PLUG-**				**ALL**
1		W3246	2501W	24		33-24-21	ALL
2		W3246	2501B	24		33-24-21	ALL
3		W3246	2011R	24		33-24-21	ALL
4		W3246	2011B	24		33-24-21	ALL
5		W3246	2501Z			33-24-21	ALL
D16444	**355/284/L025**		**RCPT-**				**ALL**
A		W0058	0002	18		33-26-51	ALL
B		W0058	0001	18		33-26-51	ALL
C		W0058	0003	18		33-26-51	ALL
D		W0058	0004	18		33-26-51	ALL
D16446	**355/284/L025**		**PLUG-**				**ALL**
A		W4258	0412	18		33-26-51	ALL
B		W4258	0411	18		33-24-11	ALL
C		W4258	0413	18		33-26-51	ALL
D		W4258	0414	18		33-26-51	ALL
D16480	**E005-02/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W0521	0338	08		34-24-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16480		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	3		W0521	0339	22		34-24-15	ALL
	4		W0521	0336	20		34-24-15	ALL
	5	UNUSED						ALL
	6		W0521	0335	20		34-24-15	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0521	0337	20		34-24-15	ALL
	10	UNUSED						ALL
D16482		**727F+18/306/R006**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16482	**727F+18/306/R006**		**PLUG (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W3755	4030R	24		44-35-12	ALL
26		W3755	4030Y	24		44-35-12	ALL
27	UNUSED						ALL
28		W3755	2505R	24		44-35-12	ALL
29		W3755	2505B	24		44-35-12	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W3755	4030G	24		44-35-12	ALL
35		W3755	4030B	24		44-35-12	ALL
36	UNUSED						ALL
37		W3755	2506R	24		44-35-12	ALL
38		W3755	2506B	24		44-35-12	ALL
39		W3755	2510R	24		44-35-12	ALL
40		W3755	2510B	24		44-35-12	ALL
41		W3755	2504R	24		44-35-12	ALL
42		W3755	2504B	24		44-35-12	ALL
43	UNUSED						ALL
44	UNUSED						ALL
45		W3755	2515R	24		44-35-12	ALL
46		W3755	2515B	24		44-35-12	ALL
47		W3755	2514R	24		44-35-12	ALL
48	UNUSED						ALL
49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16482		**727F+18/306/R006**		**PLUG (continued)**				**ALL**
	50	UNUSED						ALL
	51		W3755	2512R	24		44-35-12	ALL
	52		W3755	2512B	24		44-35-12	ALL
	53	UNUSED						ALL
	54		W3755	2514B	24		44-35-12	ALL
	55	UNUSED						ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58	UNUSED						ALL
	59		W3755	2513R	24		44-35-12	ALL
	60		W3755	2513B	24		44-35-12	ALL
	61	UNUSED						ALL
	62	UNUSED						ALL
	63	UNUSED						ALL
	64		W3755	2511R	24		44-35-12	ALL
	65		W3755	2511B	24		44-35-12	ALL
	66	UNUSED						ALL
	PERB		W3755	2504Z			44-35-12	ALL
	PERB		W3755	2505Z			44-35-12	ALL
	PERB		W3755	2506Z			44-35-12	ALL
	PERB		W3755	2510Z			44-35-12	ALL
	PERB		W3755	2511Z			44-35-12	ALL
	PERB		W3755	2512Z			44-35-12	ALL
	PERB		W3755	2513Z			44-35-12	ALL
	PERB		W3755	2514Z			44-35-12	ALL
	PERB		W3755	2525Z			44-35-12	ALL
	PERB		W3755	4030Z			44-35-12	ALL
D16484		**727F+14/306/R006**		**PLUG-**				**ALL**
	A		W3755	2501R	16		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16484	**727F+14/306/R006**		**PLUG- (continued)**				**ALL**
B		W3755	2501B	16		44-35-11	ALL
C	UNUSED						ALL
D		W3755	0050	16		44-35-11	ALL
E		W3755	2502R	16		44-35-11	ALL
F		W3755	2502B	16		44-35-11	ALL
G	UNUSED						ALL
H		W3755	0051	16		44-35-11	ALL
PERB		W3755	2501Z			44-35-11	ALL
PERB		W3755	2502Z			44-35-11	ALL
D16486	**727F+18/306/L006**		**PLUG - STR, N (13-65 0F)**				**ALL**
=A1		W4479	002CX			44-35-12	ALL
=C1		W4479	002CO			44-35-12	ALL
D16488	**727F+16/306/L006**		**PLUG - STR, TNC (13-65 0F)**				**ALL**
=A1		W4479	001CX			44-35-12	ALL
=C1		W4479	001CO			44-35-12	ALL
D16490	**P005-99/ /**		**PLUG-**				**ALL**
1		W2218	0101	20		33-12-11	ALL
2		W2218	0102	20		33-12-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2218	0098	24		44-35-11	ALL
8		W2218	0099	24		44-35-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16490		**P005-99/ /**		**PLUG- (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
D16492		**1061/242/R034**		**PLUG-APU INLET ACT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W4726	1005	18		49-62-11	ALL
	4		W4726	1008	18		49-62-11	ALL
	5		W4726	1009	18		49-62-11	ALL
	6		W4726	1004	18		49-62-11	ALL
	7		W4726	1011	18		49-62-11	ALL
	8		W4726	1012	18		49-62-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W4726	1016	18		49-62-11	ALL
	13		W4726	1014	18		49-62-11	ALL
	14		W4726	1015	18		49-62-11	ALL
	S/R		W4726	1004Z			49-62-11	ALL
	S/R		W4726	1005Z			49-62-11	ALL
	S/R		W4726	1008Z			49-62-11	ALL
	S/R		W4726	1009Z			49-62-11	ALL
	S/R		W4726	1011Z			49-62-11	ALL
	S/R		W4726	1012Z			49-62-11	ALL
	S/R		W4726	1014Z			49-62-11	ALL
	S/R		W4726	1015Z			49-62-11	ALL
	S/R		W4726	1016Z			49-62-11	ALL
D16494		**1075/243/R041**		**RCPT-APU DOOR OPEN SW**				**ALL**
	1		W4726	2237B	20		49-62-11	ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16494	**1075/243/R041**		**RCPT-APU DOOR OPEN SW (continued)**				**ALL**
3	UNUSED						ALL
4		W4726	2237R	20		49-62-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W4726	2237Z			49-62-11	ALL
D16496	**669/195/R36**		**PLUG**				**ALL**
1	UNUSED						ALL
2		W7230	2234R	20		27-61-49	ALL
3	UNUSED						ALL
4		W7230	2234B	20		27-61-49	ALL
5	UNUSED						ALL
PERB		W7230	2234Z			27-61-49	ALL
D16498	**J004-00/ /**		**RELAY-SOCKET**				**ALL**
A1		W0094	0060	20		27-41-12	ALL
A2		W0094	0061	20		27-41-12	ALL
A3		W0094	0059	20		27-41-12	ALL
B1		W0094	0058	20		27-41-12	ALL
B2		W0094	0057	20		27-41-12	ALL
B3	UNUSED						ALL
X1		W0094	0257	20		22-13-11	ALL
X2		W0094	0258	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16500		**J004-00/ /**		**RELAY-SOCKET**				**ALL**
	A1	UNUSED						ALL
	A2		W0094	0002	22		22-13-11	ALL
	A3		W0094	0001	22		22-13-11	ALL
	B1		W0092	0002	20		27-41-12	ALL
	B2		W0092	0004	20		27-41-12	ALL
	B3	UNUSED						ALL
	X1		W0092	0003	20		27-41-12	ALL
	X2		W0094	0071	20		22-13-11	ALL
D16576		**528/183/R021**		**CONNECTOR**				**ALL**
	1		W5098	6010	20		26-23-11	ALL
	2		W5098	6011	20		26-23-11	ALL
	3		W5098	6012	22		26-23-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16578		**528/183/R021**		**CONNECTOR**				**ALL**
	1		W5098	6015	22		26-23-11	ALL
	2		W5098	6013	20		26-23-11	ALL
	3		W5098	6014	20		26-23-11	ALL
D16580		**528/183/R021**		**CONNECTOR**				**ALL**
	1		W5098	6018	22		26-23-11	ALL
	2		W5098	6016	20		26-23-11	ALL
	3		W5098	6017	20		26-23-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16584		**528/183/L015**		**CONNECTOR**				**ALL**
	1		W5074	6006	22		26-23-11	ALL
	2		W5074	6004	20		26-23-11	ALL
	3		W5074	6005	20		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16586		**528/183/L015**		**CONNECTOR**				**ALL**
	1		W5074	6009	22		26-23-11	ALL
	2		W5074	6007	20		26-23-11	ALL
	3		W5074	6008	20		26-23-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D16588		**528/183/L015**		**CONNECTOR**				**ALL**
	1		W5074	6001	20		26-23-11	ALL
	2		W5074	6002	20		26-23-11	ALL
	3		W5074	6003	22		26-23-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16694		**526/150/R023**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6202	1102	20		30-71-11	ALL
	2		W6202	5556	20		30-71-11	ALL
	S/R		W6202	1102Z			30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16712	**175/200/L003**		**PLUG**				**ALL**
A	UNUSED						ALL
B		W8489	4001R	22		34-41-11	ALL
C		W8489	4001B	22		34-41-11	ALL
D	UNUSED						ALL
E	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M	UNUSED						ALL
N	UNUSED						ALL
P		W8489	4001Y	22		34-41-11	ALL
R		W8489	4001G	22		34-41-11	ALL
S	UNUSED						ALL
T	UNUSED						ALL
U	UNUSED						ALL
V	UNUSED						ALL
W		W8489	2006B	16		34-41-11	ALL
X	UNUSED						ALL
Y	UNUSED						ALL
Z		W8489	2006R	16		34-41-11	ALL
PERB		W8489	4001Z			34-41-11	ALL
PERB		W8489	YAAA			34-41-11	ALL
D16720	**651/158/L038**		**REF EQUIP FOR JOBBING ONLY**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16722		**651/158/R038**		**REF EQUIP FOR JOBBING ONLY**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D16854		**674/206/L044**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W5530	4501G	20		32-46-11	ALL
	C	UNUSED						ALL
	D		W5530	4502G	20		32-46-11	ALL
	E		W5530	4501W	20		32-46-11	ALL
	F	UNUSED						ALL
	G		W5530	4502W	20		32-46-11	ALL
	H	UNUSED						ALL
	PERB		W5530	4501Z			32-46-11	ALL
	PERB		W5530	4502Z			32-46-11	ALL
D16856		**719/206/L044**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W5234	4501G	20		32-46-11	ALL
	C	UNUSED						ALL
	D		W5234	4502G	20		32-46-11	ALL
	E		W5234	4501W	20		32-46-11	ALL
	F	UNUSED						ALL
	G		W5234	4502W	20		32-46-11	ALL
	H	UNUSED						ALL
	PERB		W5234	4501Z			32-46-11	ALL
	PERB		W5234	4502Z			32-46-11	ALL
D16858		**718/205/R044**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W6122	4501G	20		32-46-11	ALL
	C	UNUSED						ALL
	D		W6122	4502G	20		32-46-11	ALL
	E		W6122	4501W	20		32-46-11	ALL
	F	UNUSED						ALL
	G		W6122	4502W	20		32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D16858		**718/205/R044**		**PLUG (continued)**				**ALL**
	H	UNUSED						ALL
	PERB		W6122	4501Z			32-46-11	ALL
	PERB		W6122	4502Z			32-46-11	ALL
D16860		**667/206/R044**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W6732	4501G	20		32-46-11	ALL
	C	UNUSED						ALL
	D		W6732	4502G	20		32-46-11	ALL
	E		W6732	4501W	20		32-46-11	ALL
	F	UNUSED						ALL
	G		W6732	4502W	20		32-46-11	ALL
	H	UNUSED						ALL
	PERB		W6732	4501Z			32-46-11	ALL
	PERB		W6732	4502Z			32-46-11	ALL
D16890		**AB0488/304/R009**		**PANEL JACK (TNC)**				**ALL**
	=A1		W4923	002CX			46-13-52	ALL
	=C1		W4923	002CO			46-13-52	ALL
D16891		**AB0488/304/R009**		**PANEL JACK (TNC)**				**ALL**
	=A1		W4923	003CX			46-13-52	ALL
	=C1		W4923	003CO			46-13-52	ALL
D16892		**AB0488/304/R009**		**PANEL JACK (TNC)**				**ALL**
	=A1		W4923	004CX			46-13-52	ALL
	=C1		W4923	004CO			46-13-52	ALL
D16893		**AB0488/304/R009**		**PANEL JACK (TNC)**				**ALL**
	=A1		W4923	005CX			46-13-52	ALL
	=C1		W4923	005CO			46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17060	**500C+10/ /**		**PLUG - INSERT**				**ALL**
1		W3755	4001Y	24		44-35-22	ALL
2		W3755	4001R	24		44-35-22	ALL
3	UNUSED						ALL
4		W3755	4002Y	24		44-35-22	ALL
5		W3755	4002R	24		44-35-22	ALL
6		W3755	4001B	24		44-35-22	ALL
7		W3755	4001G	24		44-35-22	ALL
8	UNUSED						ALL
9		W3755	4002B	24		44-35-22	ALL
10		W3755	4002G	24		44-35-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W3755	0004	22		44-35-20	ALL
17		W3755	0005	22		44-35-20	ALL
18		W3755	0003	22		44-35-20	ALL
19	UNUSED						ALL
20	UNUSED						ALL
PERB		W3755	4001Z			44-35-22	ALL
PERB		W3755	4002Z			44-35-22	ALL
D17062	**500H+10/ /**		**PLUG - INSERT**				**ALL**
1		W3755	4008Y	24		44-35-22	ALL
2		W3755	4008R	24		44-35-22	ALL
3	UNUSED						ALL
4		W3755	4009Y	24		44-35-22	ALL
5		W3755	4009R	24		44-35-22	ALL
6		W3755	4008B	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17062		**500H+10/ /**		**PLUG - INSERT (continued)**				**ALL**
	7		W3755	4008G	24		44-35-22	ALL
	8	UNUSED						ALL
	9		W3755	4009B	24		44-35-22	ALL
	10		W3755	4009G	24		44-35-22	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W3755	0012	22		44-35-20	ALL
	17		W3755	0013	22		44-35-20	ALL
	18		W3755	0011	22		44-35-20	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	PERB		W3755	4008Z			44-35-22	ALL
	PERB		W3755	4009Z			44-35-22	ALL
D17064		**727E+15/299/L009**		**PLUG - INSERT**				**ALL**
	1		W3755	4007Y	24		44-35-22	ALL
	2		W3755	4007R	24		44-35-22	ALL
	3	UNUSED						ALL
	4		W3755	4003Y	24		44-35-22	ALL
	5		W3755	4003R	24		44-35-22	ALL
	6		W3755	4007B	24		44-35-22	ALL
	7		W3755	4007G	24		44-35-22	ALL
	8	UNUSED						ALL
	9		W3755	4003B	24		44-35-22	ALL
	10		W3755	4003G	24		44-35-22	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17064	**727E+15/299/L009**		**PLUG - INSERT (continued)**				**ALL**
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W3755	0021	22		44-35-20	ALL
17		W3755	0022	22		44-35-20	ALL
18		W3755	0020	22		44-35-20	ALL
19	UNUSED						ALL
20	UNUSED						ALL
PERB		W3755	4003Z			44-35-22	ALL
PERB		W3755	4007Z			44-35-22	ALL
D17066	**727J+11/301/L016**		**PLUG - INSERT**				**ALL**
1		W3755	4006Y	24		44-35-22	ALL
2		W3755	4006R	24		44-35-22	ALL
3	UNUSED						ALL
4		W3755	4005Y	24		44-35-22	ALL
5		W3755	4005R	24		44-35-22	ALL
6		W3755	4006B	24		44-35-22	ALL
7		W3755	4006G	24		44-35-22	ALL
8	UNUSED						ALL
9		W3755	4005B	24		44-35-22	ALL
10		W3755	4005G	24		44-35-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W3755	0038	22		44-35-20	ALL
17		W3755	0036	22		44-35-20	ALL
18		W3755	0037	22		44-35-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D17066		**727J+11/301/L016**		**PLUG - INSERT (continued)**				**ALL**
	19	UNUSED						ALL
	20	UNUSED						ALL
	PERB		W3755	4005Z			44-35-22	ALL
	PERB		W3755	4006Z			44-35-22	ALL
D17068		**500C+10/ /**		**PLUG - INSERT**				**ALL**
	1		W3755	4008Y	24		44-35-22	ALL
	2		W3755	4008R	24		44-35-22	ALL
	3	UNUSED						ALL
	4		W3755	4009Y	24		44-35-22	ALL
	5		W3755	4009R	24		44-35-22	ALL
	6		W3755	4008B	24		44-35-22	ALL
	7		W3755	4008G	24		44-35-22	ALL
	8	UNUSED						ALL
	9		W3755	4009B	24		44-35-22	ALL
	10		W3755	4009G	24		44-35-22	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3755	0011	22		44-35-20	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	PERB		W3755	4008Z			44-35-22	ALL
	PERB		W3755	4009Z			44-35-22	ALL
D17076		**727E+15/299/L010**		**PLUG - INSERT**				**ALL**
	1		W3755	4006Y	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17076	**727E+15/299/L010**		**PLUG - INSERT (continued)**				**ALL**
2		W3755	4006R	24		44-35-22	ALL
3	UNUSED						ALL
4		W3755	4005Y	24		44-35-22	ALL
5		W3755	4005R	24		44-35-22	ALL
6		W3755	4006B	24		44-35-22	ALL
7		W3755	4006G	24		44-35-22	ALL
8	UNUSED						ALL
9		W3755	4005B	24		44-35-22	ALL
10		W3755	4005G	24		44-35-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W3755	0037	22		44-35-20	ALL
19	UNUSED						ALL
20	UNUSED						ALL
PERB		W3755	4005Z			44-35-22	ALL
PERB		W3755	4006Z			44-35-22	ALL
D17084P	**E006-01/ /**		**PLUG**				**ALL**
A-1		W4477	4002R	24		44-21-12	ALL
A-2		W4477	4002Y	24		44-21-12	ALL
A-3		W4477	4002B	24		44-21-12	ALL
A-4		W4477	4002G	24		44-21-12	ALL
B-1		W4477	4001R	24		44-21-12	ALL
B-2		W4477	4001Y	24		44-21-12	ALL
B-3		W4477	4001B	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D17084P		**E006-01/ /**		**PLUG (continued)**				**ALL**
	B-4		W4477	4001G	24		44-21-12	ALL
	C-1		W4477	4003Y	24		44-21-12	ALL
	C-2		W4477	4003R	24		44-21-12	ALL
	C-3		W4477	4003G	24		44-21-12	ALL
	C-4		W4477	4003B	24		44-21-12	ALL
	D-1		W4477	4004Y	24		44-21-12	ALL
	D-2		W4477	4004R	24		44-21-12	ALL
	D-3		W4477	4004G	24		44-21-12	ALL
	D-4		W4477	4004B	24		44-21-12	ALL
	=CA		W4477	4002Z			44-21-12	ALL
	=CB		W4477	4001Z			44-21-12	ALL
	=CC		W4477	4003Z			44-21-12	ALL
	=CD		W4477	4004Z			44-21-12	ALL
D17086P		**E006-01/ /**		**PLUG**				**ALL**
	A-1		W4477	4009R	24		44-21-12	ALL
	A-2		W4477	4009Y	24		44-21-12	ALL
	A-3		W4477	4009B	24		44-21-12	ALL
	A-4		W4477	4009G	24		44-21-12	ALL
	B-1		W4477	4010R	24		44-21-12	ALL
	B-2		W4477	4010Y	24		44-21-12	ALL
	B-3		W4477	4010B	24		44-21-12	ALL
	B-4		W4477	4010G	24		44-21-12	ALL
	C-1		W4477	4011R	24		44-21-12	ALL
	C-2		W4477	4011Y	24		44-21-12	ALL
	C-3		W4477	4011B	24		44-21-12	ALL
	C-4		W4477	4011G	24		44-21-12	ALL
	D-1		W4477	4012R	24		44-21-12	ALL
	D-2		W4477	4012Y	24		44-21-12	ALL
	D-3		W4477	4012B	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17086P	**E006-01/ /**		**PLUG (continued)**				**ALL**
D-4		W4477	4012G	24		44-21-12	ALL
=CA		W4477	4009Z			44-21-12	ALL
=CB		W4477	4010Z			44-21-12	ALL
=CC		W4477	4011Z			44-21-12	ALL
=CD		W4477	4012Z			44-21-12	ALL
D17088P	**E006-01/ /**		**PLUG**				**ALL**
A-1		W4477	4033Y	24		44-21-12	ALL
A-2		W4477	4033R	24		44-21-12	ALL
A-3		W4477	4033G	24		44-21-12	ALL
A-4		W4477	4033B	24		44-21-12	ALL
B-1		W4477	4034Y	24		44-21-12	ALL
B-2		W4477	4034R	24		44-21-12	ALL
B-3		W4477	4034G	24		44-21-12	ALL
B-4		W4477	4034B	24		44-21-12	ALL
C-1		W4477	4035Y	24		44-21-12	ALL
C-2		W4477	4035R	24		44-21-12	ALL
C-3		W4477	4035G	24		44-21-12	ALL
C-4		W4477	4035B	24		44-21-12	ALL
D-1		W4477	4036Y	24		44-21-12	ALL
D-2		W4477	4036R	24		44-21-12	ALL
D-3		W4477	4036G	24		44-21-12	ALL
D-4		W4477	4036B	24		44-21-12	ALL
=CA		W4477	4033Z			44-21-12	ALL
=CB		W4477	4034Z			44-21-12	ALL
=CC		W4477	4035Z			44-21-12	ALL
=CD		W4477	4036Z			44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D17142		**721/194/L39**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7128	2201R	18		32-41-11	ALL
	2		W7128	2201B	18		32-41-11	ALL
	S/R		W7128	2201Z			32-41-11	ALL
D17144		**721/194/L40**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7126	2201R	20		32-41-11	ALL
	2		W7126	2201B	20		32-41-11	ALL
	S/R		W7126	2201Z			32-41-11	ALL
D17146		**722/R39/183**		**PLUG-CONDUCTIVE**				**ALL**
	1		W8230	2201R	18		32-41-11	ALL
	2		W8230	2201B	18		32-41-11	ALL
	S/R		W8230	2201Z			32-41-11	ALL
D17148		**722/183/R41**		**PLUG-CONDUCTIVE**				**ALL**
	1		W8524	2201R	18		32-41-11	ALL
	2		W8524	2201B	18		32-41-11	ALL
	S/R		W8524	2201Z			32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17491	**302/289/R17**		**PLUG**				**ALL**
A		W3805	2508Z			23-70-11	ALL
B		W3805	2508W	24		23-70-11	ALL
C		W3805	2508B	24		23-70-11	ALL
D		W3805	2501Z			23-70-11	ALL
E		W3805	2501W	24		23-70-11	ALL
F		W3805	2501B	24		23-70-11	ALL
G		W3805	0004	20		23-70-11	ALL
H		W3805	0002	20		23-70-11	ALL
J	UNUSED						ALL
K		W3805	0001	20		23-70-11	ALL
L		W3805	2001R	20		23-70-11	ALL
M	UNUSED						ALL
N	UNUSED						ALL
P	UNUSED						ALL
R		W3805	2509Z			23-70-11	ALL
S		W3805	2509W	24		23-70-11	ALL
T		W3805	2509B	24		23-70-11	ALL
U	UNUSED						ALL
V	UNUSED						ALL
W	UNUSED						ALL
X	UNUSED						ALL
Y		W3805	2505R	24		23-70-11	ALL
Z		W3805	3501R	24		23-70-11	ALL
DED		W3805	2505Z			23-70-11	ALL
DED		W3805	3501Z			23-70-11	ALL
A-	UNUSED						ALL
B-		W3805	2001B	20		23-70-11	ALL
C-	UNUSED						ALL
D-	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17491		**302/289/R17**		**PLUG (continued)**				**ALL**
	E-	UNUSED						ALL
	F-		W3805	2505B	24		23-70-11	ALL
	G-		W3805	3501B	24		23-70-11	ALL
	H-		W3805	3501Y	24		23-70-11	ALL
	J-		W3805	0003	24		23-70-11	ALL
D17492		**336/289/L14**		**PLUG**				**ALL**
	1		W3801	0002	22		23-70-11	ALL
	2		W3801	0003	22		23-70-11	ALL
	3		W3801	2502B	24		23-70-11	ALL
	4		W3801	2502W	24		23-70-11	ALL
	5	UNUSED						ALL
	6		W3801	0001	22		23-70-11	ALL
	PERB		W3801	2502Z			23-70-11	ALL
D17499		**E006-03/ /**		**RCPT-COAXIAL TYPE TNC**				**ALL**
	=A1		W0635	001CX			44-35-12	ALL
	=C1		W0635	001CO			44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17500	**E006-03/ /**		**PLUG-COAXIAL TYPE TNC**				**ALL**
=A1		W0631	001CX			44-35-12	ALL
=C1		W0631	001CO			44-35-12	ALL
D17501	**E006-03/ /**		**RCPT-COAXIAL TYPE TNC**				**ALL**
=A1		W0635	002CX			44-35-12	ALL
=C1		W0635	002CO			44-35-12	ALL
D17502	**E006-03/ /**		**PLUG-COAXIAL TYPE TNC**				**ALL**
=A1		W0631	002CX			44-35-12	ALL
=C1		W0631	002CO			44-35-12	ALL
D17503	**727H-I/ /**		**PLUG-**				**ALL**
A		W3755	0040	20		44-35-11	ALL
B	UNUSED						ALL
C		W3755	0053	24		44-35-12	ALL
D	UNUSED						ALL
E		W3755	4012R	24		44-35-12	ALL
F		W3755	0041	20		44-35-11	ALL
G		W3755	0042	20		44-35-11	ALL
H		W3755	2503B	24		44-35-12	ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M		W3755	4012B	24		44-35-12	ALL
N		W3755	4012Y	24		44-35-12	ALL
P		W3755	4012G	24		44-35-12	ALL
R	UNUSED						ALL
S	UNUSED						ALL
T		W3755	2503R	24		44-35-12	ALL
U	UNUSED						ALL
V	UNUSED						ALL
CAP	Y	W3755	2508B	22		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17503		**727H-I/ /**		**PLUG- (continued)**				**ALL**
	CAP	Y	W3755	2508R	22		44-35-12	ALL
	CAP	Y	W3755	2509B	22		44-35-12	ALL
	CAP	Y	W3755	2509R	22		44-35-12	ALL
	DED		W3755	2508Z			44-35-12	ALL
	DED		W3755	2509Z			44-35-12	ALL
	PERB		W3755	2503Z			44-35-12	ALL
	PERB		W3755	4012Z			44-35-12	ALL
D17504		**727H-I/ /**		**PLUG-**				**ALL**
	A		W3755	2501R	16		44-35-11	ALL
	B		W3755	2501B	16		44-35-11	ALL
	C		W3755	2502R	16		44-35-11	ALL
	D		W3755	2502B	16		44-35-11	ALL
	PERB		W3755	2501Z			44-35-11	ALL
	PERB		W3755	2502Z			44-35-11	ALL
D17505		**727H-I/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W3755	2511R	24		44-35-12	ALL
	4		W3755	2511B	24		44-35-12	ALL
	5		W3755	2510R	24		44-35-12	ALL
	6		W3755	2510B	24		44-35-12	ALL
	7		W3755	2504R	24		44-35-12	ALL
	8		W3755	2504B	24		44-35-12	ALL
	9		W3755	2505R	24		44-35-12	ALL
	10		W3755	2505B	24		44-35-12	ALL
	11		W3755	2506R	24		44-35-12	ALL
	12		W3755	2506B	24		44-35-12	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17505	**727H-I/ /**		**PLUG- (continued)**				**ALL**
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W3755	2512R	24		44-35-12	ALL
33		W3755	2512B	24		44-35-12	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W3755	2513R	24		44-35-12	ALL
37		W3755	2513B	24		44-35-12	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17505		**727H-I/ /**		**PLUG- (continued)**				**ALL**
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	56	UNUSED						ALL
	57	UNUSED						ALL
	58		W3755	2514R	24		44-35-12	ALL
	59		W3755	2514B	24		44-35-12	ALL
	60	UNUSED						ALL
	61	UNUSED						ALL
	62	UNUSED						ALL
	63	UNUSED						ALL
	64	UNUSED						ALL
	65	UNUSED						ALL
	66	UNUSED						ALL
	67		W3755	2515B	24		44-35-12	ALL
	68	UNUSED						ALL
	69	UNUSED						ALL
	70	UNUSED						ALL
	71	UNUSED						ALL
	72	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17505		**727H-I/ /**		**PLUG- (continued)**				**ALL**
	73	UNUSED						ALL
	74	UNUSED						ALL
	75	UNUSED						ALL
	76		W3755	2515R	24		44-35-12	ALL
	77	UNUSED						ALL
	78	UNUSED						ALL
	79	UNUSED						ALL
	PERB		W3755	2504Z			44-35-12	ALL
	PERB		W3755	2505Z			44-35-12	ALL
	PERB		W3755	2506Z			44-35-12	ALL
	PERB		W3755	2510Z			44-35-12	ALL
	PERB		W3755	2511Z			44-35-12	ALL
	PERB		W3755	2512Z			44-35-12	ALL
	PERB		W3755	2513Z			44-35-12	ALL
	PERB		W3755	2514Z			44-35-12	ALL
	PERB		W3755	2525Z			44-35-12	ALL
D17506		**727H-I/ /**		**PLUG**				**ALL**
	A-1		W3755	4013Y	24		44-35-12	ALL
	A-2		W3755	4013R	24		44-35-12	ALL
	A-3		W3755	4013G	24		44-35-12	ALL
	A-4		W3755	4013B	24		44-35-12	ALL
	B-1	UNUSED						ALL
	B-2	UNUSED						ALL
	B-3	UNUSED						ALL
	B-4	UNUSED						ALL
	C-1		W3755	4030R	24		44-35-12	ALL
	C-2		W3755	4030Y	24		44-35-12	ALL
	C-3		W3755	4030B	24		44-35-12	ALL
	C-4		W3755	4030G	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17506		**727H-I/ /**		**PLUG (continued)**				**ALL**
	D-1	UNUSED						ALL
	D-2	UNUSED						ALL
	D-3	UNUSED						ALL
	D-4	UNUSED						ALL
	=CA		W3755	4013Z			44-35-12	ALL
	=CB	UNUSED						ALL
	=CC		W3755	4030Z			44-35-12	ALL
	=CD	UNUSED						ALL
D17507A		***/*/***		**PLUG**				**ALL**
	CC	UNUSED						ALL
	DD	UNUSED						ALL
	FF	UNUSED						ALL
	GG	UNUSED						ALL
	HH	UNUSED						ALL
	KK	UNUSED						ALL
	LL	UNUSED						ALL
	=AA		W0631	4032Z			44-35-05	ALL
	=BB		W0631	4038Z			44-35-12	ALL
	=EE		W0631	4036Z			44-35-12	ALL
	=JJ		W0631	4037Z			44-35-12	ALL
	AA-1		W0631	4032R	24		44-35-05	ALL
	AA-2		W0631	4032Y	24		44-35-05	ALL
	AA-3	J5	W0631	4032B	24		44-35-05	ALL
	AA-4		W0631	4032G	24		44-35-05	ALL
	BB-1		W0631	4038Y	24		44-35-12	ALL
	BB-2		W0631	4038R	24		44-35-12	ALL
	BB-3		W0631	4038G	24		44-35-12	ALL
	BB-4	J5	W0631	4038B	24		44-35-12	ALL
	CC-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507A	*/*/*		**PLUG (continued)**				**ALL**
CC-2	UNUSED						ALL
CC-3	UNUSED						ALL
CC-4	UNUSED						ALL
DD-1	UNUSED						ALL
DD-2	UNUSED						ALL
DD-3	UNUSED						ALL
DD-4	UNUSED						ALL
EE-1		W0631	4036Y	24		44-35-12	ALL
EE-2		W0631	4036R	24		44-35-12	ALL
EE-3		W0631	4036G	24		44-35-12	ALL
EE-4	J5	W0631	4036B	24		44-35-12	ALL
FF-1	UNUSED						ALL
FF-2	UNUSED						ALL
FF-3	UNUSED						ALL
FF-4	UNUSED						ALL
GG-1	UNUSED						ALL
GG-2	UNUSED						ALL
GG-3	UNUSED						ALL
GG-4	UNUSED						ALL
HH-1	UNUSED						ALL
HH-2	UNUSED						ALL
HH-3	UNUSED						ALL
HH-4	UNUSED						ALL
JJ-1		W0631	4037Y	24		44-35-12	ALL
JJ-2		W0631	4037R	24		44-35-12	ALL
JJ-3		W0631	4037G	24		44-35-12	ALL
JJ-4	J5	W0631	4037B	24		44-35-12	ALL
KK-1	UNUSED						ALL
KK-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507A		***/*/***		**PLUG (continued)**				**ALL**
	KK-3	UNUSED						ALL
	KK-4	UNUSED						ALL
	LL-1	UNUSED						ALL
	LL-2	UNUSED						ALL
	LL-3	UNUSED						ALL
	LL-4	UNUSED						ALL
D17507B		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0631	2504R	24		44-35-12	ALL
	A10	UNUSED						ALL
	A11		W0631	0087	22		44-35-12	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0631	2504B	24		44-35-12	ALL
	B10		W0631	0085	22		44-35-12	ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507B		*/*/*		**PLUG (continued)**				**ALL**
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10		W0631	0084	22		44-35-12	ALL
	C11	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11		W0631	0026	22		44-35-12	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL
	E04	UNUSED						ALL
	E05	UNUSED						ALL
	E06	UNUSED						ALL
	E07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507B		***/*/***		**PLUG (continued)**				**ALL**
	E08	UNUSED						ALL
	E09		W0631	2503R	24		44-35-11	ALL
	E10	UNUSED						ALL
	E11		W0631	0083	22		44-35-12	ALL
	E12		W0631	0080	24		44-35-12	ALL
	E13		W0631	0081	22		44-35-12	ALL
	E14	UNUSED						ALL
	E15	UNUSED						ALL
	F01	UNUSED						ALL
	F02	UNUSED						ALL
	F03	UNUSED						ALL
	F04	UNUSED						ALL
	F05	UNUSED						ALL
	F06	UNUSED						ALL
	F07	UNUSED						ALL
	F08	UNUSED						ALL
	F09		W0631	2503B	24		44-35-11	ALL
	F10		W0631	0086	22		44-35-12	ALL
	F11	UNUSED						ALL
	F12	UNUSED						ALL
	F13		W0631	0082	22		44-35-12	ALL
	F14	UNUSED						ALL
	F15	UNUSED						ALL
	G01	UNUSED						ALL
	G02	UNUSED						ALL
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507B	*/*/*		**PLUG (continued)**				**ALL**
G07	UNUSED						ALL
G08	UNUSED						ALL
G09		W0631	2508R	24		44-35-12	ALL
G10	UNUSED						ALL
G11		W0631	4013R	24		44-35-12	ALL
H01	UNUSED						ALL
H02	UNUSED						ALL
H03	UNUSED						ALL
H04	UNUSED						ALL
H05	UNUSED						ALL
H06	UNUSED						ALL
H07	UNUSED						ALL
H08	UNUSED						ALL
H09		W0631	2508B	24		44-35-12	ALL
H10	UNUSED						ALL
H11		W0631	4013B	24		44-35-12	ALL
J01	UNUSED						ALL
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10	UNUSED						ALL
J11		W0631	4013Y	24		44-35-12	ALL
K01	UNUSED						ALL
K02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507B		***/*/***		**PLUG (continued)**				**ALL**
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL
	K09	UNUSED						ALL
	K10	UNUSED						ALL
	K11		W0631	4013G	24		44-35-12	ALL
	=C1T		W0631	4014Z			44-35-12	ALL
	=C2T	UNUSED						ALL
	1T-1		W0631	4014R	24		44-35-12	ALL
	1T-2		W0631	4014Y	24		44-35-12	ALL
	1T-3		W0631	4014B	24		44-35-12	ALL
	1T-4		W0631	4014G	24		44-35-12	ALL
	2T-1	UNUSED						ALL
	2T-2	UNUSED						ALL
	2T-3	UNUSED						ALL
	2T-4	UNUSED						ALL
	PERG	1A	W0631	2503Z			44-35-11	ALL
	PERG	1A	W0631	2504Z			44-35-12	ALL
	PERG	1A	W0631	2508Z			44-35-12	ALL
	PERG	1A	W0631	4013Z			44-35-12	ALL
D17507C		***/*/***		**PLUG**				**ALL**
	1		W0631	0049	20		44-35-11	ALL
	2	UNUSED						ALL
	3		W0631	0052	20		44-35-11	ALL
	4	UNUSED						ALL
	5		W0631	0023	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17507C	***/*/***		**PLUG (continued)**				**ALL**
6	DN	W0631	001CX			44-35-12	ALL
7	DN	W0631	002CX			44-35-12	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
=C6		W0631	001CO			44-35-12	ALL
=C7		W0631	002CO			44-35-12	ALL
D17508	**E006-03/ /**		**PLUG**				**ALL**
1		W0631	2504R	24		44-35-12	ALL
2		W0631	2504B	24		44-35-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0631	2503R	24		44-35-11	ALL
6		W0631	2503B	24		44-35-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
PERB		W0631	2503Z			44-35-11	ALL
PERB		W0631	2504Z			44-35-12	ALL
D17542A	***/*/***		**PLUG**				**ALL**
AA	UNUSED						ALL
BB	UNUSED						ALL
DD	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542A		***/*/***		**PLUG (continued)**				**ALL**
	EE	UNUSED						ALL
	GG	UNUSED						ALL
	KK	UNUSED						ALL
	=CC		W0631	4035Z			44-35-12	ALL
	=FF		W0631	4034Z			44-35-12	ALL
	=HH		W0631	4038Z			44-35-12	ALL
	=JJ		W0631	4029Z			44-35-22	ALL
	=LL		W0631	4028Z			44-35-22	ALL
	AA-1	UNUSED						ALL
	AA-2	UNUSED						ALL
	AA-3	UNUSED						ALL
	AA-4	UNUSED						ALL
	BB-1	UNUSED						ALL
	BB-2	UNUSED						ALL
	BB-3	UNUSED						ALL
	BB-4	UNUSED						ALL
	CC-1		W0631	4035R	24		44-35-12	ALL
	CC-2		W0631	4035Y	24		44-35-12	ALL
	CC-3	J5	W0631	4035B	24		44-35-12	ALL
	CC-4		W0631	4035G	24		44-35-12	ALL
	DD-1	UNUSED						ALL
	DD-2	UNUSED						ALL
	DD-3	UNUSED						ALL
	DD-4	UNUSED						ALL
	EE-1	UNUSED						ALL
	EE-2	UNUSED						ALL
	EE-3	UNUSED						ALL
	EE-4	UNUSED						ALL
	FF-1		W0631	4034R	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542A		*/*/*		**PLUG (continued)**				**ALL**
	FF-2		W0631	4034Y	24		44-35-12	ALL
	FF-3	J5	W0631	4034B	24		44-35-12	ALL
	FF-4		W0631	4034G	24		44-35-12	ALL
	GG-1	UNUSED						ALL
	GG-2	UNUSED						ALL
	GG-3	UNUSED						ALL
	GG-4	UNUSED						ALL
	HH-1		W0631	4038R	24		44-35-12	ALL
	HH-2		W0631	4038Y	24		44-35-12	ALL
	HH-3	J5	W0631	4038B	24		44-35-12	ALL
	HH-4		W0631	4038G	24		44-35-12	ALL
	JJ-1		W0631	4029R	24		44-35-22	ALL
	JJ-2		W0631	4029Y	24		44-35-22	ALL
	JJ-3	J5	W0631	4029B	24		44-35-22	ALL
	JJ-4		W0631	4029G	24		44-35-22	ALL
	KK-1	UNUSED						ALL
	KK-2	UNUSED						ALL
	KK-3	UNUSED						ALL
	KK-4	UNUSED						ALL
	LL-1		W0631	4028R	24		44-35-22	ALL
	LL-2		W0631	4028Y	24		44-35-22	ALL
	LL-3	J5	W0631	4028B	24		44-35-22	ALL
	LL-4		W0631	4028G	24		44-35-22	ALL
D17542B		*/*/*		**PLUG**				**ALL**
	AA	UNUSED						ALL
	BB	UNUSED						ALL
	CC	UNUSED						ALL
	DD	UNUSED						ALL
	EE	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542B		***/*/***		**PLUG (continued)**				**ALL**
	FF	UNUSED						ALL
	GG	UNUSED						ALL
	HH	UNUSED						ALL
	JJ	UNUSED						ALL
	KK	UNUSED						ALL
	LL	UNUSED						ALL
	AA-1	UNUSED						ALL
	AA-2	UNUSED						ALL
	AA-3	UNUSED						ALL
	AA-4	UNUSED						ALL
	BB-1	UNUSED						ALL
	BB-2	UNUSED						ALL
	BB-3	UNUSED						ALL
	BB-4	UNUSED						ALL
	CC-1	UNUSED						ALL
	CC-2	UNUSED						ALL
	CC-3	UNUSED						ALL
	CC-4	UNUSED						ALL
	DD-1	UNUSED						ALL
	DD-2	UNUSED						ALL
	DD-3	UNUSED						ALL
	DD-4	UNUSED						ALL
	EE-1	UNUSED						ALL
	EE-2	UNUSED						ALL
	EE-3	UNUSED						ALL
	EE-4	UNUSED						ALL
	FF-1	UNUSED						ALL
	FF-2	UNUSED						ALL
	FF-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542B		***/*/***		**PLUG (continued)**				**ALL**
	FF-4	UNUSED						ALL
	GG-1	UNUSED						ALL
	GG-2	UNUSED						ALL
	GG-3	UNUSED						ALL
	GG-4	UNUSED						ALL
	HH-1	UNUSED						ALL
	HH-2	UNUSED						ALL
	HH-3	UNUSED						ALL
	HH-4	UNUSED						ALL
	JJ-1	UNUSED						ALL
	JJ-2	UNUSED						ALL
	JJ-3	UNUSED						ALL
	JJ-4	UNUSED						ALL
	KK-1	UNUSED						ALL
	KK-2	UNUSED						ALL
	KK-3	UNUSED						ALL
	KK-4	UNUSED						ALL
	LL-1	UNUSED						ALL
	LL-2	UNUSED						ALL
	LL-3	UNUSED						ALL
	LL-4	UNUSED						ALL
D17542C		***/*/***		**PLUG**				**ALL**
	=C1T	UNUSED						ALL
	=C2T	UNUSED						ALL
	=C3T	UNUSED						ALL
	=C4T	UNUSED						ALL
	=C5T	UNUSED						ALL
	=C6T	UNUSED						ALL
	1T-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542C		***/*/***		**PLUG (continued)**				**ALL**
	1T-2	UNUSED						ALL
	1T-3	UNUSED						ALL
	1T-4	UNUSED						ALL
	2T-1	UNUSED						ALL
	2T-2	UNUSED						ALL
	2T-3	UNUSED						ALL
	2T-4	UNUSED						ALL
	3T-1	UNUSED						ALL
	3T-2	UNUSED						ALL
	3T-3	UNUSED						ALL
	3T-4	UNUSED						ALL
	4T-1	UNUSED						ALL
	4T-2	UNUSED						ALL
	4T-3	UNUSED						ALL
	4T-4	UNUSED						ALL
	5T-1	UNUSED						ALL
	5T-2	UNUSED						ALL
	5T-3	UNUSED						ALL
	5T-4	UNUSED						ALL
	6T-1	UNUSED						ALL
	6T-2	UNUSED						ALL
	6T-3	UNUSED						ALL
	6T-4	UNUSED						ALL
D17542D		***/*/***		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542D		*/*/*		**PLUG (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0631	0025	22		44-21-22	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0631	0085	22		44-35-12	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0631	0028	22		44-35-12	ALL
	B08		W0631	0028	22		44-35-12	ALL
	B09		W0631	0009	22		44-21-22	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0631	0084	22		44-35-12	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542D		***/*/***		**PLUG (continued)**				**ALL**
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12		W0631	0082	22		44-35-12	ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07		W0631	0027	22		44-35-12	ALL
	D08		W0631	0027	22		44-35-12	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12		W0631	0081	22		44-35-12	ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15		W0631	0086	22		44-35-12	ALL
	E01	UNUSED						ALL
	E02	UNUSED						ALL
	E03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542D	*/*/*		**PLUG (continued)**				**ALL**
E04	UNUSED						ALL
E05	UNUSED						ALL
E06	UNUSED						ALL
E07	UNUSED						ALL
E08	UNUSED						ALL
E09		W0631	0022	22		44-21-22	ALL
E10	UNUSED						ALL
E11		W0631	0008	22		44-21-22	ALL
E12	UNUSED						ALL
E13	UNUSED						ALL
E14	UNUSED						ALL
E15		W0631	0083	22		44-35-12	ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06	UNUSED						ALL
F07	UNUSED						ALL
F08	UNUSED						ALL
F09		W0631	0021	22		44-21-22	ALL
F10	UNUSED						ALL
F11	UNUSED						ALL
F12	UNUSED						ALL
F13	UNUSED						ALL
F14	UNUSED						ALL
F15	UNUSED						ALL
G01	UNUSED						ALL
G02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542D		***/*/***		**PLUG (continued)**				**ALL**
	G03	UNUSED						ALL
	G04	UNUSED						ALL
	G05	UNUSED						ALL
	G06	UNUSED						ALL
	G07	UNUSED						ALL
	G08	UNUSED						ALL
	G09	UNUSED						ALL
	G10	UNUSED						ALL
	G11	UNUSED						ALL
	G12	UNUSED						ALL
	G13	UNUSED						ALL
	G14	UNUSED						ALL
	G15	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	H09	UNUSED						ALL
	H10	UNUSED						ALL
	H11	UNUSED						ALL
	H12	UNUSED						ALL
	H13	UNUSED						ALL
	H14	UNUSED						ALL
	H15	UNUSED						ALL
	J01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542D	*/*/*		**PLUG (continued)**				**ALL**
J02	UNUSED						ALL
J03	UNUSED						ALL
J04	UNUSED						ALL
J05	UNUSED						ALL
J06	UNUSED						ALL
J07	UNUSED						ALL
J08	UNUSED						ALL
J09	UNUSED						ALL
J10		W0631	0024	22		44-21-22	ALL
J11		W0631	0020	22		44-21-22	ALL
J12	UNUSED						ALL
J13	UNUSED						ALL
J14	UNUSED						ALL
J15	UNUSED						ALL
K01	UNUSED						ALL
K02	UNUSED						ALL
K03	UNUSED						ALL
K04	UNUSED						ALL
K05	UNUSED						ALL
K06	UNUSED						ALL
K07	UNUSED						ALL
K08	UNUSED						ALL
K09	UNUSED						ALL
K10		W0631	0088	22		44-35-12	ALL
K11	UNUSED						ALL
K12	UNUSED						ALL
K13	UNUSED						ALL
K14	UNUSED						ALL
K15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542E		***/*/***		**PLUG**				**ALL**
	BB	UNUSED						ALL
	CC	UNUSED						ALL
	GG	UNUSED						ALL
	JJ	UNUSED						ALL
	KK	UNUSED						ALL
	LL	UNUSED						ALL
	=AA		W0631	4037Z			44-35-12	ALL
	=DD		W0631	4036Z			44-35-12	ALL
	=EE		W0631	4030Z			44-35-22	ALL
	=FF		W0631	4033Z			44-35-12	ALL
	=HH		W0631	4031Z			44-35-22	ALL
	AA-1		W0631	4037R	24		44-35-12	ALL
	AA-2		W0631	4037Y	24		44-35-12	ALL
	AA-3	J5	W0631	4037B	24		44-35-12	ALL
	AA-4		W0631	4037G	24		44-35-12	ALL
	BB-1	UNUSED						ALL
	BB-2	UNUSED						ALL
	BB-3	UNUSED						ALL
	BB-4	UNUSED						ALL
	CC-1	UNUSED						ALL
	CC-2	UNUSED						ALL
	CC-3	UNUSED						ALL
	CC-4	UNUSED						ALL
	DD-1		W0631	4036R	24		44-35-12	ALL
	DD-2		W0631	4036Y	24		44-35-12	ALL
	DD-3	J5	W0631	4036B	24		44-35-12	ALL
	DD-4		W0631	4036G	24		44-35-12	ALL
	EE-1		W0631	4030R	24		44-35-22	ALL
	EE-2		W0631	4030Y	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542E		*/*/*		**PLUG (continued)**				**ALL**
	EE-3	J5	W0631	4030B	24		44-35-22	ALL
	EE-4		W0631	4030G	24		44-35-22	ALL
	FF-1		W0631	4033R	24		44-35-12	ALL
	FF-2		W0631	4033Y	24		44-35-12	ALL
	FF-3	J5	W0631	4033B	24		44-35-12	ALL
	FF-4		W0631	4033G	24		44-35-12	ALL
	GG-1	UNUSED						ALL
	GG-2	UNUSED						ALL
	GG-3	UNUSED						ALL
	GG-4	UNUSED						ALL
	HH-1		W0631	4031R	24		44-35-22	ALL
	HH-2		W0631	4031Y	24		44-35-22	ALL
	HH-3	J5	W0631	4031B	24		44-35-22	ALL
	HH-4		W0631	4031G	24		44-35-22	ALL
	JJ-1	UNUSED						ALL
	JJ-2	UNUSED						ALL
	JJ-3	UNUSED						ALL
	JJ-4	UNUSED						ALL
	KK-1	UNUSED						ALL
	KK-2	UNUSED						ALL
	KK-3	UNUSED						ALL
	KK-4	UNUSED						ALL
	LL-1	UNUSED						ALL
	LL-2	UNUSED						ALL
	LL-3	UNUSED						ALL
	LL-4	UNUSED						ALL
D17542F		*/*/*		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542F		***/*/***		**PLUG (continued)**				**ALL**
	3		W0631	0060	20		44-35-11	ALL
	4		W0631	0059	20		44-35-11	ALL
	5		W0631	0058	20		44-35-11	ALL
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0631	2532R	22		44-35-12	ALL
	A08	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0631	2532B	22		44-35-12	ALL
	B08	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0631	2532Z			44-35-12	ALL
	C08	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542F	*/*/*		**PLUG (continued)**				**ALL**
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06		W0631	2530R	22		44-35-12	ALL
D07		W0631	2531R	22		44-35-12	ALL
D08	UNUSED						ALL
E01	UNUSED						ALL
E02	UNUSED						ALL
E03	UNUSED						ALL
E04	UNUSED						ALL
E05	UNUSED						ALL
E06		W0631	2530B	22		44-35-12	ALL
E07		W0631	2531B	22		44-35-12	ALL
E08	UNUSED						ALL
F01	UNUSED						ALL
F02	UNUSED						ALL
F03	UNUSED						ALL
F04	UNUSED						ALL
F05	UNUSED						ALL
F06		W0631	2530Z			44-35-12	ALL
F07		W0631	2531Z			44-35-12	ALL
F08	UNUSED						ALL
G01	UNUSED						ALL
G02	UNUSED						ALL
G03	UNUSED						ALL
G04	UNUSED						ALL
G05	UNUSED						ALL
G06	UNUSED						ALL
G07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17542F		***/*/***		**PLUG (continued)**				**ALL**
	G08	UNUSED						ALL
	H01	UNUSED						ALL
	H02	UNUSED						ALL
	H03	UNUSED						ALL
	H04	UNUSED						ALL
	H05	UNUSED						ALL
	H06	UNUSED						ALL
	H07	UNUSED						ALL
	H08	UNUSED						ALL
	J01	UNUSED						ALL
	J02	UNUSED						ALL
	J03	UNUSED						ALL
	J04	UNUSED						ALL
	J05	UNUSED						ALL
	J06	UNUSED						ALL
	J07	UNUSED						ALL
	J08	UNUSED						ALL
	K01	UNUSED						ALL
	K02	UNUSED						ALL
	K03	UNUSED						ALL
	K04	UNUSED						ALL
	K05	UNUSED						ALL
	K06	UNUSED						ALL
	K07	UNUSED						ALL
	K08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17858	**467/305/R005**		**PLUG, QUADRAX - EPX SHELL**				**ALL**
1-1		W4920	4002Y	24		46-13-52	ALL
1-2		W4920	4002R	24		46-13-52	ALL
1-3		W4920	4002G	24		46-13-52	ALL
1-4		W4920	4002B	24		46-13-52	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
4-1	UNUSED						ALL
4-2	UNUSED						ALL
4-3	UNUSED						ALL
4-4	UNUSED						ALL
5-1	UNUSED						ALL
5-2	UNUSED						ALL
5-3	UNUSED						ALL
5-4	UNUSED						ALL
6-1	UNUSED						ALL
6-2	UNUSED						ALL
6-3	UNUSED						ALL
6-4	UNUSED						ALL
7-1		W4920	4001Y	24		46-13-52	ALL
7-2		W4920	4001R	24		46-13-52	ALL
7-3		W4920	4001G	24		46-13-52	ALL
7-4		W4920	4001B	24		46-13-52	ALL
8-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17858		**467/305/R005**		**PLUG, QUADRAX - EPX SHELL (continued)**				**ALL**
	8-2	UNUSED						ALL
	8-3	UNUSED						ALL
	8-4	UNUSED						ALL
	9-1	UNUSED						ALL
	9-2	UNUSED						ALL
	9-3	UNUSED						ALL
	9-4	UNUSED						ALL
	=C1		W4920	4002Z			46-13-52	ALL
	=C2	UNUSED						ALL
	=C3	UNUSED						ALL
	=C4	UNUSED						ALL
	=C5	UNUSED						ALL
	=C6	UNUSED						ALL
	=C7		W4920	4001Z			46-13-52	ALL
	=C8	UNUSED						ALL
	=C9	UNUSED						ALL
	=C10	UNUSED						ALL
	=C11	UNUSED						ALL
	=C12	UNUSED						ALL
	10-1	UNUSED						ALL
	10-2	UNUSED						ALL
	10-3	UNUSED						ALL
	10-4	UNUSED						ALL
	11-1	UNUSED						ALL
	11-2	UNUSED						ALL
	11-3	UNUSED						ALL
	11-4	UNUSED						ALL
	12-1	UNUSED						ALL
	12-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D17858		**467/305/R005**		**PLUG, QUADRAX - EPX SHELL (continued)**				**ALL**
	12-3	UNUSED						ALL
	12-4	UNUSED						ALL
D17861		**467/305/R005**		**PLUG-**				**ALL**
	=A1		W4923	004CX			46-13-52	ALL
	=C1		W4923	004CO			46-13-52	ALL
D17862		**467/305/R005**		**PLUG-**				**ALL**
	=A1		W4923	005CX			46-13-52	ALL
	=C1		W4923	005CO			46-13-52	ALL
D17863		**467/305/R005**		**PLUG-**				**ALL**
	=A1		W4923	002CX			46-13-52	ALL
	=C1		W4923	002CO			46-13-52	ALL
D17864		**467/305/R005**		**PLUG-**				**ALL**
	=A1		W4923	003CX			46-13-52	ALL
	=C1		W4923	003CO			46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30002	**NSTA 202/136/L012**		**PLUG-CONDUCTIVE**				**ALL**
1		W1080	3002Y	18		78-32-61	ALL
2		W1080	A-R			78-36-11	ALL
3		W1080	B-B			78-36-11	ALL
4		W1080	3001Y	20		78-35-11	ALL
5		W1080	3001B	20		78-35-11	ALL
6		W1080	3001R	20		78-35-11	ALL
7		W1080	3002B	18		78-32-61	ALL
8		W1080	3002R	18		78-32-61	ALL
9		W1080	2002B	20		78-35-11	ALL
10		W1080	2002R	20		78-35-11	ALL
11		W1080	A-B			78-36-11	ALL
12		W1080	B-R			78-36-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
PERB		W1080	2002Z			78-35-11	ALL
PERB		W1080	3001Z			78-35-11	ALL
PERB		W1080	3002Z			78-32-61	ALL
PERB		W1080	A-Z			78-36-11	ALL
PERB		W1080	B-Z			78-36-11	ALL
D30006	**NSTA 202/137/R012**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W1086	3001B	20		78-35-11	ALL
3		W1086	3001R	20		78-35-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1086	2002R	20		78-35-11	ALL
7		W1086	2002B	20		78-35-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30006	**NSTA 202/137/R012**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10		W1086	3001Y	20		78-35-11	ALL
PERB		W1086	2002Z			78-35-11	ALL
PERB		W1086	3001Z			78-35-11	ALL
D30008	**NSTA 200/137/L012**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W1082	3001B	20		78-35-11	ALL
3		W1082	3001R	20		78-35-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1082	2001R	20		78-35-11	ALL
7		W1082	2001B	20		78-35-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W1082	3001Y	20		78-35-11	ALL
PERB		W1082	2001Z			78-35-11	ALL
PERB		W1082	3001Z			78-35-11	ALL
D30010	**NSTA 202/137/R012**		**PLUG-CONDUCTIVE**				**ALL**
1		W1084	3003Y	18		78-32-61	ALL
2		W1084	A-R			78-36-11	ALL
3		W1084	B-B			78-36-11	ALL
4		W1084	3001Y	20		78-35-11	ALL
5		W1084	3001B	20		78-35-11	ALL
6		W1084	3001R	20		78-35-11	ALL
7		W1084	3003B	18		78-32-61	ALL
8		W1084	3003R	18		78-32-61	ALL
9		W1084	2001B	20		78-35-11	ALL
10		W1084	2001R	20		78-35-11	ALL
11		W1084	A-B			78-36-11	ALL
12		W1084	B-R			78-36-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30010		**NSTA 202/137/R012**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	PERB		W1084	2001Z			78-35-11	ALL
	PERB		W1084	3001Z			78-35-11	ALL
	PERB		W1084	3003Z			78-32-61	ALL
	PERB		W1084	A-Z			78-36-11	ALL
	PERB		W1084	B-Z			78-36-11	ALL
D30014		**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1184	3001R	18		24-21-11	ALL
	2		W1184	2003R	20		SPARE	ALL
	3		W1184	4001G	20		24-24-11	ALL
	4		W1184	3001B	18		24-21-11	ALL
	5		W1184	2002R	20		24-21-11	ALL
	6		W1184	3001Y	18		24-21-11	ALL
	7	UNUSED						ALL
	8		W1184	1003	20		29-11-11	ALL
	9		W1184	1001	18		24-11-11	ALL
	10		W1184	2003B	20		SPARE	ALL
	11	UNUSED						ALL
	12		W1184	4001R	20		24-24-11	ALL
	13		W1184	4001Y	20		24-24-11	ALL
	14		W1184	4001B	20		24-24-11	ALL
	15		W1184	2002B	20		24-21-11	ALL
	16		W1184	2001R	20		24-11-11	ALL
	17		W1184	2001B	20		24-11-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	PERB		W1184	1001Z			24-11-11	ALL
	PERB		W1184	1003Z			29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30014	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1184	2001Z			24-11-11	ALL
PERB		W1184	2002ZI			24-21-11	ALL
PERB		W1184	2002ZO			24-21-11	ALL
PERB		W1184	2003Z			SPARE	ALL
PERB		W1184	3001ZI			24-21-11	ALL
PERB		W1184	3001ZO			24-21-11	ALL
PERB		W1184	4001Z			24-24-11	ALL
D30016	**NSTA 259/146/R013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1164	3001R	18		24-21-11	ALL
2		W1164	2003R	20		SPARE	ALL
3		W1164	4001G	20		24-24-11	ALL
4		W1164	3001B	18		24-21-11	ALL
5		W1164	2002R	20		24-21-11	ALL
6		W1164	3001Y	18		24-21-11	ALL
7	UNUSED						ALL
8		W1164	1003	20		29-11-11	ALL
9		W1164	1001	18		24-11-11	ALL
10		W1164	2003B	20		SPARE	ALL
11	UNUSED						ALL
12		W1164	4001R	20		24-24-11	ALL
13		W1164	4001Y	20		24-24-11	ALL
14		W1164	4001B	20		24-24-11	ALL
15		W1164	2002B	20		24-21-11	ALL
16		W1164	2001R	20		24-11-11	ALL
17		W1164	2001B	20		24-11-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
PERB		W1164	1001Z			24-11-11	ALL
PERB		W1164	1003Z			29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30016		**NSTA 259/146/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1164	2001Z			24-11-11	ALL
	PERB		W1164	2002Z			24-21-11	ALL
	PERB		W1164	2003Z			SPARE	ALL
	PERB		W1164	3001Z			24-21-11	ALL
	PERB		W1164	4001Z			24-24-11	ALL
D30032J		**NSTA 170/136/R012**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1166	0008	20		36-11-13	ALL
	2		W1166	3004Y	20		36-11-13	ALL
	3	UNUSED						ALL
	4		W1166	2012B	20		36-11-13	ALL
	5	UNUSED						ALL
	6		W1166	2011R	20		36-11-13	ALL
	7		W1166	2011B	20		36-11-13	ALL
	8		W1166	3004B	20		36-11-13	ALL
	9		W1166	3004R	20		36-11-13	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W1166	2012R	20		36-11-13	ALL
	PERB		W1166	2011Z			36-11-13	ALL
	PERB		W1166	2012Z			36-11-13	ALL
	PERB		W1166	3004Z			36-11-13	ALL
D30032P		**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1198	0008	20		36-11-13	ALL
	2		W1198	3004Y	20		36-11-13	ALL
	3	UNUSED						ALL
	4		W1198	2012B	20		36-11-13	ALL
	5	UNUSED						ALL
	6		W1198	2011R	20		36-11-13	ALL
	7		W1198	2011B	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30032P	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
8		W1198	3004B	20		36-11-13	ALL
9		W1198	3004R	20		36-11-13	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W1198	2012R	20		36-11-13	ALL
PERB		W1198	2011Z			36-11-13	ALL
PERB		W1198	2012Z			36-11-13	ALL
PERB		W1198	3004Z			36-11-13	ALL
D30036J	**NSTA 170/136/R012**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1166	1013R	20		26-11-11	ALL
5		W1166	1014R	20		26-11-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1166	1011R	20		26-11-11	ALL
9		W1166	0002	20		26-11-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
PERB		W1166	1011Z			26-11-11	ALL
PERB		W1166	1013Z			26-11-11	ALL
PERB		W1166	1014Z			26-11-11	ALL
D30036P	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1194	2001R	20		26-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30036P		**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	5		W1194	2001B	20		26-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1194	2002R	20		26-11-11	ALL
	9		W1194	2002B	20		26-11-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W1194	2001Z			26-11-11	ALL
	S/R		W1194	2002Z			26-11-11	ALL
D30038		**NSTA 170/135/L11**		**PLUG**				**ALL**
	S/R	GW	W1062	1001Z			24-21-11	ALL
	S/R	GW	W1062	1002Z			24-21-11	ALL
	S/R	GW	W1062	1003Z			24-21-11	ALL
	S/R	GW	W1062	1004Z			24-21-11	ALL
	A		W1062	1001	02		24-21-11	ALL
	B		W1062	1002	02		24-21-11	ALL
	C		W1062	1003	02		24-21-11	ALL
	D		W1062	1004	04		24-21-11	ALL
D30042		**NSTA 258/149/R013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1172	3003Y	18		78-32-51	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W1172	2005R	20		78-32-51	ALL
	5		W1172	3003R	18		78-32-51	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1172	4001Y	22		46-13-11	ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30042	**NSTA 258/149/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1172	2005B	20		78-32-51	ALL
14		W1172	3003B	18		78-32-51	ALL
15		W1172	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1172	4001R	22		46-13-11	ALL
19		W1172	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1172	2009R	20		73-21-21	ALL
22		W1172	2009B	20		73-21-21	ALL
23		W1172	2010R	20		73-21-21	ALL
24		W1172	2010B	20		73-21-21	ALL
25		W1172	2011R	20		73-21-21	ALL
26		W1172	2011B	20		73-21-21	ALL
27		W1172	2007R	20		73-21-12	ALL
28		W1172	2007B	20		73-21-12	ALL
29		W1172	2017B	20		SPARE	ALL
30		W1172	2017R	20		SPARE	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1172	2008R	20		73-21-11	ALL
34		W1172	2013R	20		73-24-12	ALL
35		W1172	2013B	20		73-24-12	ALL
36		W1172	2012B	20		73-24-11	ALL
37		W1172	2012R	20		73-24-11	ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30042		**NSTA 258/149/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	39		W1172	4001G	22		46-13-11	ALL
	PERB		W1172	2005Z			78-32-51	ALL
	PERB		W1172	2007Z			73-21-12	ALL
	PERB		W1172	2008Z			73-21-11	ALL
	PERB		W1172	2009Z			73-21-21	ALL
	PERB		W1172	2010Z			73-21-21	ALL
	PERB		W1172	2011Z			73-21-21	ALL
	PERB		W1172	2012Z			73-24-11	ALL
	PERB		W1172	2013Z			73-24-12	ALL
	PERB		W1172	2017Z			SPARE	ALL
	PERB		W1172	3003Z			78-32-51	ALL
	PERB		W1172	4001Z			46-13-11	ALL
D30046J		**NSTA 262/146/R013**		**RECP-CONDUCTIVE**				**ALL**
	1		W1170	0002	20		26-11-11	ALL
	2	UNUSED						ALL
	3		W1170	1015R	20		26-11-11	ALL
	4	UNUSED						ALL
	5		W1170	3003R	18		73-22-41	ALL
	6		W1170	3003B	18		73-22-41	ALL
	7		W1170	3003Y	18		73-22-41	ALL
	PERB		W1170	1015Z			26-11-11	ALL
	PERB		W1170	3003Z			73-22-41	ALL
D30046P		**NSTA 170/136/R012**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1166	1014R	20		26-11-11	ALL
	2	UNUSED						ALL
	3		W1166	1013R	20		26-11-11	ALL
	4	UNUSED						ALL
	5		W1166	3003R	18		73-22-41	ALL
	6		W1166	3003B	18		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30046P	**NSTA 170/136/R012**		**PLUG-CONDUCTIVE (continued)**				**ALL**
7		W1166	3003Y	18		73-22-41	ALL
PERB		W1166	1013Z			26-11-11	ALL
PERB		W1166	1014Z			26-11-11	ALL
PERB		W1166	3003Z			73-22-41	ALL
D30048	**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1178	3002R	20		36-11-12	ALL
2		W1178	1003	20		74-11-11	ALL
3		W1178	2009B	20		36-11-13	ALL
4	UNUSED						ALL
5		W1178	2006B	20		36-11-13	ALL
6		W1178	1001	18		73-22-11	ALL
7		W1178	2003B	20		78-35-11	ALL
8		W1178	2008R	20		36-11-13	ALL
9		W1178	3002Y	20		36-11-12	ALL
10		W1178	3002B	20		36-11-12	ALL
11		W1178	1020	20		78-34-11	ALL
12		W1178	2009R	20		36-11-13	ALL
13	UNUSED						ALL
14		W1178	2006R	20		36-11-13	ALL
15		W1178	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1178	2003R	20		78-35-11	ALL
18		W1178	2007B	20		36-11-13	ALL
19		W1178	1014R	20		26-11-11	ALL
20		W1178	2008B	20		36-11-13	ALL
21		W1178	2012R	20		36-11-13	ALL
22		W1178	2012B	20		36-11-13	ALL
23		W1178	2004R	20		73-21-12	ALL
24		W1178	2004B	20		73-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30048		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	25		W1178	1019	20		78-34-11	ALL
	26		W1178	1022	20		78-34-11	ALL
	27		W1178	1021	20		78-34-11	ALL
	28		W1178	2011B	20		77-12-11	ALL
	29		W1178	2011R	20		77-12-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W1178	3001B	20		79-31-11	ALL
	35		W1178	3001R	20		79-31-11	ALL
	36		W1178	2005B	20		36-11-13	ALL
	37		W1178	2005R	20		36-11-13	ALL
	38		W1178	2007R	20		36-11-13	ALL
	39		W1178	1015R	20		26-11-11	ALL
	PERB		W1178	1001ZI			73-22-11	ALL
	PERB		W1178	1001ZO			73-22-11	ALL
	PERB		W1178	1003Z			74-11-11	ALL
	PERB		W1178	1014Z			26-11-11	ALL
	PERB		W1178	1015Z			26-11-11	ALL
	PERB		W1178	1019Z			78-34-11	ALL
	PERB		W1178	1020Z			78-34-11	ALL
	PERB		W1178	1021Z			78-34-11	ALL
	PERB		W1178	1022Z			78-34-11	ALL
	PERB		W1178	2003Z			78-35-11	ALL
	PERB		W1178	2004Z			73-21-12	ALL
	PERB		W1178	2005Z			36-11-13	ALL
	PERB		W1178	2006Z			36-11-13	ALL
	PERB		W1178	2007Z			36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30048	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1178	2008Z			36-11-13	ALL
PERB		W1178	2009Z			36-11-13	ALL
PERB		W1178	2011Z			77-12-11	ALL
PERB		W1178	2012Z			36-11-13	ALL
PERB		W1178	3001Z			79-31-11	ALL
PERB		W1178	3002Z			36-11-12	ALL
D30052	**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1170	3002R	20		36-11-12	ALL
2		W1170	1003	20		74-11-11	ALL
3		W1170	2009B	20		36-11-13	ALL
4	UNUSED						ALL
5		W1170	2006B	20		36-11-13	ALL
6		W1170	1001	18		73-22-11	ALL
7		W1170	2003B	20		78-35-11	ALL
8		W1170	2008R	20		36-11-13	ALL
9		W1170	3002Y	20		36-11-12	ALL
10		W1170	3002B	20		36-11-12	ALL
11		W1170	1020	20		78-34-11	ALL
12		W1170	2009R	20		36-11-13	ALL
13	UNUSED						ALL
14		W1170	2006R	20		36-11-13	ALL
15		W1170	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1170	2003R	20		78-35-11	ALL
18		W1170	2007B	20		36-11-13	ALL
19		W1170	1014R	20		26-11-11	ALL
20		W1170	2008B	20		36-11-13	ALL
21		W1170	2012R	20		36-11-13	ALL
22		W1170	2012B	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30052		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	23		W1170	2004R	20		73-21-12	ALL
	24		W1170	2004B	20		73-21-12	ALL
	25		W1170	1019	20		78-34-11	ALL
	26		W1170	1022	20		78-34-11	ALL
	27		W1170	1021	20		78-34-11	ALL
	28		W1170	2011B	20		77-12-11	ALL
	29		W1170	2011R	20		77-12-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W1170	3001B	20		79-31-11	ALL
	35		W1170	3001R	20		79-31-11	ALL
	36		W1170	2005B	20		36-11-13	ALL
	37		W1170	2005R	20		36-11-13	ALL
	38		W1170	2007R	20		36-11-13	ALL
	39		W1170	1015R	20		26-11-11	ALL
	PERB		W1170	1001ZI			73-22-11	ALL
	PERB		W1170	1001ZO			73-22-11	ALL
	PERB		W1170	1003Z			74-11-11	ALL
	PERB		W1170	1014Z			26-11-11	ALL
	PERB		W1170	1015Z			26-11-11	ALL
	PERB		W1170	1019Z			78-34-11	ALL
	PERB		W1170	1020Z			78-34-11	ALL
	PERB		W1170	1021Z			78-34-11	ALL
	PERB		W1170	1022Z			78-34-11	ALL
	PERB		W1170	2003Z			78-35-11	ALL
	PERB		W1170	2004Z			73-21-12	ALL
	PERB		W1170	2005Z			36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30052	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1170	2006Z			36-11-13	ALL
PERB		W1170	2007Z			36-11-13	ALL
PERB		W1170	2008Z			36-11-13	ALL
PERB		W1170	2009Z			36-11-13	ALL
PERB		W1170	2011Z			77-12-11	ALL
PERB		W1170	2012Z			36-11-13	ALL
PERB		W1170	3001Z			79-31-11	ALL
PERB		W1170	3002Z			36-11-12	ALL
D30062	**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1182	3001R	18		73-22-41	ALL
2	UNUSED						ALL
3		W1182	3001B	18		73-22-41	ALL
4		W1182	2008R	20		30-21-31	ALL
5		W1182	3001Y	18		73-22-41	ALL
6		W1182	1001	18		73-22-11	ALL
7	UNUSED						ALL
8		W1182	2011B	20		36-11-13	ALL
9	UNUSED						ALL
10		W1182	2012B	20		36-11-13	ALL
11		W1182	2006B	20		76-21-11	ALL
12		W1182	3004Y	20		36-11-13	ALL
13		W1182	2008B	20		30-21-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W1182	1007	20		74-11-11	ALL
18	UNUSED						ALL
19		W1182	1010R	20		26-11-11	ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30062		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21		W1182	2011R	20		36-11-13	ALL
	22		W1182	2012R	20		36-11-13	ALL
	23		W1182	2001R	20		73-21-12	ALL
	24		W1182	2001B	20		73-21-12	ALL
	25		W1182	2006R	20		76-21-11	ALL
	26		W1182	3004R	20		36-11-13	ALL
	27		W1182	3004B	20		36-11-13	ALL
	28		W1182	2002B	20		77-12-21	ALL
	29		W1182	2002R	20		77-12-21	ALL
	30		W1182	2005B	20		30-21-31	ALL
	31		W1182	2005R	20		30-21-31	ALL
	32		W1182	2004B	20		30-21-31	ALL
	33		W1182	2004R	20		30-21-31	ALL
	34		W1182	2003B	20		30-21-31	ALL
	35		W1182	2003R	20		30-21-31	ALL
	36	18	W1182	1003R	18		26-12-11	ALL
	37		W1182	1005R	20		26-12-11	ALL
	38	UNUSED						ALL
	39		W1182	1011R	20		26-11-11	ALL
	PERB		W1182	1001ZI			73-22-11	ALL
	PERB		W1182	1001ZO			73-22-11	ALL
	PERB		W1182	1003Z			26-12-11	ALL
	PERB		W1182	1005Z			26-12-11	ALL
	PERB		W1182	1007Z			74-11-11	ALL
	PERB		W1182	1010Z			26-11-11	ALL
	PERB		W1182	1011Z			26-11-11	ALL
	PERB		W1182	2001Z			73-21-12	ALL
	PERB		W1182	2002Z			77-12-21	ALL
	PERB		W1182	2003Z			30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30062	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1182	2004Z			30-21-31	ALL
PERB		W1182	2005Z			30-21-31	ALL
PERB		W1182	2006Z			76-21-11	ALL
PERB		W1182	2008Z			30-21-31	ALL
PERB		W1182	2011Z			36-11-13	ALL
PERB		W1182	2012Z			36-11-13	ALL
PERB		W1182	3001Z			73-22-41	ALL
PERB		W1182	3004Z			36-11-13	ALL
D30064	**NSTA 260/142/R013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1166	3002R	18		73-22-41	ALL
2	UNUSED						ALL
3		W1166	3002B	18		73-22-41	ALL
4		W1166	2008R	20		30-21-31	ALL
5		W1166	3002Y	18		73-22-41	ALL
6		W1166	1001	18		73-22-11	ALL
7	UNUSED						ALL
8		W1166	2011B	20		36-11-13	ALL
9	UNUSED						ALL
10		W1166	2012B	20		36-11-13	ALL
11		W1166	2006B	20		76-21-11	ALL
12		W1166	3004Y	20		36-11-13	ALL
13		W1166	2008B	20		30-21-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W1166	1003	20		74-11-11	ALL
18	UNUSED						ALL
19		W1166	1010R	20		26-11-11	ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30064	**NSTA 260/142/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
21		W1166	2011R	20		36-11-13	ALL
22		W1166	2012R	20		36-11-13	ALL
23		W1166	2001R	20		73-21-12	ALL
24		W1166	2001B	20		73-21-12	ALL
25		W1166	2006R	20		76-21-11	ALL
26		W1166	3004R	20		36-11-13	ALL
27		W1166	3004B	20		36-11-13	ALL
28		W1166	2002B	20		77-12-21	ALL
29		W1166	2002R	20		77-12-21	ALL
30		W1166	2005B	20		30-21-31	ALL
31		W1166	2005R	20		30-21-31	ALL
32		W1166	2004B	20		30-21-31	ALL
33		W1166	2004R	20		30-21-31	ALL
34		W1166	2003B	20		30-21-31	ALL
35		W1166	2003R	20		30-21-31	ALL
36	18	W1166	1006R	18		26-12-11	ALL
37	18	W1166	1005R	18		26-12-11	ALL
38	UNUSED						ALL
39		W1166	1011R	20		26-11-11	ALL
PERB		W1166	1001ZI			73-22-11	ALL
PERB		W1166	1001ZO			73-22-11	ALL
PERB		W1166	1003Z			74-11-11	ALL
PERB		W1166	1005Z			26-12-11	ALL
PERB		W1166	1006Z			26-12-11	ALL
PERB		W1166	1010Z			26-11-11	ALL
PERB		W1166	1011Z			26-11-11	ALL
PERB		W1166	2001Z			73-21-12	ALL
PERB		W1166	2002Z			77-12-21	ALL
PERB		W1166	2003Z			30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30064	**NSTA 260/142/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1166	2004Z			30-21-31	ALL
PERB		W1166	2005Z			30-21-31	ALL
PERB		W1166	2006Z			76-21-11	ALL
PERB		W1166	2008Z			30-21-31	ALL
PERB		W1166	2011Z			36-11-13	ALL
PERB		W1166	2012Z			36-11-13	ALL
PERB		W1166	3002Z			73-22-41	ALL
PERB		W1166	3004Z			36-11-13	ALL
D30068	**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1192	3003Y	18		78-32-51	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1192	2005R	20		78-32-51	ALL
5		W1192	3003R	18		78-32-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1192	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1192	2005B	20		78-32-51	ALL
14		W1192	3003B	18		78-32-51	ALL
15		W1192	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1192	4001R	22		46-13-11	ALL
19		W1192	4001B	22		46-13-11	ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30068		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21		W1192	2009R	20		73-21-21	ALL
	22		W1192	2009B	20		73-21-21	ALL
	23		W1192	2010R	20		73-21-21	ALL
	24		W1192	2010B	20		73-21-21	ALL
	25		W1192	2011R	20		73-21-21	ALL
	26		W1192	2011B	20		73-21-21	ALL
	27		W1192	2007R	20		73-21-12	ALL
	28		W1192	2007B	20		73-21-12	ALL
	29		W1192	2017B	20		SPARE	ALL
	30		W1192	2017R	20		SPARE	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W1192	2008R	20		73-21-11	ALL
	34		W1192	2013R	20		73-24-12	ALL
	35		W1192	2013B	20		73-24-12	ALL
	36		W1192	2012B	20		73-24-11	ALL
	37		W1192	2012R	20		73-24-11	ALL
	38	UNUSED						ALL
	39		W1192	4001G	22		46-13-11	ALL
	PERB		W1192	2005Z			78-32-51	ALL
	PERB		W1192	2007Z			73-21-12	ALL
	PERB		W1192	2008Z			73-21-11	ALL
	PERB		W1192	2009Z			73-21-21	ALL
	PERB		W1192	2010Z			73-21-21	ALL
	PERB		W1192	2011Z			73-21-21	ALL
	PERB		W1192	2012Z			73-24-11	ALL
	PERB		W1192	2013Z			73-24-12	ALL
	PERB		W1192	2017Z			SPARE	ALL
	PERB		W1192	3003Z			78-32-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D30068		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1192	4001Z			46-13-11	ALL
D30072		**NSTA 200/128/L25**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1080	2002R	20		78-35-11	ALL
	2		W1080	2002B	20		78-35-11	ALL
	3		W1080	3001R	20		78-35-11	ALL
	4		W1080	3001B	20		78-35-11	ALL
	5		W1080	3001Y	20		78-35-11	ALL
	PERB		W1080	2002Z			78-35-11	ALL
	PERB		W1080	3001Z			78-35-11	ALL
D30074		**NSTA 200/124/R28**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1086	2002R	20		78-35-11	ALL
	2		W1086	2002B	20		78-35-11	ALL
	3		W1086	3001R	20		78-35-11	ALL
	4		W1086	3001B	20		78-35-11	ALL
	5		W1086	3001Y	20		78-35-11	ALL
	PERB		W1086	2002Z			78-35-11	ALL
	PERB		W1086	3001Z			78-35-11	ALL
D30076		**NSTA 200/128/L23**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1082	2001R	20		78-35-11	ALL
	2		W1082	2001B	20		78-35-11	ALL
	3		W1082	3001R	20		78-35-11	ALL
	4		W1082	3001B	20		78-35-11	ALL
	5		W1082	3001Y	20		78-35-11	ALL
	PERB		W1082	2001Z			78-35-11	ALL
	PERB		W1082	3001Z			78-35-11	ALL
D30078		**NSTA 200/126/R28**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1084	2001R	20		78-35-11	ALL
	2		W1084	2001B	20		78-35-11	ALL
	3		W1084	3001R	20		78-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30078		**NSTA 200/126/R28**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	4		W1084	3001B	20		78-35-11	ALL
	5		W1084	3001Y	20		78-35-11	ALL
	PERB		W1084	2001Z			78-35-11	ALL
	PERB		W1084	3001Z			78-35-11	ALL
D30084		**NSTA 258/144/R013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1168	3003Y	18		78-32-51	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W1168	2005R	20		78-32-51	ALL
	5		W1168	3003R	18		78-32-51	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1168	4001Y	22		46-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W1168	2005B	20		78-32-51	ALL
	14		W1168	3003B	18		78-32-51	ALL
	15		W1168	2008B	20		73-21-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W1168	4001R	22		46-13-11	ALL
	19		W1168	4001B	22		46-13-11	ALL
	20	UNUSED						ALL
	21		W1168	2009R	20		73-21-21	ALL
	22		W1168	2009B	20		73-21-21	ALL
	23		W1168	2010R	20		73-21-21	ALL
	24		W1168	2010B	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30084	**NSTA 258/144/R013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
25		W1168	2011R	20		73-21-21	ALL
26		W1168	2011B	20		73-21-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1168	2008R	20		73-21-11	ALL
34		W1168	2013R	20		73-24-12	ALL
35		W1168	2013B	20		73-24-12	ALL
36		W1168	2012B	20		73-24-11	ALL
37		W1168	2012R	20		73-24-11	ALL
38	UNUSED						ALL
39		W1168	4001G	22		46-13-11	ALL
PERB		W1168	2005Z			78-32-51	ALL
PERB		W1168	2008Z			73-21-11	ALL
PERB		W1168	2009Z			73-21-21	ALL
PERB		W1168	2010Z			73-21-21	ALL
PERB		W1168	2011Z			73-21-21	ALL
PERB		W1168	2012Z			73-24-11	ALL
PERB		W1168	2013Z			73-24-12	ALL
PERB		W1168	3003Z			78-32-51	ALL
PERB		W1168	4001Z			46-13-11	ALL
D30092	**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1190	3003Y	18		78-32-51	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1190	2005R	20		78-32-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30092		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	5		W1190	3003R	18		78-32-51	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1190	4001Y	22		46-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W1190	2005B	20		78-32-51	ALL
	14		W1190	3003B	18		78-32-51	ALL
	15		W1190	2008B	20		73-21-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W1190	4001R	22		46-13-11	ALL
	19		W1190	4001B	22		46-13-11	ALL
	20	UNUSED						ALL
	21		W1190	2009R	20		73-21-21	ALL
	22		W1190	2009B	20		73-21-21	ALL
	23		W1190	2010R	20		73-21-21	ALL
	24		W1190	2010B	20		73-21-21	ALL
	25		W1190	2011R	20		73-21-21	ALL
	26		W1190	2011B	20		73-21-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W1190	2008R	20		73-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30092	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
34		W1190	2013R	20		73-24-12	ALL
35		W1190	2013B	20		73-24-12	ALL
36		W1190	2012B	20		73-24-11	ALL
37		W1190	2012R	20		73-24-11	ALL
38	UNUSED						ALL
39		W1190	4001G	22		46-13-11	ALL
PERB		W1190	2005Z			78-32-51	ALL
PERB		W1190	2008Z			73-21-11	ALL
PERB		W1190	2009Z			73-21-21	ALL
PERB		W1190	2010Z			73-21-21	ALL
PERB		W1190	2011Z			73-21-21	ALL
PERB		W1190	2012Z			73-24-11	ALL
PERB		W1190	2013Z			73-24-12	ALL
PERB		W1190	3003Z			78-32-51	ALL
PERB		W1190	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30114		**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1284	3001R	18		24-21-21	ALL
	2		W1284	2003R	20		SPARE	ALL
	3		W1284	4001G	20		24-24-21	ALL
	4		W1284	3001B	18		24-21-21	ALL
	5		W1284	2002R	20		24-21-21	ALL
	6		W1284	3001Y	18		24-21-21	ALL
	7	UNUSED						ALL
	8		W1284	1003	20		29-11-11	ALL
	9		W1284	1001	18		24-11-21	ALL
	10		W1284	2003B	20		SPARE	ALL
	11	UNUSED						ALL
	12		W1284	4001R	20		24-24-21	ALL
	13		W1284	4001Y	20		24-24-21	ALL
	14		W1284	4001B	20		24-24-21	ALL
	15		W1284	2002B	20		24-21-21	ALL
	16		W1284	2001R	20		24-11-21	ALL
	17		W1284	2001B	20		24-11-21	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	PERB		W1284	1001Z			24-11-21	ALL
	PERB		W1284	1003Z			29-11-11	ALL
	PERB		W1284	2001Z			24-11-21	ALL
	PERB		W1284	2002ZI			24-21-21	ALL
	PERB		W1284	2002ZO			24-21-21	ALL
	PERB		W1284	2003Z			SPARE	ALL
	PERB		W1284	3001ZI			24-21-21	ALL
	PERB		W1284	3001ZO			24-21-21	ALL
	PERB		W1284	4001Z			24-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30116	**NSTA 259/146/L013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1264	3001R	18		24-21-21	ALL
2		W1264	2003R	20		SPARE	ALL
3		W1264	4001G	20		24-24-21	ALL
4		W1264	3001B	18		24-21-21	ALL
5		W1264	2002R	20		24-21-21	ALL
6		W1264	3001Y	18		24-21-21	ALL
7	UNUSED						ALL
8		W1264	1003	20		29-11-11	ALL
9		W1264	1001	18		24-11-21	ALL
10		W1264	2003B	20		SPARE	ALL
11	UNUSED						ALL
12		W1264	4001R	20		24-24-21	ALL
13		W1264	4001Y	20		24-24-21	ALL
14		W1264	4001B	20		24-24-21	ALL
15		W1264	2002B	20		24-21-21	ALL
16		W1264	2001R	20		24-11-21	ALL
17		W1264	2001B	20		24-11-21	ALL
18	UNUSED						ALL
19	UNUSED						ALL
PERB		W1264	1001Z			24-11-21	ALL
PERB		W1264	1003Z			29-11-11	ALL
PERB		W1264	2001Z			24-11-21	ALL
PERB		W1264	2002Z			24-21-21	ALL
PERB		W1264	2003Z			SPARE	ALL
PERB		W1264	3001Z			24-21-21	ALL
PERB		W1264	4001Z			24-24-21	ALL
D30132J	**NSTA 172/134/R11**		**RECP-CONDUCTIVE**				**ALL**
1		W1266	0008	20		36-11-23	ALL
2		W1266	3004Y	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30132J		**NSTA 172/134/R11**		**RECP-CONDUCTIVE (continued)**				**ALL**
	3	UNUSED						ALL
	4		W1266	2012B	20		36-11-23	ALL
	5	UNUSED						ALL
	6		W1266	2011R	20		36-11-23	ALL
	7		W1266	2011B	20		36-11-23	ALL
	8		W1266	3004B	20		36-11-23	ALL
	9		W1266	3004R	20		36-11-23	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W1266	2012R	20		36-11-23	ALL
	PERB		W1266	2011Z			36-11-23	ALL
	PERB		W1266	2012Z			36-11-23	ALL
	PERB		W1266	3004Z			36-11-23	ALL
D30132P		**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1298	0008	20		36-11-23	ALL
	2		W1298	3004Y	20		36-11-23	ALL
	3	UNUSED						ALL
	4		W1298	2012B	20		36-11-23	ALL
	5	UNUSED						ALL
	6		W1298	2011R	20		36-11-23	ALL
	7		W1298	2011B	20		36-11-23	ALL
	8		W1298	3004B	20		36-11-23	ALL
	9		W1298	3004R	20		36-11-23	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W1298	2012R	20		36-11-23	ALL
	PERB		W1298	2011Z			36-11-23	ALL
	PERB		W1298	2012Z			36-11-23	ALL
	PERB		W1298	3004Z			36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30136J	**NSTA 170/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1266	1013R	20		26-11-21	ALL
5		W1266	1014R	20		26-11-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1266	1011R	20		26-11-21	ALL
9		W1266	0002	20		26-11-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
PERB		W1266	1011Z			26-11-21	ALL
PERB		W1266	1013Z			26-11-21	ALL
PERB		W1266	1014Z			26-11-21	ALL
D30136P	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1294	2001R	20		26-11-21	ALL
5		W1294	2001B	20		26-11-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1294	2002R	20		26-11-21	ALL
9		W1294	2002B	20		26-11-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W1294	2001Z			26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30136P	**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
S/R		W1294	2002Z			26-11-21	ALL
D30142	**NSTA 258/149/L013**		**PLUG-CONDUCTIVE**				**ALL**
1		W1272	3003Y	18		78-32-61	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1272	2005R	20		78-32-61	ALL
5		W1272	3003R	18		78-32-61	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1272	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1272	2005B	20		78-32-61	ALL
14		W1272	3003B	18		78-32-61	ALL
15		W1272	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1272	4001R	22		46-13-11	ALL
19		W1272	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1272	2009R	20		73-21-21	ALL
22		W1272	2009B	20		73-21-21	ALL
23		W1272	2010R	20		73-21-21	ALL
24		W1272	2010B	20		73-21-21	ALL
25		W1272	2011R	20		73-21-21	ALL
26		W1272	2011B	20		73-21-21	ALL
27		W1272	2007R	20		73-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30142	**NSTA 258/149/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
28		W1272	2007B	20		73-21-12	ALL
29		W1272	2017B	20		SPARE	ALL
30		W1272	2017R	20		SPARE	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1272	2008R	20		73-21-11	ALL
34		W1272	2013R	20		73-24-12	ALL
35		W1272	2013B	20		73-24-12	ALL
36		W1272	2012B	20		73-24-21	ALL
37		W1272	2012R	20		73-24-21	ALL
38	UNUSED						ALL
39		W1272	4001G	22		46-13-11	ALL
PERB		W1272	2005Z			78-32-61	ALL
PERB		W1272	2007Z			73-21-12	ALL
PERB		W1272	2008Z			73-21-11	ALL
PERB		W1272	2009Z			73-21-21	ALL
PERB		W1272	2010Z			73-21-21	ALL
PERB		W1272	2011Z			73-21-21	ALL
PERB		W1272	2012Z			73-24-21	ALL
PERB		W1272	2013Z			73-24-12	ALL
PERB		W1272	2017Z			SPARE	ALL
PERB		W1272	3003Z			78-32-61	ALL
PERB		W1272	4001Z			46-13-11	ALL
D30146J	**NSTA 262/146/R013**		**RECP-CONDUCTIVE**				**ALL**
1		W1270	0002	20		26-11-21	ALL
2	UNUSED						ALL
3		W1270	1015R	20		26-11-21	ALL
4	UNUSED						ALL
5		W1270	3003R	18		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D30146J		**NSTA 262/146/R013**		**RECP-CONDUCTIVE (continued)**				**ALL**
	6		W1270	3003B	18		73-22-41	ALL
	7		W1270	3003Y	18		73-22-41	ALL
	PERB		W1270	1015Z			26-11-21	ALL
	PERB		W1270	3003Z			73-22-41	ALL
D30146P		**NSTA 170/136/R12**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1266	1014R	20		26-11-21	ALL
	2	UNUSED						ALL
	3		W1266	1013R	20		26-11-21	ALL
	4	UNUSED						ALL
	5		W1266	3003R	18		73-22-41	ALL
	6		W1266	3003B	18		73-22-41	ALL
	7		W1266	3003Y	18		73-22-41	ALL
	PERB		W1266	1013Z			26-11-21	ALL
	PERB		W1266	1014Z			26-11-21	ALL
	PERB		W1266	3003Z			73-22-41	ALL
D30148		**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1278	3002R	20		36-11-22	ALL
	2		W1278	1003	20		74-11-11	ALL
	3		W1278	2009B	20		36-11-23	ALL
	4	UNUSED						ALL
	5		W1278	2006B	20		36-11-23	ALL
	6		W1278	1001	18		73-22-11	ALL
	7		W1278	2003B	20		78-35-21	ALL
	8		W1278	2008R	20		36-11-23	ALL
	9		W1278	3002Y	20		36-11-22	ALL
	10		W1278	3002B	20		36-11-22	ALL
	11		W1278	1020	20		78-34-21	ALL
	12		W1278	2009R	20		36-11-23	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30148	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
14		W1278	2006R	20		36-11-23	ALL
15		W1278	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1278	2003R	20		78-35-21	ALL
18		W1278	2007B	20		36-11-23	ALL
19		W1278	1014R	20		26-11-21	ALL
20		W1278	2008B	20		36-11-23	ALL
21		W1278	2012R	20		36-11-23	ALL
22		W1278	2012B	20		36-11-23	ALL
23		W1278	2004R	20		73-21-12	ALL
24		W1278	2004B	20		73-21-12	ALL
25		W1278	1019	20		78-34-21	ALL
26		W1278	1022	20		78-34-21	ALL
27		W1278	1021	20		78-34-21	ALL
28		W1278	2011B	20		77-12-11	ALL
29		W1278	2011R	20		77-12-11	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W1278	3001B	20		79-31-11	ALL
35		W1278	3001R	20		79-31-11	ALL
36		W1278	2005B	20		36-11-23	ALL
37		W1278	2005R	20		36-11-23	ALL
38		W1278	2007R	20		36-11-23	ALL
39		W1278	1015R	20		26-11-21	ALL
PERB		W1278	1001ZI			73-22-11	ALL
PERB		W1278	1001ZO			73-22-11	ALL
PERB		W1278	1003Z			74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30148		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1278	1014Z			26-11-21	ALL
	PERB		W1278	1015Z			26-11-21	ALL
	PERB		W1278	1019Z			78-34-21	ALL
	PERB		W1278	1020Z			78-34-21	ALL
	PERB		W1278	1021Z			78-34-21	ALL
	PERB		W1278	1022Z			78-34-21	ALL
	PERB		W1278	2003Z			78-35-21	ALL
	PERB		W1278	2004Z			73-21-12	ALL
	PERB		W1278	2005Z			36-11-23	ALL
	PERB		W1278	2006Z			36-11-23	ALL
	PERB		W1278	2007Z			36-11-23	ALL
	PERB		W1278	2008Z			36-11-23	ALL
	PERB		W1278	2009Z			36-11-23	ALL
	PERB		W1278	2011Z			77-12-11	ALL
	PERB		W1278	2012Z			36-11-23	ALL
	PERB		W1278	3001Z			79-31-11	ALL
	PERB		W1278	3002Z			36-11-22	ALL
D30152		**NSTA-259/146/L013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1270	3002R	20		36-11-22	ALL
	2		W1270	1003	20		74-11-11	ALL
	3		W1270	2009B	20		36-11-23	ALL
	4	UNUSED						ALL
	5		W1270	2006B	20		36-11-23	ALL
	6		W1270	1001	18		73-22-11	ALL
	7		W1270	2003B	20		78-35-21	ALL
	8		W1270	2008R	20		36-11-23	ALL
	9		W1270	3002Y	20		36-11-22	ALL
	10		W1270	3002B	20		36-11-22	ALL
	11		W1270	1020	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30152	**NSTA-259/146/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
12		W1270	2009R	20		36-11-23	ALL
13	UNUSED						ALL
14		W1270	2006R	20		36-11-23	ALL
15		W1270	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1270	2003R	20		78-35-21	ALL
18		W1270	2007B	20		36-11-23	ALL
19		W1270	1014R	20		26-11-21	ALL
20		W1270	2008B	20		36-11-23	ALL
21		W1270	2012R	20		36-11-23	ALL
22		W1270	2012B	20		36-11-23	ALL
23		W1270	2004R	20		73-21-12	ALL
24		W1270	2004B	20		73-21-12	ALL
25		W1270	1019	20		78-34-21	ALL
26		W1270	1022	20		78-34-21	ALL
27		W1270	1021	20		78-34-21	ALL
28		W1270	2011B	20		77-12-11	ALL
29		W1270	2011R	20		77-12-11	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W1270	3001B	20		79-31-11	ALL
35		W1270	3001R	20		79-31-11	ALL
36		W1270	2005B	20		36-11-23	ALL
37		W1270	2005R	20		36-11-23	ALL
38		W1270	2007R	20		36-11-23	ALL
39		W1270	1015R	20		26-11-21	ALL
PERB		W1270	1001ZI			73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30152		**NSTA-259/146/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1270	1001ZO			73-22-11	ALL
	PERB		W1270	1003Z			74-11-11	ALL
	PERB		W1270	1014Z			26-11-21	ALL
	PERB		W1270	1015Z			26-11-21	ALL
	PERB		W1270	1019Z			78-34-21	ALL
	PERB		W1270	1020Z			78-34-21	ALL
	PERB		W1270	1021Z			78-34-21	ALL
	PERB		W1270	1022Z			78-34-21	ALL
	PERB		W1270	2003Z			78-35-21	ALL
	PERB		W1270	2004Z			73-21-12	ALL
	PERB		W1270	2005Z			36-11-23	ALL
	PERB		W1270	2006Z			36-11-23	ALL
	PERB		W1270	2007Z			36-11-23	ALL
	PERB		W1270	2008Z			36-11-23	ALL
	PERB		W1270	2009Z			36-11-23	ALL
	PERB		W1270	2011Z			77-12-11	ALL
	PERB		W1270	2012Z			36-11-23	ALL
	PERB		W1270	3001Z			79-31-11	ALL
	PERB		W1270	3002Z			36-11-22	ALL
D30162		**IFSS-229/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1282	3001R	18		73-22-41	ALL
	2	UNUSED						ALL
	3		W1282	3001B	18		73-22-41	ALL
	4		W1282	2008R	20		30-21-32	ALL
	5		W1282	3001Y	18		73-22-41	ALL
	6		W1282	1001	18		73-22-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W1282	2011B	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30162	**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10		W1282	2012B	20		36-11-23	ALL
11		W1282	2006B	20		76-21-21	ALL
12		W1282	3004Y	20		36-11-23	ALL
13		W1282	2008B	20		30-21-32	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W1282	1007	20		74-11-11	ALL
18	UNUSED						ALL
19		W1282	1010R	20		26-11-21	ALL
20	UNUSED						ALL
21		W1282	2011R	20		36-11-23	ALL
22		W1282	2012R	20		36-11-23	ALL
23		W1282	2001R	20		73-21-12	ALL
24		W1282	2001B	20		73-21-12	ALL
25		W1282	2006R	20		76-21-21	ALL
26		W1282	3004R	20		36-11-23	ALL
27		W1282	3004B	20		36-11-23	ALL
28		W1282	2002B	20		77-12-21	ALL
29		W1282	2002R	20		77-12-21	ALL
30		W1282	2005B	20		30-21-32	ALL
31		W1282	2005R	20		30-21-32	ALL
32		W1282	2004B	20		30-21-32	ALL
33		W1282	2004R	20		30-21-32	ALL
34		W1282	2003B	20		30-21-32	ALL
35		W1282	2003R	20		30-21-32	ALL
36	18	W1282	1003R	18		26-12-11	ALL
37		W1282	1005R	20		26-12-11	ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30162		**IFSS-229/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	39		W1282	1011R	20		26-11-21	ALL
	PERB		W1282	1001ZI			73-22-11	ALL
	PERB		W1282	1001ZO			73-22-11	ALL
	PERB		W1282	1003Z			26-12-11	ALL
	PERB		W1282	1005Z			26-12-11	ALL
	PERB		W1282	1007Z			74-11-11	ALL
	PERB		W1282	1010Z			26-11-21	ALL
	PERB		W1282	1011Z			26-11-21	ALL
	PERB		W1282	2001Z			73-21-12	ALL
	PERB		W1282	2002Z			77-12-21	ALL
	PERB		W1282	2003Z			30-21-32	ALL
	PERB		W1282	2004Z			30-21-32	ALL
	PERB		W1282	2005Z			30-21-32	ALL
	PERB		W1282	2006Z			76-21-21	ALL
	PERB		W1282	2008Z			30-21-32	ALL
	PERB		W1282	2011Z			36-11-23	ALL
	PERB		W1282	2012Z			36-11-23	ALL
	PERB		W1282	3001Z			73-22-41	ALL
	PERB		W1282	3004Z			36-11-23	ALL
D30164		**NSTA 260/142/L013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1266	3002R	18		73-22-41	ALL
	2	UNUSED						ALL
	3		W1266	3002B	18		73-22-41	ALL
	4		W1266	2008R	20		30-21-32	ALL
	5		W1266	3002Y	18		73-22-41	ALL
	6		W1266	1001	18		73-22-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W1266	2011B	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30164	**NSTA 260/142/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10		W1266	2012B	20		36-11-23	ALL
11		W1266	2006B	20		76-21-21	ALL
12		W1266	3004Y	20		36-11-23	ALL
13		W1266	2008B	20		30-21-32	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W1266	1003	20		74-11-11	ALL
18	UNUSED						ALL
19		W1266	1010R	20		26-11-21	ALL
20	UNUSED						ALL
21		W1266	2011R	20		36-11-23	ALL
22		W1266	2012R	20		36-11-23	ALL
23		W1266	2001R	20		73-21-12	ALL
24		W1266	2001B	20		73-21-12	ALL
25		W1266	2006R	20		76-21-21	ALL
26		W1266	3004R	20		36-11-23	ALL
27		W1266	3004B	20		36-11-23	ALL
28		W1266	2002B	20		77-12-21	ALL
29		W1266	2002R	20		77-12-21	ALL
30		W1266	2005B	20		30-21-32	ALL
31		W1266	2005R	20		30-21-32	ALL
32		W1266	2004B	20		30-21-32	ALL
33		W1266	2004R	20		30-21-32	ALL
34		W1266	2003B	20		30-21-32	ALL
35		W1266	2003R	20		30-21-32	ALL
36	18	W1266	1006R	18		26-12-11	ALL
37	18	W1266	1005R	18		26-12-11	ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30164		**NSTA 260/142/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	39		W1266	1011R	20		26-11-21	ALL
	PERB		W1266	1001ZI			73-22-11	ALL
	PERB		W1266	1001ZO			73-22-11	ALL
	PERB		W1266	1003Z			74-11-11	ALL
	PERB		W1266	1005Z			26-12-11	ALL
	PERB		W1266	1006Z			26-12-11	ALL
	PERB		W1266	1010Z			26-11-21	ALL
	PERB		W1266	1011Z			26-11-21	ALL
	PERB		W1266	2001Z			73-21-12	ALL
	PERB		W1266	2002Z			77-12-21	ALL
	PERB		W1266	2003Z			30-21-32	ALL
	PERB		W1266	2004Z			30-21-32	ALL
	PERB		W1266	2005Z			30-21-32	ALL
	PERB		W1266	2006Z			76-21-21	ALL
	PERB		W1266	2008Z			30-21-32	ALL
	PERB		W1266	2011Z			36-11-23	ALL
	PERB		W1266	2012Z			36-11-23	ALL
	PERB		W1266	3002Z			73-22-41	ALL
	PERB		W1266	3004Z			36-11-23	ALL
D30168		**IFSS 229/ /**		**PLUG-**				**ALL**
	1		W1292	3003Y	18		78-32-61	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W1292	2005R	20		78-32-61	ALL
	5		W1292	3003R	18		78-32-61	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1292	4001Y	22		46-13-11	ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30168	**IFSS 229/ /**		**PLUG- (continued)**				**ALL**
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1292	2005B	20		78-32-61	ALL
14		W1292	3003B	18		78-32-61	ALL
15		W1292	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1292	4001R	22		46-13-11	ALL
19		W1292	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1292	2009R	20		73-21-21	ALL
22		W1292	2009B	20		73-21-21	ALL
23		W1292	2010R	20		73-21-21	ALL
24		W1292	2010B	20		73-21-21	ALL
25		W1292	2011R	20		73-21-21	ALL
26		W1292	2011B	20		73-21-21	ALL
27		W1292	2007R	20		73-21-12	ALL
28		W1292	2007B	20		73-21-12	ALL
29		W1292	2017B	20		SPARE	ALL
30		W1292	2017R	20		SPARE	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1292	2008R	20		73-21-11	ALL
34		W1292	2013R	20		73-24-12	ALL
35		W1292	2013B	20		73-24-12	ALL
36		W1292	2012B	20		73-24-21	ALL
37		W1292	2012R	20		73-24-21	ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30168		**IFSS 229/ /**		**PLUG- (continued)**				**ALL**
	39		W1292	4001G	22		46-13-11	ALL
	PERB		W1292	2005Z			78-32-61	ALL
	PERB		W1292	2007Z			73-21-12	ALL
	PERB		W1292	2008Z			73-21-11	ALL
	PERB		W1292	2009Z			73-21-21	ALL
	PERB		W1292	2010Z			73-21-21	ALL
	PERB		W1292	2011Z			73-21-21	ALL
	PERB		W1292	2012Z			73-24-21	ALL
	PERB		W1292	2013Z			73-24-12	ALL
	PERB		W1292	2017Z			SPARE	ALL
	PERB		W1292	3003Z			78-32-61	ALL
	PERB		W1292	4001Z			46-13-11	ALL
D30184		**NSTA 258/144/L013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1268	3003Y	18		78-32-61	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W1268	2005R	20		78-32-61	ALL
	5		W1268	3003R	18		78-32-61	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1268	4001Y	22		46-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W1268	2005B	20		78-32-61	ALL
	14		W1268	3003B	18		78-32-61	ALL
	15		W1268	2008B	20		73-21-11	ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30184	**NSTA 258/144/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
17	UNUSED						ALL
18		W1268	4001R	22		46-13-11	ALL
19		W1268	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1268	2009R	20		73-21-21	ALL
22		W1268	2009B	20		73-21-21	ALL
23		W1268	2010R	20		73-21-21	ALL
24		W1268	2010B	20		73-21-21	ALL
25		W1268	2011R	20		73-21-21	ALL
26		W1268	2011B	20		73-21-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1268	2008R	20		73-21-11	ALL
34		W1268	2013R	20		73-24-12	ALL
35		W1268	2013B	20		73-24-12	ALL
36		W1268	2012B	20		73-24-21	ALL
37		W1268	2012R	20		73-24-21	ALL
38	UNUSED						ALL
39		W1268	4001G	22		46-13-11	ALL
PERB		W1268	2005Z			78-32-61	ALL
PERB		W1268	2008Z			73-21-11	ALL
PERB		W1268	2009Z			73-21-21	ALL
PERB		W1268	2010Z			73-21-21	ALL
PERB		W1268	2011Z			73-21-21	ALL
PERB		W1268	2012Z			73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30184	**NSTA 258/144/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1268	2013Z			73-24-12	ALL
PERB		W1268	3003Z			78-32-61	ALL
PERB		W1268	4001Z			46-13-11	ALL
D30192	**IFSS 229/ /**		**PLUG**				**ALL**
1		W1290	3003Y	18		78-32-61	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1290	2005R	20		78-32-61	ALL
5		W1290	3003R	18		78-32-61	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1290	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1290	2005B	20		78-32-61	ALL
14		W1290	3003B	18		78-32-61	ALL
15		W1290	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1290	4001R	22		46-13-11	ALL
19		W1290	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1290	2009R	20		73-21-21	ALL
22		W1290	2009B	20		73-21-21	ALL
23		W1290	2010R	20		73-21-21	ALL
24		W1290	2010B	20		73-21-21	ALL
25		W1290	2011R	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30192	**IFSS 229/ /**		**PLUG (continued)**				**ALL**
26		W1290	2011B	20		73-21-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1290	2008R	20		73-21-11	ALL
34		W1290	2013R	20		73-24-12	ALL
35		W1290	2013B	20		73-24-12	ALL
36		W1290	2012B	20		73-24-21	ALL
37		W1290	2012R	20		73-24-21	ALL
38	UNUSED						ALL
39		W1290	4001G	22		46-13-11	ALL
PERB		W1290	2005Z			78-32-61	ALL
PERB		W1290	2008Z			73-21-11	ALL
PERB		W1290	2009Z			73-21-21	ALL
PERB		W1290	2010Z			73-21-21	ALL
PERB		W1290	2011Z			73-21-21	ALL
PERB		W1290	2012Z			73-24-21	ALL
PERB		W1290	2013Z			73-24-12	ALL
PERB		W1290	3003Z			78-32-61	ALL
PERB		W1290	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30202		**NSTA 202/136/L12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1172	3003Y	18		78-32-51	ALL
	2		W1172	2001R	20		78-36-11	ALL
	3		W1172	2002B	20		78-36-11	ALL
	4		W1172	3001Y	20		78-35-11	ALL
	5		W1172	3001B	20		78-35-11	ALL
	6		W1172	3001R	20		78-35-11	ALL
	7		W1172	3003B	18		78-32-51	ALL
	8		W1172	3003R	18		78-32-51	ALL
	9		W1172	2003B	20		78-35-11	ALL
	10		W1172	2003R	20		78-35-11	ALL
	11		W1172	2001B	20		78-36-11	ALL
	12		W1172	2002R	20		78-36-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	PERB		W1172	2001Z			78-36-11	ALL
	PERB		W1172	2002Z			78-36-11	ALL
	PERB		W1172	2003Z			78-35-11	ALL
	PERB		W1172	3001Z			78-35-11	ALL
	PERB		W1172	3003Z			78-32-51	ALL
D30206		**NSTA 202/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2		W1172	3002B	20		78-35-11	ALL
	3		W1172	3002R	20		78-35-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1172	2004R	20		78-35-11	ALL
	7		W1172	2004B	20		78-35-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30206	**NSTA 202/136/R12**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
10		W1172	3002Y	20		78-35-11	ALL
PERB		W1172	2004Z			78-35-11	ALL
PERB		W1172	3002Z			78-35-11	ALL
D30208	**NSTA 200/136/L12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W1168	3001B	20		78-35-11	ALL
3		W1168	3001R	20		78-35-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1168	2003R	20		78-35-11	ALL
7		W1168	2003B	20		78-35-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W1168	3001Y	20		78-35-11	ALL
PERB		W1168	2003Z			78-35-11	ALL
PERB		W1168	3001Z			78-35-11	ALL
D30210	**NSTA 200/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1		W1168	3003Y	18		78-32-51	ALL
2		W1168	2001R	20		78-36-11	ALL
3		W1168	2002B	20		78-36-11	ALL
4		W1168	3002Y	20		78-35-11	ALL
5		W1168	3002B	20		78-35-11	ALL
6		W1168	3002R	20		78-35-11	ALL
7		W1168	3003B	18		78-32-51	ALL
8		W1168	3003R	18		78-32-51	ALL
9		W1168	2004B	20		78-35-11	ALL
10		W1168	2004R	20		78-35-11	ALL
11		W1168	2001B	20		78-36-11	ALL
12		W1168	2002R	20		78-36-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30210		**NSTA 200/136/R12**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	PERB		W1168	2001Z			78-36-11	ALL
	PERB		W1168	2002Z			78-36-11	ALL
	PERB		W1168	2004Z			78-35-11	ALL
	PERB		W1168	3002Z			78-35-11	ALL
	PERB		W1168	3003Z			78-32-51	ALL
D30212		**NSTA 178/134/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1170	3003R	18		73-22-41	ALL
	2		W1170	3003B	18		73-22-41	ALL
	3		W1170	1022	20		78-34-11	ALL
	4		W1170	1020	20		78-34-11	ALL
	5	UNUSED						ALL
	6		W1170	1001	18		73-22-11	ALL
	7		W1170	1002	18		73-22-11	ALL
	8		W1170	1004	20		74-11-11	ALL
	9		W1170	1003	20		74-11-11	ALL
	10		W1170	3003Y	18		73-22-41	ALL
	11		W1170	2003B	20		78-35-11	ALL
	12		W1170	2003R	20		78-35-11	ALL
	13		W1170	1021	20		78-34-11	ALL
	14		W1170	1019	20		78-34-11	ALL
	15		W1170	2004B	20		73-21-12	ALL
	16		W1170	2004R	20		73-21-12	ALL
	PERB		W1170	1001ZI			73-22-11	ALL
	PERB		W1170	1001ZO			73-22-11	ALL
	PERB		W1170	1002ZI			73-22-11	ALL
	PERB		W1170	1002ZO			73-22-11	ALL
	PERB		W1170	1003Z			74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30212	**NSTA 178/134/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
PERB		W1170	1004Z			74-11-11	ALL
PERB		W1170	1019Z			78-34-11	ALL
PERB		W1170	1020Z			78-34-11	ALL
PERB		W1170	1021Z			78-34-11	ALL
PERB		W1170	1022Z			78-34-11	ALL
PERB		W1170	2003Z			78-35-11	ALL
PERB		W1170	2004Z			73-21-12	ALL
PERB		W1170	3003Z			73-22-41	ALL
D30220	**NSTA 170/136/R012**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W1166	2004B	20		30-21-31	ALL
3		W1166	2004R	20		30-21-31	ALL
4		W1166	2005B	20		30-21-31	ALL
5		W1166	2002B	20		77-12-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1166	0006	20		30-21-31	ALL
9		W1166	2003B	20		30-21-31	ALL
10		W1166	2003R	20		30-21-31	ALL
11		W1166	0003	20		30-21-31	ALL
12		W1166	0004	20		30-21-31	ALL
13		W1166	0005	20		30-21-31	ALL
14		W1166	2005R	20		30-21-31	ALL
15	UNUSED						ALL
16		W1166	2002R	20		77-12-21	ALL
17		W1166	2006B	20		76-21-11	ALL
18		W1166	2006R	20		76-21-11	ALL
19		W1166	2008B	20		30-21-31	ALL
20		W1166	2008R	20		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30220		**NSTA 170/136/R012**		**RCPT-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W1166	0001	20		26-11-11	ALL
	24		W1166	1010R	20		26-11-11	ALL
	PERB		W1166	1010Z			26-11-11	ALL
	PERB		W1166	2002Z			77-12-21	ALL
	PERB		W1166	2003Z			30-21-31	ALL
	PERB		W1166	2004Z			30-21-31	ALL
	PERB		W1166	2005Z			30-21-31	ALL
	PERB		W1166	2006Z			76-21-11	ALL
	PERB		W1166	2008Z			30-21-31	ALL
D30224		**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1172	2006R	20		78-36-11	ALL
	2		W1172	2006B	20		78-36-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1172	2001R	20		78-36-11	ALL
	7		W1172	2001B	20		78-36-11	ALL
	8		W1172	2002R	20		78-36-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W1172	2003R	20		78-35-11	ALL
	12		W1172	2003B	20		78-35-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W1172	2008R	20		73-21-11	ALL
	16		W1172	2008B	20		73-21-11	ALL
	17		W1172	2007R	20		73-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30224	**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
18		W1172	2007B	20		73-21-12	ALL
19		W1172	2002B	20		78-36-11	ALL
20		W1172	2009R	20		73-21-21	ALL
21		W1172	2009B	20		73-21-21	ALL
22		W1172	2010B	20		73-21-21	ALL
23		W1172	2004R	20		78-35-11	ALL
24		W1172	2004B	20		78-35-11	ALL
25		W1172	3001R	20		78-35-11	ALL
26		W1172	3001Y	20		78-35-11	ALL
27	UNUSED						ALL
28		W1172	4001R	22		46-13-11	ALL
29		W1172	4001Y	22		46-13-11	ALL
30	UNUSED						ALL
31		W1172	2013R	20		73-24-12	ALL
32		W1172	2013B	20		73-24-12	ALL
33		W1172	0001	20		73-21-11	ALL
34	UNUSED						ALL
35		W1172	2017R	20		SPARE	ALL
36		W1172	2017B	20		SPARE	ALL
37		W1172	2005R	20		78-32-51	ALL
38		W1172	2011R	20		73-21-21	ALL
39		W1172	2011B	20		73-21-21	ALL
40		W1172	2010R	20		73-21-21	ALL
41		W1172	3002R	20		78-35-11	ALL
42		W1172	3002Y	20		78-35-11	ALL
43		W1172	3002B	20		78-35-11	ALL
44		W1172	3001B	20		78-35-11	ALL
45	UNUSED						ALL
46	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30224		**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	47		W1172	4001G	22		46-13-11	ALL
	48		W1172	4001B	22		46-13-11	ALL
	49	UNUSED						ALL
	50		W1172	2012R	20		73-24-11	ALL
	51		W1172	2012B	20		73-24-11	ALL
	52		W1172	0001	20		73-21-11	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W1172	2005B	20		78-32-51	ALL
	PERB		W1172	2001Z			78-36-11	ALL
	PERB		W1172	2002Z			78-36-11	ALL
	PERB		W1172	2003Z			78-35-11	ALL
	PERB		W1172	2004Z			78-35-11	ALL
	PERB		W1172	2005Z			78-32-51	ALL
	PERB		W1172	2006Z			78-36-11	ALL
	PERB		W1172	2007Z			73-21-12	ALL
	PERB		W1172	2008Z			73-21-11	ALL
	PERB		W1172	2009Z			73-21-21	ALL
	PERB		W1172	2010Z			73-21-21	ALL
	PERB		W1172	2011Z			73-21-21	ALL
	PERB		W1172	2012Z			73-24-11	ALL
	PERB		W1172	2013Z			73-24-12	ALL
	PERB		W1172	2017Z			SPARE	ALL
	PERB		W1172	3001Z			78-35-11	ALL
	PERB		W1172	3002Z			78-35-11	ALL
	PERB		W1172	4001Z			46-13-11	ALL
D30234		**NSTA 162/135/L11**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1164	3001R	18		24-21-11	ALL
	2		W1164	1004	20		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30234	**NSTA 162/135/L11**		**RCPT-CONDUCTIVE CONNECTOR (continued)**				**ALL**
3		W1164	4001G	20		24-24-11	ALL
4		W1164	2003R	20		SPARE	ALL
5		W1164	2003B	20		SPARE	ALL
6		W1164	3001Y	18		24-21-11	ALL
7		W1164	3001B	18		24-21-11	ALL
8		W1164	1003	20		29-11-11	ALL
9		W1164	1001	18		24-11-11	ALL
10		W1164	1002	18		24-11-11	ALL
11	UNUSED						ALL
12		W1164	4001R	20		24-24-11	ALL
13		W1164	4001Y	20		24-24-11	ALL
14		W1164	4001B	20		24-24-11	ALL
15	UNUSED						ALL
16		W1164	2001R	20		24-11-11	ALL
17		W1164	2001B	20		24-11-11	ALL
18		W1164	2002R	20		24-21-11	ALL
19		W1164	2002B	20		24-21-11	ALL
PERB		W1164	1001Z			24-11-11	ALL
PERB		W1164	1002Z			24-11-11	ALL
PERB		W1164	1003Z			29-11-11	ALL
PERB		W1164	1004Z			29-11-11	ALL
PERB		W1164	2001Z			24-11-11	ALL
PERB		W1164	2002Z			24-21-11	ALL
PERB		W1164	2003Z			SPARE	ALL
PERB		W1164	3001Z			24-21-11	ALL
PERB		W1164	4001Z			24-24-11	ALL
D30238	**NSTA 170/135/L11**		**RCPT-**				**ALL**
S/R	GW	W1162	1001Z			24-21-11	ALL
S/R	GW	W1162	1002Z			24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30238		**NSTA 170/135/L11**		**RCPT- (continued)**				**ALL**
	S/R	GW	W1162	1003Z			24-21-11	ALL
	S/R	GW	W1162	1004Z			24-21-11	ALL
	A		W1162	1001	*1		24-21-11	ALL
	B		W1162	1002	*1		24-21-11	ALL
	C		W1162	1003	*1		24-21-11	ALL
	D	HD	W1162	1004	04		24-21-11	ALL
D30252		**NSTA 172/134/R11**		**RECP-CONDUCTIVE**				**ALL**
	1		W1170	2011B	20		77-12-11	ALL
	2		W1170	3002R	20		36-11-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W1170	0005	20		36-11-13	ALL
	6		W1170	2011R	20		77-12-11	ALL
	7		W1170	3001B	20		79-31-11	ALL
	8		W1170	3002Y	20		36-11-12	ALL
	9		W1170	3002B	20		36-11-12	ALL
	10	UNUSED						ALL
	11		W1170	0004	20		36-11-13	ALL
	12		W1170	0003	20		36-11-13	ALL
	13		W1170	2005B	20		36-11-13	ALL
	14		W1170	2005R	20		36-11-13	ALL
	15		W1170	2009B	20		36-11-13	ALL
	16		W1170	2009R	20		36-11-13	ALL
	17		W1170	3001R	20		79-31-11	ALL
	18		W1170	3001Y	20		79-31-11	ALL
	19		W1170	2006B	20		36-11-13	ALL
	20		W1170	2006R	20		36-11-13	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30252		**NSTA 172/134/R11**		**RECP-CONDUCTIVE (continued)**				**ALL**
	23		W1170	0001	20		26-11-11	ALL
	24		W1170	1014R	20		26-11-11	ALL
	PERB		W1170	1014Z			26-11-11	ALL
	PERB		W1170	2005Z			36-11-13	ALL
	PERB		W1170	2006Z			36-11-13	ALL
	PERB		W1170	2009Z			36-11-13	ALL
	PERB		W1170	2011Z			77-12-11	ALL
	PERB		W1170	3001Z			79-31-11	ALL
	PERB		W1170	3002Z			36-11-12	ALL
D30256		**NSTA 163/136/R012**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1166	3001R	18		73-22-41	ALL
	2		W1166	3001B	18		73-22-41	ALL
	3		W1166	1002	18		73-22-11	ALL
	4		W1166	1004	20		74-11-11	ALL
	5		W1166	1003	20		74-11-11	ALL
	6		W1166	2001B	20		73-21-12	ALL
	7		W1166	2001R	20		73-21-12	ALL
	8	UNUSED						ALL
	9		W1166	3001Y	18		73-22-41	ALL
	10		W1166	1001	18		73-22-11	ALL
	PERB		W1166	1001ZI			73-22-11	ALL
	PERB		W1166	1001ZO			73-22-11	ALL
	PERB		W1166	1002ZI			73-22-11	ALL
	PERB		W1166	1002ZO			73-22-11	ALL
	PERB		W1166	1003Z			74-11-11	ALL
	PERB		W1166	1004Z			74-11-11	ALL
	PERB		W1166	2001Z			73-21-12	ALL
	PERB		W1166	3001Z			73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30260	**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1168	2001R	20		78-36-11	ALL
7		W1168	2001B	20		78-36-11	ALL
8		W1168	2002R	20		78-36-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W1168	2003R	20		78-35-11	ALL
12		W1168	2003B	20		78-35-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W1168	2008R	20		73-21-11	ALL
16		W1168	2008B	20		73-21-11	ALL
17		W1168	0001	20		73-21-11	ALL
18	UNUSED						ALL
19		W1168	2002B	20		78-36-11	ALL
20		W1168	2009R	20		73-21-21	ALL
21		W1168	2009B	20		73-21-21	ALL
22		W1168	2010B	20		73-21-21	ALL
23		W1168	2004R	20		78-35-11	ALL
24		W1168	2004B	20		78-35-11	ALL
25		W1168	3001R	20		78-35-11	ALL
26		W1168	3001Y	20		78-35-11	ALL
27	UNUSED						ALL
28		W1168	4001R	22		46-13-11	ALL
29		W1168	4001Y	22		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30260	**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
30	UNUSED						ALL
31		W1168	2013R	20		73-24-12	ALL
32		W1168	2013B	20		73-24-12	ALL
33		W1168	0001	20		73-21-11	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W1168	2005R	20		78-32-51	ALL
38		W1168	2011R	20		73-21-21	ALL
39		W1168	2011B	20		73-21-21	ALL
40		W1168	2010R	20		73-21-21	ALL
41		W1168	3002R	20		78-35-11	ALL
42		W1168	3002Y	20		78-35-11	ALL
43		W1168	3002B	20		78-35-11	ALL
44		W1168	3001B	20		78-35-11	ALL
45	UNUSED						ALL
46	UNUSED						ALL
47		W1168	4001G	22		46-13-11	ALL
48		W1168	4001B	22		46-13-11	ALL
49	UNUSED						ALL
50		W1168	2012R	20		73-24-11	ALL
51		W1168	2012B	20		73-24-11	ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W1168	2005B	20		78-32-51	ALL
PERB		W1168	2001Z			78-36-11	ALL
PERB		W1168	2002Z			78-36-11	ALL
PERB		W1168	2003Z			78-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30260		**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	PERB		W1168	2004Z			78-35-11	ALL
	PERB		W1168	2005Z			78-32-51	ALL
	PERB		W1168	2008Z			73-21-11	ALL
	PERB		W1168	2009Z			73-21-21	ALL
	PERB		W1168	2010Z			73-21-21	ALL
	PERB		W1168	2011Z			73-21-21	ALL
	PERB		W1168	2012Z			73-24-11	ALL
	PERB		W1168	2013Z			73-24-12	ALL
	PERB		W1168	3001Z			78-35-11	ALL
	PERB		W1168	3002Z			78-35-11	ALL
	PERB		W1168	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30402	**NSTA 202/136/L12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1		W1272	3003Y	18		78-32-61	ALL
2		W1272	2001R	20		78-36-21	ALL
3		W1272	2002B	20		78-36-21	ALL
4		W1272	3001Y	20		78-35-21	ALL
5		W1272	3001B	20		78-35-21	ALL
6		W1272	3001R	20		78-35-21	ALL
7		W1272	3003B	18		78-32-61	ALL
8		W1272	3003R	18		78-32-61	ALL
9		W1272	2003B	20		78-35-21	ALL
10		W1272	2003R	20		78-35-21	ALL
11		W1272	2001B	20		78-36-21	ALL
12		W1272	2002R	20		78-36-21	ALL
13	UNUSED						ALL
14	UNUSED						ALL
PERB		W1272	2001Z			78-36-21	ALL
PERB		W1272	2002Z			78-36-21	ALL
PERB		W1272	2003Z			78-35-21	ALL
PERB		W1272	3001Z			78-35-21	ALL
PERB		W1272	3003Z			78-32-61	ALL
D30406	**NSTA 202/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2		W1272	3002B	20		78-35-21	ALL
3		W1272	3002R	20		78-35-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1272	2004R	20		78-35-21	ALL
7		W1272	2004B	20		78-35-21	ALL
8	UNUSED						ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30406		**NSTA 202/136/R12**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	10		W1272	3002Y	20		78-35-21	ALL
	PERB		W1272	2004Z			78-35-21	ALL
	PERB		W1272	3002Z			78-35-21	ALL
D30408		**NSTA 200/136/L12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2		W1268	3001B	20		78-35-21	ALL
	3		W1268	3001R	20		78-35-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1268	2003R	20		78-35-21	ALL
	7		W1268	2003B	20		78-35-21	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W1268	3001Y	20		78-35-21	ALL
	PERB		W1268	2003Z			78-35-21	ALL
	PERB		W1268	3001Z			78-35-21	ALL
D30410		**NSTA 200/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1268	3003Y	18		78-32-61	ALL
	2		W1268	2001R	20		78-36-21	ALL
	3		W1268	2002B	20		78-36-21	ALL
	4		W1268	3002Y	20		78-35-21	ALL
	5		W1268	3002B	20		78-35-21	ALL
	6		W1268	3002R	20		78-35-21	ALL
	7		W1268	3003B	18		78-32-61	ALL
	8		W1268	3003R	18		78-32-61	ALL
	9		W1268	2004B	20		78-35-21	ALL
	10		W1268	2004R	20		78-35-21	ALL
	11		W1268	2001B	20		78-36-21	ALL
	12		W1268	2002R	20		78-36-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30410		**NSTA 200/136/R12**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	PERB		W1268	2001Z			78-36-21	ALL
	PERB		W1268	2002Z			78-36-21	ALL
	PERB		W1268	2004Z			78-35-21	ALL
	PERB		W1268	3002Z			78-35-21	ALL
	PERB		W1268	3003Z			78-32-61	ALL
D30412		**NSTA 178/134/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1270	3003R	18		73-22-41	ALL
	2		W1270	3003B	18		73-22-41	ALL
	3		W1270	1022	20		78-34-21	ALL
	4		W1270	1020	20		78-34-21	ALL
	5	UNUSED						ALL
	6		W1270	1001	18		73-22-11	ALL
	7		W1270	1002	18		73-22-11	ALL
	8		W1270	1004	20		74-11-11	ALL
	9		W1270	1003	20		74-11-11	ALL
	10		W1270	3003Y	18		73-22-41	ALL
	11		W1270	2003B	20		78-35-21	ALL
	12		W1270	2003R	20		78-35-21	ALL
	13		W1270	1021	20		78-34-21	ALL
	14		W1270	1019	20		78-34-21	ALL
	15		W1270	2004B	20		73-21-12	ALL
	16		W1270	2004R	20		73-21-12	ALL
	PERB		W1270	1001ZI			73-22-11	ALL
	PERB		W1270	1001ZO			73-22-11	ALL
	PERB		W1270	1002ZI			73-22-11	ALL
	PERB		W1270	1002ZO			73-22-11	ALL
	PERB		W1270	1003Z			74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D30412		**NSTA 178/134/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	PERB		W1270	1004Z			74-11-11	ALL
	PERB		W1270	1019Z			78-34-21	ALL
	PERB		W1270	1020Z			78-34-21	ALL
	PERB		W1270	1021Z			78-34-21	ALL
	PERB		W1270	1022Z			78-34-21	ALL
	PERB		W1270	2003Z			78-35-21	ALL
	PERB		W1270	2004Z			73-21-12	ALL
	PERB		W1270	3003Z			73-22-41	ALL
D30420		**NSTA 170/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2		W1266	2004B	20		30-21-32	ALL
	3		W1266	2004R	20		30-21-32	ALL
	4		W1266	2005B	20		30-21-32	ALL
	5		W1266	2002B	20		77-12-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1266	0006	20		30-21-32	ALL
	9		W1266	2003B	20		30-21-32	ALL
	10		W1266	2003R	20		30-21-32	ALL
	11		W1266	0003	20		30-21-32	ALL
	12		W1266	0004	20		30-21-32	ALL
	13		W1266	0005	20		30-21-32	ALL
	14		W1266	2005R	20		30-21-32	ALL
	15	UNUSED						ALL
	16		W1266	2002R	20		77-12-21	ALL
	17		W1266	2006B	20		76-21-21	ALL
	18		W1266	2006R	20		76-21-21	ALL
	19		W1266	2008B	20		30-21-32	ALL
	20		W1266	2008R	20		30-21-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30420	**NSTA 170/136/R12**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23		W1266	0001	20		26-11-21	ALL
24		W1266	1010R	20		26-11-21	ALL
PERB		W1266	1010Z			26-11-21	ALL
PERB		W1266	2002Z			77-12-21	ALL
PERB		W1266	2003Z			30-21-32	ALL
PERB		W1266	2004Z			30-21-32	ALL
PERB		W1266	2005Z			30-21-32	ALL
PERB		W1266	2006Z			76-21-21	ALL
PERB		W1266	2008Z			30-21-32	ALL
D30424	**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1		W1272	2006R	20		78-36-21	ALL
2		W1272	2006B	20		78-36-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1272	2001R	20		78-36-21	ALL
7		W1272	2001B	20		78-36-21	ALL
8		W1272	2002R	20		78-36-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W1272	2003R	20		78-35-21	ALL
12		W1272	2003B	20		78-35-21	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W1272	2008R	20		73-21-11	ALL
16		W1272	2008B	20		73-21-11	ALL
17		W1272	2007R	20		73-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30424		**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	18		W1272	2007B	20		73-21-12	ALL
	19		W1272	2002B	20		78-36-21	ALL
	20		W1272	2009R	20		73-21-21	ALL
	21		W1272	2009B	20		73-21-21	ALL
	22		W1272	2010B	20		73-21-21	ALL
	23		W1272	2004R	20		78-35-21	ALL
	24		W1272	2004B	20		78-35-21	ALL
	25		W1272	3001R	20		78-35-21	ALL
	26		W1272	3001Y	20		78-35-21	ALL
	27	UNUSED						ALL
	28		W1272	4001R	22		46-13-11	ALL
	29		W1272	4001Y	22		46-13-11	ALL
	30	UNUSED						ALL
	31		W1272	2013R	20		73-24-12	ALL
	32		W1272	2013B	20		73-24-12	ALL
	33	UNUSED						ALL
	34		W1272	0001	20		73-21-11	ALL
	35		W1272	2017R	20		SPARE	ALL
	36		W1272	2017B	20		SPARE	ALL
	37		W1272	2005R	20		78-32-61	ALL
	38		W1272	2011R	20		73-21-21	ALL
	39		W1272	2011B	20		73-21-21	ALL
	40		W1272	2010R	20		73-21-21	ALL
	41		W1272	3002R	20		78-35-21	ALL
	42		W1272	3002Y	20		78-35-21	ALL
	43		W1272	3002B	20		78-35-21	ALL
	44		W1272	3001B	20		78-35-21	ALL
	45	UNUSED						ALL
	46	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30424	**NSTA 182/135/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
47		W1272	4001G	22		46-13-11	ALL
48		W1272	4001B	22		46-13-11	ALL
49	UNUSED						ALL
50		W1272	2012R	20		73-24-21	ALL
51		W1272	2012B	20		73-24-21	ALL
52		W1272	0001	20		73-21-11	ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W1272	2005B	20		78-32-61	ALL
PERB		W1272	2001Z			78-36-21	ALL
PERB		W1272	2002Z			78-36-21	ALL
PERB		W1272	2003Z			78-35-21	ALL
PERB		W1272	2004Z			78-35-21	ALL
PERB		W1272	2005Z			78-32-61	ALL
PERB		W1272	2006Z			78-36-21	ALL
PERB		W1272	2007Z			73-21-12	ALL
PERB		W1272	2008Z			73-21-11	ALL
PERB		W1272	2009Z			73-21-21	ALL
PERB		W1272	2010Z			73-21-21	ALL
PERB		W1272	2011Z			73-21-21	ALL
PERB		W1272	2012Z			73-24-21	ALL
PERB		W1272	2013Z			73-24-12	ALL
PERB		W1272	2017Z			SPARE	ALL
PERB		W1272	3001Z			78-35-21	ALL
PERB		W1272	3002Z			78-35-21	ALL
PERB		W1272	4001Z			46-13-11	ALL
D30434	**NSTA 162/135/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1		W1264	3001R	18		24-21-21	ALL
2		W1264	1004	20		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30434		**NSTA 162/135/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	3		W1264	4001G	20		24-24-21	ALL
	4		W1264	2003R	20		SPARE	ALL
	5		W1264	2003B	20		SPARE	ALL
	6		W1264	3001Y	18		24-21-21	ALL
	7		W1264	3001B	18		24-21-21	ALL
	8		W1264	1003	20		29-11-11	ALL
	9		W1264	1001	18		24-11-21	ALL
	10		W1264	1002	18		24-11-21	ALL
	11	UNUSED						ALL
	12		W1264	4001R	20		24-24-21	ALL
	13		W1264	4001Y	20		24-24-21	ALL
	14		W1264	4001B	20		24-24-21	ALL
	15	UNUSED						ALL
	16		W1264	2001R	20		24-11-21	ALL
	17		W1264	2001B	20		24-11-21	ALL
	18		W1264	2002R	20		24-21-21	ALL
	19		W1264	2002B	20		24-21-21	ALL
	PERB		W1264	1001Z			24-11-21	ALL
	PERB		W1264	1002Z			24-11-21	ALL
	PERB		W1264	1003Z			29-11-11	ALL
	PERB		W1264	1004Z			29-11-11	ALL
	PERB		W1264	2001Z			24-11-21	ALL
	PERB		W1264	2002Z			24-21-21	ALL
	PERB		W1264	2003Z			SPARE	ALL
	PERB		W1264	3001Z			24-21-21	ALL
	PERB		W1264	4001Z			24-24-21	ALL
D30438		**NSTA 170/135/L11**		**RECP-**				**ALL**
	S/R	GW	W1262	1001Z			24-21-21	ALL
	S/R	GW	W1262	1002Z			24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30438	**NSTA 170/135/L11**		**RECP- (continued)**				**ALL**
S/R	GW	W1262	1003Z			24-21-21	ALL
S/R	GW	W1262	1004Z			24-21-21	ALL
A		W1262	1001	*1		24-21-21	ALL
B		W1262	1002	*1		24-21-21	ALL
C		W1262	1003	*1		24-21-21	ALL
D		W1262	1004	04		24-21-21	ALL
D30452	**NSTA 172/134/R11**		**RECP-CONDUCTIVE**				**ALL**
1		W1270	2011B	20		77-12-11	ALL
2		W1270	3002R	20		36-11-22	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1270	0005	20		36-11-23	ALL
6		W1270	2011R	20		77-12-11	ALL
7		W1270	3001B	20		79-31-11	ALL
8		W1270	3002Y	20		36-11-22	ALL
9		W1270	3002B	20		36-11-22	ALL
10	UNUSED						ALL
11		W1270	0004	20		36-11-23	ALL
12		W1270	0003	20		36-11-23	ALL
13		W1270	2005B	20		36-11-23	ALL
14		W1270	2005R	20		36-11-23	ALL
15		W1270	2009B	20		36-11-23	ALL
16		W1270	2009R	20		36-11-23	ALL
17		W1270	3001R	20		79-31-11	ALL
18		W1270	3001Y	20		79-31-11	ALL
19		W1270	2006B	20		36-11-23	ALL
20		W1270	2006R	20		36-11-23	ALL
21	UNUSED						ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30452		**NSTA 172/134/R11**		**RECP-CONDUCTIVE (continued)**				**ALL**
	23		W1270	0001	20		26-11-21	ALL
	24		W1270	1014R	20		26-11-21	ALL
	PERB		W1270	1014Z			26-11-21	ALL
	PERB		W1270	2005Z			36-11-23	ALL
	PERB		W1270	2006Z			36-11-23	ALL
	PERB		W1270	2009Z			36-11-23	ALL
	PERB		W1270	2011Z			77-12-11	ALL
	PERB		W1270	3001Z			79-31-11	ALL
	PERB		W1270	3002Z			36-11-22	ALL
D30456		**NSTA 163/136/R12**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1266	3001R	18		73-22-41	ALL
	2		W1266	3001B	18		73-22-41	ALL
	3		W1266	1002	18		73-22-11	ALL
	4		W1266	1004	20		74-11-11	ALL
	5		W1266	1003	20		74-11-11	ALL
	6		W1266	2001B	20		73-21-12	ALL
	7		W1266	2001R	20		73-21-12	ALL
	8	UNUSED						ALL
	9		W1266	3001Y	18		73-22-41	ALL
	10		W1266	1001	18		73-22-11	ALL
	PERB		W1266	1001ZI			73-22-11	ALL
	PERB		W1266	1001ZO			73-22-11	ALL
	PERB		W1266	1002ZI			73-22-11	ALL
	PERB		W1266	1002ZO			73-22-11	ALL
	PERB		W1266	1003Z			74-11-11	ALL
	PERB		W1266	1004Z			74-11-11	ALL
	PERB		W1266	2001Z			73-21-12	ALL
	PERB		W1266	3001Z			73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30460	**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W1268	2001R	20		78-36-21	ALL
7		W1268	2001B	20		78-36-21	ALL
8		W1268	2002R	20		78-36-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W1268	2003R	20		78-35-21	ALL
12		W1268	2003B	20		78-35-21	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W1268	2008R	20		73-21-11	ALL
16		W1268	2008B	20		73-21-11	ALL
17		W1268	0001	20		73-21-11	ALL
18	UNUSED						ALL
19		W1268	2002B	20		78-36-21	ALL
20		W1268	2009R	20		73-21-21	ALL
21		W1268	2009B	20		73-21-21	ALL
22		W1268	2010B	20		73-21-21	ALL
23		W1268	2004R	20		78-35-21	ALL
24		W1268	2004B	20		78-35-21	ALL
25		W1268	3001R	20		78-35-21	ALL
26		W1268	3001Y	20		78-35-21	ALL
27	UNUSED						ALL
28		W1268	4001R	22		46-13-11	ALL
29		W1268	4001Y	22		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30460		**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	30	UNUSED						ALL
	31		W1268	2013R	20		73-24-12	ALL
	32		W1268	2013B	20		73-24-12	ALL
	33		W1268	0001	20		73-21-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W1268	2005R	20		78-32-61	ALL
	38		W1268	2011R	20		73-21-21	ALL
	39		W1268	2011B	20		73-21-21	ALL
	40		W1268	2010R	20		73-21-21	ALL
	41		W1268	3002R	20		78-35-21	ALL
	42		W1268	3002Y	20		78-35-21	ALL
	43		W1268	3002B	20		78-35-21	ALL
	44		W1268	3001B	20		78-35-21	ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47		W1268	4001G	22		46-13-11	ALL
	48		W1268	4001B	22		46-13-11	ALL
	49	UNUSED						ALL
	50		W1268	2012R	20		73-24-21	ALL
	51		W1268	2012B	20		73-24-21	ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W1268	2005B	20		78-32-61	ALL
	PERB		W1268	2001Z			78-36-21	ALL
	PERB		W1268	2002Z			78-36-21	ALL
	PERB		W1268	2003Z			78-35-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D30460		**NSTA 186/136/R11**		**RECP-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	PERB		W1268	2004Z			78-35-21	ALL
	PERB		W1268	2005Z			78-32-61	ALL
	PERB		W1268	2008Z			73-21-11	ALL
	PERB		W1268	2009Z			73-21-21	ALL
	PERB		W1268	2010Z			73-21-21	ALL
	PERB		W1268	2011Z			73-21-21	ALL
	PERB		W1268	2012Z			73-24-21	ALL
	PERB		W1268	2013Z			73-24-12	ALL
	PERB		W1268	3001Z			78-35-21	ALL
	PERB		W1268	3002Z			78-35-21	ALL
	PERB		W1268	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D37001J		**AB0288/ /**		**RCPT**				**ALL**
	1		W3701	0002	20		23-70-11	ALL
	2		W3701	0003	20		23-70-11	ALL
	3		W3701	2502B	24		23-70-11	ALL
	4		W3701	2502W	24		23-70-11	ALL
	5	UNUSED						ALL
	6		W3701	0001	20		23-70-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3701	2502Z			23-70-11	ALL
D37001P		**AB0288/ /**		**PLUG**				**ALL**
	1		W3801	0002	22		23-70-11	ALL
	2		W3801	0003	22		23-70-11	ALL
	3		W3801	2502B	24		23-70-11	ALL
	4		W3801	2502W	24		23-70-11	ALL
	5	UNUSED						ALL
	6		W3801	0001	22		23-70-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3801	2502Z			23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39108	**288/193/L012**		**PLUG**				**ALL**
1		W7032	A-R			32-31-11	ALL
2		W7032	A-B			32-31-11	ALL
3		W7032	A-Y			32-31-11	ALL
4	UNUSED						ALL
5		W7034	A-R			32-64-11	ALL
6		W7034	A-B			32-64-11	ALL
7		W7034	A-Y			32-64-11	ALL
8	UNUSED						ALL
9		W8032	A-R			32-31-12	ALL
10		W8032	A-B			32-31-12	ALL
11	UNUSED						ALL
12		W8032	A-Y			32-31-12	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39108		**288/193/L012**		**PLUG (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36		W7144	2102B	20		32-49-11	ALL
	37		W7144	2102R	20		32-49-11	ALL
	38		W7144	2101B	20		32-49-11	ALL
	39		W7144	2101R	20		32-49-11	ALL
	S/R		W7144	2101ZI			32-49-11	ALL
	S/R		W7144	2102ZI			32-49-11	ALL
	DED		W7144	2101ZO			32-49-11	ALL
	DED		W7144	2102ZO			32-49-11	ALL
D39110		**290/194/L012**		**PLUG**				**ALL**
	1		W5156	2226R	20		32-31-11	ALL
	2		W5156	2226B	20		32-31-11	ALL
	3		W5156	0601	18		32-31-11	ALL
	4	UNUSED						ALL
	5		W5156	2206R	20		32-64-11	ALL
	6		W5156	2206B	20		32-64-11	ALL
	7		W5156	0651	18		32-64-11	ALL
	8	UNUSED						ALL
	9		W5156	2619R	20		32-31-12	ALL
	10		W5156	2619B	20		32-31-12	ALL
	11	UNUSED						ALL
	12		W5156	0718	18		32-31-12	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39110	**290/194/L012**		**PLUG (continued)**				**ALL**
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W5156	2104B	20		32-49-11	ALL
37		W5156	2104R	20		32-49-11	ALL
38		W5156	2103B	20		32-49-11	ALL
39		W5156	2103R	20		32-49-11	ALL
PERB		W5156	2103Z			32-49-11	ALL
PERB		W5156	2104Z			32-49-11	ALL
D39112	**259/ /**		**PLUG**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39112		**259/ /**		**PLUG (continued)**				**ALL**
	2		W8034	A-Y			32-64-12	ALL
	3		W8034	A-B			32-64-12	ALL
	4		W8034	A-R			32-64-12	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	C1	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
D39114		**290/189/R017**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5160	0505	18		32-64-12	ALL
	3		W5160	2213B	20		32-64-12	ALL
	4		W5160	2213R	20		32-64-12	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	C1	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39901	**AC0520/181/L060**		**PLUG-CONDUCTIVE**				**ALL**
1		W5166	6004R	20		26-12-11	ALL
2		W5166	0120	22		30-11-11	ALL
3	UNUSED						ALL
4		W5166	0001	20		30-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5166	2202R	24		27-81-12	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5166	2213R	24		27-81-12	ALL
12		W5166	2213B	24		27-81-12	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5166	2214R	24		27-81-12	ALL
16		W5166	2214B	24		27-81-12	ALL
17	UNUSED						ALL
18		W5166	2204B	24		27-81-12	ALL
19		W5166	2202B	24		27-81-12	ALL
20		W5166	2205R	24		27-81-12	ALL
21		W5166	2205B	24		27-81-12	ALL
22		W5166	2206R	24		27-81-12	ALL
23		W5166	2206B	24		27-81-12	ALL
24		W5166	2207R	24		27-81-12	ALL
25		W5166	2207B	24		27-81-12	ALL
26	UNUSED						ALL
27		W5166	2208R	24		27-81-12	ALL
28		W5166	2208B	24		27-81-12	ALL
29		W5166	2215R	24		27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39901	**AC0520/181/L060**		**PLUG-CONDUCTIVE (continued)**				**ALL**
30		W5166	2215B	24		27-81-12	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W5166	2211R	24		27-81-12	ALL
36		W5166	2211B	24		27-81-12	ALL
37		W5166	2212R	24		27-81-12	ALL
38		W5166	2212B	24		27-81-12	ALL
39		W5166	2204R	24		27-81-12	ALL
D39902	**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6166	6004R	20		26-12-11	ALL
2		W6166	0120	22		30-11-11	ALL
3	UNUSED						ALL
4		W6166	0001	20		30-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6166	2202R	24		27-81-22	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W6166	2213R	24		27-81-22	ALL
12		W6166	2213B	24		27-81-22	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W6166	2214R	24		27-81-22	ALL
16		W6166	2214B	24		27-81-22	ALL
17	UNUSED						ALL
18		W6166	2204B	24		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39902	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
19		W6166	2202B	24		27-81-22	ALL
20		W6166	2205R	24		27-81-22	ALL
21		W6166	2205B	24		27-81-22	ALL
22		W6166	2206R	24		27-81-22	ALL
23		W6166	2206B	24		27-81-22	ALL
24		W6166	2207R	24		27-81-22	ALL
25		W6166	2207B	24		27-81-22	ALL
26	UNUSED						ALL
27		W6166	2208R	24		27-81-22	ALL
28		W6166	2208B	24		27-81-22	ALL
29		W6166	2215R	24		27-81-22	ALL
30		W6166	2215B	24		27-81-22	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W6166	2211R	24		27-81-22	ALL
36		W6166	2211B	24		27-81-22	ALL
37		W6166	2212R	24		27-81-22	ALL
38		W6166	2212B	24		27-81-22	ALL
39		W6166	2204R	24		27-81-22	ALL
D39903	**IFSS-80/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1188	1014R	18		26-12-11	ALL
2		W1188	1012	20		30-11-11	ALL
3	UNUSED						ALL
4		W1188	1015	20		30-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39903		**IFSS-80/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8		W1188	2009R	20		27-81-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W1188	2601R	20		27-81-12	ALL
	12		W1188	2601B	20		27-81-12	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W1188	2602R	20		27-81-12	ALL
	16		W1188	2602B	20		27-81-12	ALL
	17	UNUSED						ALL
	18		W1188	2008B	20		27-81-12	ALL
	19		W1188	2009B	20		27-81-12	ALL
	20		W1188	2010R	20		27-81-12	ALL
	21		W1188	2010B	20		27-81-12	ALL
	22		W1188	2011R	20		27-81-12	ALL
	23		W1188	2011B	20		27-81-12	ALL
	24		W1188	2012R	20		27-81-12	ALL
	25		W1188	2012B	20		27-81-12	ALL
	26	UNUSED						ALL
	27		W1188	2006R	20		27-81-12	ALL
	28		W1188	2006B	20		27-81-12	ALL
	29		W1188	2603R	20		27-81-12	ALL
	30		W1188	2603B	20		27-81-12	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W1188	2005R	20		27-81-12	ALL
	36		W1188	2005B	20		27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39903	**IFSS-80/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
37		W1188	2007R	20		27-81-12	ALL
38		W1188	2007B	20		27-81-12	ALL
39		W1188	2008R	20		27-81-12	ALL
S/R		W1188	1012Z			30-11-11	ALL
S/R		W1188	1014Z			26-12-11	ALL
S/R		W1188	1015Z			30-11-11	ALL
S/R		W1188	2005Z			27-81-12	ALL
S/R		W1188	2006Z			27-81-12	ALL
S/R		W1188	2007Z			27-81-12	ALL
S/R		W1188	2008Z			27-81-12	ALL
S/R		W1188	2009Z			27-81-12	ALL
S/R		W1188	2010Z			27-81-12	ALL
S/R		W1188	2011Z			27-81-12	ALL
S/R		W1188	2012Z			27-81-12	ALL
S/R		W1188	2601Z			27-81-12	ALL
S/R		W1188	2602Z			27-81-12	ALL
S/R		W1188	2603Z			27-81-12	ALL
D39904	**IFSS 79/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1288	1014R	18		26-12-11	ALL
2		W1288	1012	20		30-11-11	ALL
3	UNUSED						ALL
4		W1288	1015	20		30-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1288	2009R	20		27-81-22	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W1288	2601R	20		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39904		**IFSS 79/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	12		W1288	2601B	20		27-81-22	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W1288	2602R	20		27-81-22	ALL
	16		W1288	2602B	20		27-81-22	ALL
	17	UNUSED						ALL
	18		W1288	2008B	20		27-81-22	ALL
	19		W1288	2009B	20		27-81-22	ALL
	20		W1288	2010R	20		27-81-22	ALL
	21		W1288	2010B	20		27-81-22	ALL
	22		W1288	2011R	20		27-81-22	ALL
	23		W1288	2011B	20		27-81-22	ALL
	24		W1288	2012R	20		27-81-22	ALL
	25		W1288	2012B	20		27-81-22	ALL
	26	UNUSED						ALL
	27		W1288	2006R	20		27-81-22	ALL
	28		W1288	2006B	20		27-81-22	ALL
	29		W1288	2603R	20		27-81-22	ALL
	30		W1288	2603B	20		27-81-22	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W1288	2005R	20		27-81-22	ALL
	36		W1288	2005B	20		27-81-22	ALL
	37		W1288	2007R	20		27-81-22	ALL
	38		W1288	2007B	20		27-81-22	ALL
	39		W1288	2008R	20		27-81-22	ALL
	S/R		W1288	1012Z			30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39904	**IFSS 79/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W1288	1014Z			26-12-11	ALL
S/R		W1288	1015Z			30-11-11	ALL
S/R		W1288	2005Z			27-81-22	ALL
S/R		W1288	2006Z			27-81-22	ALL
S/R		W1288	2007Z			27-81-22	ALL
S/R		W1288	2008Z			27-81-22	ALL
S/R		W1288	2009Z			27-81-22	ALL
S/R		W1288	2010Z			27-81-22	ALL
S/R		W1288	2011Z			27-81-22	ALL
S/R		W1288	2012Z			27-81-22	ALL
S/R		W1288	2601Z			27-81-22	ALL
S/R		W1288	2602Z			27-81-22	ALL
S/R		W1288	2603Z			27-81-22	ALL
D39921	**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5162	0001	18		78-32-51	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W5162	2201R	20		78-32-51	ALL
5		W5162	2613R	18		78-32-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5162	4001Y	24		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5162	2201B	20		78-32-51	ALL
14		W5162	2613B	18		78-32-51	ALL
15		W5162	2606B	24		73-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39921		**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W5162	4001R	24		46-13-11	ALL
	19		W5162	4001B	24		46-13-11	ALL
	20	UNUSED						ALL
	21		W5162	2603R	20		73-21-21	ALL
	22		W5162	2603B	20		73-21-21	ALL
	23		W5162	2608R	20		73-21-21	ALL
	24		W5162	2608B	20		73-21-21	ALL
	25		W5162	2607R	20		73-21-21	ALL
	26		W5162	2607B	20		73-21-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W5162	2609R	20		SPARE	ALL
	31		W5162	2609B	20		SPARE	ALL
	32	UNUSED						ALL
	33		W5162	2606R	24		73-21-11	ALL
	34		W5162	2611R	24		73-24-12	ALL
	35		W5162	2611B	24		73-24-12	ALL
	36		W5162	2604B	24		73-24-11	ALL
	37		W5162	2604R	24		73-24-11	ALL
	38	UNUSED						ALL
	39		W5162	4001G	24		46-13-11	ALL
	S/R		W5162	2201Z			78-32-51	ALL
	S/R		W5162	2603Z			73-21-21	ALL
	S/R		W5162	2604Z			73-24-11	ALL
	S/R		W5162	2606Z			73-21-11	ALL
	S/R		W5162	2607Z			73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39921	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W5162	2608Z			73-21-21	ALL
S/R		W5162	2609Z			SPARE	ALL
S/R		W5162	2611Z			73-24-12	ALL
S/R		W5162	2613Z			78-32-51	ALL
S/R		W5162	4001Z			46-13-11	ALL
D39922	**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6162	0002	18		78-32-61	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W6162	2613R	20		78-32-61	ALL
5		W6162	2614R	18		78-32-61	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6162	4001Y	24		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W6162	2613B	20		78-32-61	ALL
14		W6162	2614B	18		78-32-61	ALL
15		W6162	2606B	24		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W6162	4001R	24		46-13-11	ALL
19		W6162	4001B	24		46-13-11	ALL
20	UNUSED						ALL
21		W6162	2609R	20		73-21-21	ALL
22		W6162	2609B	20		73-21-21	ALL
23		W6162	2607R	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39922		**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	24		W6162	2607B	20		73-21-21	ALL
	25		W6162	2608R	20		73-21-21	ALL
	26		W6162	2608B	20		73-21-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W6162	2612R	20		SPARE	ALL
	31		W6162	2612B	20		SPARE	ALL
	32	UNUSED						ALL
	33		W6162	2606R	24		73-21-11	ALL
	34		W6162	2603R	24		73-24-12	ALL
	35		W6162	2603B	24		73-24-12	ALL
	36		W6162	2602B	24		73-24-21	ALL
	37		W6162	2602R	24		73-24-21	ALL
	38	UNUSED						ALL
	39		W6162	4001G	24		46-13-11	ALL
	S/R		W6162	2602Z			73-24-21	ALL
	S/R		W6162	2603Z			73-24-12	ALL
	S/R		W6162	2606Z			73-21-11	ALL
	S/R		W6162	2607Z			73-21-21	ALL
	S/R		W6162	2608Z			73-21-21	ALL
	S/R		W6162	2609Z			73-21-21	ALL
	S/R		W6162	2613Z			78-32-61	ALL
	S/R		W6162	2614Z			78-32-61	ALL
	S/R		W6162	4001Z			46-13-11	ALL
D39925		**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5170	2510R	20		36-11-12	ALL
	2		W5170	1301	20		74-11-11	ALL
	3		W5170	2009B	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39925	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
4	UNUSED						ALL
5		W5170	2006B	20		36-11-13	ALL
6		W5170	1302	20		73-22-11	ALL
7		W5170	0511	20		78-35-11	ALL
8		W5170	2008R	20		36-11-13	ALL
9		W5170	0009	20		36-11-12	ALL
10		W5170	2510B	20		36-11-12	ALL
11		W5170	1007	20		78-34-11	ALL
12		W5170	2009R	20		36-11-13	ALL
13	UNUSED						ALL
14		W5170	2006R	20		36-11-13	ALL
15		W5170	3601Y	24		79-31-11	ALL
16	UNUSED						ALL
17		W5170	0512	20		78-35-11	ALL
18		W5170	2007B	20		36-11-13	ALL
19		W5170	6002R	20		26-11-11	ALL
20		W5170	2008B	20		36-11-13	ALL
21		W5170	2012R	20		36-11-13	ALL
22		W5170	2012B	20		36-11-13	ALL
23		W5170	1001	24		73-21-12	ALL
24		W5170	0508	20		73-21-12	ALL
25		W5170	1005	20		78-34-11	ALL
26		W5170	1008	20		78-34-11	ALL
27		W5170	1006	20		78-34-11	ALL
28		W5170	2605B	24		77-12-11	ALL
29		W5170	2605R	24		77-12-11	ALL
30		W5170	6008	20		28-21-11	ALL
31		W5170	6009	20		28-21-11	ALL
32		W5170	6010	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39925	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
33	UNUSED						ALL
34		W5170	3601B	24		79-31-11	ALL
35		W5170	3601R	24		79-31-11	ALL
36		W5170	2005B	20		36-11-13	ALL
37		W5170	2005R	20		36-11-13	ALL
38		W5170	2007R	20		36-11-13	ALL
39		W5170	6001R	20		26-11-11	ALL
S/R		W5170	1001Z			73-21-12	ALL
S/R		W5170	1005Z			78-34-11	ALL
S/R		W5170	1006Z			78-34-11	ALL
S/R		W5170	1007Z			78-34-11	ALL
S/R		W5170	1008Z			78-34-11	ALL
S/R		W5170	1301Z			74-11-11	ALL
S/R		W5170	1302Z			73-22-11	ALL
S/R		W5170	2005Z			36-11-13	ALL
S/R		W5170	2006Z			36-11-13	ALL
S/R		W5170	2007Z			36-11-13	ALL
S/R		W5170	2008Z			36-11-13	ALL
S/R		W5170	2009Z			36-11-13	ALL
S/R		W5170	2012Z			36-11-13	ALL
S/R		W5170	2510Z			36-11-12	ALL
S/R		W5170	2605Z			77-12-11	ALL
S/R		W5170	3601Z			79-31-11	ALL
D39926	**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6170	2510R	20		36-11-22	ALL
2		W6170	1303	20		74-11-11	ALL
3		W6170	2009B	20		36-11-23	ALL
4	UNUSED						ALL
5		W6170	2006B	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39926	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
6		W6170	1302	20		73-22-11	ALL
7		W6170	0511	20		78-35-21	ALL
8		W6170	2008R	20		36-11-23	ALL
9		W6170	0009	20		36-11-22	ALL
10		W6170	2510B	20		36-11-22	ALL
11		W6170	1007	20		78-34-21	ALL
12		W6170	2009R	20		36-11-23	ALL
13	UNUSED						ALL
14		W6170	2006R	20		36-11-23	ALL
15		W6170	3601Y	24		79-31-11	ALL
16	UNUSED						ALL
17		W6170	0512	20		78-35-21	ALL
18		W6170	2007B	20		36-11-23	ALL
19		W6170	1305R	20		26-11-21	ALL
20		W6170	2008B	20		36-11-23	ALL
21		W6170	2012R	20		36-11-23	ALL
22		W6170	2012B	20		36-11-23	ALL
23		W6170	1001	24		73-21-12	ALL
24		W6170	0508	20		73-21-12	ALL
25		W6170	1005	20		78-34-21	ALL
26		W6170	1008	20		78-34-21	ALL
27		W6170	1006	20		78-34-21	ALL
28		W6170	2602B	24		77-12-11	ALL
29		W6170	2602R	24		77-12-11	ALL
30		W6170	6006	20		28-21-11	ALL
31		W6170	6007	20		28-21-11	ALL
32		W6170	6008	20		28-21-11	ALL
33	UNUSED						ALL
34		W6170	3601B	24		79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39926		**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	35		W6170	3601R	24		79-31-11	ALL
	36		W6170	2005B	20		36-11-23	ALL
	37		W6170	2005R	20		36-11-23	ALL
	38		W6170	2007R	20		36-11-23	ALL
	39		W6170	1304R	20		26-11-21	ALL
	S/R		W6170	1001Z			73-21-12	ALL
	S/R		W6170	1005Z			78-34-21	ALL
	S/R		W6170	1006Z			78-34-21	ALL
	S/R		W6170	1007Z			78-34-21	ALL
	S/R		W6170	1008Z			78-34-21	ALL
	S/R		W6170	1302Z			73-22-11	ALL
	S/R		W6170	1303Z			74-11-11	ALL
	S/R		W6170	1304Z			26-11-21	ALL
	S/R		W6170	1305Z			26-11-21	ALL
	S/R		W6170	2005Z			36-11-23	ALL
	S/R		W6170	2006Z			36-11-23	ALL
	S/R		W6170	2007Z			36-11-23	ALL
	S/R		W6170	2008Z			36-11-23	ALL
	S/R		W6170	2009Z			36-11-23	ALL
	S/R		W6170	2012Z			36-11-23	ALL
	S/R		W6170	2510Z			36-11-22	ALL
	S/R		W6170	2602Z			77-12-11	ALL
	S/R		W6170	3601Z			79-31-11	ALL
D39927		**IFSS-89/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1178	3002R	20		36-11-12	ALL
	2		W1178	1003	20		74-11-11	ALL
	3		W1178	2009B	20		36-11-13	ALL
	4	UNUSED						ALL
	5		W1178	2006B	20		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39927	**IFSS-89/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
6		W1178	1001	18		73-22-11	ALL
7		W1178	2003B	20		78-35-11	ALL
8		W1178	2008R	20		36-11-13	ALL
9		W1178	3002Y	20		36-11-12	ALL
10		W1178	3002B	20		36-11-12	ALL
11		W1178	1020	20		78-34-11	ALL
12		W1178	2009R	20		36-11-13	ALL
13	UNUSED						ALL
14		W1178	2006R	20		36-11-13	ALL
15		W1178	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1178	2003R	20		78-35-11	ALL
18		W1178	2007B	20		36-11-13	ALL
19		W1178	1014R	20		26-11-11	ALL
20		W1178	2008B	20		36-11-13	ALL
21		W1178	2012R	20		36-11-13	ALL
22		W1178	2012B	20		36-11-13	ALL
23		W1178	2004R	20		73-21-12	ALL
24		W1178	2004B	20		73-21-12	ALL
25		W1178	1019	20		78-34-11	ALL
26		W1178	1022	20		78-34-11	ALL
27		W1178	1021	20		78-34-11	ALL
28		W1178	2011B	20		77-12-11	ALL
29		W1178	2011R	20		77-12-11	ALL
30		W1178	1009	20		28-21-11	ALL
31		W1178	1012	20		28-21-11	ALL
32		W1178	1010	20		28-21-11	ALL
33	UNUSED						ALL
34		W1178	3001B	20		79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39927		**IFSS-89/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	35		W1178	3001R	20		79-31-11	ALL
	36		W1178	2005B	20		36-11-13	ALL
	37		W1178	2005R	20		36-11-13	ALL
	38		W1178	2007R	20		36-11-13	ALL
	39		W1178	1015R	20		26-11-11	ALL
	PERB		W1178	1001ZI			73-22-11	ALL
	PERB		W1178	1001ZO			73-22-11	ALL
	PERB		W1178	1003Z			74-11-11	ALL
	PERB		W1178	1009Z			28-21-11	ALL
	PERB		W1178	1010Z			28-21-11	ALL
	PERB		W1178	1012Z			28-21-11	ALL
	PERB		W1178	1014Z			26-11-11	ALL
	PERB		W1178	1015Z			26-11-11	ALL
	PERB		W1178	1019Z			78-34-11	ALL
	PERB		W1178	1020Z			78-34-11	ALL
	PERB		W1178	1021Z			78-34-11	ALL
	PERB		W1178	1022Z			78-34-11	ALL
	PERB		W1178	2003Z			78-35-11	ALL
	PERB		W1178	2004Z			73-21-12	ALL
	PERB		W1178	2005Z			36-11-13	ALL
	PERB		W1178	2006Z			36-11-13	ALL
	PERB		W1178	2007Z			36-11-13	ALL
	PERB		W1178	2008Z			36-11-13	ALL
	PERB		W1178	2009Z			36-11-13	ALL
	PERB		W1178	2011Z			77-12-11	ALL
	PERB		W1178	2012Z			36-11-13	ALL
	PERB		W1178	3001Z			79-31-11	ALL
	PERB		W1178	3002Z			36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39928	**IFSS-89/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1278	3002R	20		36-11-22	ALL
2		W1278	1003	20		74-11-11	ALL
3		W1278	2009B	20		36-11-23	ALL
4	UNUSED						ALL
5		W1278	2006B	20		36-11-23	ALL
6		W1278	1001	18		73-22-11	ALL
7		W1278	2003B	20		78-35-21	ALL
8		W1278	2008R	20		36-11-23	ALL
9		W1278	3002Y	20		36-11-22	ALL
10		W1278	3002B	20		36-11-22	ALL
11		W1278	1020	20		78-34-21	ALL
12		W1278	2009R	20		36-11-23	ALL
13	UNUSED						ALL
14		W1278	2006R	20		36-11-23	ALL
15		W1278	3001Y	20		79-31-11	ALL
16	UNUSED						ALL
17		W1278	2003R	20		78-35-21	ALL
18		W1278	2007B	20		36-11-23	ALL
19		W1278	1014R	20		26-11-21	ALL
20		W1278	2008B	20		36-11-23	ALL
21		W1278	2012R	20		36-11-23	ALL
22		W1278	2012B	20		36-11-23	ALL
23		W1278	2004R	20		73-21-12	ALL
24		W1278	2004B	20		73-21-12	ALL
25		W1278	1019	20		78-34-21	ALL
26		W1278	1022	20		78-34-21	ALL
27		W1278	1021	20		78-34-21	ALL
28		W1278	2011B	20		77-12-11	ALL
29		W1278	2011R	20		77-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39928		**IFSS-89/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30		W1278	1009	20		28-21-11	ALL
	31		W1278	1012	20		28-21-11	ALL
	32		W1278	1010	20		28-21-11	ALL
	33	UNUSED						ALL
	34		W1278	3001B	20		79-31-11	ALL
	35		W1278	3001R	20		79-31-11	ALL
	36		W1278	2005B	20		36-11-23	ALL
	37		W1278	2005R	20		36-11-23	ALL
	38		W1278	2007R	20		36-11-23	ALL
	39		W1278	1015R	20		26-11-21	ALL
	PERB		W1278	1001ZI			73-22-11	ALL
	PERB		W1278	1001ZO			73-22-11	ALL
	PERB		W1278	1003Z			74-11-11	ALL
	PERB		W1278	1009Z			28-21-11	ALL
	PERB		W1278	1010Z			28-21-11	ALL
	PERB		W1278	1012Z			28-21-11	ALL
	PERB		W1278	1014Z			26-11-21	ALL
	PERB		W1278	1015Z			26-11-21	ALL
	PERB		W1278	1019Z			78-34-21	ALL
	PERB		W1278	1020Z			78-34-21	ALL
	PERB		W1278	1021Z			78-34-21	ALL
	PERB		W1278	1022Z			78-34-21	ALL
	PERB		W1278	2003Z			78-35-21	ALL
	PERB		W1278	2004Z			73-21-12	ALL
	PERB		W1278	2005Z			36-11-23	ALL
	PERB		W1278	2006Z			36-11-23	ALL
	PERB		W1278	2007Z			36-11-23	ALL
	PERB		W1278	2008Z			36-11-23	ALL
	PERB		W1278	2009Z			36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39928	**IFSS-89/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1278	2011Z			77-12-11	ALL
PERB		W1278	2012Z			36-11-23	ALL
PERB		W1278	3001Z			79-31-11	ALL
PERB		W1278	3002Z			36-11-22	ALL
D39929	**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5168	0003	18		73-22-41	ALL
2	UNUSED						ALL
3		W5168	0004	18		73-22-41	ALL
4		W5168	1201	20		30-21-31	ALL
5		W5168	0005	18		73-22-41	ALL
6		W5168	1301	20		73-22-11	ALL
7	UNUSED						ALL
8		W5168	2011B	20		36-11-13	ALL
9	UNUSED						ALL
10		W5168	2012B	20		36-11-13	ALL
11		W5168	6002	20		76-21-11	ALL
12		W5168	3004Y	20		36-11-13	ALL
13		W5168	0031	20		30-21-31	ALL
14	UNUSED						ALL
15		W5168	6005R	20		26-12-11	ALL
16	UNUSED						ALL
17		W5168	1302	20		74-11-11	ALL
18	UNUSED						ALL
19		W5168	6003R	20		26-11-11	ALL
20	UNUSED						ALL
21		W5168	2011R	20		36-11-13	ALL
22		W5168	2012R	20		36-11-13	ALL
23		W5168	1303	24		73-21-12	ALL
24		W5168	0035	20		73-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39929		**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	25		W5168	6001	20		76-21-11	ALL
	26		W5168	3004R	20		36-11-13	ALL
	27		W5168	3004B	20		36-11-13	ALL
	28		W5168	2603B	24		77-12-21	ALL
	29		W5168	2603R	24		77-12-21	ALL
	30		W5168	0032	20		30-21-31	ALL
	31		W5168	0006	22		30-21-31	ALL
	32		W5168	0033	20		30-21-31	ALL
	33		W5168	0007	22		30-21-31	ALL
	34		W5168	0034	20		30-21-31	ALL
	35		W5168	0008	22		30-21-31	ALL
	36	UNUSED						ALL
	37		W5168	0100R	20		26-12-11	ALL
	38	UNUSED						ALL
	39		W5168	6004R	20		26-11-11	ALL
	S/R		W5168	1201Z			30-21-31	ALL
	S/R		W5168	1301Z			73-22-11	ALL
	S/R		W5168	1302Z			74-11-11	ALL
	S/R		W5168	1303Z			73-21-12	ALL
	S/R		W5168	2011Z			36-11-13	ALL
	S/R		W5168	2012Z			36-11-13	ALL
	S/R		W5168	2603Z			77-12-21	ALL
	S/R		W5168	3004Z			36-11-13	ALL
D39930		**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6168	0003	18		73-22-41	ALL
	2	UNUSED						ALL
	3		W6168	0004	18		73-22-41	ALL
	4		W6168	1201	20		30-21-32	ALL
	5		W6168	0005	18		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39930	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
6		W6168	1301	20		73-22-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W6168	2011B	20		36-11-23	ALL
10		W6168	2012B	20		36-11-23	ALL
11		W6168	6002	20		76-21-21	ALL
12		W6168	3004Y	20		36-11-23	ALL
13		W6168	0031	20		30-21-32	ALL
14	UNUSED						ALL
15		W6168	6003R	20		26-12-11	ALL
16	UNUSED						ALL
17		W6168	1302	20		74-11-11	ALL
18	UNUSED						ALL
19		W6168	6004R	20		26-11-21	ALL
20	UNUSED						ALL
21		W6168	2011R	20		36-11-23	ALL
22		W6168	2012R	20		36-11-23	ALL
23		W6168	1303	24		73-21-12	ALL
24		W6168	0035	20		73-21-12	ALL
25		W6168	6001	20		76-21-21	ALL
26		W6168	3004R	20		36-11-23	ALL
27		W6168	3004B	20		36-11-23	ALL
28		W6168	2201B	24		77-12-21	ALL
29		W6168	2201R	24		77-12-21	ALL
30		W6168	0032	20		30-21-32	ALL
31		W6168	0006	22		30-21-32	ALL
32		W6168	0033	20		30-21-32	ALL
33		W6168	0007	22		30-21-32	ALL
34		W6168	0034	20		30-21-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39930		**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	35		W6168	0008	22		30-21-32	ALL
	36	UNUSED						ALL
	37		W6168	6006R	20		26-12-11	ALL
	38	UNUSED						ALL
	39		W6168	6005R	20		26-11-21	ALL
	S/R		W6168	1201Z			30-21-32	ALL
	S/R		W6168	1301Z			73-22-11	ALL
	S/R		W6168	1302Z			74-11-11	ALL
	S/R		W6168	1303Z			73-21-12	ALL
	S/R		W6168	2011Z			36-11-23	ALL
	S/R		W6168	2012Z			36-11-23	ALL
	S/R		W6168	2201Z			77-12-21	ALL
	S/R		W6168	3004Z			36-11-23	ALL
D39931		**IFSS-81/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1182	3001R	18		73-22-41	ALL
	2	UNUSED						ALL
	3		W1182	3001B	18		73-22-41	ALL
	4		W1182	2008R	20		30-21-31	ALL
	5		W1182	3001Y	18		73-22-41	ALL
	6		W1182	1001	18		73-22-11	ALL
	7	UNUSED						ALL
	8		W1182	2011B	20		36-11-13	ALL
	9	UNUSED						ALL
	10		W1182	2012B	20		36-11-13	ALL
	11		W1182	2006B	20		76-21-11	ALL
	12		W1182	3004Y	20		36-11-13	ALL
	13		W1182	2008B	20		30-21-31	ALL
	14	UNUSED						ALL
	15		W1182	1009R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39931	**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
16	UNUSED						ALL
17		W1182	1007	20		74-11-11	ALL
18	UNUSED						ALL
19		W1182	1010R	20		26-11-11	ALL
20	UNUSED						ALL
21		W1182	2011R	20		36-11-13	ALL
22		W1182	2012R	20		36-11-13	ALL
23		W1182	2001R	20		73-21-12	ALL
24		W1182	2001B	20		73-21-12	ALL
25		W1182	2006R	20		76-21-11	ALL
26		W1182	3004R	20		36-11-13	ALL
27		W1182	3004B	20		36-11-13	ALL
28		W1182	2002B	20		77-12-21	ALL
29		W1182	2002R	20		77-12-21	ALL
30		W1182	2005B	20		30-21-31	ALL
31		W1182	2005R	20		30-21-31	ALL
32		W1182	2004B	20		30-21-31	ALL
33		W1182	2004R	20		30-21-31	ALL
34		W1182	2003B	20		30-21-31	ALL
35		W1182	2003R	20		30-21-31	ALL
36	UNUSED						ALL
37		W1182	1005R	20		26-12-11	ALL
38	UNUSED						ALL
39		W1182	1011R	20		26-11-11	ALL
PERB		W1182	1001ZI			73-22-11	ALL
PERB		W1182	1001ZO			73-22-11	ALL
PERB		W1182	1005Z			26-12-11	ALL
PERB		W1182	1007Z			74-11-11	ALL
PERB		W1182	1009Z			26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39931		**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1182	1010Z			26-11-11	ALL
	PERB		W1182	1011Z			26-11-11	ALL
	PERB		W1182	2001Z			73-21-12	ALL
	PERB		W1182	2002Z			77-12-21	ALL
	PERB		W1182	2003Z			30-21-31	ALL
	PERB		W1182	2004Z			30-21-31	ALL
	PERB		W1182	2005Z			30-21-31	ALL
	PERB		W1182	2006Z			76-21-11	ALL
	PERB		W1182	2008Z			30-21-31	ALL
	PERB		W1182	2011Z			36-11-13	ALL
	PERB		W1182	2012Z			36-11-13	ALL
	PERB		W1182	3001Z			73-22-41	ALL
	PERB		W1182	3004Z			36-11-13	ALL
D39932		**IFSS-81/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1282	3001R	18		73-22-41	ALL
	2	UNUSED						ALL
	3		W1282	3001B	18		73-22-41	ALL
	4		W1282	2008R	20		30-21-32	ALL
	5		W1282	3001Y	18		73-22-41	ALL
	6		W1282	1001	18		73-22-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W1282	2011B	20		36-11-23	ALL
	10		W1282	2012B	20		36-11-23	ALL
	11		W1282	2006B	20		76-21-21	ALL
	12		W1282	3004Y	20		36-11-23	ALL
	13		W1282	2008B	20		30-21-32	ALL
	14	UNUSED						ALL
	15		W1282	1009R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39932	**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
16	UNUSED						ALL
17		W1282	1007	20		74-11-11	ALL
18	UNUSED						ALL
19		W1282	1010R	20		26-11-21	ALL
20	UNUSED						ALL
21		W1282	2011R	20		36-11-23	ALL
22		W1282	2012R	20		36-11-23	ALL
23		W1282	2001R	20		73-21-12	ALL
24		W1282	2001B	20		73-21-12	ALL
25		W1282	2006R	20		76-21-21	ALL
26		W1282	3004R	20		36-11-23	ALL
27		W1282	3004B	20		36-11-23	ALL
28		W1282	2002B	20		77-12-21	ALL
29		W1282	2002R	20		77-12-21	ALL
30		W1282	2005B	20		30-21-32	ALL
31		W1282	2005R	20		30-21-32	ALL
32		W1282	2004B	20		30-21-32	ALL
33		W1282	2004R	20		30-21-32	ALL
34		W1282	2003B	20		30-21-32	ALL
35		W1282	2003R	20		30-21-32	ALL
36	UNUSED						ALL
37		W1282	1005R	20		26-12-11	ALL
38	UNUSED						ALL
39		W1282	1011R	20		26-11-21	ALL
PERB		W1282	1001ZI			73-22-11	ALL
PERB		W1282	1001ZO			73-22-11	ALL
PERB		W1282	1005Z			26-12-11	ALL
PERB		W1282	1007Z			74-11-11	ALL
PERB		W1282	1009Z			26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D39932		**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W1282	1010Z			26-11-21	ALL
	PERB		W1282	1011Z			26-11-21	ALL
	PERB		W1282	2001Z			73-21-12	ALL
	PERB		W1282	2002Z			77-12-21	ALL
	PERB		W1282	2003Z			30-21-32	ALL
	PERB		W1282	2004Z			30-21-32	ALL
	PERB		W1282	2005Z			30-21-32	ALL
	PERB		W1282	2006Z			76-21-21	ALL
	PERB		W1282	2008Z			30-21-32	ALL
	PERB		W1282	2011Z			36-11-23	ALL
	PERB		W1282	2012Z			36-11-23	ALL
	PERB		W1282	3001Z			73-22-41	ALL
	PERB		W1282	3004Z			36-11-23	ALL
D39933		**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5164	3201R	18		24-21-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5164	0501	22		29-11-11	ALL
	9		W5164	1101	18		24-11-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5164	3201B	18		24-21-11	ALL
	13	UNUSED						ALL
	14		W5164	3201Y	18		24-21-11	ALL
	15		W5164	4101B	20		24-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39933	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W5164	2602R	20		SPARE	ALL
26		W5164	2602B	20		SPARE	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5164	2202R	22		24-11-11	ALL
31		W5164	2202B	22		24-11-11	ALL
32		W5164	4101R	20		24-24-11	ALL
33		W5164	4101G	20		24-24-11	ALL
34		W5164	4101Y	20		24-24-11	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W5164	2201R	20		24-21-11	ALL
38		W5164	2201B	20		24-21-11	ALL
39	UNUSED						ALL
PERB		W5164	1101Z			24-11-11	ALL
PERB		W5164	2201Z			24-21-11	ALL
PERB		W5164	2202Z			24-11-11	ALL
PERB		W5164	2602Z			SPARE	ALL
PERB		W5164	3201Z			24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39933	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W5164	4101Z			24-24-11	ALL
D39934	**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6164	3201R	18		24-21-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6164	0501	22		29-11-11	ALL
9		W6164	1101	18		24-11-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6164	3201B	18		24-21-21	ALL
13	UNUSED						ALL
14		W6164	3201Y	18		24-21-21	ALL
15		W6164	4101B	20		24-24-21	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39934	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
28	UNUSED						ALL
29	UNUSED						ALL
30		W6164	2202R	22		24-11-21	ALL
31		W6164	2202B	22		24-11-21	ALL
32		W6164	4101R	20		24-24-21	ALL
33		W6164	4101G	20		24-24-21	ALL
34		W6164	4101Y	20		24-24-21	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W6164	2201R	20		24-21-21	ALL
38		W6164	2201B	20		24-21-21	ALL
39	UNUSED						ALL
PERB		W6164	1101Z			24-11-21	ALL
PERB		W6164	2201Z			24-21-21	ALL
PERB		W6164	2202Z			24-11-21	ALL
PERB		W6164	3201Z			24-21-21	ALL
PERB		W6164	4101Z			24-24-21	ALL
D39935	**IFSS-87/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1184	3001R	18		24-21-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1184	1003	20		29-11-11	ALL
9		W1184	1001	18		24-11-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39935	**IFSS-87/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
12		W1184	3001B	18		24-21-11	ALL
13	UNUSED						ALL
14		W1184	3001Y	18		24-21-11	ALL
15		W1184	4001B	20		24-24-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W1184	2003R	20		SPARE	ALL
26		W1184	2003B	20		SPARE	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W1184	2001R	20		24-11-11	ALL
31		W1184	2001B	20		24-11-11	ALL
32		W1184	4001R	20		24-24-11	ALL
33		W1184	4001G	20		24-24-11	ALL
34		W1184	4001Y	20		24-24-11	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W1184	2002R	20		24-21-11	ALL
38		W1184	2002B	20		24-21-11	ALL
39	UNUSED						ALL
PERB		W1184	1001Z			24-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39935	**IFSS-87/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1184	1003Z			29-11-11	ALL
PERB		W1184	2001Z			24-11-11	ALL
PERB		W1184	2002ZI			24-21-11	ALL
PERB		W1184	2002ZO			24-21-11	ALL
PERB		W1184	2003Z			SPARE	ALL
PERB		W1184	3001ZI			24-21-11	ALL
PERB		W1184	3001ZO			24-21-11	ALL
PERB		W1184	4001Z			24-24-11	ALL
D39936	**IFSS 87/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1284	3001R	18		24-21-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1284	1003	20		29-11-11	ALL
9		W1284	1001	18		24-11-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W1284	3001B	18		24-21-21	ALL
13	UNUSED						ALL
14		W1284	3001Y	18		24-21-21	ALL
15		W1284	4001B	20		24-24-21	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39936		**IFSS 87/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W1284	2003R	20		SPARE	ALL
	26		W1284	2003B	20		SPARE	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W1284	2001R	20		24-11-21	ALL
	31		W1284	2001B	20		24-11-21	ALL
	32		W1284	4001R	20		24-24-21	ALL
	33		W1284	4001G	20		24-24-21	ALL
	34		W1284	4001Y	20		24-24-21	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W1284	2002R	20		24-21-21	ALL
	38		W1284	2002B	20		24-21-21	ALL
	39	UNUSED						ALL
	PERB		W1284	1001Z			24-11-21	ALL
	PERB		W1284	1003Z			29-11-11	ALL
	PERB		W1284	2001Z			24-11-21	ALL
	PERB		W1284	2002ZI			24-21-21	ALL
	PERB		W1284	2002ZO			24-21-21	ALL
	PERB		W1284	2003Z			SPARE	ALL
	PERB		W1284	3001ZI			24-21-21	ALL
	PERB		W1284	3001ZO			24-21-21	ALL
	PERB		W1284	4001Z			24-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39937	**AC0520/178/L058**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5568	2201R	20		27-81-11	ALL
14	UNUSED						ALL
15		W5568	2204B	20		27-81-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W5568	2201B	20		27-81-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39937		**AC0520/178/L058**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30		W5568	2202B	20		27-81-11	ALL
	31		W5568	2202R	20		27-81-11	ALL
	32		W5568	2203B	20		27-81-11	ALL
	33		W5568	2203R	20		27-81-11	ALL
	34		W5568	2204R	20		27-81-11	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D39938		**IFSS-84/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W1180	2001R	20		27-81-11	ALL
	14	UNUSED						ALL
	15		W1180	2004B	20		27-81-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39938	**IFSS-84/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W1180	2001B	20		27-81-11	ALL
30		W1180	2002B	20		27-81-11	ALL
31		W1180	2002R	20		27-81-11	ALL
32		W1180	2003B	20		27-81-11	ALL
33		W1180	2003R	20		27-81-11	ALL
34		W1180	2004R	20		27-81-11	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
S/R		W1180	2001Z			27-81-11	ALL
S/R		W1180	2002Z			27-81-11	ALL
S/R		W1180	2003Z			27-81-11	ALL
S/R		W1180	2004Z			27-81-11	ALL
D39939	**AD0520/178/R058**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39939		**AD0520/178/R058**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W6588	2201R	20		27-81-21	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W6588	2201B	20		27-81-21	ALL
	30		W6588	2202B	20		27-81-21	ALL
	31		W6588	2202R	20		27-81-21	ALL
	32		W6588	2203B	20		27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39939	**AD0520/178/R058**		**PLUG-CONDUCTIVE (continued)**				**ALL**
33		W6588	2203R	20		27-81-21	ALL
34		W6588	2204R	20		27-81-21	ALL
35		W6588	2204B	20		27-81-21	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
D39940	**IFSS 84/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1280	2001R	20		27-81-21	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39940		**IFSS 84/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W1280	2001B	20		27-81-21	ALL
	30		W1280	2002B	20		27-81-21	ALL
	31		W1280	2002R	20		27-81-21	ALL
	32		W1280	2003B	20		27-81-21	ALL
	33		W1280	2003R	20		27-81-21	ALL
	34		W1280	2004R	20		27-81-21	ALL
	35		W1280	2004B	20		27-81-21	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W1280	2001Z			27-81-21	ALL
	S/R		W1280	2002Z			27-81-21	ALL
	S/R		W1280	2003Z			27-81-21	ALL
	S/R		W1280	2004Z			27-81-21	ALL
D39941		**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W6586	0006	20		30-11-11	ALL
	4		W6586	0012	20		33-42-21	ALL
	5		W6586	0018	22		30-11-11	ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39941	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
7	UNUSED						ALL
8		W6586	1001	20		30-11-11	ALL
9		W6586	0019	22		30-11-11	ALL
10	UNUSED						ALL
11		W6586	3801Z			23-41-11	ALL
12		W6586	6003	18		28-44-11	ALL
13		W6586	0013	20		33-42-21	ALL
14		W6586	0007	20		30-11-11	ALL
15	UNUSED						ALL
16		W6586	0011	18		33-42-21	ALL
17	UNUSED						ALL
18		W6586	0005	20		30-11-11	ALL
19		W6586	0002	20		33-44-12	ALL
20		W6586	0004	20		33-43-11	ALL
21	UNUSED						ALL
22		W6586	2601R	22		28-41-11	ALL
23		W6586	2601B	22		28-41-11	ALL
24	UNUSED						ALL
25		W6586	3801R	20		23-41-11	ALL
26		W6586	3801B	20		23-41-11	ALL
27		W6586	3801Y	20		23-41-11	ALL
28		W6586	6004	22		28-44-11	ALL
29		W6586	2602R	20		28-44-11	ALL
30	UNUSED						ALL
31		W6586	2602B	20		28-44-11	ALL
32		W6586	6005	20		28-44-11	ALL
33		W6586	6010	20		28-44-11	ALL
34		W6586	0014	20		33-42-21	ALL
35		W6586	0015	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39941	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
36		W6586	0016	20		33-42-21	ALL
37		W6586	0017	20		33-42-21	ALL
38	UNUSED						ALL
39	UNUSED						ALL
S/R		W6586	1001Z			30-11-11	ALL
S/R		W6586	2601Z			28-41-11	ALL
D39942	**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W6570	6011	20		28-41-11	ALL
7		W6570	6010	20		28-41-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W6570	6011	20		28-41-11	ALL
17		W6570	1301	20		28-41-11	ALL
18		W6570	FRAC			28-41-11	ALL
19	UNUSED						ALL
20		W6570	1303	20		28-41-11	ALL
21		W6570	1302	20		28-41-11	ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39942	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W6570	FRAD			28-41-11	ALL
38		W6570	6009	20		28-41-11	ALL
39		W6570	6010	20		28-41-11	ALL
S/R		W6570	1301ZO			28-41-11	ALL
S/R		W6570	1302Z			28-41-11	ALL
S/R		W6570	1303Z			28-41-11	ALL
S/R		W6570	6009	20		28-41-11	ALL
		W6570	1301ZI			28-41-11	ALL
		W6570	FRAC			28-41-11	ALL
		W6570	FRAD			28-41-11	ALL
D39943	**IFSS 97/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W1664	2003B	20		30-11-11	ALL
4		W1664	1028	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39943		**IFSS 97/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	5		W1664	2003R	20		30-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W1664	2002B	20		30-11-11	ALL
	9		W1664	2004B	20		30-11-11	ALL
	10	UNUSED						ALL
	11		W1664	3002ZI			23-41-11	ALL
	12		W1664	1013	18		28-44-11	ALL
	13		W1664	1030	20		33-42-21	ALL
	14		W1664	2004R	20		30-11-11	ALL
	15	UNUSED						ALL
	16		W1664	1027	18		33-42-21	ALL
	17	UNUSED						ALL
	18		W1664	2002R	20		30-11-11	ALL
	19		W1664	1011	20		33-44-12	ALL
	20		W1664	1010	20		33-43-11	ALL
	21	UNUSED						ALL
	22		W1664	2001R	20		28-41-11	ALL
	23		W1664	2001B	20		28-41-11	ALL
	24	UNUSED						ALL
	25		W1664	3002R	20		23-41-11	ALL
	26		W1664	3002B	20		23-41-11	ALL
	27		W1664	3002Y	20		23-41-11	ALL
	28		W1664	1014	20		28-44-11	ALL
	29		W1664	1015	20		28-44-11	ALL
	30	UNUSED						ALL
	31		W1664	1022	20		28-44-11	ALL
	32		W1664	1023	20		28-44-11	ALL
	33		W1664	1034	20		28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39943	**IFSS 97/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
34		W1664	1029	20		33-42-21	ALL
35		W1664	1031	20		33-42-21	ALL
36		W1664	1036	20		33-42-21	ALL
37		W1664	1037	20		33-42-21	ALL
38	UNUSED						ALL
39	UNUSED						ALL
S/R		W1664	1010Z			33-43-11	ALL
S/R		W1664	1011Z			33-44-12	ALL
S/R		W1664	1013Z			28-44-11	ALL
S/R		W1664	1014Z			28-44-11	ALL
S/R		W1664	1015Z			28-44-11	ALL
S/R		W1664	1022Z			28-44-11	ALL
S/R		W1664	1023Z			28-44-11	ALL
S/R		W1664	1027Z			33-42-21	ALL
S/R		W1664	1028Z			33-42-21	ALL
S/R		W1664	1029Z			33-42-21	ALL
S/R		W1664	1030Z			33-42-21	ALL
S/R		W1664	1031Z			33-42-21	ALL
S/R		W1664	1034Z			28-44-11	ALL
S/R		W1664	1036Z			33-42-21	ALL
S/R		W1664	1037Z			33-42-21	ALL
S/R		W1664	2001ZI			28-41-11	ALL
S/R		W1664	2002Z			30-11-11	ALL
S/R		W1664	2003Z			30-11-11	ALL
S/R		W1664	2004Z			30-11-11	ALL
S/R		W1664	3002ZO			23-41-11	ALL
D39944	**IFSS 90/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39944		**IFSS 90/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1138	1005	20		28-41-11	ALL
	7		W1138	1005	20		28-41-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W1138	1006	20		28-41-11	ALL
	17		W1138	001TX	20		28-41-11	ALL
	18		W1138	FRAA			28-41-11	ALL
	19	UNUSED						ALL
	20		W1138	1003	20		28-41-11	ALL
	21		W1138	1002	20		28-41-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39944		**IFSS 90/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W1138	FRAB			28-41-11	ALL
	38		W1138	1004	20		28-41-11	ALL
	39		W1138	1004	20		28-41-11	ALL
	S/R		W1138	001TO			28-41-11	ALL
	S/R		W1138	1002Z			28-41-11	ALL
	S/R		W1138	1003Z			28-41-11	ALL
	S/R		W1138	1006	20		28-41-11	ALL
			W1138	001TI			28-41-11	ALL
			W1138	FRAA			28-41-11	ALL
			W1138	FRAB			28-41-11	ALL
D39946		**AD0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6172	0009	18		78-32-61	ALL
	2	UNUSED						ALL
	3		W6172	2612R	20		SPARE	ALL
	4		W6172	2615R	20		78-32-61	ALL
	5		W6172	2601R	18		78-32-61	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W6172	4001Y	24		46-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W6172	2612B	20		SPARE	ALL
	13		W6172	2615B	20		78-32-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39946		**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	14		W6172	2601B	18		78-32-61	ALL
	15		W6172	2610B	24		73-21-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W6172	4001R	24		46-13-11	ALL
	19		W6172	4001B	24		46-13-11	ALL
	20	UNUSED						ALL
	21		W6172	2609R	20		73-21-21	ALL
	22		W6172	2609B	20		73-21-21	ALL
	23		W6172	2607R	20		73-21-21	ALL
	24		W6172	2607B	20		73-21-21	ALL
	25		W6172	2608R	20		73-21-21	ALL
	26		W6172	2608B	20		73-21-21	ALL
	27		W6172	2611R	24		73-21-12	ALL
	28		W6172	2611B	24		73-21-12	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W6172	2610R	24		73-21-11	ALL
	34		W6172	2605R	24		73-24-12	ALL
	35		W6172	2605B	24		73-24-12	ALL
	36		W6172	2606B	24		73-24-21	ALL
	37		W6172	2606R	24		73-24-21	ALL
	38	UNUSED						ALL
	39		W6172	4001G	24		46-13-11	ALL
	S/R		W6172	2601Z			78-32-61	ALL
	S/R		W6172	2605Z			73-24-12	ALL
	S/R		W6172	2606Z			73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39946	**AD0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W6172	2607Z			73-21-21	ALL
S/R		W6172	2608Z			73-21-21	ALL
S/R		W6172	2609Z			73-21-21	ALL
S/R		W6172	2610Z			73-21-11	ALL
S/R		W6172	2611Z			73-21-12	ALL
S/R		W6172	2615Z			78-32-61	ALL
S/R		W6172	4001Z			46-13-11	ALL
D39955	**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W5566	1001	20		30-11-11	ALL
4		W5566	0005	20		30-11-11	ALL
5		W5566	0014	22		30-11-11	ALL
6		W5566	0006	20		30-11-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5566	0002	20		33-44-12	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W5566	0003	18		33-42-21	ALL
15		W5566	0015	20		30-11-11	ALL
16		W5566	0007	20		30-11-11	ALL
17	UNUSED						ALL
18		W5566	0004	20		33-43-11	ALL
19	UNUSED						ALL
20		W5566	2601R	20		28-44-11	ALL
21		W5566	2601B	20		28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39955		**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	22		W5566	0013	20		33-42-21	ALL
	23		W5566	0011	20		33-42-21	ALL
	24		W5566	0012	20		33-42-21	ALL
	25		W5566	0010	20		33-42-21	ALL
	26		W5566	0009	20		33-42-21	ALL
	27		W5566	0008	20		33-42-21	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W5566	1001Z			30-11-11	ALL
D39957		**IFSS-93/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W1662	2002B	20		30-11-11	ALL
	4		W1662	2002R	20		30-11-11	ALL
	5		W1662	2003B	20		30-11-11	ALL
	6		W1662	2003R	20		30-11-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39957	**IFSS-93/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10	UNUSED						ALL
11		W1662	1011	20		33-44-12	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W1662	1023	18		33-42-21	ALL
15		W1662	2004B	20		30-11-11	ALL
16		W1662	2004R	20		30-11-11	ALL
17	UNUSED						ALL
18		W1662	1010	20		33-43-11	ALL
19	UNUSED						ALL
20		W1662	2001R	20		28-44-11	ALL
21		W1662	2001B	20		28-44-11	ALL
22		W1662	1022	20		33-42-21	ALL
23		W1662	1021	20		33-42-21	ALL
24		W1662	1020	20		33-42-21	ALL
25		W1662	1019	20		33-42-21	ALL
26		W1662	1018	20		33-42-21	ALL
27		W1662	1017	20		33-42-21	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39957		**IFSS-93/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	39	UNUSED						ALL
	S/R		W1662	1010Z			33-43-11	ALL
	S/R		W1662	1011Z			33-44-12	ALL
	S/R		W1662	1017Z			33-42-21	ALL
	S/R		W1662	1018Z			33-42-21	ALL
	S/R		W1662	1019Z			33-42-21	ALL
	S/R		W1662	1020Z			33-42-21	ALL
	S/R		W1662	1021Z			33-42-21	ALL
	S/R		W1662	1022Z			33-42-21	ALL
	S/R		W1662	1023Z			33-42-21	ALL
	S/R		W1662	2001Z			28-44-11	ALL
	S/R		W1662	2002Z			30-11-11	ALL
	S/R		W1662	2003Z			30-11-11	ALL
	S/R		W1662	2004Z			30-11-11	ALL
D39963		**AC0520/180/L059**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5562	6011	20		28-41-11	ALL
	7		W5562	6010	20		28-41-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39963	**AC0520/180/L059**		**PLUG-CONDUCTIVE (continued)**				**ALL**
15	UNUSED						ALL
16		W5562	6011	20		28-41-11	ALL
17		W5562	1301	20		28-41-11	ALL
18		W5562	FRAC			28-41-11	ALL
19	UNUSED						ALL
20		W5562	1303	20		28-41-11	ALL
21		W5562	1302	20		28-41-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W5562	FRAD			28-41-11	ALL
38		W5562	6009	20		28-41-11	ALL
39		W5562	6010	20		28-41-11	ALL
S/R		W5562	1301ZO			28-41-11	ALL
S/R		W5562	1302Z			28-41-11	ALL
S/R		W5562	1303Z			28-41-11	ALL
S/R		W5562	6009	20		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39963		**AC0520/180/L059**		**PLUG-CONDUCTIVE (continued)**				**ALL**
			W5562	1301ZI			28-41-11	ALL
			W5562	FRAC			28-41-11	ALL
			W5562	FRAD			28-41-11	ALL
D39965		**IFSS -90/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1140	1005	20		28-41-11	ALL
	7		W1140	1005	20		28-41-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W1140	1006	20		28-41-11	ALL
	17		W1140	001TX	20		28-41-11	ALL
	18		W1140	FRAA			28-41-11	ALL
	19	UNUSED						ALL
	20		W1140	1003	20		28-41-11	ALL
	21		W1140	1002	20		28-41-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39965	**IFSS -90/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W1140	FRAB			28-41-11	ALL
38		W1140	1004	20		28-41-11	ALL
39		W1140	1004	20		28-41-11	ALL
S/R		W1140	001TO			28-41-11	ALL
S/R		W1140	1002Z			28-41-11	ALL
S/R		W1140	1003Z			28-41-11	ALL
S/R		W1140	1006	20		28-41-11	ALL
		W1140	001TI			28-41-11	ALL
		W1140	FRAA			28-41-11	ALL
		W1140	FRAB			28-41-11	ALL
D39967	**AC0520/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5172	0009	18		78-32-51	ALL
2	UNUSED						ALL
3		W5172	2604R	20		SPARE	ALL
4		W5172	2201R	20		78-32-51	ALL
5		W5172	2602R	18		78-32-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39967		**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8		W5172	4001Y	24		46-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5172	2604B	20		SPARE	ALL
	13		W5172	2201B	20		78-32-51	ALL
	14		W5172	2602B	18		78-32-51	ALL
	15		W5172	2609B	24		73-21-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W5172	4001R	24		46-13-11	ALL
	19		W5172	4001B	24		46-13-11	ALL
	20	UNUSED						ALL
	21		W5172	2611R	20		73-21-21	ALL
	22		W5172	2611B	20		73-21-21	ALL
	23		W5172	2612R	20		73-21-21	ALL
	24		W5172	2612B	20		73-21-21	ALL
	25		W5172	2613R	20		73-21-21	ALL
	26		W5172	2613B	20		73-21-21	ALL
	27		W5172	2610R	24		73-21-12	ALL
	28		W5172	2610B	24		73-21-12	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W5172	2609R	24		73-21-11	ALL
	34		W5172	2614R	24		73-24-12	ALL
	35		W5172	2614B	24		73-24-12	ALL
	36		W5172	2608B	24		73-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39967	**AC0520/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
37		W5172	2608R	24		73-24-11	ALL
38	UNUSED						ALL
39		W5172	4001G	24		46-13-11	ALL
S/R		W5172	2201Z			78-32-51	ALL
S/R		W5172	2602Z			78-32-51	ALL
S/R		W5172	2604Z			SPARE	ALL
S/R		W5172	2608Z			73-24-11	ALL
S/R		W5172	2609Z			73-21-11	ALL
S/R		W5172	2610Z			73-21-12	ALL
S/R		W5172	2611Z			73-21-21	ALL
S/R		W5172	2612Z			73-21-21	ALL
S/R		W5172	2613Z			73-21-21	ALL
S/R		W5172	2614Z			73-24-12	ALL
S/R		W5172	4001Z			46-13-11	ALL
D39973	**IFSS-81/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1190	3003Y	18		78-32-51	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1190	2005R	20		78-32-51	ALL
5		W1190	3003R	18		78-32-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1190	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1190	2005B	20		78-32-51	ALL
14		W1190	3003B	18		78-32-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39973		**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	15		W1190	2008B	20		73-21-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W1190	4001R	22		46-13-11	ALL
	19		W1190	4001B	22		46-13-11	ALL
	20	UNUSED						ALL
	21		W1190	2009R	20		73-21-21	ALL
	22		W1190	2009B	20		73-21-21	ALL
	23		W1190	2010R	20		73-21-21	ALL
	24		W1190	2010B	20		73-21-21	ALL
	25		W1190	2011R	20		73-21-21	ALL
	26		W1190	2011B	20		73-21-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W1190	2008R	20		73-21-11	ALL
	34		W1190	2013R	20		73-24-12	ALL
	35		W1190	2013B	20		73-24-12	ALL
	36		W1190	2012B	20		73-24-11	ALL
	37		W1190	2012R	20		73-24-11	ALL
	38	UNUSED						ALL
	39		W1190	4001G	22		46-13-11	ALL
	PERB		W1190	2005Z			78-32-51	ALL
	PERB		W1190	2008Z			73-21-11	ALL
	PERB		W1190	2009Z			73-21-21	ALL
	PERB		W1190	2010Z			73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39973	**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1190	2011Z			73-21-21	ALL
PERB		W1190	2012Z			73-24-11	ALL
PERB		W1190	2013Z			73-24-12	ALL
PERB		W1190	3003Z			78-32-51	ALL
PERB		W1190	4001Z			46-13-11	ALL
D39974	**IFSS 78/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1290	3003Y	18		78-32-61	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1290	2005R	20		78-32-61	ALL
5		W1290	3003R	18		78-32-61	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1290	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1290	2005B	20		78-32-61	ALL
14		W1290	3003B	18		78-32-61	ALL
15		W1290	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1290	4001R	22		46-13-11	ALL
19		W1290	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1290	2009R	20		73-21-21	ALL
22		W1290	2009B	20		73-21-21	ALL
23		W1290	2010R	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39974		**IFSS 78/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	24		W1290	2010B	20		73-21-21	ALL
	25		W1290	2011R	20		73-21-21	ALL
	26		W1290	2011B	20		73-21-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W1290	2008R	20		73-21-11	ALL
	34		W1290	2013R	20		73-24-12	ALL
	35		W1290	2013B	20		73-24-12	ALL
	36		W1290	2012B	20		73-24-21	ALL
	37		W1290	2012R	20		73-24-21	ALL
	38	UNUSED						ALL
	39		W1290	4001G	22		46-13-11	ALL
	PERB		W1290	2005Z			78-32-61	ALL
	PERB		W1290	2008Z			73-21-11	ALL
	PERB		W1290	2009Z			73-21-21	ALL
	PERB		W1290	2010Z			73-21-21	ALL
	PERB		W1290	2011Z			73-21-21	ALL
	PERB		W1290	2012Z			73-24-21	ALL
	PERB		W1290	2013Z			73-24-12	ALL
	PERB		W1290	3003Z			78-32-61	ALL
	PERB		W1290	4001Z			46-13-11	ALL
D39977		**177/179/R001**		**PLUG**				**ALL**
	1		W8489	4001Y	22		34-41-11	ALL
	2		W8489	4001R	22		34-41-11	ALL
	3		W8489	4001G	22		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39977	**177/179/R001**		**PLUG (continued)**				**ALL**
4		W8489	4001B	22		34-41-11	ALL
5	UNUSED						ALL
PERB		W8489	4001Z			34-41-11	ALL
D39979	**178/179/R001**		**PLUG**				**ALL**
1		W6491	4001Y	24		34-41-11	ALL
2		W6491	4001R	24		34-41-11	ALL
3		W6491	4001G	24		34-41-11	ALL
4		W6491	4001B	24		34-41-11	ALL
5	UNUSED						ALL
PERB		W6491	4001Z			34-41-11	ALL
D39985	**IFSS-81/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1192	3003Y	18		78-32-51	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1192	2005R	20		78-32-51	ALL
5		W1192	3003R	18		78-32-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1192	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1192	2005B	20		78-32-51	ALL
14		W1192	3003B	18		78-32-51	ALL
15		W1192	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1192	4001R	22		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39985		**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	19		W1192	4001B	22		46-13-11	ALL
	20	UNUSED						ALL
	21		W1192	2009R	20		73-21-21	ALL
	22		W1192	2009B	20		73-21-21	ALL
	23		W1192	2010R	20		73-21-21	ALL
	24		W1192	2010B	20		73-21-21	ALL
	25		W1192	2011R	20		73-21-21	ALL
	26		W1192	2011B	20		73-21-21	ALL
	27		W1192	2007R	20		73-21-12	ALL
	28		W1192	2007B	20		73-21-12	ALL
	29		W1192	2017B	20		SPARE	ALL
	30		W1192	2017R	20		SPARE	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W1192	2008R	20		73-21-11	ALL
	34		W1192	2013R	20		73-24-12	ALL
	35		W1192	2013B	20		73-24-12	ALL
	36		W1192	2012B	20		73-24-11	ALL
	37		W1192	2012R	20		73-24-11	ALL
	38	UNUSED						ALL
	39		W1192	4001G	22		46-13-11	ALL
	PERB		W1192	2005Z			78-32-51	ALL
	PERB		W1192	2007Z			73-21-12	ALL
	PERB		W1192	2008Z			73-21-11	ALL
	PERB		W1192	2009Z			73-21-21	ALL
	PERB		W1192	2010Z			73-21-21	ALL
	PERB		W1192	2011Z			73-21-21	ALL
	PERB		W1192	2012Z			73-24-11	ALL
	PERB		W1192	2013Z			73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39985	**IFSS-81/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W1192	2017Z			SPARE	ALL
PERB		W1192	3003Z			78-32-51	ALL
PERB		W1192	4001Z			46-13-11	ALL
D39986	**IFSS 100/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1292	3003Y	18		78-32-61	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W1292	2005R	20		78-32-61	ALL
5		W1292	3003R	18		78-32-61	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1292	4001Y	22		46-13-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W1292	2005B	20		78-32-61	ALL
14		W1292	3003B	18		78-32-61	ALL
15		W1292	2008B	20		73-21-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W1292	4001R	22		46-13-11	ALL
19		W1292	4001B	22		46-13-11	ALL
20	UNUSED						ALL
21		W1292	2009R	20		73-21-21	ALL
22		W1292	2009B	20		73-21-21	ALL
23		W1292	2010R	20		73-21-21	ALL
24		W1292	2010B	20		73-21-21	ALL
25		W1292	2011R	20		73-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D39986	**IFSS 100/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
26		W1292	2011B	20		73-21-21	ALL
27		W1292	2007R	20		73-21-12	ALL
28		W1292	2007B	20		73-21-12	ALL
29		W1292	2017B	20		SPARE	ALL
30		W1292	2017R	20		SPARE	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33		W1292	2008R	20		73-21-11	ALL
34		W1292	2013R	20		73-24-12	ALL
35		W1292	2013B	20		73-24-12	ALL
36		W1292	2012B	20		73-24-21	ALL
37		W1292	2012R	20		73-24-21	ALL
38	UNUSED						ALL
39		W1292	4001G	22		46-13-11	ALL
PERB		W1292	2005Z			78-32-61	ALL
PERB		W1292	2007Z			73-21-12	ALL
PERB		W1292	2008Z			73-21-11	ALL
PERB		W1292	2009Z			73-21-21	ALL
PERB		W1292	2010Z			73-21-21	ALL
PERB		W1292	2011Z			73-21-21	ALL
PERB		W1292	2012Z			73-24-21	ALL
PERB		W1292	2013Z			73-24-12	ALL
PERB		W1292	2017Z			SPARE	ALL
PERB		W1292	3003Z			78-32-61	ALL
PERB		W1292	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40004J	**AL0720C/201/R033**		**RCPT-CONDUCTIVE**				**ALL**
1		W6122	2224R	22		32-64-12	ALL
2		W6122	2224B	22		32-64-12	ALL
3		W6122	2211R	22		32-41-11	ALL
4		W6122	2211B	22		32-41-11	ALL
5		W6122	2211Z			32-41-11	ALL
6		W6122	2223R	22		32-64-12	ALL
7		W6122	2223B	22		32-64-12	ALL
8	UNUSED						ALL
9		W6122	2241R	22		32-31-12	ALL
10		W6122	2241B	22		32-31-12	ALL
11	UNUSED						ALL
12		W6122	0508	20		29-31-11	ALL
13		W6122	0510	20		29-31-11	ALL
14		W6122	0509	20		29-31-11	ALL
15		W6122	0513	20		29-23-11	ALL
16		W6122	2202R	20		32-49-11	ALL
17	4L	W6122	4501W	20		32-46-11	ALL
18	4H	W6122	4501G	20		32-46-11	ALL
19		W6122	2202B	20		32-49-11	ALL
S/R		W6122	2202Z			32-49-11	ALL
S/R		W6122	4501Z			32-46-11	ALL
D40004P	**AL0720C/201/R034**		**PLUG-CONDUCTIVE**				**ALL**
1		W8224	2224R	20		32-64-12	ALL
2		W8224	2224B	20		32-64-12	ALL
3		W8224	2211R	20		32-41-11	ALL
4		W8224	2211B	20		32-41-11	ALL
5		W8224	2211ZI			32-41-11	ALL
6		W8224	2223R	20		32-64-12	ALL
7		W8224	2223B	20		32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40004P		**AL0720C/201/R034**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8	UNUSED						ALL
	9		W8224	2241R	20		32-31-12	ALL
	10		W8224	2241B	20		32-31-12	ALL
	11	UNUSED						ALL
	12		W8224	0502	20		29-31-11	ALL
	13		W8224	0503	20		29-31-11	ALL
	14		W8224	0504	20		29-31-11	ALL
	15		W8224	0501	20		29-23-11	ALL
	16		W8224	2202R	20		32-49-11	ALL
	17	4K	W8224	4501W	20		32-46-11	ALL
	18	4G	W8224	4501G	20		32-46-11	ALL
	19		W8224	2202B	20		32-49-11	ALL
	S/R		W8224	2202ZI			32-49-11	ALL
	S/R		W8224	2211ZO			32-41-11	ALL
	S/R		W8224	2223Z			32-64-12	ALL
	S/R		W8224	2241Z			32-31-12	ALL
	S/R		W8224	4501Z			32-46-11	ALL
	DED		W8224	2202ZO			32-49-11	ALL
D40005J		**392/293/R021**		**RCPT-**				**ALL**
	1		W4142	2204R	22		23-31-04	ALL
	2		W4142	2204B	22		23-31-04	ALL
	3	UNUSED						ALL
D40005P		**392/293/R021**		**PLUG**				**ALL**
	1		W3309	2001R	22		23-31-04	ALL
	2		W3309	2001B	22		23-31-04	ALL
	3	UNUSED						ALL
D40006J		**AL0720C/201/R033**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6124	0550	22		22-23-12	ALL
	2		W6124	0001	20		33-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40006J	**AL0720C/201/R033**		**RCPT-CONDUCTIVE (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
D40006P	**AL0720C/201/R34**		**PLUG- CONDUCTIVE**				**ALL**
1		W8226	0507	20		22-23-12	ALL
2		W8226	0509	20		33-25-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
D40007J	**951/300/R016**		**RCPT-**				**ALL**
1		W4142	2203R	22		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40007J		**951/300/R016**		**RCPT- (continued)**				**ALL**
	2		W4142	2203B	22		23-31-04	ALL
	3	UNUSED						ALL
D40007P		**952/300/R018**		**PLUG**				**ALL**
	1		W3309	2004R	22		23-31-04	ALL
	2		W3309	2004B	22		23-31-04	ALL
	3	UNUSED						ALL
D40008J		**726/199/L052**		**RCPT-**				**ALL**
	1		W7598	6005R	20		26-21-11	ALL
	2	UNUSED						ALL
	3		W7598	6007R	20		26-21-11	ALL
	4		W7598	6004R	20		26-21-11	ALL
	5		W7598	6008R	20		26-21-11	ALL
	6		W7598	6003R	20		26-21-11	ALL
	7		W7598	6011R	20		26-21-11	ALL
	8		W7598	6010R	20		26-21-11	ALL
	9		W7598	6009R	20		26-21-11	ALL
	10		W7598	6002R	20		26-21-11	ALL
	11		W7598	6001R	20		26-21-11	ALL
	12	UNUSED						ALL
D40008P		**726/199/L053**		**PLUG - ELEC DISC AFT**				**ALL**
	1		W7594	6005R	20		26-21-11	ALL
	2	UNUSED						ALL
	3		W7594	6007R	20		26-21-11	ALL
	4		W7594	6004R	20		26-21-11	ALL
	5		W7594	6008R	20		26-21-11	ALL
	6		W7594	6003R	20		26-21-11	ALL
	7		W7594	6009R	20		26-21-11	ALL
	8		W7594	6010R	20		26-21-11	ALL
	9		W7594	6011R	20		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40008P	**726/199/L053**		**PLUG - ELEC DISC AFT (continued)**				**ALL**
10		W7594	6012R	20		26-21-11	ALL
11		W7594	6013R	20		26-21-11	ALL
12	UNUSED						ALL
D40009J	**956/300/L019**		**RCPT-**				**ALL**
1		W3142	2201R	22		23-31-04	ALL
2		W3142	2201B	22		23-31-04	ALL
3	UNUSED						ALL
D40009P	**952/298/L015**		**PLUG**				**ALL**
1		W3309	2003R	22		23-31-04	ALL
2		W3309	2003B	22		23-31-04	ALL
3	UNUSED						ALL
D40010J	**715/199/L051**		**RCPT - ELEC DISC MID**				**ALL**
1		W7594	6005R	20		26-21-11	ALL
2		W7594	6007R	20		26-21-11	ALL
3		W7594	6008R	20		26-21-11	ALL
4		W7594	6002R	20		26-21-11	ALL
5		W7594	6001R	20		26-21-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40010P	**715/199/L053**		**PLUG - ELEC DISC MID**				**ALL**
1		W7592	6001R	20		26-21-11	ALL
2		W7592	6002R	20		26-21-11	ALL
3		W7592	6003R	20		26-21-11	ALL
4		W7592	6007R	20		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40010P		**715/199/L053**		**PLUG - ELEC DISC MID (continued)**				**ALL**
	5		W7592	6009R	20		26-21-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40011J		**AB0366/ /**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2		W3477	0038	20		44-21-12	ALL
	3		W3477	0039	20		44-21-12	ALL
	4		W3477	0040	20		44-21-12	ALL
	5		W3477	0037	20		44-21-12	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3477	0036	20		44-21-12	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40012J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0390R	20		26-21-11	ALL
	A02		W0220	0395R	20		26-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40012J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0220	0394R	20		26-21-11	ALL
	B02		W0220	0396R	20		26-21-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40012J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40012P		**E002-02/ /**		**PLUG**				**ALL**
	A01		W7594	6003R	20		26-21-11	ALL
	A02		W7594	6004R	20		26-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W7594	6002R	20		26-21-11	ALL
	B02		W7594	6001R	20		26-21-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40012P		**E002-02/ /**		**PLUG (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40019J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0159	22		22-13-11	ALL
	A02		W0111	0471	24		34-49-11	ALL
	A03		W0111	0178	22		22-14-11	ALL
	A04		W0111	0183	22		22-14-11	ALL
	A05		W0111	0188	22		22-14-11	ALL
	A06	UNUSED						ALL
	A07		W0111	0187	22		22-14-11	ALL
	A08		W0111	0778	22		22-14-11	ALL
	A09		W0111	0340	22		22-31-51	ALL
	A10		W0111	0361	22		34-61-16	ALL
	A11		W0111	0264	24		34-49-11	ALL
	A12		W0111	0266	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40019J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	A13		W0111	0268	24		34-49-11	ALL
	A14		W0111	0279	24		34-49-11	ALL
	A15		W0111	0282	24		34-49-11	ALL
	A16		W0111	0283	24		34-49-11	ALL
	A17	UNUSED						ALL
	A18		W0111	0741	22		32-31-11	ALL
	A19		W0111	2127R	24		31-65-12	ALL
	A20		W0111	2127B	24		31-65-12	ALL
	B01		W0111	0362	22		34-61-16	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0111	0182	22		22-14-11	ALL
	B11		W0111	0227	22		34-45-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0111	2127Z			31-65-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40019P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W2221	0001	22		22-13-11	ALL
A02		W2221	0012	24		34-49-11	ALL
A03		W2221	0003	22		22-14-11	ALL
A04		W2221	0004	22		22-14-11	ALL
A05		W2221	0005	22		22-14-11	ALL
A06	UNUSED						ALL
A07		W2221	0006	22		22-14-11	ALL
A08		W2221	0008	22		22-14-11	ALL
A09		W2221	0009	22		22-31-51	ALL
A10		W2221	0010	22		34-61-16	ALL
A11		W2221	0111	24		34-49-11	ALL
A12		W2221	0112	24		34-49-11	ALL
A13		W2221	0113	24		34-49-11	ALL
A14		W2221	0114	24		34-49-11	ALL
A15		W2221	0115	24		34-49-11	ALL
A16		W2221	0116	24		34-49-11	ALL
A17	UNUSED						ALL
A18		W2221	0118	22		32-31-11	ALL
A19		W2221	2019R	24		31-65-12	ALL
A20		W2221	2019B	24		31-65-12	ALL
B01		W2221	0011	22		34-61-16	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40019P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10		W2221	0020	22		22-14-11	ALL
	B11		W2221	0211	22		34-45-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2221	2019Z			31-65-12	ALL
D40024J		**ORSS 256/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1024	2001R	20		27-18-11	ALL
	7		W1024	2001B	20		27-18-11	ALL
	8		W1024	3001R	20		27-18-11	ALL
	9		W1024	3001B	20		27-18-11	ALL
	10		W1024	3001Y	20		27-18-11	ALL
	11		W1024	2009R	20		27-53-21	ALL
	12		W1024	2009B	20		27-53-21	ALL
	13		W1024	3007R	20		27-53-21	ALL
	14		W1024	3007B	20		27-53-21	ALL
	15		W1024	3007Y	20		27-53-21	ALL
	16		W1024	3006R	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40024J	**ORSS 256/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
17		W1024	3006B	20		27-53-21	ALL
18		W1024	3006Y	20		27-53-21	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1024	2005R	20		22-11-11	ALL
25		W1024	2005B	20		22-11-11	ALL
26		W1024	3005R	20		22-12-31	ALL
27		W1024	3005B	20		22-12-31	ALL
28		W1024	3005Y	20		22-12-31	ALL
29		W1024	2004R	20		27-32-21	ALL
30		W1024	2004B	20		27-32-21	ALL
31		W1024	3004R	20		27-32-21	ALL
32		W1024	3004B	20		27-32-21	ALL
33		W1024	3004Y	20		27-32-21	ALL
34		W1024	1001	20		28-21-11	ALL
35	UNUSED						ALL
36		W1024	2006R	20		27-52-11	ALL
37		W1024	2006B	20		27-52-11	ALL
38		W1024	2006ZI			27-52-11	ALL
39		W1024	2007ZI			27-52-11	ALL
40		W1024	2007R	20		27-52-11	ALL
41		W1024	2007B	20		27-52-11	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40024J		**ORSS 256/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W1024	1001Z			28-21-11	ALL
	S/R		W1024	2001Z			27-18-11	ALL
	S/R		W1024	2004Z			27-32-21	ALL
	S/R		W1024	2005Z			22-11-11	ALL
	S/R		W1024	2006ZO			27-52-11	ALL
	S/R		W1024	2007ZO			27-52-11	ALL
	S/R		W1024	2009Z			27-53-21	ALL
	S/R		W1024	3001Z			27-18-11	ALL
	S/R		W1024	3004Z			27-32-21	ALL
	S/R		W1024	3005Z			22-12-31	ALL
	S/R		W1024	3006Z			27-53-21	ALL
	S/R		W1024	3007Z			27-53-21	ALL
D40024P		**ORSS 252/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1022	2001R	20		27-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40024P	**ORSS 252/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
7		W1022	2001B	20		27-18-11	ALL
8		W1022	3001R	20		27-18-11	ALL
9		W1022	3001B	20		27-18-11	ALL
10		W1022	3001Y	20		27-18-11	ALL
11		W1022	2009R	20		27-53-21	ALL
12		W1022	2009B	20		27-53-21	ALL
13		W1022	3007R	20		27-53-21	ALL
14		W1022	3007B	20		27-53-21	ALL
15		W1022	3007Y	20		27-53-21	ALL
16		W1022	3006R	20		27-53-21	ALL
17		W1022	3006B	20		27-53-21	ALL
18		W1022	3006Y	20		27-53-21	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1022	2005R	20		22-11-11	ALL
25		W1022	2005B	20		22-11-11	ALL
26		W1022	3005R	20		22-12-31	ALL
27		W1022	3005B	20		22-12-31	ALL
28		W1022	3005Y	20		22-12-31	ALL
29		W1022	2004R	20		27-32-21	ALL
30		W1022	2004B	20		27-32-21	ALL
31		W1022	3004R	20		27-32-21	ALL
32		W1022	3004B	20		27-32-21	ALL
33		W1022	3004Y	20		27-32-21	ALL
34		W1022	1001	20		28-21-11	ALL
35	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40024P		**ORSS 252/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	36		W1022	2006R	20		27-52-11	ALL
	37		W1022	2006B	20		27-52-11	ALL
	38	18	W1022	2006ZI			27-52-11	ALL
	39	18	W1022	2007ZI			27-52-11	ALL
	40		W1022	2007R	20		27-52-11	ALL
	41		W1022	2007B	20		27-52-11	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W1022	1001Z			28-21-11	ALL
	S/R		W1022	2001Z			27-18-11	ALL
	S/R		W1022	2004Z			27-32-21	ALL
	S/R		W1022	2005Z			22-11-11	ALL
	S/R		W1022	2006ZO			27-52-11	ALL
	S/R		W1022	2007ZO			27-52-11	ALL
	S/R		W1022	2009Z			27-53-21	ALL
	S/R		W1022	3001Z			27-18-11	ALL
	S/R		W1022	3004Z			27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40024P	**ORSS 252/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W1022	3005Z			22-12-31	ALL
S/R		W1022	3006Z			27-53-21	ALL
S/R		W1022	3007Z			27-53-21	ALL
D40025J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	0238	22		22-23-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W0321	2503R	22		27-32-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W0321	2223R	22		22-23-12	ALL
A08		W0321	2223B	22		22-23-12	ALL
A09		W0321	0604	20		22-23-12	ALL
A10		W0321	0603	20		22-23-12	ALL
B01		W0321	3225R	22		22-23-12	ALL
B02		W0321	3225B	22		22-23-12	ALL
B03		W0321	3225Y	22		22-23-12	ALL
B04		W0321	2503B	22		27-32-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0321	2223Z			22-23-12	ALL
PERG	1F	W0321	2503Z			27-32-11	ALL
PERG	1F	W0321	3225Z			22-23-12	ALL
D40025P	**E003-02/ /**		**PLUG- CONDUCTIVE**				**ALL**
A01		W3377	0101	20		22-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40025P		**E003-02/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W3377	2012R	20		27-32-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W3377	2008R	22		22-23-12	ALL
	A08		W3377	2008B	22		22-23-12	ALL
	A09		W3377	2009R	22		22-23-12	ALL
	A10		W3377	2009B	22		22-23-12	ALL
	B01		W3377	3005R	22		22-23-12	ALL
	B02		W3377	3005B	22		22-23-12	ALL
	B03		W3377	3005Y	22		22-23-12	ALL
	B04		W3377	2012B	20		27-32-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W3377	2008Z			22-23-12	ALL
	PERG	1F	W3377	2009Z			22-23-12	ALL
	PERG	1F	W3377	2012Z			27-32-31	ALL
	PERG	1F	W3377	3005Z			22-23-12	ALL
D40026J		**949/290/R016**		**RCPT, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0152	0003	20		33-51-14	ALL
	4		W0152	0004	20		33-51-14	ALL
	5		W0152	0005	24		33-29-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40026J	**949/290/R016**		**RCPT, RECTANGULAR (continued)**				**ALL**
6		W0152	0006	24		33-29-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0152	0009	22		33-27-22	ALL
10		W0152	0010	22		33-27-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0152	0024	22		23-42-11	ALL
16		W0152	0026	22		23-42-11	ALL
17		W0152	0017	22		SPARE	ALL
18		W0152	0018	22		SPARE	ALL
D40026P	**949/290/R015**		**PLUG, RECTANGULAR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W3058	0463	20		33-51-14	ALL
4		W3058	0464	20		33-51-14	ALL
5		W3058	0465	24		33-29-11	ALL
6		W3058	0466	20		33-29-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W3058	0469	22		33-27-22	ALL
10		W3058	0470	22		33-27-22	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W3058	0147	22		23-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40026P		**949/290/R015**		**PLUG, RECTANGULAR (continued)**				**ALL**
	16		W3058	0476	20		23-42-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
D40029J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0270	22		27-24-11	ALL
	A02		W0321	2720R	22		27-24-11	ALL
	A03		W0321	2720B	22		27-24-11	ALL
	A04		W0321	3721R	22		27-24-11	ALL
	A05		W0321	3721B	22		27-24-11	ALL
	A06		W0321	3721Y	22		27-24-11	ALL
	A07		W0321	0605	20		27-24-11	ALL
	A08		W0321	0606	20		27-24-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0321	2506R	22		27-32-21	ALL
	B10		W0321	2506B	22		27-32-21	ALL
	PERG	1F	W0321	2506Z			27-32-21	ALL
	PERG	1F	W0321	2720Z			27-24-11	ALL
	PERG	1F	W0321	3721Z			27-24-11	ALL
D40029P		**E003-02/ /**		**PLUG- CONDUCTIVE**				**ALL**
	A01		W3379	0003	20		27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40029P	**E003-02/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
A02		W3379	2008R	22		27-24-11	ALL
A03		W3379	2008B	22		27-24-11	ALL
A04		W3379	3005R	20		27-24-11	ALL
A05		W3379	3005B	20		27-24-11	ALL
A06		W3379	3005Y	20		27-24-11	ALL
A07		W3379	2009R	22		27-24-11	ALL
A08		W3379	2009B	22		27-24-11	ALL
A09		W3379	0002	20		SPARE	ALL
A10	UNUSED						ALL
B01		W3379	2010R	22		SPARE	ALL
B02		W3379	2010B	22		SPARE	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W3379	2011R	20		27-32-31	ALL
B10		W3379	2011B	20		27-32-31	ALL
PERG	1F	W3379	2008Z			27-24-11	ALL
PERG	1F	W3379	2009Z			27-24-11	ALL
PERG	1F	W3379	2010Z			SPARE	ALL
PERG	1F	W3379	2011Z			27-32-31	ALL
PERG	1F	W3379	3005Z			27-24-11	ALL
D40032J	**949/290/L014**		**RCPT, RECTANGULAR**				**ALL**
1		W0152	0021	18		35-21-21	ALL
2		W0152	0022	18		35-21-21	ALL
3		W0152	3403Y	20		23-41-11	ALL
4		W0152	3403R	20		23-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40032J		**949/290/L014**		**RCPT, RECTANGULAR (continued)**				**ALL**
	5		W0152	3403B	20		23-41-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
D40032P		**949/290/L013**		**PLUG, RECTANGULAR**				**ALL**
	1		W7359	0001	18		35-21-21	ALL
	2		W7359	0002	18		35-21-21	ALL
	3		W7359	3503Y	20		23-41-11	ALL
	4		W7359	3503R	20		23-41-11	ALL
	5		W7359	3503B	20		23-41-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	DED		W7359	3503Z			23-41-11	ALL
D40034J		**ORSS/256/**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W1034	2001R	20		27-18-11	ALL
	7		W1034	2001B	20		27-18-11	ALL
	8		W1034	3001R	20		27-18-11	ALL
	9		W1034	3001B	20		27-18-11	ALL
	10		W1034	3001Y	20		27-18-11	ALL
	11		W1034	2009R	20		27-53-21	ALL
	12		W1034	2009B	20		27-53-21	ALL
	13		W1034	3007R	20		27-53-21	ALL
	14		W1034	3007B	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40034J	**ORSS/256/**		**RCPT-CONDUCTIVE (continued)**				**ALL**
15		W1034	3007Y	20		27-53-21	ALL
16		W1034	3006R	20		27-53-21	ALL
17		W1034	3006B	20		27-53-21	ALL
18		W1034	3006Y	20		27-53-21	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1034	2005R	20		22-11-11	ALL
25		W1034	2005B	20		22-11-11	ALL
26		W1034	3005R	20		22-12-41	ALL
27		W1034	3005B	20		22-12-41	ALL
28		W1034	3005Y	20		22-12-41	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W1034	3004R	20		27-32-11	ALL
32		W1034	3004B	20		27-32-11	ALL
33		W1034	3004Y	20		27-32-11	ALL
34		W1034	1001	20		28-21-11	ALL
35	UNUSED						ALL
36		W1034	2006R	20		27-52-11	ALL
37		W1034	2006B	20		27-52-11	ALL
38		W1034	2006ZI			27-52-11	ALL
39		W1034	2007ZI			27-52-11	ALL
40		W1034	2007R	20		27-52-11	ALL
41		W1034	2007B	20		27-52-11	ALL
42	UNUSED						ALL
43	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40034J		**ORSS/256/**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W1034	2004R	20		27-32-11	ALL
	49		W1034	2004B	20		27-32-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W1034	1001Z			28-21-11	ALL
	S/R		W1034	2001Z			27-18-11	ALL
	S/R		W1034	2004Z			27-32-11	ALL
	S/R		W1034	2005Z			22-11-11	ALL
	S/R		W1034	2006ZO			27-52-11	ALL
	S/R		W1034	2007ZO			27-52-11	ALL
	S/R		W1034	2009Z			27-53-21	ALL
	S/R		W1034	3001Z			27-18-11	ALL
	S/R		W1034	3004Z			27-32-11	ALL
	S/R		W1034	3005Z			22-12-41	ALL
	S/R		W1034	3006Z			27-53-21	ALL
	S/R		W1034	3007Z			27-53-21	ALL
D40034P		**ORSS 256/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40034P	**ORSS 256/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
5	UNUSED						ALL
6		W1032	2001R	20		27-18-11	ALL
7		W1032	2001B	20		27-18-11	ALL
8		W1032	3001R	20		27-18-11	ALL
9		W1032	3001B	20		27-18-11	ALL
10		W1032	3001Y	20		27-18-11	ALL
11		W1032	2009R	20		27-53-21	ALL
12		W1032	2009B	20		27-53-21	ALL
13		W1032	3007R	20		27-53-21	ALL
14		W1032	3007B	20		27-53-21	ALL
15		W1032	3007Y	20		27-53-21	ALL
16		W1032	3006R	20		27-53-21	ALL
17		W1032	3006B	20		27-53-21	ALL
18		W1032	3006Y	20		27-53-21	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1032	2005R	20		22-11-11	ALL
25		W1032	2005B	20		22-11-11	ALL
26		W1032	3005R	20		22-12-41	ALL
27		W1032	3005B	20		22-12-41	ALL
28		W1032	3005Y	20		22-12-41	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W1032	3004R	20		27-32-11	ALL
32		W1032	3004B	20		27-32-11	ALL
33		W1032	3004Y	20		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40034P		**ORSS 256/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	34		W1032	1001	20		28-21-11	ALL
	35	UNUSED						ALL
	36		W1032	2006R	20		27-52-11	ALL
	37		W1032	2006B	20		27-52-11	ALL
	38		W1032	2006ZI			27-52-11	ALL
	39		W1032	2007ZI			27-52-11	ALL
	40		W1032	2007R	20		27-52-11	ALL
	41		W1032	2007B	20		27-52-11	ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W1032	2004R	20		27-32-11	ALL
	49		W1032	2004B	20		27-32-11	ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W1032	1001Z			28-21-11	ALL
	S/R		W1032	2001Z			27-18-11	ALL
	S/R		W1032	2004Z			27-32-11	ALL
	S/R		W1032	2005Z			22-11-11	ALL
	S/R		W1032	2006ZO			27-52-11	ALL
	S/R		W1032	2007ZO			27-52-11	ALL
	S/R		W1032	2009Z			27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40034P		**ORSS 256/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W1032	3001Z			27-18-11	ALL
	S/R		W1032	3004Z			27-32-11	ALL
	S/R		W1032	3005Z			22-12-41	ALL
	S/R		W1032	3006Z			27-53-21	ALL
	S/R		W1032	3007Z			27-53-21	ALL
D40036J		**AB0410/205/R039**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W5530	2211Z			32-41-11	ALL
	A03	UNUSED						ALL
	A04		W5530	2211R	20		32-41-11	ALL
	A05		W5530	2222B	22		32-64-11	ALL
	A06		W5530	2221B	22		32-64-11	ALL
	A07	UNUSED						ALL
	A08		W5530	2232B	22		32-31-11	ALL
	A09		W5530	4502G	20		32-46-11	ALL
	A10		W5530	4502W	20		32-46-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5530	2211B	20		32-41-11	ALL
	B05		W5530	2222R	22		32-64-11	ALL
	B06		W5530	2221R	22		32-64-11	ALL
	B07	UNUSED						ALL
	B08		W5530	2232R	22		32-31-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5530	4502Z			32-46-11	ALL
D40036P		**AB0410/205/R039**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40036P		**AB0410/205/R039**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A02		W5156	2215Z			32-41-11	ALL
	A03	UNUSED						ALL
	A04		W5156	2215R	22		32-41-11	ALL
	A05		W5156	2212B	22		32-64-11	ALL
	A06		W5156	2211B	22		32-64-11	ALL
	A07	UNUSED						ALL
	A08		W5156	2232B	22		32-31-11	ALL
	A09		W5156	4502G	20		32-46-11	ALL
	A10		W5156	4502W	20		32-46-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5156	2215B	22		32-41-11	ALL
	B05		W5156	2212R	22		32-64-11	ALL
	B06		W5156	2211R	22		32-64-11	ALL
	B07	UNUSED						ALL
	B08		W5156	2232R	22		32-31-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	4502Z			32-46-11	ALL
D40040J		**317/290/L018**		**RCPT, RECTANGULAR**				**ALL**
	1		W0352	2001R	22		23-31-04	ALL
	2		W0352	2001B	22		23-31-04	ALL
	3		W0352	0003	20		33-51-12	ALL
	4		W0352	0004	20		33-51-12	ALL
	5		W0352	0005	18		35-21-21	ALL
	6		W0352	0006	18		35-21-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40040P	**317/289/L018**		**PLUG, RECTANGULAR**				**ALL**
1		W4142	2202R	22		23-31-04	ALL
2		W4142	2202B	22		23-31-04	ALL
3		W4142	0109	20		33-51-12	ALL
4		W4142	0159	20		33-51-12	ALL
5		W4142	0065	18		35-21-21	ALL
6		W4142	0066	18		35-21-21	ALL
7	UNUSED						ALL
8	UNUSED						ALL
D40042J	**332/289/R026**		**RCPT, RECTANGULAR**				**ALL**
1		W0342	2001R	22		23-31-04	ALL
2		W0342	2001B	22		23-31-04	ALL
3		W0342	0003	20		33-51-12	ALL
4		W0342	0004	20		33-51-12	ALL
5		W0342	0001	18		35-21-31	ALL
6		W0342	0002	18		35-21-31	ALL
7	UNUSED						ALL
8	UNUSED						ALL
D40042P	**331/289/R025**		**PLUG, RECTANGULAR**				**ALL**
1		W4142	2201R	22		23-31-04	ALL
2		W4142	2201B	22		23-31-04	ALL
3		W4142	0009	20		33-51-12	ALL
4		W4142	0059	20		33-51-12	ALL
5		W4142	0077	18		35-21-31	ALL
6		W4142	0078	18		35-21-31	ALL
7	UNUSED						ALL
8	UNUSED						ALL
D40044J	**982/289/L033**		**RCPT, RECTANGULAR**				**ALL**
1		W0452	2001R	22		23-31-04	ALL
2		W0452	2001B	22		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40044J		**982/289/L033**		**RCPT, RECTANGULAR (continued)**				**ALL**
	3		W0452	0003	20		33-51-14	ALL
	4		W0452	0004	20		33-51-14	ALL
	5		W0452	0005	22		33-26-11	ALL
	6		W0452	0006	22		33-26-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
D40044P		**982/289/L033**		**PLUG, RECTANGULAR**				**ALL**
	1		W3142	2201R	22		23-31-04	ALL
	2		W3142	2201B	22		23-31-04	ALL
	3		W3142	0409	20		33-51-14	ALL
	4		W3142	0474	20		33-51-14	ALL
	5		W3142	0475	22		33-26-11	ALL
	6		W3142	0476	20		33-26-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
D40046J		**974/289/R034**		**RCPT, RECTANGULAR**				**ALL**
	1		W0442	2001R	22		23-31-04	ALL
	2		W0442	2001B	22		23-31-04	ALL
	3		W0442	0003	20		33-51-14	ALL
	4		W0442	0004	20		33-51-14	ALL
	5		W0442	0005	22		33-26-11	ALL
	6		W0442	0006	22		33-26-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
D40046P		**974/289/R034**		**PLUG, RECTANGULAR**				**ALL**
	1		W4142	2203R	22		23-31-04	ALL
	2		W4142	2203B	22		23-31-04	ALL
	3		W4142	0409	20		33-51-14	ALL
	4		W4142	0459	20		33-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40046P	**974/289/R034**		**PLUG, RECTANGULAR (continued)**				**ALL**
5		W4142	0475	22		33-26-11	ALL
6		W4142	0476	20		33-26-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
D40050J	**AB0340A/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2		W3058	0302	22		33-22-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40050P	**AB0340A/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W6242	0014	22		33-21-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6242	0059	20		SPARE	ALL
9		W6242	0060	20		SPARE	ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40050P		**AB0340A/ /**		**PLUG- (continued)**				**ALL**
	12	UNUSED						ALL
D40053J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2701R	24		27-18-11	ALL
	A02		W0321	2701B	24		27-18-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0321	3701R	24		27-18-11	ALL
	A06		W0321	3701B	24		27-18-11	ALL
	A07		W0321	3701Y	24		27-18-11	ALL
	A08		W0321	0274	22		27-32-11	ALL
	A09		W0321	0131	22		27-32-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0321	3732R	22		27-32-11	ALL
	B05		W0321	3732B	22		27-32-11	ALL
	B06		W0321	3732Y	22		27-32-11	ALL
	B07		W0321	2361B	22		31-32-15	ALL
	B08		W0321	2361R	22		31-32-15	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	DED		W0321	3732Z			27-32-11	ALL
	PERG	1F	W0321	2361Z			31-32-15	ALL
D40053P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5367	2010R	22		27-18-11	ALL
	A02		W5367	2010B	22		27-18-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40053P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05		W5367	3015R	22		27-18-11	ALL
	A06		W5367	3015B	22		27-18-11	ALL
	A07		W5367	3015Y	22		27-18-11	ALL
	A08		W5367	2002R	22		27-32-11	ALL
	A09		W5367	2002B	22		27-32-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5367	3002R	22		27-32-11	ALL
	B05		W5367	3002B	22		27-32-11	ALL
	B06		W5367	3002Y	22		27-32-11	ALL
	B07		W5367	2004B	22		31-32-15	ALL
	B08		W5367	2004R	22		31-32-15	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	DED		W5367	2002Z			27-32-11	ALL
	DED		W5367	3002Z			27-32-11	ALL
	PERG	1F	W5367	2004Z			31-32-15	ALL
D40054J		**AB0340A/ /**		**RCPT-**				**ALL**
	1		W3058	0291	22		33-26-11	ALL
	2		W3058	0302	22		33-22-11	ALL
	3		W3058	0293	22		38-41-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40054J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40054P		**AB0340A/295/L006**		**PLUG-**				**ALL**
	1		W5142	0026	22		33-26-11	ALL
	2		W5142	0092	22		33-22-11	ALL
	3		W5142	0021	22		38-41-11	ALL
	4	UNUSED						ALL
	5		W5142	0054	20		SPARE	ALL
	6		W5142	0055	20		SPARE	ALL
	7	UNUSED						ALL
	8		W5142	0056	20		SPARE	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40056J		**AB0536L/*/***		**RCPT-CONDUCTIVE**				**ALL**
	1		W5102	2076B	20		21-51-12	ALL
	2		W5102	2076R	20		21-51-12	ALL
	3		W5102	2078B	20		21-51-12	ALL
	4		W5102	2078R	20		21-51-12	ALL
	5		W5102	2077B	20		21-51-12	ALL
	6		W5102	2077R	20		21-51-12	ALL
	7		W5102	2079B	20		21-51-12	ALL
	8		W5102	2079R	20		21-51-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40056J	**AB0536L/*/***		**RCPT-CONDUCTIVE (continued)**				**ALL**
13	UNUSED						ALL
14	UNUSED						ALL
15		W5102	1201	20		33-44-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5102	2080B	20		21-51-13	ALL
21		W5102	2080R	20		21-51-13	ALL
22		W5102	2081B	20		21-51-13	ALL
23		W5102	2081R	20		21-51-13	ALL
24		W5102	2082B	20		21-51-14	ALL
25		W5102	2082R	20		21-51-14	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5102	1049	20		21-61-51	ALL
31	UNUSED						ALL
S/R		W5102	1049Z			21-61-51	ALL
S/R		W5102	1201Z			33-44-11	ALL
S/R		W5102	2076Z			21-51-12	ALL
S/R		W5102	2077Z			21-51-12	ALL
S/R		W5102	2078Z			21-51-12	ALL
S/R		W5102	2079Z			21-51-12	ALL
S/R		W5102	2080Z			21-51-13	ALL
S/R		W5102	2081Z			21-51-13	ALL
S/R		W5102	2082Z			21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40056P		**AB0536L/*/***		**PLUG-CONDUCTIVE**				**ALL**
	1		W5104	0301	24		21-51-12	ALL
	2		W5104	0302	24		21-51-12	ALL
	3		W5104	0303	24		21-51-12	ALL
	4		W5104	0304	24		21-51-12	ALL
	5		W5104	0305	24		21-51-12	ALL
	6		W5104	0306	24		21-51-12	ALL
	7		W5104	0307	24		21-51-12	ALL
	8		W5104	0308	24		21-51-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5104	1201	20		33-44-11	ALL
	16		W5104	5522	20		SPARE	ALL
	17	UNUSED						ALL
	18		W5104	5520	20		SPARE	ALL
	19		W5104	5521	20		SPARE	ALL
	20		W5104	0311	24		21-51-13	ALL
	21		W5104	0312	24		21-51-13	ALL
	22		W5104	0313	24		21-51-13	ALL
	23		W5104	0314	24		21-51-13	ALL
	24		W5104	2003B	20		21-51-14	ALL
	25		W5104	2003R	20		21-51-14	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40056P	**AB0536L/*/***		**PLUG-CONDUCTIVE (continued)**				**ALL**
30		W5104	0309	24		21-61-51	ALL
31	UNUSED						ALL
S/R		W5104	1201Z			33-44-11	ALL
S/R		W5104	2003Z			21-51-14	ALL
D40058J	**AB0536R/*/***		**RCPT-CONDUCTIVE**				**ALL**
1		W6202	2007B	22		36-21-11	ALL
2		W6202	2090R	20		21-51-24	ALL
3		W6202	2007R	22		36-21-11	ALL
4		W6202	1018	20		30-71-11	ALL
5		W6202	2076B	20		21-51-22	ALL
6		W6202	2080B	20		21-51-23	ALL
7		W6202	1013	20		27-83-21	ALL
8		W6202	2080R	20		21-51-23	ALL
9		W6202	1014	20		33-33-11	ALL
10		W6202	1049	20		21-61-51	ALL
11		W6202	1015	20		33-33-11	ALL
12		W6202	1016	20		33-33-11	ALL
13		W6202	2081B	20		21-51-23	ALL
14		W6202	2076R	20		21-51-22	ALL
15		W6202	2078B	20		21-51-22	ALL
16		W6202	2082B	20		21-51-24	ALL
17		W6202	2082R	20		21-51-24	ALL
18		W6202	1041	20		21-61-13	ALL
19		W6202	2081R	20		21-51-23	ALL
20		W6202	2078R	20		21-51-22	ALL
21		W6202	2077B	20		21-51-22	ALL
22		W6202	2077R	20		21-51-22	ALL
23		W6202	2079B	20		21-51-22	ALL
24		W6202	2079R	20		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40058J		**AB0536R/*/***		**RCPT-CONDUCTIVE (continued)**				**ALL**
	25		W6202	2084B	20		21-61-13	ALL
	26		W6202	2084R	20		21-61-13	ALL
	27		W6202	1046	20		21-61-14	ALL
	28		W6202	2086B	20		21-61-14	ALL
	29		W6202	2086R	20		21-61-14	ALL
	30		W6202	2090B	20		21-51-24	ALL
	31		W6202	1102	20		30-71-11	ALL
	S/R		W6202	1013Z			27-83-21	ALL
	S/R		W6202	1014Z			33-33-11	ALL
	S/R		W6202	1015Z			33-33-11	ALL
	S/R		W6202	1016Z			33-33-11	ALL
	S/R		W6202	1018Z			30-71-11	ALL
	S/R		W6202	1041Z			21-61-13	ALL
	S/R		W6202	1046Z			21-61-14	ALL
	S/R		W6202	1049Z			21-61-51	ALL
	S/R		W6202	1102Z			30-71-11	ALL
	S/R		W6202	2007Z			36-21-11	ALL
	S/R		W6202	2076Z			21-51-22	ALL
	S/R		W6202	2077Z			21-51-22	ALL
	S/R		W6202	2078Z			21-51-22	ALL
	S/R		W6202	2079Z			21-51-22	ALL
	S/R		W6202	2080Z			21-51-23	ALL
	S/R		W6202	2081Z			21-51-23	ALL
	S/R		W6202	2082Z			21-51-24	ALL
	S/R		W6202	2084Z			21-61-13	ALL
	S/R		W6202	2086Z			21-61-14	ALL
	S/R		W6202	2090Z			21-51-24	ALL
D40058P		**AB0536R/*/***		**PLUG-CONDUCTIVE**				**ALL**
	1		W6230	2501B	24		36-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40058P	**AB0536R/*/***		**PLUG-CONDUCTIVE (continued)**				**ALL**
2		W6230	2090R	24		21-51-24	ALL
3		W6230	2501R	24		36-21-11	ALL
4		W6230	5535	20		30-71-11	ALL
5		W6230	0301	24		21-51-22	ALL
6		W6230	0309	24		21-51-23	ALL
7		W6230	0503	22		27-83-21	ALL
8		W6230	0310	24		21-51-23	ALL
9		W6230	0001	20		33-33-11	ALL
10		W6230	5537	24		21-61-51	ALL
11		W6230	0521	20		33-33-11	ALL
12		W6230	0522	20		33-33-11	ALL
13		W6230	0311	24		21-51-23	ALL
14		W6230	0302	24		21-51-22	ALL
15		W6230	0303	24		21-51-22	ALL
16		W6230	2003B	20		21-51-24	ALL
17		W6230	2003R	20		21-51-24	ALL
18		W6230	0316	24		21-61-13	ALL
19		W6230	0312	24		21-51-23	ALL
20		W6230	0304	24		21-51-22	ALL
21		W6230	0305	24		21-51-22	ALL
22		W6230	0306	24		21-51-22	ALL
23		W6230	0307	24		21-51-22	ALL
24		W6230	0308	24		21-51-22	ALL
25		W6230	0317	24		21-61-13	ALL
26		W6230	0318	24		21-61-13	ALL
27		W6230	0319	24		21-61-14	ALL
28		W6230	0320	24		21-61-14	ALL
29		W6230	0321	24		21-61-14	ALL
30		W6230	2090B	24		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40058P		**AB0536R/*/***		**PLUG-CONDUCTIVE (continued)**				**ALL**
	31		W6230	5526	20		30-71-11	ALL
	S/R		W6230	2003Z			21-51-24	ALL
	S/R		W6230	2090Z			21-51-24	ALL
	S/R		W6230	2501Z			36-21-11	ALL
D40059J		**AB0410/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5431	0003	22		23-71-01	ALL
	A02		W5431	0014	24		23-71-01	ALL
	A03		W5431	0012	24		23-71-01	ALL
	A04		W5431	2009R	24		23-71-01	ALL
	A05		W5431	2005R	24		23-71-01	ALL
	A06		W5431	2005Z			23-71-01	ALL
	A07		W5431	2006R	24		23-71-01	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5431	0013	24		23-71-01	ALL
	B03		W5431	0006	20		23-71-01	ALL
	B04		W5431	2009B	24		23-71-01	ALL
	B05		W5431	2005B	24		23-71-01	ALL
	B06	UNUSED						ALL
	B07		W5431	2006B	24		23-71-01	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5431	2009Z			23-71-01	ALL
D40059P		**AB0410/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W3329	0002	22		23-71-01	ALL
	A02		W3329	0010	24		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40059P	**AB0410/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A03		W3329	0014	24		23-71-01	ALL
A04		W3329	2007R	24		23-71-01	ALL
A05		W3329	2001R	24		23-71-01	ALL
A06		W3329	2001Z			23-71-01	ALL
A07		W3329	2002R	24		23-71-01	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02		W3329	0011	24		23-71-01	ALL
B03		W3329	0015	20		23-71-01	ALL
B04		W3329	2007B	24		23-71-01	ALL
B05		W3329	2001B	24		23-71-01	ALL
B06	UNUSED						ALL
B07		W3329	2002B	24		23-71-01	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W3329	2007Z			23-71-01	ALL
D40060J	**AB1088/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W4724	1101R	18		26-11-31	ALL
3		W4724	1112R	20		26-11-31	ALL
4	UNUSED						ALL
5		W4724	1005	20		33-35-11	ALL
6		W4724	0034	18		33-35-11	ALL
7		W4724	0036	18		33-35-11	ALL
8	UNUSED						ALL
9		W4724	1110R	20		26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40060J		**AB1088/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	10		W4724	1111R	20		26-11-31	ALL
	S/R		W4724	1005Z			33-35-11	ALL
	S/R		W4724	1101Z			26-11-31	ALL
	S/R		W4724	1110Z			26-11-31	ALL
	DED		W4724	1111Z			26-11-31	ALL
	DED		W4724	1112Z			26-11-31	ALL
D40060P		**AB1088/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W7538	6003R	18		26-11-31	ALL
	3		W7538	1011R	18		26-11-31	ALL
	4	UNUSED						ALL
	5		W7538	1002	18		33-35-11	ALL
	6		W7538	1004	18		33-35-11	ALL
	7		W7538	1006	18		33-35-11	ALL
	8	UNUSED						ALL
	9		W7538	1010R	18		26-11-31	ALL
	10		W7538	6004R	18		26-11-31	ALL
	S/R		W7538	1002Z			33-35-11	ALL
	S/R		W7538	1004Z			33-35-11	ALL
	S/R		W7538	1006Z			33-35-11	ALL
D40062J		**1146/248/R012**		**RCPT-**				**ALL**
	1		W7538	6001R	18		26-11-31	ALL
	2	UNUSED						ALL
	3		W7538	1011R	18		26-11-31	ALL
	4	UNUSED						ALL
	5		W7538	1010R	18		26-11-31	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40062P	**1146/248/R013**		**PLUG-**				**ALL**
1		W7540	6001R	18		26-11-31	ALL
2	UNUSED						ALL
3		W7540	6002R	18		26-11-31	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D40063J	**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
A01		W0111	2114R	24		34-21-23	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W0111	0019	22		22-11-11	ALL
A05		W0111	0020	22		22-11-11	ALL
A06		W0111	0021	22		22-11-11	ALL
A07		W0111	2135R	24		73-24-21	ALL
A08		W0111	2135B	24		73-24-21	ALL
A09	UNUSED						ALL
A10		W0111	0075	22		22-11-18	ALL
B01		W0111	2114B	24		34-21-23	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W0111	0977	22		78-34-21	ALL
PERG	1F	W0111	2114Z			34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40063J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	2135Z			73-24-21	ALL
D40063P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5723	2024R	24		34-21-23	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5723	0144	20		22-11-11	ALL
	A05		W5723	0145	20		22-11-11	ALL
	A06		W5723	0146	20		22-11-11	ALL
	A07		W5723	2049R	24		73-24-21	ALL
	A08		W5723	2049B	24		73-24-21	ALL
	A09	UNUSED						ALL
	A10		W5723	0140	22		22-11-18	ALL
	B01		W5723	2024B	24		34-21-23	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5723	0041	20		78-34-21	ALL
	PERG	1F	W5723	2024Z			34-21-23	ALL
	PERG	1F	W5723	2049Z			73-24-21	ALL
D40064J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	2002R	24		34-33-21	ALL
	A02		W0111	2005R	24		34-33-21	ALL
	A03		W0111	2249R	24		21-31-23	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40064J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A05	UNUSED						ALL
	A06		W0111	2250R	24		21-31-23	ALL
	A07	UNUSED						ALL
	A08		W0111	0802	24		21-31-23	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0111	2002B	24		34-33-21	ALL
	B02		W0111	2005B	24		34-33-21	ALL
	B03		W0111	2249B	24		21-31-23	ALL
	B04	UNUSED						ALL
	B05		W0111	1041	22		21-31-23	ALL
	B06		W0111	2250B	24		21-31-23	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0111	1041Z			21-31-23	ALL
	PERG	1F	W0111	2002Z			34-33-21	ALL
	PERG	1F	W0111	2005Z			34-33-21	ALL
	PERG	1F	W0111	2249Z			21-31-23	ALL
	PERG	1F	W0111	2250Z			21-31-23	ALL
D40064P		**E001-01/ /**		**PLUG-**				**ALL**
	A01		W2218	2020R	24		34-33-21	ALL
	A02		W2218	2021R	24		34-33-21	ALL
	A03		W2218	2101R	24		21-31-23	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W2218	2102R	24		21-31-23	ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40064P		**E001-01/ /**		**PLUG- (continued)**				**ALL**
	A08		W2218	6102	24		21-31-23	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2218	2020B	24		34-33-21	ALL
	B02		W2218	2021B	24		34-33-21	ALL
	B03		W2218	2101B	24		21-31-23	ALL
	B04	UNUSED						ALL
	B05		W2218	1004	20		21-31-23	ALL
	B06		W2218	2102B	24		21-31-23	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2218	1004Z			21-31-23	ALL
	PERG	1F	W2218	2020Z			34-33-21	ALL
	PERG	1F	W2218	2021Z			34-33-21	ALL
	PERG	1F	W2218	2101Z			21-31-23	ALL
	PERG	1F	W2218	2102Z			21-31-23	ALL
D40066J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0266	20		21-31-23	ALL
	A02		W0410	1003	20		21-31-23	ALL
	A03		W0410	2035R	24		21-31-23	ALL
	A04		W0410	2035B	24		21-31-23	ALL
	A05		W0410	2036R	24		21-31-23	ALL
	A06		W0410	2036B	24		21-31-23	ALL
	A07		W0410	0267	24		21-31-23	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40066J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0410	1003Z			21-31-23	ALL
	PERG	1F	W0410	2035Z			21-31-23	ALL
	PERG	1F	W0410	2036Z			21-31-23	ALL
D40066P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6204	5501	20		21-31-23	ALL
	A02		W6204	1001	20		21-31-23	ALL
	A03		W6204	2001R	24		21-31-23	ALL
	A04		W6204	2001B	24		21-31-23	ALL
	A05		W6204	2002R	24		21-31-23	ALL
	A06		W6204	2002B	24		21-31-23	ALL
	A07		W6204	5502	24		21-31-23	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40066P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6204	1001Z			21-31-23	ALL
	PERG	1F	W6204	2001Z			21-31-23	ALL
	PERG	1F	W6204	2002Z			21-31-23	ALL
D40067J		**P006-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0041	2518R	24		SPARE	ALL
	2		W0041	2518B	24		SPARE	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40067J	**P006-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
S/R		W0041	2518Z			SPARE	ALL
D40068J	**E004-02/ /**		**RCPT-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0420	1001	20		30-41-12	ALL
A04	UNUSED						ALL
A05		W0420	2003R	20		30-41-12	ALL
A06		W0420	2003B	20		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40068J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	A07		W0420	3001R	20		30-41-12	ALL
	A08		W0420	3001B	20		30-41-12	ALL
	A09		W0420	3001Y	20		30-41-12	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0420	2006B	20		30-41-12	ALL
	B06		W0420	2006R	20		30-41-12	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0420	1002	18		30-41-12	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0420	1001ZI			30-41-12	ALL
	PERG	1F	W0420	1001ZO			30-41-12	ALL
	PERG	1F	W0420	1002ZI			30-41-12	ALL
	PERG	1F	W0420	1002ZO			30-41-12	ALL
	PERG	1F	W0420	2003ZI			30-41-12	ALL
	PERG	1F	W0420	2003ZO			30-41-12	ALL
	PERG	1F	W0420	2006ZI			30-41-12	ALL
	PERG	1F	W0420	2006ZO			30-41-12	ALL
	PERG	1F	W0420	3001ZI			30-41-12	ALL
	PERG	1F	W0420	3001ZO			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40068P	**E004-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W2208	1004	20		30-41-12	ALL
A04	UNUSED						ALL
A05		W2208	2003R	20		30-41-12	ALL
A06		W2208	2003B	20		30-41-12	ALL
A07		W2208	3001R	20		30-41-12	ALL
A08		W2208	3001B	20		30-41-12	ALL
A09		W2208	3001Y	20		30-41-12	ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W2208	2002B	20		30-41-12	ALL
B06		W2208	2002R	20		30-41-12	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2208	1002	18		30-41-12	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W2208	1002Z			30-41-12	ALL
PERG	1F	W2208	1004Z			30-41-12	ALL
PERG	1F	W2208	2002Z			30-41-12	ALL
PERG	1F	W2208	2003Z			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40068P		**E004-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2208	3001Z			30-41-12	ALL
	PERG	1F	W2208	YAAA			30-41-12	ALL
D40070J		**E002-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0210	1001	20		30-41-11	ALL
	A04	UNUSED						ALL
	A05		W0210	2003R	20		30-41-11	ALL
	A06		W0210	2003B	20		30-41-11	ALL
	A07		W0210	3001R	20		30-41-11	ALL
	A08		W0210	3001B	20		30-41-11	ALL
	A09		W0210	3001Y	20		30-41-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0210	2006B	20		30-41-11	ALL
	B06		W0210	2006R	20		30-41-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0210	1002	18		30-41-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0210	1001ZI			30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40070J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	PERG	1F	W0210	1001ZO			30-41-11	ALL
	PERG	1F	W0210	1002ZI			30-41-11	ALL
	PERG	1F	W0210	1002ZO			30-41-11	ALL
	PERG	1F	W0210	2003ZI			30-41-11	ALL
	PERG	1F	W0210	2003ZO			30-41-11	ALL
	PERG	1F	W0210	2006ZI			30-41-11	ALL
	PERG	1F	W0210	2006ZO			30-41-11	ALL
	PERG	1F	W0210	3001ZI			30-41-11	ALL
	PERG	1F	W0210	3001ZO			30-41-11	ALL
D40070P		**E002-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W2108	1004	20		30-41-11	ALL
	A04	UNUSED						ALL
	A05		W2108	2003R	20		30-41-11	ALL
	A06		W2108	2003B	20		30-41-11	ALL
	A07		W2108	3001R	20		30-41-11	ALL
	A08		W2108	3001B	20		30-41-11	ALL
	A09		W2108	3001Y	20		30-41-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W2108	2002B	20		30-41-11	ALL
	B06		W2108	2002R	20		30-41-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40070P		**E002-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	F		W2108	1001	18		30-41-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W2108	1001Z			30-41-11	ALL
	PERG	1F	W2108	1004Z			30-41-11	ALL
	PERG	1F	W2108	2002Z			30-41-11	ALL
	PERG	1F	W2108	2003Z			30-41-11	ALL
	PERG	1F	W2108	3001Z			30-41-11	ALL
	PERG	1F	W2108	YAAA			30-41-11	ALL
D40072P		**361/293/R028**		**PLUG-**				**ALL**
	1		W4250	0921	20		33-25-31	ALL
	2		W4250	0922	20		33-25-31	ALL
	3	UNUSED						ALL
D40078J		**AB0410/205/R039**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W6208	0010	20		22-13-11	ALL
	A03		W6208	0011	20		22-13-11	ALL
	A04	UNUSED						ALL
	A05		W6208	3002R	20		27-11-11	ALL
	A06		W6208	3002B	20		27-11-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6208	0009	20		22-13-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40078J		**AB0410/205/R039**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6208	3002Y	20		27-11-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40078P		**AB0410/205/R039**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W6222	0010	20		22-13-11	ALL
	A03		W6222	0011	20		22-13-11	ALL
	A04	UNUSED						ALL
	A05		W6222	3203R	20		27-11-11	ALL
	A06		W6222	3203B	20		27-11-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6222	0009	20		22-13-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6222	3203Y	20		27-11-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40079J		**AB0410/205/R039**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5248	2409R	20		52-71-11	ALL
	A05		W5248	2444R	20		52-71-11	ALL
	A06		W5248	0046	20		52-71-12	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5248	2409B	20		52-71-11	ALL
	B05		W5248	2444B	20		52-71-11	ALL
	B06		W5248	0056	20		52-71-12	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40079P		**AB0410/205/R039**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5160	2409R	22		52-71-11	ALL
	A05		W5160	2444R	22		52-71-11	ALL
	A06		W5160	0046	22		52-71-12	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40079P		**AB0410/205/R039**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5160	2409B	22		52-71-11	ALL
	B05		W5160	2444B	22		52-71-11	ALL
	B06		W5160	0056	22		52-71-12	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40084J		**AB0340B/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W4258	0087	20		33-25-32	ALL
	8		W4258	0088	20		33-25-31	ALL
	9		W4258	0089	20		33-25-32	ALL
	10		W4258	0086	20		33-25-31	ALL
D40084P		**AB0340B/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40084P		**AB0340B/ /**		**PLUG- (continued)**				**ALL**
	6	UNUSED						ALL
	7		W4250	0907	20		33-25-32	ALL
	8		W4250	0908	20		33-25-31	ALL
	9		W4250	0909	20		33-25-32	ALL
	10		W4250	0919	20		33-25-31	ALL
D40087J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0088	0193	22		30-31-11	ALL
	A04		W0088	0044	22		30-31-11	ALL
	A05		W0088	0045	22		30-31-11	ALL
	A06		W0088	0046	22		30-31-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40087P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40087P		**J048-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A03		W5501	0014	22		30-31-11	ALL
	A04		W5501	0008	22		30-31-11	ALL
	A05		W5501	0011	22		30-31-11	ALL
	A06		W5501	0012	22		30-31-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40093J		**AB0410/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6586	0012	20		33-42-21	ALL
	A06		W6586	0014	20		33-42-21	ALL
	A07		W6586	0004	20		33-43-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40093J		**AB0410/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6586	0013	20		33-42-21	ALL
	B06		W6586	0015	20		33-42-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40093P		**AB0410/205/R039**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2218	0083	20		33-42-21	ALL
	A06		W2218	0085	20		33-42-21	ALL
	A07		W2218	0038	20		33-43-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W2218	0084	20		33-42-21	ALL
	B06		W2218	0086	20		33-42-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40093P		**AB0410/205/R039**		**PLUG- (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40095J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0062	22		34-51-41	ALL
	A02		W0088	0063	22		34-53-11	ALL
	A03		W0088	0068	22		34-55-11	ALL
	A04		W0088	0067	22		34-55-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40095P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2149	0015	22		34-51-41	ALL
	A02		W2149	0022	22		34-53-11	ALL
	A03		W2149	0013	22		34-55-11	ALL
	A04		W2149	0035	22		34-55-11	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40095P		**J048-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40096J		**AB0340B/ /**		**RCPT-**				**ALL**
	1	16	W4142	0041	16		33-51-12	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	16	W4142	0010	16		33-51-21	ALL
	5		W4142	0093	20		52-71-13	ALL
	6		W4142	0110	20		33-51-21	ALL
	7		W4142	0094	20		52-71-13	ALL
	8		W4142	0096	20		52-71-14	ALL
	9		W4142	0025	20		52-71-13	ALL
	10		W4142	0026	20		52-71-13	ALL
	11		W4142	0058	22		33-51-11	ALL
	12		W4142	0434	20		52-71-14	ALL
	13		W4142	0060	20		33-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40096J	**AB0340B/ /**		**RCPT- (continued)**				**ALL**
14		W4142	0057	22		33-51-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D40096P	**AB0340B/ /**		**PLUG-**				**ALL**
1	16	W3142	0111	16		33-51-12	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	16	W3142	0190	16		33-51-21	ALL
5		W3142	0464	20		52-71-13	ALL
6		W3142	0275	20		33-51-21	ALL
7		W3142	0466	20		52-71-13	ALL
8		W3142	0098	20		52-71-14	ALL
9		W3142	0434	20		52-71-13	ALL
10		W3142	0436	20		52-71-13	ALL
11		W3142	0504	22		33-51-11	ALL
12		W3142	0405	20		52-71-14	ALL
13		W3142	0526	20		33-51-11	ALL
14		W3142	0503	22		33-51-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40096P		**AB0340B/ /**		**PLUG- (continued)**				**ALL**
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D40097J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0420	22		30-31-12	ALL
	A02		W0066	0108	22		30-31-12	ALL
	A03		W0066	0109	22		30-31-12	ALL
	A04		W0066	0422	22		30-31-12	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0066	0358	22		21-33-11	ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40097P	**J046-00/ /**		**PLUG-**				**ALL**
A01		W5503	0012	22		30-31-12	ALL
A02		W5503	0003	22		30-31-12	ALL
A03		W5503	0004	22		30-31-12	ALL
A04		W5503	0010	22		30-31-12	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W5503	0018	22		21-33-11	ALL
B10	UNUSED						ALL
D40098J	**608/295/R036**		**RCPT, RECTANGULAR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W3142	0072	20		33-51-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W3142	0057	20		33-51-13	ALL
7	UNUSED						ALL
8		W3142	0080	20		33-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40098P		**609/295/R036**		**PLUG, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W4142	0312	20		33-51-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W4142	0309	20		33-51-13	ALL
	7	UNUSED						ALL
	8		W4142	0084	20		33-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40102J	**AB0340A/ /**		**RCPT-**				**ALL**
1		W3158	2405B	18		33-23-12	ALL
2		W3158	2402R	18		33-23-12	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W3158	2405R	18		33-23-12	ALL
6		W3158	0206	18		33-35-11	ALL
7		W3158	2408B	18		33-23-11	ALL
8		W3158	2408R	18		33-23-11	ALL
9		W3158	2402B	18		33-23-12	ALL
10		W3158	2410R	18		33-23-11	ALL
11		W3158	2401R	18		33-23-12	ALL
12	UNUSED						ALL
13		W3158	0513	18		33-22-11	ALL
14		W3158	0414	18		33-22-11	ALL
15		W3158	2415R	18		33-23-12	ALL
16		W3158	2415B	18		33-23-12	ALL
17		W3158	2407B	18		33-23-11	ALL
18		W3158	2407R	18		33-23-11	ALL
19		W3158	2409B	18		33-23-11	ALL
20		W3158	2409R	18		33-23-11	ALL
21		W3158	2411B	18		33-23-12	ALL
22		W3158	2411R	18		33-23-12	ALL
23		W3158	2410B	18		33-23-11	ALL
24		W3158	2401B	18		33-23-12	ALL
25	UNUSED						ALL
26		W3158	0426	18		33-22-11	ALL
27		W3158	0422	18		33-22-11	ALL
28	UNUSED						ALL
29		W3158	5501	22		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40102J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	30		W3158	5502	22		21-42-11	ALL
D40102P		**AB0340A/ /**		**PLUG-**				**ALL**
	1		W5142	2436B	18		33-23-12	ALL
	2		W5142	2434R	18		33-23-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5142	2436R	18		33-23-12	ALL
	6		W5142	0040	18		33-35-11	ALL
	7		W5142	2429B	18		33-23-11	ALL
	8		W5142	2429R	18		33-23-11	ALL
	9		W5142	2434B	18		33-23-12	ALL
	10		W5142	2431R	18		33-23-11	ALL
	11		W5142	2433R	18		33-23-12	ALL
	12	UNUSED						ALL
	13		W5142	0051	18		33-22-11	ALL
	14		W5142	0052	18		33-22-11	ALL
	15		W5142	2435R	18		33-23-12	ALL
	16		W5142	2435B	18		33-23-12	ALL
	17		W5142	2428B	18		33-23-11	ALL
	18		W5142	2428R	18		33-23-11	ALL
	19		W5142	2430B	18		33-23-11	ALL
	20		W5142	2430R	18		33-23-11	ALL
	21		W5142	2432B	18		33-23-12	ALL
	22		W5142	2432R	18		33-23-12	ALL
	23		W5142	2431B	18		33-23-11	ALL
	24		W5142	2433B	18		33-23-12	ALL
	25	UNUSED						ALL
	26		W5142	0089	18		33-22-11	ALL
	27		W5142	0091	18		33-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40102P		**AB0340A/ /**		**PLUG- (continued)**				**ALL**
	28	UNUSED						ALL
	29		W5142	5516	22		21-42-11	ALL
	30		W5142	5517	22		21-42-11	ALL
D40103J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0152	22		34-53-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0066	0158	22		34-53-31	ALL
	A05		W0066	0157	22		34-53-31	ALL
	A06		W0066	0153	22		34-53-31	ALL
	A07		W0066	0154	22		34-53-31	ALL
	A08		W0066	0155	22		34-53-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40103P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W2247	0024	22		34-53-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2247	0027	22		34-53-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40103P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	A05		W2247	0014	22		34-53-31	ALL
	A06		W2247	0005	22		34-53-31	ALL
	A07		W2247	0025	22		34-53-31	ALL
	A08		W2247	0026	22		34-53-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40104J		**430/300/L017**		**RCPT, RECTANGULAR**				**ALL**
	1		W3150	2692R	18		33-23-11	ALL
	2		W3150	2692B	18		33-23-11	ALL
	3		W3150	2694B	18		33-23-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W3150	2693R	18		33-23-11	ALL
	7		W3150	0937	20		33-25-21	ALL
	8		W3150	2694R	18		33-23-11	ALL
	9		W3150	0931	20		33-25-21	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W3150	2693B	18		33-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40104J	**430/300/L017**		**RCPT, RECTANGULAR (continued)**				**ALL**
13		W3150	2695R	18		33-23-11	ALL
14		W3150	2695B	18		33-23-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
D40104P	**430/300/L018**		**PLUG, RECTANGULAR**				**ALL**
1		W3158	2407R	18		33-23-11	ALL
2		W3158	2407B	18		33-23-11	ALL
3		W3158	2409B	18		33-23-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W3158	2408R	18		33-23-11	ALL
7		W3158	0087	20		33-25-21	ALL
8		W3158	2409R	18		33-23-11	ALL
9		W3158	0089	20		33-25-21	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W3158	2408B	18		33-23-11	ALL
13		W3158	2410R	18		33-23-11	ALL
14		W3158	2410B	18		33-23-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
D40108J	**AB0340A/ /**		**RCPT-**				**ALL**
1		W3158	0101	20		SPARE	ALL
2		W3158	0102	20		SPARE	ALL
3	UNUSED						ALL
4		W3158	0116	22		38-21-11	ALL
5		W3158	0117	22		38-21-11	ALL
6		W3158	0106	20		33-25-21	ALL
7		W3158	0107	20		33-25-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40108J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	8		W3158	0108	20		33-25-21	ALL
	9		W3158	0109	20		33-25-22	ALL
	10	UNUSED						ALL
	11		W3158	0111	20		SPARE	ALL
	12		W3158	0112	20		SPARE	ALL
	13	UNUSED						ALL
	14		W3158	0110	20		33-25-11	ALL
D40108P		**AB0340A/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W3150	0111	22		38-21-11	ALL
	5		W3150	0112	22		38-21-11	ALL
	6		W3150	0919	20		33-25-21	ALL
	7		W3150	0907	20		33-25-22	ALL
	8		W3150	0908	20		33-25-21	ALL
	9		W3150	0909	20		33-25-22	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W3150	0918	20		33-25-11	ALL
D40109J		**672/302/L018**		**RCPT, RECTANGULAR**				**ALL**
	1		W3150	2696R	18		33-23-12	ALL
	2		W3150	2696B	18		33-23-12	ALL
	3		W3150	2698B	18		33-23-12	ALL
	4		W3150	2801R	18		33-23-12	ALL
	5		W3150	2801B	18		33-23-12	ALL
	6		W3150	2697R	18		33-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40109J	**672/302/L018**		**RCPT, RECTANGULAR (continued)**				**ALL**
7		W3150	0947	20		33-25-22	ALL
8		W3150	2698R	18		33-23-12	ALL
9		W3150	0941	20		33-25-22	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W3150	2697B	18		33-23-12	ALL
13		W3150	2802R	18		33-23-12	ALL
14		W3150	2802B	18		33-23-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
D40109P	**673/302/L018**		**PLUG, RECTANGULAR**				**ALL**
1		W3158	2411R	18		33-23-12	ALL
2		W3158	2411B	18		33-23-12	ALL
3		W3158	2402B	18		33-23-12	ALL
4		W3158	2415R	18		33-23-12	ALL
5		W3158	2415B	18		33-23-12	ALL
6		W3158	2401R	18		33-23-12	ALL
7		W3158	0097	20		33-25-22	ALL
8		W3158	2402R	18		33-23-12	ALL
9		W3158	0099	20		33-25-22	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W3158	2401B	18		33-23-12	ALL
13		W3158	2405R	18		33-23-12	ALL
14		W3158	2405B	18		33-23-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
D40111J	**AE0602A/ /**		**RCPT**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40111J		**AE0602A/ /**		**RCPT (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0621	3001R	20		23-11-11	ALL
	7		W0621	3001Y	20		23-11-11	ALL
	8		W0621	3001B	20		23-11-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40111P		**E006-02/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W2101	3001R	20		23-11-11	ALL
	7		W2101	3001Y	20		23-11-11	ALL
	8		W2101	3001B	20		23-11-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40113J		**AE0602A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0621	2506R	24		23-11-11	ALL
	A02	UNUSED						ALL
	A03		W0621	0006	22		23-11-11	ALL
	A04		W0621	2511R	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40113J		**AE0602A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0621	2506B	24		23-11-11	ALL
	B02		W0621	0005	22		23-11-11	ALL
	B03		W0621	0138	24		23-12-41	ALL
	B04		W0621	2511B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40113J		**AE0602A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0621	2506Z			23-11-11	ALL
	PERG	1F	W0621	2511Z			23-12-41	ALL
D40113P		**E006-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5103	2501R	24		23-11-11	ALL
	A02	UNUSED						ALL
	A03		W5103	0003	22		23-11-11	ALL
	A04		W5103	2502R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40113P	**E006-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A20	UNUSED						ALL
B01		W5103	2501B	24		23-11-11	ALL
B02		W5103	0002	22		23-11-11	ALL
B03		W5103	0004	24		23-12-41	ALL
B04		W5103	2502B	24		23-12-41	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5103	2501Z			23-11-11	ALL
PERG	1F	W5103	2502Z			23-12-41	ALL
D40115J	**AE0602A/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0623	2530R	24		23-11-21	ALL
A02	UNUSED						ALL
A03		W0623	0177	22		23-11-21	ALL
A04		W0623	2510R	24		23-12-41	ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40115J		**AE0602A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0623	2530B	24		23-11-21	ALL
	B02		W0623	0176	22		23-11-21	ALL
	B03		W0623	0178	24		23-12-41	ALL
	B04		W0623	2510B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40115J		**AE0602A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0623	2510Z			23-12-41	ALL
	PERG	1F	W0623	2530Z			23-11-21	ALL
D40115P		**E006-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5105	2501R	24		23-11-21	ALL
	A02	UNUSED						ALL
	A03		W5105	0003	22		23-11-21	ALL
	A04		W5105	2502R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40115P		**E006-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B01		W5105	2501B	24		23-11-21	ALL
	B02		W5105	0002	22		23-11-21	ALL
	B03		W5105	0004	24		23-12-41	ALL
	B04		W5105	2502B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5105	2501Z			23-11-21	ALL
	PERG	1F	W5105	2502Z			23-12-41	ALL
D40116J		**900/298/L026**		**RCPT, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W3144	0090	20		33-25-11	ALL
	6		W3144	0338	22		38-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40116J	**900/298/L026**		**RCPT, RECTANGULAR (continued)**				**ALL**
7		W3144	5507	22		21-42-11	ALL
8		W3144	5502	22		21-42-11	ALL
9		W3144	0096	20		33-25-22	ALL
10		W3144	0095	20		33-25-22	ALL
11	UNUSED						ALL
12		W3144	0388	22		38-21-11	ALL
D40116P	**900/298/L026**		**PLUG, RECTANGULAR**				**ALL**
1		W3158	0111	20		SPARE	ALL
2	UNUSED						ALL
3		W3158	0112	20		SPARE	ALL
4	UNUSED						ALL
5		W3158	0053	20		33-25-11	ALL
6		W3158	0116	22		38-21-11	ALL
7		W3158	5501	22		21-42-11	ALL
8		W3158	5502	22		21-42-11	ALL
9		W3158	0052	20		33-25-22	ALL
10		W3158	0051	20		33-25-22	ALL
11	UNUSED						ALL
12		W3158	0117	22		38-21-11	ALL
D40117J	**AE0602A/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0621	2501R	24		23-11-11	ALL
A02		W0621	2501ZI			23-11-11	ALL
A03		W0621	2020R	24		23-22-11	ALL
A04		W0621	2020ZI			23-22-11	ALL
A05	UNUSED						ALL
A06		W0621	2502R	24		23-11-11	ALL
A07		W0621	2502ZI			23-11-11	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40117J		**AE0602A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A10		W0621	0019	22		23-11-11	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0621	2501B	24		23-11-11	ALL
	B02	UNUSED						ALL
	B03		W0621	2020B	24		23-22-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0621	2502B	24		23-11-11	ALL
	B07		W0621	0085	24		31-31-17	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40117J		**AE0602A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0621	2020ZO			23-22-11	ALL
	PERG	1F	W0621	2501ZO			23-11-11	ALL
	PERG	1F	W0621	2502ZO			23-11-11	ALL
D40117P		**E006-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5189	2512R	24		23-11-11	ALL
	A02		W5189	2512ZI			23-11-11	ALL
	A03		W5189	2535R	24		23-22-11	ALL
	A04		W5189	2535ZI			23-22-11	ALL
	A05	UNUSED						ALL
	A06		W5189	2513R	24		23-11-11	ALL
	A07		W5189	2513ZI			23-11-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5189	0022	22		23-11-11	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5189	2512B	24		23-11-11	ALL
	B02		W5189	0055	22		SPARE	ALL
	B03		W5189	2535B	24		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40117P		**E006-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5189	2513B	24		23-11-11	ALL
	B07		W5189	0021	24		31-31-17	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5189	2512ZO			23-11-11	ALL
	PERG	1F	W5189	2513ZO			23-11-11	ALL
	PERG	1F	W5189	2535ZO			23-22-11	ALL
D40118J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0220	0025	20		33-44-12	ALL
	A02		W0220	0142	20		33-43-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0220	0509	20		33-42-21	ALL
	A06		W0220	0510	20		33-42-21	ALL
	A07		W0220	0414	22		30-11-11	ALL
	A08		W0220	0511	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40118J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A09		W0220	0512	20		33-42-21	ALL
	A10		W0220	0413	22		30-11-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0220	1042	22		30-11-11	ALL
	F		W0220	0016	18		33-42-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0220	1042Z			30-11-11	ALL
D40118P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5566	0002	20		33-44-12	ALL
	A02		W5566	0004	20		33-43-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5566	0010	20		33-42-21	ALL
	A06		W5566	0011	20		33-42-21	ALL
	A07		W5566	0015	20		30-11-11	ALL
	A08		W5566	0012	20		33-42-21	ALL
	A09		W5566	0013	20		33-42-21	ALL
	A10		W5566	0014	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40118P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5566	1001	20		30-11-11	ALL
	F		W5566	0003	18		33-42-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5566	1001Z			30-11-11	ALL
D40119J		**AE0602A/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0623	2517R	24		23-11-21	ALL
	A02		W0623	2517ZI			23-11-21	ALL
	A03		W0623	2516R	24		23-11-21	ALL
	A04		W0623	2516ZI			23-11-21	ALL
	A05		W0623	2021R	24		23-22-11	ALL
	A06		W0623	2021ZI			23-22-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0623	2517B	24		23-11-21	ALL
	B02		W0623	0174	22		23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40119J	**AE0602A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B03		W0623	2516B	24		23-11-21	ALL
B04		W0623	0086	24		31-31-17	ALL
B05		W0623	2021B	24		23-22-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0623	2021ZO			23-22-11	ALL
PERG	1F	W0623	2516ZO			23-11-21	ALL
PERG	1F	W0623	2517ZO			23-11-21	ALL
D40119P	**E006-02/ /**		**PLUG-E6-2 SHELF**				**ALL**
A01		W5191	2518R	24		23-11-21	ALL
A02		W5191	2518ZI			23-11-21	ALL
A03		W5191	2519R	24		23-11-21	ALL
A04		W5191	2519ZI			23-11-21	ALL
A05		W5191	2525R	24		23-22-11	ALL
A06		W5191	2525ZI			23-22-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5191	2518B	24		23-11-21	ALL
B02		W5191	0009	22		23-11-21	ALL
B03		W5191	2519B	24		23-11-21	ALL
B04		W5191	0020	24		31-31-17	ALL
B05		W5191	2525B	24		23-22-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40119P		**E006-02/ /**		**PLUG-E6-2 SHELF (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5191	2518ZO			23-11-21	ALL
	PERG	1F	W5191	2519ZO			23-11-21	ALL
	PERG	1F	W5191	2525ZO			23-22-11	ALL
D40120J		**E001-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0111	0956	22		34-33-11	ALL
	A03		W0111	0961	22		22-11-18	ALL
	A04		W0111	2184B	24		27-81-11	ALL
	A05		W0111	2185B	24		27-81-11	ALL
	A06		W0111	2186B	24		27-81-11	ALL
	A07		W0111	2187B	24		27-81-11	ALL
	A08		W0111	2057R	24		34-33-11	ALL
	A09		W0111	2066R	24		34-33-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0111	2184R	24		27-81-11	ALL
	B05		W0111	2185R	24		27-81-11	ALL
	B06		W0111	2186R	24		27-81-11	ALL
	B07		W0111	2187R	24		27-81-11	ALL
	B08		W0111	2057B	24		34-33-11	ALL
	B09		W0111	2066B	24		34-33-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W0111	2057Z			34-33-11	ALL
	PERG	1F	W0111	2066Z			34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40120P	**E001-01/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02		W5568	0022	22		34-33-11	ALL
A03		W5568	0021	22		22-11-18	ALL
A04		W5568	2201B	20		27-81-11	ALL
A05		W5568	2202B	20		27-81-11	ALL
A06		W5568	2203B	20		27-81-11	ALL
A07		W5568	2204B	20		27-81-11	ALL
A08		W5568	2502R	24		34-33-11	ALL
A09		W5568	2503R	24		34-33-11	ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5568	2201R	20		27-81-11	ALL
B05		W5568	2202R	20		27-81-11	ALL
B06		W5568	2203R	20		27-81-11	ALL
B07		W5568	2204R	20		27-81-11	ALL
B08		W5568	2502B	24		34-33-11	ALL
B09		W5568	2503B	24		34-33-11	ALL
B10	UNUSED						ALL
PERG	1F	W5568	2502Z			34-33-11	ALL
PERG	1F	W5568	2503Z			34-33-11	ALL
D40121J	**AE0602A/ /**		**RCPT-**				**ALL**
A01		W0621	0017	22		23-11-11	ALL
A02		W0621	0014	22		23-11-11	ALL
A03	UNUSED						ALL
A04		W0621	0021	22		23-11-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40121J		**AE0602A/ /**		**RCPT- (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0621	0016	22		23-11-11	ALL
	B02	UNUSED						ALL
	B03		W0621	0015	22		23-11-11	ALL
	B04		W0621	0022	22		23-11-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0621	0009	18		23-11-11	ALL
	G		W0621	0011	20		23-11-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40121P		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W3553	0005	22		23-11-11	ALL
	A02		W3553	0008	22		23-11-11	ALL
	A03	UNUSED						ALL
	A04		W3553	0012	20		23-11-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40121P		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	A10	UNUSED						ALL
	B01		W3553	0007	22		23-11-11	ALL
	B02	UNUSED						ALL
	B03		W3553	0011	22		23-11-11	ALL
	B04		W3553	0013	20		23-11-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W3553	0016	18		23-11-11	ALL
	G		W3553	0014	20		23-11-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40122J		**E001-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0111	2148B	24		27-81-12	ALL
	A02		W0111	2147B	24		27-81-12	ALL
	A03		W0111	2149B	24		27-81-12	ALL
	A04		W0111	2150B	24		27-81-12	ALL
	A05		W0111	2151B	24		27-81-12	ALL
	A06		W0111	2145B	24		27-81-12	ALL
	A07		W0111	2144B	24		27-81-12	ALL
	A08		W0111	2146B	24		27-81-12	ALL
	A09		W0111	0598	20		26-12-11	ALL
	A10	UNUSED						ALL
	A11		W0111	2179R	24		27-81-12	ALL
	A12		W0111	2180R	24		27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40122J		**E001-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A13		W0111	2181R	24		27-81-12	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0111	2148R	24		27-81-12	ALL
	B02		W0111	2147R	24		27-81-12	ALL
	B03		W0111	2149R	24		27-81-12	ALL
	B04		W0111	2150R	24		27-81-12	ALL
	B05		W0111	2151R	24		27-81-12	ALL
	B06		W0111	2145R	24		27-81-12	ALL
	B07		W0111	2144R	24		27-81-12	ALL
	B08		W0111	2146R	24		27-81-12	ALL
	B09		W0111	0348	22		30-11-11	ALL
	B10	UNUSED						ALL
	B11		W0111	2179B	24		27-81-12	ALL
	B12		W0111	2180B	24		27-81-12	ALL
	B13		W0111	2181B	24		27-81-12	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40122P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5166	2202B	24		27-81-12	ALL
A02		W5166	2204B	24		27-81-12	ALL
A03		W5166	2205B	24		27-81-12	ALL
A04		W5166	2206B	24		27-81-12	ALL
A05		W5166	2207B	24		27-81-12	ALL
A06		W5166	2208B	24		27-81-12	ALL
A07		W5166	2211B	24		27-81-12	ALL
A08		W5166	2212B	24		27-81-12	ALL
A09		W5166	6004R	20		26-12-11	ALL
A10	UNUSED						ALL
A11		W5166	2213R	24		27-81-12	ALL
A12		W5166	2214R	24		27-81-12	ALL
A13		W5166	2215R	24		27-81-12	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5166	2202R	24		27-81-12	ALL
B02		W5166	2204R	24		27-81-12	ALL
B03		W5166	2205R	24		27-81-12	ALL
B04		W5166	2206R	24		27-81-12	ALL
B05		W5166	2207R	24		27-81-12	ALL
B06		W5166	2208R	24		27-81-12	ALL
B07		W5166	2211R	24		27-81-12	ALL
B08		W5166	2212R	24		27-81-12	ALL
B09		W5166	0120	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40122P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11		W5166	2213B	24		27-81-12	ALL
	B12		W5166	2214B	24		27-81-12	ALL
	B13		W5166	2215B	24		27-81-12	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40123J		**AE0602A/ /**		**JACK**				**ALL**
	=A1		W0621	001CX			23-11-11	ALL
	=C1		W0621	001CO			23-11-11	ALL
D40123P		**AE0602A/ /**		**PLUG-**				**ALL**
	=A1		W3557	001CX			23-11-11	ALL
	=C1		W3557	001CO			23-11-11	ALL
D40125J		**AE0602A/ /**		**RCPT-**				**ALL**
	A01		W0623	0172	22		23-11-21	ALL
	A02		W0623	0173	22		23-11-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0623	0171	22		23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40125J		**AE0602A/ /**		**RCPT- (continued)**				**ALL**
	B02	UNUSED						ALL
	B03		W0623	0170	22		23-11-21	ALL
	B04		W0623	0183	22		23-11-21	ALL
	B05		W0623	0182	22		23-11-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0623	0168	18		23-11-21	ALL
	G		W0623	0169	20		23-11-21	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40125P		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W3555	0005	22		23-11-21	ALL
	A02		W3555	0008	22		23-11-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W3555	0007	22		23-11-21	ALL
	B02	UNUSED						ALL
	B03		W3555	0011	22		23-11-21	ALL
	B04		W3555	0012	20		23-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40125P		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	B05		W3555	0013	20		23-11-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W3555	0016	18		23-11-21	ALL
	G		W3555	0014	20		23-11-21	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40126J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0220	0346R	20		26-11-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0220	2032B	24		73-24-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40126J	**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0220	0345R	20		26-11-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0220	2032R	24		73-24-11	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0220	2032Z			73-24-11	ALL
D40126P	**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40126P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W3170	1301R	20		26-11-11	ALL
	A10	UNUSED						ALL
	A11		W3170	2607B	20		SPARE	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W3170	2610B	24		73-24-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W3170	1302R	20		26-11-11	ALL
	B10	UNUSED						ALL
	B11		W3170	2607R	20		SPARE	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40126P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B14		W3170	2610R	24		73-24-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W3170	1301Z			26-11-11	ALL
	PERG	1F	W3170	1302Z			26-11-11	ALL
	PERG	1F	W3170	2607Z			SPARE	ALL
	PERG	1F	W3170	2610Z			73-24-11	ALL
D40127J		**AE0602A/ /**		**JACK**				**ALL**
	=A1		W0623	002CX			23-11-21	ALL
	=C1		W0623	002CO			23-11-21	ALL
D40127P		**AE0602A/ /**		**PLUG-**				**ALL**
	=A1		W3559	001CX			23-11-21	ALL
	=C1		W3559	001CO			23-11-21	ALL
D40130J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0220	2046B	24		73-24-11	ALL
	A06		W0220	2030B	24		73-21-11	ALL
	A07		W0220	2052R	20		78-32-51	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0220	2035B	24		73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40130J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0220	2046R	24		73-24-11	ALL
	B06		W0220	2030R	24		73-21-11	ALL
	B07		W0220	2052B	20		78-32-51	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0220	2035R	24		73-24-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40130J	**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0220	2030Z			73-21-11	ALL
PERG	1F	W0220	2035Z			73-24-12	ALL
PERG	1F	W0220	2046Z			73-24-11	ALL
PERG	1F	W0220	2052Z			78-32-51	ALL
D40130P	**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W5162	2604B	24		73-24-11	ALL
A06		W5162	2606B	24		73-21-11	ALL
A07		W5162	2201R	20		78-32-51	ALL
A08	UNUSED						ALL
A09		W5162	2609B	20		SPARE	ALL
A10	UNUSED						ALL
A11		W5162	2611B	24		73-24-12	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40130P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B05		W5162	2604R	24		73-24-11	ALL
	B06		W5162	2606R	24		73-21-11	ALL
	B07		W5162	2201B	20		78-32-51	ALL
	B08	UNUSED						ALL
	B09		W5162	2609R	20		SPARE	ALL
	B10	UNUSED						ALL
	B11		W5162	2611R	24		73-24-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5162	2201Z			78-32-51	ALL
	PERG	1F	W5162	2604Z			73-24-11	ALL
	PERG	1F	W5162	2606Z			73-21-11	ALL
	PERG	1F	W5162	2609Z			SPARE	ALL
	PERG	1F	W5162	2611Z			73-24-12	ALL
D40132J		**E002-01/ /**		**RCPT-CONDUCTIVE-W/ BACKSHELL-ZERO-LENGTH**				**ALL**
	A01		W0212	4003G	22		24-24-11	ALL
	A02		W0212	4003B	22		24-24-11	ALL
	A03		W0212	2001R	22		24-11-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40132J	**E002-01/ /**		**RCPT-CONDUCTIVE-W/ BACKSHELL-ZERO-LENGTH (continued)**				**ALL**
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0212	4003Y	22		24-24-11	ALL
B02		W0212	4003R	22		24-24-11	ALL
B03		W0212	2001B	22		24-11-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W0212	3001R	18		24-21-11	ALL
G		W0212	3001B	18		24-21-11	ALL
H		W0212	3001Y	18		24-21-11	ALL
J		W0212	2002R	20		24-21-11	ALL
K		W0212	2002B	20		24-21-11	ALL
PERB		W0212	2001Z			24-11-11	ALL
PERB		W0212	2002Z			24-21-11	ALL
PERB		W0212	3001Z			24-21-11	ALL
PERB		W0212	4003Z			24-24-11	ALL
D40132P	**E002-01/ /**		**PLUG-CONDUCTIVE (BACKSHELL-ZERO LENGTH).**				**ALL**
A01		W5164	4101G	20		24-24-11	ALL
A02		W5164	4101B	20		24-24-11	ALL
A03		W5164	2202R	22		24-11-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40132P		**E002-01/ /**		**PLUG-CONDUCTIVE (BACKSHELL-ZERO LENGTH). (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5164	4101Y	20		24-24-11	ALL
	B02		W5164	4101R	20		24-24-11	ALL
	B03		W5164	2202B	22		24-11-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5164	3201R	18		24-21-11	ALL
	G		W5164	3201B	18		24-21-11	ALL
	H		W5164	3201Y	18		24-21-11	ALL
	J		W5164	2201R	20		24-21-11	ALL
	K		W5164	2201B	20		24-21-11	ALL
	PERB		W5164	2201Z			24-21-11	ALL
	PERB		W5164	2202Z			24-11-11	ALL
	PERB		W5164	3201Z			24-21-11	ALL
	PERB		W5164	4101Z			24-24-11	ALL
D40133J		**E001-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40133J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A06	UNUSED						ALL
	A07		W0111	0881	24		34-49-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0111	0882	24		34-49-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40133P		**E001-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W2221	0120	24		34-49-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W2221	0121	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40133P		**E001-01/ /**		**PLUG- (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40138J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0220	1005	20		74-11-11	ALL
	A02		W0220	0331R	20		26-12-11	ALL
	A03	UNUSED						ALL
	A04		W0220	0348R	20		26-11-11	ALL
	A05		W0220	1061	20		30-21-31	ALL
	A06		W0220	0349	22		30-21-31	ALL
	A07		W0220	1004	20		73-22-11	ALL
	A08		W0220	2037B	24		77-12-21	ALL
	A09		W0220	0215	20		76-21-11	ALL
	A10	UNUSED						ALL
	B01		W0220	0414R	20		26-12-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0220	0347R	20		26-11-11	ALL
	B05		W0220	0400	22		30-21-31	ALL
	B06		W0220	0410	22		30-21-31	ALL
	B07		W0220	1065	24		73-21-12	ALL
	B08		W0220	2037R	24		77-12-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40138J	**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W0220	1004Z			73-22-11	ALL
PERG	1F	W0220	1005Z			74-11-11	ALL
PERG	1F	W0220	1061Z			30-21-31	ALL
PERG	1F	W0220	1065Z			73-21-12	ALL
PERG	1F	W0220	2037Z			77-12-21	ALL
D40138P	**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5168	1302	20		74-11-11	ALL
A02		W5168	6005R	20		26-12-11	ALL
A03	UNUSED						ALL
A04		W5168	6003R	20		26-11-11	ALL
A05		W5168	1201	20		30-21-31	ALL
A06		W5168	0006	22		30-21-31	ALL
A07		W5168	1301	20		73-22-11	ALL
A08		W5168	2603B	24		77-12-21	ALL
A09		W5168	6001	20		76-21-11	ALL
A10	UNUSED						ALL
B01		W5168	0100R	20		26-12-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5168	6004R	20		26-11-11	ALL
B05		W5168	0007	22		30-21-31	ALL
B06		W5168	0008	22		30-21-31	ALL
B07		W5168	1303	24		73-21-12	ALL
B08		W5168	2603R	24		77-12-21	ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40138P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5168	1201Z			30-21-31	ALL
	PERG	1F	W5168	1301Z			73-22-11	ALL
	PERG	1F	W5168	1302Z			74-11-11	ALL
	PERG	1F	W5168	1303Z			73-21-12	ALL
	PERG	1F	W5168	2603Z			77-12-21	ALL
D40140J		**E004-02/ /**		**RCPT-CONDUCTIVE BY BACKSHELL ZERO LENGTH**				**ALL**
	A01	UNUSED						ALL
	A02		W0422	2004B	22		24-11-21	ALL
	A03		W0422	4002B	22		24-24-21	ALL
	A04		W0422	4002R	22		24-24-21	ALL
	A05		W0422	2002R	20		24-21-21	ALL
	A06		W0422	2002B	20		24-21-21	ALL
	A07	UNUSED						ALL
	A08		W0422	0072	20		28-21-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0422	2004R	22		24-11-21	ALL
	B03		W0422	4002G	22		24-24-21	ALL
	B04		W0422	4002Y	22		24-24-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40140J	**E004-02/ /**		**RCPT-CONDUCTIVE BY BACKSHELL ZERO LENGTH (continued)**				**ALL**
B08		W0422	0052	22		29-11-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G		W0422	3001B	18		24-21-21	ALL
H		W0422	3001R	18		24-21-21	ALL
J		W0422	3001Y	18		24-21-21	ALL
K		W0422	0082	18		24-11-21	ALL
PERB		W0422	2002Z			24-21-21	ALL
PERB		W0422	2004Z			24-11-21	ALL
PERB		W0422	3001Z			24-21-21	ALL
PERB		W0422	4002Z			24-24-21	ALL
D40140P	**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
A01	UNUSED						ALL
A02		W6164	2202B	22		24-11-21	ALL
A03		W6164	4101B	20		24-24-21	ALL
A04		W6164	4101R	20		24-24-21	ALL
A05		W6164	2201R	20		24-21-21	ALL
A06		W6164	2201B	20		24-21-21	ALL
A07	UNUSED						ALL
A08		W6164	1301	20		28-21-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02		W6164	2202R	22		24-11-21	ALL
B03		W6164	4101G	20		24-24-21	ALL
B04		W6164	4101Y	20		24-24-21	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40140P		**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W6164	0501	22		29-11-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W6164	3201B	18		24-21-21	ALL
	H		W6164	3201R	18		24-21-21	ALL
	J		W6164	3201Y	18		24-21-21	ALL
	K		W6164	1101	18		24-11-21	ALL
	PERB		W6164	1101Z			24-11-21	ALL
	PERB		W6164	1301Z			28-21-11	ALL
	PERB		W6164	2201Z			24-21-21	ALL
	PERB		W6164	2202Z			24-11-21	ALL
	PERB		W6164	3201Z			24-21-21	ALL
	PERB		W6164	4101Z			24-24-21	ALL
D40142J		**E001-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0111	2160B	24		27-81-22	ALL
	A02		W0111	2159B	24		27-81-22	ALL
	A03		W0111	2161B	24		27-81-22	ALL
	A04		W0111	2162B	24		27-81-22	ALL
	A05		W0111	2164B	24		27-81-22	ALL
	A06		W0111	2157B	24		27-81-22	ALL
	A07		W0111	2156B	24		27-81-22	ALL
	A08		W0111	2158B	24		27-81-22	ALL
	A09	UNUSED						ALL
	A10		W0111	0597	20		26-12-11	ALL
	B01		W0111	2160R	24		27-81-22	ALL
	B02		W0111	2159R	24		27-81-22	ALL
	B03		W0111	2161R	24		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40142J	**E001-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B04		W0111	2162R	24		27-81-22	ALL
B05		W0111	2164R	24		27-81-22	ALL
B06		W0111	2157R	24		27-81-22	ALL
B07		W0111	2156R	24		27-81-22	ALL
B08		W0111	2158R	24		27-81-22	ALL
B09	UNUSED						ALL
B10		W0111	0349	22		30-11-11	ALL
D40142P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W6166	2202B	24		27-81-22	ALL
A02		W6166	2204B	24		27-81-22	ALL
A03		W6166	2205B	24		27-81-22	ALL
A04		W6166	2206B	24		27-81-22	ALL
A05		W6166	2207B	24		27-81-22	ALL
A06		W6166	2208B	24		27-81-22	ALL
A07		W6166	2211B	24		27-81-22	ALL
A08		W6166	2212B	24		27-81-22	ALL
A09	UNUSED						ALL
A10		W6166	6004R	20		26-12-11	ALL
B01		W6166	2202R	24		27-81-22	ALL
B02		W6166	2204R	24		27-81-22	ALL
B03		W6166	2205R	24		27-81-22	ALL
B04		W6166	2206R	24		27-81-22	ALL
B05		W6166	2207R	24		27-81-22	ALL
B06		W6166	2208R	24		27-81-22	ALL
B07		W6166	2211R	24		27-81-22	ALL
B08		W6166	2212R	24		27-81-22	ALL
B09	UNUSED						ALL
B10		W6166	0120	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40144J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0410	1304R	20		26-11-21	ALL
	A04		W0410	1002	20		74-11-11	ALL
	A05		W0410	0040	20		76-21-21	ALL
	A06		W0410	1001	20		73-22-11	ALL
	A07		W0410	0627	22		30-21-32	ALL
	A08		W0410	1201	20		30-21-32	ALL
	A09		W0410	0624R	20		26-12-11	ALL
	A10		W0410	2008R	24		77-12-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0410	1303R	20		26-11-21	ALL
	B04	UNUSED						ALL
	B05		W0410	0583R	20		26-12-11	ALL
	B06		W0410	0628	22		30-21-32	ALL
	B07		W0410	1080	24		73-21-12	ALL
	B08		W0410	0629	22		30-21-32	ALL
	B09	UNUSED						ALL
	B10		W0410	2008B	24		77-12-21	ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	DED		W0410	1303Z			26-11-21	ALL
	DED		W0410	1304Z			26-11-21	ALL
	PERG	1F	W0410	1001Z			73-22-11	ALL
	PERG	1F	W0410	1002Z			74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40144J	**E004-01/ /**		**RCPT- (continued)**				**ALL**
PERG	1F	W0410	1080Z			73-21-12	ALL
PERG	1F	W0410	1201Z			30-21-32	ALL
PERG	1F	W0410	2008Z			77-12-21	ALL
D40144P	**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W6168	6004R	20		26-11-21	ALL
A04		W6168	1302	20		74-11-11	ALL
A05		W6168	6001	20		76-21-21	ALL
A06		W6168	1301	20		73-22-11	ALL
A07		W6168	0006	22		30-21-32	ALL
A08		W6168	1201	20		30-21-32	ALL
A09		W6168	6003R	20		26-12-11	ALL
A10		W6168	2201R	24		77-12-21	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W6168	6005R	20		26-11-21	ALL
B04	UNUSED						ALL
B05		W6168	6006R	20		26-12-11	ALL
B06		W6168	0007	22		30-21-32	ALL
B07		W6168	1303	24		73-21-12	ALL
B08		W6168	0008	22		30-21-32	ALL
B09	UNUSED						ALL
B10		W6168	2201B	24		77-12-21	ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40144P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W6168	1201Z			30-21-32	ALL
	PERG	1F	W6168	1301Z			73-22-11	ALL
	PERG	1F	W6168	1302Z			74-11-11	ALL
	PERG	1F	W6168	1303Z			73-21-12	ALL
	PERG	1F	W6168	2201Z			77-12-21	ALL
D40147J		**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0076	0100	22		34-41-11	ALL
	2		W0076	0118	22		34-41-11	ALL
	3		W0076	0104	20		30-71-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0076	0078	20		34-41-11	ALL
	12		W0076	0105	20		30-71-11	ALL
	13		W0076	0064	24		34-41-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0076	2003Z			34-49-11	ALL
	21		W0076	2003R	24		34-49-11	ALL
	22		W0076	2003B	24		34-49-11	ALL
	23		W0076	0058	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40147J	**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
24		W0076	0103	20		30-71-11	ALL
25		W0076	0184	22		34-41-11	ALL
26		W0076	0185	22		34-41-11	ALL
27		W0076	0183	24		34-41-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40147P	**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6491	0035	22		34-41-11	ALL
2		W6491	0036	22		34-41-11	ALL
3		W6491	0502	20		30-71-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W6491	0018	20		34-41-11	ALL
12		W6491	0528	20		30-71-11	ALL
13		W6491	0047	24		34-41-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W6491	FRAO			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40147P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21		W6491	2022R	24		34-49-11	ALL
	22		W6491	2022B	24		34-49-11	ALL
	23		W6491	0034	24		34-49-11	ALL
	24		W6491	0527	20		30-71-11	ALL
	25		W6491	0006	22		34-41-11	ALL
	26		W6491	0015	22		34-41-11	ALL
	27		W6491	0022	24		34-41-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	S/R		W6491	FRA1			34-49-11	ALL
			W6491	2022Z			34-49-11	ALL
			W6491	FRA1			34-49-11	ALL
			W6491	FRAO			34-49-11	ALL
D40148J		**853/294/L034**		**RCPT, RECTANGULAR**				**ALL**
	1		W5146	0001	22		38-41-11	ALL
	2		W5146	0002	22		38-41-11	ALL
	3		W5146	0003	22		38-41-11	ALL
	4		W5146	0224	20		38-32-13	ALL
	5		W5146	0225	22		38-32-13	ALL
	6	UNUSED						ALL
	7		W5146	0227	20		38-32-13	ALL
	8		W5146	0228	20		38-32-13	ALL
	9		W5146	0229	22		38-32-13	ALL
	10		W5146	0230	20		38-32-13	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40148P	**856/294/L034**		**PLUG, RECTANGULAR**				**ALL**
1		W3058	0240	22		38-41-11	ALL
2		W3058	0243	22		38-41-11	ALL
3		W3058	0263	22		38-41-11	ALL
4		W3058	0230	20		38-32-13	ALL
5		W3058	0228	22		38-32-13	ALL
6	UNUSED						ALL
7		W3058	0229	22		38-32-13	ALL
8		W3058	0231	20		38-32-13	ALL
9		W3058	0232	22		38-32-13	ALL
10		W3058	0060	20		38-32-13	ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40149J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0313	2672R	24		34-41-11	ALL
A02		W0313	2672B	24		34-41-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W0313	0702	24		34-41-11	ALL
A09		W0313	2670R	24		31-65-25	ALL
A10		W0313	2670B	24		31-65-25	ALL
A11		W0313	2671W	24		34-41-11	ALL
A12		W0313	2671B	24		34-41-11	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40149J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A17		W0313	2182R	24		34-41-11	ALL
	A18		W0313	2182B	24		34-41-11	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0313	2669R	24		31-65-15	ALL
	B02		W0313	2669B	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0313	0661	22		34-41-11	ALL
	B08		W0313	0662	22		34-41-11	ALL
	B09		W0313	2642R	24		34-41-11	ALL
	B10		W0313	2642B	24		34-41-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0313	2643W	24		34-41-11	ALL
	B14		W0313	2643B	24		34-41-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2182Z			34-41-11	ALL
	PERG	1F	W0313	2642Z			34-41-11	ALL
	PERG	1F	W0313	2643Z			34-41-11	ALL
	PERG	1F	W0313	2669Z			31-65-15	ALL
	PERG	1F	W0313	2670Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40149J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0313	2671Z			34-41-11	ALL
	PERG	1F	W0313	2672Z			34-41-11	ALL
D40149P		**E003-01/ /**		**PLUG**				**ALL**
	A01		W6491	2015R	24		34-41-11	ALL
	A02		W6491	2015B	24		34-41-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W6491	0013	22		34-41-11	ALL
	A09		W6491	2010R	24		31-65-25	ALL
	A10		W6491	2010B	24		31-65-25	ALL
	A11		W6491	2007W	24		34-41-11	ALL
	A12		W6491	2007B	24		34-41-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W6491	2055R	24		34-41-11	ALL
	A18		W6491	2055B	24		34-41-11	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6491	2008R	24		31-65-15	ALL
	B02		W6491	2008B	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40149P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	B07		W6491	0023	22		34-41-11	ALL
	B08		W6491	0024	22		34-41-11	ALL
	B09		W6491	2016R	24		34-41-11	ALL
	B10		W6491	2016B	24		34-41-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W6491	2009W	24		34-41-11	ALL
	B14		W6491	2009B	24		34-41-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6491	2007Z			34-41-11	ALL
	PERG	1F	W6491	2008Z			31-65-15	ALL
	PERG	1F	W6491	2009Z			34-41-11	ALL
	PERG	1F	W6491	2010Z			31-65-25	ALL
	PERG	1F	W6491	2015Z			34-41-11	ALL
	PERG	1F	W6491	2016Z			34-41-11	ALL
	PERG	1F	W6491	2055Z			34-41-11	ALL
D40150J		**860/289/L043**		**RCPT, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2		W5146	0122	18		38-32-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40150J		**860/289/L043**		**RCPT, RECTANGULAR (continued)**				**ALL**
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5146	0132	20		38-32-12	ALL
D40150P		**860/289/L043**		**PLUG, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2		W3144	0033	18		38-32-12	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W3144	0032	20		38-32-12	ALL
D40152J		**849/188/L050**		**RCPT-**				**ALL**
	1		W5230	0514	18		38-32-12	ALL
	2		W5230	0519	20		38-32-12	ALL
	3	UNUSED						ALL
D40152P		**849/188/L050**		**PLUG-**				**ALL**
	1		W5146	0101	18		38-32-12	ALL
	2		W5146	0127	20		38-32-12	ALL
	3	UNUSED						ALL
D40156J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40156J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0410	1201	20		30-21-32	ALL
	A18		W0410	0627	22		30-21-32	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40156J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0410	0628	22		30-21-32	ALL
	B18		W0410	0629	22		30-21-32	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0410	1201Z			30-21-32	ALL
D40156P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W6162	2612B	20		SPARE	ALL
	A16	UNUSED						ALL
	A17		W6162	1201	20		30-21-32	ALL
	A18		W6162	0003	22		30-21-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40156P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W6162	2612R	20		SPARE	ALL
	B16	UNUSED						ALL
	B17		W6162	0004	22		30-21-32	ALL
	B18		W6162	0005	22		30-21-32	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6162	1201Z			30-21-32	ALL
D40160J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	2152B	24		27-81-21	ALL
	A02		W0111	2153B	24		27-81-21	ALL
	A03		W0111	2154B	24		27-81-21	ALL
	A04		W0111	2155B	24		27-81-21	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40160J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0111	0867	20		21-31-23	ALL
	A10		W0111	0863	24		21-31-23	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0111	2152R	24		27-81-21	ALL
	B02		W0111	2153R	24		27-81-21	ALL
	B03		W0111	2154R	24		27-81-21	ALL
	B04		W0111	2155R	24		27-81-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40160J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40160P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6588	2201B	20		27-81-21	ALL
	A02		W6588	2202B	20		27-81-21	ALL
	A03		W6588	2203B	20		27-81-21	ALL
	A04		W6588	2204B	20		27-81-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6588	0007	20		21-31-23	ALL
	A10		W6588	0008	24		21-31-23	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6588	2201R	20		27-81-21	ALL
	B02		W6588	2202R	20		27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40160P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B03		W6588	2203R	20		27-81-21	ALL
	B04		W6588	2204R	20		27-81-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40162J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	3017R	22		27-53-21	ALL
	A02		W0111	3017B	22		27-53-21	ALL
	A03		W0111	3017Y	22		27-53-21	ALL
	A04		W0111	3016R	22		27-53-21	ALL
	A05		W0111	3016B	22		27-53-21	ALL
	A06		W0111	3016Y	22		27-53-21	ALL
	A07		W0111	0639	22		27-53-21	ALL
	A08		W0111	2192R	24		27-52-11	ALL
	A09		W0111	2192Z			27-52-11	ALL
	A10		W0111	2193R	20		27-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40162J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	B01		W0111	3019R	22		27-53-21	ALL
	B02		W0111	3019B	22		27-53-21	ALL
	B03		W0111	3019Y	22		27-53-21	ALL
	B04		W0111	3018R	22		27-53-21	ALL
	B05		W0111	3018B	22		27-53-21	ALL
	B06		W0111	3018Y	22		27-53-21	ALL
	B07		W0111	0712	22		27-53-21	ALL
	B08		W0111	2192B	24		27-52-11	ALL
	B09		W0111	2193Z			27-52-11	ALL
	B10		W0111	2193B	20		27-52-11	ALL
D40162P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5032	3008R	22		27-53-21	ALL
	A02		W5032	3008B	22		27-53-21	ALL
	A03		W5032	3008Y	22		27-53-21	ALL
	A04		W5032	3009R	22		27-53-21	ALL
	A05		W5032	3009B	22		27-53-21	ALL
	A06		W5032	3009Y	22		27-53-21	ALL
	A07		W5032	2010R	22		27-53-21	ALL
	A08		W5032	2206R	22		27-52-11	ALL
	A09		W5032	2206Z			27-52-11	ALL
	A10		W5032	2207R	20		27-52-11	ALL
	B01		W5032	3006R	22		27-53-21	ALL
	B02		W5032	3006B	22		27-53-21	ALL
	B03		W5032	3006Y	22		27-53-21	ALL
	B04		W5032	3007R	22		27-53-21	ALL
	B05		W5032	3007B	22		27-53-21	ALL
	B06		W5032	3007Y	22		27-53-21	ALL
	B07		W5032	2010B	22		27-53-21	ALL
	B08		W5032	2206B	22		27-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40162P	**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B09		W5032	2207Z			27-52-11	ALL
B10		W5032	2207B	20		27-52-11	ALL
D40164J	**E004-02/ /**		**RCPT**				**ALL**
A01		W0422	0068	20		33-44-12	ALL
A02		W0422	1006	20		30-11-11	ALL
A03		W0422	0537	22		30-11-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W0422	2602B	22		28-41-11	ALL
B01	UNUSED						ALL
B02		W0422	0536	22		30-11-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W0422	0153	20		28-44-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W0422	0075	22		28-44-11	ALL
B09		W0422	0076	20		28-44-11	ALL
B10		W0422	2602R	22		28-41-11	ALL
F	UNUSED						ALL
G	UNUSED						ALL
H		W0422	0074	18		28-44-11	ALL
J		W0422	0066	18		33-42-21	ALL
K	UNUSED						ALL
PERG	1F	W0422	1006Z			30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40164J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	PERG	1F	W0422	2602Z			28-41-11	ALL
D40164P		**E004-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6586	0002	20		33-44-12	ALL
	A02		W6586	1001	20		30-11-11	ALL
	A03		W6586	0019	22		30-11-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6586	2601B	22		28-41-11	ALL
	B01	UNUSED						ALL
	B02		W6586	0018	22		30-11-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6586	6005	20		28-44-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W6586	6004	22		28-44-11	ALL
	B09		W6586	6010	20		28-44-11	ALL
	B10		W6586	2601R	22		28-41-11	ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H		W6586	6003	18		28-44-11	ALL
	J		W6586	0011	18		33-42-21	ALL
	K	UNUSED						ALL
	PERG	1F	W6586	1001Z			30-11-11	ALL
	PERG	1F	W6586	2601Z			28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40170J	**AB0340A/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W3058	0146	22		23-42-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W3058	0003	22		23-42-11	ALL
16		W3058	0004	22		23-42-11	ALL
17		W3058	0428	22		33-51-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W3058	0027	24		52-71-11	ALL
27	UNUSED						ALL
28		W3058	0429	22		33-51-11	ALL
29		W3058	0012	22		23-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40170J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	30		W3058	0005	22		23-42-11	ALL
	31	UNUSED						ALL
D40170P		**AB0340A/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2218	0001	22		23-42-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W2218	0003	22		23-42-11	ALL
	16		W2218	0004	22		23-42-11	ALL
	17		W2218	0033	22		33-51-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W2218	0067	24		52-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40170P	**AB0340A/ /**		**PLUG- (continued)**				**ALL**
27	UNUSED						ALL
28		W2218	0035	22		33-51-11	ALL
29	UNUSED						ALL
30		W2218	0005	22		23-42-11	ALL
31	UNUSED						ALL
D40180J	**E001-01/ /**		**RCPT-**				**ALL**
A01		W0111	3021R	22		27-53-21	ALL
A02		W0111	3021B	22		27-53-21	ALL
A03		W0111	3021Y	22		27-53-21	ALL
A04		W0111	3020R	22		27-53-21	ALL
A05		W0111	3020B	22		27-53-21	ALL
A06		W0111	3020Y	22		27-53-21	ALL
A07		W0111	0714	22		27-53-21	ALL
A08		W0111	2189R	24		27-52-11	ALL
A09		W0111	2189Z			27-52-11	ALL
A10		W0111	2188R	20		27-52-11	ALL
B01		W0111	3023R	22		27-53-21	ALL
B02		W0111	3023B	22		27-53-21	ALL
B03		W0111	3023Y	22		27-53-21	ALL
B04		W0111	3022R	22		27-53-21	ALL
B05		W0111	3022B	22		27-53-21	ALL
B06		W0111	3022Y	22		27-53-21	ALL
B07		W0111	0713	22		27-53-21	ALL
B08		W0111	2189B	24		27-52-11	ALL
B09		W0111	2188Z			27-52-11	ALL
B10		W0111	2188B	20		27-52-11	ALL
D40180P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W6028	3008R	22		27-53-21	ALL
A02		W6028	3008B	22		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40180P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A03		W6028	3008Y	22		27-53-21	ALL
	A04		W6028	3009R	22		27-53-21	ALL
	A05		W6028	3009B	22		27-53-21	ALL
	A06		W6028	3009Y	22		27-53-21	ALL
	A07		W6028	2010R	22		27-53-21	ALL
	A08		W6028	2206R	22		27-52-11	ALL
	A09		W6028	2206Z			27-52-11	ALL
	A10		W6028	2207R	20		27-52-11	ALL
	B01		W6028	3006R	22		27-53-21	ALL
	B02		W6028	3006B	22		27-53-21	ALL
	B03		W6028	3006Y	22		27-53-21	ALL
	B04		W6028	3007R	22		27-53-21	ALL
	B05		W6028	3007B	22		27-53-21	ALL
	B06		W6028	3007Y	22		27-53-21	ALL
	B07		W6028	2010B	22		27-53-21	ALL
	B08		W6028	2206B	22		27-52-11	ALL
	B09		W6028	2207Z			27-52-11	ALL
	B10		W6028	2207B	20		27-52-11	ALL
D40188J		**AB1156L/274/L026**		**RECP-CONDUCTIVE**				**ALL**
	1		W7038	2201B	20		27-38-11	ALL
	2		W7038	2201R	20		27-38-11	ALL
	3		W7038	3201Y	20		27-38-11	ALL
	4		W7038	3501R	20		33-49-11	ALL
	5		W7038	3201B	20		27-38-11	ALL
	6		W7038	3201R	20		27-38-11	ALL
	7		W7038	3501B	20		33-49-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W7038	3501Y	20		33-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40188J	**AB1156L/274/L026**		**RECP-CONDUCTIVE (continued)**				**ALL**
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W7038	2201Z			27-38-11	ALL
S/R		W7038	3201Z			27-38-11	ALL
S/R		W7038	3501Z			33-49-11	ALL
D40188P	**AB1156L/273/L025**		**PLUG-CONDUCTIVE**				**ALL**
1		W8030	2211B	20		27-38-11	ALL
2		W8030	2211R	20		27-38-11	ALL
3		W8030	3211Y	20		27-38-11	ALL
4		W8030	2512R	18		33-49-11	ALL
5		W8030	3211B	20		27-38-11	ALL
6		W8030	3211R	20		27-38-11	ALL
7		W8030	2512B	18		33-49-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W8030	1511	18		33-49-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
S/R		W8030	1511Z			33-49-11	ALL
S/R		W8030	2211Z			27-38-11	ALL
S/R		W8030	2512Z			33-49-11	ALL
S/R		W8030	3211Z			27-38-11	ALL
D40190J	**AB1156R/274/R026**		**RECP-CONDUCTIVE**				**ALL**
1		W8038	2201B	20		27-38-11	ALL
2		W8038	2201R	20		27-38-11	ALL
3		W8038	3201Y	20		27-38-11	ALL
4		W8038	3501R	20		33-49-11	ALL
5		W8038	3201B	20		27-38-11	ALL
6		W8038	3201R	20		27-38-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40190J		**AB1156R/274/R026**		**RECP-CONDUCTIVE (continued)**				**ALL**
	7		W8038	3501B	20		33-49-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W8038	3501Y	20		33-49-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W8038	2201Z			27-38-11	ALL
	S/R		W8038	3201Z			27-38-11	ALL
	S/R		W8038	3501Z			33-49-11	ALL
D40190P		**AB1156R/273/R025**		**PLUG-CONDUCTIVE**				**ALL**
	1		W8030	2201B	20		27-38-11	ALL
	2		W8030	2201R	20		27-38-11	ALL
	3		W8030	3201Y	20		27-38-11	ALL
	4		W8030	2502R	18		33-49-11	ALL
	5		W8030	3201B	20		27-38-11	ALL
	6		W8030	3201R	20		27-38-11	ALL
	7		W8030	2502B	18		33-49-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W8030	1501	18		33-49-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W8030	1501Z			33-49-11	ALL
	S/R		W8030	2201Z			27-38-11	ALL
	S/R		W8030	2502Z			33-49-11	ALL
	S/R		W8030	3201Z			27-38-11	ALL
D40192J		**AB1030C/300/L010**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6134	2201B	20		27-38-11	ALL
	2		W6134	2201R	20		27-38-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40192J	**AB1030C/300/L010**		**RCPT-CONDUCTIVE (continued)**				**ALL**
3		W6134	3201Y	20		27-38-11	ALL
4		W6134	3201R	20		27-38-11	ALL
5		W6134	3201B	20		27-38-11	ALL
6		W6134	0006	20		33-49-11	ALL
7	18	W6134	0530	18		27-31-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W6134	2211B	20		27-38-11	ALL
12		W6134	2211R	20		27-38-11	ALL
13		W6134	3211Y	20		27-38-11	ALL
14		W6134	3211R	20		27-38-11	ALL
15		W6134	3211B	20		27-38-11	ALL
16		W6134	2231B	20		27-48-11	ALL
17		W6134	2231R	20		27-48-11	ALL
18		W6134	3231Y	20		27-48-11	ALL
19		W6134	3231R	20		27-48-11	ALL
20		W6134	3231B	20		27-48-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D40192P	**AB1030C/300/L10**		**PLUG-CONDUCTIVE**				**ALL**
1		W8030	2201B	20		27-38-11	ALL
2		W8030	2201R	20		27-38-11	ALL
3		W8030	3201Y	20		27-38-11	ALL
4		W8030	3201R	20		27-38-11	ALL
5		W8030	3201B	20		27-38-11	ALL
6	18	W8030	1521	18		33-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40192P		**AB1030C/300/L10**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	7	18	W8030	1001	18		27-31-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W8030	2211B	20		27-38-11	ALL
	12		W8030	2211R	20		27-38-11	ALL
	13		W8030	3211Y	20		27-38-11	ALL
	14		W8030	3211R	20		27-38-11	ALL
	15		W8030	3211B	20		27-38-11	ALL
	16		W8030	2231B	20		27-48-11	ALL
	17		W8030	2231R	20		27-48-11	ALL
	18		W8030	3231Y	20		27-48-11	ALL
	19		W8030	3231R	20		27-48-11	ALL
	20		W8030	3231B	20		27-48-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W8030	1001Z			27-31-11	ALL
	S/R		W8030	1521Z			33-49-11	ALL
	S/R		W8030	2201Z			27-38-11	ALL
	S/R		W8030	2211Z			27-38-11	ALL
	S/R		W8030	2231Z			27-48-11	ALL
	S/R		W8030	3201Z			27-38-11	ALL
	S/R		W8030	3211Z			27-38-11	ALL
	S/R		W8030	3231Z			27-48-11	ALL
D40194J		**E003-02/ /**		**RCPT-**				**ALL**
	A01		W0321	0012	24		31-35-08	ALL
	A02		W0321	0426	22		29-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40194J	**E003-02/ /**		**RCPT- (continued)**				**ALL**
A03		W0321	0112	20		27-53-11	ALL
A04	UNUSED						ALL
A05		W0321	2095B	24		27-28-11	ALL
A06		W0321	2095R	24		27-28-11	ALL
A07		W0321	2704B	24		27-28-11	ALL
A08		W0321	2704R	24		27-28-11	ALL
A09	UNUSED						ALL
A10		W0321	2706B	24		27-38-11	ALL
A11		W0321	2706R	24		27-38-11	ALL
A12		W0321	2707B	24		27-38-11	ALL
A13		W0321	2707R	24		27-38-11	ALL
A14		W0321	2708B	24		27-48-11	ALL
A15		W0321	2708R	24		27-48-11	ALL
A16		W0321	3706B	24		27-38-11	ALL
A17		W0321	3706R	24		27-38-11	ALL
A18		W0321	3706Y	24		27-38-11	ALL
A19	UNUSED						ALL
A20		W0321	0470	20		27-25-11	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W0321	2705B	24		27-28-11	ALL
B05		W0321	2705R	24		27-28-11	ALL
B06		W0321	3705R	24		27-28-11	ALL
B07		W0321	3705B	24		27-28-11	ALL
B08		W0321	3705Y	24		27-28-11	ALL
B09		W0321	0317	22		31-53-11	ALL
B10		W0321	0110	20		27-53-11	ALL
B11		W0321	0111	20		27-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40194J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	B12		W0321	3711B	24		27-48-11	ALL
	B13		W0321	3711R	24		27-48-11	ALL
	B14		W0321	3711Y	24		27-48-11	ALL
	B15	UNUSED						ALL
	B16		W0321	3707B	24		27-38-11	ALL
	B17		W0321	3707R	24		27-38-11	ALL
	B18		W0321	3707Y	24		27-38-11	ALL
	B19		W0321	0078	20		27-31-11	ALL
	B20		W0321	0471	20		27-25-11	ALL
	DED		W0321	2704Z			27-28-11	ALL
D40194P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W6134	0003	24		31-35-08	ALL
	A02		W6134	0517	20		29-23-11	ALL
	A03		W6134	0529	20		27-53-11	ALL
	A04	UNUSED						ALL
	A05		W6134	2029B	20		27-28-11	ALL
	A06		W6134	2029R	20		27-28-11	ALL
	A07		W6134	2202B	20		27-28-11	ALL
	A08		W6134	2202R	20		27-28-11	ALL
	A09	UNUSED						ALL
	A10		W6134	2201B	20		27-38-11	ALL
	A11		W6134	2201R	20		27-38-11	ALL
	A12		W6134	2211B	20		27-38-11	ALL
	A13		W6134	2211R	20		27-38-11	ALL
	A14		W6134	2231B	20		27-48-11	ALL
	A15		W6134	2231R	20		27-48-11	ALL
	A16		W6134	3201B	20		27-38-11	ALL
	A17		W6134	3201R	20		27-38-11	ALL
	A18		W6134	3201Y	20		27-38-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40194P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A19	UNUSED						ALL
	A20		W6134	0001	20		27-25-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6134	2203B	20		27-28-11	ALL
	B05		W6134	2203R	20		27-28-11	ALL
	B06		W6134	3203R	20		27-28-11	ALL
	B07		W6134	3203B	20		27-28-11	ALL
	B08		W6134	3203Y	20		27-28-11	ALL
	B09		W6134	0514	20		31-53-11	ALL
	B10		W6134	0527	20		27-53-11	ALL
	B11		W6134	0528	20		27-53-11	ALL
	B12		W6134	3231B	20		27-48-11	ALL
	B13		W6134	3231R	20		27-48-11	ALL
	B14		W6134	3231Y	20		27-48-11	ALL
	B15	UNUSED						ALL
	B16		W6134	3211B	20		27-38-11	ALL
	B17		W6134	3211R	20		27-38-11	ALL
	B18		W6134	3211Y	20		27-38-11	ALL
	B19		W6134	0533	20		27-31-11	ALL
	B20		W6134	0002	20		27-25-11	ALL
D40196J		**AB0340A/ /**		**RCPT-**				**ALL**
	1		W3142	0031	22		33-51-11	ALL
	2		W3142	0032	22		33-51-11	ALL
	3	UNUSED						ALL
	4	18	W3142	0034	18		33-41-11	ALL
	5		W3142	0035	20		33-51-11	ALL
	6		W3142	0363	22		30-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40196J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	7	UNUSED						ALL
	8		W3142	0038	20		SPARE	ALL
	9		W3142	5512	20		21-42-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W3142	0462	20		52-71-13	ALL
	18		W3142	0463	20		52-71-13	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W3142	0420	20		52-71-13	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	CAP	Y	W3142	0039	20		SPARE	ALL
D40196P		**AB0340A/ /**		**PLUG-**				**ALL**
	1		W2114	0017	22		33-51-11	ALL
	2		W2114	0016	22		33-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40196P	**AB0340A/ /**		**PLUG- (continued)**				**ALL**
3	UNUSED						ALL
4	18	W2114	0003	18		33-41-11	ALL
5		W2114	0020	20		33-51-11	ALL
6		W2114	5535	22		30-31-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2114	0027	20		21-42-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W2114	0030	20		52-71-13	ALL
18		W2114	0031	20		52-71-13	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2114	0040	20		52-71-13	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40198J	**P018-00/ /**		**RCPT-**				**ALL**
1		W0018	0362	22		38-21-11	ALL
2		W0018	0202	22		38-21-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0018	0313	20		33-25-11	ALL
8		W0018	0312	20		33-25-11	ALL
9		W0018	0311	20		33-25-11	ALL
10		W0018	0310	20		33-25-11	ALL
11		W0018	0327	22		33-27-11	ALL
12		W0018	0326	22		33-27-11	ALL
13		W0018	0323	22		33-27-11	ALL
14		W0018	0324	22		33-27-11	ALL
15		W0018	0357	16		35-21-11	ALL
16		W0018	0358	16		35-21-11	ALL
17	UNUSED						ALL
18		W0018	0305	20		33-25-11	ALL
19	UNUSED						ALL
D40198P	**P018-00/ /**		**PLUG-CTR CEILING**				**ALL**
1		W3150	0111	22		38-21-11	ALL
2		W3150	0112	22		38-21-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W3150	0907	20		33-25-22	ALL
8		W3150	0908	20		33-25-21	ALL
9		W3150	0909	20		33-25-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40198P	**P018-00/ /**		**PLUG-CTR CEILING (continued)**				**ALL**
10		W3150	0919	20		33-25-21	ALL
11		W3150	0911	22		33-27-21	ALL
12		W3150	0912	22		33-27-21	ALL
13		W3150	0913	22		33-27-21	ALL
14		W3150	0914	22		33-27-11	ALL
15		W3150	0915	16		35-21-21	ALL
16		W3150	0916	16		35-21-21	ALL
17	UNUSED						ALL
18		W3150	0918	20		33-25-11	ALL
19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40202J		**AB0340B/ /**		**RCPT-**				**ALL**
	1		W4258	0269	18		33-21-12	ALL
	2		W4258	0268	18		33-21-12	ALL
	3	UNUSED						ALL
	4		W4258	0407	18		33-24-11	ALL
	5		W4258	2405R	18		33-23-22	ALL
	6		W4258	2405B	18		33-23-22	ALL
	7		W4258	2408B	18		33-23-21	ALL
	8		W4258	2408R	18		33-23-21	ALL
	9		W4258	2410B	18		33-23-21	ALL
	10		W4258	2410R	18		33-23-21	ALL
	11		W4258	2412B	18		33-23-22	ALL
	12		W4258	2412R	18		33-23-22	ALL
	13		W4258	2413R	18		33-23-22	ALL
	14		W4258	2413B	18		33-23-22	ALL
	15		W4258	2415R	18		33-23-22	ALL
	16		W4258	2415B	18		33-23-22	ALL
	17		W4258	2407B	18		33-23-21	ALL
	18		W4258	2407R	18		33-23-21	ALL
	19		W4258	2409B	18		33-23-21	ALL
	20		W4258	2409R	18		33-23-21	ALL
	21		W4258	2411B	18		33-23-22	ALL
	22		W4258	2411R	18		33-23-22	ALL
	23	UNUSED						ALL
	24		W4258	0091	18		25-29-11	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40202J	**AB0340B/ /**		**RCPT- (continued)**				**ALL**
30	UNUSED						ALL
D40202P	**AB0340B/ /**		**PLUG-**				**ALL**
1		W6242	0003	18		33-21-11	ALL
2		W6242	0013	18		33-21-11	ALL
3	UNUSED						ALL
4		W6242	0034	18		33-24-11	ALL
5		W6242	2436R	18		33-23-22	ALL
6		W6242	2436B	18		33-23-22	ALL
7		W6242	2429B	18		33-23-21	ALL
8		W6242	2429R	18		33-23-21	ALL
9		W6242	2431B	18		33-23-21	ALL
10		W6242	2431R	18		33-23-21	ALL
11		W6242	2433B	18		33-23-22	ALL
12		W6242	2433R	18		33-23-22	ALL
13		W6242	2434R	18		33-23-22	ALL
14		W6242	2434B	18		33-23-22	ALL
15		W6242	2435R	18		33-23-22	ALL
16		W6242	2435B	18		33-23-22	ALL
17		W6242	2428B	18		33-23-21	ALL
18		W6242	2428R	18		33-23-21	ALL
19		W6242	2430B	18		33-23-21	ALL
20		W6242	2430R	18		33-23-21	ALL
21		W6242	2432B	18		33-23-22	ALL
22		W6242	2432R	18		33-23-22	ALL
23	UNUSED						ALL
24		W6242	0036	18		25-29-11	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40202P		**AB0340B/ /**		**PLUG- (continued)**				**ALL**
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
D40205J		**408/282/R049**		**RCPT, RECTANGULAR**				**ALL**
	1		W4250	2692R	18		33-23-21	ALL
	2		W4250	2692B	18		33-23-21	ALL
	3		W4250	2694B	18		33-23-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W4250	2693R	18		33-23-21	ALL
	7		W4250	0937	20		33-25-31	ALL
	8		W4250	2694R	18		33-23-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W4250	2693B	18		33-23-21	ALL
	13		W4250	2695R	18		33-23-21	ALL
	14		W4250	2695B	18		33-23-21	ALL
	15	UNUSED						ALL
	16		W4250	0931	20		33-25-31	ALL
D40205P		**408/282/R049**		**PLUG, RECTANGULAR**				**ALL**
	1		W4258	2407R	18		33-23-21	ALL
	2		W4258	2407B	18		33-23-21	ALL
	3		W4258	2409B	18		33-23-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W4258	2408R	18		33-23-21	ALL
	7		W4258	0088	20		33-25-31	ALL
	8		W4258	2409R	18		33-23-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40205P	**408/282/R049**		**PLUG, RECTANGULAR (continued)**				**ALL**
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W4258	2408B	18		33-23-21	ALL
13		W4258	2410R	18		33-23-21	ALL
14		W4258	2410B	18		33-23-21	ALL
15	UNUSED						ALL
16		W4258	0086	20		33-25-31	ALL
D40207J	**674/302/R018**		**RCPT, RECTANGULAR**				**ALL**
1		W4250	2696R	18		33-23-22	ALL
2		W4250	2696B	18		33-23-22	ALL
3		W4250	2698B	18		33-23-22	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W4250	2697R	18		33-23-22	ALL
7		W4250	2802B	18		33-23-22	ALL
8		W4250	2698R	18		33-23-22	ALL
9		W4250	2801R	18		33-23-22	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W4250	2697B	18		33-23-22	ALL
13		W4250	2802R	18		33-23-22	ALL
14		W4250	2801B	18		33-23-22	ALL
15		W4250	0947	20		33-25-32	ALL
16		W4250	0941	20		33-25-32	ALL
D40207P	**674/302/R018**		**PLUG, RECTANGULAR**				**ALL**
1		W4258	2411R	18		33-23-22	ALL
2		W4258	2411B	18		33-23-22	ALL
3		W4258	2413B	18		33-23-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40207P		**674/302/R018**		**PLUG, RECTANGULAR (continued)**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W4258	2412R	18		33-23-22	ALL
	7		W4258	2405B	18		33-23-22	ALL
	8		W4258	2413R	18		33-23-22	ALL
	9		W4258	2415R	18		33-23-22	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W4258	2412B	18		33-23-22	ALL
	13		W4258	2405R	18		33-23-22	ALL
	14		W4258	2415B	18		33-23-22	ALL
	15		W4258	0087	20		33-25-32	ALL
	16		W4258	0089	20		33-25-32	ALL
D40211J		**AB0410/*/***		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W6214	5511	24		21-42-11	ALL
	A04	UNUSED						ALL
	A05		W6214	0030	22		23-22-11	ALL
	A06		W6214	0032	22		23-22-11	ALL
	A07		W6214	0033	22		23-71-01	ALL
	A08		W6214	5502	24		21-51-14	ALL
	A09		W6214	6001	24		73-22-31	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W6214	5512	24		21-42-11	ALL
	B04	UNUSED						ALL
	B05		W6214	0031	22		23-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40211J		**AB0410/*/***		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W6214	0034	22		23-71-01	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40211P		**AB0410/205/R039**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5156	5520	24		21-42-11	ALL
	A04	UNUSED						ALL
	A05		W5156	0503	22		23-22-11	ALL
	A06		W5156	0505	22		23-22-11	ALL
	A07		W5156	0519	20		23-71-01	ALL
	A08		W5156	5501	24		21-51-14	ALL
	A09		W5156	6006	24		73-22-31	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5156	5521	24		21-42-11	ALL
	B04	UNUSED						ALL
	B05		W5156	0504	22		23-22-11	ALL
	B06	UNUSED						ALL
	B07		W5156	0518	20		23-71-01	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40216J		**AB0340A/ /**		**RCPT-**				**ALL**
	1		W3158	0061	20		33-25-21	ALL
	2		W3158	0062	20		33-25-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40216J		**AB0340A/ /**		**RCPT- (continued)**				**ALL**
	3	UNUSED						ALL
	4		W3158	0101	20		SPARE	ALL
	5		W3158	0102	20		SPARE	ALL
	6		W3158	0063	20		33-25-11	ALL
	7	UNUSED						ALL
D40216P		**AB0340A/ /**		**PLUG-**				**ALL**
	1		W3144	0071	20		33-25-21	ALL
	2		W3144	0072	20		33-25-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W3144	0127	20		33-25-11	ALL
	7	UNUSED						ALL
D40218J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W0044	0698	22		23-27-31	ALL
	3		W0044	1010	22		30-31-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0044	6251	20		74-11-11	ALL
	7	UNUSED						ALL
	8		W0044	1020	22		30-31-12	ALL
	9		W0044	0101	20		33-17-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0044	0997	20		23-70-11	ALL
	14		W0044	0301	20		33-25-11	ALL
	15		W0044	0302	20		33-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40218J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
16		W0044	0318	20		33-25-11	ALL
17		W0044	0319	20		33-25-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0044	1019	22		30-31-12	ALL
21		W0044	0304	24		33-25-11	ALL
22		W0044	0747	20		52-71-13	ALL
23		W0044	1021	22		30-31-12	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W0044	0554	20		22-23-11	ALL
27		W0044	0320	20		33-25-11	ALL
28	UNUSED						ALL
29		W0044	0321	20		33-25-11	ALL
30		W0044	0317	20		33-25-11	ALL
31		W0044	0311	20		33-25-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W0044	0574	16		23-12-31	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W0044	0994	20		23-70-11	ALL
43		W0044	0308	20		33-25-11	ALL
DED		W0044	1010Z			30-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40218J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	DED		W0044	1019Z			30-31-12	ALL
	DED		W0044	1020Z			30-31-12	ALL
	DED		W0044	1021Z			30-31-12	ALL
D40218P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W0018	0520	22		23-27-31	ALL
	3		W0018	0115	22		30-31-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0018	6208	20		74-11-11	ALL
	7	UNUSED						ALL
	8		W0018	0124	22		30-31-12	ALL
	9		W0018	5501	20		33-17-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0018	2001B	20		23-70-11	ALL
	14		W0018	0300	20		33-25-11	ALL
	15		W0018	0301	20		33-25-11	ALL
	16		W0018	0307	20		33-25-11	ALL
	17		W0018	0308	20		33-25-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0018	0125	22		30-31-12	ALL
	21		W0018	0302	24		33-25-11	ALL
	22		W0018	0066	20		52-71-13	ALL
	23		W0018	0123	22		30-31-12	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40218P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
26		W0018	0020	20		22-23-11	ALL
27		W0018	0309	20		33-25-11	ALL
28	UNUSED						ALL
29		W0018	0305	20		33-25-11	ALL
30		W0018	0306	20		33-25-11	ALL
31		W0018	0304	20		33-25-11	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W0018	0505	16		23-12-31	ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42		W0018	2001R	20		23-70-11	ALL
43		W0018	0303	20		33-25-11	ALL
D40220J	**P018-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0018	0361	22		38-21-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0018	0319	20		33-26-31	ALL
8		W0018	0318	20		33-26-31	ALL
9	UNUSED						ALL
10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40220J		**P018-00/ /**		**RCPT- (continued)**				**ALL**
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0018	0378	20		38-32-13	ALL
	21	UNUSED						ALL
	22		W0018	0116	22		30-31-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0018	2001R	20		23-70-11	ALL
	26		W0018	2001B	20		23-70-11	ALL
	27		W0018	0260	22		26-14-11	ALL
	28		W0018	0329	22		33-27-11	ALL
	29		W0018	0328	22		33-27-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40220P	**P018-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W3144	0138	22		38-21-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W3144	0007	20		33-26-31	ALL
8		W3144	0008	20		33-26-31	ALL
9		W3144	1001Z			30-31-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W3144	0013	20		SPARE	ALL
14		W3144	0014	20		SPARE	ALL
15		W3144	0015	20		SPARE	ALL
16		W3144	0016	20		SPARE	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W3144	0020	20		38-32-13	ALL
21	UNUSED						ALL
22		W3144	1001	22		30-31-11	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W3144	2261R	20		23-70-11	ALL
26		W3144	2261B	20		23-70-11	ALL
27		W3144	0027	22		26-14-11	ALL
28		W3144	0102	22		33-27-11	ALL
29		W3144	0129	22		33-27-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40220P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D40222J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	0001	20		22-13-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0422	0004	24		27-21-11	ALL
	A05		W0422	0228	24		27-21-11	ALL
	A06		W0422	0229	24		27-21-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0422	0008	20		27-23-11	ALL
	A13		W0422	0009	20		27-23-11	ALL
	A14		W0422	0010	20		27-23-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0422	0051	22		29-11-11	ALL
	A18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40222J	**E004-02/ /**		**RCPT- (continued)**				**ALL**
A19		W0422	0535	20		27-23-11	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0422	0016	20		27-23-11	ALL
B13		W0422	0017	20		27-23-11	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
D40222P	**E004-02/ /**		**PLUG-**				**ALL**
A01		W6208	0008	20		22-13-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W6208	0507	24		27-21-11	ALL
A05		W6208	0508	24		27-21-11	ALL
A06		W6208	0509	24		27-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40222P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W6208	0566	20		27-23-11	ALL
	A13		W6208	0567	20		27-23-11	ALL
	A14		W6208	0568	22		27-23-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W6208	0571	22		29-11-11	ALL
	A18	UNUSED						ALL
	A19		W6208	0601	20		27-23-11	ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W6208	0620	20		27-23-11	ALL
	B13		W6208	0618	20		27-23-11	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40222P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
D40226J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0007	22		24-23-51	ALL
2		W0044	2001R	22		24-23-51	ALL
3		W0044	2001B	22		24-23-51	ALL
4		W0044	1019	22		30-31-12	ALL
5		W0044	0323	24		33-29-11	ALL
6		W0044	0326	24		33-29-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0044	6168	22		46-13-52	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0044	6107	22		32-31-12	ALL
14		W0044	1019Z			30-31-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0044	6089	22		33-51-11	ALL
18		W0044	6019	22		32-31-12	ALL
19	UNUSED						ALL
20		W0044	6098	22		23-42-14	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40226J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0044	6323	22		46-13-52	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40226P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W3058	0020	22		24-23-51	ALL
	2		W3058	2218R	22		24-23-51	ALL
	3		W3058	2218B	22		24-23-51	ALL
	4		W3058	1003	22		30-31-12	ALL
	5		W3058	0062	24		33-29-11	ALL
	6		W3058	0465	24		33-29-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W3058	0540	22		46-13-52	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3058	0447	22		32-31-12	ALL
	14		W3058	1003Z			30-31-12	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W3058	0188	22		33-51-11	ALL
	18		W3058	0448	22		32-31-12	ALL
	19	UNUSED						ALL
	20		W3058	0170	22		23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40226P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W3058	0542	22		46-13-52	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
CAP	Y	W3058	0320	20		SPARE	ALL
D40228J	**E004-02/ /**		**RCPT**				**ALL**
A01		W0422	0504	20		27-81-51	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0422	0505	20		27-81-51	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40228J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0422	0066	18		33-42-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40228P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W6208	0586	20		27-81-51	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6208	0587	20		27-81-51	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40228P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B10	UNUSED						ALL
	F		W6208	0001	18		33-42-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40236J		**1040/298/L006**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6134	0547	18		27-31-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
D40236P		**1040/298/L006**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7030	1001	18		27-31-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	S/R		W7030	1001Z			27-31-11	ALL
D40238J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	0004	24		27-21-11	ALL
	A02		W0422	0503	20		27-81-51	ALL
	A03		W0422	0506	20		27-81-51	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0422	0228	24		27-21-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0422	1006	20		30-11-11	ALL
	B01		W0422	0505	20		27-81-51	ALL
	B02		W0422	0507	20		27-81-51	ALL
	B03		W0422	0013	20		27-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40238J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0422	0229	24		27-21-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0422	0003	24		31-35-08	ALL
	F		W0422	0053	18		29-25-11	ALL
	G		W0422	0054	18		29-25-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0422	1006Z			30-11-11	ALL
D40238P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W6134	3215R	20		27-21-11	ALL
	A02		W6134	0521	20		27-81-51	ALL
	A03		W6134	0522	20		27-81-51	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W6134	3215Y	20		27-21-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6134	1007	20		30-11-11	ALL
	B01		W6134	0523	20		27-81-51	ALL
	B02		W6134	0524	20		27-81-51	ALL
	B03		W6134	0536	22		27-23-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40238P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W6134	3215B	20		27-21-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6134	0003	24		31-35-08	ALL
	F		W6134	0515	18		29-25-11	ALL
	G		W6134	0516	18		29-25-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W6134	1007Z			30-11-11	ALL
D40240J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0220	0048	20		21-31-22	ALL
	A02		W0220	1002	20		21-31-22	ALL
	A03		W0220	2010R	24		21-31-22	ALL
	A04		W0220	2010B	24		21-31-22	ALL
	A05		W0220	2011R	24		21-31-22	ALL
	A06		W0220	2011B	24		21-31-22	ALL
	A07		W0220	0058	24		21-31-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40240J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0220	1002Z			21-31-22	ALL
	PERG	1F	W0220	2010Z			21-31-22	ALL
	PERG	1F	W0220	2011Z			21-31-22	ALL
D40240P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6102	5501	20		21-31-22	ALL
	A02		W6102	1001	20		21-31-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40240P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A03		W6102	2001R	24		21-31-22	ALL
	A04		W6102	2001B	24		21-31-22	ALL
	A05		W6102	2002R	24		21-31-22	ALL
	A06		W6102	2002B	24		21-31-22	ALL
	A07		W6102	5502	24		21-31-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40240P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6102	1001Z			21-31-22	ALL
	PERG	1F	W6102	2001Z			21-31-22	ALL
	PERG	1F	W6102	2002Z			21-31-22	ALL
D40242J		**E004-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0410	2013R	22		21-31-11	ALL
	A02		W0410	2013B	22		21-31-11	ALL
	A03	UNUSED						ALL
	A04		W0410	3001R	24		21-31-11	ALL
	A05		W0410	3001B	24		21-31-11	ALL
	A06		W0410	3001Y	24		21-31-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40242J	**E004-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0410	2013Z			21-31-11	ALL
PERG	1F	W0410	3001Z			21-31-11	ALL
D40242P	**E004-01/ /**		**PLUG-**				**ALL**
A01		W6102	2004R	22		21-31-11	ALL
A02		W6102	2004B	22		21-31-11	ALL
A03	UNUSED						ALL
A04		W6102	3002R	24		21-31-11	ALL
A05		W6102	3002B	24		21-31-11	ALL
A06		W6102	3002Y	24		21-31-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W6102	2004Z			21-31-11	ALL
PERG	1F	W6102	3002Z			21-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40244J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0537	24		21-51-14	ALL
	A02		W0410	0531	24		21-51-14	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0410	0449	24		21-61-51	ALL
	A09	UNUSED						ALL
	A10		W0410	0534	24		21-51-14	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0410	0540	24		21-51-14	ALL
	B04		W0410	0475	24		21-25-11	ALL
	B05	UNUSED						ALL
	B06		W0410	0530	24		21-51-14	ALL
	B07		W0410	0315	24		21-51-12	ALL
	B08		W0410	0321	24		21-51-12	ALL
	B09		W0410	0322	24		21-51-12	ALL
	B10		W0410	0323	24		21-51-12	ALL
D40244P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W5104	0131	24		21-51-14	ALL
	A02		W5104	0134	24		21-51-14	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5104	0309	24		21-61-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40244P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10		W5104	0132	24		21-51-14	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5104	0130	24		21-51-14	ALL
	B04		W5104	0310	22		21-25-11	ALL
	B05		W5104	5520	20		SPARE	ALL
	B06		W5104	0133	24		21-51-14	ALL
	B07		W5104	0301	24		21-51-12	ALL
	B08		W5104	0302	24		21-51-12	ALL
	B09		W5104	0303	24		21-51-12	ALL
	B10		W5104	0304	24		21-51-12	ALL
	CAP	Y	W5104	5521	20		SPARE	ALL
D40246J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0220	1001	20		33-44-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40246J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0220	1001Z			33-44-11	ALL
D40246P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5104	1201	20		33-44-11	ALL
	A08		W5104	5522	20		SPARE	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5104	1201Z			33-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40248J	**727A+10/297/R027**		**RCPT-**				**ALL**
1		W6222	3203R	20		27-11-11	ALL
2		W6222	0513	16		27-53-12	ALL
3		W6222	0514	16		27-53-12	ALL
4		W6222	0515	16		27-53-12	ALL
5		W6222	3203B	20		27-11-11	ALL
6		W6222	3203Y	20		27-11-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
D40248P	**727A+10/298/R027**		**PLUG-**				**ALL**
1		W5224	3001R	20		27-11-11	ALL
2		W5224	0511	16		27-53-12	ALL
3		W5224	0512	16		27-53-12	ALL
4		W5224	0513	16		27-53-12	ALL
5		W5224	3001B	20		27-11-11	ALL
6		W5224	3001Y	20		27-11-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
D40254J	**E002-01/ /**		**RCPT- CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W0212	0082	20		49-62-11	ALL
A03		W0212	0083	20		49-62-11	ALL
A04		W0212	0081	20		49-62-11	ALL
A05	UNUSED						ALL
A06		W0212	2036R	24		34-33-11	ALL
A07		W0212	2037R	24		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40254J		**E002-01/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	A08		W0212	0076	20		38-32-12	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0212	2036B	24		34-33-11	ALL
	B07		W0212	2037B	24		34-33-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W0212	0075	18		38-32-12	ALL
	K	UNUSED						ALL
	PERG	1F	W0212	2036Z			34-33-11	ALL
	PERG	1F	W0212	2037Z			34-33-11	ALL
D40254P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W5726	0600	22		49-62-11	ALL
	A03		W5726	0601	22		49-62-11	ALL
	A04		W5726	0599	20		49-62-11	ALL
	A05	UNUSED						ALL
	A06		W5726	2234R	24		34-33-11	ALL
	A07		W5726	2244R	24		34-33-11	ALL
	A08		W5726	0593	20		38-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40254P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5726	2234B	24		34-33-11	ALL
	B07		W5726	2244B	24		34-33-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W5726	0594	18		38-32-12	ALL
	K	UNUSED						ALL
	PERG	1F	W5726	2234Z			34-33-11	ALL
	PERG	1F	W5726	2244Z			34-33-11	ALL
D40256J		**E002-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0212	0518	20		38-41-13	ALL
	A04		W0212	0520	20		38-41-13	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40256J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0212	0519	20		38-41-13	ALL
	B04		W0212	0521	20		38-41-13	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40256P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5112	0502	20		38-41-13	ALL
	A04		W5112	0504	20		38-41-13	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40256P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	B03		W5112	0503	20		38-41-13	ALL
	B04		W5112	0518	20		38-41-13	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40258J		**E002-01/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0212	0208	22		28-43-11	ALL
	A05		W0212	0094	22		22-11-18	ALL
	A06		W0212	2034B	24		34-33-11	ALL
	A07		W0212	2033R	24		34-33-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0212	0074	22		28-43-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0212	0007	22		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40258J		**E002-01/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B06		W0212	2034R	24		34-33-11	ALL
	B07		W0212	2033B	24		34-33-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0212	3202R	18		28-23-11	ALL
	G		W0212	3202Y	18		28-23-11	ALL
	H		W0212	3202B	18		28-23-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0212	2033Z			34-33-11	ALL
	PERG	1F	W0212	2034Z			34-33-11	ALL
D40258P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5568	1302	22		28-43-11	ALL
	A05		W5568	0021	22		22-11-18	ALL
	A06		W5568	2503B	24		34-33-11	ALL
	A07		W5568	2502R	24		34-33-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5568	1301	22		28-43-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5568	0022	22		34-33-11	ALL
	B06		W5568	2503R	24		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40258P	**E002-01/ /**		**PLUG- (continued)**				**ALL**
B07		W5568	2502B	24		34-33-11	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W5568	3602R	18		28-23-11	ALL
G		W5568	3602Y	18		28-23-11	ALL
H		W5568	3602B	18		28-23-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL
DED		W5568	1301Z			28-43-11	ALL
DED		W5568	1302Z			28-43-11	ALL
PERG	1F	W5568	2502Z			34-33-11	ALL
PERG	1F	W5568	2503Z			34-33-11	ALL
D40260J	**E002-01/ /**		**RCPT-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0212	0518	20		38-41-13	ALL
A04		W0212	0520	20		38-41-13	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0212	0519	20		38-41-13	ALL
B04		W0212	0521	20		38-41-13	ALL
B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40260J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40260P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5110	0534	20		38-41-13	ALL
	A04		W5110	0536	20		38-41-13	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5110	0535	20		38-41-13	ALL
	B04		W5110	0537	20		38-41-13	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40264J		**727A+10/297/L027**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40264J	**727A+10/297/L027**		**RCPT- (continued)**				**ALL**
3		W6134	0515	18		29-25-11	ALL
4		W6134	0516	18		29-25-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6134	0533	20		27-31-11	ALL
9		W6134	0530	18		27-31-11	ALL
10	UNUSED						ALL
D40264P	**727A+10/298/L027**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6124	0566	18		29-25-11	ALL
4		W6124	0567	18		29-25-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6124	0565	20		27-31-11	ALL
9		W6124	0528	20		27-31-11	ALL
10	UNUSED						ALL
D40266J	**547/301/L019**		**RCPT-**				**ALL**
1		W5222	0518	20		27-23-11	ALL
2		W5222	0519	20		27-23-11	ALL
3		W5222	0520	20		27-23-14	ALL
4		W5222	0523	20		29-31-11	ALL
5		W5222	0521	20		29-31-11	ALL
6		W5222	0522	20		29-31-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40266J		**547/301/L019**		**RCPT- (continued)**				**ALL**
	10	UNUSED						ALL
D40266P		**547/301/L019**		**PLUG-**				**ALL**
	1		W5170	0504	20		27-23-11	ALL
	2		W5170	0505	20		27-23-11	ALL
	3		W5170	0506	22		27-23-14	ALL
	4		W5170	0501	20		29-31-11	ALL
	5		W5170	0502	20		29-31-11	ALL
	6		W5170	0503	20		29-31-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
D40268J		**AB1080/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W4134	2203B	20		27-28-11	ALL
	2		W4134	2203R	20		27-28-11	ALL
	3		W4134	3203Y	20		27-28-11	ALL
	4		W4134	3203R	20		27-28-11	ALL
	5		W4134	3203B	20		27-28-11	ALL
	6		W4134	2204B	20		27-28-11	ALL
	7		W4134	2204R	20		27-28-11	ALL
	8		W4134	2202B	20		27-28-11	ALL
	9		W4134	2202R	20		27-28-11	ALL
	10		W4134	1002	20		27-25-11	ALL
	11		W4134	1003	20		27-25-11	ALL
	12		W4134	3204Y	20		27-21-11	ALL
	13		W4134	3204R	20		27-21-11	ALL
	14		W4134	3204B	20		27-21-11	ALL
	15	UNUSED						ALL
	16		W4134	2001R	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40268J	**AB1080/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
17		W4134	2001B	20		27-25-11	ALL
18		W4134	1101	20		27-23-11	ALL
19		W4134	1102	20		27-23-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40268J		**AB1080/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W4134	1002Z			27-25-11	ALL
	S/R		W4134	1003Z			27-25-11	ALL
	S/R		W4134	1101Z			27-23-11	ALL
	S/R		W4134	1102Z			27-23-11	ALL
	S/R		W4134	2001Z			27-25-11	ALL
	S/R		W4134	2202Z			27-28-11	ALL
	S/R		W4134	2203Z			27-28-11	ALL
	S/R		W4134	2204Z			27-28-11	ALL
	S/R		W4134	3203Z			27-28-11	ALL
	S/R		W4134	3204Z			27-21-11	ALL
D40268P		**AB1080/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6136	2203B	20		27-28-11	ALL
	2		W6136	2203R	20		27-28-11	ALL
	3		W6136	3203Y	20		27-28-11	ALL
	4		W6136	3203R	20		27-28-11	ALL
	5		W6136	3203B	20		27-28-11	ALL
	6		W6136	2204B	20		27-28-11	ALL
	7		W6136	2204R	20		27-28-11	ALL
	8		W6136	2202B	20		27-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40268P	**AB1080/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
9		W6136	2202R	20		27-28-11	ALL
10		W6136	1001	20		27-25-11	ALL
11		W6136	1002	20		27-25-11	ALL
12		W6136	3204Y	20		27-21-11	ALL
13		W6136	3204R	20		27-21-11	ALL
14		W6136	3204B	20		27-21-11	ALL
15	UNUSED						ALL
16		W6136	2002R	20		27-25-11	ALL
17		W6136	2002B	20		27-25-11	ALL
18		W6136	1009	20		27-23-11	ALL
19		W6136	1010	20		27-23-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40268P		**AB1080/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W6136	1001Z			27-25-11	ALL
	S/R		W6136	1002Z			27-25-11	ALL
	S/R		W6136	1009Z			27-23-11	ALL
	S/R		W6136	1010Z			27-23-11	ALL
	S/R		W6136	2002Z			27-25-11	ALL
	S/R		W6136	2202Z			27-28-11	ALL
	S/R		W6136	2203Z			27-28-11	ALL
	S/R		W6136	2204Z			27-28-11	ALL
	S/R		W6136	3203Z			27-28-11	ALL
	S/R		W6136	3204Z			27-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40270J	**937/300/L017**		**RCPT, RECTANGULAR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W3144	0085	22		33-27-22	ALL
6		W3144	0086	18		35-21-21	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W3144	0302	22		33-27-22	ALL
11		W3144	0083	22		33-27-22	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W3144	2403R	22		23-31-02	ALL
16		W3144	2403B	22		23-31-02	ALL
D40270P	**937/300/L017**		**PLUG, RECTANGULAR**				**ALL**
1		W3150	0951	20		33-25-22	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W3150	0957	20		33-25-22	ALL
5		W3150	0955	22		33-27-22	ALL
6		W3150	0950	16		35-21-21	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W3150	0952	22		33-27-22	ALL
11		W3150	0953	22		33-27-22	ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40270P		**937/300/L017**		**PLUG, RECTANGULAR (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W3150	2700R	22		23-31-02	ALL
	16		W3150	2700B	22		23-31-02	ALL
D40272J		**937/301/R017**		**RCPT, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W3144	0352	22		33-27-32	ALL
	11	UNUSED						ALL
	12		W3144	2404B	22		23-31-03	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W3144	2404R	22		23-31-03	ALL
	16		W3144	0372	18		35-21-31	ALL
D40272P		**937/301/R017**		**PLUG, RECTANGULAR**				**ALL**
	1		W4250	0951	20		33-25-32	ALL
	2		W4250	0901	20		SPARE	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W4250	0955	22		33-27-32	ALL
	6		W4250	0957	20		33-25-32	ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40272P	**937/301/R017**		**PLUG, RECTANGULAR (continued)**				**ALL**
8		W4250	0903	20		SPARE	ALL
9		W4250	0904	20		SPARE	ALL
10		W4250	0952	22		33-27-32	ALL
11		W4250	0953	22		33-27-32	ALL
12		W4250	2700B	22		23-31-03	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W4250	2700R	22		23-31-03	ALL
16		W4250	0950	16		35-21-31	ALL
D40276J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	1073	24		31-31-14	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0321	2099R	20		27-25-11	ALL
A10		W0321	2099B	20		27-25-11	ALL
B01		W0321	0366	24		31-31-14	ALL
B02		W0321	0368	24		31-31-14	ALL
B03		W0321	0469	20		27-23-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0321	0474	22		31-31-14	ALL
B08		W0321	0476	22		31-31-14	ALL
B09		W0321	0478	22		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40276J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	PERG	1F	W0321	1073Z			31-31-14	ALL
	PERG	1F	W0321	2099Z			27-25-11	ALL
D40276P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W6134	2003R	20		31-31-14	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6134	2206R	20		27-25-11	ALL
	A10		W6134	2206B	20		27-25-11	ALL
	B01		W6134	2003B	20		31-31-14	ALL
	B02		W6134	1001	20		31-31-14	ALL
	B03		W6134	0540	20		27-23-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W6134	3001R	20		31-31-14	ALL
	B08		W6134	3001B	20		31-31-14	ALL
	B09		W6134	3001Y	20		31-31-14	ALL
	B10	UNUSED						ALL
	PERG	1F	W6134	1001Z			31-31-14	ALL
	PERG	1F	W6134	2003Z			31-31-14	ALL
	PERG	1F	W6134	2206Z			27-25-11	ALL
	PERG	1F	W6134	3001Z			31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40292J	**AB0340B/ /**		**RCPT-**				**ALL**
1		W4142	0027	20		52-71-13	ALL
2		W4142	0098	20		52-71-13	ALL
3		W4142	0026	20		52-71-13	ALL
4		W4142	0093	20		52-71-13	ALL
5		W4142	0025	20		52-71-13	ALL
6		W4142	0094	20		52-71-13	ALL
7		W4142	0434	20		52-71-14	ALL
8		W4142	0096	20		52-71-14	ALL
9		W4142	0437	20		52-71-14	ALL
10		W4142	0440	20		52-71-14	ALL
11		W4142	0466	20		52-71-14	ALL
12		W4142	0464	20		52-71-14	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40292J		**AB0340B/ /**		**RCPT- (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
D40292P		**AB0340B/ /**		**PLUG-**				**ALL**
	1		W5160	0533	20		52-71-13	ALL
	2		W5160	0022	20		52-71-13	ALL
	3		W5160	0509	20		52-71-13	ALL
	4		W5160	0004	20		52-71-13	ALL
	5		W5160	0510	20		52-71-13	ALL
	6		W5160	0007	20		52-71-13	ALL
	7		W5160	0535	20		52-71-14	ALL
	8		W5160	0017	20		52-71-14	ALL
	9		W5160	0536	20		52-71-14	ALL
	10		W5160	0539	20		52-71-14	ALL
	11		W5160	0019	20		52-71-14	ALL
	12		W5160	0018	20		52-71-14	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40292P	**AB0340B/ /**		**PLUG- (continued)**				**ALL**
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40296J	**AB0340B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W4142	0031	20		33-51-11	ALL
2		W4142	0032	22		33-51-11	ALL
3		W4142	0033	22		33-51-11	ALL
4		W4142	0036	20		SPARE	ALL
5		W4142	0035	20		33-51-11	ALL
6	UNUSED						ALL
7		W4142	0037	20		SPARE	ALL
8	UNUSED						ALL
9		W4142	5512	20		21-42-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W4142	0038	20		SPARE	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W4142	0034	18		33-41-11	ALL
22	UNUSED						ALL
23		W4142	0462	20		52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40296J		**AB0340B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	24		W4142	0463	20		52-71-14	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W4142	0435	20		52-71-14	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W4142	0641	20		33-44-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38		W4142	0114	20		33-51-12	ALL
	39	UNUSED						ALL
	CAP	Y	W4142	0039	20		SPARE	ALL
D40296P		**AB0340B/ /**		**PLUG-**				**ALL**
	1		W2114	0013	20		33-51-11	ALL
	2		W2114	0014	22		33-51-11	ALL
	3		W2114	0015	22		33-51-11	ALL
	4	UNUSED						ALL
	5		W2114	0021	20		33-51-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2114	0028	20		21-42-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40296P	**AB0340B/ /**		**PLUG- (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W2114	0018	18		33-41-11	ALL
22	UNUSED						ALL
23		W2114	0035	20		52-71-14	ALL
24		W2114	0036	20		52-71-14	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W2114	0045	20		52-71-14	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W2114	0039	20		33-44-11	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38		W2114	0022	20		33-51-12	ALL
39	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40298J		**P018-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0018	0315	20		33-25-11	ALL
	8		W0018	0314	20		33-25-11	ALL
	9		W0018	0317	20		33-25-11	ALL
	10	UNUSED						ALL
	11		W0018	0321	22		33-27-11	ALL
	12		W0018	0322	22		33-27-11	ALL
	13		W0018	0323	22		33-27-11	ALL
	14		W0018	0324	22		33-27-11	ALL
	15		W0018	0355	16		35-21-11	ALL
	16		W0018	0356	16		35-21-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0018	0316	20		33-25-11	ALL
D40298P		**P018-00/ /**		**PLUG-CTR CEILING**				**ALL**
	1		W4250	0901	20		SPARE	ALL
	2	UNUSED						ALL
	3		W4250	0903	20		SPARE	ALL
	4		W4250	0904	20		SPARE	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W4250	0907	20		33-25-32	ALL
	8		W4250	0908	20		33-25-31	ALL
	9		W4250	0909	20		33-25-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40298P	**P018-00/ /**		**PLUG-CTR CEILING (continued)**				**ALL**
10	UNUSED						ALL
11		W4250	0911	22		33-27-31	ALL
12		W4250	0912	22		33-27-31	ALL
13		W4250	0913	22		33-27-31	ALL
14		W4250	0914	22		33-27-31	ALL
15		W4250	0915	16		35-21-31	ALL
16		W4250	0916	16		35-21-31	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W4250	0919	20		33-25-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40302J		**AB0500DL/ /**		**RCPT-**				**ALL**
	1		W5526	0511	24		32-44-11	ALL
	2		W5526	0513	24		32-44-11	ALL
	3		W5526	0514	24		32-44-11	ALL
	4		W5526	0516	24		32-44-11	ALL
	5		W5526	0517	24		32-44-11	ALL
	6		W5526	0591	22		32-41-11	ALL
	7		W5526	0601	20		78-34-11	ALL
	8		W5526	0602	20		78-34-11	ALL
	9		W5526	6007R	20		26-12-11	ALL
	10		W5526	5516	20		SPARE	ALL
	11		W5526	5517	20		SPARE	ALL
	12	UNUSED						ALL
	13		W5526	5530	20		29-11-11	ALL
	14		W5526	5531	20		29-11-11	ALL
	15		W5526	6001R	20		26-12-11	ALL
D40302P		**AB0500DL/ /**		**PLUG-**				**ALL**
	1		W5222	0511	20		32-44-11	ALL
	2		W5222	0513	20		32-44-11	ALL
	3		W5222	0514	20		32-44-11	ALL
	4		W5222	0516	20		32-44-11	ALL
	5		W5222	0517	20		32-44-11	ALL
	6		W5222	0591	20		32-41-11	ALL
	7		W5222	0534	20		78-34-11	ALL
	8		W5222	0535	20		78-34-11	ALL
	9		W5222	0509R	20		26-12-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W5222	0504	20		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40302P	**AB0500DL/ /**		**PLUG- (continued)**				**ALL**
14		W5222	0505	20		29-11-11	ALL
15		W5222	0500R	20		26-12-11	ALL
D40306J	**AB0410/205/R039**		**RECPT-CONDUCTIVE**				**ALL**
A01		W6588	3603R	20		28-23-11	ALL
A02		W6588	3603Y	20		28-23-11	ALL
A03		W6588	3603B	20		28-23-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W6588	3601R	20		28-23-11	ALL
A07		W6588	3601B	20		28-23-11	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W6588	3601Y	20		28-23-11	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W6588	6001	22		28-43-11	ALL
D40306P	**AB0410/205/R039**		**PLUG-**				**ALL**
A01		W6210	3203R	20		28-23-11	ALL
A02		W6210	3203Y	20		28-23-11	ALL
A03		W6210	3203B	20		28-23-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40306P		**AB0410/205/R039**		**PLUG- (continued)**				**ALL**
	A06		W6210	3201R	20		28-23-11	ALL
	A07		W6210	3201B	20		28-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W6210	3201Y	20		28-23-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6210	0531	22		28-43-11	ALL
D40312J		**AB0500DL/ /**		**RCPT**				**ALL**
	1		W5134	0503	22		27-23-14	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5134	0570	18		29-25-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40312P	**AB0500DL/ /**		**PLUG-**				**ALL**
1		W5224	0503	22		27-23-14	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5224	0568	18		29-25-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40314J	**AB0410/205/R039**		**RCPT - CONDUCTIVE**				**ALL**
A01		W6732	4502G	20		32-46-11	ALL
A02		W6732	4502W	20		32-46-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W6732	2213B	22		32-64-11	ALL
A06		W6732	2214B	22		32-64-11	ALL
A07	UNUSED						ALL
A08		W6732	2240B	22		32-31-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W6732	2213R	22		32-64-11	ALL
B06		W6732	2214R	22		32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40314J		**AB0410/205/R039**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W6732	2240R	22		32-31-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6732	4502Z			32-46-11	ALL
D40314P		**AB0410/205/R039**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5156	4501G	20		32-46-11	ALL
	A02		W5156	4501W	20		32-46-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5156	2213B	22		32-64-11	ALL
	A06		W5156	2214B	22		32-64-11	ALL
	A07	UNUSED						ALL
	A08		W5156	2240B	22		32-31-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5156	2213R	22		32-64-11	ALL
	B06		W5156	2214R	22		32-64-11	ALL
	B07	UNUSED						ALL
	B08		W5156	2240R	22		32-31-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	4501Z			32-46-11	ALL
D40318J		**AB0500DL/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40318J	**AB0500DL/ /**		**RCPT- (continued)**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5530	6004	20		78-34-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5530	0518	22		29-33-11	ALL
16		W5530	0517	22		29-33-11	ALL
17		W5530	6001	20		78-34-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5530	1101	22		31-65-14	ALL
24		W5530	0030	22		31-31-15	ALL
S/R		W5530	1101Z			31-65-14	ALL
D40318P	**AB0500DL/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40318P		**AB0500DL/ /**		**PLUG- (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5222	0532	20		78-34-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5222	0506	22		29-33-11	ALL
	16		W5222	0507	22		29-33-11	ALL
	17		W5222	0531	20		78-34-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W5222	1508	22		31-65-14	ALL
	24		W5222	0524	20		31-31-15	ALL
	S/R		W5222	1508Z			31-65-14	ALL
D40326J		**E004-01/ /**		**RCPT-**				**ALL**
	1		W0410	0104	24		21-51-21	ALL
	2		W0410	0513	24		21-51-21	ALL
	3		W0410	0517	24		21-51-21	ALL
	4		W0410	0516	24		21-51-21	ALL
	5		W0410	0117	24		21-51-21	ALL
	6	UNUSED						ALL
	7		W0410	0515	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40326J	**E004-01/ /**		**RCPT- (continued)**				**ALL**
8		W0410	0521	24		36-11-22	ALL
9		W0410	0522	24		36-11-22	ALL
10		W0410	0523	24		36-11-22	ALL
11		W0410	0565	24		36-11-22	ALL
12		W0410	0568	24		36-11-22	ALL
13		W0410	0569	24		36-11-22	ALL
14		W0410	0046	14		21-25-11	ALL
15		W0410	0570	24		36-11-22	ALL
16		W0410	0047	14		21-25-11	ALL
17		W0410	0574	24		36-11-22	ALL
18		W0410	0048	14		21-25-11	ALL
19		W0410	0584	24		36-11-23	ALL
20	UNUSED						ALL
21		W0410	0585	24		36-11-23	ALL
22	UNUSED						ALL
23		W0410	0105	24		21-51-21	ALL
24	UNUSED						ALL
25	UNUSED						ALL
D40326P	**E004-01/ /**		**PLUG**				**ALL**
1		W6412	0205	24		21-51-21	ALL
2		W6412	0206	24		21-51-21	ALL
3		W6412	0207	24		21-51-21	ALL
4		W6412	0208	24		21-51-21	ALL
5		W6412	0209	24		21-51-21	ALL
6	UNUSED						ALL
7		W6412	0211	24		21-51-21	ALL
8		W6412	5578	24		36-11-22	ALL
9		W6412	5577	24		36-11-22	ALL
10		W6412	5576	24		36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40326P		**E004-01/ /**		**PLUG (continued)**				**ALL**
	11		W6412	5575	24		36-11-22	ALL
	12		W6412	5574	24		36-11-22	ALL
	13		W6412	5573	24		36-11-22	ALL
	14		W6412	5501	14		21-25-11	ALL
	15		W6412	5572	24		36-11-22	ALL
	16		W6412	5502	14		21-25-11	ALL
	17		W6412	5571	24		36-11-22	ALL
	18		W6412	5503	14		21-25-11	ALL
	19		W6412	5581	24		36-11-23	ALL
	20	UNUSED						ALL
	21		W6412	5580	24		36-11-23	ALL
	22	UNUSED						ALL
	23		W6412	0210	24		21-51-21	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D40330J		**E004-01/ /**		**RCPT-**				**ALL**
	1		W0410	0464	24		21-25-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40330J	**E004-01/ /**		**RCPT- (continued)**				**ALL**
14		W0410	0046	14		21-25-11	ALL
15	UNUSED						ALL
16		W0410	0047	14		21-25-11	ALL
17	UNUSED						ALL
18		W0410	0048	14		21-25-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D40330P	**E004-01/ /**		**PLUG-**				**ALL**
1		W6230	0326	22		21-25-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W6230	0323	14		21-25-11	ALL
15	UNUSED						ALL
16		W6230	0324	14		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40330P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	17	UNUSED						ALL
	18		W6230	0325	14		21-25-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D40338J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	0111	22		24-23-51	ALL
	A02		W0422	0115	22		24-28-41	ALL
	A03		W0422	0123	24		24-28-41	ALL
	A04		W0422	0104	22		24-23-11	ALL
	A05		W0422	2025B	22		24-22-11	ALL
	A06		W0422	2419R	22		52-71-11	ALL
	A07		W0422	0085	22		24-22-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0422	0220	22		24-28-41	ALL
	B02	UNUSED						ALL
	B03		W0422	0103	22		24-23-11	ALL
	B04		W0422	0090	22		24-22-21	ALL
	B05		W0422	2025R	22		24-22-11	ALL
	B06		W0422	2419B	22		52-71-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40338J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W0422	1011	20		24-41-11	ALL
	K	UNUSED						ALL
	PERG	1F	W0422	1011Z			24-41-11	ALL
	PERG	1F	W0422	2025Z			24-22-11	ALL
D40338P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5110	0501	22		24-23-51	ALL
	A02		W5110	0503	22		24-28-41	ALL
	A03		W5110	0505	24		24-28-41	ALL
	A04		W5110	0508	22		24-23-11	ALL
	A05		W5110	2001B	22		24-22-11	ALL
	A06		W5110	2419R	20		52-71-11	ALL
	A07		W5110	0532	22		24-22-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5110	0516	20		SPARE	ALL
	B01		W5110	0502	22		24-28-41	ALL
	B02	UNUSED						ALL
	B03		W5110	0507	22		24-23-11	ALL
	B04		W5110	0519	22		24-22-21	ALL
	B05		W5110	2001R	22		24-22-11	ALL
	B06		W5110	2419B	20		52-71-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40338P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W5110	1001	20		24-41-11	ALL
	K	UNUSED						ALL
	PERG	1F	W5110	1001Z			24-41-11	ALL
	PERG	1F	W5110	2001Z			24-22-11	ALL
D40340J		**E002-01/ /**		**RCPT-BACKSHELL (ZERO LENGTH)**				**ALL**
	A01		W0212	0211	22		21-27-21	ALL
	A02	UNUSED						ALL
	A03		W0212	2020R	22		24-22-11	ALL
	A04		W0212	0024	22		24-22-11	ALL
	A05		W0212	0041	24		24-28-41	ALL
	A06		W0212	3003R	20		24-22-11	ALL
	A07		W0212	3006R	20		24-23-11	ALL
	A08		W0212	3006Y	20		24-23-11	ALL
	A09		W0212	4004B	22		24-24-11	ALL
	A10		W0212	4004Y	22		24-24-11	ALL
	B01	UNUSED						ALL
	B02		W0212	2020B	22		24-22-11	ALL
	B03		W0212	0019	22		24-22-11	ALL
	B04		W0212	0020	22		24-22-11	ALL
	B05		W0212	3003B	20		24-22-11	ALL
	B06		W0212	3003Y	20		24-22-11	ALL
	B07		W0212	3006B	20		24-23-11	ALL
	B08		W0212	4004R	22		24-24-11	ALL
	B09		W0212	4004G	22		24-24-11	ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40340J	**E002-01/ /**		**RCPT-BACKSHELL (ZERO LENGTH) (continued)**				**ALL**
G	UNUSED						ALL
H		W0212	1002	20		24-41-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERB		W0212	1002Z			24-41-11	ALL
PERB		W0212	2020Z			24-22-11	ALL
PERB		W0212	4004Z			24-24-11	ALL
D40340P	**E002-01/ /**		**PLUG-**				**ALL**
A01		W5110	5501	22		21-27-21	ALL
A02	UNUSED						ALL
A03		W5110	2001R	22		24-22-11	ALL
A04		W5110	0509	22		24-22-11	ALL
A05		W5110	0505	24		24-28-41	ALL
A06		W5110	3201R	20		24-22-11	ALL
A07		W5110	3202R	20		24-23-11	ALL
A08		W5110	3202Y	20		24-23-11	ALL
A09		W5110	4101B	22		24-24-11	ALL
A10		W5110	4101Y	22		24-24-11	ALL
B01		W5110	0516	20		SPARE	ALL
B02		W5110	2001B	22		24-22-11	ALL
B03		W5110	0513	22		24-22-11	ALL
B04		W5110	0533	22		24-22-11	ALL
B05		W5110	3201B	20		24-22-11	ALL
B06		W5110	3201Y	20		24-22-11	ALL
B07		W5110	3202B	20		24-23-11	ALL
B08		W5110	4101R	22		24-24-11	ALL
B09		W5110	4101G	22		24-24-11	ALL
B10	UNUSED						ALL
F	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40340P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	G	UNUSED						ALL
	H		W5110	1001	20		24-41-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERB		W5110	1001Z			24-41-11	ALL
	PERB		W5110	2001Z			24-22-11	ALL
	PERB		W5110	4101Z			24-24-11	ALL
D40342J		**E002-01/ /**		**RCPT CONDUCTIVE-W/ BACKSHELL ZERO LENGTH**				**ALL**
	A01		W0212	4001R	20		24-21-11	ALL
	A02		W0212	4001G	20		24-21-11	ALL
	A03		W0212	0070	20		28-23-11	ALL
	A04		W0212	0205	20		28-23-11	ALL
	A05		W0212	0072	20		28-23-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0212	4001B	20		24-21-11	ALL
	B02		W0212	4001Y	20		24-21-11	ALL
	B03		W0212	0076	20		38-32-12	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0212	0075	18		38-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40342J	**E002-01/ /**		**RCPT CONDUCTIVE-W/ BACKSHELL ZERO LENGTH (continued)**				**ALL**
G	UNUSED						ALL
H		W0212	1002	20		24-41-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERB		W0212	1002Z			24-41-11	ALL
PERB		W0212	4001Z			24-21-11	ALL
D40342P	**E002-01/ /**		**PLUG-**				**ALL**
A01		W5112	3206R	20		24-21-11	ALL
A02		W5112	1106	20		24-21-11	ALL
A03		W5112	0513	20		28-23-11	ALL
A04		W5112	0514	20		28-23-11	ALL
A05		W5112	0515	20		28-23-11	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5112	3206B	20		24-21-11	ALL
B02		W5112	3206Y	20		24-21-11	ALL
B03		W5112	0517	20		38-32-12	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W5112	0516	18		38-32-12	ALL
G	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40342P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	H		W5112	1001	20		24-41-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERB		W5112	1001Z			24-41-11	ALL
	PERB		W5112	1106Z			24-21-11	ALL
	PERB		W5112	3206Z			24-21-11	ALL
D40344J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0131	2510Z			32-41-11	ALL
	A11		W0131	2510R	24		32-41-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0131	2575R	24		32-42-12	ALL
	A16		W0131	2575B	24		32-42-12	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0131	0068	22		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40344J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B03		W0131	0089	24		32-42-11	ALL
	B04		W0131	0090	24		32-42-11	ALL
	B05		W0131	0112	24		32-41-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0131	2510B	24		32-41-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0131	0398	22		32-46-11	ALL
	PERG	1F	W0131	2575Z			32-42-12	ALL
D40344P		**E001-03/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40344P		**E001-03/ /**		**PLUG- (continued)**				**ALL**
	A10		W5610	2251Z			32-41-11	ALL
	A11		W5610	2251R	22		32-41-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W5610	2501R	24		32-42-12	ALL
	A16		W5610	2501B	24		32-42-12	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5610	0528	22		32-41-11	ALL
	B03		W5610	0510	24		32-42-11	ALL
	B04		W5610	0512	24		32-42-11	ALL
	B05		W5610	0591	22		32-41-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W5610	2251B	22		32-41-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40344P	**E001-03/ /**		**PLUG- (continued)**				**ALL**
B19	UNUSED						ALL
B20		W5610	0025	22		32-46-11	ALL
PERG	1F	W5610	2501Z			32-42-12	ALL
D40348J	**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0220	0140	24		31-31-15	ALL
A02	UNUSED						ALL
A03		W0220	0365R	20		26-11-21	ALL
A04		W0220	0513	24		75-11-11	ALL
A05		W0220	0307	24		31-35-05	ALL
A06		W0220	0405R	20		26-11-21	ALL
A07		W0220	0216	24		80-11-11	ALL
A08		W0220	2044B	24		73-24-11	ALL
A09		W0220	1101R	20		26-12-11	ALL
A10		W0220	0303	24		26-16-21	ALL
A11		W0220	2201R	24		31-35-04	ALL
A12		W0220	0350R	22		26-11-21	ALL
A13		W0220	2050R	24		31-31-13	ALL
A14		W0220	0412R	20		26-12-11	ALL
A15		W0220	0215	20		76-21-11	ALL
A16		W0220	0360R	22		26-11-21	ALL
A17		W0220	0362R	22		26-11-21	ALL
A18		W0220	0409R	22		26-11-21	ALL
A19		W0220	0411R	20		26-12-11	ALL
A20		W0220	0407R	22		26-11-21	ALL
B01		W0220	0141	24		31-31-15	ALL
B02	UNUSED						ALL
B03		W0220	0103	22		49-62-11	ALL
B04		W0220	0331R	20		26-12-11	ALL
B05		W0220	0308	24		31-35-05	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40348J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06		W0220	0404R	20		26-11-21	ALL
	B07		W0220	0220	20		80-11-11	ALL
	B08		W0220	2044R	24		73-24-11	ALL
	B09	UNUSED						ALL
	B10		W0220	0304	24		26-16-22	ALL
	B11		W0220	2201B	24		31-35-04	ALL
	B12		W0220	0353R	22		26-11-21	ALL
	B13		W0220	2050B	24		31-31-13	ALL
	B14		W0220	0413R	20		26-12-11	ALL
	B15		W0220	0359R	22		26-11-21	ALL
	B16		W0220	0361R	22		26-11-21	ALL
	B17		W0220	0363R	22		26-11-21	ALL
	B18		W0220	0410R	20		26-12-11	ALL
	B19		W0220	0355R	22		26-11-21	ALL
	B20		W0220	0414R	20		26-12-11	ALL
	DED		W0220	1101Z			26-12-11	ALL
	PERG	1F	W0220	2044Z			73-24-11	ALL
	PERG	1F	W0220	2050Z			31-31-13	ALL
	PERG	1F	W0220	2201Z			31-35-04	ALL
D40348P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5610	0001	24		31-31-15	ALL
	A02		W5610	0501	22		SPARE	ALL
	A03		W5610	6058R	20		26-11-21	ALL
	A04		W5610	0593	24		75-11-11	ALL
	A05		W5610	0026	24		31-35-05	ALL
	A06		W5610	6064R	20		26-11-21	ALL
	A07		W5610	6043	24		80-11-11	ALL
	A08		W5610	2601B	24		73-24-11	ALL
	A09		W5610	6042R	22		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40348P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A10		W5610	6048	24		26-16-21	ALL
A11		W5610	2010R	24		31-35-04	ALL
A12		W5610	6018R	22		26-11-21	ALL
A13		W5610	2004R	24		31-31-13	ALL
A14		W5610	6060R	20		26-12-11	ALL
A15		W5610	6027	20		76-21-11	ALL
A16		W5610	6029R	22		26-11-21	ALL
A17		W5610	6031R	22		26-11-21	ALL
A18		W5610	6033R	22		26-11-21	ALL
A19		W5610	6035R	20		26-12-11	ALL
A20		W5610	6037R	22		26-11-21	ALL
B01		W5610	0002	24		31-31-15	ALL
B02		W5610	0502	22		SPARE	ALL
B03		W5610	0504	22		49-62-11	ALL
B04		W5610	6059R	20		26-12-11	ALL
B05		W5610	0027	24		31-35-05	ALL
B06		W5610	6063R	20		26-11-21	ALL
B07		W5610	6041	20		80-11-11	ALL
B08		W5610	2601R	24		73-24-11	ALL
B09	UNUSED						ALL
B10		W5610	6049	24		26-16-22	ALL
B11		W5610	2010B	24		31-35-04	ALL
B12		W5610	6019R	22		26-11-21	ALL
B13		W5610	2004B	24		31-31-13	ALL
B14		W5610	6061R	20		26-12-11	ALL
B15		W5610	6028R	22		26-11-21	ALL
B16		W5610	6030R	22		26-11-21	ALL
B17		W5610	6032R	22		26-11-21	ALL
B18		W5610	6034R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40348P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B19		W5610	6036R	22		26-11-21	ALL
	B20		W5610	6062R	20		26-12-11	ALL
	PERG	1F	W5610	2004Z			31-31-13	ALL
	PERG	1F	W5610	2010Z			31-35-04	ALL
	PERG	1F	W5610	2601Z			73-24-11	ALL
D40349J		**AB0358/ /**		**RCPT-**				**ALL**
	1		W3144	2261R	20		23-70-11	ALL
	2		W3144	2261B	20		23-70-11	ALL
	3		W3144	1161	20		23-70-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D40349P		**AB0358/ /**		**PLUG**				**ALL**
	1		W3805	2001R	20		23-70-11	ALL
	2		W3805	2001B	20		23-70-11	ALL
	3		W3805	0001	20		23-70-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
D40350J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0075	24		31-31-15	ALL
	A02		W0321	2101R	22		28-41-11	ALL
	A03		W0321	1004R	20		26-11-21	ALL
	A04		W0321	0402	24		26-16-21	ALL
	A05		W0321	0076	24		31-31-15	ALL
	A06		W0321	0403	24		26-16-22	ALL
	A07		W0321	0297	24		29-33-11	ALL
	A08		W0321	1005R	20		26-11-21	ALL
	A09		W0321	2151B	24		32-41-11	ALL
	A10		W0321	2260R	24		31-31-13	ALL
	B01		W0321	0511R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40350J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B02		W0321	2101B	22		28-41-11	ALL
B03		W0321	0072	24		31-31-15	ALL
B04		W0321	0310	20		78-34-21	ALL
B05		W0321	0311	20		78-34-21	ALL
B06		W0321	0296	24		29-33-11	ALL
B07		W0321	0313	22		32-41-11	ALL
B08		W0321	2151R	24		32-41-11	ALL
B09		W0321	2151Z			32-41-11	ALL
B10		W0321	2260B	24		31-31-13	ALL
DED		W0321	1004Z			26-11-21	ALL
DED		W0321	1005Z			26-11-21	ALL
PERG	1F	W0321	2101Z			28-41-11	ALL
PERG	1F	W0321	2260Z			31-31-13	ALL
D40350P	**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5610	0001	24		31-31-15	ALL
A02		W5610	2604R	22		28-41-11	ALL
A03		W5610	6063R	20		26-11-21	ALL
A04		W5610	6048	24		26-16-21	ALL
A05		W5610	0002	24		31-31-15	ALL
A06		W5610	6049	24		26-16-22	ALL
A07		W5610	0524	24		29-33-11	ALL
A08		W5610	6064R	20		26-11-21	ALL
A09		W5610	2251B	22		32-41-11	ALL
A10		W5610	2004R	24		31-31-13	ALL
B01		W5610	6013R	20		26-12-11	ALL
B02		W5610	2604B	22		28-41-11	ALL
B03		W5610	0006	24		31-31-15	ALL
B04		W5610	0511	20		78-34-21	ALL
B05		W5610	0509	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40350P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B06		W5610	0523	24		29-33-11	ALL
	B07		W5610	0528	22		32-41-11	ALL
	B08		W5610	2251R	22		32-41-11	ALL
	B09		W5610	2251Z			32-41-11	ALL
	B10		W5610	2004B	24		31-31-13	ALL
	PERG	1F	W5610	2004Z			31-31-13	ALL
	PERG	1F	W5610	2604Z			28-41-11	ALL
D40351J		**AB0358/ /**		**RCPT-**				**ALL**
	1		W3701	0002	20		23-70-11	ALL
	2		W3701	0003	20		23-70-11	ALL
	3		W3701	2502B	24		23-70-11	ALL
	4		W3701	2502W	24		23-70-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3701	2502Z			23-70-11	ALL
D40351P		**AB0358/ /**		**PLUG**				**ALL**
	1		W3805	0002	20		23-70-11	ALL
	2		W3805	0004	20		23-70-11	ALL
	3		W3805	2501B	24		23-70-11	ALL
	4		W3805	2501W	24		23-70-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40351P		**AB0358/ /**		**PLUG (continued)**				**ALL**
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3805	2501Z			23-70-11	ALL
D40352J		**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE**				**ALL**
	1		W0044	1004R	20		26-11-31	ALL
	2	UNUSED						ALL
	3		W0044	0500	20		49-62-11	ALL
	4		W0044	0001	20		24-11-11	ALL
	5		W0044	0047	22		24-41-11	ALL
	6		W0044	0003	20		24-11-21	ALL
	7		W0044	0896	24		24-28-41	ALL
	8		W0044	0005	20		24-22-31	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0044	0615	22		31-33-01	ALL
	13		W0044	0021	24		24-31-11	ALL
	14		W0044	0582	22		24-28-11	ALL
	15		W0044	0586	24		24-33-13	ALL
	16		W0044	0583	22		24-28-11	ALL
	17		W0044	0587	24		24-33-13	ALL
	18		W0044	0584	24		24-33-13	ALL
	19		W0044	0857	20		27-25-11	ALL
	20		W0044	0853	20		27-25-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40352J		**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE (continued)**				**ALL**
	23		W0044	0048	20		24-41-11	ALL
	24	UNUSED						ALL
	25		W0044	0897	24		24-28-41	ALL
	26		W0044	0589	24		24-33-13	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0044	0585	24		24-33-13	ALL
	30		W0044	0588	24		24-33-13	ALL
	31		W0044	0850	20		27-23-11	ALL
	32		W0044	0592	20		27-81-51	ALL
D40352P		**P006-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5612	6012R	20		26-11-31	ALL
	2	UNUSED						ALL
	3		W5612	0505	20		49-62-11	ALL
	4		W5612	1108	20		24-11-11	ALL
	5		W5612	0536	22		24-41-11	ALL
	6		W5612	1109	20		24-11-21	ALL
	7		W5612	0207	24		24-28-41	ALL
	8		W5612	0521	20		24-22-31	ALL
	9		W5612	2204R	24		SPARE	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5612	0550	22		31-33-01	ALL
	13		W5612	0507	24		24-31-11	ALL
	14		W5612	0541	22		24-28-11	ALL
	15		W5612	0545	24		24-33-13	ALL
	16		W5612	0542	22		24-28-11	ALL
	17		W5612	0546	24		24-33-13	ALL
	18		W5612	0543	24		24-33-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40352P	**P006-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
19		W5612	0206	20		27-25-11	ALL
20		W5612	0205	20		27-25-11	ALL
21		W5612	0554	24		SPARE	ALL
22		W5612	0555	22		SPARE	ALL
23		W5612	1003	20		24-41-11	ALL
24		W5612	0501	20		SPARE	ALL
25		W5612	0208	24		24-28-41	ALL
26		W5612	0548	24		24-33-13	ALL
27	UNUSED						ALL
28		W5612	2204B	24		SPARE	ALL
29		W5612	0544	24		24-33-13	ALL
30		W5612	0547	24		24-33-13	ALL
31		W5612	0204	20		27-23-11	ALL
32		W5612	0549	20		27-81-51	ALL
S/R		W5612	1003Z			24-41-11	ALL
S/R		W5612	1108Z			24-11-11	ALL
S/R		W5612	1109Z			24-11-21	ALL
DED		W5612	2204Z			SPARE	ALL
D40356J	**E004-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0422	0052	22		29-11-11	ALL
A02		W0422	0536	22		30-11-11	ALL
A03	UNUSED						ALL
A04		W0422	1015	22		24-23-11	ALL
A05		W0422	0121	24		24-28-41	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0422	1014	20		24-11-21	ALL
A10		W0422	1010	20		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40356J		**E004-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B01		W0422	0068	20		33-44-12	ALL
	B02	UNUSED						ALL
	B03		W0422	0537	22		30-11-11	ALL
	B04		W0422	1016	22		24-23-11	ALL
	B05		W0422	1008	24		24-28-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0422	1008Z			24-28-41	ALL
	PERG	1F	W0422	1010Z			24-41-11	ALL
	PERG	1F	W0422	1014Z			24-11-21	ALL
	PERG	1F	W0422	1015Z			24-23-11	ALL
	PERG	1F	W0422	1016Z			24-23-11	ALL
D40356P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5612	0531	22		29-11-11	ALL
	A02		W5612	0563	22		30-11-11	ALL
	A03	UNUSED						ALL
	A04		W5612	2001R	22		24-23-11	ALL
	A05		W5612	0515	24		24-28-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40356P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
A09		W5612	1109	20		24-11-21	ALL
A10		W5612	1003	20		24-41-11	ALL
B01		W5612	1201	20		33-44-12	ALL
B02	UNUSED						ALL
B03		W5612	0564	22		30-11-11	ALL
B04		W5612	2001B	22		24-23-11	ALL
B05		W5612	1002	24		24-28-41	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
DED		W5612	1201Z			33-44-12	ALL
PERG	1F	W5612	1002Z			24-28-41	ALL
PERG	1F	W5612	1003Z			24-41-11	ALL
PERG	1F	W5612	1109Z			24-11-21	ALL
PERG	1F	W5612	2001Z			24-23-11	ALL
D40357J	**AB0358/ /**		**RCPT-**				**ALL**
1		W3709	3501R	24		23-70-11	ALL
2		W3709	3501Y	24		23-70-11	ALL
3	UNUSED						ALL
4		W3709	3501B	24		23-70-11	ALL
5		W3709	2501R	24		23-70-11	ALL
6		W3709	2501B	24		23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40357J		**AB0358/ /**		**RCPT- (continued)**				**ALL**
	7		W3709	0003	24		31-65-42	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3709	2501Z			23-70-11	ALL
	S/R		W3709	3501Z			23-70-11	ALL
D40357P		**AB0358/ /**		**PLUG**				**ALL**
	1		W3805	3501R	24		23-70-11	ALL
	2		W3805	3501Y	24		23-70-11	ALL
	3	UNUSED						ALL
	4		W3805	3501B	24		23-70-11	ALL
	5		W3805	2505R	24		23-70-11	ALL
	6		W3805	2505B	24		23-70-11	ALL
	7		W3805	0003	24		23-70-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3805	2505Z			23-70-11	ALL
	S/R		W3805	3501Z			23-70-11	ALL
D40358J		**E002-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02		W0212	0034	22		24-22-31	ALL
	A03		W0212	0079	22		24-22-31	ALL
	A04	UNUSED						ALL
	A05		W0212	2039R	22		24-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40358J	**E002-01/ /**		**RCPT- (continued)**				**ALL**
A06		W0212	2039B	22		24-23-11	ALL
A07		W0212	0039	24		24-28-41	ALL
A08		W0212	1003	24		24-28-41	ALL
A09		W0212	0021	22		24-22-11	ALL
A10		W0212	2009R	22		24-22-31	ALL
A11		W0212	0025	20		24-22-31	ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0212	0036	22		24-22-31	ALL
B02		W0212	2005R	22		24-22-11	ALL
B03		W0212	2005B	22		24-22-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0212	0033	22		24-22-31	ALL
B07		W0212	0035	22		24-22-31	ALL
B08	UNUSED						ALL
B09		W0212	0031	22		24-22-31	ALL
B10		W0212	2009B	22		24-22-31	ALL
B11		W0212	1001	20		24-11-11	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40358J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0212	1001Z			24-11-11	ALL
	PERG	1F	W0212	1003Z			24-28-41	ALL
	PERG	1F	W0212	2039Z			24-23-11	ALL
D40358P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W5612	0526	22		24-22-31	ALL
	A03		W5612	0553	22		24-22-31	ALL
	A04		W5612	2207R	22		SPARE	ALL
	A05		W5612	2001R	22		24-23-11	ALL
	A06		W5612	2001B	22		24-23-11	ALL
	A07		W5612	0515	24		24-28-41	ALL
	A08		W5612	1002	24		24-28-41	ALL
	A09		W5612	0539	22		24-22-11	ALL
	A10		W5612	2206R	22		24-22-31	ALL
	A11		W5612	0521	20		24-22-31	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40358P	**E002-01/ /**		**PLUG- (continued)**				**ALL**
A20	UNUSED						ALL
B01		W5612	0525	22		24-22-31	ALL
B02		W5612	2201R	22		24-22-11	ALL
B03		W5612	2201B	22		24-22-11	ALL
B04		W5612	2204R	24		SPARE	ALL
B05		W5612	2204B	24		SPARE	ALL
B06		W5612	0522	22		24-22-31	ALL
B07		W5612	0524	22		24-22-31	ALL
B08		W5612	2207B	22		SPARE	ALL
B09		W5612	0540	22		24-22-31	ALL
B10		W5612	2206B	22		24-22-31	ALL
B11		W5612	1108	20		24-11-11	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
DED		W5612	2204Z			SPARE	ALL
PERG	1F	W5612	1002Z			24-28-41	ALL
PERG	1F	W5612	1108Z			24-11-11	ALL
PERG	1F	W5612	2001Z			24-23-11	ALL
D40360J	**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0220	0024	20		33-44-12	ALL
A02		W0220	2003R	22		24-22-11	ALL
A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40360J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A04		W0220	0411	22		30-11-11	ALL
	A05		W0220	0139	24		31-31-15	ALL
	A06		W0220	0105	20		49-62-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0220	2005B	22		24-23-11	ALL
	A10		W0220	0037	22		29-11-11	ALL
	B01		W0220	2003B	22		24-22-11	ALL
	B02		W0220	2004R	22		24-22-31	ALL
	B03		W0220	2004B	22		24-22-31	ALL
	B04	UNUSED						ALL
	B05		W0220	0368R	20		26-11-31	ALL
	B06	UNUSED						ALL
	B07		W0220	0006	24		24-31-11	ALL
	B08	UNUSED						ALL
	B09		W0220	0412	22		30-11-11	ALL
	B10		W0220	2005R	22		24-23-11	ALL
D40360P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5612	1201	20		33-44-12	ALL
	A02		W5612	2201R	22		24-22-11	ALL
	A03	UNUSED						ALL
	A04		W5612	0563	22		30-11-11	ALL
	A05		W5612	0210	24		31-31-15	ALL
	A06		W5612	0505	20		49-62-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5612	2203B	22		24-23-11	ALL
	A10		W5612	0531	22		29-11-11	ALL
	B01		W5612	2201B	22		24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40360P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B02		W5612	2206R	22		24-22-31	ALL
B03		W5612	2206B	22		24-22-31	ALL
B04	UNUSED						ALL
B05		W5612	6012R	20		26-11-31	ALL
B06		W5612	0501	20		SPARE	ALL
B07		W5612	0507	24		24-31-11	ALL
B08	UNUSED						ALL
B09		W5612	0564	22		30-11-11	ALL
B10		W5612	2203R	22		24-23-11	ALL
DED		W5612	1201Z			33-44-12	ALL
D40362J	**E003-02/ /**		**RCPT-**				**ALL**
A01	UNUSED						ALL
A02		W0321	0171	22		24-28-11	ALL
A03	UNUSED						ALL
A04		W0321	0174	24		24-33-13	ALL
A05		W0321	0176	24		24-33-13	ALL
A06		W0321	0172	24		24-33-13	ALL
A07	UNUSED						ALL
A08		W0321	0470	20		27-25-11	ALL
A09		W0321	0469	20		27-23-11	ALL
A10	UNUSED						ALL
B01		W0321	0074	24		31-31-15	ALL
B02		W0321	0170	22		24-28-11	ALL
B03	UNUSED						ALL
B04		W0321	0175	24		24-33-13	ALL
B05		W0321	0177	24		24-33-13	ALL
B06		W0321	0173	24		24-33-13	ALL
B07	UNUSED						ALL
B08		W0321	0471	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40362J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	B09	UNUSED						ALL
	B10		W0321	0390	22		31-33-01	ALL
D40362P		**E003-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W5612	0542	22		24-28-11	ALL
	A03		W5612	0554	24		SPARE	ALL
	A04		W5612	0545	24		24-33-13	ALL
	A05		W5612	0547	24		24-33-13	ALL
	A06		W5612	0543	24		24-33-13	ALL
	A07		W5612	2207R	22		SPARE	ALL
	A08		W5612	0205	20		27-25-11	ALL
	A09		W5612	0204	20		27-23-11	ALL
	A10		W5612	0555	22		SPARE	ALL
	B01		W5612	0210	24		31-31-15	ALL
	B02		W5612	0541	22		24-28-11	ALL
	B03	UNUSED						ALL
	B04		W5612	0546	24		24-33-13	ALL
	B05		W5612	0548	24		24-33-13	ALL
	B06		W5612	0544	24		24-33-13	ALL
	B07		W5612	2207B	22		SPARE	ALL
	B08		W5612	0206	20		27-25-11	ALL
	B09	UNUSED						ALL
	B10		W5612	0550	22		31-33-01	ALL
D40364J		**E001-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02		W0111	1035	20		27-25-11	ALL
	A03		W0111	0890	22		25-51-21	ALL
	A04		W0111	0583	24		24-32-11	ALL
	A05		W0111	0586	24		24-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40364J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0111	0697	22		27-81-11	ALL
	A10		W0111	0804	24		21-31-23	ALL
	B01		W0111	1032	20		27-25-11	ALL
	B02		W0111	0865	20		21-31-23	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0111	0411	22		27-53-11	ALL
	B08		W0111	0801	22		27-83-11	ALL
	B09		W0111	0641	20		27-53-11	ALL
	B10		W0111	0643	20		27-53-11	ALL
	PERG	1F	W0111	1032Z			27-25-11	ALL
	PERG	1F	W0111	1035Z			27-25-11	ALL
D40364P		**E001-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W6110	0203	20		27-25-11	ALL
	A03		W6110	0033	22		25-51-21	ALL
	A04		W6110	0519	24		24-32-11	ALL
	A05		W6110	0503	24		24-32-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6110	0523	22		27-81-11	ALL
	A10		W6110	0206	24		21-31-23	ALL
	B01		W6110	0204	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40364P		**E001-01/ /**		**PLUG- (continued)**				**ALL**
	B02		W6110	0205	20		21-31-23	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W6110	0514	20		27-53-11	ALL
	B08		W6110	0524	22		27-83-11	ALL
	B09		W6110	0525	20		27-53-11	ALL
	B10		W6110	0526	20		27-53-11	ALL
D40365J		**AB0358/ /**		**RCPT-**				**ALL**
	1		W3710	2501W	24		23-70-11	ALL
	2		W3710	2501B	24		23-70-11	ALL
	3		W3710	2502W	24		23-70-11	ALL
	4		W3710	2502B	24		23-70-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3710	2501Z			23-70-11	ALL
	S/R		W3710	2502Z			23-70-11	ALL
D40365P		**AB0358/ /**		**PLUG**				**ALL**
	1		W3805	2508W	24		23-70-11	ALL
	2		W3805	2508B	24		23-70-11	ALL
	3		W3805	2509W	24		23-70-11	ALL
	4		W3805	2509B	24		23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40365P		**AB0358/ /**		**PLUG (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W3805	2508Z			23-70-11	ALL
	S/R		W3805	2509Z			23-70-11	ALL
D40368J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0009	22		24-23-51	ALL
	2		W0044	0025	24		24-32-11	ALL
	3		W0044	0023	24		24-32-11	ALL
	4		W0044	0028	20		24-32-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0044	0566	22		25-51-21	ALL
	15		W0044	0190	20		33-18-61	ALL
	16		W0044	0239	22		27-83-11	ALL
	17		W0044	0291	22		27-81-11	ALL
	18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40368J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0044	0855	20		27-25-11	ALL
	22		W0044	0859	20		27-25-11	ALL
	23		W0044	0919	20		21-31-23	ALL
	24		W0044	0920	24		21-31-23	ALL
D40368P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W6110	0513	22		24-23-51	ALL
	2		W6110	0519	24		24-32-11	ALL
	3		W6110	0504	24		24-32-11	ALL
	4		W6110	0505	20		24-32-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W6110	0014	22		25-51-21	ALL
	15		W6110	0019	20		33-18-61	ALL
	16		W6110	0524	22		27-83-11	ALL
	17		W6110	0523	22		27-81-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W6110	0203	20		27-25-11	ALL
	22		W6110	0204	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40368P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
23		W6110	0205	20		21-31-23	ALL
24		W6110	0206	24		21-31-23	ALL
D40370J	**E004-02/ /**		**RCPT-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
A01		W0422	4001R	20		24-21-21	ALL
A02		W0422	4001G	20		24-21-21	ALL
A03		W0422	4004R	22		24-41-11	ALL
A04		W0422	4004G	22		24-41-11	ALL
A05		W0422	0051	22		29-11-11	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0422	4001B	20		24-21-21	ALL
B02		W0422	4001Y	20		24-21-21	ALL
B03		W0422	4004B	22		24-41-11	ALL
B04		W0422	4004Y	22		24-41-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W0422	0128	18		24-32-11	ALL
G		W0422	0129	18		24-32-11	ALL
H		W0422	0127	18		24-32-11	ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERB		W0422	4001Z			24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40370P		**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
	A01		W6210	3206R	20		24-21-21	ALL
	A02		W6210	1004	20		24-21-21	ALL
	A03		W6210	4102R	22		24-41-11	ALL
	A04		W6210	4102G	22		24-41-11	ALL
	A05		W6210	0510	22		29-11-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6210	3206B	20		24-21-21	ALL
	B02		W6210	3206Y	20		24-21-21	ALL
	B03		W6210	4102B	22		24-41-11	ALL
	B04		W6210	4102Y	22		24-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W6210	0504	18		24-32-11	ALL
	G		W6210	0505	18		24-32-11	ALL
	H		W6210	0506	18		24-32-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERB		W6210	1004Z			24-21-21	ALL
	PERB		W6210	3206Z			24-21-21	ALL
D40372J		**E002-01/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40372J	**E002-01/ /**		**RCPT- (continued)**				**ALL**
2		W0212	0008	22		29-11-11	ALL
3	UNUSED						ALL
4		W0212	0032	18		24-22-31	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0212	0212	22		21-27-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40372P	**E002-01/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W6210	0510	22		29-11-11	ALL
3	UNUSED						ALL
4		W6210	0515	20		24-22-31	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W6210	5510	22		21-27-21	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40375J	**AB0410/205/R039**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W6134	1104	20		27-33-11	ALL
A04		W6134	1105	20		27-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40375J		**AB0410/205/R039**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A05		W6134	0538	20		27-53-12	ALL
	A06		W6134	0513	20		31-53-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W6134	1106	20		27-33-11	ALL
	B04	UNUSED						ALL
	B05		W6134	0539	20		27-53-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6134	1104Z			27-33-11	ALL
	PERG	1F	W6134	1105Z			27-33-11	ALL
	PERG	1F	W6134	1106Z			27-33-11	ALL
D40375P		**AB0410/205/R039**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5160	1003	22		27-33-11	ALL
	A04		W5160	1004	22		27-33-11	ALL
	A05		W5160	0513	20		27-53-12	ALL
	A06		W5160	0583	22		31-53-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40375P		**AB0410/205/R039**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5160	0126	22		27-33-11	ALL
	B04	UNUSED						ALL
	B05		W5160	0514	20		27-53-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5160	1003Z			27-33-11	ALL
	PERG	1F	W5160	1004Z			27-33-11	ALL
D40377J		**AB0410/*/***		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6230	0503	22		27-83-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W6230	0301	24		21-51-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6230	0001	20		33-33-11	ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40377J		**AB0410/*/***		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40377P		**AB0410/*/***		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6412	0507	22		27-83-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W6412	0301	24		21-51-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6412	0002	20		33-33-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40378J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0007	22		23-51-51	ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40378J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0410	0538	24		21-51-14	ALL
	A12		W0410	0338	24		21-51-15	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0410	0081	24		21-42-11	ALL
	A18		W0410	0082	24		21-42-11	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0410	0324	22		21-51-14	ALL
	B10		W0410	0008	22		23-51-51	ALL
	B11		W0410	0038	24		73-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40378J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B12		W0410	1303R	20		26-11-21	ALL
	B13		W0410	1304R	20		26-11-21	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0410	0206	20		30-71-11	ALL
	B19		W0410	0485	20		30-71-11	ALL
	B20	UNUSED						ALL
	DED		W0410	1303Z			26-11-21	ALL
	DED		W0410	1304Z			26-11-21	ALL
D40378P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6214	0201	22		23-51-51	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W6214	5502	24		21-51-14	ALL
	A12		W6214	5503	24		21-51-15	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W6214	5511	24		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40378P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A18		W6214	5512	24		21-42-11	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W6214	5522	22		21-51-14	ALL
	B10		W6214	0202	22		23-51-51	ALL
	B11		W6214	6001	24		73-22-31	ALL
	B12		W6214	1303R	20		26-11-21	ALL
	B13		W6214	1304R	20		26-11-21	ALL
	B14		W6214	5541	20		SPARE	ALL
	B15		W6214	5536	20		SPARE	ALL
	B16		W6214	5540	20		SPARE	ALL
	B17	UNUSED						ALL
	B18		W6214	5539	20		30-71-11	ALL
	B19		W6214	5556	20		30-71-11	ALL
	B20	UNUSED						ALL
	DED		W6214	1303Z			26-11-21	ALL
	DED		W6214	1304Z			26-11-21	ALL
D40380J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0220	2012B	24		21-31-24	ALL
	A03		W0220	2012R	24		21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40380J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A04		W0220	2015B	24		21-31-24	ALL
	A05		W0220	2015R	24		21-31-24	ALL
	A06		W0220	2014B	24		21-31-24	ALL
	A07		W0220	2014R	24		21-31-24	ALL
	A08		W0220	2013B	24		21-31-24	ALL
	A09		W0220	2013R	24		21-31-24	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0220	0242	20		30-71-11	ALL
	A19	UNUSED						ALL
	A20		W0220	0012	20		33-32-11	ALL
	B01	UNUSED						ALL
	B02		W0220	0066	24		21-31-24	ALL
	B03		W0220	0065	24		21-31-24	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0220	0068	24		21-31-24	ALL
	B07		W0220	0069	24		21-31-24	ALL
	B08		W0220	0067	24		21-31-24	ALL
	B09		W0220	0071	24		21-31-24	ALL
	B10		W0220	0074	24		21-31-24	ALL
	B11	UNUSED						ALL
	B12		W0220	0403R	20		26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40380J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B13		W0220	0402R	20		26-11-21	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0220	0243	20		30-71-11	ALL
	B19	UNUSED						ALL
	B20		W0220	0011	20		33-32-11	ALL
	PERG	1F	W0220	2012Z			21-31-24	ALL
	PERG	1F	W0220	2013Z			21-31-24	ALL
	PERG	1F	W0220	2014Z			21-31-24	ALL
	PERG	1F	W0220	2015Z			21-31-24	ALL
D40380P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W6214	2010B	24		21-31-24	ALL
	A03		W6214	2010R	24		21-31-24	ALL
	A04		W6214	2007B	24		21-31-24	ALL
	A05		W6214	2007R	24		21-31-24	ALL
	A06		W6214	2008B	24		21-31-24	ALL
	A07		W6214	2008R	24		21-31-24	ALL
	A08		W6214	2009B	24		21-31-24	ALL
	A09		W6214	2009R	24		21-31-24	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40380P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A17	UNUSED						ALL
	A18		W6214	5556	20		30-71-11	ALL
	A19	UNUSED						ALL
	A20		W6214	0001	20		33-32-11	ALL
	B01	UNUSED						ALL
	B02		W6214	0209	24		21-31-24	ALL
	B03		W6214	0210	24		21-31-24	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W6214	0208	24		21-31-24	ALL
	B07		W6214	0207	24		21-31-24	ALL
	B08		W6214	0204	24		21-31-24	ALL
	B09		W6214	0206	24		21-31-24	ALL
	B10		W6214	0211	24		21-31-24	ALL
	B11	UNUSED						ALL
	B12		W6214	1303R	20		26-11-21	ALL
	B13		W6214	1304R	20		26-11-21	ALL
	B14	UNUSED						ALL
	B15		W6214	5536	20		SPARE	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W6214	5539	20		30-71-11	ALL
	B19	UNUSED						ALL
	B20		W6214	0002	20		33-32-11	ALL
	DED		W6214	1303Z			26-11-21	ALL
	DED		W6214	1304Z			26-11-21	ALL
	PERG	1F	W6214	2007Z			21-31-24	ALL
	PERG	1F	W6214	2008Z			21-31-24	ALL
	PERG	1F	W6214	2009Z			21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40380P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W6214	2010Z			21-31-24	ALL
D40382J	**E004-02/ /**		**RCPT-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
A01		W0422	0109	22		24-23-51	ALL
A02		W0422	0118	22		24-28-41	ALL
A03		W0422	0106	22		24-23-21	ALL
A04		W0422	0093	22		24-22-21	ALL
A05		W0422	0091	22		24-22-21	ALL
A06		W0422	2018R	20		24-41-11	ALL
A07		W0422	3003R	20		24-22-21	ALL
A08		W0422	3003Y	20		24-22-21	ALL
A09		W0422	3004B	20		24-23-21	ALL
A10		W0422	4003R	22		24-24-21	ALL
A11		W0422	4003G	22		24-24-21	ALL
A12		W0422	4005R	22		24-41-11	ALL
A13		W0422	4005G	22		24-41-11	ALL
A14		W0422	0064	20		33-36-12	ALL
A15		W0422	0065	20		33-36-12	ALL
A16		W0422	0061	20		33-33-11	ALL
A17	UNUSED						ALL
A18		W0422	0146	22		24-22-31	ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02		W0422	0221	22		24-28-41	ALL
B03		W0422	0107	22		24-23-21	ALL
B04		W0422	0096	22		24-22-21	ALL
B05		W0422	0092	22		24-22-21	ALL
B06		W0422	2018B	20		24-41-11	ALL
B07		W0422	3003B	20		24-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40382J		**E004-02/ /**		**RCPT-CONDUCTIVE W/ BACKSHELL ZERO LENGTH (continued)**				**ALL**
	B08		W0422	3004R	20		24-23-21	ALL
	B09		W0422	3004Y	20		24-23-21	ALL
	B10		W0422	4003B	22		24-24-21	ALL
	B11		W0422	4003Y	22		24-24-21	ALL
	B12		W0422	4005B	22		24-41-11	ALL
	B13		W0422	4005Y	22		24-41-11	ALL
	B14		W0422	0062	20		33-36-11	ALL
	B15		W0422	0063	20		33-36-11	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0422	0145	22		24-22-11	ALL
	B19	UNUSED						ALL
	B20		W0422	0148	22		21-27-31	ALL
	PERB		W0422	4003Z			24-24-21	ALL
D40382P		**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
	A01		W6410	0501	22		24-23-51	ALL
	A02		W6410	0503	22		24-28-41	ALL
	A03		W6410	0514	22		24-23-21	ALL
	A04		W6410	0516	22		24-22-21	ALL
	A05		W6410	0518	22		24-22-21	ALL
	A06		W6410	2201R	20		24-41-11	ALL
	A07		W6410	3201R	20		24-22-21	ALL
	A08		W6410	3201Y	20		24-22-21	ALL
	A09		W6410	3202B	20		24-23-21	ALL
	A10		W6410	4101R	22		24-24-21	ALL
	A11		W6410	4101G	22		24-24-21	ALL
	A12		W6410	4102R	22		24-41-11	ALL
	A13		W6410	4102G	22		24-41-11	ALL
	A14		W6410	0023	20		33-36-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40382P	**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH (continued)**				**ALL**
A15		W6410	0009	20		33-36-12	ALL
A16		W6410	0042	20		33-33-11	ALL
A17	UNUSED						ALL
A18		W6410	0505	22		24-22-31	ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02		W6410	0504	22		24-28-41	ALL
B03		W6410	0515	22		24-23-21	ALL
B04		W6410	0517	22		24-22-21	ALL
B05		W6410	0519	22		24-22-21	ALL
B06		W6410	2201B	20		24-41-11	ALL
B07		W6410	3201B	20		24-22-21	ALL
B08		W6410	3202R	20		24-23-21	ALL
B09		W6410	3202Y	20		24-23-21	ALL
B10		W6410	4101B	22		24-24-21	ALL
B11		W6410	4101Y	22		24-24-21	ALL
B12		W6410	4102B	22		24-41-11	ALL
B13		W6410	4102Y	22		24-41-11	ALL
B14		W6410	0021	20		33-36-11	ALL
B15		W6410	0039	20		33-36-11	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18		W6410	0520	22		24-22-11	ALL
B19	UNUSED						ALL
B20		W6410	5501	22		21-27-31	ALL
PERB		W6410	4101Z			24-24-21	ALL
D40386J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0436	14		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40386J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	2		W0044	0437	14		21-25-11	ALL
	3		W0044	0413	22		27-83-21	ALL
	4		W0044	0438	14		21-25-11	ALL
	5		W0044	0277	22		34-33-21	ALL
	6		W0044	0495	14		30-41-12	ALL
	7		W0044	6081	24		21-51-24	ALL
	8		W0044	0494	12		30-41-12	ALL
	9	UNUSED						ALL
	10		W0044	0298	18		28-44-11	ALL
	11		W0044	0502	22		23-51-51	ALL
	12		W0044	0503	22		23-51-51	ALL
	13	UNUSED						ALL
	14		W0044	0007	22		24-23-51	ALL
	15	UNUSED						ALL
	16		W0044	0011	22		24-23-51	ALL
	17	UNUSED						ALL
	18		W0044	2001B	22		24-23-51	ALL
	19	UNUSED						ALL
	20		W0044	2001R	22		24-23-51	ALL
	21	UNUSED						ALL
	22		W0044	0062	22		34-51-21	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0044	0299	20		28-44-11	ALL
	26		W0044	0282	22		28-44-11	ALL
	27	UNUSED						ALL
	28		W0044	0061	22		34-51-21	ALL
	29		W0044	0643	20		27-31-11	ALL
	30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40386J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
31	UNUSED						ALL
32	UNUSED						ALL
D40386P	**P006-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W6412	5501	14		21-25-11	ALL
2		W6412	5502	14		21-25-11	ALL
3		W6412	0505	22		27-83-21	ALL
4		W6412	5503	14		21-25-11	ALL
5		W6412	0004	22		34-33-21	ALL
6		W6412	1004	14		30-41-12	ALL
7		W6412	5512	22		21-51-24	ALL
8		W6412	1005	12		30-41-12	ALL
9		W6412	5508	22		SPARE	ALL
10		W6412	6016	18		28-44-11	ALL
11		W6412	0201	22		23-51-51	ALL
12		W6412	0202	22		23-51-51	ALL
13	UNUSED						ALL
14		W6412	0501	22		24-23-51	ALL
15	UNUSED						ALL
16		W6412	0502	22		24-23-51	ALL
17	UNUSED						ALL
18		W6412	2201B	22		24-23-51	ALL
19	UNUSED						ALL
20		W6412	2201R	22		24-23-51	ALL
21	UNUSED						ALL
22		W6412	1305	22		34-51-21	ALL
23	UNUSED						ALL
24		W6412	5533	20		SPARE	ALL
25		W6412	6025	20		28-44-11	ALL
26		W6412	6014	22		28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40386P		**P006-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	27		W6412	0008	20		SPARE	ALL
	28		W6412	1304	22		34-51-21	ALL
	29		W6412	5547	20		27-31-11	ALL
	30	UNUSED						ALL
	31		W6412	0009	20		SPARE	ALL
	32	UNUSED						ALL
	PERB		W6412	1004Z			30-41-12	ALL
	PERB		W6412	1005Z			30-41-12	ALL
D40388J		**E004-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0422	0113	22		24-23-51	ALL
	A03		W0422	0110	22		24-23-51	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0422	2007B	22		24-23-51	ALL
	A07		W0422	2007R	22		24-23-51	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0422	2014B	22		24-41-11	ALL
	A12		W0422	2014R	22		24-41-11	ALL
	A13		W0422	2015B	22		24-41-11	ALL
	A14		W0422	2015R	22		24-41-11	ALL
	A15		W0422	2602B	22		28-41-11	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0422	0061	20		33-33-11	ALL
	A19		W0422	0147	24		31-65-24	ALL
	A20		W0422	0240	22		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40388J	**E004-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W0422	0170	22		29-23-11	ALL
B06		W0422	0244	22		27-33-11	ALL
B07		W0422	0245	22		27-33-11	ALL
B08		W0422	2001R	24		73-21-11	ALL
B09		W0422	2001B	24		73-21-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0422	0246	22		27-33-11	ALL
B15		W0422	2602R	22		28-41-11	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0422	2001Z			73-21-11	ALL
PERG	1F	W0422	2602Z			28-41-11	ALL
D40388P	**E004-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02		W6412	0501	22		24-23-51	ALL
A03		W6412	0502	22		24-23-51	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W6412	2201B	22		24-23-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40388P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	A07		W6412	2201R	22		24-23-51	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W6412	2202B	22		24-41-11	ALL
	A12		W6412	2202R	22		24-41-11	ALL
	A13		W6412	2203B	22		24-41-11	ALL
	A14		W6412	2203R	22		24-41-11	ALL
	A15		W6412	2607B	22		28-41-11	ALL
	A16		W6412	5533	20		SPARE	ALL
	A17	UNUSED						ALL
	A18		W6412	0002	20		33-33-11	ALL
	A19		W6412	0007	24		31-65-24	ALL
	A20		W6412	5546	24		31-65-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6412	0515	22		29-23-11	ALL
	B06		W6412	0045	22		27-33-11	ALL
	B07		W6412	0046	20		27-33-11	ALL
	B08		W6412	2612R	24		73-21-11	ALL
	B09		W6412	2612B	24		73-21-11	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W6412	0044	22		27-33-11	ALL
	B15		W6412	2607R	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40388P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6412	2607Z			28-41-11	ALL
	PERG	1F	W6412	2612Z			73-21-11	ALL
D40390J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0030	24		29-33-11	ALL
	A02	UNUSED						ALL
	A03		W0410	0005	22		23-51-51	ALL
	A04		W0410	1001	20		73-22-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0410	0009	22		27-83-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0410	0006	22		23-51-51	ALL
	A11		W0410	2008R	24		77-12-21	ALL
	A12		W0410	2008B	24		77-12-21	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0410	0612	24		21-25-11	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0410	0622	24		21-51-21	ALL
	B01		W0410	0617	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40390J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B02		W0410	0618	24		21-51-11	ALL
	B03	UNUSED						ALL
	B04		W0410	0543	24		21-51-24	ALL
	B05		W0410	0556	24		21-51-24	ALL
	B06		W0410	0037	24		73-22-31	ALL
	B07		W0410	0365	24		21-51-24	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0410	0253	24		21-51-21	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0410	1001Z			73-22-11	ALL
	PERG	1F	W0410	2008Z			77-12-21	ALL
D40390P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6412	0518	24		29-33-11	ALL
	A02	UNUSED						ALL
	A03		W6412	0201	22		23-51-51	ALL
	A04		W6412	1301	20		73-22-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W6412	0506	22		27-83-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40390P	**E004-01/ /**		**PLUG- (continued)**				**ALL**
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W6412	0202	22		23-51-51	ALL
A11		W6412	2602R	24		77-12-21	ALL
A12		W6412	2602B	24		77-12-21	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17		W6412	5529	24		21-25-11	ALL
A18	UNUSED						ALL
A19		W6412	5508	22		SPARE	ALL
A20		W6412	0547	24		21-51-21	ALL
B01		W6412	0546	24		21-51-11	ALL
B02		W6412	0545	24		21-51-11	ALL
B03		W6412	5504	24		SPARE	ALL
B04		W6412	5514	24		21-51-24	ALL
B05		W6412	5515	24		21-51-24	ALL
B06		W6412	6006	24		73-22-31	ALL
B07		W6412	5512	22		21-51-24	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W6412	5548	24		SPARE	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W6412	0200	24		21-51-21	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40390P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6412	1301Z			73-22-11	ALL
	PERG	1F	W6412	2602Z			77-12-21	ALL
D40392J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0321	0121	22		27-83-21	ALL
	A03		W0321	0122	22		27-83-21	ALL
	A04		W0321	0120	22		27-83-21	ALL
	A05		W0321	0357	22		27-11-11	ALL
	A06		W0321	0356	22		27-11-11	ALL
	A07		W0321	0078	20		27-31-11	ALL
	A08		W0321	0294	24		29-33-11	ALL
	A09		W0321	0979	24		21-51-22	ALL
	A10		W0321	0978	24		21-51-22	ALL
	A11		W0321	1796	24		21-51-11	ALL
	A12		W0321	1004R	20		26-11-21	ALL
	A13		W0321	1005R	20		26-11-21	ALL
	A14		W0321	1075	24		21-25-11	ALL
	A15		W0321	1002	22		31-65-24	ALL
	A16	UNUSED						ALL
	A17		W0321	2295R	24		34-51-21	ALL
	A18	UNUSED						ALL
	A19		W0321	2295B	24		34-51-21	ALL
	A20		W0321	0359	24		27-21-11	ALL
	B01		W0321	2297R	24		34-51-21	ALL
	B02		W0321	2297B	24		34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40392J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B03	UNUSED						ALL
B04		W0321	0217	24		21-51-24	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0321	0088	24		73-22-31	ALL
B10		W0321	0030	22		73-23-11	ALL
B11		W0321	1798	24		21-51-21	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0321	0200	24		21-51-21	ALL
B15		W0321	0066	22		31-31-15	ALL
B16		W0321	0067	22		31-31-15	ALL
B17		W0321	2501R	24		34-51-21	ALL
B18		W0321	2501B	24		34-51-21	ALL
B19		W0321	1794	24		21-51-11	ALL
B20		W0321	0358	24		27-21-11	ALL
DED		W0321	1004Z			26-11-21	ALL
DED		W0321	1005Z			26-11-21	ALL
PERG	1F	W0321	1002Z			31-65-24	ALL
PERG	1F	W0321	2295Z			34-51-21	ALL
PERG	1F	W0321	2297Z			34-51-21	ALL
PERG	1F	W0321	2501Z			34-51-21	ALL
D40392P	**E003-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02		W6412	0505	22		27-83-21	ALL
A03		W6412	0506	22		27-83-21	ALL
A04		W6412	0507	22		27-83-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40392P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A05		W6412	0519	22		27-11-11	ALL
	A06		W6412	0520	22		27-11-11	ALL
	A07		W6412	5547	20		27-31-11	ALL
	A08		W6412	0518	24		29-33-11	ALL
	A09		W6412	0535	24		21-51-22	ALL
	A10		W6412	0536	24		21-51-22	ALL
	A11		W6412	0546	24		21-51-11	ALL
	A12		W6412	1303R	20		26-11-21	ALL
	A13		W6412	1302R	20		26-11-21	ALL
	A14		W6412	5529	24		21-25-11	ALL
	A15		W6412	1001	22		31-65-24	ALL
	A16		W6412	5548	24		SPARE	ALL
	A17		W6412	2208R	24		34-51-21	ALL
	A18	UNUSED						ALL
	A19		W6412	2208B	24		34-51-21	ALL
	A20		W6412	0512	24		27-21-11	ALL
	B01		W6412	2207R	24		34-51-21	ALL
	B02		W6412	2207B	24		34-51-21	ALL
	B03		W6412	5504	24		SPARE	ALL
	B04		W6412	5514	24		21-51-24	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W6412	6006	24		73-22-31	ALL
	B10		W6412	6007	24		73-23-11	ALL
	B11		W6412	0547	24		21-51-21	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40392P	**E003-02/ /**		**PLUG- (continued)**				**ALL**
B14		W6412	0200	24		21-51-21	ALL
B15		W6412	0040	20		31-31-15	ALL
B16		W6412	0041	20		31-31-15	ALL
B17		W6412	2206R	24		34-51-21	ALL
B18		W6412	2206B	24		34-51-21	ALL
B19		W6412	0545	24		21-51-11	ALL
B20		W6412	0513	24		27-21-11	ALL
DED		W6412	1302Z			26-11-21	ALL
DED		W6412	1303Z			26-11-21	ALL
PERG	1F	W6412	1001Z			31-65-24	ALL
PERG	1F	W6412	2206Z			34-51-21	ALL
PERG	1F	W6412	2207Z			34-51-21	ALL
PERG	1F	W6412	2208Z			34-51-21	ALL
D40394J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0313	2601R	24		34-51-21	ALL
A02		W0313	2601B	24		34-51-21	ALL
A03		W0313	2714R	24		31-65-26	ALL
A04		W0313	0691	24		31-65-24	ALL
A05		W0313	2542B	24		73-24-21	ALL
A06		W0313	2542R	24		73-24-21	ALL
A07		W0313	2569B	24		77-12-21	ALL
A08		W0313	2569R	24		77-12-21	ALL
A09	UNUSED						ALL
A10		W0313	0592	24		29-31-11	ALL
A11		W0313	2559B	22		28-41-11	ALL
A12		W0313	2559R	22		28-41-11	ALL
A13		W0313	1702	22		34-33-21	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40394J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A16		W0313	1501	22		31-65-24	ALL
	A17		W0313	1752	24		75-11-11	ALL
	A18		W0313	1509R	20		26-11-21	ALL
	A19		W0313	2551R	24		73-24-12	ALL
	A20		W0313	0581	24		80-11-11	ALL
	B01		W0313	2714B	24		31-65-26	ALL
	B02		W0313	0554	24		73-22-11	ALL
	B03		W0313	0557	24		73-22-31	ALL
	B04		W0313	0561	24		73-23-11	ALL
	B05		W0313	0562	24		73-23-11	ALL
	B06		W0313	0536	24		76-21-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0313	0591	24		29-31-11	ALL
	B10		W0313	0590	24		29-31-11	ALL
	B11		W0313	1755	24		76-21-21	ALL
	B12	UNUSED						ALL
	B13		W0313	0517	24		31-65-24	ALL
	B14		W0313	0605	24		29-32-11	ALL
	B15		W0313	0606	24		29-32-11	ALL
	B16		W0313	2602R	24		34-51-21	ALL
	B17		W0313	2602B	24		34-51-21	ALL
	B18		W0313	1510R	20		26-11-21	ALL
	B19		W0313	2551B	24		73-24-12	ALL
	B20		W0313	1764	20		80-11-11	ALL
	DED		W0313	1509Z			26-11-21	ALL
	DED		W0313	1510Z			26-11-21	ALL
	PERG	1F	W0313	1501Z			31-65-24	ALL
	PERG	1F	W0313	2542Z			73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40394J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0313	2551Z			73-24-12	ALL
	PERG	1F	W0313	2559Z			28-41-11	ALL
	PERG	1F	W0313	2569Z			77-12-21	ALL
	PERG	1F	W0313	2601Z			34-51-21	ALL
	PERG	1F	W0313	2602Z			34-51-21	ALL
	PERG	1F	W0313	2714Z			31-65-26	ALL
D40394P		**E003-01/ /**		**PLUG-**				**ALL**
	A01		W6412	2204R	24		34-51-21	ALL
	A02		W6412	2204B	24		34-51-21	ALL
	A03		W6412	2501R	24		31-65-26	ALL
	A04		W6412	5546	24		31-65-24	ALL
	A05		W6412	2601B	20		73-24-21	ALL
	A06		W6412	2601R	20		73-24-21	ALL
	A07		W6412	2602B	24		77-12-21	ALL
	A08		W6412	2602R	24		77-12-21	ALL
	A09		W6412	0508	20		SPARE	ALL
	A10		W6412	0510	20		29-31-11	ALL
	A11		W6412	2607B	22		28-41-11	ALL
	A12		W6412	2607R	22		28-41-11	ALL
	A13		W6412	0004	22		34-33-21	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W6412	1001	22		31-65-24	ALL
	A17		W6412	6019	24		75-11-11	ALL
	A18		W6412	1302R	20		26-11-21	ALL
	A19		W6412	2606R	24		73-24-12	ALL
	A20		W6412	6002	24		80-11-11	ALL
	B01		W6412	2501B	24		31-65-26	ALL
	B02		W6412	6004	24		73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40394P		**E003-01/ /**		**PLUG- (continued)**				**ALL**
	B03		W6412	6005	24		73-22-31	ALL
	B04		W6412	6007	24		73-23-11	ALL
	B05		W6412	6008	24		73-23-11	ALL
	B06		W6412	6009	22		76-21-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W6412	0509	20		29-31-11	ALL
	B10		W6412	0514	20		29-31-11	ALL
	B11		W6412	6020	24		76-21-21	ALL
	B12	UNUSED						ALL
	B13		W6412	0007	24		31-65-24	ALL
	B14		W6412	0516	24		29-32-11	ALL
	B15		W6412	0517	24		29-32-11	ALL
	B16		W6412	2205R	24		34-51-21	ALL
	B17		W6412	2205B	24		34-51-21	ALL
	B18		W6412	1303R	20		26-11-21	ALL
	B19		W6412	2606B	24		73-24-12	ALL
	B20		W6412	6080	20		80-11-11	ALL
	DED		W6412	1302Z			26-11-21	ALL
	DED		W6412	1303Z			26-11-21	ALL
	PERG	1F	W6412	1001Z			31-65-24	ALL
	PERG	1F	W6412	2204Z			34-51-21	ALL
	PERG	1F	W6412	2205Z			34-51-21	ALL
	PERG	1F	W6412	2501Z			31-65-26	ALL
	PERG	1F	W6412	2601Z			73-24-21	ALL
	PERG	1F	W6412	2602Z			77-12-21	ALL
	PERG	1F	W6412	2606Z			73-24-12	ALL
	PERG	1F	W6412	2607Z			28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40396J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0049	22		24-41-11	ALL
2		W0044	0012	22		24-23-51	ALL
3		W0044	0030	20		24-32-11	ALL
4	UNUSED						ALL
5		W0044	0254	20		25-29-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0044	0029	24		24-32-11	ALL
9		W0044	0024	24		24-32-11	ALL
10	UNUSED						ALL
11		W0044	0638	24		21-27-21	ALL
12		W0044	0328	20		33-32-11	ALL
D40396P	**P006-00/ /**		**PLUG-**				**ALL**
1		W6414	0501	22		24-41-11	ALL
2		W6414	0506	22		24-23-51	ALL
3		W6414	0507	20		24-32-11	ALL
4		W6414	5508	18		SPARE	ALL
5		W6414	0014	20		25-29-11	ALL
6		W6414	0502	24		SPARE	ALL
7	UNUSED						ALL
8		W6414	0504	24		24-32-11	ALL
9		W6414	0503	24		24-32-11	ALL
10	UNUSED						ALL
11		W6414	5501	24		21-27-21	ALL
12		W6414	0002	20		33-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40400J		**AB0500DR/ /**		**RCPT**				**ALL**
	1		W6530	0507	20		29-11-11	ALL
	2		W6530	0508	20		29-11-11	ALL
	3		W6530	1101	22		31-65-24	ALL
	4	UNUSED						ALL
	5		W6530	0517	22		29-33-11	ALL
	6		W6530	0518	22		29-33-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W6530	1101Z			31-65-24	ALL
D40400P		**AB0500DR/ /**		**PLUG-**				**ALL**
	1		W6122	0504	20		29-11-11	ALL
	2		W6122	0505	20		29-11-11	ALL
	3		W6122	1515	22		31-65-24	ALL
	4	UNUSED						ALL
	5		W6122	0506	22		29-33-11	ALL
	6		W6122	0507	22		29-33-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W6122	1515Z			31-65-24	ALL
D40402J		**AB0500DR/ /**		**RCPT**				**ALL**
	1		W6032	6001R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40402J	**AB0500DR/ /**		**RCPT (continued)**				**ALL**
2	UNUSED						ALL
3		W6032	0503	20		27-23-11	ALL
4		W6032	0504	20		27-23-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W6032	0524	20		29-23-11	ALL
16		W6032	0112	22		27-31-37	ALL
17		W6032	0542	20		27-61-43	ALL
18		W6032	0531	20		27-61-43	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W6032	0521	22		27-54-11	ALL
23		W6032	0511	22		27-54-11	ALL
24		W6032	0523	20		29-23-11	ALL
D40402P	**AB0500DR/ /**		**PLUG-**				**ALL**
1		W6124	0512R	20		26-12-11	ALL
2	UNUSED						ALL
3		W6124	0501	20		27-23-11	ALL
4		W6124	0502	20		27-23-11	ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40402P		**AB0500DR/ /**		**PLUG- (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W6124	0524	22		29-23-11	ALL
	16		W6124	0110	22		27-31-37	ALL
	17		W6124	0542	20		27-61-43	ALL
	18		W6124	0543	20		27-61-43	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W6124	0541	22		27-54-11	ALL
	23		W6124	0520	22		27-54-11	ALL
	24		W6124	0523	22		29-23-11	ALL
D40404J		**AB0500DR/ /**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W6034	0030	22		31-31-15	ALL
	4		W6034	0031	22		27-83-11	ALL
	5		W6034	0550	22		22-23-12	ALL
	6	UNUSED						ALL
	7		W6034	0501	20		27-31-11	ALL
	8	UNUSED						ALL
	9		W6034	5501	24		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40404J	**AB0500DR/ /**		**RCPT (continued)**				**ALL**
10	UNUSED						ALL
11		W6034	0001	20		33-25-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W6034	0561	22		32-64-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W6034	0562	22		32-64-21	ALL
27	UNUSED						ALL
28		W6034	2002R	22		27-61-49	ALL
29		W6034	2002B	22		27-61-49	ALL
30		W6034	2001R	22		27-61-49	ALL
31		W6034	2001B	22		27-61-49	ALL
S/R		W6034	2001Z			27-61-49	ALL
S/R		W6034	2002Z			27-61-49	ALL
D40404P	**AB0500DR/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6124	0030	20		31-31-15	ALL
4		W6124	0548	22		27-83-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40404P		**AB0500DR/ /**		**PLUG- (continued)**				**ALL**
	5		W6124	0550	22		22-23-12	ALL
	6	UNUSED						ALL
	7		W6124	0507	20		27-31-11	ALL
	8	UNUSED						ALL
	9		W6124	5501	20		21-51-14	ALL
	10	UNUSED						ALL
	11		W6124	0001	20		33-25-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W6124	0561	22		32-64-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W6124	0553	22		32-64-21	ALL
	27	UNUSED						ALL
	28		W6124	2002R	22		27-61-49	ALL
	29		W6124	2002B	22		27-61-49	ALL
	30		W6124	2001R	22		27-61-49	ALL
	31		W6124	2001B	22		27-61-49	ALL
	S/R		W6124	2001Z			27-61-49	ALL
	S/R		W6124	2002Z			27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40404P	**AB0500DR/ /**		**PLUG- (continued)**				**ALL**
S/R		W6124	5501Z			21-51-14	ALL
D40406J	**AB0500DR/ /**		**RCPT-**				**ALL**
1		W6528	0501	22		32-42-11	ALL
2		W6528	0502	22		32-42-11	ALL
3		W6528	0591	22		32-41-11	ALL
4		W6528	2203R	22		32-42-11	ALL
5		W6528	2203B	22		32-42-11	ALL
6		W6528	2203Z			32-42-11	ALL
7		W6528	2204R	22		32-42-11	ALL
8		W6528	2204B	22		32-42-11	ALL
9		W6528	5513	22		31-31-15	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
D40406P	**AB0500DR/ /**		**PLUG-**				**ALL**
1		W6228	0501	22		32-42-11	ALL
2		W6228	0502	22		32-42-11	ALL
3		W6228	0591	22		32-41-11	ALL
4		W6228	2203R	22		32-42-11	ALL
5		W6228	2203B	22		32-42-11	ALL
6		W6228	2203Z			32-42-11	ALL
7		W6228	2204R	22		32-42-11	ALL
8		W6228	2204B	22		32-42-11	ALL
9		W6228	0509	22		31-31-15	ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40406P		**AB0500DR/ /**		**PLUG- (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
D40410J		**AB0500DR/ /**		**RCPT-**				**ALL**
	1		W6528	0521	22		29-32-11	ALL
	2		W6528	0522	22		29-32-11	ALL
	3		W6528	2211R	22		32-41-11	ALL
	4		W6528	2211B	22		32-41-11	ALL
	5		W6528	2211Z			32-41-11	ALL
	6		W6528	2223R	22		32-64-12	ALL
	7		W6528	2223B	22		32-64-12	ALL
	8		W6528	2224R	22		32-64-12	ALL
	9		W6528	2224B	22		32-64-12	ALL
	10		W6528	2241R	22		32-31-12	ALL
	11		W6528	2241B	22		32-31-12	ALL
	12		W6528	1001R	20		26-12-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W6528	4501G	20		32-46-11	ALL
	20		W6528	4501Z			32-46-11	ALL
	21		W6528	2202R	20		32-49-11	ALL
	22		W6528	2202B	20		32-49-11	ALL
	23		W6528	4501W	20		32-46-11	ALL
	24		W6528	2202Z			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40410P	**AB0500DR/ /**		**PLUG-**				**ALL**
1		W6122	0501	22		29-32-11	ALL
2		W6122	0502	22		29-32-11	ALL
3		W6122	2211R	22		32-41-11	ALL
4		W6122	2211B	22		32-41-11	ALL
5		W6122	2211Z			32-41-11	ALL
6		W6122	2223R	22		32-64-12	ALL
7		W6122	2223B	22		32-64-12	ALL
8		W6122	2224R	22		32-64-12	ALL
9		W6122	2224B	22		32-64-12	ALL
10		W6122	2241R	22		32-31-12	ALL
11		W6122	2241B	22		32-31-12	ALL
12		W6122	0500R	20		26-12-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W6122	4502G	20		32-46-11	ALL
20		W6122	4502Z			32-46-11	ALL
21		W6122	2202R	20		32-49-11	ALL
22		W6122	2202B	20		32-49-11	ALL
23		W6122	4502W	20		32-46-11	ALL
24		W6122	2202Z			32-49-11	ALL
D40413J	**AB0857L/302/L014**		**INSERT RCPT**				**ALL**
A01		W3477	0032	22		44-21-22	ALL
A02		W3477	0033	22		44-21-22	ALL
A03		W3477	0028	22		44-21-22	ALL
A04		W3477	0029	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40413J		**AB0857L/302/L014**		**INSERT RCPT (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W3477	2001B	22		44-35-02	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W3477	2001R	22		44-35-02	ALL
	C01		W3477	2003R	22		44-21-20	ALL
	C02		W3477	2004R	22		44-21-20	ALL
	C03		W3477	2005R	22		44-21-20	ALL
	C04		W3477	2006R	22		44-21-20	ALL
	C05		W3477	2007R	22		44-21-20	ALL
	C06	UNUSED						ALL
	C07		W3477	0027	22		44-21-22	ALL
	C08		W3477	0070	22		44-21-22	ALL
	C09		W3477	0020	22		44-21-22	ALL
	C10		W3477	0021	22		44-21-22	ALL
	D01		W3477	2003B	22		44-21-20	ALL
	D02		W3477	2004B	22		44-21-20	ALL
	D03		W3477	2005B	22		44-21-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40413J	**AB0857L/302/L014**		**INSERT RCPT (continued)**				**ALL**
D04		W3477	2006B	22		44-21-20	ALL
D05		W3477	2007B	22		44-21-20	ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
PERB		W3477	2001Z			44-35-02	ALL
PERB		W3477	2003Z			44-21-20	ALL
PERB		W3477	2004Z			44-21-20	ALL
PERB		W3477	2005Z			44-21-20	ALL
PERB		W3477	2006Z			44-21-20	ALL
PERB		W3477	2007Z			44-21-20	ALL
D40413P	**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
A01		W4477	0002	22		44-21-22	ALL
A02		W4477	0003	22		44-21-22	ALL
A03		W4477	0013	22		44-21-22	ALL
A04		W4477	0014	22		44-21-22	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40413P		**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01		W4477	2501R	22		44-21-20	ALL
	C02		W4477	2502R	22		44-21-20	ALL
	C03		W4477	2503R	22		44-21-20	ALL
	C04		W4477	2504R	22		44-21-20	ALL
	C05		W4477	2505R	22		44-21-20	ALL
	C06	UNUSED						ALL
	C07		W4477	0016	22		44-21-22	ALL
	C08		W4477	0011	22		44-21-22	ALL
	C09		W4477	0021	22		44-21-22	ALL
	C10		W4477	0025	22		44-21-22	ALL
	D01		W4477	2501B	22		44-21-20	ALL
	D02		W4477	2502B	22		44-21-20	ALL
	D03		W4477	2503B	22		44-21-20	ALL
	D04		W4477	2504B	22		44-21-20	ALL
	D05		W4477	2505B	22		44-21-20	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERB		W4477	2501Z			44-21-20	ALL
	PERB		W4477	2502Z			44-21-20	ALL
	PERB		W4477	2503Z			44-21-20	ALL
	PERB		W4477	2504Z			44-21-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40413P	**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
PERB		W4477	2505Z			44-21-20	ALL
D40415J	**AB0857L/302/L014**		**INSERT RCPT**				**ALL**
3		W3477	0035	20		44-21-10	ALL
4	UNUSED						ALL
5		W3477	0065	20		44-35-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W3477	0068	20		44-35-20	ALL
10	UNUSED						ALL
1-1		W3477	4003R	24		44-21-12	ALL
1-2		W3477	4003Y	24		44-21-12	ALL
1-3		W3477	4003B	24		44-21-12	ALL
1-4		W3477	4003G	24		44-21-12	ALL
2-1		W3477	4004R	24		44-21-12	ALL
2-2		W3477	4004Y	24		44-21-12	ALL
2-3		W3477	4004B	24		44-21-12	ALL
2-4		W3477	4004G	24		44-21-12	ALL
=C1		W3477	4003Z			44-21-12	ALL
=C2		W3477	4004Z			44-21-12	ALL
D40415P	**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
3		W4477	0017	20		44-21-10	ALL
4	UNUSED						ALL
5		W4477	0023	20		44-35-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W4477	0010	20		44-35-11	ALL
10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40415P		**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
	1-1		W4477	4003R	24		44-21-12	ALL
	1-2		W4477	4003Y	24		44-21-12	ALL
	1-3		W4477	4003B	24		44-21-12	ALL
	1-4		W4477	4003G	24		44-21-12	ALL
	2-1		W4477	4004R	24		44-21-12	ALL
	2-2		W4477	4004Y	24		44-21-12	ALL
	2-3		W4477	4004B	24		44-21-12	ALL
	2-4		W4477	4004G	24		44-21-12	ALL
	=C1		W4477	4003Z			44-21-12	ALL
	=C2		W4477	4004Z			44-21-12	ALL
D40416J		**AB0500DR/ /**		**RCPT**				**ALL**
	1	UNUSED						ALL
	2		W6032	0030	20		31-31-15	ALL
	3		W6032	0545	20		32-31-15	ALL
	4	UNUSED						ALL
	5		W6032	0514	20		27-23-11	ALL
	6		W6032	0512	20		27-61-43	ALL
	7	UNUSED						ALL
	8		W6032	0515	20		27-23-11	ALL
	9		W6032	0532	20		27-61-43	ALL
	10	UNUSED						ALL
	11		W6032	0546	20		32-31-15	ALL
	12		W6032	0544	20		32-31-15	ALL
D40416P		**AB0500DR/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W5224	0030	20		31-31-15	ALL
	3		W5224	0527	20		32-31-15	ALL
	4	UNUSED						ALL
	5		W5224	0501	20		27-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40416P	**AB0500DR/ /**		**PLUG- (continued)**				**ALL**
6		W5224	0506	20		27-61-43	ALL
7	UNUSED						ALL
8		W5224	0502	20		27-23-11	ALL
9		W5224	0507	20		27-61-43	ALL
10	UNUSED						ALL
11		W5224	0528	20		32-31-15	ALL
12		W5224	0526	20		32-31-15	ALL
D40417J	**AB0857L/302/L014**		**INSERT**				**ALL**
1-1		W3477	4009R	24		44-21-12	ALL
1-2		W3477	4009Y	24		44-21-12	ALL
1-3	J8	W3477	4009B	24		44-21-12	ALL
1-4		W3477	4009G	24		44-21-12	ALL
2-1		W3477	4010R	24		44-21-12	ALL
2-2		W3477	4010Y	24		44-21-12	ALL
2-3	J8	W3477	4010B	24		44-21-12	ALL
2-4		W3477	4010G	24		44-21-12	ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
=C1		W3477	4009Z			44-21-12	ALL
=C2		W3477	4010Z			44-21-12	ALL
=C3	UNUSED						ALL
D40417P	**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
1-1		W4477	4009R	24		44-21-12	ALL
1-2		W4477	4009Y	24		44-21-12	ALL
1-3	J5	W4477	4009B	24		44-21-12	ALL
1-4		W4477	4009G	24		44-21-12	ALL
2-1		W4477	4010R	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40417P		**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
	2-2		W4477	4010Y	24		44-21-12	ALL
	2-3	J5	W4477	4010B	24		44-21-12	ALL
	2-4		W4477	4010G	24		44-21-12	ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
	=C1		W4477	4009Z			44-21-12	ALL
	=C2		W4477	4010Z			44-21-12	ALL
	=C3	UNUSED						ALL
D40418J		**AB0857L/302/L014**		**INSERT RCPT**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W4477	4011R	24		44-21-12	ALL
	1-2		W4477	4011Y	24		44-21-12	ALL
	1-3		W4477	4011B	24		44-21-12	ALL
	1-4		W4477	4011G	24		44-21-12	ALL
	2-1		W4477	4012R	24		44-21-12	ALL
	2-2		W4477	4012Y	24		44-21-12	ALL
	2-3		W4477	4012B	24		44-21-12	ALL
	2-4		W4477	4012G	24		44-21-12	ALL
	=C1		W4477	4011Z			44-21-12	ALL
	=C2		W4477	4012Z			44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40419J	**AB0857L/302/L014**		**INSERT**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W3477	4013R	24		44-21-12	ALL
1-2		W3477	4013Y	24		44-21-12	ALL
1-3		W3477	4013B	24		44-21-12	ALL
1-4		W3477	4013G	24		44-21-12	ALL
2-1		W3477	4014R	24		44-21-12	ALL
2-2		W3477	4014Y	24		44-21-12	ALL
2-3		W3477	4014B	24		44-21-12	ALL
2-4		W3477	4014G	24		44-21-12	ALL
=C1		W3477	4013Z			44-21-12	ALL
=C2		W3477	4014Z			44-21-12	ALL
D40419P	**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W4477	4033R	24		44-21-12	ALL
1-2		W4477	4033Y	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40419P		**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
	1-3		W4477	4033B	24		44-21-12	ALL
	1-4		W4477	4033G	24		44-21-12	ALL
	2-1		W4477	4034R	24		44-21-12	ALL
	2-2		W4477	4034Y	24		44-21-12	ALL
	2-3		W4477	4034B	24		44-21-12	ALL
	2-4		W4477	4034G	24		44-21-12	ALL
	=C1		W4477	4033Z			44-21-12	ALL
	=C2		W4477	4034Z			44-21-12	ALL
D40420J		**AB0857L/302/L014**		**INSERT**				**ALL**
	1-1		W3477	4015Y	24		44-21-12	ALL
	1-2		W3477	4015R	24		44-21-12	ALL
	1-3		W3477	4015G	24		44-21-12	ALL
	1-4	J8	W3477	4015B	24		44-21-12	ALL
	2-1		W3477	4016Y	24		44-21-12	ALL
	2-2		W3477	4016R	24		44-21-12	ALL
	2-3		W3477	4016G	24		44-21-12	ALL
	2-4	J8	W3477	4016B	24		44-21-12	ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
	=C1		W3477	4015Z			44-21-12	ALL
	=C2		W3477	4016Z			44-21-12	ALL
	=C3	UNUSED						ALL
D40420P		**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
	1-1		W4477	4035Y	24		44-21-12	ALL
	1-2		W4477	4035R	24		44-21-12	ALL
	1-3		W4477	4035G	24		44-21-12	ALL
	1-4	J5	W4477	4035B	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40420P	**AB0857L/302/L014**		**INSERT PLUG (continued)**				**ALL**
2-1		W4477	4036Y	24		44-21-12	ALL
2-2		W4477	4036R	24		44-21-12	ALL
2-3		W4477	4036G	24		44-21-12	ALL
2-4	J5	W4477	4036B	24		44-21-12	ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
=C1		W4477	4035Z			44-21-12	ALL
=C2		W4477	4036Z			44-21-12	ALL
=C3	UNUSED						ALL
D40428J	**E002-01/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE**				**ALL**
A01		W0212	6001	20		28-21-11	ALL
A02		W0212	2014B	22		24-33-11	ALL
A03	UNUSED						ALL
A04		W0212	0200	22		23-71-01	ALL
A05		W0212	0212	22		21-27-21	ALL
A06		W0212	2004R	22		24-22-11	ALL
A07		W0212	0205	20		28-23-11	ALL
A08		W0212	0206	20		28-23-11	ALL
A09		W0212	0201	22		23-71-01	ALL
A10		W0212	2007B	22		24-22-31	ALL
B01		W0212	0002	22		21-27-31	ALL
B02		W0212	2014R	22		24-33-11	ALL
B03		W0212	0211	22		21-27-21	ALL
B04	UNUSED						ALL
B05		W0212	0210	22		28-23-11	ALL
B06		W0212	2004B	22		24-22-11	ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40428J		**E002-01/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0212	2007R	22		24-22-31	ALL
	F		W0212	0011	18		24-11-11	ALL
	G	UNUSED						ALL
	H		W0212	0214	20		28-23-11	ALL
	J		W0212	0213	20		28-23-11	ALL
	K		W0212	0215	20		28-23-11	ALL
	DED		W0212	2007Z			24-22-31	ALL
	DED		W0212	2014Z			24-33-11	ALL
	PERB		W0212	2004Z			24-22-11	ALL
D40428P		**E002-01/ /**		**PLUG-**				**ALL**
	A01		W5510	6013	20		28-21-11	ALL
	A02		W5510	2203B	22		24-33-11	ALL
	A03	UNUSED						ALL
	A04		W5510	0011	22		23-71-01	ALL
	A05		W5510	6018	22		21-27-21	ALL
	A06		W5510	2201R	22		24-22-11	ALL
	A07		W5510	0019	20		28-23-11	ALL
	A08		W5510	0020	20		28-23-11	ALL
	A09		W5510	0012	22		23-71-01	ALL
	A10		W5510	2202B	22		24-22-31	ALL
	B01		W5510	5501	22		21-27-31	ALL
	B02		W5510	2203R	22		24-33-11	ALL
	B03		W5510	6019	22		21-27-21	ALL
	B04	UNUSED						ALL
	B05		W5510	0018	20		28-23-11	ALL
	B06		W5510	2201B	22		24-22-11	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40428P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5510	2202R	22		24-22-31	ALL
	F		W5510	0574	18		24-11-11	ALL
	G	UNUSED						ALL
	H		W5510	0043	20		28-23-11	ALL
	J		W5510	0042	20		28-23-11	ALL
	K		W5510	0044	20		28-23-11	ALL
	DED		W5510	2202Z			24-22-31	ALL
	DED		W5510	2203Z			24-33-11	ALL
	PERG	1F	W5510	2201Z			24-22-11	ALL
D40430J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0220	1005	20		74-11-11	ALL
	A02		W0220	2030R	24		73-21-11	ALL
	A03		W0220	0371R	22		26-11-31	ALL
	A04		W0220	0369R	22		26-11-31	ALL
	A05		W0220	1065	24		73-21-12	ALL
	A06		W0220	1004	20		73-22-11	ALL
	A07		W0220	2052R	20		78-32-51	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0220	2030B	24		73-21-11	ALL
	B03		W0220	0373R	22		26-11-31	ALL
	B04		W0220	0357R	22		26-11-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0220	2052B	20		78-32-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40430J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B08		W0220	0099	22		32-35-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0220	1004Z			73-22-11	ALL
	PERG	1F	W0220	1005Z			74-11-11	ALL
	PERG	1F	W0220	1065Z			73-21-12	ALL
	PERG	1F	W0220	2030Z			73-21-11	ALL
	PERG	1F	W0220	2052Z			78-32-51	ALL
D40430P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5506	1303	20		74-11-11	ALL
	A02		W5506	2611R	24		73-21-11	ALL
	A03		W5506	6002R	20		26-11-31	ALL
	A04		W5506	6003R	20		26-11-31	ALL
	A05		W5506	1001	24		73-21-12	ALL
	A06		W5506	1311	20		73-22-11	ALL
	A07		W5506	2202R	20		78-32-51	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5506	2611B	24		73-21-11	ALL
	B03		W5506	6001R	22		26-11-31	ALL
	B04		W5506	6053R	22		26-11-21	ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40430P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W5506	2202B	20		78-32-51	ALL
	B08		W5506	0524	20		32-35-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5506	1001Z			73-21-12	ALL
	PERG	1F	W5506	1303Z			74-11-11	ALL
	PERG	1F	W5506	1311Z			73-22-11	ALL
	PERG	1F	W5506	2202Z			78-32-51	ALL
	PERG	1F	W5506	2611Z			73-21-11	ALL
D40432J		**E004-02/ /**		**RCPT**				**ALL**
	A01		W0422	0001	20		22-13-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40432J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40432P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W6222	0008	20		22-13-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40434J	**AB0839L/302/L12**		**INSERT**				**ALL**
3		W3477	0064	20		44-35-11	ALL
4		W3477	0062	20		44-35-11	ALL
5		W3477	0061	20		44-35-11	ALL
6		W3477	0063	20		44-35-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W3477	4017Y	24		44-35-05	ALL
1-2		W3477	4017R	24		44-35-05	ALL
1-3		W3477	4017G	24		44-35-05	ALL
1-4		W3477	4017B	24		44-35-05	ALL
2-1		W3477	4018Y	24		44-35-05	ALL
2-2		W3477	4018R	24		44-35-05	ALL
2-3		W3477	4018G	24		44-35-05	ALL
2-4		W3477	4018B	24		44-35-05	ALL
=C1		W3477	4017Z			44-35-05	ALL
=C2		W3477	4018Z			44-35-05	ALL
D40434P	**AB0839L/302/L12**		**INSERT PLUG**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W4479	4001Y	24		44-35-05	ALL
1-2		W4479	4001R	24		44-35-05	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40434P		**AB0839L/302/L12**		**INSERT PLUG (continued)**				**ALL**
	1-3		W4479	4001G	24		44-35-05	ALL
	1-4		W4479	4001B	24		44-35-05	ALL
	2-1		W4479	4002Y	24		44-35-05	ALL
	2-2		W4479	4002R	24		44-35-05	ALL
	2-3		W4479	4002G	24		44-35-05	ALL
	2-4		W4479	4002B	24		44-35-05	ALL
	=C1		W4479	4001Z			44-35-05	ALL
	=C2		W4479	4002Z			44-35-05	ALL
D40439J		**AB0410/205/R039**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6208	0502	22		27-11-11	ALL
	A05		W6208	0501	24		27-21-11	ALL
	A06		W6208	0530	20		27-41-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6208	0529	22		27-11-11	ALL
	B05		W6208	0500	24		27-21-11	ALL
	B06		W6208	0531	20		27-41-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40439P		**AB0410/*/***		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6412	0520	22		27-11-11	ALL
	A05		W6412	0513	24		27-21-11	ALL
	A06		W6412	0041	20		31-31-15	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6412	0519	22		27-11-11	ALL
	B05		W6412	0512	24		27-21-11	ALL
	B06		W6412	0040	20		31-31-15	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40441J		**AB0410/*/***		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6420	2002R	24		21-51-22	ALL
	A05		W6420	3001B	24		21-51-22	ALL
	A06		W6420	3001Y	24		21-51-22	ALL
	A07		W6420	2003B	24		21-51-22	ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40441J		**AB0410/*/***		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6420	2002B	24		21-51-22	ALL
	B05		W6420	3001R	24		21-51-22	ALL
	B06		W6420	2003R	24		21-51-22	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6420	2002Z			21-51-22	ALL
	PERG	1F	W6420	2003Z			21-51-22	ALL
	PERG	1F	W6420	3001Z			21-51-22	ALL
D40441P		**AB0410/205/R039**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6528	2002R	24		21-51-22	ALL
	A05		W6528	3002B	24		21-51-22	ALL
	A06		W6528	3002Y	24		21-51-22	ALL
	A07		W6528	2003B	24		21-51-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40441P		**AB0410/205/R039**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04		W6528	2002B	24		21-51-22	ALL
	B05		W6528	3002R	24		21-51-22	ALL
	B06		W6528	2003R	24		21-51-22	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6528	2002Z			21-51-22	ALL
	PERG	1F	W6528	2003Z			21-51-22	ALL
	PERG	1F	W6528	3002Z			21-51-22	ALL
D40442J		**AB0410/205/R039**		**RECP-CONDUCTIVE**				**ALL**
	A01		W5112	3203R	20		28-23-11	ALL
	A02		W5112	3203Y	20		28-23-11	ALL
	A03		W5112	3203B	20		28-23-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5112	3201R	20		28-23-11	ALL
	A07		W5112	3201B	20		28-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5112	3201Y	20		28-23-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40442J		**AB0410/205/R039**		**RECP-CONDUCTIVE (continued)**				**ALL**
	B09	UNUSED						ALL
	B10		W5112	0531	22		28-43-11	ALL
D40442P		**AB0410/205/R039**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5568	3601R	20		28-23-11	ALL
	A02		W5568	3601Y	20		28-23-11	ALL
	A03		W5568	3601B	20		28-23-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5568	3603R	20		28-23-11	ALL
	A07		W5568	3603B	20		28-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5568	3603Y	20		28-23-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5568	6003	22		28-43-11	ALL
D40444J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0044	0606	24		21-61-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40444J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0044	6243	20		36-11-13	ALL
12		W0044	6244	20		36-11-13	ALL
13		W0044	0595	24		21-51-12	ALL
14		W0044	0599	24		21-51-15	ALL
15	UNUSED						ALL
16		W0044	0824	24		21-51-12	ALL
17		W0044	0596	24		21-51-12	ALL
18		W0044	0597	22		21-51-12	ALL
19		W0044	0344	20		33-32-11	ALL
20		W0044	0332	20		33-32-11	ALL
21	UNUSED						ALL
22		W0044	0598	24		21-51-14	ALL
23		W0044	0504	22		23-51-51	ALL
24		W0044	0505	22		23-51-51	ALL
D40444P	**P006-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6214	5550	24		21-61-11	ALL
4		W6214	5544	20		SPARE	ALL
5		W6214	5545	20		SPARE	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W6214	5540	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40444P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	10		W6214	5541	20		SPARE	ALL
	11		W6214	5542	20		36-11-13	ALL
	12		W6214	5543	20		36-11-13	ALL
	13		W6214	0301	24		21-51-12	ALL
	14		W6214	5503	24		21-51-15	ALL
	15	UNUSED						ALL
	16		W6214	0310	24		21-51-12	ALL
	17		W6214	0302	24		21-51-12	ALL
	18		W6214	0303	24		21-51-12	ALL
	19		W6214	0001	20		33-32-11	ALL
	20		W6214	0002	20		33-32-11	ALL
	21	UNUSED						ALL
	22		W6214	5522	22		21-51-14	ALL
	23		W6214	0201	22		23-51-51	ALL
	24		W6214	0202	22		23-51-51	ALL
D40445J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0399	22		22-11-18	ALL
	A02		W0066	2019R	24		22-11-51	ALL
	A03		W0066	2020R	24		34-31-21	ALL
	A04		W0066	0405	22		34-51-41	ALL
	A05		W0066	0407	22		34-51-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0066	2019B	24		22-11-51	ALL
	B03		W0066	2020B	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40445J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B04		W0066	0406	22		34-51-41	ALL
	B05		W0066	0409	22		34-51-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	2019Z			22-11-51	ALL
	PERG	1F	W0066	2020Z			34-31-21	ALL
D40445P		**J046-00/ /**		**PLUG -**				**ALL**
	A01		W2151	0045	22		22-11-18	ALL
	A02		W2151	2004R	24		22-11-51	ALL
	A03		W2151	2001R	24		34-31-21	ALL
	A04		W2151	0031	22		34-51-41	ALL
	A05		W2151	0033	22		34-51-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2151	2004B	24		22-11-51	ALL
	B03		W2151	2001B	24		34-31-21	ALL
	B04		W2151	0032	22		34-51-41	ALL
	B05		W2151	0051	22		34-51-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40445P		**J046-00/ /**		**PLUG - (continued)**				**ALL**
	B10	UNUSED						ALL
	PERG	1F	W2151	2001Z			34-31-21	ALL
	PERG	1F	W2151	2004Z			22-11-51	ALL
D40446J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0321	2351R	24		31-31-13	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0321	0213	24		21-31-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0321	2351B	24		31-31-13	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2351Z			31-31-13	ALL
D40446P		**E003-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40446P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5310	2301R	24		31-31-13	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5310	5501	24		21-31-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5310	2301B	24		31-31-13	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5310	5502	24		SPARE	ALL
	PERG	1F	W5310	2301Z			31-31-13	ALL
D40448J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	0081	24		80-11-11	ALL
	A02		W0311	2051B	24		73-24-12	ALL
	A03	UNUSED						ALL
	A04		W0311	0009	22		30-31-12	ALL
	A05		W0311	2042B	24		73-24-11	ALL
	A06		W0311	2069B	24		77-12-21	ALL
	A07		W0311	2717R	24		31-31-13	ALL
	A08	UNUSED						ALL
	A09		W0311	1766	20		80-11-11	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40448J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0311	1754	24		75-11-11	ALL
	B02		W0311	2051R	24		73-24-12	ALL
	B03	UNUSED						ALL
	B04		W0311	0008	22		30-31-12	ALL
	B05		W0311	2042R	24		73-24-11	ALL
	B06		W0311	2069R	24		77-12-21	ALL
	B07		W0311	2717B	24		31-31-13	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40448J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B20	UNUSED						ALL
	PERG	1F	W0311	2042Z			73-24-11	ALL
	PERG	1F	W0311	2051Z			73-24-12	ALL
	PERG	1F	W0311	2069Z			77-12-21	ALL
	PERG	1F	W0311	2717Z			31-31-13	ALL
D40448P		**E003-01/ /**		**PLUG-**				**ALL**
	A01		W5310	6001	24		80-11-11	ALL
	A02		W5310	2602B	24		73-24-12	ALL
	A03	UNUSED						ALL
	A04		W5310	6005	22		30-31-12	ALL
	A05		W5310	2601B	24		73-24-11	ALL
	A06		W5310	2607B	24		77-12-21	ALL
	A07		W5310	2301R	24		31-31-13	ALL
	A08	UNUSED						ALL
	A09		W5310	0001	20		80-11-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5310	6006	24		75-11-11	ALL
	B02		W5310	2602R	24		73-24-12	ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40448P		**E003-01/ /**		**PLUG- (continued)**				**ALL**
	B04		W5310	6004	22		30-31-12	ALL
	B05		W5310	2601R	24		73-24-11	ALL
	B06		W5310	2607R	24		77-12-21	ALL
	B07		W5310	2301B	24		31-31-13	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5310	2301Z			31-31-13	ALL
	PERG	1F	W5310	2601Z			73-24-11	ALL
	PERG	1F	W5310	2602Z			73-24-12	ALL
	PERG	1F	W5310	2607Z			77-12-21	ALL
D40450J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0220	0216	24		80-11-11	ALL
	A02		W0220	2035B	24		73-24-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0220	0329	22		30-31-12	ALL
	A06		W0220	0064	24		21-31-24	ALL
	A07		W0220	2045B	24		73-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40450J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0220	2037B	24		77-12-21	ALL
	A12		W0220	0298	20		80-11-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0220	0513	24		75-11-11	ALL
	B02		W0220	2035R	24		73-24-12	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0220	0328	22		30-31-12	ALL
	B06	UNUSED						ALL
	B07		W0220	2045R	24		73-24-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0220	2037R	24		77-12-21	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40450J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0220	2035Z			73-24-12	ALL
	PERG	1F	W0220	2037Z			77-12-21	ALL
	PERG	1F	W0220	2045Z			73-24-11	ALL
D40450P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5310	6001	24		80-11-11	ALL
	A02		W5310	2602B	24		73-24-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5310	6005	22		30-31-12	ALL
	A06		W5310	5501	24		21-31-24	ALL
	A07		W5310	2601B	24		73-24-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W5310	2607B	24		77-12-21	ALL
	A12		W5310	0001	20		80-11-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5310	6006	24		75-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40450P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B02		W5310	2602R	24		73-24-12	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W5310	6004	22		30-31-12	ALL
B06		W5310	5502	24		SPARE	ALL
B07		W5310	2601R	24		73-24-11	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W5310	2607R	24		77-12-21	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5310	2601Z			73-24-11	ALL
PERG	1F	W5310	2602Z			73-24-12	ALL
PERG	1F	W5310	2607Z			77-12-21	ALL
D40451J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0066	0399	22		22-11-18	ALL
A02		W0066	2019R	24		22-11-51	ALL
A03		W0066	0406	22		34-51-41	ALL
A04		W0066	0408	22		34-51-41	ALL
A05		W0066	0428	22		27-61-42	ALL
A06		W0066	0429	22		27-61-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40451J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A07	UNUSED						ALL
	A08		W0066	0433	22		34-21-22	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0066	0405	22		34-51-41	ALL
	B02		W0066	2019B	24		22-11-51	ALL
	B03		W0066	2020R	24		34-31-21	ALL
	B04		W0066	2020B	24		34-31-21	ALL
	B05		W0066	0430	22		27-61-42	ALL
	B06		W0066	0431	22		27-61-42	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	2019Z			22-11-51	ALL
	PERG	1F	W0066	2020Z			34-31-21	ALL
D40451P		**J046-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5121	0018	22		22-11-18	ALL
	A02		W5121	2037R	24		22-11-51	ALL
	A03		W5121	0030	22		34-51-41	ALL
	A04		W5121	0004	22		34-51-41	ALL
	A05		W5121	0040	22		27-61-42	ALL
	A06		W5121	0041	22		27-61-42	ALL
	A07	UNUSED						ALL
	A08		W5121	0502	22		34-21-22	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5121	0003	22		34-51-41	ALL
	B02		W5121	2037B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40451P		**J046-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B03		W5121	2039R	24		34-31-21	ALL
	B04		W5121	2039B	24		34-31-21	ALL
	B05		W5121	0042	22		27-61-42	ALL
	B06		W5121	0043	22		27-61-42	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5121	2037Z			22-11-51	ALL
	PERG	1F	W5121	2039Z			34-31-21	ALL
D40452J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0043	20		22-11-12	ALL
	A02		W0111	0045	22		22-11-12	ALL
	A03		W0111	0046	22		22-11-12	ALL
	A04		W0111	0375	22		34-21-11	ALL
	A05		W0111	0655	22		27-53-11	ALL
	A06		W0111	0745	22		32-64-11	ALL
	A07	UNUSED						ALL
	A08		W0111	0350	22		34-21-16	ALL
	A09		W0111	0741	22		32-31-11	ALL
	A10		W0111	0859	24		21-31-24	ALL
	B01		W0111	0746	22		32-64-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0111	0742	22		32-31-11	ALL
	B05		W0111	2133B	24		73-24-11	ALL
	B06		W0111	2133R	24		73-24-11	ALL
	B07	UNUSED						ALL
	B08		W0111	0398	22		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40452J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B09		W0111	0482	22		32-64-21	ALL
	B10		W0111	0854	24		21-31-24	ALL
	PERG	1F	W0111	2133Z			73-24-11	ALL
D40452P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5156	0501	20		22-11-12	ALL
	A02		W5156	0502	20		22-11-12	ALL
	A03		W5156	0595	20		22-11-12	ALL
	A04		W5156	0517	22		34-21-11	ALL
	A05		W5156	0542	22		27-53-11	ALL
	A06		W5156	0544	22		32-64-11	ALL
	A07	UNUSED						ALL
	A08		W5156	0615	22		34-21-16	ALL
	A09		W5156	0656	22		32-31-11	ALL
	A10		W5156	0206	24		21-31-24	ALL
	B01		W5156	0573	22		32-64-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5156	0614	22		32-31-11	ALL
	B05		W5156	2610B	24		73-24-11	ALL
	B06		W5156	2610R	24		73-24-11	ALL
	B07	UNUSED						ALL
	B08		W5156	0513	22		34-51-11	ALL
	B09		W5156	0598	22		32-64-21	ALL
	B10		W5156	0205	24		21-31-24	ALL
	PERG	1F	W5156	2610Z			73-24-11	ALL
D40454J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0288	24		34-49-11	ALL
	A02		W0111	0228	24		34-45-11	ALL
	A03		W0111	0364	22		34-61-17	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40454J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	A04		W0111	2203R	24		31-32-15	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0111	2205R	24		34-49-11	ALL
	A10		W0111	0946	20		78-34-11	ALL
	B01		W0111	2132R	22		24-28-41	ALL
	B02		W0111	2132B	22		24-28-41	ALL
	B03		W0111	0355	22		34-21-16	ALL
	B04		W0111	2203B	24		31-32-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0111	0475	24		34-49-11	ALL
	B08	UNUSED						ALL
	B09		W0111	2205B	24		34-49-11	ALL
	B10		W0111	0410	22		31-32-15	ALL
	PERG	1F	W0111	2203Z			31-32-15	ALL
	PERG	1F	W0111	2205Z			34-49-11	ALL
D40454P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5156	0511	22		34-49-11	ALL
	A02		W5156	0512	22		34-45-11	ALL
	A03		W5156	0521	22		34-61-17	ALL
	A04		W5156	2011R	24		31-32-15	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5156	2003R	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40454P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A10		W5156	6014	20		78-34-11	ALL
	B01		W5156	2202R	22		24-28-41	ALL
	B02		W5156	2202B	22		24-28-41	ALL
	B03		W5156	5515	22		34-21-16	ALL
	B04		W5156	2011B	24		31-32-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5156	0014	24		34-49-11	ALL
	B08	UNUSED						ALL
	B09		W5156	2003B	24		34-49-11	ALL
	B10		W5156	0669	22		31-32-15	ALL
	PERG	1F	W5156	2003Z			34-49-11	ALL
	PERG	1F	W5156	2011Z			31-32-15	ALL
D40456J		**E002-02/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0220	0314	24		21-31-22	ALL
	A05		W0220	0318	22		26-16-21	ALL
	A06		W0220	2003B	22		24-22-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0220	0078	24		21-51-12	ALL
	A10		W0220	0316	20		21-31-22	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0220	2003R	22		24-22-11	ALL
	B04		W0220	0315	24		21-31-22	ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40456J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W0220	0381R	20		26-11-31	ALL
	B08		W0220	0062	24		21-31-24	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0220	0130	20		29-25-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40456P		**E002-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5156	0054	24		21-31-22	ALL
	A05		W5156	0057	22		26-16-21	ALL
	A06		W5156	2201B	22		24-22-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5156	0039	24		21-51-12	ALL
	A10		W5156	0056	20		21-31-22	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5156	2201R	22		24-22-11	ALL
	B04		W5156	0055	24		21-31-22	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5156	6001R	20		26-11-31	ALL
	B08		W5156	5522	24		21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40456P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5156	0585	18		29-25-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D40458J		**E001-01/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0111	2404R	24		32-64-31	ALL
	A02		W0111	2404B	24		32-64-31	ALL
	A03	UNUSED						ALL
	A04		W0111	2284R	24		31-35-04	ALL
	A05		W0111	0494	24		34-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0111	2405R	24		32-64-31	ALL
	A10		W0111	2405B	24		32-64-31	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0111	2284B	24		31-35-04	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0111	0956	22		34-33-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0111	2284Z			31-35-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40458J		**E001-01/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	2404Z			32-64-31	ALL
	PERG	1F	W0111	2405Z			32-64-31	ALL
D40458P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5156	2620R	24		32-64-31	ALL
	A02		W5156	2620B	24		32-64-31	ALL
	A03	UNUSED						ALL
	A04		W5156	2630R	24		31-35-04	ALL
	A05		W5156	0026	24		34-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5156	2621R	24		32-64-31	ALL
	A10		W5156	2621B	24		32-64-31	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5156	2630B	24		31-35-04	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W5156	0510	22		34-33-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	2620Z			32-64-31	ALL
	PERG	1F	W5156	2621Z			32-64-31	ALL
	PERG	1F	W5156	2630Z			31-35-04	ALL
D40460J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	0206	24		34-61-26	ALL
	A02		W0311	0149	22		34-57-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40460J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A03		W0311	0063	24		73-22-31	ALL
	A04		W0311	0067	24		73-23-11	ALL
	A05		W0311	0068	24		73-23-11	ALL
	A06		W0311	0036	24		76-21-11	ALL
	A07		W0311	0060	24		73-22-11	ALL
	A08		W0311	0140	20		SPARE	ALL
	A09		W0311	2769R	24		31-65-15	ALL
	A10		W0311	2719R	24		36-11-14	ALL
	A11		W0311	2752R	24		31-65-14	ALL
	A12		W0311	2755R	24		32-64-31	ALL
	A13		W0311	2756R	24		31-65-15	ALL
	A14		W0311	2759R	24		31-65-15	ALL
	A15		W0311	2768R	24		31-65-25	ALL
	A16		W0311	1757	24		76-21-11	ALL
	A17		W0311	2773R	24		31-65-14	ALL
	A18		W0311	2773B	24		31-65-14	ALL
	A19		W0311	2779R	24		31-65-15	ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0311	2052R	24		73-24-12	ALL
	B03		W0311	2052B	24		73-24-12	ALL
	B04	UNUSED						ALL
	B05		W0311	2041B	24		73-24-11	ALL
	B06		W0311	2041R	24		73-24-11	ALL
	B07		W0311	0629	22		34-41-11	ALL
	B08	UNUSED						ALL
	B09		W0311	2769B	24		31-65-15	ALL
	B10		W0311	2719B	24		36-11-14	ALL
	B11		W0311	2752B	24		31-65-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40460J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B12		W0311	2755B	24		32-64-31	ALL
	B13		W0311	2756B	24		31-65-15	ALL
	B14		W0311	2759B	24		31-65-15	ALL
	B15		W0311	2768B	24		31-65-25	ALL
	B16		W0311	1769	22		30-21-31	ALL
	B17		W0313	0506	22		21-27-21	ALL
	B18		W0311	2202R	22		32-46-11	ALL
	B19		W0311	2779B	24		31-65-15	ALL
	B20		W0311	2202B	22		32-46-11	ALL
	PERG	1F	W0311	2041Z			73-24-11	ALL
	PERG	1F	W0311	2052Z			73-24-12	ALL
	PERG	1F	W0311	2202Z			32-46-11	ALL
	PERG	1F	W0311	2719Z			36-11-14	ALL
	PERG	1F	W0311	2752Z			31-65-14	ALL
	PERG	1F	W0311	2755Z			32-64-31	ALL
	PERG	1F	W0311	2756Z			31-65-15	ALL
	PERG	1F	W0311	2759Z			31-65-15	ALL
	PERG	1F	W0311	2768Z			31-65-25	ALL
	PERG	1F	W0311	2769Z			31-65-15	ALL
	PERG	1F	W0311	2773Z			31-65-14	ALL
	PERG	1F	W0311	2779Z			31-65-15	ALL
D40460P		**E003-01/ /**		**PLUG-**				**ALL**
	A01		W5156	0126	24		34-61-26	ALL
	A02		W5156	0516	22		34-57-11	ALL
	A03		W5156	6004	24		73-22-31	ALL
	A04		W5156	6007	24		73-23-11	ALL
	A05		W5156	6008	24		73-23-11	ALL
	A06		W5156	6012	24		76-21-11	ALL
	A07		W5156	6017	24		73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40460P		**E003-01/ /**		**PLUG- (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W5156	2402R	24		31-65-15	ALL
	A10		W5156	2502R	24		36-11-14	ALL
	A11		W5156	2503R	24		31-65-14	ALL
	A12		W5156	2614R	24		32-64-31	ALL
	A13		W5156	2615R	24		31-65-15	ALL
	A14		W5156	2616R	24		31-65-15	ALL
	A15		W5156	2607R	24		31-65-25	ALL
	A16		W5156	6026	24		76-21-11	ALL
	A17		W5156	2622R	24		31-65-14	ALL
	A18		W5156	2622B	24		31-65-14	ALL
	A19		W5156	2101R	24		31-65-15	ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5156	2013R	24		73-24-12	ALL
	B03		W5156	2013B	24		73-24-12	ALL
	B04	UNUSED						ALL
	B05		W5156	2613B	24		73-24-11	ALL
	B06		W5156	2613R	24		73-24-11	ALL
	B07		W5156	0028	22		34-41-11	ALL
	B08	UNUSED						ALL
	B09		W5156	2402B	24		31-65-15	ALL
	B10		W5156	2502B	24		36-11-14	ALL
	B11		W5156	2503B	24		31-65-14	ALL
	B12		W5156	2614B	24		32-64-31	ALL
	B13		W5156	2615B	24		31-65-15	ALL
	B14		W5156	2616B	24		31-65-15	ALL
	B15		W5156	2607B	24		31-65-25	ALL
	B16		W5156	0092	22		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40460P		**E003-01/ /**		**PLUG- (continued)**				**ALL**
	B17		W5156	5535	22		21-27-21	ALL
	B18		W5156	2102R	22		32-46-11	ALL
	B19		W5156	2101B	24		31-65-15	ALL
	B20		W5156	2102B	22		32-46-11	ALL
	PERG	1F	W5156	2013Z			73-24-12	ALL
	PERG	1F	W5156	2101Z			31-65-15	ALL
	PERG	1F	W5156	2102Z			32-46-11	ALL
	PERG	1F	W5156	2402Z			31-65-15	ALL
	PERG	1F	W5156	2502Z			36-11-14	ALL
	PERG	1F	W5156	2503Z			31-65-14	ALL
	PERG	1F	W5156	2607Z			31-65-25	ALL
	PERG	1F	W5156	2613Z			73-24-11	ALL
	PERG	1F	W5156	2614Z			32-64-31	ALL
	PERG	1F	W5156	2615Z			31-65-15	ALL
	PERG	1F	W5156	2616Z			31-65-15	ALL
	PERG	1F	W5156	2622Z			31-65-14	ALL
D40462J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0134	22		27-32-11	ALL
	A02		W0321	0626	22		27-61-45	ALL
	A03		W0321	0136	24		27-32-11	ALL
	A04		W0321	0054	24		31-31-15	ALL
	A05		W0321	0083	22		26-16-21	ALL
	A06		W0321	2258B	24		31-35-04	ALL
	A07		W0321	2258R	24		31-35-04	ALL
	A08		W0321	0823	22		27-62-11	ALL
	A09	UNUSED						ALL
	A10		W0321	2049R	22		27-61-43	ALL
	A11		W0321	0824	22		27-62-11	ALL
	A12		W0321	2126R	24		31-35-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40462J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W0321	0138	24		27-32-11	ALL
	A17	UNUSED						ALL
	A18		W0321	0315	22		31-53-11	ALL
	A19		W0321	0317	22		31-53-11	ALL
	A20		W0321	0933	22		27-62-11	ALL
	B01		W0321	0579	22		27-61-41	ALL
	B02	UNUSED						ALL
	B03		W0321	2049B	22		27-61-43	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0321	2126B	24		31-35-04	ALL
	B13		W0321	0426	22		29-23-11	ALL
	B14		W0321	2380R	24		31-65-14	ALL
	B15		W0321	2380B	24		31-65-14	ALL
	B16		W0321	0986	22		27-61-49	ALL
	B17	UNUSED						ALL
	B18		W0321	2257B	24		31-35-04	ALL
	B19		W0321	2257R	24		31-35-04	ALL
	B20		W0321	0962	22		27-61-49	ALL
	PERG	1F	W0321	2126Z			31-35-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40462J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0321	2257Z			31-35-04	ALL
PERG	1F	W0321	2258Z			31-35-04	ALL
PERG	1F	W0321	2380Z			31-65-14	ALL
D40462P	**E003-02/ /**		**PLUG-**				**ALL**
A01		W5156	0506	22		27-32-11	ALL
A02		W5156	0118	22		27-61-45	ALL
A03		W5156	0508	22		27-32-11	ALL
A04		W5156	0522	22		31-31-15	ALL
A05		W5156	0057	22		26-16-21	ALL
A06		W5156	2617B	24		21-51-12	ALL
A07		W5156	2617R	24		21-51-12	ALL
A08		W5156	0082	22		27-62-11	ALL
A09	UNUSED						ALL
A10		W5156	2002R	22		27-61-43	ALL
A11		W5156	0083	22		27-62-11	ALL
A12		W5156	2630R	24		31-35-04	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16		W5156	0567	22		27-32-11	ALL
A17	UNUSED						ALL
A18		W5156	0582	22		31-53-11	ALL
A19		W5156	0583	22		31-53-11	ALL
A20		W5156	0104	20		27-62-11	ALL
B01		W5156	0117	22		27-61-41	ALL
B02	UNUSED						ALL
B03		W5156	2002B	22		27-61-43	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40462P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W5156	2630B	24		31-35-04	ALL
	B13		W5156	0550	22		29-23-11	ALL
	B14		W5156	2622R	24		31-65-14	ALL
	B15		W5156	2622B	24		31-65-14	ALL
	B16		W5156	0721	22		27-61-49	ALL
	B17	UNUSED						ALL
	B18		W5156	2618B	24		21-51-12	ALL
	B19		W5156	2618R	24		21-51-12	ALL
	B20		W5156	0715	22		27-61-49	ALL
	PERG	1F	W5156	2617Z			21-51-12	ALL
	PERG	1F	W5156	2618Z			21-51-12	ALL
	PERG	1F	W5156	2622Z			31-65-14	ALL
	PERG	1F	W5156	2630Z			31-35-04	ALL
D40464J		**E001-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0111	0149	20		22-13-11	ALL
	A02		W0111	0142	20		22-13-11	ALL
	A03		W0111	0581	22		31-53-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0111	0483	22		32-64-21	ALL
	A07		W0111	2253R	24		27-32-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40464J	**E001-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A10	UNUSED						ALL
B01		W0111	0450	22		22-13-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W0111	0890	22		25-51-21	ALL
B05	UNUSED						ALL
B06		W0111	0955	20		33-42-21	ALL
B07		W0111	2253B	24		27-32-22	ALL
B08		W0111	0806	24		21-31-23	ALL
B09		W0111	0807	24		21-31-23	ALL
B10		W0111	0808	20		21-31-23	ALL
PERG	1F	W0111	2253Z			27-32-22	ALL
D40464P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5160	0501	22		22-13-11	ALL
A02		W5160	0502	22		22-13-11	ALL
A03		W5160	0599	22		31-53-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W5160	0609	22		32-64-21	ALL
A07		W5160	2003R	24		27-32-22	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5160	0538	22		22-13-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5160	0619	22		25-51-21	ALL
B05	UNUSED						ALL
B06		W5160	0152	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40464P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B07		W5160	2003B	24		27-32-22	ALL
	B08		W5160	0066	24		21-31-23	ALL
	B09		W5160	0067	24		21-31-23	ALL
	B10		W5160	0068	20		21-31-23	ALL
	PERG	1F	W5160	2003Z			27-32-22	ALL
D40466J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0137	0045	22		27-62-11	ALL
	A02		W0137	0047	22		27-62-11	ALL
	A03		W0131	0449	20		44-21-10	ALL
	A04		W0131	0447	20		44-21-10	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0131	0092	22		32-64-21	ALL
	A08		W0131	0104	22		52-71-12	ALL
	A09		W0131	0084	24		32-42-11	ALL
	A10		W0131	0085	24		32-42-11	ALL
	A11		W0131	0086	22		32-42-11	ALL
	A12		W0131	0087	22		32-42-11	ALL
	A13		W0131	0129	20		22-11-12	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0131	0248	22		44-21-22	ALL
	A19	UNUSED						ALL
	A20		W0131	2032R	22		32-46-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40466J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0131	0054	24		23-31-06	ALL
B13		W0131	0055	24		23-31-06	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W0131	2037R	22		32-49-11	ALL
B18		W0131	2037B	22		32-49-11	ALL
B19	UNUSED						ALL
B20		W0131	2032B	22		32-46-11	ALL
PERG	1F	W0131	2032Z			32-46-11	ALL
PERG	1F	W0131	2037Z			32-49-11	ALL
D40466P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5160	0658	22		27-62-11	ALL
A02		W5160	0659	22		27-62-11	ALL
A03		W5160	0104	20		44-21-10	ALL
A04		W5160	0103	20		44-21-10	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5160	0559	22		32-64-21	ALL
A08		W5160	0003	22		52-71-12	ALL
A09		W5160	0700	22		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40466P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A10		W5160	0701	22		32-42-11	ALL
	A11		W5160	0703	22		32-42-11	ALL
	A12		W5160	0705	22		32-42-11	ALL
	A13		W5160	0596	20		22-11-12	ALL
	A14		W5160	0652	22		SPARE	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W5160	0537	22		44-21-22	ALL
	A19	UNUSED						ALL
	A20		W5160	2102R	22		32-46-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5160	0653	22		SPARE	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W5160	0654	24		23-31-06	ALL
	B13		W5160	0655	24		23-31-06	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5160	2202R	20		32-49-11	ALL
	B18		W5160	2202B	20		32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40466P	**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B19	UNUSED						ALL
B20		W5160	2102B	22		32-46-11	ALL
PERG	1F	W5160	2102Z			32-46-11	ALL
PERG	1F	W5160	2202Z			32-49-11	ALL
D40470J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	0559	24		31-31-15	ALL
A02		W0321	0223	20		28-42-11	ALL
A03		W0321	0318	20		78-34-21	ALL
A04		W0321	0014	22		44-21-22	ALL
A05		W0321	0631	22		27-61-45	ALL
A06		W0321	0558	24		31-31-15	ALL
A07		W0321	0939	22		27-62-11	ALL
A08		W0321	0942	22		27-62-11	ALL
A09		W0321	0157	22		23-27-38	ALL
A10		W0321	0152	22		23-27-38	ALL
B01		W0321	0639	22		22-11-31	ALL
B02		W0321	0314	20		78-34-21	ALL
B03	UNUSED						ALL
B04		W0321	0224	20		28-42-11	ALL
B05		W0321	0055	24		31-31-15	ALL
B06		W0321	0092	24		31-31-15	ALL
B07		W0325	0967	22		27-61-49	ALL
B08		W0321	0154	22		23-27-38	ALL
B09		W0321	0158	22		23-27-38	ALL
B10		W0321	0153	22		23-27-38	ALL
D40470P	**E003-02/ /**		**PLUG-**				**ALL**
A01		W5160	0142	24		31-31-15	ALL
A02		W5160	6006	20		28-42-11	ALL
A03		W5160	6028	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40470P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A04		W5160	0537	22		44-21-22	ALL
	A05		W5160	0193	22		27-61-45	ALL
	A06		W5160	0141	24		31-31-15	ALL
	A07		W5160	0623	22		27-62-11	ALL
	A08		W5160	0624	22		27-62-11	ALL
	A09		W5160	0617	22		23-27-38	ALL
	A10		W5160	0614	22		23-27-38	ALL
	B01		W5160	0205	22		22-11-31	ALL
	B02		W5160	6027	20		78-34-21	ALL
	B03	UNUSED						ALL
	B04		W5160	6007	20		28-42-11	ALL
	B05		W5160	0561	22		31-31-15	ALL
	B06		W5160	0584	22		31-31-15	ALL
	B07		W5160	0719	22		27-61-49	ALL
	B08		W5160	0616	22		23-27-38	ALL
	B09		W5160	0618	22		23-27-38	ALL
	B10		W5160	0615	22		23-27-38	ALL
D40472J		**E004-02/ /**		**RCPT**				**ALL**
	A01		W0422	2019B	22		24-22-21	ALL
	A02		W0422	2019R	22		24-22-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0422	2419R	22		52-71-11	ALL
	A10		W0422	2419B	22		52-71-11	ALL
	A11		W0422	0249	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40472J	**E004-02/ /**		**RCPT (continued)**				**ALL**
A12		W0422	0243	22		28-23-11	ALL
A13		W0422	0239	20		28-23-11	ALL
A14		W0422	0019	24		23-15-15	ALL
A15		W0422	0020	24		23-15-15	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0422	0055	22		29-23-11	ALL
B04		W0422	0170	22		29-23-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0422	0247	20		28-23-11	ALL
B08		W0422	0233	24		21-31-23	ALL
B09		W0422	0234	24		21-31-23	ALL
B10		W0422	0235	20		21-31-23	ALL
B11	UNUSED						ALL
B12		W0422	0238	20		28-23-11	ALL
B13		W0422	0250	20		28-23-11	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40472P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5160	2201B	22		24-22-21	ALL
	A02		W5160	2201R	22		24-22-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5160	2419R	22		52-71-11	ALL
	A10		W5160	2419B	22		52-71-11	ALL
	A11		W5160	0119	20		28-23-11	ALL
	A12		W5160	0110	20		28-23-11	ALL
	A13		W5160	0112	20		28-23-11	ALL
	A14		W5160	0312	24		23-15-15	ALL
	A15		W5160	0313	24		23-15-15	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5160	0520	22		29-23-11	ALL
	B04		W5160	0595	22		29-23-11	ALL
	B05		W5160	2460R	22		SPARE	ALL
	B06		W5160	2460B	22		SPARE	ALL
	B07		W5160	0118	20		28-23-11	ALL
	B08		W5160	0066	24		21-31-23	ALL
	B09		W5160	0067	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40472P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B10		W5160	0068	20		21-31-23	ALL
	B11	UNUSED						ALL
	B12		W5160	0111	20		28-23-11	ALL
	B13		W5160	0120	20		28-23-11	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40474J		**E004-02/ /**		**RCPT-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
	A01		W0422	0014	20		27-23-11	ALL
	A02		W0422	0015	20		27-23-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0422	0532	22		32-31-15	ALL
	A06		W0422	0533	22		32-31-15	ALL
	A07		W0422	0531	22		32-31-15	ALL
	A08	UNUSED						ALL
	A09		W0422	2003B	22		24-22-21	ALL
	A10		W0422	2003R	22		24-22-21	ALL
	B01	UNUSED						ALL
	B02		W0422	0307	22		46-13-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40474J		**E004-02/ /**		**RCPT-CONDUCTIVE W/ BACKSHELL ZERO LENGTH (continued)**				**ALL**
	B08	UNUSED						ALL
	B09		W0422	0535	20		27-23-11	ALL
	B10	UNUSED						ALL
	PERB		W0422	2003Z			24-22-21	ALL
D40474P		**E004-02/ /**		**PLUG-CONDUCTIVE W/ BACKSHELL ZERO LENGTH**				**ALL**
	A01		W5160	0310	22		27-23-11	ALL
	A02		W5160	0311	22		27-23-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5160	0713	22		32-31-15	ALL
	A06		W5160	0716	22		32-31-15	ALL
	A07		W5160	0715	22		32-31-15	ALL
	A08	UNUSED						ALL
	A09		W5160	2203B	22		24-22-21	ALL
	A10		W5160	2203R	22		24-22-21	ALL
	B01	UNUSED						ALL
	B02		W5160	0718	22		46-13-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5160	0309	20		27-23-11	ALL
	B10	UNUSED						ALL
	PERB		W5160	2203Z			24-22-21	ALL
D40484J		**E004-02/ /**		**RCPT**				**ALL**
	A01		W0422	2001B	24		73-21-11	ALL
	A02		W0422	2001R	24		73-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40484J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	A03		W0422	0308R	20		26-12-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0422	0148	22		21-27-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0422	0154	20		22-11-11	ALL
	B04	UNUSED						ALL
	B05		W0422	0011	20		27-23-11	ALL
	B06		W0422	0012	20		27-23-11	ALL
	B07	UNUSED						ALL
	B08		W0422	0232	24		21-31-24	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0422	0053	18		29-25-11	ALL
	G		W0422	0054	18		29-25-11	ALL
	H		W0422	0056	20		29-23-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0422	2001Z			73-21-11	ALL
D40484P		**E004-02/ /**		**CONNECTOR - PLUG**				**ALL**
	A01		W5158	2611B	24		73-21-11	ALL
	A02		W5158	2611R	24		73-21-11	ALL
	A03		W5158	6012R	20		26-12-11	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40484P		**E004-02/ /**		**CONNECTOR - PLUG (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5158	0577	22		21-27-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5158	0544	20		22-11-11	ALL
	B04	UNUSED						ALL
	B05		W5158	0534	22		27-23-11	ALL
	B06		W5158	0533	22		27-23-11	ALL
	B07	UNUSED						ALL
	B08		W5158	0555	22		21-31-24	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5158	0549	18		29-25-11	ALL
	G		W5158	0550	18		29-25-11	ALL
	H		W5158	0519	20		29-23-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5158	2611Z			73-21-11	ALL
D40486J		**E003-02/ /**		**RCPT-**				**ALL**
	A01		W0325	0589	22		27-62-11	ALL
	A02		W0321	0775	22		34-57-21	ALL
	A03		W0321	0030	22		73-23-11	ALL
	A04		W0321	0085	24		31-31-15	ALL
	A05		W0321	0978	24		21-51-22	ALL
	A06		W0321	1791	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40486J	**E003-02/ /**		**RCPT- (continued)**				**ALL**
A07		W0321	0008	22		31-31-11	ALL
A08		W0321	0014	22		44-21-22	ALL
A09		W0321	0736	22		27-61-49	ALL
A10		W0321	0755	22		27-61-49	ALL
A11		W0321	0742	22		27-61-49	ALL
A12		W0321	0056	24		31-31-15	ALL
A13		W0321	0178	24		31-31-15	ALL
A14		W0321	1799	24		21-51-21	ALL
A15		W0321	0208	24		31-31-15	ALL
A16		W0321	2050B	22		27-61-43	ALL
A17		W0321	2050R	22		27-61-43	ALL
A18		W0321	1793	24		21-43-21	ALL
A19		W0321	0126	20		29-11-11	ALL
A20		W0321	0058	24		31-31-15	ALL
B01		W0321	1790	24		21-27-31	ALL
B02		W0321	0979	24		21-51-22	ALL
B03		W0321	0216	24		21-51-11	ALL
B04		W0321	0088	24		73-22-31	ALL
B05		W0321	0498	22		26-16-21	ALL
B06		W0321	1792	24		21-43-21	ALL
B07		W0321	0007	22		31-31-11	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0321	0748	22		27-61-49	ALL
B12		W0321	0825	22		27-62-11	ALL
B13	UNUSED						ALL
B14		W0321	1797	24		21-51-11	ALL
B15		W0321	0637	22		22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40486J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	B16		W0321	0968	22		27-61-49	ALL
	B17		W0321	2291R	22		27-62-11	ALL
	B18		W0321	2291B	22		27-62-11	ALL
	B19		W0321	0125	20		29-11-11	ALL
	B20		W0321	0499	20		47-30-11	ALL
D40486P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W5158	0112	20		27-62-11	ALL
	A02		W5158	0516	22		34-57-21	ALL
	A03		W5158	6001	24		73-23-11	ALL
	A04		W5158	0525	22		31-31-15	ALL
	A05		W5158	0699	24		21-51-22	ALL
	A06		W5158	0708	24		21-43-21	ALL
	A07		W5158	0696	22		31-31-11	ALL
	A08		W5158	0512	22		44-21-22	ALL
	A09		W5158	0715	22		27-61-49	ALL
	A10		W5158	0716	20		27-61-49	ALL
	A11		W5158	0717	20		27-61-49	ALL
	A12		W5158	0505	22		31-31-15	ALL
	A13		W5158	0622	24		31-31-15	ALL
	A14		W5158	5511	24		21-51-21	ALL
	A15		W5158	0030	22		31-31-15	ALL
	A16		W5158	2004B	22		27-61-43	ALL
	A17		W5158	2004R	22		27-61-43	ALL
	A18		W5158	0710	24		21-43-21	ALL
	A19		W5158	0528	20		29-11-11	ALL
	A20		W5158	0520	22		31-31-15	ALL
	B01		W5158	0698	24		21-27-31	ALL
	B02		W5158	1104	24		21-51-22	ALL
	B03		W5158	5502	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40486P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	B04		W5158	6005	24		73-22-31	ALL
	B05		W5158	0032	22		26-16-21	ALL
	B06		W5158	0709	24		21-43-21	ALL
	B07		W5158	0697	22		31-31-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W5158	0719	22		27-61-49	ALL
	B12		W5158	0713	22		27-62-11	ALL
	B13	UNUSED						ALL
	B14		W5158	5503	24		21-51-11	ALL
	B15		W5158	0217	22		22-11-31	ALL
	B16		W5158	0718	22		27-61-49	ALL
	B17		W5158	2008R	22		27-62-11	ALL
	B18		W5158	2008B	22		27-62-11	ALL
	B19		W5158	0527	20		29-11-11	ALL
	B20		W5158	0635	20		47-30-11	ALL
D40488J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0137	0091	24		32-44-11	ALL
	A02		W0137	0115	24		32-42-11	ALL
	A03		W0137	0116	24		32-42-11	ALL
	A04		W0137	0062	22		32-41-11	ALL
	A05		W0137	0004	24		31-31-15	ALL
	A06		W0131	2012R	24		23-31-06	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0137	2574R	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40488J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A12	UNUSED						ALL
	A13		W0137	0058	24		31-31-15	ALL
	A14		W0131	2012B	24		23-31-06	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0131	2026R	24		23-31-06	ALL
	A19		W0131	2526R	24		23-31-06	ALL
	A20		W0131	0149	20		23-31-06	ALL
	B01		W0137	0060	24		32-41-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0137	2574B	24		31-65-25	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0131	2026B	24		23-31-06	ALL
	B19		W0131	2526B	24		23-31-06	ALL
	B20		W0131	0390	22		23-31-06	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40488J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0131	2012Z			23-31-06	ALL
PERG	1F	W0131	2026Z			23-31-06	ALL
PERG	1F	W0131	2526Z			23-31-06	ALL
PERG	1F	W0137	2574Z			31-65-25	ALL
D40488P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5158	0524	22		32-44-11	ALL
A02		W5158	0560	22		32-42-11	ALL
A03		W5158	0561	22		32-42-11	ALL
A04		W5158	0611	22		32-41-11	ALL
A05		W5158	0622	24		31-31-15	ALL
A06		W5158	2001R	24		23-31-06	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11		W5158	2401R	24		31-65-25	ALL
A12	UNUSED						ALL
A13		W5158	0525	22		31-31-15	ALL
A14		W5158	2001B	24		23-31-06	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18		W5158	2002R	24		23-31-06	ALL
A19		W5158	2003R	24		23-31-06	ALL
A20		W5158	0630	20		23-31-06	ALL
B01		W5158	0612	22		32-41-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40488P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W5158	2401B	24		31-65-25	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W5158	2002B	24		23-31-06	ALL
	B19		W5158	2003B	24		23-31-06	ALL
	B20		W5158	0631	22		23-31-06	ALL
	PERG	1F	W5158	2001Z			23-31-06	ALL
	PERG	1F	W5158	2002Z			23-31-06	ALL
	PERG	1F	W5158	2003Z			23-31-06	ALL
	PERG	1F	W5158	2401Z			31-65-25	ALL
D40498J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0131	0123	22		34-31-11	ALL
	A02		W0131	0117	24		32-42-11	ALL
	A03		W0131	0118	24		32-42-11	ALL
	A04		W0131	0065	22		32-41-11	ALL
	A05		W0131	0122	22		32-41-11	ALL
	A06		W0131	0066	22		32-41-11	ALL
	A07		W0131	0037	24		23-12-11	ALL
	A08		W0131	0093	24		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40498J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A09		W0131	0399	22		32-46-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0131	4504W	22		32-46-11	ALL
	B04		W0131	4504G	22		32-46-11	ALL
	B05		W0131	0153	22		44-21-22	ALL
	B06		W0131	0151	22		44-21-22	ALL
	B07		W0131	2062R	22		27-62-11	ALL
	B08		W0131	2062B	22		27-62-11	ALL
	B09		W0131	0246	22		44-21-22	ALL
	B10	UNUSED						ALL
	F		W0131	0104	22		52-71-12	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0131	4504Z			32-46-11	ALL
D40498P		**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5156	0509	22		34-31-11	ALL
	A02		W5156	0560	22		32-42-11	ALL
	A03		W5156	0561	22		32-42-11	ALL
	A04		W5156	0632	22		32-41-11	ALL
	A05		W5156	0634	22		32-41-11	ALL
	A06		W5156	0635	22		32-41-11	ALL
	A07		W5156	0520	22		23-12-11	ALL
	A08		W5156	0631	22		32-41-11	ALL
	A09		W5156	0722	22		32-46-11	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40498P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5156	4502W	20		32-46-11	ALL
	B04		W5156	4502G	20		32-46-11	ALL
	B05		W5156	0618	22		44-21-22	ALL
	B06		W5156	0616	22		44-21-22	ALL
	B07		W5156	2019R	22		27-62-11	ALL
	B08		W5156	2019B	22		27-62-11	ALL
	B09		W5156	0659	22		44-21-22	ALL
	B10		W5156	0645	20		SPARE	ALL
	F		W5156	0001	18		52-71-12	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5156	4502Z			32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40500J	**AB0500DL/ /**		**RCPT-**				**ALL**
1		W5248	0499	20		SPARE	ALL
2		W5248	5509	20		30-71-11	ALL
3		W5248	0500	20		SPARE	ALL
4		W5248	0287	20		33-36-12	ALL
5		W5248	0288	20		33-36-12	ALL
6	UNUSED						ALL
7		W5248	0303R	20		26-12-11	ALL
8		W5248	0304R	20		26-12-11	ALL
9	UNUSED						ALL
10		W5248	2444B	20		52-71-11	ALL
11		W5248	2409B	20		52-71-11	ALL
12		W5248	0384	20		33-36-12	ALL
13		W5248	5513	20		30-71-11	ALL
14		W5248	5514	20		30-71-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5248	0046	20		52-71-12	ALL
24		W5248	5524	20		30-71-11	ALL
25		W5248	2444R	20		52-71-11	ALL
26		W5248	2409R	20		52-71-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40500J		**AB0500DL/ /**		**RCPT- (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W5248	0301R	20		26-12-11	ALL
	38		W5248	0302R	20		26-12-11	ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
D40500P		**AB0500DL/ /**		**PLUG-**				**ALL**
	1		W6248	0499	20		SPARE	ALL
	2		W6248	5509	20		30-71-11	ALL
	3		W6248	0500	20		SPARE	ALL
	4		W6248	0287	20		33-36-12	ALL
	5		W6248	0288	20		33-36-12	ALL
	6	UNUSED						ALL
	7		W6248	0303R	20		26-12-11	ALL
	8		W6248	0304R	20		26-12-11	ALL
	9	UNUSED						ALL
	10		W6248	2444B	20		52-71-11	ALL
	11		W6248	2409B	20		52-71-11	ALL
	12		W6248	0384	20		33-36-12	ALL
	13		W6248	5513	20		30-71-11	ALL
	14		W6248	5514	20		30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40500P	**AB0500DL/ /**		**PLUG- (continued)**				**ALL**
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W6248	0046	20		52-71-12	ALL
24		W6248	5590	20		30-71-11	ALL
25		W6248	2444R	20		52-71-11	ALL
26		W6248	2409R	20		52-71-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W6248	0301R	20		26-12-11	ALL
38		W6248	0302R	20		26-12-11	ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40502J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W0044	0228	20		27-23-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0044	0243	22		29-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0044	0230	20		27-53-11	ALL
	9	UNUSED						ALL
	10		W0044	6209	20		33-42-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40502P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W2104	0501	20		27-23-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2104	0504	22		29-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2104	0520	20		27-53-11	ALL
	9	UNUSED						ALL
	10		W2104	0030	20		33-42-21	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40504J		**P018-00/ /**		**RCPT-**				**ALL**
	1		W0018	6150	20		33-44-12	ALL
	2		W0018	0205	22		26-16-21	ALL
	3		W0018	0206	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40504J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
4		W0018	0339	20		33-44-12	ALL
5	18	W0018	0194	18		33-42-21	ALL
6		W0018	0338	20		33-44-11	ALL
7		W0018	0727	18		30-42-11	ALL
8		W0018	0207	22		26-16-22	ALL
9		W0018	0208	22		26-16-22	ALL
10		W0018	0171	22		30-31-12	ALL
11		W0018	0209	22		26-23-11	ALL
12		W0018	0210	22		26-23-11	ALL
D40504P	**P018-00/ /**		**PLUG-**				**ALL**
1		W2104	0032	20		33-44-12	ALL
2		W2104	6007	22		26-16-21	ALL
3		W2104	6008	22		26-16-21	ALL
4		W2104	0008	20		33-44-12	ALL
5	18	W2104	0034	18		33-42-21	ALL
6		W2104	0014	20		33-44-11	ALL
7		W2104	5505	18		30-42-11	ALL
8		W2104	6009	22		26-16-22	ALL
9		W2104	6010	22		26-16-22	ALL
10		W2104	0036	22		30-31-12	ALL
11		W2104	6011	22		26-23-11	ALL
12		W2104	6012	22		26-23-11	ALL
D40506J	**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0220	0509	20		33-42-21	ALL
A02		W0220	0031	24		27-23-14	ALL
A03		W0220	1001	20		33-44-11	ALL
A04		W0220	0257	22		26-16-21	ALL
A05	UNUSED						ALL
A06		W0220	0270	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40506J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A07		W0220	0273	22		26-16-22	ALL
	A08		W0220	0289	22		26-23-11	ALL
	A09		W0220	0290	22		26-23-11	ALL
	A10		W0220	0023	20		33-44-12	ALL
	B01		W0220	0510	20		33-42-21	ALL
	B02		W0220	0511	20		33-42-21	ALL
	B03		W0220	0512	20		33-42-21	ALL
	B04		W0220	0260	22		26-16-21	ALL
	B05		W0220	0326	22		30-31-12	ALL
	B06		W0220	0133	24		29-34-11	ALL
	B07		W0220	0037	22		29-11-11	ALL
	B08		W0220	0022	20		33-44-12	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0220	0016	18		33-42-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0220	1001Z			33-44-11	ALL
D40506P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W2104	0026	20		33-42-21	ALL
	A02		W2104	0514	24		27-23-14	ALL
	A03		W2104	1016	20		33-44-11	ALL
	A04		W2104	6007	22		26-16-21	ALL
	A05	UNUSED						ALL
	A06		W2104	6009	22		26-16-22	ALL
	A07		W2104	6010	22		26-16-22	ALL
	A08		W2104	6011	22		26-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40506P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A09		W2104	6012	22		26-23-11	ALL
A10		W2104	0009	20		33-44-12	ALL
B01		W2104	0027	20		33-42-21	ALL
B02		W2104	0028	20		33-42-21	ALL
B03		W2104	0029	20		33-42-21	ALL
B04		W2104	6008	22		26-16-21	ALL
B05		W2104	0036	22		30-31-12	ALL
B06		W2104	0510	24		29-34-11	ALL
B07		W2104	0505	22		29-11-11	ALL
B08		W2104	0031	20		33-44-12	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2104	0034	18		33-42-21	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W2104	1016Z			33-44-11	ALL
D40508J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0313	2672R	24		34-41-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40508J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0313	2672B	24		34-41-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40508J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B20	UNUSED						ALL
	PERG	1F	W0313	2672Z			34-41-11	ALL
D40508P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2112	2014R	24		34-41-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2112	2014B	24		34-41-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40508P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2112	2014Z			34-41-11	ALL
D40510J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	0955	20		33-42-21	ALL
	A02	UNUSED						ALL
	A03		W0111	0705	24		27-81-11	ALL
	A04		W0111	0708	24		27-81-11	ALL
	A05		W0111	0665	24		27-81-12	ALL
	A06		W0111	0667	24		27-81-12	ALL
	A07		W0111	0669	24		27-81-12	ALL
	A08		W0111	0671	24		27-81-12	ALL
	A09		W0111	0673	24		27-81-12	ALL
	A10		W0111	0675	24		27-81-12	ALL
	A11		W0111	0677	24		27-81-21	ALL
	A12		W0111	0679	24		27-81-21	ALL
	A13		W0111	0681	24		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40510J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A14		W0111	0683	24		27-81-22	ALL
	A15		W0111	0685	24		27-81-22	ALL
	A16		W0111	0687	24		27-81-22	ALL
	A17		W0111	0689	24		27-81-22	ALL
	A18		W0111	0691	24		27-81-22	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0111	0143	22		34-51-41	ALL
	B02	UNUSED						ALL
	B03		W0111	0706	24		27-81-11	ALL
	B04		W0111	0709	24		27-81-11	ALL
	B05		W0111	0666	24		27-81-12	ALL
	B06		W0111	0668	24		27-81-12	ALL
	B07		W0111	0670	24		27-81-12	ALL
	B08		W0111	0672	24		27-81-12	ALL
	B09		W0111	0674	24		27-81-12	ALL
	B10		W0111	0676	24		27-81-12	ALL
	B11		W0111	0678	24		27-81-21	ALL
	B12		W0111	0680	24		27-81-21	ALL
	B13		W0111	0682	24		27-81-22	ALL
	B14		W0111	0684	24		27-81-22	ALL
	B15		W0111	0686	24		27-81-22	ALL
	B16		W0111	0688	24		27-81-22	ALL
	B17		W0111	0690	24		27-81-22	ALL
	B18		W0111	0692	24		27-81-22	ALL
	B19		W0111	0805	24		21-31-11	ALL
	B20	UNUSED						ALL
D40510P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W2218	0090	20		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40510P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A02	UNUSED						ALL
	A03		W2218	0524	24		27-81-11	ALL
	A04		W2218	0526	24		27-81-11	ALL
	A05		W2218	0528	24		27-81-12	ALL
	A06		W2218	0530	24		27-81-12	ALL
	A07		W2218	0532	24		27-81-12	ALL
	A08		W2218	0534	24		27-81-12	ALL
	A09		W2218	0536	24		27-81-12	ALL
	A10		W2218	0538	24		27-81-12	ALL
	A11		W2218	0540	24		27-81-21	ALL
	A12		W2218	0542	24		27-81-21	ALL
	A13		W2218	0544	24		27-81-22	ALL
	A14		W2218	0546	24		27-81-22	ALL
	A15		W2218	0548	24		27-81-22	ALL
	A16		W2218	0550	24		27-81-22	ALL
	A17		W2218	0552	24		27-81-22	ALL
	A18		W2218	0554	24		27-81-22	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2218	0013	22		34-51-41	ALL
	B02	UNUSED						ALL
	B03		W2218	0525	24		27-81-11	ALL
	B04		W2218	0527	24		27-81-11	ALL
	B05		W2218	0529	24		27-81-12	ALL
	B06		W2218	0531	24		27-81-12	ALL
	B07		W2218	0533	24		27-81-12	ALL
	B08		W2218	0535	24		27-81-12	ALL
	B09		W2218	0537	24		27-81-12	ALL
	B10		W2218	0539	24		27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40510P	**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B11		W2218	0541	24		27-81-21	ALL
B12		W2218	0543	24		27-81-21	ALL
B13		W2218	0545	24		27-81-22	ALL
B14		W2218	0547	24		27-81-22	ALL
B15		W2218	0549	24		27-81-22	ALL
B16		W2218	0551	24		27-81-22	ALL
B17		W2218	0553	24		27-81-22	ALL
B18		W2218	0555	24		27-81-22	ALL
B19		W2218	6101	24		21-31-11	ALL
B20	UNUSED						ALL
D40512J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0449	24		21-31-22	ALL
2	UNUSED						ALL
3	18	W0044	6158	18		73-22-41	ALL
4	UNUSED						ALL
5		W0044	0519	20		31-32-15	ALL
6		W0044	0334	20		30-41-11	ALL
7		W0044	0445	20		21-31-22	ALL
8		W0044	0448	24		21-31-22	ALL
9		W0044	0486	22		30-31-12	ALL
10	18	W0044	6159	18		73-22-41	ALL
11	UNUSED						ALL
12	18	W0044	6157	18		73-22-41	ALL
13		W0044	6163	24		36-11-13	ALL
14		W0044	0100	20		33-17-11	ALL
15		W0044	6164	24		36-11-13	ALL
D40512P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2112	5521	24		21-31-22	ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40512P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	3	18	W2112	6090	18		73-22-41	ALL
	4	UNUSED						ALL
	5		W2112	8026	20		31-32-15	ALL
	6		W2112	5537	20		30-41-11	ALL
	7		W2112	5522	20		21-31-22	ALL
	8		W2112	5524	24		21-31-22	ALL
	9		W2112	5525	22		30-31-12	ALL
	10	18	W2112	6091	18		73-22-41	ALL
	11	UNUSED						ALL
	12	18	W2112	6089	18		73-22-41	ALL
	13		W2112	6085	24		36-11-13	ALL
	14		W2112	5552	20		33-17-11	ALL
	15		W2112	6086	24		36-11-13	ALL
D40514J		**P018-00/ /**		**RCPT-**				**ALL**
	1		W0018	0517	20		34-21-15	ALL
	2		W0018	6149	20		30-11-11	ALL
	3		W0018	0813	22		34-33-11	ALL
	4		W0018	0812	22		34-51-11	ALL
	5		W0018	0880	22		34-51-11	ALL
	6		W0018	6119	20		30-11-11	ALL
	7		W0018	0731	20		30-71-11	ALL
	8		W0018	0045	20		30-71-11	ALL
	9		W0018	0711	20		30-21-31	ALL
	10		W0018	0337	20		33-43-11	ALL
	11		W0018	0343	20		33-49-11	ALL
	12		W0018	0722	22		30-31-12	ALL
	13		W0018	0721	22		30-31-12	ALL
	14		W0018	0719	22		30-31-12	ALL
	15		W0018	6118	20		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40514J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
16		W0018	0863	20		80-11-11	ALL
17		W0018	0743	22		31-31-11	ALL
18		W0018	0755	20		30-11-11	ALL
19	UNUSED						ALL
20		W0018	0733	20		30-71-11	ALL
21		W0018	0742	22		31-31-11	ALL
22		W0018	6120	20		30-11-11	ALL
23		W0018	0712	20		30-21-31	ALL
24		W0018	0720	22		30-31-12	ALL
25		W0018	0838	20		31-32-15	ALL
26		W0018	0077	20		23-71-01	ALL
27		W0018	0076	22		23-71-01	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40514P	**P018-00/ /**		**PLUG-**				**ALL**
1		W2112	8027	20		34-21-15	ALL
2		W2112	0013	20		30-11-11	ALL
3		W2112	6088	22		34-33-11	ALL
4		W2112	6076	22		34-51-11	ALL
5		W2112	6075	22		34-51-11	ALL
6		W2112	0010	20		30-11-11	ALL
7		W2112	0500	20		30-71-11	ALL
8		W2112	0527	20		30-71-11	ALL
9		W2112	6001	20		30-21-31	ALL
10		W2112	0005	20		33-43-11	ALL
11		W2112	0001	20		33-49-11	ALL
12		W2112	5527	22		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40514P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	13		W2112	5528	22		30-31-12	ALL
	14		W2112	5529	22		30-31-12	ALL
	15		W2112	6057	20		30-11-11	ALL
	16		W2112	6050	20		80-11-11	ALL
	17		W2112	8002	22		31-31-11	ALL
	18		W2112	6066	20		30-11-11	ALL
	19	UNUSED						ALL
	20		W2112	0528	20		30-71-11	ALL
	21		W2112	8001	22		31-31-11	ALL
	22		W2112	1061	20		30-11-11	ALL
	23		W2112	6049	20		30-21-31	ALL
	24		W2112	5526	22		30-31-12	ALL
	25		W2112	8026	20		31-32-15	ALL
	26		W2112	5560	20		23-71-01	ALL
	27		W2112	5559	22		23-71-01	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	DED		W2112	1061Z			30-11-11	ALL
	DED		W2112	6057Z			30-11-11	ALL
D40516J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	2101R	24		34-51-11	ALL
	A02		W0311	0130	22		34-21-15	ALL
	A03		W0311	2102R	24		34-51-11	ALL
	A04		W0311	0078	24		73-32-11	ALL
	A05		W0311	0027	24		74-31-11	ALL
	A06		W0311	0066	22		30-21-31	ALL
	A07		W0311	0033	24		74-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40516J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A08		W0311	2727R	24		34-33-11	ALL
	A09		W0311	0198	22		30-21-31	ALL
	A10		W0311	1760	20		78-36-11	ALL
	A11	UNUSED						ALL
	A12		W0311	0042	22		30-11-11	ALL
	A13	UNUSED						ALL
	A14		W0311	0017	24		31-65-14	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0311	2101B	24		34-51-11	ALL
	B02		W0311	0127	22		34-21-15	ALL
	B03		W0311	2102B	24		34-51-11	ALL
	B04		W0311	0030	24		74-31-11	ALL
	B05		W0311	0057	24		73-21-12	ALL
	B06		W0311	0075	24		73-31-11	ALL
	B07		W0311	0180	24		31-65-41	ALL
	B08		W0311	2727B	24		34-33-11	ALL
	B09		W0311	0012	22		30-21-31	ALL
	B10		W0311	0111	22		34-51-41	ALL
	B11		W0311	1763	20		78-36-21	ALL
	B12		W0311	0191	24		31-65-14	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W0311	0087	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40516J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2101Z			34-51-11	ALL
	PERG	1F	W0311	2102Z			34-51-11	ALL
	PERG	1F	W0311	2727Z			34-33-11	ALL
D40516P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2112	2009R	24		34-51-11	ALL
	A02		W2112	8023	22		34-21-15	ALL
	A03		W2112	2010R	24		34-51-11	ALL
	A04		W2112	6014	24		73-32-11	ALL
	A05		W2112	6017	24		74-31-11	ALL
	A06		W2112	6028	22		30-21-31	ALL
	A07		W2112	6019	24		74-31-11	ALL
	A08		W2112	2013R	24		34-33-11	ALL
	A09		W2112	6084	22		30-21-31	ALL
	A10		W2112	0090	20		78-36-11	ALL
	A11	UNUSED						ALL
	A12		W2112	5586	22		30-11-11	ALL
	A13	UNUSED						ALL
	A14		W2112	6071	24		31-65-14	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2112	2009B	24		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40516P	**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B02		W2112	8022	22		34-21-15	ALL
B03		W2112	2010B	24		34-51-11	ALL
B04		W2112	6016	24		74-31-11	ALL
B05		W2112	6025	24		73-21-12	ALL
B06		W2112	6031	24		73-31-11	ALL
B07		W2112	5608	22		31-65-41	ALL
B08		W2112	2013B	24		34-33-11	ALL
B09		W2112	6083	22		30-21-31	ALL
B10		W2112	8009	22		34-51-41	ALL
B11		W2112	0070	20		78-36-21	ALL
B12		W2112	6072	24		31-65-14	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16		W2112	0178	22		49-62-11	ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W2112	2009Z			34-51-11	ALL
PERG	1F	W2112	2010Z			34-51-11	ALL
PERG	1F	W2112	2013Z			34-33-11	ALL
D40518J	**E002-01/ /**		**RCPT-**				**ALL**
A01		W0210	0004	24		31-35-08	ALL
A02		W0210	2004R	24		30-41-11	ALL
A03	UNUSED						ALL
A04		W0212	0067	24		31-65-14	ALL
A05	UNUSED						ALL
A06		W0210	5517	24		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40518J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	A07		W0210	5508	24		30-41-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0210	5533	22		23-71-01	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0210	5534	22		23-71-01	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0210	5505	24		30-41-11	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0210	2004B	24		30-41-11	ALL
	B03	UNUSED						ALL
	B04		W0212	0207	22		28-43-11	ALL
	B05		W0210	5516	24		30-41-11	ALL
	B06		W0210	5518	24		30-41-11	ALL
	B07		W0210	5509	24		30-41-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0210	5507	24		30-41-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40518J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	B16		W0210	5514	24		30-41-11	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0210	2004Z			30-41-11	ALL
D40518P		**E002-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2112	0043	24		31-35-08	ALL
	A02		W2112	2003R	24		30-41-11	ALL
	A03	UNUSED						ALL
	A04		W2112	6071	24		31-65-14	ALL
	A05	UNUSED						ALL
	A06		W2112	5534	24		30-41-11	ALL
	A07		W2112	5540	24		30-41-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W2112	5561	22		23-71-01	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W2112	5562	22		23-71-01	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W2112	5538	24		30-41-11	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2112	2003B	24		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40518P		**E002-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B03	UNUSED						ALL
	B04		W2112	6072	24		31-65-14	ALL
	B05		W2112	5533	24		30-41-11	ALL
	B06		W2112	5535	24		30-41-11	ALL
	B07		W2112	5541	24		30-41-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W2112	5539	24		30-41-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W2112	5532	24		30-41-11	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2112	2003Z			30-41-11	ALL
D40520J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0220	0057	24		21-31-22	ALL
	A03		W0220	0046	24		21-31-11	ALL
	A04		W0220	0343R	22		26-11-11	ALL
	A05		W0220	0054	24		21-31-22	ALL
	A06		W0220	1002	20		21-31-22	ALL
	A07		W0220	2009R	24		21-31-22	ALL
	A08		W0220	2008R	24		21-31-22	ALL
	A09		W0220	1061	20		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40520J	**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A10		W0220	0349	22		30-21-31	ALL
A11	UNUSED						ALL
A12		W0220	0047	20		21-31-22	ALL
A13		W0220	0241	20		30-71-11	ALL
A14		W0220	2005R	22		24-23-11	ALL
A15	UNUSED						ALL
A16		W0220	2501R	24		36-21-11	ALL
A17	UNUSED						ALL
A18		W0220	0412	22		30-11-11	ALL
A19		W0220	0411	22		30-11-11	ALL
A20		W0220	0413	22		30-11-11	ALL
B01		W0220	0414	22		30-11-11	ALL
B02	UNUSED						ALL
B03		W0220	0053	24		21-31-22	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0220	1003	22		21-31-22	ALL
B07		W0220	2009B	24		21-31-22	ALL
B08		W0220	2008B	24		21-31-22	ALL
B09		W0220	0400	22		30-21-31	ALL
B10	UNUSED						ALL
B11		W0220	0410	22		30-21-31	ALL
B12	UNUSED						ALL
B13		W0220	0231	20		30-71-11	ALL
B14		W0220	2005B	22		24-23-11	ALL
B15	UNUSED						ALL
B16		W0220	2501B	24		36-21-11	ALL
B17	UNUSED						ALL
B18		W0220	0017	20		33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40520J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B19	UNUSED						ALL
	B20		W0220	1042	22		30-11-11	ALL
	PERG	1F	W0220	1002Z			21-31-22	ALL
	PERG	1F	W0220	1003Z			21-31-22	ALL
	PERG	1F	W0220	1042Z			30-11-11	ALL
	PERG	1F	W0220	1061Z			30-21-31	ALL
	PERG	1F	W0220	2008Z			21-31-22	ALL
	PERG	1F	W0220	2009Z			21-31-22	ALL
	PERG	1F	W0220	2501Z			36-21-11	ALL
D40520P		**E002-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W2112	5520	24		21-31-22	ALL
	A03		W2112	5510	24		21-31-11	ALL
	A04		W2112	1004R	22		26-11-11	ALL
	A05		W2112	5524	24		21-31-22	ALL
	A06		W2112	1001	20		21-31-22	ALL
	A07		W2112	2002R	24		21-31-22	ALL
	A08		W2112	2001R	24		21-31-22	ALL
	A09		W2112	1201	20		30-21-31	ALL
	A10		W2112	0007	22		30-21-31	ALL
	A11	UNUSED						ALL
	A12		W2112	5523	20		21-31-22	ALL
	A13		W2112	0499	20		30-71-11	ALL
	A14		W2112	2201R	22		24-23-11	ALL
	A15	UNUSED						ALL
	A16		W2112	2012R	24		36-21-11	ALL
	A17	UNUSED						ALL
	A18		W2112	0012	22		30-11-11	ALL
	A19		W2112	0011	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40520P	**E002-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A20		W2112	0014	22		30-11-11	ALL
B01		W2112	0015	22		30-11-11	ALL
B02	UNUSED						ALL
B03		W2112	5516	24		21-31-22	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W2112	1002	20		21-31-22	ALL
B07		W2112	2002B	24		21-31-22	ALL
B08		W2112	2001B	24		21-31-22	ALL
B09		W2112	0008	22		30-21-31	ALL
B10	UNUSED						ALL
B11		W2112	0009	22		30-21-31	ALL
B12	UNUSED						ALL
B13		W2112	0500	20		30-71-11	ALL
B14		W2112	2201B	22		24-23-11	ALL
B15	UNUSED						ALL
B16		W2112	2012B	24		36-21-11	ALL
B17	UNUSED						ALL
B18		W2112	0004	20		33-43-11	ALL
B19	UNUSED						ALL
B20		W2112	1061	20		30-11-11	ALL
PERG	1F	W2112	1001Z			21-31-22	ALL
PERG	1F	W2112	1002Z			21-31-22	ALL
PERG	1F	W2112	1061Z			30-11-11	ALL
PERG	1F	W2112	1201Z			30-21-31	ALL
PERG	1F	W2112	2001Z			21-31-22	ALL
PERG	1F	W2112	2002Z			21-31-22	ALL
PERG	1F	W2112	2012Z			36-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40522J		**P018-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0018	0717	22		30-31-11	ALL
	4	UNUSED						ALL
	5		W0018	0345	20		33-51-11	ALL
	6		W0018	0346	20		33-51-11	ALL
	7		W0018	0344	20		33-51-11	ALL
	8		W0018	0715	22		30-31-11	ALL
	9	UNUSED						ALL
	10		W0018	0331	18		33-41-11	ALL
	11		W0018	0718	22		30-31-11	ALL
	12		W0018	0716	22		30-31-11	ALL
D40522P		**P018-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2114	5513	22		30-31-11	ALL
	4	UNUSED						ALL
	5		W2114	0020	20		33-51-11	ALL
	6		W2114	0021	20		33-51-11	ALL
	7		W2114	0012	20		33-51-11	ALL
	8		W2114	5524	22		30-31-11	ALL
	9	UNUSED						ALL
	10		W2114	0001	18		33-41-11	ALL
	11		W2114	5515	22		30-31-11	ALL
	12		W2114	5514	22		30-31-11	ALL
D40524J		**P018-00/ /**		**RCPT-**				**ALL**
	1	18	W0018	0193	18		33-42-21	ALL
	2		W0018	0121	22		30-31-12	ALL
	3		W0018	0172	22		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40524J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
4	UNUSED						ALL
5		W0018	0173	22		30-31-12	ALL
6		W0018	0174	22		30-31-12	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0018	0728	18		30-42-11	ALL
11	UNUSED						ALL
12	18	W0018	0388	18		33-42-21	ALL
D40524P	**P018-00/ /**		**PLUG-**				**ALL**
1	18	W2212	0024	18		33-42-21	ALL
2		W2212	5551	22		30-31-12	ALL
3		W2212	5552	22		30-31-12	ALL
4	UNUSED						ALL
5		W2212	5553	22		30-31-12	ALL
6		W2212	5554	22		30-31-12	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W2212	5505	18		30-42-11	ALL
11	UNUSED						ALL
12		W2212	0014	20		33-42-21	ALL
D40526J	**P006-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0044	0226	20		27-23-11	ALL
6		W0044	0242	22		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40526J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0044	0227	20		27-23-11	ALL
	12		W0044	0235	20		27-61-43	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
D40526P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2212	0519	20		27-23-11	ALL
	6		W2212	0513	22		29-11-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W2212	0501	20		27-23-11	ALL
	12		W2212	0508	20		27-61-43	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
D40528J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W6208	0566	20		27-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40528J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
4		W6208	0567	20		27-23-11	ALL
5		W6208	0568	22		27-23-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W6208	0620	20		27-23-11	ALL
18		W6208	0618	20		27-23-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W6208	0001	18		33-42-21	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W6208	0601	20		27-23-11	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W6208	0571	22		29-11-11	ALL
31	UNUSED						ALL
32	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40528J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D40528P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2212	0503	20		27-23-11	ALL
	4		W2212	0504	20		27-23-11	ALL
	5		W2212	0505	22		27-23-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W2212	0517	20		27-23-11	ALL
	18		W2212	0518	20		27-23-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W2212	0024	18		33-42-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40528P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2212	0507	22		27-23-11	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W2212	0514	22		29-11-11	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D40530J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0410	0030	24		29-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40530J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40530P		**E004-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W2214	0506	24		29-33-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40530P	**E004-01/ /**		**PLUG- (continued)**				**ALL**
B09	UNUSED						ALL
B10	UNUSED						ALL
D40532J	**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE**				**ALL**
1	UNUSED						ALL
2	18	W0044	0077	18		33-12-11	ALL
3	18	W0044	0076	18		33-12-11	ALL
4		W0044	0483	24		36-11-31	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0044	0482	20		36-11-12	ALL
10	18	W0044	0070	18		33-12-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	16	W0044	1027	16		21-51-14	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0044	0607	24		21-61-11	ALL
21	18	W0044	0071	18		33-12-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D40532P	**P006-00/ /**		**PLUG- CONDUCTIVE**				**ALL**
1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40532P		**P006-00/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	2	18	W2216	5651	18		33-12-11	ALL
	3	18	W2216	5701	18		33-12-11	ALL
	4		W2216	5541	24		36-11-31	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2216	5565	20		36-11-12	ALL
	10	18	W2216	5601	18		33-12-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	16	W2216	6014	16		21-51-14	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W2216	5507	24		21-61-11	ALL
	21	18	W2216	5542	18		33-12-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W2216	5565Z			36-11-12	ALL
D40534J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0410	1574	20		36-11-12	ALL
	A02		W0410	1575	20		36-11-12	ALL
	A03		W0410	0070	24		36-11-12	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40534J	**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A05		W0410	1455	20		36-11-12	ALL
A06		W0410	0071	24		36-11-12	ALL
A07		W0410	1576	20		36-11-12	ALL
A08		W0410	1577	20		36-11-12	ALL
A09		W0410	1073	20		36-11-12	ALL
A10	UNUSED						ALL
A11		W0410	2501R	24		36-11-31	ALL
A12		W0410	0599	24		36-11-31	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15		W0410	0386	24		21-61-11	ALL
A16		W0410	0316	24		21-51-12	ALL
A17		W0410	0408	24		21-61-12	ALL
A18	UNUSED						ALL
A19		W0410	0431	24		21-61-14	ALL
A20		W0410	0317	24		21-51-12	ALL
B01		W0410	0588	24		36-11-31	ALL
B02		W0410	0088	24		21-51-11	ALL
B03	UNUSED						ALL
B04		W0410	0454	24		36-11-12	ALL
B05		W0410	0212	24		36-11-12	ALL
B06	UNUSED						ALL
B07		W0410	1080	24		73-21-12	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0410	2501B	24		36-11-31	ALL
B12		W0410	0594	24		36-11-31	ALL
B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40534J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B14	UNUSED						ALL
	B15		W0410	0450	24		21-61-51	ALL
	B16		W0410	0451	24		21-61-51	ALL
	B17	UNUSED						ALL
	B18		W0410	0449	24		21-61-51	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0410	1073Z			36-11-12	ALL
	PERG	1F	W0410	1080Z			73-21-12	ALL
	PERG	1F	W0410	1455Z			36-11-12	ALL
	PERG	1F	W0410	1574Z			36-11-12	ALL
	PERG	1F	W0410	1575Z			36-11-12	ALL
	PERG	1F	W0410	1576Z			36-11-12	ALL
	PERG	1F	W0410	1577Z			36-11-12	ALL
D40534P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W2216	5565	20		36-11-12	ALL
	A02		W2216	5566	20		36-11-12	ALL
	A03		W2216	5567	24		36-11-12	ALL
	A04	UNUSED						ALL
	A05		W2216	5535	20		36-11-12	ALL
	A06		W2216	5569	24		36-11-12	ALL
	A07		W2216	5536	20		36-11-12	ALL
	A08		W2216	2502R	20		36-11-12	ALL
	A09		W2216	2502B	20		36-11-12	ALL
	A10	UNUSED						ALL
	A11		W2216	2501R	24		36-11-31	ALL
	A12		W2216	5538	24		36-11-31	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40534P	**E004-01/ /**		**PLUG- (continued)**				**ALL**
A15		W2216	5509	24		21-61-11	ALL
A16		W2216	5512	24		21-51-12	ALL
A17		W2216	5514	24		21-61-12	ALL
A18	UNUSED						ALL
A19		W2216	5522	24		21-61-14	ALL
A20		W2216	5530	24		21-51-12	ALL
B01		W2216	5576	24		36-11-31	ALL
B02		W2216	0018	24		21-51-11	ALL
B03	UNUSED						ALL
B04		W2216	5534	24		36-11-12	ALL
B05		W2216	5537	24		36-11-12	ALL
B06	UNUSED						ALL
B07		W2216	1303	24		73-21-12	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W2216	2501B	24		36-11-31	ALL
B12		W2216	5556	24		36-11-31	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W2216	5511	24		21-61-51	ALL
B16		W2216	5513	24		21-61-51	ALL
B17	UNUSED						ALL
B18		W2216	5510	24		21-61-51	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W2216	1303Z			73-21-12	ALL
PERG	1F	W2216	2502Z			36-11-12	ALL
PERG	1F	W2216	5535Z			36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40534P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W2216	5536Z			36-11-12	ALL
	PERG	1F	W2216	5565Z			36-11-12	ALL
	PERG	1F	W2216	5566Z			36-11-12	ALL
D40536J		**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE**				**ALL**
	1	18	W0044	0091	18		33-14-12	ALL
	2		W0044	0223	20		34-61-12	ALL
	3		W0044	0590	22		24-28-11	ALL
	4		W0044	0701	24		23-24-11	ALL
	5		W0044	0331	20		33-32-11	ALL
	6		W0044	0332	20		33-32-11	ALL
	7		W0044	0283	22		23-43-11	ALL
	8		W0044	0484	24		36-21-11	ALL
	9		W0044	0314	24		33-25-11	ALL
	10	UNUSED						ALL
	11		W0044	0014	22		24-28-11	ALL
	12		W0044	0497	20		30-41-12	ALL
	13	UNUSED						ALL
	14	18	W0044	0086	18		33-12-12	ALL
	15	18	W0044	0082	18		33-12-12	ALL
	16		W0044	0296	22		28-42-11	ALL
	17		W0044	0458	24		21-31-25	ALL
	18		W0044	0312	24		33-25-11	ALL
	19		W0044	0284	22		23-43-11	ALL
	20		W0044	0485	22		30-31-11	ALL
	21		W0044	0474	20		21-61-51	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W0044	0612	20		21-61-15	ALL
	25		W0044	0335	20		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40536J	**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE (continued)**				**ALL**
26		W0044	0330	20		33-32-11	ALL
27	18	W0044	0087	18		33-12-12	ALL
28	UNUSED						ALL
29	18	W0044	0095	18		33-14-12	ALL
30		W0044	0313	24		33-25-11	ALL
31		W0044	0285	22		23-42-11	ALL
32	UNUSED						ALL
33		W0044	0481	20		36-11-22	ALL
34		W0044	6165	24		36-11-23	ALL
35		W0044	6166	24		36-11-23	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W0044	6020	20		30-21-32	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53		W0044	0169	20		33-18-31	ALL
54		W0044	0762	20		33-18-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40536J		**P006-00/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE (continued)**				**ALL**
	55		W0044	6238	20		33-18-41	ALL
D40536P		**P006-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1	18	W2218	5560	18		33-14-12	ALL
	2		W2218	8005	20		34-61-12	ALL
	3		W2218	0507	22		24-28-11	ALL
	4		W2218	0012	24		23-24-11	ALL
	5		W2218	0026	20		33-32-11	ALL
	6		W2218	0027	20		33-32-11	ALL
	7		W2218	0007	22		23-43-11	ALL
	8		W2218	5557	24		36-21-11	ALL
	9		W2218	0017	24		33-25-11	ALL
	10	UNUSED						ALL
	11		W2218	0508	22		24-28-11	ALL
	12		W2218	5531	20		30-41-12	ALL
	13	UNUSED						ALL
	14	18	W2218	5701	18		33-12-12	ALL
	15	18	W2218	5601	18		33-12-12	ALL
	16		W2218	6001	22		28-42-11	ALL
	17		W2218	5512	24		21-31-25	ALL
	18		W2218	0014	24		33-25-11	ALL
	19		W2218	0006	22		23-43-11	ALL
	20		W2218	5558	22		30-31-11	ALL
	21		W2218	5559	20		21-61-51	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W2218	5566	20		21-61-15	ALL
	25		W2218	5530	20		30-41-12	ALL
	26		W2218	0024	20		33-32-11	ALL
	27	18	W2218	5651	18		33-12-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40536P	**P006-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
28	UNUSED						ALL
29	18	W2218	5562	18		33-14-12	ALL
30		W2218	0020	24		33-25-11	ALL
31		W2218	0004	22		23-42-11	ALL
32	UNUSED						ALL
33		W2218	5642	20		36-11-22	ALL
34		W2218	5579	24		36-11-23	ALL
35		W2218	5582	24		36-11-23	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W2218	6022	20		30-21-32	ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53		W2218	6651	20		33-18-31	ALL
54		W2218	6600	20		33-18-37	ALL
55		W2218	6601	20		33-18-41	ALL
S/R		W2218	5642Z			36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40538J		**P018-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W0018	0379	24		33-25-11	ALL
	3		W0018	0336	20		33-43-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0018	0713	20		30-21-32	ALL
	7		W0018	0035	22		23-42-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0018	0113	22		30-31-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0018	0067	20		23-15-11	ALL
	21		W0018	0148	22		30-31-11	ALL
	22		W0018	0151	22		30-31-11	ALL
	23		W0018	0152	22		30-31-11	ALL
	24		W0018	0147	22		30-31-11	ALL
D40538P		**P018-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W2218	0028	24		33-25-11	ALL
	3		W2218	0037	20		33-43-11	ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40538P	**P018-00/ /**		**PLUG- (continued)**				**ALL**
5	UNUSED						ALL
6		W2218	6006	20		30-21-32	ALL
7		W2218	0011	22		23-42-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2218	5801	22		30-31-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W2218	5599	22		23-15-11	ALL
21		W2218	5806	22		30-31-11	ALL
22		W2218	5807	22		30-31-11	ALL
23		W2218	5808	22		30-31-11	ALL
24		W2218	5809	22		30-31-11	ALL
D40539J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0066	2021B	22		32-31-12	ALL
A02		W0066	2021R	22		32-31-12	ALL
A03		W0066	2026B	22		32-64-12	ALL
A04		W0066	2026R	22		32-64-12	ALL
A05		W0066	2027B	22		32-64-12	ALL
A06		W0066	2027R	22		32-64-12	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40539J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40539P		**J046-00/ /**		**PLUG**				**ALL**
	A01		W5234	2233B	22		32-31-12	ALL
	A02		W5234	2233R	22		32-31-12	ALL
	A03		W5234	2221B	22		32-64-12	ALL
	A04		W5234	2221R	22		32-64-12	ALL
	A05		W5234	2222B	22		32-64-12	ALL
	A06		W5234	2222R	22		32-64-12	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40539P		**J046-00/ /**		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40540J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	0250	20		28-23-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0422	0081	22		24-11-21	ALL
	A05		W0422	0089	22		24-22-21	ALL
	A06		W0422	3002B	22		24-22-21	ALL
	A07	UNUSED						ALL
	A08		W0422	2009R	22		24-28-41	ALL
	A09		W0422	2016R	22		24-41-11	ALL
	A10		W0422	3005R	22		24-41-11	ALL
	A11		W0422	3005Y	22		24-41-11	ALL
	A12		W0422	0174	20		28-22-11	ALL
	A13		W0422	0175	20		28-22-11	ALL
	A14		W0422	0176	20		28-22-11	ALL
	A15		W0422	0242	22		28-43-11	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W0422	0309	22		23-15-11	ALL
	A20		W0422	2008R	22		24-28-11	ALL
	B01		W0422	0171	20		28-23-11	ALL
	B02		W0422	0239	20		28-23-11	ALL
	B03		W0422	0173	20		28-23-11	ALL
	B04		W0422	0088	22		24-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40540J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B05		W0422	3002R	22		24-22-21	ALL
	B06		W0422	3002Y	22		24-22-21	ALL
	B07	UNUSED						ALL
	B08		W0422	2009B	22		24-28-41	ALL
	B09		W0422	2016B	22		24-41-11	ALL
	B10		W0422	3005B	22		24-41-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0422	0178	22		28-43-11	ALL
	B16	UNUSED						ALL
	B17		W0422	0240	22		28-43-11	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0422	2008B	22		24-28-11	ALL
D40540P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W2218	6054	20		28-23-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2218	0501	22		24-11-21	ALL
	A05		W2218	0505	22		24-22-21	ALL
	A06		W2218	3201B	22		24-22-21	ALL
	A07	UNUSED						ALL
	A08		W2218	2202R	22		24-28-41	ALL
	A09		W2218	2205R	22		24-41-11	ALL
	A10		W2218	3202R	22		24-41-11	ALL
	A11		W2218	3202Y	22		24-41-11	ALL
	A12		W2218	6023	20		28-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40540P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
A13		W2218	6024	20		28-22-11	ALL
A14		W2218	6025	20		28-22-11	ALL
A15		W2218	6026	20		28-43-11	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W2218	5599	22		23-15-11	ALL
A20		W2218	2201R	22		24-28-11	ALL
B01		W2218	6040	20		28-23-11	ALL
B02		W2218	6041	20		28-23-11	ALL
B03		W2218	6042	20		28-23-11	ALL
B04		W2218	0503	22		24-22-21	ALL
B05		W2218	3201R	22		24-22-21	ALL
B06		W2218	3201Y	22		24-22-21	ALL
B07	UNUSED						ALL
B08		W2218	2202B	22		24-28-41	ALL
B09		W2218	2205B	22		24-41-11	ALL
B10		W2218	3202B	22		24-41-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W2218	6027	20		28-43-11	ALL
B16	UNUSED						ALL
B17		W2218	6005	20		28-43-11	ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20		W2218	2201B	22		24-28-11	ALL
DED		W2218	3201Z			24-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40542J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0254	22		23-43-11	ALL
	A02		W0410	0255	22		23-42-11	ALL
	A03		W0410	0574	24		36-11-22	ALL
	A04		W0410	1003	20		21-31-23	ALL
	A05		W0410	1578	20		36-11-22	ALL
	A06		W0410	1579	20		36-11-22	ALL
	A07		W0410	0591	24		36-11-31	ALL
	A08	UNUSED						ALL
	A09		W0410	0358	24		21-51-22	ALL
	A10		W0410	0414	24		21-61-13	ALL
	A11	UNUSED						ALL
	A12		W0410	0246	20		21-61-15	ALL
	A13		W0410	0207	24		36-11-22	ALL
	A14		W0410	0453	24		36-11-22	ALL
	A15	UNUSED						ALL
	A16		W0410	2502R	24		36-21-11	ALL
	A17	UNUSED						ALL
	A18		W0410	0575	24		36-11-22	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0410	1580	20		36-11-22	ALL
	B02		W0410	1581	20		36-11-22	ALL
	B03		W0410	1573	20		36-11-22	ALL
	B04		W0410	0621	24		21-51-21	ALL
	B05	UNUSED						ALL
	B06		W0410	0598	24		36-11-31	ALL
	B07		W0410	0597	24		36-11-31	ALL
	B08	UNUSED						ALL
	B09		W0410	0357	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40542J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0410	1571	20		36-11-22	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W0410	2502B	24		36-21-11	ALL
	B17		W0410	0497	22		34-51-41	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0410	1003Z			21-31-23	ALL
	PERG	1F	W0410	1571Z			36-11-22	ALL
	PERG	1F	W0410	1573Z			36-11-22	ALL
	PERG	1F	W0410	1578Z			36-11-22	ALL
	PERG	1F	W0410	1579Z			36-11-22	ALL
	PERG	1F	W0410	1580Z			36-11-22	ALL
	PERG	1F	W0410	1581Z			36-11-22	ALL
	PERG	1F	W0410	2502Z			36-21-11	ALL
D40542P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W2218	0007	22		23-43-11	ALL
	A02		W2218	0003	22		23-42-11	ALL
	A03		W2218	5644	24		36-11-22	ALL
	A04		W2218	1001	20		21-31-23	ALL
	A05		W2218	5642	20		36-11-22	ALL
	A06		W2218	5643	20		36-11-22	ALL
	A07		W2218	5672	24		36-11-31	ALL
	A08	UNUSED						ALL
	A09		W2218	5518	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40542P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A10		W2218	5520	24		21-61-13	ALL
	A11	UNUSED						ALL
	A12		W2218	5569	20		21-61-15	ALL
	A13		W2218	5640	24		36-11-22	ALL
	A14		W2218	5669	24		36-11-22	ALL
	A15	UNUSED						ALL
	A16		W2218	2019R	24		36-21-11	ALL
	A17	UNUSED						ALL
	A18		W2218	5648	24		36-11-22	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2218	5649	20		36-11-22	ALL
	B02		W2218	2502R	20		36-11-22	ALL
	B03		W2218	2502B	20		36-11-22	ALL
	B04		W2218	5508	24		21-51-21	ALL
	B05	UNUSED						ALL
	B06		W2218	0043	24		36-11-31	ALL
	B07		W2218	5671	24		36-11-31	ALL
	B08	UNUSED						ALL
	B09		W2218	5519	24		21-51-22	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W2218	5666	20		36-11-22	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W2218	2019B	24		36-21-11	ALL
	B17		W2218	0013	22		34-51-41	ALL
	B18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40542P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2218	1001Z			21-31-23	ALL
	PERG	1F	W2218	2019Z			36-21-11	ALL
	PERG	1F	W2218	2502Z			36-11-22	ALL
	PERG	1F	W2218	5642Z			36-11-22	ALL
	PERG	1F	W2218	5643Z			36-11-22	ALL
	PERG	1F	W2218	5649Z			36-11-22	ALL
	PERG	1F	W2218	5666Z			36-11-22	ALL
D40544J		**E003-01/ /**		**RCPT**				**ALL**
	A01		W0313	1770	20		73-22-41	ALL
	A02		W0313	0640	22		27-32-21	ALL
	A03		W0313	2768R	24		31-65-15	ALL
	A04	UNUSED						ALL
	A05		W0313	2756R	24		31-65-25	ALL
	A06		W0313	0611	22		34-51-41	ALL
	A07	UNUSED						ALL
	A08		W0313	0551	24		73-21-12	ALL
	A09		W0313	0575	24		73-31-11	ALL
	A10		W0313	0530	24		74-31-11	ALL
	A11	UNUSED						ALL
	A12		W0313	2755R	24		32-64-31	ALL
	A13		W0313	0512	22		30-21-32	ALL
	A14		W0313	2755B	24		32-64-31	ALL
	A15		W0313	1772	22		30-21-32	ALL
	A16		W0313	2742R	24		34-33-21	ALL
	A17		W0313	2743R	24		34-33-21	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40544J		**E003-01/ /**		**RCPT (continued)**				**ALL**
	A20	UNUSED						ALL
	B01		W0313	1710	22		34-33-21	ALL
	B02		W0313	1761	20		78-36-21	ALL
	B03		W0313	2768B	24		31-65-15	ALL
	B04	UNUSED						ALL
	B05		W0313	2756B	24		31-65-25	ALL
	B06		W0313	1758	20		78-36-11	ALL
	B07		W0313	0533	24		74-31-11	ALL
	B08		W0313	0560	22		30-21-32	ALL
	B09		W0313	0578	24		73-32-11	ALL
	B10		W0313	0527	24		74-31-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0313	0698	22		30-21-32	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W0313	2742B	24		34-33-21	ALL
	B17		W0313	2743B	24		34-33-21	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2742Z			34-33-21	ALL
	PERG	1F	W0313	2743Z			34-33-21	ALL
	PERG	1F	W0313	2755Z			32-64-31	ALL
	PERG	1F	W0313	2756Z			31-65-25	ALL
	PERG	1F	W0313	2768Z			31-65-15	ALL
D40544P		**E003-01/ /**		**PLUG-**				**ALL**
	A01		W2218	6057	20		73-22-41	ALL
	A02		W2218	8001	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40544P	**E003-01/ /**		**PLUG- (continued)**				**ALL**
A03		W2218	2011R	24		31-65-15	ALL
A04	UNUSED						ALL
A05		W2218	2007R	24		31-65-25	ALL
A06		W2218	8003	22		34-51-41	ALL
A07	UNUSED						ALL
A08		W2218	6009	24		73-21-12	ALL
A09		W2218	6012	24		73-31-11	ALL
A10		W2218	6016	24		74-31-11	ALL
A11	UNUSED						ALL
A12		W2218	2006R	24		32-64-31	ALL
A13		W2218	5639	22		30-21-32	ALL
A14		W2218	2006B	24		32-64-31	ALL
A15		W2218	5637	22		30-21-32	ALL
A16		W2218	2020R	24		34-33-21	ALL
A17		W2218	2021R	24		34-33-21	ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2218	6058	22		34-33-21	ALL
B02		W2218	0094	20		78-36-21	ALL
B03		W2218	2011B	24		31-65-15	ALL
B04	UNUSED						ALL
B05		W2218	2007B	24		31-65-25	ALL
B06		W2218	0070	20		78-36-11	ALL
B07		W2218	6019	24		74-31-11	ALL
B08		W2218	6010	22		30-21-32	ALL
B09		W2218	6013	24		73-32-11	ALL
B10		W2218	6017	24		74-31-11	ALL
B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40544P		**E003-01/ /**		**PLUG- (continued)**				**ALL**
	B12	UNUSED						ALL
	B13		W2218	5638	22		30-21-32	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W2218	2020B	24		34-33-21	ALL
	B17		W2218	2021B	24		34-33-21	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2218	2006Z			32-64-31	ALL
	PERG	1F	W2218	2007Z			31-65-25	ALL
	PERG	1F	W2218	2011Z			31-65-15	ALL
	PERG	1F	W2218	2020Z			34-33-21	ALL
	PERG	1F	W2218	2021Z			34-33-21	ALL
D40550J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0441	20		21-31-11	ALL
	2		W0044	0185	20		33-18-37	ALL
	3		W0044	0097	20		33-14-12	ALL
	4		W0044	0063	20		31-52-75	ALL
	5		W0044	0183	20		33-18-36	ALL
	6		W0044	0459	22		21-33-11	ALL
	7		W0044	0058	20		31-52-25	ALL
	8		W0044	0177	20		33-18-34	ALL
	9		W0044	0540	20		33-18-32	ALL
	10		W0044	0059	20		31-52-51	ALL
	11		W0044	0057	20		31-52-21	ALL
	12	UNUSED						ALL
	13	18	W0044	0002	18		24-11-11	ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40550J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
15		W0044	0175	20		33-18-33	ALL
16		W0044	0171	20		33-18-31	ALL
17		W0044	0176	20		33-18-33	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0044	0693	22		44-21-22	ALL
21		W0044	0092	20		33-14-12	ALL
22		W0044	0420	24		76-21-11	ALL
23		W0044	0180	20		33-18-36	ALL
24	UNUSED						ALL
25		W0044	6208	20		33-18-41	ALL
26		W0044	0461	24		21-51-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W0044	0042	24		24-34-11	ALL
31		W0044	0173	20		33-18-32	ALL
32		W0044	0179	20		33-18-36	ALL
33		W0044	0174	20		33-18-32	ALL
34	UNUSED						ALL
35		W0044	0020	24		24-31-11	ALL
36		W0044	0035	24		24-33-11	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W0044	0027	24		24-32-11	ALL
40		W0044	0549	24		24-31-11	ALL
41		W0044	0186	20		33-18-41	ALL
42		W0044	0512	24		24-33-11	ALL
43		W0044	0184	20		33-18-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40550J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	44		W0044	0443	24		21-31-11	ALL
	45		W0044	0552	24		24-31-12	ALL
	46		W0044	0034	24		24-33-11	ALL
	47		W0044	0040	24		24-34-11	ALL
	48		W0044	0041	24		24-34-11	ALL
	49		W0044	0043	24		24-34-11	ALL
	50		W0044	0178	20		33-18-35	ALL
	51		W0044	0553	24		24-31-12	ALL
	52		W0044	0093	20		33-14-12	ALL
	53		W0044	0032	24		24-33-11	ALL
	54		W0044	0036	24		24-33-11	ALL
	55		W0044	0033	24		24-33-11	ALL
D40550P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W2508	5501	20		21-31-11	ALL
	2		W2508	5582	20		33-18-37	ALL
	3		W2508	5610	20		33-14-12	ALL
	4		W2508	5734	20		31-52-75	ALL
	5		W2508	5565	20		33-18-36	ALL
	6		W2508	5506	22		21-33-11	ALL
	7		W2508	5707	20		31-52-25	ALL
	8		W2508	5548	20		33-18-34	ALL
	9		W2508	5529	20		33-18-32	ALL
	10		W2508	5720	20		31-52-51	ALL
	11		W2508	5701	20		31-52-21	ALL
	12	UNUSED						ALL
	13	18	W2508	0523	18		24-11-11	ALL
	14	UNUSED						ALL
	15		W2508	5535	20		33-18-33	ALL
	16		W2508	5526	20		33-18-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40550P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
17		W2508	5547	20		33-18-33	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W2508	5660	22		44-21-22	ALL
21		W2508	5521	20		33-14-12	ALL
22		W2508	6022	24		76-21-11	ALL
23		W2508	5563	20		33-18-36	ALL
24	UNUSED						ALL
25		W2508	1017	20		33-18-41	ALL
26		W2508	5637	24		21-51-11	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W2508	0521	24		24-34-11	ALL
31		W2508	5531	20		33-18-32	ALL
32		W2508	5562	20		33-18-36	ALL
33		W2508	5533	20		33-18-32	ALL
34	UNUSED						ALL
35		W2508	0502	24		24-31-11	ALL
36		W2508	0512	24		24-33-11	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39		W2508	0506	24		24-32-11	ALL
40		W2508	0533	24		24-31-11	ALL
41		W2508	5591	20		33-18-41	ALL
42		W2508	0514	24		24-33-11	ALL
43		W2508	5583	20		33-18-37	ALL
44		W2508	5505	24		21-31-11	ALL
45		W2508	0534	24		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40550P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	46		W2508	0511	24		24-33-11	ALL
	47		W2508	0515	24		24-34-11	ALL
	48		W2508	0516	24		24-34-11	ALL
	49		W2508	0520	24		24-34-11	ALL
	50		W2508	5556	20		33-18-35	ALL
	51		W2508	0535	24		24-31-12	ALL
	52		W2508	5522	20		33-14-12	ALL
	53		W2508	0509	24		24-33-11	ALL
	54		W2508	0513	24		24-33-11	ALL
	55		W2508	0510	24		24-33-11	ALL
D40554J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0301	24		21-51-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0410	0304	24		21-51-11	ALL
	A05		W0410	3001R	24		21-31-11	ALL
	A06		W0410	3001Y	24		21-31-11	ALL
	A07		W0410	0340	24		21-51-15	ALL
	A08		W0410	2013R	22		21-31-11	ALL
	A09		W0410	0096	24		21-51-11	ALL
	A10		W0410	0302	24		21-51-11	ALL
	B01	UNUSED						ALL
	B02		W0410	0631	22		21-27-51	ALL
	B03		W0410	0089	24		21-51-11	ALL
	B04		W0410	0630	22		21-27-51	ALL
	B05		W0410	3001B	24		21-31-11	ALL
	B06		W0410	0474	24		21-25-11	ALL
	B07		W0410	0339	24		21-51-15	ALL
	B08		W0410	2013B	22		21-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40554J	**E004-01/ /**		**RCPT- (continued)**				**ALL**
B09		W0410	0091	24		21-51-11	ALL
B10		W0410	0303	24		21-51-11	ALL
PERG	1F	W0410	2013Z			21-31-11	ALL
PERG	1F	W0410	3001Z			21-31-11	ALL
D40554P	**E004-01/ /**		**PLUG-**				**ALL**
A01		W2508	5638	24		21-51-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W2508	5517	24		21-51-11	ALL
A05		W2508	3001R	24		21-31-11	ALL
A06		W2508	3001Y	24		21-31-11	ALL
A07		W2508	5520	24		21-51-15	ALL
A08		W2508	2001R	22		21-31-11	ALL
A09		W2508	5516	24		21-51-11	ALL
A10		W2508	5514	24		21-51-11	ALL
B01	UNUSED						ALL
B02		W2508	5781	22		21-27-51	ALL
B03		W2508	5511	24		21-51-11	ALL
B04		W2508	5780	22		21-27-51	ALL
B05		W2508	3001B	24		21-31-11	ALL
B06		W2508	5530	22		21-25-11	ALL
B07		W2508	5519	24		21-51-15	ALL
B08		W2508	2001B	22		21-31-11	ALL
B09		W2508	5513	24		21-51-11	ALL
B10		W2508	5515	24		21-51-11	ALL
PERG	1F	W2508	2001Z			21-31-11	ALL
PERG	1F	W2508	3001Z			21-31-11	ALL
D40558J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0466	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40558J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	2		W0044	0532	24		24-31-12	ALL
	3		W0044	0528	24		24-31-12	ALL
	4		W0044	0428	20		80-11-11	ALL
	5		W0044	0452	24		21-31-23	ALL
	6		W0044	0293	20		28-21-11	ALL
	7		W0044	0295	20		28-22-11	ALL
	8	UNUSED						ALL
	9		W0044	0704	20		49-62-11	ALL
	10	18	W0044	0004	18		24-11-21	ALL
	11		W0044	0531	24		24-31-12	ALL
	12		W0044	0530	24		24-31-12	ALL
	13		W0044	0529	24		24-31-12	ALL
	14		W0044	0945	22		24-28-41	ALL
	15		W0044	0422	24		76-21-21	ALL
	16		W0044	6247	20		28-22-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	18	W0044	6160	18		73-22-41	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	18	W0044	6162	18		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40558J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
31	18	W0044	6161	18		73-22-41	ALL
D40558P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2510	5507	24		21-51-21	ALL
2		W2510	0502	24		24-31-12	ALL
3		W2510	0503	24		24-31-12	ALL
4		W2510	6021	20		80-11-11	ALL
5		W2510	5503	24		21-31-23	ALL
6		W2510	6006	20		28-21-11	ALL
7		W2510	6007	20		28-22-11	ALL
8	UNUSED						ALL
9		W2510	0511	20		49-62-11	ALL
10	18	W2510	0515	18		24-11-21	ALL
11		W2510	0505	24		24-31-12	ALL
12		W2510	0507	24		24-31-12	ALL
13		W2510	0508	24		24-31-12	ALL
14		W2510	6032	22		24-28-41	ALL
15		W2510	6015	24		76-21-21	ALL
16		W2510	6031	20		28-22-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	18	W2510	0017	18		73-22-41	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40558P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	18	W2510	0019	18		73-22-41	ALL
	31	18	W2510	0018	18		73-22-41	ALL
D40562J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0581	24		75-11-11	ALL
	A02	UNUSED						ALL
	A03		W0410	0346	24		21-51-21	ALL
	A04		W0410	0111	24		21-51-21	ALL
	A05		W0410	0583R	20		26-12-11	ALL
	A06		W0410	0009	22		27-83-21	ALL
	A07		W0410	0040	20		76-21-21	ALL
	A08		W0410	0624R	20		26-12-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0410	0044	20		80-11-11	ALL
	A13		W0410	0053	22		21-25-11	ALL
	A14		W0410	0247	24		29-34-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0410	0345	24		21-51-21	ALL
	B03		W0410	0110	24		21-51-21	ALL
	B04		W0410	0382	24		21-51-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40562J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B05		W0410	0582	20		76-21-21	ALL
	B06		W0410	0343	24		21-51-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0410	0043	24		80-11-11	ALL
	B12	UNUSED						ALL
	B13		W0410	0380	24		21-51-25	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D40562P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W2510	0531	24		75-11-11	ALL
	A02	UNUSED						ALL
	A03		W2510	5510	24		21-51-21	ALL
	A04		W2510	5512	24		21-51-21	ALL
	A05		W2510	0530R	20		26-12-11	ALL
	A06		W2510	0519	22		27-83-21	ALL
	A07		W2510	6029	20		76-21-21	ALL
	A08		W2510	0523R	20		26-12-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W2510	6024	20		80-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40562P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A13		W2510	5502	22		21-25-11	ALL
	A14		W2510	0514	24		29-34-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2510	5509	24		21-51-21	ALL
	B03		W2510	5511	24		21-51-21	ALL
	B04		W2510	5516	24		21-51-25	ALL
	B05		W2510	6052	24		76-21-21	ALL
	B06		W2510	5514	24		21-51-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W2510	6022	24		80-11-11	ALL
	B12	UNUSED						ALL
	B13		W2510	5515	24		21-51-25	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40564J		**E002-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02		W0212	0058	22		49-62-11	ALL
	A03		W0212	0059	22		49-62-11	ALL
	A04		W0212	0061	22		49-62-11	ALL
	A05		W0212	0029	22		24-22-31	ALL
	A06		W0212	0065	22		49-94-21	ALL
	A07		W0212	2006R	22		24-22-31	ALL
	A08		W0212	2006B	22		24-22-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0212	0093	22		49-62-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0212	0082	20		49-62-11	ALL
	B02		W0212	0080	20		49-62-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40564J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	B10	UNUSED						ALL
	B11		W0212	3004R	22		24-22-31	ALL
	B12		W0212	3004B	22		24-22-31	ALL
	B13		W0212	3004Y	22		24-22-31	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	DED		W0212	2006Z			24-22-31	ALL
	DED		W0212	3004Z			24-22-31	ALL
D40564P		**E002-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W2702	0504	22		49-62-11	ALL
	A03		W2702	0505	22		49-62-11	ALL
	A04		W2702	0506	22		49-62-11	ALL
	A05		W2702	0501	22		24-22-31	ALL
	A06		W2702	0508	22		49-94-21	ALL
	A07		W2702	2201R	22		24-22-31	ALL
	A08		W2702	2201B	22		24-22-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W2702	0509	22		49-62-11	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40564P	**E002-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2702	0002	20		49-62-11	ALL
B02		W2702	0003	20		49-62-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W2702	3201R	22		24-22-31	ALL
B12		W2702	3201B	22		24-22-31	ALL
B13		W2702	3201Y	22		24-22-31	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
DED		W2702	2201Z			24-22-31	ALL
DED		W2702	3201Z			24-22-31	ALL
D40574J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0231	16		27-53-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40574J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	2		W0044	0232	16		27-53-12	ALL
	3		W0044	0233	16		27-53-12	ALL
	4		W0044	3001B	14		27-41-12	ALL
	5		W0044	3001R	14		27-41-12	ALL
	6		W0044	3001Y	14		27-41-12	ALL
	7		W0044	1024	12		21-51-24	ALL
	8		W0044	6141	16		44-35-11	ALL
	9		W0044	6140	20		44-35-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40574P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W6222	0516	16		27-53-12	ALL
	2		W6222	0517	16		27-53-12	ALL
	3		W6222	0518	16		27-53-12	ALL
	4		W6222	3202B	14		27-41-12	ALL
	5		W6222	3202R	14		27-41-12	ALL
	6		W6222	3202Y	14		27-41-12	ALL
	7		W6222	0548	12		21-51-24	ALL
	8		W6222	0029	16		44-35-11	ALL
	9		W6222	0030	20		44-35-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40576J		**P018-00/ /**		**RCPT-**				**ALL**
	1		W0018	0744	22		31-31-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40576J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
5	UNUSED						ALL
6		W0018	0033	22		23-22-11	ALL
7		W0018	0853	20		74-11-11	ALL
8		W0018	0073	22		23-15-15	ALL
9	UNUSED						ALL
10		W0018	0066	20		52-71-13	ALL
11		W0018	0850	20		73-22-11	ALL
12		W0018	0852	24		73-22-31	ALL
13		W0018	0855	24		76-21-11	ALL
14	UNUSED						ALL
15		W0018	0511	22		21-25-11	ALL
16	10	W0018	0707	10		30-42-11	ALL
17	UNUSED						ALL
18		W0018	0509	14		21-25-11	ALL
19	UNUSED						ALL
20		W0018	0510	14		21-25-11	ALL
21	UNUSED						ALL
22		W0018	0508	14		21-25-11	ALL
23		W0018	0001	22		21-27-21	ALL
24		W0018	0075	18		23-71-01	ALL
25		W0018	0074	22		23-71-01	ALL
D40576P	**P018-00/ /**		**PLUG-**				**ALL**
1		W5156	0528	22		31-31-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5156	0568	22		23-22-11	ALL
7		W5156	0081	20		74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40576P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	8		W5156	0644	22		23-15-15	ALL
	9	UNUSED						ALL
	10		W5156	0003	20		52-71-13	ALL
	11		W5156	6003	20		73-22-11	ALL
	12		W5156	6005	24		73-22-31	ALL
	13		W5156	6009	24		76-21-11	ALL
	14	UNUSED						ALL
	15		W5156	0628	22		21-25-11	ALL
	16	10	W5156	0116	10		30-42-11	ALL
	17	UNUSED						ALL
	18		W5156	0626	14		21-25-11	ALL
	19	UNUSED						ALL
	20		W5156	0627	14		21-25-11	ALL
	21	UNUSED						ALL
	22		W5156	0625	14		21-25-11	ALL
	23		W5156	5532	22		21-27-21	ALL
	24		W5156	0025	18		23-71-01	ALL
	25		W5156	0024	22		23-71-01	ALL
D40578J		**P001-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0001	1062	22		31-53-11	ALL
	A02		W0001	1060	22		21-33-11	ALL
	A03		W0001	0328	22		34-41-11	ALL
	A04		W0001	0154	24		32-64-11	ALL
	A05		W0001	0156	24		32-64-11	ALL
	A06		W0001	0158	24		32-64-11	ALL
	A07		W0001	1764	22		32-31-15	ALL
	A08		W0001	1767	22		32-31-15	ALL
	A09	UNUSED						ALL
	A10		W0003	2515R	22		29-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40578J	**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20		W0001	1770	22		32-31-15	ALL
B01	UNUSED						ALL
B02		W0001	0096	24		32-44-11	ALL
B03		W0001	0254	22		29-23-11	ALL
B04		W0001	0155	24		32-64-11	ALL
B05		W0001	0157	24		32-64-11	ALL
B06		W0001	0159	24		32-64-11	ALL
B07		W0001	1766	22		32-31-15	ALL
B08		W0001	1769	22		32-31-15	ALL
B09	UNUSED						ALL
B10		W0003	2515B	22		29-32-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40578J		**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B20	UNUSED						ALL
	PERG	1F	W0001	1060Z			21-33-11	ALL
	PERG	1F	W0001	1062Z			31-53-11	ALL
	PERG	1F	W0001	1764Z			32-31-15	ALL
	PERG	1F	W0001	1766Z			32-31-15	ALL
	PERG	1F	W0001	1767Z			32-31-15	ALL
	PERG	1F	W0001	1769Z			32-31-15	ALL
	PERG	1F	W0001	1770Z			32-31-15	ALL
	PERG	1F	W0003	2515Z			29-32-11	ALL
D40578P		**P009-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5156	0499	22		31-53-11	ALL
	A02		W5156	0402	22		21-33-11	ALL
	A03		W5156	0016	22		34-41-11	ALL
	A04		W5156	0551	22		32-64-11	ALL
	A05		W5156	0553	22		32-64-11	ALL
	A06		W5156	0555	22		32-64-11	ALL
	A07		W5156	0708	22		32-31-15	ALL
	A08		W5156	0710	22		32-31-15	ALL
	A09	UNUSED						ALL
	A10		W5156	2001R	22		29-32-11	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40578P	**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A20		W5156	0712	22		32-31-15	ALL
B01	UNUSED						ALL
B02		W5156	0657	22		32-44-11	ALL
B03		W5156	0549	22		29-23-11	ALL
B04		W5156	0552	22		32-64-11	ALL
B05		W5156	0554	22		32-64-11	ALL
B06		W5156	0556	22		32-64-11	ALL
B07		W5156	0709	22		32-31-15	ALL
B08		W5156	0711	22		32-31-15	ALL
B09	UNUSED						ALL
B10		W5156	2001B	22		29-32-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5156	2001Z			29-32-11	ALL
D40580J	**P003-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0003	0624	24		32-64-12	ALL
A02		W0003	0626	24		32-64-12	ALL
A03		W0003	1517	22		27-62-11	ALL
A04		W0003	1038	24		31-31-15	ALL
A05	UNUSED						ALL
A06		W0003	0596	24		32-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40580J		**P003-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A07	UNUSED						ALL
	A08		W0003	1778	22		32-31-15	ALL
	A09		W0003	1775	22		32-31-15	ALL
	A10		W0003	1772	22		32-31-15	ALL
	B01		W0003	0625	24		32-64-12	ALL
	B02		W0003	1519	22		27-62-11	ALL
	B03		W0003	1518	22		27-62-11	ALL
	B04	UNUSED						ALL
	B05		W0003	0037	24		31-31-15	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0003	1777	22		32-31-15	ALL
	B10		W0003	1773	22		32-31-15	ALL
	PERG	1F	W0003	1038Z			31-31-15	ALL
	PERG	1F	W0003	1517Z			27-62-11	ALL
	PERG	1F	W0003	1518Z			27-62-11	ALL
	PERG	1F	W0003	1519Z			27-62-11	ALL
	PERG	1F	W0003	1772Z			32-31-15	ALL
	PERG	1F	W0003	1773Z			32-31-15	ALL
	PERG	1F	W0003	1775Z			32-31-15	ALL
	PERG	1F	W0003	1777Z			32-31-15	ALL
	PERG	1F	W0003	1778Z			32-31-15	ALL
D40580P		**P009-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5160	0544	22		32-64-12	ALL
	A02		W5160	0546	22		32-64-12	ALL
	A03		W5160	0623	22		27-62-11	ALL
	A04		W5160	0142	24		31-31-15	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40580P	**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A06		W5160	0625	22		32-44-11	ALL
A07	UNUSED						ALL
A08		W5160	0715	22		32-31-15	ALL
A09		W5160	0713	22		32-31-15	ALL
A10		W5160	0711	22		32-31-15	ALL
B01		W5160	0545	22		32-64-12	ALL
B02		W5160	0177	22		27-62-11	ALL
B03		W5160	0624	22		27-62-11	ALL
B04	UNUSED						ALL
B05		W5160	0141	24		31-31-15	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W5160	0714	22		32-31-15	ALL
B10		W5160	0712	22		32-31-15	ALL
D40582J	**P006-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0044	0099	20		33-17-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0044	0497	20		30-41-12	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40582J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D40582P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W2204	5508	20		33-17-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W2204	5536	20		30-41-12	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40582P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D40584J	**E004-02/ /**		**RCPT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W0422	0151	20		33-36-11	ALL
A05	UNUSED						ALL
A06		W0422	0063	20		33-36-11	ALL
A07		W0422	0064	20		33-36-12	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W0422	0152	20		33-36-12	ALL
B05	UNUSED						ALL
B06		W0422	0062	20		33-36-11	ALL
B07		W0422	0065	20		33-36-12	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40584P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5248	0499	20		SPARE	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5248	0017	20		33-36-11	ALL
	A05	UNUSED						ALL
	A06		W5248	0024	20		33-36-11	ALL
	A07		W5248	0288	20		33-36-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5248	0500	20		SPARE	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5248	0287	20		33-36-12	ALL
	B05	UNUSED						ALL
	B06		W5248	0028	20		33-36-11	ALL
	B07		W5248	0384	20		33-36-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40586J		**E002-02/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0220	0230	20		30-71-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40586J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	A09		W0220	0412R	20		26-12-11	ALL
	A10		W0220	0410R	20		26-12-11	ALL
	B01		W0220	0244	20		30-71-11	ALL
	B02		W0220	0250	20		30-71-11	ALL
	B03		W0220	0231	20		30-71-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0220	0413R	20		26-12-11	ALL
	B10		W0220	0411R	20		26-12-11	ALL
D40586P		**E002-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5248	5524	20		30-71-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5248	0304R	20		26-12-11	ALL
	A10		W5248	0301R	20		26-12-11	ALL
	B01		W5248	5514	20		30-71-11	ALL
	B02		W5248	5509	20		30-71-11	ALL
	B03		W5248	5513	20		30-71-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40586P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5248	0303R	20		26-12-11	ALL
	B10		W5248	0302R	20		26-12-11	ALL
D40594J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2290R	22		27-62-11	ALL
	A02		W0321	2290B	22		27-62-11	ALL
	A03		W0321	2287R	22		27-62-11	ALL
	A04		W0321	0974	22		27-62-11	ALL
	A05		W0321	0934	22		27-62-11	ALL
	A06	UNUSED						ALL
	A07		W0321	0151	22		23-27-38	ALL
	A08		W0321	0935	22		27-62-11	ALL
	A09		W0321	0379	22		27-61-49	ALL
	A10		W0321	0380	22		27-61-49	ALL
	B01		W0321	0948	22		27-62-11	ALL
	B02		W0321	0949	22		27-62-11	ALL
	B03		W0321	2287B	22		27-62-11	ALL
	B04		W0321	0327	22		32-64-21	ALL
	B05		W0321	0931	22		27-62-11	ALL
	B06	UNUSED						ALL
	B07		W0321	2235R	20		32-49-11	ALL
	B08		W0321	2235B	20		32-49-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2235Z			32-49-11	ALL
D40594P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W5156	2021R	22		27-62-11	ALL
	A02		W5156	2021B	22		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40594P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A03		W5156	2019R	22		27-62-11	ALL
	A04		W5156	0105	20		27-62-11	ALL
	A05		W5156	0084	20		27-62-11	ALL
	A06	UNUSED						ALL
	A07		W5156	0610	22		23-27-38	ALL
	A08		W5156	0107	20		27-62-11	ALL
	A09		W5156	0719	22		27-61-49	ALL
	A10		W5156	0720	22		27-61-49	ALL
	B01		W5156	0716	22		27-62-11	ALL
	B02		W5156	0717	22		27-62-11	ALL
	B03		W5156	2019B	22		27-62-11	ALL
	B04		W5156	0600	22		32-64-21	ALL
	B05		W5156	0106	20		27-62-11	ALL
	B06	UNUSED						ALL
	B07		W5156	2216R	20		32-49-11	ALL
	B08		W5156	2216B	20		32-49-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	2216Z			32-49-11	ALL
D40596J		**E003-02/ /**		**RCPT-**				**ALL**
	A01		W0321	0792	22		34-51-11	ALL
	A02		W0321	0332	20		33-25-11	ALL
	A03		W0321	0342	22		27-32-11	ALL
	A04		W0321	0086	24		31-31-15	ALL
	A05		W0321	0009	22		31-31-11	ALL
	A06		W0321	0011	24		31-35-08	ALL
	A07		W0321	0232	22		22-23-11	ALL
	A08		W0321	0234	20		22-23-11	ALL
	A09		W0321	0239	22		22-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40596J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	A10		W0321	0010	22		31-31-11	ALL
	B01		W0321	2367R	24		34-51-11	ALL
	B02		W0321	0090	22		27-83-11	ALL
	B03		W0321	2367B	24		34-51-11	ALL
	B04		W0321	0767	22		34-51-11	ALL
	B05		W0321	2368R	24		34-51-11	ALL
	B06		W0321	2368B	24		34-51-11	ALL
	B07		W0321	0233	22		22-23-11	ALL
	B08		W0321	0235	20		22-23-11	ALL
	B09		W0321	0240	22		22-23-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2367Z			34-51-11	ALL
	PERG	1F	W0321	2368Z			34-51-11	ALL
D40596P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W2112	6075	22		34-51-11	ALL
	A02		W2112	0003	20		33-25-11	ALL
	A03		W2112	8007	22		27-32-11	ALL
	A04		W2112	8021	24		31-31-15	ALL
	A05		W2112	8005	22		31-31-11	ALL
	A06		W2112	0043	24		31-35-08	ALL
	A07		W2112	8011	20		22-23-11	ALL
	A08		W2112	8013	20		22-23-11	ALL
	A09		W2112	8019	22		22-23-11	ALL
	A10		W2112	8006	22		31-31-11	ALL
	B01		W2112	2009R	24		34-51-11	ALL
	B02		W2112	0519	22		27-83-11	ALL
	B03		W2112	2009B	24		34-51-11	ALL
	B04		W2112	6076	22		34-51-11	ALL
	B05		W2112	2010R	24		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40596P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B06		W2112	2010B	24		34-51-11	ALL
	B07		W2112	8012	22		22-23-11	ALL
	B08		W2112	8016	20		22-23-11	ALL
	B09		W2112	8020	20		22-23-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W2112	2009Z			34-51-11	ALL
	PERG	1F	W2112	2010Z			34-51-11	ALL
D40598J		**E002-01/ /**		**RCPT-**				**ALL**
	A01		W0212	0209	22		28-43-11	ALL
	A02	UNUSED						ALL
	A03		W0212	2012R	22		24-28-11	ALL
	A04		W0212	0215	20		28-23-11	ALL
	A05		W0212	0018	22		24-22-11	ALL
	A06		W0212	0070	20		28-23-11	ALL
	A07		W0212	0206	20		28-23-11	ALL
	A08		W0212	0072	20		28-23-11	ALL
	A09		W0212	3002R	22		24-22-11	ALL
	A10		W0212	3002Y	22		24-22-11	ALL
	B01		W0212	0074	22		28-43-11	ALL
	B02		W0212	0207	22		28-43-11	ALL
	B03		W0212	2012B	22		24-28-11	ALL
	B04		W0212	0017	22		24-22-11	ALL
	B05	UNUSED						ALL
	B06		W0212	2016R	22		24-28-11	ALL
	B07		W0212	2016B	22		24-28-11	ALL
	B08		W0212	0006	22		34-33-11	ALL
	B09		W0212	3002B	22		24-22-11	ALL
	B10		W0212	0010	22		24-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40598P	**E002-01/ /**		**PLUG-**				**ALL**
A01		W2112	6047	20		28-43-11	ALL
A02	UNUSED						ALL
A03		W2112	2203R	22		24-28-11	ALL
A04		W2112	6054	20		28-23-11	ALL
A05		W2112	0506	22		24-22-11	ALL
A06		W2112	6040	20		28-23-11	ALL
A07		W2112	6041	20		28-23-11	ALL
A08		W2112	6042	20		28-23-11	ALL
A09		W2112	3201R	22		24-22-11	ALL
A10		W2112	3201Y	22		24-22-11	ALL
B01		W2112	6046	20		28-43-11	ALL
B02		W2112	6039	20		28-43-11	ALL
B03		W2112	2203B	22		24-28-11	ALL
B04		W2112	0504	22		24-22-11	ALL
B05	UNUSED						ALL
B06		W2112	2202R	22		24-28-11	ALL
B07		W2112	2202B	22		24-28-11	ALL
B08		W2112	6088	22		34-33-11	ALL
B09		W2112	3201B	22		24-22-11	ALL
B10		W2112	0501	22		24-11-11	ALL
DED		W2112	3201Z			24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40600J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	2021B	22		32-31-12	ALL
	A02		W0066	2021R	22		32-31-12	ALL
	A03		W0066	2026B	22		32-64-12	ALL
	A04		W0066	2026R	22		32-64-12	ALL
	A05		W0066	2027B	22		32-64-12	ALL
	A06		W0066	2027R	22		32-64-12	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0066	0366	22		23-15-15	ALL
	A10		W0066	0367	22		23-15-15	ALL
	B01		W0066	1024	20		73-22-11	ALL
	B02		W0066	0389	24		73-22-11	ALL
	B03		W0066	0390	22		73-23-11	ALL
	B04		W0066	0391	24		76-21-21	ALL
	B05		W0066	0392	24		73-22-31	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	1024Z			73-22-11	ALL
D40600P		**J046-00/ /**		**PLUG**				**ALL**
	A01		W5160	2233B	22		32-31-12	ALL
	A02		W5160	2233R	22		32-31-12	ALL
	A03		W5160	2221B	22		32-64-12	ALL
	A04		W5160	2221R	22		32-64-12	ALL
	A05		W5160	2222B	22		32-64-12	ALL
	A06		W5160	2222R	22		32-64-12	ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40600P		**J046-00/ /**		**PLUG (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W5160	0312	24		23-15-15	ALL
	A10		W5160	0313	24		23-15-15	ALL
	B01		W5160	1301	20		73-22-11	ALL
	B02		W5160	6002	24		73-22-11	ALL
	B03		W5160	6004	24		73-23-11	ALL
	B04		W5160	6005	24		76-21-21	ALL
	B05		W5160	6008	24		73-22-31	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5160	1301Z			73-22-11	ALL
D40602J		**J004-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0094	0025	16		27-53-12	ALL
	2		W0094	0029	16		27-53-12	ALL
	3		W0094	0033	16		27-53-12	ALL
	4		W0094	3003B	14		27-41-12	ALL
	5		W0094	3003R	14		27-41-12	ALL
	6		W0094	3003Y	14		27-41-12	ALL
	7		W0094	0446	16		44-35-11	ALL
	8	UNUSED						ALL
D40602P		**J004-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6222	0516	16		27-53-12	ALL
	2		W6222	0517	16		27-53-12	ALL
	3		W6222	0518	16		27-53-12	ALL
	4		W6222	3202B	14		27-41-12	ALL
	5		W6222	3202R	14		27-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40602P	**J004-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
6		W6222	3202Y	14		27-41-12	ALL
7		W6222	0016	16		44-35-11	ALL
8	UNUSED						ALL
D40606J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W0066	0375R	20		26-12-11	ALL
A03	UNUSED						ALL
A04		W0066	0374R	20		26-12-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0066	0439	22		32-46-11	ALL
A10		W0066	2502R	20		36-11-12	ALL
B01		W0066	0384R	20		26-12-11	ALL
B02		W0066	0386R	20		26-12-11	ALL
B03		W0066	0387R	20		26-12-11	ALL
B04		W0066	0432	20		78-34-21	ALL
B05		W0066	0415	20		78-34-21	ALL
B06		W0066	0416	20		78-34-21	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W0066	2502B	20		36-11-12	ALL
PERG	1F	W0066	2502Z			36-11-12	ALL
D40606P	**AJ0046A/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W5610	6066R	20		26-12-11	ALL
A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40606P		**AJ0046A/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A04		W5610	6040R	20		26-12-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5610	0025	22		32-46-11	ALL
	A10		W5610	2510R	20		36-11-12	ALL
	B01		W5610	6038R	20		26-12-11	ALL
	B02		W5610	6055R	20		26-12-11	ALL
	B03		W5610	6056R	20		26-12-11	ALL
	B04		W5610	0519	20		78-34-21	ALL
	B05		W5610	0509	20		78-34-21	ALL
	B06		W5610	0511	20		78-34-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5610	2510B	20		36-11-12	ALL
	PERG	1F	W5610	2510Z			36-11-12	ALL
D40610J		**J004-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0094	0085	22		27-61-45	ALL
	2		W0094	0081	20		33-42-21	ALL
	3		W0094	0036	20		27-53-12	ALL
	4		W0094	0042	20		27-53-12	ALL
	5		W0094	0022	20		27-53-12	ALL
	6		W0094	0082	20		33-42-21	ALL
	7		W0094	0056	20		27-41-12	ALL
	8		W0094	0071	20		22-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40610J	**J004-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
11		W0094	0087	22		27-61-45	ALL
12		W0094	0002	22		22-13-11	ALL
13		W0094	0001	22		22-13-11	ALL
14	UNUSED						ALL
15		W0094	0088	22		27-61-45	ALL
16		W0094	0041	20		27-53-12	ALL
17		W0094	0502	20		28-23-11	ALL
18		W0094	0503	20		28-23-11	ALL
19		W0094	0510	20		28-23-11	ALL
20		W0094	0509	20		28-23-11	ALL
21		W0094	0508	20		28-23-11	ALL
22		W0094	0512	20		28-23-11	ALL
23		W0094	0513	20		28-23-11	ALL
24	UNUSED						ALL
25		W0094	0259	22		22-11-31	ALL
26		W0094	0252	20		73-22-41	ALL
27		W0094	0253	20		73-22-41	ALL
28	UNUSED						ALL
29		W0094	0061	20		27-41-12	ALL
30		W0094	0501	20		28-23-11	ALL
31		W0094	0514	20		28-23-11	ALL
D40610P	**J004-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5160	0193	22		27-61-45	ALL
2		W5160	0149	20		33-42-21	ALL
3		W5160	0513	20		27-53-12	ALL
4		W5160	0514	20		27-53-12	ALL
5		W5160	0515	20		27-53-12	ALL
6		W5160	0012	20		33-42-21	ALL
7		W5160	0569	20		27-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40610P		**J004-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	8		W5160	0538	22		22-13-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5160	0194	22		27-61-45	ALL
	12		W5160	0502	22		22-13-11	ALL
	13		W5160	0501	22		22-13-11	ALL
	14	UNUSED						ALL
	15		W5160	0195	22		27-61-41	ALL
	16		W5160	0516	20		27-53-12	ALL
	17		W5160	0108	20		28-23-11	ALL
	18		W5160	0109	20		28-23-11	ALL
	19		W5160	0112	20		28-23-11	ALL
	20		W5160	0111	20		28-23-11	ALL
	21		W5160	0110	20		28-23-11	ALL
	22		W5160	0120	20		28-23-11	ALL
	23		W5160	0119	20		28-23-11	ALL
	24	UNUSED						ALL
	25		W5160	0205	22		22-11-31	ALL
	26		W5160	0187	20		73-22-41	ALL
	27		W5160	0188	20		73-22-41	ALL
	28	UNUSED						ALL
	29		W5160	0127	20		27-41-12	ALL
	30		W5160	0107	20		28-23-11	ALL
	31		W5160	0118	20		28-23-11	ALL
D40612J		**J004-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40612J	**J004-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0094	0164	22		44-21-22	ALL
13		W0094	0119	20		44-21-22	ALL
14		W0094	0163	22		44-21-22	ALL
D40612P	**J004-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5160	0097	22		44-21-22	ALL
13		W5160	0098	20		44-21-22	ALL
14		W5160	0096	22		44-21-22	ALL
D40614J	**J004-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0094	0023	16		27-53-12	ALL
2		W0094	0257	20		22-13-11	ALL
3		W0094	0031	16		27-53-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40614J		**J004-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	4	UNUSED						ALL
	5		W0094	0441	16		44-35-11	ALL
	6		W0092	0005	20		27-41-12	ALL
	7		W0092	0002	20		27-41-12	ALL
	8		W0094	0027	16		27-53-12	ALL
	9	UNUSED						ALL
	10		W0094	0083	20		33-42-21	ALL
	11	UNUSED						ALL
	12		W0094	0058	20		27-41-12	ALL
	13	UNUSED						ALL
	14		W0094	0430	20		44-35-11	ALL
D40614P		**J004-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6222	0513	16		27-53-12	ALL
	2		W6222	0012	20		22-13-11	ALL
	3		W6222	0515	16		27-53-12	ALL
	4	UNUSED						ALL
	5		W6222	0029	16		44-35-11	ALL
	6		W6222	0554	20		27-41-12	ALL
	7		W6222	0553	20		27-41-12	ALL
	8		W6222	0514	16		27-53-12	ALL
	9	UNUSED						ALL
	10		W6222	0006	20		33-42-21	ALL
	11	UNUSED						ALL
	12		W6222	0555	20		27-41-12	ALL
	13	UNUSED						ALL
	14		W6222	0030	20		44-35-11	ALL
D40618J		**E004-02/ /**		**CONNECTOR-RCPT**				**ALL**
	A01		W0422	2011B	22		24-33-11	ALL
	A02		W0422	0072	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40618J		**E004-02/ /**		**CONNECTOR-RCPT (continued)**				**ALL**
	A03		W0422	2012B	22		24-33-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0422	0233	24		21-31-23	ALL
	A07		W0422	0234	24		21-31-23	ALL
	A08		W0422	0310	22		27-31-37	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0422	2011R	22		24-33-11	ALL
	B02		W0422	0300	22		31-31-15	ALL
	B03		W0422	2012R	22		24-33-11	ALL
	B04		W0422	0151	20		33-36-11	ALL
	B05		W0422	0152	20		33-36-12	ALL
	B06		W0422	0235	20		21-31-23	ALL
	B07		W0422	0153	20		28-44-11	ALL
	B08		W0422	0244	22		27-33-11	ALL
	B09		W0422	0245	22		27-33-11	ALL
	B10		W0422	0246	22		27-33-11	ALL
	F		W0422	0082	18		24-11-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	DED		W0422	2011Z			24-33-11	ALL
	DED		W0422	2012Z			24-33-11	ALL
D40618P		**E004-02/ /**		**CONNECTOR - PLUG**				**ALL**
	A01		W5158	2603B	22		24-33-11	ALL
	A02		W5158	0529	20		28-21-11	ALL
	A03		W5158	2604B	22		24-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40618P		**E004-02/ /**		**CONNECTOR - PLUG (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5158	0020	24		21-31-23	ALL
	A07		W5158	0021	24		21-31-23	ALL
	A08		W5158	0310	22		27-31-37	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5158	2603R	22		24-33-11	ALL
	B02		W5158	0030	22		31-31-15	ALL
	B03		W5158	2604R	22		24-33-11	ALL
	B04		W5158	0688	20		33-36-11	ALL
	B05		W5158	0689	20		33-36-12	ALL
	B06		W5158	0022	20		21-31-23	ALL
	B07		W5158	0637	20		28-44-11	ALL
	B08		W5158	0050	22		27-33-11	ALL
	B09		W5158	0051	22		27-33-11	ALL
	B10		W5158	0052	22		27-33-11	ALL
	F		W5158	0532	18		24-11-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	DED		W5158	2603Z			24-33-11	ALL
	DED		W5158	2604Z			24-33-11	ALL
D40621J		**AE0602A/ /**		**RCPT**				**ALL**
	1		W0623	3001B	20		23-11-21	ALL
	2		W0623	3001Y	20		23-11-21	ALL
	3		W0623	3001R	20		23-11-21	ALL
	4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40621J		**AE0602A/ /**		**RCPT (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40621P		**E006-02/ /**		**PLUG-**				**ALL**
	1		W2103	3003B	20		23-11-21	ALL
	2		W2103	3003Y	20		23-11-21	ALL
	3		W2103	3003R	20		23-11-21	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D40623J		**P006-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0041	0019	22		34-58-11	ALL
	2		W0041	0020	22		34-21-21	ALL
	3		W0041	0021	22		34-21-21	ALL
	4		W0041	0022	22		34-21-21	ALL
	5		W0041	0023	22		34-21-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40623J		**P006-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	8		W0041	0036	24		31-65-25	ALL
	9		W0041	2513R	24		34-58-21	ALL
	10		W0041	2513B	24		34-58-21	ALL
	11		W0041	2514R	24		34-58-21	ALL
	12		W0041	2514B	24		34-58-21	ALL
	13		W0041	2545R	24		27-61-47	ALL
	14		W0041	2545B	24		27-61-47	ALL
	15		W0041	0128	22		34-58-11	ALL
	16		W0041	2505R	22		31-32-15	ALL
	17		W0041	2505B	22		31-32-15	ALL
	18		W0041	0090	24		34-61-18	ALL
	19		W0041	2527R	24		34-61-18	ALL
	20		W0041	2527B	24		34-61-18	ALL
	21		W0041	0103	22		34-58-11	ALL
	22		W0041	0105	22		34-58-11	ALL
	23		W0041	0092	24		34-61-26	ALL
	24		W0041	2530R	24		34-61-26	ALL
	25		W0041	2530B	24		34-61-26	ALL
	26		W0041	2532R	24		22-11-53	ALL
	27		W0041	2532B	24		22-11-53	ALL
	28		W0041	0097	24		22-11-53	ALL
	29		W0041	0098	24		22-11-53	ALL
	30		W0041	0099	24		22-11-53	ALL
	31	UNUSED						ALL
	S/R		W0041	2505Z			31-32-15	ALL
	S/R		W0041	2513Z			34-58-21	ALL
	S/R		W0041	2514Z			34-58-21	ALL
	S/R		W0041	2527Z			34-61-18	ALL
	S/R		W0041	2530Z			34-61-26	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40623J	**P006-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
S/R		W0041	2532Z			22-11-53	ALL
S/R		W0041	2545Z			27-61-47	ALL
D40623P	**P006-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W2135	0010	22		34-58-11	ALL
2		W2135	0009	22		34-21-21	ALL
3		W2135	0013	22		34-21-21	ALL
4		W2135	0014	22		34-21-21	ALL
5		W2135	0015	22		34-21-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W2135	0021	24		31-65-25	ALL
9		W2135	2504R	24		34-58-21	ALL
10		W2135	2504B	24		34-58-21	ALL
11		W2135	2505R	24		34-58-21	ALL
12		W2135	2505B	24		34-58-21	ALL
13		W2135	2002R	24		27-61-47	ALL
14		W2135	2002B	24		27-61-47	ALL
15		W2135	0064	22		34-58-11	ALL
16		W2135	2510R	22		31-32-15	ALL
17		W2135	2510B	22		31-32-15	ALL
18		W2135	0045	24		34-61-18	ALL
19		W2135	2508R	24		34-61-18	ALL
20		W2135	2508B	24		34-61-18	ALL
21		W2135	0061	22		34-58-11	ALL
22		W2135	0060	22		34-58-11	ALL
23		W2135	0046	24		34-61-26	ALL
24		W2135	2509R	24		34-61-26	ALL
25		W2135	2509B	24		34-61-26	ALL
26		W2135	2511R	24		22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40623P		**P006-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	27		W2135	2511B	24		22-11-53	ALL
	28		W2135	0047	24		22-11-53	ALL
	29		W2135	0048	24		22-11-53	ALL
	30		W2135	0049	24		22-11-53	ALL
	31	UNUSED						ALL
	S/R		W2135	2002Z			27-61-47	ALL
	S/R		W2135	2504Z			34-58-21	ALL
	S/R		W2135	2505Z			34-58-21	ALL
	S/R		W2135	2508Z			34-61-18	ALL
	S/R		W2135	2509Z			34-61-26	ALL
	S/R		W2135	2510Z			31-32-15	ALL
	S/R		W2135	2511Z			22-11-53	ALL
D40625J		**P006-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0041	0024	22		34-21-11	ALL
	2		W0041	0025	22		34-21-11	ALL
	3		W0041	0026	22		34-21-11	ALL
	4		W0041	0027	22		34-21-11	ALL
	5		W0041	0031	22		34-21-16	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0041	0046	22		31-32-15	ALL
	9		W0041	2533R	22		31-32-15	ALL
	10		W0041	2533B	22		31-32-15	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0041	2529R	24		34-61-26	ALL
	14		W0041	2529B	24		34-61-26	ALL
	15		W0041	0030	24		31-65-15	ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40625J	**P006-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W0041	2511R	24		34-58-11	ALL
23		W0041	2511B	24		34-58-11	ALL
24		W0041	2516R	24		23-27-39	ALL
25		W0041	2516B	24		23-27-39	ALL
26		W0041	0016	24		31-35-01	ALL
27		W0041	0017	24		31-35-01	ALL
28	UNUSED						ALL
29		W0041	2510R	22		31-32-15	ALL
30		W0041	2510B	22		31-32-15	ALL
31		W0041	0039	24		23-27-39	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W0041	2512R	24		34-58-11	ALL
35		W0041	2512B	24		34-58-11	ALL
36		W0041	2519R	22		49-62-11	ALL
37		W0041	2519B	22		49-62-11	ALL
38		W0041	2520R	22		23-15-15	ALL
39		W0041	2520B	22		23-15-15	ALL
40		W0041	0048	22		23-15-15	ALL
41		W0041	0091	24		34-61-26	ALL
42		W0041	2525R	24		34-61-18	ALL
43		W0041	2525B	24		34-61-18	ALL
44		W0041	0089	24		34-61-18	ALL
45		W0041	2526R	24		34-61-18	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40625J		**P006-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	46		W0041	2526B	24		34-61-18	ALL
	47		W0041	2531R	24		22-11-53	ALL
	48		W0041	2531B	24		22-11-53	ALL
	49		W0041	0093	24		22-11-53	ALL
	50		W0041	0094	24		22-11-53	ALL
	51		W0041	0095	24		22-11-53	ALL
	52		W0041	0096	24		22-11-53	ALL
	53		W0041	0121	22		27-61-42	ALL
	54		W0041	0122	22		27-61-42	ALL
	55		W0041	0123	22		27-61-42	ALL
	S/R		W0041	2510Z			31-32-15	ALL
	S/R		W0041	2511Z			34-58-11	ALL
	S/R		W0041	2512Z			34-58-11	ALL
	S/R		W0041	2516Z			23-27-39	ALL
	S/R		W0041	2519Z			49-62-11	ALL
	S/R		W0041	2520Z			23-15-15	ALL
	S/R		W0041	2525Z			34-61-18	ALL
	S/R		W0041	2526Z			34-61-18	ALL
	S/R		W0041	2529Z			34-61-26	ALL
	S/R		W0041	2531Z			22-11-53	ALL
	S/R		W0041	2533Z			31-32-15	ALL
D40625P		**P006-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1		W2597	0001	22		34-21-11	ALL
	2		W2597	0002	22		34-21-11	ALL
	3		W2597	0003	22		34-21-11	ALL
	4		W2597	0004	22		34-21-11	ALL
	5		W2597	0005	22		34-21-16	ALL
	6		W2597	2509R	24		SPARE	ALL
	7		W2597	2509B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40625P	**P006-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
8		W2597	0016	22		31-32-15	ALL
9		W2597	2501R	22		31-32-15	ALL
10		W2597	2501B	22		31-32-15	ALL
11		W2597	2502R	22		SPARE	ALL
12		W2597	2502B	22		SPARE	ALL
13		W2597	2516R	24		34-61-26	ALL
14		W2597	2516B	24		34-61-26	ALL
15		W2597	0008	24		31-65-15	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2597	2506R	24		34-58-11	ALL
23		W2597	2506B	24		34-58-11	ALL
24		W2597	2510R	24		23-27-39	ALL
25		W2597	2510B	24		23-27-39	ALL
26		W2597	0011	24		31-35-01	ALL
27		W2597	0012	24		31-35-01	ALL
28	UNUSED						ALL
29		W2597	2508R	22		31-32-15	ALL
30		W2597	2508B	22		31-32-15	ALL
31		W2597	0014	24		23-27-39	ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W2597	2507R	24		34-58-11	ALL
35		W2597	2507B	24		34-58-11	ALL
36		W2597	2512R	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40625P		**P006-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	37		W2597	2512B	22		49-62-11	ALL
	38		W2597	2513R	22		23-15-15	ALL
	39		W2597	2513B	22		23-15-15	ALL
	40		W2597	0017	22		23-15-15	ALL
	41		W2597	0019	24		34-61-26	ALL
	42		W2597	2514R	24		34-61-18	ALL
	43		W2597	2514B	24		34-61-18	ALL
	44		W2597	0018	24		34-61-18	ALL
	45		W2597	2515R	24		34-61-18	ALL
	46		W2597	2515B	24		34-61-18	ALL
	47		W2597	2517R	24		22-11-53	ALL
	48		W2597	2517B	24		22-11-53	ALL
	49		W2597	0020	24		22-11-53	ALL
	50		W2597	0021	24		22-11-53	ALL
	51		W2597	0022	24		22-11-53	ALL
	52		W2597	0023	24		22-11-53	ALL
	53		W2597	0029	22		27-61-42	ALL
	54		W2597	0030	22		27-61-42	ALL
	55		W2597	0031	22		27-61-42	ALL
	S/R		W2597	2501Z			31-32-15	ALL
	S/R		W2597	2502Z			SPARE	ALL
	S/R		W2597	2506Z			34-58-11	ALL
	S/R		W2597	2507Z			34-58-11	ALL
	S/R		W2597	2508Z			31-32-15	ALL
	S/R		W2597	2509Z			SPARE	ALL
	S/R		W2597	2510Z			23-27-39	ALL
	S/R		W2597	2512Z			49-62-11	ALL
	S/R		W2597	2513Z			23-15-15	ALL
	S/R		W2597	2514Z			34-61-18	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40625P	**P006-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
S/R		W2597	2515Z			34-61-18	ALL
S/R		W2597	2516Z			34-61-26	ALL
S/R		W2597	2517Z			22-11-53	ALL
D40632J	**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0072	0507	24		32-31-12	ALL
2		W0072	0062	24		32-31-12	ALL
3		W0072	0072	24		32-31-12	ALL
4		W0072	0082	24		32-31-12	ALL
5		W0072	0092	24		32-31-12	ALL
6		W0072	0065	24		32-51-11	ALL
7		W0072	0063	24		32-51-11	ALL
8		W0072	0111	24		21-27-31	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0072	0506	24		32-31-11	ALL
21		W0072	0052	24		32-31-12	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40632J		**J020-0B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40632P		**J020-0B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5100	0602	22		32-31-12	ALL
	2		W5100	0604	22		32-31-12	ALL
	3		W5100	0605	22		32-31-12	ALL
	4		W5100	0606	22		32-31-12	ALL
	5		W5100	0607	22		32-31-12	ALL
	6		W5100	0506	22		32-51-11	ALL
	7		W5100	0509	22		32-51-11	ALL
	8		W5100	0510	24		21-27-31	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5100	0521	22		32-31-11	ALL
	21		W5100	0601	22		32-31-12	ALL
	22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40632P	**J020-0B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40634J	**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0072	2001B	24		73-21-11	ALL
2		W0072	2001R	24		73-21-11	ALL
3		W0072	2001Z			73-21-11	ALL
4		W0072	0510	24		76-21-21	ALL
5		W0072	0104	24		76-21-21	ALL
6		W0072	0102	24		76-21-21	ALL
7	UNUSED						ALL
8		W0072	2012Z			73-24-12	ALL
9		W0072	2012R	24		73-24-12	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0072	0117	22		21-27-31	ALL
14		W0072	2004R	24		23-31-06	ALL
15		W0072	2004B	24		23-31-06	ALL
16		W0072	2003R	24		23-31-06	ALL
17		W0072	0119	22		21-27-31	ALL
18		W0072	2003B	24		23-31-06	ALL
19		W0072	0292	24		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40634J		**J020-0B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	20		W0072	0293	24		21-27-31	ALL
	21	UNUSED						ALL
	22		W0072	2012B	24		73-24-12	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W0072	2005R	24		23-31-06	ALL
	28		W0072	2005B	24		23-31-06	ALL
	29		W0072	0116	22		21-27-31	ALL
	30		W0072	0208	20		23-31-06	ALL
	31		W0072	0203	22		23-31-06	ALL
	DED		W0072	2003Z			23-31-06	ALL
	DED		W0072	2004Z			23-31-06	ALL
	DED		W0072	2005Z			23-31-06	ALL
D40634P		**J020-0B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5158	2611B	24		73-21-11	ALL
	2		W5158	2611R	24		73-21-11	ALL
	3		W5158	FRS5			73-21-11	ALL
	4		W5158	6021	24		76-21-21	ALL
	5		W5158	6022	24		76-21-21	ALL
	6		W5158	6023	24		76-21-21	ALL
	7	UNUSED						ALL
	8		W5158	FRBA			73-24-12	ALL
	9		W5158	2009R	24		73-24-12	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W5158	0577	22		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40634P	**J020-0B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
14		W5158	2001R	24		23-31-06	ALL
15		W5158	2001B	24		23-31-06	ALL
16		W5158	2002R	24		23-31-06	ALL
17		W5158	0569	22		21-27-31	ALL
18		W5158	2002B	24		23-31-06	ALL
19		W5158	0673	22		21-27-31	ALL
20		W5158	0698	24		21-27-31	ALL
21	UNUSED						ALL
22		W5158	2009B	24		73-24-12	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W5158	2003R	24		23-31-06	ALL
28		W5158	2003B	24		23-31-06	ALL
29		W5158	0576	22		21-27-31	ALL
30		W5158	0630	20		23-31-06	ALL
31		W5158	0631	22		23-31-06	ALL
S/R		W5158	FRB1			73-24-12	ALL
S/R		W5158	FRS6			73-21-11	ALL
DED		W5158	2001Z			23-31-06	ALL
DED		W5158	2002Z			23-31-06	ALL
DED		W5158	2003Z			23-31-06	ALL
		W5158	2009Z			73-24-12	ALL
		W5158	2611Z			73-21-11	ALL
		W5158	FRB1			73-24-12	ALL
		W5158	FRBA			73-24-12	ALL
		W5158	FRS5			73-21-11	ALL
		W5158	FRS6			73-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40636J		**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0072	0137	22		21-27-31	ALL
	2		W0072	0514	22		21-27-31	ALL
	3		W0072	0121	22		21-27-31	ALL
	4	UNUSED						ALL
	5		W0072	0616	22		27-61-43	ALL
	6		W0072	2002R	22		27-61-43	ALL
	7		W0072	2002B	22		27-61-43	ALL
	8		W0072	0220	22		27-62-11	ALL
	9		W0072	0221	20		27-62-11	ALL
	10		W0072	0222	20		27-62-11	ALL
	11		W0072	0225	20		27-62-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D40636P		**AJ0020B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5156	0640	22		21-27-31	ALL
	2		W5156	0641	22		21-27-31	ALL
	3		W5156	0642	22		21-27-31	ALL
	4	UNUSED						ALL
	5		W5156	0119	20		27-61-43	ALL
	6		W5156	2002R	22		27-61-43	ALL
	7		W5156	2002B	22		27-61-43	ALL
	8		W5156	0108	22		27-62-11	ALL
	9		W5156	0109	20		27-62-11	ALL
	10		W5156	0110	20		27-62-11	ALL
	11		W5156	0111	20		27-62-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40638J	**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0072	0064	24		32-51-11	ALL
2	UNUSED						ALL
3		W0072	0505	24		32-31-12	ALL
4		W0072	0105	18		24-11-21	ALL
5		W0072	0106	18		24-11-21	ALL
6		W0072	0511	22		21-27-31	ALL
7		W0072	0093	22		27-23-11	ALL
8		W0072	0094	22		27-23-11	ALL
9		W0072	0114	22		21-27-31	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0072	0006	22		26-16-21	ALL
14	UNUSED						ALL
D40638P	**J020-0B/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5158	0536	22		32-51-11	ALL
2		W5158	0680	22		SPARE	ALL
3		W5158	0621	22		32-31-12	ALL
4		W5158	0531	18		24-11-21	ALL
5		W5158	0532	18		24-11-21	ALL
6		W5158	0579	22		21-27-31	ALL
7		W5158	0534	22		27-23-11	ALL
8		W5158	0533	22		27-23-11	ALL
9		W5158	0580	22		21-27-31	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5158	0031	22		26-16-21	ALL
14		W5158	0678	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40640J		**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W0072	0226	20		27-62-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0072	0056	22		29-25-11	ALL
	6		W0072	0057	18		29-25-11	ALL
	7		W0072	0055	18		29-25-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W0072	0053	24		21-51-11	ALL
	11		W0072	0054	24		21-51-11	ALL
	12		W0072	0007	22		26-16-21	ALL
	13		W0072	0295	24		21-51-11	ALL
	14	UNUSED						ALL
D40640P		**J020-0B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5158	0706	20		SPARE	ALL
	2		W5158	0112	20		27-62-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5158	0548	22		29-25-11	ALL
	6		W5158	0549	18		29-25-11	ALL
	7		W5158	0550	18		29-25-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W5158	5501	24		21-51-11	ALL
	11		W5158	5502	24		21-51-11	ALL
	12		W5158	0032	22		26-16-21	ALL
	13		W5158	5510	24		21-51-11	ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40642J	**J020-0B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0072	0230	22		31-32-15	ALL
2		W0072	2011R	24		31-32-15	ALL
3		W0072	2011B	24		31-32-15	ALL
4		W0072	2011Z			31-32-15	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0072	2013R	24		73-24-12	ALL
9		W0072	2013B	24		73-24-12	ALL
10		W0072	2013Z			73-24-12	ALL
11		W0072	0231	20		49-62-11	ALL
12	UNUSED						ALL
D40642P	**J020-0B/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5156	0669	22		31-32-15	ALL
2		W5156	2011R	24		31-32-15	ALL
3		W5156	2011B	24		31-32-15	ALL
4		W5156	FRGA			31-32-15	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5156	2013R	24		73-24-12	ALL
9		W5156	2013B	24		73-24-12	ALL
10		W5156	FRGC			73-24-12	ALL
11		W5156	0670	20		49-62-11	ALL
12	UNUSED						ALL
S/R		W5156	FRGB			31-32-15	ALL
S/R		W5156	FRGD			73-24-12	ALL
		W5156	2011Z			31-32-15	ALL
		W5156	2013Z			73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40642P		**J020-0B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
			W5156	FRGA			31-32-15	ALL
			W5156	FRGB			31-32-15	ALL
			W5156	FRGC			73-24-12	ALL
			W5156	FRGD			73-24-12	ALL
D40646J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0296	22		26-23-11	ALL
	A02		W0220	0211	24		26-16-21	ALL
	A03		W0220	0297	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W0220	0290	22		26-23-11	ALL
	A06		W0220	0289	22		26-23-11	ALL
	A07		W0220	0291	22		26-23-11	ALL
	A08		W0220	0261	22		26-16-21	ALL
	A09		W0220	0258	22		26-16-21	ALL
	A10		W0220	0263	22		26-16-21	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0220	0264	22		26-16-21	ALL
	B02		W0220	0265	22		26-16-21	ALL
	B03		W0220	0266	22		26-16-21	ALL
	B04		W0220	0267	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40646J	**E002-02/ /**		**RCPT- (continued)**				**ALL**
B05		W0220	0268	22		26-16-21	ALL
B06		W0220	0269	22		26-16-21	ALL
B07		W0220	0317	22		26-16-21	ALL
B08		W0220	0408R	22		26-11-21	ALL
B09		W0220	0374R	22		26-11-31	ALL
B10		W0220	0222	24		26-16-22	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
D40646P	**E002-02/ /**		**PLUG-**				**ALL**
A01		W2110	6041	22		26-23-11	ALL
A02		W2110	6044	24		26-16-21	ALL
A03		W2110	6042	22		26-23-11	ALL
A04	UNUSED						ALL
A05		W2110	6039	22		26-23-11	ALL
A06		W2110	6022	22		26-23-11	ALL
A07		W2110	6040	22		26-23-11	ALL
A08		W2110	6001	22		26-16-21	ALL
A09		W2110	6002	22		26-16-21	ALL
A10		W2110	6003	22		26-16-21	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40646P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2110	6004	22		26-16-21	ALL
	B02		W2110	6005	22		26-16-21	ALL
	B03		W2110	6006	22		26-16-21	ALL
	B04		W2110	6007	22		26-16-21	ALL
	B05		W2110	6008	22		26-16-21	ALL
	B06		W2110	6009	22		26-16-21	ALL
	B07		W2110	6034	22		26-16-21	ALL
	B08		W2110	6035	22		26-11-21	ALL
	B09		W2110	6036	22		26-11-31	ALL
	B10		W2110	6045	24		26-16-22	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40652J	**710/199/L052**		**RCPT-**				**ALL**
1		W7596	6011R	20		26-21-11	ALL
2		W7596	6002R	20		26-21-11	ALL
3		W7596	6001R	20		26-21-11	ALL
4		W7596	6010R	20		26-21-11	ALL
5		W7596	6009R	20		26-21-11	ALL
6		W7596	6005R	20		26-21-11	ALL
7	UNUSED						ALL
8		W7596	6008R	20		26-21-11	ALL
9		W7596	6003R	20		26-21-11	ALL
10		W7596	6007R	20		26-21-11	ALL
11		W7596	6004R	20		26-21-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
D40652P	**710/199/L053**		**PLUG - ELEC DISC FWD**				**ALL**
1		W7592	6010R	20		26-21-11	ALL
2		W7592	6011R	20		26-21-11	ALL
3		W7592	6012R	20		26-21-11	ALL
4		W7592	6013R	20		26-21-11	ALL
5		W7592	6014R	20		26-21-11	ALL
6		W7592	6004R	20		26-21-11	ALL
7	UNUSED						ALL
8		W7592	6006R	20		26-21-11	ALL
9		W7592	6007R	20		26-21-11	ALL
10		W7592	6008R	20		26-21-11	ALL
11		W7592	6009R	20		26-21-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40652P		**710/199/L053**		**PLUG - ELEC DISC FWD (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
D40654J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0283	22		23-43-11	ALL
	2		W0044	0284	22		23-43-11	ALL
	3		W0044	0049	22		24-41-11	ALL
	4		W0044	6209	20		33-42-21	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0044	0285	22		23-42-11	ALL
	8	UNUSED						ALL
	9		W0044	0329	20		33-32-11	ALL
	10		W0044	0331	20		33-32-11	ALL
	11	UNUSED						ALL
	12		W0044	0563	24		33-29-11	ALL
D40654P		**P006-00/ /**		**PLUG-P6 LOWER**				**ALL**
	1		W6024	0505	22		23-43-11	ALL
	2		W6024	0506	22		23-43-11	ALL
	3		W6024	0504	22		24-41-11	ALL
	4		W6024	0110	20		33-42-21	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W6024	0203	22		23-42-11	ALL
	8	UNUSED						ALL
	9		W6024	0509	20		33-32-11	ALL
	10		W6024	0510	20		33-32-11	ALL
	11	UNUSED						ALL
	12		W6024	0301	22		33-29-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40656J	**E002-02/ /**		**RCPT-**				**ALL**
A01		W0220	0397R	20		26-21-11	ALL
A02		W0220	0392R	20		26-21-11	ALL
A03		W0220	0391R	20		26-21-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0220	0393R	20		26-21-11	ALL
B02		W0220	0398R	20		26-21-11	ALL
B03		W0220	0399R	20		26-21-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D40656P	**E002-02/ /**		**PLUG**				**ALL**
A01		W7592	6004R	20		26-21-11	ALL
A02		W7592	6003R	20		26-21-11	ALL
A03		W7592	6001R	20		26-21-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40656P		**E002-02/ /**		**PLUG (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W7592	6002R	20		26-21-11	ALL
	B02		W7592	6006R	20		26-21-11	ALL
	B03		W7592	6008R	20		26-21-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40658J		**J004-00/ /**		**RCPT-**				**ALL**
	1	18	W0094	0255	18		73-22-41	ALL
	2	18	W0094	0248	18		73-22-41	ALL
	3	18	W0094	0254	18		73-22-41	ALL
	4	18	W0094	0256	18		73-22-41	ALL
	5	18	W0094	0251	18		73-22-41	ALL
	6	18	W0094	0249	18		73-22-41	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0094	0237	20		33-42-21	ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40658J	**J004-00/ /**		**RCPT- (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40658P	**J004-00/ /**		**PLUG-**				**ALL**
1	18	W5160	0191	18		73-22-41	ALL
2	18	W5160	0183	18		73-22-41	ALL
3	18	W5160	0190	18		73-22-41	ALL
4	18	W5160	0192	18		73-22-41	ALL
5	18	W5160	0186	18		73-22-41	ALL
6	18	W5160	0184	18		73-22-41	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40658P		**J004-00/ /**		**PLUG- (continued)**				**ALL**
	14	UNUSED						ALL
	15		W5160	0152	20		33-42-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40662J		**J004-00/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02		W0094	0532	20		44-35-20	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0094	0531	20		44-35-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40662J		**J004-00/ /**		**RCPT- (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40662P		**J004-00/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02		W6212	0012	20		44-35-20	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6212	0023	20		44-35-20	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40662P		**J004-00/ /**		**PLUG (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40664		**234/187/R034**		**PLUG-CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W6024	0504	22		24-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W6024	0202	22		23-43-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W6024	0502	20		33-32-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W6024	0509	20		33-32-11	ALL
	19		W6024	0506	22		23-43-11	ALL
	20		W6024	0510	20		33-32-11	ALL
	21	UNUSED						ALL
	22		W6024	0505	22		23-43-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W6024	2201B	22		24-41-11	ALL
	26		W6024	2201R	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40664	**234/187/R034**		**PLUG-CONNECTOR (continued)**				**ALL**
27		W6024	0503	22		24-41-11	ALL
28		W6024	3503R	22		23-41-11	ALL
29		W6024	3503B	22		23-41-11	ALL
30		W6024	3503Y	22		23-41-11	ALL
31		W6024	3504R	22		23-41-11	ALL
32		W6024	3504B	22		23-41-11	ALL
33		W6024	3504Y	22		23-41-11	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
DED		W6024	3503Z			23-41-11	ALL
DED		W6024	3504Z			23-41-11	ALL
D40665	**234/187/R034**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0048	0504	22		24-41-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0048	8004	20		23-43-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0048	0009	20		33-32-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40665		**234/187/R034**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0048	0008	20		33-32-11	ALL
	19		W0048	8001	20		23-43-11	ALL
	20		W0048	0010	20		33-32-11	ALL
	21	UNUSED						ALL
	22		W0048	8003	20		23-43-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0048	2201B	22		24-41-11	ALL
	26		W0048	2201R	22		24-41-11	ALL
	27		W0048	0503	22		24-41-11	ALL
	28		W0048	A-RD			23-41-11	ALL
	29		W0048	A-BL			23-41-11	ALL
	30		W0048	A-BK			23-41-11	ALL
	31		W0048	B-RD			23-41-11	ALL
	32		W0048	B-BL			23-41-11	ALL
	33		W0048	B-BK			23-41-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D40666J		**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0076	0504	22		31-31-11	ALL
	2		W0076	0505	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40666J	**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
3		W0076	2504R	20		78-32-51	ALL
4		W0076	2504B	20		78-32-51	ALL
5		W0076	0420	24		36-11-12	ALL
6		W0076	0056	22		23-22-11	ALL
7		W0076	0192	24		73-22-11	ALL
8		W0076	0251	22		21-25-11	ALL
9		W0076	0447	20		73-22-11	ALL
10		W0076	0515	24		76-21-11	ALL
11		W0076	1001	20		73-22-11	ALL
12		W0076	1001Z			73-22-11	ALL
13	UNUSED						ALL
14		W0076	0449	20		73-22-11	ALL
15		W0076	0123	24		73-22-31	ALL
16	UNUSED						ALL
17		W0076	0142	24		76-21-11	ALL
18		W0076	0132	24		76-21-11	ALL
19		W0076	2504Z			78-32-51	ALL
20		W0076	0462	20		74-11-11	ALL
21	UNUSED						ALL
22		W0076	2001R	24		73-21-11	ALL
23		W0076	2001B	24		73-21-11	ALL
24		W0076	2001Z			73-21-11	ALL
25		W0076	0191	24		73-22-11	ALL
26		W0076	0007	20		52-71-13	ALL
27		W0076	0146	22		23-15-15	ALL
28		W0076	0145	22		23-15-15	ALL
29	18	W0076	0154	18		23-71-01	ALL
30	UNUSED						ALL
31		W0076	0166	22		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40666P		**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5156	0528	22		31-31-11	ALL
	2		W5156	0529	22		31-31-11	ALL
	3		W5156	2501R	20		78-32-51	ALL
	4		W5156	2501B	20		78-32-51	ALL
	5		W5156	0088	24		36-11-12	ALL
	6		W5156	0568	22		23-22-11	ALL
	7		W5156	6017	24		73-22-11	ALL
	8		W5156	0628	22		21-25-11	ALL
	9		W5156	0076	20		73-22-11	ALL
	10		W5156	6009	24		76-21-11	ALL
	11		W5156	1301	20		73-22-11	ALL
	12		W5156	FREA			73-22-11	ALL
	13	UNUSED						ALL
	14		W5156	6003	20		73-22-11	ALL
	15		W5156	6005	24		73-22-31	ALL
	16	UNUSED						ALL
	17		W5156	6010	24		76-21-11	ALL
	18		W5156	6011	24		76-21-11	ALL
	19		W5156	2501Z			78-32-51	ALL
	20		W5156	0081	20		74-11-11	ALL
	21	UNUSED						ALL
	22		W5156	2601R	24		73-21-11	ALL
	23		W5156	2601B	24		73-21-11	ALL
	24		W5156	FRSA			73-21-11	ALL
	25		W5156	0077	20		73-22-11	ALL
	26		W5156	0003	20		52-71-13	ALL
	27		W5156	0066	22		23-15-15	ALL
	28		W5156	0689	22		23-15-15	ALL
	29	18	W5156	0025	18		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40666P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
30		W5156	0594	24		SPARE	ALL
31		W5156	0024	22		23-71-01	ALL
S/R		W5156	FREB			73-22-11	ALL
S/R		W5156	FRSB			73-21-11	ALL
		W5156	1301Z			73-22-11	ALL
		W5156	2601Z			73-21-11	ALL
		W5156	FREA			73-22-11	ALL
		W5156	FREB			73-22-11	ALL
		W5156	FRSA			73-21-11	ALL
		W5156	FRSB			73-21-11	ALL
D40668J	**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0076	0216	24		32-41-11	ALL
2	UNUSED						ALL
3		W0076	0509	22		31-31-11	ALL
4		W0076	0510	22		31-31-11	ALL
5	UNUSED						ALL
6		W0076	0179	22		23-71-01	ALL
7		W0076	0124	22		29-23-11	ALL
8	UNUSED						ALL
9		W0076	0061	24		32-31-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40668J		**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W0076	0167	22		23-71-01	ALL
	32		W0076	0344	22		21-25-11	ALL
	33		W0076	0345	22		21-25-11	ALL
	34		W0076	0348	24		21-43-21	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W0076	0349	24		21-43-21	ALL
	43		W0076	0417	22		46-13-11	ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40668J	**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W0076	0414	22		44-21-22	ALL
D40668P	**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5100	0631	22		32-41-11	ALL
2	UNUSED						ALL
3		W5100	0502	22		31-31-11	ALL
4		W5100	0503	22		31-31-11	ALL
5	UNUSED						ALL
6		W5100	0007	22		23-71-01	ALL
7		W5100	0518	22		29-23-11	ALL
8		W5100	6001R	22		SPARE	ALL
9		W5100	0521	22		32-31-11	ALL
10		W5100	0003	24		SPARE	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5100	6002R	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40668P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21		W5100	6003R	22		SPARE	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W5100	0006	22		23-71-01	ALL
	32		W5100	0012	22		21-25-11	ALL
	33		W5100	0013	22		21-25-11	ALL
	34		W5100	0014	24		21-43-21	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42		W5100	0015	24		21-43-21	ALL
	43		W5100	0024	22		46-13-11	ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40668P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55		W5100	0021	22		44-21-22	ALL
D40670J	**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0076	0055	22		23-22-11	ALL
2		W0076	0052	22		23-22-11	ALL
3		W0076	0053	22		23-22-11	ALL
4		W0076	0135	24		31-31-15	ALL
5	UNUSED						ALL
6		W0076	0363	22		27-33-11	ALL
7		W0076	0364	22		27-33-11	ALL
8		W0076	0365	22		27-33-11	ALL
9		W0076	0072	24		32-31-11	ALL
10		W0076	0082	24		32-31-11	ALL
11		W0076	0092	24		32-31-11	ALL
12		W0076	0102	24		32-31-11	ALL
13		W0076	0112	24		32-31-11	ALL
14		W0076	0514	24		32-31-11	ALL
15		W0076	0203	24		32-41-11	ALL
16		W0076	0211	24		32-41-11	ALL
17		W0076	0217	24		32-41-11	ALL
18		W0076	0204	24		32-41-11	ALL
19		W0076	0201	24		32-41-11	ALL
20	UNUSED						ALL
21		W0076	0100	22		34-41-11	ALL
22		W0076	0118	22		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40670J		**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	23		W0076	0076	24		21-42-11	ALL
	24		W0076	0077	24		21-42-11	ALL
	25		W0076	0030	24		73-22-31	ALL
	26		W0076	0126	24		73-22-31	ALL
	27		W0076	0137	24		76-21-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0076	0275	24		34-61-26	ALL
	31		W0076	0062	24		32-31-11	ALL
	32		W0076	0346	22		21-25-11	ALL
	33		W0076	0347	22		21-25-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50		W0076	0139	20		78-34-11	ALL
	51		W0076	0540	20		78-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40670J	**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
D40670P	**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5156	0503	22		23-22-11	ALL
2		W5156	0504	22		23-22-11	ALL
3		W5156	0505	22		23-22-11	ALL
4		W5156	0522	22		31-31-15	ALL
5	UNUSED						ALL
6		W5156	0069	22		27-33-11	ALL
7		W5156	0070	22		27-33-11	ALL
8		W5156	0071	22		27-33-11	ALL
9		W5156	0605	22		32-31-11	ALL
10		W5156	0606	22		32-31-11	ALL
11		W5156	0607	22		32-31-11	ALL
12		W5156	0303	22		32-31-11	ALL
13		W5156	0609	22		32-31-11	ALL
14		W5156	0614	22		32-31-11	ALL
15		W5156	0631	22		32-41-11	ALL
16		W5156	0632	22		32-41-11	ALL
17		W5156	0633	22		32-41-11	ALL
18		W5156	0634	22		32-41-11	ALL
19		W5156	0635	22		32-41-11	ALL
20		W5156	6025R	22		SPARE	ALL
21		W5156	0028	22		34-41-11	ALL
22		W5156	0016	22		34-41-11	ALL
23		W5156	5520	24		21-42-11	ALL
24		W5156	5521	24		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40670P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	25		W5156	6004	24		73-22-31	ALL
	26		W5156	6006	24		73-22-31	ALL
	27		W5156	6012	24		76-21-11	ALL
	28		W5156	0645	20		SPARE	ALL
	29	UNUSED						ALL
	30		W5156	0126	24		34-61-26	ALL
	31		W5156	0604	22		32-31-11	ALL
	32		W5156	5529	22		21-25-11	ALL
	33		W5156	5530	22		21-25-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50		W5156	6031	20		78-34-11	ALL
	51		W5156	6030	20		78-34-11	ALL
	52	UNUSED						ALL
	53	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40670P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
54	UNUSED						ALL
55	UNUSED						ALL
D40671J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0066	0393	22		21-25-11	ALL
A02		W0066	0398	24		21-51-24	ALL
A03		W0066	0412	22		27-33-11	ALL
A04		W0066	0417	22		27-33-11	ALL
A05		W0066	0418	22		27-33-11	ALL
A06		W0066	0427	24		21-25-11	ALL
A07		W0066	2028B	22		52-71-11	ALL
A08		W0066	2028R	22		52-71-11	ALL
A09		W0066	2016B	24		73-21-11	ALL
A10		W0066	2016R	24		73-21-11	ALL
B01		W0066	1024	20		73-22-11	ALL
B02		W0066	0389	24		73-22-11	ALL
B03		W0066	0392	24		73-22-31	ALL
B04		W0066	0390	22		73-23-11	ALL
B05		W0066	2017R	24		73-24-12	ALL
B06		W0066	2017B	24		73-24-12	ALL
B07		W0066	2018R	24		73-24-21	ALL
B08		W0066	2018B	24		73-24-21	ALL
B09		W0066	0391	24		76-21-21	ALL
B10	UNUSED						ALL
PERG	1F	W0066	1024Z			73-22-11	ALL
PERG	1F	W0066	2016Z			73-21-11	ALL
PERG	1F	W0066	2017Z			73-24-12	ALL
PERG	1F	W0066	2018Z			73-24-21	ALL
D40671P	**AJ0046B/*/***		**PLUG**				**ALL**
A01		W6412	5536	22		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40671P		**AJ0046B/*/***		**PLUG (continued)**				**ALL**
	A02		W6412	5515	24		21-51-24	ALL
	A03		W6412	0045	22		27-33-11	ALL
	A04		W6412	0046	20		27-33-11	ALL
	A05		W6412	0044	22		27-33-11	ALL
	A06		W6412	0010	24		21-25-11	ALL
	A07		W6412	2401B	20		52-71-11	ALL
	A08		W6412	2401R	20		52-71-11	ALL
	A09		W6412	2612B	24		73-21-11	ALL
	A10		W6412	2612R	24		73-21-11	ALL
	B01		W6412	1301	20		73-22-11	ALL
	B02		W6412	6004	24		73-22-11	ALL
	B03		W6412	6005	24		73-22-31	ALL
	B04		W6412	6008	24		73-23-11	ALL
	B05		W6412	2606R	24		73-24-12	ALL
	B06		W6412	2606B	24		73-24-12	ALL
	B07		W6412	2601R	20		73-24-21	ALL
	B08		W6412	2601B	20		73-24-21	ALL
	B09		W6412	6009	22		76-21-21	ALL
	B10	UNUSED						ALL
	PERG	1F	W6412	1301Z			73-22-11	ALL
	PERG	1F	W6412	2601Z			73-24-21	ALL
	PERG	1F	W6412	2606Z			73-24-12	ALL
	PERG	1F	W6412	2612Z			73-21-11	ALL
D40672J		**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40672J	**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
6		W0076	0066	24		21-43-21	ALL
7	18	W0076	0469	18		78-32-51	ALL
8	UNUSED						ALL
9		W0076	0177	22		23-71-01	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0076	0178	22		23-71-01	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0076	0069	24		21-43-21	ALL
17		W0076	0184	22		34-41-11	ALL
18	18	W0076	0310	18		78-32-51	ALL
19	18	W0076	0313	18		78-32-51	ALL
20	18	W0076	0312	18		78-32-51	ALL
21	UNUSED						ALL
22		W0076	0148	22		23-15-15	ALL
23		W0076	0170	20		23-71-01	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	18	W0076	0516	18		78-32-51	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W0076	0453	20		74-11-11	ALL
30	18	W0076	0311	18		78-32-51	ALL
31	UNUSED						ALL
D40672P	**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40672P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5510	5502	24		21-43-21	ALL
	7	18	W5510	6088	18		78-32-51	ALL
	8	UNUSED						ALL
	9		W5510	0011	22		23-71-01	ALL
	10	UNUSED						ALL
	11		W5510	5503	24		SPARE	ALL
	12		W5510	0012	22		23-71-01	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5510	5510	24		SPARE	ALL
	16		W5510	5511	24		21-43-21	ALL
	17		W5510	0500	22		34-41-11	ALL
	18	18	W5510	2601B	18		78-32-51	ALL
	19	18	W5510	2602R	18		78-32-51	ALL
	20	18	W5510	2602B	18		78-32-51	ALL
	21	UNUSED						ALL
	22		W5510	6016	22		23-15-15	ALL
	23		W5510	0010	20		23-71-01	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	18	W5510	6008	18		78-32-51	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W5510	6004	20		74-11-11	ALL
	30	18	W5510	2601R	18		78-32-51	ALL
	31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40672P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
S/R		W5510	2601Z			78-32-51	ALL
S/R		W5510	2602Z			78-32-51	ALL
D40674J	**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0076	0459	20		74-11-11	ALL
2		W0076	0460	20		74-11-11	ALL
3	UNUSED						ALL
4		W0076	0458	20		74-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0076	0339	20		47-30-11	ALL
9		W0076	0078	20		34-41-11	ALL
10		W0076	0160	22		26-23-11	ALL
11		W0076	0340	20		47-30-11	ALL
12		W0076	0196	20		73-22-11	ALL
13		W0076	1002	20		73-22-11	ALL
14		W0076	1002Z			73-22-11	ALL
15		W0076	0277	24		34-61-26	ALL
16	UNUSED						ALL
17		W0076	2503R	20		78-32-51	ALL
18		W0076	2503B	20		78-32-51	ALL
19		W0076	2503Z			78-32-51	ALL
20		W0076	0540	20		78-34-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40674J		**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40674P		**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5506	6045	20		74-11-11	ALL
	2		W5506	0112	20		74-11-11	ALL
	3	UNUSED						ALL
	4		W5506	0111	20		74-11-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5506	0601	20		47-30-11	ALL
	9		W5506	6001	20		34-41-11	ALL
	10		W5506	6080	22		26-23-11	ALL
	11		W5506	0602	20		47-30-11	ALL
	12		W5506	6081	20		73-22-11	ALL
	13		W5506	1311	20		73-22-11	ALL
	14		W5506	FRE1			73-22-11	ALL
	15		W5506	6505	24		34-61-26	ALL
	16	UNUSED						ALL
	17		W5506	2202R	20		78-32-51	ALL
	18		W5506	2202B	20		78-32-51	ALL
	19		W5506	2202Z			78-32-51	ALL
	20		W5506	6041	20		78-34-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40674P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
S/R		W5506	FRE2			73-22-11	ALL
		W5506	1311Z			73-22-11	ALL
		W5506	FRE1			73-22-11	ALL
		W5506	FRE2			73-22-11	ALL
D40676J	**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0076	0093	22		29-25-11	ALL
2		W0076	0094	18		29-25-11	ALL
3		W0076	0008	20		52-71-13	ALL
4		W0076	0500	20		52-71-13	ALL
5		W0076	0517	20		52-71-13	ALL
6		W0076	0020	20		52-71-13	ALL
7		W0076	0520	20		52-71-13	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0076	0252	22		21-25-11	ALL
13		W0076	0074	24		21-42-11	ALL
14		W0076	0114	20		78-34-11	ALL
D40676P	**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5156	0584	22		29-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40676P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2		W5156	0585	18		29-25-11	ALL
	3		W5156	0004	20		52-71-13	ALL
	4		W5156	0005	20		52-71-13	ALL
	5		W5156	0006	20		52-71-13	ALL
	6		W5156	0007	20		52-71-13	ALL
	7		W5156	0569	20		52-71-13	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5156	0629	22		21-25-11	ALL
	13		W5156	5519	24		21-42-11	ALL
	14		W5156	6014	20		78-34-11	ALL
D40678J		**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W0076	0254	14		21-25-11	ALL
	2		W0076	0256	14		21-25-11	ALL
	3		W0076	0258	14		21-25-11	ALL
	4		W0076	0253	14		21-25-11	ALL
	5		W0076	0255	14		21-25-11	ALL
	6		W0076	0257	14		21-25-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
D40678P		**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5156	0622	14		21-25-11	ALL
	2		W5156	0623	14		21-25-11	ALL
	3		W5156	0624	14		21-25-11	ALL
	4		W5156	0625	14		21-25-11	ALL
	5		W5156	0626	14		21-25-11	ALL
	6		W5156	0627	14		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40678P	**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
7	UNUSED						ALL
8	UNUSED						ALL
D40680J	**J022-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0076	0058	24		34-49-11	ALL
16		W0076	2003Z			34-49-11	ALL
17		W0076	2003B	24		34-49-11	ALL
18		W0076	2003R	24		34-49-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W0076	0183	24		34-41-11	ALL
25		W0076	0185	22		34-41-11	ALL
26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40680J		**J022-00/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	27		W0076	0418	22		27-62-11	ALL
	28		W0076	0419	22		27-62-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40680P		**J022-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5156	0014	24		34-49-11	ALL
	16		W5156	FRAC			34-49-11	ALL
	17		W5156	2003B	24		34-49-11	ALL
	18		W5156	2003R	24		34-49-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40680P		**J022-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	24		W5156	0026	24		34-41-11	ALL
	25		W5156	0027	22		34-41-11	ALL
	26	UNUSED						ALL
	27		W5156	0082	22		27-62-11	ALL
	28		W5156	0083	22		27-62-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	S/R		W5156	FRA1			34-49-11	ALL
			W5156	2003Z			34-49-11	ALL
			W5156	FRA1			34-49-11	ALL
			W5156	FRAC			34-49-11	ALL
D40686J		**AJ0023/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0078	0231	22		23-31-06	ALL
	4	UNUSED						ALL
	5		W0078	2607Z			73-21-11	ALL
	6		W0078	2607B	24		73-21-11	ALL
	7		W0078	2607R	24		73-21-11	ALL
	8		W0078	6008	24		76-21-11	ALL
	9		W0078	6009	24		76-21-11	ALL
	10		W0078	6010	24		76-21-11	ALL
	11	UNUSED						ALL
	12		W0078	0311	22		35-21-11	ALL
	13		W0078	0002	22		35-21-11	ALL
	14	UNUSED						ALL
D40686P		**AJ0023/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40686P		**AJ0023/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2	UNUSED						ALL
	3		W5506	6501	22		23-31-06	ALL
	4	UNUSED						ALL
	5		W5506	FRS5			73-21-11	ALL
	6		W5506	2611B	24		73-21-11	ALL
	7		W5506	2611R	24		73-21-11	ALL
	8		W5506	6009	24		76-21-11	ALL
	9		W5506	6010	24		76-21-11	ALL
	10		W5506	6047	24		76-21-11	ALL
	11	UNUSED						ALL
	12		W5506	0001	22		35-21-11	ALL
	13		W5506	0002	22		35-21-11	ALL
	14	UNUSED						ALL
	S/R		W5506	FRS6			73-21-11	ALL
			W5506	2611Z			73-21-11	ALL
			W5506	FRS5			73-21-11	ALL
			W5506	FRS6			73-21-11	ALL
D40687J		**AP1800A/ /**		**RCPT-**				**ALL**
	1		W0018	0106	22		23-71-01	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	14	W0018	0107	14		23-71-01	ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40687J	**AP1800A/ /**		**RCPT- (continued)**				**ALL**
12	UNUSED						ALL
D40687P	**P018-00/ /**		**PLUG**				**ALL**
1		W3004	0001	22		23-71-01	ALL
2	UNUSED						ALL
3		W3004	0003	22		SPARE	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	14	W3004	0002	14		23-71-01	ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40688J	**AJ0023/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0078	0301	22		35-21-11	ALL
2		W0078	0302	16		35-21-11	ALL
3		W0078	0303	16		35-21-11	ALL
4		W0078	0304	16		35-21-11	ALL
5		W0078	0305	16		35-21-11	ALL
6		W0078	0306	22		35-21-11	ALL
7		W0078	0507	18		24-11-11	ALL
8		W0078	0508	18		24-11-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0078	0332	20		33-25-11	ALL
12		W0078	0333	20		33-25-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40688P		**AJ0023/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5510	0001	22		35-21-11	ALL
	2		W5510	0002	16		35-21-11	ALL
	3		W5510	0003	16		35-21-11	ALL
	4		W5510	0004	16		35-21-11	ALL
	5		W5510	0005	16		35-21-11	ALL
	6		W5510	0006	22		35-21-11	ALL
	7		W5510	0501	18		24-11-11	ALL
	8		W5510	0574	18		24-11-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5510	0051	20		33-25-11	ALL
	12		W5510	0052	20		33-25-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D40692J		**J024-00/ /**		**RCPT-**				**ALL**
	1		W0080	5523	24		21-43-21	ALL
	2		W0080	5597	24		21-43-21	ALL
	3		W0080	5598	24		21-43-21	ALL
	4		W0080	5624	24		21-43-21	ALL
	5		W0080	6043	18		78-32-61	ALL
	6		W0080	6048	18		78-32-61	ALL
	7		W0080	6049	18		78-32-61	ALL
	8		W0080	6042	18		78-32-61	ALL
	9		W0080	0044	18		78-32-61	ALL
	10		W0080	5516	24		21-43-21	ALL
	11		W0080	5571	24		21-43-21	ALL
	12		W0080	5513	24		21-43-21	ALL
	13		W0080	6017	18		78-32-61	ALL
	14		W0080	5623	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40692P	**AJ0024/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5158	0566	24		21-43-21	ALL
2		W5158	0709	24		21-43-21	ALL
3		W5158	0710	24		21-43-21	ALL
4		W5158	0221	24		21-43-21	ALL
5		W5158	2602B	18		78-32-61	ALL
6		W5158	2602R	18		78-32-61	ALL
7		W5158	2601B	18		78-32-61	ALL
8		W5158	2601R	18		78-32-61	ALL
9		W5158	0005	18		78-32-61	ALL
10		W5158	0564	24		21-43-21	ALL
11		W5158	0563	24		21-43-21	ALL
12		W5158	0562	24		21-43-21	ALL
13		W5158	6002	18		78-32-61	ALL
14		W5158	0708	24		21-43-21	ALL
S/R		W5158	2601Z			78-32-61	ALL
S/R		W5158	2602Z			78-32-61	ALL
D40694J	**J024-00/ /**		**RCPT-**				**ALL**
1		W0080	6501	24		31-31-15	ALL
2		W0080	6104	20		47-30-11	ALL
3		W0080	6105	20		47-30-11	ALL
4		W0080	2608R	20		78-32-61	ALL
5		W0080	6109	20		47-30-11	ALL
6		W0080	2608Z			78-32-61	ALL
7		W0080	6016	24		76-21-21	ALL
8		W0080	0504	22		29-23-11	ALL
9		W0080	6003	24		73-22-11	ALL
10		W0080	0527	22		27-62-11	ALL
11		W0080	1302	20		73-22-11	ALL
12		W0080	6007	24		73-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40694J		**J024-00/ /**		**RCPT- (continued)**				**ALL**
	13	UNUSED						ALL
	14		W0080	5503	22		21-25-11	ALL
	15		W0080	5556	22		21-25-11	ALL
	16		W0080	6087	20		47-30-11	ALL
	17		W0080	5532	24		21-27-21	ALL
	18		W0080	5510	22		21-27-21	ALL
	19		W0080	5569	22		21-27-21	ALL
	20		W0080	0579	24		21-25-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W0080	1302Z			73-22-11	ALL
	24	UNUSED						ALL
	25		W0080	0049	22		46-13-11	ALL
	26		W0080	6552	20		44-21-22	ALL
	27		W0080	2608B	20		78-32-61	ALL
	28		W0080	5570	22		21-27-21	ALL
	29		W0080	6053	20		78-34-21	ALL
	30		W0080	6052	20		78-34-21	ALL
	31	UNUSED						ALL
D40694P		**AJ0024/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5160	0561	22		31-31-15	ALL
	2		W5160	0320	20		47-30-11	ALL
	3		W5160	0321	20		47-30-11	ALL
	4		W5160	2503R	20		78-32-61	ALL
	5		W5160	0322	20		47-30-11	ALL
	6		W5160	2503Z			78-32-61	ALL
	7		W5160	6005	24		76-21-21	ALL
	8		W5160	0518	22		29-23-11	ALL
	9		W5160	6002	24		73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40694P	**AJ0024/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
10		W5160	0176	22		27-62-11	ALL
11		W5160	1301	20		73-22-11	ALL
12		W5160	6008	24		73-22-31	ALL
13		W5160	0588	22		SPARE	ALL
14		W5160	0529	22		21-25-11	ALL
15		W5160	0528	22		21-25-11	ALL
16		W5160	0323	20		47-30-11	ALL
17		W5160	0531	22		21-27-21	ALL
18		W5160	0532	22		21-27-21	ALL
19		W5160	0585	22		21-27-21	ALL
20		W5160	0540	24		21-25-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5160	FRE1			73-22-11	ALL
24	UNUSED						ALL
25		W5160	0718	22		46-13-11	ALL
26		W5160	0098	20		44-21-22	ALL
27		W5160	2503B	20		78-32-61	ALL
28		W5160	0586	22		21-27-21	ALL
29		W5160	6028	20		78-34-21	ALL
30		W5160	6027	20		78-34-21	ALL
31		W5160	0620	20		SPARE	ALL
S/R		W5160	FRE2			73-22-11	ALL
		W5160	1301Z			73-22-11	ALL
		W5160	FRE1			73-22-11	ALL
		W5160	FRE2			73-22-11	ALL
D40696J	**J024-00/ /**		**RCPT-**				**ALL**
1		W0080	2601R	24		73-21-11	ALL
2		W0080	2601B	24		73-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40696J		**J024-00/ /**		**RCPT- (continued)**				**ALL**
	3		W0080	1301	20		73-22-11	ALL
	4		W0080	6002	20		73-22-11	ALL
	5		W0080	6013	24		76-21-21	ALL
	6		W0080	6015	24		76-21-21	ALL
	7		W0080	6005	24		73-22-31	ALL
	8		W0080	6010	24		76-21-21	ALL
	9		W0080	2601Z			73-21-11	ALL
	10		W0080	1301Z			73-22-11	ALL
	11		W0080	5508	24		21-27-21	ALL
	12	UNUSED						ALL
	13		W0080	5535	24		21-27-21	ALL
	14		W0080	6034	20		78-34-21	ALL
	15		W0080	5537	24		21-27-21	ALL
	16		W0080	5632	22		21-43-21	ALL
	17		W0080	5633	22		21-27-21	ALL
	18		W0080	5634	22		21-27-21	ALL
	19		W0080	5631	22		21-43-21	ALL
	20		W0080	0060	20		74-11-11	ALL
	21		W0080	6053	20		78-34-21	ALL
	22	UNUSED						ALL
	23		W0080	5635	24		21-43-21	ALL
	24		W0080	5630	24		21-43-21	ALL
	25		W0080	5567	22		21-27-21	ALL
	26		W0080	5568	22		21-27-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0080	0057	20		74-11-11	ALL
	30		W0080	5619	24		21-43-21	ALL
	31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40696P	**AJ0024/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W6510	2601R	24		73-21-11	ALL
2		W6510	2601B	24		73-21-11	ALL
3		W6510	1311	20		73-22-11	ALL
4		W6510	6011	20		73-22-11	ALL
5		W6510	6005	24		76-21-21	ALL
6		W6510	6006	24		76-21-21	ALL
7		W6510	6012	24		73-22-31	ALL
8		W6510	6013	24		76-21-21	ALL
9		W6510	FRSF			73-21-11	ALL
10		W6510	FREG			73-22-11	ALL
11		W6510	5503	24		21-27-21	ALL
12	UNUSED						ALL
13		W6510	5502	24		21-27-21	ALL
14		W6510	6063	20		78-34-21	ALL
15		W6510	5504	24		21-27-21	ALL
16		W6510	0016	22		21-43-21	ALL
17		W6510	0017	22		21-27-21	ALL
18		W6510	0018	22		21-27-21	ALL
19		W6510	0015	22		21-43-21	ALL
20		W6510	6015	20		74-11-11	ALL
21		W6510	6030	20		78-34-21	ALL
22	UNUSED						ALL
23		W6510	0019	24		21-43-21	ALL
24		W6510	0020	24		21-43-21	ALL
25		W6510	6009	22		21-27-21	ALL
26		W6510	6010	22		21-27-21	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W6510	6016	20		74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40696P		**AJ0024/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	30		W6510	0013	24		21-51-12	ALL
	31	UNUSED						ALL
	S/R		W6510	FREF			73-22-11	ALL
	S/R		W6510	FRSG			73-21-11	ALL
			W6510	1311Z			73-22-11	ALL
			W6510	2601Z			73-21-11	ALL
			W6510	FREF			73-22-11	ALL
			W6510	FREG			73-22-11	ALL
			W6510	FRSF			73-21-11	ALL
			W6510	FRSG			73-21-11	ALL
D40698J		**J024-00/ /**		**RCPT-**				**ALL**
	1		W0080	0505	22		32-31-12	ALL
	2		W0080	0023	22		23-71-01	ALL
	3		W0080	6512	22		31-31-11	ALL
	4		W0080	6508	22		31-31-11	ALL
	5		W0080	0025	22		23-71-01	ALL
	6	UNUSED						ALL
	7		W0080	0504	22		29-23-11	ALL
	8	UNUSED						ALL
	9		W0080	0516	22		32-41-11	ALL
	10		W0080	0509	22		32-31-12	ALL
	11		W0080	0507	22		32-31-12	ALL
	12		W0080	0506	22		32-31-12	ALL
	13		W0080	0508	22		32-31-12	ALL
	14		W0080	0510	22		32-31-12	ALL
	15		W0080	5531	24		21-27-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40698J	**J024-00/ /**		**RCPT- (continued)**				**ALL**
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W0080	5559	22		21-25-11	ALL
33		W0080	5562	22		21-25-11	ALL
34		W0080	5599	24		21-43-21	ALL
35		W0080	5578	24		21-43-21	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W0080	0049	22		46-13-11	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40698J		**J024-00/ /**		**RCPT- (continued)**				**ALL**
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W0080	6115	22		44-21-22	ALL
D40698P		**AJ0024/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5100	0601	22		32-31-12	ALL
	2		W5100	0006	22		23-71-01	ALL
	3		W5100	0502	22		31-31-11	ALL
	4		W5100	0503	22		31-31-11	ALL
	5		W5100	0007	22		23-71-01	ALL
	6	UNUSED						ALL
	7		W5100	0518	22		29-23-11	ALL
	8		W5100	6001R	22		SPARE	ALL
	9		W5100	0631	22		32-41-11	ALL
	10		W5100	0602	22		32-31-12	ALL
	11		W5100	0605	22		32-31-12	ALL
	12		W5100	0604	22		32-31-12	ALL
	13		W5100	0606	22		32-31-12	ALL
	14		W5100	0607	22		32-31-12	ALL
	15		W5100	0510	24		21-27-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5100	6002R	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40698P	**AJ0024/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
21		W5100	6003R	22		SPARE	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5100	0003	24		SPARE	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W5100	0012	22		21-25-11	ALL
33		W5100	0013	22		21-25-11	ALL
34		W5100	0014	24		21-43-21	ALL
35		W5100	0015	24		21-43-21	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43		W5100	0024	22		46-13-11	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40698P		**AJ0024/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W5100	0021	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40700J	**J024-00/ /**		**RCPT-**				**ALL**
1		W0080	6511	22		31-31-11	ALL
2		W0080	6503	24		31-31-15	ALL
3		W0080	0505	22		32-31-12	ALL
4		W0080	0017	20		52-71-14	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0080	0053	20		74-11-11	ALL
8		W0080	6505	22		31-31-11	ALL
9		W0080	2607B	20		78-32-61	ALL
10		W0080	6001	20		73-22-11	ALL
11		W0080	0551	22		32-31-12	ALL
12		W0080	0550	22		32-31-12	ALL
13		W0080	2607Z			78-32-61	ALL
14		W0080	2607R	20		78-32-61	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0080	0051	20		74-11-11	ALL
19		W0080	0054	20		74-11-11	ALL
20		W0080	6507	22		31-31-11	ALL
21		W0080	6530	22		31-31-11	ALL
22		W0080	0004	20		52-71-14	ALL
23		W0080	0016	20		52-71-14	ALL
24		W0080	0512	22		32-31-12	ALL
25		W0080	0007	20		52-71-14	ALL
26		W0080	0010	20		52-71-14	ALL
27		W0080	0021	20		52-71-14	ALL
28		W0080	6552	20		44-21-22	ALL
29		W0080	0501	22		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40700J		**J024-00/ /**		**RCPT- (continued)**				**ALL**
	30		W0080	5626	20		21-43-21	ALL
	31		W0080	5627	20		21-43-21	ALL
D40700P		**AJ0024/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5158	0503	22		31-31-11	ALL
	2		W5158	0504	22		31-31-15	ALL
	3		W5158	0601	22		32-31-12	ALL
	4		W5158	0012	20		52-71-14	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5158	6016	20		74-11-11	ALL
	8		W5158	0684	22		31-31-11	ALL
	9		W5158	2501B	20		78-32-61	ALL
	10		W5158	0692	20		73-22-11	ALL
	11		W5158	0219	22		32-31-12	ALL
	12		W5158	0218	22		32-31-12	ALL
	13		W5158	2501Z			78-32-61	ALL
	14		W5158	2501R	20		78-32-61	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W5158	0070	20		74-11-11	ALL
	19		W5158	0069	20		74-11-11	ALL
	20		W5158	0697	22		31-31-11	ALL
	21		W5158	0696	22		31-31-11	ALL
	22		W5158	0010	20		52-71-14	ALL
	23		W5158	0011	20		52-71-14	ALL
	24		W5158	0604	22		32-31-12	ALL
	25		W5158	0013	20		52-71-14	ALL
	26		W5158	0014	20		52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40700P	**AJ0024/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
27		W5158	0530	20		52-71-14	ALL
28		W5158	0040	20		44-21-22	ALL
29		W5158	0713	22		27-62-11	ALL
30		W5158	0133	22		21-27-51	ALL
31		W5158	0132	22		21-27-51	ALL
D40702J	**J024-00/ /**		**RCPT-**				**ALL**
1		W0080	0519	22		32-44-11	ALL
2		W0080	0520	22		32-44-11	ALL
3		W0080	0521	22		32-44-11	ALL
4		W0080	0523	22		32-44-11	ALL
5		W0080	0517	22		32-41-11	ALL
6		W0080	0518	22		32-41-11	ALL
7	UNUSED						ALL
8		W0080	6009	24		73-22-31	ALL
9		W0080	0506	22		32-31-12	ALL
10		W0080	0507	22		32-31-12	ALL
11		W0080	0508	22		32-31-12	ALL
12		W0080	0510	22		32-31-12	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0080	5576	24		21-43-21	ALL
17		W0080	5528	24		21-43-21	ALL
18		W0080	6114	22		44-21-22	ALL
19		W0080	5622	24		36-11-22	ALL
20		W0080	0002	20		52-71-14	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40702J		**J024-00/ /**		**RCPT- (continued)**				**ALL**
	24		W0080	0513	22		32-31-12	ALL
	25	UNUSED						ALL
	26		W0080	0550	22		32-31-12	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0080	5620	24		21-43-21	ALL
	31	UNUSED						ALL
D40702P		**AJ0024/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5158	0521	22		32-44-11	ALL
	2		W5158	0522	22		32-44-11	ALL
	3		W5158	0523	22		32-44-11	ALL
	4		W5158	0524	22		32-44-11	ALL
	5		W5158	0610	22		32-41-11	ALL
	6		W5158	0611	22		32-41-11	ALL
	7	UNUSED						ALL
	8		W5158	6005	24		73-22-31	ALL
	9		W5158	0581	22		32-31-12	ALL
	10		W5158	0584	22		32-31-12	ALL
	11		W5158	0587	22		32-31-12	ALL
	12		W5158	0588	22		32-31-12	ALL
	13	UNUSED						ALL
	14		W5158	0546	22		SPARE	ALL
	15		W5158	0547	22		SPARE	ALL
	16		W5158	0552	22		21-43-21	ALL
	17		W5158	0551	22		21-43-21	ALL
	18		W5158	0512	22		44-21-22	ALL
	19		W5158	0076	24		36-11-22	ALL
	20		W5158	0009	20		52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40702P	**AJ0024/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
21	UNUSED						ALL
22		W5158	0693	20		SPARE	ALL
23	UNUSED						ALL
24		W5158	0685	22		32-31-12	ALL
25	UNUSED						ALL
26		W5158	0653	22		32-31-12	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5158	1104	24		21-51-22	ALL
31	UNUSED						ALL
D40704J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0066	6087	22		30-11-11	ALL
A02		W0066	0071	22		31-53-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0066	2016B	24		73-21-11	ALL
A10		W0066	2016R	24		73-21-11	ALL
B01		W0066	0203	22		32-64-21	ALL
B02		W0066	0204	22		32-64-21	ALL
B03		W0066	0224	22		34-41-11	ALL
B04	UNUSED						ALL
B05		W0066	2017R	24		73-24-12	ALL
B06		W0066	2017B	24		73-24-12	ALL
B07		W0066	2018R	24		73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40704J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B08		W0066	2018B	24		73-24-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	2016Z			73-21-11	ALL
	PERG	1F	W0066	2017Z			73-24-12	ALL
	PERG	1F	W0066	2018Z			73-24-21	ALL
D40704P		**AJ0046B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6162	6087	22		30-11-11	ALL
	A02		W6162	0526	22		31-53-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6162	2606B	24		73-21-11	ALL
	A10		W6162	2606R	24		73-21-11	ALL
	B01		W6162	0557	22		32-64-21	ALL
	B02		W6162	0558	22		32-64-21	ALL
	B03		W6162	0500	22		34-41-11	ALL
	B04	UNUSED						ALL
	B05		W6162	2603R	24		73-24-12	ALL
	B06		W6162	2603B	24		73-24-12	ALL
	B07		W6162	2602R	24		73-24-21	ALL
	B08		W6162	2602B	24		73-24-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6162	2602Z			73-24-21	ALL
	PERG	1F	W6162	2603Z			73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40704P	**AJ0046B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W6162	2606Z			73-21-11	ALL
D40706J	**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0088	0411	22		27-61-42	ALL
A02		W0088	0412	22		27-61-42	ALL
A03		W0088	0413	22		27-61-42	ALL
A04		W0088	0215	24		31-35-01	ALL
A05		W0088	0216	24		31-35-01	ALL
A06	UNUSED						ALL
A07		W0088	2020B	22		31-31-14	ALL
A08		W0088	2018R	22		31-32-15	ALL
A09		W0088	0237	22		34-21-16	ALL
A10		W0088	2019R	22		31-32-15	ALL
B01		W0088	0238	22		31-32-15	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W0088	3001R	22		31-31-14	ALL
B05		W0088	3001B	22		31-31-14	ALL
B06		W0088	3001Y	22		31-31-14	ALL
B07		W0088	2020R	22		31-31-14	ALL
B08		W0088	2018B	22		31-32-15	ALL
B09	UNUSED						ALL
B10		W0088	2019B	22		31-32-15	ALL
PERG	1F	W0088	2018Z			31-32-15	ALL
PERG	1F	W0088	2019Z			31-32-15	ALL
D40706P	**J048-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5461	0019	22		27-61-42	ALL
A02		W5461	0020	22		27-61-42	ALL
A03		W5461	0021	22		27-61-42	ALL
A04		W5461	0001	24		31-35-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40706P		**J048-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05		W5461	0003	24		31-35-01	ALL
	A06	UNUSED						ALL
	A07		W5461	2501B	22		31-31-14	ALL
	A08		W5461	2106R	24		31-32-15	ALL
	A09		W5461	0037	22		34-21-16	ALL
	A10		W5461	2104R	22		31-32-15	ALL
	B01		W5461	0006	22		31-32-15	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5461	3709R	22		31-31-14	ALL
	B05		W5461	3709B	22		31-31-14	ALL
	B06		W5461	3709Y	22		31-31-14	ALL
	B07		W5461	2501R	22		31-31-14	ALL
	B08		W5461	2106B	24		31-32-15	ALL
	B09	UNUSED						ALL
	B10		W5461	2104B	22		31-32-15	ALL
	PERG	1F	W5461	2104Z			31-32-15	ALL
	PERG	1F	W5461	2106Z			31-32-15	ALL
D40708J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	2011R	24		23-42-14	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0044	2012R	24		23-42-14	ALL
	5		W0044	0988	20		44-21-10	ALL
	6		W0044	2011B	24		23-42-14	ALL
	7		W0044	0883	20		44-35-20	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W0044	6136	20		44-35-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40708J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
11		W0044	2012B	24		23-42-14	ALL
12		W0044	6101	24		23-42-14	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0044	0968	20		44-21-10	ALL
20	UNUSED						ALL
21		W0044	FRAC			23-42-14	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
		W0044	2011Z			23-42-14	ALL
		W0044	2012Z			23-42-14	ALL
		W0044	FRAC			23-42-14	ALL
D40708P	**P006-00/ /**		**PLUG-**				**ALL**
1		W6212	2001R	24		23-42-14	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W6212	2002R	24		23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40708P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	5		W6212	0004	20		44-21-10	ALL
	6		W6212	2001B	24		23-42-14	ALL
	7		W6212	0012	20		44-35-20	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6212	0023	20		44-35-20	ALL
	11		W6212	2002B	24		23-42-14	ALL
	12		W6212	0007	24		23-42-14	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W6212	0003	20		44-21-10	ALL
	20	UNUSED						ALL
	21		W6212	FRAA			23-42-14	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
			W6212	2001Z			23-42-14	ALL
			W6212	2002Z			23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40708P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
		W6212	FRAA			23-42-14	ALL
D40710J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	2156R	24		34-61-15	ALL
A02		W0321	2220R	24		31-35-09	ALL
A03		W0321	2313R	24		27-61-47	ALL
A04		W0321	2374R	24		34-21-14	ALL
A05		W0321	2233R	24		31-35-09	ALL
A06		W0321	2314R	24		27-61-47	ALL
A07		W0321	2289R	24		34-51-11	ALL
A08		W0321	2288R	24		34-51-11	ALL
A09		W0321	2234R	24		31-35-09	ALL
A10		W0321	2234B	24		31-35-09	ALL
B01		W0321	2156B	24		34-61-15	ALL
B02		W0321	2220B	24		31-35-09	ALL
B03		W0321	2313B	24		27-61-47	ALL
B04		W0321	2374B	24		34-21-14	ALL
B05		W0321	2233B	24		31-35-09	ALL
B06		W0321	2314B	24		27-61-47	ALL
B07		W0321	2289B	24		34-51-11	ALL
B08		W0321	2288B	24		34-51-11	ALL
B09		W0321	2229B	24		34-57-11	ALL
B10		W0321	2229R	24		34-57-11	ALL
PERG	1F	W0321	2156Z			34-61-15	ALL
PERG	1F	W0321	2220Z			31-35-09	ALL
PERG	1F	W0321	2229Z			34-57-11	ALL
PERG	1F	W0321	2233Z			31-35-09	ALL
PERG	1F	W0321	2234Z			31-35-09	ALL
PERG	1F	W0321	2288Z			34-51-11	ALL
PERG	1F	W0321	2289Z			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40710J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0321	2313Z			27-61-47	ALL
	PERG	1F	W0321	2314Z			27-61-47	ALL
	PERG	1F	W0321	2374Z			34-21-14	ALL
D40710P		**E003-02/ /**		**PLUG**				**ALL**
	A01		W5047	2506R	24		34-61-15	ALL
	A02		W5047	2503R	24		31-35-09	ALL
	A03		W5047	2512R	24		27-61-47	ALL
	A04		W5047	2509R	24		34-21-14	ALL
	A05		W5047	2530R	24		31-35-09	ALL
	A06		W5047	2513R	24		27-61-47	ALL
	A07		W5047	2510R	24		34-51-11	ALL
	A08		W5047	2511R	24		34-51-11	ALL
	A09		W5047	2531R	24		31-35-09	ALL
	A10		W5047	2531B	24		31-35-09	ALL
	B01		W5047	2506B	24		34-61-15	ALL
	B02		W5047	2503B	24		31-35-09	ALL
	B03		W5047	2512B	24		27-61-47	ALL
	B04		W5047	2509B	24		34-21-14	ALL
	B05		W5047	2530B	24		31-35-09	ALL
	B06		W5047	2513B	24		27-61-47	ALL
	B07		W5047	2510B	24		34-51-11	ALL
	B08		W5047	2511B	24		34-51-11	ALL
	B09		W5047	2505B	24		34-57-11	ALL
	B10		W5047	2505R	24		34-57-11	ALL
	PERG	1F	W5047	2503Z			31-35-09	ALL
	PERG	1F	W5047	2505Z			34-57-11	ALL
	PERG	1F	W5047	2506Z			34-61-15	ALL
	PERG	1F	W5047	2509Z			34-21-14	ALL
	PERG	1F	W5047	2510Z			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40710P	**E003-02/ /**		**PLUG (continued)**				**ALL**
PERG	1F	W5047	2511Z			34-51-11	ALL
PERG	1F	W5047	2512Z			27-61-47	ALL
PERG	1F	W5047	2513Z			27-61-47	ALL
PERG	1F	W5047	2530Z			31-35-09	ALL
PERG	1F	W5047	2531Z			31-35-09	ALL
D40712J	**E004-02/ /**		**RCPT**				**ALL**
1	UNUSED						ALL
2		W0422	0236	20		21-31-23	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0422	0237	24		21-31-23	ALL
11		W0422	0075	22		28-44-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0422	0076	20		28-44-11	ALL
20		W0422	0074	18		28-44-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40712J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	24	UNUSED						ALL
	25	UNUSED						ALL
D40712P		**E004-02/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W6412	0203	20		21-31-23	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W6412	0204	24		21-31-23	ALL
	11		W6412	6014	22		28-44-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W6412	6025	20		28-44-11	ALL
	20		W6412	6016	18		28-44-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40714J	**E004-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0422	0241	22		28-43-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W0422	0174	20		28-22-11	ALL
A07		W0422	0175	20		28-22-11	ALL
A08		W0422	0176	20		28-22-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0422	0178	22		28-43-11	ALL
B02	UNUSED						ALL
B03		W0422	0236	20		21-31-23	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0422	0237	24		21-31-23	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G		W0422	3202R	18		28-23-11	ALL
H		W0422	3202Y	18		28-23-11	ALL
J		W0422	3202B	18		28-23-11	ALL
K	UNUSED						ALL
D40714P	**E004-02/ /**		**PLUG**				**ALL**
A01		W6588	1303	22		28-43-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40714P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W6588	1305	20		28-22-11	ALL
	A07		W6588	1306	20		28-22-11	ALL
	A08		W6588	1309	20		28-22-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6588	1304	22		28-43-11	ALL
	B02	UNUSED						ALL
	B03		W6588	0007	20		21-31-23	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W6588	0008	24		21-31-23	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W6588	3602R	18		28-23-11	ALL
	H		W6588	3602Y	18		28-23-11	ALL
	J		W6588	3602B	18		28-23-11	ALL
	K	UNUSED						ALL
	DED		W6588	1303Z			28-43-11	ALL
	PERG	1F	W6588	1304Z			28-43-11	ALL
	PERG	1F	W6588	1305Z			28-22-11	ALL
	PERG	1F	W6588	1306Z			28-22-11	ALL
	PERG	1F	W6588	1309Z			28-22-11	ALL
D40718J		**E002-01/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE**				**ALL**
	A01		W0212	0008	22		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40718J	**E002-01/ /**		**RCPT- CONDUCTIVE FOR P-SIDE, SHIELD WIRE (continued)**				**ALL**
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W0212	6001	20		28-21-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W0212	0011	18		24-11-11	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
D40718P	**E002-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5164	0501	22		29-11-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40718P		**E002-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05		W5164	2602B	20		SPARE	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5164	2602R	20		SPARE	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W5164	0301	20		28-21-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5164	1101	18		24-11-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5164	1101Z			24-11-11	ALL
	PERG	1F	W5164	2602Z			SPARE	ALL
D40721J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40721J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07		W0088	2020B	22		31-31-14	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0088	3001R	22		31-31-14	ALL
	B05		W0088	3001B	22		31-31-14	ALL
	B06		W0088	3001Y	22		31-31-14	ALL
	B07		W0088	2020R	22		31-31-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40721P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5369	2176B	22		31-31-14	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40721P		**J048-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04		W5369	3027R	22		31-31-14	ALL
	B05		W5369	3027B	22		31-31-14	ALL
	B06		W5369	3027Y	22		31-31-14	ALL
	B07		W5369	2176R	22		31-31-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40723J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0411	22		27-61-42	ALL
	A02		W0088	0412	22		27-61-42	ALL
	A03		W0088	0413	22		27-61-42	ALL
	A04		W0088	0215	24		31-35-01	ALL
	A05		W0088	0216	24		31-35-01	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0088	0237	22		34-21-16	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0088	0238	22		31-32-15	ALL
	B02		W0088	2009R	22		31-32-15	ALL
	B03		W0088	2009B	22		31-32-15	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0088	2009Z			31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40723P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2597	0029	22		27-61-42	ALL
	A02		W2597	0030	22		27-61-42	ALL
	A03		W2597	0031	22		27-61-42	ALL
	A04		W2597	0011	24		31-35-01	ALL
	A05		W2597	0012	24		31-35-01	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W2597	0005	22		34-21-16	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2597	0016	22		31-32-15	ALL
	B02		W2597	2501R	22		31-32-15	ALL
	B03		W2597	2501B	22		31-32-15	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2597	2501Z			31-32-15	ALL
D40724J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40724J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W0220	2031B	24		73-24-11	ALL
	A10		W0220	0078	24		21-51-12	ALL
	A11		W0220	0063	24		21-31-24	ALL
	A12		W0220	0070	24		21-31-24	ALL
	A13	UNUSED						ALL
	A14		W0220	2033B	24		73-24-11	ALL
	A15		W0220	0205	22		21-25-11	ALL
	A16		W0220	0210	22		21-25-11	ALL
	A17		W0220	0246	20		49-62-11	ALL
	A18		W0220	0388R	20		26-21-11	ALL
	A19		W0220	0389R	20		26-21-11	ALL
	A20		W0220	0390R	20		26-21-11	ALL
	B01		W0220	0251	24		32-31-15	ALL
	B02		W0220	0252	22		32-31-15	ALL
	B03		W0220	0253	24		32-31-15	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0220	2031R	24		73-24-11	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0220	2033R	24		73-24-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40724J	**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B17	UNUSED						ALL
B18		W0220	0393R	20		26-21-11	ALL
B19		W0220	0392R	20		26-21-11	ALL
B20		W0220	0391R	20		26-21-11	ALL
PERG	1F	W0220	2031Z			73-24-11	ALL
PERG	1F	W0220	2033Z			73-24-11	ALL
D40724P	**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W5156	2613B	24		73-24-11	ALL
A10		W5156	0038	24		21-51-12	ALL
A11		W5156	0206	24		21-31-24	ALL
A12		W5156	0205	24		21-31-24	ALL
A13	UNUSED						ALL
A14		W5156	2610B	24		73-24-11	ALL
A15		W5156	5529	22		21-25-11	ALL
A16		W5156	5530	22		21-25-11	ALL
A17		W5156	0670	20		49-62-11	ALL
A18		W5156	6018R	20		26-21-11	ALL
A19		W5156	6019R	20		26-21-11	ALL
A20		W5156	6020R	20		26-21-11	ALL
B01		W5156	0709	22		32-31-15	ALL
B02		W5156	0599	22		32-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40724P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B03		W5156	0712	22		32-31-15	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5156	2613R	24		73-24-11	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W5156	2610R	24		73-24-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5156	6025R	22		SPARE	ALL
	B18		W5156	6021R	20		26-21-11	ALL
	B19		W5156	6022R	20		26-21-11	ALL
	B20		W5156	6023R	20		26-21-11	ALL
	PERG	1F	W5156	2610Z			73-24-11	ALL
	PERG	1F	W5156	2613Z			73-24-11	ALL
D40728J		**AB0405B/ /**		**RCPT**				**ALL**
	1		W6170	2006R	20		36-11-23	ALL
	2		W6170	2006B	20		36-11-23	ALL
	3	UNUSED						ALL
	4		W6170	2602B	24		77-12-11	ALL
	5		W6170	2602R	24		77-12-11	ALL
	6		W6170	2009R	20		36-11-23	ALL
	7		W6170	2009B	20		36-11-23	ALL
	8		W6170	2005R	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40728J	**AB0405B/ /**		**RCPT (continued)**				**ALL**
9		W6170	2005B	20		36-11-23	ALL
10		W6170	2007R	20		36-11-23	ALL
11		W6170	2007B	20		36-11-23	ALL
12		W6170	3601B	24		79-31-11	ALL
13		W6170	3601R	24		79-31-11	ALL
14		W6170	3601Y	24		79-31-11	ALL
15		W6170	2008R	20		36-11-23	ALL
16		W6170	2008B	20		36-11-23	ALL
17		W6170	2012R	20		36-11-23	ALL
18		W6170	2012B	20		36-11-23	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W6170	1304R	20		26-11-21	ALL
23		W6170	1305R	20		26-11-21	ALL
24	UNUSED						ALL
S/R		W6170	1304Z			26-11-21	ALL
S/R		W6170	1305Z			26-11-21	ALL
S/R		W6170	2005Z			36-11-23	ALL
S/R		W6170	2006Z			36-11-23	ALL
S/R		W6170	2007Z			36-11-23	ALL
S/R		W6170	2008Z			36-11-23	ALL
S/R		W6170	2009Z			36-11-23	ALL
S/R		W6170	2012Z			36-11-23	ALL
S/R		W6170	2602Z			77-12-11	ALL
S/R		W6170	3601Z			79-31-11	ALL
D40728P	**AB0405B/ /**		**PLUG**				**ALL**
1		W4170	2515R	20		36-11-23	ALL
2		W4170	2515B	20		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40728P		**AB0405B/ /**		**PLUG (continued)**				**ALL**
	3	UNUSED						ALL
	4		W4170	2608B	24		77-12-11	ALL
	5		W4170	2608R	24		77-12-11	ALL
	6		W4170	2516R	20		36-11-23	ALL
	7		W4170	2516B	20		36-11-23	ALL
	8		W4170	2517R	20		36-11-23	ALL
	9		W4170	2517B	20		36-11-23	ALL
	10		W4170	2518R	20		36-11-23	ALL
	11		W4170	2518B	20		36-11-23	ALL
	12		W4170	3601B	24		79-31-11	ALL
	13		W4170	3601R	24		79-31-11	ALL
	14		W4170	3601Y	24		79-31-11	ALL
	15		W4170	2519R	20		36-11-23	ALL
	16		W4170	2519B	20		36-11-23	ALL
	17		W4170	2520R	20		36-11-23	ALL
	18		W4170	2520B	20		36-11-23	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W4170	1301R	20		26-11-21	ALL
	23		W4170	1302R	20		26-11-21	ALL
	24	UNUSED						ALL
	S/R		W4170	1301Z			26-11-21	ALL
	S/R		W4170	1302Z			26-11-21	ALL
	S/R		W4170	2515Z			36-11-23	ALL
	S/R		W4170	2516Z			36-11-23	ALL
	S/R		W4170	2517Z			36-11-23	ALL
	S/R		W4170	2518Z			36-11-23	ALL
	S/R		W4170	2519Z			36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40728P	**AB0405B/ /**		**PLUG (continued)**				**ALL**
S/R		W4170	2520Z			36-11-23	ALL
S/R		W4170	2608Z			77-12-11	ALL
S/R		W4170	3601Z			79-31-11	ALL
D40730J	**AB0405B/ /**		**RCPT**				**ALL**
1		W6172	2605Z			73-24-12	ALL
2		W6172	2606Z			73-24-21	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W6172	2605B	24		73-24-12	ALL
6		W6172	2605R	24		73-24-12	ALL
7		W6172	2606B	24		73-24-21	ALL
8		W6172	2606R	24		73-24-21	ALL
9		W6172	2612B	20		SPARE	ALL
10		W6172	2612R	20		SPARE	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40730P		**AB0405B/ /**		**PLUG**				**ALL**
	1		W4170	2603Z			73-24-12	ALL
	2		W4170	2604Z			73-24-21	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W4170	2603B	24		73-24-12	ALL
	6		W4170	2603R	24		73-24-12	ALL
	7		W4170	2604B	24		73-24-21	ALL
	8		W4170	2604R	24		73-24-21	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D40732J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0313	2550B	24		73-24-12	ALL
	A04		W0313	2541B	24		73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40732J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0313	2565B	24		77-12-11	ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0313	3501B	24		79-31-11	ALL
A14		W0313	3501Y	24		79-31-11	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W0313	1509R	20		26-11-21	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0313	2550R	24		73-24-12	ALL
B04		W0313	2541R	24		73-24-21	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0313	2565R	24		77-12-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W0313	3501R	24		79-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40732J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W0313	1510R	20		26-11-21	ALL
	B20	UNUSED						ALL
	DED		W0313	1509Z			26-11-21	ALL
	DED		W0313	1510Z			26-11-21	ALL
	PERG	1F	W0313	2541Z			73-24-21	ALL
	PERG	1F	W0313	2550Z			73-24-12	ALL
	PERG	1F	W0313	2565Z			77-12-11	ALL
	PERG	1F	W0313	3501Z			79-31-11	ALL
D40732P		**E003-01/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W4170	2603B	24		73-24-12	ALL
	A04		W4170	2604B	24		73-24-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W4170	2608B	24		77-12-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W4170	3601B	24		79-31-11	ALL
	A14		W4170	3601Y	24		79-31-11	ALL
	A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40732P	**E003-01/ /**		**PLUG (continued)**				**ALL**
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W4170	1302R	20		26-11-21	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W4170	2603R	24		73-24-12	ALL
B04		W4170	2604R	24		73-24-21	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W4170	2608R	24		77-12-11	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W4170	3601R	24		79-31-11	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W4170	1301R	20		26-11-21	ALL
B20	UNUSED						ALL
PERG	1F	W4170	1301Z			26-11-21	ALL
PERG	1F	W4170	1302Z			26-11-21	ALL
PERG	1F	W4170	2603Z			73-24-12	ALL
PERG	1F	W4170	2604Z			73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40732P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W4170	2608Z			77-12-11	ALL
	PERG	1F	W4170	3601Z			79-31-11	ALL
D40734J		**AB0420A/ /**		**RCPT**				**ALL**
	1		W5170	2006R	20		36-11-13	ALL
	2		W5170	2006B	20		36-11-13	ALL
	3		W5170	2009R	20		36-11-13	ALL
	4		W5170	2009B	20		36-11-13	ALL
	5		W5170	2005R	20		36-11-13	ALL
	6		W5170	2005B	20		36-11-13	ALL
	7		W5170	2007R	20		36-11-13	ALL
	8		W5170	2007B	20		36-11-13	ALL
	9		W5170	2008R	20		36-11-13	ALL
	10		W5170	2008B	20		36-11-13	ALL
	11		W5170	2012R	20		36-11-13	ALL
	12		W5170	3601B	24		79-31-11	ALL
	13		W5170	3601R	24		79-31-11	ALL
	14		W5170	3601Y	24		79-31-11	ALL
	15		W5170	2605R	24		77-12-11	ALL
	16		W5170	2605B	24		77-12-11	ALL
	17	UNUSED						ALL
	18		W5170	0501	20		29-31-11	ALL
	19		W5170	0502	20		29-31-11	ALL
	20		W5170	0503	20		29-31-11	ALL
	21	UNUSED						ALL
	22		W5170	6002R	20		26-11-11	ALL
	23		W5170	6001R	20		26-11-11	ALL
	24		W5170	2012B	20		36-11-13	ALL
	S/R		W5170	2005Z			36-11-13	ALL
	S/R		W5170	2006Z			36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40734J		**AB0420A/ /**		**RCPT (continued)**				**ALL**
	S/R		W5170	2007Z			36-11-13	ALL
	S/R		W5170	2008Z			36-11-13	ALL
	S/R		W5170	2009Z			36-11-13	ALL
	S/R		W5170	2012Z			36-11-13	ALL
	S/R		W5170	2605Z			77-12-11	ALL
	S/R		W5170	3601Z			79-31-11	ALL
D40734P		**AB0420A/ /**		**PLUG**				**ALL**
	1		W3170	2504R	20		36-11-13	ALL
	2		W3170	2504B	20		36-11-13	ALL
	3		W3170	2505R	20		36-11-13	ALL
	4		W3170	2505B	20		36-11-13	ALL
	5		W3170	2506R	20		36-11-13	ALL
	6		W3170	2506B	20		36-11-13	ALL
	7		W3170	2507R	20		36-11-13	ALL
	8		W3170	2507B	20		36-11-13	ALL
	9		W3170	2508R	20		36-11-13	ALL
	10		W3170	2508B	20		36-11-13	ALL
	11		W3170	2509R	20		36-11-13	ALL
	12		W3170	3601B	24		79-31-11	ALL
	13		W3170	3601R	24		79-31-11	ALL
	14		W3170	3601Y	24		79-31-11	ALL
	15		W3170	2605R	24		77-12-11	ALL
	16		W3170	2605B	24		77-12-11	ALL
	17	UNUSED						ALL
	18		W3170	0501	24		29-31-11	ALL
	19		W3170	0502	24		29-31-11	ALL
	20		W3170	0503	24		29-31-11	ALL
	21	UNUSED						ALL
	22		W3170	1302R	20		26-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40734P		**AB0420A/ /**		**PLUG (continued)**				**ALL**
	23		W3170	1301R	20		26-11-11	ALL
	24		W3170	2509B	20		36-11-13	ALL
	S/R		W3170	1301Z			26-11-11	ALL
	S/R		W3170	1302Z			26-11-11	ALL
	S/R		W3170	2504Z			36-11-13	ALL
	S/R		W3170	2505Z			36-11-13	ALL
	S/R		W3170	2506Z			36-11-13	ALL
	S/R		W3170	2507Z			36-11-13	ALL
	S/R		W3170	2508Z			36-11-13	ALL
	S/R		W3170	2509Z			36-11-13	ALL
	S/R		W3170	2605Z			77-12-11	ALL
	S/R		W3170	3601Z			79-31-11	ALL
D40736J		**AB0420A/ /**		**RCPT**				**ALL**
	1		W5172	2604B	20		SPARE	ALL
	2		W5172	2604R	20		SPARE	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5172	2608Z			73-24-11	ALL
	7	UNUSED						ALL
	8		W5172	2614Z			73-24-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5172	2608B	24		73-24-11	ALL
	12		W5172	2608R	24		73-24-11	ALL
	13		W5172	2614B	24		73-24-12	ALL
	14		W5172	2614R	24		73-24-12	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40736J	**AB0420A/ /**		**RCPT (continued)**				**ALL**
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
S/R		W5172	2604Z			SPARE	ALL
D40736P	**AB0420A/ /**		**PLUG**				**ALL**
1		W3170	2606B	20		SPARE	ALL
2		W3170	2606R	20		SPARE	ALL
3	UNUSED						ALL
4		W3170	2607B	20		SPARE	ALL
5		W3170	2607R	20		SPARE	ALL
6		W3170	2610Z			73-24-11	ALL
7	UNUSED						ALL
8		W3170	2611Z			73-24-12	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W3170	2610B	24		73-24-11	ALL
12		W3170	2610R	24		73-24-11	ALL
13		W3170	2611B	24		73-24-12	ALL
14		W3170	2611R	24		73-24-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40736P		**AB0420A/ /**		**PLUG (continued)**				**ALL**
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	S/R		W3170	2606Z			SPARE	ALL
	S/R		W3170	2607Z			SPARE	ALL
D40738J		**P007-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0001	0178	20		31-52-11	ALL
	A02		W0001	0179	20		31-52-11	ALL
	A03		W0001	0180	20		31-52-11	ALL
	A04		W0001	0174	20		31-52-11	ALL
	A05		W0001	0175	20		31-52-11	ALL
	A06		W0001	0272	20		33-14-11	ALL
	A07		W0001	0177	20		31-52-11	ALL
	A08		W0001	0181	20		31-52-25	ALL
	A09		W0001	0186	20		31-52-71	ALL
	A10		W0001	0184	20		31-52-41	ALL
	A11		W0001	0182	20		31-52-31	ALL
	A12		W0001	0183	20		31-52-35	ALL
	A13		W0001	0185	20		31-52-45	ALL
	A14		W0001	1014R	22		26-11-21	ALL
	A15		W0001	1015R	22		26-11-21	ALL
	A16		W0001	1753	24		31-65-23	ALL
	A17		W0001	1752	24		31-65-13	ALL
	A18	UNUSED						ALL
	A19		W0001	0330	24		23-51-11	ALL
	A20		W0001	0331	24		23-51-11	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40738J	**P007-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B02		W0001	3001R	24		31-65-11	ALL
B03		W0001	3001B	24		31-65-11	ALL
B04		W0001	3001Y	24		31-65-11	ALL
B05		W0001	2001R	24		31-65-11	ALL
B06		W0001	2001B	24		31-65-11	ALL
B07		W0001	1249	20		33-18-51	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0001	0176	20		31-52-11	ALL
B13		W0001	0271	20		33-14-11	ALL
B14		W0001	1016R	22		26-11-21	ALL
B15		W0001	0269	20		33-14-11	ALL
B16		W0001	0753	24		31-65-23	ALL
B17		W0001	0752	24		31-65-13	ALL
B18		W0001	0270	20		33-14-11	ALL
B19		W0001	0325	20		33-11-31	ALL
B20		W0001	0326	20		33-11-31	ALL
PERG	1F	W0001	1014Z			26-11-21	ALL
PERG	1F	W0001	1015Z			26-11-21	ALL
PERG	1F	W0001	1016Z			26-11-21	ALL
PERG	1F	W0001	1249Z			33-18-51	ALL
PERG	1F	W0001	1752Z			31-65-13	ALL
PERG	1F	W0001	1753Z			31-65-23	ALL
PERG	1F	W0001	2001Z			31-65-11	ALL
PERG	1F	W0001	3001Z			31-65-11	ALL
D40738P	**P007-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W0104	5501	20		31-52-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40738P		**P007-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A02		W0104	5502	20		31-52-11	ALL
	A03		W0104	5503	20		31-52-11	ALL
	A04		W0104	1001	20		31-52-11	ALL
	A05		W0104	1004	20		31-52-11	ALL
	A06		W0104	5519	20		33-14-11	ALL
	A07		W0104	1003	20		31-52-11	ALL
	A08		W0104	5508	20		31-52-25	ALL
	A09		W0104	5509	20		31-52-71	ALL
	A10		W0104	5510	20		31-52-41	ALL
	A11		W0104	5511	20		31-52-31	ALL
	A12		W0104	5512	20		31-52-35	ALL
	A13		W0104	5513	20		31-52-45	ALL
	A14		W0104	5514R	22		26-11-21	ALL
	A15		W0104	5515R	22		26-11-21	ALL
	A16		W0104	2752R	24		31-65-23	ALL
	A17		W0104	2751R	24		31-65-13	ALL
	A18	UNUSED						ALL
	A19		W0104	0001	24		23-51-11	ALL
	A20		W0104	0002	24		23-51-11	ALL
	B01	UNUSED						ALL
	B02		W0104	A-AA			31-65-11	ALL
	B03		W0104	A-AB			31-65-11	ALL
	B04		W0104	A-AC			31-65-11	ALL
	B05		W0104	A-AD			31-65-11	ALL
	B06		W0104	A-AE			31-65-11	ALL
	B07		W0104	5521R	20		33-18-51	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40738P		**P007-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B11	UNUSED						ALL
	B12		W0104	1002	20		31-52-11	ALL
	B13		W0104	5520	20		33-14-11	ALL
	B14		W0104	5516R	22		26-11-21	ALL
	B15		W0104	5518	20		33-14-11	ALL
	B16		W0104	2752B	24		31-65-23	ALL
	B17		W0104	2751B	24		31-65-13	ALL
	B18		W0104	5517	20		33-14-11	ALL
	B19		W0104	5527	20		33-11-31	ALL
	B20		W0104	5528	20		33-11-31	ALL
	DED		W0104	1001Z			31-52-11	ALL
	DED		W0104	1002Z			31-52-11	ALL
	DED		W0104	1003Z			31-52-11	ALL
	DED		W0104	1004Z			31-52-11	ALL
D40740J		**P007-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0003	0653	20		31-52-11	ALL
	A02		W0003	0652	20		31-52-11	ALL
	A03		W0003	0651	20		31-52-11	ALL
	A04		W0003	0648	20		31-52-11	ALL
	A05		W0001	0175	20		31-52-11	ALL
	A06	UNUSED						ALL
	A07		W0003	0650	20		31-52-11	ALL
	A08		W0003	0657	20		31-52-55	ALL
	A09		W0003	0655	20		31-52-21	ALL
	A10		W0003	0659	20		31-52-65	ALL
	A11		W0003	1752	24		31-65-23	ALL
	A12		W0003	1753	24		31-65-13	ALL
	A13		W0003	0656	20		31-52-51	ALL
	A14		W0003	1514R	22		26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40740J		**P007-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A15		W0003	1515R	22		26-11-21	ALL
	A16		W0003	1516R	22		26-11-21	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W0003	0007	24		23-51-21	ALL
	A20		W0003	0008	24		23-51-21	ALL
	B01		W0003	3501R	24		31-65-21	ALL
	B02		W0003	3501B	24		31-65-21	ALL
	B03	UNUSED						ALL
	B04		W0003	3501Y	24		31-65-21	ALL
	B05		W0003	2501R	24		31-65-21	ALL
	B06		W0003	2501B	24		31-65-21	ALL
	B07		W0003	1706	20		33-18-51	ALL
	B08		W0003	0649	20		31-52-11	ALL
	B09	UNUSED						ALL
	B10		W0003	0658	20		31-52-61	ALL
	B11		W0003	0753	24		31-65-23	ALL
	B12		W0003	0752	24		31-65-13	ALL
	B13		W0003	0660	20		31-52-75	ALL
	B14		W0003	0327	20		33-11-21	ALL
	B15	UNUSED						ALL
	B16		W0001	0277	20		33-14-11	ALL
	B17		W0001	0280	20		33-14-11	ALL
	B18		W0001	0278	20		33-14-11	ALL
	B19		W0001	0279	20		33-14-11	ALL
	B20		W0003	0328	20		33-11-21	ALL
	PERG	1F	W0003	1514Z			26-11-21	ALL
	PERG	1F	W0003	1515Z			26-11-21	ALL
	PERG	1F	W0003	1516Z			26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40740J	**P007-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0003	1706Z			33-18-51	ALL
PERG	1F	W0003	1752Z			31-65-23	ALL
PERG	1F	W0003	1753Z			31-65-13	ALL
PERG	1F	W0003	2501Z			31-65-21	ALL
PERG	1F	W0003	3501Z			31-65-21	ALL
D40740P	**P007-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W0204	5501	20		31-52-11	ALL
A02		W0204	5502	20		31-52-11	ALL
A03		W0204	5503	20		31-52-11	ALL
A04		W0204	1001	20		31-52-11	ALL
A05		W0204	1004	20		31-52-11	ALL
A06	UNUSED						ALL
A07		W0204	1003	20		31-52-11	ALL
A08		W0204	5508	20		31-52-55	ALL
A09		W0204	5509	20		31-52-21	ALL
A10		W0204	5510	20		31-52-65	ALL
A11		W0204	2752R	24		31-65-23	ALL
A12		W0204	2751R	24		31-65-13	ALL
A13		W0204	5513	20		31-52-51	ALL
A14		W0204	5514R	22		26-11-21	ALL
A15		W0204	5515R	22		26-11-21	ALL
A16		W0204	5516R	22		26-11-21	ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W0204	0001	24		23-51-21	ALL
A20		W0204	0002	24		23-51-21	ALL
B01		W0204	A-AA			31-65-21	ALL
B02		W0204	A-AB			31-65-21	ALL
B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40740P		**P007-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B04		W0204	A-AC			31-65-21	ALL
	B05		W0204	A-AD			31-65-21	ALL
	B06		W0204	A-AE			31-65-21	ALL
	B07		W0204	5521R	20		33-18-51	ALL
	B08		W0204	1002	20		31-52-11	ALL
	B09	UNUSED						ALL
	B10		W0204	5511	20		31-52-61	ALL
	B11		W0204	2752B	24		31-65-23	ALL
	B12		W0204	2751B	24		31-65-13	ALL
	B13		W0204	5512	20		31-52-75	ALL
	B14		W0204	5527	20		33-11-21	ALL
	B15	UNUSED						ALL
	B16		W0204	5517	20		33-14-11	ALL
	B17		W0204	5518	20		33-14-11	ALL
	B18		W0204	5519	20		33-14-11	ALL
	B19		W0204	5520	20		33-14-11	ALL
	B20		W0204	5528	20		33-11-21	ALL
	DED		W0204	1001Z			31-52-11	ALL
	DED		W0204	1002Z			31-52-11	ALL
	DED		W0204	1003Z			31-52-11	ALL
	DED		W0204	1004Z			31-52-11	ALL
D40744J		**P006-00/ /**		**RCPT-**				**ALL**
	=1	VY	W0044	0093	20		33-14-12	ALL
D40744P		**P006-00/ /**		**PLUG-**				**ALL**
	=1	VG	W0044	A-AA			33-14-12	ALL
D40748J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40748J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0088	0231	24		31-65-15	ALL
	A08		W0088	0233	24		31-65-15	ALL
	A09		W0088	0236	22		23-43-11	ALL
	A10		W0088	0228	22		22-13-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0088	0229	22		22-18-11	ALL
	B06		W0088	0235	22		23-42-11	ALL
	B07		W0088	0232	24		31-65-15	ALL
	B08		W0088	0230	24		31-65-15	ALL
	B09		W0088	0240	22		34-21-11	ALL
	B10	UNUSED						ALL
D40748P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W2035	0026	24		31-65-15	ALL
	A08		W2035	0028	24		31-65-15	ALL
	A09		W2035	0034	22		23-43-11	ALL
	A10		W2035	0042	22		22-13-11	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40748P		**J048-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W2035	0035	22		22-18-11	ALL
	B06		W2035	0033	22		23-42-11	ALL
	B07		W2035	0027	24		31-65-15	ALL
	B08		W2035	0037	24		31-65-15	ALL
	B09		W2035	0001	22		34-21-11	ALL
	B10	UNUSED						ALL
D40750J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0280	22		34-53-31	ALL
	2		W0044	0513	24		32-41-11	ALL
	3		W0044	0417	20		74-11-11	ALL
	4		W0044	6019	22		32-31-12	ALL
	5		W0044	0260	22		32-31-12	ALL
	6	UNUSED						ALL
	7		W0044	0273	22		32-51-11	ALL
	8		W0044	0275	22		32-64-12	ALL
	9		W0044	0709	20		33-18-11	ALL
	10	UNUSED						ALL
	11		W0044	0867	20		44-21-22	ALL
	12		W0044	1010	22		30-31-11	ALL
	13		W0044	0581	24		76-21-21	ALL
	14	UNUSED						ALL
	15		W0044	0934	20		28-23-11	ALL
	16		W0044	0748	20		52-71-14	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0044	0543	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40750J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
20		W0044	6104	22		32-31-12	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0044	6213	20		27-61-49	ALL
24		W0044	1010Z			30-31-11	ALL
25		W0044	6207	20		74-11-11	ALL
26	UNUSED						ALL
27		W0044	0935	20		28-23-11	ALL
28		W0044	0936	20		28-23-11	ALL
29		W0044	0210	22		29-23-11	ALL
30		W0044	0415	20		73-22-11	ALL
31	UNUSED						ALL
D40750P	**P006-00/ /**		**PLUG-**				**ALL**
1		W5158	0691	22		34-53-31	ALL
2		W5158	0686	22		32-41-11	ALL
3		W5158	0070	20		74-11-11	ALL
4		W5158	0086	22		32-31-12	ALL
5		W5158	0685	22		32-31-12	ALL
6	UNUSED						ALL
7		W5158	0536	22		32-51-11	ALL
8		W5158	0589	22		32-64-12	ALL
9		W5158	0687	20		33-18-11	ALL
10		W5158	0707	22		SPARE	ALL
11		W5158	0040	20		44-21-22	ALL
12		W5158	1001	22		30-31-11	ALL
13		W5158	6021	24		76-21-21	ALL
14		W5158	0693	20		SPARE	ALL
15		W5158	0101	20		28-23-11	ALL
16		W5158	0009	20		52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40750P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W5158	0562	24		21-43-21	ALL
	20		W5158	0621	22		32-31-12	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W5158	0714	20		27-61-49	ALL
	24		W5158	1001Z			30-31-11	ALL
	25		W5158	0069	20		74-11-11	ALL
	26	UNUSED						ALL
	27		W5158	0102	20		28-23-11	ALL
	28		W5158	0103	20		28-23-11	ALL
	29		W5158	0113	22		29-23-11	ALL
	30		W5158	0692	20		73-22-11	ALL
	31	UNUSED						ALL
D40751J		**955/302/L008**		**RCPT -**				**ALL**
	1		W3004	0001	22		23-71-01	ALL
	2	UNUSED						ALL
	3		W3004	0003	22		SPARE	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40751J	**955/302/L008**		**RCPT - (continued)**				**ALL**
14	UNUSED						ALL
15	UNUSED						ALL
16		W3004	0002	14		23-71-01	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D40751P	**955/302/L009**		**PLUG**				**ALL**
1		W5433	0020	22		23-71-01	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5433	0021	14		23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40751P		**955/302/L009**		**PLUG (continued)**				**ALL**
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D40758J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0228	22		22-13-11	ALL
	A02		W0088	0229	22		22-18-11	ALL
	A03		W0088	0235	22		23-42-11	ALL
	A04		W0088	0236	22		23-43-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0088	0233	24		31-65-15	ALL
	B02		W0088	0232	24		31-65-15	ALL
	B03		W0088	0231	24		31-65-15	ALL
	B04		W0088	0230	24		31-65-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40758J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
D40758P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5161	0001	22		22-13-11	ALL
	A02		W5161	0018	22		22-18-11	ALL
	A03		W5161	0020	22		23-42-11	ALL
	A04		W5161	0019	22		23-43-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5161	0022	24		31-65-15	ALL
	B02		W5161	0023	24		31-65-15	ALL
	B03		W5161	0024	24		31-65-15	ALL
	B04		W5161	0034	24		31-65-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40761J		**E005-02/ /**		**RCPT-**				**ALL**
	A01		W5047	2521R	24		34-61-23	ALL
	A02	UNUSED						ALL
	A03		W5047	0006	24		34-61-26	ALL
	A04		W5047	2509R	24		34-21-14	ALL
	A05	UNUSED						ALL
	A06		W5047	2506R	24		34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40761J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	A07		W5047	2510R	24		34-51-11	ALL
	A08		W5047	2511R	24		34-51-11	ALL
	A09		W5047	2508R	24		34-21-14	ALL
	A10		W5047	2507R	24		34-21-14	ALL
	A11		W5047	2512R	24		27-61-47	ALL
	A12		W5047	2515R	24		34-21-13	ALL
	A13		W5047	2516R	24		34-21-14	ALL
	A14		W5047	2514R	24		46-13-11	ALL
	A15		W5047	2517R	24		34-61-15	ALL
	A16		W5047	2519R	24		34-61-14	ALL
	A17		W5047	2520R	24		34-21-14	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W5047	2513R	24		27-61-47	ALL
	B01		W5047	2521B	24		34-61-23	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5047	2509B	24		34-21-14	ALL
	B05	UNUSED						ALL
	B06		W5047	2506B	24		34-61-15	ALL
	B07		W5047	2510B	24		34-51-11	ALL
	B08		W5047	2511B	24		34-51-11	ALL
	B09		W5047	2508B	24		34-21-14	ALL
	B10		W5047	2507B	24		34-21-14	ALL
	B11		W5047	2512B	24		27-61-47	ALL
	B12		W5047	2515B	24		34-21-13	ALL
	B13		W5047	2516B	24		34-21-14	ALL
	B14		W5047	2514B	24		46-13-11	ALL
	B15		W5047	2517B	24		34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40761J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	B16		W5047	2519B	24		34-61-14	ALL
	B17		W5047	2520B	24		34-21-14	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W5047	2513B	24		27-61-47	ALL
	PERG	1F	W5047	2506Z			34-61-15	ALL
	PERG	1F	W5047	2507Z			34-21-14	ALL
	PERG	1F	W5047	2508Z			34-21-14	ALL
	PERG	1F	W5047	2509Z			34-21-14	ALL
	PERG	1F	W5047	2510Z			34-51-11	ALL
	PERG	1F	W5047	2511Z			34-51-11	ALL
	PERG	1F	W5047	2512Z			27-61-47	ALL
	PERG	1F	W5047	2513Z			27-61-47	ALL
	PERG	1F	W5047	2514Z			46-13-11	ALL
	PERG	1F	W5047	2515Z			34-21-13	ALL
	PERG	1F	W5047	2516Z			34-21-14	ALL
	PERG	1F	W5047	2517Z			34-61-15	ALL
	PERG	1F	W5047	2519Z			34-61-14	ALL
	PERG	1F	W5047	2520Z			34-21-14	ALL
	PERG	1F	W5047	2521Z			34-61-23	ALL
D40761P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2667R	24		34-61-23	ALL
	A02	UNUSED						ALL
	A03		W0521	0278	24		34-61-26	ALL
	A04		W0521	2723R	24		34-21-14	ALL
	A05	UNUSED						ALL
	A06		W0521	2713R	24		34-61-15	ALL
	A07		W0521	2581R	24		34-51-11	ALL
	A08		W0521	2582R	24		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40761P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A09		W0521	2720R	24		34-21-14	ALL
	A10		W0521	2721R	24		34-21-14	ALL
	A11		W0521	2740R	24		27-61-47	ALL
	A12		W0521	2709R	24		34-21-13	ALL
	A13		W0521	2708R	24		34-21-14	ALL
	A14		W0521	2724R	24		46-13-11	ALL
	A15		W0521	2743R	24		34-61-15	ALL
	A16		W0521	2755R	24		34-61-14	ALL
	A17		W0521	2749R	24		34-21-14	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0521	2739R	24		27-61-47	ALL
	B01		W0521	2667B	24		34-61-23	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0521	2723B	24		34-21-14	ALL
	B05	UNUSED						ALL
	B06		W0521	2713B	24		34-61-15	ALL
	B07		W0521	2581B	24		34-51-11	ALL
	B08		W0521	2582B	24		34-51-11	ALL
	B09		W0521	2720B	24		34-21-14	ALL
	B10		W0521	2721B	24		34-21-14	ALL
	B11		W0521	2740B	24		27-61-47	ALL
	B12		W0521	2709B	24		34-21-13	ALL
	B13		W0521	2708B	24		34-21-14	ALL
	B14		W0521	2724B	24		46-13-11	ALL
	B15		W0521	2743B	24		34-61-15	ALL
	B16		W0521	2755B	24		34-61-14	ALL
	B17		W0521	2749B	24		34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40761P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0521	2739B	24		27-61-47	ALL
	PERG	1F	W0521	2581Z			34-51-11	ALL
	PERG	1F	W0521	2582Z			34-51-11	ALL
	PERG	1F	W0521	2667Z			34-61-23	ALL
	PERG	1F	W0521	2708Z			34-21-14	ALL
	PERG	1F	W0521	2709Z			34-21-13	ALL
	PERG	1F	W0521	2713Z			34-61-15	ALL
	PERG	1F	W0521	2720Z			34-21-14	ALL
	PERG	1F	W0521	2721Z			34-21-14	ALL
	PERG	1F	W0521	2723Z			34-21-14	ALL
	PERG	1F	W0521	2724Z			46-13-11	ALL
	PERG	1F	W0521	2739Z			27-61-47	ALL
	PERG	1F	W0521	2740Z			27-61-47	ALL
	PERG	1F	W0521	2743Z			34-61-15	ALL
	PERG	1F	W0521	2749Z			34-21-14	ALL
	PERG	1F	W0521	2755Z			34-61-14	ALL
D40767J		**E005-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5049	2510R	24		34-61-15	ALL
	A04		W5049	2512R	24		34-21-24	ALL
	A05		W5049	2513R	24		34-21-24	ALL
	A06		W5049	2520R	24		34-51-21	ALL
	A07		W5049	2521R	24		34-51-21	ALL
	A08		W5049	2514R	24		34-21-24	ALL
	A09		W5049	2522R	24		27-61-47	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40767J		**E005-02/ /**		**RCPT (continued)**				**ALL**
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5049	2510B	24		34-61-15	ALL
	B04		W5049	2512B	24		34-21-24	ALL
	B05		W5049	2513B	24		34-21-24	ALL
	B06		W5049	2520B	24		34-51-21	ALL
	B07		W5049	2521B	24		34-51-21	ALL
	B08		W5049	2514B	24		34-21-24	ALL
	B09		W5049	2522B	24		27-61-47	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40767J	**E005-02/ /**		**RCPT (continued)**				**ALL**
B20	UNUSED						ALL
PERG	1F	W5049	2510Z			34-61-15	ALL
PERG	1F	W5049	2512Z			34-21-24	ALL
PERG	1F	W5049	2513Z			34-21-24	ALL
PERG	1F	W5049	2514Z			34-21-24	ALL
PERG	1F	W5049	2520Z			34-51-21	ALL
PERG	1F	W5049	2521Z			34-51-21	ALL
PERG	1F	W5049	2522Z			27-61-47	ALL
D40767P	**E005-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0523	2501R	22		34-61-15	ALL
A04		W0523	2860R	24		34-21-24	ALL
A05		W0523	2858R	24		34-21-24	ALL
A06		W0523	2861R	24		34-51-21	ALL
A07		W0523	2862R	24		34-51-21	ALL
A08		W0523	2857R	24		34-21-24	ALL
A09		W0523	2515R	24		27-61-47	ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40767P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0523	2501B	22		34-61-15	ALL
	B04		W0523	2860B	24		34-21-24	ALL
	B05		W0523	2858B	24		34-21-24	ALL
	B06		W0523	2861B	24		34-51-21	ALL
	B07		W0523	2862B	24		34-51-21	ALL
	B08		W0523	2857B	24		34-21-24	ALL
	B09		W0523	2515B	24		27-61-47	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0523	2501Z			34-61-15	ALL
	PERG	1F	W0523	2515Z			27-61-47	ALL
	PERG	1F	W0523	2857Z			34-21-24	ALL
	PERG	1F	W0523	2858Z			34-21-24	ALL
	PERG	1F	W0523	2860Z			34-21-24	ALL
	PERG	1F	W0523	2861Z			34-51-21	ALL
	PERG	1F	W0523	2862Z			34-51-21	ALL
D40769J		**268/212/R36**		**RCPT-**				**ALL**
	1		W0041	0108	24		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40769J	**268/212/R36**		**RCPT- (continued)**				**ALL**
2		W0041	0109	24		31-32-15	ALL
3		W0041	0110	24		31-32-15	ALL
4	UNUSED						ALL
5		W0041	2538Z			31-32-15	ALL
6		W0041	2538B	24		31-32-15	ALL
7		W0041	2538R	24		31-32-15	ALL
8		W0041	2539B	24		31-32-15	ALL
9		W0041	2539R	24		31-32-15	ALL
10		W0041	2539Z			31-32-15	ALL
11		W0041	2540R	24		34-49-11	ALL
12		W0041	2540B	24		34-49-11	ALL
13		W0041	2540Z			34-49-11	ALL
14		W0041	0114	24		34-49-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0041	0120	22		46-13-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0041	2543R	24		27-61-47	ALL
24		W0041	2543B	24		27-61-47	ALL
25		W0041	2543Z			27-61-47	ALL
26		W0041	2544R	24		27-61-47	ALL
27		W0041	2544B	24		27-61-47	ALL
28		W0041	2544Z			27-61-47	ALL
29		W0041	6144	22		46-13-11	ALL
30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40769J		**268/212/R36**		**RCPT- (continued)**				**ALL**
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D40769P		**268/212/R036**		**PLUG-**				**ALL**
	1		W2597	0015	24		31-32-15	ALL
	2		W2597	0024	24		31-32-15	ALL
	3		W2597	0025	24		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40769P	**268/212/R036**		**PLUG- (continued)**				**ALL**
4	UNUSED						ALL
5		W2597	2511Z			31-32-15	ALL
6		W2597	2511B	24		31-32-15	ALL
7		W2597	2511R	24		31-32-15	ALL
8		W2597	2521B	24		31-32-15	ALL
9		W2597	2521R	24		31-32-15	ALL
10		W2597	2521Z			31-32-15	ALL
11		W2597	2522R	24		34-49-11	ALL
12		W2597	2522B	24		34-49-11	ALL
13		W2597	2522Z			34-49-11	ALL
14		W2597	0027	24		34-49-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W2597	0028	22		46-13-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W2597	2523R	24		27-61-47	ALL
24		W2597	2523B	24		27-61-47	ALL
25		W2597	2523Z			27-61-47	ALL
26		W2597	2524R	24		27-61-47	ALL
27		W2597	2524B	24		27-61-47	ALL
28		W2597	2524Z			27-61-47	ALL
29		W2597	0032	22		46-13-11	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40769P		**268/212/R036**		**PLUG- (continued)**				**ALL**
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D40771J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0198R	20		26-21-11	ALL
	A02		W0088	0199R	20		26-21-11	ALL
	A03		W0088	0222R	20		26-21-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40771J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0088	0223R	20		26-21-11	ALL
	B02		W0088	0106R	22		26-21-11	ALL
	B03		W0088	0108R	22		26-21-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0088	2098R	20		32-49-11	ALL
	B08		W0088	2098B	20		32-49-11	ALL
	B09		W0088	2099R	20		32-49-11	ALL
	B10		W0088	2099B	20		32-49-11	ALL
	PERG	1F	W0088	2098Z			32-49-11	ALL
	PERG	1F	W0088	2099Z			32-49-11	ALL
D40771P		**AJ0048A/ /**		**PLUG**				**ALL**
	A01		W5156	6018R	20		26-21-11	ALL
	A02		W5156	6019R	20		26-21-11	ALL
	A03		W5156	6023R	20		26-21-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5156	6021R	20		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40771P		**AJ0048A/ /**		**PLUG (continued)**				**ALL**
	B02		W5156	6020R	20		26-21-11	ALL
	B03		W5156	6022R	20		26-21-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5156	2103R	20		32-49-11	ALL
	B08		W5156	2103B	20		32-49-11	ALL
	B09		W5156	2104R	20		32-49-11	ALL
	B10		W5156	2104B	20		32-49-11	ALL
	PERG	1F	W5156	2103Z			32-49-11	ALL
	PERG	1F	W5156	2104Z			32-49-11	ALL
D40773J		**E002-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0220	0341R	22		26-11-11	ALL
	A11		W0220	0337R	22		26-11-11	ALL
	A12		W0220	0336R	22		26-11-11	ALL
	A13		W0220	0335R	22		26-11-11	ALL
	A14		W0220	0334R	22		26-11-11	ALL
	A15		W0220	0340R	22		26-11-11	ALL
	A16		W0220	0342R	22		26-11-11	ALL
	A17		W0220	0338R	22		26-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40773J		**E002-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0220	0397R	20		26-21-11	ALL
	B12		W0220	0395R	20		26-21-11	ALL
	B13		W0220	0396R	20		26-21-11	ALL
	B14		W0220	0399R	20		26-21-11	ALL
	B15		W0220	0398R	20		26-21-11	ALL
	B16		W0220	0394R	20		26-21-11	ALL
	B17		W0220	0250	20		30-71-11	ALL
	B18		W0220	0230	20		30-71-11	ALL
	B19	UNUSED						ALL
	B20		W0220	0366R	22		26-11-21	ALL
D40773P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40773P		**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5506	6097R	22		26-11-11	ALL
	A11		W5506	6019R	22		26-11-11	ALL
	A12		W5506	6020R	22		26-11-11	ALL
	A13		W5506	6021R	22		26-11-11	ALL
	A14		W5506	6022R	22		26-11-11	ALL
	A15		W5506	6023R	22		26-11-11	ALL
	A16		W5506	6016R	22		26-11-11	ALL
	A17		W5506	6018R	22		26-11-11	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W5506	6075R	22		26-21-11	ALL
	B12		W5506	6076R	22		26-21-11	ALL
	B13		W5506	6077R	22		26-21-11	ALL
	B14		W5506	6078R	22		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40773P	**E002-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B15		W5506	6066R	22		26-21-11	ALL
B16		W5506	6067R	22		26-21-11	ALL
B17		W5506	5519	20		30-71-11	ALL
B18		W5506	5517	20		30-71-11	ALL
B19	UNUSED						ALL
B20		W5506	6096R	22		26-11-21	ALL
D40774J	**E001-01/ /**		**RCPT-**				**ALL**
A01		W0113	1001	20		22-13-11	ALL
A02		W0111	0861	24		21-31-24	ALL
A03		W0111	0850	24		21-31-24	ALL
A04		W0111	0856	24		21-31-24	ALL
A05		W0111	2242R	24		21-31-24	ALL
A06		W0111	2244R	24		21-31-24	ALL
A07		W0111	2246R	24		21-31-24	ALL
A08		W0111	2248R	24		21-31-24	ALL
A09		W0111	0803	24		21-31-23	ALL
A10		W0111	0858	24		21-31-24	ALL
B01		W0113	1002	20		22-13-11	ALL
B02	UNUSED						ALL
B03		W0111	0851	24		21-31-24	ALL
B04		W0111	0857	24		21-31-24	ALL
B05		W0111	2242B	24		21-31-24	ALL
B06		W0111	2244B	24		21-31-24	ALL
B07		W0111	2246B	24		21-31-24	ALL
B08		W0111	2248B	24		21-31-24	ALL
B09	UNUSED						ALL
B10		W0111	0852	24		21-31-24	ALL
PERG	1F	W0111	2242Z			21-31-24	ALL
PERG	1F	W0111	2244Z			21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40774J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	PERG	1F	W0111	2246Z			21-31-24	ALL
	PERG	1F	W0111	2248Z			21-31-24	ALL
	PERG	1F	W0113	1001Z			22-13-11	ALL
	PERG	1F	W0113	1002Z			22-13-11	ALL
D40774P		**E001-01/ /**		**PLUG-**				**ALL**
	A01		W5119	0005	20		22-13-11	ALL
	A02		W6214	0211	24		21-31-24	ALL
	A03		W6214	0207	24		21-31-24	ALL
	A04		W6214	0209	24		21-31-24	ALL
	A05		W6214	2007R	24		21-31-24	ALL
	A06		W6214	2008R	24		21-31-24	ALL
	A07		W6214	2009R	24		21-31-24	ALL
	A08		W6214	2010R	24		21-31-24	ALL
	A09		W6214	0212	24		21-31-23	ALL
	A10		W6214	0204	24		21-31-24	ALL
	B01		W5711	0012	20		22-13-11	ALL
	B02	UNUSED						ALL
	B03		W6214	0208	24		21-31-24	ALL
	B04		W6214	0210	24		21-31-24	ALL
	B05		W6214	2007B	24		21-31-24	ALL
	B06		W6214	2008B	24		21-31-24	ALL
	B07		W6214	2009B	24		21-31-24	ALL
	B08		W6214	2010B	24		21-31-24	ALL
	B09	UNUSED						ALL
	B10		W6214	0206	24		21-31-24	ALL
	PERG	1F	W6214	2007Z			21-31-24	ALL
	PERG	1F	W6214	2008Z			21-31-24	ALL
	PERG	1F	W6214	2009Z			21-31-24	ALL
	PERG	1F	W6214	2010Z			21-31-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40775J	**209/206/L020**		**RCPT**				**ALL**
=1	VY	W0145	0001	20		27-32-11	ALL
D40775P	**209/206/L019**		**PLUG**				**ALL**
=1	VG	W2201	0020	20		27-32-11	ALL
D40776J	**J023-0B/ /**		**INSERT**				**ALL**
1		W0098	0102	22		26-19-11	ALL
2		W0098	0176	24		21-51-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W0098	0409	20		73-22-41	ALL
7		W0098	0147	22		26-19-11	ALL
8		W0098	0108	22		26-19-11	ALL
9		W0098	0107	22		26-19-11	ALL
10		W0098	0106	22		26-19-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0098	0408	20		73-22-41	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0098	0141	22		26-19-11	ALL
18		W0098	0142	22		26-19-11	ALL
19		W0098	0143	22		26-19-11	ALL
20		W0098	0144	22		26-19-11	ALL
21		W0098	0103	22		26-19-11	ALL
22		W0098	0104	22		26-19-11	ALL
23		W0098	0184	24		21-25-11	ALL
24		W0098	0183	24		21-27-31	ALL
25		W0098	0181	24		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40776J		**J023-0B/ /**		**INSERT (continued)**				**ALL**
	26		W0098	0182	24		21-25-11	ALL
	27		W0098	0105	22		26-19-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0098	0101	22		26-19-11	ALL
D40776P		**AJ0023B/ /**		**INSERT**				**ALL**
	1		W5506	0080	22		26-19-11	ALL
	2		W5506	0604	24		21-51-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5506	0099	20		73-22-41	ALL
	7		W5506	0113	22		26-19-11	ALL
	8		W5506	1004	22		26-19-11	ALL
	9		W5506	1003	22		26-19-11	ALL
	10		W5506	1002	22		26-19-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5506	0098	20		73-22-41	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5506	0087	22		26-19-11	ALL
	18		W5506	0088	22		26-19-11	ALL
	19		W5506	0089	22		26-19-11	ALL
	20		W5506	0090	22		26-19-11	ALL
	21		W5506	1005	22		26-19-11	ALL
	22		W5506	1006	22		26-19-11	ALL
	23		W5506	0603	24		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40776P	**AJ0023B/ /**		**INSERT (continued)**				**ALL**
24		W5506	5525	24		21-27-31	ALL
25		W5506	5526	24		21-25-11	ALL
26		W5506	5527	24		21-25-11	ALL
27		W5506	1007	22		26-19-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5506	0020	22		26-19-11	ALL
PERS	1A	W5506	1002Z			26-19-11	ALL
PERS	1A	W5506	1003Z			26-19-11	ALL
PERS	1A	W5506	1004Z			26-19-11	ALL
PERS	1A	W5506	1005Z			26-19-11	ALL
PERS	1A	W5506	1006Z			26-19-11	ALL
PERS	1A	W5506	1007Z			26-19-11	ALL
D40779J	**J023-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W0078	0331	24		33-25-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40779P		**AJ0023/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W5506	0011	22		33-25-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D40781J		**J004-00/ /**		**RCPT-**				**ALL**
	A01		W0094	0469	20		44-35-11	ALL
	A02		W0094	0436	20		44-35-11	ALL
	A03		W0094	0417	20		44-35-11	ALL
	A04		W0094	0421	20		44-35-11	ALL
	A05		W0094	0434	20		44-35-11	ALL
	A06		W0094	0448	20		44-35-11	ALL
	A07		W0094	0533	20		44-35-20	ALL
	A08		W0094	0464	20		44-35-11	ALL
	A09	UNUSED						ALL
	A10		W0094	0538	20		44-35-20	ALL
	B01		W0094	0470	20		44-35-11	ALL
	B02		W0094	0435	20		44-35-11	ALL
	B03		W0094	0447	20		44-35-11	ALL
	B04		W0094	0463	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40781J		**J004-00/ /**		**RCPT- (continued)**				**ALL**
	B05		W0094	0472	20		44-35-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0094	0539	20		44-35-20	ALL
D40781P		**J004-00/ /**		**PLUG**				**ALL**
	A01		W3453	0032	20		44-35-11	ALL
	A02		W3453	0049	20		44-35-11	ALL
	A03		W3453	0037	20		44-35-11	ALL
	A04		W3453	0036	20		44-35-11	ALL
	A05		W3453	0048	20		44-35-11	ALL
	A06		W3453	0052	20		44-35-11	ALL
	A07		W3453	0035	20		44-35-20	ALL
	A08		W3453	0056	20		44-35-11	ALL
	A09	UNUSED						ALL
	A10		W3453	0045	20		44-35-20	ALL
	B01		W3453	0050	20		44-35-11	ALL
	B02		W3453	0044	20		44-35-11	ALL
	B03		W3453	0051	20		44-35-11	ALL
	B04		W3453	0043	20		44-35-11	ALL
	B05		W3453	0053	20		44-35-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W3453	0034	20		44-35-20	ALL
D40783J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	2610R	24		31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40783J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	A02		W0422	2611R	24		31-32-15	ALL
	A03		W0422	0538	24		31-32-15	ALL
	A04		W0422	0539	24		31-32-15	ALL
	A05		W0422	0540	24		31-32-15	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0422	2610B	24		31-32-15	ALL
	B02		W0422	2611B	24		31-32-15	ALL
	B03		W0422	0301	22		46-13-11	ALL
	B04		W0422	0306	22		46-13-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40783J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0422	2610Z			31-32-15	ALL
	PERG	1F	W0422	2611Z			31-32-15	ALL
D40783P		**E004-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2597	2511R	24		31-32-15	ALL
	A02		W2597	2521R	24		31-32-15	ALL
	A03		W2597	0015	24		31-32-15	ALL
	A04		W2597	0024	24		31-32-15	ALL
	A05		W2597	0025	24		31-32-15	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40783P		**E004-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2597	2511B	24		31-32-15	ALL
	B02		W2597	2521B	24		31-32-15	ALL
	B03		W2597	0032	22		46-13-11	ALL
	B04		W2597	0028	22		46-13-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2597	2511Z			31-32-15	ALL
	PERG	1F	W2597	2521Z			31-32-15	ALL
D40785J		**E004-02/ /**		**RCPT**				**ALL**
	A01		W0422	2428R	24		31-65-25	ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40785J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0422	2428B	24		31-65-25	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40785J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0422	2428Z			31-65-25	ALL
D40785P		**E004-02/ /**		**PLUG**				**ALL**
	A01		W5049	2526R	24		31-65-25	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40785P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5049	2526B	24		31-65-25	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5049	2526Z			31-65-25	ALL
D40787J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	2472R	24		46-13-11	ALL
	A02		W0422	2421R	24		34-21-13	ALL
	A03		W0422	2422R	24		34-21-14	ALL
	A04		W0422	2425R	24		34-61-15	ALL
	A05		W0422	2612R	24		31-35-09	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40787J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	A06		W0422	2427R	24		31-65-15	ALL
	A07		W0422	2424R	24		34-61-14	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0422	2028R	24		34-61-23	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0422	2029R	24		31-35-09	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W0422	2030R	24		31-35-09	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0422	2472B	24		46-13-11	ALL
	B02		W0422	2421B	24		34-21-13	ALL
	B03		W0422	2422B	24		34-21-14	ALL
	B04		W0422	2425B	24		34-61-15	ALL
	B05		W0422	2612B	24		31-35-09	ALL
	B06		W0422	2427B	24		31-65-15	ALL
	B07		W0422	2424B	24		34-61-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0422	2028B	24		34-61-23	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0422	2029B	24		31-35-09	ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40787J	**E004-02/ /**		**RCPT- (continued)**				**ALL**
B15	UNUSED						ALL
B16		W0422	2030B	24		31-35-09	ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0422	2028Z			34-61-23	ALL
PERG	1F	W0422	2029Z			31-35-09	ALL
PERG	1F	W0422	2030Z			31-35-09	ALL
PERG	1F	W0422	2421Z			34-21-13	ALL
PERG	1F	W0422	2422Z			34-21-14	ALL
PERG	1F	W0422	2424Z			34-61-14	ALL
PERG	1F	W0422	2425Z			34-61-15	ALL
PERG	1F	W0422	2427Z			31-65-15	ALL
PERG	1F	W0422	2472Z			46-13-11	ALL
PERG	1F	W0422	2612Z			31-35-09	ALL
D40787P	**E004-02/ /**		**PLUG**				**ALL**
A01		W5047	2514R	24		46-13-11	ALL
A02		W5047	2515R	24		34-21-13	ALL
A03		W5047	2516R	24		34-21-14	ALL
A04		W5047	2517R	24		34-61-15	ALL
A05		W5047	2503R	24		31-35-09	ALL
A06		W5047	2518R	24		31-65-15	ALL
A07		W5047	2519R	24		34-61-14	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W5047	2521R	24		34-61-23	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40787P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	A13		W5047	2530R	24		31-35-09	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W5047	2531R	24		31-35-09	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5047	2514B	24		46-13-11	ALL
	B02		W5047	2515B	24		34-21-13	ALL
	B03		W5047	2516B	24		34-21-14	ALL
	B04		W5047	2517B	24		34-61-15	ALL
	B05		W5047	2503B	24		31-35-09	ALL
	B06		W5047	2518B	24		31-65-15	ALL
	B07		W5047	2519B	24		34-61-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5047	2521B	24		34-61-23	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W5047	2530B	24		31-35-09	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W5047	2531B	24		31-35-09	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5047	2503Z			31-35-09	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40787P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5047	2514Z			46-13-11	ALL
	PERG	1F	W5047	2515Z			34-21-13	ALL
	PERG	1F	W5047	2516Z			34-21-14	ALL
	PERG	1F	W5047	2517Z			34-61-15	ALL
	PERG	1F	W5047	2518Z			31-65-15	ALL
	PERG	1F	W5047	2519Z			34-61-14	ALL
	PERG	1F	W5047	2521Z			34-61-23	ALL
	PERG	1F	W5047	2530Z			31-35-09	ALL
	PERG	1F	W5047	2531Z			31-35-09	ALL
D40788J		**AJ0023B/ /**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0098	0187	22		21-43-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40788J		**AJ0023B/ /**		**INSERT (continued)**				**ALL**
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
D40788P		**AJ0023B/ /**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5510	0055	20		21-43-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40788P	**AJ0023B/ /**		**INSERT (continued)**				**ALL**
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
D40789J	**E004-02/ /**		**RCPT-**				**ALL**
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
=1		W0422	4006Z			46-13-11	ALL
=2		W0422	4007Z			46-13-11	ALL
=3		W0422	4010Z			46-13-11	ALL
1-1		W0422	4006Y	24		46-13-11	ALL
1-2		W0422	4006R	24		46-13-11	ALL
1-3		W0422	4006G	24		46-13-11	ALL
1-4		W0422	4006B	24		46-13-11	ALL
2-1		W0422	4007Y	24		46-13-11	ALL
2-2		W0422	4007R	24		46-13-11	ALL
2-3		W0422	4007G	24		46-13-11	ALL
2-4		W0422	4007B	24		46-13-11	ALL
3-1		W0422	4010Y	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40789J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	3-2		W0422	4010R	24		46-13-11	ALL
	3-3		W0422	4010G	24		46-13-11	ALL
	3-4		W0422	4010B	24		46-13-11	ALL
	4-1	UNUSED						ALL
	4-2	UNUSED						ALL
	4-3	UNUSED						ALL
	4-4	UNUSED						ALL
	5-1	UNUSED						ALL
	5-2	UNUSED						ALL
	5-3	UNUSED						ALL
	5-4	UNUSED						ALL
	6-1	UNUSED						ALL
	6-2	UNUSED						ALL
	6-3	UNUSED						ALL
	6-4	UNUSED						ALL
D40789P		**E004-02/ /**		**PLUG**				**ALL**
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	=1		W2031	4001Z			46-13-11	ALL
	=2		W2031	4002Z			46-13-11	ALL
	=3		W2031	4005Z			46-13-11	ALL
	1-1		W2031	4001Y	24		46-13-11	ALL
	1-2		W2031	4001R	24		46-13-11	ALL
	1-3		W2031	4001G	24		46-13-11	ALL
	1-4		W2031	4001B	24		46-13-11	ALL
	2-1		W2031	4002Y	24		46-13-11	ALL
	2-2		W2031	4002R	24		46-13-11	ALL
	2-3		W2031	4002G	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40789P	**E004-02/ /**		**PLUG (continued)**				**ALL**
2-4		W2031	4002B	24		46-13-11	ALL
3-1		W2031	4005Y	24		46-13-11	ALL
3-2		W2031	4005R	24		46-13-11	ALL
3-3		W2031	4005G	24		46-13-11	ALL
3-4		W2031	4005B	24		46-13-11	ALL
4-1	UNUSED						ALL
4-2	UNUSED						ALL
4-3	UNUSED						ALL
4-4	UNUSED						ALL
5-1	UNUSED						ALL
5-2	UNUSED						ALL
5-3	UNUSED						ALL
5-4	UNUSED						ALL
6-1	UNUSED						ALL
6-2	UNUSED						ALL
6-3	UNUSED						ALL
6-4	UNUSED						ALL
D40790J	**AB1050R/299/R007**		**RCPT-CONDUCTIVE**				**ALL**
1	TC	W4726	4504G	20		49-71-21	ALL
2	18	W4726	1005	18		49-62-11	ALL
3	UNUSED						ALL
4	18	W4726	1008	18		49-62-11	ALL
5	TD	W4726	4504W	20		49-71-21	ALL
6	UNUSED						ALL
7		W4726	4103B	20		24-24-31	ALL
8		W4726	4103R	20		24-24-31	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40790J		**AB1050R/299/R007**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W4726	2209B	22		49-52-31	ALL
	15		W4726	2209R	22		49-52-31	ALL
	16		W4726	2237R	20		49-62-11	ALL
	17		W4726	2210B	22		49-52-31	ALL
	18		W4726	4103Y	20		24-24-31	ALL
	19		W4726	4103G	20		24-24-31	ALL
	20	TD	W4726	4502W	20		49-71-21	ALL
	21	18	W4726	1012	18		49-62-11	ALL
	22		W4726	2237B	20		49-62-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W4726	2220B	22		49-62-12	ALL
	29		W4726	2220R	22		49-62-12	ALL
	30		W4726	2221B	22		49-62-12	ALL
	31		W4726	2221R	22		49-62-12	ALL
	32		W4726	2222B	22		49-62-12	ALL
	33		W4726	2222R	22		49-62-12	ALL
	34	UNUSED						ALL
	35		W4726	2210R	22		49-52-31	ALL
	36		W4726	2211B	22		49-52-31	ALL
	37		W4726	2211R	22		49-52-31	ALL
	38		W4726	2227B	22		49-71-21	ALL
	39		W4726	2227R	22		49-71-21	ALL
	40	TC	W4726	4502G	20		49-71-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40790J	**AB1050R/299/R007**		**RCPT-CONDUCTIVE (continued)**				**ALL**
41	UNUSED						ALL
42		W4726	1105R	20		26-21-11	ALL
43		W4726	1103R	20		26-21-11	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	18	W4726	1009	18		49-62-11	ALL
47		W4726	2232B	22		49-94-21	ALL
48		W4726	2232R	22		49-94-21	ALL
49	18	W4726	1004	18		49-62-11	ALL
50	18	W4726	1011	18		49-62-11	ALL
51	UNUSED						ALL
52	18	W4726	1016	18		49-62-11	ALL
53	18	W4726	1014	18		49-62-11	ALL
54	UNUSED						ALL
55	18	W4726	1015	18		49-62-11	ALL
S/R		W4726	1004Z			49-62-11	ALL
S/R		W4726	1005Z			49-62-11	ALL
S/R		W4726	1008Z			49-62-11	ALL
S/R		W4726	1009Z			49-62-11	ALL
S/R		W4726	1011Z			49-62-11	ALL
S/R		W4726	1012Z			49-62-11	ALL
S/R		W4726	1014Z			49-62-11	ALL
S/R		W4726	1015Z			49-62-11	ALL
S/R		W4726	1016Z			49-62-11	ALL
S/R		W4726	1103Z			26-21-11	ALL
S/R		W4726	1105Z			26-21-11	ALL
S/R		W4726	2209Z			49-52-31	ALL
S/R		W4726	2210Z			49-52-31	ALL
S/R		W4726	2211Z			49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40790J		**AB1050R/299/R007**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	S/R		W4726	2220Z			49-62-12	ALL
	S/R		W4726	2221Z			49-62-12	ALL
	S/R		W4726	2222Z			49-62-12	ALL
	S/R		W4726	2227Z			49-71-21	ALL
	S/R		W4726	2232Z			49-94-21	ALL
	S/R		W4726	2237Z			49-62-11	ALL
	S/R		W4726	4103Z			24-24-31	ALL
	S/R		W4726	4502Z			49-71-21	ALL
	S/R		W4726	4504Z			49-71-21	ALL
D40790P		**AB1050R/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	TC	W5726	4504G	20		49-71-21	ALL
	2	16	W5726	0610	16		49-62-11	ALL
	3	UNUSED						ALL
	4	18	W5726	0581	18		49-62-11	ALL
	5	TD	W5726	4504W	20		49-71-21	ALL
	6	UNUSED						ALL
	7		W5726	4103B	20		24-24-31	ALL
	8		W5726	4103R	20		24-24-31	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5726	2209B	22		49-52-31	ALL
	15		W5726	2209R	22		49-52-31	ALL
	16		W5726	0543	22		49-62-11	ALL
	17		W5726	2210B	22		49-52-31	ALL
	18		W5726	4103Y	20		24-24-31	ALL
	19		W5726	4103G	20		24-24-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40790P	**AB1050R/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
20	TD	W5726	4502W	20		49-71-21	ALL
21	18	W5726	0586	18		49-62-11	ALL
22		W5726	0545	22		49-62-11	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28		W5726	2220B	22		49-62-12	ALL
29		W5726	2220R	22		49-62-12	ALL
30		W5726	2221B	22		49-62-12	ALL
31		W5726	2221R	22		49-62-12	ALL
32		W5726	2222B	22		49-62-12	ALL
33		W5726	2222R	22		49-62-12	ALL
34	UNUSED						ALL
35		W5726	2210R	22		49-52-31	ALL
36		W5726	2211B	22		49-52-31	ALL
37		W5726	2211R	22		49-52-31	ALL
38		W5726	2227B	22		49-71-21	ALL
39		W5726	2227R	22		49-71-21	ALL
40	TC	W5726	4502G	20		49-71-21	ALL
41	UNUSED						ALL
42		W5726	1105R	20		26-21-11	ALL
43		W5726	1103R	20		26-21-11	ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	18	W5726	0606	18		49-62-11	ALL
47		W5726	2232B	22		49-94-21	ALL
48		W5726	2232R	22		49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40790P		**AB1050R/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	49	16	W5726	0609	16		49-62-11	ALL
	50	18	W5726	0607	18		49-62-11	ALL
	51	UNUSED						ALL
	52	18	W5726	0605	18		49-62-11	ALL
	53	18	W5726	0603	18		49-62-11	ALL
	54	UNUSED						ALL
	55	18	W5726	0591	18		49-62-11	ALL
	S/R		W5726	2209Z			49-52-31	ALL
	S/R		W5726	2210Z			49-52-31	ALL
	S/R		W5726	2211Z			49-52-31	ALL
	S/R		W5726	2220Z			49-62-12	ALL
	S/R		W5726	2221Z			49-62-12	ALL
	S/R		W5726	2222Z			49-62-12	ALL
	S/R		W5726	2227Z			49-71-21	ALL
	S/R		W5726	2232Z			49-94-21	ALL
	S/R		W5726	4103Z			24-24-31	ALL
	S/R		W5726	4502Z			49-71-21	ALL
	S/R		W5726	4504Z			49-71-21	ALL
	DED		W5726	1103Z			26-21-11	ALL
	DED		W5726	1105Z			26-21-11	ALL
D40791J		**E004-02/ /**		**RCPT-**				**ALL**
	5	UNUSED						ALL
	=1		W0422	4008Z			46-13-11	ALL
	=2		W0422	4009Z			46-13-11	ALL
	=3		W0422	4011Z			46-13-11	ALL
	=4		W0422	4016Z			46-13-11	ALL
	=6		W0422	4017Z			46-13-11	ALL
	1-1		W0422	4008Y	24		46-13-11	ALL
	1-2		W0422	4008R	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40791J	**E004-02/ /**		**RCPT- (continued)**				**ALL**
1-3		W0422	4008G	24		46-13-11	ALL
1-4		W0422	4008B	24		46-13-11	ALL
2-1		W0422	4009Y	24		46-13-11	ALL
2-2		W0422	4009R	24		46-13-11	ALL
2-3		W0422	4009G	24		46-13-11	ALL
2-4		W0422	4009B	24		46-13-11	ALL
3-1		W0422	4011Y	24		46-13-11	ALL
3-2		W0422	4011R	24		46-13-11	ALL
3-3		W0422	4011G	24		46-13-11	ALL
3-4		W0422	4011B	24		46-13-11	ALL
4-1		W0422	4016Y	24		46-13-11	ALL
4-2		W0422	4016R	24		46-13-11	ALL
4-3		W0422	4016G	24		46-13-11	ALL
4-4		W0422	4016B	24		46-13-11	ALL
5-1	UNUSED						ALL
5-2	UNUSED						ALL
5-3	UNUSED						ALL
5-4	UNUSED						ALL
6-1		W0422	4017Y	24		46-13-11	ALL
6-2		W0422	4017R	24		46-13-11	ALL
6-3		W0422	4017G	24		46-13-11	ALL
6-4		W0422	4017B	24		46-13-11	ALL
D40791P	**E004-02/ /**		**PLUG**				**ALL**
5	UNUSED						ALL
=1		W2043	4001Z			46-13-11	ALL
=2		W2043	4002Z			46-13-11	ALL
=3		W2043	4003Z			46-13-11	ALL
=4		W2043	4004Z			46-13-11	ALL
=6		W2043	4006Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40791P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	1-1		W2043	4001Y	24		46-13-11	ALL
	1-2		W2043	4001R	24		46-13-11	ALL
	1-3		W2043	4001G	24		46-13-11	ALL
	1-4		W2043	4001B	24		46-13-11	ALL
	2-1		W2043	4002Y	24		46-13-11	ALL
	2-2		W2043	4002R	24		46-13-11	ALL
	2-3		W2043	4002G	24		46-13-11	ALL
	2-4		W2043	4002B	24		46-13-11	ALL
	3-1		W2043	4003Y	24		46-13-11	ALL
	3-2		W2043	4003R	24		46-13-11	ALL
	3-3		W2043	4003G	24		46-13-11	ALL
	3-4		W2043	4003B	24		46-13-11	ALL
	4-1		W2043	4004Y	24		46-13-11	ALL
	4-2		W2043	4004R	24		46-13-11	ALL
	4-3		W2043	4004G	24		46-13-11	ALL
	4-4		W2043	4004B	24		46-13-11	ALL
	5-1	UNUSED						ALL
	5-2	UNUSED						ALL
	5-3	UNUSED						ALL
	5-4	UNUSED						ALL
	6-1		W2043	4006Y	24		46-13-11	ALL
	6-2		W2043	4006R	24		46-13-11	ALL
	6-3		W2043	4006G	24		46-13-11	ALL
	6-4		W2043	4006B	24		46-13-11	ALL
D40792J		**J004-00/ /**		**RCPT-**				**ALL**
	A01		W0094	0059	20		27-41-12	ALL
	A02		W0094	0060	20		27-41-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40792J		**J004-00/ /**		**RCPT- (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40792P		**J004-00/ /**		**PLUG -**				**ALL**
	A01		W3381	0026	20		27-41-12	ALL
	A02		W3381	0027	20		27-41-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40792P		**J004-00/ /**		**PLUG - (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40800J	**P006-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0044	0240	20		29-11-11	ALL
4		W0044	1009R	22		26-21-11	ALL
5		W0044	0419	20		76-21-11	ALL
6		W0044	0194	20		33-18-63	ALL
7		W0044	0204	20		33-18-63	ALL
8	UNUSED						ALL
9		W0044	1001R	22		26-11-11	ALL
10		W0044	1003R	22		26-11-21	ALL
11		W0044	1006R	22		26-21-11	ALL
12		W0044	1007R	22		26-21-11	ALL
13	UNUSED						ALL
14		W0044	0292	20		28-21-11	ALL
15		W0044	0412	22		28-41-11	ALL
16		W0044	0614	24		21-25-11	ALL
17	UNUSED						ALL
18		W0044	0261	22		32-35-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W0044	0641	24		21-27-31	ALL
23	UNUSED						ALL
24		W0044	0541	24		21-43-21	ALL
25	UNUSED						ALL
26		W0044	0038	24		24-34-11	ALL
27	UNUSED						ALL
28		W0044	6212	22		26-19-11	ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40800J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33		W0044	5521	22		27-33-11	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W0044	0756	20		34-41-11	ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	DED		W0044	1001Z			26-11-11	ALL
	DED		W0044	1003Z			26-11-21	ALL
	DED		W0044	1006Z			26-21-11	ALL
	DED		W0044	1007Z			26-21-11	ALL
	DED		W0044	1009Z			26-21-11	ALL
D40800P		**P006-00/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W5506	0506	20		29-11-11	ALL
	4		W5506	6061R	22		26-21-11	ALL
	5		W5506	6006	20		76-21-11	ALL
	6		W5506	5506	20		33-18-63	ALL
	7		W5506	5507	20		33-18-63	ALL
	8	UNUSED						ALL
	9		W5506	6015R	22		26-11-11	ALL
	10		W5506	6048R	22		26-11-21	ALL
	11		W5506	6054R	22		26-21-11	ALL
	12		W5506	6055R	22		26-21-11	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40800P	**P006-00/ /**		**PLUG (continued)**				**ALL**
14		W5506	6027	20		28-21-11	ALL
15		W5506	6088	22		28-41-11	ALL
16		W5506	5515	22		21-25-11	ALL
17	UNUSED						ALL
18		W5506	0523	20		32-35-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W5506	5520	24		21-27-31	ALL
23	UNUSED						ALL
24		W5506	5512	24		21-43-21	ALL
25	UNUSED						ALL
26		W5506	0521	24		24-34-11	ALL
27	UNUSED						ALL
28		W5506	0020	22		26-19-11	ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W5506	6506	20		SPARE	ALL
32	UNUSED						ALL
33		W5506	0076	22		27-33-11	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W5506	6001	20		34-41-11	ALL
38	UNUSED						ALL
39	UNUSED						ALL
D40802J	**P018-00/ /**		**RCPT-**				**ALL**
1		W0018	0354	22		35-21-11	ALL
2		W0018	0379	24		33-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40802J		**P018-00/ /**		**RCPT- (continued)**				**ALL**
	3		W0018	0007	24		21-42-11	ALL
	4		W0018	0860	20		78-34-11	ALL
	5	UNUSED						ALL
	6		W0018	0854	20		74-11-11	ALL
	7		W0018	0856	24		76-21-11	ALL
	8		W0018	0350	22		35-11-11	ALL
	9	UNUSED						ALL
	10		W0018	0006	22		21-27-31	ALL
	11		W0018	0039	20		30-71-11	ALL
	12		W0018	6208	20		74-11-11	ALL
	13		W0018	0041	20		30-71-11	ALL
	14		W0018	0851	20		73-22-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0018	0861	20		78-35-11	ALL
	21		W0018	0754	22		26-19-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	16	W0018	0096	16		47-30-11	ALL
D40802P		**P018-00/ /**		**PLUG**				**ALL**
	1		W5506	0001	22		35-21-11	ALL
	2		W5506	0013	22		33-25-11	ALL
	3		W5506	5511	24		21-42-11	ALL
	4		W5506	6033	20		78-34-11	ALL
	5	UNUSED						ALL
	6		W5506	6045	20		74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40802P	**P018-00/ /**		**PLUG (continued)**				**ALL**
7		W5506	6047	24		76-21-11	ALL
8		W5506	0015	22		35-11-11	ALL
9	UNUSED						ALL
10		W5506	5514	22		21-27-31	ALL
11		W5506	5517	20		30-71-11	ALL
12		W5506	0112	20		74-11-11	ALL
13		W5506	5519	20		30-71-11	ALL
14		W5506	6081	20		73-22-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5506	6083	20		78-35-11	ALL
21		W5506	0080	22		26-19-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	16	W5506	0074	16		47-30-11	ALL
D40804J	**P001-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0001	0315	24		33-25-11	ALL
A02		W0001	1012R	22		26-11-21	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40804J		**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02		W0001	1013R	22		26-11-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0001	1012Z			26-11-21	ALL
	PERG	1F	W0001	1013Z			26-11-21	ALL
D40804P		**P009-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5506	0012	22		33-25-11	ALL
	A02		W5506	6051R	22		26-11-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5506	6079R	22		26-11-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40804P	**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D40808J	**J023-0B/ /**		**INSERT-**				**ALL**
1		W0098	0178	24		21-51-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0098	0180	24		21-51-21	ALL
8		W0098	0179	24		21-51-21	ALL
9		W0098	0405	18		73-22-41	ALL
10		W0098	0406	18		73-22-41	ALL
11		W0098	0407	18		73-22-41	ALL
12		W0098	0412	18		73-22-41	ALL
13		W0098	0411	18		73-22-41	ALL
14		W0098	0410	18		73-22-41	ALL
15	UNUSED						ALL
16		W0098	0140	22		26-19-11	ALL
17		W0098	0177	24		21-51-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
D40808P	**J023-0B/ /**		**INSERT**				**ALL**
1		W2112	0065	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40808P		**J023-0B/ /**		**INSERT (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W2112	0067	24		21-51-21	ALL
	8		W2112	0069	24		21-51-21	ALL
	9		W2112	6091	18		73-22-41	ALL
	10		W2112	6090	18		73-22-41	ALL
	11		W2112	6089	18		73-22-41	ALL
	12		W2112	6095	18		73-22-41	ALL
	13		W2112	6096	18		73-22-41	ALL
	14		W2112	6097	18		73-22-41	ALL
	15	UNUSED						ALL
	16		W2112	6093	22		26-19-11	ALL
	17		W2112	0066	24		21-51-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
D40810J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40810J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W0131	1509R	20		26-21-11	ALL
	A10		W0131	1510R	20		26-21-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0131	2068R	22		32-49-11	ALL
	B07		W0131	2068B	22		32-49-11	ALL
	B08		W0131	2069R	22		32-49-11	ALL
	B09		W0131	2069B	22		32-49-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W0131	2068Z			32-49-11	ALL
	PERG	1F	W0131	2069Z			32-49-11	ALL
D40810P		**E001-03/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6506	6075R	22		26-21-11	ALL
	A10		W6506	6053R	22		26-21-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40810P		**E001-03/ /**		**PLUG (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W6506	2003R	20		32-49-11	ALL
	B07		W6506	2003B	20		32-49-11	ALL
	B08		W6506	2004R	20		32-49-11	ALL
	B09		W6506	2004B	20		32-49-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W6506	2003Z			32-49-11	ALL
	PERG	1F	W6506	2004Z			32-49-11	ALL
D40812J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0044	0241	20		29-11-11	ALL
	4		W0044	0205	20		33-18-63	ALL
	5		W0044	0206	20		33-18-63	ALL
	6	UNUSED						ALL
	7		W0044	0501	20		49-62-11	ALL
	8	UNUSED						ALL
	9		W0044	0294	20		28-21-11	ALL
	10		W0044	0425	20		78-34-21	ALL
	11	UNUSED						ALL
	12		W0044	0421	20		76-21-21	ALL
	13		W0044	1002R	22		26-11-21	ALL
	14		W0044	1005R	22		26-21-11	ALL
	15		W0044	1008R	22		26-21-11	ALL
	16		W0044	0426	20		78-35-21	ALL
	17		W0044	0408	22		28-41-11	ALL
	18	UNUSED						ALL
	19		W0044	0637	24		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40812J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40812J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	DED		W0044	1002Z			26-11-21	ALL
	DED		W0044	1005Z			26-21-11	ALL
	DED		W0044	1008Z			26-21-11	ALL
D40812P		**AP0600B/ /**		**PLUG**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W6506	0506	20		29-11-11	ALL
	4		W6506	5504	20		33-18-63	ALL
	5		W6506	5505	20		33-18-63	ALL
	6	UNUSED						ALL
	7		W6506	0501	20		49-62-11	ALL
	8	UNUSED						ALL
	9		W6506	6008	20		28-21-11	ALL
	10		W6506	6014	20		78-34-21	ALL
	11	UNUSED						ALL
	12		W6506	6028	20		76-21-21	ALL
	13		W6506	6031R	22		26-11-21	ALL
	14		W6506	6041R	22		26-21-11	ALL
	15		W6506	6046R	22		26-21-11	ALL
	16		W6506	6077	20		78-35-21	ALL
	17		W6506	6087	22		28-41-11	ALL
	18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40812P	**AP0600B/ /**		**PLUG (continued)**				**ALL**
19		W6506	5510	24		21-27-21	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40812P		**AP0600B/ /**		**PLUG (continued)**				**ALL**
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
D40813J		**265/221/R33**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	14	W0044	6229	14		33-11-41	ALL
	3	14	W0044	6215	14		33-11-41	ALL
	4		W0044	6236	16		33-11-41	ALL
	5		W0044	6237	20		33-11-41	ALL
	6	14	W0044	6230	14		33-11-33	ALL
	7		W0044	6231	16		33-11-33	ALL
	8	14	W0044	6232	14		33-11-33	ALL
	9		W0044	6233	16		33-11-33	ALL
	10		W0044	6235	18		33-11-41	ALL
	11	UNUSED						ALL
	12		W0044	6255	16		33-11-41	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40813P	**265/221/R33**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	14	W6206	5536	14		33-11-41	ALL
3	14	W6206	5531	14		33-11-41	ALL
4		W6206	5563	16		33-11-41	ALL
5		W6206	5564	20		33-11-41	ALL
6	14	W6206	5505	14		33-11-33	ALL
7		W6206	5507	16		33-11-33	ALL
8	14	W6206	5547	14		33-11-33	ALL
9		W6206	5544	16		33-11-33	ALL
10		W6206	5562	18		33-11-41	ALL
11	UNUSED						ALL
12		W6206	0530	16		33-11-41	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
D40816J	**P006-00/ /**		**RCPT-**				**ALL**
1	18	W0044	0090	18		33-14-12	ALL
2	UNUSED						ALL
3		W0044	0904	22		52-51-11	ALL
4		W0044	0069	16		33-11-33	ALL
5		W0044	0902	22		52-51-11	ALL
6		W0044	0903	22		52-51-11	ALL
7	UNUSED						ALL
8		W0044	0068	20		33-11-33	ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40816J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	10		W0044	0091	18		33-14-12	ALL
	11	UNUSED						ALL
	12		W0044	0905	22		52-51-11	ALL
D40816P		**P006-00/ /**		**PLUG-**				**ALL**
	1	18	W6206	5537	18		33-14-12	ALL
	2	UNUSED						ALL
	3		W6206	0015	22		52-51-11	ALL
	4		W6206	5512	16		33-11-33	ALL
	5		W6206	0012	22		52-51-11	ALL
	6		W6206	0014	22		52-51-11	ALL
	7	UNUSED						ALL
	8		W6206	5501	20		33-11-33	ALL
	9	UNUSED						ALL
	10		W6206	5539	18		33-14-12	ALL
	11	UNUSED						ALL
	12		W6206	0016	22		52-51-11	ALL
D40817J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2183R	24		73-24-12	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	2183B	24		73-24-12	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40817J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2183Z			73-24-12	ALL
D40817P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W5158	2009R	24		73-24-12	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5158	2009B	24		73-24-12	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40817P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	B10	UNUSED						ALL
	PERG	1F	W5158	2009Z			73-24-12	ALL
D40818J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	0117	22		27-51-11	ALL
	A02		W0111	3024R	22		27-51-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0111	0742	22		32-31-11	ALL
	A06		W0111	0745	22		32-64-11	ALL
	A07		W0111	2141B	24		27-28-11	ALL
	A08		W0111	0608	24		27-28-11	ALL
	A09		W0111	0605	24		27-28-11	ALL
	A10		W0111	0578	22		23-43-11	ALL
	B01		W0111	0118	22		27-51-11	ALL
	B02		W0111	3024B	22		27-51-11	ALL
	B03		W0111	3024Y	22		27-51-11	ALL
	B04		W0111	0146	20		22-13-11	ALL
	B05		W0111	0141	20		22-13-11	ALL
	B06	UNUSED						ALL
	B07		W0111	0174	20		22-13-11	ALL
	B08		W0111	2141R	24		27-28-11	ALL
	B09		W0111	0171	20		22-13-11	ALL
	B10		W0111	0953	20		22-13-11	ALL
D40818P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6208	2001R	22		27-51-11	ALL
	A02		W6208	3001R	22		27-51-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6208	0574	22		32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40818P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A06		W6208	0575	22		32-64-11	ALL
	A07		W6208	2201B	24		27-28-11	ALL
	A08		W6208	0534	24		27-28-11	ALL
	A09		W6208	0513	20		27-28-11	ALL
	A10		W6208	5510	22		23-43-11	ALL
	B01		W6208	2001B	22		27-51-11	ALL
	B02		W6208	3001B	22		27-51-11	ALL
	B03		W6208	3001Y	22		27-51-11	ALL
	B04		W6208	0005	20		22-13-11	ALL
	B05		W6208	0006	20		22-13-11	ALL
	B06	UNUSED						ALL
	B07		W6208	0009	20		22-13-11	ALL
	B08		W6208	2201R	24		27-28-11	ALL
	B09		W6208	0010	20		22-13-11	ALL
	B10		W6208	0011	20		22-13-11	ALL
D40819J		**E004-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02		W0422	2614R	24		23-27-34	ALL
	A03	UNUSED						ALL
	A04		W0422	2613R	24		46-13-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0422	2614B	24		23-27-34	ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40819J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B04		W0422	2613B	24		46-13-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0422	2613Z			46-13-11	ALL
	PERG	1F	W0422	2614Z			23-27-34	ALL
D40819P		**E004-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W5331	2528R	24		23-27-34	ALL
	A03	UNUSED						ALL
	A04		W5331	2507R	24		46-13-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5331	2528B	24		23-27-34	ALL
	B03	UNUSED						ALL
	B04		W5331	2507B	24		46-13-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40819P	**E004-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B10	UNUSED						ALL
PERG	1F	W5331	2507Z			46-13-11	ALL
PERG	1F	W5331	2528Z			23-27-34	ALL
D40820J	**P006-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0044	1021Z			30-31-12	ALL
4		W0044	6260	16		33-11-41	ALL
5		W0044	1021	22		30-31-12	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0044	0258	24		32-31-11	ALL
10	UNUSED						ALL
11		W0044	0418	20		74-11-11	ALL
12		W0044	0416	24		73-22-31	ALL
13		W0044	0225	24		27-21-11	ALL
14		W0044	0974	20		44-21-10	ALL
15		W0044	0237	20		27-62-11	ALL
16		W0044	0229	20		27-41-11	ALL
17		W0044	0414	20		73-22-11	ALL
18		W0044	0274	24		32-64-11	ALL
19		W0044	1020Z			30-31-12	ALL
20	UNUSED						ALL
21		W0044	0207	22		29-25-11	ALL
22		W0044	1020	22		30-31-12	ALL
23		W0044	0234	22		27-54-11	ALL
24		W0044	0209	22		29-23-11	ALL
25		W0044	0208	22		29-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40820J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	26		W0044	0224	24		27-11-11	ALL
	27	UNUSED						ALL
	28	18	W0044	6218	18		27-61-41	ALL
	29	UNUSED						ALL
	30		W0044	0986	20		44-21-10	ALL
	31	UNUSED						ALL
	32		W0044	0580	24		76-21-21	ALL
D40820P		**P006-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W6208	1005Z			30-31-12	ALL
	4		W6208	0733	16		33-11-41	ALL
	5		W6208	1005	22		30-31-12	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W6208	0574	22		32-31-11	ALL
	10	UNUSED						ALL
	11		W6208	0643	20		74-11-11	ALL
	12		W6208	0642	24		73-22-31	ALL
	13		W6208	0506	24		27-21-11	ALL
	14		W6208	0028	20		44-21-10	ALL
	15		W6208	0588	20		27-62-11	ALL
	16		W6208	0543	20		27-41-11	ALL
	17		W6208	0641	20		73-22-11	ALL
	18		W6208	0575	22		32-64-11	ALL
	19		W6208	1004Z			30-31-12	ALL
	20	UNUSED						ALL
	21		W6208	0584	22		29-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40820P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
22		W6208	1004	22		30-31-12	ALL
23		W6208	0536	22		27-54-11	ALL
24		W6208	0583	22		29-23-11	ALL
25		W6208	0585	22		29-25-11	ALL
26		W6208	0532	22		27-11-11	ALL
27	UNUSED						ALL
28	18	W6208	0014	18		27-61-41	ALL
29	UNUSED						ALL
30		W6208	0029	20		44-21-10	ALL
31	UNUSED						ALL
32		W6208	0644	24		76-21-21	ALL
D40822J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0188	20		33-18-51	ALL
2		W0044	0189	20		33-18-51	ALL
3		W0044	0052	22		31-51-11	ALL
4		W0044	0939	20		28-23-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0044	0056	20		31-52-11	ALL
8		W0044	6206	20		73-22-11	ALL
9		W0044	0191	20		33-18-61	ALL
10		W0044	0192	20		33-18-61	ALL
11		W0044	0193	20		33-18-61	ALL
12	UNUSED						ALL
13		W0044	0272	24		32-44-11	ALL
14		W0044	0940	20		28-23-11	ALL
15		W0044	0938	20		28-23-11	ALL
16		W0044	0212	22		34-16-21	ALL
17		W0044	0642	24		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40822J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	18		W0044	0515	20		31-52-71	ALL
	19		W0044	0517	20		31-52-71	ALL
	20		W0044	0200	20		33-18-62	ALL
	21		W0044	6205	20		73-22-11	ALL
	22		W0044	6211	22		32-31-15	ALL
	23		W0044	0547	20		33-18-62	ALL
	24		W0044	0548	20		33-18-62	ALL
D40822P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W5514	5505	20		33-18-51	ALL
	2		W5514	5506	20		33-18-51	ALL
	3		W5514	5502	22		31-51-11	ALL
	4		W5514	5592	20		28-23-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5514	5516	20		31-52-11	ALL
	8		W5514	0561	20		73-22-11	ALL
	9		W5514	5509	20		33-18-61	ALL
	10		W5514	5510	20		33-18-61	ALL
	11		W5514	5511	20		33-18-61	ALL
	12	UNUSED						ALL
	13		W5514	0520	20		32-44-11	ALL
	14		W5514	5593	20		28-23-11	ALL
	15		W5514	5591	20		28-23-11	ALL
	16		W5514	5553	22		34-16-21	ALL
	17		W5514	5784	24		21-27-31	ALL
	18		W5514	5559	20		31-52-71	ALL
	19		W5514	5547	20		31-52-71	ALL
	20		W5514	5561	20		33-18-62	ALL
	21		W5514	0560	20		73-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40822P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
22		W5514	0046	22		32-31-15	ALL
23		W5514	5576	20		33-18-62	ALL
24		W5514	5577	20		33-18-62	ALL
D40824J	**P003-00/ /**		**INSERT**				**ALL**
1		W0001	0181	20		31-52-25	ALL
2		W0003	0655	20		31-52-21	ALL
3		W0003	0657	20		31-52-55	ALL
4		W0003	0656	20		31-52-51	ALL
5		W0003	0658	20		31-52-61	ALL
6		W0001	0185	20		31-52-45	ALL
7		W0003	0705	20		33-18-51	ALL
8		W0003	0659	20		31-52-65	ALL
9		W0003	0660	20		31-52-75	ALL
10		W0003	1072	22		31-53-11	ALL
11		W0003	0645	20		31-52-11	ALL
12		W0003	0648	20		31-52-11	ALL
13		W0003	0646	20		31-52-11	ALL
14		W0003	0644	20		31-52-11	ALL
15		W0001	0182	20		31-52-31	ALL
16	UNUSED						ALL
17		W0001	0183	20		31-52-35	ALL
18		W0001	0184	20		31-52-41	ALL
19		W0003	1070	22		21-33-11	ALL
20		W0001	0186	20		31-52-71	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0001	1242	20		33-18-21	ALL
24	UNUSED						ALL
25	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40824J		**P003-00/ /**		**INSERT (continued)**				**ALL**
	26		W0003	1760	22		32-31-15	ALL
	27		W0001	0096	24		32-44-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0003	1690	20		33-18-21	ALL
	PERS	1A	W0001	1242Z			33-18-21	ALL
	PERS	1A	W0003	1070Z			21-33-11	ALL
	PERS	1A	W0003	1072Z			31-53-11	ALL
	PERS	1A	W0003	1690Z			33-18-21	ALL
	PERS	1A	W0003	1760Z			32-31-15	ALL
D40824P		**P009-00/ /**		**INSERT**				**ALL**
	1		W5514	5528	20		31-52-25	ALL
	2		W5514	5526	20		31-52-21	ALL
	3		W5514	5540	20		31-52-55	ALL
	4		W5514	5538	20		31-52-51	ALL
	5		W5514	5542	20		31-52-61	ALL
	6		W5514	5536	20		31-52-45	ALL
	7		W5514	5507	20		33-18-51	ALL
	8		W5514	5544	20		31-52-65	ALL
	9		W5514	5549	20		31-52-75	ALL
	10		W5514	5602	22		31-53-11	ALL
	11		W5514	5523	20		31-52-11	ALL
	12		W5514	5522	20		31-52-11	ALL
	13		W5514	5524	20		31-52-11	ALL
	14		W5514	5517	20		31-52-11	ALL
	15		W5514	5530	20		31-52-31	ALL
	16	UNUSED						ALL
	17		W5514	5532	20		31-52-35	ALL
	18		W5514	5534	20		31-52-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40824P	**P009-00/ /**		**INSERT (continued)**				**ALL**
19		W5514	5601	22		21-33-11	ALL
20		W5514	5546	20		31-52-71	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5514	5503	20		33-18-21	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W5514	0046	22		32-31-15	ALL
27		W5514	5783	22		32-44-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5514	5504	20		33-18-21	ALL
D40827J	**E004-02/ /**		**RCPT-**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
=1		W0422	4019Z			46-13-52	ALL
=2		W0422	4018Z			46-13-52	ALL
1-1		W0422	4019Y	24		46-13-52	ALL
1-2		W0422	4019R	24		46-13-52	ALL
1-3		W0422	4019G	24		46-13-52	ALL
1-4		W0422	4019B	24		46-13-52	ALL
2-1		W0422	4018Y	24		46-13-52	ALL
2-2		W0422	4018R	24		46-13-52	ALL
2-3		W0422	4018G	24		46-13-52	ALL
2-4		W0422	4018B	24		46-13-52	ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40827J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
	4-1	UNUSED						ALL
	4-2	UNUSED						ALL
	4-3	UNUSED						ALL
	4-4	UNUSED						ALL
	5-1	UNUSED						ALL
	5-2	UNUSED						ALL
	5-3	UNUSED						ALL
	5-4	UNUSED						ALL
	6-1	UNUSED						ALL
	6-2	UNUSED						ALL
	6-3	UNUSED						ALL
	6-4	UNUSED						ALL
D40827P		**E004-02/ /**		**PLUG**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	=1		W3910	4001Z			46-13-52	ALL
	=2		W3910	4002Z			46-13-52	ALL
	1-1		W3910	4001Y	24		46-13-52	ALL
	1-2		W3910	4001R	24		46-13-52	ALL
	1-3		W3910	4001G	24		46-13-52	ALL
	1-4		W3910	4001B	24		46-13-52	ALL
	2-1		W3910	4002Y	24		46-13-52	ALL
	2-2		W3910	4002R	24		46-13-52	ALL
	2-3		W3910	4002G	24		46-13-52	ALL
	2-4		W3910	4002B	24		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40827P	**E004-02/ /**		**PLUG (continued)**				**ALL**
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
4-1	UNUSED						ALL
4-2	UNUSED						ALL
4-3	UNUSED						ALL
4-4	UNUSED						ALL
5-1	UNUSED						ALL
5-2	UNUSED						ALL
5-3	UNUSED						ALL
5-4	UNUSED						ALL
6-1	UNUSED						ALL
6-2	UNUSED						ALL
6-3	UNUSED						ALL
6-4	UNUSED						ALL
D40830J	**P018-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W0018	0353	22		35-21-11	ALL
7		W0018	0352	16		35-21-11	ALL
8		W0018	0351	16		35-21-11	ALL
9		W0018	0359	16		35-21-11	ALL
10		W0018	0360	16		35-21-11	ALL
11	UNUSED						ALL
12		W0018	0414	16		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40830J		**P018-00/ /**		**RCPT- (continued)**				**ALL**
	13	UNUSED						ALL
	14		W0018	0801	22		34-16-11	ALL
D40830P		**P018-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W5514	5572	20		SPARE	ALL
	4		W5514	5573	20		SPARE	ALL
	5	UNUSED						ALL
	6		W5514	0001	22		35-21-11	ALL
	7		W5514	0002	16		35-21-11	ALL
	8		W5514	0003	16		35-21-11	ALL
	9		W5514	0004	16		35-21-11	ALL
	10		W5514	0005	16		35-21-11	ALL
	11	UNUSED						ALL
	12		W5514	5594	16		47-30-11	ALL
	13	UNUSED						ALL
	14		W5514	5555	22		34-16-11	ALL
D40831J		**E006-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0626	1001	22		49-62-12	ALL
	A02		W0626	2002R	22		49-62-12	ALL
	A03		W0626	2003R	22		49-62-12	ALL
	A04		W0626	2004R	22		49-62-12	ALL
	A05		W0626	1003	22		49-62-12	ALL
	A06		W0626	2005R	22		49-62-12	ALL
	A07		W0626	2006R	22		49-62-12	ALL
	A08		W0626	2007R	22		49-62-12	ALL
	A09		W0626	3001R	22		49-62-12	ALL
	A10		W0626	3001B	22		49-62-12	ALL
	A11		W0626	2010R	22		49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40831J	**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A12		W0626	0016	22		49-62-11	ALL
A13		W0626	0029	22		49-62-51	ALL
A14		W0626	2011R	22		49-71-21	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17		W0626	0013	22		49-62-11	ALL
A18		W0626	2023B	22		49-62-11	ALL
A19		W0626	0001	20		49-62-11	ALL
A20		W0626	0035	24		49-62-11	ALL
B01		W0626	1002	22		49-62-12	ALL
B02		W0626	2002B	22		49-62-12	ALL
B03		W0626	2003B	22		49-62-12	ALL
B04		W0626	2004B	22		49-62-12	ALL
B05		W0626	1004	22		49-62-12	ALL
B06		W0626	2005B	22		49-62-12	ALL
B07		W0626	2006B	22		49-62-12	ALL
B08		W0626	2007B	22		49-62-12	ALL
B09		W0626	3001Y	22		49-62-12	ALL
B10		W0626	2001B	22		49-62-11	ALL
B11		W0626	2010B	22		49-62-12	ALL
B12		W0626	2001R	22		49-62-11	ALL
B13		W0626	0030	22		49-62-51	ALL
B14		W0626	2011B	22		49-71-21	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W0626	0010	22		49-62-11	ALL
B18		W0626	0012	22		49-62-11	ALL
B19		W0626	2023R	22		49-62-11	ALL
B20		W0626	0011	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40831J		**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0626	1001Z			49-62-12	ALL
	PERG	1F	W0626	1002Z			49-62-12	ALL
	PERG	1F	W0626	1003Z			49-62-12	ALL
	PERG	1F	W0626	1004Z			49-62-12	ALL
	PERG	1F	W0626	2001Z			49-62-11	ALL
	PERG	1F	W0626	2002Z			49-62-12	ALL
	PERG	1F	W0626	2003Z			49-62-12	ALL
	PERG	1F	W0626	2004Z			49-62-12	ALL
	PERG	1F	W0626	2005Z			49-62-12	ALL
	PERG	1F	W0626	2006Z			49-62-12	ALL
	PERG	1F	W0626	2007Z			49-62-12	ALL
	PERG	1F	W0626	2010Z			49-62-12	ALL
	PERG	1F	W0626	2011Z			49-71-21	ALL
	PERG	1F	W0626	3001Z			49-62-12	ALL
D40831P		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W5726	1002	22		49-62-12	ALL
	A02		W5726	2214R	22		49-62-12	ALL
	A03		W5726	2215R	22		49-62-12	ALL
	A04		W5726	2216R	22		49-62-12	ALL
	A05		W5726	1005	22		49-62-12	ALL
	A06		W5726	2217R	22		49-62-12	ALL
	A07		W5726	2218R	22		49-62-12	ALL
	A08		W5726	2219R	22		49-62-12	ALL
	A09		W5726	3203R	22		49-62-12	ALL
	A10		W5726	3203B	22		49-62-12	ALL
	A11		W5726	2222R	22		49-62-12	ALL
	A12		W5726	0529	22		49-62-11	ALL
	A13		W5726	0517	22		49-62-51	ALL
	A14		W5726	2227R	22		49-71-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40831P	**E006-02/ /**		**PLUG- (continued)**				**ALL**
A15	UNUSED						ALL
A16	UNUSED						ALL
A17		W5726	0541	22		49-62-11	ALL
A18		W5726	2212B	22		49-62-11	ALL
A19		W5726	0584	20		49-62-11	ALL
A20		W5726	0570	24		24-28-41	ALL
B01		W5726	1003	22		49-62-12	ALL
B02		W5726	2214B	22		49-62-12	ALL
B03		W5726	2215B	22		49-62-12	ALL
B04		W5726	2216B	22		49-62-12	ALL
B05		W5726	1006	22		49-62-12	ALL
B06		W5726	2217B	22		49-62-12	ALL
B07		W5726	2218B	22		49-62-12	ALL
B08		W5726	2219B	22		49-62-12	ALL
B09		W5726	3203Y	22		49-62-12	ALL
B10		W5726	2213B	22		49-62-11	ALL
B11		W5726	2222B	22		49-62-12	ALL
B12		W5726	2213R	22		49-62-11	ALL
B13		W5726	0518	22		49-62-51	ALL
B14		W5726	2227B	22		49-71-21	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W5726	0525	22		49-62-11	ALL
B18		W5726	0527	22		49-62-11	ALL
B19		W5726	2212R	22		49-62-11	ALL
B20		W5726	0526	22		49-62-11	ALL
PERG	1F	W5726	1002Z			49-62-12	ALL
PERG	1F	W5726	1003Z			49-62-12	ALL
PERG	1F	W5726	1005Z			49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40831P		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W5726	1006Z			49-62-12	ALL
	PERG	1F	W5726	2213Z			49-62-11	ALL
	PERG	1F	W5726	2214Z			49-62-12	ALL
	PERG	1F	W5726	2215Z			49-62-12	ALL
	PERG	1F	W5726	2216Z			49-62-12	ALL
	PERG	1F	W5726	2217Z			49-62-12	ALL
	PERG	1F	W5726	2218Z			49-62-12	ALL
	PERG	1F	W5726	2219Z			49-62-12	ALL
	PERG	1F	W5726	2222Z			49-62-12	ALL
	PERG	1F	W5726	2227Z			49-71-21	ALL
	PERG	1F	W5726	3203Z			49-62-12	ALL
D40833J		**E006-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0626	2022R	24		49-62-11	ALL
	A02		W0626	2022B	24		49-62-11	ALL
	A03		W0626	0018	22		49-62-11	ALL
	A04		W0626	2008R	22		49-62-12	ALL
	A05		W0626	2009R	22		49-62-12	ALL
	A06		W0626	0024	22		49-62-11	ALL
	A07		W0626	0059	20		49-62-11	ALL
	A08		W0626	0062	20		49-62-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0626	0017	22		49-62-11	ALL
	B03		W0626	2008B	22		49-62-12	ALL
	B04		W0626	2009B	22		49-62-12	ALL
	B05		W0626	0023	22		49-62-11	ALL
	B06		W0626	0058	20		49-62-11	ALL
	B07		W0626	0061	20		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40833J	**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G		W0626	0057	18		49-62-11	ALL
H		W0626	0056	18		49-62-11	ALL
J		W0626	0054	18		49-62-11	ALL
K		W0626	0053	18		49-62-11	ALL
PERG	1F	W0626	2008Z			49-62-12	ALL
PERG	1F	W0626	2009Z			49-62-12	ALL
PERG	1F	W0626	2022Z			49-62-11	ALL
D40833P	**E006-02/ /**		**PLUG-**				**ALL**
A01		W5726	2601R	24		73-24-12	ALL
A02		W5726	2601B	24		73-24-12	ALL
A03		W5726	0582	22		49-62-11	ALL
A04		W5726	2220R	22		49-62-12	ALL
A05		W5726	2221R	22		49-62-12	ALL
A06		W5726	0545	22		49-62-11	ALL
A07		W5726	0540	20		49-62-11	ALL
A08		W5726	0544	20		49-62-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02		W5726	0573	22		49-62-11	ALL
B03		W5726	2220B	22		49-62-12	ALL
B04		W5726	2221B	22		49-62-12	ALL
B05		W5726	0543	22		49-62-11	ALL
B06		W5726	0538	20		49-62-11	ALL
B07		W5726	0542	20		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40833P		**E006-02/ /**		**PLUG- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W5726	0605	18		49-62-11	ALL
	H		W5726	0603	18		49-62-11	ALL
	J		W5726	0586	18		49-62-11	ALL
	K		W5726	0581	18		49-62-11	ALL
	PERG	1F	W5726	2220Z			49-62-12	ALL
	PERG	1F	W5726	2221Z			49-62-12	ALL
	PERG	1F	W5726	2601Z			73-24-12	ALL
D40835J		**E006-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0626	2020R	22		49-52-31	ALL
	A02		W0626	2019R	22		49-52-31	ALL
	A03		W0626	2018R	22		49-52-31	ALL
	A04		W0626	2017R	22		49-52-31	ALL
	A05		W0626	3003R	22		49-52-31	ALL
	A06		W0626	3003Y	22		49-52-31	ALL
	A07		W0626	2015R	22		49-52-31	ALL
	A08		W0626	3002R	22		49-52-31	ALL
	A09		W0626	3002Y	22		49-52-31	ALL
	A10		W0626	2014R	22		49-52-31	ALL
	A11		W0626	0049	24		49-52-31	ALL
	A12		W0626	0051	24		49-52-31	ALL
	A13	UNUSED						ALL
	A14		W0626	0008	22		49-62-11	ALL
	A15		W0626	2016R	22		49-52-31	ALL
	A16		W0626	0006	22		49-62-11	ALL
	A17		W0626	2021R	22		49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40835J	**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A18		W0626	0037	22		49-94-21	ALL
A19		W0626	0039	22		49-94-21	ALL
A20		W0626	0034	22		49-94-21	ALL
B01		W0626	2020B	22		49-52-31	ALL
B02		W0626	2019B	22		49-52-31	ALL
B03		W0626	2018B	22		49-52-31	ALL
B04		W0626	2017B	22		49-52-31	ALL
B05		W0626	3003B	22		49-52-31	ALL
B06		W0626	0060	22		49-52-31	ALL
B07		W0626	2015B	22		49-52-31	ALL
B08		W0626	3002B	22		49-52-31	ALL
B09		W0626	0055	22		49-52-31	ALL
B10		W0626	2014B	22		49-52-31	ALL
B11		W0626	0050	24		49-52-31	ALL
B12		W0626	0052	24		49-52-31	ALL
B13		W0626	0038	24		49-52-31	ALL
B14		W0626	0005	22		49-62-11	ALL
B15		W0626	2016B	22		49-52-31	ALL
B16		W0626	0009	22		49-62-11	ALL
B17		W0626	2021B	22		49-94-21	ALL
B18		W0626	0036	22		49-94-21	ALL
B19		W0626	0040	22		49-94-21	ALL
B20		W0626	0007	22		49-62-11	ALL
PERG	1F	W0626	2014Z			49-52-31	ALL
PERG	1F	W0626	2015Z			49-52-31	ALL
PERG	1F	W0626	2016Z			49-52-31	ALL
PERG	1F	W0626	2017Z			49-52-31	ALL
PERG	1F	W0626	2018Z			49-52-31	ALL
PERG	1F	W0626	2019Z			49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40835J		**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0626	2020Z			49-52-31	ALL
	PERG	1F	W0626	2021Z			49-94-21	ALL
	PERG	1F	W0626	3002Z			49-52-31	ALL
	PERG	1F	W0626	3003Z			49-52-31	ALL
D40835P		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W5726	2211R	22		49-52-31	ALL
	A02		W5726	2210R	22		49-52-31	ALL
	A03		W5726	2209R	22		49-52-31	ALL
	A04		W5726	2208R	22		49-52-31	ALL
	A05		W5726	3202R	22		49-52-31	ALL
	A06		W5726	3202Y	22		49-52-31	ALL
	A07		W5726	2206R	22		49-52-31	ALL
	A08		W5726	3201R	22		49-52-31	ALL
	A09		W5726	3201Y	22		49-52-31	ALL
	A10		W5726	2205R	22		49-52-31	ALL
	A11		W5726	0509	24		49-52-31	ALL
	A12		W5726	0508	24		49-52-31	ALL
	A13	UNUSED						ALL
	A14		W5726	0600	22		49-62-11	ALL
	A15		W5726	2207R	22		49-52-31	ALL
	A16		W5726	0528	22		49-62-11	ALL
	A17		W5726	2232R	22		49-94-21	ALL
	A18		W5726	0588	22		49-94-21	ALL
	A19		W5726	0561	22		49-94-21	ALL
	A20		W5726	0558	22		49-94-21	ALL
	B01		W5726	2211B	22		49-52-31	ALL
	B02		W5726	2210B	22		49-52-31	ALL
	B03		W5726	2209B	22		49-52-31	ALL
	B04		W5726	2208B	22		49-52-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40835P	**E006-02/ /**		**PLUG- (continued)**				**ALL**
B05		W5726	3202B	22		49-52-31	ALL
B06		W5726	0514	22		49-52-31	ALL
B07		W5726	2206B	22		49-52-31	ALL
B08		W5726	3201B	22		49-52-31	ALL
B09		W5726	0516	22		49-52-31	ALL
B10		W5726	2205B	22		49-52-31	ALL
B11		W5726	0513	24		49-52-31	ALL
B12		W5726	0510	24		49-52-31	ALL
B13		W5726	5501	24		21-51-11	ALL
B14		W5726	0520	22		49-62-11	ALL
B15		W5726	2207B	22		49-52-31	ALL
B16		W5726	0601	22		49-62-11	ALL
B17		W5726	2232B	22		49-94-21	ALL
B18		W5726	0559	22		49-94-21	ALL
B19		W5726	0562	22		49-94-21	ALL
B20		W5726	0521	22		49-62-11	ALL
PERG	1F	W5726	2205Z			49-52-31	ALL
PERG	1F	W5726	2206Z			49-52-31	ALL
PERG	1F	W5726	2207Z			49-52-31	ALL
PERG	1F	W5726	2208Z			49-52-31	ALL
PERG	1F	W5726	2209Z			49-52-31	ALL
PERG	1F	W5726	2210Z			49-52-31	ALL
PERG	1F	W5726	2211Z			49-52-31	ALL
PERG	1F	W5726	2232Z			49-94-21	ALL
PERG	1F	W5726	3201Z			49-52-31	ALL
PERG	1F	W5726	3202Z			49-52-31	ALL
D40836J	**AB1050R/298/R007**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W4222	1014	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40836J		**AB1050R/298/R007**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	3	UNUSED						ALL
	4		W4222	1020	20		22-13-11	ALL
	5	UNUSED						ALL
	6		W4222	1013	20		22-13-11	ALL
	7		W4222	1012	20		22-13-11	ALL
	8	UNUSED						ALL
	9		W4222	1015	20		27-41-12	ALL
	10		W4222	1004	18		27-41-12	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	S/R		W4222	1004Z			27-41-12	ALL
	S/R		W4222	1012Z			22-13-11	ALL
	S/R		W4222	1013Z			22-13-11	ALL
	S/R		W4222	1014Z			22-13-11	ALL
	S/R		W4222	1015Z			27-41-12	ALL
	S/R		W4222	1020Z			22-13-11	ALL
D40836P		**AB1050R/298/R010**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W6222	0009	20		22-13-11	ALL
	3	UNUSED						ALL
	4		W6222	0008	20		22-13-11	ALL
	5	UNUSED						ALL
	6		W6222	0010	20		22-13-11	ALL
	7		W6222	0011	20		22-13-11	ALL
	8	UNUSED						ALL
	9		W6222	0555	20		27-41-12	ALL
	10		W6222	0553	20		27-41-12	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40842J	**AB1050L/296/L017**		**RCPT-CONDUCTIVE**				**ALL**
1		W4134	1002	20		27-25-11	ALL
2	UNUSED						ALL
3		W4134	3204R	20		27-21-11	ALL
4		W4134	3204Y	20		27-21-11	ALL
5		W4134	3204B	20		27-21-11	ALL
6		W4134	2204B	20		27-28-11	ALL
7		W4134	2204R	20		27-28-11	ALL
8		W4134	1009	20		27-31-37	ALL
9		W4134	1010	20		27-31-37	ALL
10		W4134	1011	20		27-31-37	ALL
11		W4134	1012	20		27-31-37	ALL
12		W4134	1013	20		31-53-11	ALL
13		W4134	1014	20		31-53-11	ALL
14		W4134	3203B	20		27-28-11	ALL
15		W4134	3203R	20		27-28-11	ALL
16		W4134	2202B	20		27-28-11	ALL
17		W4134	2202R	20		27-28-11	ALL
18		W4134	2203B	20		27-28-11	ALL
19		W4134	2203R	20		27-28-11	ALL
20		W4134	1102	20		27-23-11	ALL
21		W4134	1101	20		27-23-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W4134	1016	20		27-33-11	ALL
25		W4134	1019	20		27-33-11	ALL
26		W4134	1020	20		27-33-11	ALL
27		W4134	3203Y	20		27-28-11	ALL
28	UNUSED						ALL
29		W4134	1003	20		27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40842J		**AB1050L/296/L017**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	30		W4134	2001R	20		27-25-11	ALL
	31		W4134	2001B	20		27-25-11	ALL
	S/R		W4134	1002Z			27-25-11	ALL
	S/R		W4134	1003Z			27-25-11	ALL
	S/R		W4134	1009Z			27-31-37	ALL
	S/R		W4134	1010Z			27-31-37	ALL
	S/R		W4134	1011Z			27-31-37	ALL
	S/R		W4134	1012Z			27-31-37	ALL
	S/R		W4134	1013Z			31-53-11	ALL
	S/R		W4134	1014Z			31-53-11	ALL
	S/R		W4134	1016Z			27-33-11	ALL
	S/R		W4134	1019Z			27-33-11	ALL
	S/R		W4134	1020Z			27-33-11	ALL
	S/R		W4134	1101Z			27-23-11	ALL
	S/R		W4134	1102Z			27-23-11	ALL
	S/R		W4134	2001Z			27-25-11	ALL
	S/R		W4134	2202Z			27-28-11	ALL
	S/R		W4134	2203Z			27-28-11	ALL
	S/R		W4134	2204Z			27-28-11	ALL
	S/R		W4134	3203Z			27-28-11	ALL
	S/R		W4134	3204Z			27-21-11	ALL
D40842P		**AB1050L/297/L013**		**PLUG-CONDUCTIVE**				**ALL**
	1		W6134	0001	20		27-25-11	ALL
	2	UNUSED						ALL
	3		W6134	3215R	20		27-21-11	ALL
	4		W6134	3215Y	20		27-21-11	ALL
	5		W6134	3215B	20		27-21-11	ALL
	6		W6134	2029B	20		27-28-11	ALL
	7		W6134	2029R	20		27-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40842P	**AB1050L/297/L013**		**PLUG-CONDUCTIVE (continued)**				**ALL**
8		W6134	0507	20		27-31-37	ALL
9		W6134	0508	20		27-31-37	ALL
10		W6134	0509	20		27-31-37	ALL
11		W6134	0510	20		27-31-37	ALL
12		W6134	0513	20		31-53-11	ALL
13		W6134	0514	20		31-53-11	ALL
14		W6134	3203B	20		27-28-11	ALL
15		W6134	3203R	20		27-28-11	ALL
16		W6134	2202B	20		27-28-11	ALL
17		W6134	2202R	20		27-28-11	ALL
18		W6134	2203B	20		27-28-11	ALL
19		W6134	2203R	20		27-28-11	ALL
20		W6134	0540	20		27-23-11	ALL
21		W6134	0551	20		27-23-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W6134	1104	20		27-33-11	ALL
25		W6134	1106	20		27-33-11	ALL
26		W6134	1105	20		27-33-11	ALL
27		W6134	3203Y	20		27-28-11	ALL
28	UNUSED						ALL
29		W6134	0002	20		27-25-11	ALL
30		W6134	2206R	20		27-25-11	ALL
31		W6134	2206B	20		27-25-11	ALL
S/R		W6134	1104Z			27-33-11	ALL
S/R		W6134	1105Z			27-33-11	ALL
S/R		W6134	1106Z			27-33-11	ALL
S/R		W6134	2206Z			27-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40844J		**578/154/L007**		**RCPT-**				**ALL**
	1		W5504	1001	20		21-51-11	ALL
	2		W5504	1002	20		21-42-11	ALL
	3		W5504	1003	20		21-51-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	S/R		W5504	1001Z			21-51-11	ALL
	S/R		W5504	1002Z			21-42-11	ALL
	S/R		W5504	1003Z			21-51-11	ALL
D40844P		**578/154/L007**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5502	1016	20		21-51-11	ALL
	2		W5502	1017	20		21-42-11	ALL
	3		W5502	1018	20		21-51-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	S/R		W5502	1017Z			21-42-11	ALL
	S/R		W5502	1018Z			21-51-11	ALL
D40845J		**E006-02/ /**		**RCPT-**				**ALL**
	1		W0626	4504Z			49-71-21	ALL
	2	UNUSED						ALL
	3		W0626	0004	16		49-62-11	ALL
	4	UNUSED						ALL
	5	4G	W0626	4504G	20		49-71-21	ALL
	6	4K	W0626	4504W	20		49-71-21	ALL
	7	4G	W0626	4502G	20		49-71-21	ALL
	8	4K	W0626	4502W	20		49-71-21	ALL
	9		W0626	4502Z			49-71-21	ALL
	10	UNUSED						ALL
D40845P		**E006-02/ /**		**PLUG-**				**ALL**
	1		W5726	4504Z			49-71-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40845P	**E006-02/ /**		**PLUG- (continued)**				**ALL**
2	UNUSED						ALL
3		W5726	0613	16		49-62-11	ALL
4	UNUSED						ALL
5	4H	W5726	4504G	20		49-71-21	ALL
6	4L	W5726	4504W	20		49-71-21	ALL
7	4H	W5726	4502G	20		49-71-21	ALL
8	4L	W5726	4502W	20		49-71-21	ALL
9		W5726	4502Z			49-71-21	ALL
10	UNUSED						ALL
D40846J	**558/155/R08**		**RCPT-**				**ALL**
1		W6504	1001	20		21-51-21	ALL
2		W6504	1002	20		21-42-11	ALL
3		W6504	1003	20		21-51-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
S/R		W6504	1001Z			21-51-21	ALL
S/R		W6504	1002Z			21-42-11	ALL
S/R		W6504	1003Z			21-51-21	ALL
D40846P	**558/155/R008**		**PLUG-CONDUCTIVE**				**ALL**
1		W6502	1013	20		21-51-21	ALL
2		W6502	1014	20		21-42-11	ALL
3		W6502	1015	20		21-51-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
S/R		W6502	1014Z			21-42-11	ALL
S/R		W6502	1015Z			21-51-21	ALL
D40847J	**E006-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0626	0045	24		49-41-11	ALL
A02		W0626	0043	24		49-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40847J		**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A03		W0626	0046	24		49-52-31	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0626	2013R	20		49-41-11	ALL
	A10		W0626	0042	24		49-41-11	ALL
	B01		W0626	0044	24		49-41-11	ALL
	B02	UNUSED						ALL
	B03		W0626	0047	24		49-52-31	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0626	2013B	20		49-41-11	ALL
	B09		W0626	0041	24		49-41-11	ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0626	2013Z			49-41-11	ALL
D40847P		**E006-02/ /**		**PLUG-**				**ALL**
	A01		W5726	0505	24		49-41-11	ALL
	A02		W5726	0502	24		49-41-11	ALL
	A03		W5726	0507	24		49-52-31	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40847P	**E006-02/ /**		**PLUG- (continued)**				**ALL**
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W5726	2204R	20		49-41-11	ALL
A10		W5726	0503	24		49-41-11	ALL
B01		W5726	0501	24		49-41-11	ALL
B02	UNUSED						ALL
B03		W5726	0512	24		49-52-31	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W5726	2204B	20		49-41-11	ALL
B09		W5726	0504	24		49-41-11	ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W5726	2204Z			49-41-11	ALL
D40854J	**AB1050R/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W4724	2224R	22		49-62-51	ALL
2		W4724	2224B	22		49-62-51	ALL
3		W4724	3201Y	22		49-52-31	ALL
4		W4724	2214B	22		49-62-12	ALL
5		W4724	2215R	22		49-62-12	ALL
6		W4724	2216B	22		49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40854J		**AB1050R/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	7		W4724	2204B	20		49-41-11	ALL
	8		W4724	2204R	20		49-41-11	ALL
	9		W4724	1018	20		49-52-31	ALL
	10		W4724	1016	20		49-52-31	ALL
	11		W4724	2205B	22		49-52-31	ALL
	12		W4724	2205R	22		49-52-31	ALL
	13		W4724	3201B	22		49-52-31	ALL
	14		W4724	3201R	22		49-52-31	ALL
	15		W4724	2215B	22		49-62-12	ALL
	16		W4724	2206B	22		49-52-31	ALL
	17		W4724	2206R	22		49-52-31	ALL
	18		W4724	2207B	22		49-52-31	ALL
	19		W4724	2207R	22		49-52-31	ALL
	20		W4724	3202B	22		49-52-31	ALL
	21		W4724	3202R	22		49-52-31	ALL
	22		W4724	2219B	22		49-62-12	ALL
	23		W4724	3203Y	22		49-62-12	ALL
	24		W4724	2208B	22		49-52-31	ALL
	25	UNUSED						ALL
	26		W4724	1009	20		33-44-12	ALL
	27	UNUSED						ALL
	28		W4724	2214R	22		49-62-12	ALL
	29		W4724	1037	20		33-43-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W4724	2216R	22		49-62-12	ALL
	33		W4724	1218	20		49-62-12	ALL
	34		W4724	1210	20		49-62-12	ALL
	35		W4724	2217B	22		49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40854J	**AB1050R/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
36		W4724	2217R	22		49-62-12	ALL
37		W4724	2218B	22		49-62-12	ALL
38		W4724	2218R	22		49-62-12	ALL
39		W4724	3202Y	22		49-52-31	ALL
40		W4724	2219R	22		49-62-12	ALL
41		W4724	3203B	22		49-62-12	ALL
42		W4724	3203R	22		49-62-12	ALL
43		W4724	2208R	22		49-52-31	ALL
44		W4724	1019	20		33-35-11	ALL
45		W4724	1005	20		33-35-11	ALL
46	18	W4724	1001	18		33-35-11	ALL
47	UNUSED						ALL
48		W4724	1110R	20		26-11-31	ALL
49	18	W4724	1108R	18		26-11-31	ALL
50		W4724	1029	20		49-94-21	ALL
51		W4724	1035	20		49-94-21	ALL
52		W4724	1036	20		49-94-21	ALL
53		W4724	1208	20		49-62-12	ALL
54		W4724	1033	20		49-94-21	ALL
55		W4724	1209	20		49-62-12	ALL
S/R		W4724	1037Z			33-43-11	ALL
S/R		W4724	1108Z			26-11-31	ALL
S/R		W4724	1110Z			26-11-31	ALL
S/R		W4724	2204Z			49-41-11	ALL
S/R		W4724	2205Z			49-52-31	ALL
S/R		W4724	2206Z			49-52-31	ALL
S/R		W4724	2207Z			49-52-31	ALL
S/R		W4724	2208Z			49-52-31	ALL
S/R		W4724	2214Z			49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40854J		**AB1050R/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	S/R		W4724	2215Z			49-62-12	ALL
	S/R		W4724	2216Z			49-62-12	ALL
	S/R		W4724	2217Z			49-62-12	ALL
	S/R		W4724	2218Z			49-62-12	ALL
	S/R		W4724	2219Z			49-62-12	ALL
	S/R		W4724	2224Z			49-62-51	ALL
	S/R		W4724	3201Z			49-52-31	ALL
	S/R		W4724	3202Z			49-52-31	ALL
	S/R		W4724	3203Z			49-62-12	ALL
	S/R		W4724	FRAD			49-62-12	ALL
	S/R		W4724	FRAQ			33-35-11	ALL
	S/R		W4724	FRBA			49-94-21	ALL
			W4724	1001Z			33-35-11	ALL
			W4724	1005Z			33-35-11	ALL
			W4724	1009Z			33-44-12	ALL
			W4724	1016Z			49-52-31	ALL
			W4724	1018Z			49-52-31	ALL
			W4724	1019Z			33-35-11	ALL
			W4724	1029Z			49-94-21	ALL
			W4724	1033Z			49-94-21	ALL
			W4724	1035Z			49-94-21	ALL
			W4724	1036Z			49-94-21	ALL
			W4724	1208Z			49-62-12	ALL
			W4724	1209Z			49-62-12	ALL
			W4724	1210Z			49-62-12	ALL
			W4724	1218Z			49-62-12	ALL
			W4724	FRAD			49-62-12	ALL
			W4724	FRAQ			33-35-11	ALL
			W4724	FRBA			49-94-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40854P	**AB1050R/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5726	0517	22		49-62-51	ALL
2		W5726	0518	22		49-62-51	ALL
3		W5726	3201Y	22		49-52-31	ALL
4		W5726	2214B	22		49-62-12	ALL
5		W5726	2215R	22		49-62-12	ALL
6		W5726	2216B	22		49-62-12	ALL
7		W5726	2204B	20		49-41-11	ALL
8		W5726	2204R	20		49-41-11	ALL
9		W5726	0514	22		49-52-31	ALL
10		W5726	0564	22		49-52-31	ALL
11		W5726	2205B	22		49-52-31	ALL
12		W5726	2205R	22		49-52-31	ALL
13		W5726	3201B	22		49-52-31	ALL
14		W5726	3201R	22		49-52-31	ALL
15		W5726	2215B	22		49-62-12	ALL
16		W5726	2206B	22		49-52-31	ALL
17		W5726	2206R	22		49-52-31	ALL
18		W5726	2207B	22		49-52-31	ALL
19		W5726	2207R	22		49-52-31	ALL
20		W5726	3202B	22		49-52-31	ALL
21		W5726	3202R	22		49-52-31	ALL
22		W5726	2219B	22		49-62-12	ALL
23		W5726	3203Y	22		49-62-12	ALL
24		W5726	2208B	22		49-52-31	ALL
25	UNUSED						ALL
26		W5726	0003	20		33-44-12	ALL
27	UNUSED						ALL
28		W5726	2214R	22		49-62-12	ALL
29		W5726	0552	20		33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40854P		**AB1050R/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W5726	2216R	22		49-62-12	ALL
	33		W5726	1005	22		49-62-12	ALL
	34		W5726	1006	22		49-62-12	ALL
	35		W5726	2217B	22		49-62-12	ALL
	36		W5726	2217R	22		49-62-12	ALL
	37		W5726	2218B	22		49-62-12	ALL
	38		W5726	2218R	22		49-62-12	ALL
	39		W5726	3202Y	22		49-52-31	ALL
	40		W5726	2219R	22		49-62-12	ALL
	41		W5726	3203B	22		49-62-12	ALL
	42		W5726	3203R	22		49-62-12	ALL
	43		W5726	2208R	22		49-52-31	ALL
	44		W5726	0021	20		33-35-11	ALL
	45		W5726	0032	20		33-35-11	ALL
	46	18	W5726	0001	18		33-35-11	ALL
	47	UNUSED						ALL
	48		W5726	1110R	20		26-11-31	ALL
	49	18	W5726	1108R	18		26-11-31	ALL
	50		W5726	0559	22		49-94-21	ALL
	51		W5726	0561	22		49-94-21	ALL
	52		W5726	0562	22		49-94-21	ALL
	53		W5726	1002	22		49-62-12	ALL
	54		W5726	0588	22		49-94-21	ALL
	55		W5726	1003	22		49-62-12	ALL
	S/R		W5726	1002Z			49-62-12	ALL
	S/R		W5726	1003Z			49-62-12	ALL
	S/R		W5726	1005Z			49-62-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40854P		**AB1050R/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W5726	1006Z			49-62-12	ALL
	S/R		W5726	1108Z			26-11-31	ALL
	S/R		W5726	1110Z			26-11-31	ALL
	S/R		W5726	2204Z			49-41-11	ALL
	S/R		W5726	2205Z			49-52-31	ALL
	S/R		W5726	2206Z			49-52-31	ALL
	S/R		W5726	2207Z			49-52-31	ALL
	S/R		W5726	2208Z			49-52-31	ALL
	S/R		W5726	2214Z			49-62-12	ALL
	S/R		W5726	2215Z			49-62-12	ALL
	S/R		W5726	2216Z			49-62-12	ALL
	S/R		W5726	2217Z			49-62-12	ALL
	S/R		W5726	2218Z			49-62-12	ALL
	S/R		W5726	2219Z			49-62-12	ALL
	S/R		W5726	3201Z			49-52-31	ALL
	S/R		W5726	3202Z			49-52-31	ALL
	S/R		W5726	3203Z			49-62-12	ALL
D40858J		**J020-00/ /**		**RCPT-**				**ALL**
	1		W0072	0601	20		28-23-11	ALL
	2		W0072	0602	20		28-23-11	ALL
	3		W0072	0603	20		28-23-11	ALL
	4		W0072	0608	20		28-23-11	ALL
	5		W0072	0609	20		28-23-11	ALL
	6		W0072	0606	20		28-23-11	ALL
	7		W0072	0612	20		28-23-11	ALL
	8		W0072	0613	20		28-23-11	ALL
	9		W0072	0614	20		28-23-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40858J		**J020-00/ /**		**RCPT- (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0072	0194	20		47-30-11	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W0072	0157	20		47-30-11	ALL
D40858P		**J020-00/ /**		**PLUG-**				**ALL**
	1		W5158	0101	20		28-23-11	ALL
	2		W5158	0102	20		28-23-11	ALL
	3		W5158	0103	20		28-23-11	ALL
	4		W5158	0104	20		28-23-11	ALL
	5		W5158	0105	20		28-23-11	ALL
	6		W5158	0106	20		28-23-11	ALL
	7		W5158	0110	20		28-23-11	ALL
	8		W5158	0109	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40858P	**J020-00/ /**		**PLUG- (continued)**				**ALL**
9		W5158	0108	20		28-23-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W5158	0609	20		47-30-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	16	W5158	0638	16		47-30-11	ALL
D40874J	**240/185/R036**		**RCPT**				**ALL**
1		W6024	3503Y	22		23-41-11	ALL
2		W6024	3503R	22		23-41-11	ALL
3		W6024	3503B	22		23-41-11	ALL
4		W6024	3503Z			23-41-11	ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40874J		**240/185/R036**		**RCPT (continued)**				**ALL**
	6	UNUSED						ALL
D40874P		**239/185/R036**		**PLUG**				**ALL**
	1		W5337	3503Y	22		23-41-11	ALL
	2		W5337	3503R	22		23-41-11	ALL
	3		W5337	3503B	22		23-41-11	ALL
	4		W5337	3503Z			23-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
D40875J		**249/185/R037**		**RCPT**				**ALL**
	1		W6024	3504Y	22		23-41-11	ALL
	2		W6024	3504R	22		23-41-11	ALL
	3		W6024	3504B	22		23-41-11	ALL
	4		W6024	3504Z			23-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
D40875P		**248/185/R037**		**PLUG**				**ALL**
	1		W5337	3504Y	22		23-41-11	ALL
	2		W5337	3504R	22		23-41-11	ALL
	3		W5337	3504B	22		23-41-11	ALL
	4		W5337	3504Z			23-41-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
D40876J		**AB1050R/299/R007**		**RCPT-CONDUCTIVE**				**ALL**
	1		W4726	3204B	16		24-21-31	ALL
	2		W4726	3204R	16		24-21-31	ALL
	3		W4726	3204Y	16		24-21-31	ALL
	4		W4726	3204Z			24-21-31	ALL
	5		W4726	2236R	16		24-21-31	ALL
	6		W4726	2236B	16		24-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40876J	**AB1050R/299/R007**		**RCPT-CONDUCTIVE (continued)**				**ALL**
7		W4726	2236Z			24-21-31	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
S/R		W4726	YAAA			24-21-31	ALL
D40876P	**AB1050R/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5726	3204B	16		24-21-31	ALL
2		W5726	3204R	16		24-21-31	ALL
3		W5726	3204Y	16		24-21-31	ALL
4		W5726	3204Z			24-21-31	ALL
5		W5726	2236R	16		24-21-31	ALL
6		W5726	2236B	16		24-21-31	ALL
7		W5726	2236Z			24-21-31	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
D40878J	**AJ0020C/ /**		**RCPT- CONDUCTIVE**				**ALL**
1		W0074	0183	24		21-31-22	ALL
2		W0074	0184	24		21-31-22	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0074	0008	24		21-51-12	ALL
10	UNUSED						ALL
11		W0074	0192	20		21-31-22	ALL
12		W0074	0053	22		27-61-43	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40878P		**AJ0020C/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W5156	0054	24		21-31-22	ALL
	2		W5156	0055	24		21-31-22	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5156	0039	24		21-51-12	ALL
	10	UNUSED						ALL
	11		W5156	0056	20		21-31-22	ALL
	12		W5156	0121	20		27-61-43	ALL
D40884J		**AJ0020A/ /**		**RCPT- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0074	0208	20		28-44-11	ALL
	7	UNUSED						ALL
	8		W0074	2001R	22		27-61-43	ALL
	9		W0074	2001B	22		27-61-43	ALL
	10		W0074	0206	20		47-30-11	ALL
	11	UNUSED						ALL
	12		W0074	0193	24		21-31-23	ALL
	13		W0074	0194	24		21-31-23	ALL
	14		W0074	0202	20		21-31-23	ALL
	15		W0074	0007	22		26-16-21	ALL
	16		W0074	0290	22		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40884J	**AJ0020A/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
17		W0074	0291	22		32-31-12	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0074	0213	22		27-33-11	ALL
21		W0074	0214	22		27-33-11	ALL
22		W0074	0215	22		27-33-11	ALL
23		W0074	0212	22		27-33-11	ALL
24		W0074	0211	22		27-33-11	ALL
25		W0074	0210	22		27-33-11	ALL
26		W0074	0015	24		21-51-22	ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
D40884P	**AJ0020A/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5158	0637	20		28-44-11	ALL
7	UNUSED						ALL
8		W5158	2004R	22		27-61-43	ALL
9		W5158	2004B	22		27-61-43	ALL
10		W5158	0636	20		47-30-11	ALL
11	UNUSED						ALL
12		W5158	0020	24		21-31-23	ALL
13		W5158	0021	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40884P		**AJ0020A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	14		W5158	0022	20		21-31-23	ALL
	15		W5158	0031	22		26-16-21	ALL
	16		W5158	0219	22		32-31-12	ALL
	17		W5158	0218	22		32-31-12	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5158	0050	22		27-33-11	ALL
	21		W5158	0051	22		27-33-11	ALL
	22		W5158	0052	22		27-33-11	ALL
	23		W5158	0053	22		27-33-11	ALL
	24		W5158	0054	22		27-33-11	ALL
	25		W5158	0055	22		27-33-11	ALL
	26		W5158	0699	24		21-51-22	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
D40893J		**248/185/R36**		**RCPT-**				**ALL**
	1		W6024	2201B	22		24-41-11	ALL
	2	UNUSED						ALL
	3		W6024	2201R	22		24-41-11	ALL
D40893P		**248/185/R036**		**PLUG**				**ALL**
	1		W3309	2201B	22		24-41-11	ALL
	2	UNUSED						ALL
	3		W3309	2201R	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40904J	**E004-01/ /**		**RCPT-**				**ALL**
A01		W0410	0032	24		49-52-31	ALL
A02		W0410	0034	24		49-52-31	ALL
A03		W0410	0036	22		49-52-31	ALL
A04		W0410	2510R	24		34-51-11	ALL
A05	UNUSED						ALL
A06		W0410	2030R	24		34-32-11	ALL
A07		W0410	0280	24		31-35-05	ALL
A08		W0410	0281	24		31-35-05	ALL
A09		W0410	0240	24		34-61-17	ALL
A10	UNUSED						ALL
B01		W0410	0033	24		49-52-31	ALL
B02		W0410	0035	24		49-52-31	ALL
B03	UNUSED						ALL
B04		W0410	2510B	24		34-51-11	ALL
B05		W0410	2510ZI			34-51-11	ALL
B06		W0410	2030B	24		34-32-11	ALL
B07		W0410	2030ZI			34-32-11	ALL
B08	UNUSED						ALL
B09		W0410	0489	24		34-61-17	ALL
B10	UNUSED						ALL
PERG	1F	W0410	2030ZO			34-32-11	ALL
PERG	1F	W0410	2510ZO			34-51-11	ALL
D40904P	**E004-01/ /**		**PLUG-**				**ALL**
A01		W5726	0508	24		49-52-31	ALL
A02		W5726	0510	24		49-52-31	ALL
A03		W5726	0522	22		49-52-31	ALL
A04		W5726	2502R	24		34-51-11	ALL
A05	UNUSED						ALL
A06		W5726	2501R	24		34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40904P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A07		W5726	6014	24		31-35-05	ALL
	A08		W5726	6015	24		31-35-05	ALL
	A09		W5726	6017	24		34-61-17	ALL
	A10	UNUSED						ALL
	B01		W5726	0509	24		49-52-31	ALL
	B02		W5726	0513	24		49-52-31	ALL
	B03	UNUSED						ALL
	B04		W5726	2502B	24		34-51-11	ALL
	B05		W5726	2502ZI			34-51-11	ALL
	B06		W5726	2501B	24		34-32-11	ALL
	B07		W5726	2501ZI			34-32-11	ALL
	B08	UNUSED						ALL
	B09		W5726	6018	24		34-61-17	ALL
	B10	UNUSED						ALL
	PERG	1F	W5726	2501ZO			34-32-11	ALL
	PERG	1F	W5726	2502ZO			34-51-11	ALL
D40908J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0495	24		49-52-31	ALL
	A02		W0321	2022R	22		49-62-11	ALL
	A03		W0321	2183R	24		73-24-12	ALL
	A04		W0321	0216	24		21-51-11	ALL
	A05		W0321	2283R	24		34-33-11	ALL
	A06		W0321	2012R	24		34-33-11	ALL
	A07		W0321	0016	24		34-61-17	ALL
	A08		W0321	0018	24		34-61-17	ALL
	A09		W0321	2366R	24		34-51-11	ALL
	A10		W0321	2346R	24		34-32-11	ALL
	B01		W0321	0490	24		49-62-11	ALL
	B02		W0321	2022B	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40908J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B03		W0321	2183B	24		73-24-12	ALL
B04		W0321	2346ZI			34-32-11	ALL
B05		W0321	2283B	24		34-33-11	ALL
B06		W0321	2012B	24		34-33-11	ALL
B07		W0321	0434	24		31-35-05	ALL
B08		W0321	0435	24		31-35-05	ALL
B09		W0321	2366B	24		34-51-11	ALL
B10		W0321	2346B	24		34-32-11	ALL
DED		W0321	2366ZI			34-51-11	ALL
PERG	1F	W0321	2012Z			34-33-11	ALL
PERG	1F	W0321	2022Z			49-62-11	ALL
PERG	1F	W0321	2183Z			73-24-12	ALL
PERG	1F	W0321	2283Z			34-33-11	ALL
PERG	1F	W0321	2346ZO			34-32-11	ALL
PERG	1F	W0321	2366ZO			34-51-11	ALL
D40908P	**E003-02/ /**		**PLUG-**				**ALL**
A01		W5726	0507	24		49-52-31	ALL
A02		W5726	2213R	22		49-62-11	ALL
A03		W5726	2601R	24		73-24-12	ALL
A04		W5726	5501	24		21-51-11	ALL
A05		W5726	2234R	24		34-33-11	ALL
A06		W5726	2244R	24		34-33-11	ALL
A07		W5726	6017	24		34-61-17	ALL
A08		W5726	6018	24		34-61-17	ALL
A09		W5726	2502R	24		34-51-11	ALL
A10		W5726	2501R	24		34-32-11	ALL
B01		W5726	0529	22		49-62-11	ALL
B02		W5726	2213B	22		49-62-11	ALL
B03		W5726	2601B	24		73-24-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40908P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	B04		W5726	2501ZI			34-32-11	ALL
	B05		W5726	2234B	24		34-33-11	ALL
	B06		W5726	2244B	24		34-33-11	ALL
	B07		W5726	6014	24		31-35-05	ALL
	B08		W5726	6015	24		31-35-05	ALL
	B09		W5726	2502B	24		34-51-11	ALL
	B10		W5726	2501B	24		34-32-11	ALL
	DED		W5726	2502ZI			34-51-11	ALL
	PERG	1F	W5726	2213Z			49-62-11	ALL
	PERG	1F	W5726	2234Z			34-33-11	ALL
	PERG	1F	W5726	2244Z			34-33-11	ALL
	PERG	1F	W5726	2501ZO			34-32-11	ALL
	PERG	1F	W5726	2502ZO			34-51-11	ALL
	PERG	1F	W5726	2601Z			73-24-12	ALL
D40910J		**E002-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0212	3005R	20		24-22-31	ALL
	A02		W0212	3005Y	20		24-22-31	ALL
	A03		W0212	4006R	20		24-24-31	ALL
	A04		W0212	4006G	20		24-24-31	ALL
	A05		W0212	4005B	22		24-24-31	ALL
	A06		W0212	4005G	22		24-24-31	ALL
	A07	UNUSED						ALL
	A08		W0212	2003R	22		24-21-31	ALL
	A09		W0212	2010R	22		24-23-11	ALL
	A10		W0212	2008R	22		24-22-31	ALL
	B01		W0212	3005B	20		24-22-31	ALL
	B02		W0212	4006B	20		24-24-31	ALL
	B03		W0212	4006Y	20		24-24-31	ALL
	B04		W0212	4005R	22		24-24-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40910J		**E002-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B05		W0212	4005Y	22		24-24-31	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0212	2003B	22		24-21-31	ALL
	B09		W0212	2010B	22		24-23-11	ALL
	B10		W0212	2008B	22		24-22-31	ALL
	F		W0212	4002R	20		24-21-31	ALL
	G		W0212	4002B	20		24-21-31	ALL
	H		W0212	4002Y	20		24-21-31	ALL
	J		W0212	4002G	20		24-21-31	ALL
	K	UNUSED						ALL
	DED		W0212	2003Z			24-21-31	ALL
	DED		W0212	2008Z			24-22-31	ALL
	DED		W0212	3005Z			24-22-31	ALL
	DED		W0212	4006Z			24-24-31	ALL
	PERG	1F	W0212	2010Z			24-23-11	ALL
D40910P		**E002-01/ /**		**PLUG-**				**ALL**
	A01		W5726	3205R	20		24-22-31	ALL
	A02		W5726	3205Y	20		24-22-31	ALL
	A03		W5726	4103R	20		24-24-31	ALL
	A04		W5726	4103G	20		24-24-31	ALL
	A05		W5726	4104B	22		24-24-31	ALL
	A06		W5726	4104G	22		24-24-31	ALL
	A07	UNUSED						ALL
	A08		W5726	2235R	22		24-21-31	ALL
	A09		W5726	2237R	22		24-23-11	ALL
	A10		W5726	2239R	22		24-22-31	ALL
	B01		W5726	3205B	20		24-22-31	ALL
	B02		W5726	4103B	20		24-24-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40910P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	B03		W5726	4103Y	20		24-24-31	ALL
	B04		W5726	4104R	22		24-24-31	ALL
	B05		W5726	4104Y	22		24-24-31	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W5726	2235B	22		24-21-31	ALL
	B09		W5726	2237B	22		24-23-11	ALL
	B10		W5726	2239B	22		24-22-31	ALL
	F		W5726	4102R	20		24-21-31	ALL
	G		W5726	4102B	20		24-21-31	ALL
	H		W5726	4102Y	20		24-21-31	ALL
	J		W5726	4102G	20		24-21-31	ALL
	K	UNUSED						ALL
	DED		W5726	2235Z			24-21-31	ALL
	DED		W5726	2239Z			24-22-31	ALL
	PERG	1F	W5726	2237Z			24-23-11	ALL
	PERG	1F	W5726	4103Z			24-24-31	ALL
D40912J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0389R	20		26-21-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0220	0023	20		33-44-12	ALL
	A05	UNUSED						ALL
	A06		W0220	0143	20		33-43-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0220	2001R	22		24-21-31	ALL
	A10		W0220	2002Z			24-21-31	ALL
	B01		W0220	0388R	20		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40912J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0220	0221	24		49-52-31	ALL
	B08	UNUSED						ALL
	B09		W0220	2001B	22		24-21-31	ALL
	B10		W0220	3001Z			24-21-31	ALL
	F		W0220	2002R	16		24-21-31	ALL
	G		W0220	2002B	16		24-21-31	ALL
	H		W0220	3001R	16		24-21-31	ALL
	J		W0220	3001B	16		24-21-31	ALL
	K		W0220	3001Y	16		24-21-31	ALL
	DED		W0220	2001Z			24-21-31	ALL
D40912P		**E002-02/ /**		**PLUG-**				**ALL**
	A01		W5726	1103R	20		26-21-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5726	0003	20		33-44-12	ALL
	A05	UNUSED						ALL
	A06		W5726	0552	20		33-43-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5726	2235R	22		24-21-31	ALL
	A10		W5726	2236Z			24-21-31	ALL
	B01		W5726	1105R	20		26-21-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40912P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5726	0512	24		49-52-31	ALL
	B08	UNUSED						ALL
	B09		W5726	2235B	22		24-21-31	ALL
	B10		W5726	3204Z			24-21-31	ALL
	F		W5726	2236R	16		24-21-31	ALL
	G		W5726	2236B	16		24-21-31	ALL
	H		W5726	3204R	16		24-21-31	ALL
	J		W5726	3204B	16		24-21-31	ALL
	K		W5726	3204Y	16		24-21-31	ALL
	DED		W5726	1103Z			26-21-11	ALL
	DED		W5726	1105Z			26-21-11	ALL
	DED		W5726	2235Z			24-21-31	ALL
D40914J		**P001-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0001	0138	24		32-42-11	ALL
	A03		W0001	0140	24		32-42-11	ALL
	A04		W0001	0142	24		32-42-11	ALL
	A05	UNUSED						ALL
	A06		W0001	0144	24		32-42-11	ALL
	A07		W0001	0148	24		32-42-11	ALL
	A08		W0001	1313	24		32-41-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0001	0136	24		32-42-11	ALL
	B02		W0001	0139	24		32-42-11	ALL
	B03		W0001	0141	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40914J		**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B04		W0001	0143	24		32-42-11	ALL
	B05	UNUSED						ALL
	B06		W0001	0147	22		32-42-11	ALL
	B07		W0001	1316	24		32-41-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0001	1313Z			32-41-11	ALL
	PERG	1F	W0001	1316Z			32-41-11	ALL
D40914P		**P009-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W2022	0503	24		32-42-11	ALL
	A03		W2022	0505	24		32-42-11	ALL
	A04		W2022	0507	24		32-42-11	ALL
	A05	UNUSED						ALL
	A06		W2022	0509	24		32-42-11	ALL
	A07		W2022	0511	24		32-42-11	ALL
	A08		W2022	0513	24		32-41-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2022	0502	24		32-42-11	ALL
	B02		W2022	0504	24		32-42-11	ALL
	B03		W2022	0506	24		32-42-11	ALL
	B04		W2022	0508	24		32-42-11	ALL
	B05	UNUSED						ALL
	B06		W2022	0510	22		32-42-11	ALL
	B07		W2022	0512	24		32-41-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40914P		**P009-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
D40924J		**P003-00/ /**		**RCPT-- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W0003	0712	16		33-11-32	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0001	0239	20		33-18-21	ALL
	10	UNUSED						ALL
	11		W0003	1704	20		33-18-24	ALL
	12		W0001	0237	20		33-18-21	ALL
	13		W0001	0241	20		33-18-21	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W0001	1530	20		33-18-11	ALL
	18		W0001	1531	20		33-18-11	ALL
	19		W0001	1250	20		33-18-62	ALL
	20		W0001	1251	20		33-18-62	ALL
	21	UNUSED						ALL
	22		W0003	0694	20		33-18-22	ALL
	23		W0003	0610	22		29-32-11	ALL
	24		W0001	0174	20		31-52-11	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40924J	**P003-00/ /**		**RCPT-- CONDUCTIVE (continued)**				**ALL**
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W0001	1309	22		32-31-11	ALL
32	UNUSED						ALL
S/R		W0001	1250Z			33-18-62	ALL
S/R		W0001	1251Z			33-18-62	ALL
S/R		W0001	1309Z			32-31-11	ALL
S/R		W0001	1530Z			33-18-11	ALL
S/R		W0001	1531Z			33-18-11	ALL
S/R		W0003	1704Z			33-18-24	ALL
D40924P	**P009-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W2030	5506	16		33-11-32	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W2030	5512	20		33-18-21	ALL
10	UNUSED						ALL
11		W2030	5514	20		33-18-24	ALL
12		W2030	5511	20		33-18-21	ALL
13		W2030	5513	20		33-18-21	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W2030	5509	20		33-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40924P		**P009-00/ /**		**PLUG- (continued)**				**ALL**
	18		W2030	5525	20		33-18-11	ALL
	19		W2030	5521	20		33-18-62	ALL
	20		W2030	5517	20		33-18-62	ALL
	21	UNUSED						ALL
	22		W2030	5520	20		33-18-22	ALL
	23		W2030	5528	22		29-32-11	ALL
	24		W2030	5524	20		31-52-11	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W2030	5529	22		32-31-11	ALL
	32	UNUSED						ALL
D40926J		**E002-01/ /**		**RCPT-**				**ALL**
	A01		W0212	0058	22		49-62-11	ALL
	A02		W0212	0061	22		49-62-11	ALL
	A03		W0212	0065	22		49-94-21	ALL
	A04		W0212	0014	22		24-21-31	ALL
	A05		W0212	0016	22		24-21-31	ALL
	A06		W0212	0030	22		24-22-31	ALL
	A07		W0212	2015R	22		49-62-11	ALL
	A08	UNUSED						ALL
	A09		W0212	0093	22		49-62-11	ALL
	A10	UNUSED						ALL
	B01		W0212	0060	22		49-62-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40926J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	B04		W0212	0015	22		24-21-31	ALL
	B05		W0212	0041	24		24-28-41	ALL
	B06		W0212	0029	22		24-22-31	ALL
	B07		W0212	2015B	22		49-62-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40926P		**E002-01/ /**		**PLUG-**				**ALL**
	A01		W5726	0525	22		49-62-11	ALL
	A02		W5726	0527	22		49-62-11	ALL
	A03		W5726	0558	22		49-94-21	ALL
	A04		W5726	0566	22		24-21-31	ALL
	A05		W5726	0568	22		24-21-31	ALL
	A06		W5726	0571	22		24-22-31	ALL
	A07		W5726	2212R	22		49-62-11	ALL
	A08	UNUSED						ALL
	A09		W5726	0541	22		49-62-11	ALL
	A10	UNUSED						ALL
	B01		W5726	0526	22		49-62-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5726	0567	22		24-21-31	ALL
	B05		W5726	0570	24		24-28-41	ALL
	B06		W5726	0572	22		24-22-31	ALL
	B07		W5726	2212B	22		49-62-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40928J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	2029R	24		49-41-11	ALL
	A02	UNUSED						ALL
	A03		W0220	0122	24		49-41-11	ALL
	A04		W0220	0120	24		49-41-11	ALL
	A05		W0220	0123	24		49-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0220	2029B	24		49-41-11	ALL
	B02	UNUSED						ALL
	B03		W0220	0119	24		49-41-11	ALL
	B04		W0220	0121	24		49-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40928P		**E002-02/ /**		**PLUG-**				**ALL**
	A01		W5726	2238R	24		49-41-11	ALL
	A02	UNUSED						ALL
	A03		W5726	0501	24		49-41-11	ALL
	A04		W5726	0503	24		49-41-11	ALL
	A05		W5726	0505	24		49-41-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40928P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5726	2238B	24		49-41-11	ALL
	B02	UNUSED						ALL
	B03		W5726	0502	24		49-41-11	ALL
	B04		W5726	0504	24		49-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40930J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0422	0097	22		24-22-31	ALL
	A02	UNUSED						ALL
	A03		W0422	0502	20		27-81-51	ALL
	A04		W0422	2005R	22		24-23-11	ALL
	A05		W0422	0136	22		24-41-11	ALL
	A06	UNUSED						ALL
	A07		W0422	0222	24		24-28-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0422	0100	22		24-22-31	ALL
	B01		W0422	0099	22		24-22-31	ALL
	B02	UNUSED						ALL
	B03		W0422	2005B	22		24-23-11	ALL
	B04		W0422	0098	22		24-22-31	ALL
	B05		W0422	0145	22		24-22-11	ALL
	B06		W0422	0184	22		24-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40930J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B07		W0422	0223	24		24-28-41	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0422	0146	22		24-22-31	ALL
	PERG	1F	W0422	2005Z			24-23-11	ALL
D40930P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W5612	0522	22		24-22-31	ALL
	A02	UNUSED						ALL
	A03		W5612	0549	20		27-81-51	ALL
	A04		W5612	2203R	22		24-23-11	ALL
	A05		W5612	0536	22		24-41-11	ALL
	A06	UNUSED						ALL
	A07		W5612	0207	24		24-28-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5612	0525	22		24-22-31	ALL
	B01		W5612	0524	22		24-22-31	ALL
	B02	UNUSED						ALL
	B03		W5612	2203B	22		24-23-11	ALL
	B04		W5612	0526	22		24-22-31	ALL
	B05		W5612	0539	22		24-22-11	ALL
	B06		W5612	0553	22		24-22-31	ALL
	B07		W5612	0208	24		24-28-41	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5612	0540	22		24-22-31	ALL
D40933J		**727A+10/295/R022**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40933J	**727A+10/295/R022**		**RCPT- (continued)**				**ALL**
3	UNUSED						ALL
4		W3755	0052	16		44-35-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40933P	**727A+10/295/R022**		**PLUG**				**ALL**
1		W3453	0032	20		44-35-11	ALL
2		W3453	0028	20		44-35-11	ALL
3		W3453	0029	20		44-35-11	ALL
4		W3453	0042	16		44-35-11	ALL
5		W3453	0031	20		44-35-11	ALL
6		W3453	0030	20		44-35-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D40934J	**E002-01/ /**		**RCPT-**				**ALL**
A01		W0212	0002	22		21-27-31	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40934J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0212	0053	18		24-32-11	ALL
	G		W0212	0054	18		24-32-11	ALL
	H	UNUSED						ALL
	J		W0212	0052	18		24-32-11	ALL
	K	UNUSED						ALL
D40934P		**E002-01/ /**		**PLUG-**				**ALL**
	A01		W5112	5501	22		21-27-31	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40934P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5112	0507	18		24-32-11	ALL
	G		W5112	0508	18		24-32-11	ALL
	H	UNUSED						ALL
	J		W5112	0506	18		24-32-11	ALL
	K	UNUSED						ALL
D40938J		**E004-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02		W0422	2006R	22		24-23-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0422	0247	20		28-23-11	ALL
	A07		W0422	0249	20		28-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0422	2017R	22		24-41-11	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40938J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B02		W0422	2006B	22		24-23-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0422	0171	20		28-23-11	ALL
	B07		W0422	0238	20		28-23-11	ALL
	B08		W0422	0173	20		28-23-11	ALL
	B09	UNUSED						ALL
	B10		W0422	2017B	22		24-41-11	ALL
	F	UNUSED						ALL
	G		W0422	3202R	18		28-23-11	ALL
	H		W0422	3202Y	18		28-23-11	ALL
	J		W0422	3202B	18		28-23-11	ALL
	K	UNUSED						ALL
	PERG	1F	W0422	2006Z			24-23-21	ALL
	PERG	1F	W0422	2017Z			24-41-11	ALL
D40938P		**E004-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W6210	2201R	22		24-23-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W6210	0214	20		28-23-11	ALL
	A07		W6210	0215	20		28-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6210	1002	22		24-41-11	ALL
	B01	UNUSED						ALL
	B02		W6210	2201B	22		24-23-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40938P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W6210	0516	20		28-23-11	ALL
	B07		W6210	0517	20		28-23-11	ALL
	B08		W6210	0518	20		28-23-11	ALL
	B09	UNUSED						ALL
	B10		W6210	1003	22		24-41-11	ALL
	F	UNUSED						ALL
	G		W6210	3205R	18		28-23-11	ALL
	H		W6210	3205Y	18		28-23-11	ALL
	J		W6210	3205B	18		28-23-11	ALL
	K	UNUSED						ALL
	PERG	1F	W6210	1002Z			24-41-11	ALL
	PERG	1F	W6210	1003Z			24-41-11	ALL
	PERG	1F	W6210	2201Z			24-23-21	ALL
D40944J		**P001-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0001	0264	20		33-14-11	ALL
	A02		W0001	0267	20		33-14-11	ALL
	A03		W0001	0269	20		33-14-11	ALL
	A04	UNUSED						ALL
	A05		W0001	0279	20		33-14-11	ALL
	A06		W0001	0273	20		33-14-11	ALL
	A07		W0001	0275	20		33-14-11	ALL
	A08		W0001	0277	20		33-14-11	ALL
	A09		W0001	0280	20		33-14-11	ALL
	A10	UNUSED						ALL
	B01		W0001	0268	20		33-14-11	ALL
	B02		W0001	0266	20		33-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40944J		**P001-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B03		W0001	0270	20		33-14-11	ALL
	B04	UNUSED						ALL
	B05		W0001	0278	20		33-14-11	ALL
	B06		W0001	0276	20		33-14-11	ALL
	B07		W0001	0274	20		33-14-11	ALL
	B08		W0001	0271	20		33-14-11	ALL
	B09		W0001	0272	20		33-14-11	ALL
	B10	UNUSED						ALL
D40944P		**P009-00/ /**		**PLUG-**				**ALL**
	A01		W5202	5501	20		33-14-11	ALL
	A02		W5202	5504	20		33-14-11	ALL
	A03		W5202	5508	20		33-14-11	ALL
	A04	UNUSED						ALL
	A05		W5202	5521	20		33-14-11	ALL
	A06		W5202	5525	20		33-14-11	ALL
	A07		W5202	5527	20		33-14-11	ALL
	A08		W5202	5517	20		33-14-11	ALL
	A09		W5202	5522	20		33-14-11	ALL
	A10	UNUSED						ALL
	B01		W5202	5505	20		33-14-11	ALL
	B02		W5202	5503	20		33-14-11	ALL
	B03		W5202	5509	20		33-14-11	ALL
	B04	UNUSED						ALL
	B05		W5202	5519	20		33-14-11	ALL
	B06		W5202	5526	20		33-14-11	ALL
	B07		W5202	5528	20		33-14-11	ALL
	B08		W5202	5518	20		33-14-11	ALL
	B09		W5202	5520	20		33-14-11	ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40946J	**E002-02/ /**		**RCPT-**				**ALL**
A01		W0220	0233	22		49-62-11	ALL
A02		W0220	0103	22		49-62-11	ALL
A03		W0220	0386R	20		26-11-31	ALL
A04	UNUSED						ALL
A05		W0220	0003	22		24-21-31	ALL
A06		W0220	0001	22		24-21-31	ALL
A07		W0220	4001Y	20		24-21-31	ALL
A08		W0220	4001R	20		24-21-31	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0220	0245	20		49-41-11	ALL
B02		W0220	0107	22		49-62-11	ALL
B03		W0220	0387R	20		26-11-31	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0220	0002	22		24-21-31	ALL
B07		W0220	4001G	20		24-21-31	ALL
B08		W0220	4001B	20		24-21-31	ALL
B09	UNUSED						ALL
B10		W0220	0237	20		38-32-12	ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K		W0220	0236	18		38-32-12	ALL
DED		W0220	4001Z			24-21-31	ALL
D40946P	**E002-02/ /**		**PLUG-**				**ALL**
A01		W5726	0528	22		49-62-11	ALL
A02		W5726	0521	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40946P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	A03		W5726	6001R	20		26-11-31	ALL
	A04	UNUSED						ALL
	A05		W5726	0568	22		24-21-31	ALL
	A06		W5726	0566	22		24-21-31	ALL
	A07		W5726	4101Y	20		24-21-31	ALL
	A08		W5726	4101R	20		24-21-31	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5726	0599	20		49-62-11	ALL
	B02		W5726	0520	22		49-62-11	ALL
	B03		W5726	1110R	20		26-11-31	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5726	0567	22		24-21-31	ALL
	B07		W5726	4101G	20		24-21-31	ALL
	B08		W5726	4101B	20		24-21-31	ALL
	B09	UNUSED						ALL
	B10		W5726	0593	20		38-32-12	ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K		W5726	0594	18		38-32-12	ALL
	DED		W5726	1110Z			26-11-31	ALL
D40947J		**AP0600A/ /**		**RCPT-**				**ALL**
	A-1		W0041	4001R	24		46-13-11	ALL
	A-2		W0041	4001Y	24		46-13-11	ALL
	A-3		W0041	4001B	24		46-13-11	ALL
	A-4		W0041	4001G	24		46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40947J		**AP0600A/ /**		**RCPT- (continued)**				**ALL**
	B-1		W0041	4002R	24		46-13-11	ALL
	B-2		W0041	4002Y	24		46-13-11	ALL
	B-3		W0041	4002B	24		46-13-11	ALL
	B-4		W0041	4002G	24		46-13-11	ALL
	=CA		W0041	4001Z			46-13-11	ALL
	=CB		W0041	4002Z			46-13-11	ALL
D40947P		**P006-00/ /**		**PLUG**				**ALL**
	A-1		W2031	4001R	24		46-13-11	ALL
	A-2		W2031	4001Y	24		46-13-11	ALL
	A-3		W2031	4001B	24		46-13-11	ALL
	A-4		W2031	4001G	24		46-13-11	ALL
	B-1		W2031	4002R	24		46-13-11	ALL
	B-2		W2031	4002Y	24		46-13-11	ALL
	B-3		W2031	4002B	24		46-13-11	ALL
	B-4		W2031	4002G	24		46-13-11	ALL
	=CA		W2031	4001Z			46-13-11	ALL
	=CB		W2031	4002Z			46-13-11	ALL
D40948J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	2182R	24		27-81-22	ALL
	A02		W0111	2201R	24		27-81-22	ALL
	A03		W0111	2202R	24		27-81-22	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0111	2182B	24		27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40948J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	B02		W0111	2201B	24		27-81-22	ALL
	B03		W0111	2202B	24		27-81-22	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40948P		**E001-01/ /**		**PLUG-**				**ALL**
	A01		W6166	2213R	24		27-81-22	ALL
	A02		W6166	2214R	24		27-81-22	ALL
	A03		W6166	2215R	24		27-81-22	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6166	2213B	24		27-81-22	ALL
	B02		W6166	2214B	24		27-81-22	ALL
	B03		W6166	2215B	24		27-81-22	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40948P		**E001-01/ /**		**PLUG- (continued)**				**ALL**
	B10	UNUSED						ALL
D40950J		**E003-02/ /**		**RCPT**				**ALL**
	A01		W0321	0957	22		26-19-11	ALL
	A02	UNUSED						ALL
	A03		W0321	0956	20		78-34-11	ALL
	A04		W0321	0959	22		26-19-11	ALL
	A05		W0321	0329	20		78-34-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0321	0958	22		26-19-11	ALL
	B04		W0321	0960	22		26-19-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0321	1790	24		21-27-31	ALL
D40950P		**E003-02/ /**		**PLUG**				**ALL**
	A01		W5506	0087	22		26-19-11	ALL
	A02	UNUSED						ALL
	A03		W5506	0117	20		78-34-11	ALL
	A04		W5506	0089	22		26-19-11	ALL
	A05		W5506	0118	20		78-34-11	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40950P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5506	0088	22		26-19-11	ALL
	B04		W5506	0090	22		26-19-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5506	5525	24		21-27-31	ALL
D40951J		**E003-02/ /**		**RCPT**				**ALL**
	A01		W0321	1792	24		21-43-21	ALL
	A02		W0321	1793	24		21-43-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0321	1795	24		21-51-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0321	1075	24		21-25-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40951J		**E003-02/ /**		**RCPT (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40951P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W5506	5526	24		21-25-11	ALL
	A02		W5506	5527	24		21-25-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5506	0604	24		21-51-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5506	0603	24		21-25-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D40952J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40952J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A02		W0321	0586	22		27-62-11	ALL
	A03		W0321	0587	22		27-62-11	ALL
	A04		W0321	0588	22		27-62-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0321	2117R	24		27-32-22	ALL
	A08	UNUSED						ALL
	A09		W0321	0622	22		27-61-45	ALL
	A10	UNUSED						ALL
	A11		W0321	0609	22		27-61-42	ALL
	A12	UNUSED						ALL
	A13		W0321	0526	20		47-30-11	ALL
	A14	UNUSED						ALL
	A15		W0321	0328	22		32-64-21	ALL
	A16		W0321	2236R	20		32-49-11	ALL
	A17		W0321	0287	24		27-32-21	ALL
	A18		W0321	0527	20		47-30-11	ALL
	A19		W0321	0213	24		21-31-24	ALL
	A20		W0321	2236B	20		32-49-11	ALL
	B01		W0321	2074R	22		32-46-11	ALL
	B02		W0321	2074B	22		32-46-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0321	0528	20		47-30-11	ALL
	B06		W0321	0495	24		49-52-31	ALL
	B07		W0321	2117B	24		27-32-22	ALL
	B08		W0321	0762	22		27-61-41	ALL
	B09		W0321	0525	20		47-30-11	ALL
	B10		W0321	0945	22		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40952J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B11		W0321	0263	22		27-32-21	ALL
	B12		W0321	0961	22		27-61-49	ALL
	B13		W0321	0355	22		32-64-21	ALL
	B14		W0321	0290	24		29-33-11	ALL
	B15		W0321	0826	22		27-62-11	ALL
	B16		W0321	0381	22		27-61-49	ALL
	B17		W0321	0382	22		27-61-49	ALL
	B18	UNUSED						ALL
	B19		W0321	0821	22		27-62-11	ALL
	B20		W0321	0822	22		27-62-11	ALL
	PERG	1F	W0321	2074Z			32-46-11	ALL
	PERG	1F	W0321	2117Z			27-32-22	ALL
	PERG	1F	W0321	2236Z			32-49-11	ALL
D40952P		**E003-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W5160	0171	20		27-62-11	ALL
	A03		W5160	0172	20		27-62-11	ALL
	A04		W5160	0174	20		27-62-11	ALL
	A05		W5160	0620	20		SPARE	ALL
	A06	UNUSED						ALL
	A07		W5160	2003R	24		27-32-22	ALL
	A08	UNUSED						ALL
	A09		W5160	0159	22		27-61-45	ALL
	A10	UNUSED						ALL
	A11		W5160	0308	22		27-61-42	ALL
	A12	UNUSED						ALL
	A13		W5160	0321	20		47-30-11	ALL
	A14	UNUSED						ALL
	A15		W5160	0560	22		32-64-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40952P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	A16		W5160	2202R	20		32-49-11	ALL
	A17		W5160	0567	22		27-32-21	ALL
	A18		W5160	0322	20		47-30-11	ALL
	A19		W5160	5503	24		21-31-24	ALL
	A20		W5160	2202B	20		32-49-11	ALL
	B01		W5160	2102R	22		32-46-11	ALL
	B02		W5160	2102B	22		32-46-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5160	0323	20		47-30-11	ALL
	B06		W5160	0612	22		49-52-31	ALL
	B07		W5160	2003B	24		27-32-22	ALL
	B08		W5160	0195	22		27-61-41	ALL
	B09		W5160	0320	20		47-30-11	ALL
	B10		W5160	0177	22		27-62-11	ALL
	B11		W5160	0506	22		27-32-21	ALL
	B12		W5160	0717	22		27-61-49	ALL
	B13		W5160	0611	22		32-64-21	ALL
	B14		W5160	0527	20		29-33-11	ALL
	B15		W5160	0176	22		27-62-11	ALL
	B16		W5160	0196	22		27-61-49	ALL
	B17		W5160	0197	22		27-61-49	ALL
	B18	UNUSED						ALL
	B19		W5160	0658	22		27-62-11	ALL
	B20		W5160	0659	22		27-62-11	ALL
	PERG	1F	W5160	2003Z			27-32-22	ALL
	PERG	1F	W5160	2102Z			32-46-11	ALL
	PERG	1F	W5160	2202Z			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40953J	**E006-03/*/***		**RCPT-**				**ALL**
1		W0631	0009	22		44-21-22	ALL
2	UNUSED						ALL
3		W0631	0008	22		44-21-22	ALL
4		W0631	0024	22		44-21-22	ALL
5	UNUSED						ALL
6		W0631	0025	22		44-21-22	ALL
7		W0631	0023	20		44-35-11	ALL
8		W0631	0058	20		44-35-11	ALL
9		W0631	0062	22		44-35-12	ALL
10		W0631	2530R	22		44-35-12	ALL
11		W0631	2530B	22		44-35-12	ALL
12		W0631	2531R	22		44-35-12	ALL
13		W0631	2531B	22		44-35-12	ALL
14		W0631	2532R	22		44-35-12	ALL
15		W0631	2532B	22		44-35-12	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0631	0020	22		44-21-22	ALL
24		W0631	0021	22		44-21-22	ALL
25		W0631	0022	22		44-21-22	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40953J		**E006-03/*/***		**RCPT- (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W0631	2530Z			44-35-12	ALL
	PERB		W0631	2531Z			44-35-12	ALL
	PERB		W0631	2532Z			44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40953P	**E006-03/ /**		**PLUG-**				**ALL**
1		W4477	0002	22		44-21-22	ALL
2		W4477	0003	22		44-21-22	ALL
3		W4477	0013	22		44-21-22	ALL
4		W4477	0014	22		44-21-22	ALL
5	UNUSED						ALL
6		W4477	0016	22		44-21-22	ALL
7		W4477	0328	20		44-35-11	ALL
8		W4477	0329	20		44-35-11	ALL
9		W4477	0026	22		44-35-12	ALL
10		W4477	2530R	22		44-35-12	ALL
11		W4477	2530B	22		44-35-12	ALL
12		W4477	2531R	22		44-35-12	ALL
13		W4477	2531B	22		44-35-12	ALL
14		W4477	2532R	22		44-35-12	ALL
15		W4477	2532B	22		44-35-12	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W4477	0011	22		44-21-22	ALL
24		W4477	0021	22		44-21-22	ALL
25		W4477	0025	22		44-21-22	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40953P	**E006-03/ /**		**PLUG- (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
PERB		W4477	2530Z			44-35-12	ALL
PERB		W4477	2531Z			44-35-12	ALL
PERB		W4477	2532Z			44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40964J	**E006-03/ /**		**RCPT**				**ALL**
A-1		W0631	4032Y	24		44-35-05	ALL
A-2		W0631	4032R	24		44-35-05	ALL
A-3		W0631	4032G	24		44-35-05	ALL
A-4		W0631	4032B	24		44-35-05	ALL
B-1	UNUSED						ALL
B-2	UNUSED						ALL
B-3	UNUSED						ALL
B-4	UNUSED						ALL
C-1	UNUSED						ALL
C-2	UNUSED						ALL
C-3	UNUSED						ALL
C-4	UNUSED						ALL
D-1	UNUSED						ALL
D-2	UNUSED						ALL
D-3	UNUSED						ALL
D-4	UNUSED						ALL
=CA		W0631	4032Z			44-35-05	ALL
=CB	UNUSED						ALL
=CC	UNUSED						ALL
=CD	UNUSED						ALL
D40964P	**E006-03/ /**		**PLUG**				**ALL**
A-1		W4479	4001Y	24		44-35-05	ALL
A-2		W4479	4001R	24		44-35-05	ALL
A-3		W4479	4001G	24		44-35-05	ALL
A-4		W4479	4001B	24		44-35-05	ALL
B-1		W4479	4002Y	24		44-35-05	ALL
B-2		W4479	4002R	24		44-35-05	ALL
B-3		W4479	4002G	24		44-35-05	ALL
B-4		W4479	4002B	24		44-35-05	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40964P		**E006-03/ /**		**PLUG (continued)**				**ALL**
	C-1	UNUSED						ALL
	C-2	UNUSED						ALL
	C-3	UNUSED						ALL
	C-4	UNUSED						ALL
	D-1	UNUSED						ALL
	D-2	UNUSED						ALL
	D-3	UNUSED						ALL
	D-4	UNUSED						ALL
	=CA		W4479	4001Z			44-35-05	ALL
	=CB		W4479	4002Z			44-35-05	ALL
	=CC	UNUSED						ALL
	=CD	UNUSED						ALL
D40968J		**AB0839L/302/L12**		**RCPT**				**ALL**
	3		W3755	2508R	22		44-35-12	ALL
	4		W3755	2508B	22		44-35-12	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W3755	2509R	22		44-35-12	ALL
	9		W3755	2509B	22		44-35-12	ALL
	10	UNUSED						ALL
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40968J		**AB0839L/302/L12**		**RCPT (continued)**				**ALL**
	=C1	UNUSED						ALL
	=C2	UNUSED						ALL
	PERB		W3755	2508Z			44-35-12	ALL
	PERB		W3755	2509Z			44-35-12	ALL
D40968P		**AB0839L/302/L12**		**INSERT - PLUG**				**ALL**
	3		W4477	2506R	22		44-35-12	ALL
	4		W4477	2506B	22		44-35-12	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W4477	2507R	22		44-35-12	ALL
	9		W4477	2507B	22		44-35-12	ALL
	10	UNUSED						ALL
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	=C1	UNUSED						ALL
	=C2	UNUSED						ALL
	PERB		W4477	2506Z			44-35-12	ALL
	PERB		W4477	2507Z			44-35-12	ALL
D40973J		**E006-03/ /**		**RCPT-**				**ALL**
	U-1	UNUSED						ALL
	U-2	UNUSED						ALL
	U-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40973J		**E006-03/ /**		**RCPT- (continued)**				**ALL**
	U-4	UNUSED						ALL
	V-1		W0631	4013Y	24		44-35-12	ALL
	V-2		W0631	4013R	24		44-35-12	ALL
	V-3		W0631	4013G	24		44-35-12	ALL
	V-4		W0631	4013B	24		44-35-12	ALL
	A		W0631	2508R	24		44-35-12	ALL
	B		W0631	2508B	24		44-35-12	ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P	UNUSED						ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	=CU	UNUSED						ALL
	=CV		W0631	4013Z			44-35-12	ALL
	PERB		W0631	2508Z			44-35-12	ALL
D40973P		**AE0603A/ /**		**PLUG**				**ALL**
	U-1		W4479	4003Y	24		44-35-12	ALL
	U-2		W4479	4003R	24		44-35-12	ALL
	U-3		W4479	4003G	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40973P	**AE0603A/ /**		**PLUG (continued)**				**ALL**
U-4		W4479	4003B	24		44-35-12	ALL
V-1		W4479	4004Y	24		44-35-12	ALL
V-2		W4479	4004R	24		44-35-12	ALL
V-3		W4479	4004G	24		44-35-12	ALL
V-4		W4479	4004B	24		44-35-12	ALL
A		W4479	2501R	24		44-35-12	ALL
B		W4479	2501B	24		44-35-12	ALL
C	UNUSED						ALL
D	UNUSED						ALL
E	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M	UNUSED						ALL
N	UNUSED						ALL
P	UNUSED						ALL
R	UNUSED						ALL
S	UNUSED						ALL
T	UNUSED						ALL
=CU		W4479	4003Z			44-35-12	ALL
=CV		W4479	4004Z			44-35-12	ALL
PERB		W4479	2501Z			44-35-12	ALL
D40975J	**AB0839L/302/L12**		**RCPT**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40975J		**AB0839L/302/L12**		**RCPT (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W3755	4013R	24		44-35-12	ALL
	1-2		W3755	4013Y	24		44-35-12	ALL
	1-3		W3755	4013B	24		44-35-12	ALL
	1-4		W3755	4013G	24		44-35-12	ALL
	2-1		W3755	4014R	24		44-35-12	ALL
	2-2		W3755	4014Y	24		44-35-12	ALL
	2-3		W3755	4014B	24		44-35-12	ALL
	2-4		W3755	4014G	24		44-35-12	ALL
	=C1		W3755	4013Z			44-35-12	ALL
	=C2		W3755	4014Z			44-35-12	ALL
D40975P		**AB0839L/302/L12**		**PLUG**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W4479	4005R	24		44-35-12	ALL
	1-2		W4479	4005Y	24		44-35-12	ALL
	1-3		W4479	4005B	24		44-35-12	ALL
	1-4		W4479	4005G	24		44-35-12	ALL
	2-1		W4479	4006R	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40975P	**AB0839L/302/L12**		**PLUG (continued)**				**ALL**
2-2		W4479	4006Y	24		44-35-12	ALL
2-3		W4479	4006B	24		44-35-12	ALL
2-4		W4479	4006G	24		44-35-12	ALL
=C1		W4479	4005Z			44-35-12	ALL
=C2		W4479	4006Z			44-35-12	ALL
D40979J	**AB0839L/302/L12**		**PLUG**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W4479	4007R	24		44-35-12	ALL
1-2		W4479	4007Y	24		44-35-12	ALL
1-3		W4479	4007B	24		44-35-12	ALL
1-4		W4479	4007G	24		44-35-12	ALL
2-1		W4479	4008R	24		44-35-12	ALL
2-2		W4479	4008Y	24		44-35-12	ALL
2-3		W4479	4008B	24		44-35-12	ALL
2-4		W4479	4008G	24		44-35-12	ALL
=C1		W4479	4007Z			44-35-12	ALL
=C2		W4479	4008Z			44-35-12	ALL
D40981J	**AB0839L/302/L12**		**INSERT**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40981J		**AB0839L/302/L12**		**INSERT (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W3755	4001Y	24		44-35-22	ALL
	1-2		W3755	4001R	24		44-35-22	ALL
	1-3		W3755	4001G	24		44-35-22	ALL
	1-4		W3755	4001B	24		44-35-22	ALL
	2-1		W3755	4002Y	24		44-35-22	ALL
	2-2		W3755	4002R	24		44-35-22	ALL
	2-3		W3755	4002G	24		44-35-22	ALL
	2-4		W3755	4002B	24		44-35-22	ALL
	=C1		W3755	4001Z			44-35-22	ALL
	=C2		W3755	4002Z			44-35-22	ALL
D40981P		**AB0839L/302/L12**		**INSERT - PLUG**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W4479	4020Y	24		44-35-22	ALL
	1-2		W4479	4020R	24		44-35-22	ALL
	1-3		W4479	4020G	24		44-35-22	ALL
	1-4		W4479	4020B	24		44-35-22	ALL
	2-1		W4479	4021Y	24		44-35-22	ALL
	2-2		W4479	4021R	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40981P	**AB0839L/302/L12**		**INSERT - PLUG (continued)**				**ALL**
2-3		W4479	4021G	24		44-35-22	ALL
2-4		W4479	4021B	24		44-35-22	ALL
=C1		W4479	4020Z			44-35-22	ALL
=C2		W4479	4021Z			44-35-22	ALL
D40983J	**E006-03/ /**		**RCPT**				**ALL**
A-1		W0631	4014R	24		44-35-12	ALL
A-2		W0631	4014Y	24		44-35-12	ALL
A-3		W0631	4014B	24		44-35-12	ALL
A-4		W0631	4014G	24		44-35-12	ALL
B-1		W0631	4033R	24		44-35-12	ALL
B-2		W0631	4033Y	24		44-35-12	ALL
B-3		W0631	4033B	24		44-35-12	ALL
B-4		W0631	4033G	24		44-35-12	ALL
C-1		W0631	4034R	24		44-35-12	ALL
C-2		W0631	4034Y	24		44-35-12	ALL
C-3		W0631	4034B	24		44-35-12	ALL
C-4		W0631	4034G	24		44-35-12	ALL
D-1		W0631	4035R	24		44-35-12	ALL
D-2		W0631	4035Y	24		44-35-12	ALL
D-3		W0631	4035B	24		44-35-12	ALL
D-4		W0631	4035G	24		44-35-12	ALL
=CA		W0631	4014Z			44-35-12	ALL
=CB		W0631	4033Z			44-35-12	ALL
=CC		W0631	4034Z			44-35-12	ALL
=CD		W0631	4035Z			44-35-12	ALL
D40983P	**E006-03/ /**		**PLUG**				**ALL**
A-1		W4479	4005R	24		44-35-12	ALL
A-2		W4479	4005Y	24		44-35-12	ALL
A-3		W4479	4005B	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D40983P		**E006-03/ /**		**PLUG (continued)**				**ALL**
	A-4		W4479	4005G	24		44-35-12	ALL
	B-1		W4479	4006R	24		44-35-12	ALL
	B-2		W4479	4006Y	24		44-35-12	ALL
	B-3		W4479	4006B	24		44-35-12	ALL
	B-4		W4479	4006G	24		44-35-12	ALL
	C-1		W4479	4007R	24		44-35-12	ALL
	C-2		W4479	4007Y	24		44-35-12	ALL
	C-3		W4479	4007B	24		44-35-12	ALL
	C-4		W4479	4007G	24		44-35-12	ALL
	D-1		W4479	4008R	24		44-35-12	ALL
	D-2		W4479	4008Y	24		44-35-12	ALL
	D-3		W4479	4008B	24		44-35-12	ALL
	D-4		W4479	4008G	24		44-35-12	ALL
	=CA		W4479	4005Z			44-35-12	ALL
	=CB		W4479	4006Z			44-35-12	ALL
	=CC		W4479	4007Z			44-35-12	ALL
	=CD		W4479	4008Z			44-35-12	ALL
D40985J		**AB0857L/302/L014**		**INSERT**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W3477	4001Y	24		44-21-12	ALL
	1-2		W3477	4001R	24		44-21-12	ALL
	1-3		W3477	4001G	24		44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40985J	**AB0857L/302/L014**		**INSERT (continued)**				**ALL**
1-4		W3477	4001B	24		44-21-12	ALL
2-1		W3477	4002Y	24		44-21-12	ALL
2-2		W3477	4002R	24		44-21-12	ALL
2-3		W3477	4002G	24		44-21-12	ALL
2-4		W3477	4002B	24		44-21-12	ALL
=C1		W3477	4001Z			44-21-12	ALL
=C2		W3477	4002Z			44-21-12	ALL
D40985P	**AB0857L/302/L014**		**INSERT PLUG**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W4477	4001Y	24		44-21-12	ALL
1-2		W4477	4001R	24		44-21-12	ALL
1-3		W4477	4001G	24		44-21-12	ALL
1-4		W4477	4001B	24		44-21-12	ALL
2-1		W4477	4002Y	24		44-21-12	ALL
2-2		W4477	4002R	24		44-21-12	ALL
2-3		W4477	4002G	24		44-21-12	ALL
2-4		W4477	4002B	24		44-21-12	ALL
=C1		W4477	4001Z			44-21-12	ALL
=C2		W4477	4002Z			44-21-12	ALL
D40999J	**411/198/R002**		**RCPT-**				**ALL**
1		W5602	2501R	24		23-27-37	ALL
2		W5602	2501B	24		23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D40999J		**411/198/R002**		**RCPT- (continued)**				**ALL**
	3		W5602	2501Z			23-27-37	ALL
D40999P		**411/198/R002**		**PLUG -**				**ALL**
	1		W5111	2196R	24		23-27-37	ALL
	2		W5111	2196B	24		23-27-37	ALL
	3		W5111	2196Z			23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41012J	**E002-02/ /**		**RCPT-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W0220	0049	24		21-31-23	ALL
A09		W0220	2502R	24		36-21-11	ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0220	2502B	24		36-21-11	ALL
B10	UNUSED						ALL
PERG	1F	W0220	2502Z			36-21-11	ALL
D41012P	**E002-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41012P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	A08		W6214	0212	24		21-31-23	ALL
	A09		W6214	2501R	24		36-21-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W6214	2501B	24		36-21-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W6214	2501Z			36-21-11	ALL
D41023J		**E001-01/ /**		**RCPT-**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0111	4002Z			46-13-11	ALL
	1-1		W0111	4002R	24		46-13-11	ALL
	1-2		W0111	4002Y	24		46-13-11	ALL
	1-3		W0111	4002B	24		46-13-11	ALL
	1-4		W0111	4002G	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41023J	**E001-01/ /**		**RCPT- (continued)**				**ALL**
3-4	UNUSED						ALL
D41023P	**E001-01/ /**		**PLUG**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W2043	4001Z			46-13-11	ALL
1-1		W2043	4001R	24		46-13-11	ALL
1-2		W2043	4001Y	24		46-13-11	ALL
1-3		W2043	4001B	24		46-13-11	ALL
1-4		W2043	4001G	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
D41027J	**412/276/R55**		**RCPT, RECTANGULAR**				**ALL**
1		W4116	0001	24		21-61-13	ALL
2		W4116	2001B	24		21-61-13	ALL
3		W4116	2001R	24		21-61-13	ALL
4		W4116	2002R	24		21-61-13	ALL
5		W4116	2002B	24		21-61-13	ALL
6		W4116	0002	20		21-61-13	ALL
7		W4116	0003	20		21-61-13	ALL
8		W4116	0004	20		21-61-51	ALL
9		W4116	0005	20		21-61-51	ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41027J		**412/276/R55**		**RCPT, RECTANGULAR (continued)**				**ALL**
	12	UNUSED						ALL
D41027P		**412/275/R055**		**PLUG, RECTANGULAR**				**ALL**
	1		W6288	0003	24		21-61-13	ALL
	2		W6288	2002B	24		21-61-13	ALL
	3		W6288	2002R	24		21-61-13	ALL
	4		W6288	2003R	24		21-61-13	ALL
	5		W6288	2003B	24		21-61-13	ALL
	6		W6288	0004	20		21-61-13	ALL
	7		W6288	0005	20		21-61-13	ALL
	8		W6288	0014	20		21-61-51	ALL
	9		W6288	0013	24		21-61-51	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D41028J		**727F+18/283/R051**		**RCPT, RECTANGULAR**				**ALL**
	1		W4118	0001	24		21-61-14	ALL
	2		W4118	2001B	24		21-61-14	ALL
	3		W4118	2001R	24		21-61-14	ALL
	4		W4118	2002R	24		21-61-14	ALL
	5		W4118	2002B	24		21-61-14	ALL
	6		W4118	0002	20		21-61-14	ALL
	7		W4118	0003	20		21-61-14	ALL
	8		W4118	0004	20		21-61-51	ALL
	9		W4118	0005	20		21-61-51	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
D41028P		**727F+17/283/R051**		**PLUG, RECTANGULAR**				**ALL**
	1		W6288	0008	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41028P	**727F+17/283/R051**		**PLUG, RECTANGULAR (continued)**				**ALL**
2		W6288	2005B	24		21-61-14	ALL
3		W6288	2005R	24		21-61-14	ALL
4		W6288	2006R	24		21-61-14	ALL
5		W6288	2006B	24		21-61-14	ALL
6		W6288	0009	20		21-61-14	ALL
7		W6288	0010	20		21-61-14	ALL
8		W6288	0016	20		21-61-51	ALL
9		W6288	0015	20		21-61-51	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
D41032J	**E003-03/ /**		**RCPT- CONDUCTIVE**				**ALL**
A01		W0330	0526	24		21-51-22	ALL
A02		W0330	0339	24		21-51-22	ALL
A03		W0330	0461	24		21-51-22	ALL
A04		W0330	2033R	24		21-51-22	ALL
A05		W0330	0463	22		21-61-15	ALL
A06		W0330	3002R	24		21-51-22	ALL
A07		W0330	3002Y	24		21-51-22	ALL
A08		W0330	2034R	24		21-51-22	ALL
A09		W0330	2033B	24		21-51-22	ALL
A10		W0330	3002B	24		21-51-22	ALL
B01		W0330	0375	24		21-51-24	ALL
B02		W0330	0376	24		21-51-24	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0330	2034B	24		21-51-22	ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41032J		**E003-03/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0330	2033Z			21-51-22	ALL
	PERG	1F	W0330	2034Z			21-51-22	ALL
	PERG	1F	W0330	3002Z			21-51-22	ALL
D41032P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W6420	0301	24		21-51-22	ALL
	A02		W6420	0302	24		21-51-22	ALL
	A03		W6420	0303	24		21-51-22	ALL
	A04		W6420	2002R	24		21-51-22	ALL
	A05		W6420	0309	22		21-61-15	ALL
	A06		W6420	3001R	24		21-51-22	ALL
	A07		W6420	3001Y	24		21-51-22	ALL
	A08		W6420	2003R	24		21-51-22	ALL
	A09		W6420	2002B	24		21-51-22	ALL
	A10		W6420	3001B	24		21-51-22	ALL
	B01		W6420	0311	24		21-51-24	ALL
	B02		W6420	0310	24		21-51-24	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W6420	2003B	24		21-51-22	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6420	2002Z			21-51-22	ALL
	PERG	1F	W6420	2003Z			21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41032P	**E003-03/ /**		**PLUG- (continued)**				**ALL**
PERG	1F	W6420	3001Z			21-51-22	ALL
D41033J	**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0131	2060R	24		34-21-13	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0131	2060B	24		34-21-13	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0131	2060Z			34-21-13	ALL
D41033P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5719	2009R	24		34-21-13	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W5719	2010R	24		SPARE	ALL
A05		W5719	2011R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41033P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5719	2009B	24		34-21-13	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5719	2010B	24		SPARE	ALL
	B05		W5719	2011B	24		SPARE	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5719	2009Z			34-21-13	ALL
	PERG	1F	W5719	2010Z			SPARE	ALL
	PERG	1F	W5719	2011Z			SPARE	ALL
D41037J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0131	2513R	24		32-41-11	ALL
	A02		W0131	2522Z			29-32-11	ALL
	A03		W0131	2522R	22		29-32-11	ALL
	A04		W0131	2573R	24		31-65-15	ALL
	A05		W0131	0044	22		27-62-11	ALL
	A06		W0131	2565R	24		31-65-15	ALL
	A07		W0131	2031R	22		32-46-11	ALL
	A08		W0131	2031B	22		32-46-11	ALL
	A09		W0131	4501W	22		32-46-11	ALL
	A10		W0131	4501G	22		32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41037J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B01		W0131	2513B	24		32-41-11	ALL
B02		W0131	2513Z			32-41-11	ALL
B03		W0131	2522B	22		29-32-11	ALL
B04		W0131	2573B	24		31-65-15	ALL
B05		W0131	0046	22		27-62-11	ALL
B06		W0131	2565B	24		31-65-15	ALL
B07		W0131	2034R	22		32-49-11	ALL
B08		W0131	2034B	22		32-49-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0131	2031Z			32-46-11	ALL
PERG	1F	W0131	2034Z			32-49-11	ALL
PERG	1F	W0131	2565Z			31-65-15	ALL
PERG	1F	W0131	2573Z			31-65-15	ALL
PERG	1F	W0131	4501Z			32-46-11	ALL
D41037P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5156	2215R	22		32-41-11	ALL
A02		W5156	2001Z			29-32-11	ALL
A03		W5156	2001R	22		29-32-11	ALL
A04		W5156	2402R	24		31-65-15	ALL
A05		W5156	0716	22		27-62-11	ALL
A06		W5156	2101R	24		31-65-15	ALL
A07		W5156	2102R	22		32-46-11	ALL
A08		W5156	2102B	22		32-46-11	ALL
A09		W5156	4501W	20		32-46-11	ALL
A10		W5156	4501G	20		32-46-11	ALL
B01		W5156	2215B	22		32-41-11	ALL
B02		W5156	2215Z			32-41-11	ALL
B03		W5156	2001B	22		29-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41037P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B04		W5156	2402B	24		31-65-15	ALL
	B05		W5156	0717	22		27-62-11	ALL
	B06		W5156	2101B	24		31-65-15	ALL
	B07		W5156	2216R	20		32-49-11	ALL
	B08		W5156	2216B	20		32-49-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	2101Z			31-65-15	ALL
	PERG	1F	W5156	2102Z			32-46-11	ALL
	PERG	1F	W5156	2216Z			32-49-11	ALL
	PERG	1F	W5156	2402Z			31-65-15	ALL
	PERG	1F	W5156	4501Z			32-46-11	ALL
D41039J		**E003-01/ /**		**RCPT - CONDUCTTIVE**				**ALL**
	A01		W0313	2769R	24		31-65-25	ALL
	A02		W0311	0107	22		21-27-31	ALL
	A03	UNUSED						ALL
	A04		W0311	2781R	22		28-41-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0313	2769B	24		31-65-25	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0311	2781B	22		28-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41039J	**E003-01/ /**		**RCPT - CONDUCTTIVE (continued)**				**ALL**
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0311	2781Z			28-41-11	ALL
PERG	1F	W0313	2769Z			31-65-25	ALL
D41039P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5158	2401R	24		31-65-25	ALL
A02		W5158	0712	22		21-27-31	ALL
A03	UNUSED						ALL
A04		W5158	2015R	22		28-41-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5158	2401B	24		31-65-25	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5158	2015B	22		28-41-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5158	2015Z			28-41-11	ALL
PERG	1F	W5158	2401Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41042J		**AB0839L/302/L12**		**INSERT**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W3755	4003Y	24		44-35-22	ALL
	1-2		W3755	4003R	24		44-35-22	ALL
	1-3		W3755	4003G	24		44-35-22	ALL
	1-4		W3755	4003B	24		44-35-22	ALL
	2-1		W3755	4007Y	24		44-35-22	ALL
	2-2		W3755	4007R	24		44-35-22	ALL
	2-3		W3755	4007G	24		44-35-22	ALL
	2-4		W3755	4007B	24		44-35-22	ALL
	=C1		W3755	4003Z			44-35-22	ALL
	=C2		W3755	4007Z			44-35-22	ALL
D41042P		**AB0839L/302/L12**		**INSERT - PLUG**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1		W4479	4022Y	24		44-35-22	ALL
	1-2		W4479	4022R	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41042P	**AB0839L/302/L12**		**INSERT - PLUG (continued)**				**ALL**
1-3		W4479	4022G	24		44-35-22	ALL
1-4		W4479	4022B	24		44-35-22	ALL
2-1		W4479	4023Y	24		44-35-22	ALL
2-2		W4479	4023R	24		44-35-22	ALL
2-3		W4479	4023G	24		44-35-22	ALL
2-4		W4479	4023B	24		44-35-22	ALL
=C1		W4479	4022Z			44-35-22	ALL
=C2		W4479	4023Z			44-35-22	ALL
D41062J	**425/295/L021**		**RCPT-**				**ALL**
1		W4166	2003W	24		33-22-31	ALL
2		W4166	2003B	24		33-22-31	ALL
3		W4166	2004R	24		33-22-31	ALL
4		W4166	2004B	24		33-22-31	ALL
5		W4166	2003Z			33-22-31	ALL
D41062P	**427/295/L021**		**PLUG-**				**ALL**
1		W3058	2003W	24		33-22-31	ALL
2		W3058	2003B	24		33-22-31	ALL
3		W3058	2004R	24		33-22-31	ALL
4		W3058	2004B	24		33-22-31	ALL
5		W3058	2003Z			33-22-31	ALL
D41064J	**445/295/L023**		**RCPT-**				**ALL**
A		W3166	0204	18		33-22-21	ALL
B		W3166	0014	18		33-22-41	ALL
C	UNUSED						ALL
D41064P	**445/295/L023**		**PLUG-**				**ALL**
A		W3158	0241	18		33-22-21	ALL
B		W3158	0247	18		33-22-41	ALL
C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41066J		**426/295/L019**		**RCPT-**				**ALL**
	A		W4166	0204	18		33-22-31	ALL
	B		W4166	0014	18		33-22-51	ALL
	C	UNUSED						ALL
D41066P		**426/295/L019**		**PLUG-**				**ALL**
	A		W3158	0243	18		33-22-31	ALL
	B		W3158	0245	18		33-22-51	ALL
	C	UNUSED						ALL
D41070J		**414/295/L022**		**RCPT-**				**ALL**
	1		W4246	2001W	24		33-21-12	ALL
	2		W4246	2001B	24		33-21-12	ALL
	3		W4246	2002R	24		33-21-12	ALL
	4		W4246	2002B	24		33-21-12	ALL
	5		W4246	2001Z			33-21-12	ALL
D41070P		**414/295/L022**		**PLUG-**				**ALL**
	1		W3058	2001W	24		33-21-12	ALL
	2		W3058	2001B	24		33-21-12	ALL
	3		W3058	2002R	24		33-21-12	ALL
	4		W3058	2002B	24		33-21-12	ALL
	5		W3058	2001Z			33-21-12	ALL
D41072J		**345/290/L010**		**RCPT, RECTANGULAR**				**ALL**
	1		W0156	0004	18		33-24-21	ALL
	2		W0156	0002	18		33-24-21	ALL
	3		W0156	0013	18		33-24-21	ALL
	4		W0156	0012	18		33-24-21	ALL
	5		W0156	0003	18		33-24-21	ALL
	6		W0156	0022	18		33-24-21	ALL
	7		W0156	0023	18		33-24-21	ALL
	8		W0156	0032	18		33-24-21	ALL
	9		W0156	0033	18		33-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41072J		**345/290/L010**		**RCPT, RECTANGULAR (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
D41072P		**345/290/L010**		**PLUG, RECTANGULAR**				**ALL**
	1		W3168	0004	18		33-24-21	ALL
	2		W3168	0002	18		33-24-21	ALL
	3		W3168	0013	18		33-24-21	ALL
	4		W3168	0012	18		33-24-21	ALL
	5		W3168	0003	18		33-24-21	ALL
	6		W3168	0022	18		33-24-21	ALL
	7		W3168	0023	18		33-24-21	ALL
	8		W3168	0033	18		33-24-21	ALL
	9		W3168	0032	18		33-24-21	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
D41074J		**910/290/L013**		**RCPT, RECTANGULAR**				**ALL**
	1		W0158	0004	18		33-24-22	ALL
	2		W0158	0002	18		33-24-22	ALL
	3		W0158	0013	18		33-24-22	ALL
	4		W0158	0012	18		33-24-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41074J		**910/290/L013**		**RCPT, RECTANGULAR (continued)**				**ALL**
	5		W0158	0003	18		33-24-22	ALL
	6		W0158	0022	18		33-24-22	ALL
	7		W0158	0023	18		33-24-22	ALL
	8		W0158	0008	20		33-26-31	ALL
	9		W0158	0009	20		33-26-31	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
D41074P		**912/290/L013**		**PLUG, RECTANGULAR**				**ALL**
	1		W4168	0004	18		33-24-22	ALL
	2		W4168	0002	18		33-24-22	ALL
	3		W4168	0013	18		33-24-22	ALL
	4		W4168	0012	18		33-24-22	ALL
	5		W4168	0003	18		33-24-22	ALL
	6		W4168	0022	18		33-24-22	ALL
	7		W4168	0023	18		33-24-22	ALL
	8		W4168	0008	18		33-26-31	ALL
	9		W4168	0009	20		33-26-31	ALL
	10		W4168	0575	18		SPARE	ALL
	11		W4168	0576	18		SPARE	ALL
	12		W4168	0577	18		SPARE	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41076J	**466/296/L024**		**RCPT-**				**ALL**
1		W3166	2001W	24		33-22-41	ALL
2		W3166	2001B	24		33-22-41	ALL
3		W3166	2002R	24		33-22-41	ALL
4		W3166	2002B	24		33-22-41	ALL
5		W3166	2001Z			33-22-41	ALL
D41076P	**466/296/L024**		**PLUG-**				**ALL**
1		W3058	2005W	24		33-22-41	ALL
2		W3058	2005B	24		33-22-41	ALL
3		W3058	2006R	24		33-22-41	ALL
4		W3058	2006B	24		33-22-41	ALL
5		W3058	2005Z			33-22-41	ALL
D41078J	**982/297/L014**		**RCPT-**				**ALL**
A		W0160	0005	18		33-24-22	ALL
B	UNUSED						ALL
C		W0160	0006	18		33-24-22	ALL
D41078P	**982/297/L014**		**PLUG-**				**ALL**
A		W4168	0005	18		33-24-22	ALL
B		W4168	0575	18		SPARE	ALL
C		W4168	0006	18		33-24-22	ALL
CAP	Y	W4168	0576	18		SPARE	ALL
CAP	Y	W4168	0577	18		SPARE	ALL
D41082J	**346/290/R010**		**RCPT, RECTANGULAR**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0142	0003	20		33-51-12	ALL
4		W0142	0004	20		33-51-12	ALL
5		W0142	0005	24		33-29-11	ALL
6		W0142	0006	24		33-29-11	ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41082J		**346/290/R010**		**RCPT, RECTANGULAR (continued)**				**ALL**
	8	UNUSED						ALL
	9		W0142	0009	22		23-42-11	ALL
	10		W0142	0010	22		23-42-11	ALL
	11		W0142	0011	22		33-27-11	ALL
	12		W0142	0012	22		33-27-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0142	0015	20		33-26-11	ALL
	16		W0142	0016	22		33-26-11	ALL
	17		W0142	0017	22		SPARE	ALL
	18		W0142	0018	22		SPARE	ALL
D41082P		**346/290/R010**		**PLUG, RECTANGULAR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W3058	0363	20		33-51-12	ALL
	4		W3058	0364	20		33-51-12	ALL
	5		W3058	0062	24		33-29-11	ALL
	6		W3058	0063	20		33-29-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W3058	0369	22		23-42-11	ALL
	10		W3058	0370	20		23-42-11	ALL
	11		W3058	0371	22		33-27-11	ALL
	12		W3058	0372	22		33-27-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W3058	0055	20		33-26-11	ALL
	16		W3058	0056	22		33-26-11	ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41082P	**346/290/R010**		**PLUG, RECTANGULAR (continued)**				**ALL**
18	UNUSED						ALL
D41084J	**711/296/R020**		**RCPT-**				**ALL**
A		W4166	0306	18		33-22-32	ALL
B		W4166	0017	18		33-22-51	ALL
C	UNUSED						ALL
D41084P	**711/296/R020**		**PLUG-**				**ALL**
A		W3158	0244	18		33-22-32	ALL
B		W3158	0246	18		33-22-51	ALL
C	UNUSED						ALL
D41086J	**674/296/L022**		**RCPT-**				**ALL**
A		W3166	0304	18		33-22-22	ALL
B		W3166	0017	18		33-22-41	ALL
C	UNUSED						ALL
D41086P	**674/296/L022**		**PLUG-**				**ALL**
A		W3158	0242	18		33-22-22	ALL
B		W3158	0248	18		33-22-41	ALL
C	UNUSED						ALL
D41088J	**367/289/LBL0**		**RCPT, RECTANGULAR**				**ALL**
1		W0144	0001	20		33-26-31	ALL
2		W0144	0002	20		33-26-31	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
D41088P	**374/290/R013**		**PLUG, RECTANGULAR**				**ALL**
1		W3058	0511	20		33-26-31	ALL
2		W3058	0512	18		33-26-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41088P		**374/290/R013**		**PLUG, RECTANGULAR (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41101J	**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0411	0264	24		23-15-12	ALL
A02		W0411	0282	24		23-15-13	ALL
A03		W0411	0281	24		23-15-13	ALL
A04		W0411	2639R	24		23-15-12	ALL
A05		W0411	2639Z			23-15-12	ALL
A06		W0411	2641R	24		23-15-12	ALL
A07		W0411	2595R	24		23-15-13	ALL
A08		W0411	2595Z			23-15-13	ALL
A09		W0411	2598R	24		23-15-13	ALL
A10		W0411	2662R	24		23-15-15	ALL
B01		W0411	0263	24		23-15-12	ALL
B02		W0411	0284	24		23-15-13	ALL
B03		W0411	0285	24		23-15-13	ALL
B04		W0411	2639B	24		23-15-12	ALL
B05		W0411	2641Z			23-15-12	ALL
B06		W0411	2641B	24		23-15-12	ALL
B07		W0411	2595B	24		23-15-13	ALL
B08		W0411	2598Z			23-15-13	ALL
B09		W0411	2598B	24		23-15-13	ALL
B10		W0411	2662B	24		23-15-15	ALL
PERG	1F	W0411	2662Z			23-15-15	ALL
D41101P	**E004-01/ /**		**PLUG-**				**ALL**
A01		W5602	0006	24		23-15-12	ALL
A02		W5602	0010	24		23-15-13	ALL
A03		W5602	0012	24		23-15-13	ALL
A04		W5602	2502R	24		23-15-12	ALL
A05		W5602	2502Z			23-15-12	ALL
A06		W5602	2503R	24		23-15-12	ALL
A07		W5602	2504R	24		23-15-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41101P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A08		W5602	2504Z			23-15-13	ALL
	A09		W5602	2505R	24		23-15-13	ALL
	A10		W5602	2512R	24		23-15-15	ALL
	B01		W5602	0007	24		23-15-12	ALL
	B02		W5602	0011	24		23-15-13	ALL
	B03		W5602	0013	24		23-15-13	ALL
	B04		W5602	2502B	24		23-15-12	ALL
	B05		W5602	2503Z			23-15-12	ALL
	B06		W5602	2503B	24		23-15-12	ALL
	B07		W5602	2504B	24		23-15-13	ALL
	B08		W5602	2505Z			23-15-13	ALL
	B09		W5602	2505B	24		23-15-13	ALL
	B10		W5602	2512B	24		23-15-15	ALL
	PERG	1F	W5602	2512Z			23-15-15	ALL
D41106J		**534/194/R026**		**RCPT-**				**ALL**
	A		W6586	0017	20		33-42-21	ALL
	B		W6586	0016	20		33-42-21	ALL
	C	UNUSED						ALL
D41106P		**534/195/R024**		**PLUG-**				**ALL**
	A		W5566	0008	20		33-42-21	ALL
	B		W5566	0009	20		33-42-21	ALL
	C	UNUSED						ALL
D41121J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	1001	22		22-11-11	ALL
	A02		W0111	0018	22		22-11-11	ALL
	A03		W0111	0029	20		22-11-11	ALL
	A04		W0111	0027	20		22-11-11	ALL
	A05		W0111	0028	20		22-11-11	ALL
	A06		W0111	0049	20		22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41121J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A07		W0111	0050	20		22-11-12	ALL
A08		W0111	0151	22		22-13-11	ALL
A09		W0111	0148	22		22-13-11	ALL
A10		W0111	0166	20		22-13-11	ALL
A11		W0111	0167	20		22-13-11	ALL
A12		W0111	0168	20		SPARE	ALL
A13		W0111	0169	20		22-13-11	ALL
A14	UNUSED						ALL
A15		W0111	0192	22		22-14-11	ALL
A16		W0111	0347	22		30-11-11	ALL
A17		W0111	0814	22		34-51-41	ALL
A18		W0111	0436	22		34-51-41	ALL
A19		W0111	0377	22		34-21-15	ALL
A20		W0111	0378	22		34-21-15	ALL
B01		W0111	0196	22		22-14-11	ALL
B02		W0111	0170	20		22-13-11	ALL
B03		W0111	2031R	24		22-11-51	ALL
B04		W0111	2031B	24		22-11-51	ALL
B05		W0111	2030R	24		22-11-51	ALL
B06		W0111	2030B	24		22-11-51	ALL
B07		W0111	2055R	24		34-33-11	ALL
B08		W0111	2055B	24		34-33-11	ALL
B09		W0111	0452	22		22-13-11	ALL
B10		W0111	2044R	22		22-18-11	ALL
B11		W0111	2044B	22		22-18-11	ALL
B12		W0111	2099R	24		34-21-13	ALL
B13		W0111	2099B	24		34-21-13	ALL
B14		W0111	0379	22		34-21-15	ALL
B15		W0111	0376	22		34-16-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41121J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B16	UNUSED						ALL
	B17		W0111	2134R	24		73-24-11	ALL
	B18		W0111	2134B	24		73-24-11	ALL
	B19		W0111	0597	20		26-12-11	ALL
	B20		W0111	0598	20		26-12-11	ALL
	PERG	1F	W0111	1001Z			22-11-11	ALL
	PERG	1F	W0111	2030Z			22-11-51	ALL
	PERG	1F	W0111	2031Z			22-11-51	ALL
	PERG	1F	W0111	2044Z			22-18-11	ALL
	PERG	1F	W0111	2055Z			34-33-11	ALL
	PERG	1F	W0111	2099Z			34-21-13	ALL
	PERG	1F	W0111	2134Z			73-24-11	ALL
D41121P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5721	1001	22		22-11-11	ALL
	A02		W5721	0002	22		22-11-11	ALL
	A03		W5721	0003	20		22-11-11	ALL
	A04		W5721	0004	20		22-11-11	ALL
	A05		W5721	0005	20		22-11-11	ALL
	A06		W5721	0006	20		22-11-12	ALL
	A07		W5721	0007	20		22-11-12	ALL
	A08		W5721	0008	22		22-13-11	ALL
	A09		W5721	0009	22		22-13-11	ALL
	A10		W5721	0010	20		22-13-11	ALL
	A11		W5721	0011	20		22-13-11	ALL
	A12		W5721	0012	20		SPARE	ALL
	A13		W5721	0013	20		22-13-11	ALL
	A14	UNUSED						ALL
	A15		W5721	0015	22		22-14-11	ALL
	A16		W5721	0032	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41121P	**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A17		W5721	0016	22		34-51-41	ALL
A18		W5721	0022	22		34-51-41	ALL
A19		W5721	0050	22		34-21-15	ALL
A20		W5721	0051	22		34-21-15	ALL
B01		W5721	0017	22		22-14-11	ALL
B02		W5721	0014	20		22-13-11	ALL
B03		W5721	2040R	24		22-11-51	ALL
B04		W5721	2040B	24		22-11-51	ALL
B05		W5721	2043R	24		22-11-51	ALL
B06		W5721	2043B	24		22-11-51	ALL
B07		W5721	2001R	24		34-33-11	ALL
B08		W5721	2001B	24		34-33-11	ALL
B09		W5721	0031	22		22-13-11	ALL
B10		W5721	2049R	22		22-18-11	ALL
B11		W5721	2049B	22		22-18-11	ALL
B12		W5721	2003R	24		34-21-13	ALL
B13		W5721	2003B	24		34-21-13	ALL
B14		W5721	0052	22		34-21-15	ALL
B15		W5721	0025	22		34-16-11	ALL
B16		W5721	0026	22		SPARE	ALL
B17		W5721	2005R	24		73-24-11	ALL
B18		W5721	2005B	24		73-24-11	ALL
B19		W5721	4501R	20		26-12-11	ALL
B20		W5721	4502R	20		26-12-11	ALL
PERG	1F	W5721	1001Z			22-11-11	ALL
PERG	1F	W5721	2001Z			34-33-11	ALL
PERG	1F	W5721	2003Z			34-21-13	ALL
PERG	1F	W5721	2005Z			73-24-11	ALL
PERG	1F	W5721	2040Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41121P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5721	2043Z			22-11-51	ALL
	PERG	1F	W5721	2049Z			22-18-11	ALL
D41125J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2078R	24		34-55-11	ALL
	A02		W0111	2078B	24		34-55-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0111	2070R	24		34-45-21	ALL
	A06		W0111	2070B	24		34-45-21	ALL
	A07		W0111	0722	22		22-11-11	ALL
	A08	UNUSED						ALL
	A09		W0111	2101R	24		34-21-13	ALL
	A10	UNUSED						ALL
	A11		W0111	2299R	24		34-51-11	ALL
	A12		W0111	2045R	24		22-11-51	ALL
	A13		W0111	2045B	24		22-11-51	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0111	0862	24		21-31-24	ALL
	A18	UNUSED						ALL
	A19		W0111	2132R	22		24-28-41	ALL
	A20		W0111	2132B	22		24-28-41	ALL
	B01		W0111	2209R	24		34-58-11	ALL
	B02		W0111	2209B	24		34-58-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0111	2071R	24		34-45-21	ALL
	B06		W0111	2071B	24		34-45-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41125J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0111	2101B	24		34-21-13	ALL
	B10	UNUSED						ALL
	B11		W0111	2299B	24		34-51-11	ALL
	B12		W0111	0577	22		23-42-11	ALL
	B13	UNUSED						ALL
	B14		W0111	0959	22		34-51-41	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0111	0119	22		27-81-51	ALL
	B18		W0111	0369	22		31-31-17	ALL
	B19		W0111	0756	22		27-54-11	ALL
	B20		W0111	0120	22		27-81-51	ALL
	PERG	1F	W0111	2045Z			22-11-51	ALL
	PERG	1F	W0111	2070Z			34-45-21	ALL
	PERG	1F	W0111	2071Z			34-45-21	ALL
	PERG	1F	W0111	2078Z			34-55-11	ALL
	PERG	1F	W0111	2101Z			34-21-13	ALL
	PERG	1F	W0111	2209Z			34-58-11	ALL
	PERG	1F	W0111	2299Z			34-51-11	ALL
D41125P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5719	2003R	24		34-55-11	ALL
	A02		W5719	2003B	24		34-55-11	ALL
	A03		W5719	2005R	24		SPARE	ALL
	A04		W5719	2005B	24		SPARE	ALL
	A05		W5719	2001R	24		34-45-21	ALL
	A06		W5719	2001B	24		34-45-21	ALL
	A07		W5719	0029	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41125P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W5719	2009R	24		34-21-13	ALL
	A10		W5719	0037	22		SPARE	ALL
	A11		W5719	2038R	24		34-51-11	ALL
	A12		W5719	2017R	24		22-11-51	ALL
	A13		W5719	2017B	24		22-11-51	ALL
	A14		W5719	2010R	24		SPARE	ALL
	A15		W5719	2010B	24		SPARE	ALL
	A16		W5719	0039	20		SPARE	ALL
	A17		W5719	0063	24		21-31-24	ALL
	A18		W5719	0043	22		SPARE	ALL
	A19		W5719	2007R	22		24-28-41	ALL
	A20		W5719	2007B	22		24-28-41	ALL
	B01		W5719	2004R	24		34-58-11	ALL
	B02		W5719	2004B	24		34-58-11	ALL
	B03		W5719	2006R	24		SPARE	ALL
	B04		W5719	2006B	24		SPARE	ALL
	B05		W5719	2002R	24		34-45-21	ALL
	B06		W5719	2002B	24		34-45-21	ALL
	B07		W5719	0030	22		SPARE	ALL
	B08	UNUSED						ALL
	B09		W5719	2009B	24		34-21-13	ALL
	B10		W5719	0038	24		SPARE	ALL
	B11		W5719	2038B	24		34-51-11	ALL
	B12		W5719	0034	22		23-42-11	ALL
	B13		W5719	0036	20		SPARE	ALL
	B14		W5719	0069	22		34-51-41	ALL
	B15		W5719	0051	22		SPARE	ALL
	B16		W5719	0041	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41125P	**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B17		W5719	0052	20		27-81-51	ALL
B18		W5719	0042	22		31-31-17	ALL
B19		W5719	0045	22		27-54-11	ALL
B20		W5719	0053	20		27-81-51	ALL
PERG	1F	W5719	2001Z			34-45-21	ALL
PERG	1F	W5719	2002Z			34-45-21	ALL
PERG	1F	W5719	2003Z			34-55-11	ALL
PERG	1F	W5719	2004Z			34-58-11	ALL
PERG	1F	W5719	2005Z			SPARE	ALL
PERG	1F	W5719	2006Z			SPARE	ALL
PERG	1F	W5719	2009Z			34-21-13	ALL
PERG	1F	W5719	2010Z			SPARE	ALL
PERG	1F	W5719	2017Z			22-11-51	ALL
PERG	1F	W5719	2038Z			34-51-11	ALL
D41131J	**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0131	0301	24		34-53-21	ALL
A02		W0131	0302	24		34-53-21	ALL
A03		W0131	0303	24		34-53-21	ALL
A04		W0131	0304	24		34-53-21	ALL
A05		W0131	0305	24		34-53-21	ALL
A06		W0131	0306	24		34-53-21	ALL
A07		W0131	0307	24		34-53-21	ALL
A08		W0131	0308	24		34-53-21	ALL
A09		W0131	0309	24		34-53-21	ALL
A10		W0131	0310	24		34-53-21	ALL
A11		W0131	0321	24		34-53-21	ALL
A12		W0131	0322	24		34-53-21	ALL
A13		W0131	0323	24		34-53-21	ALL
A14		W0131	0324	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41131J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A15		W0131	0325	24		34-53-21	ALL
	A16		W0131	2532R	24		23-27-37	ALL
	A17		W0131	2531R	24		23-27-37	ALL
	A18		W0137	2501R	24		23-12-41	ALL
	A19	UNUSED						ALL
	A20		W0131	2509R	24		34-21-23	ALL
	B01		W0131	0311	24		34-53-21	ALL
	B02		W0131	0312	24		34-53-21	ALL
	B03		W0131	0313	24		34-53-21	ALL
	B04		W0131	0314	24		34-53-21	ALL
	B05		W0131	0315	24		34-53-21	ALL
	B06		W0131	0316	24		34-53-21	ALL
	B07		W0131	0317	24		34-53-21	ALL
	B08		W0131	0318	24		34-53-21	ALL
	B09		W0131	0319	24		34-53-21	ALL
	B10		W0131	0320	24		34-53-21	ALL
	B11		W0131	0092	22		32-64-21	ALL
	B12		W0131	0129	20		22-11-12	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W0131	2532B	24		23-27-37	ALL
	B17		W0131	2531B	24		23-27-37	ALL
	B18		W0137	2501B	24		23-12-41	ALL
	B19	UNUSED						ALL
	B20		W0131	2509B	24		34-21-23	ALL
	PERG	1F	W0131	2509Z			34-21-23	ALL
	PERG	1F	W0131	2531Z			23-27-37	ALL
	PERG	1F	W0131	2532Z			23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41131J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0137	2501Z			23-12-41	ALL
D41131P	**E001-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5723	0001	24		34-53-21	ALL
A02		W5723	0002	24		34-53-21	ALL
A03		W5723	0003	24		34-53-21	ALL
A04		W5723	0004	24		34-53-21	ALL
A05		W5723	0005	24		34-53-21	ALL
A06		W5723	0006	24		34-53-21	ALL
A07		W5723	0007	24		34-53-21	ALL
A08		W5723	0008	24		34-53-21	ALL
A09		W5723	0009	24		34-53-21	ALL
A10		W5723	0010	24		34-53-21	ALL
A11		W5723	0021	24		34-53-21	ALL
A12		W5723	0022	24		34-53-21	ALL
A13		W5723	0023	24		34-53-21	ALL
A14		W5723	0024	24		34-53-21	ALL
A15		W5723	0025	24		34-53-21	ALL
A16		W5723	2509R	24		23-27-37	ALL
A17		W5723	2510R	24		23-27-37	ALL
A18		W5723	2528R	24		23-12-41	ALL
A19	UNUSED						ALL
A20		W5723	2024R	24		34-21-23	ALL
B01		W5723	0011	24		34-53-21	ALL
B02		W5723	0012	24		34-53-21	ALL
B03		W5723	0013	24		34-53-21	ALL
B04		W5723	0014	24		34-53-21	ALL
B05		W5723	0015	24		34-53-21	ALL
B06		W5723	0016	24		34-53-21	ALL
B07		W5723	0017	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41131P		**E001-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B08		W5723	0018	24		34-53-21	ALL
	B09		W5723	0019	24		34-53-21	ALL
	B10		W5723	0020	24		34-53-21	ALL
	B11		W5723	0064	22		32-64-21	ALL
	B12		W5723	0034	20		22-11-12	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W5723	2509B	24		23-27-37	ALL
	B17		W5723	2510B	24		23-27-37	ALL
	B18		W5723	2528B	24		23-12-41	ALL
	B19	UNUSED						ALL
	B20		W5723	2024B	24		34-21-23	ALL
	PERG	1F	W5723	2024Z			34-21-23	ALL
	PERG	1F	W5723	2509Z			23-27-37	ALL
	PERG	1F	W5723	2510Z			23-27-37	ALL
	PERG	1F	W5723	2528Z			23-12-41	ALL
D41145J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0375	22		34-21-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0111	0374	22		34-21-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41145J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B02	UNUSED						ALL
	B03		W0111	2171R	24		22-11-51	ALL
	B04		W0111	2171B	24		22-11-51	ALL
	B05		W0111	2023R	24		22-11-51	ALL
	B06		W0111	2023B	24		22-11-51	ALL
	B07		W0111	2018R	24		22-11-51	ALL
	B08		W0111	2018B	24		22-11-51	ALL
	B09		W0111	2019R	24		22-11-51	ALL
	B10		W0111	2019B	24		22-11-51	ALL
	PERG	1F	W0111	2018Z			22-11-51	ALL
	PERG	1F	W0111	2019Z			22-11-51	ALL
	PERG	1F	W0111	2023Z			22-11-51	ALL
	PERG	1F	W0111	2171Z			22-11-51	ALL
D41145P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5161	0026	22		34-21-11	ALL
	A02		W5161	2511R	22		SPARE	ALL
	A03		W5161	2511B	22		SPARE	ALL
	A04		W5161	0035	24		SPARE	ALL
	A05		W5161	0038	22		34-21-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5161	2532R	24		22-11-51	ALL
	B04		W5161	2532B	24		22-11-51	ALL
	B05		W5161	2535R	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41145P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B06		W5161	2535B	24		22-11-51	ALL
	B07		W5161	2536R	24		22-11-51	ALL
	B08		W5161	2536B	24		22-11-51	ALL
	B09		W5161	2537R	24		22-11-51	ALL
	B10		W5161	2537B	24		22-11-51	ALL
	PERG	1F	W5161	2511Z			SPARE	ALL
	PERG	1F	W5161	2532Z			22-11-51	ALL
	PERG	1F	W5161	2535Z			22-11-51	ALL
	PERG	1F	W5161	2536Z			22-11-51	ALL
	PERG	1F	W5161	2537Z			22-11-51	ALL
D41147J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2130R	24		31-65-25	ALL
	A02		W0111	2130B	24		31-65-25	ALL
	A03		W0111	2208R	24		34-21-24	ALL
	A04		W0111	2208B	24		34-21-24	ALL
	A05		W0111	2131R	24		31-65-25	ALL
	A06		W0111	2131B	24		31-65-25	ALL
	A07	UNUSED						ALL
	A08		W0111	0572	22		34-51-41	ALL
	A09		W0111	0143	22		34-51-41	ALL
	A10		W0111	0943	24		34-49-11	ALL
	B01		W0111	2288R	24		34-49-11	ALL
	B02		W0111	2288B	24		34-49-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0111	2256R	24		34-21-24	ALL
	B07	UNUSED						ALL
	B08		W0111	2256B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41147J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0111	0579	16		23-12-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0111	2130Z			31-65-25	ALL
	PERG	1F	W0111	2131Z			31-65-25	ALL
	PERG	1F	W0111	2208Z			34-21-24	ALL
	PERG	1F	W0111	2256Z			34-21-24	ALL
	PERG	1F	W0111	2288Z			34-49-11	ALL
D41147P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5163	2522R	24		31-65-25	ALL
	A02		W5163	2522B	24		31-65-25	ALL
	A03		W5163	2537R	24		34-21-24	ALL
	A04		W5163	2537B	24		34-21-24	ALL
	A05		W5163	2525R	24		31-65-25	ALL
	A06		W5163	2525B	24		31-65-25	ALL
	A07	UNUSED						ALL
	A08		W5163	0036	22		34-51-41	ALL
	A09		W5163	0041	22		34-51-41	ALL
	A10		W5163	0019	24		34-49-11	ALL
	B01		W5163	2551R	24		34-49-11	ALL
	B02		W5163	2551B	24		34-49-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5163	2542R	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41147P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W5163	2542B	24		34-21-24	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5163	0024	16		23-12-21	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5163	2522Z			31-65-25	ALL
	PERG	1F	W5163	2525Z			31-65-25	ALL
	PERG	1F	W5163	2537Z			34-21-24	ALL
	PERG	1F	W5163	2542Z			34-21-24	ALL
	PERG	1F	W5163	2551Z			34-49-11	ALL
D41153J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2219R	24		22-11-53	ALL
	A02		W0111	0554	24		22-11-53	ALL
	A03		W0111	0558	24		22-11-53	ALL
	A04		W0111	2296R	24		22-11-51	ALL
	A05		W0111	2287R	24		22-11-51	ALL
	A06		W0111	2297R	24		22-11-51	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0111	0962	22		22-11-31	ALL
	A10		W0111	2293R	24		31-65-15	ALL
	B01		W0111	2219B	24		22-11-53	ALL
	B02		W0111	0557	24		22-11-53	ALL
	B03		W0111	0559	24		22-11-53	ALL
	B04		W0111	2296B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41153J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B05		W0111	2287B	24		22-11-51	ALL
	B06		W0111	2297B	24		22-11-51	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0111	2293B	24		31-65-15	ALL
	PERG	1F	W0111	2219Z			22-11-53	ALL
	PERG	1F	W0111	2287Z			22-11-51	ALL
	PERG	1F	W0111	2293Z			31-65-15	ALL
	PERG	1F	W0111	2296Z			22-11-51	ALL
	PERG	1F	W0111	2297Z			22-11-51	ALL
D41153P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	2005R	24		22-11-53	ALL
	A02		W5111	0013	24		22-11-53	ALL
	A03		W5111	0020	24		22-11-53	ALL
	A04		W5111	2751R	24		22-11-51	ALL
	A05		W5111	2117R	24		22-11-51	ALL
	A06		W5111	2752R	24		22-11-51	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5111	1701	22		22-11-31	ALL
	A10		W5111	2710R	24		31-65-15	ALL
	B01		W5111	2005B	24		22-11-53	ALL
	B02		W5111	0019	24		22-11-53	ALL
	B03		W5111	0021	24		22-11-53	ALL
	B04		W5111	2751B	24		22-11-51	ALL
	B05		W5111	2117B	24		22-11-51	ALL
	B06		W5111	2752B	24		22-11-51	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41153P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5111	2710B	24		31-65-15	ALL
	PERG	1F	W5111	2005Z			22-11-53	ALL
	PERG	1F	W5111	2117Z			22-11-51	ALL
	PERG	1F	W5111	2710Z			31-65-15	ALL
	PERG	1F	W5111	2751Z			22-11-51	ALL
	PERG	1F	W5111	2752Z			22-11-51	ALL
D41155J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2107R	24		34-21-14	ALL
	A02		W0111	2107B	24		34-21-14	ALL
	A03		W0111	2108R	24		34-21-14	ALL
	A04		W0111	2108B	24		34-21-14	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0111	2199R	24		34-61-22	ALL
	A08		W0111	2199B	24		34-61-22	ALL
	A09		W0111	2088R	24		22-31-52	ALL
	A10		W0111	2088B	24		22-31-52	ALL
	A11		W0111	0376	22		34-16-11	ALL
	A12		W0111	2102R	24		34-21-13	ALL
	A13		W0111	2102B	24		34-21-13	ALL
	A14		W0111	2103R	24		34-21-13	ALL
	A15		W0111	2103B	24		34-21-13	ALL
	A16		W0111	0163	22		22-13-11	ALL
	A17	UNUSED						ALL
	A18		W0111	2074R	24		34-49-11	ALL
	A19		W0111	2074B	24		34-49-11	ALL
	A20		W0111	2074ZI			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41155J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02		W0111	2118R	24		34-61-14	ALL
	B03		W0111	2118B	24		34-61-14	ALL
	B04		W0111	0361	22		34-61-16	ALL
	B05		W0111	0362	22		34-61-16	ALL
	B06		W0111	2220R	22		31-32-15	ALL
	B07		W0111	2198R	24		34-61-22	ALL
	B08		W0111	2198B	24		34-61-22	ALL
	B09		W0111	0122	20		34-61-22	ALL
	B10		W0111	0123	20		34-61-22	ALL
	B11		W0111	2220B	22		31-32-15	ALL
	B12		W0111	0136	22		22-18-11	ALL
	B13		W0111	0576	22		23-43-11	ALL
	B14		W0111	0577	22		23-42-11	ALL
	B15		W0111	2197R	24		34-61-22	ALL
	B16		W0111	2197B	24		34-61-22	ALL
	B17	UNUSED						ALL
	B18		W0111	2121R	22		34-61-15	ALL
	B19		W0111	2121B	22		34-61-15	ALL
	B20		W0111	0364	22		34-61-17	ALL
	PERG	1F	W0111	2074ZO			34-49-11	ALL
	PERG	1F	W0111	2088Z			22-31-52	ALL
	PERG	1F	W0111	2102Z			34-21-13	ALL
	PERG	1F	W0111	2103Z			34-21-13	ALL
	PERG	1F	W0111	2107Z			34-21-14	ALL
	PERG	1F	W0111	2108Z			34-21-14	ALL
	PERG	1F	W0111	2118Z			34-61-14	ALL
	PERG	1F	W0111	2121Z			34-61-15	ALL
	PERG	1F	W0111	2197Z			34-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41155J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0111	2198Z			34-61-22	ALL
	PERG	1F	W0111	2199Z			34-61-22	ALL
	PERG	1F	W0111	2220Z			31-32-15	ALL
D41155P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5161	2501R	24		34-21-14	ALL
	A02		W5161	2501B	24		34-21-14	ALL
	A03		W5161	2502R	24		34-21-14	ALL
	A04		W5161	2502B	24		34-21-14	ALL
	A05		W5161	2503R	24		SPARE	ALL
	A06		W5161	2503B	24		SPARE	ALL
	A07		W5161	2540R	24		34-61-22	ALL
	A08		W5161	2540B	24		34-61-22	ALL
	A09		W5161	2505R	24		22-31-52	ALL
	A10		W5161	2505B	24		22-31-52	ALL
	A11		W5161	0012	22		34-16-11	ALL
	A12		W5161	2508R	24		34-21-13	ALL
	A13		W5161	2508B	24		34-21-13	ALL
	A14		W5161	2509R	24		34-21-13	ALL
	A15		W5161	2509B	24		34-21-13	ALL
	A16		W5161	0001	22		22-13-11	ALL
	A17	UNUSED						ALL
	A18		W5161	2510R	24		34-49-11	ALL
	A19		W5161	2510B	24		34-49-11	ALL
	A20		W5161	2510ZI			34-49-11	ALL
	B01	UNUSED						ALL
	B02		W5161	2516R	24		34-61-14	ALL
	B03		W5161	2516B	24		34-61-14	ALL
	B04		W5161	0010	22		34-61-16	ALL
	B05		W5161	0011	22		34-61-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41155P	**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B06		W5161	2522R	22		31-32-15	ALL
B07		W5161	2541R	24		34-61-22	ALL
B08		W5161	2541B	24		34-61-22	ALL
B09		W5161	0041	20		34-61-22	ALL
B10		W5161	0039	20		34-61-22	ALL
B11		W5161	2522B	22		31-32-15	ALL
B12		W5161	0018	22		22-18-11	ALL
B13		W5161	0019	22		23-43-11	ALL
B14		W5161	0020	22		23-42-11	ALL
B15		W5161	2542R	24		34-61-22	ALL
B16		W5161	2542B	24		34-61-22	ALL
B17	UNUSED						ALL
B18		W5161	2519R	22		34-61-15	ALL
B19		W5161	2519B	22		34-61-15	ALL
B20		W5161	0025	22		34-61-17	ALL
PERG	1F	W5161	2501Z			34-21-14	ALL
PERG	1F	W5161	2502Z			34-21-14	ALL
PERG	1F	W5161	2503Z			SPARE	ALL
PERG	1F	W5161	2505Z			22-31-52	ALL
PERG	1F	W5161	2508Z			34-21-13	ALL
PERG	1F	W5161	2509Z			34-21-13	ALL
PERG	1F	W5161	2510ZO			34-49-11	ALL
PERG	1F	W5161	2516Z			34-61-14	ALL
PERG	1F	W5161	2519Z			34-61-15	ALL
PERG	1F	W5161	2522Z			31-32-15	ALL
PERG	1F	W5161	2540Z			34-61-22	ALL
PERG	1F	W5161	2541Z			34-61-22	ALL
PERG	1F	W5161	2542Z			34-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41157J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0111	2116R	24		34-21-24	ALL
	A04		W0111	2116B	24		34-21-24	ALL
	A05		W0111	2136R	24		73-24-21	ALL
	A06		W0111	2136B	24		73-24-21	ALL
	A07		W0111	2091R	24		22-31-52	ALL
	A08		W0111	2091B	24		22-31-52	ALL
	A09		W0111	2092R	24		22-31-52	ALL
	A10		W0111	2092B	24		22-31-52	ALL
	A11		W0111	0373	24		22-31-52	ALL
	A12		W0111	2072R	24		34-45-21	ALL
	A13		W0111	2072B	24		34-45-21	ALL
	A14		W0111	2073R	24		34-45-21	ALL
	A15		W0111	2073B	24		34-45-21	ALL
	A16		W0111	0567	22		34-51-41	ALL
	A17		W0111	0356	22		34-21-21	ALL
	A18	UNUSED						ALL
	A19		W0111	0383	20		34-21-21	ALL
	A20		W0111	0385	20		34-21-21	ALL
	B01		W0111	0392	20		34-21-21	ALL
	B02		W0111	2115R	24		34-21-23	ALL
	B03		W0111	2115B	24		34-21-23	ALL
	B04		W0111	0718	22		34-61-12	ALL
	B05	UNUSED						ALL
	B06		W0111	0562	22		34-51-41	ALL
	B07		W0111	2058R	24		34-45-11	ALL
	B08		W0111	2058B	24		34-45-11	ALL
	B09		W0111	0231	24		34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41157J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
B10		W0111	0716	22		34-61-12	ALL
B11	UNUSED						ALL
B12		W0111	2046R	24		22-11-51	ALL
B13		W0111	2046B	24		22-11-51	ALL
B14		W0111	2075R	24		34-49-11	ALL
B15		W0111	2075B	24		34-49-11	ALL
B16		W0111	0523	22		34-51-41	ALL
B17		W0111	0564	22		34-51-41	ALL
B18		W0111	0370	24		22-31-52	ALL
B19		W0111	0358	22		34-21-16	ALL
B20	UNUSED						ALL
PERG	1F	W0111	2046Z			22-11-51	ALL
PERG	1F	W0111	2058Z			34-45-11	ALL
PERG	1F	W0111	2072Z			34-45-21	ALL
PERG	1F	W0111	2073Z			34-45-21	ALL
PERG	1F	W0111	2075Z			34-49-11	ALL
PERG	1F	W0111	2091Z			22-31-52	ALL
PERG	1F	W0111	2092Z			22-31-52	ALL
PERG	1F	W0111	2115Z			34-21-23	ALL
PERG	1F	W0111	2116Z			34-21-24	ALL
PERG	1F	W0111	2136Z			73-24-21	ALL
D41157P	**E001-01/ /**		**PLUG**				**ALL**
A01		W5163	2501R	24		SPARE	ALL
A02		W5163	2501B	24		SPARE	ALL
A03		W5163	2502R	24		34-21-24	ALL
A04		W5163	2502B	24		34-21-24	ALL
A05		W5163	2503R	24		73-24-21	ALL
A06		W5163	2503B	24		73-24-21	ALL
A07		W5163	2504R	24		22-31-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41157P		**E001-01/ /**		**PLUG (continued)**				**ALL**
	A08		W5163	2504B	24		22-31-52	ALL
	A09		W5163	2505R	24		22-31-52	ALL
	A10		W5163	2505B	24		22-31-52	ALL
	A11		W5163	0001	24		22-31-52	ALL
	A12		W5163	2533R	24		34-45-21	ALL
	A13		W5163	2533B	24		34-45-21	ALL
	A14		W5163	2534R	24		34-45-21	ALL
	A15		W5163	2534B	24		34-45-21	ALL
	A16		W5163	0033	22		34-51-41	ALL
	A17		W5163	0003	22		34-21-21	ALL
	A18	UNUSED						ALL
	A19		W5163	0005	20		34-21-21	ALL
	A20		W5163	0006	20		34-21-21	ALL
	B01		W5163	0007	20		34-21-21	ALL
	B02		W5163	2512R	24		34-21-23	ALL
	B03		W5163	2512B	24		34-21-23	ALL
	B04		W5163	0008	22		34-61-12	ALL
	B05		W5163	0035	22		SPARE	ALL
	B06		W5163	0034	22		34-51-41	ALL
	B07		W5163	2528R	24		34-45-11	ALL
	B08		W5163	2528B	24		34-45-11	ALL
	B09		W5163	0020	24		34-45-11	ALL
	B10		W5163	0049	22		34-61-12	ALL
	B11	UNUSED						ALL
	B12		W5163	2541R	24		22-11-51	ALL
	B13		W5163	2541B	24		22-11-51	ALL
	B14		W5163	2531R	24		34-49-11	ALL
	B15		W5163	2531B	24		34-49-11	ALL
	B16		W5163	0031	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41157P		**E001-01/ /**		**PLUG (continued)**				**ALL**
	B17		W5163	0032	22		34-51-41	ALL
	B18		W5163	0018	24		22-31-52	ALL
	B19		W5163	0038	22		34-21-16	ALL
	B20	UNUSED						ALL
	PERG	1F	W5163	2501Z			SPARE	ALL
	PERG	1F	W5163	2502Z			34-21-24	ALL
	PERG	1F	W5163	2503Z			73-24-21	ALL
	PERG	1F	W5163	2504Z			22-31-52	ALL
	PERG	1F	W5163	2505Z			22-31-52	ALL
	PERG	1F	W5163	2512Z			34-21-23	ALL
	PERG	1F	W5163	2528Z			34-45-11	ALL
	PERG	1F	W5163	2531Z			34-49-11	ALL
	PERG	1F	W5163	2533Z			34-45-21	ALL
	PERG	1F	W5163	2534Z			34-45-21	ALL
	PERG	1F	W5163	2541Z			22-11-51	ALL
D41159J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2079R	24		22-31-31	ALL
	A02		W0111	2082R	24		22-31-31	ALL
	A03		W0111	2083R	22		22-31-31	ALL
	A04		W0111	2084R	24		22-31-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0111	2079B	24		22-31-31	ALL
	B02		W0111	2082B	24		22-31-31	ALL
	B03		W0111	2083B	22		22-31-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41159J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B04		W0111	2084B	24		22-31-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0111	2079Z			22-31-31	ALL
	PERG	1F	W0111	2084Z			22-31-31	ALL
D41159P		**E001-01/ /**		**PLUG**				**ALL**
	A01		W5353	2501R	24		22-31-31	ALL
	A02		W5353	2002R	24		22-31-31	ALL
	A03		W5353	2001R	22		22-31-31	ALL
	A04		W5353	2504R	24		22-31-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5353	2501B	24		22-31-31	ALL
	B02		W5353	2002B	24		22-31-31	ALL
	B03		W5353	2001B	22		22-31-31	ALL
	B04		W5353	2504B	24		22-31-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41159P	**E001-01/ /**		**PLUG (continued)**				**ALL**
B10	UNUSED						ALL
PERG	1F	W5353	2501Z			22-31-31	ALL
PERG	1F	W5353	2504Z			22-31-31	ALL
D41161J	**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
A01		W0111	2081R	24		22-31-41	ALL
A02		W0111	2085R	24		22-31-41	ALL
A03		W0111	2086R	22		22-31-41	ALL
A04	UNUSED						ALL
A05		W0111	2087R	24		22-31-41	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0111	2081B	24		22-31-41	ALL
B02		W0111	2085B	24		22-31-41	ALL
B03		W0111	2086B	22		22-31-41	ALL
B04	UNUSED						ALL
B05		W0111	2087B	24		22-31-41	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0111	2081Z			22-31-41	ALL
PERG	1F	W0111	2085Z			22-31-41	ALL
PERG	1F	W0111	2086Z			22-31-41	ALL
PERG	1F	W0111	2087Z			22-31-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41161P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5397	2501R	24		22-31-41	ALL
	A02		W5397	2002R	24		22-31-41	ALL
	A03		W5397	2001R	22		22-31-41	ALL
	A04	UNUSED						ALL
	A05		W5397	2504R	24		22-31-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5397	2501B	24		22-31-41	ALL
	B02		W5397	2002B	24		22-31-41	ALL
	B03		W5397	2001B	22		22-31-41	ALL
	B04	UNUSED						ALL
	B05		W5397	2504B	24		22-31-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5397	2501Z			22-31-41	ALL
	PERG	1F	W5397	2504Z			22-31-41	ALL
D41163J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0536	22		34-51-41	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0111	2062R	24		27-32-22	ALL
	A05		W0111	0337	22		31-31-15	ALL
	A06		W0111	0720	24		31-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41163J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A07	UNUSED						ALL
A08		W0111	0990	22		22-31-51	ALL
A09		W0111	0817	22		34-51-41	ALL
A10		W0111	2094R	24		22-31-52	ALL
A11		W0111	0201	24		22-11-75	ALL
A12		W0111	0202	24		22-11-75	ALL
A13		W0111	0203	24		22-11-75	ALL
A14		W0111	0204	24		22-11-75	ALL
A15		W0111	0205	24		22-11-75	ALL
A16		W0111	0206	24		22-11-75	ALL
A17		W0111	0207	24		22-11-75	ALL
A18		W0111	0208	24		22-11-75	ALL
A19		W0111	0209	24		22-11-75	ALL
A20		W0111	0210	24		22-11-75	ALL
B01		W0111	0211	24		22-11-75	ALL
B02		W0111	0398	22		34-51-11	ALL
B03	UNUSED						ALL
B04		W0111	2062B	24		27-32-22	ALL
B05	UNUSED						ALL
B06		W0111	0721	24		31-31-15	ALL
B07		W0111	0589	24		21-51-24	ALL
B08		W0111	0343	22		22-31-51	ALL
B09		W0111	0338	22		22-31-51	ALL
B10		W0111	2094B	24		22-31-52	ALL
B11		W0111	0212	24		22-11-75	ALL
B12		W0111	0963	22		22-31-51	ALL
B13		W0111	0572	22		34-51-41	ALL
B14	UNUSED						ALL
B15		W0111	0449	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41163J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B16		W0111	0568	22		34-51-41	ALL
	B17		W0111	0565	22		34-51-41	ALL
	B18		W0111	0214	24		22-11-75	ALL
	B19		W0111	0215	24		22-11-75	ALL
	B20		W0111	0224	24		22-11-75	ALL
	PERG	1F	W0111	2062Z			27-32-22	ALL
	PERG	1F	W0111	2094Z			22-31-52	ALL
D41163P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5463	0095	22		34-51-41	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5463	2003R	24		27-32-22	ALL
	A05		W5463	0005	24		31-31-15	ALL
	A06		W5463	0003	24		31-31-15	ALL
	A07	UNUSED						ALL
	A08		W5463	0008	22		22-31-51	ALL
	A09		W5463	0010	22		34-51-41	ALL
	A10		W5463	2004R	24		22-31-52	ALL
	A11		W5463	0034	24		22-11-75	ALL
	A12		W5463	0035	24		22-11-75	ALL
	A13		W5463	0036	24		22-11-75	ALL
	A14		W5463	0037	24		22-11-75	ALL
	A15		W5463	0038	24		22-11-75	ALL
	A16		W5463	0039	24		22-11-75	ALL
	A17		W5463	0040	24		22-11-75	ALL
	A18		W5463	0041	24		22-11-75	ALL
	A19		W5463	0042	24		22-11-75	ALL
	A20		W5463	0043	24		22-11-75	ALL
	B01		W5463	0044	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41163P	**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B02		W5463	0018	22		34-51-11	ALL
B03	UNUSED						ALL
B04		W5463	2003B	24		27-32-22	ALL
B05	UNUSED						ALL
B06		W5463	0004	24		31-31-15	ALL
B07		W5463	0021	24		21-51-24	ALL
B08		W5463	0014	22		22-31-51	ALL
B09		W5463	0009	22		22-31-51	ALL
B10		W5463	2004B	24		22-31-52	ALL
B11		W5463	0045	24		22-11-75	ALL
B12		W5463	0046	22		22-31-51	ALL
B13		W5463	0033	22		SPARE	ALL
B14		W5463	0020	22		SPARE	ALL
B15		W5463	0079	24		22-11-75	ALL
B16		W5463	0016	22		34-51-41	ALL
B17		W5463	0017	22		34-51-41	ALL
B18		W5463	0047	24		22-11-75	ALL
B19		W5463	0048	24		22-11-75	ALL
B20		W5463	0049	24		22-11-75	ALL
PERG	1F	W5463	2003Z			27-32-22	ALL
PERG	1F	W5463	2004Z			22-31-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41212J		**OFSS769/ /**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1244	1121	18		33-44-12	ALL
	2		W1244	0024	18		33-44-12	ALL
	3	UNUSED						ALL
	S/R		W1244	1121Z			33-44-12	ALL
D41212P		**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	1		W0264	2501R	18		33-44-12	ALL
	2		W0264	2501B	18		33-44-12	ALL
	3	UNUSED						ALL
	S/R		W0264	2501ZI			33-44-12	ALL
	S/R		W0264	2501ZO			33-44-12	ALL
D41215J		**AB0310/ /**		**PANEL JACK (TNC)**				**ALL**
	=A1		W5183	001CX			34-55-11	ALL
	=C1		W5183	001CO			34-55-11	ALL
D41215P		**AB0310/ /**		**PLUG - (TNC)**				**ALL**
	=A1		W0121	006CX			34-55-11	ALL
	=C1		W0121	006CO			34-55-11	ALL
D41216J		**ORSS747/ /**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
	1		W1244	1107	20		33-43-11	ALL
	2		W1244	0008	20		33-43-11	ALL
	3		W1244	0009	20		33-43-11	ALL
	S/R		W1244	1107Z			33-43-11	ALL
D41216P		**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
	1		W0244	2501R	20		33-43-11	ALL
	2		W0244	2501B	20		33-43-11	ALL
	3		W0244	1001	20		33-43-11	ALL
	S/R		W0244	1001Z			33-43-11	ALL
	S/R		W0244	2501ZI			33-43-11	ALL
	S/R		W0244	2501ZO			33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41312J	**OFSS-769/ /**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
1		W1242	1121	18		33-44-12	ALL
2		W1242	0024	18		33-44-12	ALL
3	UNUSED						ALL
S/R		W1242	1121Z			33-44-12	ALL
D41312P	**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
1		W0262	2501R	18		33-44-12	ALL
2		W0262	2501B	18		33-44-12	ALL
3	UNUSED						ALL
S/R		W0262	2501ZI			33-44-12	ALL
S/R		W0262	2501ZO			33-44-12	ALL
D41316J	**ORSS-747/ /**		**RCPT-CONDUCTIVE CONNECTOR**				**ALL**
1		W1242	1107	20		33-43-11	ALL
2		W1242	0008	20		33-43-11	ALL
3		W1242	0009	20		33-43-11	ALL
S/R		W1242	1107Z			33-43-11	ALL
D41316P	**WINGLET/ /**		**PLUG- CONDUCTIVE CONNECTOR**				**ALL**
1		W0242	2501R	20		33-43-11	ALL
2		W0242	2501B	20		33-43-11	ALL
3		W0242	1001	20		33-43-11	ALL
S/R		W0242	1001Z			33-43-11	ALL
S/R		W0242	2501ZI			33-43-11	ALL
S/R		W0242	2501ZO			33-43-11	ALL
D41337J	**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0131	2001R	24		23-31-01	ALL
A02		W0131	3502R	24		23-42-12	ALL
A03		W0131	3502Y	24		23-42-12	ALL
A04		W0131	0168	22		23-31-06	ALL
A05		W0131	0011	20		23-31-01	ALL
A06		W0131	0024	24		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41337J		**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A07		W0131	0526	22		23-42-12	ALL
	A08	UNUSED						ALL
	A09		W0131	0150	24		23-31-06	ALL
	A10		W0131	0271	22		44-21-22	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0131	0025	22		23-31-06	ALL
	A15	UNUSED						ALL
	A16		W0131	2011R	24		23-31-06	ALL
	A17		W0131	2526B	24		23-31-06	ALL
	A18		W0131	2012R	24		23-31-06	ALL
	A19		W0131	2029R	22		44-21-22	ALL
	A20		W0131	0517	22		44-21-22	ALL
	B01		W0131	2001B	24		23-31-01	ALL
	B02		W0131	3502B	24		23-42-12	ALL
	B03		W0131	3502Z			23-42-12	ALL
	B04		W0131	0447	20		44-21-10	ALL
	B05		W0131	0449	20		44-21-10	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0131	0027	22		23-31-06	ALL
	B09		W0131	0031	24		23-31-06	ALL
	B10		W0131	0260	22		23-31-06	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0131	0026	22		23-31-06	ALL
	B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41337J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B16		W0131	2011B	24		23-31-06	ALL
B17		W0131	2526R	24		23-31-06	ALL
B18		W0131	2012B	24		23-31-06	ALL
B19		W0131	2029B	22		44-21-22	ALL
B20		W0131	0164	22		44-21-22	ALL
PERG	1F	W0131	2011Z			23-31-06	ALL
PERG	1F	W0131	2012Z			23-31-06	ALL
PERG	1F	W0131	2526Z			23-31-06	ALL
D41337P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W3307	2510R	24		23-31-01	ALL
A02		W3307	3501R	24		23-42-12	ALL
A03		W3307	3501Y	24		23-42-12	ALL
A04		W3307	0007	22		23-31-06	ALL
A05		W3307	0009	20		23-31-01	ALL
A06		W3307	0005	24		23-31-01	ALL
A07		W3307	0107	22		23-42-12	ALL
A08		W3307	0008	24		SPARE	ALL
A09		W3307	0028	24		23-31-06	ALL
A10		W3307	0088	22		44-21-22	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W3307	0002	22		23-31-06	ALL
A15	UNUSED						ALL
A16		W3307	2001R	24		23-31-06	ALL
A17		W3307	2512B	22		44-21-22	ALL
A18		W3307	2002R	24		23-31-06	ALL
A19		W3307	2012R	22		44-21-22	ALL
A20		W3307	0093	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41337P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B01		W3307	2510B	24		23-31-01	ALL
	B02		W3307	3501B	24		23-42-12	ALL
	B03		W3307	FRAC			23-42-12	ALL
	B04		W3307	0021	20		44-21-10	ALL
	B05		W3307	0011	20		44-21-10	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W3307	0003	22		23-31-06	ALL
	B09		W3307	0027	24		23-31-06	ALL
	B10		W3307	0006	22		23-31-06	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W3307	0001	22		23-31-06	ALL
	B15	UNUSED						ALL
	B16		W3307	2001B	24		23-31-06	ALL
	B17		W3307	2512R	22		44-21-22	ALL
	B18		W3307	2002B	24		23-31-06	ALL
	B19		W3307	2012B	22		44-21-22	ALL
	B20	UNUSED						ALL
	CAP	Y	W3307	0089	22		44-21-22	ALL
	CAP	Y	W3307	0102	22		44-21-22	ALL
	CAP	Y	W3307	0106	22		44-21-22	ALL
	CAP	Y	W3307	0127	22		44-21-22	ALL
	CAP	Y	W3307	0128	22		44-21-22	ALL
	CAP	Y	W3307	2011B	22		44-21-22	ALL
	CAP	Y	W3307	2011R	22		44-21-22	ALL
	CAP	Y	W3307	2014B	22		44-21-22	ALL
	CAP	Y	W3307	2014R	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41337P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	DED		W3307	2011Z			44-21-22	ALL
	DED		W3307	2014Z			44-21-22	ALL
			W3307	2510Z			23-31-01	ALL
			W3307	3501Z			23-42-12	ALL
			W3307	FRAC			23-42-12	ALL
	PERG	1F	W3307	2001Z			23-31-06	ALL
	PERG	1F	W3307	2002Z			23-31-06	ALL
	PERG	1F	W3307	2012Z			44-21-22	ALL
	PERG	1F	W3307	2512Z			44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41400J		**E001-03/ /**		**RCPT**				**ALL**
	A01		W0131	0114	24		32-42-11	ALL
	A02		W0131	0073	24		32-42-11	ALL
	A03		W0131	0075	24		32-42-11	ALL
	A04		W0131	0076	24		32-42-11	ALL
	A05		W0131	0077	24		32-42-11	ALL
	A06		W0131	0078	24		32-42-11	ALL
	A07		W0131	0079	24		32-42-11	ALL
	A08		W0131	0080	24		32-42-11	ALL
	A09		W0131	0081	24		32-42-11	ALL
	A10		W0131	0082	22		32-42-11	ALL
	B01		W0131	0083	24		32-42-11	ALL
	B02		W0131	0063	22		32-41-11	ALL
	B03		W0131	0064	22		32-41-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0131	1003	22		32-49-11	ALL
	B10		W0131	1001	22		32-46-11	ALL
	PERG	1F	W0131	1001Z			32-46-11	ALL
	PERG	1F	W0131	1003Z			32-49-11	ALL
D41400P		**E001-03/ /**		**PLUG-E1-3 SHELF**				**ALL**
	A01		W2022	0501	24		32-42-11	ALL
	A02		W2022	0502	24		32-42-11	ALL
	A03		W2022	0503	24		32-42-11	ALL
	A04		W2022	0504	24		32-42-11	ALL
	A05		W2022	0505	24		32-42-11	ALL
	A06		W2022	0506	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41400P	**E001-03/ /**		**PLUG-E1-3 SHELF (continued)**				**ALL**
A07		W2022	0507	24		32-42-11	ALL
A08		W2022	0508	24		32-42-11	ALL
A09		W2022	0509	24		32-42-11	ALL
A10		W2022	0510	22		32-42-11	ALL
B01		W2022	0511	24		32-42-11	ALL
B02		W2022	0512	24		32-41-11	ALL
B03		W2022	0513	24		32-41-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W2022	1003	22		32-49-11	ALL
B10		W2022	1002	22		32-46-11	ALL
PERG	1F	W2022	1002Z			32-46-11	ALL
PERG	1F	W2022	1003Z			32-49-11	ALL
D41417J	**E004-02/ /**		**RCPT**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W0422	4012Z			46-13-11	ALL
1-1		W0422	4012Y	24		46-13-11	ALL
1-2		W0422	4012R	24		46-13-11	ALL
1-3		W0422	4012G	24		46-13-11	ALL
1-4		W0422	4012B	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41417J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41417P		**E004-02/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W5172	4001Z			46-13-11	ALL
	1-1		W5172	4001Y	24		46-13-11	ALL
	1-2		W5172	4001R	24		46-13-11	ALL
	1-3		W5172	4001G	24		46-13-11	ALL
	1-4		W5172	4001B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41421J		**E004-02/ /**		**RCPT-**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0422	4013Z			46-13-11	ALL
	1-1		W0422	4013Y	24		46-13-11	ALL
	1-2		W0422	4013R	24		46-13-11	ALL
	1-3		W0422	4013G	24		46-13-11	ALL
	1-4		W0422	4013B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41421J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41421P		**E004-02/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W5162	4001Z			46-13-11	ALL
	1-1		W5162	4001Y	24		46-13-11	ALL
	1-2		W5162	4001R	24		46-13-11	ALL
	1-3		W5162	4001G	24		46-13-11	ALL
	1-4		W5162	4001B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41430J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0491	12		30-41-11	ALL
	2		W0044	0492	14		30-41-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
D41430P		**P006-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W2138	1001	12		30-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41430P		**P006-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	2		W2138	1002	14		30-41-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	PERB		W2138	1001Z			30-41-11	ALL
	PERB		W2138	1002Z			30-41-11	ALL
D41432J		**E002-01/ /**		**RCPT-**				**ALL**
	1		W0210	1003	12		30-41-11	ALL
	2		W0210	1004	14		30-41-11	ALL
	3		W0210	1003Z			30-41-11	ALL
	4		W0210	1004Z			30-41-11	ALL
D41432P		**E002-01/ /**		**PLUG-**				**ALL**
	1		W2138	1001	12		30-41-11	ALL
	2		W2138	1002	14		30-41-11	ALL
	3		W2138	1001Z			30-41-11	ALL
	4		W2138	1002Z			30-41-11	ALL
D41440J		**E004-02/ /**		**RCPT-**				**ALL**
	A01		W0420	5514	24		30-41-12	ALL
	A02		W0420	5517	24		30-41-12	ALL
	A03		W0420	2004R	24		30-41-12	ALL
	A04		W0420	5508	24		30-41-12	ALL
	A05		W0420	5509	24		30-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0420	5516	24		30-41-12	ALL
	B02		W0420	5518	24		30-41-12	ALL
	B03		W0420	2004B	24		30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41440J		**E004-02/ /**		**RCPT- (continued)**				**ALL**
	B04		W0420	5505	24		30-41-12	ALL
	B05		W0420	5507	24		30-41-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0420	2004Z			30-41-12	ALL
D41440P		**E004-02/ /**		**PLUG-**				**ALL**
	A01		W2218	5534	24		30-41-12	ALL
	A02		W2218	5536	24		30-41-12	ALL
	A03		W2218	2003R	24		30-41-12	ALL
	A04		W2218	5540	24		30-41-12	ALL
	A05		W2218	5538	24		30-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2218	5535	24		30-41-12	ALL
	B02		W2218	5537	24		30-41-12	ALL
	B03		W2218	2003B	24		30-41-12	ALL
	B04		W2218	5541	24		30-41-12	ALL
	B05		W2218	5539	24		30-41-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41440P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W2218	2003Z			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41500	**542/163/L009**		**PLUG-CONDUCTIVE**				**ALL**
1		W5502	2001B	20		21-51-11	ALL
2		W5502	2001R	20		21-51-11	ALL
3	UNUSED						ALL
4		W5502	1018	20		21-51-11	ALL
5		W5502	1040	20		33-33-11	ALL
6		W5502	2002R	20		21-51-11	ALL
7	UNUSED						ALL
8		W5502	1017	20		21-42-11	ALL
9	UNUSED						ALL
10		W5502	2005R	20		36-11-31	ALL
11		W5502	2005B	20		36-11-31	ALL
12		W5502	1005	20		36-11-31	ALL
13		W5502	1008	20		36-11-31	ALL
14		W5502	1011R	20		26-12-11	ALL
15	UNUSED						ALL
16		W5502	2002B	20		21-51-11	ALL
17		W5502	2083B	20		21-61-11	ALL
18		W5502	2083R	20		21-61-11	ALL
19		W5502	1037	20		21-61-11	ALL
20		W5502	1039	20		21-61-11	ALL
21		W5502	2084B	20		21-61-11	ALL
22		W5502	2084R	20		21-61-11	ALL
23		W5502	2003R	20		21-51-12	ALL
24		W5502	2003B	20		21-51-12	ALL
25		W5502	3001B	20		21-51-12	ALL
26		W5502	3001R	20		21-51-12	ALL
27		W5502	3001Y	20		21-51-12	ALL
28		W5502	2004R	20		21-51-12	ALL
29		W5502	2004B	20		21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41500		**542/163/L009**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W5502	1042	20		33-33-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W5502	1005Z			36-11-31	ALL
	S/R		W5502	1008Z			36-11-31	ALL
	S/R		W5502	1011Z			26-12-11	ALL
	S/R		W5502	1017Z			21-42-11	ALL
	S/R		W5502	1018Z			21-51-11	ALL
	S/R		W5502	1037Z			21-61-11	ALL
	S/R		W5502	1039Z			21-61-11	ALL
	S/R		W5502	1040Z			33-33-11	ALL
	S/R		W5502	1042Z			33-33-11	ALL
	S/R		W5502	2001Z			21-51-11	ALL
	S/R		W5502	2002Z			21-51-11	ALL
	S/R		W5502	2003Z			21-51-12	ALL
	S/R		W5502	2004Z			21-51-12	ALL
	S/R		W5502	2005Z			36-11-31	ALL
	S/R		W5502	2083Z			21-61-11	ALL
	S/R		W5502	2084Z			21-61-11	ALL
	S/R		W5502	3001Z			21-51-12	ALL
D41502		**536/163/L009**		**PLUG-**				**ALL**
	1		W5526	5533	24		21-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41502	**536/163/L009**		**PLUG- (continued)**				**ALL**
2		W5526	5534	24		21-61-11	ALL
3	UNUSED						ALL
4		W5526	5504	24		21-51-11	ALL
5		W5526	0519	20		33-33-11	ALL
6		W5526	5506	24		21-51-11	ALL
7	UNUSED						ALL
8		W5526	5507	22		21-42-11	ALL
9	UNUSED						ALL
10		W5526	2502R	22		36-11-31	ALL
11		W5526	2502B	22		36-11-31	ALL
12		W5526	5521	22		36-11-31	ALL
13		W5526	5522	22		36-11-31	ALL
14		W5526	6005R	20		26-12-11	ALL
15	UNUSED						ALL
16		W5526	5505	24		21-51-11	ALL
17		W5526	5524	24		21-61-11	ALL
18		W5526	5525	24		21-61-11	ALL
19		W5526	5526	24		21-61-11	ALL
20		W5526	5527	24		21-61-11	ALL
21		W5526	5528	24		21-61-11	ALL
22		W5526	5529	24		21-61-11	ALL
23		W5526	2002R	24		21-51-12	ALL
24		W5526	2002B	24		21-51-12	ALL
25		W5526	3001B	24		21-51-12	ALL
26		W5526	3001R	24		21-51-12	ALL
27		W5526	3001Y	24		21-51-12	ALL
28		W5526	2003R	24		21-51-12	ALL
29		W5526	2003B	24		21-51-12	ALL
30	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41502		**536/163/L009**		**PLUG- (continued)**				**ALL**
	31	UNUSED						ALL
	32		W5526	0518	20		33-33-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W5526	2002Z			21-51-12	ALL
	S/R		W5526	2003Z			21-51-12	ALL
	S/R		W5526	3001Z			21-51-12	ALL
D41507J		**AE0105A/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1		W5723	0001	24		34-53-21	ALL
	2		W5723	0002	24		34-53-21	ALL
	3		W5723	0003	24		34-53-21	ALL
	4		W5723	0004	24		34-53-21	ALL
	5		W5723	0005	24		34-53-21	ALL
	6		W5723	0006	24		34-53-21	ALL
	7		W5723	0007	24		34-53-21	ALL
	8		W5723	0008	24		34-53-21	ALL
	9		W5723	0009	24		34-53-21	ALL
	10		W5723	0010	24		34-53-21	ALL
	11		W5723	0011	24		34-53-21	ALL
	12		W5723	0012	24		34-53-21	ALL
	13		W5723	0013	24		34-53-21	ALL
	14		W5723	0014	24		34-53-21	ALL
	15		W5723	0015	24		34-53-21	ALL
	16		W5723	0016	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41507J	**AE0105A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
17		W5723	0017	24		34-53-21	ALL
18		W5723	0018	24		34-53-21	ALL
19		W5723	0019	24		34-53-21	ALL
20		W5723	0020	24		34-53-21	ALL
21		W5723	0021	24		34-53-21	ALL
22		W5723	0022	24		34-53-21	ALL
23		W5723	0023	24		34-53-21	ALL
24		W5723	0024	24		34-53-21	ALL
25		W5723	0025	24		34-53-21	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W5723	0031	22		34-55-21	ALL
32		W5723	0032	20		34-53-21	ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W5723	2016R	24		34-21-24	ALL
36		W5723	2016B	24		34-21-24	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41507J		**AE0105A/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51		W5723	2020R	22		34-53-21	ALL
	52		W5723	2020B	22		34-53-21	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W5723	2016Z			34-21-24	ALL
	S/R		W5723	2020Z			34-53-21	ALL
D41507P		**AE0105A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W0151	0201	24		34-53-21	ALL
	2		W0151	0202	24		34-53-21	ALL
	3		W0151	0203	24		34-53-21	ALL
	4		W0151	0204	24		34-53-21	ALL
	5		W0151	0205	24		34-53-21	ALL
	6		W0151	0206	24		34-53-21	ALL
	7		W0151	0207	24		34-53-21	ALL
	8		W0151	0208	24		34-53-21	ALL
	9		W0151	0209	24		34-53-21	ALL
	10		W0151	0210	24		34-53-21	ALL
	11		W0151	0211	24		34-53-21	ALL
	12		W0151	0212	24		34-53-21	ALL
	13		W0151	0213	24		34-53-21	ALL
	14		W0151	0214	24		34-53-21	ALL
	15		W0151	0215	24		34-53-21	ALL
	16		W0151	0216	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41507P	**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
17		W0151	0217	24		34-53-21	ALL
18		W0151	0218	24		34-53-21	ALL
19		W0151	0219	24		34-53-21	ALL
20		W0151	0220	24		34-53-21	ALL
21		W0151	0221	24		34-53-21	ALL
22		W0151	0222	24		34-53-21	ALL
23		W0151	0223	24		34-53-21	ALL
24		W0151	0224	24		34-53-21	ALL
25		W0151	0225	24		34-53-21	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31		W0151	0021	22		34-55-21	ALL
32		W0151	0002	20		34-53-21	ALL
33	UNUSED						ALL
34	UNUSED						ALL
35		W0151	2017R	24		34-21-24	ALL
36		W0151	2017B	24		34-21-24	ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41507P		**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51		W0151	2059R	22		34-53-21	ALL
	52		W0151	2059B	22		34-53-21	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W0151	2017Z			34-21-24	ALL
	S/R		W0151	2059Z			34-53-21	ALL
D41509J		**E001-03/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0131	0201	24		34-53-11	ALL
	A02		W0131	0202	24		34-53-11	ALL
	A03		W0131	0203	24		34-53-11	ALL
	A04		W0131	0204	24		34-53-11	ALL
	A05		W0131	0205	24		34-53-11	ALL
	A06		W0131	0206	24		34-53-11	ALL
	A07		W0131	0207	24		34-53-11	ALL
	A08		W0131	0208	24		34-53-11	ALL
	A09		W0131	0209	24		34-53-11	ALL
	A10		W0131	0210	24		34-53-11	ALL
	A11		W0131	0211	24		34-53-11	ALL
	A12		W0131	0212	24		34-53-11	ALL
	A13		W0131	0213	24		34-53-11	ALL
	A14		W0131	0214	24		34-53-11	ALL
	A15		W0131	0215	24		34-53-11	ALL
	A16		W0131	0216	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41509J	**E001-03/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A17		W0131	0217	24		34-53-11	ALL
A18		W0131	0218	24		34-53-11	ALL
A19		W0131	0219	24		34-53-11	ALL
A20		W0131	0220	24		34-53-11	ALL
B01		W0131	0221	24		34-53-11	ALL
B02		W0131	0222	24		34-53-11	ALL
B03		W0131	0223	24		34-53-11	ALL
B04		W0131	0224	24		34-53-11	ALL
B05		W0131	0225	24		34-53-11	ALL
B06		W0131	0043	22		23-42-11	ALL
B07		W0131	0123	22		34-31-11	ALL
B08		W0131	0057	24		31-31-17	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
D41509P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5719	0001	24		34-53-11	ALL
A02		W5719	0002	24		34-53-11	ALL
A03		W5719	0003	24		34-53-11	ALL
A04		W5719	0004	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41509P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05		W5719	0005	24		34-53-11	ALL
	A06		W5719	0006	24		34-53-11	ALL
	A07		W5719	0007	24		34-53-11	ALL
	A08		W5719	0008	24		34-53-11	ALL
	A09		W5719	0009	24		34-53-11	ALL
	A10		W5719	0010	24		34-53-11	ALL
	A11		W5719	0011	24		34-53-11	ALL
	A12		W5719	0012	24		34-53-11	ALL
	A13		W5719	0013	24		34-53-11	ALL
	A14		W5719	0014	24		34-53-11	ALL
	A15		W5719	0015	24		34-53-11	ALL
	A16		W5719	0016	24		34-53-11	ALL
	A17		W5719	0017	24		34-53-11	ALL
	A18		W5719	0018	24		34-53-11	ALL
	A19		W5719	0019	24		34-53-11	ALL
	A20		W5719	0020	24		34-53-11	ALL
	B01		W5719	0021	24		34-53-11	ALL
	B02		W5719	0022	24		34-53-11	ALL
	B03		W5719	0023	24		34-53-11	ALL
	B04		W5719	0024	24		34-53-11	ALL
	B05		W5719	0025	24		34-53-11	ALL
	B06		W5719	0034	22		23-42-11	ALL
	B07		W5719	0049	22		34-31-11	ALL
	B08		W5719	0042	22		31-31-17	ALL
	B09		W5719	0026	24		SPARE	ALL
	B10		W5719	0027	24		SPARE	ALL
	B11		W5719	0028	20		SPARE	ALL
	B12		W5719	0036	20		SPARE	ALL
	B13		W5719	0037	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41509P	**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B14		W5719	0038	24		SPARE	ALL
B15		W5719	2005R	24		SPARE	ALL
B16		W5719	2005B	24		SPARE	ALL
B17		W5719	2006R	24		SPARE	ALL
B18		W5719	2006B	24		SPARE	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5719	2005Z			SPARE	ALL
PERG	1F	W5719	2006Z			SPARE	ALL
D41511J	**AE0105A/ /**		**JACK-COAX**				**ALL**
=A1		W5099	001CX			34-53-31	ALL
=C1		W5099	001CO			34-53-31	ALL
D41511P	**E001-05/ /**		**PLUG-COAX**				**ALL**
=A1		W0151	003CX			34-53-31	ALL
=C1		W0151	003CO			34-53-31	ALL
D41515J	**AE0105A/ /**		**JACK-DME 2**				**ALL**
=A1		W5185	001CX			34-55-21	ALL
=C1		W5185	001CO			34-55-21	ALL
D41515P	**E001-05/ /**		**PLUG-COAX**				**ALL**
=A1		W0151	006CX			34-55-21	ALL
=C1		W0151	006CO			34-55-21	ALL
D41517J	**E001-05/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W2247	0020	24		34-53-21	ALL
2	UNUSED						ALL
3		W2247	0003	20		34-53-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W2247	0016	24		34-53-21	ALL
7		W2247	0007	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41517J		**E001-05/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	8	UNUSED						ALL
	9		W2247	0009	20		34-53-21	ALL
	10		W2247	0010	20		34-53-21	ALL
	11		W2247	0011	24		34-53-21	ALL
	12		W2247	0012	24		34-53-21	ALL
	13		W2247	2001R	24		34-53-21	ALL
	14		W2247	2001B	24		34-53-21	ALL
	15		W2247	0015	24		34-53-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41517J	**E001-05/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W2247	2001Z			34-53-21	ALL
D41517P	**AE0105A/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W0151	0020	24		34-53-21	ALL
2	UNUSED						ALL
3		W0151	0003	20		34-53-21	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W0151	0016	24		34-53-21	ALL
7		W0151	0007	24		34-53-21	ALL
8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41517P		**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	9		W0151	0009	20		34-53-21	ALL
	10		W0151	0010	20		34-53-21	ALL
	11		W0151	0011	24		34-53-21	ALL
	12		W0151	0012	24		34-53-21	ALL
	13		W0151	2001R	24		34-53-21	ALL
	14		W0151	2001B	24		34-53-21	ALL
	15		W0151	0015	24		34-53-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41517P	**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W0151	2001Z			34-53-21	ALL
D41557J	**E001-05/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W5163	2534R	24		34-45-21	ALL
2		W5163	2534B	24		34-45-21	ALL
3		W5163	0033	22		34-51-41	ALL
4		W5163	0035	22		SPARE	ALL
5		W5163	2532R	24		34-55-21	ALL
6		W5163	2532B	24		34-55-21	ALL
7		W5163	0041	22		34-51-41	ALL
8		W5163	2510R	24		34-21-24	ALL
9		W5163	2510B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41557J		**E001-05/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5163	0034	22		34-51-41	ALL
	13		W5163	2533R	24		34-45-21	ALL
	14		W5163	2533B	24		34-45-21	ALL
	15		W5163	2535R	24		34-61-14	ALL
	16		W5163	2535B	24		34-61-14	ALL
	17		W5163	2518R	24		34-21-23	ALL
	18		W5163	2518B	24		34-21-23	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W5163	0024	16		23-12-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W5163	2541R	24		22-11-51	ALL
	30		W5163	2541B	24		22-11-51	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41557J	**E001-05/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
39	UNUSED						ALL
S/R		W5163	2510Z			34-21-24	ALL
S/R		W5163	2518Z			34-21-23	ALL
S/R		W5163	2532Z			34-55-21	ALL
S/R		W5163	2533Z			34-45-21	ALL
S/R		W5163	2534Z			34-45-21	ALL
S/R		W5163	2535Z			34-61-14	ALL
S/R		W5163	2541Z			22-11-51	ALL
D41557P	**AE0105A/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W0151	2023R	24		34-45-21	ALL
2		W0151	2023B	24		34-45-21	ALL
3		W0151	0038	22		34-51-41	ALL
4	UNUSED						ALL
5		W0151	2013R	24		34-55-21	ALL
6		W0151	2013B	24		34-55-21	ALL
7		W0151	0061	22		34-51-41	ALL
8		W0151	2018R	24		34-21-24	ALL
9		W0151	2018B	24		34-21-24	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0151	0040	22		34-51-41	ALL
13		W0151	2004R	24		34-45-21	ALL
14		W0151	2004B	24		34-45-21	ALL
15		W0151	2020R	24		34-61-14	ALL
16		W0151	2020B	24		34-61-14	ALL
17		W0151	2002R	24		34-21-23	ALL
18		W0151	2002B	24		34-21-23	ALL
19	UNUSED						ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41557P		**AE0105A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	21		W0151	0031	16		23-12-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0151	2056R	24		22-11-51	ALL
	30		W0151	2056B	24		22-11-51	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W0151	2002Z			34-21-23	ALL
	S/R		W0151	2004Z			34-45-21	ALL
	S/R		W0151	2013Z			34-55-21	ALL
	S/R		W0151	2018Z			34-21-24	ALL
	S/R		W0151	2020Z			34-61-14	ALL
	S/R		W0151	2023Z			34-45-21	ALL
	S/R		W0151	2056Z			22-11-51	ALL
D41561J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5461	2003R	24		SPARE	ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41561J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A03		W5461	2013R	24		34-21-13	ALL
A04		W5461	2014R	24		34-21-13	ALL
A05		W5461	2015R	24		22-11-51	ALL
A06		W5461	2016R	24		22-11-51	ALL
A07		W5461	2017R	24		34-21-14	ALL
A08	UNUSED						ALL
A09		W5461	0061	24		34-61-17	ALL
A10	UNUSED						ALL
A11		W5461	2018R	24		SPARE	ALL
A12	UNUSED						ALL
A13		W5461	2020R	24		SPARE	ALL
A14		W5461	0008	22		34-61-12	ALL
A15		W5461	2011R	24		SPARE	ALL
A16		W5461	0071	24		31-31-17	ALL
A17		W5461	0063	24		34-61-17	ALL
A18	UNUSED						ALL
A19		W5461	0065	22		34-61-17	ALL
A20		W5461	2034R	24		SPARE	ALL
B01		W5461	2003B	24		SPARE	ALL
B02	UNUSED						ALL
B03		W5461	2013B	24		34-21-13	ALL
B04		W5461	2014B	24		34-21-13	ALL
B05		W5461	2015B	24		22-11-51	ALL
B06		W5461	2016B	24		22-11-51	ALL
B07		W5461	2017B	24		34-21-14	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W5461	2018B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41561J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B12	UNUSED						ALL
	B13		W5461	2020B	24		SPARE	ALL
	B14		W5461	0059	24		31-31-17	ALL
	B15		W5461	2011B	24		SPARE	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W5461	0038	22		34-21-16	ALL
	B19	UNUSED						ALL
	B20		W5461	2034B	24		SPARE	ALL
	PERG	1F	W5461	2003Z			SPARE	ALL
	PERG	1F	W5461	2011Z			SPARE	ALL
	PERG	1F	W5461	2013Z			34-21-13	ALL
	PERG	1F	W5461	2014Z			34-21-13	ALL
	PERG	1F	W5461	2015Z			22-11-51	ALL
	PERG	1F	W5461	2016Z			22-11-51	ALL
	PERG	1F	W5461	2017Z			34-21-14	ALL
	PERG	1F	W5461	2018Z			SPARE	ALL
	PERG	1F	W5461	2020Z			SPARE	ALL
	PERG	1F	W5461	2034Z			SPARE	ALL
D41561P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0521	2536R	24		34-21-13	ALL
	A04		W0521	2537R	24		34-21-13	ALL
	A05		W0521	2566R	24		22-11-51	ALL
	A06		W0521	2567R	24		22-11-51	ALL
	A07		W0521	2557R	24		34-21-14	ALL
	A08	UNUSED						ALL
	A09		W0521	0040	24		34-61-17	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41561P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0521	0020	22		34-61-12	ALL
A15	UNUSED						ALL
A16		W0521	0253	24		31-31-17	ALL
A17		W0521	0044	24		34-61-17	ALL
A18	UNUSED						ALL
A19		W0521	0048	24		34-61-17	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0521	2536B	24		34-21-13	ALL
B04		W0521	2537B	24		34-21-13	ALL
B05		W0521	2566B	24		22-11-51	ALL
B06		W0521	2567B	24		22-11-51	ALL
B07		W0521	2557B	24		34-21-14	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0521	0254	24		31-31-17	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18		W0521	0208	22		34-21-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41561P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2536Z			34-21-13	ALL
	PERG	1F	W0521	2537Z			34-21-13	ALL
	PERG	1F	W0521	2557Z			34-21-14	ALL
	PERG	1F	W0521	2566Z			22-11-51	ALL
	PERG	1F	W0521	2567Z			22-11-51	ALL
D41563J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0111	0810	24		21-51-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0111	0607	24		27-28-11	ALL
	A09		W0111	0604	24		27-28-11	ALL
	A10		W0111	2140R	24		27-28-11	ALL
	B01		W0111	2140B	24		27-28-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0111	2335R	24		22-23-12	ALL
	B07		W0111	2335B	24		22-23-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0111	2335Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41563P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W5463	0200	24		21-51-21	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W5463	2050B	24		27-28-11	ALL
A09		W5463	2050R	24		27-28-11	ALL
A10		W5463	2021R	24		27-28-11	ALL
B01		W5463	2021B	24		27-28-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W5463	2023R	24		22-23-12	ALL
B07		W5463	2023B	24		22-23-12	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5463	2023Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41600	**542/163/R009**		**PLUG-CONDUCTIVE**				**ALL**
1		W6502	2001B	20		21-51-21	ALL
2		W6502	2001R	20		21-51-21	ALL
3		W6502	1015	20		21-51-21	ALL
4		W6502	2002B	20		21-51-21	ALL
5	UNUSED						ALL
6		W6502	2002R	20		21-51-21	ALL
7	UNUSED						ALL
8		W6502	1014	20		21-42-11	ALL
9		W6502	1002R	20		26-12-11	ALL
10	UNUSED						ALL
11		W6502	1009	20		21-61-15	ALL
12		W6502	2003R	20		21-51-22	ALL
13		W6502	2003B	20		21-51-22	ALL
14		W6502	3001B	20		21-51-22	ALL
15		W6502	3001R	20		21-51-22	ALL
16		W6502	3001Y	20		21-51-22	ALL
17		W6502	2004R	20		21-51-22	ALL
18		W6502	2004B	20		21-51-22	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W6502	1022	20		33-33-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41600	**542/163/R009**		**PLUG-CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
S/R		W6502	1002Z			26-12-11	ALL
S/R		W6502	1009Z			21-61-15	ALL
S/R		W6502	1014Z			21-42-11	ALL
S/R		W6502	1015Z			21-51-21	ALL
S/R		W6502	1022Z			33-33-11	ALL
S/R		W6502	2001Z			21-51-21	ALL
S/R		W6502	2002Z			21-51-21	ALL
S/R		W6502	2003Z			21-51-22	ALL
S/R		W6502	2004Z			21-51-22	ALL
S/R		W6502	3001Z			21-51-22	ALL
D41602	**536/163/R009**		**PLUG-**				**ALL**
1		W6528	5502	24		21-51-21	ALL
2		W6528	5501	24		21-51-21	ALL
3		W6528	5503	24		21-51-21	ALL
4		W6528	5504	24		21-51-21	ALL
5	UNUSED						ALL
6		W6528	5506	24		21-51-21	ALL
7	UNUSED						ALL
8		W6528	5509	22		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41602	**536/163/R009**		**PLUG- (continued)**				**ALL**
9		W6528	6004R	20		26-12-11	ALL
10	UNUSED						ALL
11		W6528	0308	24		21-61-15	ALL
12		W6528	2002R	24		21-51-22	ALL
13		W6528	2002B	24		21-51-22	ALL
14		W6528	3002B	24		21-51-22	ALL
15		W6528	3002R	24		21-51-22	ALL
16		W6528	3002Y	24		21-51-22	ALL
17		W6528	2003R	24		21-51-22	ALL
18		W6528	2003B	24		21-51-22	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W6528	0001	20		33-33-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41602		**536/163/R009**		**PLUG- (continued)**				**ALL**
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W6528	2002Z			21-51-22	ALL
	S/R		W6528	2003Z			21-51-22	ALL
	S/R		W6528	3002Z			21-51-22	ALL
D41604J		**E004-02/ /**		**PANEL JACK THREADED (COAX)**				**ALL**
	=A1		W0421	001CX			23-15-12	ALL
	=C1		W0421	001CO			23-15-12	ALL
D41604P		**AE0402A/ /**		**PLUG - E4-2 SHELF**				**ALL**
	=A1		W3110	001CX			23-15-12	ALL
	=C1		W3110	001CO			23-15-12	ALL
D41607J		**E004-02/ /**		**PANEL JACK THREADED (COAX)**				**ALL**
	=A1		W0421	002CX			23-15-12	ALL
	=C1		W0421	002CO			23-15-12	ALL
D41607P		**AE0402A/ /**		**PLUG - E4-2 SHELF**				**ALL**
	=A1		W3120	001CX			23-15-12	ALL
	=C1		W3120	001CO			23-15-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41718J		**E004-02/ /**		**RCPT**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0422	4014Z			46-13-11	ALL
	1-1		W0422	4014Y	24		46-13-11	ALL
	1-2		W0422	4014R	24		46-13-11	ALL
	1-3		W0422	4014G	24		46-13-11	ALL
	1-4		W0422	4014B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41718P		**E004-02/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W6172	4001Z			46-13-11	ALL
	1-1		W6172	4001Y	24		46-13-11	ALL
	1-2		W6172	4001R	24		46-13-11	ALL
	1-3		W6172	4001G	24		46-13-11	ALL
	1-4		W6172	4001B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41718P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41722J		**E004-02/ /**		**RCPT**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0422	4015Z			46-13-11	ALL
	1-1		W0422	4015Y	24		46-13-11	ALL
	1-2		W0422	4015R	24		46-13-11	ALL
	1-3		W0422	4015G	24		46-13-11	ALL
	1-4		W0422	4015B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D41722P		**E004-02/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W6162	4001Z			46-13-11	ALL
	1-1		W6162	4001Y	24		46-13-11	ALL
	1-2		W6162	4001R	24		46-13-11	ALL
	1-3		W6162	4001G	24		46-13-11	ALL
	1-4		W6162	4001B	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41722P		**E004-02/ /**		**PLUG (continued)**				**ALL**
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41801J	**P018-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0018	0821	20		34-45-11	ALL
5		W0018	0008	20		22-11-11	ALL
6		W0018	0017	20		22-18-11	ALL
7		W0018	0823	22		34-49-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0018	3003R	20		23-11-11	ALL
17		W0018	3003Y	20		23-11-11	ALL
18		W0018	3003B	20		23-11-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
D41801P	**P018-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2101	0004	20		34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41801P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	5		W2101	0005	20		22-11-11	ALL
	6		W2101	0006	20		22-18-11	ALL
	7		W2101	0007	22		34-49-11	ALL
	8	UNUSED						ALL
	9		W2101	0009	22		SPARE	ALL
	10		W2101	0010	20		SPARE	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2101	3001R	20		23-11-11	ALL
	17		W2101	3001Y	20		23-11-11	ALL
	18		W2101	3001B	20		23-11-11	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
D41802J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	0304	24		21-51-12	ALL
	A02		W0330	0302	24		21-51-12	ALL
	A03		W0330	0301	24		21-51-12	ALL
	A04	UNUSED						ALL
	A05		W0330	0333	24		21-51-14	ALL
	A06		W0330	0334	24		21-51-14	ALL
	A07		W0330	0335	24		21-51-14	ALL
	A08		W0330	0336	24		21-51-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41802J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	A09		W0330	0207	24		21-51-12	ALL
	A10		W0330	0205	24		21-51-11	ALL
	B01		W0330	0383	24		21-61-11	ALL
	B02		W0330	0378	24		21-61-11	ALL
	B03		W0330	0382	24		21-61-11	ALL
	B04		W0330	0381	24		21-61-11	ALL
	B05		W0330	0380	24		21-61-11	ALL
	B06		W0330	0399	24		21-61-12	ALL
	B07		W0330	0400	24		21-61-12	ALL
	B08		W0330	0401	24		21-61-12	ALL
	B09		W0330	0208	24		21-51-12	ALL
	B10		W0330	0203	24		21-51-11	ALL
D41802P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W6220	0301	24		21-51-12	ALL
	A02		W6220	0302	24		21-51-12	ALL
	A03		W6220	0303	24		21-51-12	ALL
	A04	UNUSED						ALL
	A05		W6220	0305	24		21-51-14	ALL
	A06		W6220	0306	24		21-51-14	ALL
	A07		W6220	0307	24		21-51-14	ALL
	A08		W6220	0308	24		21-51-14	ALL
	A09		W6220	0409	24		21-51-12	ALL
	A10		W6220	0314	24		21-51-11	ALL
	B01		W6220	0401	24		21-61-11	ALL
	B02		W6220	0402	24		21-61-11	ALL
	B03		W6220	0403	24		21-61-11	ALL
	B04		W6220	0404	24		21-61-11	ALL
	B05		W6220	0405	24		21-61-11	ALL
	B06		W6220	0406	24		21-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41802P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	B07		W6220	0407	24		21-61-12	ALL
	B08		W6220	0408	24		21-61-12	ALL
	B09		W6220	0410	24		21-51-12	ALL
	B10		W6220	0316	24		21-51-11	ALL
D41803J		**P018-00/ /**		**RCPT-**				**ALL**
	1		W0018	0009	20		22-11-11	ALL
	2	UNUSED						ALL
	3		W0018	0011	20		22-11-12	ALL
	4		W0018	0018	20		22-18-11	ALL
	5		W0018	0704	22		27-32-11	ALL
	6	UNUSED						ALL
	7		W0018	0019	20		22-23-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0018	0024	18		22-31-31	ALL
	15	UNUSED						ALL
	16	10	W0018	0706	10		30-42-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0018	0515	20		34-61-22	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22		W0018	0805	16		34-21-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41803J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
25		W0018	0010	20		22-11-12	ALL
D41803P	**P018-00/ /**		**PLUG-**				**ALL**
1		W2175	0001	20		22-11-11	ALL
2	UNUSED						ALL
3		W2175	0003	20		22-11-12	ALL
4		W2175	0004	20		22-18-11	ALL
5		W2175	0005	22		27-32-11	ALL
6		W2175	0006	22		SPARE	ALL
7		W2175	0007	20		22-23-11	ALL
8		W2175	0008	20		SPARE	ALL
9		W2175	0009	22		SPARE	ALL
10		W2175	0010	22		SPARE	ALL
11	UNUSED						ALL
12		W2175	0012	20		SPARE	ALL
13		W2175	0013	20		SPARE	ALL
14		W2175	0014	18		22-31-31	ALL
15		W2175	0015	20		SPARE	ALL
16	10	W2175	0019	10		30-42-11	ALL
17		W2175	0017	20		SPARE	ALL
18		W2175	0018	18		SPARE	ALL
19		W2175	0011	20		34-61-22	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W2175	0022	16		34-21-11	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W2175	0002	20		22-11-12	ALL
CAP	Y	W2175	0024	16		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41804J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0318	24		21-51-12	ALL
	A02		W0410	0319	24		21-51-12	ALL
	A03		W0410	0320	24		21-51-12	ALL
	A04	UNUSED						ALL
	A05		W0410	0533	24		21-51-14	ALL
	A06		W0410	0541	24		21-51-14	ALL
	A07		W0410	0530	24		21-51-14	ALL
	A08		W0410	0531	24		21-51-14	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0410	0561	24		21-51-12	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0410	0385	24		21-61-11	ALL
	B02		W0410	0387	24		21-61-11	ALL
	B03		W0410	0388	24		21-61-11	ALL
	B04		W0410	0389	24		21-61-11	ALL
	B05		W0410	0390	24		21-61-11	ALL
	B06		W0410	0411	24		21-61-12	ALL
	B07		W0410	0410	24		21-61-12	ALL
	B08		W0410	0409	24		21-61-12	ALL
	B09		W0410	0095	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41804J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B10		W0410	0564	24		21-51-11	ALL
	B11		W0410	0562	24		21-51-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41804P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6220	0301	24		21-51-12	ALL
	A02		W6220	0302	24		21-51-12	ALL
	A03		W6220	0303	24		21-51-12	ALL
	A04	UNUSED						ALL
	A05		W6220	0305	24		21-51-14	ALL
	A06		W6220	0306	24		21-51-14	ALL
	A07		W6220	0307	24		21-51-14	ALL
	A08		W6220	0308	24		21-51-14	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W6220	0410	24		21-51-12	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41804P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6220	0401	24		21-61-11	ALL
	B02		W6220	0402	24		21-61-11	ALL
	B03		W6220	0403	24		21-61-11	ALL
	B04		W6220	0404	24		21-61-11	ALL
	B05		W6220	0405	24		21-61-11	ALL
	B06		W6220	0406	24		21-61-12	ALL
	B07		W6220	0407	24		21-61-12	ALL
	B08		W6220	0408	24		21-61-12	ALL
	B09		W6220	0316	24		21-51-11	ALL
	B10		W6220	0314	24		21-51-11	ALL
	B11		W6220	0409	24		21-51-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41805J		**P018-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0018	0021	20		22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41805J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
6		W0018	0749	22		31-31-14	ALL
7		W0018	0741	22		31-31-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	18	W0018	0859	18		78-32-51	ALL
21	UNUSED						ALL
22		W0018	0520	22		23-27-31	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
D41805P	**P018-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W2201	0005	20		22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41805P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	6		W2201	0006	22		31-31-14	ALL
	7		W2201	0007	22		31-31-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W2201	0013	20		SPARE	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2201	0016	20		SPARE	ALL
	17		W2201	0017	20		SPARE	ALL
	18		W2201	0018	20		SPARE	ALL
	19	UNUSED						ALL
	20	18	W2201	6043	18		78-32-51	ALL
	21	UNUSED						ALL
	22		W2201	0022	22		23-27-31	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
D41806J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	0350	24		21-51-22	ALL
	A02		W0330	0351	24		21-51-22	ALL
	A03		W0330	0353	24		21-51-22	ALL
	A04		W0330	0354	24		21-51-22	ALL
	A05		W0330	2002R	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41806J	**E003-03/ /**		**RCPT- (continued)**				**ALL**
A06		W0330	2002B	24		21-51-22	ALL
A07		W0330	0365	24		21-51-23	ALL
A08		W0330	0366	24		21-51-23	ALL
A09		W0330	0367	24		21-51-23	ALL
A10		W0330	0368	24		21-51-23	ALL
A11		W0330	0451	24		21-61-14	ALL
A12		W0330	0453	24		21-61-14	ALL
A13		W0330	0454	24		21-61-14	ALL
A14		W0330	0080	24		21-51-22	ALL
A15		W0330	0081	24		21-51-22	ALL
A16		W0330	0534	24		21-51-24	ALL
A17		W0330	0535	24		21-51-24	ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0330	0416	24		21-61-13	ALL
B04		W0330	0418	24		21-61-13	ALL
B05		W0330	0419	24		21-61-13	ALL
B06		W0330	2526B	24		36-21-11	ALL
B07		W0330	2526R	24		36-21-11	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41806J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0330	2526Z			36-21-11	ALL
D41806P		**E003-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6230	0305	24		21-51-22	ALL
	A02		W6230	0306	24		21-51-22	ALL
	A03		W6230	0307	24		21-51-22	ALL
	A04		W6230	0308	24		21-51-22	ALL
	A05		W6230	2001R	20		21-51-22	ALL
	A06		W6230	2001B	20		21-51-22	ALL
	A07		W6230	0309	24		21-51-23	ALL
	A08		W6230	0310	24		21-51-23	ALL
	A09		W6230	0311	24		21-51-23	ALL
	A10		W6230	0312	24		21-51-23	ALL
	A11		W6230	0319	24		21-61-14	ALL
	A12		W6230	0320	24		21-61-14	ALL
	A13		W6230	0321	24		21-61-14	ALL
	A14		W6230	2005B	24		21-51-22	ALL
	A15		W6230	2005R	24		21-51-22	ALL
	A16		W6230	2090R	24		21-51-24	ALL
	A17		W6230	2090B	24		21-51-24	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41806P	**E003-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B02	UNUSED						ALL
B03		W6230	0316	24		21-61-13	ALL
B04		W6230	0317	24		21-61-13	ALL
B05		W6230	0318	24		21-61-13	ALL
B06		W6230	2501B	24		36-21-11	ALL
B07		W6230	2501R	24		36-21-11	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W6230	2090Z			21-51-24	ALL
PERG	1F	W6230	2501Z			36-21-11	ALL
D41807J	**P018-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2		W0018	0809	16		31-65-11	ALL
3		W0018	0016	20		22-14-11	ALL
4		W0018	0029	16		23-12-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0018	0807	22		34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41807J		**P018-00/ /**		**RCPT- (continued)**				**ALL**
	8		W0018	0808	16		31-65-11	ALL
	9	UNUSED						ALL
	10		W0018	0810	20		31-65-11	ALL
	11		W0018	0815	20		34-53-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0018	0330	22		33-27-11	ALL
	15		W0018	0814	22		34-51-41	ALL
	16		W0018	0063	22		34-55-11	ALL
	17		W0018	0884	22		31-65-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
D41807P		**P018-00/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2		W2651	0002	16		31-65-11	ALL
	3		W2651	0003	20		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41807P	**P018-00/ /**		**PLUG- (continued)**				**ALL**
4		W2651	0015	16		23-12-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2651	0007	22		34-31-11	ALL
8		W2651	0023	16		31-65-11	ALL
9	UNUSED						ALL
10		W2651	0027	20		31-65-11	ALL
11		W2651	0011	20		34-53-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W2651	0014	22		33-27-11	ALL
15		W2651	0004	22		34-51-41	ALL
16		W2651	0016	20		34-55-11	ALL
17		W2651	0017	22		31-65-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W2651	0024	20		SPARE	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41808J		**E003-03/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0330	0371	24		21-51-24	ALL
	A06		W0330	0372	24		21-51-24	ALL
	A07		W0330	0373	24		21-51-24	ALL
	A08		W0330	0374	24		21-51-24	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0330	0412	24		21-61-13	ALL
	B02		W0330	0410	24		21-61-13	ALL
	B03		W0330	0409	24		21-61-13	ALL
	B04		W0330	0408	24		21-61-13	ALL
	B05		W0330	0407	24		21-61-13	ALL
	B06		W0330	0447	24		21-61-14	ALL
	B07		W0330	0445	24		21-61-14	ALL
	B08		W0330	0444	24		21-61-14	ALL
	B09		W0330	0423	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41808J		**E003-03/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B10		W0330	0422	24		21-61-14	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0330	0024	24		36-11-13	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41808P		**E003-03/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6420	0305	24		21-51-24	ALL
	A06		W6420	0306	24		21-51-24	ALL
	A07		W6420	0307	24		21-51-24	ALL
	A08		W6420	0308	24		21-51-24	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41808P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6420	0401	24		21-61-13	ALL
	B02		W6420	0402	24		21-61-13	ALL
	B03		W6420	0403	24		21-61-13	ALL
	B04		W6420	0404	24		21-61-13	ALL
	B05		W6420	0405	24		21-61-13	ALL
	B06		W6420	0406	24		21-61-14	ALL
	B07		W6420	0407	24		21-61-14	ALL
	B08		W6420	0408	24		21-61-14	ALL
	B09		W6420	0409	24		21-61-14	ALL
	B10		W6420	0410	24		21-61-14	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W6420	0313	24		36-11-13	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41809J		**P018-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0018	0832	22		34-57-11	ALL
	4		W0018	0803	20		34-21-11	ALL
	5		W0018	0804	20		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41809J	**P018-00/ /**		**RCPT- (continued)**				**ALL**
6		W0018	0394	20		34-61-11	ALL
7		W0018	0835	20		34-61-11	ALL
8		W0018	0701	22		27-32-11	ALL
9		W0018	0702	22		27-32-11	ALL
10		W0018	0703	22		27-32-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0018	0887	16		31-65-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28		W0018	0816	20		34-24-15	ALL
D41809P	**P018-00/ /**		**PLUG-**				**ALL**
1		W2653	0001	20		SPARE	ALL
2		W2653	0002	22		SPARE	ALL
3		W2653	0003	22		34-57-11	ALL
4		W2653	0004	20		34-21-11	ALL
5		W2653	0005	20		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41809P		**P018-00/ /**		**PLUG- (continued)**				**ALL**
	6		W2653	0006	20		34-61-11	ALL
	7		W2653	0007	20		34-61-11	ALL
	8		W2653	0008	22		27-32-11	ALL
	9		W2653	0009	22		27-32-11	ALL
	10		W2653	0010	22		27-32-11	ALL
	11		W2653	0011	20		SPARE	ALL
	12		W2653	0012	20		SPARE	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W2653	0015	16		31-65-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W2653	0019	16		SPARE	ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2653	0023	18		SPARE	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2653	0017	20		34-24-15	ALL
D41810J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0359	24		21-51-22	ALL
	A02		W0410	0360	24		21-51-22	ALL
	A03		W0410	0361	24		21-51-22	ALL
	A04		W0410	0551	24		21-51-24	ALL
	A05		W0410	0547	24		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41810J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	A06		W0410	0559	24		21-51-24	ALL
	A07		W0410	0548	24		21-51-24	ALL
	A08		W0410	0550	24		21-51-24	ALL
	A09		W0410	0448	24		21-61-15	ALL
	A10		W0410	0552	24		21-51-24	ALL
	B01		W0410	0413	24		21-61-13	ALL
	B02		W0410	0416	24		21-61-13	ALL
	B03		W0410	0417	24		21-61-13	ALL
	B04		W0410	0418	24		21-61-13	ALL
	B05		W0410	0419	24		21-61-13	ALL
	B06		W0410	0430	24		21-61-14	ALL
	B07		W0410	0433	24		21-61-14	ALL
	B08		W0410	0434	24		21-61-14	ALL
	B09		W0410	0435	24		21-61-14	ALL
	B10		W0410	0436	24		21-61-14	ALL
D41810P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6420	0301	24		21-51-22	ALL
	A02		W6420	0302	24		21-51-22	ALL
	A03		W6420	0303	24		21-51-22	ALL
	A04		W6420	0311	24		21-51-24	ALL
	A05		W6420	0305	24		21-51-24	ALL
	A06		W6420	0306	24		21-51-24	ALL
	A07		W6420	0307	24		21-51-24	ALL
	A08		W6420	0308	24		21-51-24	ALL
	A09		W6420	0309	22		21-61-15	ALL
	A10		W6420	0310	24		21-51-24	ALL
	B01		W6420	0401	24		21-61-13	ALL
	B02		W6420	0402	24		21-61-13	ALL
	B03		W6420	0403	24		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41810P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	B04		W6420	0404	24		21-61-13	ALL
	B05		W6420	0405	24		21-61-13	ALL
	B06		W6420	0406	24		21-61-14	ALL
	B07		W6420	0407	24		21-61-14	ALL
	B08		W6420	0408	24		21-61-14	ALL
	B09		W6420	0409	24		21-61-14	ALL
	B10		W6420	0410	24		21-61-14	ALL
D41811J		**E001-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0111	0066	20		34-45-11	ALL
	A05		W0111	0023	20		22-11-11	ALL
	A06		W0111	0130	20		22-18-11	ALL
	A07		W0111	0263	22		34-49-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41811P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2101	0004	20		34-45-11	ALL
	A05		W2101	0005	20		22-11-11	ALL
	A06		W2101	0006	20		22-18-11	ALL
	A07		W2101	0007	22		34-49-11	ALL
	A08	UNUSED						ALL
	A09		W2101	0009	22		SPARE	ALL
	A10		W2101	0010	20		SPARE	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41812J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	0306	24		21-51-12	ALL
	A02		W0330	0307	24		21-51-12	ALL
	A03		W0330	0312	24		21-51-12	ALL
	A04		W0330	0384	24		21-61-11	ALL
	A05		W0330	0386	24		21-61-11	ALL
	A06		W0330	2003B	24		21-61-11	ALL
	A07		W0330	2003R	24		21-61-11	ALL
	A08		W0330	3003Y	24		21-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41812J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	A09		W0330	3003R	24		21-61-11	ALL
	A10		W0330	3003B	24		21-61-11	ALL
	A11		W0330	0448	24		21-61-14	ALL
	A12		W0330	3010B	24		21-61-14	ALL
	A13		W0330	3010R	24		21-61-14	ALL
	A14		W0330	3010Y	24		21-61-14	ALL
	A15		W0330	0091	22		36-11-13	ALL
	A16		W0330	3009B	24		21-61-14	ALL
	A17		W0330	3009R	24		21-61-14	ALL
	A18		W0330	3009Y	24		21-61-14	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0330	0377	24		21-61-11	ALL
	B02		W0330	0402	24		21-61-12	ALL
	B03		W0330	3004Y	24		21-61-12	ALL
	B04		W0330	3004R	24		21-61-12	ALL
	B05		W0330	3004B	24		21-61-12	ALL
	B06		W0330	2005B	24		21-61-12	ALL
	B07		W0330	2005R	24		21-61-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0330	0054	24		36-11-31	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41812J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41812P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W2216	5549	24		21-51-12	ALL
	A02		W2216	5555	24		21-51-12	ALL
	A03		W2216	5552	24		21-51-12	ALL
	A04		W2216	5553	24		21-61-11	ALL
	A05		W2216	5506	24		21-61-11	ALL
	A06		W2216	2001B	24		21-61-11	ALL
	A07		W2216	2001R	24		21-61-11	ALL
	A08		W2216	3001Y	24		21-61-11	ALL
	A09		W2216	3001R	24		21-61-11	ALL
	A10		W2216	3001B	24		21-61-11	ALL
	A11		W2216	5563	24		21-61-14	ALL
	A12		W2216	3003B	24		21-61-14	ALL
	A13		W2216	3003R	24		21-61-14	ALL
	A14		W2216	3003Y	24		21-61-14	ALL
	A15		W2216	0020	22		36-11-13	ALL
	A16		W2216	3004B	24		21-61-14	ALL
	A17		W2216	3004R	24		21-61-14	ALL
	A18		W2216	3004Y	24		21-61-14	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W2216	5508	24		21-61-11	ALL
	B02		W2216	5558	24		21-61-12	ALL
	B03		W2216	3002Y	24		21-61-12	ALL
	B04		W2216	3002R	24		21-61-12	ALL
	B05		W2216	3002B	24		21-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41812P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	B06		W2216	2002B	24		21-61-12	ALL
	B07		W2216	2002R	24		21-61-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W2216	5576	24		36-11-31	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41813J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	0077	22		30-21-31	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41813J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41813P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W2216	6017	22		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41813P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41813P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41814J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	0308	24		21-51-12	ALL
	A02		W0330	2004R	24		21-61-11	ALL
	A03		W0330	2004B	24		21-61-11	ALL
	A04		W0330	2006R	24		21-61-12	ALL
	A05		W0330	2006B	24		21-61-12	ALL
	A06		W0330	0010	24		36-11-12	ALL
	A07		W0330	0011	24		36-11-12	ALL
	A08		W0330	0026	24		36-11-13	ALL
	A09		W0330	2528R	24		36-21-11	ALL
	A10		W0330	2528B	24		36-21-11	ALL
	B01		W0330	0309	24		21-51-12	ALL
	B02		W0330	0012	24		36-11-12	ALL
	B03		W0330	0013	24		36-11-12	ALL
	B04		W0330	0014	24		36-11-12	ALL
	B05		W0330	0015	24		36-11-12	ALL
	B06		W0330	0016	24		36-11-12	ALL
	B07		W0330	0017	24		36-11-12	ALL
	B08		W0330	0027	24		36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41814J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	B09		W0330	0018	22		36-11-13	ALL
	B10		W0330	0020	22		36-11-13	ALL
	PERG	1F	W0330	2528Z			36-21-11	ALL
D41814P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W6214	0302	24		21-51-12	ALL
	A02		W6214	2005R	20		21-61-11	ALL
	A03		W6214	2005B	20		21-61-11	ALL
	A04		W6214	2006R	20		21-61-12	ALL
	A05		W6214	2006B	20		21-61-12	ALL
	A06		W6214	0311	24		36-11-12	ALL
	A07		W6214	0312	24		36-11-12	ALL
	A08		W6214	0003	24		36-11-13	ALL
	A09		W6214	2501R	24		36-21-11	ALL
	A10		W6214	2501B	24		36-21-11	ALL
	B01		W6214	0303	24		21-51-12	ALL
	B02		W6214	0313	24		36-11-12	ALL
	B03		W6214	0314	24		36-11-12	ALL
	B04		W6214	0315	24		36-11-12	ALL
	B05		W6214	0316	24		36-11-12	ALL
	B06		W6214	0317	24		36-11-12	ALL
	B07		W6214	0318	24		36-11-12	ALL
	B08		W6214	0004	24		36-11-13	ALL
	B09		W6214	5542	20		36-11-13	ALL
	B10		W6214	5543	20		36-11-13	ALL
	PERG	1F	W6214	2501Z			36-21-11	ALL
D41816J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0410	0424	24		21-61-13	ALL
	A02		W0410	0441	24		21-61-14	ALL
	A03		W0410	0586	24		36-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41816J		**E004-01/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A04		W0410	0587	24		36-11-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0410	2503R	24		36-21-11	ALL
	B01	UNUSED						ALL
	B02		W0410	0609	24		36-11-31	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0410	2503B	24		36-21-11	ALL
	PERG	1F	W0410	2503Z			36-21-11	ALL
D41816P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6288	0001	20		21-61-13	ALL
	A02		W6288	0006	20		21-61-14	ALL
	A03		W6288	0021	24		36-11-31	ALL
	A04		W6288	0022	24		36-11-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W6288	2502R	24		36-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41816P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	B01		W6288	0020	24		SPARE	ALL
	B02		W6288	0061	24		36-11-31	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6288	2502B	24		36-21-11	ALL
	PERG	1F	W6288	2502Z			36-21-11	ALL
D41818J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	2527R	24		36-21-11	ALL
	A02		W0330	2527B	24		36-21-11	ALL
	A03		W0330	2009B	24		21-61-13	ALL
	A04		W0330	2009R	24		21-61-13	ALL
	A05		W0330	0417	24		21-61-13	ALL
	A06		W0330	2008B	24		21-61-13	ALL
	A07		W0330	2008R	24		21-61-13	ALL
	A08		W0330	2007R	24		21-61-13	ALL
	A09		W0330	2007B	24		21-61-13	ALL
	A10	UNUSED						ALL
	B01		W0330	2011B	24		21-61-14	ALL
	B02		W0330	2011R	24		21-61-14	ALL
	B03		W0330	0452	24		21-61-14	ALL
	B04		W0330	2010B	24		21-61-14	ALL
	B05		W0330	2010R	24		21-61-14	ALL
	B06		W0330	2012R	24		21-61-14	ALL
	B07		W0330	2012B	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41818J	**E003-03/ /**		**RCPT- (continued)**				**ALL**
B08		W0330	0061	24		36-11-31	ALL
B09		W0330	0059	24		36-11-31	ALL
B10		W0330	0060	24		36-11-31	ALL
PERG	1F	W0330	2527Z			36-21-11	ALL
D41818P	**E003-03/ /**		**PLUG-**				**ALL**
A01		W6288	2502R	24		36-21-11	ALL
A02		W6288	2502B	24		36-21-11	ALL
A03		W6288	2001B	20		21-61-13	ALL
A04		W6288	2001R	20		21-61-13	ALL
A05		W6288	0003	24		21-61-13	ALL
A06		W6288	2002B	24		21-61-13	ALL
A07		W6288	2002R	24		21-61-13	ALL
A08		W6288	2003R	24		21-61-13	ALL
A09		W6288	2003B	24		21-61-13	ALL
A10		W6288	0020	24		SPARE	ALL
B01		W6288	2004B	20		21-61-14	ALL
B02		W6288	2004R	20		21-61-14	ALL
B03		W6288	0008	24		21-61-14	ALL
B04		W6288	2005B	24		21-61-14	ALL
B05		W6288	2005R	24		21-61-14	ALL
B06		W6288	2006R	24		21-61-14	ALL
B07		W6288	2006B	24		21-61-14	ALL
B08		W6288	0061	24		36-11-31	ALL
B09		W6288	0022	24		36-11-31	ALL
B10		W6288	0021	24		36-11-31	ALL
PERG	1F	W6288	2502Z			36-21-11	ALL
D41819J	**E003-02/ /**		**RCPT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41819J		**E003-02/ /**		**RCPT (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0321	0226	20		22-23-12	ALL
	6		W0321	0022	22		31-31-14	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0321	0576	18		27-61-41	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W0321	0133	22		27-32-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
D41819P		**E003-02/ /**		**PLUG E3-2 SHELF**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41819P	**E003-02/ /**		**PLUG E3-2 SHELF (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5		W2201	0005	20		22-23-12	ALL
6		W2201	0006	22		31-31-14	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2201	0013	20		SPARE	ALL
14	UNUSED						ALL
15		W2201	0046	18		27-61-41	ALL
16		W2201	0016	20		SPARE	ALL
17		W2201	0017	20		SPARE	ALL
18		W2201	0018	20		SPARE	ALL
19	UNUSED						ALL
20		W2201	0020	20		27-32-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
D41821J	**E001-01/ /**		**RCPT-**				**ALL**
A01		W0111	0001	20		22-11-11	ALL
A02		W0111	0037	20		22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41821J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A03		W0111	0036	20		22-11-12	ALL
	A04		W0111	0199	20		22-18-11	ALL
	A05		W0111	0222	22		27-32-11	ALL
	A06	UNUSED						ALL
	A07		W0111	0250	20		22-23-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0111	0121	20		34-61-22	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0111	0300	18		22-31-31	ALL
	G	UNUSED						ALL
	H		W0111	0725	16		34-21-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D41821P		**E001-01/ /**		**PLUG E1-1 SHELF**				**ALL**
	A01		W2175	0001	20		22-11-11	ALL
	A02		W2175	0002	20		22-11-12	ALL
	A03		W2175	0003	20		22-11-12	ALL
	A04		W2175	0004	20		22-18-11	ALL
	A05		W2175	0005	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41821P	**E001-01/ /**		**PLUG E1-1 SHELF (continued)**				**ALL**
A06		W2175	0006	22		SPARE	ALL
A07		W2175	0007	20		22-23-11	ALL
A08		W2175	0008	20		SPARE	ALL
A09		W2175	0009	22		SPARE	ALL
A10		W2175	0010	22		SPARE	ALL
B01		W2175	0011	20		34-61-22	ALL
B02		W2175	0012	20		SPARE	ALL
B03		W2175	0013	20		SPARE	ALL
B04	UNUSED						ALL
B05		W2175	0015	20		SPARE	ALL
B06	UNUSED						ALL
B07		W2175	0017	20		SPARE	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2175	0014	18		22-31-31	ALL
G		W2175	0024	16		SPARE	ALL
H		W2175	0022	16		34-21-11	ALL
J	UNUSED						ALL
K		W2175	0018	18		SPARE	ALL
D41822J	**E003-03/ /**		**RCPT-**				**ALL**
A01		W0330	0345	24		21-51-22	ALL
A02		W0330	0346	22		21-51-22	ALL
A03		W0330	0406	24		21-61-13	ALL
A04		W0330	0421	24		21-61-14	ALL
A05		W0330	0505	24		21-51-21	ALL
A06		W0330	0506	24		21-51-21	ALL
A07		W0330	0507	24		21-51-21	ALL
A08		W0330	0508	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41822J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10		W0330	0233	24		21-51-22	ALL
	B01		W0330	0510	24		21-51-21	ALL
	B02		W0330	0232	24		21-51-22	ALL
	B03		W0330	0511	24		21-51-21	ALL
	B04		W0330	0049	22		36-11-23	ALL
	B05		W0330	0042	22		36-11-23	ALL
	B06		W0330	0509	24		21-51-21	ALL
	B07		W0330	0202	24		21-51-12	ALL
	B08		W0330	0206	24		21-51-12	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41822P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W6412	0302	24		21-51-22	ALL
	A02		W6412	0303	22		21-51-22	ALL
	A03		W6412	5542	24		21-61-13	ALL
	A04		W6412	5544	24		21-61-14	ALL
	A05		W6412	0205	24		21-51-21	ALL
	A06		W6412	0206	24		21-51-21	ALL
	A07		W6412	0207	24		21-51-21	ALL
	A08		W6412	0208	24		21-51-21	ALL
	A09	UNUSED						ALL
	A10		W6412	0536	24		21-51-22	ALL
	B01		W6412	0211	24		21-51-21	ALL
	B02		W6412	0535	24		21-51-22	ALL
	B03		W6412	0210	24		21-51-21	ALL
	B04		W6412	5534	20		36-11-23	ALL
	B05		W6412	5535	20		36-11-23	ALL
	B06		W6412	0209	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41822P	**E003-03/ /**		**PLUG- (continued)**				**ALL**
B07		W6412	0548	24		21-51-12	ALL
B08		W6412	0540	24		21-51-12	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D41824J	**E003-03/173/L005**		**RCPT-**				**ALL**
1		W0330	0076	22		30-21-31	ALL
2	UNUSED						ALL
3		W0330	0224	24		21-51-12	ALL
4		W0330	2502R	24		31-65-14	ALL
5		W0330	0456	14		21-25-11	ALL
6		W0330	2501R	24		31-65-15	ALL
7		W0330	2502B	24		31-65-14	ALL
8		W0330	0457	14		21-25-11	ALL
9		W0330	2501B	24		31-65-15	ALL
10		W0330	0458	14		21-25-11	ALL
11		W0330	2020B	24		21-51-12	ALL
12		W0330	2511R	24		36-11-14	ALL
13		W0330	0223	24		21-51-12	ALL
14		W0330	2511B	24		36-11-14	ALL
15		W0330	2020R	24		21-51-12	ALL
16		W0330	2021B	24		21-51-12	ALL
17		W0330	2021R	24		21-51-12	ALL
PERS	1A	W0330	2020Z			21-51-12	ALL
PERS	1A	W0330	2021Z			21-51-12	ALL
PERS	1A	W0330	2501Z			31-65-15	ALL
PERS	1A	W0330	2502Z			31-65-14	ALL
PERS	1A	W0330	2511Z			36-11-14	ALL
D41824P	**E003-03/173/L005**		**INSERT - SOCKET**				**ALL**
1		W5156	0092	22		30-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41824P		**E003-03/173/L005**		**INSERT - SOCKET (continued)**				**ALL**
	2	UNUSED						ALL
	3		W5156	5590	24		21-51-12	ALL
	4		W5156	2503R	24		31-65-14	ALL
	5		W5156	0622	14		21-25-11	ALL
	6		W5156	2616R	24		31-65-15	ALL
	7		W5156	2503B	24		31-65-14	ALL
	8		W5156	0623	14		21-25-11	ALL
	9		W5156	2616B	24		31-65-15	ALL
	10		W5156	0624	14		21-25-11	ALL
	11		W5156	2617B	24		21-51-12	ALL
	12		W5156	2502R	24		36-11-14	ALL
	13		W5156	0038	24		21-51-12	ALL
	14		W5156	2502B	24		36-11-14	ALL
	15		W5156	2617R	24		21-51-12	ALL
	16		W5156	2618B	24		21-51-12	ALL
	17		W5156	2618R	24		21-51-12	ALL
	PERS	1A	W5156	2502Z			36-11-14	ALL
	PERS	1A	W5156	2503Z			31-65-14	ALL
	PERS	1A	W5156	2616Z			31-65-15	ALL
	PERS	1A	W5156	2617Z			21-51-12	ALL
	PERS	1A	W5156	2618Z			21-51-12	ALL
D41826J		**E003-03/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01		W0330	0343	24		21-51-22	ALL
	A02		W0330	0344	24		21-51-22	ALL
	A03		W0330	0348	24		21-51-22	ALL
	A04		W0330	0513	22		30-21-32	ALL
	A05	UNUSED						ALL
	A06		W0330	0512	22		30-21-32	ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41826J		**E003-03/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W0330	0464	22		21-61-15	ALL
	A10		W0330	0045	24		36-11-23	ALL
	B01		W0330	0413	24		21-61-13	ALL
	B02		W0330	3008Y	24		21-61-13	ALL
	B03		W0330	3008R	24		21-61-13	ALL
	B04		W0330	3008B	24		21-61-13	ALL
	B05	UNUSED						ALL
	B06		W0330	3007Y	24		21-61-13	ALL
	B07		W0330	3007B	24		21-61-13	ALL
	B08		W0330	3007R	24		21-61-13	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41826P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W2218	5517	24		21-51-22	ALL
	A02		W2218	5515	24		21-51-22	ALL
	A03		W2218	5551	24		21-51-22	ALL
	A04		W2218	5650	22		30-21-32	ALL
	A05	UNUSED						ALL
	A06		W2218	5637	22		30-21-32	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W2218	5568	22		21-61-15	ALL
	A10		W2218	5579	24		36-11-23	ALL
	B01		W2218	5556	24		21-61-13	ALL
	B02		W2218	3001Y	24		21-61-13	ALL
	B03		W2218	3001R	24		21-61-13	ALL
	B04		W2218	3001B	24		21-61-13	ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41826P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	B06		W2218	3002Y	24		21-61-13	ALL
	B07		W2218	3002B	24		21-61-13	ALL
	B08		W2218	3002R	24		21-61-13	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41828J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0315	24		21-51-12	ALL
	A02		W0410	0384	24		21-61-11	ALL
	A03	UNUSED						ALL
	A04		W0410	0233	22		23-22-11	ALL
	A05		W0410	0234	22		23-22-11	ALL
	A06		W0410	0235	22		23-22-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0410	0450	24		21-61-51	ALL
	A10		W0410	0520	24		36-11-13	ALL
	A11		W0410	0394	24		21-51-12	ALL
	A12		W0410	0399	24		21-61-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0410	0061	24		36-11-12	ALL
	B02		W0410	0062	24		36-11-12	ALL
	B03		W0410	0063	24		36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41828J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B04		W0410	0064	24		36-11-12	ALL
	B05		W0410	0065	24		36-11-12	ALL
	B06		W0410	0226	24		36-11-12	ALL
	B07		W0410	0067	24		36-11-12	ALL
	B08		W0410	0070	24		36-11-12	ALL
	B09	UNUSED						ALL
	B10		W0410	0518	24		36-11-13	ALL
	B11		W0410	0236	22		23-71-01	ALL
	B12		W0410	0237	22		23-71-01	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41828P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6214	0301	24		21-51-12	ALL
	A02		W6214	5550	24		21-61-11	ALL
	A03	UNUSED						ALL
	A04		W6214	0030	22		23-22-11	ALL
	A05		W6214	0031	22		23-22-11	ALL
	A06		W6214	0032	22		23-22-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6214	5553	20		21-61-51	ALL
	A10		W6214	0003	24		36-11-13	ALL
	A11		W6214	0310	24		21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41828P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A12		W6214	5551	20		21-61-11	ALL
	A13	UNUSED						ALL
	A14		W6214	5544	20		SPARE	ALL
	A15		W6214	5545	20		SPARE	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6214	0318	24		36-11-12	ALL
	B02		W6214	0317	24		36-11-12	ALL
	B03		W6214	0316	24		36-11-12	ALL
	B04		W6214	0315	24		36-11-12	ALL
	B05		W6214	0314	24		36-11-12	ALL
	B06		W6214	0313	24		36-11-12	ALL
	B07		W6214	0312	24		36-11-12	ALL
	B08		W6214	0311	24		36-11-12	ALL
	B09	UNUSED						ALL
	B10		W6214	0004	24		36-11-13	ALL
	B11		W6214	0033	22		23-71-01	ALL
	B12		W6214	0034	22		23-71-01	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41830J	**E004-01/ /**		**RCPT-**				**ALL**
A01		W0410	0620	24		21-51-12	ALL
A02		W0410	0379	24		21-51-25	ALL
A03		W0410	0580	20		80-11-11	ALL
A04		W0410	0028	24		29-32-11	ALL
A05		W0410	0029	24		29-32-11	ALL
A06		W0410	0043	24		80-11-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0410	0613	24		21-25-11	ALL
A10		W0410	2202R	22		24-41-11	ALL
A11		W0410	2202B	22		24-41-11	ALL
A12		W0410	2201B	22		24-41-11	ALL
A13		W0410	2201R	22		24-41-11	ALL
A14		W0410	2021R	24		34-51-21	ALL
A15		W0410	2022R	24		34-51-21	ALL
A16		W0410	2023R	24		34-51-21	ALL
A17		W0410	2024R	24		34-51-21	ALL
A18		W0410	2025R	24		34-51-21	ALL
A19		W0410	0119	22		34-51-21	ALL
A20		W0410	0121	22		34-51-21	ALL
B01		W0410	0473	24		21-61-13	ALL
B02		W0410	0429	24		21-61-14	ALL
B03		W0410	0582	20		76-21-21	ALL
B04		W0410	0401	24		21-51-22	ALL
B05		W0410	0484	24		21-25-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W0410	0563	24		21-51-12	ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41830J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B10		W0410	0581	24		75-11-11	ALL
	B11		W0410	0266	20		21-31-23	ALL
	B12		W0410	0267	24		21-31-23	ALL
	B13	UNUSED						ALL
	B14		W0410	2021B	24		34-51-21	ALL
	B15	UNUSED						ALL
	B16		W0410	2023B	24		34-51-21	ALL
	B17		W0410	2024B	24		34-51-21	ALL
	B18		W0410	2025B	24		34-51-21	ALL
	B19		W0410	2022B	24		34-51-21	ALL
	B20		W0410	0120	22		34-51-21	ALL
	PERG	1F	W0410	2021Z			34-51-21	ALL
	PERG	1F	W0410	2022Z			34-51-21	ALL
	PERG	1F	W0410	2023Z			34-51-21	ALL
	PERG	1F	W0410	2024Z			34-51-21	ALL
	PERG	1F	W0410	2025Z			34-51-21	ALL
D41830P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W6412	0548	24		21-51-12	ALL
	A02		W6412	5539	24		21-51-25	ALL
	A03		W6412	6080	20		80-11-11	ALL
	A04		W6412	0516	24		29-32-11	ALL
	A05		W6412	0517	24		29-32-11	ALL
	A06		W6412	6002	24		80-11-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6412	0010	24		21-25-11	ALL
	A10		W6412	2202R	22		24-41-11	ALL
	A11		W6412	2202B	22		24-41-11	ALL
	A12		W6412	2203B	22		24-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41830P	**E004-01/ /**		**PLUG- (continued)**				**ALL**
A13		W6412	2203R	22		24-41-11	ALL
A14		W6412	2204R	24		34-51-21	ALL
A15		W6412	2205R	24		34-51-21	ALL
A16		W6412	2206R	24		34-51-21	ALL
A17		W6412	2207R	24		34-51-21	ALL
A18		W6412	2208R	24		34-51-21	ALL
A19		W6412	1305	22		34-51-21	ALL
A20		W6412	1304	22		34-51-21	ALL
B01		W6412	5541	24		21-61-13	ALL
B02		W6412	5543	24		21-61-14	ALL
B03		W6412	6020	24		76-21-21	ALL
B04		W6412	0310	24		21-51-22	ALL
B05		W6412	5536	22		21-25-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W6412	0540	24		21-51-12	ALL
B09		W6412	0508	20		SPARE	ALL
B10		W6412	6019	24		75-11-11	ALL
B11		W6412	0203	20		21-31-23	ALL
B12		W6412	0204	24		21-31-23	ALL
B13		W6412	0009	20		SPARE	ALL
B14		W6412	2204B	24		34-51-21	ALL
B15		W6412	0008	20		SPARE	ALL
B16		W6412	2206B	24		34-51-21	ALL
B17		W6412	2207B	24		34-51-21	ALL
B18		W6412	2208B	24		34-51-21	ALL
B19		W6412	2205B	24		34-51-21	ALL
B20		W6412	0543	22		34-51-21	ALL
PERG	1F	W6412	2204Z			34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41830P		**E004-01/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W6412	2205Z			34-51-21	ALL
	PERG	1F	W6412	2206Z			34-51-21	ALL
	PERG	1F	W6412	2207Z			34-51-21	ALL
	PERG	1F	W6412	2208Z			34-51-21	ALL
D41831J		**E001-03/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0131	0097	22		33-27-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0131	0029	16		23-12-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41831J	**E001-03/ /**		**RCPT (continued)**				**ALL**
K	UNUSED						ALL
D41831P	**E001-03/ /**		**PLUG E1-3 SHELF**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W2651	0014	22		33-27-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2651	0026	16		23-12-11	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
D41832J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0608	24		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41832J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	2		W0044	0609	24		21-51-22	ALL
	3		W0044	0610	24		21-51-22	ALL
	4		W0044	0603	24		21-51-25	ALL
	5	UNUSED						ALL
	6		W0044	0605	24		21-61-13	ALL
	7	UNUSED						ALL
	8		W0044	0602	24		21-61-14	ALL
	9		W0044	6246	20		36-11-23	ALL
	10		W0044	6245	20		36-11-23	ALL
	11		W0044	2570B	24		31-65-26	ALL
	12	UNUSED						ALL
	13		W0044	0601	24		21-61-14	ALL
	14	UNUSED						ALL
	15		W0044	0604	24		21-61-13	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W0044	0825	24		21-51-22	ALL
	20	UNUSED						ALL
	21		W0044	2570R	24		31-65-26	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	18	W0044	0424	18		78-32-61	ALL
	S/R		W0044	2570Z			31-65-26	ALL
D41832P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W6412	0301	24		21-51-22	ALL
	2		W6412	0302	24		21-51-22	ALL
	3		W6412	0303	22		21-51-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41832P	**P006-00/ /**		**PLUG- (continued)**				**ALL**
4		W6412	5539	24		21-51-25	ALL
5	UNUSED						ALL
6		W6412	5542	24		21-61-13	ALL
7	UNUSED						ALL
8		W6412	5544	24		21-61-14	ALL
9		W6412	5535	20		36-11-23	ALL
10		W6412	5534	20		36-11-23	ALL
11		W6412	2501B	24		31-65-26	ALL
12	UNUSED						ALL
13		W6412	5543	24		21-61-14	ALL
14	UNUSED						ALL
15		W6412	5541	24		21-61-13	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W6412	0310	24		21-51-22	ALL
20	UNUSED						ALL
21		W6412	2501R	24		31-65-26	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	18	W6412	6125	18		78-32-61	ALL
S/R		W6412	2501Z			31-65-26	ALL
D41833J	**P001-00/ /**		**INSERT**				**ALL**
1		W0001	1004	22		31-65-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0001	1003	20		31-65-11	ALL
5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D41833J		**P001-00/ /**		**INSERT (continued)**				**ALL**
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0001	1001	16		31-65-11	ALL
	10		W0001	1002	16		31-65-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	PERS	1A	W0001	1001Z			31-65-11	ALL
	PERS	1A	W0001	1002Z			31-65-11	ALL
	PERS	1A	W0001	1003Z			31-65-11	ALL
	PERS	1A	W0001	1004Z			31-65-11	ALL
D41833P		**P009-00/ /**		**INSERT**				**ALL**
	1		W2651	0017	22		31-65-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W2651	0027	20		31-65-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41833P	**P009-00/ /**		**INSERT (continued)**				**ALL**
8		W2651	0024	20		SPARE	ALL
9		W2651	0023	16		31-65-11	ALL
10		W2651	0002	16		31-65-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
D41836J	**E003-03/173/L005**		**INSERT - SOCKET**				**ALL**
1		W0330	0314	24		21-51-12	ALL
2		W0330	0315	24		21-51-12	ALL
3		W0330	0317	24		21-51-12	ALL
4		W0330	0318	24		21-51-12	ALL
5		W0330	0456	14		21-25-11	ALL
6		W0330	0329	24		21-51-13	ALL
7		W0330	0330	24		21-51-13	ALL
8		W0330	0457	14		21-25-11	ALL
9		W0330	0520	24		21-51-12	ALL
10		W0330	0458	14		21-25-11	ALL
11		W0330	2001B	24		21-51-12	ALL
12		W0330	2001R	24		21-51-12	ALL
13		W0330	0327	24		21-51-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41836J	**E003-03/173/L005**		**INSERT - SOCKET (continued)**				**ALL**
14		W0330	0328	24		21-51-13	ALL
15		W0330	0337	24		21-51-14	ALL
16		W0330	0338	24		21-51-14	ALL
17		W0330	0521	24		21-51-12	ALL
D41836P	**E003-03/173/L005**		**INSERT - PLUG**				**ALL**
1		W5104	0305	24		21-51-12	ALL
2		W5104	0306	24		21-51-12	ALL
3		W5104	0307	24		21-51-12	ALL
4		W5104	0308	24		21-51-12	ALL
5		W5104	0326	14		21-25-11	ALL
6		W5104	0313	24		21-51-13	ALL
7		W5104	0314	24		21-51-13	ALL
8		W5104	0325	14		21-25-11	ALL
9		W5104	2006B	24		21-51-12	ALL
10		W5104	0324	14		21-25-11	ALL
11		W5104	2001B	20		21-51-12	ALL
12		W5104	2001R	20		21-51-12	ALL
13		W5104	0311	24		21-51-13	ALL
14		W5104	0312	24		21-51-13	ALL
15		W5104	0135	24		21-51-14	ALL
16		W5104	0136	24		21-51-14	ALL
17		W5104	2006R	24		21-51-12	ALL
D41837J	**E003-01/ /**		**RCPT**				**ALL**
A01		W0311	0141	20		34-57-11	ALL
A02		W0311	0138	20		34-21-11	ALL
A03		W0311	0134	20		34-61-11	ALL
A04		W0311	1770	20		34-24-15	ALL
A05		W0311	2775R	24		32-64-31	ALL
A06		W0311	2775B	24		32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41837J	**E003-01/ /**		**RCPT (continued)**				**ALL**
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0311	1001	22		31-65-14	ALL
B02		W0311	0139	20		34-21-11	ALL
B03		W0311	0135	20		34-61-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W0311	0002	16		31-65-11	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W0311	1001Z			31-65-14	ALL
PERG	1F	W0311	2775Z			32-64-31	ALL
D41837P	**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
A01		W2653	0003	22		34-57-11	ALL
A02		W2653	0005	20		34-21-11	ALL
A03		W2653	0006	20		34-61-11	ALL
A04		W2653	0017	20		34-24-15	ALL
A05		W2653	2401R	24		32-64-31	ALL
A06		W2653	2401B	24		32-64-31	ALL
A07		W2653	0001	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41837P		**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2653	1001	22		31-65-14	ALL
	B02		W2653	0004	20		34-21-11	ALL
	B03		W2653	0007	20		34-61-11	ALL
	B04	UNUSED						ALL
	B05		W2653	0002	22		SPARE	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W2653	0015	16		31-65-11	ALL
	G		W2653	0019	16		SPARE	ALL
	H		W2653	0023	18		SPARE	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W2653	1001Z			31-65-14	ALL
	PERG	1F	W2653	2401Z			32-64-31	ALL
D41838J		**AB0340B/ /**		**RCPT-**				**ALL**
	1		W6288	0011	20		21-61-51	ALL
	2		W6288	0017	20		21-61-51	ALL
	3		W6288	0013	24		21-61-51	ALL
	4		W6288	0015	20		21-61-51	ALL
	5	UNUSED						ALL
D41838P		**AB0340B/ /**		**PLUG-**				**ALL**
	1		W2114	5521	24		21-61-51	ALL
	2		W2114	5522	24		21-61-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41838P		**AB0340B/ /**		**PLUG- (continued)**				**ALL**
	3		W2114	5523	24		21-61-51	ALL
	4		W2114	5525	20		21-61-51	ALL
	5	UNUSED						ALL
D41839J		**E003-02/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0321	2158B	24		32-64-31	ALL
	A04		W0321	2158R	24		32-64-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0321	0095	22		27-32-11	ALL
	A09		W0321	0096	22		27-32-11	ALL
	A10		W0321	0097	22		27-32-11	ALL
	B01		W0321	1001	22		31-65-14	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	1001Z			31-65-14	ALL
	PERG	1F	W0321	2158Z			32-64-31	ALL
D41839P		**E003-02/ /**		**PLUG E3-2 SHELF**				**ALL**
	A01		W2653	0011	20		SPARE	ALL
	A02		W2653	0012	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41839P		**E003-02/ /**		**PLUG E3-2 SHELF (continued)**				**ALL**
	A03		W2653	2401B	24		32-64-31	ALL
	A04		W2653	2401R	24		32-64-31	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W2653	0008	22		27-32-11	ALL
	A09		W2653	0009	22		27-32-11	ALL
	A10		W2653	0010	22		27-32-11	ALL
	B01		W2653	1001	22		31-65-14	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2653	1001Z			31-65-14	ALL
	PERG	1F	W2653	2401Z			32-64-31	ALL
D41840J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0297	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W0220	0296	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W0220	0293	22		26-23-11	ALL
	A06		W0220	0272	22		26-16-22	ALL
	A07		W0220	0275	22		26-16-22	ALL
	A08		W0220	0276	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41840J	**E002-02/ /**		**RCPT- (continued)**				**ALL**
A09		W0220	0277	22		26-16-22	ALL
A10		W0220	0278	22		26-16-22	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W0220	0279	22		26-16-22	ALL
B06		W0220	0280	22		26-16-22	ALL
B07		W0220	0281	22		26-16-22	ALL
B08		W0220	0282	22		26-16-22	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41840J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41840P		**E002-02/ /**		**PLUG-**				**ALL**
	A01		W5094	6012	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W5094	6011	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W5094	6010	22		26-23-11	ALL
	A06		W5094	6001	22		26-16-22	ALL
	A07		W5094	6002	22		26-16-22	ALL
	A08		W5094	6003	22		26-16-22	ALL
	A09		W5094	6004	22		26-16-22	ALL
	A10		W5094	6005	22		26-16-22	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5094	6006	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41840P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B06		W5094	6007	22		26-16-22	ALL
	B07		W5094	6008	22		26-16-22	ALL
	B08		W5094	6009	22		26-16-22	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D41842J		**E003-03/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01		W0330	0377	24		21-61-11	ALL
	A02		W0330	0397	24		21-61-11	ALL
	A03		W0330	0398	24		21-61-11	ALL
	A04	UNUSED						ALL
	A05		W0330	2529B	24		36-21-11	ALL
	A06		W0330	0532	24		21-51-14	ALL
	A07		W0330	2031R	24		21-51-12	ALL
	A08		W0330	2031B	24		21-51-12	ALL
	A09		W0330	3001B	24		21-51-12	ALL
	A10		W0330	3001R	24		21-51-12	ALL
	B01		W0330	0209	24		21-61-11	ALL
	B02		W0330	0210	24		21-61-11	ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41842J		**E003-03/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B04	UNUSED						ALL
	B05		W0330	2529R	24		36-21-11	ALL
	B06		W0330	0533	24		21-51-14	ALL
	B07		W0330	3001Y	24		21-51-12	ALL
	B08		W0330	2032R	24		21-51-12	ALL
	B09		W0330	2032B	24		21-51-12	ALL
	B10	UNUSED						ALL
	PERG	1F	W0330	2031Z			21-51-12	ALL
	PERG	1F	W0330	2032Z			21-51-12	ALL
	PERG	1F	W0330	2529Z			36-21-11	ALL
	PERG	1F	W0330	3001Z			21-51-12	ALL
D41842P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W5526	5527	24		21-61-11	ALL
	A02		W5526	5528	24		21-61-11	ALL
	A03		W5526	5529	24		21-61-11	ALL
	A04		W5526	0001	24		SPARE	ALL
	A05		W5526	2501B	24		36-21-11	ALL
	A06		W5526	2090R	24		21-51-14	ALL
	A07		W5526	2002R	24		21-51-12	ALL
	A08		W5526	2002B	24		21-51-12	ALL
	A09		W5526	3001B	24		21-51-12	ALL
	A10		W5526	3001R	24		21-51-12	ALL
	B01		W5526	5533	24		21-61-11	ALL
	B02		W5526	5534	24		21-61-11	ALL
	B03	UNUSED						ALL
	B04		W5526	0002	24		SPARE	ALL
	B05		W5526	2501R	24		36-21-11	ALL
	B06		W5526	2090B	24		21-51-14	ALL
	B07		W5526	3001Y	24		21-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41842P	**E003-03/ /**		**PLUG- (continued)**				**ALL**
B08		W5526	2003R	24		21-51-12	ALL
B09		W5526	2003B	24		21-51-12	ALL
B10	UNUSED						ALL
PERG	1F	W5526	2002Z			21-51-12	ALL
PERG	1F	W5526	2003Z			21-51-12	ALL
PERG	1F	W5526	2090Z			21-51-14	ALL
PERG	1F	W5526	2501Z			36-21-11	ALL
PERG	1F	W5526	3001Z			21-51-12	ALL
D41844J	**E003-03/ /**		**RCPT-**				**ALL**
A01		W0330	2504R	22		36-11-13	ALL
A02		W0330	2505R	22		36-11-13	ALL
A03		W0330	2506R	22		36-11-13	ALL
A04		W0330	2507R	22		36-11-13	ALL
A05		W0330	2508R	22		36-11-13	ALL
A06		W0330	2509R	22		36-11-13	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0330	2504B	22		36-11-13	ALL
B02		W0330	2505B	22		36-11-13	ALL
B03		W0330	2506B	22		36-11-13	ALL
B04		W0330	2507B	22		36-11-13	ALL
B05		W0330	2508B	22		36-11-13	ALL
B06		W0330	2509B	22		36-11-13	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41844J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	PERG	1F	W0330	2504Z			36-11-13	ALL
	PERG	1F	W0330	2505Z			36-11-13	ALL
	PERG	1F	W0330	2506Z			36-11-13	ALL
	PERG	1F	W0330	2507Z			36-11-13	ALL
	PERG	1F	W0330	2508Z			36-11-13	ALL
	PERG	1F	W0330	2509Z			36-11-13	ALL
D41844P		**E003-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W3170	2504R	20		36-11-13	ALL
	A02		W3170	2505R	20		36-11-13	ALL
	A03		W3170	2506R	20		36-11-13	ALL
	A04		W3170	2507R	20		36-11-13	ALL
	A05		W3170	2508R	20		36-11-13	ALL
	A06		W3170	2509R	20		36-11-13	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W3170	2504B	20		36-11-13	ALL
	B02		W3170	2505B	20		36-11-13	ALL
	B03		W3170	2506B	20		36-11-13	ALL
	B04		W3170	2507B	20		36-11-13	ALL
	B05		W3170	2508B	20		36-11-13	ALL
	B06		W3170	2509B	20		36-11-13	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W3170	2504Z			36-11-13	ALL
	PERG	1F	W3170	2505Z			36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41844P	**E003-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W3170	2506Z			36-11-13	ALL
PERG	1F	W3170	2507Z			36-11-13	ALL
PERG	1F	W3170	2508Z			36-11-13	ALL
PERG	1F	W3170	2509Z			36-11-13	ALL
D41848J	**E003-03/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0330	3501R	22		36-11-13	ALL
A02		W0330	3501Y	22		36-11-13	ALL
A03		W0330	2530R	22		36-11-13	ALL
A04		W0330	2510R	22		36-11-13	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0330	3501B	22		36-11-13	ALL
B02	UNUSED						ALL
B03		W0330	2530B	22		36-11-13	ALL
B04		W0330	2510B	22		36-11-13	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0330	2510Z			36-11-13	ALL
PERG	1F	W0330	2530Z			36-11-13	ALL
PERG	1F	W0330	3501Z			36-11-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41848P		**E003-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5168	3004R	20		36-11-13	ALL
	A02		W5168	3004Y	20		36-11-13	ALL
	A03		W5168	2012R	20		36-11-13	ALL
	A04		W5168	2011R	20		36-11-13	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5168	3004B	20		36-11-13	ALL
	B02	UNUSED						ALL
	B03		W5168	2012B	20		36-11-13	ALL
	B04		W5168	2011B	20		36-11-13	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5168	2011Z			36-11-13	ALL
	PERG	1F	W5168	2012Z			36-11-13	ALL
	PERG	1F	W5168	3004Z			36-11-13	ALL
D41850J		**AB0500DR/ /**		**RECP-**				**ALL**
	1		W6588	1303	22		28-43-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41850J	**AB0500DR/ /**		**RECP- (continued)**				**ALL**
6	UNUSED						ALL
7	UNUSED						ALL
DED		W6588	1303Z			28-43-11	ALL
D41850P	**AB0500DR/ /**		**PLUG-**				**ALL**
1		W1126	1303	20		28-43-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
DED		W1126	1303Z			28-43-11	ALL
D41854J	**AB0500DL/ /**		**RECP-**				**ALL**
1		W5568	1302	22		28-43-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
DED		W5568	1302Z			28-43-11	ALL
D41854P	**AB0500DL/ /**		**PLUG-**				**ALL**
1		W1128	1301	20		28-43-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41854P		**AB0500DL/ /**		**PLUG- (continued)**				**ALL**
	DED		W1128	1301Z			28-43-11	ALL
D41862J		**E003-03/ /**		**RCPT-**				**ALL**
	A01		W0330	2515R	22		36-11-23	ALL
	A02		W0330	2516R	22		36-11-23	ALL
	A03		W0330	2517R	22		36-11-23	ALL
	A04		W0330	2518R	22		36-11-23	ALL
	A05		W0330	2519R	22		36-11-23	ALL
	A06		W0330	2520R	22		36-11-23	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0330	2515B	22		36-11-23	ALL
	B02		W0330	2516B	22		36-11-23	ALL
	B03		W0330	2517B	22		36-11-23	ALL
	B04		W0330	2518B	22		36-11-23	ALL
	B05		W0330	2519B	22		36-11-23	ALL
	B06		W0330	2520B	22		36-11-23	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0330	2515Z			36-11-23	ALL
	PERG	1F	W0330	2516Z			36-11-23	ALL
	PERG	1F	W0330	2517Z			36-11-23	ALL
	PERG	1F	W0330	2518Z			36-11-23	ALL
	PERG	1F	W0330	2519Z			36-11-23	ALL
	PERG	1F	W0330	2520Z			36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41862P	**E003-03/ /**		**PLUG**				**ALL**
A01		W4170	2515R	20		36-11-23	ALL
A02		W4170	2516R	20		36-11-23	ALL
A03		W4170	2517R	20		36-11-23	ALL
A04		W4170	2518R	20		36-11-23	ALL
A05		W4170	2519R	20		36-11-23	ALL
A06		W4170	2520R	20		36-11-23	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W4170	2515B	20		36-11-23	ALL
B02		W4170	2516B	20		36-11-23	ALL
B03		W4170	2517B	20		36-11-23	ALL
B04		W4170	2518B	20		36-11-23	ALL
B05		W4170	2519B	20		36-11-23	ALL
B06		W4170	2520B	20		36-11-23	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W4170	2515Z			36-11-23	ALL
PERG	1F	W4170	2516Z			36-11-23	ALL
PERG	1F	W4170	2517Z			36-11-23	ALL
PERG	1F	W4170	2518Z			36-11-23	ALL
PERG	1F	W4170	2519Z			36-11-23	ALL
PERG	1F	W4170	2520Z			36-11-23	ALL
D41864J	**E003-03/ /**		**RCPT-**				**ALL**
A01		W0330	2531R	22		36-11-23	ALL
A02		W0330	2521R	22		36-11-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41864J		**E003-03/ /**		**RCPT- (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0330	3502R	22		36-11-23	ALL
	A10		W0330	3502Y	22		36-11-23	ALL
	B01		W0330	2531B	22		36-11-23	ALL
	B02		W0330	2521B	22		36-11-23	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0330	3502B	22		36-11-23	ALL
	B10	UNUSED						ALL
	PERG	1F	W0330	2521Z			36-11-23	ALL
	PERG	1F	W0330	2531Z			36-11-23	ALL
	PERG	1F	W0330	3502Z			36-11-23	ALL
D41864P		**E003-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6168	2012R	20		36-11-23	ALL
	A02		W6168	2011R	20		36-11-23	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41864P		**E003-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09		W6168	3004R	20		36-11-23	ALL
	A10		W6168	3004Y	20		36-11-23	ALL
	B01		W6168	2012B	20		36-11-23	ALL
	B02		W6168	2011B	20		36-11-23	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W6168	3004B	20		36-11-23	ALL
	B10	UNUSED						ALL
	PERG	1F	W6168	2011Z			36-11-23	ALL
	PERG	1F	W6168	2012Z			36-11-23	ALL
	PERG	1F	W6168	3004Z			36-11-23	ALL
D41866J		**500D/201/R54**		**RCPT**				**ALL**
	A		W6128	1003	20		28-22-11	ALL
	B		W6128	1004	20		28-22-11	ALL
	C		W6128	1007	20		28-22-11	ALL
	DED		W6128	1003Z			28-22-11	ALL
	DED		W6128	1004Z			28-22-11	ALL
	DED		W6128	1007Z			28-22-11	ALL
D41866P		**500D/201/R54**		**PLUG-**				**ALL**
	A		W6588	1305	20		28-22-11	ALL
	B		W6588	1306	20		28-22-11	ALL
	C		W6588	1309	20		28-22-11	ALL
	DED		W6588	1305Z			28-22-11	ALL
	DED		W6588	1306Z			28-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41866P		**500D/201/R54**		**PLUG- (continued)**				**ALL**
	DED		W6588	1309Z			28-22-11	ALL
D41868J		**E003-03/ /**		**RECPT-**				**ALL**
	A01		W0330	0031	24		36-11-22	ALL
	A02		W0330	0033	24		36-11-22	ALL
	A03		W0330	0035	24		36-11-22	ALL
	A04		W0330	0037	24		36-11-22	ALL
	A05		W0330	0047	24		36-11-23	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0330	0032	24		36-11-22	ALL
	B02		W0330	0034	24		36-11-22	ALL
	B03		W0330	0036	24		36-11-22	ALL
	B04		W0330	0038	24		36-11-22	ALL
	B05		W0330	0048	24		36-11-23	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41868P		**E003-03/ /**		**PLUG-**				**ALL**
	A01		W6412	5571	24		36-11-22	ALL
	A02		W6412	5573	24		36-11-22	ALL
	A03		W6412	5575	24		36-11-22	ALL
	A04		W6412	5577	24		36-11-22	ALL
	A05		W6412	5580	24		36-11-23	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41868P		**E003-03/ /**		**PLUG- (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6412	5572	24		36-11-22	ALL
	B02		W6412	5574	24		36-11-22	ALL
	B03		W6412	5576	24		36-11-22	ALL
	B04		W6412	5578	24		36-11-22	ALL
	B05		W6412	5581	24		36-11-23	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D41874J		**P003-00/ /**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0001	0261	20		33-14-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0001	0262	20		33-14-11	ALL
	9		W0001	0187	16		33-11-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0003	0661	16		33-11-21	ALL
	13	UNUSED						ALL
	14		W0003	0662	16		33-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41874J		**P003-00/ /**		**INSERT (continued)**				**ALL**
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
D41874P		**P001-00/ /**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2383	0030	20		33-14-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2383	0008	20		33-14-11	ALL
	9		W2383	0050	16		33-11-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2383	0017	16		33-11-21	ALL
	13	UNUSED						ALL
	14		W2383	0033	16		33-11-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D41874P	**P001-00/ /**		**INSERT (continued)**				**ALL**
21	UNUSED						ALL
22	UNUSED						ALL
D41877J	**P009-00/ /**		**RCPT-- CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W0001	0192	16		33-11-11	ALL
3		W0001	0201	18		33-11-31	ALL
4		W0001	0256	16		33-11-32	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D41877P	**P009-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W2207	0006	16		33-11-11	ALL
3		W2207	1001	18		33-11-31	ALL
4		W2207	0007	16		33-11-32	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
S/R		W2207	1001Z			33-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42005J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	0141	20		34-57-11	ALL
	A02		W0311	2128R	24		34-57-11	ALL
	A03		W0311	2128B	24		34-57-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0311	0142	22		34-57-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42005J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2128Z			34-57-11	ALL
D42005P		**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
	A01		W2265	0002	20		34-57-11	ALL
	A02		W2265	2001R	24		34-57-11	ALL
	A03		W2265	2001B	24		34-57-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W2265	0003	22		34-57-11	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42005P		**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2265	2001Z			34-57-11	ALL
D42007J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	0641	20		34-57-21	ALL
	A02		W0313	2628R	24		34-57-21	ALL
	A03		W0313	2628B	24		34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42007J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0313	0642	22		34-57-21	ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W0313	2628Z			34-57-21	ALL
D42007P	**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
A01		W2267	0002	20		34-57-21	ALL
A02		W2267	2001R	24		34-57-21	ALL
A03		W2267	2001B	24		34-57-21	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42007P		**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W2267	0003	22		34-57-21	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W2267	2001Z			34-57-21	ALL
D42014J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0294	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W0220	0295	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W0220	0292	22		26-23-11	ALL
	A06		W0220	0259	22		26-16-21	ALL
	A07		W0220	0262	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42014J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	A08		W0220	0263	22		26-16-21	ALL
	A09		W0220	0264	22		26-16-21	ALL
	A10		W0220	0265	22		26-16-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0220	0266	22		26-16-21	ALL
	B06		W0220	0267	22		26-16-21	ALL
	B07		W0220	0268	22		26-16-21	ALL
	B08		W0220	0269	22		26-16-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D42014P		**E002-02/ /**		**PLUG-**				**ALL**
	A01		W5088	6016	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W5088	6017	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W5088	6015	22		26-23-11	ALL
	A06		W5088	6001	22		26-16-21	ALL
	A07		W5088	6002	22		26-16-21	ALL
	A08		W5088	6003	22		26-16-21	ALL
	A09		W5088	6004	22		26-16-21	ALL
	A10		W5088	6005	22		26-16-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5088	6006	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42014P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B06		W5088	6007	22		26-16-21	ALL
	B07		W5088	6008	22		26-16-21	ALL
	B08		W5088	6009	22		26-16-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D42026J		**E003-01/198/L11**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2741R	24		34-33-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0313	2781R	22		28-41-11	ALL
	A06		W0311	2772R	24		32-42-12	ALL
	A07		W0311	2772B	24		32-42-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0313	2741B	24		34-33-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0313	2781B	22		28-41-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0311	2772Z			32-42-12	ALL
	PERG	1F	W0313	2741Z			34-33-21	ALL
	PERG	1F	W0313	2781Z			28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42026P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5610	2007R	24		34-33-21	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W5610	2604R	22		28-41-11	ALL
A06		W5610	2501R	24		32-42-12	ALL
A07		W5610	2501B	24		32-42-12	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5610	2007B	24		34-33-21	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W5610	2604B	22		28-41-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5610	2007Z			34-33-21	ALL
PERG	1F	W5610	2501Z			32-42-12	ALL
PERG	1F	W5610	2604Z			28-41-11	ALL
D42047J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0311	2181R	24		31-65-15	ALL
A02		W0311	2182R	24		34-57-11	ALL
A03		W0311	0206	24		34-61-26	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42047J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0311	2181B	24		31-65-15	ALL
	B02		W0311	2182B	24		34-57-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42047J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0311	2181Z			31-65-15	ALL
PERG	1F	W0311	2182Z			34-57-11	ALL
D42047P	**E003-01/ /**		**PLUG**				**ALL**
A01		W5047	2518R	24		31-65-15	ALL
A02		W5047	2505R	24		34-57-11	ALL
A03		W5047	0006	24		34-61-26	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42047P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	B01		W5047	2518B	24		31-65-15	ALL
	B02		W5047	2505B	24		34-57-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5047	2505Z			34-57-11	ALL
	PERG	1F	W5047	2518Z			31-65-15	ALL
D42049J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2772R	24		31-65-24	ALL
	A02		W0313	2182R	24		34-41-11	ALL
	A03		W0313	2716R	24		31-31-13	ALL
	A04	UNUSED						ALL
	A05		W0313	2185R	24		34-57-21	ALL
	A06		W0313	2719R	24		36-11-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42049J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A07		W0313	2758R	22		31-32-15	ALL
	A08		W0313	2752R	24		31-65-24	ALL
	A09		W0313	2710R	24		31-65-25	ALL
	A10	UNUSED						ALL
	B01		W0313	2772B	24		31-65-24	ALL
	B02		W0313	2182B	24		34-41-11	ALL
	B03		W0313	2716B	24		31-31-13	ALL
	B04	UNUSED						ALL
	B05		W0313	2185B	24		34-57-21	ALL
	B06		W0313	2719B	24		36-11-24	ALL
	B07		W0313	2758B	22		31-32-15	ALL
	B08		W0313	2752B	24		31-65-24	ALL
	B09		W0313	2710B	24		31-65-25	ALL
	B10	UNUSED						ALL
	PERG	1F	W0313	2182Z			34-41-11	ALL
	PERG	1F	W0313	2185Z			34-57-21	ALL
	PERG	1F	W0313	2710Z			31-65-25	ALL
	PERG	1F	W0313	2716Z			31-31-13	ALL
	PERG	1F	W0313	2719Z			36-11-24	ALL
	PERG	1F	W0313	2752Z			31-65-24	ALL
	PERG	1F	W0313	2758Z			31-32-15	ALL
	PERG	1F	W0313	2772Z			31-65-24	ALL
D42049P		**E003-01/ /**		**PLUG**				**ALL**
	A01		W5049	2527R	24		31-65-24	ALL
	A02		W5049	2507R	24		34-41-11	ALL
	A03		W5049	2518R	24		31-31-13	ALL
	A04	UNUSED						ALL
	A05		W5049	2509R	24		34-57-21	ALL
	A06		W5049	2523R	24		36-11-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42049P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	A07		W5049	2517R	22		31-32-15	ALL
	A08		W5049	2524R	24		31-65-24	ALL
	A09		W5049	2525R	24		31-65-25	ALL
	A10	UNUSED						ALL
	B01		W5049	2527B	24		31-65-24	ALL
	B02		W5049	2507B	24		34-41-11	ALL
	B03		W5049	2518B	24		31-31-13	ALL
	B04	UNUSED						ALL
	B05		W5049	2509B	24		34-57-21	ALL
	B06		W5049	2523B	24		36-11-24	ALL
	B07		W5049	2517B	22		31-32-15	ALL
	B08		W5049	2524B	24		31-65-24	ALL
	B09		W5049	2525B	24		31-65-25	ALL
	B10	UNUSED						ALL
	PERG	1F	W5049	2507Z			34-41-11	ALL
	PERG	1F	W5049	2509Z			34-57-21	ALL
	PERG	1F	W5049	2517Z			31-32-15	ALL
	PERG	1F	W5049	2518Z			31-31-13	ALL
	PERG	1F	W5049	2523Z			36-11-24	ALL
	PERG	1F	W5049	2524Z			31-65-24	ALL
	PERG	1F	W5049	2525Z			31-65-25	ALL
	PERG	1F	W5049	2527Z			31-65-24	ALL
D42051J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2181R	24		31-65-25	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42051J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0313	2181B	24		31-65-25	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42051J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2181Z			31-65-25	ALL
D42051P		**E003-01/ /**		**PLUG**				**ALL**
	A01		W5049	2526R	24		31-65-25	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5049	2526B	24		31-65-25	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42051P	**E003-01/ /**		**PLUG (continued)**				**ALL**
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5049	2526Z			31-65-25	ALL
D42053J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	2700R	24		27-18-11	ALL
A02		W0321	2700B	24		27-18-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W0321	0251	22		27-32-21	ALL
A08		W0321	0252	22		27-32-21	ALL
A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42053J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A10	UNUSED						ALL
	B01		W0321	3700R	24		27-18-11	ALL
	B02		W0321	3700B	24		27-18-11	ALL
	B03		W0321	3700Y	24		27-18-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0321	3712R	22		27-32-21	ALL
	B08		W0321	3712B	22		27-32-21	ALL
	B09		W0321	3712Y	22		27-32-21	ALL
	B10	UNUSED						ALL
D42053P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5375	2010R	22		27-18-11	ALL
	A02		W5375	2010B	22		27-18-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5375	0007	20		SPARE	ALL
	A06		W5375	0008	20		SPARE	ALL
	A07		W5375	2012R	22		27-32-21	ALL
	A08		W5375	2012B	22		27-32-21	ALL
	A09		W5375	0010	20		SPARE	ALL
	A10		W5375	0011	20		SPARE	ALL
	B01		W5375	3015R	22		27-18-11	ALL
	B02		W5375	3015B	22		27-18-11	ALL
	B03		W5375	3015Y	22		27-18-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5375	3012R	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42053P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B08		W5375	3012B	22		27-32-21	ALL
	B09		W5375	3012Y	22		27-32-21	ALL
	B10		W5375	0009	20		SPARE	ALL
	PERG	1F	W5375	2012Z			27-32-21	ALL
	PERG	1F	W5375	3012Z			27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42100J		**AL0720A/202/L033**		**RECPT-CONDUCTIVE**				**ALL**
	1		W5375	2010R	22		27-18-11	ALL
	2		W5375	2010B	22		27-18-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5375	3015R	22		27-18-11	ALL
	6		W5375	3015B	22		27-18-11	ALL
	7		W5375	3015Y	22		27-18-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5375	2012R	22		27-32-21	ALL
	21		W5375	2012B	22		27-32-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W5375	3012R	22		27-32-21	ALL
	25		W5375	3012B	22		27-32-21	ALL
	26		W5375	3012Y	22		27-32-21	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	S/R		W5375	2012Z			27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42100J	**AL0720A/202/L033**		**RECPT-CONDUCTIVE (continued)**				**ALL**
S/R		W5375	3012Z			27-32-21	ALL
D42100P	**AL0720A/201/L035**		**PLUG-CONDUCTIVE**				**ALL**
1		W1022	2001R	20		27-18-11	ALL
2		W1022	2001B	20		27-18-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1022	3001R	20		27-18-11	ALL
6		W1022	3001B	20		27-18-11	ALL
7		W1022	3001Y	20		27-18-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W1022	2004R	20		27-32-21	ALL
21		W1022	2004B	20		27-32-21	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1022	3004R	20		27-32-21	ALL
25		W1022	3004B	20		27-32-21	ALL
26		W1022	3004Y	20		27-32-21	ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42100P		**AL0720A/201/L035**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	28	UNUSED						ALL
	S/R		W1022	2001Z			27-18-11	ALL
	S/R		W1022	2004Z			27-32-21	ALL
	S/R		W1022	3001Z			27-18-11	ALL
	S/R		W1022	3004Z			27-32-21	ALL
D42102J		**AL0720A/201/L033**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W5367	2015R	22		22-11-11	ALL
	4		W5367	2015B	22		22-11-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5367	3007R	22		22-12-31	ALL
	9		W5367	3007B	22		22-12-31	ALL
	10		W5367	3007Y	22		22-12-31	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42102J	**AL0720A/201/L033**		**RCPT-CONDUCTIVE (continued)**				**ALL**
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
S/R		W5367	2015Z			22-11-11	ALL
S/R		W5367	3007Z			22-12-31	ALL
D42102P	**AL0720A/201/L034**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W1022	2005R	20		22-11-11	ALL
4		W1022	2005B	20		22-11-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1022	3005R	20		22-12-31	ALL
9		W1022	3005B	20		22-12-31	ALL
10		W1022	3005Y	20		22-12-31	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42102P		**AL0720A/201/L034**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	S/R		W1022	2005Z			22-11-11	ALL
	S/R		W1022	3005Z			22-12-31	ALL
D42104J		**AB0727L/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5032	2206R	22		27-52-11	ALL
	2		W5032	2206B	22		27-52-11	ALL
	3		W5032	2206Z			27-52-11	ALL
	4		W5032	2207R	20		27-52-11	ALL
	5		W5032	2207B	20		27-52-11	ALL
	6		W5032	2207Z			27-52-11	ALL
	7		W5032	2010R	22		27-53-21	ALL
	8		W5032	2010B	22		27-53-21	ALL
	9		W5032	3006R	22		27-53-21	ALL
	10		W5032	3006B	22		27-53-21	ALL
	11		W5032	3006Y	22		27-53-21	ALL
	12		W5032	3007R	22		27-53-21	ALL
	13		W5032	3007B	22		27-53-21	ALL
	14		W5032	3007Y	22		27-53-21	ALL
	15	UNUSED						ALL
	16		W5032	3008R	22		27-53-21	ALL
	17		W5032	3008B	22		27-53-21	ALL
	18		W5032	3008Y	22		27-53-21	ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42104J	**AB0727L/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
20		W5032	3009R	22		27-53-21	ALL
21		W5032	3009B	22		27-53-21	ALL
22		W5032	3009Y	22		27-53-21	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W5032	6001	20		28-21-11	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
D42104P	**AB0727L/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W1022	2006R	20		27-52-11	ALL
2		W1022	2006B	20		27-52-11	ALL
3		W1022	2006ZI			27-52-11	ALL
4		W1022	2007R	20		27-52-11	ALL
5		W1022	2007B	20		27-52-11	ALL
6		W1022	2007ZI			27-52-11	ALL
7		W1022	2010R	20		27-53-21	ALL
8		W1022	2010B	20		27-53-21	ALL
9		W1022	3006R	20		27-53-21	ALL
10		W1022	3006B	20		27-53-21	ALL
11		W1022	3006Y	20		27-53-21	ALL
12		W1022	3007R	20		27-53-21	ALL
13		W1022	3007B	20		27-53-21	ALL
14		W1022	3007Y	20		27-53-21	ALL
15	UNUSED						ALL
16		W1022	3008R	20		27-53-21	ALL
17		W1022	3008B	20		27-53-21	ALL
18		W1022	3008Y	20		27-53-21	ALL
19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42104P		**AB0727L/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	20		W1022	3009R	20		27-53-21	ALL
	21		W1022	3009B	20		27-53-21	ALL
	22		W1022	3009Y	20		27-53-21	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W1022	1001	20		28-21-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	S/R		W1022	1001Z			28-21-11	ALL
	S/R		W1022	2006ZO			27-52-11	ALL
	S/R		W1022	2007ZO			27-52-11	ALL
	S/R		W1022	2010Z			27-53-21	ALL
	S/R		W1022	3006Z			27-53-21	ALL
	S/R		W1022	3007Z			27-53-21	ALL
	S/R		W1022	3008Z			27-53-21	ALL
	S/R		W1022	3009Z			27-53-21	ALL
D42111J		**E004-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0422	2010R	22		24-28-41	ALL
	A04		W0422	2010B	22		24-28-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0422	2423R	24		34-53-11	ALL
	A08	UNUSED						ALL
	A09		W0422	2426R	24		34-58-11	ALL
	A10		W0422	0232	24		21-31-24	ALL
	B01		W0422	0157	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42111J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0422	0506	20		27-81-51	ALL
	B05		W0422	0507	20		27-81-51	ALL
	B06	UNUSED						ALL
	B07		W0422	2423B	24		34-53-11	ALL
	B08	UNUSED						ALL
	B09		W0422	2426B	24		34-58-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W0422	2423Z			34-53-11	ALL
	PERG	1F	W0422	2426Z			34-58-11	ALL
D42111P		**E004-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5719	2007R	22		24-28-41	ALL
	A04		W5719	2007B	22		24-28-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5719	2036R	24		34-53-11	ALL
	A08	UNUSED						ALL
	A09		W5719	2037R	24		34-58-11	ALL
	A10		W5719	0063	24		21-31-24	ALL
	B01		W5719	0029	20		22-11-11	ALL
	B02		W5719	0030	22		SPARE	ALL
	B03	UNUSED						ALL
	B04		W5719	0052	20		27-81-51	ALL
	B05		W5719	0053	20		27-81-51	ALL
	B06	UNUSED						ALL
	B07		W5719	2036B	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42111P		**E004-02/ /**		**PLUG- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09		W5719	2037B	24		34-58-11	ALL
	B10	UNUSED						ALL
	PERG	1F	W5719	2036Z			34-53-11	ALL
	PERG	1F	W5719	2037Z			34-58-11	ALL
D42163J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	2131R	22		34-57-11	ALL
	A02		W0311	2131B	22		34-57-11	ALL
	A03		W0311	2132R	22		34-57-11	ALL
	A04		W0311	2132B	22		34-57-11	ALL
	A05		W0311	2133R	22		34-57-11	ALL
	A06		W0311	2133B	22		34-57-11	ALL
	A07		W0311	2134R	22		34-57-11	ALL
	A08		W0311	2134B	22		34-57-11	ALL
	A09		W0311	1008	22		34-57-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0311	1008Z			34-57-11	ALL
	PERG	1F	W0311	2131Z			34-57-11	ALL
	PERG	1F	W0311	2132Z			34-57-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42163J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0311	2133Z			34-57-11	ALL
PERG	1F	W0311	2134Z			34-57-11	ALL
D42163P	**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
A01		W5273	8991R	24		34-57-11	ALL
A02		W5273	8991B	24		34-57-11	ALL
A03		W5273	8991Y	24		34-57-11	ALL
A04		W5273	8991G	24		34-57-11	ALL
A05		W5273	8991V	24		34-57-11	ALL
A06		W5273	8991K	24		34-57-11	ALL
A07		W5273	8991O	22		34-57-11	ALL
A08		W5273	8991N	22		34-57-11	ALL
A09		W5273	8991W	20		34-57-11	ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5273	8991Z			34-57-11	ALL
PERG	1F	W5273	8991ZA			34-57-11	ALL
PERG	1F	W5273	8991ZB			34-57-11	ALL
PERG	1F	W5273	8991ZC			34-57-11	ALL
D42165J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0313	2631R	22		34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42165J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A02		W0313	2631B	22		34-57-21	ALL
	A03		W0313	2632R	22		34-57-21	ALL
	A04		W0313	2632B	22		34-57-21	ALL
	A05		W0313	2633R	22		34-57-21	ALL
	A06		W0313	2633B	22		34-57-21	ALL
	A07		W0313	2634R	22		34-57-21	ALL
	A08		W0313	2634B	22		34-57-21	ALL
	A09		W0313	1508	22		34-57-21	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42165J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	1508Z			34-57-21	ALL
	PERG	1F	W0313	2631Z			34-57-21	ALL
	PERG	1F	W0313	2632Z			34-57-21	ALL
	PERG	1F	W0313	2633Z			34-57-21	ALL
	PERG	1F	W0313	2634Z			34-57-21	ALL
D42165P		**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
	A01		W5275	8991R	24		34-57-21	ALL
	A02		W5275	8991B	24		34-57-21	ALL
	A03		W5275	8991Y	24		34-57-21	ALL
	A04		W5275	8991G	24		34-57-21	ALL
	A05		W5275	8991V	24		34-57-21	ALL
	A06		W5275	8991K	24		34-57-21	ALL
	A07		W5275	8991O	22		34-57-21	ALL
	A08		W5275	8991N	22		34-57-21	ALL
	A09		W5275	8991W	20		34-57-21	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42165P		**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5275	8991Z			34-57-21	ALL
	PERG	1F	W5275	8991ZA			34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42165P		**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
	PERG	1F	W5275	8991ZB			34-57-21	ALL
	PERG	1F	W5275	8991ZC			34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42261J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0321	2165R	24		34-21-13	ALL
	A04		W0321	2166R	24		34-21-13	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0321	2030R	24		34-21-14	ALL
	A08		W0321	2051B	24		31-31-14	ALL
	A09		W0321	2051R	24		31-31-14	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0321	0073	22		34-61-12	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0321	2165B	24		34-21-13	ALL
	B04		W0321	2166B	24		34-21-13	ALL
	B05		W0321	0193	24		31-31-17	ALL
	B06		W0321	0215	24		21-51-14	ALL
	B07		W0321	2030B	24		34-21-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42261J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B10		W0321	0194	24		31-31-17	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16		W0321	3008R	24		31-31-14	ALL
B17		W0321	3008B	24		31-31-14	ALL
B18		W0321	3008Y	24		31-31-14	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0321	2030Z			34-21-14	ALL
PERG	1F	W0321	2165Z			34-21-13	ALL
PERG	1F	W0321	2166Z			34-21-13	ALL
D42261P	**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5461	2003R	24		SPARE	ALL
A02	UNUSED						ALL
A03		W5461	2013R	24		34-21-13	ALL
A04		W5461	2014R	24		34-21-13	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5461	2017R	24		34-21-14	ALL
A08		W5461	2501B	22		31-31-14	ALL
A09		W5461	2501R	22		31-31-14	ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W5461	0008	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42261P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A15		W5461	2011R	24		SPARE	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5461	2003B	24		SPARE	ALL
	B02	UNUSED						ALL
	B03		W5461	2013B	24		34-21-13	ALL
	B04		W5461	2014B	24		34-21-13	ALL
	B05		W5461	0071	24		31-31-17	ALL
	B06		W5461	0067	24		21-51-14	ALL
	B07		W5461	2017B	24		34-21-14	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5461	0059	24		31-31-17	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W5461	2011B	24		SPARE	ALL
	B16		W5461	3709R	22		31-31-14	ALL
	B17		W5461	3709B	22		31-31-14	ALL
	B18		W5461	3709Y	22		31-31-14	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5461	2003Z			SPARE	ALL
	PERG	1F	W5461	2011Z			SPARE	ALL
	PERG	1F	W5461	2013Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42261P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5461	2014Z			34-21-13	ALL
	PERG	1F	W5461	2017Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42311J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0111	2298R	24		34-51-11	ALL
	A04	UNUSED						ALL
	A05		W0111	2251R	24		21-31-23	ALL
	A06		W0111	2251B	24		21-31-23	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0111	2298B	24		34-51-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0111	2252R	24		21-31-23	ALL
	B10		W0111	2252B	24		21-31-23	ALL
	PERG	1F	W0111	2251Z			21-31-23	ALL
	PERG	1F	W0111	2252Z			21-31-23	ALL
	PERG	1F	W0111	2298Z			34-51-11	ALL
D42311P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5461	2056R	24		34-51-11	ALL
	A04	UNUSED						ALL
	A05		W5461	2130R	24		21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42311P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A06		W5461	2130B	24		21-31-23	ALL
	A07	UNUSED						ALL
	A08		W5461	2020R	24		SPARE	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5461	2056B	24		34-51-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W5461	2020B	24		SPARE	ALL
	B09		W5461	2131R	24		21-31-23	ALL
	B10		W5461	2131B	24		21-31-23	ALL
	PERG	1F	W5461	2020Z			SPARE	ALL
	PERG	1F	W5461	2056Z			34-51-11	ALL
	PERG	1F	W5461	2130Z			21-31-23	ALL
	PERG	1F	W5461	2131Z			21-31-23	ALL
D42361J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2045R	24		22-31-52	ALL
	A02		W0321	2041R	24		34-45-11	ALL
	A03		W0321	2042R	24		34-49-11	ALL
	A04		W0321	2046R	22		34-21-15	ALL
	A05		W0321	0110	20		27-53-11	ALL
	A06	UNUSED						ALL
	A07		W0321	0070	22		34-21-15	ALL
	A08		W0321	0185	20		27-31-11	ALL
	A09		W0321	2211R	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42361J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A10		W0321	2212R	24		22-11-51	ALL
	A11		W0321	0068	24		31-31-15	ALL
	A12	UNUSED						ALL
	A13		W0321	2717R	24		27-32-12	ALL
	A14	UNUSED						ALL
	A15		W0321	2717B	24		27-32-12	ALL
	A16		W0321	2725R	24		27-81-41	ALL
	A17	UNUSED						ALL
	A18		W0321	2044R	24		22-11-51	ALL
	A19		W0321	2820R	24		22-11-51	ALL
	A20		W0321	2365R	24		34-51-11	ALL
	B01		W0321	2045B	24		22-31-52	ALL
	B02		W0321	2041B	24		34-45-11	ALL
	B03		W0321	2042B	24		34-49-11	ALL
	B04		W0321	2046B	22		34-21-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0321	0069	24		31-31-15	ALL
	B08		W0321	0093	24		31-31-17	ALL
	B09		W0321	2211B	24		22-11-51	ALL
	B10		W0321	2212B	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12		W0321	0111	20		27-53-11	ALL
	B13	UNUSED						ALL
	B14		W0321	0112	20		27-53-11	ALL
	B15		W0321	0099	24		31-31-17	ALL
	B16		W0321	2725B	24		27-81-41	ALL
	B17	UNUSED						ALL
	B18		W0321	2044B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42361J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B19		W0321	2820B	24		22-11-51	ALL
	B20		W0321	2365B	24		34-51-11	ALL
	PERG	1F	W0321	2041Z			34-45-11	ALL
	PERG	1F	W0321	2042Z			34-49-11	ALL
	PERG	1F	W0321	2044Z			22-11-51	ALL
	PERG	1F	W0321	2045Z			22-31-52	ALL
	PERG	1F	W0321	2046Z			34-21-15	ALL
	PERG	1F	W0321	2211Z			22-11-51	ALL
	PERG	1F	W0321	2212Z			22-11-51	ALL
	PERG	1F	W0321	2365Z			34-51-11	ALL
	PERG	1F	W0321	2717Z			27-32-12	ALL
	PERG	1F	W0321	2725Z			27-81-41	ALL
	PERG	1F	W0321	2820Z			22-11-51	ALL
D42361P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5461	2004R	24		22-31-52	ALL
	A02		W5461	2008R	24		34-45-11	ALL
	A03		W5461	2006R	24		34-49-11	ALL
	A04		W5461	2007R	22		34-21-15	ALL
	A05		W5461	0501	20		27-53-11	ALL
	A06		W5461	0058	24		SPARE	ALL
	A07		W5461	0018	22		34-21-15	ALL
	A08		W5461	0010	20		27-31-11	ALL
	A09		W5461	2209R	24		22-11-51	ALL
	A10		W5461	2210R	24		22-11-51	ALL
	A11		W5461	0056	24		31-31-15	ALL
	A12	UNUSED						ALL
	A13		W5461	2113R	24		27-32-12	ALL
	A14		W5461	0073	24		SPARE	ALL
	A15		W5461	2113B	24		27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42361P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A16		W5461	2021R	24		27-81-41	ALL
	A17	UNUSED						ALL
	A18		W5461	2100R	24		22-11-51	ALL
	A19		W5461	2102R	24		22-11-51	ALL
	A20		W5461	2056R	24		34-51-11	ALL
	B01		W5461	2004B	24		22-31-52	ALL
	B02		W5461	2008B	24		34-45-11	ALL
	B03		W5461	2006B	24		34-49-11	ALL
	B04		W5461	2007B	22		34-21-15	ALL
	B05	UNUSED						ALL
	B06		W5461	0057	24		SPARE	ALL
	B07		W5461	0009	24		31-31-15	ALL
	B08		W5461	0046	24		31-31-17	ALL
	B09		W5461	2209B	24		22-11-51	ALL
	B10		W5461	2210B	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12		W5461	0502	20		27-53-11	ALL
	B13	UNUSED						ALL
	B14		W5461	0503	20		27-53-11	ALL
	B15		W5461	0048	24		31-31-17	ALL
	B16		W5461	2021B	24		27-81-41	ALL
	B17	UNUSED						ALL
	B18		W5461	2100B	24		22-11-51	ALL
	B19		W5461	2102B	24		22-11-51	ALL
	B20		W5461	2056B	24		34-51-11	ALL
	PERG	1F	W5461	2004Z			22-31-52	ALL
	PERG	1F	W5461	2006Z			34-49-11	ALL
	PERG	1F	W5461	2007Z			34-21-15	ALL
	PERG	1F	W5461	2008Z			34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42361P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5461	2021Z			27-81-41	ALL
	PERG	1F	W5461	2056Z			34-51-11	ALL
	PERG	1F	W5461	2100Z			22-11-51	ALL
	PERG	1F	W5461	2102Z			22-11-51	ALL
	PERG	1F	W5461	2113Z			27-32-12	ALL
	PERG	1F	W5461	2209Z			22-11-51	ALL
	PERG	1F	W5461	2210Z			22-11-51	ALL
D42363J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0217	24		21-51-24	ALL
	A02		W0321	0080	24		31-31-15	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0321	0950	22		31-52-11	ALL
	A07		W0321	2036R	24		31-35-02	ALL
	A08		W0321	2036B	24		31-35-02	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	0018	24		34-61-17	ALL
	B02		W0321	0081	24		31-31-15	ALL
	B03	UNUSED						ALL
	B04		W0321	0795	22		34-51-11	ALL
	B05	UNUSED						ALL
	B06		W0321	2225R	24		22-23-12	ALL
	B07		W0321	2225B	24		22-23-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0321	0016	24		34-61-17	ALL
	PERG	1F	W0321	2036Z			31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42363J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0321	2225Z			22-23-12	ALL
D42363P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5463	0021	24		21-51-24	ALL
	A02		W5463	0003	24		31-31-15	ALL
	A03		W5463	0030	24		SPARE	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5463	0050	20		31-52-11	ALL
	A07		W5463	2007R	24		31-35-02	ALL
	A08		W5463	2007B	24		31-35-02	ALL
	A09		W5463	2022R	24		SPARE	ALL
	A10		W5463	2022B	24		SPARE	ALL
	B01		W5463	0091	24		34-61-17	ALL
	B02		W5463	0004	24		31-31-15	ALL
	B03		W5463	0031	24		SPARE	ALL
	B04		W5463	0018	22		34-51-11	ALL
	B05	UNUSED						ALL
	B06		W5463	2023R	24		22-23-12	ALL
	B07		W5463	2023B	24		22-23-12	ALL
	B08		W5463	2035R	24		SPARE	ALL
	B09		W5463	2035B	24		SPARE	ALL
	B10		W5463	0090	24		34-61-17	ALL
	PERG	1F	W5463	2007Z			31-35-02	ALL
	PERG	1F	W5463	2022Z			SPARE	ALL
	PERG	1F	W5463	2023Z			22-23-12	ALL
	PERG	1F	W5463	2035Z			SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42400J		**E004-02/ /**		**RCPT-**				**ALL**
	1		W0420	1004	12		30-41-12	ALL
	2		W0420	1003	14		30-41-12	ALL
	3		W0420	1003Z			30-41-12	ALL
	4		W0420	1004Z			30-41-12	ALL
D42400P		**E004-02/ /**		**PLUG-**				**ALL**
	1		W6412	1005	12		30-41-12	ALL
	2		W6412	1004	14		30-41-12	ALL
	3		W6412	1004Z			30-41-12	ALL
	4		W6412	1005Z			30-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42710J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0325	3100R	22		27-61-44	ALL
	A02		W0325	3100B	22		27-61-44	ALL
	A03		W0325	3103R	22		27-61-44	ALL
	A04		W0325	3103B	22		27-61-44	ALL
	A05		W0325	2307R	22		27-61-44	ALL
	A06		W0325	2310R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0325	3100Y	22		27-61-44	ALL
	B02	UNUSED						ALL
	B03		W0325	3103Y	22		27-61-44	ALL
	B04	UNUSED						ALL
	B05		W0325	2307B	22		27-61-44	ALL
	B06		W0325	2310B	22		27-61-44	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0325	2307Z			27-61-44	ALL
	PERG	1F	W0325	2310Z			27-61-44	ALL
	PERG	1F	W0325	3100Z			27-61-44	ALL
	PERG	1F	W0325	3103Z			27-61-44	ALL
D42710P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5382	3701R	22		27-61-44	ALL
	A02		W5382	3701B	22		27-61-44	ALL
	A03		W5382	3702R	22		27-61-44	ALL
	A04		W5382	3702B	22		27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42710P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A05		W5382	2701R	22		27-61-44	ALL
	A06		W5382	2702R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5382	3701Y	22		27-61-44	ALL
	B02	UNUSED						ALL
	B03		W5382	3702Y	22		27-61-44	ALL
	B04	UNUSED						ALL
	B05		W5382	2701B	22		27-61-44	ALL
	B06		W5382	2702B	22		27-61-44	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5382	2701Z			27-61-44	ALL
	PERG	1F	W5382	2702Z			27-61-44	ALL
	PERG	1F	W5382	3701Z			27-61-44	ALL
	PERG	1F	W5382	3702Z			27-61-44	ALL
D42712J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0326	3101R	22		27-61-44	ALL
	A02		W0326	3101B	22		27-61-44	ALL
	A03		W0326	3104R	22		27-61-44	ALL
	A04		W0326	3104B	22		27-61-44	ALL
	A05		W0326	2308R	22		27-61-44	ALL
	A06		W0326	2311R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42712J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0326	3101Y	22		27-61-44	ALL
	B02	UNUSED						ALL
	B03		W0326	3104Y	22		27-61-44	ALL
	B04	UNUSED						ALL
	B05		W0326	2308B	22		27-61-44	ALL
	B06		W0326	2311B	22		27-61-44	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0326	2308Z			27-61-44	ALL
	PERG	1F	W0326	2311Z			27-61-44	ALL
	PERG	1F	W0326	3101Z			27-61-44	ALL
	PERG	1F	W0326	3104Z			27-61-44	ALL
D42712P		**E003-02/ /**		**PLUG CONDUCTIVE**				**ALL**
	A01		W5380	3701R	22		27-61-44	ALL
	A02		W5380	3701B	22		27-61-44	ALL
	A03		W5380	3702R	22		27-61-44	ALL
	A04		W5380	3702B	22		27-61-44	ALL
	A05		W5380	2701R	22		27-61-44	ALL
	A06		W5380	2702R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5380	3701Y	22		27-61-44	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42712P	**E003-02/ /**		**PLUG CONDUCTIVE (continued)**				**ALL**
B03		W5380	3702Y	22		27-61-44	ALL
B04	UNUSED						ALL
B05		W5380	2701B	22		27-61-44	ALL
B06		W5380	2702B	22		27-61-44	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5380	2701Z			27-61-44	ALL
PERG	1F	W5380	2702Z			27-61-44	ALL
PERG	1F	W5380	3701Z			27-61-44	ALL
PERG	1F	W5380	3702Z			27-61-44	ALL
D42714J	**ORSS 256/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42714J		**ORSS 256/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W1026	3002B	20		27-61-48	ALL
	27		W1026	3002Y	20		27-61-48	ALL
	28		W1026	3002R	20		27-61-48	ALL
	29		W1026	2004B	20		27-61-48	ALL
	30		W1026	2004R	20		27-61-48	ALL
	31		W1026	2003B	20		27-61-48	ALL
	32		W1026	2003R	20		27-61-48	ALL
	33		W1026	3001B	20		27-61-48	ALL
	34		W1026	3001Y	20		27-61-48	ALL
	35		W1026	3001R	20		27-61-48	ALL
	36		W1026	2002B	20		27-61-48	ALL
	37		W1026	2002R	20		27-61-48	ALL
	38		W1026	2001B	20		27-61-48	ALL
	39		W1026	2001R	20		27-61-48	ALL
	PERB		W1026	2001Z			27-61-48	ALL
	PERB		W1026	2002Z			27-61-48	ALL
	PERB		W1026	2003Z			27-61-48	ALL
	PERB		W1026	2004Z			27-61-48	ALL
	PERB		W1026	3001Z			27-61-48	ALL
	PERB		W1026	3002Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42714P	**ORSS 252/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W2026	3002B	20		27-61-48	ALL
27		W2026	3002Y	20		27-61-48	ALL
28		W2026	3002R	20		27-61-48	ALL
29		W2026	2004B	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42714P		**ORSS 252/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30		W2026	2004R	20		27-61-48	ALL
	31		W2026	2003B	20		27-61-48	ALL
	32		W2026	2003R	20		27-61-48	ALL
	33		W2026	3001B	20		27-61-48	ALL
	34		W2026	3001Y	20		27-61-48	ALL
	35		W2026	3001R	20		27-61-48	ALL
	36		W2026	2002B	20		27-61-48	ALL
	37		W2026	2002R	20		27-61-48	ALL
	38		W2026	2001B	20		27-61-48	ALL
	39		W2026	2001R	20		27-61-48	ALL
	PERB		W2026	2001Z			27-61-48	ALL
	PERB		W2026	2002Z			27-61-48	ALL
	PERB		W2026	2003Z			27-61-48	ALL
	PERB		W2026	2004Z			27-61-48	ALL
	PERB		W2026	3001Z			27-61-48	ALL
	PERB		W2026	3002Z			27-61-48	ALL
D42716J		**727/186/L34**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3026	2001R	22		27-61-48	ALL
	2		W3026	2001B	22		27-61-48	ALL
	3		W3026	2002R	22		27-61-48	ALL
	4		W3026	2002B	22		27-61-48	ALL
	5		W3026	3001R	22		27-61-48	ALL
	6		W3026	3001Y	22		27-61-48	ALL
	7		W3026	3001B	22		27-61-48	ALL
	8		W3026	2003R	22		27-61-48	ALL
	9		W3026	2003B	22		27-61-48	ALL
	10		W3026	2004R	22		27-61-48	ALL
	11		W3026	2004B	22		27-61-48	ALL
	12		W3026	3002R	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42716J	**727/186/L34**		**RCPT-CONDUCTIVE (continued)**				**ALL**
13		W3026	3002Y	22		27-61-48	ALL
14		W3026	3002B	22		27-61-48	ALL
S/R		W3026	2001Z			27-61-48	ALL
S/R		W3026	2002Z			27-61-48	ALL
S/R		W3026	2003Z			27-61-48	ALL
S/R		W3026	2004Z			27-61-48	ALL
S/R		W3026	3001Z			27-61-48	ALL
S/R		W3026	3002Z			27-61-48	ALL
D42716P	**727/186/L034**		**PLUG-CONDUCTIVE**				**ALL**
1		W2026	2001R	20		27-61-48	ALL
2		W2026	2001B	20		27-61-48	ALL
3		W2026	2002R	20		27-61-48	ALL
4		W2026	2002B	20		27-61-48	ALL
5		W2026	3001R	20		27-61-48	ALL
6		W2026	3001Y	20		27-61-48	ALL
7		W2026	3001B	20		27-61-48	ALL
8		W2026	2003R	20		27-61-48	ALL
9		W2026	2003B	20		27-61-48	ALL
10		W2026	2004R	20		27-61-48	ALL
11		W2026	2004B	20		27-61-48	ALL
12		W2026	3002R	20		27-61-48	ALL
13		W2026	3002Y	20		27-61-48	ALL
14		W2026	3002B	20		27-61-48	ALL
S/R		W2026	2001Z			27-61-48	ALL
S/R		W2026	2002Z			27-61-48	ALL
S/R		W2026	2003Z			27-61-48	ALL
S/R		W2026	2004Z			27-61-48	ALL
S/R		W2026	3001Z			27-61-48	ALL
S/R		W2026	3002Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42718J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0325	2263R	22		27-61-48	ALL
A02		W0325	2263B	22		27-61-48	ALL
A03		W0325	2264R	22		27-61-48	ALL
A04		W0325	2264B	22		27-61-48	ALL
A05		W0325	3026R	22		27-61-48	ALL
A06		W0325	3026Y	22		27-61-48	ALL
A07		W0325	3026B	22		27-61-48	ALL
A08		W0325	2265R	22		27-61-48	ALL
A09		W0325	2265B	22		27-61-48	ALL
A10		W0325	2266R	22		27-61-48	ALL
B01		W0325	2266B	22		27-61-48	ALL
B02		W0325	3027R	22		27-61-48	ALL
B03		W0325	3027Y	22		27-61-48	ALL
B04		W0325	3027B	22		27-61-48	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0325	2263Z			27-61-48	ALL
PERG	1F	W0325	2264Z			27-61-48	ALL
PERG	1F	W0325	2265Z			27-61-48	ALL
PERG	1F	W0325	2266Z			27-61-48	ALL
PERG	1F	W0325	3026Z			27-61-48	ALL
PERG	1F	W0325	3027Z			27-61-48	ALL
D42718P	**E003-02/ /**		**PLUG**				**ALL**
A01		W3026	2001R	22		27-61-48	ALL
A02		W3026	2001B	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42718P	**E003-02/ /**		**PLUG (continued)**				**ALL**
A03		W3026	2002R	22		27-61-48	ALL
A04		W3026	2002B	22		27-61-48	ALL
A05		W3026	3001R	22		27-61-48	ALL
A06		W3026	3001Y	22		27-61-48	ALL
A07		W3026	3001B	22		27-61-48	ALL
A08		W3026	2003R	22		27-61-48	ALL
A09		W3026	2003B	22		27-61-48	ALL
A10		W3026	2004R	22		27-61-48	ALL
B01		W3026	2004B	22		27-61-48	ALL
B02		W3026	3002R	22		27-61-48	ALL
B03		W3026	3002Y	22		27-61-48	ALL
B04		W3026	3002B	22		27-61-48	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W3026	2001Z			27-61-48	ALL
PERG	1F	W3026	2002Z			27-61-48	ALL
PERG	1F	W3026	2003Z			27-61-48	ALL
PERG	1F	W3026	2004Z			27-61-48	ALL
PERG	1F	W3026	3001Z			27-61-48	ALL
PERG	1F	W3026	3002Z			27-61-48	ALL
D42720J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	3102R	22		27-61-44	ALL
A02		W0321	3102B	22		27-61-44	ALL
A03		W0321	3105R	22		27-61-44	ALL
A04		W0321	3105B	22		27-61-44	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42720J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A05		W0321	2309R	22		27-61-44	ALL
	A06		W0321	2312R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	3102Y	22		27-61-44	ALL
	B02	UNUSED						ALL
	B03		W0321	3105Y	22		27-61-44	ALL
	B04	UNUSED						ALL
	B05		W0321	2309B	22		27-61-44	ALL
	B06		W0321	2312B	22		27-61-44	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2309Z			27-61-44	ALL
	PERG	1F	W0321	2312Z			27-61-44	ALL
	PERG	1F	W0321	3102Z			27-61-44	ALL
	PERG	1F	W0321	3105Z			27-61-44	ALL
D42720P		**E003-02/ /**		**PLUG CONDUCTIVE**				**ALL**
	A01		W5371	3701R	22		27-61-44	ALL
	A02		W5371	3701B	22		27-61-44	ALL
	A03		W5371	3702R	22		27-61-44	ALL
	A04		W5371	3702B	22		27-61-44	ALL
	A05		W5371	2701R	22		27-61-44	ALL
	A06		W5371	2702R	22		27-61-44	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42720P	**E003-02/ /**		**PLUG CONDUCTIVE (continued)**				**ALL**
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5371	3701Y	22		27-61-44	ALL
B02	UNUSED						ALL
B03		W5371	3702Y	22		27-61-44	ALL
B04	UNUSED						ALL
B05		W5371	2701B	22		27-61-44	ALL
B06		W5371	2702B	22		27-61-44	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5371	2701Z			27-61-44	ALL
PERG	1F	W5371	2702Z			27-61-44	ALL
PERG	1F	W5371	3701Z			27-61-44	ALL
PERG	1F	W5371	3702Z			27-61-44	ALL
D42722J	**ORSS 256/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42722J		**ORSS 256/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W1040	3002B	20		27-61-48	ALL
	27		W1040	3002Y	20		27-61-48	ALL
	28		W1040	3002R	20		27-61-48	ALL
	29		W1040	2004B	20		27-61-48	ALL
	30		W1040	2004R	20		27-61-48	ALL
	31		W1040	2003B	20		27-61-48	ALL
	32		W1040	2003R	20		27-61-48	ALL
	33		W1040	3001B	20		27-61-48	ALL
	34		W1040	3001Y	20		27-61-48	ALL
	35		W1040	3001R	20		27-61-48	ALL
	36		W1040	2002B	20		27-61-48	ALL
	37		W1040	2002R	20		27-61-48	ALL
	38		W1040	2001B	20		27-61-48	ALL
	39		W1040	2001R	20		27-61-48	ALL
	PERB		W1040	2001Z			27-61-48	ALL
	PERB		W1040	2002Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42722J	**ORSS 256/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERB		W1040	2003Z			27-61-48	ALL
PERB		W1040	2004Z			27-61-48	ALL
PERB		W1040	3001Z			27-61-48	ALL
PERB		W1040	3002Z			27-61-48	ALL
D42722P	**ORSS 252/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D42722P		**ORSS 252/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	25	UNUSED						ALL
	26		W2040	3002B	20		27-61-48	ALL
	27		W2040	3002Y	20		27-61-48	ALL
	28		W2040	3002R	20		27-61-48	ALL
	29		W2040	2004B	20		27-61-48	ALL
	30		W2040	2004R	20		27-61-48	ALL
	31		W2040	2003B	20		27-61-48	ALL
	32		W2040	2003R	20		27-61-48	ALL
	33		W2040	3001B	20		27-61-48	ALL
	34		W2040	3001Y	20		27-61-48	ALL
	35		W2040	3001R	20		27-61-48	ALL
	36		W2040	2002B	20		27-61-48	ALL
	37		W2040	2002R	20		27-61-48	ALL
	38		W2040	2001B	20		27-61-48	ALL
	39		W2040	2001R	20		27-61-48	ALL
	PERB		W2040	2001Z			27-61-48	ALL
	PERB		W2040	2002Z			27-61-48	ALL
	PERB		W2040	2003Z			27-61-48	ALL
	PERB		W2040	2004Z			27-61-48	ALL
	PERB		W2040	3001Z			27-61-48	ALL
	PERB		W2040	3002Z			27-61-48	ALL
D42724J		**727+2.6/192/R033**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3040	2001R	22		27-61-48	ALL
	2		W3040	2001B	22		27-61-48	ALL
	3		W3040	2002R	22		27-61-48	ALL
	4		W3040	2002B	22		27-61-48	ALL
	5		W3040	3001R	22		27-61-48	ALL
	6		W3040	3001Y	22		27-61-48	ALL
	7		W3040	3001B	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42724J	**727+2.6/192/R033**		**RCPT-CONDUCTIVE (continued)**				**ALL**
8		W3040	2003R	22		27-61-48	ALL
9		W3040	2003B	22		27-61-48	ALL
10		W3040	2004R	22		27-61-48	ALL
11		W3040	2004B	22		27-61-48	ALL
12		W3040	3002R	22		27-61-48	ALL
13		W3040	3002Y	22		27-61-48	ALL
14		W3040	3002B	22		27-61-48	ALL
S/R		W3040	2001Z			27-61-48	ALL
S/R		W3040	2002Z			27-61-48	ALL
S/R		W3040	2003Z			27-61-48	ALL
S/R		W3040	2004Z			27-61-48	ALL
S/R		W3040	3001Z			27-61-48	ALL
S/R		W3040	3002Z			27-61-48	ALL
D42724P	**727/193/R033**		**PLUG-CONDUCTIVE**				**ALL**
1		W2040	2001R	20		27-61-48	ALL
2		W2040	2001B	20		27-61-48	ALL
3		W2040	2002R	20		27-61-48	ALL
4		W2040	2002B	20		27-61-48	ALL
5		W2040	3001R	20		27-61-48	ALL
6		W2040	3001Y	20		27-61-48	ALL
7		W2040	3001B	20		27-61-48	ALL
8		W2040	2003R	20		27-61-48	ALL
9		W2040	2003B	20		27-61-48	ALL
10		W2040	2004R	20		27-61-48	ALL
11		W2040	2004B	20		27-61-48	ALL
12		W2040	3002R	20		27-61-48	ALL
13		W2040	3002Y	20		27-61-48	ALL
14		W2040	3002B	20		27-61-48	ALL
S/R		W2040	2001Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42724P		**727/193/R033**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W2040	2002Z			27-61-48	ALL
	S/R		W2040	2003Z			27-61-48	ALL
	S/R		W2040	2004Z			27-61-48	ALL
	S/R		W2040	3001Z			27-61-48	ALL
	S/R		W2040	3002Z			27-61-48	ALL
D42726J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0326	2271R	22		27-61-48	ALL
	A02		W0326	2271B	22		27-61-48	ALL
	A03		W0326	2272R	22		27-61-48	ALL
	A04		W0326	2272B	22		27-61-48	ALL
	A05		W0326	3030R	22		27-61-48	ALL
	A06		W0326	3030Y	22		27-61-48	ALL
	A07		W0326	3030B	22		27-61-48	ALL
	A08		W0326	2273R	22		27-61-48	ALL
	A09		W0326	2273B	22		27-61-48	ALL
	A10		W0326	2274R	22		27-61-48	ALL
	B01		W0326	2274B	22		27-61-48	ALL
	B02		W0326	3031R	22		27-61-48	ALL
	B03		W0326	3031Y	22		27-61-48	ALL
	B04		W0326	3031B	22		27-61-48	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0326	2271Z			27-61-48	ALL
	PERG	1F	W0326	2272Z			27-61-48	ALL
	PERG	1F	W0326	2273Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42726J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0326	2274Z			27-61-48	ALL
PERG	1F	W0326	3030Z			27-61-48	ALL
PERG	1F	W0326	3031Z			27-61-48	ALL
D42726P	**AE0302A/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W3040	2001R	22		27-61-48	ALL
A02		W3040	2001B	22		27-61-48	ALL
A03		W3040	2002R	22		27-61-48	ALL
A04		W3040	2002B	22		27-61-48	ALL
A05		W3040	3001R	22		27-61-48	ALL
A06		W3040	3001Y	22		27-61-48	ALL
A07		W3040	3001B	22		27-61-48	ALL
A08		W3040	2003R	22		27-61-48	ALL
A09		W3040	2003B	22		27-61-48	ALL
A10		W3040	2004R	22		27-61-48	ALL
B01		W3040	2004B	22		27-61-48	ALL
B02		W3040	3002R	22		27-61-48	ALL
B03		W3040	3002Y	22		27-61-48	ALL
B04		W3040	3002B	22		27-61-48	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W3040	2001Z			27-61-48	ALL
PERG	1F	W3040	2002Z			27-61-48	ALL
PERG	1F	W3040	2003Z			27-61-48	ALL
PERG	1F	W3040	2004Z			27-61-48	ALL
PERG	1F	W3040	3001Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42726P		**AE0302A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W3040	3002Z			27-61-48	ALL
D42727J		**E003-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0321	0247	22		27-32-21	ALL
	A05	UNUSED						ALL
	A06		W0321	0262	22		27-32-21	ALL
	A07	UNUSED						ALL
	A08		W0321	0231	22		22-23-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0321	0573	18		27-61-41	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D42727P		**E003-02/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42727P	**E003-02/ /**		**PLUG (continued)**				**ALL**
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W2231	0004	22		27-32-21	ALL
A05	UNUSED						ALL
A06		W2231	0016	20		27-32-21	ALL
A07	UNUSED						ALL
A08		W2231	0008	20		22-23-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2231	0020	18		27-61-41	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
D42730J	**E003-02/ /**		**RCPT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0321	1798	24		21-51-21	ALL
A04		W0321	1796	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42730J		**E003-02/ /**		**RCPT (continued)**				**ALL**
	A05		W0321	0490	24		49-62-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0321	1799	24		21-51-21	ALL
	B04		W0321	1797	24		21-51-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D42730P		**E003-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W2112	0067	24		21-51-21	ALL
	A04		W2112	0065	24		21-51-11	ALL
	A05		W2112	0178	22		49-62-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D42730P		**E003-02/ /**		**PLUG- (continued)**				**ALL**
	B03		W2112	0069	24		21-51-21	ALL
	B04		W2112	0066	24		21-51-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43008J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0031	24		27-23-14	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0220	0130	20		29-25-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43008J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D43008P		**E002-02/ /**		**PLUG**				**ALL**
	A01		W5134	0503	22		27-23-14	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43008P		**E002-02/ /**		**PLUG (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5134	0568	20		29-25-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D43010J		**E001-03/ /**		**RCPT**				**ALL**
	A01		W0131	2019R	24		32-42-11	ALL
	A02		W0131	2020R	24		32-42-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43010J	**E001-03/ /**		**RCPT (continued)**				**ALL**
A06		W0131	2512R	24		32-41-11	ALL
A07		W0131	2512Z			32-41-11	ALL
A08		W0131	0122	22		32-41-11	ALL
A09		W0137	0058	24		31-31-15	ALL
A10	UNUSED						ALL
B01		W0131	2019B	24		32-42-11	ALL
B02		W0131	2020B	24		32-42-11	ALL
B03		W0131	2036R	22		32-49-11	ALL
B04		W0131	2036B	22		32-49-11	ALL
B05	UNUSED						ALL
B06		W0131	2512B	24		32-41-11	ALL
B07	UNUSED						ALL
B08		W0131	0111	24		32-41-11	ALL
B09		W0131	4503W	22		32-46-11	ALL
B10		W0131	4503G	22		32-46-11	ALL
PERG	1F	W0131	2036Z			32-49-11	ALL
PERG	1F	W0131	4503Z			32-46-11	ALL
D43010P	**E001-03/ /**		**PLUG**				**ALL**
A01		W5234	2203R	22		32-42-11	ALL
A02		W5234	2204R	22		32-42-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06		W5234	2211R	22		32-41-11	ALL
A07		W5234	2211Z			32-41-11	ALL
A08		W5234	0501	20		32-41-11	ALL
A09		W5234	0511	22		31-31-15	ALL
A10	UNUSED						ALL
B01		W5234	2203B	22		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43010P		**E001-03/ /**		**PLUG (continued)**				**ALL**
	B02		W5234	2204B	22		32-42-11	ALL
	B03		W5234	2202R	20		32-49-11	ALL
	B04		W5234	2202B	20		32-49-11	ALL
	B05	UNUSED						ALL
	B06		W5234	2211B	22		32-41-11	ALL
	B07	UNUSED						ALL
	B08		W5234	0591	22		32-41-11	ALL
	B09		W5234	4502W	20		32-46-11	ALL
	B10		W5234	4502G	20		32-46-11	ALL
	PERG	1F	W5234	2202Z			32-49-11	ALL
	PERG	1F	W5234	4502Z			32-46-11	ALL
D43018J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	2501R	24		36-11-31	ALL
	A02		W0410	2501B	24		36-11-31	ALL
	A03	UNUSED						ALL
	A04		W0410	0097	24		21-51-11	ALL
	A05		W0410	0102	24		21-51-11	ALL
	A06		W0410	0100	24		21-51-11	ALL
	A07		W0410	0081	24		21-42-11	ALL
	A08		W0410	0132	24		21-51-15	ALL
	A09		W0410	0133	24		21-51-15	ALL
	A10		W0410	0271	24		21-51-15	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0410	0590	24		36-11-31	ALL
	B05		W0410	0608	22		36-11-31	ALL
	B06		W0410	0403	24		21-61-11	ALL
	B07		W0410	0404	24		21-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43018J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B08		W0410	0406	24		21-61-11	ALL
	B09		W0410	0258	20		47-30-11	ALL
	B10	UNUSED						ALL
D43018P		**E004-01/ /**		**PLUG-**				**ALL**
	A01		W5526	2502R	22		36-11-31	ALL
	A02		W5526	2502B	22		36-11-31	ALL
	A03		W5526	0002	24		SPARE	ALL
	A04		W5526	5504	24		21-51-11	ALL
	A05		W5526	5505	24		21-51-11	ALL
	A06		W5526	5506	24		21-51-11	ALL
	A07		W5526	5507	22		21-42-11	ALL
	A08		W5526	5508	24		21-51-15	ALL
	A09		W5526	0301	24		21-51-15	ALL
	A10		W5526	5523	20		21-51-15	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5526	5521	22		36-11-31	ALL
	B05		W5526	5522	22		36-11-31	ALL
	B06		W5526	5524	24		21-61-11	ALL
	B07		W5526	5525	24		21-61-11	ALL
	B08		W5526	5526	24		21-61-11	ALL
	B09		W5526	0501	20		47-30-11	ALL
	B10		W5526	0001	24		SPARE	ALL
D43022J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0321	0210	24		31-31-15	ALL
	A04		W0321	0329	20		78-34-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43022J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A05	UNUSED						ALL
	A06		W0325	0967	22		27-61-49	ALL
	A07	UNUSED						ALL
	A08		W0325	0990	22		27-61-49	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0321	0901	24		29-32-11	ALL
	A13		W0321	0223	20		28-42-11	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0321	1001	22		31-65-14	ALL
	A18	UNUSED						ALL
	A19		W0321	0298	24		29-33-11	ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0321	0956	20		78-34-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0325	0989	22		27-61-49	ALL
	B07	UNUSED						ALL
	B08		W0325	0991	22		27-61-49	ALL
	B09	UNUSED						ALL
	B10		W0321	2236R	20		32-49-11	ALL
	B11		W0321	2236B	20		32-49-11	ALL
	B12		W0321	0902	24		29-32-11	ALL
	B13		W0321	0224	20		28-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43022J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B14		W0321	0511R	20		26-12-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W0321	0299	24		29-33-11	ALL
	B20	UNUSED						ALL
	PERG	1F	W0321	1001Z			31-65-14	ALL
	PERG	1F	W0321	2236Z			32-49-11	ALL
D43022P		**E003-02/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5530	0030	22		31-31-15	ALL
	A04		W5530	6001	20		78-34-11	ALL
	A05	UNUSED						ALL
	A06		W5530	2212R	22		27-61-49	ALL
	A07	UNUSED						ALL
	A08		W5530	2213R	22		27-61-49	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W5530	0511	22		29-32-11	ALL
	A13		W5530	6007	20		28-42-11	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W5530	1101	22		31-65-14	ALL
	A18	UNUSED						ALL
	A19		W5530	0517	22		29-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43022P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5530	6004	20		78-34-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5530	2212B	22		27-61-49	ALL
	B07	UNUSED						ALL
	B08		W5530	2213B	22		27-61-49	ALL
	B09	UNUSED						ALL
	B10		W5530	2202R	20		32-49-11	ALL
	B11		W5530	2202B	20		32-49-11	ALL
	B12		W5530	0512	22		29-32-11	ALL
	B13		W5530	6008	20		28-42-11	ALL
	B14		W5530	0500R	20		26-12-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W5530	0518	22		29-33-11	ALL
	B20	UNUSED						ALL
	PERG	1F	W5530	1101Z			31-65-14	ALL
	PERG	1F	W5530	2202Z			32-49-11	ALL
	PERG	1F	W5530	2212Z			27-61-49	ALL
	PERG	1F	W5530	2213Z			27-61-49	ALL
D43024J		**E002-02/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0220	0099	22		32-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43024J	**E002-02/ /**		**RCPT- (continued)**				**ALL**
A04		W0220	0012	20		33-32-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0220	0209	22		32-41-11	ALL
B04		W0220	0011	20		33-32-11	ALL
B05	UNUSED						ALL
B06		W0220	0252	22		32-31-15	ALL
B07		W0220	0253	24		32-31-15	ALL
B08		W0220	0251	24		32-31-15	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43024J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D43024P		**E002-02/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5728	0513	20		32-35-11	ALL
	A04		W5728	0001	20		33-32-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43024P		**E002-02/ /**		**PLUG (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5728	0591	22		32-41-11	ALL
	B04		W5728	0002	20		33-32-11	ALL
	B05	UNUSED						ALL
	B06		W5728	0595	20		32-31-15	ALL
	B07		W5728	0593	20		32-31-15	ALL
	B08		W5728	0594	20		32-31-15	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D43028J		**E004-02/ /**		**RCPT**				**ALL**
	A01		W0422	0308R	20		26-12-11	ALL
	A02		W0422	0016	20		27-23-11	ALL
	A03		W0422	0310	22		27-31-37	ALL
	A04		W0422	0532	22		32-31-15	ALL
	A05		W0422	0533	22		32-31-15	ALL
	A06		W0422	0300	22		31-31-15	ALL
	A07	UNUSED						ALL
	A08		W0422	0009	20		27-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43028J		**E004-02/ /**		**RCPT (continued)**				**ALL**
	A09	UNUSED						ALL
	A10		W0422	0056	20		29-23-11	ALL
	B01	UNUSED						ALL
	B02		W0422	0017	20		27-23-11	ALL
	B03	UNUSED						ALL
	B04		W0422	0531	22		32-31-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0422	0008	20		27-23-11	ALL
	B09	UNUSED						ALL
	B10		W0422	0055	22		29-23-11	ALL
D43028P		**E004-02/ /**		**PLUG**				**ALL**
	A01		W6032	6001R	20		26-12-11	ALL
	A02		W6032	0503	20		27-23-11	ALL
	A03		W6032	0112	22		27-31-37	ALL
	A04		W6032	0545	20		32-31-15	ALL
	A05		W6032	0546	20		32-31-15	ALL
	A06		W6032	0030	20		31-31-15	ALL
	A07	UNUSED						ALL
	A08		W6032	0515	20		27-23-11	ALL
	A09	UNUSED						ALL
	A10		W6032	0523	20		29-23-11	ALL
	B01	UNUSED						ALL
	B02		W6032	0504	20		27-23-11	ALL
	B03	UNUSED						ALL
	B04		W6032	0544	20		32-31-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43028P	**E004-02/ /**		**PLUG (continued)**				**ALL**
B07	UNUSED						ALL
B08		W6032	0514	20		27-23-11	ALL
B09	UNUSED						ALL
B10		W6032	0524	20		29-23-11	ALL
D43030J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	0355	22		32-64-21	ALL
A02		W0321	0209	24		31-31-15	ALL
A03		W0321	0279	22		27-83-11	ALL
A04		W0321	0600	22		22-23-12	ALL
A05		W0321	0215	24		21-51-14	ALL
A06	UNUSED						ALL
A07		W0321	0980	22		27-61-49	ALL
A08		W0321	0981	22		27-61-49	ALL
A09		W0321	0968	22		27-61-49	ALL
A10		W0321	0753	22		27-61-49	ALL
B01	UNUSED						ALL
B02		W0321	0185	20		27-31-11	ALL
B03	UNUSED						ALL
B04		W0321	0332	20		33-25-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0321	2102R	22		28-41-11	ALL
B08		W0321	2102B	22		28-41-11	ALL
B09	UNUSED						ALL
B10		W0321	0328	22		32-64-21	ALL
PERG	1F	W0321	2102Z			28-41-11	ALL
D43030P	**E003-02/ /**		**PLUG**				**ALL**
A01		W6034	0562	22		32-64-21	ALL
A02		W6034	0030	22		31-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43030P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	A03		W6034	0031	22		27-83-11	ALL
	A04		W6034	0550	22		22-23-12	ALL
	A05		W6034	5501	24		21-51-14	ALL
	A06	UNUSED						ALL
	A07		W6034	2002R	22		27-61-49	ALL
	A08		W6034	2002B	22		27-61-49	ALL
	A09		W6034	2001R	22		27-61-49	ALL
	A10		W6034	2001B	22		27-61-49	ALL
	B01	UNUSED						ALL
	B02		W6034	0501	20		27-31-11	ALL
	B03	UNUSED						ALL
	B04		W6034	0001	20		33-25-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W6034	2003R	22		28-41-11	ALL
	B08		W6034	2003B	22		28-41-11	ALL
	B09	UNUSED						ALL
	B10		W6034	0561	22		32-64-21	ALL
	PERG	1F	W6034	2001Z			27-61-49	ALL
	PERG	1F	W6034	2002Z			27-61-49	ALL
	PERG	1F	W6034	2003Z			28-41-11	ALL
D43038J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43038J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W0410	0362	24		21-51-22	ALL
	A14		W0410	0363	24		21-51-22	ALL
	A15		W0410	0364	24		21-51-22	ALL
	A16		W0410	0485	20		30-71-11	ALL
	A17	UNUSED						ALL
	A18		W0410	0560	24		21-51-24	ALL
	A19		W0410	0557	24		21-51-24	ALL
	A20		W0410	0554	24		21-51-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0410	0451	24		21-61-51	ALL
	B11		W0410	0206	20		30-71-11	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0410	0548	24		21-51-24	ALL
	B16		W0410	0550	24		21-51-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43038J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B17	UNUSED						ALL
	B18		W0410	0551	24		21-51-24	ALL
	B19		W0410	0552	24		21-51-24	ALL
	B20	UNUSED						ALL
D43038P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13		W6230	0302	24		21-51-22	ALL
	A14		W6230	0303	24		21-51-22	ALL
	A15		W6230	0304	24		21-51-22	ALL
	A16		W6230	5535	20		30-71-11	ALL
	A17	UNUSED						ALL
	A18		W6230	0036	24		21-51-24	ALL
	A19		W6230	0035	24		21-51-24	ALL
	A20		W6230	0034	24		21-51-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43038P	**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W6230	5537	24		21-61-51	ALL
B11		W6230	5526	20		30-71-11	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W6230	0037	24		21-51-24	ALL
B16		W6230	0038	24		21-51-24	ALL
B17	UNUSED						ALL
B18		W6230	0039	24		21-51-24	ALL
B19		W6230	0040	24		21-51-24	ALL
B20	UNUSED						ALL
D43040J	**E001-03/ /**		**RCPT**				**ALL**
A01		W0131	2514R	24		32-42-11	ALL
A02		W0131	2514Z			32-42-11	ALL
A03		W0131	2511R	24		32-41-11	ALL
A04		W0131	2511Z			32-41-11	ALL
A05		W0131	2021R	24		32-42-11	ALL
A06		W0131	0121	24		32-42-11	ALL
A07		W0131	2035R	22		32-49-11	ALL
A08		W0131	2035B	22		32-49-11	ALL
A09		W0131	4502W	22		32-46-11	ALL
A10		W0131	4502G	22		32-46-11	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43040J		**E001-03/ /**		**RCPT (continued)**				**ALL**
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0131	2514B	24		32-42-11	ALL
	B02	UNUSED						ALL
	B03		W0131	2511B	24		32-41-11	ALL
	B04	UNUSED						ALL
	B05		W0131	2021B	24		32-42-11	ALL
	B06		W0131	0119	24		32-42-11	ALL
	B07		W0131	0110	24		32-41-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0137	0004	24		31-31-15	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0131	2035Z			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43040J	**E001-03/ /**		**RCPT (continued)**				**ALL**
PERG	1F	W0131	4502Z			32-46-11	ALL
D43040P	**E001-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W6528	2203R	22		32-42-11	ALL
A02		W6528	2203Z			32-42-11	ALL
A03		W6528	2211R	22		32-41-11	ALL
A04		W6528	2211Z			32-41-11	ALL
A05		W6528	2204R	22		32-42-11	ALL
A06		W6528	0501	22		32-42-11	ALL
A07		W6528	2202R	20		32-49-11	ALL
A08		W6528	2202B	20		32-49-11	ALL
A09		W6528	4501W	20		32-46-11	ALL
A10		W6528	4501G	20		32-46-11	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W6528	2203B	22		32-42-11	ALL
B02	UNUSED						ALL
B03		W6528	2211B	22		32-41-11	ALL
B04	UNUSED						ALL
B05		W6528	2204B	22		32-42-11	ALL
B06		W6528	0502	22		32-42-11	ALL
B07		W6528	0591	22		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43040P		**E001-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6528	5513	22		31-31-15	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6528	2202Z			32-49-11	ALL
	PERG	1F	W6528	4501Z			32-46-11	ALL
D43044J		**E004-01/ /**		**RCPT-**				**ALL**
	A01		W0410	0104	24		21-51-21	ALL
	A02		W0410	0106	24		21-51-21	ALL
	A03	UNUSED						ALL
	A04		W0410	0274	24		21-51-25	ALL
	A05		W0410	0443	24		21-61-14	ALL
	A06		W0410	0444	24		21-61-14	ALL
	A07		W0410	0028	24		29-32-11	ALL
	A08		W0410	1002	20		74-11-11	ALL
	A09		W0410	0272	24		21-51-25	ALL
	A10		W0410	0273	24		21-51-25	ALL
	B01		W0410	0513	24		21-51-21	ALL
	B02		W0410	0115	24		21-51-21	ALL
	B03		W0410	0118	24		21-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43044J	**E004-01/ /**		**RCPT- (continued)**				**ALL**
B04		W0410	0082	24		21-42-11	ALL
B05		W0410	0246	20		21-61-15	ALL
B06		W0410	0445	24		21-61-14	ALL
B07		W0410	0029	24		29-32-11	ALL
B08		W0410	0426	24		21-61-13	ALL
B09		W0410	0427	24		21-61-13	ALL
B10		W0410	0428	24		21-61-13	ALL
PERG	1F	W0410	1002Z			74-11-11	ALL
D43044P	**E004-01/ /**		**PLUG**				**ALL**
A01		W6528	5502	24		21-51-21	ALL
A02		W6528	5503	24		21-51-21	ALL
A03	UNUSED						ALL
A04		W6528	0301	20		21-51-25	ALL
A05		W6528	0305	24		21-61-14	ALL
A06		W6528	0306	24		21-61-14	ALL
A07		W6528	0521	22		29-32-11	ALL
A08		W6528	1301	20		74-11-11	ALL
A09		W6528	5510	24		21-51-25	ALL
A10		W6528	5511	24		21-51-25	ALL
B01		W6528	5501	24		21-51-21	ALL
B02		W6528	5504	24		21-51-21	ALL
B03		W6528	5506	24		21-51-21	ALL
B04		W6528	5509	22		21-42-11	ALL
B05		W6528	0308	24		21-61-15	ALL
B06		W6528	0307	24		21-61-14	ALL
B07		W6528	0522	22		29-32-11	ALL
B08		W6528	0302	24		21-61-13	ALL
B09		W6528	0303	24		21-61-13	ALL
B10		W6528	0304	24		21-61-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43044P		**E004-01/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W6528	1301Z			74-11-11	ALL
D43046J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0125	20		29-11-11	ALL
	A02		W0321	0291	24		29-33-11	ALL
	A03		W0321	1002	22		31-65-24	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	0126	20		29-11-11	ALL
	B02		W0321	0295	24		29-33-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	1002Z			31-65-24	ALL
D43046P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W6530	0507	20		29-11-11	ALL
	A02		W6530	0517	22		29-33-11	ALL
	A03		W6530	1101	22		31-65-24	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43046P	**E003-02/ /**		**PLUG- (continued)**				**ALL**
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W6530	0508	20		29-11-11	ALL
B02		W6530	0518	22		29-33-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W6530	1101Z			31-65-24	ALL
D43048J	**E001-03/ /**		**RCPT**				**ALL**
A01		W0131	2522R	22		29-32-11	ALL
A02		W0131	2522Z			29-32-11	ALL
A03		W0131	1509R	20		26-21-11	ALL
A04		W0131	0109	24		32-41-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0131	2522B	22		29-32-11	ALL
B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43048J		**E001-03/ /**		**RCPT (continued)**				**ALL**
	B03		W0131	1510R	20		26-21-11	ALL
	B04		W0131	0067	22		32-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D43048P		**E001-03/ /**		**PLUG**				**ALL**
	A01		W6730	2001R	20		29-32-11	ALL
	A02		W6730	2001Z			29-32-11	ALL
	A03		W6730	6006R	20		26-21-11	ALL
	A04		W6730	0591	22		32-41-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6730	2001B	20		29-32-11	ALL
	B02	UNUSED						ALL
	B03		W6730	6007R	20		26-21-11	ALL
	B04		W6730	0515	22		32-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43050J	**E002-02/ /**		**RCPT-**				**ALL**
A01		W0220	0376R	20		26-11-31	ALL
A02		W0220	0378R	20		26-11-31	ALL
A03		W0220	0381R	20		26-11-31	ALL
A04		W0220	0107	22		49-62-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W0220	2004B	22		24-22-31	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0220	0377R	20		26-11-31	ALL
B02		W0220	0380R	20		26-11-31	ALL
B03		W0220	0106	22		49-62-11	ALL
B04		W0220	0209	22		32-41-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0220	2004R	22		24-22-31	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D43050P	**E002-02/ /**		**PLUG**				**ALL**
A01		W6730	6001R	20		26-11-31	ALL
A02		W6730	6003R	20		26-11-31	ALL
A03		W6730	6005R	20		26-11-31	ALL
A04		W6730	0514	20		49-62-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W6730	2201B	22		24-22-31	ALL
A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43050P		**E002-02/ /**		**PLUG (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6730	6002R	20		26-11-31	ALL
	B02		W6730	6004R	20		26-11-31	ALL
	B03		W6730	0513	20		49-62-11	ALL
	B04		W6730	0515	22		32-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W6730	2201R	22		24-22-31	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	DED		W6730	2201Z			24-22-31	ALL
D43054J		**E003-02/ /**		**RCPT-**				**ALL**
	A01		W0321	2151B	24		32-41-11	ALL
	A02		W0321	2151Z			32-41-11	ALL
	A03		W0321	0310	20		78-34-21	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0321	2235R	20		32-49-11	ALL
	A15		W0321	2235B	20		32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43054J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0321	2151R	24		32-41-11	ALL
	B02		W0321	0313	22		32-41-11	ALL
	B03		W0321	0311	20		78-34-21	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0321	2235Z			32-49-11	ALL
D43054P		**E003-02/ /**		**PLUG**				**ALL**
	A01		W6732	2211B	22		32-41-11	ALL
	A02		W6732	2211Z			32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43054P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	A03		W6732	1004	20		78-34-21	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W6732	2202R	20		32-49-11	ALL
	A15		W6732	2202B	20		32-49-11	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W6732	2211R	22		32-41-11	ALL
	B02		W6732	0591	22		32-41-11	ALL
	B03		W6732	1005	20		78-34-21	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43054P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W6732	1004Z			78-34-21	ALL
	PERG	1F	W6732	1005Z			78-34-21	ALL
	PERG	1F	W6732	2202Z			32-49-11	ALL
D43056J		**E003-03/ /**		**RCPT- CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0330	2602R	24		34-21-14	ALL
	A09		W0330	2512R	24		36-11-14	ALL
	A10		W0330	2523R	24		36-11-24	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43056J		**E003-03/ /**		**RCPT- CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W0330	2602B	24		34-21-14	ALL
	B09		W0330	2512B	24		36-11-14	ALL
	B10		W0330	2523B	24		36-11-24	ALL
	PERG	1F	W0330	2512Z			36-11-14	ALL
	PERG	1F	W0330	2523Z			36-11-24	ALL
	PERG	1F	W0330	2602Z			34-21-14	ALL
D43056P		**E003-03/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5047	2520R	24		34-21-14	ALL
	A09		W5047	2508R	24		34-21-14	ALL
	A10		W5047	2507R	24		34-21-14	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W5047	2520B	24		34-21-14	ALL
	B09		W5047	2508B	24		34-21-14	ALL
	B10		W5047	2507B	24		34-21-14	ALL
	PERG	1F	W5047	2507Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43056P		**E003-03/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5047	2508Z			34-21-14	ALL
	PERG	1F	W5047	2520Z			34-21-14	ALL
D43060J		**E002-02/ /**		**RCPT-**				**ALL**
	A		W0220	0133	24		29-34-11	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
D43060P		**E002-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A		W6128	0509	18		29-34-11	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
D43062J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43062J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W0410	0247	24		29-34-11	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D43062P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43062P	**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G		W5230	0509	18		29-34-11	ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
D43084J	**E002-02/ /**		**RCPT-**				**ALL**
1		W0220	0115	12		49-41-11	ALL
2		W0220	0116	12		49-41-11	ALL
3		W0220	0117	12		49-41-11	ALL
4		W0220	0237	20		38-32-12	ALL
5		W0220	0236	18		38-32-12	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
D43084P	**E002-02/ /**		**PLUG-**				**ALL**
1		W5230	0510	12		49-41-11	ALL
2		W5230	0511	12		49-41-11	ALL
3		W5230	0512	12		49-41-11	ALL
4		W5230	0513	18		38-32-12	ALL
5		W5230	0514	18		38-32-12	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43100J		**AL0720C/202/R033**		**RECPT-CONDUCTIVE**				**ALL**
	1		W5367	2010R	22		27-18-11	ALL
	2		W5367	2010B	22		27-18-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5367	3015R	22		27-18-11	ALL
	6		W5367	3015B	22		27-18-11	ALL
	7		W5367	3015Y	22		27-18-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20		W5367	2002R	22		27-32-11	ALL
	21		W5367	2002B	22		27-32-11	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W5367	3002R	22		27-32-11	ALL
	25		W5367	3002B	22		27-32-11	ALL
	26		W5367	3002Y	22		27-32-11	ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	DED		W5367	2002Z			27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43100J	**AL0720C/202/R033**		**RECPT-CONDUCTIVE (continued)**				**ALL**
DED		W5367	3002Z			27-32-11	ALL
D43100P	**AL0720C/201/R033**		**PLUG-CONDUCTIVE**				**ALL**
1		W1032	2001R	20		27-18-11	ALL
2		W1032	2001B	20		27-18-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W1032	3001R	20		27-18-11	ALL
6		W1032	3001B	20		27-18-11	ALL
7		W1032	3001Y	20		27-18-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W1032	2004R	20		27-32-11	ALL
21		W1032	2004B	20		27-32-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W1032	3004R	20		27-32-11	ALL
25		W1032	3004B	20		27-32-11	ALL
26		W1032	3004Y	20		27-32-11	ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43100P		**AL0720C/201/R033**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	28	UNUSED						ALL
	S/R		W1032	2001Z			27-18-11	ALL
	S/R		W1032	2004Z			27-32-11	ALL
	S/R		W1032	3001Z			27-18-11	ALL
	S/R		W1032	3004Z			27-32-11	ALL
D43102J		**AL0720D/202/R033**		**RECPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W5375	2008R	22		22-11-11	ALL
	4		W5375	2008B	22		22-11-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W5375	3005R	22		22-12-41	ALL
	9		W5375	3005B	22		22-12-41	ALL
	10		W5375	3005Y	22		22-12-41	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	S/R		W5375	2008Z			22-11-11	ALL
	S/R		W5375	3005Z			22-12-41	ALL
D43102P		**AL0720D/201/R025**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W1032	2005R	20		22-11-11	ALL
	4		W1032	2005B	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43102P	**AL0720D/201/R025**		**PLUG-CONDUCTIVE (continued)**				**ALL**
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W1032	3005R	20		22-12-41	ALL
9		W1032	3005B	20		22-12-41	ALL
10		W1032	3005Y	20		22-12-41	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
S/R		W1032	2005Z			22-11-11	ALL
S/R		W1032	3005Z			22-12-41	ALL
D43104J	**AB0727R/193/R043**		**RCPT-CONDUCTIVE**				**ALL**
1		W6028	2206R	22		27-52-11	ALL
2		W6028	2206B	22		27-52-11	ALL
3		W6028	2206Z			27-52-11	ALL
4		W6028	2207R	20		27-52-11	ALL
5		W6028	2207B	20		27-52-11	ALL
6		W6028	2207Z			27-52-11	ALL
7		W6028	2010R	22		27-53-21	ALL
8		W6028	2010B	22		27-53-21	ALL
9		W6028	3006R	22		27-53-21	ALL
10		W6028	3006B	22		27-53-21	ALL
11		W6028	3006Y	22		27-53-21	ALL
12		W6028	3007R	22		27-53-21	ALL
13		W6028	3007B	22		27-53-21	ALL
14		W6028	3007Y	22		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43104J		**AB0727R/193/R043**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	15	UNUSED						ALL
	16		W6028	3008R	22		27-53-21	ALL
	17		W6028	3008B	22		27-53-21	ALL
	18		W6028	3008Y	22		27-53-21	ALL
	19	UNUSED						ALL
	20		W6028	3009R	22		27-53-21	ALL
	21		W6028	3009B	22		27-53-21	ALL
	22		W6028	3009Y	22		27-53-21	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W6028	6001	20		28-21-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
D43104P		**AB0727R/191/R043**		**PLUG-CONDUCTIVE**				**ALL**
	1		W1032	2006R	20		27-52-11	ALL
	2		W1032	2006B	20		27-52-11	ALL
	3		W1032	2006ZI			27-52-11	ALL
	4		W1032	2007R	20		27-52-11	ALL
	5		W1032	2007B	20		27-52-11	ALL
	6		W1032	2007ZI			27-52-11	ALL
	7		W1032	2010R	20		27-53-21	ALL
	8		W1032	2010B	20		27-53-21	ALL
	9		W1032	3006R	20		27-53-21	ALL
	10		W1032	3006B	20		27-53-21	ALL
	11		W1032	3006Y	20		27-53-21	ALL
	12		W1032	3007R	20		27-53-21	ALL
	13		W1032	3007B	20		27-53-21	ALL
	14		W1032	3007Y	20		27-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43104P	**AB0727R/191/R043**		**PLUG-CONDUCTIVE (continued)**				**ALL**
15	UNUSED						ALL
16		W1032	3008R	20		27-53-21	ALL
17		W1032	3008B	20		27-53-21	ALL
18		W1032	3008Y	20		27-53-21	ALL
19	UNUSED						ALL
20		W1032	3009R	20		27-53-21	ALL
21		W1032	3009B	20		27-53-21	ALL
22		W1032	3009Y	20		27-53-21	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W1032	1001	20		28-21-11	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
S/R		W1032	1001Z			28-21-11	ALL
S/R		W1032	2006ZO			27-52-11	ALL
S/R		W1032	2007ZO			27-52-11	ALL
S/R		W1032	2010Z			27-53-21	ALL
S/R		W1032	3006Z			27-53-21	ALL
S/R		W1032	3007Z			27-53-21	ALL
S/R		W1032	3008Z			27-53-21	ALL
S/R		W1032	3009Z			27-53-21	ALL
D43106J	**464/303/R018**		**RCPT - CONDUCTIVE**				**ALL**
U-1		W3910	4001Y	24		46-13-52	ALL
U-2		W3910	4001R	24		46-13-52	ALL
U-3		W3910	4001G	24		46-13-52	ALL
U-4		W3910	4001B	24		46-13-52	ALL
V-1		W3910	4002Y	24		46-13-52	ALL
V-2		W3910	4002R	24		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43106J		**464/303/R018**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	V-3		W3910	4002G	24		46-13-52	ALL
	V-4		W3910	4002B	24		46-13-52	ALL
	A		W3910	0001	22		46-13-52	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E		W3910	0097	22		46-13-52	ALL
	F		W3910	0098	22		46-13-52	ALL
	G		W3910	0099	22		46-13-52	ALL
	H		W3910	0005	22		46-13-52	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	L	UNUSED						ALL
	M	UNUSED						ALL
	N	UNUSED						ALL
	P		W3910	0006	22		46-13-52	ALL
	R	UNUSED						ALL
	S	UNUSED						ALL
	T	UNUSED						ALL
	=CU		W3910	4001Z			46-13-52	ALL
	=CV		W3910	4002Z			46-13-52	ALL
D43106P		**464/303/R018**		**PLUG**				**ALL**
	U-1		W4920	4001Y	24		46-13-52	ALL
	U-2		W4920	4001R	24		46-13-52	ALL
	U-3		W4920	4001G	24		46-13-52	ALL
	U-4		W4920	4001B	24		46-13-52	ALL
	V-1		W4920	4002Y	24		46-13-52	ALL
	V-2		W4920	4002R	24		46-13-52	ALL
	V-3		W4920	4002G	24		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43106P	**464/303/R018**		**PLUG (continued)**				**ALL**
V-4		W4920	4002B	24		46-13-52	ALL
A		W4920	0001	22		46-13-52	ALL
B	UNUSED						ALL
C	UNUSED						ALL
D	UNUSED						ALL
E		W4920	0002	22		46-13-52	ALL
F		W4920	0003	22		46-13-52	ALL
G		W4920	0004	22		46-13-52	ALL
H		W4920	0005	22		46-13-52	ALL
J	UNUSED						ALL
K	UNUSED						ALL
L	UNUSED						ALL
M	UNUSED						ALL
N	UNUSED						ALL
P		W4920	0006	22		46-13-52	ALL
R	UNUSED						ALL
S	UNUSED						ALL
T	UNUSED						ALL
=CU		W4920	4001Z			46-13-52	ALL
=CV		W4920	4002Z			46-13-52	ALL
D43139J	**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
A01		W0335	2864R	24		21-51-22	ALL
A02		W0335	2863R	24		21-51-22	ALL
A03		W0335	2860R	24		23-12-41	ALL
A04		W0335	2901R	24		21-51-12	ALL
A05		W0335	2865R	24		21-51-22	ALL
A06		W0335	2858R	24		23-12-41	ALL
A07		W0335	2859R	24		23-12-41	ALL
A08		W0335	2902R	24		36-11-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43139J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A09		W0335	2861R	24		23-12-41	ALL
	A10		W0335	2862R	24		23-12-41	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0335	2903R	24		31-65-24	ALL
	A19		W0335	2904R	24		31-65-25	ALL
	A20	UNUSED						ALL
	B01		W0335	2864B	24		21-51-22	ALL
	B02		W0335	2863B	24		21-51-22	ALL
	B03		W0335	2860B	24		23-12-41	ALL
	B04		W0335	2901B	24		21-51-12	ALL
	B05		W0335	2865B	24		21-51-22	ALL
	B06		W0335	2858B	24		23-12-41	ALL
	B07		W0335	2859B	24		23-12-41	ALL
	B08		W0335	2902B	24		36-11-24	ALL
	B09		W0335	2861B	24		23-12-41	ALL
	B10		W0335	2862B	24		23-12-41	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43139J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B18		W0335	2903B	24		31-65-24	ALL
	B19		W0335	2904B	24		31-65-25	ALL
	B20		W0335	0107	22		31-31-17	ALL
	PERG	1F	W0335	2858Z			23-12-41	ALL
	PERG	1F	W0335	2859Z			23-12-41	ALL
	PERG	1F	W0335	2860Z			23-12-41	ALL
	PERG	1F	W0335	2861Z			23-12-41	ALL
	PERG	1F	W0335	2862Z			23-12-41	ALL
	PERG	1F	W0335	2863Z			21-51-22	ALL
	PERG	1F	W0335	2864Z			21-51-22	ALL
	PERG	1F	W0335	2865Z			21-51-22	ALL
	PERG	1F	W0335	2901Z			21-51-12	ALL
	PERG	1F	W0335	2902Z			36-11-24	ALL
	PERG	1F	W0335	2903Z			31-65-24	ALL
	PERG	1F	W0335	2904Z			31-65-25	ALL
D43139P		**E003-03/ /**		**PLUG**				**ALL**
	A01		W5049	2515R	24		21-51-22	ALL
	A02		W5049	2516R	24		21-51-22	ALL
	A03		W5049	2504R	24		23-12-41	ALL
	A04		W5049	2512R	24		34-21-24	ALL
	A05		W5049	2513R	24		34-21-24	ALL
	A06		W5049	2502R	24		23-12-41	ALL
	A07		W5049	2503R	24		23-12-41	ALL
	A08		W5049	2523R	24		36-11-24	ALL
	A09		W5049	2505R	24		23-12-41	ALL
	A10		W5049	2506R	24		23-12-41	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43139P		**E003-03/ /**		**PLUG (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W5049	2524R	24		31-65-24	ALL
	A19		W5049	2525R	24		31-65-25	ALL
	A20	UNUSED						ALL
	B01		W5049	2515B	24		21-51-22	ALL
	B02		W5049	2516B	24		21-51-22	ALL
	B03		W5049	2504B	24		23-12-41	ALL
	B04		W5049	2512B	24		34-21-24	ALL
	B05		W5049	2513B	24		34-21-24	ALL
	B06		W5049	2502B	24		23-12-41	ALL
	B07		W5049	2503B	24		23-12-41	ALL
	B08		W5049	2523B	24		36-11-24	ALL
	B09		W5049	2505B	24		23-12-41	ALL
	B10		W5049	2506B	24		23-12-41	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W5049	2524B	24		31-65-24	ALL
	B19		W5049	2525B	24		31-65-25	ALL
	B20		W5049	0004	24		31-31-17	ALL
	PERG	1F	W5049	2502Z			23-12-41	ALL
	PERG	1F	W5049	2503Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43139P		**E003-03/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5049	2504Z			23-12-41	ALL
	PERG	1F	W5049	2505Z			23-12-41	ALL
	PERG	1F	W5049	2506Z			23-12-41	ALL
	PERG	1F	W5049	2512Z			34-21-24	ALL
	PERG	1F	W5049	2513Z			34-21-24	ALL
	PERG	1F	W5049	2515Z			21-51-22	ALL
	PERG	1F	W5049	2516Z			21-51-22	ALL
	PERG	1F	W5049	2523Z			36-11-24	ALL
	PERG	1F	W5049	2524Z			31-65-24	ALL
	PERG	1F	W5049	2525Z			31-65-25	ALL
D43145J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0311	1751	24		73-21-31	ALL
	A08		W0311	0044	24		73-21-31	ALL
	A09		W0311	0045	24		73-21-31	ALL
	A10		W0311	0046	24		73-21-31	ALL
	A11		W0311	2121R	24		34-21-14	ALL
	A12		W0311	2121B	24		34-21-14	ALL
	A13		W0311	2118R	24		34-21-14	ALL
	A14		W0311	2118B	24		34-21-14	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0311	2139R	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43145J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A19		W0311	2139B	24		34-49-11	ALL
	A20		W0311	2139ZI			34-49-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0311	2150R	24		22-11-51	ALL
	B04		W0311	2150B	24		22-11-51	ALL
	B05		W0311	2149R	24		22-11-51	ALL
	B06		W0311	2149B	24		22-11-51	ALL
	B07		W0311	2089R	24		22-11-51	ALL
	B08		W0311	2089B	24		22-11-51	ALL
	B09		W0311	2090R	24		22-11-51	ALL
	B10		W0311	2090B	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0311	0133	24		31-65-15	ALL
	B14		W0311	2015R	24		31-65-15	ALL
	B15		W0311	2015B	24		31-65-15	ALL
	B16		W0311	2016R	24		31-65-15	ALL
	B17		W0311	2016B	24		31-65-15	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2015Z			31-65-15	ALL
	PERG	1F	W0311	2016Z			31-65-15	ALL
	PERG	1F	W0311	2089Z			22-11-51	ALL
	PERG	1F	W0311	2090Z			22-11-51	ALL
	PERG	1F	W0311	2118Z			34-21-14	ALL
	PERG	1F	W0311	2121Z			34-21-14	ALL
	PERG	1F	W0311	2139ZO			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43145J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0311	2149Z			22-11-51	ALL
PERG	1F	W0311	2150Z			22-11-51	ALL
D43145P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W5161	0027	20		SPARE	ALL
A04		W5161	0028	20		SPARE	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5161	0030	24		73-21-31	ALL
A08		W5161	0031	24		73-21-31	ALL
A09		W5161	0032	24		73-21-31	ALL
A10		W5161	0033	24		73-21-31	ALL
A11		W5161	2529R	24		34-21-14	ALL
A12		W5161	2529B	24		34-21-14	ALL
A13		W5161	2530R	24		34-21-14	ALL
A14		W5161	2530B	24		34-21-14	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18		W5161	2510R	24		34-49-11	ALL
A19		W5161	2510B	24		34-49-11	ALL
A20		W5161	2510ZI			34-49-11	ALL
B01		W5161	0035	24		SPARE	ALL
B02	UNUSED						ALL
B03		W5161	2532R	24		22-11-51	ALL
B04		W5161	2532B	24		22-11-51	ALL
B05		W5161	2535R	24		22-11-51	ALL
B06		W5161	2535B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43145P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B07		W5161	2536R	24		22-11-51	ALL
	B08		W5161	2536B	24		22-11-51	ALL
	B09		W5161	2537R	24		22-11-51	ALL
	B10		W5161	2537B	24		22-11-51	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W5161	0009	24		31-65-15	ALL
	B14		W5161	2525R	24		31-65-15	ALL
	B15		W5161	2525B	24		31-65-15	ALL
	B16		W5161	2526R	24		31-65-15	ALL
	B17		W5161	2526B	24		31-65-15	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5161	2510ZO			34-49-11	ALL
	PERG	1F	W5161	2525Z			31-65-15	ALL
	PERG	1F	W5161	2526Z			31-65-15	ALL
	PERG	1F	W5161	2529Z			34-21-14	ALL
	PERG	1F	W5161	2530Z			34-21-14	ALL
	PERG	1F	W5161	2532Z			22-11-51	ALL
	PERG	1F	W5161	2535Z			22-11-51	ALL
	PERG	1F	W5161	2536Z			22-11-51	ALL
	PERG	1F	W5161	2537Z			22-11-51	ALL
D43147J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0313	2636R	24		34-45-11	ALL
	A04		W0313	2636B	24		34-45-11	ALL
	A05		W0313	0660	24		34-45-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43147J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06		W0313	1751	24		73-21-31	ALL
	A07		W0313	0543	24		73-21-31	ALL
	A08		W0313	0544	24		73-21-31	ALL
	A09	UNUSED						ALL
	A10		W0313	2639R	24		34-49-11	ALL
	A11		W0313	2639B	24		34-49-11	ALL
	A12	UNUSED						ALL
	A13		W0313	0637	20		34-61-11	ALL
	A14		W0313	0636	20		34-61-11	ALL
	A15		W0313	4002R	24		31-65-15	ALL
	A16		W0313	4002Y	24		31-65-15	ALL
	A17		W0313	4001R	24		31-65-25	ALL
	A18		W0313	4001Y	24		31-65-25	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0313	2622R	24		34-21-24	ALL
	B02		W0313	2622B	24		34-21-24	ALL
	B03		W0313	2619R	24		34-21-24	ALL
	B04		W0313	2619B	24		34-21-24	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43147J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B15		W0313	4002G	24		31-65-15	ALL
	B16		W0313	4002B	24		31-65-15	ALL
	B17		W0313	4001G	24		31-65-25	ALL
	B18		W0313	4001B	24		31-65-25	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2619Z			34-21-24	ALL
	PERG	1F	W0313	2622Z			34-21-24	ALL
	PERG	1F	W0313	2636Z			34-45-11	ALL
	PERG	1F	W0313	2639Z			34-49-11	ALL
	PERG	1F	W0313	4001Z			31-65-25	ALL
	PERG	1F	W0313	4002Z			31-65-15	ALL
D43147P		**E003-01/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5163	2528R	24		34-45-11	ALL
	A04		W5163	2528B	24		34-45-11	ALL
	A05		W5163	0020	24		34-45-11	ALL
	A06		W5163	0028	24		73-21-31	ALL
	A07		W5163	0029	24		73-21-31	ALL
	A08		W5163	0030	24		73-21-31	ALL
	A09	UNUSED						ALL
	A10		W5163	2531R	24		34-49-11	ALL
	A11		W5163	2531B	24		34-49-11	ALL
	A12	UNUSED						ALL
	A13		W5163	0026	20		34-61-11	ALL
	A14		W5163	0027	20		34-61-11	ALL
	A15		W5163	4001R	24		31-65-15	ALL
	A16		W5163	4001Y	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43147P	**E003-01/ /**		**PLUG (continued)**				**ALL**
A17		W5163	4002R	24		31-65-25	ALL
A18		W5163	4002Y	24		31-65-25	ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5163	2511R	24		34-21-24	ALL
B02		W5163	2511B	24		34-21-24	ALL
B03		W5163	2506R	24		34-21-24	ALL
B04		W5163	2506B	24		34-21-24	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W5163	4001G	24		31-65-15	ALL
B16		W5163	4001B	24		31-65-15	ALL
B17		W5163	4002G	24		31-65-25	ALL
B18		W5163	4002B	24		31-65-25	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5163	2506Z			34-21-24	ALL
PERG	1F	W5163	2511Z			34-21-24	ALL
PERG	1F	W5163	2528Z			34-45-11	ALL
PERG	1F	W5163	2531Z			34-49-11	ALL
PERG	1F	W5163	4001Z			31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43147P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5163	4002Z			31-65-25	ALL
D43155J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	0018	24		31-65-15	ALL
	A02		W0311	0019	24		31-65-15	ALL
	A03		W0311	0020	24		31-65-15	ALL
	A04		W0311	0023	24		31-65-15	ALL
	A05		W0311	2116R	24		34-21-13	ALL
	A06		W0311	2116B	24		34-21-13	ALL
	A07		W0311	2115R	24		34-21-13	ALL
	A08		W0311	2115B	24		34-21-13	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0311	2025R	24		31-65-15	ALL
	A12		W0311	2025B	24		31-65-15	ALL
	A13		W0311	4001R	24		31-65-15	ALL
	A14		W0311	4001Y	24		31-65-15	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0311	0122	22		34-61-12	ALL
	A18		W0311	0119	22		34-61-12	ALL
	A19		W0311	4002R	24		31-65-25	ALL
	A20		W0311	4002Y	24		31-65-25	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0311	2027R	24		31-65-15	ALL
	B04		W0311	2027B	24		31-65-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43155J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W0311	4001G	24		31-65-15	ALL
B14		W0311	4001B	24		31-65-15	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W0311	2162R	22		49-62-11	ALL
B18		W0311	2162B	22		49-62-11	ALL
B19		W0311	4002G	24		31-65-25	ALL
B20		W0311	4002B	24		31-65-25	ALL
PERG	1F	W0311	2025Z			31-65-15	ALL
PERG	1F	W0311	2027Z			31-65-15	ALL
PERG	1F	W0311	2115Z			34-21-13	ALL
PERG	1F	W0311	2116Z			34-21-13	ALL
PERG	1F	W0311	2162Z			49-62-11	ALL
PERG	1F	W0311	4001Z			31-65-15	ALL
PERG	1F	W0311	4002Z			31-65-25	ALL
D43155P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5161	0022	24		31-65-15	ALL
A02		W5161	0023	24		31-65-15	ALL
A03		W5161	0024	24		31-65-15	ALL
A04		W5161	0034	24		31-65-15	ALL
A05		W5161	2506R	24		34-21-13	ALL
A06		W5161	2506B	24		34-21-13	ALL
A07		W5161	2507R	24		34-21-13	ALL
A08		W5161	2507B	24		34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43155P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W5161	2513R	24		31-65-15	ALL
	A12		W5161	2513B	24		31-65-15	ALL
	A13		W5161	4001R	24		31-65-15	ALL
	A14		W5161	4001Y	24		31-65-15	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W5161	0005	22		34-61-12	ALL
	A18		W5161	0006	22		34-61-12	ALL
	A19		W5161	4002R	24		31-65-25	ALL
	A20		W5161	4002Y	24		31-65-25	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5161	2514R	24		31-65-15	ALL
	B04		W5161	2514B	24		31-65-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W5161	4001G	24		31-65-15	ALL
	B14		W5161	4001B	24		31-65-15	ALL
	B15		W5161	2511R	22		SPARE	ALL
	B16		W5161	2511B	22		SPARE	ALL
	B17		W5161	2543R	22		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43155P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B18		W5161	2543B	22		49-62-11	ALL
	B19		W5161	4002G	24		31-65-25	ALL
	B20		W5161	4002B	24		31-65-25	ALL
	PERG	1F	W5161	2506Z			34-21-13	ALL
	PERG	1F	W5161	2507Z			34-21-13	ALL
	PERG	1F	W5161	2511Z			SPARE	ALL
	PERG	1F	W5161	2513Z			31-65-15	ALL
	PERG	1F	W5161	2514Z			31-65-15	ALL
	PERG	1F	W5161	2543Z			49-62-11	ALL
	PERG	1F	W5161	4001Z			31-65-15	ALL
	PERG	1F	W5161	4002Z			31-65-25	ALL
D43157J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2548R	24		73-24-21	ALL
	A02		W0313	2548B	24		73-24-21	ALL
	A03		W0313	2613R	24		22-31-52	ALL
	A04		W0313	2613B	24		22-31-52	ALL
	A05		W0313	0626	24		22-31-52	ALL
	A06		W0313	2614R	24		22-31-52	ALL
	A07		W0313	2614B	24		22-31-52	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0313	2615R	24		34-21-23	ALL
	A13		W0313	2615B	24		34-21-23	ALL
	A14		W0313	2616R	24		34-21-23	ALL
	A15		W0313	2616B	24		34-21-23	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43157J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0313	0633	24		31-65-25	ALL
	B02		W0313	0523	24		31-65-25	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0313	2515R	24		31-65-25	ALL
	B06		W0313	2515B	24		31-65-25	ALL
	B07		W0313	2516R	24		31-65-25	ALL
	B08		W0313	2516B	24		31-65-25	ALL
	B09		W0313	2522R	24		31-65-25	ALL
	B10		W0313	2522B	24		31-65-25	ALL
	B11		W0313	0518	24		31-65-25	ALL
	B12		W0313	0519	24		31-65-25	ALL
	B13		W0313	0520	24		31-65-25	ALL
	B14		W0313	2525R	24		31-65-25	ALL
	B15		W0313	2525B	24		31-65-25	ALL
	B16		W0313	2527R	24		31-65-25	ALL
	B17		W0313	2527B	24		31-65-25	ALL
	B18		W0313	2529R	24		31-65-25	ALL
	B19		W0313	2529B	24		31-65-25	ALL
	B20		W0313	0625	24		22-31-52	ALL
	PERG	1F	W0313	2515Z			31-65-25	ALL
	PERG	1F	W0313	2516Z			31-65-25	ALL
	PERG	1F	W0313	2522Z			31-65-25	ALL
	PERG	1F	W0313	2525Z			31-65-25	ALL
	PERG	1F	W0313	2527Z			31-65-25	ALL
	PERG	1F	W0313	2529Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43157J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0313	2548Z			73-24-21	ALL
	PERG	1F	W0313	2613Z			22-31-52	ALL
	PERG	1F	W0313	2614Z			22-31-52	ALL
	PERG	1F	W0313	2615Z			34-21-23	ALL
	PERG	1F	W0313	2616Z			34-21-23	ALL
D43157P		**E003-01/ /**		**PLUG**				**ALL**
	A01		W5163	2503R	24		73-24-21	ALL
	A02		W5163	2503B	24		73-24-21	ALL
	A03		W5163	2504R	24		22-31-52	ALL
	A04		W5163	2504B	24		22-31-52	ALL
	A05		W5163	0001	24		22-31-52	ALL
	A06		W5163	2505R	24		22-31-52	ALL
	A07		W5163	2505B	24		22-31-52	ALL
	A08		W5163	2508R	24		SPARE	ALL
	A09		W5163	2508B	24		SPARE	ALL
	A10		W5163	2509R	24		SPARE	ALL
	A11		W5163	2509B	24		SPARE	ALL
	A12		W5163	2513R	24		34-21-23	ALL
	A13		W5163	2513B	24		34-21-23	ALL
	A14		W5163	2514R	24		34-21-23	ALL
	A15		W5163	2514B	24		34-21-23	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5163	0009	24		31-65-25	ALL
	B02		W5163	0002	24		31-65-25	ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43157P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	B04	UNUSED						ALL
	B05		W5163	2520R	24		31-65-25	ALL
	B06		W5163	2520B	24		31-65-25	ALL
	B07		W5163	2521R	24		31-65-25	ALL
	B08		W5163	2521B	24		31-65-25	ALL
	B09		W5163	2522R	24		31-65-25	ALL
	B10		W5163	2522B	24		31-65-25	ALL
	B11		W5163	0010	24		31-65-25	ALL
	B12		W5163	0011	24		31-65-25	ALL
	B13		W5163	0012	24		31-65-25	ALL
	B14		W5163	2523R	24		31-65-25	ALL
	B15		W5163	2523B	24		31-65-25	ALL
	B16		W5163	2524R	24		31-65-25	ALL
	B17		W5163	2524B	24		31-65-25	ALL
	B18		W5163	2525R	24		31-65-25	ALL
	B19		W5163	2525B	24		31-65-25	ALL
	B20		W5163	0018	24		22-31-52	ALL
	PERG	1F	W5163	2503Z			73-24-21	ALL
	PERG	1F	W5163	2504Z			22-31-52	ALL
	PERG	1F	W5163	2505Z			22-31-52	ALL
	PERG	1F	W5163	2508Z			SPARE	ALL
	PERG	1F	W5163	2509Z			SPARE	ALL
	PERG	1F	W5163	2513Z			34-21-23	ALL
	PERG	1F	W5163	2514Z			34-21-23	ALL
	PERG	1F	W5163	2520Z			31-65-25	ALL
	PERG	1F	W5163	2521Z			31-65-25	ALL
	PERG	1F	W5163	2522Z			31-65-25	ALL
	PERG	1F	W5163	2523Z			31-65-25	ALL
	PERG	1F	W5163	2524Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43157P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5163	2525Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43203J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0034	22		31-31-14	ALL
	A02		W0321	0036	22		31-31-14	ALL
	A03		W0321	0038	22		31-31-14	ALL
	A04		W0321	0040	22		31-31-14	ALL
	A05		W0321	0041	22		31-31-14	ALL
	A06		W0321	0043	22		31-31-14	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	2037R	24		31-31-14	ALL
	B02		W0321	2037B	24		31-31-14	ALL
	B03		W0321	2038R	24		31-31-14	ALL
	B04		W0321	2038B	24		31-31-14	ALL
	B05		W0321	2039R	24		31-31-14	ALL
	B06		W0321	2039B	24		31-31-14	ALL
	B07		W0321	2040R	24		31-31-14	ALL
	B08		W0321	2040B	24		31-31-14	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2037Z			31-31-14	ALL
	PERG	1F	W0321	2038Z			31-31-14	ALL
	PERG	1F	W0321	2039Z			31-31-14	ALL
	PERG	1F	W0321	2040Z			31-31-14	ALL
D43203P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5603	3001R	20		31-31-14	ALL
	A02		W5603	3001B	20		31-31-14	ALL
	A03		W5603	3001Y	20		31-31-14	ALL
	A04		W5603	3002R	20		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43203P	**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A05		W5603	3002B	20		31-31-14	ALL
A06		W5603	3002Y	20		31-31-14	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W5603	2001R	20		31-31-14	ALL
B02		W5603	2001B	20		31-31-14	ALL
B03		W5603	2002R	20		31-31-14	ALL
B04		W5603	2002B	20		31-31-14	ALL
B05		W5603	2003R	20		31-31-14	ALL
B06		W5603	2003B	20		31-31-14	ALL
B07		W5603	2004R	20		31-31-14	ALL
B08		W5603	2004B	20		31-31-14	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5603	2001Z			31-31-14	ALL
PERG	1F	W5603	2002Z			31-31-14	ALL
PERG	1F	W5603	2003Z			31-31-14	ALL
PERG	1F	W5603	2004Z			31-31-14	ALL
PERG	1F	W5603	3001Z			31-31-14	ALL
PERG	1F	W5603	3002Z			31-31-14	ALL
D43205J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	0044	22		31-31-14	ALL
A02		W0321	0046	22		31-31-14	ALL
A03		W0321	0048	22		31-31-14	ALL
A04		W0321	0050	22		31-31-14	ALL
A05		W0321	0051	22		31-31-14	ALL
A06		W0321	0053	22		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43205J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D43205P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5605	3001R	20		31-31-14	ALL
	A02		W5605	3001B	20		31-31-14	ALL
	A03		W5605	3001Y	20		31-31-14	ALL
	A04		W5605	3002R	20		31-31-14	ALL
	A05		W5605	3002B	20		31-31-14	ALL
	A06		W5605	3002Y	20		31-31-14	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43205P	**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W5605	3001Z			31-31-14	ALL
PERG	1F	W5605	3002Z			31-31-14	ALL
D43209J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	2005R	24		31-31-11	ALL
A02		W0321	2005B	24		31-31-11	ALL
A03		W0321	0026	22		31-31-11	ALL
A04		W0321	2003R	24		31-31-11	ALL
A05		W0321	2003B	24		31-31-11	ALL
A06		W0321	0010	22		31-31-11	ALL
A07		W0321	0009	22		31-31-11	ALL
A08		W0321	0008	22		31-31-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43209J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0321	2003Z			31-31-11	ALL
	PERG	1F	W0321	2005Z			31-31-11	ALL
D43209P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5409	2001R	22		31-31-11	ALL
	A02		W5409	2001B	22		31-31-11	ALL
	A03		W5409	0002	22		31-31-11	ALL
	A04		W5409	2002R	22		31-31-11	ALL
	A05		W5409	2002B	22		31-31-11	ALL
	A06		W5409	0001	22		31-31-11	ALL
	A07		W5409	0007	22		31-31-11	ALL
	A08		W5409	0008	22		31-31-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5409	2001Z			31-31-11	ALL
	PERG	1F	W5409	2002Z			31-31-11	ALL
D43211J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	2093R	24		22-31-52	ALL
	A02		W0111	2067R	24		34-45-11	ALL
	A03		W0111	2076R	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43211J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
A04		W0111	2110R	22		34-21-15	ALL
A05		W0111	0723	22		27-53-11	ALL
A06		W0111	0410	22		31-32-15	ALL
A07		W0111	0381	22		34-21-15	ALL
A08		W0111	0172	20		27-31-11	ALL
A09		W0111	2029R	24		22-11-51	ALL
A10		W0111	0644	20		27-53-11	ALL
A11		W0111	2025R	24		22-11-51	ALL
A12		W0111	2026R	24		22-11-51	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15		W0111	0194	22		22-14-11	ALL
A16		W0111	2168R	24		27-81-41	ALL
A17		W0111	2028R	24		22-11-51	ALL
A18		W0111	2017R	24		22-11-51	ALL
A19		W0111	2203R	24		31-32-15	ALL
A20		W0111	2203B	24		31-32-15	ALL
B01		W0111	2093B	24		22-31-52	ALL
B02		W0111	2067B	24		34-45-11	ALL
B03		W0111	2076B	24		34-49-11	ALL
B04		W0111	2110B	22		34-21-15	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0111	0365	24		31-31-15	ALL
B08		W0111	0369	22		31-31-17	ALL
B09		W0111	2029B	24		22-11-51	ALL
B10		W0111	0342	24		31-31-15	ALL
B11		W0111	2025B	24		22-11-51	ALL
B12		W0111	2026B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43211J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B13	UNUSED						ALL
	B14		W0111	0645	20		27-53-11	ALL
	B15	UNUSED						ALL
	B16		W0111	2168B	24		27-81-41	ALL
	B17		W0111	2028B	24		22-11-51	ALL
	B18		W0111	2017B	24		22-11-51	ALL
	B19		W0111	2333R	24		22-11-51	ALL
	B20		W0111	2333B	24		22-11-51	ALL
	PERG	1F	W0111	2017Z			22-11-51	ALL
	PERG	1F	W0111	2025Z			22-11-51	ALL
	PERG	1F	W0111	2026Z			22-11-51	ALL
	PERG	1F	W0111	2028Z			22-11-51	ALL
	PERG	1F	W0111	2029Z			22-11-51	ALL
	PERG	1F	W0111	2067Z			34-45-11	ALL
	PERG	1F	W0111	2076Z			34-49-11	ALL
	PERG	1F	W0111	2093Z			22-31-52	ALL
	PERG	1F	W0111	2110Z			34-21-15	ALL
	PERG	1F	W0111	2168Z			27-81-41	ALL
	PERG	1F	W0111	2203Z			31-32-15	ALL
	PERG	1F	W0111	2333Z			22-11-51	ALL
D43211P		**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5461	2004R	24		22-31-52	ALL
	A02		W5461	2008R	24		34-45-11	ALL
	A03		W5461	2006R	24		34-49-11	ALL
	A04		W5461	2007R	22		34-21-15	ALL
	A05		W5461	0501	20		27-53-11	ALL
	A06		W5461	0006	22		31-32-15	ALL
	A07		W5461	0018	22		34-21-15	ALL
	A08		W5461	0010	20		27-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43211P	**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A09		W5461	2209R	24		22-11-51	ALL
A10		W5461	0502	20		27-53-11	ALL
A11		W5461	2015R	24		22-11-51	ALL
A12		W5461	2016R	24		22-11-51	ALL
A13	UNUSED						ALL
A14		W5461	0073	24		SPARE	ALL
A15		W5461	0015	22		22-14-11	ALL
A16		W5461	2021R	24		27-81-41	ALL
A17		W5461	2210R	24		22-11-51	ALL
A18		W5461	2100R	24		22-11-51	ALL
A19		W5461	2106R	24		31-32-15	ALL
A20		W5461	2106B	24		31-32-15	ALL
B01		W5461	2004B	24		22-31-52	ALL
B02		W5461	2008B	24		34-45-11	ALL
B03		W5461	2006B	24		34-49-11	ALL
B04		W5461	2007B	22		34-21-15	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W5461	0009	24		31-31-15	ALL
B08		W5461	0046	24		31-31-17	ALL
B09		W5461	2209B	24		22-11-51	ALL
B10		W5461	0056	24		31-31-15	ALL
B11		W5461	2015B	24		22-11-51	ALL
B12		W5461	2016B	24		22-11-51	ALL
B13	UNUSED						ALL
B14		W5461	0503	20		27-53-11	ALL
B15	UNUSED						ALL
B16		W5461	2021B	24		27-81-41	ALL
B17		W5461	2210B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43211P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B18		W5461	2100B	24		22-11-51	ALL
	B19		W5461	2102R	24		22-11-51	ALL
	B20		W5461	2102B	24		22-11-51	ALL
	PERG	1F	W5461	2004Z			22-31-52	ALL
	PERG	1F	W5461	2006Z			34-49-11	ALL
	PERG	1F	W5461	2007Z			34-21-15	ALL
	PERG	1F	W5461	2008Z			34-45-11	ALL
	PERG	1F	W5461	2015Z			22-11-51	ALL
	PERG	1F	W5461	2016Z			22-11-51	ALL
	PERG	1F	W5461	2021Z			27-81-41	ALL
	PERG	1F	W5461	2100Z			22-11-51	ALL
	PERG	1F	W5461	2102Z			22-11-51	ALL
	PERG	1F	W5461	2106Z			31-32-15	ALL
	PERG	1F	W5461	2209Z			22-11-51	ALL
	PERG	1F	W5461	2210Z			22-11-51	ALL
D43215J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0390	22		31-33-01	ALL
	A02		W0321	2033R	24		31-33-01	ALL
	A03		W0321	2034R	24		31-33-01	ALL
	A04	UNUSED						ALL
	A05		W0321	2070R	24		23-27-32	ALL
	A06		W0321	2085R	24		31-65-16	ALL
	A07		W0321	2086R	24		31-65-26	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43215J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0321	2033B	24		31-33-01	ALL
	B03		W0321	2034B	24		31-33-01	ALL
	B04	UNUSED						ALL
	B05		W0321	2070B	24		23-27-32	ALL
	B06		W0321	2085B	24		31-65-16	ALL
	B07		W0321	2086B	24		31-65-26	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0321	2033Z			31-33-01	ALL
	PERG	1F	W0321	2034Z			31-33-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43215J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0321	2070Z			23-27-32	ALL
	PERG	1F	W0321	2085Z			31-65-16	ALL
	PERG	1F	W0321	2086Z			31-65-26	ALL
D43215P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2805	0001	22		31-33-01	ALL
	A02		W2805	2501R	24		31-33-01	ALL
	A03		W2805	2502R	24		31-33-01	ALL
	A04		W2805	2503R	24		SPARE	ALL
	A05		W2805	2504R	24		23-27-32	ALL
	A06		W2805	2505R	24		31-65-16	ALL
	A07		W2805	2506R	24		31-65-26	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W2805	2501B	24		31-33-01	ALL
	B03		W2805	2502B	24		31-33-01	ALL
	B04		W2805	2503B	24		SPARE	ALL
	B05		W2805	2504B	24		23-27-32	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43215P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B06		W2805	2505B	24		31-65-16	ALL
	B07		W2805	2506B	24		31-65-26	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2805	2501Z			31-33-01	ALL
	PERG	1F	W2805	2502Z			31-33-01	ALL
	PERG	1F	W2805	2503Z			SPARE	ALL
	PERG	1F	W2805	2504Z			23-27-32	ALL
	PERG	1F	W2805	2505Z			31-65-16	ALL
	PERG	1F	W2805	2506Z			31-65-26	ALL
D43219J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0321	2001R	24		31-31-11	ALL
	A04		W0321	2001B	24		31-31-11	ALL
	A05		W0321	2004R	24		31-31-11	ALL
	A06		W0321	2004B	24		31-31-11	ALL
	A07		W0321	0001	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43219J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A08		W0321	0165	22		31-31-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2001Z			31-31-11	ALL
	PERG	1F	W0321	2004Z			31-31-11	ALL
D43219P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W2419	2001R	24		31-31-11	ALL
	A04		W2419	2001B	24		31-31-11	ALL
	A05		W2419	2002R	24		31-31-11	ALL
	A06		W2419	2002B	24		31-31-11	ALL
	A07		W2419	0003	22		31-31-11	ALL
	A08		W2419	0004	22		31-31-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43219P	**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W2419	2001Z			31-31-11	ALL
PERG	1F	W2419	2002Z			31-31-11	ALL
D43257J	**E003-02/ /**		**RCPT-**				**ALL**
A01		W0321	3004B	24		31-31-14	ALL
A02		W0321	3004R	24		31-31-14	ALL
A03		W0321	3004Y	24		31-31-14	ALL
A04		W0321	0642	22		31-31-14	ALL
A05		W0321	0643	22		31-31-14	ALL
A06		W0321	0644	22		31-31-14	ALL
A07		W0321	0645	22		31-31-14	ALL
A08		W0321	3005R	24		31-31-14	ALL
A09		W0321	3005B	24		31-31-14	ALL
A10		W0321	3005Y	24		31-31-14	ALL
B01		W0321	0646	22		31-31-14	ALL
B02		W0321	0647	22		31-31-14	ALL
B03		W0321	3006R	24		31-31-14	ALL
B04		W0321	3006B	24		31-31-14	ALL
B05		W0321	3006Y	24		31-31-14	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43257J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	B10	UNUSED						ALL
D43257P		**E003-02/ /**		**PLUG-**				**ALL**
	A01		W5257	3001B	22		31-31-14	ALL
	A02		W5257	3001R	22		31-31-14	ALL
	A03		W5257	3001Y	22		31-31-14	ALL
	A04		W5257	2001R	22		31-31-14	ALL
	A05		W5257	2001B	22		31-31-14	ALL
	A06		W5257	2002R	22		31-31-14	ALL
	A07		W5257	2002B	22		31-31-14	ALL
	A08		W5257	3002R	22		31-31-14	ALL
	A09		W5257	3002B	22		31-31-14	ALL
	A10		W5257	3002Y	22		31-31-14	ALL
	B01		W5257	2003R	22		31-31-14	ALL
	B02		W5257	2003B	22		31-31-14	ALL
	B03		W5257	3003R	22		31-31-14	ALL
	B04		W5257	3003B	22		31-31-14	ALL
	B05		W5257	3003Y	22		31-31-14	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D43261J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0321	0017	24		31-35-01	ALL
	A04		W0321	0015	24		31-35-01	ALL
	A05		W0321	0118	24		27-81-31	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43261J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A07		W0321	2015R	22		34-61-15	ALL
A08		W0321	2018R	24		34-61-14	ALL
A09		W0321	2035R	24		31-35-02	ALL
A10		W0321	2035B	24		31-35-02	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0321	0273	22		27-32-11	ALL
A15		W0321	3733R	22		27-32-11	ALL
A16		W0321	3733B	22		27-32-11	ALL
A17		W0321	3733Y	22		27-32-11	ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0321	0117	24		27-81-31	ALL
B04		W0321	2009R	22		31-32-15	ALL
B05		W0321	2009B	22		31-32-15	ALL
B06		W0321	0616	22		27-61-42	ALL
B07		W0321	2015B	22		34-61-15	ALL
B08		W0321	2018B	24		34-61-14	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0321	0127	20		27-32-11	ALL
B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43261J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0321	0614	22		27-61-42	ALL
	B19		W0321	0615	22		27-61-42	ALL
	B20	UNUSED						ALL
	DED		W0321	3733Z			27-32-11	ALL
	PERG	1F	W0321	2009Z			31-32-15	ALL
	PERG	1F	W0321	2015Z			34-61-15	ALL
	PERG	1F	W0321	2018Z			34-61-14	ALL
	PERG	1F	W0321	2035Z			31-35-02	ALL
D43261P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5461	0003	24		31-35-01	ALL
	A04		W5461	0001	24		31-35-01	ALL
	A05		W5461	0082	24		27-81-31	ALL
	A06	UNUSED						ALL
	A07		W5461	2009R	22		34-61-15	ALL
	A08		W5461	2010R	24		34-61-14	ALL
	A09		W5461	2005R	24		31-35-02	ALL
	A10		W5461	2005B	24		31-35-02	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W5461	2101R	22		27-32-11	ALL
	A15		W5461	3001R	22		27-32-11	ALL
	A16		W5461	3001B	22		27-32-11	ALL
	A17		W5461	3001Y	22		27-32-11	ALL
	A18		W5461	2033R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43261P	**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A19		W5461	2033B	24		SPARE	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W5461	0081	24		27-81-31	ALL
B04		W5461	2104R	22		31-32-15	ALL
B05		W5461	2104B	22		31-32-15	ALL
B06		W5461	0021	22		27-61-42	ALL
B07		W5461	2009B	22		34-61-15	ALL
B08		W5461	2010B	24		34-61-14	ALL
B09		W5461	2032R	24		SPARE	ALL
B10		W5461	2032B	24		SPARE	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W5461	2101B	22		27-32-11	ALL
B15		W5461	2034R	24		SPARE	ALL
B16		W5461	2034B	24		SPARE	ALL
B17	UNUSED						ALL
B18		W5461	0019	22		27-61-42	ALL
B19		W5461	0020	22		27-61-42	ALL
B20	UNUSED						ALL
PERG	1F	W5461	2005Z			31-35-02	ALL
PERG	1F	W5461	2009Z			34-61-15	ALL
PERG	1F	W5461	2010Z			34-61-14	ALL
PERG	1F	W5461	2032Z			SPARE	ALL
PERG	1F	W5461	2033Z			SPARE	ALL
PERG	1F	W5461	2034Z			SPARE	ALL
PERG	1F	W5461	2104Z			31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43263J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0525	20		47-30-11	ALL
	A02		W0321	0526	20		47-30-11	ALL
	A03	UNUSED						ALL
	A04		W0321	2168R	24		34-61-14	ALL
	A05		W0321	2753R	24		27-32-22	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0321	2170R	24		34-21-24	ALL
	A10		W0321	0077	24		31-31-15	ALL
	A11		W0321	0200	24		21-51-21	ALL
	A12		W0321	2754R	24		27-32-22	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0321	2375R	24		34-21-23	ALL
	A16		W0321	2114R	24		34-21-23	ALL
	A17		W0321	0253	22		27-32-21	ALL
	A18		W0321	2095B	24		27-28-11	ALL
	A19		W0321	2095R	24		27-28-11	ALL
	A20		W0321	2704R	24		27-28-11	ALL
	B01		W0321	2704B	24		27-28-11	ALL
	B02		W0321	0527	20		47-30-11	ALL
	B03	UNUSED						ALL
	B04		W0321	2168B	24		34-61-14	ALL
	B05		W0321	2753B	24		27-32-22	ALL
	B06		W0321	0528	20		47-30-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0321	2170B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43263J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0321	2754B	24		27-32-22	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0321	2375B	24		34-21-23	ALL
	B16		W0321	2114B	24		34-21-23	ALL
	B17		W0321	0254	20		27-32-21	ALL
	B18		W0321	3713R	22		27-32-21	ALL
	B19		W0321	3713B	22		27-32-21	ALL
	B20		W0321	3713Y	22		27-32-21	ALL
	DED		W0321	2704Z			27-28-11	ALL
	PERG	1F	W0321	2114Z			34-21-23	ALL
	PERG	1F	W0321	2168Z			34-61-14	ALL
	PERG	1F	W0321	2170Z			34-21-24	ALL
	PERG	1F	W0321	2375Z			34-21-23	ALL
	PERG	1F	W0321	2753Z			27-32-22	ALL
	PERG	1F	W0321	2754Z			27-32-22	ALL
D43263P		**E003-02/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W5463	0100	20		47-30-11	ALL
	A02		W5463	0101	20		47-30-11	ALL
	A03		W5463	2011R	24		SPARE	ALL
	A04		W5463	2012R	24		34-61-14	ALL
	A05		W5463	2003R	24		27-32-22	ALL
	A06	UNUSED						ALL
	A07		W5463	2013R	24		SPARE	ALL
	A08		W5463	2014R	24		SPARE	ALL
	A09		W5463	2015R	24		34-21-24	ALL
	A10		W5463	0005	24		31-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43263P		**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A11		W5463	0200	24		21-51-21	ALL
	A12		W5463	2009R	24		27-32-22	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W5463	2017R	24		34-21-23	ALL
	A16		W5463	2016R	24		34-21-23	ALL
	A17		W5463	2002R	22		27-32-21	ALL
	A18		W5463	2050B	24		27-28-11	ALL
	A19		W5463	2050R	24		27-28-11	ALL
	A20		W5463	2021R	24		27-28-11	ALL
	B01		W5463	2021B	24		27-28-11	ALL
	B02		W5463	0102	20		47-30-11	ALL
	B03		W5463	2011B	24		SPARE	ALL
	B04		W5463	2012B	24		34-61-14	ALL
	B05		W5463	2003B	24		27-32-22	ALL
	B06		W5463	0103	20		47-30-11	ALL
	B07		W5463	2013B	24		SPARE	ALL
	B08		W5463	2014B	24		SPARE	ALL
	B09		W5463	2015B	24		34-21-24	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W5463	2009B	24		27-32-22	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W5463	2017B	24		34-21-23	ALL
	B16		W5463	2016B	24		34-21-23	ALL
	B17		W5463	2002B	22		27-32-21	ALL
	B18		W5463	3001R	22		27-32-21	ALL
	B19		W5463	3001B	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43263P	**E003-02/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
B20		W5463	3001Y	22		27-32-21	ALL
PERG	1F	W5463	2003Z			27-32-22	ALL
PERG	1F	W5463	2009Z			27-32-22	ALL
PERG	1F	W5463	2011Z			SPARE	ALL
PERG	1F	W5463	2012Z			34-61-14	ALL
PERG	1F	W5463	2013Z			SPARE	ALL
PERG	1F	W5463	2014Z			SPARE	ALL
PERG	1F	W5463	2015Z			34-21-24	ALL
PERG	1F	W5463	2016Z			34-21-23	ALL
PERG	1F	W5463	2017Z			34-21-23	ALL
D43267J	**916/295/L003**		**RCPT-**				**ALL**
1		W0767	2001R	22		31-31-11	ALL
2		W0767	2001B	22		31-31-11	ALL
3		W0767	2001Z			31-31-11	ALL
4		W0767	2002R	22		31-31-11	ALL
5		W0767	2002B	22		31-31-11	ALL
6		W0767	2002Z			31-31-11	ALL
7		W0767	0007	22		31-31-11	ALL
8		W0767	0008	22		31-31-11	ALL
9		W0767	0005	20		31-31-11	ALL
10		W0767	0004	20		31-31-11	ALL
11	UNUSED						ALL
12		W0767	0001	22		31-31-11	ALL
13		W0767	0002	22		31-31-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
D43267P	**916/295/L003**		**PLUG**				**ALL**
1		W5409	2001R	22		31-31-11	ALL
2		W5409	2001B	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43267P		**916/295/L003**		**PLUG (continued)**				**ALL**
	3		W5409	FRAC			31-31-11	ALL
	4		W5409	2002R	22		31-31-11	ALL
	5		W5409	2002B	22		31-31-11	ALL
	6		W5409	FRAA			31-31-11	ALL
	7		W5409	0007	22		31-31-11	ALL
	8		W5409	0008	22		31-31-11	ALL
	9		W5409	0005	20		31-31-11	ALL
	10		W5409	0004	20		31-31-11	ALL
	11	UNUSED						ALL
	12		W5409	0001	22		31-31-11	ALL
	13		W5409	0002	22		31-31-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	S/R		W5409	FRAB			31-31-11	ALL
	S/R		W5409	FRAD			31-31-11	ALL
			W5409	2001Z			31-31-11	ALL
			W5409	2002Z			31-31-11	ALL
			W5409	FRAA			31-31-11	ALL
			W5409	FRAB			31-31-11	ALL
			W5409	FRAC			31-31-11	ALL
			W5409	FRAD			31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43301J		**E003-03/ /**		**INSERT**				**ALL**
	=A1	DH	W0335	001CX			23-12-31	ALL
	=C1		W0335	001CO			23-12-31	ALL
D43301P		**E003-03/ /**		**INSERT**				**ALL**
	=A1	DR	W5415	001CX			23-12-31	ALL
	=C1		W5415	001CO			23-12-31	ALL
D43306J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	2663R	24		23-27-37	ALL
	A02		W0331	2624R	24		23-27-37	ALL
	A03		W0331	2881R	24		23-12-41	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0331	2663B	24		23-27-37	ALL
	B02		W0331	2624B	24		23-27-37	ALL
	B03		W0331	2881B	24		23-12-41	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0331	2624Z			23-27-37	ALL
	PERG	1F	W0331	2663Z			23-27-37	ALL
	PERG	1F	W0331	2881Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43306P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5723	2509R	24		23-27-37	ALL
	A02		W5723	2510R	24		23-27-37	ALL
	A03		W5723	2528R	24		23-12-41	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5723	2509B	24		23-27-37	ALL
	B02		W5723	2510B	24		23-27-37	ALL
	B03		W5723	2528B	24		23-12-41	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5723	2509Z			23-27-37	ALL
	PERG	1F	W5723	2510Z			23-27-37	ALL
	PERG	1F	W5723	2528Z			23-12-41	ALL
D43307J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	2635R	24		31-32-15	ALL
	A02		W0331	2758R	24		23-27-37	ALL
	A03		W0331	2629R	24		23-27-38	ALL
	A04		W0331	2660R	24		34-45-21	ALL
	A05		W0331	2655R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43307J	**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
A06		W0331	2654R	24		31-35-02	ALL
A07		W0331	2601R	24		23-27-32	ALL
A08		W0331	2656R	24		31-33-01	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12		W0331	0214	22		23-27-38	ALL
A13		W0331	0216	22		23-27-38	ALL
A14	UNUSED						ALL
A15		W0331	0218	22		23-27-38	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0331	2635B	24		31-32-15	ALL
B02		W0331	2758B	24		23-27-37	ALL
B03		W0331	2629B	24		23-27-38	ALL
B04		W0331	2660B	24		34-45-21	ALL
B05		W0331	2655B	24		31-35-02	ALL
B06		W0331	2654B	24		31-35-02	ALL
B07		W0331	2601B	24		23-27-32	ALL
B08		W0331	2656B	24		31-33-01	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0331	0217	22		23-27-38	ALL
B13		W0331	0215	22		23-27-38	ALL
B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43307J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B15		W0331	0219	22		23-27-38	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0331	2601Z			23-27-32	ALL
	PERG	1F	W0331	2629Z			23-27-38	ALL
	PERG	1F	W0331	2635Z			31-32-15	ALL
	PERG	1F	W0331	2654Z			31-35-02	ALL
	PERG	1F	W0331	2655Z			31-35-02	ALL
	PERG	1F	W0331	2656Z			31-33-01	ALL
	PERG	1F	W0331	2660Z			34-45-21	ALL
	PERG	1F	W0331	2758Z			23-27-37	ALL
D43307P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	2066R	24		31-32-15	ALL
	A02		W5111	2196R	24		23-27-37	ALL
	A03		W5111	2055R	24		23-27-38	ALL
	A04		W5111	2093R	24		34-45-21	ALL
	A05		W5111	2061R	24		31-35-02	ALL
	A06		W5111	2060R	24		31-35-02	ALL
	A07		W5111	2024R	24		23-27-32	ALL
	A08		W5111	2075R	24		31-33-01	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W5111	0034	22		23-27-38	ALL
	A13		W5111	0036	22		23-27-38	ALL
	A14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43307P	**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A15		W5111	0040	22		23-27-38	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5111	2066B	24		31-32-15	ALL
B02		W5111	2196B	24		23-27-37	ALL
B03		W5111	2055B	24		23-27-38	ALL
B04		W5111	2093B	24		34-45-21	ALL
B05		W5111	2061B	24		31-35-02	ALL
B06		W5111	2060B	24		31-35-02	ALL
B07		W5111	2024B	24		23-27-32	ALL
B08		W5111	2075B	24		31-33-01	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W5111	0035	22		23-27-38	ALL
B13		W5111	0037	22		23-27-38	ALL
B14	UNUSED						ALL
B15		W5111	0041	22		23-27-38	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5111	2024Z			23-27-32	ALL
PERG	1F	W5111	2055Z			23-27-38	ALL
PERG	1F	W5111	2060Z			31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43307P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5111	2061Z			31-35-02	ALL
	PERG	1F	W5111	2066Z			31-32-15	ALL
	PERG	1F	W5111	2075Z			31-33-01	ALL
	PERG	1F	W5111	2093Z			34-45-21	ALL
	PERG	1F	W5111	2196Z			23-27-37	ALL
D43309J		**E003-03/173/L005**		**INSERT**				**ALL**
	1		W0335	0355	22		23-27-31	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0335	0099	16		23-12-31	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D43309P		**E003-03/173/L005**		**INSERT - SOCKET**				**ALL**
	1		W2231	0013	22		23-27-31	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W2231	0015	16		23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43309P	**E003-03/173/L005**		**INSERT - SOCKET (continued)**				**ALL**
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
D43313J	**E003-03/ /**		**INSERT**				**ALL**
1		W0331	0202	22		23-27-31	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
D43313P	**E003-03/ /**		**INSERT-SOCKET**				**ALL**
1		W2201	0022	22		23-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43313P		**E003-03/ /**		**INSERT-SOCKET (continued)**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
D43314J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0335	2685R	24		23-12-41	ALL
	A02		W0335	2686R	24		23-12-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0335	0253	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0335	2685B	24		23-12-41	ALL
	B02		W0335	2686B	24		23-12-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43314J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W0335	0254	22		23-12-21	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0335	2685Z			23-12-41	ALL
	PERG	1F	W0335	2686Z			23-12-21	ALL
D43314P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5177	2501R	24		23-12-41	ALL
	A02		W5177	2502R	24		23-12-21	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5177	0003	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5177	2501B	24		23-12-41	ALL
	B02		W5177	2502B	24		23-12-21	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5177	0004	22		23-12-21	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5177	2501Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43314P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5177	2502Z			23-12-21	ALL
D43317J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0483	22		32-64-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0111	1002	22		22-11-11	ALL
	A05		W0111	0755	22		22-11-11	ALL
	A06		W0111	0003	20		22-11-12	ALL
	A07		W0111	0059	22		22-11-12	ALL
	A08		W0111	0060	22		22-11-12	ALL
	A09	UNUSED						ALL
	A10		W0111	0099	20		22-14-11	ALL
	A11		W0111	2048B	22		22-18-11	ALL
	A12		W0111	0158	22		22-13-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0111	0157	22		22-13-11	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0111	2124R	24		34-31-21	ALL
	A19		W0111	2032R	24		22-11-51	ALL
	A20		W0111	2032B	24		22-11-51	ALL
	B01	UNUSED						ALL
	B02		W0111	0244	22		22-18-11	ALL
	B03		W0111	2210R	24		34-58-21	ALL
	B04		W0111	2210B	24		34-58-21	ALL
	B05		W0111	2125R	24		34-31-21	ALL
	B06		W0111	2125B	24		34-31-21	ALL
	B07		W0111	0030	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43317J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B08		W0111	0033	22		22-11-11	ALL
	B09	UNUSED						ALL
	B10		W0111	0186	22		22-14-11	ALL
	B11		W0111	2048R	22		22-18-11	ALL
	B12		W0111	0138	20		22-18-11	ALL
	B13		W0111	0240	22		22-18-11	ALL
	B14		W0111	0241	22		22-18-11	ALL
	B15		W0111	0242	22		22-18-11	ALL
	B16		W0111	0243	22		22-18-11	ALL
	B17	UNUSED						ALL
	B18		W0111	2124B	24		34-31-21	ALL
	B19		W0111	2033R	24		22-11-51	ALL
	B20		W0111	2033B	24		22-11-51	ALL
	PERG	1F	W0111	1002Z			22-11-11	ALL
	PERG	1F	W0111	2032Z			22-11-51	ALL
	PERG	1F	W0111	2033Z			22-11-51	ALL
	PERG	1F	W0111	2124Z			34-31-21	ALL
	PERG	1F	W0111	2125Z			34-31-21	ALL
	PERG	1F	W0111	2210Z			34-58-21	ALL
D43317P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5723	0101	20		32-64-21	ALL
	A02		W5723	0102	20		SPARE	ALL
	A03		W5723	0103	20		SPARE	ALL
	A04		W5723	1104	20		22-11-11	ALL
	A05		W5723	0055	22		22-11-11	ALL
	A06		W5723	0106	20		22-11-12	ALL
	A07		W5723	0107	20		22-11-12	ALL
	A08		W5723	0108	20		22-11-12	ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43317P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A10		W5723	0046	20		22-14-11	ALL
	A11		W5723	2130B	22		22-18-11	ALL
	A12		W5723	0042	22		22-13-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W5723	0043	22		22-13-11	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W5723	2135R	24		34-31-21	ALL
	A19		W5723	2116R	22		22-11-51	ALL
	A20		W5723	2116B	22		22-11-51	ALL
	B01	UNUSED						ALL
	B02		W5723	0133	22		22-18-11	ALL
	B03		W5723	2122R	24		34-58-21	ALL
	B04		W5723	2122B	24		34-58-21	ALL
	B05		W5723	2136R	24		34-31-21	ALL
	B06		W5723	2136B	24		34-31-21	ALL
	B07		W5723	0147	20		22-11-11	ALL
	B08		W5723	0148	20		22-11-11	ALL
	B09	UNUSED						ALL
	B10		W5723	0045	22		22-14-11	ALL
	B11		W5723	2130R	22		22-18-11	ALL
	B12		W5723	0125	20		22-18-11	ALL
	B13		W5723	0126	22		22-18-11	ALL
	B14		W5723	0127	22		22-18-11	ALL
	B15		W5723	0128	22		22-18-11	ALL
	B16		W5723	0129	22		22-18-11	ALL
	B17	UNUSED						ALL
	B18		W5723	2135B	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43317P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B19		W5723	2113R	22		22-11-51	ALL
	B20		W5723	2113B	22		22-11-51	ALL
	PERG	1F	W5723	1104Z			22-11-11	ALL
	PERG	1F	W5723	2113Z			22-11-51	ALL
	PERG	1F	W5723	2116Z			22-11-51	ALL
	PERG	1F	W5723	2122Z			34-58-21	ALL
	PERG	1F	W5723	2130Z			22-18-11	ALL
	PERG	1F	W5723	2135Z			34-31-21	ALL
	PERG	1F	W5723	2136Z			34-31-21	ALL
D43321J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0331	2641R	24		34-61-23	ALL
	A08		W0331	2642R	24		34-61-23	ALL
	A09	UNUSED						ALL
	A10		W0331	2637R	24		34-61-21	ALL
	A11		W0331	2638R	24		34-61-21	ALL
	A12		W0331	2602R	24		23-27-32	ALL
	A13		W0331	2630R	24		23-27-39	ALL
	A14		W0331	0226	24		23-27-39	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43321J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0331	2641B	24		34-61-23	ALL
	B08		W0331	2642B	24		34-61-23	ALL
	B09	UNUSED						ALL
	B10		W0331	2637B	24		34-61-21	ALL
	B11		W0331	2638B	24		34-61-21	ALL
	B12		W0331	2602B	24		23-27-32	ALL
	B13		W0331	2630B	24		23-27-39	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0331	2602Z			23-27-32	ALL
	PERG	1F	W0331	2630Z			23-27-39	ALL
	PERG	1F	W0331	2637Z			34-61-21	ALL
	PERG	1F	W0331	2638Z			34-61-21	ALL
	PERG	1F	W0331	2641Z			34-61-23	ALL
	PERG	1F	W0331	2642Z			34-61-23	ALL
D43321P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43321P	**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5111	2065R	24		34-61-23	ALL
A08		W5111	2073R	24		34-61-23	ALL
A09		W5111	2102R	22		44-21-20	ALL
A10		W5111	2164R	24		34-61-21	ALL
A11		W5111	2064R	24		34-61-21	ALL
A12		W5111	2068R	24		23-27-32	ALL
A13		W5111	2069R	24		23-27-39	ALL
A14		W5111	0042	24		23-27-39	ALL
A15		W5111	2099R	24		SPARE	ALL
A16		W5111	2094R	24		SPARE	ALL
A17	UNUSED						ALL
A18		W5111	2092R	22		44-21-20	ALL
A19	UNUSED						ALL
A20		W5111	2063R	24		SPARE	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W5111	2065B	24		34-61-23	ALL
B08		W5111	2073B	24		34-61-23	ALL
B09		W5111	2102B	22		44-21-20	ALL
B10		W5111	2164B	24		34-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43321P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B11		W5111	2064B	24		34-61-21	ALL
	B12		W5111	2068B	24		23-27-32	ALL
	B13		W5111	2069B	24		23-27-39	ALL
	B14	UNUSED						ALL
	B15		W5111	2099B	24		SPARE	ALL
	B16		W5111	2094B	24		SPARE	ALL
	B17	UNUSED						ALL
	B18		W5111	2092B	22		44-21-20	ALL
	B19	UNUSED						ALL
	B20		W5111	2063B	24		SPARE	ALL
	PERG	1F	W5111	2063Z			SPARE	ALL
	PERG	1F	W5111	2064Z			34-61-21	ALL
	PERG	1F	W5111	2065Z			34-61-23	ALL
	PERG	1F	W5111	2068Z			23-27-32	ALL
	PERG	1F	W5111	2069Z			23-27-39	ALL
	PERG	1F	W5111	2073Z			34-61-23	ALL
	PERG	1F	W5111	2092Z			44-21-20	ALL
	PERG	1F	W5111	2094Z			SPARE	ALL
	PERG	1F	W5111	2099Z			SPARE	ALL
	PERG	1F	W5111	2102Z			44-21-20	ALL
	PERG	1F	W5111	2164Z			34-61-21	ALL
D43323J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0335	2541R	24		34-61-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43323J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A08		W0335	2542R	24		34-61-23	ALL
	A09		W0335	2807R	24		34-45-21	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0335	2609R	24		23-27-33	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0335	2608R	24		23-27-33	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0335	2541B	24		34-61-23	ALL
	B08		W0335	2542B	24		34-61-23	ALL
	B09		W0335	2807B	24		34-45-21	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0335	2609B	24		23-27-33	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43323J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18		W0335	2608B	24		23-27-33	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0335	2541Z			34-61-23	ALL
	PERG	1F	W0335	2542Z			34-61-23	ALL
	PERG	1F	W0335	2608Z			23-27-33	ALL
	PERG	1F	W0335	2609Z			23-27-33	ALL
	PERG	1F	W0335	2807Z			34-45-21	ALL
D43323P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5121	2043R	24		34-61-23	ALL
	A08		W5121	2045R	24		34-61-23	ALL
	A09		W5121	2072R	24		34-45-21	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W5121	2060R	24		23-27-33	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W5121	2059R	24		23-27-33	ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43323P	**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W5121	2043B	24		34-61-23	ALL
B08		W5121	2045B	24		34-61-23	ALL
B09		W5121	2072B	24		34-45-21	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W5121	2060B	24		23-27-33	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18		W5121	2059B	24		23-27-33	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5121	2043Z			34-61-23	ALL
PERG	1F	W5121	2045Z			34-61-23	ALL
PERG	1F	W5121	2059Z			23-27-33	ALL
PERG	1F	W5121	2060Z			23-27-33	ALL
PERG	1F	W5121	2072Z			34-45-21	ALL
D43329J	**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43329J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A03		W0335	2707R	24		23-12-41	ALL
	A04		W0335	2659R	24		23-12-41	ALL
	A05		W0335	2691R	24		23-12-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0335	0228	22		23-12-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0335	2707B	24		23-12-41	ALL
	B04		W0335	2659B	24		23-12-41	ALL
	B05		W0335	2691B	24		23-12-41	ALL
	B06		W0335	0147	22		23-12-31	ALL
	B07	UNUSED						ALL
	B08		W0335	0256	22		23-12-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0335	0135	18		23-12-31	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0335	2659Z			23-12-41	ALL
	PERG	1F	W0335	2691Z			23-12-41	ALL
	PERG	1F	W0335	2707Z			23-12-41	ALL
D43329P		**E003-03/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43329P	**E003-03/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A03		W2417	2501R	24		23-12-41	ALL
A04		W2417	2506R	24		23-12-41	ALL
A05		W2417	2508R	24		23-12-41	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W2417	0010	22		23-12-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W2417	2501B	24		23-12-41	ALL
B04		W2417	2506B	24		23-12-41	ALL
B05		W2417	2508B	24		23-12-41	ALL
B06		W2417	0011	22		23-12-31	ALL
B07	UNUSED						ALL
B08		W2417	0012	22		23-12-21	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2417	0040	18		23-12-31	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W2417	2501Z			23-12-41	ALL
PERG	1F	W2417	2506Z			23-12-41	ALL
PERG	1F	W2417	2508Z			23-12-41	ALL
D43331J	**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
A01		W0335	2524R	24		23-27-37	ALL
A02		W0335	2525R	24		23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43331J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A03		W0335	2527R	24		23-27-37	ALL
	A04		W0335	2535R	24		23-27-37	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0335	2507ZI			23-22-11	ALL
	A15		W0335	2507R	24		23-22-11	ALL
	A16		W0335	2529R	24		23-12-31	ALL
	A17		W0335	2529ZI			23-12-31	ALL
	A18		W0335	2530R	24		23-12-31	ALL
	A19		W0335	2530ZI			23-12-31	ALL
	A20	UNUSED						ALL
	B01		W0335	2524B	24		23-27-37	ALL
	B02		W0335	2525B	24		23-27-37	ALL
	B03		W0335	2527B	24		23-27-37	ALL
	B04		W0335	2535B	24		23-27-37	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43331J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W0335	2507B	24		23-22-11	ALL
	B16		W0335	2529B	24		23-12-31	ALL
	B17		W0335	0102	22		23-12-31	ALL
	B18		W0335	2530B	24		23-12-31	ALL
	B19		W0335	0103	24		23-12-31	ALL
	B20	UNUSED						ALL
	PERG	1F	W0335	2507ZO			23-22-11	ALL
	PERG	1F	W0335	2524Z			23-27-37	ALL
	PERG	1F	W0335	2525Z			23-27-37	ALL
	PERG	1F	W0335	2527Z			23-27-37	ALL
	PERG	1F	W0335	2529ZO			23-12-31	ALL
	PERG	1F	W0335	2530ZO			23-12-31	ALL
	PERG	1F	W0335	2535Z			23-27-37	ALL
D43331P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5191	2005R	24		23-27-37	ALL
	A02		W5191	2006R	24		23-27-37	ALL
	A03		W5191	2007R	24		23-27-37	ALL
	A04		W5191	2008R	24		23-27-37	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43331P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A13	UNUSED						ALL
	A14		W5191	2542ZI			23-22-11	ALL
	A15		W5191	2542R	24		23-22-11	ALL
	A16		W5191	2528R	24		23-12-31	ALL
	A17		W5191	2528ZI			23-12-31	ALL
	A18		W5191	2529R	24		23-12-31	ALL
	A19		W5191	2529ZI			23-12-31	ALL
	A20	UNUSED						ALL
	B01		W5191	2005B	24		23-27-37	ALL
	B02		W5191	2006B	24		23-27-37	ALL
	B03		W5191	2007B	24		23-27-37	ALL
	B04		W5191	2008B	24		23-27-37	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W5191	2542B	24		23-22-11	ALL
	B16		W5191	2528B	24		23-12-31	ALL
	B17		W5191	0014	22		23-12-31	ALL
	B18		W5191	2529B	24		23-12-31	ALL
	B19		W5191	0015	22		23-12-31	ALL
	B20	UNUSED						ALL
	PERG	1F	W5191	2005Z			23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43331P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5191	2006Z			23-27-37	ALL
	PERG	1F	W5191	2007Z			23-27-37	ALL
	PERG	1F	W5191	2008Z			23-27-37	ALL
	PERG	1F	W5191	2528ZO			23-12-31	ALL
	PERG	1F	W5191	2529ZO			23-12-31	ALL
	PERG	1F	W5191	2542ZO			23-22-11	ALL
D43345J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0331	2603R	24		23-27-32	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0331	2663R	24		23-27-37	ALL
	A13		W0331	2626R	24		23-27-37	ALL
	A14	UNUSED						ALL
	A15		W0331	2630R	24		23-27-39	ALL
	A16	UNUSED						ALL
	A17		W0331	0226	24		23-27-39	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0331	0571	24		23-27-31	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43345J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0331	2603B	24		23-27-32	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0331	2663B	24		23-27-37	ALL
	B13		W0331	2626B	24		23-27-37	ALL
	B14	UNUSED						ALL
	B15		W0331	2630B	24		23-27-39	ALL
	B16	UNUSED						ALL
	B17		W0331	0202	22		23-27-31	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0331	2603Z			23-27-32	ALL
	PERG	1F	W0331	2626Z			23-27-37	ALL
	PERG	1F	W0331	2630Z			23-27-39	ALL
	PERG	1F	W0331	2663Z			23-27-37	ALL
D43345P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5331	2527R	24		SPARE	ALL
	A02	UNUSED						ALL
	A03		W5331	2532R	24		SPARE	ALL
	A04	UNUSED						ALL
	A05		W5331	2506R	24		SPARE	ALL
	A06		W5331	2505R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43345P	**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A07		W5331	2501R	24		SPARE	ALL
A08		W5331	2502R	24		23-27-32	ALL
A09		W5331	2503R	24		SPARE	ALL
A10		W5331	2504R	24		SPARE	ALL
A11		W5331	2508R	24		SPARE	ALL
A12		W5331	2509R	24		23-27-37	ALL
A13		W5331	2510R	24		23-27-37	ALL
A14		W5331	2511R	24		SPARE	ALL
A15		W5331	2513R	24		23-27-39	ALL
A16		W5331	2524R	24		SPARE	ALL
A17		W5331	0008	24		23-27-39	ALL
A18		W5331	2529R	24		SPARE	ALL
A19		W5331	2530R	24		SPARE	ALL
A20		W5331	0039	24		23-27-31	ALL
B01		W5331	2527B	24		SPARE	ALL
B02	UNUSED						ALL
B03		W5331	2532B	24		SPARE	ALL
B04	UNUSED						ALL
B05		W5331	2506B	24		SPARE	ALL
B06		W5331	2505B	24		SPARE	ALL
B07		W5331	2501B	24		SPARE	ALL
B08		W5331	2502B	24		23-27-32	ALL
B09		W5331	2503B	24		SPARE	ALL
B10		W5331	2504B	24		SPARE	ALL
B11		W5331	2508B	24		SPARE	ALL
B12		W5331	2509B	24		23-27-37	ALL
B13		W5331	2510B	24		23-27-37	ALL
B14		W5331	2511B	24		SPARE	ALL
B15		W5331	2513B	24		23-27-39	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43345P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B16		W5331	2524B	24		SPARE	ALL
	B17		W5331	0001	22		23-27-31	ALL
	B18		W5331	2529B	24		SPARE	ALL
	B19		W5331	2530B	24		SPARE	ALL
	B20	UNUSED						ALL
	PERG	1F	W5331	2501Z			SPARE	ALL
	PERG	1F	W5331	2502Z			23-27-32	ALL
	PERG	1F	W5331	2503Z			SPARE	ALL
	PERG	1F	W5331	2504Z			SPARE	ALL
	PERG	1F	W5331	2505Z			SPARE	ALL
	PERG	1F	W5331	2506Z			SPARE	ALL
	PERG	1F	W5331	2508Z			SPARE	ALL
	PERG	1F	W5331	2509Z			23-27-37	ALL
	PERG	1F	W5331	2510Z			23-27-37	ALL
	PERG	1F	W5331	2511Z			SPARE	ALL
	PERG	1F	W5331	2513Z			23-27-39	ALL
	PERG	1F	W5331	2524Z			SPARE	ALL
	PERG	1F	W5331	2527Z			SPARE	ALL
	PERG	1F	W5331	2529Z			SPARE	ALL
	PERG	1F	W5331	2530Z			SPARE	ALL
	PERG	1F	W5331	2532Z			SPARE	ALL
D43347J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	0214	22		23-27-38	ALL
	A02		W0331	0216	22		23-27-38	ALL
	A03		W0331	0219	22		23-27-38	ALL
	A04		W0331	2637R	24		34-61-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0331	2655R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43347J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A08		W0331	2654R	24		31-35-02	ALL
	A09		W0331	2656R	24		31-33-01	ALL
	A10	UNUSED						ALL
	A11		W0331	2629R	24		23-27-38	ALL
	A12		W0331	2635R	24		31-32-15	ALL
	A13		W0331	2640R	24		34-61-23	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0331	2638R	24		34-61-21	ALL
	A18		W0331	2660R	24		34-45-21	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0331	0215	22		23-27-38	ALL
	B02		W0331	0217	22		23-27-38	ALL
	B03		W0331	0218	22		23-27-38	ALL
	B04		W0331	2637B	24		34-61-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0331	2655B	24		31-35-02	ALL
	B08		W0331	2654B	24		31-35-02	ALL
	B09		W0331	2656B	24		31-33-01	ALL
	B10	UNUSED						ALL
	B11		W0331	2629B	24		23-27-38	ALL
	B12		W0331	2635B	24		31-32-15	ALL
	B13		W0331	2640B	24		34-61-23	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43347J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B17		W0331	2638B	24		34-61-21	ALL
	B18		W0331	2660B	24		34-45-21	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0331	2629Z			23-27-38	ALL
	PERG	1F	W0331	2635Z			31-32-15	ALL
	PERG	1F	W0331	2637Z			34-61-21	ALL
	PERG	1F	W0331	2638Z			34-61-21	ALL
	PERG	1F	W0331	2640Z			34-61-23	ALL
	PERG	1F	W0331	2654Z			31-35-02	ALL
	PERG	1F	W0331	2655Z			31-35-02	ALL
	PERG	1F	W0331	2656Z			31-33-01	ALL
	PERG	1F	W0331	2660Z			34-45-21	ALL
D43347P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5331	0002	22		23-27-38	ALL
	A02		W5331	0004	22		23-27-38	ALL
	A03		W5331	0006	22		23-27-38	ALL
	A04		W5331	2566R	24		34-61-21	ALL
	A05		W5331	0022	24		SPARE	ALL
	A06		W5331	0024	24		SPARE	ALL
	A07		W5331	2515R	24		31-35-02	ALL
	A08		W5331	2514R	24		31-35-02	ALL
	A09		W5331	2518R	24		31-33-01	ALL
	A10		W5331	2516R	24		SPARE	ALL
	A11		W5331	2512R	24		23-27-38	ALL
	A12		W5331	2517R	24		31-32-15	ALL
	A13		W5331	2519R	24		34-61-23	ALL
	A14		W5331	2520R	24		SPARE	ALL
	A15		W5331	2521R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43347P	**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A16		W5331	2522R	24		SPARE	ALL
A17		W5331	2523R	24		34-61-21	ALL
A18		W5331	2526R	24		34-45-21	ALL
A19		W5331	2561ZI			SPARE	ALL
A20		W5331	2561R	24		SPARE	ALL
B01		W5331	0003	22		23-27-38	ALL
B02		W5331	0005	22		23-27-38	ALL
B03		W5331	0007	22		23-27-38	ALL
B04		W5331	2566B	24		34-61-21	ALL
B05		W5331	0023	24		SPARE	ALL
B06		W5331	0025	24		SPARE	ALL
B07		W5331	2515B	24		31-35-02	ALL
B08		W5331	2514B	24		31-35-02	ALL
B09		W5331	2518B	24		31-33-01	ALL
B10		W5331	2516B	24		SPARE	ALL
B11		W5331	2512B	24		23-27-38	ALL
B12		W5331	2517B	24		31-32-15	ALL
B13		W5331	2519B	24		34-61-23	ALL
B14		W5331	2520B	24		SPARE	ALL
B15		W5331	2521B	24		SPARE	ALL
B16		W5331	2522B	24		SPARE	ALL
B17		W5331	2523B	24		34-61-21	ALL
B18		W5331	2526B	24		34-45-21	ALL
B19	UNUSED						ALL
B20		W5331	2561B	24		SPARE	ALL
PERG	1F	W5331	2512Z			23-27-38	ALL
PERG	1F	W5331	2514Z			31-35-02	ALL
PERG	1F	W5331	2515Z			31-35-02	ALL
PERG	1F	W5331	2516Z			SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43347P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5331	2517Z			31-32-15	ALL
	PERG	1F	W5331	2518Z			31-33-01	ALL
	PERG	1F	W5331	2519Z			34-61-23	ALL
	PERG	1F	W5331	2520Z			SPARE	ALL
	PERG	1F	W5331	2521Z			SPARE	ALL
	PERG	1F	W5331	2522Z			SPARE	ALL
	PERG	1F	W5331	2523Z			34-61-21	ALL
	PERG	1F	W5331	2526Z			34-45-21	ALL
	PERG	1F	W5331	2561ZO			SPARE	ALL
	PERG	1F	W5331	2566Z			34-61-21	ALL
D43355J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0335	2683R	24		23-12-41	ALL
	A02		W0335	2681R	24		23-12-41	ALL
	A03		W0335	2714R	24		23-12-41	ALL
	A04		W0335	0251	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06		W0335	0241	22		23-11-21	ALL
	A07		W0335	0249	22		23-12-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0335	2684R	24		23-12-21	ALL
	A12		W0335	2667R	24		23-11-11	ALL
	A13		W0335	2674R	24		23-11-21	ALL
	A14		W0335	2682R	24		23-12-11	ALL
	A15		W0335	2546R	24		23-12-31	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43355J	**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
A19		W0335	0505	24		23-27-31	ALL
A20		W0335	0507	24		23-27-31	ALL
B01		W0335	2683B	24		23-12-41	ALL
B02		W0335	2681B	24		23-12-41	ALL
B03		W0335	2714B	24		23-12-41	ALL
B04		W0335	0252	22		23-12-21	ALL
B05	UNUSED						ALL
B06		W0335	0242	22		23-11-21	ALL
B07		W0335	0270	22		23-12-31	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0335	2684B	24		23-12-21	ALL
B12		W0335	2667B	24		23-11-11	ALL
B13		W0335	2674B	24		23-11-21	ALL
B14		W0335	2682B	24		23-12-11	ALL
B15		W0335	2546B	24		23-12-31	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W0335	0506	24		23-27-31	ALL
B20	UNUSED						ALL
PERG	1F	W0335	2546Z			23-12-31	ALL
PERG	1F	W0335	2667Z			23-11-11	ALL
PERG	1F	W0335	2674Z			23-11-21	ALL
PERG	1F	W0335	2681Z			23-12-41	ALL
PERG	1F	W0335	2682Z			23-12-11	ALL
PERG	1F	W0335	2683Z			23-12-41	ALL
PERG	1F	W0335	2684Z			23-12-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43355J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0335	2714Z			23-12-41	ALL
D43355P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2415	2501R	24		23-12-41	ALL
	A02		W2415	2505R	24		23-12-41	ALL
	A03		W2415	2508R	24		23-12-41	ALL
	A04		W2415	0004	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06		W2415	0026	22		23-11-21	ALL
	A07		W2415	0010	22		23-12-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W2415	2502R	24		23-12-21	ALL
	A12		W2415	2503R	24		23-11-11	ALL
	A13		W2415	2504R	24		23-11-21	ALL
	A14		W2415	2506R	24		23-12-11	ALL
	A15		W2415	2507R	24		23-12-31	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W2415	0054	24		23-27-31	ALL
	A20		W2415	0059	24		23-27-31	ALL
	B01		W2415	2501B	24		23-12-41	ALL
	B02		W2415	2505B	24		23-12-41	ALL
	B03		W2415	2508B	24		23-12-41	ALL
	B04		W2415	0012	22		23-12-21	ALL
	B05	UNUSED						ALL
	B06		W2415	0029	22		23-11-21	ALL
	B07		W2415	0011	22		23-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43355P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W2415	2502B	24		23-12-21	ALL
	B12		W2415	2503B	24		23-11-11	ALL
	B13		W2415	2504B	24		23-11-21	ALL
	B14		W2415	2506B	24		23-12-11	ALL
	B15		W2415	2507B	24		23-12-31	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W2415	0055	24		23-27-31	ALL
	B20	UNUSED						ALL
	PERG	1F	W2415	2501Z			23-12-41	ALL
	PERG	1F	W2415	2502Z			23-12-21	ALL
	PERG	1F	W2415	2503Z			23-11-11	ALL
	PERG	1F	W2415	2504Z			23-11-21	ALL
	PERG	1F	W2415	2505Z			23-12-41	ALL
	PERG	1F	W2415	2506Z			23-12-11	ALL
	PERG	1F	W2415	2507Z			23-12-31	ALL
	PERG	1F	W2415	2508Z			23-12-41	ALL
D43359J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	2671R	24		23-11-11	ALL
	A02	UNUSED						ALL
	A03		W0331	0235	22		23-11-11	ALL
	A04		W0331	2669R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43359J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0331	2671B	24		23-11-11	ALL
	B02		W0331	0234	22		23-11-11	ALL
	B03		W0331	0236	24		23-12-41	ALL
	B04		W0331	2669B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0331	2669Z			23-12-41	ALL
	PERG	1F	W0331	2671Z			23-11-11	ALL
D43359P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5103	2501R	24		23-11-11	ALL
	A02	UNUSED						ALL
	A03		W5103	0003	22		23-11-11	ALL
	A04		W5103	2502R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5103	2501B	24		23-11-11	ALL
	B02		W5103	0002	22		23-11-11	ALL
	B03		W5103	0004	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43359P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04		W5103	2502B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5103	2501Z			23-11-11	ALL
	PERG	1F	W5103	2502Z			23-12-41	ALL
D43361J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0335	2675R	24		23-11-21	ALL
	A02	UNUSED						ALL
	A03		W0335	0242	22		23-11-21	ALL
	A04		W0335	2670R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0335	2675B	24		23-11-21	ALL
	B02		W0335	0241	22		23-11-21	ALL
	B03		W0335	0243	24		23-12-41	ALL
	B04		W0335	2670B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43361J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	PERG	1F	W0335	2670Z			23-12-41	ALL
	PERG	1F	W0335	2675Z			23-11-21	ALL
D43361P		**E003-03/ /**		**PLUG -CONDUCTIVE**				**ALL**
	A01		W5105	2501R	24		23-11-21	ALL
	A02	UNUSED						ALL
	A03		W5105	0003	22		23-11-21	ALL
	A04		W5105	2502R	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5105	2501B	24		23-11-21	ALL
	B02		W5105	0002	22		23-11-21	ALL
	B03		W5105	0004	24		23-12-41	ALL
	B04		W5105	2502B	24		23-12-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5105	2501Z			23-11-21	ALL
	PERG	1F	W5105	2502Z			23-12-41	ALL
D43363J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	2676R	24		23-12-41	ALL
	A02		W0331	2688R	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43363J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	A03		W0331	2711R	24		23-12-41	ALL
	A04		W0331	0245	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06		W0331	0235	22		23-11-11	ALL
	A07		W0331	0269	22		23-12-31	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0331	2677R	24		23-12-11	ALL
	A12		W0331	2668R	24		23-11-11	ALL
	A13		W0331	2673R	24		23-11-21	ALL
	A14		W0331	2689R	24		23-12-21	ALL
	A15		W0331	2587R	24		23-12-31	ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W0331	0568	24		23-27-31	ALL
	A20		W0331	0570	24		23-27-31	ALL
	B01		W0331	2676B	24		23-12-41	ALL
	B02		W0331	2688B	24		23-12-41	ALL
	B03		W0331	2711B	24		23-12-41	ALL
	B04		W0331	0246	22		23-12-11	ALL
	B05		W0331	0234	22		23-11-11	ALL
	B06	UNUSED						ALL
	B07		W0331	0255	22		23-12-21	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0331	2677B	24		23-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43363J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B12		W0331	2668B	24		23-11-11	ALL
	B13		W0331	2673B	24		23-11-21	ALL
	B14		W0331	2689B	24		23-12-21	ALL
	B15		W0331	2587B	24		23-12-31	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W0331	0569	24		23-27-31	ALL
	B20	UNUSED						ALL
	PERG	1F	W0331	2587Z			23-12-31	ALL
	PERG	1F	W0331	2668Z			23-11-11	ALL
	PERG	1F	W0331	2673Z			23-11-21	ALL
	PERG	1F	W0331	2676Z			23-12-41	ALL
	PERG	1F	W0331	2677Z			23-12-11	ALL
	PERG	1F	W0331	2688Z			23-12-41	ALL
	PERG	1F	W0331	2689Z			23-12-21	ALL
	PERG	1F	W0331	2711Z			23-12-41	ALL
D43363P		**E003-03/ /**		**PLUG- CONDUCTIVE**				**ALL**
	A01		W2413	2501R	24		23-12-41	ALL
	A02		W2413	2505R	24		23-12-41	ALL
	A03		W2413	2507R	24		23-12-41	ALL
	A04		W2413	0004	24		23-12-41	ALL
	A05	UNUSED						ALL
	A06		W2413	0029	22		23-11-11	ALL
	A07		W2413	0011	22		23-12-31	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W2413	2502R	24		23-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43363P	**E003-03/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
A12		W2413	2503R	24		23-11-11	ALL
A13		W2413	2504R	24		23-11-21	ALL
A14		W2413	2506R	24		23-12-21	ALL
A15		W2413	2508R	24		23-12-31	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W2413	0054	24		23-27-31	ALL
A20		W2413	0059	24		23-27-31	ALL
B01		W2413	2501B	24		23-12-41	ALL
B02		W2413	2505B	24		23-12-41	ALL
B03		W2413	2507B	24		23-12-41	ALL
B04		W2413	0010	22		23-12-11	ALL
B05		W2413	0026	22		23-11-11	ALL
B06	UNUSED						ALL
B07		W2413	0012	22		23-12-21	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W2413	2502B	24		23-12-11	ALL
B12		W2413	2503B	24		23-11-11	ALL
B13		W2413	2504B	24		23-11-21	ALL
B14		W2413	2506B	24		23-12-21	ALL
B15		W2413	2508B	24		23-12-31	ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W2413	0055	24		23-27-31	ALL
B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43363P		**E003-03/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2413	2501Z			23-12-41	ALL
	PERG	1F	W2413	2502Z			23-12-11	ALL
	PERG	1F	W2413	2503Z			23-11-11	ALL
	PERG	1F	W2413	2504Z			23-11-21	ALL
	PERG	1F	W2413	2505Z			23-12-41	ALL
	PERG	1F	W2413	2506Z			23-12-21	ALL
	PERG	1F	W2413	2507Z			23-12-41	ALL
	PERG	1F	W2413	2508Z			23-12-31	ALL
D43367J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0331	2678R	24		23-12-41	ALL
	A02		W0331	2679R	24		23-12-11	ALL
	A03		W0331	2687R	24		23-12-41	ALL
	A04		W0331	2845R	24		34-21-14	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0331	0247	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0331	2678B	24		23-12-41	ALL
	B02		W0331	2679B	24		23-12-11	ALL
	B03		W0331	2687B	24		23-12-41	ALL
	B04		W0331	2845B	24		34-21-14	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0331	0248	22		23-12-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43367J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0331	2678Z			23-12-41	ALL
	PERG	1F	W0331	2679Z			23-12-11	ALL
	PERG	1F	W0331	2687Z			23-12-41	ALL
	PERG	1F	W0331	2845Z			34-21-14	ALL
D43367P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5107	2501R	24		23-12-41	ALL
	A02		W5107	2502R	24		23-12-11	ALL
	A03		W5107	2503R	24		23-12-41	ALL
	A04		W5107	2504R	24		34-21-14	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W5107	0003	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5107	2501B	24		23-12-41	ALL
	B02		W5107	2502B	24		23-12-11	ALL
	B03		W5107	2503B	24		23-12-41	ALL
	B04		W5107	2504B	24		34-21-14	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5107	0004	22		23-12-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5107	2501Z			23-12-41	ALL
	PERG	1F	W5107	2502Z			23-12-11	ALL
	PERG	1F	W5107	2503Z			23-12-41	ALL
	PERG	1F	W5107	2504Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43379J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0335	2525R	24		23-27-37	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0335	2803R	24		34-61-23	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0335	2807R	24		34-45-21	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20		W0335	2822R	24		23-27-33	ALL
	B01		W0335	0355	22		23-27-31	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0335	2525B	24		23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43379J		**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0335	2803B	24		34-61-23	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0335	2807B	24		34-45-21	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0335	2822B	24		23-27-33	ALL
	PERG	1F	W0335	2525Z			23-27-37	ALL
	PERG	1F	W0335	2803Z			34-61-23	ALL
	PERG	1F	W0335	2807Z			34-45-21	ALL
	PERG	1F	W0335	2822Z			23-27-33	ALL
D43379P		**E003-03/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5335	0001	22		SPARE	ALL
	A02		W5335	0003	22		SPARE	ALL
	A03		W5335	2561R	24		SPARE	ALL
	A04	UNUSED						ALL
	A05		W5335	2566ZI			SPARE	ALL
	A06		W5335	2566R	24		SPARE	ALL
	A07		W5335	2510R	24		SPARE	ALL
	A08		W5335	2501R	24		SPARE	ALL
	A09		W5335	2502R	24		23-27-37	ALL
	A10		W5335	2503R	24		SPARE	ALL
	A11		W5335	2504R	24		SPARE	ALL
	A12		W5335	2505R	24		34-61-23	ALL
	A13		W5335	2506R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43379P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A14		W5335	2507R	24		SPARE	ALL
	A15		W5335	2508R	24		SPARE	ALL
	A16		W5335	2509R	24		SPARE	ALL
	A17		W5335	2511R	24		34-45-21	ALL
	A18		W5335	2513R	24		SPARE	ALL
	A19		W5335	2567R	24		SPARE	ALL
	A20		W5335	2562R	24		23-27-33	ALL
	B01		W5335	0002	22		23-27-31	ALL
	B02		W5335	0004	22		SPARE	ALL
	B03		W5335	2561B	24		SPARE	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5335	2566B	24		SPARE	ALL
	B07		W5335	2510B	24		SPARE	ALL
	B08		W5335	2501B	24		SPARE	ALL
	B09		W5335	2502B	24		23-27-37	ALL
	B10		W5335	2503B	24		SPARE	ALL
	B11		W5335	2504B	24		SPARE	ALL
	B12		W5335	2505B	24		34-61-23	ALL
	B13		W5335	2506B	24		SPARE	ALL
	B14		W5335	2507B	24		SPARE	ALL
	B15		W5335	2508B	24		SPARE	ALL
	B16		W5335	2509B	24		SPARE	ALL
	B17		W5335	2511B	24		34-45-21	ALL
	B18		W5335	2513B	24		SPARE	ALL
	B19		W5335	2567B	24		SPARE	ALL
	B20		W5335	2562B	24		23-27-33	ALL
	PERG	1F	W5335	2501Z			SPARE	ALL
	PERG	1F	W5335	2502Z			23-27-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43379P		**E003-03/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5335	2503Z			SPARE	ALL
	PERG	1F	W5335	2504Z			SPARE	ALL
	PERG	1F	W5335	2505Z			34-61-23	ALL
	PERG	1F	W5335	2506Z			SPARE	ALL
	PERG	1F	W5335	2507Z			SPARE	ALL
	PERG	1F	W5335	2508Z			SPARE	ALL
	PERG	1F	W5335	2509Z			SPARE	ALL
	PERG	1F	W5335	2510Z			SPARE	ALL
	PERG	1F	W5335	2511Z			34-45-21	ALL
	PERG	1F	W5335	2513Z			SPARE	ALL
	PERG	1F	W5335	2561Z			SPARE	ALL
	PERG	1F	W5335	2562Z			23-27-33	ALL
	PERG	1F	W5335	2566ZO			SPARE	ALL
	PERG	1F	W5335	2567Z			SPARE	ALL
D43387J		**AB1080/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3397	3005R	22		22-23-12	ALL
	2		W3397	3005B	22		22-23-12	ALL
	3		W3397	3005Y	22		22-23-12	ALL
	4		W3397	2009R	22		22-23-12	ALL
	5		W3397	2009B	22		22-23-12	ALL
	6		W3397	2008R	22		22-23-12	ALL
	7		W3397	2008B	22		22-23-12	ALL
	8		W3397	1005	20		22-23-11	ALL
	9		W3397	1009	20		22-23-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43387J		**AB1080/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	15	UNUSED						ALL
	S/R		W3397	1005Z			22-23-11	ALL
	S/R		W3397	1009Z			22-23-11	ALL
	S/R		W3397	2008Z			22-23-12	ALL
	S/R		W3397	2009Z			22-23-12	ALL
	S/R		W3397	3005Z			22-23-12	ALL
D43387P		**AB1080/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W3387	3001R	20		22-23-12	ALL
	2		W3387	3001B	20		22-23-12	ALL
	3		W3387	3001Y	20		22-23-12	ALL
	4		W3387	2001R	20		22-23-12	ALL
	5		W3387	2001B	20		22-23-12	ALL
	6		W3387	2002R	20		22-23-12	ALL
	7		W3387	2002B	20		22-23-12	ALL
	8		W3387	1001	20		22-23-11	ALL
	9		W3387	1002	20		22-23-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	S/R		W3387	1001Z			22-23-11	ALL
	S/R		W3387	1002Z			22-23-11	ALL
	S/R		W3387	2001Z			22-23-12	ALL
	S/R		W3387	2002Z			22-23-12	ALL
	S/R		W3387	3001Z			22-23-12	ALL
D43389J		**AB1080/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3399	3005R	20		27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43389J	**AB1080/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
2		W3399	3005B	20		27-24-11	ALL
3		W3399	3005Y	20		27-24-11	ALL
4		W3399	2008R	22		27-24-11	ALL
5		W3399	2008B	22		27-24-11	ALL
6		W3399	2009R	22		27-24-11	ALL
7		W3399	2009B	22		27-24-11	ALL
8		W3399	1005	20		27-24-11	ALL
9		W3399	1009	20		27-24-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
S/R		W3399	1005Z			27-24-11	ALL
S/R		W3399	1009Z			27-24-11	ALL
S/R		W3399	2008Z			27-24-11	ALL
S/R		W3399	2009Z			27-24-11	ALL
S/R		W3399	3005Z			27-24-11	ALL
D43389P	**AB1080/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W3389	3001R	20		27-24-11	ALL
2		W3389	3001B	20		27-24-11	ALL
3		W3389	3001Y	20		27-24-11	ALL
4		W3389	2001R	20		27-24-11	ALL
5		W3389	2001B	20		27-24-11	ALL
6		W3389	2002R	20		27-24-11	ALL
7		W3389	2002B	20		27-24-11	ALL
8		W3389	1001	20		27-24-11	ALL
9		W3389	1002	20		27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43389P		**AB1080/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	S/R		W3389	1001Z			27-24-11	ALL
	S/R		W3389	1002Z			27-24-11	ALL
	S/R		W3389	2001Z			27-24-11	ALL
	S/R		W3389	2002Z			27-24-11	ALL
	S/R		W3389	3001Z			27-24-11	ALL
D43391J		**E003-03/ /**		**RECPT - CONDUCTIVE**				**ALL**
	A01		W0335	2709R	24		23-12-31	ALL
	A02		W0335	2657R	24		23-11-11	ALL
	A03		W0335	2672R	24		23-11-21	ALL
	A04		W0335	2658R	24		23-12-11	ALL
	A05		W0335	2690R	24		23-12-21	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0335	0502	24		23-27-31	ALL
	A10		W0335	0504	24		23-27-31	ALL
	B01		W0335	2709B	24		23-12-31	ALL
	B02		W0335	2657B	24		23-11-11	ALL
	B03		W0335	2672B	24		23-11-21	ALL
	B04		W0335	2658B	24		23-12-11	ALL
	B05		W0335	2690B	24		23-12-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43391J	**E003-03/ /**		**RECPT - CONDUCTIVE (continued)**				**ALL**
B08	UNUSED						ALL
B09		W0335	0503	24		23-27-31	ALL
B10	UNUSED						ALL
PERG	1F	W0335	2657Z			23-11-11	ALL
PERG	1F	W0335	2658Z			23-12-11	ALL
PERG	1F	W0335	2672Z			23-11-21	ALL
PERG	1F	W0335	2690Z			23-12-21	ALL
PERG	1F	W0335	2709Z			23-12-31	ALL
D43391P	**E003-03/ /**		**PLUG- CONDUCTIVE**				**ALL**
A01		W2417	2502R	24		23-12-31	ALL
A02		W2417	2503R	24		23-11-11	ALL
A03		W2417	2504R	24		23-11-21	ALL
A04		W2417	2505R	24		23-12-11	ALL
A05		W2417	2507R	24		23-12-21	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W2417	0054	24		23-27-31	ALL
A10		W2417	0059	24		23-27-31	ALL
B01		W2417	2502B	24		23-12-31	ALL
B02		W2417	2503B	24		23-11-11	ALL
B03		W2417	2504B	24		23-11-21	ALL
B04		W2417	2505B	24		23-12-11	ALL
B05		W2417	2507B	24		23-12-21	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W2417	0055	24		23-27-31	ALL
B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43391P		**E003-03/ /**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2417	2502Z			23-12-31	ALL
	PERG	1F	W2417	2503Z			23-11-11	ALL
	PERG	1F	W2417	2504Z			23-11-21	ALL
	PERG	1F	W2417	2505Z			23-12-11	ALL
	PERG	1F	W2417	2507Z			23-12-21	ALL
D43393J		**AB1050L/296/L017**		**RCPT - CONDUCTIVE**				**ALL**
	1		W3393	2001R	22		22-18-11	ALL
	2		W3393	2001B	22		22-18-11	ALL
	3		W3393	2024R	22		22-18-11	ALL
	4		W3393	2024B	22		22-18-11	ALL
	5		W3393	2006R	22		22-18-11	ALL
	6		W3393	2006B	22		22-18-11	ALL
	7		W3393	2026R	22		22-18-11	ALL
	8		W3393	2026B	22		22-18-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W3393	1013	20		22-18-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43393J	**AB1050L/296/L017**		**RCPT - CONDUCTIVE (continued)**				**ALL**
24	UNUSED						ALL
S/R		W3393	1013Z			22-18-11	ALL
S/R		W3393	2001Z			22-18-11	ALL
S/R		W3393	2006Z			22-18-11	ALL
S/R		W3393	2024Z			22-18-11	ALL
S/R		W3393	2026Z			22-18-11	ALL
D43393P	**AB1050L/297/L013**		**PLUG - CONDUCTIVE**				**ALL**
1		W5301	2001R	22		22-18-11	ALL
2		W5301	2001B	22		22-18-11	ALL
3		W5301	2024R	22		22-18-11	ALL
4		W5301	2024B	22		22-18-11	ALL
5		W5301	2006R	22		22-18-11	ALL
6		W5301	2006B	22		22-18-11	ALL
7		W5301	2026R	22		22-18-11	ALL
8		W5301	2026B	22		22-18-11	ALL
9		W5301	2007R	22		SPARE	ALL
10		W5301	2007B	22		SPARE	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5301	0013	20		22-18-11	ALL
14	UNUSED						ALL
15		W5301	0015	22		SPARE	ALL
16	UNUSED						ALL
17		W5301	0017	22		SPARE	ALL
18	UNUSED						ALL
19		W5301	0019	22		SPARE	ALL
20	UNUSED						ALL
21		W5301	0021	22		SPARE	ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43393P		**AB1050L/297/L013**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	23	UNUSED						ALL
	24	UNUSED						ALL
D43396J		**229/198/L014**		**RCPT**				**ALL**
	A	UNUSED						ALL
	B		W0443	0012V	20		27-41-11	ALL
	C		W0443	0010KO	20		27-41-11	ALL
	D		W0443	0009O	20		27-41-11	ALL
D43396P		**229/198/L014**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W5374	0002	20		27-41-11	ALL
	C		W5374	0003	20		27-41-11	ALL
	D		W5374	0004	20		27-41-11	ALL
D43397J		**AB1050L/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1		W3397	1001	20		22-12-31	ALL
	2	UNUSED						ALL
	3		W3397	2001R	22		22-12-31	ALL
	4		W3397	2001B	22		22-12-31	ALL
	5		W3397	2004R	22		22-12-31	ALL
	6		W3397	2004B	22		22-12-31	ALL
	7		W3397	2003R	22		22-12-31	ALL
	8		W3397	2003B	22		22-12-31	ALL
	9		W3397	2005R	22		22-12-31	ALL
	10		W3397	2005B	22		22-12-31	ALL
	11		W3397	2006R	22		22-12-31	ALL
	12		W3397	2006B	22		22-12-31	ALL
	13		W3397	2007R	22		22-12-31	ALL
	14		W3397	2007B	22		22-12-31	ALL
	15		W3397	3001R	22		22-12-31	ALL
	16		W3397	3001B	22		22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43397J	**AB1050L/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
17		W3397	3001Y	22		22-12-31	ALL
18		W3397	3002R	22		22-12-31	ALL
19		W3397	3002B	22		22-12-31	ALL
20	UNUSED						ALL
21		W3397	3003R	22		22-12-31	ALL
22		W3397	3003B	22		22-12-31	ALL
23		W3397	3003Y	22		22-12-31	ALL
24		W3397	2009R	22		22-23-12	ALL
25		W3397	2009B	22		22-23-12	ALL
26		W3397	2008R	22		22-23-12	ALL
27		W3397	2008B	22		22-23-12	ALL
28		W3397	3005R	22		22-23-12	ALL
29		W3397	3005B	22		22-23-12	ALL
30		W3397	3005Y	22		22-23-12	ALL
31	UNUSED						ALL
32		W3397	1002	20		22-11-12	ALL
33		W3397	1003	20		22-11-12	ALL
34		W3397	1004	20		22-12-31	ALL
35		W3397	1005	20		22-23-11	ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44		W3397	2012B	20		27-32-31	ALL
45		W3397	2012R	20		27-32-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43397J		**AB1050L/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W3397	1009	20		22-23-11	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W3397	1001Z			22-12-31	ALL
	S/R		W3397	1002Z			22-11-12	ALL
	S/R		W3397	1003Z			22-11-12	ALL
	S/R		W3397	1004Z			22-12-31	ALL
	S/R		W3397	1005Z			22-23-11	ALL
	S/R		W3397	1009Z			22-23-11	ALL
	S/R		W3397	2001Z			22-12-31	ALL
	S/R		W3397	2003Z			22-12-31	ALL
	S/R		W3397	2004Z			22-12-31	ALL
	S/R		W3397	2005Z			22-12-31	ALL
	S/R		W3397	2006Z			22-12-31	ALL
	S/R		W3397	2007Z			22-12-31	ALL
	S/R		W3397	2008Z			22-23-12	ALL
	S/R		W3397	2009Z			22-23-12	ALL
	S/R		W3397	2012Z			27-32-31	ALL
	S/R		W3397	3001Z			22-12-31	ALL
	S/R		W3397	3002Z			22-12-31	ALL
	S/R		W3397	3003Z			22-12-31	ALL
	S/R		W3397	3005Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43397P	**AB1050L/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W3377	1013	20		22-12-31	ALL
2	UNUSED						ALL
3		W3377	2002R	22		22-12-31	ALL
4		W3377	2002B	22		22-12-31	ALL
5		W3377	2004R	22		22-12-31	ALL
6		W3377	2004B	22		22-12-31	ALL
7		W3377	2003R	22		22-12-31	ALL
8		W3377	2003B	22		22-12-31	ALL
9		W3377	2005R	22		22-12-31	ALL
10		W3377	2005B	22		22-12-31	ALL
11		W3377	2006R	22		22-12-31	ALL
12		W3377	2006B	22		22-12-31	ALL
13		W3377	2007R	22		22-12-31	ALL
14		W3377	2007B	22		22-12-31	ALL
15		W3377	3001R	22		22-12-31	ALL
16		W3377	3001B	22		22-12-31	ALL
17		W3377	3001Y	22		22-12-31	ALL
18		W3377	2023R	22		22-12-31	ALL
19		W3377	2023B	22		22-12-31	ALL
20	UNUSED						ALL
21		W3377	3003R	22		22-12-31	ALL
22		W3377	3003B	22		22-12-31	ALL
23		W3377	3003Y	22		22-12-31	ALL
24		W3377	2009R	22		22-23-12	ALL
25		W3377	2009B	22		22-23-12	ALL
26		W3377	2008R	22		22-23-12	ALL
27		W3377	2008B	22		22-23-12	ALL
28		W3377	3005R	22		22-23-12	ALL
29		W3377	3005B	22		22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43397P		**AB1050L/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	30		W3377	3005Y	22		22-23-12	ALL
	31	UNUSED						ALL
	32		W3377	0011	20		22-11-12	ALL
	33		W3377	0012	20		22-11-12	ALL
	34		W3377	1012	20		22-12-31	ALL
	35		W3377	0101	20		22-23-11	ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44		W3377	2012B	20		27-32-31	ALL
	45		W3377	2012R	20		27-32-31	ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48		W3377	1009	20		22-23-11	ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W3377	1009Z			22-23-11	ALL
	S/R		W3377	1012Z			22-12-31	ALL
	S/R		W3377	1013Z			22-12-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43397P		**AB1050L/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	S/R		W3377	2002Z			22-12-31	ALL
	S/R		W3377	2003Z			22-12-31	ALL
	S/R		W3377	2004Z			22-12-31	ALL
	S/R		W3377	2005Z			22-12-31	ALL
	S/R		W3377	2006Z			22-12-31	ALL
	S/R		W3377	2007Z			22-12-31	ALL
	S/R		W3377	2008Z			22-23-12	ALL
	S/R		W3377	2009Z			22-23-12	ALL
	S/R		W3377	2012Z			27-32-31	ALL
	S/R		W3377	2023Z			22-12-31	ALL
	S/R		W3377	3001Z			22-12-31	ALL
	S/R		W3377	3003Z			22-12-31	ALL
	S/R		W3377	3005Z			22-23-12	ALL
D43398J		**226/198/R014**		**RCPT**				**ALL**
	A	UNUSED						ALL
	B		W0445	0032V	20		27-41-11	ALL
	C		W0445	0030KO	20		27-41-11	ALL
	D		W0445	0029O	20		27-41-11	ALL
D43398P		**228/198/R014**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W5373	0002	20		27-41-11	ALL
	C		W5373	0003	20		27-41-11	ALL
	D		W5373	0004	20		27-41-11	ALL
D43399J		**AB1050R/298/R009**		**RCPT - CONDUCTIVE**				**ALL**
	1		W3399	1001	20		22-12-41	ALL
	2	UNUSED						ALL
	3		W3399	2001R	22		22-12-41	ALL
	4		W3399	2001B	22		22-12-41	ALL
	5		W3399	2004R	22		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43399J		**AB1050R/298/R009**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	6		W3399	2004B	22		22-12-41	ALL
	7		W3399	2003R	22		22-12-41	ALL
	8		W3399	2003B	22		22-12-41	ALL
	9		W3399	2005R	20		22-12-41	ALL
	10		W3399	2005B	20		22-12-41	ALL
	11		W3399	2006R	22		22-12-41	ALL
	12		W3399	2006B	22		22-12-41	ALL
	13		W3399	2007R	22		22-12-41	ALL
	14		W3399	2007B	22		22-12-41	ALL
	15		W3399	3001R	22		22-12-41	ALL
	16		W3399	3001B	22		22-12-41	ALL
	17		W3399	3001Y	22		22-12-41	ALL
	18		W3399	3002R	22		22-12-41	ALL
	19		W3399	3002B	22		22-12-41	ALL
	20		W3399	3003B	22		22-12-41	ALL
	21		W3399	3003R	22		22-12-41	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W3399	1002	20		22-11-12	ALL
	33		W3399	1003	20		22-11-12	ALL
	34		W3399	1004	20		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43399J	**AB1050R/298/R009**		**RCPT - CONDUCTIVE (continued)**				**ALL**
35	UNUSED						ALL
36	UNUSED						ALL
37		W3399	3003Y	22		22-12-41	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W3399	2009R	22		27-24-11	ALL
42		W3399	2009B	22		27-24-11	ALL
43		W3399	2008R	22		27-24-11	ALL
44		W3399	2008B	22		27-24-11	ALL
45		W3399	3005R	20		27-24-11	ALL
46		W3399	3005B	20		27-24-11	ALL
47		W3399	3005Y	20		27-24-11	ALL
48		W3399	1009	20		27-24-11	ALL
49		W3399	1005	20		27-24-11	ALL
50	UNUSED						ALL
51		W3399	2011R	20		27-32-31	ALL
52		W3399	2011B	20		27-32-31	ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
S/R		W3399	1001Z			22-12-41	ALL
S/R		W3399	1002Z			22-11-12	ALL
S/R		W3399	1003Z			22-11-12	ALL
S/R		W3399	1004Z			22-12-41	ALL
S/R		W3399	1005Z			27-24-11	ALL
S/R		W3399	1009Z			27-24-11	ALL
S/R		W3399	2001Z			22-12-41	ALL
S/R		W3399	2003Z			22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43399J		**AB1050R/298/R009**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	S/R		W3399	2004Z			22-12-41	ALL
	S/R		W3399	2005Z			22-12-41	ALL
	S/R		W3399	2006Z			22-12-41	ALL
	S/R		W3399	2007Z			22-12-41	ALL
	S/R		W3399	2008Z			27-24-11	ALL
	S/R		W3399	2009Z			27-24-11	ALL
	S/R		W3399	2011Z			27-32-31	ALL
	S/R		W3399	3001Z			22-12-41	ALL
	S/R		W3399	3002Z			22-12-41	ALL
	S/R		W3399	3003Z			22-12-41	ALL
	S/R		W3399	3005Z			27-24-11	ALL
D43399P		**AB1050R/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1		W3379	1002	20		22-12-41	ALL
	2		W3379	0002	20		SPARE	ALL
	3		W3379	2002R	22		22-12-41	ALL
	4		W3379	2002B	22		22-12-41	ALL
	5		W3379	2004R	22		22-12-41	ALL
	6		W3379	2004B	22		22-12-41	ALL
	7		W3379	2003R	22		22-12-41	ALL
	8		W3379	2003B	22		22-12-41	ALL
	9		W3379	2005R	20		22-12-41	ALL
	10		W3379	2005B	20		22-12-41	ALL
	11		W3379	2006R	22		22-12-41	ALL
	12		W3379	2006B	22		22-12-41	ALL
	13		W3379	2007R	22		22-12-41	ALL
	14		W3379	2007B	22		22-12-41	ALL
	15		W3379	3001R	22		22-12-41	ALL
	16		W3379	3001B	22		22-12-41	ALL
	17		W3379	3001Y	22		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43399P	**AB1050R/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
18		W3379	2017R	22		22-12-41	ALL
19		W3379	2017B	22		22-12-41	ALL
20		W3379	3003B	22		22-12-41	ALL
21		W3379	3003R	22		22-12-41	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32		W3379	0011	20		22-11-12	ALL
33		W3379	0012	20		22-11-12	ALL
34		W3379	1001	20		22-12-41	ALL
35	UNUSED						ALL
36		W3379	2010R	22		SPARE	ALL
37		W3379	3003Y	22		22-12-41	ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41		W3379	2009R	22		27-24-11	ALL
42		W3379	2009B	22		27-24-11	ALL
43		W3379	2008R	22		27-24-11	ALL
44		W3379	2008B	22		27-24-11	ALL
45		W3379	3005R	20		27-24-11	ALL
46		W3379	3005B	20		27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43399P		**AB1050R/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	47		W3379	3005Y	20		27-24-11	ALL
	48		W3379	1009	20		27-24-11	ALL
	49		W3379	0003	20		27-24-11	ALL
	50	UNUSED						ALL
	51		W3379	2011R	20		27-32-31	ALL
	52		W3379	2011B	20		27-32-31	ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55		W3379	2010B	22		SPARE	ALL
	S/R		W3379	1001Z			22-12-41	ALL
	S/R		W3379	1002Z			22-12-41	ALL
	S/R		W3379	1009Z			27-24-11	ALL
	S/R		W3379	2002Z			22-12-41	ALL
	S/R		W3379	2003Z			22-12-41	ALL
	S/R		W3379	2004Z			22-12-41	ALL
	S/R		W3379	2005Z			22-12-41	ALL
	S/R		W3379	2006Z			22-12-41	ALL
	S/R		W3379	2007Z			22-12-41	ALL
	S/R		W3379	2008Z			27-24-11	ALL
	S/R		W3379	2009Z			27-24-11	ALL
	S/R		W3379	2010Z			SPARE	ALL
	S/R		W3379	2011Z			27-32-31	ALL
	S/R		W3379	2017Z			22-12-41	ALL
	S/R		W3379	3001Z			22-12-41	ALL
	S/R		W3379	3003Z			22-12-41	ALL
	S/R		W3379	3005Z			27-24-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43400J	**727A+10/288/L044**		**RCPT-**				**ALL**
1		W6134	0527	20		27-53-11	ALL
2		W6134	0528	20		27-53-11	ALL
3		W6134	0529	20		27-53-11	ALL
4		W6134	0521	20		27-81-51	ALL
5		W6134	0522	20		27-81-51	ALL
6		W6134	0523	20		27-81-51	ALL
7		W6134	0524	20		27-81-51	ALL
8		W6134	0518	20		27-53-11	ALL
9		W6134	0520	20		27-53-11	ALL
10		W6134	0526	22		29-35-11	ALL
11		W6134	0525	24		29-31-11	ALL
12		W6134	0543	22		27-23-11	ALL
13		W6134	0536	22		27-23-11	ALL
14		W6134	0534	22		27-23-14	ALL
15		W6134	0512	20		27-31-37	ALL
16		W6134	0538	20		27-53-12	ALL
17		W6134	0539	20		27-53-12	ALL
18	18	W6134	0547	18		27-31-11	ALL
19		W6134	3001Z			31-31-14	ALL
20		W6134	0552	20		27-31-37	ALL
21		W6134	0511	20		27-31-37	ALL
22		W6134	3001R	20		31-31-14	ALL
23		W6134	3001B	20		31-31-14	ALL
24		W6134	3001Y	20		31-31-14	ALL
D43400P	**727A+10/288/L044**		**PLUG-**				**ALL**
1		W6124	0509	20		27-53-11	ALL
2		W6124	0510	20		27-53-11	ALL
3		W6124	0511	20		27-53-11	ALL
4		W6124	0545	20		27-81-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43400P		**727A+10/288/L044**		**PLUG- (continued)**				**ALL**
	5		W6124	0546	20		27-81-51	ALL
	6		W6124	0578	20		27-81-51	ALL
	7		W6124	0579	20		27-81-51	ALL
	8		W6124	0575	20		27-53-11	ALL
	9		W6124	0577	20		27-53-11	ALL
	10		W6124	0581	20		29-35-11	ALL
	11		W6124	0580	22		29-31-11	ALL
	12		W6124	0504	22		27-23-11	ALL
	13		W6124	0505	22		27-23-11	ALL
	14		W6124	0503	22		27-23-14	ALL
	15		W6124	0564	24		27-31-37	ALL
	16		W6124	0518	20		27-53-12	ALL
	17		W6124	0519	20		27-53-12	ALL
	18		W6124	0507	20		27-31-11	ALL
	19		W6124	3001Z			31-31-14	ALL
	20		W6124	0563	20		27-31-37	ALL
	21		W6124	0562	24		27-31-37	ALL
	22		W6124	3001R	20		31-31-14	ALL
	23		W6124	3001B	20		31-31-14	ALL
	24		W6124	3001Y	20		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43714J	**ORSS/ /**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W1028	3002B	20		27-61-48	ALL
27		W1028	3002Y	20		27-61-48	ALL
28		W1028	3002R	20		27-61-48	ALL
29		W1028	2004B	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43714J		**ORSS/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	30		W1028	2004R	20		27-61-48	ALL
	31		W1028	2003B	20		27-61-48	ALL
	32		W1028	2003R	20		27-61-48	ALL
	33		W1028	3001B	20		27-61-48	ALL
	34		W1028	3001Y	20		27-61-48	ALL
	35		W1028	3001R	20		27-61-48	ALL
	36		W1028	2002B	20		27-61-48	ALL
	37		W1028	2002R	20		27-61-48	ALL
	38		W1028	2001B	20		27-61-48	ALL
	39		W1028	2001R	20		27-61-48	ALL
	PERB		W1028	2001Z			27-61-48	ALL
	PERB		W1028	2002Z			27-61-48	ALL
	PERB		W1028	2003Z			27-61-48	ALL
	PERB		W1028	2004Z			27-61-48	ALL
	PERB		W1028	3001Z			27-61-48	ALL
	PERB		W1028	3002Z			27-61-48	ALL
D43714P		**ORSS248/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43714P	**ORSS248/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W2028	3002B	20		27-61-48	ALL
27		W2028	3002Y	20		27-61-48	ALL
28		W2028	3002R	20		27-61-48	ALL
29		W2028	2004B	20		27-61-48	ALL
30		W2028	2004R	20		27-61-48	ALL
31		W2028	2003B	20		27-61-48	ALL
32		W2028	2003R	20		27-61-48	ALL
33		W2028	3001B	20		27-61-48	ALL
34		W2028	3001Y	20		27-61-48	ALL
35		W2028	3001R	20		27-61-48	ALL
36		W2028	2002B	20		27-61-48	ALL
37		W2028	2002R	20		27-61-48	ALL
38		W2028	2001B	20		27-61-48	ALL
39		W2028	2001R	20		27-61-48	ALL
PERB		W2028	2001Z			27-61-48	ALL
PERB		W2028	2002Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43714P		**ORSS248/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	PERB		W2028	2003Z			27-61-48	ALL
	PERB		W2028	2004Z			27-61-48	ALL
	PERB		W2028	3001Z			27-61-48	ALL
	PERB		W2028	3002Z			27-61-48	ALL
D43716J		**727/186/L034**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3028	2001R	22		27-61-48	ALL
	2		W3028	2001B	22		27-61-48	ALL
	3		W3028	2002R	22		27-61-48	ALL
	4		W3028	2002B	22		27-61-48	ALL
	5		W3028	3001R	22		27-61-48	ALL
	6		W3028	3001Y	22		27-61-48	ALL
	7		W3028	3001B	22		27-61-48	ALL
	8		W3028	2003R	22		27-61-48	ALL
	9		W3028	2003B	22		27-61-48	ALL
	10		W3028	2004R	22		27-61-48	ALL
	11		W3028	2004B	22		27-61-48	ALL
	12		W3028	3002R	22		27-61-48	ALL
	13		W3028	3002Y	22		27-61-48	ALL
	14		W3028	3002B	22		27-61-48	ALL
	S/R		W3028	2001Z			27-61-48	ALL
	S/R		W3028	2002Z			27-61-48	ALL
	S/R		W3028	2003Z			27-61-48	ALL
	S/R		W3028	2004Z			27-61-48	ALL
	S/R		W3028	3001Z			27-61-48	ALL
	S/R		W3028	3002Z			27-61-48	ALL
D43716P		**727/186/L034**		**PLUG-CONDUCTIVE**				**ALL**
	1		W2028	2001R	20		27-61-48	ALL
	2		W2028	2001B	20		27-61-48	ALL
	3		W2028	2002R	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43716P	**727/186/L034**		**PLUG-CONDUCTIVE (continued)**				**ALL**
4		W2028	2002B	20		27-61-48	ALL
5		W2028	3001R	20		27-61-48	ALL
6		W2028	3001Y	20		27-61-48	ALL
7		W2028	3001B	20		27-61-48	ALL
8		W2028	2003R	20		27-61-48	ALL
9		W2028	2003B	20		27-61-48	ALL
10		W2028	2004R	20		27-61-48	ALL
11		W2028	2004B	20		27-61-48	ALL
12		W2028	3002R	20		27-61-48	ALL
13		W2028	3002Y	20		27-61-48	ALL
14		W2028	3002B	20		27-61-48	ALL
S/R		W2028	2001Z			27-61-48	ALL
S/R		W2028	2002Z			27-61-48	ALL
S/R		W2028	2003Z			27-61-48	ALL
S/R		W2028	2004Z			27-61-48	ALL
S/R		W2028	3001Z			27-61-48	ALL
S/R		W2028	3002Z			27-61-48	ALL
D43717J	**E006-03/*/***		**RCPT-**				**ALL**
1		W0631	0080	24		44-35-12	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43717J		**E006-03/*/***		**RCPT- (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43717J	**E006-03/*/***		**RCPT- (continued)**				**ALL**
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
D43717P	**E006-03/*/***		**PLUG**				**ALL**
1		W4479	0001	24		44-35-12	ALL
2	UNUSED						ALL
3		W4479	0003	24		44-35-12	ALL
4		W4479	0004	24		44-35-12	ALL
5		W4479	0005	24		44-35-12	ALL
6		W4479	0006	24		44-35-12	ALL
7		W4479	0007	24		44-35-12	ALL
8		W4479	0008	24		44-35-12	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43717P		**E006-03/*/***		**PLUG (continued)**				**ALL**
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43717P	**E006-03/*/***		**PLUG (continued)**				**ALL**
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
D43718J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0325	2267R	22		27-61-48	ALL
A02		W0325	2267B	22		27-61-48	ALL
A03		W0325	2268R	22		27-61-48	ALL
A04		W0325	2268B	22		27-61-48	ALL
A05		W0325	3028R	22		27-61-48	ALL
A06		W0325	3028Y	22		27-61-48	ALL
A07		W0325	3028B	22		27-61-48	ALL
A08		W0325	2269R	22		27-61-48	ALL
A09		W0325	2269B	22		27-61-48	ALL
A10		W0325	2270R	22		27-61-48	ALL
B01		W0325	2270B	22		27-61-48	ALL
B02		W0325	3029R	22		27-61-48	ALL
B03		W0325	3029Y	22		27-61-48	ALL
B04		W0325	3029B	22		27-61-48	ALL
B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43718J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0325	2267Z			27-61-48	ALL
	PERG	1F	W0325	2268Z			27-61-48	ALL
	PERG	1F	W0325	2269Z			27-61-48	ALL
	PERG	1F	W0325	2270Z			27-61-48	ALL
	PERG	1F	W0325	3028Z			27-61-48	ALL
	PERG	1F	W0325	3029Z			27-61-48	ALL
D43718P		**AE0302A/ /**		**PLUG**				**ALL**
	A01		W3028	2001R	22		27-61-48	ALL
	A02		W3028	2001B	22		27-61-48	ALL
	A03		W3028	2002R	22		27-61-48	ALL
	A04		W3028	2002B	22		27-61-48	ALL
	A05		W3028	3001R	22		27-61-48	ALL
	A06		W3028	3001Y	22		27-61-48	ALL
	A07		W3028	3001B	22		27-61-48	ALL
	A08		W3028	2003R	22		27-61-48	ALL
	A09		W3028	2003B	22		27-61-48	ALL
	A10		W3028	2004R	22		27-61-48	ALL
	B01		W3028	2004B	22		27-61-48	ALL
	B02		W3028	3002R	22		27-61-48	ALL
	B03		W3028	3002Y	22		27-61-48	ALL
	B04		W3028	3002B	22		27-61-48	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43718P		**AE0302A/ /**		**PLUG (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W3028	2001Z			27-61-48	ALL
	PERG	1F	W3028	2002Z			27-61-48	ALL
	PERG	1F	W3028	2003Z			27-61-48	ALL
	PERG	1F	W3028	2004Z			27-61-48	ALL
	PERG	1F	W3028	3001Z			27-61-48	ALL
	PERG	1F	W3028	3002Z			27-61-48	ALL
D43722J		**ORSS250/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43722J		**ORSS250/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W1042	3002B	20		27-61-48	ALL
	27		W1042	3002Y	20		27-61-48	ALL
	28		W1042	3002R	20		27-61-48	ALL
	29		W1042	2004B	20		27-61-48	ALL
	30		W1042	2004R	20		27-61-48	ALL
	31		W1042	2003B	20		27-61-48	ALL
	32		W1042	2003R	20		27-61-48	ALL
	33		W1042	3001B	20		27-61-48	ALL
	34		W1042	3001Y	20		27-61-48	ALL
	35		W1042	3001R	20		27-61-48	ALL
	36		W1042	2002B	20		27-61-48	ALL
	37		W1042	2002R	20		27-61-48	ALL
	38		W1042	2001B	20		27-61-48	ALL
	39		W1042	2001R	20		27-61-48	ALL
	PERB		W1042	2001Z			27-61-48	ALL
	PERB		W1042	2002Z			27-61-48	ALL
	PERB		W1042	2003Z			27-61-48	ALL
	PERB		W1042	2004Z			27-61-48	ALL
	PERB		W1042	3001Z			27-61-48	ALL
	PERB		W1042	3002Z			27-61-48	ALL
D43722P		**ORSS248/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43722P	**ORSS248/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W2042	3002B	20		27-61-48	ALL
27		W2042	3002Y	20		27-61-48	ALL
28		W2042	3002R	20		27-61-48	ALL
29		W2042	2004B	20		27-61-48	ALL
30		W2042	2004R	20		27-61-48	ALL
31		W2042	2003B	20		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43722P		**ORSS248/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	32		W2042	2003R	20		27-61-48	ALL
	33		W2042	3001B	20		27-61-48	ALL
	34		W2042	3001Y	20		27-61-48	ALL
	35		W2042	3001R	20		27-61-48	ALL
	36		W2042	2002B	20		27-61-48	ALL
	37		W2042	2002R	20		27-61-48	ALL
	38		W2042	2001B	20		27-61-48	ALL
	39		W2042	2001R	20		27-61-48	ALL
	PERB		W2042	2001Z			27-61-48	ALL
	PERB		W2042	2002Z			27-61-48	ALL
	PERB		W2042	2003Z			27-61-48	ALL
	PERB		W2042	2004Z			27-61-48	ALL
	PERB		W2042	3001Z			27-61-48	ALL
	PERB		W2042	3002Z			27-61-48	ALL
D43724J		**727+3/193/R032**		**RCPT-CONDUCTIVE**				**ALL**
	1		W3042	2001R	22		27-61-48	ALL
	2		W3042	2001B	22		27-61-48	ALL
	3		W3042	2002R	22		27-61-48	ALL
	4		W3042	2002B	22		27-61-48	ALL
	5		W3042	3001R	22		27-61-48	ALL
	6		W3042	3001Y	22		27-61-48	ALL
	7		W3042	3001B	22		27-61-48	ALL
	8		W3042	2003R	22		27-61-48	ALL
	9		W3042	2003B	22		27-61-48	ALL
	10		W3042	2004R	22		27-61-48	ALL
	11		W3042	2004B	22		27-61-48	ALL
	12		W3042	3002R	22		27-61-48	ALL
	13		W3042	3002Y	22		27-61-48	ALL
	14		W3042	3002B	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43724J	**727+3/193/R032**		**RCPT-CONDUCTIVE (continued)**				**ALL**
S/R		W3042	2001Z			27-61-48	ALL
S/R		W3042	2002Z			27-61-48	ALL
S/R		W3042	2003Z			27-61-48	ALL
S/R		W3042	2004Z			27-61-48	ALL
S/R		W3042	3001Z			27-61-48	ALL
S/R		W3042	3002Z			27-61-48	ALL
D43724P	**727/193/R033**		**PLUG-CONDUCTIVE**				**ALL**
1		W2042	2001R	20		27-61-48	ALL
2		W2042	2001B	20		27-61-48	ALL
3		W2042	2002R	20		27-61-48	ALL
4		W2042	2002B	20		27-61-48	ALL
5		W2042	3001R	20		27-61-48	ALL
6		W2042	3001Y	20		27-61-48	ALL
7		W2042	3001B	20		27-61-48	ALL
8		W2042	2003R	20		27-61-48	ALL
9		W2042	2003B	20		27-61-48	ALL
10		W2042	2004R	20		27-61-48	ALL
11		W2042	2004B	20		27-61-48	ALL
12		W2042	3002R	20		27-61-48	ALL
13		W2042	3002Y	20		27-61-48	ALL
14		W2042	3002B	20		27-61-48	ALL
S/R		W2042	2001Z			27-61-48	ALL
S/R		W2042	2002Z			27-61-48	ALL
S/R		W2042	2003Z			27-61-48	ALL
S/R		W2042	2004Z			27-61-48	ALL
S/R		W2042	3001Z			27-61-48	ALL
S/R		W2042	3002Z			27-61-48	ALL
D43726J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0326	2275R	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43726J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A02		W0326	2275B	22		27-61-48	ALL
	A03		W0326	2276R	22		27-61-48	ALL
	A04		W0326	2276B	22		27-61-48	ALL
	A05		W0326	3032R	22		27-61-48	ALL
	A06		W0326	3032Y	22		27-61-48	ALL
	A07		W0326	3032B	22		27-61-48	ALL
	A08		W0326	2277R	22		27-61-48	ALL
	A09		W0326	2277B	22		27-61-48	ALL
	A10		W0326	2278R	22		27-61-48	ALL
	B01		W0326	2278B	22		27-61-48	ALL
	B02		W0326	3033R	22		27-61-48	ALL
	B03		W0326	3033Y	22		27-61-48	ALL
	B04		W0326	3033B	22		27-61-48	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0326	2275Z			27-61-48	ALL
	PERG	1F	W0326	2276Z			27-61-48	ALL
	PERG	1F	W0326	2277Z			27-61-48	ALL
	PERG	1F	W0326	2278Z			27-61-48	ALL
	PERG	1F	W0326	3032Z			27-61-48	ALL
	PERG	1F	W0326	3033Z			27-61-48	ALL
D43726P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W3042	2001R	22		27-61-48	ALL
	A02		W3042	2001B	22		27-61-48	ALL
	A03		W3042	2002R	22		27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43726P	**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A04		W3042	2002B	22		27-61-48	ALL
A05		W3042	3001R	22		27-61-48	ALL
A06		W3042	3001Y	22		27-61-48	ALL
A07		W3042	3001B	22		27-61-48	ALL
A08		W3042	2003R	22		27-61-48	ALL
A09		W3042	2003B	22		27-61-48	ALL
A10		W3042	2004R	22		27-61-48	ALL
B01		W3042	2004B	22		27-61-48	ALL
B02		W3042	3002R	22		27-61-48	ALL
B03		W3042	3002Y	22		27-61-48	ALL
B04		W3042	3002B	22		27-61-48	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W3042	2001Z			27-61-48	ALL
PERG	1F	W3042	2002Z			27-61-48	ALL
PERG	1F	W3042	2003Z			27-61-48	ALL
PERG	1F	W3042	2004Z			27-61-48	ALL
PERG	1F	W3042	3001Z			27-61-48	ALL
PERG	1F	W3042	3002Z			27-61-48	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43876J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0226R	22		26-11-21	ALL
	A02		W0088	0227R	22		26-11-21	ALL
	A03		W0088	0218R	22		26-11-21	ALL
	A04		W0088	0239R	20		26-11-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0088	2510R	20		36-11-12	ALL
	B01		W0088	0219R	22		26-11-21	ALL
	B02		W0088	0220R	22		26-11-21	ALL
	B03		W0088	0221R	22		26-11-21	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0088	2510B	20		36-11-12	ALL
	PERG	1F	W0088	2510Z			36-11-12	ALL
D43876P		**AJ0048A/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5610	6033R	22		26-11-21	ALL
	A02		W5610	6028R	22		26-11-21	ALL
	A03		W5610	6029R	22		26-11-21	ALL
	A04		W5610	6058R	20		26-11-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43876P		**AJ0048A/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5610	2510R	20		36-11-12	ALL
	B01		W5610	6030R	22		26-11-21	ALL
	B02		W5610	6031R	22		26-11-21	ALL
	B03		W5610	6032R	22		26-11-21	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5610	2510B	20		36-11-12	ALL
	PERG	1F	W5610	2510Z			36-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43900J		**J039-0A/ /**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0082	0074	22		27-33-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0082	0079	22		27-33-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D43900P		**AJ0039A/ /**		**INSERT - SOCKET**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5506	0076	22		27-33-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43900P	**AJ0039A/ /**		**INSERT - SOCKET (continued)**				**ALL**
12	UNUSED						ALL
13	UNUSED						ALL
14		W5506	0077	22		27-33-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
D43902J	**AJ0039A/ /**		**INSERT**				**ALL**
1		W0082	0139	20		27-62-11	ALL
2		W0082	0140	20		27-62-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0082	0078	22		27-33-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0082	0144	22		27-61-45	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0082	0145	22		27-61-45	ALL
D43902P	**AJ0039A/ /**		**INSERT**				**ALL**
1		W5156	0110	20		27-62-11	ALL
2		W5156	0111	20		27-62-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43902P		**AJ0039A/ /**		**INSERT (continued)**				**ALL**
	5		W5156	0721	22		27-61-49	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5156	0117	22		27-61-41	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5156	0118	22		27-61-45	ALL
D43904J		**AJ0039A/ /**		**INSERT**				**ALL**
	1		W0082	0142	22		27-61-45	ALL
	2		W0082	0252	22		22-11-31	ALL
	3	UNUSED						ALL
	4		W0082	0122	22		27-61-49	ALL
	5		W0082	0150	20		27-61-49	ALL
	6		W0082	0128	20		27-61-49	ALL
	7		W0082	0130	22		27-61-49	ALL
	8		W0082	0131	22		27-61-49	ALL
	9	UNUSED						ALL
	10		W0082	0124	20		27-61-49	ALL
	11		W0082	0146	22		27-33-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43904J	**AJ0039A/ /**		**INSERT (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
D43904P	**AJ0039A/ /**		**INSERT**				**ALL**
1		W5158	0711	22		27-61-45	ALL
2		W5158	0217	22		22-11-31	ALL
3	UNUSED						ALL
4		W5158	0715	22		27-61-49	ALL
5		W5158	0716	20		27-61-49	ALL
6		W5158	0717	20		27-61-49	ALL
7		W5158	0718	22		27-61-49	ALL
8		W5158	0719	22		27-61-49	ALL
9	UNUSED						ALL
10		W5158	0714	20		27-61-49	ALL
11		W5158	0310	22		27-31-37	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43904P		**AJ0039A/ /**		**INSERT (continued)**				**ALL**
	22	UNUSED						ALL
D43906J		**J039-0A/ /**		**INSERT**				**ALL**
	1		W0082	0136	20		27-62-11	ALL
	2	UNUSED						ALL
	3		W0082	0132	20		27-62-11	ALL
	4	UNUSED						ALL
	5		W0082	0147	20		27-23-11	ALL
	6		W0082	0148	22		27-23-11	ALL
	7		W0082	0149	22		27-23-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0082	0137	20		27-62-11	ALL
	12	UNUSED						ALL
	13		W0082	0133	20		27-62-11	ALL
	14		W0082	1101	22		27-33-11	ALL
	15	UNUSED						ALL
	16		W0082	1102	22		27-33-11	ALL
	17		W0082	0109	22		27-33-11	ALL
	18		W0082	1101Z			27-33-11	ALL
	19		W0082	1102Z			27-33-11	ALL
	20		W0082	0084	22		27-33-11	ALL
	21		W0082	0093	22		27-33-11	ALL
	22		W0082	0096	22		27-33-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0082	0129	22		27-61-49	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43906J	**J039-0A/ /**		**INSERT (continued)**				**ALL**
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
D43906P	**AJ0039A/ /**		**PLUG**				**ALL**
1		W5160	0023	22		27-62-11	ALL
2	UNUSED						ALL
3		W5160	0171	20		27-62-11	ALL
4	UNUSED						ALL
5		W5160	0309	20		27-23-11	ALL
6		W5160	0310	22		27-23-11	ALL
7		W5160	0311	22		27-23-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W5160	0174	20		27-62-11	ALL
12	UNUSED						ALL
13		W5160	0172	20		27-62-11	ALL
14		W5160	1004	22		27-33-11	ALL
15	UNUSED						ALL
16		W5160	1003	22		27-33-11	ALL
17		W5160	0126	22		27-33-11	ALL
18		W5160	1004Z			27-33-11	ALL
19		W5160	1003Z			27-33-11	ALL
20		W5160	0122	22		27-33-11	ALL
21		W5160	0124	22		27-33-11	ALL
22		W5160	0123	22		27-33-11	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W5160	0719	22		27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43906P		**AJ0039A/ /**		**PLUG (continued)**				**ALL**
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
D43922J		**AJ0039B/ /**		**CONNECTOR RECEPTACLE**				**ALL**
	A01		W0084	2003R	24		23-42-14	ALL
	A02		W0084	2004R	24		23-42-14	ALL
	A03		W0084	0059	24		23-42-14	ALL
	A04		W0084	0060	24		23-42-14	ALL
	A05	UNUSED						ALL
	A06		W0084	0110	24		23-15-15	ALL
	A07		W0084	0001	22		32-31-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0084	2003B	24		23-42-14	ALL
	B02		W0084	2004B	24		23-42-14	ALL
	B03	UNUSED						ALL
	B04		W0084	0058	24		23-42-14	ALL
	B05	UNUSED						ALL
	B06		W0084	0090	22		46-13-52	ALL
	B07		W0084	0002	22		32-31-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W0084	2003Z			23-42-14	ALL
			W0084	2004Z			23-42-14	ALL
			W0084	FRAC			23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43922J		**AJ0039B/ /**		**CONNECTOR RECEPTACLE (continued)**				**ALL**
	PERG	1F	W0084	FRAC			23-42-14	ALL
D43922P		**AJ0039B/ /**		**CONNECTOR PLUG**				**ALL**
	A01		W3058	2021R	24		23-42-14	ALL
	A02		W3058	2022R	24		23-42-14	ALL
	A03		W3058	0191	22		23-42-14	ALL
	A04		W3058	0190	22		23-42-14	ALL
	A05	UNUSED						ALL
	A06		W3058	0581	24		23-15-15	ALL
	A07		W3058	0447	22		32-31-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W3058	2021B	24		23-42-14	ALL
	B02		W3058	2022B	24		23-42-14	ALL
	B03	UNUSED						ALL
	B04		W3058	0189	24		23-42-14	ALL
	B05	UNUSED						ALL
	B06		W3058	0541	22		46-13-52	ALL
	B07		W3058	0448	22		32-31-12	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W3058	2021Z			23-42-14	ALL
			W3058	2022Z			23-42-14	ALL
			W3058	FRAB			23-42-14	ALL
	PERG	1F	W3058	FRAB			23-42-14	ALL
D43924J		**AJ0039B/ /**		**CONNECTOR RECEPTACLE**				**ALL**
	A01		W0084	2001R	24		23-42-14	ALL
	A02		W0084	2002R	24		23-42-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43924J		**AJ0039B/ /**		**CONNECTOR RECEPTACLE (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0084	2001B	24		23-42-14	ALL
	B02		W0084	2002B	24		23-42-14	ALL
	B03		W0084	0058	24		23-42-14	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W0084	2001Z			23-42-14	ALL
			W0084	2002Z			23-42-14	ALL
			W0084	FRAA			23-42-14	ALL
	PERG	1F	W0084	FRAA			23-42-14	ALL
D43924P		**AJ0039B/ /**		**CONNECTOR PLUG**				**ALL**
	A01		W6212	2001R	24		23-42-14	ALL
	A02		W6212	2002R	24		23-42-14	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43924P		**AJ0039B/ /**		**CONNECTOR PLUG (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6212	2001B	24		23-42-14	ALL
	B02		W6212	2002B	24		23-42-14	ALL
	B03		W6212	0007	24		23-42-14	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
			W6212	2001Z			23-42-14	ALL
			W6212	2002Z			23-42-14	ALL
			W6212	FRAB			23-42-14	ALL
	PERG	1F	W6212	FRAB			23-42-14	ALL
D43927J		**228/198/R014**		**RCPT-**				**ALL**
	A		W5373	0005	20		22-11-12	ALL
	B		W5373	0006	20		22-11-12	ALL
	C		W5373	0007	20		22-11-12	ALL
	D		W5373	0008	20		22-11-12	ALL
D43927P		**226/198/R014**		**PLUG**				**ALL**
	A		W0445	0027Y	20		22-11-12	ALL
	B		W0445	0028G	20		22-11-12	ALL
	C		W0445	0037KB	20		22-11-12	ALL
	D		W0445	0038N	20		22-11-12	ALL
	CAP	Y	W0445	0022K	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D43927P		**226/198/R014**		**PLUG (continued)**				**ALL**
	CAP	Y	W0445	0033KG	20		SPARE	ALL
	CAP	Y	W0445	0034KY	20		SPARE	ALL
	CAP	Y	W0445	0035RN	20		SPARE	ALL
	CAP	Y	W0445	0036ON	20		SPARE	ALL
	CAP	Y	W0445	0039KV	20		SPARE	ALL
	CAP	Y	W0445	0061	20		SPARE	ALL
	CAP	Y	W0445	0062	20		SPARE	ALL
D43928J		**229/198/L013**		**RCPT-**				**ALL**
	A		W5374	0005	20		22-11-12	ALL
	B		W5374	0006	20		22-11-12	ALL
	C		W5374	0007	20		22-11-12	ALL
	D		W5374	0008	20		22-11-12	ALL
D43928P		**229/198/L013**		**PLUG**				**ALL**
	A		W0443	0008G	20		22-11-12	ALL
	B		W0443	0007Y	20		22-11-12	ALL
	C		W0443	0018N	20		22-11-12	ALL
	D		W0443	0017KB	20		22-11-12	ALL
	CAP	Y	W0443	0002K	20		SPARE	ALL
	CAP	Y	W0443	0013KG	20		SPARE	ALL
	CAP	Y	W0443	0014KY	20		SPARE	ALL
	CAP	Y	W0443	0015RN	20		SPARE	ALL
	CAP	Y	W0443	0016ON	20		SPARE	ALL
	CAP	Y	W0443	0019KV	20		SPARE	ALL
	CAP	Y	W0443	0051	20		SPARE	ALL
	CAP	Y	W0443	0052	20		SPARE	ALL
D43929J		**231/198/L014**		**RCPT-**				**ALL**
	A		W0443	0005B	20		22-14-11	ALL
	B		W0443	0004KA	20		22-14-11	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D43929P		**232/198/L014**		**PLUG**				**ALL**
	A		W5374	0009	20		22-14-11	ALL
	B		W5374	0010	20		22-14-11	ALL
	C	UNUSED						ALL
D43930J		**229/198/R018**		**RCPT-**				**ALL**
	A		W0445	0025B	20		22-14-11	ALL
	B		W0445	0024KA	20		22-14-11	ALL
	C	UNUSED						ALL
D43930P		**229/198/R020**		**PLUG**				**ALL**
	A		W5373	0009	20		22-14-11	ALL
	B		W5373	0010	20		22-14-11	ALL
	C	UNUSED						ALL
D43933J		**232/198/L013**		**RCPT**				**ALL**
	A		W3323	0042	24		23-51-11	ALL
	B		W3323	0045	24		23-51-11	ALL
	C		W3323	0046	24		23-51-11	ALL
D43933P		**231/198/L013**		**PLUG**				**ALL**
	A		W0443	0001A	20		23-51-11	ALL
	B		W0443	0006KR	20		23-51-11	ALL
	C		W0443	0003KN	20		23-51-11	ALL
D43934J		**230/198/R020**		**RCPT**				**ALL**
	A		W3319	0042	24		23-51-21	ALL
	B		W3319	0045	24		23-51-21	ALL
	C		W3319	0046	24		23-51-21	ALL
D43934P		**230/198/R020**		**PLUG**				**ALL**
	A		W0445	0021A	20		23-51-21	ALL
	B		W0445	0026KR	20		23-51-21	ALL
	C		W0445	0023KN	20		23-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D44139J		**E004-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0411	2031R	22		24-41-11	ALL
	A02		W0411	2031B	22		24-41-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0411	2020R	22		23-31-04	ALL
	A06		W0411	2021R	22		23-31-04	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0411	2030R	22		24-41-11	ALL
	B02		W0411	2030B	22		24-41-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0411	2020B	22		23-31-04	ALL
	B06		W0411	2021B	22		23-31-04	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D44139P		**E004-01/ /**		**PLUG**				**ALL**
	A01		W3309	2201R	22		24-41-11	ALL
	A02		W3309	2201B	22		24-41-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W3309	2001R	22		23-31-04	ALL
	A06		W3309	2002R	22		23-31-04	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D44139P		**E004-01/ /**		**PLUG (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W3309	2202R	22		24-41-11	ALL
	B02		W3309	2202B	22		24-41-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W3309	2001B	22		23-31-04	ALL
	B06		W3309	2002B	22		23-31-04	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D44161J		**E004-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0410	2035R	24		21-31-23	ALL
	A06	UNUSED						ALL
	A07		W0410	0535	24		21-51-14	ALL
	A08		W0410	0496	22		34-51-41	ALL
	A09		W0410	0239	24		34-61-17	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0410	2028R	22		34-45-21	ALL
	A13		W0410	2028B	22		34-45-21	ALL
	A14		W0410	2028ZI			34-45-21	ALL
	A15		W0410	0241	22		22-14-11	ALL
	A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D44161J		**E004-01/ /**		**RCPT- (continued)**				**ALL**
	A17		W0410	0487	24		34-61-17	ALL
	A18	UNUSED						ALL
	A19		W0410	0015	22		34-61-17	ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0410	2035B	24		21-31-23	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0410	0252	24		21-51-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0410	2036R	24		21-31-23	ALL
	B15		W0410	0495	24		31-31-17	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0410	2036B	24		21-31-23	ALL
	B19		W0410	0264	22		34-21-12	ALL
	B20	UNUSED						ALL
	PERG	1F	W0410	2028ZO			34-45-21	ALL
	PERG	1F	W0410	2035Z			21-31-23	ALL
	PERG	1F	W0410	2036Z			21-31-23	ALL
D44161P		**E004-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44161P	**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W5461	2130R	24		21-31-23	ALL
A06		W5461	0058	24		SPARE	ALL
A07		W5461	0067	24		21-51-14	ALL
A08		W5461	0012	22		34-51-41	ALL
A09		W5461	0061	24		34-61-17	ALL
A10	UNUSED						ALL
A11		W5461	2018R	24		SPARE	ALL
A12		W5461	2024R	24		34-45-21	ALL
A13		W5461	2024B	24		34-45-21	ALL
A14		W5461	2024ZI			34-45-21	ALL
A15		W5461	0015	22		22-14-11	ALL
A16	UNUSED						ALL
A17		W5461	0063	24		34-61-17	ALL
A18	UNUSED						ALL
A19		W5461	0065	22		34-61-17	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5461	0057	24		SPARE	ALL
B05		W5461	2130B	24		21-31-23	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W5461	0100	24		21-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44161P		**E004-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B11		W5461	2018B	24		SPARE	ALL
	B12		W5461	2029R	24		SPARE	ALL
	B13		W5461	2029B	24		SPARE	ALL
	B14		W5461	2131R	24		21-31-23	ALL
	B15		W5461	0048	24		31-31-17	ALL
	B16		W5461	2030R	24		SPARE	ALL
	B17		W5461	2030B	24		SPARE	ALL
	B18		W5461	2131B	24		21-31-23	ALL
	B19		W5461	0077	22		34-21-12	ALL
	B20	UNUSED						ALL
	PERG	1F	W5461	2018Z			SPARE	ALL
	PERG	1F	W5461	2024ZO			34-45-21	ALL
	PERG	1F	W5461	2029Z			SPARE	ALL
	PERG	1F	W5461	2030Z			SPARE	ALL
	PERG	1F	W5461	2130Z			21-31-23	ALL
	PERG	1F	W5461	2131Z			21-31-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44381J	**AB1050L/297/L014**		**RCPT - CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W3391	1004	20		22-13-11	ALL
5		W3391	1005	20		22-13-11	ALL
6	UNUSED						ALL
7		W3391	1025	20		27-41-12	ALL
8	14	W3391	3002Y	14		27-41-12	ALL
9	14	W3391	3002R	14		27-41-12	ALL
10	14	W3391	3002B	14		27-41-12	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W3391	1023	20		27-41-12	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W3391	1024	20		27-41-12	ALL
19	UNUSED						ALL
S/R		W3391	1004Z			22-13-11	ALL
S/R		W3391	1005Z			22-13-11	ALL
S/R		W3391	1023Z			27-41-12	ALL
S/R		W3391	1024Z			27-41-12	ALL
S/R		W3391	1025Z			27-41-12	ALL
S/R		W3391	3002Z			27-41-12	ALL
D44381P	**AB1050L/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W3381	0006	20		SPARE	ALL
2		W3381	0007	20		SPARE	ALL
3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44381P		**AB1050L/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	4		W3381	0004	20		22-13-11	ALL
	5		W3381	0005	20		22-13-11	ALL
	6	UNUSED						ALL
	7		W3381	0026	20		27-41-12	ALL
	8	14	W3381	3002Y	14		27-41-12	ALL
	9	14	W3381	3002R	14		27-41-12	ALL
	10	14	W3381	3002B	14		27-41-12	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W3381	0025	20		27-41-12	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W3381	0027	20		27-41-12	ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44440J	**J004-00/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W0094	3001R	14		27-41-12	ALL
2		W0094	3001Y	14		27-41-12	ALL
3		W0094	3001B	14		27-41-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
D44440P	**J004-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W3381	3002R	14		27-41-12	ALL
2		W3381	3002Y	14		27-41-12	ALL
3		W3381	3002B	14		27-41-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D44584J		**1166/244/R014**		**RCPT-CONDUCTIVE**				**ALL**
	1		W7150	1201	18		33-35-11	ALL
	2		W7150	1202	18		33-35-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	S/R		W7150	1201Z			33-35-11	ALL
	S/R		W7150	1202Z			33-35-11	ALL
D44584P		**1166/243/R014**		**PLUG-CONDUCTIVE**				**ALL**
	1		W4724	1001	18		33-35-11	ALL
	2		W4724	1002	18		33-35-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	S/R		W4724	1001Z			33-35-11	ALL
	S/R		W4724	1002Z			33-35-11	ALL
D44592J		**1158/280/R020**		**RCPT-CONDUCTIVE**				**ALL**
	1		W4724	1044	18		33-43-11	ALL
	2		W4724	1013	18		33-44-12	ALL
	3		W4724	1041	18		33-43-11	ALL
	4		W4724	1043	18		33-43-11	ALL
	5		W4724	1042	18		33-43-11	ALL
	6		W4724	1014	18		33-44-12	ALL
	7		W4724	1045	18		33-43-11	ALL
	S/R		W4724	1013Z			33-44-12	ALL
	S/R		W4724	1014Z			33-44-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44592J	**1158/280/R020**		**RCPT-CONDUCTIVE (continued)**				**ALL**
S/R		W4724	1041Z			33-43-11	ALL
S/R		W4724	1042Z			33-43-11	ALL
S/R		W4724	1043Z			33-43-11	ALL
S/R		W4724	1044Z			33-43-11	ALL
S/R		W4724	1045Z			33-43-11	ALL
D44592P	**1160/287/R016**		**PLUG-CONDUCTIVE**				**ALL**
1		W7152	3502R	18		33-43-11	ALL
2		W7152	3502Y	18		33-44-12	ALL
3		W7152	3502B	18		33-43-11	ALL
4		W7152	1001	18		33-43-11	ALL
5		W7152	3501B	18		33-43-11	ALL
6		W7152	3501Y	18		33-44-12	ALL
7		W7152	3501R	18		33-43-11	ALL
S/R		W7152	1001Z			33-43-11	ALL
S/R		W7152	3501ZI			33-43-11	ALL
S/R		W7152	3501ZO			33-43-11	ALL
S/R		W7152	3502ZI			33-43-11	ALL
S/R		W7152	3502ZO			33-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44719J		**AB0839L/302/L12**		**RCPT**				**ALL**
	3		W3755	0053	24		44-35-12	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	=C1	UNUSED						ALL
	=C2	UNUSED						ALL
D44719P		**AB0839L/302/L12**		**PLUG**				**ALL**
	3		W4479	0001	24		44-35-12	ALL
	4		W4479	0002	24		44-35-12	ALL
	5		W4479	0003	24		44-35-12	ALL
	6		W4479	0004	24		44-35-12	ALL
	7		W4479	0005	24		44-35-12	ALL
	8		W4479	0006	24		44-35-12	ALL
	9		W4479	0007	24		44-35-12	ALL
	10		W4479	0008	24		44-35-12	ALL
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D44719P		**AB0839L/302/L12**		**PLUG (continued)**				**ALL**
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	=C1	UNUSED						ALL
	=C2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45001J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5602	0005	24		31-31-17	ALL
	A04	UNUSED						ALL
	A05		W5602	0016	24		23-15-15	ALL
	A06		W5602	2506R	24		23-15-15	ALL
	A07		W5602	2507R	22		31-32-15	ALL
	A08	UNUSED						ALL
	A09		W5602	2508R	24		23-15-15	ALL
	A10	UNUSED						ALL
	A11		W5602	2511R	24		34-61-23	ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W5602	2509R	24		34-53-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5602	0004	24		31-31-17	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5602	2506B	24		23-15-15	ALL
	B07		W5602	2507B	22		31-32-15	ALL
	B08	UNUSED						ALL
	B09		W5602	2508B	24		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45001J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B10	UNUSED						ALL
B11		W5602	2511B	24		34-61-23	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W5602	2509B	24		34-53-11	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5602	2506Z			23-15-15	ALL
PERG	1F	W5602	2507Z			31-32-15	ALL
PERG	1F	W5602	2508Z			23-15-15	ALL
PERG	1F	W5602	2509Z			34-53-11	ALL
PERG	1F	W5602	2511Z			34-61-23	ALL
D45001P	**E005-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0521	0254	24		31-31-17	ALL
A04	UNUSED						ALL
A05		W0521	0250	24		23-15-15	ALL
A06		W0521	2672R	24		23-15-15	ALL
A07		W0521	2657R	22		31-32-15	ALL
A08	UNUSED						ALL
A09		W0521	2671R	24		23-15-15	ALL
A10	UNUSED						ALL
A11		W0523	2806R	24		34-61-23	ALL
A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45001P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A13	UNUSED						ALL
	A14		W0521	2940R	24		34-53-11	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0521	0253	24		31-31-17	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0521	2672B	24		23-15-15	ALL
	B07		W0521	2657B	22		31-32-15	ALL
	B08	UNUSED						ALL
	B09		W0521	2671B	24		23-15-15	ALL
	B10	UNUSED						ALL
	B11		W0523	2806B	24		34-61-23	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0521	2940B	24		34-53-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2657Z			31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45001P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
PERG	1F	W0521	2671Z			23-15-15	ALL
PERG	1F	W0521	2672Z			23-15-15	ALL
PERG	1F	W0521	2940Z			34-53-11	ALL
PERG	1F	W0523	2806Z			34-61-23	ALL
D45067J	**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W2135	0046	24		34-61-26	ALL
A02		W2135	2509R	24		34-61-26	ALL
A03		W2135	2508R	24		34-61-18	ALL
A04		W2135	2511R	24		22-11-53	ALL
A05		W2135	0047	24		22-11-53	ALL
A06		W2135	0048	24		22-11-53	ALL
A07		W2135	0049	24		22-11-53	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2135	0045	24		34-61-18	ALL
B02		W2135	2509B	24		34-61-26	ALL
B03		W2135	2508B	24		34-61-18	ALL
B04		W2135	2511B	24		22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45067J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2135	2508Z			34-61-18	ALL
	PERG	1F	W2135	2509Z			34-61-26	ALL
	PERG	1F	W2135	2511Z			22-11-53	ALL
D45067P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0523	0374	24		34-61-26	ALL
	A02		W0523	2832R	24		34-61-26	ALL
	A03		W0523	2717R	24		34-61-18	ALL
	A04		W0523	2834R	24		22-11-53	ALL
	A05		W0523	0391	24		22-11-53	ALL
	A06		W0523	0392	24		22-11-53	ALL
	A07		W0523	0393	24		22-11-53	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45067P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0523	0325	24		34-61-18	ALL
	B02		W0523	2832B	24		34-61-26	ALL
	B03		W0523	2717B	24		34-61-18	ALL
	B04		W0523	2834B	24		22-11-53	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45067P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0523	2717Z			34-61-18	ALL
	PERG	1F	W0523	2832Z			34-61-26	ALL
	PERG	1F	W0523	2834Z			22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45102J	**E003-02/ /**		**RCPT-**				**ALL**
A01		W0321	2516R	24		31-31-13	ALL
A02		W0321	2516B	24		31-31-13	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0321	2148R	24		22-11-51	ALL
A06		W0321	2218R	24		34-58-21	ALL
A07		W0321	0985	22		27-61-42	ALL
A08		W0321	0984	22		27-61-42	ALL
A09		W0321	2343R	24		22-11-51	ALL
A10		W0321	2410R	24		22-11-51	ALL
B01		W0321	0638	22		22-11-31	ALL
B02		W0321	0983	22		27-61-42	ALL
B03		W0321	0982	22		27-61-42	ALL
B04	UNUSED						ALL
B05		W0321	2148B	24		22-11-51	ALL
B06		W0321	2218B	24		34-58-21	ALL
B07		W0321	2149R	24		34-53-21	ALL
B08		W0321	2149B	24		34-53-21	ALL
B09		W0321	2343B	24		22-11-51	ALL
B10		W0321	2410B	24		22-11-51	ALL
PERG	1F	W0321	2148Z			22-11-51	ALL
PERG	1F	W0321	2149Z			34-53-21	ALL
PERG	1F	W0321	2218Z			34-58-21	ALL
PERG	1F	W0321	2343Z			22-11-51	ALL
PERG	1F	W0321	2410Z			22-11-51	ALL
PERG	1F	W0321	2516Z			31-31-13	ALL
D45102P	**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5121	2516R	24		31-31-13	ALL
A02		W5121	2516B	24		31-31-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Bundle	Description				
	Term	Type		Wire No.	GA	CO	Diagram	Effectivity
D45102P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5121	2117R	22		22-11-51	ALL
	A06		W5121	2511R	24		34-58-21	ALL
	A07		W5121	0043	22		27-61-42	ALL
	A08		W5121	0042	22		27-61-42	ALL
	A09		W5121	2751R	24		22-11-51	ALL
	A10		W5121	2752R	24		22-11-51	ALL
	B01		W5121	1702	22		22-11-31	ALL
	B02		W5121	0041	22		27-61-42	ALL
	B03		W5121	0040	22		27-61-42	ALL
	B04	UNUSED						ALL
	B05		W5121	2117B	22		22-11-51	ALL
	B06		W5121	2511B	24		34-58-21	ALL
	B07		W5121	2110R	24		34-53-21	ALL
	B08		W5121	2110B	24		34-53-21	ALL
	B09		W5121	2751B	24		22-11-51	ALL
	B10		W5121	2752B	24		22-11-51	ALL
	PERG	1F	W5121	2110Z			34-53-21	ALL
	PERG	1F	W5121	2117Z			22-11-51	ALL
	PERG	1F	W5121	2511Z			34-58-21	ALL
	PERG	1F	W5121	2516Z			31-31-13	ALL
	PERG	1F	W5121	2751Z			22-11-51	ALL
	PERG	1F	W5121	2752Z			22-11-51	ALL
D45111J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	0160	24		34-45-11	ALL
	A02	UNUSED						ALL
	A03		W0311	2096R	24		34-31-11	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45111J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09		W0311	2136R	24		34-45-11	ALL
A10		W0311	2093R	24		34-55-11	ALL
A11	UNUSED						ALL
A12		W0311	2085R	24		31-35-02	ALL
A13		W0311	2091R	24		27-32-12	ALL
A14		W0311	2127R	22		SPARE	ALL
A15		W0311	2092R	24		27-32-12	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0311	2096B	24		34-31-11	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W0311	2136B	24		34-45-11	ALL
B10		W0311	2093B	24		34-55-11	ALL
B11	UNUSED						ALL
B12		W0311	2085B	24		31-35-02	ALL
B13		W0311	2091B	24		27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45111J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B14		W0311	2127B	22		SPARE	ALL
	B15		W0311	2092B	24		27-32-12	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2085Z			31-35-02	ALL
	PERG	1F	W0311	2091Z			27-32-12	ALL
	PERG	1F	W0311	2092Z			27-32-12	ALL
	PERG	1F	W0311	2093Z			34-55-11	ALL
	PERG	1F	W0311	2096Z			34-31-11	ALL
	PERG	1F	W0311	2127Z			SPARE	ALL
	PERG	1F	W0311	2136Z			34-45-11	ALL
D45111P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	0004	24		34-45-11	ALL
	A02	UNUSED						ALL
	A03		W5111	2004R	24		34-31-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W5111	2022R	24		34-45-11	ALL
	A10		W5111	2023R	24		34-55-11	ALL
	A11	UNUSED						ALL
	A12		W5111	2025R	24		31-35-02	ALL
	A13		W5111	2029R	24		27-32-12	ALL
	A14		W5111	2030R	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45111P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A15		W5111	2031R	24		27-32-12	ALL
	A16	UNUSED						ALL
	A17		W5111	2033R	24		SPARE	ALL
	A18		W5111	2043R	24		SPARE	ALL
	A19		W5111	2048R	24		SPARE	ALL
	A20		W5111	2045R	24		SPARE	ALL
	B01	UNUSED						ALL
	B02		W5111	0024	22		SPARE	ALL
	B03		W5111	2004B	24		34-31-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5111	2022B	24		34-45-11	ALL
	B10		W5111	2023B	24		34-55-11	ALL
	B11	UNUSED						ALL
	B12		W5111	2025B	24		31-35-02	ALL
	B13		W5111	2029B	24		27-32-12	ALL
	B14		W5111	2030B	22		SPARE	ALL
	B15		W5111	2031B	24		27-32-12	ALL
	B16	UNUSED						ALL
	B17		W5111	2033B	24		SPARE	ALL
	B18		W5111	2043B	24		SPARE	ALL
	B19		W5111	2048B	24		SPARE	ALL
	B20		W5111	2045B	24		SPARE	ALL
	PERG	1F	W5111	2004Z			34-31-11	ALL
	PERG	1F	W5111	2022Z			34-45-11	ALL
	PERG	1F	W5111	2023Z			34-55-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45111P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5111	2025Z			31-35-02	ALL
	PERG	1F	W5111	2029Z			27-32-12	ALL
	PERG	1F	W5111	2030Z			SPARE	ALL
	PERG	1F	W5111	2031Z			27-32-12	ALL
	PERG	1F	W5111	2033Z			SPARE	ALL
	PERG	1F	W5111	2043Z			SPARE	ALL
	PERG	1F	W5111	2045Z			SPARE	ALL
	PERG	1F	W5111	2048Z			SPARE	ALL
D45113J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0072	22		22-11-18	ALL
	A02		W0111	0251	22		27-32-11	ALL
	A03		W0111	0063	24		22-11-14	ALL
	A04	UNUSED						ALL
	A05		W0111	2122R	24		34-31-11	ALL
	A06		W0111	2123R	24		34-31-11	ALL
	A07	UNUSED						ALL
	A08		W0111	2334R	24		22-23-12	ALL
	A09		W0111	2127R	24		31-65-12	ALL
	A10		W0111	2128R	24		31-65-15	ALL
	A11		W0111	2129R	24		31-65-15	ALL
	A12		W0111	2068R	24		34-45-11	ALL
	A13		W0111	2051R	24		27-32-12	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0111	0501	22		22-23-11	ALL
	A18	UNUSED						ALL
	A19		W0111	0537	24		27-81-31	ALL
	A20		W0111	0080	22		27-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45113J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02		W0111	0232	24		34-45-11	ALL
	B03		W0111	0250	20		22-23-11	ALL
	B04	UNUSED						ALL
	B05		W0111	2122B	24		34-31-11	ALL
	B06		W0111	2123B	24		34-31-11	ALL
	B07	UNUSED						ALL
	B08		W0111	2334B	24		22-23-12	ALL
	B09		W0111	2127B	24		31-65-12	ALL
	B10		W0111	2128B	24		31-65-15	ALL
	B11		W0111	2129B	24		31-65-15	ALL
	B12		W0111	2068B	24		34-45-11	ALL
	B13		W0111	2051B	24		27-32-12	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0111	0144	22		34-51-41	ALL
	B18	UNUSED						ALL
	B19		W0111	0801	22		27-83-11	ALL
	B20		W0111	0252	22		27-32-11	ALL
	PERG	1F	W0111	2051Z			27-32-12	ALL
	PERG	1F	W0111	2068Z			34-45-11	ALL
	PERG	1F	W0111	2122Z			34-31-11	ALL
	PERG	1F	W0111	2123Z			34-31-11	ALL
	PERG	1F	W0111	2127Z			31-65-12	ALL
	PERG	1F	W0111	2128Z			31-65-15	ALL
	PERG	1F	W0111	2129Z			31-65-15	ALL
	PERG	1F	W0111	2334Z			22-23-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45113P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	0001	22		22-11-18	ALL
	A02		W5111	0003	22		27-32-11	ALL
	A03		W5111	0008	24		22-11-14	ALL
	A04	UNUSED						ALL
	A05		W5111	2001R	24		34-31-11	ALL
	A06		W5111	2002R	24		34-31-11	ALL
	A07	UNUSED						ALL
	A08		W5111	2077R	24		22-23-12	ALL
	A09		W5111	2011R	24		31-65-12	ALL
	A10		W5111	2012R	24		31-65-15	ALL
	A11		W5111	2017R	24		31-65-15	ALL
	A12		W5111	2022R	24		34-45-11	ALL
	A13		W5111	2044R	24		27-32-12	ALL
	A14		W5111	2033R	24		SPARE	ALL
	A15		W5111	2042R	24		SPARE	ALL
	A16	UNUSED						ALL
	A17		W5111	0047	22		22-23-11	ALL
	A18	UNUSED						ALL
	A19		W5111	1702	24		27-81-31	ALL
	A20		W5111	0006	22		27-32-11	ALL
	B01	UNUSED						ALL
	B02		W5111	0004	24		34-45-11	ALL
	B03		W5111	0027	20		22-23-11	ALL
	B04	UNUSED						ALL
	B05		W5111	2001B	24		34-31-11	ALL
	B06		W5111	2002B	24		34-31-11	ALL
	B07	UNUSED						ALL
	B08		W5111	2077B	24		22-23-12	ALL
	B09		W5111	2011B	24		31-65-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45113P	**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
B10		W5111	2012B	24		31-65-15	ALL
B11		W5111	2017B	24		31-65-15	ALL
B12		W5111	2022B	24		34-45-11	ALL
B13		W5111	2044B	24		27-32-12	ALL
B14		W5111	2033B	24		SPARE	ALL
B15		W5111	2042B	24		SPARE	ALL
B16	UNUSED						ALL
B17		W5111	0028	22		34-51-41	ALL
B18	UNUSED						ALL
B19		W5111	0007	22		27-83-11	ALL
B20		W5111	0009	22		27-32-11	ALL
PERG	1F	W5111	2001Z			34-31-11	ALL
PERG	1F	W5111	2002Z			34-31-11	ALL
PERG	1F	W5111	2011Z			31-65-12	ALL
PERG	1F	W5111	2012Z			31-65-15	ALL
PERG	1F	W5111	2017Z			31-65-15	ALL
PERG	1F	W5111	2022Z			34-45-11	ALL
PERG	1F	W5111	2033Z			SPARE	ALL
PERG	1F	W5111	2042Z			SPARE	ALL
PERG	1F	W5111	2044Z			27-32-12	ALL
PERG	1F	W5111	2077Z			22-23-12	ALL
D45117J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0321	0275	22		27-32-11	ALL
A02		W0321	0166	22		22-23-11	ALL
A03	UNUSED						ALL
A04		W0321	0221	24		22-11-14	ALL
A05	UNUSED						ALL
A06		W0321	2131R	24		34-31-11	ALL
A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45117J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A08		W0321	2013R	24		31-65-15	ALL
	A09		W0321	2716R	24		31-65-15	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W0321	2070R	24		23-27-32	ALL
	A13	UNUSED						ALL
	A14		W0321	2715R	24		27-32-12	ALL
	A15	UNUSED						ALL
	A16		W0321	2714R	24		27-32-12	ALL
	A17	UNUSED						ALL
	A18		W0321	2713R	24		27-32-12	ALL
	A19		W0321	2228R	24		22-23-12	ALL
	A20		W0321	0703	22		27-32-11	ALL
	B01		W0321	0230	22		22-23-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0321	0277	22		27-32-11	ALL
	B05	UNUSED						ALL
	B06		W0321	2131B	24		34-31-11	ALL
	B07	UNUSED						ALL
	B08		W0321	2013B	24		31-65-15	ALL
	B09		W0321	2716B	24		31-65-15	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W0321	2070B	24		23-27-32	ALL
	B13	UNUSED						ALL
	B14		W0321	2715B	24		27-32-12	ALL
	B15	UNUSED						ALL
	B16		W0321	2714B	24		27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45117J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18		W0321	2713B	24		27-32-12	ALL
	B19		W0321	2228B	24		22-23-12	ALL
	B20		W0321	0119	22		27-83-11	ALL
	PERG	1F	W0321	2013Z			31-65-15	ALL
	PERG	1F	W0321	2070Z			23-27-32	ALL
	PERG	1F	W0321	2131Z			34-31-11	ALL
	PERG	1F	W0321	2228Z			22-23-12	ALL
	PERG	1F	W0321	2713Z			27-32-12	ALL
	PERG	1F	W0321	2714Z			27-32-12	ALL
	PERG	1F	W0321	2715Z			27-32-12	ALL
	PERG	1F	W0321	2716Z			31-65-15	ALL
D45117P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	0003	22		27-32-11	ALL
	A02		W5111	0047	22		22-23-11	ALL
	A03	UNUSED						ALL
	A04		W5111	0008	24		22-11-14	ALL
	A05	UNUSED						ALL
	A06		W5111	2003R	24		34-31-11	ALL
	A07	UNUSED						ALL
	A08		W5111	2015R	24		31-65-15	ALL
	A09		W5111	2016R	24		31-65-15	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12		W5111	2024R	24		23-27-32	ALL
	A13		W5111	2030R	22		SPARE	ALL
	A14		W5111	2031R	24		27-32-12	ALL
	A15	UNUSED						ALL
	A16		W5111	2029R	24		27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45117P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A17		W5111	2043R	24		SPARE	ALL
	A18		W5111	2044R	24		27-32-12	ALL
	A19		W5111	2077R	24		22-23-12	ALL
	A20		W5111	0006	22		27-32-11	ALL
	B01		W5111	0027	20		22-23-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5111	0009	22		27-32-11	ALL
	B05	UNUSED						ALL
	B06		W5111	2003B	24		34-31-11	ALL
	B07	UNUSED						ALL
	B08		W5111	2015B	24		31-65-15	ALL
	B09		W5111	2016B	24		31-65-15	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12		W5111	2024B	24		23-27-32	ALL
	B13		W5111	2030B	22		SPARE	ALL
	B14		W5111	2031B	24		27-32-12	ALL
	B15	UNUSED						ALL
	B16		W5111	2029B	24		27-32-12	ALL
	B17		W5111	2043B	24		SPARE	ALL
	B18		W5111	2044B	24		27-32-12	ALL
	B19		W5111	2077B	24		22-23-12	ALL
	B20		W5111	0007	22		27-83-11	ALL
	PERG	1F	W5111	2003Z			34-31-11	ALL
	PERG	1F	W5111	2015Z			31-65-15	ALL
	PERG	1F	W5111	2016Z			31-65-15	ALL
	PERG	1F	W5111	2024Z			23-27-32	ALL
	PERG	1F	W5111	2029Z			27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45117P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5111	2030Z			SPARE	ALL
	PERG	1F	W5111	2031Z			27-32-12	ALL
	PERG	1F	W5111	2043Z			SPARE	ALL
	PERG	1F	W5111	2044Z			27-32-12	ALL
	PERG	1F	W5111	2077Z			22-23-12	ALL
D45121J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	0614	22		34-51-41	ALL
	A02		W0313	0640	22		27-32-21	ALL
	A03		W0313	2046R	24		31-65-25	ALL
	A04		W0313	0572	24		31-65-41	ALL
	A05		W0313	2717R	24		31-31-13	ALL
	A06		W0313	0010	24		31-31-17	ALL
	A07		W0313	2547R	24		73-24-21	ALL
	A08		W0313	2774R	24		31-65-25	ALL
	A09		W0313	2725R	24		34-33-21	ALL
	A10		W0313	2518R	24		31-65-25	ALL
	A11		W0313	2519R	24		31-65-25	ALL
	A12	UNUSED						ALL
	A13		W0313	2521R	24		31-65-25	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W0313	2593R	24		34-55-21	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19		W0313	2724R	24		34-33-21	ALL
	A20	UNUSED						ALL
	B01		W0313	2709R	24		31-65-25	ALL
	B02		W0313	0649	22		34-57-21	ALL
	B03		W0313	2046B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45121J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B04		W0313	2709B	24		31-65-25	ALL
	B05		W0313	2717B	24		31-31-13	ALL
	B06	UNUSED						ALL
	B07		W0313	2547B	24		73-24-21	ALL
	B08		W0313	2774B	24		31-65-25	ALL
	B09		W0313	2725B	24		34-33-21	ALL
	B10		W0313	2518B	24		31-65-25	ALL
	B11		W0313	2519B	24		31-65-25	ALL
	B12	UNUSED						ALL
	B13		W0313	2521B	24		31-65-25	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W0313	2593B	24		34-55-21	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W0313	2724B	24		34-33-21	ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2046Z			31-65-25	ALL
	PERG	1F	W0313	2518Z			31-65-25	ALL
	PERG	1F	W0313	2519Z			31-65-25	ALL
	PERG	1F	W0313	2521Z			31-65-25	ALL
	PERG	1F	W0313	2547Z			73-24-21	ALL
	PERG	1F	W0313	2593Z			34-55-21	ALL
	PERG	1F	W0313	2709Z			31-65-25	ALL
	PERG	1F	W0313	2717Z			31-31-13	ALL
	PERG	1F	W0313	2724Z			34-33-21	ALL
	PERG	1F	W0313	2725Z			34-33-21	ALL
	PERG	1F	W0313	2774Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45121P	**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5121	0004	22		34-51-41	ALL
A02		W5121	0012	22		27-32-21	ALL
A03		W5121	2070R	24		SPARE	ALL
A04		W5121	0029	24		31-65-41	ALL
A05		W5121	2302R	24		31-31-13	ALL
A06		W5121	0045	24		31-31-17	ALL
A07		W5121	2026R	24		73-24-21	ALL
A08		W5121	2774R	24		31-65-25	ALL
A09		W5121	2028R	24		34-33-21	ALL
A10		W5121	2010R	24		31-65-25	ALL
A11		W5121	2011R	24		31-65-25	ALL
A12	UNUSED						ALL
A13		W5121	2013R	24		31-65-25	ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16		W5121	2017R	24		34-55-21	ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W5121	2020R	24		34-33-21	ALL
A20	UNUSED						ALL
B01		W5121	2709R	24		31-65-25	ALL
B02		W5121	0016	22		34-57-21	ALL
B03		W5121	2070B	24		SPARE	ALL
B04		W5121	2709B	24		31-65-25	ALL
B05		W5121	2302B	24		31-31-13	ALL
B06	UNUSED						ALL
B07		W5121	2026B	24		73-24-21	ALL
B08		W5121	2774B	24		31-65-25	ALL
B09		W5121	2028B	24		34-33-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45121P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B10		W5121	2010B	24		31-65-25	ALL
	B11		W5121	2011B	24		31-65-25	ALL
	B12	UNUSED						ALL
	B13		W5121	2013B	24		31-65-25	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W5121	2017B	24		34-55-21	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W5121	2020B	24		34-33-21	ALL
	B20	UNUSED						ALL
	PERG	1F	W5121	2010Z			31-65-25	ALL
	PERG	1F	W5121	2011Z			31-65-25	ALL
	PERG	1F	W5121	2013Z			31-65-25	ALL
	PERG	1F	W5121	2017Z			34-55-21	ALL
	PERG	1F	W5121	2020Z			34-33-21	ALL
	PERG	1F	W5121	2026Z			73-24-21	ALL
	PERG	1F	W5121	2028Z			34-33-21	ALL
	PERG	1F	W5121	2070Z			SPARE	ALL
	PERG	1F	W5121	2302Z			31-31-13	ALL
	PERG	1F	W5121	2709Z			31-65-25	ALL
	PERG	1F	W5121	2774Z			31-65-25	ALL
D45125J		**E001-05/ /**		**RCPT - CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45125J	**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W5121	0014	24		31-31-17	ALL
15		W5121	2110R	24		34-53-21	ALL
16		W5121	2110B	24		34-53-21	ALL
17	UNUSED						ALL
18		W5121	2072R	24		34-45-21	ALL
19		W5121	2072B	24		34-45-21	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W5121	2016R	24		34-55-21	ALL
23		W5121	2016B	24		34-55-21	ALL
24		W5121	2017R	24		34-55-21	ALL
25		W5121	2017B	24		34-55-21	ALL
26		W5121	2035R	24		34-55-21	ALL
27		W5121	2035B	24		34-55-21	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45125J		**E001-05/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41		W5121	2668R	24		SPARE	ALL
	42		W5121	2668B	24		SPARE	ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W5121	2016Z			34-55-21	ALL
	S/R		W5121	2017Z			34-55-21	ALL
	S/R		W5121	2035Z			34-55-21	ALL
	S/R		W5121	2072Z			34-45-21	ALL
	S/R		W5121	2110Z			34-53-21	ALL
	S/R		W5121	2668Z			SPARE	ALL
D45125P		**E001-05/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45125P	**E001-05/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0151	0052	24		31-31-17	ALL
15		W0151	2062R	24		34-53-21	ALL
16		W0151	2062B	24		34-53-21	ALL
17	UNUSED						ALL
18		W0151	2024R	24		34-45-21	ALL
19		W0151	2024B	24		34-45-21	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W0151	2008R	24		34-55-21	ALL
23		W0151	2008B	24		34-55-21	ALL
24		W0151	2012R	24		34-55-21	ALL
25		W0151	2012B	24		34-55-21	ALL
26		W0151	2015R	24		34-55-21	ALL
27		W0151	2015B	24		34-55-21	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45125P		**E001-05/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	S/R		W0151	2008Z			34-55-21	ALL
	S/R		W0151	2012Z			34-55-21	ALL
	S/R		W0151	2015Z			34-55-21	ALL
	S/R		W0151	2024Z			34-45-21	ALL
	S/R		W0151	2062Z			34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45127J	**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W0321	0094	24		31-31-17	ALL
A03		W0321	0775	22		34-57-21	ALL
A04	UNUSED						ALL
A05		W0321	2353R	24		31-31-13	ALL
A06		W0321	0032	24		31-31-17	ALL
A07		W0321	2123R	24		34-55-21	ALL
A08	UNUSED						ALL
A09		W0321	2043R	24		22-11-51	ALL
A10		W0321	2500R	24		34-31-21	ALL
A11		W0321	2415R	24		36-11-24	ALL
A12		W0321	2750R	24		31-65-25	ALL
A13		W0321	2011R	24		31-65-25	ALL
A14		W0321	2819R	24		22-11-51	ALL
A15		W0321	2284R	24		34-33-21	ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20		W0321	2180R	24		34-33-21	ALL
B01		W0321	0260	22		27-32-21	ALL
B02		W0321	0227	24		22-11-14	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W0321	2353B	24		31-31-13	ALL
B06	UNUSED						ALL
B07		W0321	2123B	24		34-55-21	ALL
B08	UNUSED						ALL
B09		W0321	2043B	24		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45127J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10		W0321	2500B	24		34-31-21	ALL
	B11		W0321	2415B	24		36-11-24	ALL
	B12		W0321	2750B	24		31-65-25	ALL
	B13		W0321	2011B	24		31-65-25	ALL
	B14		W0321	2819B	24		22-11-51	ALL
	B15		W0321	2284B	24		34-33-21	ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0321	2180B	24		34-33-21	ALL
	PERG	1F	W0321	2011Z			31-65-25	ALL
	PERG	1F	W0321	2043Z			22-11-51	ALL
	PERG	1F	W0321	2123Z			34-55-21	ALL
	PERG	1F	W0321	2180Z			34-33-21	ALL
	PERG	1F	W0321	2284Z			34-33-21	ALL
	PERG	1F	W0321	2353Z			31-31-13	ALL
	PERG	1F	W0321	2415Z			36-11-24	ALL
	PERG	1F	W0321	2500Z			34-31-21	ALL
	PERG	1F	W0321	2750Z			31-65-25	ALL
	PERG	1F	W0321	2819Z			22-11-51	ALL
D45127P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5121	0011	22		SPARE	ALL
	A02		W5121	0014	24		31-31-17	ALL
	A03		W5121	0016	22		34-57-21	ALL
	A04	UNUSED						ALL
	A05		W5121	2302R	24		31-31-13	ALL
	A06		W5121	0045	24		31-31-17	ALL
	A07		W5121	2035R	24		34-55-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45127P	**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A08	UNUSED						ALL
A09		W5121	2032R	24		22-11-51	ALL
A10		W5121	2003R	24		34-31-21	ALL
A11		W5121	2721R	24		36-11-24	ALL
A12		W5121	2010R	24		31-65-25	ALL
A13		W5121	2011R	24		31-65-25	ALL
A14		W5121	2009R	24		22-11-51	ALL
A15		W5121	2020R	24		34-33-21	ALL
A16		W5121	2668R	24		SPARE	ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W5121	2025R	24		SPARE	ALL
A20		W5121	2028R	24		34-33-21	ALL
B01		W5121	0012	22		27-32-21	ALL
B02		W5121	0015	24		22-11-14	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W5121	2302B	24		31-31-13	ALL
B06	UNUSED						ALL
B07		W5121	2035B	24		34-55-21	ALL
B08	UNUSED						ALL
B09		W5121	2032B	24		22-11-51	ALL
B10		W5121	2003B	24		34-31-21	ALL
B11		W5121	2721B	24		36-11-24	ALL
B12		W5121	2010B	24		31-65-25	ALL
B13		W5121	2011B	24		31-65-25	ALL
B14		W5121	2009B	24		22-11-51	ALL
B15		W5121	2020B	24		34-33-21	ALL
B16		W5121	2668B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45127P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W5121	2025B	24		SPARE	ALL
	B20		W5121	2028B	24		34-33-21	ALL
	PERG	1F	W5121	2003Z			34-31-21	ALL
	PERG	1F	W5121	2009Z			22-11-51	ALL
	PERG	1F	W5121	2010Z			31-65-25	ALL
	PERG	1F	W5121	2011Z			31-65-25	ALL
	PERG	1F	W5121	2020Z			34-33-21	ALL
	PERG	1F	W5121	2025Z			SPARE	ALL
	PERG	1F	W5121	2028Z			34-33-21	ALL
	PERG	1F	W5121	2032Z			22-11-51	ALL
	PERG	1F	W5121	2035Z			34-55-21	ALL
	PERG	1F	W5121	2302Z			31-31-13	ALL
	PERG	1F	W5121	2668Z			SPARE	ALL
	PERG	1F	W5121	2721Z			36-11-24	ALL
D45131J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0311	0105	24		29-32-11	ALL
	A03		W0311	2774R	24		31-65-15	ALL
	A04		W0311	2730R	24		31-65-25	ALL
	A05		W0311	2731R	24		31-65-25	ALL
	A06		W0311	2729R	24		31-65-25	ALL
	A07		W0311	2028R	24		31-65-15	ALL
	A08		W0311	2003R	24		31-65-12	ALL
	A09		W0311	2022R	24		31-65-15	ALL
	A10		W0311	2021R	24		31-65-15	ALL
	A11		W0311	2020R	24		31-65-15	ALL
	A12		W0311	2019R	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45131J	**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A13		W0311	2018R	24		31-65-15	ALL
A14		W0311	2171R	24		31-65-15	ALL
A15		W0311	2165R	24		31-65-15	ALL
A16		W0311	2166R	24		31-65-15	ALL
A17		W0311	2702R	24		34-58-11	ALL
A18		W0311	2703R	24		34-58-11	ALL
A19		W0311	2156R	24		27-81-41	ALL
A20		W0311	2073R	24		31-65-15	ALL
B01	UNUSED						ALL
B02		W0311	0106	24		29-32-11	ALL
B03		W0311	2774B	24		31-65-15	ALL
B04		W0311	2730B	24		31-65-25	ALL
B05		W0311	2731B	24		31-65-25	ALL
B06		W0311	2729B	24		31-65-25	ALL
B07		W0311	2028B	24		31-65-15	ALL
B08		W0311	2003B	24		31-65-12	ALL
B09		W0311	2022B	24		31-65-15	ALL
B10		W0311	2021B	24		31-65-15	ALL
B11		W0311	2020B	24		31-65-15	ALL
B12		W0311	2019B	24		31-65-15	ALL
B13		W0311	2018B	24		31-65-15	ALL
B14		W0311	2171B	24		31-65-15	ALL
B15		W0311	2165B	24		31-65-15	ALL
B16		W0311	2166B	24		31-65-15	ALL
B17		W0311	2702B	24		34-58-11	ALL
B18		W0311	2703B	24		34-58-11	ALL
B19		W0311	2156B	24		27-81-41	ALL
B20		W0311	2073B	24		31-65-15	ALL
PERG	1F	W0311	2003Z			31-65-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45131J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0311	2018Z			31-65-15	ALL
	PERG	1F	W0311	2019Z			31-65-15	ALL
	PERG	1F	W0311	2020Z			31-65-15	ALL
	PERG	1F	W0311	2021Z			31-65-15	ALL
	PERG	1F	W0311	2022Z			31-65-15	ALL
	PERG	1F	W0311	2028Z			31-65-15	ALL
	PERG	1F	W0311	2073Z			31-65-15	ALL
	PERG	1F	W0311	2156Z			27-81-41	ALL
	PERG	1F	W0311	2165Z			31-65-15	ALL
	PERG	1F	W0311	2166Z			31-65-15	ALL
	PERG	1F	W0311	2171Z			31-65-15	ALL
	PERG	1F	W0311	2702Z			34-58-11	ALL
	PERG	1F	W0311	2703Z			34-58-11	ALL
	PERG	1F	W0311	2729Z			31-65-25	ALL
	PERG	1F	W0311	2730Z			31-65-25	ALL
	PERG	1F	W0311	2731Z			31-65-25	ALL
	PERG	1F	W0311	2774Z			31-65-15	ALL
D45131P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W5111	0015	22		29-32-11	ALL
	A03		W5111	2774R	24		31-65-15	ALL
	A04		W5111	2730R	24		31-65-25	ALL
	A05		W5111	2731R	24		31-65-25	ALL
	A06		W5111	2729R	24		31-65-25	ALL
	A07	UNUSED						ALL
	A08		W5111	2011R	24		31-65-12	ALL
	A09		W5111	2012R	24		31-65-15	ALL
	A10		W5111	2013R	24		31-65-15	ALL
	A11		W5111	2014R	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45131P	**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A12		W5111	2015R	24		31-65-15	ALL
A13		W5111	2016R	24		31-65-15	ALL
A14		W5111	2017R	24		31-65-15	ALL
A15		W5111	2018R	24		31-65-15	ALL
A16		W5111	2019R	24		31-65-15	ALL
A17		W5111	2702R	24		34-58-11	ALL
A18		W5111	2703R	24		34-58-11	ALL
A19		W5111	2049R	24		27-81-41	ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02		W5111	0016	22		29-32-11	ALL
B03		W5111	2774B	24		31-65-15	ALL
B04		W5111	2730B	24		31-65-25	ALL
B05		W5111	2731B	24		31-65-25	ALL
B06		W5111	2729B	24		31-65-25	ALL
B07	UNUSED						ALL
B08		W5111	2011B	24		31-65-12	ALL
B09		W5111	2012B	24		31-65-15	ALL
B10		W5111	2013B	24		31-65-15	ALL
B11		W5111	2014B	24		31-65-15	ALL
B12		W5111	2015B	24		31-65-15	ALL
B13		W5111	2016B	24		31-65-15	ALL
B14		W5111	2017B	24		31-65-15	ALL
B15		W5111	2018B	24		31-65-15	ALL
B16		W5111	2019B	24		31-65-15	ALL
B17		W5111	2702B	24		34-58-11	ALL
B18		W5111	2703B	24		34-58-11	ALL
B19		W5111	2049B	24		27-81-41	ALL
B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45131P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5111	2011Z			31-65-12	ALL
	PERG	1F	W5111	2012Z			31-65-15	ALL
	PERG	1F	W5111	2013Z			31-65-15	ALL
	PERG	1F	W5111	2014Z			31-65-15	ALL
	PERG	1F	W5111	2015Z			31-65-15	ALL
	PERG	1F	W5111	2016Z			31-65-15	ALL
	PERG	1F	W5111	2017Z			31-65-15	ALL
	PERG	1F	W5111	2018Z			31-65-15	ALL
	PERG	1F	W5111	2019Z			31-65-15	ALL
	PERG	1F	W5111	2049Z			27-81-41	ALL
	PERG	1F	W5111	2702Z			34-58-11	ALL
	PERG	1F	W5111	2703Z			34-58-11	ALL
	PERG	1F	W5111	2729Z			31-65-25	ALL
	PERG	1F	W5111	2730Z			31-65-25	ALL
	PERG	1F	W5111	2731Z			31-65-25	ALL
	PERG	1F	W5111	2774Z			31-65-15	ALL
D45133J		**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
	A01		W0111	0145	20		22-13-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0111	2020R	24		22-11-51	ALL
	B01		W0111	0154	20		SPARE	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45133J	**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W0111	2020B	24		22-11-51	ALL
PERG	1F	W0111	2020Z			22-11-51	ALL
D45133P	**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5111	0050	20		22-13-11	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W5111	2046R	24		SPARE	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10		W5111	2053R	24		22-11-51	ALL
B01		W5111	0005	20		SPARE	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W5111	2046B	24		SPARE	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45133P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B10		W5111	2053B	24		22-11-51	ALL
	PERG	1F	W5111	2046Z			SPARE	ALL
	PERG	1F	W5111	2053Z			22-11-51	ALL
D45137J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0901	24		29-32-11	ALL
	A02		W0321	2746R	24		31-65-15	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0321	2747R	24		31-65-15	ALL
	A06	UNUSED						ALL
	A07		W0321	2008R	24		31-35-02	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0321	2752R	24		27-81-41	ALL
	A18		W0321	2064R	24		31-33-01	ALL
	A19		W0321	2064B	24		31-33-01	ALL
	A20		W0321	2132R	24		34-55-11	ALL
	B01		W0321	0902	24		29-32-11	ALL
	B02		W0321	2746B	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0321	2747B	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45137J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06	UNUSED						ALL
	B07		W0321	2008B	24		31-35-02	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0321	2752B	24		27-81-41	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0321	2132B	24		34-55-11	ALL
	PERG	1F	W0321	2008Z			31-35-02	ALL
	PERG	1F	W0321	2064Z			31-33-01	ALL
	PERG	1F	W0321	2132Z			34-55-11	ALL
	PERG	1F	W0321	2746Z			31-65-15	ALL
	PERG	1F	W0321	2747Z			31-65-15	ALL
	PERG	1F	W0321	2752Z			27-81-41	ALL
D45137P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	0015	22		29-32-11	ALL
	A02		W5111	2086R	24		31-65-15	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5111	2087R	24		31-65-15	ALL
	A06	UNUSED						ALL
	A07		W5111	2025R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45137P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W5111	2045R	24		SPARE	ALL
	A16		W5111	2048R	24		SPARE	ALL
	A17		W5111	2049R	24		27-81-41	ALL
	A18		W5111	2764R	24		31-33-01	ALL
	A19		W5111	2764B	24		31-33-01	ALL
	A20		W5111	2054R	24		34-55-11	ALL
	B01		W5111	0016	22		29-32-11	ALL
	B02		W5111	2086B	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5111	2087B	24		31-65-15	ALL
	B06	UNUSED						ALL
	B07		W5111	2025B	24		31-35-02	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W5111	2045B	24		SPARE	ALL
	B16		W5111	2048B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45137P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B17		W5111	2049B	24		27-81-41	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W5111	2054B	24		34-55-11	ALL
	PERG	1F	W5111	2025Z			31-35-02	ALL
	PERG	1F	W5111	2045Z			SPARE	ALL
	PERG	1F	W5111	2048Z			SPARE	ALL
	PERG	1F	W5111	2049Z			27-81-41	ALL
	PERG	1F	W5111	2054Z			34-55-11	ALL
	PERG	1F	W5111	2086Z			31-65-15	ALL
	PERG	1F	W5111	2087Z			31-65-15	ALL
	PERG	1F	W5111	2764Z			31-33-01	ALL
D45141J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0313	2801R	24		31-65-25	ALL
	A02	UNUSED						ALL
	A03		W0313	2663R	24		31-65-25	ALL
	A04		W0313	2664R	24		31-65-25	ALL
	A05		W0313	2596R	24		34-31-21	ALL
	A06		W0313	2591R	24		27-32-22	ALL
	A07		W0313	2721R	24		36-11-24	ALL
	A08		W0313	0501	22		22-11-18	ALL
	A09		W0313	2501R	24		31-65-22	ALL
	A10		W0313	2776R	24		31-65-26	ALL
	A11		W0313	2648R	24		22-11-51	ALL
	A12		W0313	2590R	24		22-11-51	ALL
	A13		W0313	2589R	24		22-11-51	ALL
	A14		W0313	2818R	24		31-33-01	ALL
	A15	UNUSED						ALL
	A16		W0313	2592R	24		27-32-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45141J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A17		W0313	2703R	24		34-58-21	ALL
	A18		W0313	2707R	24		31-65-25	ALL
	A19		W0313	2704R	24		34-58-21	ALL
	A20		W0313	1768	20		73-22-41	ALL
	B01		W0313	2801B	24		31-65-25	ALL
	B02	UNUSED						ALL
	B03		W0313	2663B	24		31-65-25	ALL
	B04		W0313	2664B	24		31-65-25	ALL
	B05		W0313	2596B	24		34-31-21	ALL
	B06		W0313	2591B	24		27-32-22	ALL
	B07		W0313	2721B	24		36-11-24	ALL
	B08	UNUSED						ALL
	B09		W0313	2501B	24		31-65-22	ALL
	B10		W0313	2776B	24		31-65-26	ALL
	B11		W0313	2648B	24		22-11-51	ALL
	B12		W0313	2590B	24		22-11-51	ALL
	B13		W0313	2589B	24		22-11-51	ALL
	B14		W0313	2818B	24		31-33-01	ALL
	B15	UNUSED						ALL
	B16		W0313	2592B	24		27-32-22	ALL
	B17		W0313	2703B	24		34-58-21	ALL
	B18		W0313	2707B	24		31-65-25	ALL
	B19		W0313	2704B	24		34-58-21	ALL
	B20	UNUSED						ALL
	PERG	1F	W0313	2501Z			31-65-22	ALL
	PERG	1F	W0313	2589Z			22-11-51	ALL
	PERG	1F	W0313	2590Z			22-11-51	ALL
	PERG	1F	W0313	2591Z			27-32-22	ALL
	PERG	1F	W0313	2592Z			27-32-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45141J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W0313	2596Z			34-31-21	ALL
	PERG	1F	W0313	2648Z			22-11-51	ALL
	PERG	1F	W0313	2663Z			31-65-25	ALL
	PERG	1F	W0313	2664Z			31-65-25	ALL
	PERG	1F	W0313	2703Z			34-58-21	ALL
	PERG	1F	W0313	2704Z			34-58-21	ALL
	PERG	1F	W0313	2707Z			31-65-25	ALL
	PERG	1F	W0313	2721Z			36-11-24	ALL
	PERG	1F	W0313	2776Z			31-65-26	ALL
	PERG	1F	W0313	2801Z			31-65-25	ALL
	PERG	1F	W0313	2818Z			31-33-01	ALL
D45141P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5121	2084R	24		SPARE	ALL
	A02		W5121	2086R	24		SPARE	ALL
	A03		W5121	2066R	24		31-65-25	ALL
	A04		W5121	2067R	24		31-65-25	ALL
	A05		W5121	2001R	24		34-31-21	ALL
	A06		W5121	2002R	24		27-32-22	ALL
	A07		W5121	2721R	24		36-11-24	ALL
	A08		W5121	0501	22		22-11-18	ALL
	A09		W5121	2008R	24		31-65-22	ALL
	A10		W5121	2775R	24		31-65-26	ALL
	A11		W5121	2029R	24		22-11-51	ALL
	A12		W5121	2030R	24		22-11-51	ALL
	A13		W5121	2031R	24		22-11-51	ALL
	A14		W5121	2765R	24		31-33-01	ALL
	A15		W5121	2025R	24		SPARE	ALL
	A16		W5121	2018R	24		27-32-22	ALL
	A17		W5121	2703R	24		34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45141P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A18		W5121	2707R	24		31-65-25	ALL
	A19		W5121	2704R	24		34-58-21	ALL
	A20		W5121	1751	20		73-22-41	ALL
	B01		W5121	2084B	24		SPARE	ALL
	B02		W5121	2086B	24		SPARE	ALL
	B03		W5121	2066B	24		31-65-25	ALL
	B04		W5121	2067B	24		31-65-25	ALL
	B05		W5121	2001B	24		34-31-21	ALL
	B06		W5121	2002B	24		27-32-22	ALL
	B07		W5121	2721B	24		36-11-24	ALL
	B08	UNUSED						ALL
	B09		W5121	2008B	24		31-65-22	ALL
	B10		W5121	2775B	24		31-65-26	ALL
	B11		W5121	2029B	24		22-11-51	ALL
	B12		W5121	2030B	24		22-11-51	ALL
	B13		W5121	2031B	24		22-11-51	ALL
	B14		W5121	2765B	24		31-33-01	ALL
	B15		W5121	2025B	24		SPARE	ALL
	B16		W5121	2018B	24		27-32-22	ALL
	B17		W5121	2703B	24		34-58-21	ALL
	B18		W5121	2707B	24		31-65-25	ALL
	B19		W5121	2704B	24		34-58-21	ALL
	B20	UNUSED						ALL
	PERG	1F	W5121	2001Z			34-31-21	ALL
	PERG	1F	W5121	2002Z			27-32-22	ALL
	PERG	1F	W5121	2008Z			31-65-22	ALL
	PERG	1F	W5121	2018Z			27-32-22	ALL
	PERG	1F	W5121	2025Z			SPARE	ALL
	PERG	1F	W5121	2029Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45141P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5121	2030Z			22-11-51	ALL
	PERG	1F	W5121	2031Z			22-11-51	ALL
	PERG	1F	W5121	2066Z			31-65-25	ALL
	PERG	1F	W5121	2067Z			31-65-25	ALL
	PERG	1F	W5121	2084Z			SPARE	ALL
	PERG	1F	W5121	2086Z			SPARE	ALL
	PERG	1F	W5121	2703Z			34-58-21	ALL
	PERG	1F	W5121	2704Z			34-58-21	ALL
	PERG	1F	W5121	2707Z			31-65-25	ALL
	PERG	1F	W5121	2721Z			36-11-24	ALL
	PERG	1F	W5121	2765Z			31-33-01	ALL
	PERG	1F	W5121	2775Z			31-65-26	ALL
D45147J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0321	0071	24		31-31-15	ALL
	A03		W0321	2748R	24		31-65-25	ALL
	A04		W0321	2749R	24		31-65-25	ALL
	A05	UNUSED						ALL
	A06		W0321	2065R	24		31-33-01	ALL
	A07		W0321	2281R	24		31-65-25	ALL
	A08		W0321	2282R	24		31-65-25	ALL
	A09		W0321	2306R	24		34-61-23	ALL
	A10		W0321	2755R	24		27-32-22	ALL
	A11	UNUSED						ALL
	A12		W0321	2756R	24		27-32-22	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45147J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A17	UNUSED						ALL
	A18		W0321	2301R	24		23-27-33	ALL
	A19	UNUSED						ALL
	A20		W0321	2086R	24		31-65-26	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0321	2748B	24		31-65-25	ALL
	B04		W0321	2749B	24		31-65-25	ALL
	B05	UNUSED						ALL
	B06		W0321	2065B	24		31-33-01	ALL
	B07		W0321	2281B	24		31-65-25	ALL
	B08		W0321	2282B	24		31-65-25	ALL
	B09		W0321	2306B	24		34-61-23	ALL
	B10		W0321	2755B	24		27-32-22	ALL
	B11	UNUSED						ALL
	B12		W0321	2756B	24		27-32-22	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18		W0321	2301B	24		23-27-33	ALL
	B19	UNUSED						ALL
	B20		W0321	2086B	24		31-65-26	ALL
	PERG	1F	W0321	2065Z			31-33-01	ALL
	PERG	1F	W0321	2086Z			31-65-26	ALL
	PERG	1F	W0321	2281Z			31-65-25	ALL
	PERG	1F	W0321	2282Z			31-65-25	ALL
	PERG	1F	W0321	2301Z			23-27-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45147J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0321	2306Z			34-61-23	ALL
PERG	1F	W0321	2748Z			31-65-25	ALL
PERG	1F	W0321	2749Z			31-65-25	ALL
PERG	1F	W0321	2755Z			27-32-22	ALL
PERG	1F	W0321	2756Z			27-32-22	ALL
D45147P	**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W5121	0005	24		31-31-15	ALL
A03		W5121	2066R	24		31-65-25	ALL
A04		W5121	2067R	24		31-65-25	ALL
A05		W5121	2070R	24		SPARE	ALL
A06		W5121	2765R	24		31-33-01	ALL
A07		W5121	2707R	24		31-65-25	ALL
A08		W5121	2709R	24		31-65-25	ALL
A09		W5121	2045R	24		34-61-23	ALL
A10		W5121	2002R	24		27-32-22	ALL
A11		W5121	2084R	24		SPARE	ALL
A12		W5121	2018R	24		27-32-22	ALL
A13		W5121	2022R	24		SPARE	ALL
A14		W5121	2023R	24		SPARE	ALL
A15		W5121	2024R	24		SPARE	ALL
A16		W5121	2086R	24		SPARE	ALL
A17	UNUSED						ALL
A18		W5121	2059R	24		23-27-33	ALL
A19	UNUSED						ALL
A20		W5121	2775R	24		31-65-26	ALL
B01		W5121	0010	22		SPARE	ALL
B02	UNUSED						ALL
B03		W5121	2066B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45147P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B04		W5121	2067B	24		31-65-25	ALL
	B05		W5121	2070B	24		SPARE	ALL
	B06		W5121	2765B	24		31-33-01	ALL
	B07		W5121	2707B	24		31-65-25	ALL
	B08		W5121	2709B	24		31-65-25	ALL
	B09		W5121	2045B	24		34-61-23	ALL
	B10		W5121	2002B	24		27-32-22	ALL
	B11		W5121	2084B	24		SPARE	ALL
	B12		W5121	2018B	24		27-32-22	ALL
	B13		W5121	2022B	24		SPARE	ALL
	B14		W5121	2023B	24		SPARE	ALL
	B15		W5121	2024B	24		SPARE	ALL
	B16		W5121	2086B	24		SPARE	ALL
	B17	UNUSED						ALL
	B18		W5121	2059B	24		23-27-33	ALL
	B19	UNUSED						ALL
	B20		W5121	2775B	24		31-65-26	ALL
	PERG	1F	W5121	2002Z			27-32-22	ALL
	PERG	1F	W5121	2018Z			27-32-22	ALL
	PERG	1F	W5121	2022Z			SPARE	ALL
	PERG	1F	W5121	2023Z			SPARE	ALL
	PERG	1F	W5121	2024Z			SPARE	ALL
	PERG	1F	W5121	2045Z			34-61-23	ALL
	PERG	1F	W5121	2059Z			23-27-33	ALL
	PERG	1F	W5121	2066Z			31-65-25	ALL
	PERG	1F	W5121	2067Z			31-65-25	ALL
	PERG	1F	W5121	2070Z			SPARE	ALL
	PERG	1F	W5121	2084Z			SPARE	ALL
	PERG	1F	W5121	2086Z			SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45147P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5121	2707Z			31-65-25	ALL
	PERG	1F	W5121	2709Z			31-65-25	ALL
	PERG	1F	W5121	2765Z			31-33-01	ALL
	PERG	1F	W5121	2775Z			31-65-26	ALL
D45151J		**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0311	2159R	24		23-27-38	ALL
	A07	UNUSED						ALL
	A08		W0311	2155R	24		31-35-02	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45151J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B05	UNUSED						ALL
	B06		W0311	2159B	24		23-27-38	ALL
	B07	UNUSED						ALL
	B08		W0311	2155B	24		31-35-02	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2155Z			31-35-02	ALL
	PERG	1F	W0311	2159Z			23-27-38	ALL
D45151P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5111	2055R	24		23-27-38	ALL
	A07	UNUSED						ALL
	A08		W5111	2061R	24		31-35-02	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45151P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5111	2055B	24		23-27-38	ALL
	B07	UNUSED						ALL
	B08		W5111	2061B	24		31-35-02	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45151P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B20	UNUSED						ALL
	PERG	1F	W5111	2055Z			23-27-38	ALL
	PERG	1F	W5111	2061Z			31-35-02	ALL
D45157J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0151	22		23-27-38	ALL
	A02		W0321	0153	22		23-27-38	ALL
	A03		W0321	2349R	22		31-32-15	ALL
	A04		W0321	0157	22		23-27-38	ALL
	A05		W0321	2241B	24		34-58-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W0321	2763R	24		31-33-01	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0321	2021R	24		31-35-02	ALL
	A18		W0321	2147R	24		22-11-51	ALL
	A19	UNUSED						ALL
	A20		W0321	2305R	24		34-61-23	ALL
	B01		W0321	0152	22		23-27-38	ALL
	B02		W0321	0154	22		23-27-38	ALL
	B03		W0321	2349B	22		31-32-15	ALL
	B04		W0321	0158	22		23-27-38	ALL
	B05		W0321	2241R	24		34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45157J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W0321	2763B	24		31-33-01	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W0321	2021B	24		31-35-02	ALL
B18		W0321	2147B	24		22-11-51	ALL
B19	UNUSED						ALL
B20		W0321	2305B	24		34-61-23	ALL
PERG	1F	W0321	2021Z			31-35-02	ALL
PERG	1F	W0321	2147Z			22-11-51	ALL
PERG	1F	W0321	2241Z			34-58-11	ALL
PERG	1F	W0321	2305Z			34-61-23	ALL
PERG	1F	W0321	2349Z			31-32-15	ALL
PERG	1F	W0321	2763Z			31-33-01	ALL
D45157P	**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5111	0034	22		23-27-38	ALL
A02		W5111	0036	22		23-27-38	ALL
A03		W5111	2066R	24		31-32-15	ALL
A04		W5111	0040	22		23-27-38	ALL
A05		W5111	2110B	24		34-58-11	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45157P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W5111	2075R	24		31-33-01	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W5111	2060R	24		31-35-02	ALL
	A18		W5111	2117R	24		22-11-51	ALL
	A19	UNUSED						ALL
	A20		W5111	2073R	24		34-61-23	ALL
	B01		W5111	0035	22		23-27-38	ALL
	B02		W5111	0037	22		23-27-38	ALL
	B03		W5111	2066B	24		31-32-15	ALL
	B04		W5111	0041	22		23-27-38	ALL
	B05		W5111	2110R	24		34-58-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W5111	2075B	24		31-33-01	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45157P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B17		W5111	2060B	24		31-35-02	ALL
	B18		W5111	2117B	24		22-11-51	ALL
	B19	UNUSED						ALL
	B20		W5111	2073B	24		34-61-23	ALL
	PERG	1F	W5111	2060Z			31-35-02	ALL
	PERG	1F	W5111	2066Z			31-32-15	ALL
	PERG	1F	W5111	2073Z			34-61-23	ALL
	PERG	1F	W5111	2075Z			31-33-01	ALL
	PERG	1F	W5111	2110Z			34-58-11	ALL
	PERG	1F	W5111	2117Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45203J		**E001-01/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0111	0426	22		34-51-41	ALL
	A02		W0111	0427	22		34-51-41	ALL
	A03		W0111	0972	22		34-51-41	ALL
	A04		W0111	0430	22		34-51-41	ALL
	A05		W0111	0431	22		34-51-41	ALL
	A06		W0111	0973	22		34-51-41	ALL
	A07		W0111	0439	22		34-51-41	ALL
	A08		W0111	0958	22		34-51-41	ALL
	A09		W0111	2206W	24		34-49-11	ALL
	A10		W0111	2204W	24		34-49-11	ALL
	B01		W0111	0175	20		22-14-11	ALL
	B02		W0111	2139B	20		27-25-11	ALL
	B03		W0111	2139R	20		27-25-11	ALL
	B04		W0111	0815	22		34-51-41	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0111	2255R	24		34-21-14	ALL
	B08		W0111	2255B	24		34-21-14	ALL
	B09		W0111	2206B	24		34-49-11	ALL
	B10		W0111	2204B	24		34-49-11	ALL
	F		W0111	0724	16		34-21-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0111	2139Z			27-25-11	ALL
	PERG	1F	W0111	2204Z			34-49-11	ALL
	PERG	1F	W0111	2206Z			34-49-11	ALL
	PERG	1F	W0111	2255Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45203P	**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5205	0001	22		34-51-41	ALL
A02		W5205	0002	22		34-51-41	ALL
A03		W5205	0003	22		34-51-41	ALL
A04		W5205	0004	22		34-51-41	ALL
A05		W5205	0005	22		34-51-41	ALL
A06		W5205	0006	22		34-51-41	ALL
A07		W5205	0007	22		34-51-41	ALL
A08		W5205	0008	22		34-51-41	ALL
A09		W5205	2003W	24		34-49-11	ALL
A10		W5205	2004W	24		34-49-11	ALL
B01		W5205	0063	20		22-14-11	ALL
B02		W5205	2007B	20		27-25-11	ALL
B03		W5205	2007R	20		27-25-11	ALL
B04		W5205	0012	22		34-51-41	ALL
B05		W5205	2006R	22		SPARE	ALL
B06		W5205	2006B	22		SPARE	ALL
B07		W5205	2002R	24		34-21-14	ALL
B08		W5205	2002B	24		34-21-14	ALL
B09		W5205	2003B	24		34-49-11	ALL
B10		W5205	2004B	24		34-49-11	ALL
F		W5205	0021	16		34-21-11	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W5205	2002Z			34-21-14	ALL
PERG	1F	W5205	2003Z			34-49-11	ALL
PERG	1F	W5205	2004Z			34-49-11	ALL
PERG	1F	W5205	2006Z			SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45203P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5205	2007Z			27-25-11	ALL
D45204J		**E005-02/ /**		**RCPT-**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	=1		W3477	4017Z			44-35-05	ALL
	=2		W3477	4018Z			44-35-05	ALL
	1-1		W3477	4017Y	24		44-35-05	ALL
	1-2		W3477	4017R	24		44-35-05	ALL
	1-3		W3477	4017G	24		44-35-05	ALL
	1-4		W3477	4017B	24		44-35-05	ALL
	2-1		W3477	4018Y	24		44-35-05	ALL
	2-2		W3477	4018R	24		44-35-05	ALL
	2-3		W3477	4018G	24		44-35-05	ALL
	2-4		W3477	4018B	24		44-35-05	ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
	4-1	UNUSED						ALL
	4-2	UNUSED						ALL
	4-3	UNUSED						ALL
	4-4	UNUSED						ALL
	5-1	UNUSED						ALL
	5-2	UNUSED						ALL
	5-3	UNUSED						ALL
	5-4	UNUSED						ALL
	6-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45204J	**E005-02/ /**		**RCPT- (continued)**				**ALL**
6-2	UNUSED						ALL
6-3	UNUSED						ALL
6-4	UNUSED						ALL
D45205J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0311	0114	22		34-51-41	ALL
A02		W0311	0138	20		34-21-11	ALL
A03		W0311	1770	20		34-24-15	ALL
A04		W0311	0139	20		34-21-11	ALL
A05		W0311	2760B	24		34-49-11	ALL
A06		W0311	2040B	22		49-62-11	ALL
A07		W0311	0135	20		34-61-11	ALL
A08		W0311	0134	20		34-61-11	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02		W0311	2765B	24		34-49-11	ALL
B03		W0311	2765W	24		34-49-11	ALL
B04		W0311	2760W	24		34-49-11	ALL
B05		W0311	2040R	22		49-62-11	ALL
B06	UNUSED						ALL
B07		W0311	2037R	22		49-62-11	ALL
B08		W0311	2037B	22		49-62-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0311	2037Z			49-62-11	ALL
PERG	1F	W0311	2040Z			49-62-11	ALL
PERG	1F	W0311	2760Z			34-49-11	ALL
PERG	1F	W0311	2765Z			34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45205P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5205	0011	22		34-51-41	ALL
	A02		W5205	0022	20		34-21-11	ALL
	A03		W5205	0101	20		34-24-15	ALL
	A04		W5205	0024	20		34-21-11	ALL
	A05		W5205	2003B	24		34-49-11	ALL
	A06		W5205	2021B	22		49-62-11	ALL
	A07		W5205	0027	20		34-61-11	ALL
	A08		W5205	0026	20		34-61-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5205	2004B	24		34-49-11	ALL
	B03		W5205	2004W	24		34-49-11	ALL
	B04		W5205	2003W	24		34-49-11	ALL
	B05		W5205	2021R	22		49-62-11	ALL
	B06	UNUSED						ALL
	B07		W5205	2022R	22		49-62-11	ALL
	B08		W5205	2022B	22		49-62-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5205	2003Z			34-49-11	ALL
	PERG	1F	W5205	2004Z			34-49-11	ALL
	PERG	1F	W5205	2021Z			49-62-11	ALL
	PERG	1F	W5205	2022Z			49-62-11	ALL
D45207J		**E003-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0321	2181R	24		34-51-11	ALL
	A03	UNUSED						ALL
	A04		W0321	2362R	24		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45207J		**E003-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A05		W0321	2014R	24		49-62-11	ALL
	A06	UNUSED						ALL
	A07		W0321	2022R	22		49-62-11	ALL
	A08		W0321	2022B	22		49-62-11	ALL
	A09		W0321	2286R	24		34-51-11	ALL
	A10		W0321	2099R	20		27-25-11	ALL
	B01	UNUSED						ALL
	B02		W0321	2181B	24		34-51-11	ALL
	B03		W0321	0767	22		34-51-11	ALL
	B04		W0321	2362B	24		34-51-11	ALL
	B05	UNUSED						ALL
	B06		W0321	2014B	24		49-62-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0321	2286B	24		34-51-11	ALL
	B10		W0321	2099B	20		27-25-11	ALL
	PERG	1F	W0321	2014Z			49-62-11	ALL
	PERG	1F	W0321	2022Z			49-62-11	ALL
	PERG	1F	W0321	2099Z			27-25-11	ALL
	PERG	1F	W0321	2181Z			34-51-11	ALL
	PERG	1F	W0321	2286Z			34-51-11	ALL
	PERG	1F	W0321	2362Z			34-51-11	ALL
D45207P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W5205	2104R	24		34-51-11	ALL
	A03		W5205	0053	20		SPARE	ALL
	A04		W5205	2105R	24		34-51-11	ALL
	A05		W5205	2021R	22		49-62-11	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45207P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A07		W5205	2022R	22		49-62-11	ALL
	A08		W5205	2022B	22		49-62-11	ALL
	A09		W5205	2009R	24		34-51-11	ALL
	A10		W5205	2007R	20		27-25-11	ALL
	B01	UNUSED						ALL
	B02		W5205	2104B	24		34-51-11	ALL
	B03		W5205	0103	22		34-51-11	ALL
	B04		W5205	2105B	24		34-51-11	ALL
	B05	UNUSED						ALL
	B06		W5205	2021B	22		49-62-11	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5205	2009B	24		34-51-11	ALL
	B10		W5205	2007B	20		27-25-11	ALL
	PERG	1F	W5205	2007Z			27-25-11	ALL
	PERG	1F	W5205	2009Z			34-51-11	ALL
	PERG	1F	W5205	2021Z			49-62-11	ALL
	PERG	1F	W5205	2022Z			49-62-11	ALL
	PERG	1F	W5205	2104Z			34-51-11	ALL
	PERG	1F	W5205	2105Z			34-51-11	ALL
D45209J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W5205	0022	20		34-21-11	ALL
	A03	UNUSED						ALL
	A04		W5205	0024	20		34-21-11	ALL
	A05	UNUSED						ALL
	A06		W5205	2031R	24		SPARE	ALL
	A07		W5205	2031B	24		SPARE	ALL
	A08		W5205	0026	20		34-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45209J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A09		W5205	0027	20		34-61-11	ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5205	0101	20		34-24-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5205	2002R	24		34-21-14	ALL
	B08		W5205	2002B	24		34-21-14	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W5205	0021	16		34-21-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W5205	2002Z			34-21-14	ALL
	PERG	1F	W5205	2031Z			SPARE	ALL
D45209P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W0521	0140	20		34-21-11	ALL
	A03	UNUSED						ALL
	A04		W0521	0143	20		34-21-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0521	0001	20		34-61-11	ALL
	A09		W0521	0002	20		34-61-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45209P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0521	0335	20		34-24-15	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0521	2556R	24		34-21-14	ALL
	B08		W0521	2556B	24		34-21-14	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0521	0182	16		34-21-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0521	2556Z			34-21-14	ALL
D45211J		**E005-02/ /**		**RCPT-**				**ALL**
	A01		W5111	2164R	24		34-61-21	ALL
	A02		W5111	0042	24		23-27-39	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5111	2069R	24		23-27-39	ALL
	A07	UNUSED						ALL
	A08		W5111	2068R	24		23-27-32	ALL
	A09	UNUSED						ALL
	A10		W5111	2063R	24		SPARE	ALL
	A11		W5111	2064R	24		34-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45211J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	A12		W5111	2065R	24		34-61-23	ALL
	A13		W5111	2094R	24		SPARE	ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W5111	2092R	22		44-21-20	ALL
	A17	UNUSED						ALL
	A18		W5111	2099R	24		SPARE	ALL
	A19	UNUSED						ALL
	A20		W5111	2102R	22		44-21-20	ALL
	B01		W5111	2164B	24		34-61-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5111	2069B	24		23-27-39	ALL
	B07	UNUSED						ALL
	B08		W5111	2068B	24		23-27-32	ALL
	B09	UNUSED						ALL
	B10		W5111	2063B	24		SPARE	ALL
	B11		W5111	2064B	24		34-61-21	ALL
	B12		W5111	2065B	24		34-61-23	ALL
	B13		W5111	2094B	24		SPARE	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16		W5111	2092B	22		44-21-20	ALL
	B17	UNUSED						ALL
	B18		W5111	2099B	24		SPARE	ALL
	B19	UNUSED						ALL
	B20		W5111	2102B	22		44-21-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45211J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	PERG	1F	W5111	2063Z			SPARE	ALL
	PERG	1F	W5111	2064Z			34-61-21	ALL
	PERG	1F	W5111	2065Z			34-61-23	ALL
	PERG	1F	W5111	2068Z			23-27-32	ALL
	PERG	1F	W5111	2069Z			23-27-39	ALL
	PERG	1F	W5111	2092Z			44-21-20	ALL
	PERG	1F	W5111	2094Z			SPARE	ALL
	PERG	1F	W5111	2099Z			SPARE	ALL
	PERG	1F	W5111	2102Z			44-21-20	ALL
	PERG	1F	W5111	2164Z			34-61-21	ALL
D45211P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2758R	24		34-61-21	ALL
	A02		W0521	0147	24		23-27-39	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0521	2629R	24		23-27-39	ALL
	A07	UNUSED						ALL
	A08		W0521	2652R	24		23-27-32	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0521	2623R	24		34-61-21	ALL
	A12		W0521	2630R	24		34-61-23	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W0521	2692R	22		44-21-20	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45211P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A19	UNUSED						ALL
A20		W0521	2697R	22		44-21-20	ALL
B01		W0521	2758B	24		34-61-21	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06		W0521	2629B	24		23-27-39	ALL
B07	UNUSED						ALL
B08		W0521	2652B	24		23-27-32	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0521	2623B	24		34-61-21	ALL
B12		W0521	2630B	24		34-61-23	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16		W0521	2692B	22		44-21-20	ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20		W0521	2697B	22		44-21-20	ALL
PERG	1F	W0521	2623Z			34-61-21	ALL
PERG	1F	W0521	2629Z			23-27-39	ALL
PERG	1F	W0521	2630Z			34-61-23	ALL
PERG	1F	W0521	2652Z			23-27-32	ALL
PERG	1F	W0521	2692Z			44-21-20	ALL
PERG	1F	W0521	2697Z			44-21-20	ALL
PERG	1F	W0521	2758Z			34-61-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45213J		**E005-02/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5121	0502	22		34-21-22	ALL
	A09	UNUSED						ALL
	A10		W5121	2043R	24		34-61-23	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14		W5121	2060R	24		23-27-33	ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45213J	**E005-02/ /**		**RCPT- (continued)**				**ALL**
B10		W5121	2043B	24		34-61-23	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W5121	2060B	24		23-27-33	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W5121	2043Z			34-61-23	ALL
PERG	1F	W5121	2060Z			23-27-33	ALL
D45213P	**E005-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W0523	0266	22		34-21-22	ALL
A09	UNUSED						ALL
A10		W0523	2719R	24		34-61-23	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0523	2738R	24		23-27-33	ALL
A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45213P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0523	2719B	24		34-61-23	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0523	2738B	24		23-27-33	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0523	2719Z			34-61-23	ALL
	PERG	1F	W0523	2738Z			23-27-33	ALL
D45221J		**351/176/R031**		**RCPT-**				**ALL**
	A01		W0737	0001	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45221J	**351/176/R031**		**RCPT- (continued)**				**ALL**
A02		W0737	0002	22		34-61-19	ALL
A03		W0737	0003	22		34-61-19	ALL
A04		W0737	0004	22		34-61-19	ALL
A05		W0737	0005	22		34-61-19	ALL
A06		W0737	0006	22		34-61-19	ALL
A07		W0737	0007	22		34-61-19	ALL
A08		W0737	0008	22		34-61-19	ALL
A09		W0737	0009	22		34-61-19	ALL
A10		W0737	0010	22		34-61-19	ALL
A11		W0737	0011	22		34-61-19	ALL
A12		W0737	0012	22		34-61-19	ALL
A13		W0737	0013	22		34-61-19	ALL
A14		W0737	0040	22		34-61-19	ALL
A15		W0737	0015	22		34-61-19	ALL
A16		W0737	0016	22		34-61-19	ALL
A17		W0737	0017	22		34-61-19	ALL
A18		W0737	0018	22		34-61-19	ALL
A19		W0737	0019	22		34-61-19	ALL
A20		W0737	0020	22		34-61-19	ALL
B01		W0737	0021	22		34-61-19	ALL
B02		W0737	0022	22		34-61-19	ALL
B03		W0737	0023	22		34-61-19	ALL
B04		W0737	0024	22		34-61-19	ALL
B05	UNUSED						ALL
B06		W0737	0026	22		34-61-12	ALL
B07		W0737	0027	22		34-61-12	ALL
B08		W0737	0028	22		34-61-12	ALL
B09		W0737	0029	22		34-61-12	ALL
B10		W0737	0030	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45221J		**351/176/R031**		**RCPT- (continued)**				**ALL**
	B11		W0737	0031	22		34-61-12	ALL
	B12		W0737	0032	22		34-61-12	ALL
	B13		W0737	0033	22		34-61-12	ALL
	B14		W0737	0034	22		34-61-19	ALL
	B15		W0737	0035	22		34-61-19	ALL
	B16		W0737	0038	22		34-61-19	ALL
	B17		W0737	0039	22		34-61-19	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D45221P		**351/176/R029**		**PLUG-**				**ALL**
	A01		W0521	0086	22		34-61-19	ALL
	A02		W0521	0087	22		34-61-19	ALL
	A03		W0521	0091	22		34-61-19	ALL
	A04		W0521	0092	22		34-61-19	ALL
	A05		W0521	0093	22		34-61-19	ALL
	A06		W0521	0094	22		34-61-19	ALL
	A07		W0521	0095	22		34-61-19	ALL
	A08		W0521	0096	22		34-61-19	ALL
	A09		W0521	0097	22		34-61-19	ALL
	A10		W0521	0098	22		34-61-19	ALL
	A11		W0521	0089	22		34-61-19	ALL
	A12		W0521	0090	22		34-61-19	ALL
	A13		W0521	0125	22		34-61-19	ALL
	A14		W0521	0323	22		34-61-19	ALL
	A15		W0521	0127	22		34-61-19	ALL
	A16		W0521	0128	22		34-61-19	ALL
	A17		W0521	0129	22		34-61-19	ALL
	A18		W0521	0130	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45221P		**351/176/R029**		**PLUG- (continued)**				**ALL**
	A19		W0521	0131	22		34-61-19	ALL
	A20		W0521	0132	22		34-61-19	ALL
	B01		W0521	0133	22		34-61-19	ALL
	B02		W0521	0134	22		34-61-19	ALL
	B03		W0521	0135	22		34-61-19	ALL
	B04		W0521	0136	22		34-61-19	ALL
	B05	UNUSED						ALL
	B06		W0521	0021	22		34-61-12	ALL
	B07		W0521	0017	22		34-61-12	ALL
	B08		W0521	0018	22		34-61-12	ALL
	B09		W0521	0196	22		34-61-12	ALL
	B10		W0521	0014	22		34-61-12	ALL
	B11		W0521	0022	22		34-61-12	ALL
	B12		W0521	0199	22		34-61-12	ALL
	B13		W0521	0023	22		34-61-12	ALL
	B14		W0521	0263	22		34-61-19	ALL
	B15		W0521	0264	22		34-61-19	ALL
	B16		W0521	0300	22		34-61-19	ALL
	B17		W0521	0301	22		34-61-19	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D45225J		**E005-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W2597	0001	22		34-21-11	ALL
	A02		W2597	0002	22		34-21-11	ALL
	A03		W2597	0003	22		34-21-11	ALL
	A04		W2597	0004	22		34-21-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45225J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W2597	2506R	24		34-58-11	ALL
	A12		W2597	2506B	24		34-58-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W2597	2508R	22		31-32-15	ALL
	A17		W2597	2508B	22		31-32-15	ALL
	A18		W2597	0008	24		31-65-15	ALL
	A19		W2597	2509R	24		SPARE	ALL
	A20		W2597	2509B	24		SPARE	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W2597	2502R	22		SPARE	ALL
	B04		W2597	2502B	22		SPARE	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W2597	2507R	24		34-58-11	ALL
	B12		W2597	2507B	24		34-58-11	ALL
	B13		W2597	2513R	22		23-15-15	ALL
	B14		W2597	2513B	22		23-15-15	ALL
	B15		W2597	2510R	24		23-27-39	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45225J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B16		W2597	2510B	24		23-27-39	ALL
	B17		W2597	0014	24		23-27-39	ALL
	B18		W2597	2512R	22		49-62-11	ALL
	B19		W2597	2512B	22		49-62-11	ALL
	B20		W2597	0017	22		23-15-15	ALL
	PERG	1F	W2597	2502Z			SPARE	ALL
	PERG	1F	W2597	2506Z			34-58-11	ALL
	PERG	1F	W2597	2507Z			34-58-11	ALL
	PERG	1F	W2597	2508Z			31-32-15	ALL
	PERG	1F	W2597	2509Z			SPARE	ALL
	PERG	1F	W2597	2510Z			23-27-39	ALL
	PERG	1F	W2597	2512Z			49-62-11	ALL
	PERG	1F	W2597	2513Z			23-15-15	ALL
D45225P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	0152	22		34-21-11	ALL
	A02		W0521	0153	22		34-21-11	ALL
	A03		W0521	0154	22		34-21-11	ALL
	A04		W0521	0160	22		34-21-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11		W0521	2616R	24		34-58-11	ALL
	A12		W0521	2616B	24		34-58-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45225P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A16		W0521	2681R	22		31-32-15	ALL
	A17		W0521	2681B	22		31-32-15	ALL
	A18		W0521	0061	24		31-65-15	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0521	2617R	24		34-31-11	ALL
	B12		W0521	2617B	24		34-31-11	ALL
	B13		W0521	2672R	24		23-15-15	ALL
	B14		W0521	2672B	24		23-15-15	ALL
	B15		W0521	2629R	24		23-27-39	ALL
	B16		W0521	2629B	24		23-27-39	ALL
	B17		W0521	0147	24		23-27-39	ALL
	B18		W0521	2656R	22		49-62-11	ALL
	B19		W0521	2656B	22		49-62-11	ALL
	B20		W0521	0250	24		23-15-15	ALL
	PERG	1F	W0521	2616Z			34-58-11	ALL
	PERG	1F	W0521	2617Z			34-31-11	ALL
	PERG	1F	W0521	2629Z			23-27-39	ALL
	PERG	1F	W0521	2656Z			49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45225P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
PERG	1F	W0521	2672Z			23-15-15	ALL
PERG	1F	W0521	2681Z			31-32-15	ALL
D45227J	**E001-03/ /**		**RCPT**				**ALL**
A01		W0131	0478	22		44-21-22	ALL
A02		W0131	0248	22		44-21-22	ALL
A03		W0131	0246	22		44-21-22	ALL
A04		W0131	0154	22		44-21-22	ALL
A05	UNUSED						ALL
A06		W0131	0145	22		44-21-22	ALL
A07		W0131	0516	22		44-21-22	ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0131	0153	22		44-21-22	ALL
B04		W0131	0151	22		44-21-22	ALL
B05	UNUSED						ALL
B06		W0131	0032	22		44-21-22	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D45227P	**E001-03/ /**		**PLUG**				**ALL**
A01		W3477	0027	22		44-21-22	ALL
A02		W3477	0032	22		44-21-22	ALL
A03		W3477	0029	22		44-21-22	ALL
A04		W3477	0033	22		44-21-22	ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45227P		**E001-03/ /**		**PLUG (continued)**				**ALL**
	A06		W3477	0070	22		44-21-22	ALL
	A07		W3477	0021	22		44-21-22	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W3477	0041	22		44-21-22	ALL
	B04		W3477	0028	22		44-21-22	ALL
	B05	UNUSED						ALL
	B06		W3477	0020	22		44-21-22	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D45235J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W2035	0016	24		34-21-11	ALL
	A02		W2035	0004	22		34-61-12	ALL
	A03		W2035	0002	22		34-61-12	ALL
	A04		W2035	0003	22		34-61-12	ALL
	A05		W2035	0005	22		34-61-12	ALL
	A06		W2035	0006	22		30-21-32	ALL
	A07		W2035	0007	22		30-21-31	ALL
	A08		W2035	0008	22		30-11-11	ALL
	A09		W2035	0009	24		34-61-17	ALL
	A10		W2035	0001	22		34-21-11	ALL
	A11		W2035	0011	22		34-21-11	ALL
	A12		W2035	2001R	24		34-21-11	ALL
	A13		W2035	2001B	24		34-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45235J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A14		W2035	0054	24		34-21-11	ALL
A15		W2035	0015	24		34-21-11	ALL
A16		W2035	0045	22		34-21-11	ALL
A17		W2035	0017	22		34-21-11	ALL
A18		W2035	0018	22		34-21-11	ALL
A19		W2035	0019	22		34-21-11	ALL
A20		W2035	0020	22		34-21-11	ALL
B01		W2035	0021	22		34-21-11	ALL
B02		W2035	0022	22		34-21-11	ALL
B03		W2035	0023	22		34-21-12	ALL
B04		W2035	0024	22		34-21-12	ALL
B05		W2035	0025	22		34-21-12	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09		W2035	2501R	22		34-21-13	ALL
B10		W2035	2501B	22		34-21-13	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13		W2035	0030	22		34-16-11	ALL
B14		W2035	2503R	24		34-61-11	ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17		W2035	2503B	24		34-61-11	ALL
B18		W2035	2502R	24		34-61-22	ALL
B19	UNUSED						ALL
B20		W2035	2502B	24		34-61-22	ALL
PERG	1F	W2035	2001Z			34-21-11	ALL
PERG	1F	W2035	2501Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45235J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W2035	2502Z			34-61-22	ALL
	PERG	1F	W2035	2503Z			34-61-11	ALL
D45235P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	0247	24		34-21-11	ALL
	A02		W0521	0009	22		34-61-12	ALL
	A03		W0521	0013	22		34-61-12	ALL
	A04		W0521	0194	22		34-61-12	ALL
	A05		W0521	0197	22		34-61-12	ALL
	A06		W0521	0030	22		30-21-32	ALL
	A07		W0521	0032	22		30-21-31	ALL
	A08		W0521	0034	22		30-11-11	ALL
	A09		W0521	0036	24		34-61-17	ALL
	A10		W0521	0340	22		34-21-11	ALL
	A11		W0521	0167	22		34-21-11	ALL
	A12		W0521	2751R	24		34-21-11	ALL
	A13		W0521	2751B	24		34-21-11	ALL
	A14		W0521	0171	24		34-21-11	ALL
	A15		W0521	0172	24		34-21-11	ALL
	A16		W0521	0173	22		34-21-11	ALL
	A17		W0521	0178	22		34-21-11	ALL
	A18		W0521	0179	22		34-21-11	ALL
	A19		W0521	0180	22		34-21-11	ALL
	A20		W0521	0158	22		34-21-11	ALL
	B01		W0521	0159	22		34-21-11	ALL
	B02		W0521	0160	22		34-21-11	ALL
	B03		W0521	0184	22		34-21-12	ALL
	B04		W0521	0185	22		34-21-12	ALL
	B05		W0521	0187	22		34-21-12	ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45235P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0521	2533R	24		34-21-13	ALL
	B10		W0521	2533B	24		34-21-13	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0521	0206	22		34-16-11	ALL
	B14		W0521	2637R	24		34-61-11	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0521	2637B	24		34-61-11	ALL
	B18		W0521	2640R	24		34-61-22	ALL
	B19	UNUSED						ALL
	B20		W0521	2640B	24		34-61-22	ALL
	PERG	1F	W0521	2533Z			34-21-13	ALL
	PERG	1F	W0521	2637Z			34-61-11	ALL
	PERG	1F	W0521	2640Z			34-61-22	ALL
	PERG	1F	W0521	2751Z			34-21-11	ALL
D45237J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W2135	0001	22		34-21-21	ALL
	A02		W2135	2501R	24		34-21-21	ALL
	A03		W2135	2501B	24		34-21-21	ALL
	A04		W2135	0038	22		34-21-21	ALL
	A05		W2135	0040	22		34-21-21	ALL
	A06		W2135	0003	22		34-21-21	ALL
	A07		W2135	0004	22		34-21-21	ALL
	A08		W2135	0005	22		34-21-21	ALL
	A09		W2135	0006	22		34-21-21	ALL
	A10		W2135	0007	22		34-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45237J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A11		W2135	0008	22		34-21-21	ALL
	A12		W2135	2002B	24		27-61-47	ALL
	A13		W2135	2002R	24		27-61-47	ALL
	A14	UNUSED						ALL
	A15		W2135	2510R	22		31-32-15	ALL
	A16		W2135	0013	22		34-21-21	ALL
	A17		W2135	0014	22		34-21-21	ALL
	A18		W2135	0015	22		34-21-21	ALL
	A19		W2135	2510B	22		31-32-15	ALL
	A20		W2135	0032	22		34-16-21	ALL
	B01		W2135	0016	24		31-65-25	ALL
	B02		W2135	0017	24		31-65-25	ALL
	B03		W2135	0018	24		31-65-25	ALL
	B04	UNUSED						ALL
	B05		W2135	0021	24		31-65-25	ALL
	B06		W2135	0024	22		34-51-41	ALL
	B07		W2135	0029	24		31-65-25	ALL
	B08		W2135	0028	22		22-18-11	ALL
	B09		W2135	2502R	22		34-21-23	ALL
	B10		W2135	2502B	22		34-21-23	ALL
	B11		W2135	0011	22		34-21-21	ALL
	B12	UNUSED						ALL
	B13		W2135	0022	22		34-21-22	ALL
	B14		W2135	0023	22		34-21-22	ALL
	B15		W2135	2504R	24		34-58-21	ALL
	B16		W2135	2504B	24		34-58-21	ALL
	B17		W2135	2505R	24		34-58-21	ALL
	B18		W2135	2505B	24		34-58-21	ALL
	B19		W2135	0033	22		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45237J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B20		W2135	0063	24		34-61-17	ALL
	PERG	1F	W2135	2002Z			27-61-47	ALL
	PERG	1F	W2135	2501Z			34-21-21	ALL
	PERG	1F	W2135	2502Z			34-21-23	ALL
	PERG	1F	W2135	2504Z			34-58-21	ALL
	PERG	1F	W2135	2505Z			34-58-21	ALL
	PERG	1F	W2135	2510Z			31-32-15	ALL
D45237P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0523	0344	22		34-21-21	ALL
	A02		W0523	2720R	24		34-21-21	ALL
	A03		W0523	2720B	24		34-21-21	ALL
	A04		W0523	2106R	22		34-21-21	ALL
	A05		W0523	2106B	22		34-21-21	ALL
	A06		W0523	0348	22		34-21-21	ALL
	A07		W0523	0350	22		34-21-21	ALL
	A08		W0523	0351	22		34-21-21	ALL
	A09		W0523	0352	22		34-21-21	ALL
	A10		W0523	0357	22		34-21-21	ALL
	A11		W0523	0358	22		34-21-21	ALL
	A12		W0523	2515B	24		27-61-47	ALL
	A13		W0523	2515R	24		27-61-47	ALL
	A14	UNUSED						ALL
	A15		W0523	2828R	22		31-32-15	ALL
	A16		W0523	0363	22		34-21-21	ALL
	A17		W0523	0364	22		34-21-21	ALL
	A18		W0523	0365	22		34-21-21	ALL
	A19		W0523	2828B	22		31-32-15	ALL
	A20		W0523	0387	22		34-16-21	ALL
	B01		W0523	0381	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45237P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B02		W0523	0382	24		31-65-25	ALL
	B03		W0523	0383	24		31-65-25	ALL
	B04	UNUSED						ALL
	B05		W0523	0326	24		31-65-25	ALL
	B06		W0523	0385	22		34-51-41	ALL
	B07		W0523	0380	24		31-65-25	ALL
	B08		W0523	0379	22		22-18-11	ALL
	B09		W0523	2724R	24		34-21-23	ALL
	B10		W0523	2724B	24		34-21-23	ALL
	B11		W0523	0003	22		34-21-21	ALL
	B12	UNUSED						ALL
	B13		W0523	0369	22		34-21-22	ALL
	B14		W0523	0370	22		34-21-22	ALL
	B15		W0523	2789R	24		34-58-21	ALL
	B16		W0523	2789B	24		34-58-21	ALL
	B17		W0523	2790R	24		34-31-21	ALL
	B18		W0523	2790B	24		34-31-21	ALL
	B19		W0523	0378	22		22-13-11	ALL
	B20		W0523	0007	24		34-61-17	ALL
	PERG	1F	W0523	2515Z			27-61-47	ALL
	PERG	1F	W0523	2720Z			34-21-21	ALL
	PERG	1F	W0523	2724Z			34-21-23	ALL
	PERG	1F	W0523	2789Z			34-58-21	ALL
	PERG	1F	W0523	2790Z			34-31-21	ALL
	PERG	1F	W0523	2828Z			31-32-15	ALL
D45239J		**E005-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W5501	2501R	24		34-21-12	ALL
	A02		W5501	2501B	24		34-21-12	ALL
	A03		W5501	3501R	22		34-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45239J	**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A04		W5501	3501B	22		34-21-12	ALL
A05		W5501	3501Y	22		34-21-12	ALL
A06		W5501	2502R	20		34-21-12	ALL
A07		W5501	2502B	20		34-21-12	ALL
A08		W5501	3001R	24		34-21-12	ALL
A09		W5501	3001B	24		34-21-12	ALL
A10		W5501	3001Y	24		34-21-12	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5501	0005	22		34-21-12	ALL
B02		W5501	2503R	20		34-21-22	ALL
B03		W5501	2503B	20		34-21-22	ALL
B04		W5501	2001R	22		27-32-11	ALL
B05		W5501	2001B	22		27-32-11	ALL
B06		W5501	3002R	22		27-32-11	ALL
B07		W5501	3002B	22		27-32-11	ALL
B08		W5501	3002Y	22		27-32-11	ALL
B09		W5501	2504R	22		34-61-14	ALL
B10		W5501	2504B	22		34-61-14	ALL
B11		W5501	2505R	22		28-41-11	ALL
B12		W5501	2505B	22		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45239J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5501	2501Z			34-21-12	ALL
	PERG	1F	W5501	2502Z			34-21-12	ALL
	PERG	1F	W5501	2503Z			34-21-22	ALL
	PERG	1F	W5501	2504Z			34-61-14	ALL
	PERG	1F	W5501	2505Z			28-41-11	ALL
	PERG	1F	W5501	3501Z			34-21-12	ALL
D45239P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2584R	24		34-21-12	ALL
	A02		W0521	2584B	24		34-21-12	ALL
	A03		W0521	3501R	22		34-21-12	ALL
	A04		W0521	3501B	22		34-21-12	ALL
	A05		W0521	3501Y	22		34-21-12	ALL
	A06		W0521	2532R	22		34-21-12	ALL
	A07		W0521	2532B	22		34-21-12	ALL
	A08		W0521	3001R	24		34-21-12	ALL
	A09		W0521	3001B	24		34-21-12	ALL
	A10		W0521	3001Y	24		34-21-12	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45239P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0521	0188	22		34-21-12	ALL
	B02		W0521	2619R	22		34-21-22	ALL
	B03		W0521	2619B	22		34-21-22	ALL
	B04		W0521	2011R	22		27-32-11	ALL
	B05		W0521	2011B	22		27-32-11	ALL
	B06		W0521	3002R	22		27-32-11	ALL
	B07		W0521	3002B	22		27-32-11	ALL
	B08		W0521	3002Y	22		27-32-11	ALL
	B09		W0521	2520R	22		34-61-14	ALL
	B10		W0521	2520B	22		34-61-14	ALL
	B11		W0521	2571R	22		28-41-11	ALL
	B12		W0521	2571B	22		28-41-11	ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2520Z			34-61-14	ALL
	PERG	1F	W0521	2532Z			34-21-12	ALL
	PERG	1F	W0521	2571Z			28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45239P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W0521	2584Z			34-21-12	ALL
	PERG	1F	W0521	2619Z			34-21-22	ALL
	PERG	1F	W0521	3501Z			34-21-12	ALL
D45241J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5503	2501R	24		34-21-22	ALL
	A02		W5503	2501B	24		34-21-22	ALL
	A03		W5503	3501R	22		34-21-22	ALL
	A04		W5503	3501B	22		34-21-22	ALL
	A05		W5503	3501Y	22		34-21-22	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5503	3001R	24		34-21-22	ALL
	A09		W5503	3001B	24		34-21-22	ALL
	A10		W5503	3001Y	24		34-21-22	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5503	0005	22		34-21-22	ALL
	B02		W5503	2001R	22		27-32-21	ALL
	B03		W5503	2001B	22		27-32-21	ALL
	B04		W5503	3002R	22		27-32-21	ALL
	B05		W5503	3002B	22		27-32-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45241J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06		W5503	3002Y	22		27-32-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5503	2501Z			34-21-22	ALL
	PERG	1F	W5503	3501Z			34-21-22	ALL
D45241P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0523	2721R	24		34-21-22	ALL
	A02		W0523	2721B	24		34-21-22	ALL
	A03		W0523	3601R	22		34-21-22	ALL
	A04		W0523	3601B	22		34-21-22	ALL
	A05		W0523	3601Y	22		34-21-22	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0523	3101R	24		34-21-22	ALL
	A09		W0523	3101B	24		34-21-22	ALL
	A10		W0523	3101Y	24		34-21-22	ALL
	A11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45241P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0523	0373	22		34-21-22	ALL
	B02		W0523	2107R	22		27-32-21	ALL
	B03		W0523	2107B	22		27-32-21	ALL
	B04		W0523	3102R	22		27-32-21	ALL
	B05		W0523	3102B	22		27-32-21	ALL
	B06		W0523	3102Y	22		27-32-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45241P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
PERG	1F	W0523	2721Z			34-21-22	ALL
PERG	1F	W0523	3601Z			34-21-22	ALL
D45245J	**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W5161	2519R	22		34-61-15	ALL
A02		W5161	2519B	22		34-61-15	ALL
A03		W5161	2514R	24		31-65-15	ALL
A04		W5161	2514B	24		31-65-15	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5161	0010	22		34-61-16	ALL
A08		W5161	0011	22		34-61-16	ALL
A09	UNUSED						ALL
A10		W5161	0009	24		31-65-15	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W5161	2525R	24		31-65-15	ALL
A14		W5161	2525B	24		31-65-15	ALL
A15		W5161	2526R	24		31-65-15	ALL
A16		W5161	2526B	24		31-65-15	ALL
A17		W5161	3501R	22		34-21-12	ALL
A18		W5161	3501B	22		34-21-12	ALL
A19		W5161	3501Y	22		34-21-12	ALL
A20		W5161	0025	22		34-61-17	ALL
B01		W5161	2527R	24		34-21-12	ALL
B02		W5161	2527B	24		34-21-12	ALL
B03	UNUSED						ALL
B04		W5161	0026	22		34-21-11	ALL
B05		W5161	0038	22		34-21-11	ALL
B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45245J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W5161	0027	20		SPARE	ALL
	B14		W5161	0028	20		SPARE	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5161	2513R	24		31-65-15	ALL
	B18		W5161	2513B	24		31-65-15	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5161	2513Z			31-65-15	ALL
	PERG	1F	W5161	2514Z			31-65-15	ALL
	PERG	1F	W5161	2519Z			34-61-15	ALL
	PERG	1F	W5161	2525Z			31-65-15	ALL
	PERG	1F	W5161	2526Z			31-65-15	ALL
	PERG	1F	W5161	2527Z			34-21-12	ALL
	PERG	1F	W5161	3501Z			34-21-12	ALL
D45245P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2525R	22		34-61-15	ALL
	A02		W0521	2525B	22		34-61-15	ALL
	A03		W0521	2578R	24		31-65-15	ALL
	A04		W0521	2578B	24		31-65-15	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0521	0024	22		34-61-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45245P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A08		W0521	0025	22		34-61-16	ALL
A09	UNUSED						ALL
A10		W0521	0061	24		31-65-15	ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0521	2575R	24		31-65-15	ALL
A14		W0521	2575B	24		31-65-15	ALL
A15		W0521	2576R	24		31-65-15	ALL
A16		W0521	2576B	24		31-65-15	ALL
A17		W0521	3503R	22		34-21-12	ALL
A18		W0521	3503B	22		34-21-12	ALL
A19		W0521	3503Y	22		34-21-12	ALL
A20		W0521	0224	24		34-61-17	ALL
B01		W0521	2531R	24		34-21-12	ALL
B02		W0521	2531B	24		34-21-12	ALL
B03	UNUSED						ALL
B04		W0521	0150	22		34-21-11	ALL
B05		W0521	0149	22		34-21-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45245P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B17		W0521	2577R	24		31-65-15	ALL
	B18		W0521	2577B	24		31-65-15	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2525Z			34-61-15	ALL
	PERG	1F	W0521	2531Z			34-21-12	ALL
	PERG	1F	W0521	2575Z			31-65-15	ALL
	PERG	1F	W0521	2576Z			31-65-15	ALL
	PERG	1F	W0521	2577Z			31-65-15	ALL
	PERG	1F	W0521	2578Z			31-65-15	ALL
	PERG	1F	W0521	3503Z			34-21-12	ALL
D45247J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5163	0010	24		31-65-25	ALL
	A02		W5163	0011	24		31-65-25	ALL
	A03		W5163	0012	24		31-65-25	ALL
	A04		W5163	2523R	24		31-65-25	ALL
	A05		W5163	2523B	24		31-65-25	ALL
	A06		W5163	2524R	24		31-65-25	ALL
	A07		W5163	2524B	24		31-65-25	ALL
	A08	UNUSED						ALL
	A09		W5163	3501R	22		34-21-22	ALL
	A10		W5163	3501B	22		34-21-22	ALL
	A11		W5163	3501Y	22		34-21-22	ALL
	A12		W5163	2526R	24		34-21-22	ALL
	A13		W5163	2526B	24		34-21-22	ALL
	A14		W5163	2532R	24		34-55-21	ALL
	A15		W5163	2532B	24		34-55-21	ALL
	A16	UNUSED						ALL
	A17		W5163	2518R	24		34-21-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45247J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A18		W5163	2518B	24		34-21-23	ALL
A19		W5163	0026	20		34-61-11	ALL
A20		W5163	0027	20		34-61-11	ALL
B01		W5163	0028	24		73-21-31	ALL
B02		W5163	0029	24		73-21-31	ALL
B03		W5163	0030	24		73-21-31	ALL
B04		W5163	2510R	24		34-21-24	ALL
B05		W5163	2510B	24		34-21-24	ALL
B06		W5163	2502R	24		34-21-24	ALL
B07		W5163	2502B	24		34-21-24	ALL
B08		W5163	0002	24		31-65-25	ALL
B09		W5163	2535R	24		34-61-14	ALL
B10		W5163	2535B	24		34-61-14	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W5163	2537R	24		34-21-24	ALL
B16		W5163	2537B	24		34-21-24	ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W5163	2542R	24		34-21-24	ALL
B20		W5163	2542B	24		34-21-24	ALL
PERG	1F	W5163	2502Z			34-21-24	ALL
PERG	1F	W5163	2510Z			34-21-24	ALL
PERG	1F	W5163	2518Z			34-21-23	ALL
PERG	1F	W5163	2523Z			31-65-25	ALL
PERG	1F	W5163	2524Z			31-65-25	ALL
PERG	1F	W5163	2526Z			34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45247J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5163	2532Z			34-55-21	ALL
	PERG	1F	W5163	2535Z			34-61-14	ALL
	PERG	1F	W5163	2537Z			34-21-24	ALL
	PERG	1F	W5163	2542Z			34-21-24	ALL
	PERG	1F	W5163	3501Z			34-21-22	ALL
D45247P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0523	0383	24		31-65-25	ALL
	A02		W0523	0382	24		31-65-25	ALL
	A03		W0523	0381	24		31-65-25	ALL
	A04		W0523	2757R	24		31-65-25	ALL
	A05		W0523	2757B	24		31-65-25	ALL
	A06		W0523	2758R	24		31-65-25	ALL
	A07		W0523	2758B	24		31-65-25	ALL
	A08	UNUSED						ALL
	A09		W0523	3603R	22		34-21-22	ALL
	A10		W0523	3603B	22		34-21-22	ALL
	A11		W0523	3603Y	22		34-21-22	ALL
	A12		W0523	2722R	24		34-21-22	ALL
	A13		W0523	2722B	24		34-21-22	ALL
	A14		W0523	2765R	24		34-55-21	ALL
	A15		W0523	2765B	24		34-55-21	ALL
	A16	UNUSED						ALL
	A17		W0523	2839R	24		34-21-23	ALL
	A18		W0523	2839B	24		34-21-23	ALL
	A19		W0523	0307	20		34-61-11	ALL
	A20		W0523	0301	20		34-61-11	ALL
	B01		W0523	0006	24		73-21-31	ALL
	B02		W0523	0004	24		73-21-31	ALL
	B03		W0523	0005	24		73-21-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45247P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
B04		W0523	2739R	24		34-21-24	ALL
B05		W0523	2739B	24		34-21-24	ALL
B06		W0523	2744R	24		34-21-24	ALL
B07		W0523	2744B	24		34-21-24	ALL
B08		W0523	0380	24		31-65-25	ALL
B09		W0523	2512R	24		34-61-14	ALL
B10		W0523	2512B	24		34-61-14	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W0523	2820R	24		34-21-24	ALL
B16		W0523	2820B	24		34-21-24	ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19		W0523	2747R	24		34-21-24	ALL
B20		W0523	2747B	24		34-21-24	ALL
PERG	1F	W0523	2512Z			34-61-14	ALL
PERG	1F	W0523	2722Z			34-21-22	ALL
PERG	1F	W0523	2739Z			34-21-24	ALL
PERG	1F	W0523	2744Z			34-21-24	ALL
PERG	1F	W0523	2747Z			34-21-24	ALL
PERG	1F	W0523	2757Z			31-65-25	ALL
PERG	1F	W0523	2758Z			31-65-25	ALL
PERG	1F	W0523	2765Z			34-55-21	ALL
PERG	1F	W0523	2820Z			34-21-24	ALL
PERG	1F	W0523	2839Z			34-21-23	ALL
PERG	1F	W0523	3603Z			34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45255J		**E005-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W5161	2501R	24		34-21-14	ALL
	A02		W5161	2501B	24		34-21-14	ALL
	A03		W5161	2502R	24		34-21-14	ALL
	A04		W5161	2502B	24		34-21-14	ALL
	A05		W5161	2503R	24		SPARE	ALL
	A06		W5161	2503B	24		SPARE	ALL
	A07		W5161	0012	22		34-16-11	ALL
	A08		W5161	2506R	24		34-21-13	ALL
	A09		W5161	2506B	24		34-21-13	ALL
	A10		W5161	2507R	24		34-21-13	ALL
	A11		W5161	2507B	24		34-21-13	ALL
	A12		W5161	2508R	24		34-21-13	ALL
	A13		W5161	2508B	24		34-21-13	ALL
	A14		W5161	2509R	24		34-21-13	ALL
	A15		W5161	2509B	24		34-21-13	ALL
	A16	UNUSED						ALL
	A17		W5161	2522R	22		31-32-15	ALL
	A18		W5161	2522B	22		31-32-15	ALL
	A19		W5161	2540R	24		34-61-22	ALL
	A20		W5161	2540B	24		34-61-22	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5161	2505R	24		22-31-52	ALL
	B04		W5161	2505B	24		22-31-52	ALL
	B05		W5161	2541R	24		34-61-22	ALL
	B06		W5161	2541B	24		34-61-22	ALL
	B07		W5161	0039	20		34-61-22	ALL
	B08		W5161	0041	20		34-61-22	ALL
	B09		W5161	2542R	24		34-61-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45255J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B10		W5161	2542B	24		34-61-22	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W5161	0005	22		34-61-12	ALL
	B14		W5161	0006	22		34-61-12	ALL
	B15		W5161	2516R	24		34-61-14	ALL
	B16		W5161	2516B	24		34-61-14	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5161	2501Z			34-21-14	ALL
	PERG	1F	W5161	2502Z			34-21-14	ALL
	PERG	1F	W5161	2503Z			SPARE	ALL
	PERG	1F	W5161	2505Z			22-31-52	ALL
	PERG	1F	W5161	2506Z			34-21-13	ALL
	PERG	1F	W5161	2507Z			34-21-13	ALL
	PERG	1F	W5161	2508Z			34-21-13	ALL
	PERG	1F	W5161	2509Z			34-21-13	ALL
	PERG	1F	W5161	2516Z			34-61-14	ALL
	PERG	1F	W5161	2522Z			31-32-15	ALL
	PERG	1F	W5161	2540Z			34-61-22	ALL
	PERG	1F	W5161	2541Z			34-61-22	ALL
	PERG	1F	W5161	2542Z			34-61-22	ALL
D45255P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2550R	24		34-21-14	ALL
	A02		W0521	2550B	24		34-21-14	ALL
	A03		W0521	2934R	24		34-21-14	ALL
	A04		W0521	2934B	24		34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45255P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0521	0205	22		34-16-11	ALL
	A08		W0521	2540R	24		34-21-13	ALL
	A09		W0521	2540B	24		34-21-13	ALL
	A10		W0521	2541R	24		34-21-13	ALL
	A11		W0521	2541B	24		34-21-13	ALL
	A12		W0521	2546R	24		34-21-13	ALL
	A13		W0521	2546B	24		34-21-13	ALL
	A14		W0521	2547R	24		34-21-13	ALL
	A15		W0521	2547B	24		34-21-13	ALL
	A16	UNUSED						ALL
	A17		W0521	2516R	22		31-32-15	ALL
	A18		W0521	2516B	22		31-32-15	ALL
	A19		W0521	2918R	24		34-61-22	ALL
	A20		W0521	2918B	24		34-61-22	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0521	2586R	24		22-31-52	ALL
	B04		W0521	2586B	24		22-31-52	ALL
	B05		W0521	2644R	24		34-61-22	ALL
	B06		W0521	2644B	24		34-61-22	ALL
	B07		W0521	0243	20		34-61-22	ALL
	B08		W0521	0242	20		34-61-22	ALL
	B09		W0521	2501R	24		34-61-22	ALL
	B10		W0521	2501B	24		34-61-22	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13		W0521	0018	22		34-61-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45255P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B14		W0521	0019	22		34-61-12	ALL
	B15		W0521	2518R	24		34-61-14	ALL
	B16		W0521	2518B	24		34-61-14	ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2501Z			34-61-22	ALL
	PERG	1F	W0521	2516Z			31-32-15	ALL
	PERG	1F	W0521	2518Z			34-61-14	ALL
	PERG	1F	W0521	2540Z			34-21-13	ALL
	PERG	1F	W0521	2541Z			34-21-13	ALL
	PERG	1F	W0521	2546Z			34-21-13	ALL
	PERG	1F	W0521	2547Z			34-21-13	ALL
	PERG	1F	W0521	2550Z			34-21-14	ALL
	PERG	1F	W0521	2586Z			22-31-52	ALL
	PERG	1F	W0521	2644Z			34-61-22	ALL
	PERG	1F	W0521	2918Z			34-61-22	ALL
	PERG	1F	W0521	2934Z			34-21-14	ALL
D45257J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5163	2501R	24		SPARE	ALL
	A02		W5163	2501B	24		SPARE	ALL
	A03		W5163	2511R	24		34-21-24	ALL
	A04		W5163	2511B	24		34-21-24	ALL
	A05		W5163	2506R	24		34-21-24	ALL
	A06		W5163	2506B	24		34-21-24	ALL
	A07	UNUSED						ALL
	A08		W5163	0038	22		34-21-16	ALL
	A09		W5163	2508R	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45257J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A10		W5163	2508B	24		SPARE	ALL
	A11		W5163	2509R	24		SPARE	ALL
	A12		W5163	2509B	24		SPARE	ALL
	A13	UNUSED						ALL
	A14		W5163	0003	22		34-21-21	ALL
	A15	UNUSED						ALL
	A16		W5163	0005	20		34-21-21	ALL
	A17		W5163	0006	20		34-21-21	ALL
	A18		W5163	0007	20		34-21-21	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5163	2512R	24		34-21-23	ALL
	B02		W5163	2512B	24		34-21-23	ALL
	B03		W5163	2513R	24		34-21-23	ALL
	B04		W5163	2513B	24		34-21-23	ALL
	B05		W5163	2514R	24		34-21-23	ALL
	B06		W5163	2514B	24		34-21-23	ALL
	B07		W5163	0008	22		34-61-12	ALL
	B08	UNUSED						ALL
	B09		W5163	0009	24		31-65-25	ALL
	B10	UNUSED						ALL
	B11		W5163	0049	22		34-61-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5163	2520R	24		31-65-25	ALL
	B18		W5163	2520B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45257J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B19		W5163	2521R	24		31-65-25	ALL
B20		W5163	2521B	24		31-65-25	ALL
PERG	1F	W5163	2501Z			SPARE	ALL
PERG	1F	W5163	2506Z			34-21-24	ALL
PERG	1F	W5163	2508Z			SPARE	ALL
PERG	1F	W5163	2509Z			SPARE	ALL
PERG	1F	W5163	2511Z			34-21-24	ALL
PERG	1F	W5163	2512Z			34-21-23	ALL
PERG	1F	W5163	2513Z			34-21-23	ALL
PERG	1F	W5163	2514Z			34-21-23	ALL
PERG	1F	W5163	2520Z			31-65-25	ALL
PERG	1F	W5163	2521Z			31-65-25	ALL
D45257P	**E005-02/ /**		**PLUG-**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0523	2745R	24		34-21-24	ALL
A04		W0523	2745B	24		34-21-24	ALL
A05		W0523	2746R	24		34-21-24	ALL
A06		W0523	2746B	24		34-21-24	ALL
A07	UNUSED						ALL
A08		W0523	0388	22		34-21-16	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0523	0312	22		34-21-21	ALL
A15	UNUSED						ALL
A16		W0523	0366	20		34-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45257P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A17		W0523	0332	20		34-21-21	ALL
	A18		W0523	0335	20		34-21-21	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0523	2736R	24		34-21-23	ALL
	B02		W0523	2736B	24		34-21-23	ALL
	B03		W0523	2732R	24		34-21-23	ALL
	B04		W0523	2732B	24		34-21-23	ALL
	B05		W0523	2733R	24		34-21-23	ALL
	B06		W0523	2733B	24		34-21-23	ALL
	B07		W0523	0311	22		34-61-12	ALL
	B08	UNUSED						ALL
	B09		W0523	0326	24		31-65-25	ALL
	B10	UNUSED						ALL
	B11		W0521	0010	22		34-61-12	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0523	2755R	24		31-65-25	ALL
	B18		W0523	2755B	24		31-65-25	ALL
	B19		W0523	2756R	24		31-65-25	ALL
	B20		W0523	2756B	24		31-65-25	ALL
	PERG	1F	W0523	2732Z			34-21-23	ALL
	PERG	1F	W0523	2733Z			34-21-23	ALL
	PERG	1F	W0523	2736Z			34-21-23	ALL
	PERG	1F	W0523	2745Z			34-21-24	ALL
	PERG	1F	W0523	2746Z			34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45257P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
PERG	1F	W0523	2755Z			31-65-25	ALL
PERG	1F	W0523	2756Z			31-65-25	ALL
D45261J	**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W5461	2033R	24		SPARE	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07		W5461	2009R	22		34-61-15	ALL
A08		W5461	2010R	24		34-61-14	ALL
A09		W5461	2005R	24		31-35-02	ALL
A10		W5461	2005B	24		31-35-02	ALL
A11	UNUSED						ALL
A12		W5461	2101B	22		27-32-11	ALL
A13	UNUSED						ALL
A14		W5461	0034	20		34-61-22	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W5461	3001R	22		27-32-11	ALL
B04		W5461	3001B	22		27-32-11	ALL
B05		W5461	3001Y	22		27-32-11	ALL
B06		W5461	2033B	24		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45261J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B07		W5461	2009B	22		34-61-15	ALL
	B08		W5461	2010B	24		34-61-14	ALL
	B09		W5461	2032R	24		SPARE	ALL
	B10		W5461	2032B	24		SPARE	ALL
	B11	UNUSED						ALL
	B12		W5461	2101R	22		27-32-11	ALL
	B13	UNUSED						ALL
	B14		W5461	2029R	24		SPARE	ALL
	B15		W5461	2029B	24		SPARE	ALL
	B16		W5461	2030R	24		SPARE	ALL
	B17		W5461	2030B	24		SPARE	ALL
	B18	UNUSED						ALL
	B19		W5461	0077	22		34-21-12	ALL
	B20	UNUSED						ALL
	PERG	1F	W5461	2005Z			31-35-02	ALL
	PERG	1F	W5461	2009Z			34-61-15	ALL
	PERG	1F	W5461	2010Z			34-61-14	ALL
	PERG	1F	W5461	2029Z			SPARE	ALL
	PERG	1F	W5461	2030Z			SPARE	ALL
	PERG	1F	W5461	2032Z			SPARE	ALL
	PERG	1F	W5461	2033Z			SPARE	ALL
D45261P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0521	2523R	22		34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45261P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A08		W0521	2522R	24		34-61-14	ALL
A09		W0521	2645R	24		31-35-02	ALL
A10		W0521	2645B	24		31-35-02	ALL
A11	UNUSED						ALL
A12		W0521	2011B	22		27-32-11	ALL
A13	UNUSED						ALL
A14		W0521	0204	20		34-61-22	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0521	3002R	22		27-32-11	ALL
B04		W0521	3002B	22		27-32-11	ALL
B05		W0521	3002Y	22		27-32-11	ALL
B06	UNUSED						ALL
B07		W0521	2523B	22		34-61-15	ALL
B08		W0521	2522B	24		34-61-14	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12		W0521	2011R	22		27-32-11	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45261P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19		W0521	0265	22		34-21-12	ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2522Z			34-61-14	ALL
	PERG	1F	W0521	2523Z			34-61-15	ALL
	PERG	1F	W0521	2645Z			31-35-02	ALL
D45263J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5463	2011R	24		SPARE	ALL
	A04		W5463	2012R	24		34-61-14	ALL
	A05		W5463	0022	22		SPARE	ALL
	A06	UNUSED						ALL
	A07		W5463	2013R	24		SPARE	ALL
	A08		W5463	2014R	24		SPARE	ALL
	A09		W5463	2015R	24		34-21-24	ALL
	A10		W5463	0001	22		34-21-21	ALL
	A11		W5463	0023	22		22-13-11	ALL
	A12		W5463	2018R	24		34-61-14	ALL
	A13		W5463	2035R	24		SPARE	ALL
	A14	UNUSED						ALL
	A15		W5463	2017R	24		34-21-23	ALL
	A16		W5463	2016R	24		34-21-23	ALL
	A17		W5463	2002R	22		27-32-21	ALL
	A18	UNUSED						ALL
	A19		W5463	2022R	24		SPARE	ALL
	A20		W5463	2022B	24		SPARE	ALL
	B01		W5463	2007R	24		31-35-02	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45263J	**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B02		W5463	2007B	24		31-35-02	ALL
B03		W5463	2011B	24		SPARE	ALL
B04		W5463	2012B	24		34-61-14	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W5463	2013B	24		SPARE	ALL
B08		W5463	2014B	24		SPARE	ALL
B09		W5463	2015B	24		34-21-24	ALL
B10		W5463	0090	24		34-61-17	ALL
B11		W5463	0091	24		34-61-17	ALL
B12		W5463	2018B	24		34-61-14	ALL
B13		W5463	2035B	24		SPARE	ALL
B14	UNUSED						ALL
B15		W5463	2017B	24		34-21-23	ALL
B16		W5463	2016B	24		34-21-23	ALL
B17		W5463	2002B	22		27-32-21	ALL
B18		W5463	3001R	22		27-32-21	ALL
B19		W5463	3001B	22		27-32-21	ALL
B20		W5463	3001Y	22		27-32-21	ALL
PERG	1F	W5463	2007Z			31-35-02	ALL
PERG	1F	W5463	2011Z			SPARE	ALL
PERG	1F	W5463	2012Z			34-61-14	ALL
PERG	1F	W5463	2013Z			SPARE	ALL
PERG	1F	W5463	2014Z			SPARE	ALL
PERG	1F	W5463	2015Z			34-21-24	ALL
PERG	1F	W5463	2016Z			34-21-23	ALL
PERG	1F	W5463	2017Z			34-21-23	ALL
PERG	1F	W5463	2018Z			34-61-14	ALL
PERG	1F	W5463	2022Z			SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45263J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	PERG	1F	W5463	2035Z			SPARE	ALL
D45263P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0523	2712R	24		34-61-14	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0523	2742R	24		34-21-24	ALL
	A10		W0523	0368	22		34-21-21	ALL
	A11		W0523	0378	22		22-13-11	ALL
	A12		W0523	2708R	24		34-61-14	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0523	2728R	24		34-21-23	ALL
	A16		W0523	2727R	24		34-21-23	ALL
	A17		W0523	2107R	22		27-32-21	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0523	2750R	24		31-35-02	ALL
	B02		W0523	2750B	24		31-35-02	ALL
	B03	UNUSED						ALL
	B04		W0523	2712B	24		34-61-14	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45263P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
B08	UNUSED						ALL
B09		W0523	2742B	24		34-21-24	ALL
B10		W0523	0010	24		34-61-17	ALL
B11		W0523	0013	24		34-61-17	ALL
B12		W0523	2708B	24		34-61-14	ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W0523	2728B	24		34-21-23	ALL
B16		W0523	2727B	24		34-21-23	ALL
B17		W0523	2107B	22		27-32-21	ALL
B18		W0523	3102R	22		27-32-21	ALL
B19		W0523	3102B	22		27-32-21	ALL
B20		W0523	3102Y	22		27-32-21	ALL
PERG	1F	W0523	2708Z			34-61-14	ALL
PERG	1F	W0523	2712Z			34-61-14	ALL
PERG	1F	W0523	2727Z			34-21-23	ALL
PERG	1F	W0523	2728Z			34-21-23	ALL
PERG	1F	W0523	2742Z			34-21-24	ALL
PERG	1F	W0523	2750Z			31-35-02	ALL
D45265J	**E005-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02		W5161	0030	24		73-21-31	ALL
A03		W5161	0031	24		73-21-31	ALL
A04		W5161	0032	24		73-21-31	ALL
A05		W5161	0033	24		73-21-31	ALL
A06		W5161	2529R	24		34-21-14	ALL
A07		W5161	2529B	24		34-21-14	ALL
A08		W5161	2530R	24		34-21-14	ALL
A09		W5161	2530B	24		34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45265J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A10	UNUSED						ALL
	A11		W5161	2543R	22		49-62-11	ALL
	A12		W5161	2543B	22		49-62-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W5161	4001Y	24		31-65-15	ALL
	A18		W5161	4001R	24		31-65-15	ALL
	A19		W5161	4002Y	24		31-65-25	ALL
	A20		W5161	4002R	24		31-65-25	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5161	4001B	24		31-65-15	ALL
	B18		W5161	4001G	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45265J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B19		W5161	4002B	24		31-65-25	ALL
	B20		W5161	4002G	24		31-65-25	ALL
	PERG	1F	W5161	2529Z			34-21-14	ALL
	PERG	1F	W5161	2530Z			34-21-14	ALL
	PERG	1F	W5161	2543Z			49-62-11	ALL
	PERG	1F	W5161	4001Z			31-65-15	ALL
	PERG	1F	W5161	4002Z			31-65-25	ALL
D45265P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W0521	0226	24		73-21-31	ALL
	A03		W0521	0227	24		73-21-31	ALL
	A04		W0521	0228	24		73-21-31	ALL
	A05		W0521	0229	24		73-21-31	ALL
	A06		W0521	2554R	24		34-21-14	ALL
	A07		W0521	2554B	24		34-21-14	ALL
	A08		W0521	2555R	24		34-21-14	ALL
	A09		W0521	2555B	24		34-21-14	ALL
	A10	UNUSED						ALL
	A11		W0521	2656R	22		49-62-11	ALL
	A12		W0521	2656B	22		49-62-11	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17		W0521	4006Y	24		31-65-15	ALL
	A18		W0521	4006R	24		31-65-15	ALL
	A19		W0521	4007Y	24		31-65-25	ALL
	A20		W0521	4007R	24		31-65-25	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45265P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0521	4006B	24		31-65-15	ALL
	B18		W0521	4006G	24		31-65-15	ALL
	B19		W0521	4007B	24		31-65-25	ALL
	B20		W0521	4007G	24		31-65-25	ALL
	PERG	1F	W0521	2554Z			34-21-14	ALL
	PERG	1F	W0521	2555Z			34-21-14	ALL
	PERG	1F	W0521	2656Z			49-62-11	ALL
	PERG	1F	W0521	4006Z			31-65-15	ALL
	PERG	1F	W0521	4007Z			31-65-25	ALL
D45293J		**E005-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W2597	2514R	24		34-61-18	ALL
	A02		W2597	2515R	24		34-61-18	ALL
	A03		W2597	0018	24		34-61-18	ALL
	A04		W2597	2517R	24		22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45293J	**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
A05		W2597	0020	24		22-11-53	ALL
A06		W2597	0021	24		22-11-53	ALL
A07		W2597	0022	24		22-11-53	ALL
A08		W2597	0019	24		34-61-26	ALL
A09		W2597	2516R	24		34-61-26	ALL
A10		W2597	2516B	24		34-61-26	ALL
A11	UNUSED						ALL
A12		W2597	0033	24		34-24-15	ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W2597	2514B	24		34-61-18	ALL
B02		W2597	2515B	24		34-61-18	ALL
B03		W2597	0023	24		22-11-53	ALL
B04		W2597	2517B	24		22-11-53	ALL
B05		W2597	2522R	24		34-49-11	ALL
B06		W2597	2522B	24		34-49-11	ALL
B07		W2597	0027	24		34-49-11	ALL
B08		W2597	2523B	24		27-61-47	ALL
B09		W2597	2523R	24		27-61-47	ALL
B10		W2597	2524B	24		27-61-47	ALL
B11		W2597	2524R	24		27-61-47	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45293J		**E005-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W2597	2514Z			34-61-18	ALL
	PERG	1F	W2597	2515Z			34-61-18	ALL
	PERG	1F	W2597	2516Z			34-61-26	ALL
	PERG	1F	W2597	2517Z			22-11-53	ALL
	PERG	1F	W2597	2522Z			34-49-11	ALL
	PERG	1F	W2597	2523Z			27-61-47	ALL
	PERG	1F	W2597	2524Z			27-61-47	ALL
D45293P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2527R	24		34-61-18	ALL
	A02		W0521	2913R	24		34-61-18	ALL
	A03		W0521	0139	24		34-61-18	ALL
	A04		W0521	2917R	24		22-11-53	ALL
	A05		W0521	0280	24		22-11-53	ALL
	A06		W0521	0281	24		22-11-53	ALL
	A07		W0521	0282	24		22-11-53	ALL
	A08		W0521	0277	24		34-61-26	ALL
	A09		W0521	2916R	24		34-61-26	ALL
	A10		W0521	2916B	24		34-61-26	ALL
	A11	UNUSED						ALL
	A12		W0521	0339	22		34-24-15	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45293P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0521	2527B	24		34-61-18	ALL
B02		W0521	2913B	24		34-61-18	ALL
B03		W0521	0283	24		22-11-53	ALL
B04		W0521	2917B	24		22-11-53	ALL
B05		W0521	2719R	24		34-49-11	ALL
B06		W0521	2719B	24		34-49-11	ALL
B07		W0521	0315	24		34-49-11	ALL
B08		W0521	2740B	24		27-61-47	ALL
B09		W0521	2740R	24		27-61-47	ALL
B10		W0521	2739B	24		27-61-47	ALL
B11		W0521	2739R	24		27-61-47	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0521	2527Z			34-61-18	ALL
PERG	1F	W0521	2719Z			34-49-11	ALL
PERG	1F	W0521	2739Z			27-61-47	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45293P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W0521	2740Z			27-61-47	ALL
	PERG	1F	W0521	2913Z			34-61-18	ALL
	PERG	1F	W0521	2916Z			34-61-26	ALL
	PERG	1F	W0521	2917Z			22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45449J		**AB0366/ /**		**RCPT**				**ALL**
	A-1		W3477	4007R	24		44-21-12	ALL
	A-2		W3477	4007Y	24		44-21-12	ALL
	A-3		W3477	4007B	24		44-21-12	ALL
	A-4		W3477	4007G	24		44-21-12	ALL
	B-1		W3477	4008R	24		44-21-12	ALL
	B-2		W3477	4008Y	24		44-21-12	ALL
	B-3		W3477	4008B	24		44-21-12	ALL
	B-4		W3477	4008G	24		44-21-12	ALL
	=CA		W3477	4007Z			44-21-12	ALL
	=CB		W3477	4008Z			44-21-12	ALL
D45485J		**AB0373/ /**		**RCPT**				**ALL**
	A-1		W3477	4013Y	24		44-21-12	ALL
	A-2		W3477	4013R	24		44-21-12	ALL
	A-3		W3477	4013G	24		44-21-12	ALL
	A-4		W3477	4013B	24		44-21-12	ALL
	B-1		W3477	4014Y	24		44-21-12	ALL
	B-2		W3477	4014R	24		44-21-12	ALL
	B-3		W3477	4014G	24		44-21-12	ALL
	B-4		W3477	4014B	24		44-21-12	ALL
	C-1		W3477	4015Y	24		44-21-12	ALL
	C-2		W3477	4015R	24		44-21-12	ALL
	C-3		W3477	4015G	24		44-21-12	ALL
	C-4		W3477	4015B	24		44-21-12	ALL
	D-1		W3477	4016Y	24		44-21-12	ALL
	D-2		W3477	4016R	24		44-21-12	ALL
	D-3		W3477	4016G	24		44-21-12	ALL
	D-4		W3477	4016B	24		44-21-12	ALL
	=CA		W3477	4013Z			44-21-12	ALL
	=CB		W3477	4014Z			44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D45485J		**AB0373/ /**		**RCPT (continued)**				**ALL**
	=CC		W3477	4015Z			44-21-12	ALL
	=CD		W3477	4016Z			44-21-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45515J		**E001-01/ /**		**RECPT**				**ALL**
	A01		W0111	0908	24		22-11-75	ALL
	A02		W0111	0909	24		22-11-75	ALL
	A03		W0111	0910	24		22-11-75	ALL
	A04		W0111	0911	24		22-11-75	ALL
	A05		W0111	0912	24		22-11-75	ALL
	A06		W0111	0913	24		22-11-75	ALL
	A07		W0111	0914	24		22-11-75	ALL
	A08		W0111	0915	24		22-11-75	ALL
	A09		W0111	0916	24		22-11-75	ALL
	A10		W0111	0917	24		22-11-75	ALL
	A11		W0111	0918	24		22-11-75	ALL
	A12		W0111	0919	24		22-11-75	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18		W0111	0952	20		22-13-11	ALL
	A19		W0111	0953	20		22-13-11	ALL
	A20		W0111	0954	22		22-13-11	ALL
	B01		W0111	0920	24		22-11-75	ALL
	B02		W0111	0921	24		22-11-75	ALL
	B03		W0111	0923	24		22-11-75	ALL
	B04		W0111	0924	24		22-11-75	ALL
	B05		W0111	0925	24		22-11-75	ALL
	B06		W0111	0926	24		22-11-75	ALL
	B07		W0111	0922	24		22-11-75	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45515J		**E001-01/ /**		**RECPT (continued)**				**ALL**
	B10		W0111	0976	20		78-34-11	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D45515P		**E001-01/ /**		**PLUG-**				**ALL**
	A01		W5463	0061	24		22-11-75	ALL
	A02		W5463	0062	24		22-11-75	ALL
	A03		W5463	0063	24		22-11-75	ALL
	A04		W5463	0064	24		22-11-75	ALL
	A05		W5463	0065	24		22-11-75	ALL
	A06		W5463	0066	24		22-11-75	ALL
	A07		W5463	0067	24		22-11-75	ALL
	A08		W5463	0068	24		22-11-75	ALL
	A09		W5463	0069	24		22-11-75	ALL
	A10		W5463	0070	24		22-11-75	ALL
	A11		W5463	0071	24		22-11-75	ALL
	A12		W5463	0072	24		22-11-75	ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45515P	**E001-01/ /**		**PLUG- (continued)**				**ALL**
A18		W5463	0011	20		22-13-11	ALL
A19		W5463	0012	20		22-13-11	ALL
A20		W5463	0013	20		22-13-11	ALL
B01		W5463	0073	24		22-11-75	ALL
B02		W5463	0074	24		22-11-75	ALL
B03		W5463	0075	24		22-11-75	ALL
B04		W5463	0076	24		22-11-75	ALL
B05		W5463	0077	24		22-11-75	ALL
B06		W5463	0078	24		22-11-75	ALL
B07		W5463	0080	24		22-11-75	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W5463	0099	20		78-34-11	ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16	UNUSED						ALL
B17	UNUSED						ALL
B18	UNUSED						ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
D45521J	**E005-02/ /**		**RCPT-**				**ALL**
A01	UNUSED						ALL
A02		W3477	2005R	22		44-21-20	ALL
A03		W3477	2007R	22		44-21-20	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45521J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	A06		W3477	2003R	22		44-21-20	ALL
	A07	UNUSED						ALL
	A08		W3477	2004R	22		44-21-20	ALL
	A09	UNUSED						ALL
	A10		W3477	2006R	22		44-21-20	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W3477	2005B	22		44-21-20	ALL
	B03		W3477	2007B	22		44-21-20	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W3477	2003B	22		44-21-20	ALL
	B07	UNUSED						ALL
	B08		W3477	2004B	22		44-21-20	ALL
	B09	UNUSED						ALL
	B10		W3477	2006B	22		44-21-20	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45521J		**E005-02/ /**		**RCPT- (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W3477	2003Z			44-21-20	ALL
	PERG	1F	W3477	2004Z			44-21-20	ALL
	PERG	1F	W3477	2005Z			44-21-20	ALL
	PERG	1F	W3477	2006Z			44-21-20	ALL
	PERG	1F	W3477	2007Z			44-21-20	ALL
D45521P		**E005-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W0521	2765R	24		34-61-15	ALL
	A03		W0521	2754R	24		34-21-13	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0521	2697R	22		44-21-20	ALL
	A07	UNUSED						ALL
	A08		W0521	2692R	22		44-21-20	ALL
	A09	UNUSED						ALL
	A10		W0521	2764R	24		34-21-14	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45521P		**E005-02/ /**		**PLUG- (continued)**				**ALL**
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0521	2765B	24		34-61-15	ALL
	B03		W0521	2754B	24		34-21-13	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0521	2697B	22		44-21-20	ALL
	B07	UNUSED						ALL
	B08		W0521	2692B	22		44-21-20	ALL
	B09	UNUSED						ALL
	B10		W0521	2764B	24		34-21-14	ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0521	2692Z			44-21-20	ALL
	PERG	1F	W0521	2697Z			44-21-20	ALL
	PERG	1F	W0521	2754Z			34-21-13	ALL
	PERG	1F	W0521	2764Z			34-21-14	ALL
	PERG	1F	W0521	2765Z			34-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45563J		**E005-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W5163	2551R	24		34-49-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5163	0019	24		34-49-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W5163	4001Y	24		31-65-15	ALL
	A16		W5163	4001R	24		31-65-15	ALL
	A17		W5163	4002Y	24		31-65-25	ALL
	A18		W5163	4002R	24		31-65-25	ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W5163	2551B	24		34-49-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45563J		**E005-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15		W5163	4001B	24		31-65-15	ALL
	B16		W5163	4001G	24		31-65-15	ALL
	B17		W5163	4002B	24		31-65-25	ALL
	B18		W5163	4002G	24		31-65-25	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5163	2551Z			34-49-11	ALL
	PERG	1F	W5163	4001Z			31-65-15	ALL
	PERG	1F	W5163	4002Z			31-65-25	ALL
D45563P		**E005-02/ /**		**PLUG-**				**ALL**
	A01		W0521	2719R	24		34-49-11	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0521	0315	24		34-49-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45563P	**E005-02/ /**		**PLUG- (continued)**				**ALL**
A15		W0523	4001Y	24		31-65-15	ALL
A16		W0523	4001R	24		31-65-15	ALL
A17		W0523	4002Y	24		31-65-25	ALL
A18		W0523	4002R	24		31-65-25	ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W0521	2719B	24		34-49-11	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15		W0523	4001B	24		31-65-15	ALL
B16		W0523	4001G	24		31-65-15	ALL
B17		W0523	4002B	24		31-65-25	ALL
B18		W0523	4002G	24		31-65-25	ALL
B19	UNUSED						ALL
B20	UNUSED						ALL
PERG	1F	W0521	2719Z			34-49-11	ALL
PERG	1F	W0523	4001Z			31-65-15	ALL
PERG	1F	W0523	4002Z			31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D45919J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DQ	W0121	016CX			34-32-11	ALL
	=C1		W0121	016CO			34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46002J	**IRSS/179/**		**RCPT-CONDUCTIVE**				**ALL**
1		W7230	2221R	20		32-64-11	ALL
2		W7230	2221B	20		32-64-11	ALL
3		W7230	0521	18		32-64-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
S/R		W7230	2221Z			32-64-11	ALL
D46002P	**693/191/L97**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
1		W7022	A-R			32-64-11	ALL
2		W7022	A-B			32-64-11	ALL
3		W7022	A-Y			32-64-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D46004J	**IRSS/178/**		**RCPT-CONDUCTIVE**				**ALL**
1		W7230	2211R	20		32-41-11	ALL
2		W7230	2211ZI			32-41-11	ALL
3		W7230	2211B	20		32-41-11	ALL
4		W7230	FRA9			32-46-11	ALL
5		W7230	2233R	20		32-31-11	ALL
6		W7230	2233B	20		32-31-11	ALL
7	18	W7230	0533	18		32-31-11	ALL
8	TD	W7230	4501W	20		32-46-11	ALL
9	TC	W7230	4501G	20		32-46-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46004J		**IRSS/178/**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	13		W7230	2202ZI			32-49-11	ALL
	14		W7230	2202R	20		32-49-11	ALL
	15		W7230	2202B	20		32-49-11	ALL
	S/R		W7230	2202ZO			32-49-11	ALL
	S/R		W7230	2211ZO			32-41-11	ALL
	S/R		W7230	2233Z			32-31-11	ALL
	S/R		W7230	FRA8			32-46-11	ALL
			W7230	4501Z			32-46-11	ALL
			W7230	FRA8			32-46-11	ALL
			W7230	FRA9			32-46-11	ALL
D46004P		**694/192/L102**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
	1		W7134	2211R	20		32-41-11	ALL
	2		W7134	2211Z			32-41-11	ALL
	3		W7134	2211B	20		32-41-11	ALL
	4		W7134	4501Z			32-46-11	ALL
	5		W7134	3201R	20		32-31-11	ALL
	6		W7134	3201B	20		32-31-11	ALL
	7		W7134	3201Y	20		32-31-11	ALL
	8	TD	W7134	4501W	20		32-46-11	ALL
	9	TC	W7134	4501G	20		32-46-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W7134	2202ZI			32-49-11	ALL
	14		W7134	2202R	20		32-49-11	ALL
	15		W7134	2202B	20		32-49-11	ALL
	DED		W7134	2202ZO			32-49-11	ALL
D46006J		**ORSS/217/**		**RCPT-CONDUCTIVE**				**ALL**
	1		W7126	2211R	20		32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46006J	**ORSS/217/**		**RCPT-CONDUCTIVE (continued)**				**ALL**
2		W7126	2211ZI			32-41-11	ALL
3		W7126	2211B	20		32-41-11	ALL
4		W7126	FRA9			32-46-11	ALL
5		W7126	2233R	20		32-31-12	ALL
6		W7126	2233B	20		32-31-12	ALL
7	18	W7126	0533	18		32-31-12	ALL
8	TD	W7126	4501W	20		32-46-11	ALL
9	TC	W7126	4501G	20		32-46-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W7126	2202ZI			32-49-11	ALL
14		W7126	2202R	20		32-49-11	ALL
15		W7126	2202B	20		32-49-11	ALL
S/R		W7126	2202ZO			32-49-11	ALL
S/R		W7126	2211ZO			32-41-11	ALL
S/R		W7126	2233Z			32-31-12	ALL
S/R		W7126	FRA8			32-46-11	ALL
		W7126	4501Z			32-46-11	ALL
		W7126	FRA8			32-46-11	ALL
		W7126	FRA9			32-46-11	ALL
D46006P	**706/192/L137**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
1		W7136	2211R	20		32-41-11	ALL
2		W7136	2211Z			32-41-11	ALL
3		W7136	2211B	20		32-41-11	ALL
4		W7136	4501Z			32-46-11	ALL
5		W7136	3201R	20		32-31-12	ALL
6		W7136	3201B	20		32-31-12	ALL
7		W7136	3201Y	20		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46006P		**706/192/L137**		**PLUG, CONDUCTIVE CONNECTOR (continued)**				**ALL**
	8	TD	W7136	4501W	20		32-46-11	ALL
	9	TC	W7136	4501G	20		32-46-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W7136	2202ZI			32-49-11	ALL
	14		W7136	2202R	20		32-49-11	ALL
	15		W7136	2202B	20		32-49-11	ALL
	DED		W7136	2202ZO			32-49-11	ALL
D46008J		**ORSS/169/**		**RCPT-CONDUCTIVE**				**ALL**
	1		W7126	2221R	20		32-64-12	ALL
	2		W7126	2221B	20		32-64-12	ALL
	3		W7126	0521	18		32-64-12	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	S/R		W7126	2221Z			32-64-12	ALL
D46008P		**711/180/L86**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
	1		W7024	A-R			32-64-12	ALL
	2		W7024	A-B			32-64-12	ALL
	3		W7024	A-Y			32-64-12	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D46010J		**AL0675A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5224	3001B	20		27-11-11	ALL
	2		W5224	3001R	20		27-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46010J	**AL0675A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
3		W5224	0536	18		29-25-11	ALL
4		W5224	3001Y	20		27-11-11	ALL
5		W5224	0528	20		32-31-15	ALL
6		W5224	0501	20		27-23-11	ALL
7		W5224	0502	20		27-23-11	ALL
8		W5224	0030	20		31-31-15	ALL
9		W5224	0503	22		27-23-14	ALL
10		W5224	0521	20		29-23-11	ALL
11		W5224	0535	18		29-25-11	ALL
12		W5224	0529	20		32-31-15	ALL
13		W5224	0526	20		32-31-15	ALL
14		W5224	0527	20		32-31-15	ALL
D46010P	**AL0675A/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W7122	0520	20		27-11-11	ALL
2		W7122	0518	20		27-11-11	ALL
3		W7122	2003R	18		29-25-11	ALL
4		W7122	0519	20		27-11-11	ALL
5		W7122	2002B	20		32-31-15	ALL
6		W7122	0511	18		27-23-11	ALL
7		W7122	0510	18		27-23-11	ALL
8		W7122	0530	20		31-31-15	ALL
9		W7122	0504	20		27-23-14	ALL
10		W8122	1005	20		29-23-11	ALL
11		W7122	2003B	18		29-25-11	ALL
12		W7122	2002R	20		32-31-15	ALL
13		W7122	2001B	20		32-31-15	ALL
14		W7122	2001R	20		32-31-15	ALL
S/R		W7122	2001Z			32-31-15	ALL
S/R		W7122	2002Z			32-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46010P		**AL0675A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W7122	2003Z			29-25-11	ALL
	S/R		W8122	1005Z			29-23-11	ALL
D46012J		**IRSS 179/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W8228	2213R	20		32-64-11	ALL
	2		W8228	2213B	20		32-64-11	ALL
	3		W8228	0513	18		32-64-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	S/R		W8228	2213Z			32-64-11	ALL
D46012P		**IRSS 178/ /**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
	1		W8022	A-R			32-64-11	ALL
	2		W8022	A-B			32-64-11	ALL
	3		W8022	A-Y			32-64-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
D46013J		**E001-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0111	1004	24		27-52-11	ALL
	A04		W0111	1005	24		27-52-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07		W0111	0034	20		22-11-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46013J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	A10		W0111	0190	20		22-14-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W0111	0387	16		34-21-21	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	DED		W0111	1004Z			27-52-11	ALL
	DED		W0111	1005Z			27-52-11	ALL
D46013P		**E001-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W2103	0015	24		27-52-11	ALL
	A04		W2103	0014	24		27-52-11	ALL
	A05	UNUSED						ALL
	A06		W2103	0006	20		SPARE	ALL
	A07		W2103	0007	20		22-11-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W2103	0028	20		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46013P		**E001-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W2103	0023	16		34-21-21	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D46014J		**IRSS 178/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W8228	2211R	20		32-41-11	ALL
	2		W8228	2211ZI			32-41-11	ALL
	3		W8228	2211B	20		32-41-11	ALL
	4		W8228	FRA9			32-46-11	ALL
	5		W8228	2240R	20		32-31-11	ALL
	6		W8228	2240B	20		32-31-11	ALL
	7		W8228	0540	20		32-31-11	ALL
	8	TD	W8228	4501W	20		32-46-11	ALL
	9	TC	W8228	4501G	20		32-46-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W8228	2202ZI			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46014J	**IRSS 178/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
14		W8228	2202R	20		32-49-11	ALL
15		W8228	2202B	20		32-49-11	ALL
S/R		W8228	2202ZO			32-49-11	ALL
S/R		W8228	2211ZO			32-41-11	ALL
S/R		W8228	2240Z			32-31-11	ALL
S/R		W8228	FRA8			32-46-11	ALL
		W8228	4501Z			32-46-11	ALL
		W8228	FRA8			32-46-11	ALL
		W8228	FRA9			32-46-11	ALL
D46014P	**IRSS 178/ /**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
1		W8234	2211R	20		32-41-11	ALL
2		W8234	2211Z			32-41-11	ALL
3		W8234	2211B	20		32-41-11	ALL
4		W8234	4501Z			32-46-11	ALL
5		W8234	3201R	20		32-31-11	ALL
6		W8234	3201B	20		32-31-11	ALL
7		W8234	3201Y	20		32-31-11	ALL
8	TD	W8234	4501W	20		32-46-11	ALL
9	TC	W8234	4501G	20		32-46-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W8234	2202ZI			32-49-11	ALL
14		W8234	2202R	20		32-49-11	ALL
15		W8234	2202B	20		32-49-11	ALL
DED		W8234	2202ZO			32-49-11	ALL
D46016J	**IRSS 215/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W8224	2211R	20		32-41-11	ALL
2		W8224	2211ZI			32-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46016J		**IRSS 215/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	3		W8224	2211B	20		32-41-11	ALL
	4		W8224	FRA9			32-46-11	ALL
	5		W8224	2241R	20		32-31-12	ALL
	6		W8224	2241B	20		32-31-12	ALL
	7	18	W8224	0541	18		32-31-12	ALL
	8	TD	W8224	4501W	20		32-46-11	ALL
	9	TC	W8224	4501G	20		32-46-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W8224	2202ZI			32-49-11	ALL
	14		W8224	2202R	20		32-49-11	ALL
	15		W8224	2202B	20		32-49-11	ALL
	S/R		W8224	2202ZO			32-49-11	ALL
	S/R		W8224	2211ZO			32-41-11	ALL
	S/R		W8224	2241Z			32-31-12	ALL
	S/R		W8224	FRA8			32-46-11	ALL
			W8224	4501Z			32-46-11	ALL
			W8224	FRA8			32-46-11	ALL
			W8224	FRA9			32-46-11	ALL
D46016P		**IRSS 215/ /**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
	1		W8236	2211R	20		32-41-11	ALL
	2		W8236	2211Z			32-41-11	ALL
	3		W8236	2211B	20		32-41-11	ALL
	4		W8236	4501Z			32-46-11	ALL
	5		W8236	3201R	20		32-31-12	ALL
	6		W8236	3201B	20		32-31-12	ALL
	7		W8236	3201Y	20		32-31-12	ALL
	8	TD	W8236	4501W	20		32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46016P	**IRSS 215/ /**		**PLUG, CONDUCTIVE CONNECTOR (continued)**				**ALL**
9	TC	W8236	4501G	20		32-46-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W8236	2202ZI			32-49-11	ALL
14		W8236	2202R	20		32-49-11	ALL
15		W8236	2202B	20		32-49-11	ALL
DED		W8236	2202ZO			32-49-11	ALL
D46017J	**E003-01/ /**		**RCPT - POWER**				**ALL**
A01		W0313	0641	20		34-57-21	ALL
A02		W0313	0637	20		34-61-11	ALL
A03		W0313	0636	20		34-61-11	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46017J		**E003-01/ /**		**RCPT - POWER (continued)**				**ALL**
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D46017P		**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
	A01		W2231	0003	22		34-57-21	ALL
	A02		W2231	0002	20		34-61-11	ALL
	A03		W2231	0001	20		34-61-11	ALL
	A04	UNUSED						ALL
	A05		W2231	0007	20		SPARE	ALL
	A06		W2231	0006	20		SPARE	ALL
	A07	UNUSED						ALL
	A08		W2231	0028	20		SPARE	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W2231	0027	16		SPARE	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46017P	**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
J	UNUSED						ALL
K	UNUSED						ALL
D46018J	**IRSS 168/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W8224	2223R	20		32-64-12	ALL
2		W8224	2223B	20		32-64-12	ALL
3		W8224	0523	18		32-64-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
S/R		W8224	2223Z			32-64-12	ALL
D46018P	**IRSS 168/ /**		**PLUG, CONDUCTIVE CONNECTOR**				**ALL**
1		W8024	A-R			32-64-12	ALL
2		W8024	A-B			32-64-12	ALL
3		W8024	A-Y			32-64-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D46020J	**AL0720B/202/L026**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W6124	0580	22		29-31-11	ALL
3		W6124	0581	20		29-35-11	ALL
4		W6124	0576	20		27-53-11	ALL
5		W6124	0578	20		27-81-51	ALL
6		W6124	0579	20		27-81-51	ALL
7		W6124	0575	20		27-53-11	ALL
8		W6124	3001Z			31-31-14	ALL
9		W6124	3001R	20		31-31-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46020J		**AL0720B/202/L026**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	10	UNUSED						ALL
	11		W6124	3001B	20		31-31-14	ALL
	12		W6124	3001Y	20		31-31-14	ALL
D46020P		**AL0720B/201/L025**		**PLUG- CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2		W7128	0406	20		29-31-11	ALL
	3		W7128	0401	20		29-35-11	ALL
	4		W7128	0404	18		27-53-11	ALL
	5		W7128	0409	20		27-81-51	ALL
	6		W7128	0410	20		27-81-51	ALL
	7		W7128	0403	18		27-53-11	ALL
	8	18	W7128	3001Z			31-31-14	ALL
	9		W7128	3001R	20		31-31-14	ALL
	10	UNUSED						ALL
	11		W7128	3001B	20		31-31-14	ALL
	12		W7128	3001Y	20		31-31-14	ALL
D46022J		**E002-02/ /**		**RCPT-**				**ALL**
	A01		W0220	0294	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W0220	0295	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W0220	0274	22		26-16-22	ALL
	A06		W0220	0271	22		26-16-22	ALL
	A07		W0220	0276	22		26-16-22	ALL
	A08		W0220	0277	22		26-16-22	ALL
	A09		W0220	0278	22		26-16-22	ALL
	A10		W0220	0279	22		26-16-22	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46022J		**E002-02/ /**		**RCPT- (continued)**				**ALL**
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0220	0280	22		26-16-22	ALL
	B06		W0220	0281	22		26-16-22	ALL
	B07		W0220	0282	22		26-16-22	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46022P		**E002-02/ /**		**PLUG-**				**ALL**
	A01		W2110	6037	22		26-23-11	ALL
	A02	UNUSED						ALL
	A03		W2110	6038	22		26-23-11	ALL
	A04	UNUSED						ALL
	A05		W2110	6013	22		26-16-22	ALL
	A06		W2110	6014	22		26-16-22	ALL
	A07		W2110	6015	22		26-16-22	ALL
	A08		W2110	6016	22		26-16-22	ALL
	A09		W2110	6017	22		26-16-22	ALL
	A10		W2110	6018	22		26-16-22	ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W2110	6019	22		26-16-22	ALL
	B06		W2110	6020	22		26-16-22	ALL
	B07		W2110	6021	22		26-16-22	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46022P		**E002-02/ /**		**PLUG- (continued)**				**ALL**
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
D46023J		**E001-01/ /**		**RCPT-**				**ALL**
	A01		W0111	0735	22		27-81-11	ALL
	A02		W0111	0603	24		27-28-11	ALL
	A03		W0111	0137	20		22-18-11	ALL
	A04		W0111	0443	22		34-51-41	ALL
	A05	UNUSED						ALL
	A06		W0111	0384	20		34-21-21	ALL
	A07		W0111	0383	20		34-21-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46023J		**E001-01/ /**		**RCPT- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W0111	0579	16		23-12-21	ALL
	K	UNUSED						ALL
D46023P		**E001-01/ /**		**PLUG**				**ALL**
	A01		W2383	0021	22		27-81-11	ALL
	A02		W2383	0022	24		27-28-11	ALL
	A03		W2383	0003	20		22-18-11	ALL
	A04		W2383	0005	22		34-51-41	ALL
	A05		W2383	0023	20		SPARE	ALL
	A06		W2383	0028	20		34-21-21	ALL
	A07		W2383	0007	20		34-21-21	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46023P	**E001-01/ /**		**PLUG (continued)**				**ALL**
F	UNUSED						ALL
G	UNUSED						ALL
H	UNUSED						ALL
J		W2383	0036	16		23-12-21	ALL
K	UNUSED						ALL
D46024J	**AL0720A/202/L034**		**RCPT-CONDUCTIVE**				**ALL**
1		W5234	0511	22		31-31-15	ALL
2	UNUSED						ALL
3		W5234	0501	20		32-41-11	ALL
4	UNUSED						ALL
5		W5234	2222R	22		32-64-12	ALL
6		W5234	2222B	22		32-64-12	ALL
7		W5234	2221R	22		32-64-12	ALL
8		W5234	2221B	22		32-64-12	ALL
9		W5234	2233R	22		32-31-12	ALL
10		W5234	2233B	22		32-31-12	ALL
11		W5234	0591	22		32-41-11	ALL
12		W5234	0592	22		32-41-11	ALL
13		W5234	2203R	22		32-42-11	ALL
14		W5234	2203B	22		32-42-11	ALL
15		W5234	2204R	22		32-42-11	ALL
16		W5234	2204B	22		32-42-11	ALL
17		W5234	2211R	22		32-41-11	ALL
18		W5234	2211B	22		32-41-11	ALL
19		W5234	2211Z			32-41-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46024J		**AL0720A/202/L034**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36		W5234	2202R	20		32-49-11	ALL
	37		W5234	2202B	20		32-49-11	ALL
	38	TD	W5234	4501W	20		32-46-11	ALL
	39	TC	W5234	4501G	20		32-46-11	ALL
	S/R		W5234	2202Z			32-49-11	ALL
	S/R		W5234	4501Z			32-46-11	ALL
D46024P		**AL0720A/201/L34**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7126	1501	18		31-31-15	ALL
	2	UNUSED						ALL
	3		W7126	1001	18		32-41-11	ALL
	4	UNUSED						ALL
	5		W7126	2222R	20		32-64-12	ALL
	6		W7126	2222B	20		32-64-12	ALL
	7		W7126	2221R	20		32-64-12	ALL
	8		W7126	2221B	20		32-64-12	ALL
	9		W7126	2233R	20		32-31-12	ALL
	10		W7126	2233B	20		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46024P	**AL0720A/201/L34**		**PLUG-CONDUCTIVE (continued)**				**ALL**
11		W7126	2201R	20		32-41-11	ALL
12		W7126	2201B	20		32-41-11	ALL
13		W7126	2203R	20		32-42-11	ALL
14		W7126	2203B	20		32-42-11	ALL
15		W7126	2204R	20		32-42-11	ALL
16		W7126	2204B	20		32-42-11	ALL
17		W7126	2211R	20		32-41-11	ALL
18		W7126	2211B	20		32-41-11	ALL
19		W7126	2211ZI			32-41-11	ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W7126	2202R	20		32-49-11	ALL
37		W7126	2202B	20		32-49-11	ALL
38	TD	W7126	4501W	20		32-46-11	ALL
39	TC	W7126	4501G	20		32-46-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46024P		**AL0720A/201/L34**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	S/R		W7126	1001Z			32-41-11	ALL
	S/R		W7126	1501Z			31-31-15	ALL
	S/R		W7126	2201Z			32-41-11	ALL
	S/R		W7126	2202ZI			32-49-11	ALL
	S/R		W7126	2203Z			32-42-11	ALL
	S/R		W7126	2204Z			32-42-11	ALL
	S/R		W7126	2211ZO			32-41-11	ALL
	S/R		W7126	2221Z			32-64-12	ALL
	S/R		W7126	2233Z			32-31-12	ALL
	S/R		W7126	4501Z			32-46-11	ALL
	DED		W7126	2202ZO			32-49-11	ALL
D46026J		**AL0675B/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5728	0508	20		49-62-11	ALL
	2		W5728	0507	20		49-62-11	ALL
	3		W5728	0506	20		49-62-11	ALL
	4		W5728	0591	22		32-41-11	ALL
	5		W5728	0513	20		32-35-11	ALL
	6		W5728	0512	20		32-35-11	ALL
	7		W5728	0001	20		33-32-11	ALL
	8		W5728	0002	20		33-32-11	ALL
	9		W5728	0596	20		32-31-15	ALL
	10		W5728	0509	20		49-62-11	ALL
	11		W5728	0592	22		32-41-11	ALL
	12		W5728	0593	20		32-31-15	ALL
	13		W5728	0594	20		32-31-15	ALL
	14		W5728	0595	20		32-31-15	ALL
D46026P		**AL0675B/ /**		**PLUG-CONDUCTIVE**				**ALL**
	1		W7026	0501	18		49-62-11	ALL
	2		W7026	0502	18		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46026P	**AL0675B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
3		W7026	0504	18		49-62-11	ALL
4		W7026	2201R	18		32-41-11	ALL
5		W7026	2501R	20		32-35-11	ALL
6		W7026	2501B	20		32-35-11	ALL
7		W7026	1001	20		33-32-11	ALL
8		W7026	1002	20		33-32-11	ALL
9		W7026	2203R	20		32-31-15	ALL
10		W7026	0503	18		49-62-11	ALL
11		W7026	2201B	18		32-41-11	ALL
12		W7026	2202B	20		32-31-15	ALL
13		W7026	2202R	20		32-31-15	ALL
14		W7026	2203B	20		32-31-15	ALL
S/R		W7026	1001Z			33-32-11	ALL
S/R		W7026	1002Z			33-32-11	ALL
S/R		W7026	2201Z			32-41-11	ALL
S/R		W7026	2202Z			32-31-15	ALL
S/R		W7026	2203Z			32-31-15	ALL
S/R		W7026	2501Z			32-35-11	ALL
D46028J	**AL0675B/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W5530	0512	22		29-32-11	ALL
2		W5530	0511	22		29-32-11	ALL
3		W5530	6011	20		28-21-11	ALL
4		W5530	2222R	22		32-64-11	ALL
5		W5530	2222B	22		32-64-11	ALL
6		W5530	2211R	20		32-41-11	ALL
7		W5530	2211B	20		32-41-11	ALL
8		W5530	2211Z			32-41-11	ALL
9		W5530	2221R	22		32-64-11	ALL
10		W5530	2221B	22		32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46028J	**AL0675B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
11		W5530	2212R	22		27-61-49	ALL
12		W5530	2232R	22		32-31-11	ALL
13		W5530	2232B	22		32-31-11	ALL
14		W5530	0500R	20		26-12-11	ALL
15		W5530	6008	20		28-42-11	ALL
16		W5530	6007	20		28-42-11	ALL
17		W5530	2212B	22		27-61-49	ALL
18		W5530	2213R	22		27-61-49	ALL
19		W5530	2213B	22		27-61-49	ALL
20	TD	W5530	4501W	20		32-46-11	ALL
21	TC	W5530	4501G	20		32-46-11	ALL
22		W5530	2202R	20		32-49-11	ALL
23		W5530	2202B	20		32-49-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46028J	**AL0675B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
S/R		W5530	2202Z			32-49-11	ALL
S/R		W5530	2212Z			27-61-49	ALL
S/R		W5530	2213Z			27-61-49	ALL
S/R		W5530	4501Z			32-46-11	ALL
D46028P	**AL0675B/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W7230	1005	18		29-32-11	ALL
2		W7230	1004	18		29-32-11	ALL
3		W7230	6011	18		28-21-11	ALL
4		W7230	2222R	20		32-64-11	ALL
5		W7230	2222B	20		32-64-11	ALL
6		W7230	2211R	20		32-41-11	ALL
7		W7230	2211B	20		32-41-11	ALL
8		W7230	2211ZI			32-41-11	ALL
9		W7230	2221R	20		32-64-11	ALL
10		W7230	2221B	20		32-64-11	ALL
11		W7230	2234R	20		27-61-49	ALL
12		W7230	2233R	20		32-31-11	ALL
13		W7230	2233B	20		32-31-11	ALL
14		W7230	6005R	20		26-12-11	ALL
15		W7230	2220R	20		28-42-11	ALL
16		W7230	2220B	20		28-42-11	ALL
17		W7230	2234B	20		27-61-49	ALL
18		W7230	2235R	20		27-61-49	ALL
19		W7230	2235B	20		27-61-49	ALL
20	TD	W7230	4501W	20		32-46-11	ALL
21	TC	W7230	4501G	20		32-46-11	ALL
22		W7230	2202R	20		32-49-11	ALL
23		W7230	2202B	20		32-49-11	ALL
24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46028P		**AL0675B/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W7230	1004Z			29-32-11	ALL
	S/R		W7230	1005Z			29-32-11	ALL
	S/R		W7230	2202ZI			32-49-11	ALL
	S/R		W7230	2211ZO			32-41-11	ALL
	S/R		W7230	2220Z			28-42-11	ALL
	S/R		W7230	2221Z			32-64-11	ALL
	S/R		W7230	2233Z			32-31-11	ALL
	S/R		W7230	2234Z			27-61-49	ALL
	S/R		W7230	2235Z			27-61-49	ALL
	S/R		W7230	4501Z			32-46-11	ALL
	DED		W7230	2202ZO			32-49-11	ALL
D46030J		**AL0675B/ /**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5222	1508	22		31-65-14	ALL
	2		W5222	0505	20		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46030J	**AL0675B/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
3		W5222	0530	20		78-34-11	ALL
4		W5222	0531	20		78-34-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W5222	0535	20		78-34-11	ALL
8		W5222	0509R	20		26-12-11	ALL
9		W5222	0507	22		29-33-11	ALL
10		W5222	0504	20		29-11-11	ALL
11		W5222	0506	22		29-33-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W5222	0532	20		78-34-11	ALL
18		W5222	0533	20		78-34-11	ALL
19		W5222	0534	20		78-34-11	ALL
S/R		W5222	1508Z			31-65-14	ALL
D46030P	**AL0675B/ /**		**PLUG - CONDUCTIVE**				**ALL**
1		W7522	1508	18		31-65-14	ALL
2		W7522	2001B	18		29-11-11	ALL
3		W7522	2603B	20		78-34-11	ALL
4		W7522	2603R	20		78-34-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W7522	2602R	20		78-34-11	ALL
8		W7522	6003R	20		26-12-11	ALL
9		W7522	0506	20		29-33-11	ALL
10		W7522	2001R	18		29-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46030P		**AL0675B/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	11		W7522	0504	20		29-33-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W7522	2601B	20		78-34-11	ALL
	18		W7522	2601R	20		78-34-11	ALL
	19		W7522	2602B	20		78-34-11	ALL
	S/R		W7522	1508Z			31-65-14	ALL
	S/R		W7522	2001Z			29-11-11	ALL
	S/R		W7522	2601Z			78-34-11	ALL
	S/R		W7522	2602Z			78-34-11	ALL
	S/R		W7522	2603Z			78-34-11	ALL
D46032J		**AL0720B/201/L026**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5222	0523	20		29-31-11	ALL
	2		W5222	0521	20		29-31-11	ALL
	3		W5222	0522	20		29-31-11	ALL
	4		W5222	0591	20		32-41-11	ALL
	5		W5222	0592	20		32-41-11	ALL
	6		W5222	0500R	20		26-12-11	ALL
	7		W5222	0513	20		32-44-11	ALL
	8		W5222	0511	20		32-44-11	ALL
	9		W5222	0517	20		32-44-11	ALL
	10		W5222	0514	20		32-44-11	ALL
	11		W5222	0516	20		32-44-11	ALL
	12		W5222	0518	20		27-23-11	ALL
	13		W5222	0519	20		27-23-11	ALL
	14		W5222	0525	20		27-23-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46032P	**AL0720B/201/L026**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0501	20		29-31-11	ALL
2		W7128	0502	20		29-31-11	ALL
3		W7128	0503	20		29-31-11	ALL
4		W7128	2201R	18		32-41-11	ALL
5		W7128	2201B	18		32-41-11	ALL
6		W7128	1003R	20		26-12-11	ALL
7		W7128	1008	16		32-44-11	ALL
8		W7128	1007	16		32-44-11	ALL
9		W7128	3003Y	16		32-44-11	ALL
10		W7128	3003R	16		32-44-11	ALL
11		W7128	3003B	16		32-44-11	ALL
12		W7128	0518	18		27-23-11	ALL
13		W7128	0519	18		27-23-11	ALL
14		W7128	0520	18		27-23-14	ALL
S/R		W7128	1003Z			26-12-11	ALL
S/R		W7128	1007Z			32-44-11	ALL
S/R		W7128	1008Z			32-44-11	ALL
S/R		W7128	2201Z			32-41-11	ALL
S/R		W7128	3003Z			32-44-11	ALL
D46033J	**P003-00/ /**		**INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0003	1502	16		31-65-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46033J		**P003-00/ /**		**INSERT (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0003	1501	16		31-65-21	ALL
	14	UNUSED						ALL
	15		W0001	0135	22		32-42-11	ALL
	16	UNUSED						ALL
	17		W0001	1756	22		32-31-15	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0003	1504	22		31-65-21	ALL
	22		W0003	1691	20		33-18-21	ALL
	PERS	1A	W0001	1756Z			32-31-15	ALL
	PERS	1A	W0003	1501Z			31-65-21	ALL
	PERS	1A	W0003	1502Z			31-65-21	ALL
	PERS	1A	W0003	1504Z			31-65-21	ALL
	PERS	1A	W0003	1691Z			33-18-21	ALL
D46033P		**P009-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W2383	0002	16		31-65-21	ALL
	10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46033P	**P009-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
11	UNUSED						ALL
12	UNUSED						ALL
13		W2383	0001	16		31-65-21	ALL
14	UNUSED						ALL
15		W2383	0006	22		32-42-11	ALL
16	UNUSED						ALL
17		W2383	0047	22		32-31-15	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W2383	0029	22		31-65-21	ALL
22		W2383	0020	20		33-18-21	ALL
D46035J	**E003-01/ /**		**RCPT - POWER**				**ALL**
A01		W0313	2775B	24		32-64-31	ALL
A02		W0313	2775R	24		32-64-31	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46035J		**E003-01/ /**		**RCPT - POWER (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0313	0694	16		31-65-11	ALL
	G	UNUSED						ALL
	H		W0313	0504	16		31-65-21	ALL
	J	UNUSED						ALL
	K		W0313	0502	16		31-65-21	ALL
	PERG	1F	W0313	2775Z			32-64-31	ALL
D46035P		**E003-01/ /**		**PLUG E3-1 SHELF**				**ALL**
	A01		W2169	2401B	24		32-64-31	ALL
	A02		W2169	2401R	24		32-64-31	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W2169	0009	20		SPARE	ALL
	A09		W2169	0003	20		SPARE	ALL
	A10		W2169	0001	20		SPARE	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46035P	**E003-01/ /**		**PLUG E3-1 SHELF (continued)**				**ALL**
B09		W2169	0010	20		SPARE	ALL
B10		W2169	0002	22		SPARE	ALL
F		W2169	0023	16		31-65-11	ALL
G	UNUSED						ALL
H		W2169	0015	16		31-65-21	ALL
J	UNUSED						ALL
K		W2169	0019	16		31-65-21	ALL
PERG	1F	W2169	2401Z			32-64-31	ALL
D46036J	**AL0720B/201/L025**		**RCPT-CONDUCTIVE**				**ALL**
1		W5224	0511	16		27-53-12	ALL
2		W5224	0512	16		27-53-12	ALL
3		W5224	0513	16		27-53-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D46036P	**AL0720B/201/L026**		**PLUG- CONDUCTIVE**				**ALL**
1		W7128	0301	16		27-53-12	ALL
2		W7128	0302	16		27-53-12	ALL
3		W7128	0303	16		27-53-12	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
D46038J	**AL0675C/ /**		**RCPT-CONDUCTIVE**				**ALL**
1		W6732	2214R	22		32-64-11	ALL
2		W6732	2214B	22		32-64-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46038J		**AL0675C/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W6732	0591	22		32-41-11	ALL
	8		W6732	0592	22		32-41-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W6732	2213R	22		32-64-11	ALL
	12		W6732	2213B	22		32-64-11	ALL
	13	UNUSED						ALL
	14		W6732	2240R	22		32-31-11	ALL
	15		W6732	2240B	22		32-31-11	ALL
	16		W6732	2501B	20		78-34-21	ALL
	17		W6732	2501R	20		78-34-21	ALL
	18		W6732	1005	20		78-34-21	ALL
	19		W6732	1006	20		78-34-21	ALL
	20		W6732	1003	20		78-34-21	ALL
	21		W6732	2211Z			32-41-11	ALL
	22		W6732	1004	20		78-34-21	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W6732	2211R	22		32-41-11	ALL
	29		W6732	2211B	22		32-41-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46038J	**AL0675C/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
34	UNUSED						ALL
35	UNUSED						ALL
36	TD	W6732	4501W	20		32-46-11	ALL
37	TC	W6732	4501G	20		32-46-11	ALL
38		W6732	2202R	20		32-49-11	ALL
39		W6732	2202B	20		32-49-11	ALL
S/R		W6732	1003Z			78-34-21	ALL
S/R		W6732	1004Z			78-34-21	ALL
S/R		W6732	1005Z			78-34-21	ALL
S/R		W6732	1006Z			78-34-21	ALL
S/R		W6732	2202Z			32-49-11	ALL
S/R		W6732	2501Z			78-34-21	ALL
S/R		W6732	4501Z			32-46-11	ALL
D46038P	**AL0675C/ /**		**PLUG-CONDUCTOR**				**ALL**
1		W8228	2214R	20		32-64-11	ALL
2		W8228	2214B	20		32-64-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W8228	2201R	20		32-41-11	ALL
8		W8228	2201B	20		32-41-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W8228	2213R	20		32-64-11	ALL
12		W8228	2213B	20		32-64-11	ALL
13	UNUSED						ALL
14		W8228	2240R	20		32-31-11	ALL
15		W8228	2240B	20		32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46038P		**AL0675C/ /**		**PLUG-CONDUCTOR (continued)**				**ALL**
	16		W8228	2602B	20		78-34-21	ALL
	17		W8228	2602R	20		78-34-21	ALL
	18		W8228	2601B	20		78-34-21	ALL
	19		W8228	2601R	20		78-34-21	ALL
	20		W8228	2603B	20		78-34-21	ALL
	21		W8228	2211ZI			32-41-11	ALL
	22		W8228	2603R	20		78-34-21	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W8228	2211R	20		32-41-11	ALL
	29		W8228	2211B	20		32-41-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	TD	W8228	4501W	20		32-46-11	ALL
	37	TC	W8228	4501G	20		32-46-11	ALL
	38		W8228	2202R	20		32-49-11	ALL
	39		W8228	2202B	20		32-49-11	ALL
	S/R		W8228	2201Z			32-41-11	ALL
	S/R		W8228	2202ZI			32-49-11	ALL
	S/R		W8228	2211ZO			32-41-11	ALL
	S/R		W8228	2213Z			32-64-11	ALL
	S/R		W8228	2240Z			32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46038P	**AL0675C/ /**		**PLUG-CONDUCTOR (continued)**				**ALL**
S/R		W8228	2601Z			78-34-21	ALL
S/R		W8228	2602Z			78-34-21	ALL
S/R		W8228	2603Z			78-34-21	ALL
S/R		W8228	4501Z			32-46-11	ALL
DED		W8228	2202ZO			32-49-11	ALL
D46040J	**AL0720D/201/R026**		**RCPT-CONDUCTIVE**				**ALL**
1		W6124	0533	18		29-25-11	ALL
2		W6124	0530	18		29-25-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W6124	0504	22		27-23-11	ALL
6	UNUSED						ALL
7		W6124	0511	20		27-53-11	ALL
8		W6124	0561	22		32-64-21	ALL
9	UNUSED						ALL
10		W6124	0553	22		32-64-21	ALL
11	UNUSED						ALL
12		W6124	0565	20		27-31-11	ALL
13		W6124	0527	20		27-31-11	ALL
14		W6124	5501	20		21-51-14	ALL
15		W6124	0505	22		27-23-11	ALL
16		W6124	0509	20		27-53-11	ALL
17		W6124	0510	20		27-53-11	ALL
18		W6124	0532	22		29-25-11	ALL
19	UNUSED						ALL
S/R		W6124	5501Z			21-51-14	ALL
D46040P	**AL0720D/201/R25**		**PLUG- CONDUCTIVE**				**ALL**
1		W8124	0519	20		29-25-11	ALL
2		W8124	0518	20		29-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46040P		**AL0720D/201/R25**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W8124	0513	20		27-23-11	ALL
	6	UNUSED						ALL
	7		W8124	0502	20		27-53-11	ALL
	8		W8124	0506	20		32-64-21	ALL
	9	UNUSED						ALL
	10		W8124	0511	20		32-64-21	ALL
	11	UNUSED						ALL
	12		W8124	0517	20		27-31-11	ALL
	13		W8124	0516	20		27-31-11	ALL
	14		W8124	0515	20		21-51-14	ALL
	15		W8124	0512	20		27-23-11	ALL
	16		W8124	0503	20		27-53-11	ALL
	17		W8124	0501	20		27-53-11	ALL
	18		W8124	0520	20		29-25-11	ALL
	19	UNUSED						ALL
D46042J		**AL0675C/198/R036**		**RCPT-CONDUCTIVE**				**ALL**
	1		W6122	0507	22		29-33-11	ALL
	2		W6122	0506	22		29-33-11	ALL
	3		W6122	0502	22		29-32-11	ALL
	4		W6122	0501	22		29-32-11	ALL
	5		W6122	6011	20		28-21-11	ALL
	6		W6122	0504	20		29-11-11	ALL
	7		W6122	0505	20		29-11-11	ALL
	8		W6122	1515	22		31-65-24	ALL
	9	UNUSED						ALL
	10		W6122	0500R	20		26-12-11	ALL
	S/R		W6122	1515Z			31-65-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46042P	**AL0675C/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W8222	0501	20		29-33-11	ALL
2		W8222	0506	20		29-33-11	ALL
3		W8222	1009	18		29-32-11	ALL
4		W8222	1008	18		29-32-11	ALL
5		W8222	6011	18		28-21-11	ALL
6		W8222	2002R	18		29-11-11	ALL
7		W8222	2002B	18		29-11-11	ALL
8		W8222	1513	18		31-65-24	ALL
9	UNUSED						ALL
10		W8222	6003R	20		26-12-11	ALL
S/R		W8222	1008Z			29-32-11	ALL
S/R		W8222	1009Z			29-32-11	ALL
S/R		W8222	1513Z			31-65-24	ALL
S/R		W8222	2002Z			29-11-11	ALL
D46043J	**E003-02/ /**		**RCPT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0321	0249	22		27-32-21	ALL
A06		W0321	0250	22		27-32-21	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0321	2159R	24		32-64-31	ALL
B04		W0321	2159B	24		32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46043J		**E003-02/ /**		**RCPT (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2159Z			32-64-31	ALL
D46043P		**E003-02/ /**		**PLUG E3-2 SHELF**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2169	0004	22		SPARE	ALL
	A05		W2169	0005	22		27-32-21	ALL
	A06		W2169	0006	22		27-32-21	ALL
	A07		W2169	0007	22		SPARE	ALL
	A08		W2169	0008	22		SPARE	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2169	0011	20		SPARE	ALL
	B02		W2169	0012	20		SPARE	ALL
	B03		W2169	2401R	24		32-64-31	ALL
	B04		W2169	2401B	24		32-64-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2169	2401Z			32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46044J	**AL0720C/201/R033**		**RCPT-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W6124	0520	22		27-54-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6124	0519	20		27-53-12	ALL
13		W6124	0518	20		27-53-12	ALL
14		W6124	0541	22		27-54-11	ALL
D46044P	**AL0720C/201/R34**		**PLUG- CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W8226	0501	18		27-54-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W8226	0505	20		27-53-12	ALL
13		W8226	B-CC			27-53-12	ALL
14		W8226	0503	18		27-54-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46046J		**AL0675C/ /**		**RCPT CONDUCTIVE**				**ALL**
	1		W6124	0542	20		27-61-43	ALL
	2		W6124	0543	20		27-61-43	ALL
	3		W6124	0030	20		31-31-15	ALL
	4	UNUSED						ALL
	5		W6124	0546	20		27-81-51	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W6124	0523	22		29-23-11	ALL
	9		W6124	0529	22		29-25-11	ALL
	10		W6124	0503	22		27-23-14	ALL
	11		W6124	0524	22		29-23-11	ALL
	12		W6124	0548	22		27-83-11	ALL
	13		W6124	0501	20		27-23-11	ALL
	14		W6124	0502	20		27-23-11	ALL
	15		W6124	0512R	20		26-12-11	ALL
	16		W6124	0545	20		27-81-51	ALL
	17	UNUSED						ALL
	18		W6124	2001R	22		27-61-49	ALL
	19		W6124	2001B	22		27-61-49	ALL
	20		W6124	2002R	22		27-61-49	ALL
	21		W6124	2002B	22		27-61-49	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46046J	**AL0675C/ /**		**RCPT CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
S/R		W6124	2001Z			27-61-49	ALL
S/R		W6124	2002Z			27-61-49	ALL
D46046P	**AL0675C/198/R038**		**PLUG-CONDUCTIVE**				**ALL**
1		W8122	0542	18		27-61-43	ALL
2		W8122	0543	18		27-61-43	ALL
3		W8122	0530	20		31-31-15	ALL
4	UNUSED						ALL
5		W8122	0516	18		27-81-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W8122	1006	20		29-23-11	ALL
9		W8122	1010	20		29-25-11	ALL
10		W8122	0501	20		27-23-14	ALL
11		W8122	1008	20		29-23-11	ALL
12		W8122	1011	20		27-83-11	ALL
13		W8122	0512	20		27-23-11	ALL
14		W8122	0511	20		27-23-11	ALL
15		W8122	6002R	20		26-12-11	ALL
16		W8122	0515	18		27-81-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46046P		**AL0675C/198/R038**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	17	UNUSED						ALL
	18		W8122	2001R	20		27-61-49	ALL
	19		W8122	2001B	20		27-61-49	ALL
	20		W8122	2002R	20		27-61-49	ALL
	21		W8122	2002B	20		27-61-49	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	S/R		W8122	1006Z			29-23-11	ALL
	S/R		W8122	1008Z			29-23-11	ALL
	S/R		W8122	1010Z			29-25-11	ALL
	S/R		W8122	1011Z			27-83-11	ALL
	S/R		W8122	2001Z			27-61-49	ALL
	S/R		W8122	2002Z			27-61-49	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46048J	**AL0720D/201/R026**		**RCPT-CONDUCTIVE**				**ALL**
1		W6228	0511	22		32-42-11	ALL
2		W6228	0501	22		32-42-11	ALL
3	UNUSED						ALL
4		W6228	0591	22		32-41-11	ALL
5		W6228	0592	22		32-41-11	ALL
6		W6228	0502	22		32-42-11	ALL
7		W6228	0512	22		32-42-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W6228	2204R	22		32-42-11	ALL
11		W6228	2204B	22		32-42-11	ALL
12	UNUSED						ALL
13		W6228	2203R	22		32-42-11	ALL
14		W6228	2203B	22		32-42-11	ALL
15	UNUSED						ALL
16		W6228	0509	22		31-31-15	ALL
S/R		W6228	2203Z			32-42-11	ALL
D46048P	**AL0720D/201/R024**		**PLUG- CONDUCTIVE**				**ALL**
1		W8230	2205R	20		32-42-11	ALL
2		W8230	2205B	20		32-42-11	ALL
3	UNUSED						ALL
4		W8230	2201R	18		32-41-11	ALL
5		W8230	2201B	18		32-41-11	ALL
6		W8230	2202R	20		32-42-11	ALL
7		W8230	2202B	20		32-42-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W8230	2204R	20		32-42-11	ALL
11		W8230	2204B	20		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46048P		**AL0720D/201/R024**		**PLUG- CONDUCTIVE (continued)**				**ALL**
	12	UNUSED						ALL
	13		W8230	2203R	20		32-42-11	ALL
	14		W8230	2203B	20		32-42-11	ALL
	15	UNUSED						ALL
	16		W8230	1001	20		31-31-15	ALL
	S/R		W8230	1001Z			31-31-15	ALL
	S/R		W8230	2201Z			32-41-11	ALL
	S/R		W8230	2202Z			32-42-11	ALL
	S/R		W8230	2203Z			32-42-11	ALL
	S/R		W8230	2204Z			32-42-11	ALL
	S/R		W8230	2205Z			32-42-11	ALL
D46050J		**AL0720D/ /**		**RCPT**				**ALL**
	1		W6730	0513	20		49-62-11	ALL
	2		W6730	0514	20		49-62-11	ALL
	3		W6730	2001R	20		29-32-11	ALL
	4		W6730	2001B	20		29-32-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W6730	6006R	20		26-21-11	ALL
	8		W6730	6007R	20		26-21-11	ALL
	9		W6730	0591	22		32-41-11	ALL
	10		W6730	0592	22		32-41-11	ALL
	11		W6730	6001R	20		26-11-31	ALL
	12		W6730	6002R	20		26-11-31	ALL
	13		W6730	6003R	20		26-11-31	ALL
	14	UNUSED						ALL
	15		W6730	2201B	22		24-22-31	ALL
	16		W6730	2201R	22		24-22-31	ALL
	17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46050J	**AL0720D/ /**		**RCPT (continued)**				**ALL**
18		W6730	6004R	20		26-11-31	ALL
19		W6730	6005R	20		26-11-31	ALL
S/R		W6730	2001Z			29-32-11	ALL
DED		W6730	2201Z			24-22-31	ALL
D46050P	**AL0720D/ /**		**PLUG- CONDUCTIVE**				**ALL**
1		W8524	0513	18		49-62-11	ALL
2		W8524	0514	18		49-62-11	ALL
3		W8524	2001R	18		29-32-11	ALL
4		W8524	2001B	18		29-32-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W8524	6007R	18		26-21-11	ALL
8		W8524	6008R	18		26-21-11	ALL
9		W8524	2201R	18		32-41-11	ALL
10		W8524	2201B	18		32-41-11	ALL
11		W8524	6001R	18		26-11-31	ALL
12		W8524	6002R	18		26-11-31	ALL
13		W8524	6003R	18		26-11-31	ALL
14	UNUSED						ALL
15		W8524	2202B	18		24-22-31	ALL
16		W8524	2202R	18		24-22-31	ALL
17	UNUSED						ALL
18		W8524	6006R	18		26-11-31	ALL
19		W8524	6005R	18		26-11-31	ALL
S/R		W8524	2001Z			29-32-11	ALL
S/R		W8524	2201Z			32-41-11	ALL
DED		W8524	2202Z			24-22-31	ALL
D46051J	**E001-03/ /**		**RCPT**				**ALL**
A01		W0131	0154	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46051J		**E001-03/ /**		**RCPT (continued)**				**ALL**
	A02	UNUSED						ALL
	A03		W0131	0010	20		23-31-01	ALL
	A04	UNUSED						ALL
	A05		W0131	0095	24		33-25-11	ALL
	A06		W0131	0096	24		33-25-11	ALL
	A07	UNUSED						ALL
	A08		W0131	0061	24		32-41-11	ALL
	A09		W0131	0069	24		32-42-11	ALL
	A10		W0131	0395	22		32-49-11	ALL
	B01		W0131	0070	24		32-42-11	ALL
	B02		W0131	0071	24		32-42-11	ALL
	B03	UNUSED						ALL
	B04		W0131	0401	22		32-46-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0131	0013	18		23-31-01	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D46051P		**E001-03/ /**		**PLUG E1-3 SHELF**				**ALL**
	A01		W2661	0001	20		44-21-22	ALL
	A02	UNUSED						ALL
	A03		W2661	0003	20		23-31-01	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46051P	**E001-03/ /**		**PLUG E1-3 SHELF (continued)**				**ALL**
A05		W2661	0005	24		33-25-11	ALL
A06		W2661	0006	24		33-25-11	ALL
A07	UNUSED						ALL
A08		W2661	0008	24		32-41-11	ALL
A09		W2661	0009	24		32-42-11	ALL
A10		W2661	0014	22		32-49-11	ALL
B01		W2661	0011	24		32-42-11	ALL
B02		W2661	0012	24		32-42-11	ALL
B03	UNUSED						ALL
B04		W2661	0013	22		32-46-11	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W2661	0004	18		23-31-01	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
D46052J	**P006-00/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0044	0107	20		33-18-11	ALL
4		W0044	0708	20		33-18-11	ALL
5		W0044	0153	20		33-18-21	ALL
6		W0044	0155	20		33-18-21	ALL
7		W0044	0157	20		33-18-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46052J		**P006-00/ /**		**RCPT- (continued)**				**ALL**
	8		W0044	0168	20		33-18-24	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0044	0162	20		33-18-62	ALL
	12	UNUSED						ALL
	13		W0044	0203	20		33-18-62	ALL
	14	UNUSED						ALL
	15		W0044	0165	20		33-18-22	ALL
	16		W0044	0055	20		31-52-11	ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0044	0066	16		33-11-32	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25		W0044	0538	22		29-32-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0044	0257	24		32-31-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46052J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
D46052P	**P006-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W2030	5509	20		33-18-11	ALL
4		W2030	5525	20		33-18-11	ALL
5		W2030	5511	20		33-18-21	ALL
6		W2030	5512	20		33-18-21	ALL
7		W2030	5513	20		33-18-21	ALL
8		W2030	5514	20		33-18-24	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W2030	5521	20		33-18-62	ALL
12	UNUSED						ALL
13		W2030	5517	20		33-18-62	ALL
14	UNUSED						ALL
15		W2030	5520	20		33-18-22	ALL
16		W2030	5524	20		31-52-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W2030	5506	16		33-11-32	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W2030	5528	22		29-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46052P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2030	5529	22		32-31-11	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D46054J		**E003-02/ /**		**RCTP-CONDUCTIVE**				**ALL**
	A01		W0321	0318	20		78-34-21	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	0314	20		78-34-21	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46054J	**E003-02/ /**		**RCTP-CONDUCTIVE (continued)**				**ALL**
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D46054P	**E003-02/ /**		**PLUG**				**ALL**
A01		W6732	2501B	20		78-34-21	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W6732	2501R	20		78-34-21	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W6732	2501Z			78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46061J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0561	22		34-31-21	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0044	0508	20		22-18-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0044	0351	20		22-11-11	ALL
	8		W0044	0279	20		34-53-21	ALL
	9		W0044	0281	22		34-55-21	ALL
	10		W0044	0349	22		23-31-06	ALL
	11		W0044	0286R	22		26-12-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0044	0288	24		27-52-11	ALL
	15		W0044	0562	24		27-52-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W0044	0522	16		34-21-21	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W0044	0506	20		22-14-11	ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46061J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
30	UNUSED						ALL
31		W0044	3215B	20		23-11-21	ALL
32		W0044	3215Y	20		23-11-21	ALL
33		W0044	3215R	20		23-11-21	ALL
34	UNUSED						ALL
35	UNUSED						ALL
36		W0044	6171	20		21-27-51	ALL
37		W0044	6172	20		21-27-51	ALL
38		W0044	6173	20		21-27-51	ALL
39		W0044	6174	20		21-27-51	ALL
D46061P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2103	0001	22		34-31-21	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2103	0004	20		22-18-11	ALL
5	UNUSED						ALL
6		W2103	0006	20		SPARE	ALL
7		W2103	0007	20		22-11-11	ALL
8		W2103	0008	20		34-53-21	ALL
9		W2103	0009	22		34-55-21	ALL
10		W2103	0010	22		23-31-06	ALL
11		W2103	0011R	22		26-12-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W2103	0014	24		27-52-11	ALL
15		W2103	0015	24		27-52-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46061P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2103	0023	16		34-21-21	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W2103	0028	20		22-14-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W2103	3003B	20		23-11-21	ALL
	32		W2103	3003Y	20		23-11-21	ALL
	33		W2103	3003R	20		23-11-21	ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36		W2103	0050	20		21-27-51	ALL
	37		W2103	0051	20		21-27-51	ALL
	38		W2103	0052	20		21-27-51	ALL
	39		W2103	0053	22		21-27-51	ALL
D46063J		**P006-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0044	0511	22		27-32-21	ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46063J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0044	0398	16		31-65-21	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19		W0044	0397	16		31-65-21	ALL
20		W0044	0510	22		27-32-21	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0044	0888	16		31-65-11	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
D46063P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2169	0001	20		SPARE	ALL
2		W2169	0002	22		SPARE	ALL
3		W2169	0003	20		SPARE	ALL
4		W2169	0004	22		SPARE	ALL
5	UNUSED						ALL
6		W2169	0006	22		27-32-21	ALL
7		W2169	0007	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46063P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	8		W2169	0008	22		SPARE	ALL
	9		W2169	0009	20		SPARE	ALL
	10		W2169	0010	20		SPARE	ALL
	11		W2169	0011	20		SPARE	ALL
	12		W2169	0012	20		SPARE	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W2169	0015	16		31-65-21	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19		W2169	0019	16		31-65-21	ALL
	20		W2169	0005	22		27-32-21	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2169	0023	16		31-65-11	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
D46065J		**P006-00/ /**		**RCPT-**				**ALL**
	1		W0044	0393	16		31-65-21	ALL
	2		W0044	0394	16		31-65-21	ALL
	3		W0044	0507	20		22-18-11	ALL
	4	UNUSED						ALL
	5		W0044	0523	22		34-51-41	ALL
	6		W0044	0247	16		23-12-21	ALL
	7		W0044	0520	20		34-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46065J	**P006-00/ /**		**RCPT- (continued)**				**ALL**
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0044	0352	20		22-11-12	ALL
13		W0044	0350	20		22-11-11	ALL
14		W0044	0353	20		22-11-12	ALL
15		W0044	0290	20		22-11-12	ALL
16		W0044	0270	22		32-42-11	ALL
17	16	W0044	0065	16		33-11-21	ALL
18		W0044	0089	20		33-14-11	ALL
19		W0044	0321	20		33-25-11	ALL
20		W0044	0161	20		33-18-21	ALL
21		W0044	0591	22		27-81-11	ALL
22		W0044	0287	24		27-28-11	ALL
23	16	W0044	0064	16		33-11-11	ALL
24	UNUSED						ALL
25		W0044	0316	20		33-25-11	ALL
26	UNUSED						ALL
27		W0044	6210	22		32-31-15	ALL
28		W0044	0521	20		34-21-21	ALL
29		W0044	0396	22		31-65-21	ALL
30	UNUSED						ALL
31		W0044	0544	20		33-14-11	ALL
32	UNUSED						ALL
D46065P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2383	0001	16		31-65-21	ALL
2		W2383	0002	16		31-65-21	ALL
3		W2383	0003	20		22-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46065P		**P006-00/ /**		**PLUG- (continued)**				**ALL**
	4		W2383	0038	18		SPARE	ALL
	5		W2383	0005	22		34-51-41	ALL
	6		W2383	0016	16		23-12-21	ALL
	7		W2383	0007	20		34-21-21	ALL
	8	UNUSED						ALL
	9		W2383	0009	24		SPARE	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W2383	0012	20		22-11-12	ALL
	13		W2383	0013	20		22-11-11	ALL
	14		W2383	0004	20		22-11-12	ALL
	15		W2383	0025	20		22-11-12	ALL
	16		W2383	0006	22		32-42-11	ALL
	17	16	W2383	0017	16		33-11-21	ALL
	18		W2383	0008	20		33-14-11	ALL
	19	18	W2383	0049	18		33-25-11	ALL
	20		W2383	0020	20		33-18-21	ALL
	21		W2383	0021	22		27-81-11	ALL
	22		W2383	0022	24		27-28-11	ALL
	23	16	W2383	0050	16		33-11-11	ALL
	24		W2383	0024	20		SPARE	ALL
	25	18	W2383	0048	18		33-25-11	ALL
	26		W2383	0026	22		SPARE	ALL
	27		W2383	0047	22		32-31-15	ALL
	28		W2383	0028	20		34-21-21	ALL
	29		W2383	0029	22		31-65-21	ALL
	30	UNUSED						ALL
	31		W2383	0030	20		33-14-11	ALL
	32		W2383	0023	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46067J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0222	20		34-61-11	ALL
2		W0044	0221	20		34-61-11	ALL
3		W0044	0245	22		34-57-21	ALL
4		W0044	0509	22		27-32-21	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0044	0554	20		22-23-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0044	0772	22		23-27-31	ALL
14	UNUSED						ALL
15		W0044	0574	16		23-12-31	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	18	W0044	6217	18		27-61-41	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46067P		**P006-00/ /**		**PLUG-**				**ALL**
	1		W2231	0001	20		34-61-11	ALL
	2		W2231	0002	20		34-61-11	ALL
	3		W2231	0003	22		34-57-21	ALL
	4		W2231	0004	22		27-32-21	ALL
	5	UNUSED						ALL
	6		W2231	0006	20		SPARE	ALL
	7		W2231	0007	20		SPARE	ALL
	8		W2231	0008	20		22-23-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W2231	0013	22		23-27-31	ALL
	14	UNUSED						ALL
	15		W2231	0015	16		23-12-31	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	18	W2231	0020	18		27-61-41	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W2231	0027	16		SPARE	ALL
	28		W2231	0028	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46069J	**P006-00/ /**		**RCPT-**				**ALL**
1		W0044	0693	22		44-21-22	ALL
2		W0044	0788	22		32-46-11	ALL
3		W0044	0636	20		23-31-01	ALL
4		W0044	0348	18		23-31-01	ALL
5		W0044	0333	24		33-25-11	ALL
6		W0044	0315	24		33-25-11	ALL
7	UNUSED						ALL
8		W0044	0514	24		32-41-11	ALL
9		W0044	0266	24		32-42-11	ALL
10		W0044	6169	22		32-49-11	ALL
11		W0044	0268	24		32-42-11	ALL
12		W0044	0269	24		32-42-11	ALL
D46069P	**P006-00/ /**		**PLUG-**				**ALL**
1		W2661	0001	20		44-21-22	ALL
2		W2661	0013	22		32-46-11	ALL
3		W2661	0003	20		23-31-01	ALL
4		W2661	0004	18		23-31-01	ALL
5		W2661	0005	24		33-25-11	ALL
6		W2661	0006	24		33-25-11	ALL
7	UNUSED						ALL
8		W2661	0008	24		32-41-11	ALL
9		W2661	0009	24		32-42-11	ALL
10		W2661	0014	22		32-49-11	ALL
11		W2661	0011	24		32-42-11	ALL
12		W2661	0012	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46100J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0113	24		32-41-11	ALL
	A02		W0066	0111	24		32-41-11	ALL
	A03		W0066	6016	20		74-11-11	ALL
	A04		W0066	0152	22		34-53-21	ALL
	A05		W0066	0156	22		34-53-31	ALL
	A06		W0066	0008	22		21-27-31	ALL
	A07		W0066	0076	22		SPARE	ALL
	A08		W0066	0075	22		SPARE	ALL
	A09		W0066	0016	22		21-27-31	ALL
	A10		W0066	0112	24		32-41-11	ALL
	B01		W0066	0116	22		32-44-11	ALL
	B02		W0066	0118	22		32-44-11	ALL
	B03		W0066	0121	22		32-44-11	ALL
	B04		W0066	0138	20		33-36-11	ALL
	B05	UNUSED						ALL
	B06		W0066	0395	24		36-11-22	ALL
	B07		W0066	0015	22		21-27-31	ALL
	B08		W0066	0099	22		29-23-11	ALL
	B09		W0066	0434	22		21-27-31	ALL
	B10		W0066	0373	22		34-33-21	ALL
D46100P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W5158	0610	22		32-41-11	ALL
	A02		W5158	0686	22		32-41-11	ALL
	A03		W5158	6016	20		74-11-11	ALL
	A04		W5158	0514	22		34-53-21	ALL
	A05		W5158	0691	22		34-53-31	ALL
	A06		W5158	0576	22		21-27-31	ALL
	A07		W5158	0546	22		SPARE	ALL
	A08		W5158	0547	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46100P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
A09		W5158	0720	22		21-27-31	ALL
A10		W5158	0612	22		32-41-11	ALL
B01		W5158	0521	22		32-44-11	ALL
B02		W5158	0522	22		32-44-11	ALL
B03		W5158	0523	22		32-44-11	ALL
B04		W5158	0688	20		33-36-11	ALL
B05	UNUSED						ALL
B06		W5158	0076	24		36-11-22	ALL
B07		W5158	0676	22		21-27-31	ALL
B08		W5158	0113	22		29-23-11	ALL
B09		W5158	0712	22		21-27-31	ALL
B10		W5158	0510	22		34-33-21	ALL
D46102J	**J046-00/ /**		**RCPT-**				**ALL**
1		W0066	0103	24		29-33-11	ALL
2		W0066	0005	22		21-27-21	ALL
3		W0066	0006	22		21-27-21	ALL
4		W0066	0071	22		31-53-11	ALL
5		W0066	2003B	22		32-31-12	ALL
6		W0066	2003R	22		32-31-12	ALL
7		W0066	0123	24		32-64-12	ALL
8		W0066	0124	24		32-64-12	ALL
9		W0066	0125	24		32-64-12	ALL
10		W0066	2005B	22		32-64-12	ALL
11		W0066	2005R	22		32-64-12	ALL
12		W0066	2004B	22		32-64-12	ALL
13		W0066	2004R	22		32-64-12	ALL
14		W0066	0203	22		32-64-21	ALL
15		W0066	0204	22		32-64-21	ALL
16		W0066	0427	24		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46102J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	17		W0066	0003	24		21-25-11	ALL
	18		W0066	0075	22		SPARE	ALL
	19		W0066	0076	22		SPARE	ALL
	20		W0066	0082	22		SPARE	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W0066	0265	20		44-21-10	ALL
	24		W0066	0238	20		33-42-21	ALL
	25		W0066	0143	20		33-42-21	ALL
	26		W0066	0412	22		27-33-11	ALL
	27		W0066	0417	22		27-33-11	ALL
	28		W0066	0418	22		27-33-11	ALL
	29		W0066	0393	22		21-25-11	ALL
	30		W0066	0135	20		32-64-21	ALL
	31		W0066	0134	20		32-64-21	ALL
	32		W0066	0136	20		33-36-11	ALL
	33		W0066	0140	20		33-36-12	ALL
	34		W0066	0266	20		44-21-10	ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W0066	2028R	22		52-71-11	ALL
	38		W0066	2028B	22		52-71-11	ALL
	39		W0066	0398	24		21-51-24	ALL
D46102P		**J046-00/ /**		**PLUG-**				**ALL**
	1		W5160	0527	20		29-33-11	ALL
	2		W5160	0531	22		21-27-21	ALL
	3		W5160	0532	22		21-27-21	ALL
	4		W5160	0578	22		31-53-11	ALL
	5		W5160	2232B	22		32-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46102P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
6		W5160	2232R	22		32-31-12	ALL
7		W5160	0541	22		32-64-12	ALL
8		W5160	0542	22		32-64-12	ALL
9		W5160	0543	22		32-64-12	ALL
10		W5160	2223B	22		32-64-12	ALL
11		W5160	2223R	22		32-64-12	ALL
12		W5160	2224B	22		32-64-12	ALL
13		W5160	2224R	22		32-64-12	ALL
14		W5160	0557	22		32-64-21	ALL
15		W5160	0558	22		32-64-21	ALL
16		W5160	0540	24		21-25-11	ALL
17		W5160	0529	22		21-25-11	ALL
18		W5160	0652	22		SPARE	ALL
19		W5160	0653	22		SPARE	ALL
20		W5160	0629	22		SPARE	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W5160	0103	20		44-21-10	ALL
24		W5160	0149	20		33-42-21	ALL
25		W5160	0012	20		33-42-21	ALL
26		W5160	0122	22		27-33-11	ALL
27		W5160	0123	22		27-33-11	ALL
28		W5160	0124	22		27-33-11	ALL
29		W5160	0528	22		21-25-11	ALL
30		W5160	0549	22		32-64-21	ALL
31		W5160	0556	22		32-64-21	ALL
32		W5160	0055	20		33-36-11	ALL
33		W5160	0047	20		33-36-12	ALL
34		W5160	0104	20		44-21-10	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46102P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	35	UNUSED						ALL
	36	UNUSED						ALL
	37		W5160	2458R	22		52-71-11	ALL
	38		W5160	2458B	22		52-71-11	ALL
	39		W5160	5501	24		21-51-24	ALL
D46104J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0012	22		21-27-31	ALL
	A02		W0066	0018	22		21-33-11	ALL
	A03		W0066	0020	22		21-33-11	ALL
	A04		W0066	0029	20		31-52-11	ALL
	A05		W0066	0030	20		31-52-11	ALL
	A06		W0066	0033	20		31-52-21	ALL
	A07		W0066	0034	20		31-52-21	ALL
	A08		W0066	0039	20		31-52-25	ALL
	A09		W0066	0040	20		31-52-25	ALL
	A10		W0066	0041	20		31-52-31	ALL
	B01		W0066	0042	20		31-52-31	ALL
	B02		W0066	0045	20		31-52-35	ALL
	B03		W0066	0046	20		31-52-35	ALL
	B04		W0066	0048	20		31-52-41	ALL
	B05		W0066	0049	20		31-52-41	ALL
	B06		W0066	0052	20		31-52-51	ALL
	B07		W0066	0053	20		31-52-51	ALL
	B08		W0066	0340	22		21-33-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46104P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W5514	5784	24		21-27-31	ALL
	A02		W5514	5551	22		21-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46104P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
A03		W5514	5552	22		21-33-11	ALL
A04		W5514	5582	20		31-52-11	ALL
A05		W5514	5524	20		31-52-11	ALL
A06		W5514	5525	20		31-52-21	ALL
A07		W5514	5526	20		31-52-21	ALL
A08		W5514	5527	20		31-52-25	ALL
A09		W5514	5528	20		31-52-25	ALL
A10		W5514	5529	20		31-52-31	ALL
B01		W5514	5530	20		31-52-31	ALL
B02		W5514	5531	20		31-52-35	ALL
B03		W5514	5532	20		31-52-35	ALL
B04		W5514	5533	20		31-52-41	ALL
B05		W5514	5534	20		31-52-41	ALL
B06		W5514	5537	20		31-52-51	ALL
B07		W5514	5538	20		31-52-51	ALL
B08		W5514	5601	22		21-33-11	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D46106J	**J046-00/ /**		**RCPT-**				**ALL**
1		W0066	2022B	22		24-22-21	ALL
2		W0066	2022R	22		24-22-21	ALL
3		W0066	0103	24		29-33-11	ALL
4		W0066	0104	24		29-33-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46106J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	11	UNUSED						ALL
	12		W0066	0185	24		76-21-21	ALL
	13		W0066	0186	24		76-21-21	ALL
	14		W0066	0190	20		76-21-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0066	0394	24		36-11-22	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W0066	0441	20		78-34-21	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46106P	**AJ0046B/ /**		**PLUG-**				**ALL**
1		W6506	2201B	22		24-22-21	ALL
2		W6506	2201R	22		24-22-21	ALL
3		W6506	0516	24		29-33-11	ALL
4		W6506	0515	24		29-33-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W6506	6005	24		76-21-21	ALL
13		W6506	6006	24		76-21-21	ALL
14		W6506	6030	20		76-21-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W6506	5503	24		36-11-22	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46106P		**AJ0046B/ /**		**PLUG- (continued)**				**ALL**
	30		W6506	6015	20		78-34-21	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D46108J		**J046-00/ /**		**RCPT-**				**ALL**
	1		W0066	0001	24		21-25-11	ALL
	2		W0066	0004	22		21-25-11	ALL
	3		W0066	0017	22		21-33-11	ALL
	4		W0066	0019	22		21-33-11	ALL
	5		W0066	0021	24		21-43-21	ALL
	6		W0066	0270	24		21-43-21	ALL
	7		W0066	0035	20		31-52-21	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W0066	0036	20		31-52-21	ALL
	11		W0066	0038	20		31-52-25	ALL
	12		W0066	0037	20		31-52-25	ALL
	13		W0066	0043	20		31-52-31	ALL
	14		W0066	0044	20		31-52-35	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0066	0054	20		31-52-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46108J	**J046-00/ /**		**RCPT- (continued)**				**ALL**
19		W0066	0057	20		31-52-65	ALL
20		W0066	0066	20		31-52-75	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0066	0166	24		52-71-12	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W0066	0212	20		52-71-13	ALL
27		W0066	0213	20		52-71-13	ALL
28		W0066	0216	20		52-71-14	ALL
29		W0066	0217	20		52-71-14	ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34		W0066	0449	22		21-27-51	ALL
35		W0066	0051	20		31-52-51	ALL
36		W0066	0032	20		31-52-51	ALL
37		W0066	0061	20		31-52-55	ALL
38		W0066	0450	22		21-27-51	ALL
39	UNUSED						ALL
D46108P	**J046-00/ /**		**PLUG-**				**ALL**
1		W2508	5611	22		21-25-11	ALL
2		W2508	5512	22		21-25-11	ALL
3		W2508	5507	22		21-33-11	ALL
4		W2508	5508	22		21-33-11	ALL
5		W2508	5614	24		21-43-21	ALL
6		W2508	5615	24		21-43-21	ALL
7		W2508	5703	20		31-52-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46108P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	8	UNUSED						ALL
	9	UNUSED						ALL
	10		W2508	5705	20		31-52-21	ALL
	11		W2508	5710	20		31-52-25	ALL
	12		W2508	5706	20		31-52-25	ALL
	13		W2508	5713	20		31-52-31	ALL
	14		W2508	5716	20		31-52-35	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W2508	5729	20		31-52-61	ALL
	19		W2508	5732	20		31-52-65	ALL
	20		W2508	5735	20		31-52-75	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2508	0003	24		52-71-12	ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W2508	0008	20		52-71-13	ALL
	27		W2508	0006	20		52-71-13	ALL
	28		W2508	0009	20		52-71-14	ALL
	29		W2508	0007	20		52-71-14	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34		W2508	5780	22		21-27-51	ALL
	35		W2508	5722	20		31-52-51	ALL
	36		W2508	5747	20		31-52-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46108P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
37		W2508	5726	20		31-52-55	ALL
38		W2508	5781	22		21-27-51	ALL
39	UNUSED						ALL
D46110J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0066	0101	22		29-25-11	ALL
A02	UNUSED						ALL
A03		W0066	1016	22		30-31-12	ALL
A04	UNUSED						ALL
A05		W0066	1017	22		30-31-12	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0066	0102	22		29-25-11	ALL
B02		W0066	0098	22		29-23-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0066	1016Z			30-31-12	ALL
PERG	1F	W0066	1017Z			30-31-12	ALL
D46110P	**AJ0046A/178/R026**		**PLUG-**				**ALL**
A01		W6208	0584	22		29-25-11	ALL
A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46110P		**AJ0046A/178/R026**		**PLUG- (continued)**				**ALL**
	A03		W6208	1005	22		30-31-12	ALL
	A04	UNUSED						ALL
	A05		W6208	1004	22		30-31-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6208	0585	22		29-25-11	ALL
	B02		W6208	0583	22		29-23-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6208	1004Z			30-31-12	ALL
	PERG	1F	W6208	1005Z			30-31-12	ALL
D46112J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0007	22		21-27-31	ALL
	A02		W0066	0014	22		21-27-31	ALL
	A03		W0066	0242	22		52-71-11	ALL
	A04		W0066	0161	24		52-71-11	ALL
	A05		W0066	0163	24		52-71-11	ALL
	A06		W0066	0164	24		52-71-11	ALL
	A07		W0066	0165	24		52-71-12	ALL
	A08		W0066	0167	24		52-71-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46112J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	A09		W0066	0343	24		52-71-11	ALL
	A10		W0066	0443	22		27-61-45	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46112P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W2216	5524	22		21-27-31	ALL
	A02		W2216	5502	22		21-27-31	ALL
	A03		W2216	0012	24		52-71-11	ALL
	A04		W2216	0004	24		52-71-11	ALL
	A05		W2216	0003	24		52-71-11	ALL
	A06		W2216	0005	24		52-71-11	ALL
	A07		W2216	0006	24		52-71-12	ALL
	A08		W2216	0008	24		52-71-12	ALL
	A09		W2216	0014	24		52-71-11	ALL
	A10		W2216	5619	22		27-61-45	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46112P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46114J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0005	22		21-27-21	ALL
	A02		W0066	0079	22		24-22-21	ALL
	A03		W0066	0080	22		24-28-11	ALL
	A04		W0066	0081	22		24-28-11	ALL
	A05		W0066	0091	20		28-42-11	ALL
	A06		W0066	0092	20		28-42-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0066	0123	24		32-64-12	ALL
	B02		W0066	0124	24		32-64-12	ALL
	B03		W0066	0125	24		32-64-12	ALL
	B04		W0066	0126	24		23-31-06	ALL
	B05		W0066	0127	24		23-31-06	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0066	0373	22		34-33-21	ALL
D46114P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W2218	5501	22		21-27-21	ALL
	A02		W2218	0502	22		24-22-21	ALL
	A03		W2218	0509	22		24-28-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46114P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
A04		W2218	0510	22		24-28-11	ALL
A05		W2218	6003	20		28-42-11	ALL
A06		W2218	6004	20		28-42-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W2218	0601	24		32-64-12	ALL
B02		W2218	0602	24		32-64-12	ALL
B03		W2218	0603	24		32-64-12	ALL
B04		W2218	0041	24		23-31-06	ALL
B05		W2218	0042	24		23-31-06	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W2218	6058	22		34-33-21	ALL
D46116J	**J046-00/ /**		**RCPT-**				**ALL**
1		W0066	0070	22		31-53-11	ALL
2		W0066	0275	20		27-62-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W0066	0336	22		31-53-11	ALL
6		W0066	0281	20		27-62-11	ALL
7		W0066	0280	20		27-62-11	ALL
8		W0066	0211	20		52-71-13	ALL
9		W0066	0213	20		52-71-13	ALL
10		W0066	0212	20		52-71-13	ALL
11		W0066	0341	22		21-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46116J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	12		W0066	0143	20		33-42-21	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0066	0004	22		21-25-11	ALL
	16		W0066	0013	22		21-27-31	ALL
	17		W0066	0277	20		27-62-11	ALL
	18		W0066	0366	22		23-15-15	ALL
	19		W0066	0367	22		23-15-15	ALL
	20		W0066	0282	20		27-62-11	ALL
	21		W0066	0246	22		44-21-22	ALL
	22		W0066	0284	20		27-62-11	ALL
	23		W0066	0283	20		27-62-11	ALL
	24	UNUSED						ALL
	25		W0066	0101	22		29-25-11	ALL
	26	UNUSED						ALL
	27		W0066	0098	22		29-23-11	ALL
	28		W0066	0007	22		21-27-31	ALL
	29		W0066	0009	22		21-27-31	ALL
	30		W0066	0074	20		33-18-11	ALL
	31		W0066	0224	22		34-41-11	ALL
	32		W0066	0370	20		73-22-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W0066	0381	24		36-11-12	ALL
	36		W0066	0371	20		73-22-11	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46116J	**J046-00/ /**		**RCPT- (continued)**				**ALL**
41	UNUSED						ALL
D46116P	**J046-00/ /**		**PLUG-**				**ALL**
1		W5156	0578	22		31-53-11	ALL
2		W5156	0105	20		27-62-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5156	0576	22		31-53-11	ALL
6		W5156	0106	20		27-62-11	ALL
7		W5156	0104	20		27-62-11	ALL
8		W5156	0004	20		52-71-13	ALL
9		W5156	0008	20		52-71-13	ALL
10		W5156	0630	20		52-71-13	ALL
11		W5156	0402	22		21-33-11	ALL
12		W5156	0021	20		33-42-21	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W5156	0629	22		21-25-11	ALL
16		W5156	0640	22		21-27-31	ALL
17		W5156	0084	20		27-62-11	ALL
18		W5156	0658	22		23-15-15	ALL
19		W5156	0066	22		23-15-15	ALL
20		W5156	0109	20		27-62-11	ALL
21		W5156	0659	22		44-21-22	ALL
22		W5156	0108	22		27-62-11	ALL
23		W5156	0107	20		27-62-11	ALL
24	UNUSED						ALL
25		W5156	0584	22		29-25-11	ALL
26	UNUSED						ALL
27		W5156	0548	22		29-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46116P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	28		W5156	0641	22		21-27-31	ALL
	29		W5156	0642	22		21-27-31	ALL
	30		W5156	5512	20		33-18-11	ALL
	31		W5156	0027	22		34-41-11	ALL
	32		W5156	0076	20		73-22-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35		W5156	0088	24		36-11-12	ALL
	36		W5156	0077	20		73-22-11	ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
D46118J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	2012R	24		73-21-11	ALL
	A02		W0066	2012B	24		73-21-11	ALL
	A03		W0066	0464	24		21-43-21	ALL
	A04		W0066	0168	24		73-22-31	ALL
	A05		W0066	1002	20		74-11-11	ALL
	A06		W0066	0465	24		21-43-21	ALL
	A07		W0066	0200	20		74-11-11	ALL
	A08		W0066	0184	24		76-21-21	ALL
	A09	UNUSED						ALL
	A10		W0066	0191	20		76-21-21	ALL
	B01		W0066	1001	20		73-22-11	ALL
	B02		W0066	0179	20		73-22-11	ALL
	B03		W0066	0453	22		21-43-21	ALL
	B04		W0066	0432	20		78-34-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46118J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B05		W0066	0452	22		21-43-21	ALL
	B06		W0066	0442	20		78-34-21	ALL
	B07		W0066	0454	22		21-27-21	ALL
	B08		W0066	0455	22		21-27-21	ALL
	B09		W0066	0187	20		76-21-21	ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	1001Z			73-22-11	ALL
	PERG	1F	W0066	1002Z			74-11-11	ALL
	PERG	1F	W0066	2012Z			73-21-11	ALL
D46118P		**J046-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W6510	2601R	24		73-21-11	ALL
	A02		W6510	2601B	24		73-21-11	ALL
	A03		W6510	0019	24		21-43-21	ALL
	A04		W6510	6012	24		73-22-31	ALL
	A05		W6510	1301	20		74-11-11	ALL
	A06		W6510	0020	24		21-43-21	ALL
	A07		W6510	6015	20		74-11-11	ALL
	A08		W6510	6013	24		76-21-21	ALL
	A09	UNUSED						ALL
	A10		W6510	6003	20		76-21-21	ALL
	B01		W6510	1311	20		73-22-11	ALL
	B02		W6510	6011	20		73-22-11	ALL
	B03		W6510	0016	22		21-43-21	ALL
	B04		W6510	6063	20		78-34-21	ALL
	B05		W6510	0015	22		21-43-21	ALL
	B06		W6510	6031	20		78-34-21	ALL
	B07		W6510	0017	22		21-27-21	ALL
	B08		W6510	0018	22		21-27-21	ALL
	B09		W6510	6004	20		76-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46118P		**J046-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	PERG	1F	W6510	1301Z			74-11-11	ALL
	PERG	1F	W6510	1311Z			73-22-11	ALL
	PERG	1F	W6510	2601Z			73-21-11	ALL
D46120J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0093	20		29-11-11	ALL
	A02		W0066	0023	24		21-43-21	ALL
	A03		W0066	0088	20		28-21-11	ALL
	A04		W0066	0073	20		33-18-11	ALL
	A05	UNUSED						ALL
	A06		W0066	0024	24		21-51-11	ALL
	A07		W0066	0459	22		21-27-51	ALL
	A08		W0066	0259	20		28-23-11	ALL
	A09		W0066	0260	20		28-23-11	ALL
	A10		W0066	0443	22		27-61-45	ALL
	B01		W0066	0094	20		29-11-11	ALL
	B02		W0066	0272	24		21-43-21	ALL
	B03		W0066	0027	24		21-43-21	ALL
	B04		W0066	0072	20		33-18-11	ALL
	B05		W0066	0214	20		52-71-14	ALL
	B06	UNUSED						ALL
	B07		W0066	0461	22		21-27-51	ALL
	B08		W0066	0261	20		28-23-11	ALL
	B09		W0066	0334	20		28-23-11	ALL
	B10		W0066	0215	20		52-71-14	ALL
D46120P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W5158	0527	20		29-11-11	ALL
	A02		W5158	0563	24		21-43-21	ALL
	A03		W5158	0529	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46120P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	A04		W5158	0674	20		33-18-11	ALL
	A05	UNUSED						ALL
	A06		W5158	5501	24		21-51-11	ALL
	A07		W5158	0132	22		21-27-51	ALL
	A08		W5158	0106	20		28-23-11	ALL
	A09		W5158	0105	20		28-23-11	ALL
	A10		W5158	0711	22		27-61-45	ALL
	B01		W5158	0528	20		29-11-11	ALL
	B02		W5158	0564	24		21-43-21	ALL
	B03		W5158	0566	24		21-43-21	ALL
	B04		W5158	0687	20		33-18-11	ALL
	B05		W5158	0010	20		52-71-14	ALL
	B06	UNUSED						ALL
	B07		W5158	0133	22		21-27-51	ALL
	B08		W5158	0104	20		28-23-11	ALL
	B09		W5158	0110	20		28-23-11	ALL
	B10		W5158	0014	20		52-71-14	ALL
D46122J		**J046-00/ /**		**RCPT-**				**ALL**
	1		W0066	0028	22		31-31-15	ALL
	2		W0066	0163	24		52-71-11	ALL
	3		W0066	0162	24		SPARE	ALL
	4		W0066	0164	24		52-71-11	ALL
	5		W0066	0243	22		52-71-11	ALL
	6		W0066	0161	24		52-71-11	ALL
	7		W0066	0167	24		52-71-12	ALL
	8		W0066	0166	24		52-71-12	ALL
	9		W0066	0165	24		52-71-12	ALL
	10		W0066	0245	22		44-21-22	ALL
	11		W0066	2022B	22		24-22-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46122J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	12		W0066	2022R	22		24-22-21	ALL
	13	UNUSED						ALL
	14		W0066	0216	20		52-71-14	ALL
	15		W0066	0217	20		52-71-14	ALL
	16		W0066	0214	20		52-71-14	ALL
	17		W0066	0215	20		52-71-14	ALL
	18		W0066	0211	20		52-71-13	ALL
	19		W0066	0343	24		52-71-11	ALL
	20	UNUSED						ALL
	21		W0066	0126	24		23-31-06	ALL
	22		W0066	0127	24		23-31-06	ALL
	23	UNUSED						ALL
	24		W0066	0246	22		44-21-22	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W0066	0091	20		28-42-11	ALL
	28		W0066	0092	20		28-42-11	ALL
	29	UNUSED						ALL
	30		W0066	0279	20		27-62-11	ALL
	31	UNUSED						ALL
	32		W0066	0348	22		27-61-45	ALL
	33	UNUSED						ALL
	34		W0066	0359	22		31-53-11	ALL
	35		W0066	0439	22		32-46-11	ALL
	36	UNUSED						ALL
	37		W0066	0346	22		21-33-11	ALL
	38		W0066	0268	22		21-27-21	ALL
	39		W0066	0269	22		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46122P	**J046-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1		W5160	0584	22		31-31-15	ALL
2		W5160	0021	22		52-71-11	ALL
3	UNUSED						ALL
4		W5160	0043	22		52-71-11	ALL
5		W5160	0050	22		52-71-11	ALL
6		W5160	0059	22		52-71-11	ALL
7		W5160	0005	22		52-71-12	ALL
8		W5160	0026	22		52-71-12	ALL
9		W5160	0033	22		52-71-12	ALL
10		W5160	0096	22		44-21-22	ALL
11		W5160	2203B	22		24-22-21	ALL
12		W5160	2203R	22		24-22-21	ALL
13		W5160	0588	22		SPARE	ALL
14		W5160	0571	20		52-71-14	ALL
15		W5160	0572	20		52-71-14	ALL
16		W5160	0553	20		52-71-14	ALL
17		W5160	0566	20		52-71-14	ALL
18		W5160	0034	20		52-71-13	ALL
19		W5160	0179	24		52-71-11	ALL
20	UNUSED						ALL
21		W5160	0654	24		23-31-06	ALL
22		W5160	0655	24		23-31-06	ALL
23	UNUSED						ALL
24		W5160	0097	22		44-21-22	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W5160	6006	20		28-42-11	ALL
28		W5160	6007	20		28-42-11	ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46122P		**J046-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	30		W5160	0023	22		27-62-11	ALL
	31	UNUSED						ALL
	32		W5160	0159	22		27-61-45	ALL
	33	UNUSED						ALL
	34		W5160	0180	22		31-53-11	ALL
	35		W5160	0722	22		32-46-11	ALL
	36	UNUSED						ALL
	37		W5160	0308	22		27-61-42	ALL
	38		W5160	0585	22		21-27-21	ALL
	39		W5160	0586	22		21-27-21	ALL
	S/R		W5160	2203Z			24-22-21	ALL
D46124J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0095	22		29-11-12	ALL
	A02		W0066	0096	22		29-11-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0066	0097	22		29-22-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0066	0238	20		33-42-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46124J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46124P		**J046-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W2212	0515	22		29-11-12	ALL
	A02		W2212	0516	22		29-11-12	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2212	0522	22		29-22-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W2212	0014	20		33-42-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46126J		**J046-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W0066	0027	24		21-43-21	ALL
	3		W0066	0104	24		29-33-11	ALL
	4		W0066	0047	20		31-52-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46126J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	5		W0066	0187	20		76-21-21	ALL
	6		W0066	0208	20		76-21-21	ALL
	7		W0066	0189	20		76-21-21	ALL
	8		W0066	0087	20		28-21-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0066	0077	18		24-11-21	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0066	0457	22		21-27-51	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W0066	0356	22		21-33-11	ALL
	33	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46126J	**J046-00/ /**		**RCPT- (continued)**				**ALL**
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
D46126P	**J046-00/ /**		**PLUG-**				**ALL**
1	UNUSED						ALL
2		W2510	5505	24		21-43-21	ALL
3		W2510	0004	24		29-33-11	ALL
4		W2510	5701	20		31-52-41	ALL
5		W2510	6017	20		76-21-21	ALL
6		W2510	6018	20		76-21-21	ALL
7		W2510	6029	20		76-21-21	ALL
8		W2510	6026	20		28-21-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W2510	0516	18		24-11-21	ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46126P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2510	6033	22		21-27-51	ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W2510	0101	22		21-33-11	ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
D46128J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0002	24		21-25-11	ALL
	A02		W0066	0022	24		21-43-21	ALL
	A03	UNUSED						ALL
	A04		W0066	0050	20		31-52-45	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0066	0380	24		36-11-12	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46128J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0066	0271	24		21-43-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46128P		**J046-00/ /**		**PLUG**				**ALL**
	A01		W5506	5515	22		21-25-11	ALL
	A02		W5506	5512	24		21-43-21	ALL
	A03	UNUSED						ALL
	A04		W5506	5510	20		31-52-45	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5506	5503	24		36-11-12	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5506	5523	24		21-43-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46128P		**J046-00/ /**		**PLUG (continued)**				**ALL**
	B10		W5506	6506	20		SPARE	ALL
D46130J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0008	22		21-27-31	ALL
	A02		W0066	0070	22		31-53-11	ALL
	A03		W0066	6087	22		30-11-11	ALL
	A04	UNUSED						ALL
	A05		W0066	0452	22		21-43-21	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0066	0268	22		21-27-21	ALL
	B01		W0066	0259	20		28-23-11	ALL
	B02		W0066	0260	20		28-23-11	ALL
	B03		W0066	0261	20		28-23-11	ALL
	B04	UNUSED						ALL
	B05		W0066	0334	20		28-23-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0066	0269	22		21-27-21	ALL
D46130P		**AJ0046A/ /**		**PLUG-**				**ALL**
	A01		W5510	5501	22		21-27-31	ALL
	A02		W5510	0526	22		31-53-11	ALL
	A03		W5510	6090	22		30-11-11	ALL
	A04	UNUSED						ALL
	A05		W5510	0055	20		21-43-21	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46130P		**AJ0046A/ /**		**PLUG- (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5510	6018	22		21-27-21	ALL
	B01		W5510	0018	20		28-23-11	ALL
	B02		W5510	0019	20		28-23-11	ALL
	B03		W5510	0020	20		28-23-11	ALL
	B04	UNUSED						ALL
	B05		W5510	0044	20		28-23-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5510	6019	22		21-27-21	ALL
D46132J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0093	20		29-11-11	ALL
	A02		W0066	0094	20		29-11-11	ALL
	A03		W0066	0088	20		28-21-11	ALL
	A04		W0066	0087	20		28-21-11	ALL
	A05		W0066	1003	20		74-11-11	ALL
	A06		W0066	0419	20		78-35-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46132J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B05		W0066	6016	20		74-11-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	1003Z			74-11-11	ALL
D46132P		**AJ0046B/ /**		**PLUG-**				**ALL**
	A01		W6506	0507	20		29-11-11	ALL
	A02		W6506	0508	20		29-11-11	ALL
	A03		W6506	6013	20		28-21-11	ALL
	A04		W6506	6012	20		28-21-11	ALL
	A05		W6506	1303	20		74-11-11	ALL
	A06		W6506	6078	20		78-35-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6506	6016	20		74-11-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6506	1303Z			74-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46134J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0062	20		31-52-55	ALL
	A02		W0066	0063	20		31-52-55	ALL
	A03		W0066	0055	20		31-52-61	ALL
	A04		W0066	0056	20		31-52-61	ALL
	A05		W0066	0058	20		31-52-65	ALL
	A06		W0066	0060	20		31-52-71	ALL
	A07		W0066	0064	20		31-52-75	ALL
	A08		W0066	0065	20		31-52-75	ALL
	A09		W0066	0119	22		32-44-11	ALL
	A10		W0066	0116	22		32-44-11	ALL
	B01		W0066	0120	22		32-44-11	ALL
	B02		W0066	0121	22		32-44-11	ALL
	B03		W0066	0134	20		32-64-21	ALL
	B04		W0066	0059	20		31-52-65	ALL
	B05		W0066	0370	20		73-22-11	ALL
	B06		W0066	0359	22		31-53-11	ALL
	B07		W0066	0371	20		73-22-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D46134P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W5514	5539	20		31-52-55	ALL
	A02		W5514	5540	20		31-52-55	ALL
	A03		W5514	5541	20		31-52-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46134P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	A04		W5514	5542	20		31-52-61	ALL
	A05		W5514	5543	20		31-52-65	ALL
	A06		W5514	5559	20		31-52-71	ALL
	A07		W5514	5548	20		31-52-75	ALL
	A08		W5514	5549	20		31-52-75	ALL
	A09		W5514	0521	24		32-44-11	ALL
	A10		W5514	0514	24		32-44-11	ALL
	B01		W5514	0516	24		32-44-11	ALL
	B02		W5514	0517	24		32-44-11	ALL
	B03		W5514	0556	22		32-64-21	ALL
	B04		W5514	5544	20		31-52-65	ALL
	B05		W5514	0560	20		73-22-11	ALL
	B06		W5514	5602	22		31-53-11	ALL
	B07		W5514	0561	20		73-22-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D46136J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	2003R	22		32-31-12	ALL
	A02		W0066	2003B	22		32-31-12	ALL
	A03		W0066	2004R	22		32-64-12	ALL
	A04		W0066	2004B	22		32-64-12	ALL
	A05		W0066	2005R	22		32-64-12	ALL
	A06		W0066	2005B	22		32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46136J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A07		W0066	1003	20		74-11-11	ALL
	A08		W0066	0374R	20		26-12-11	ALL
	A09	UNUSED						ALL
	A10		W0066	0375R	20		26-12-11	ALL
	B01		W0066	0384R	20		26-12-11	ALL
	B02		W0066	0386R	20		26-12-11	ALL
	B03		W0066	0387R	20		26-12-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	1003Z			74-11-11	ALL
D46136P		**J046-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6528	2241R	22		32-31-12	ALL
	A02		W6528	2241B	22		32-31-12	ALL
	A03		W6528	2224R	22		32-64-12	ALL
	A04		W6528	2224B	22		32-64-12	ALL
	A05		W6528	2223R	22		32-64-12	ALL
	A06		W6528	2223B	22		32-64-12	ALL
	A07		W6528	1301	20		74-11-11	ALL
	A08		W6528	0590R	20		26-12-11	ALL
	A09	UNUSED						ALL
	A10		W6528	1001R	20		26-12-11	ALL
	B01		W6528	6002R	20		26-12-11	ALL
	B02		W6528	6005R	20		26-12-11	ALL
	B03		W6528	6006R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46136P		**J046-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6528	1301Z			74-11-11	ALL
D46138J		**J046-00/ /**		**RCPT-**				**ALL**
	A01		W0066	0009	22		21-27-31	ALL
	A02		W0066	0011	22		21-27-31	ALL
	A03	UNUSED						ALL
	A04		W0066	0082	22		SPARE	ALL
	A05	UNUSED						ALL
	A06		W0066	0095	22		29-11-12	ALL
	A07		W0066	0096	22		29-11-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46138P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W6242	5509	24		21-27-31	ALL
	A02		W6242	5508	22		21-27-31	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W6242	0509	22		29-11-12	ALL
	A07		W6242	0523	22		29-11-12	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46140J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0139	20		33-36-12	ALL
	A02		W0066	0185	24		76-21-21	ALL
	A03		W0066	0186	24		76-21-21	ALL
	A04		W0066	2024R	24		32-64-31	ALL
	A05		W0066	2024B	24		32-64-31	ALL
	A06		W0066	2025R	24		31-65-25	ALL
	A07		W0066	2025B	24		31-65-25	ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46140J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A09		W0066	0099	22		29-23-11	ALL
	A10		W0066	0102	22		29-25-11	ALL
	B01		W0066	2023R	24		31-65-15	ALL
	B02		W0066	2023B	24		31-65-15	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F	UNUSED						ALL
	G		W0066	0077	18		24-11-21	ALL
	H	UNUSED						ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
	PERG	1F	W0066	2023Z			31-65-15	ALL
	PERG	1F	W0066	2024Z			32-64-31	ALL
	PERG	1F	W0066	2025Z			31-65-25	ALL
D46140P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W5158	0689	20		33-36-12	ALL
	A02		W5158	6022	24		76-21-21	ALL
	A03		W5158	6023	24		76-21-21	ALL
	A04		W5158	2607R	24		32-64-31	ALL
	A05		W5158	2607B	24		32-64-31	ALL
	A06		W5158	2608R	24		31-65-25	ALL
	A07		W5158	2608B	24		31-65-25	ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46140P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
A09		W5158	0518	22		29-23-11	ALL
A10		W5158	0548	22		29-25-11	ALL
B01		W5158	2605R	24		31-65-15	ALL
B02		W5158	2605B	24		31-65-15	ALL
B03		W5158	0706	20		SPARE	ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F	UNUSED						ALL
G		W5158	0531	18		24-11-21	ALL
H	UNUSED						ALL
J	UNUSED						ALL
K	UNUSED						ALL
PERG	1F	W5158	2605Z			31-65-15	ALL
PERG	1F	W5158	2607Z			32-64-31	ALL
PERG	1F	W5158	2608Z			31-65-25	ALL
D46142J	**J046-00/ /**		**RCPT-**				**ALL**
A01		W0066	0006	22		21-27-21	ALL
A02		W0066	0079	22		24-22-21	ALL
A03		W0066	0080	22		24-28-11	ALL
A04		W0066	0081	22		24-28-11	ALL
A05		W0066	0097	22		29-22-11	ALL
A06		W0066	0137	20		33-36-11	ALL
A07		W0066	0141	20		33-36-12	ALL
A08		W0066	0433	22		34-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46142J		**J046-00/ /**		**RCPT- (continued)**				**ALL**
	A09		W0066	0356	22		21-33-11	ALL
	A10		W0066	0357	22		21-33-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46142P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W6414	5507	20		21-27-21	ALL
	A02		W6414	0523	22		24-22-21	ALL
	A03		W6414	0509	22		24-28-11	ALL
	A04		W6414	0510	22		24-28-11	ALL
	A05		W6414	0514	22		29-22-11	ALL
	A06		W6414	0006	20		33-36-11	ALL
	A07		W6414	0017	20		33-36-12	ALL
	A08		W6414	0012	22		34-21-22	ALL
	A09		W6414	0009	22		21-33-11	ALL
	A10		W6414	0010	22		21-33-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46142P	**J046-00/ /**		**PLUG- (continued)**				**ALL**
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D46144J	**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0066	1002	20		74-11-11	ALL
A06		W0066	1001	20		73-22-11	ALL
A07	UNUSED						ALL
A08		W0066	1023	24		73-21-12	ALL
A09	UNUSED						ALL
A10		W0066	2510R	20		36-11-22	ALL
B01		W0066	0413	20		78-34-21	ALL
B02		W0066	0414	20		78-34-21	ALL
B03		W0066	0415	20		78-34-21	ALL
B04		W0066	0416	20		78-34-21	ALL
B05		W0066	0419	20		78-35-21	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10		W0066	2510B	20		36-11-22	ALL
PERG	1F	W0066	1001Z			73-22-11	ALL
PERG	1F	W0066	1002Z			74-11-11	ALL
PERG	1F	W0066	1023Z			73-21-12	ALL
PERG	1F	W0066	2510Z			36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46144P		**AJ0046A/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6170	1303	20		74-11-11	ALL
	A06		W6170	1302	20		73-22-11	ALL
	A07	UNUSED						ALL
	A08		W6170	1001	24		73-21-12	ALL
	A09	UNUSED						ALL
	A10		W6170	2510R	20		36-11-22	ALL
	B01		W6170	1005	20		78-34-21	ALL
	B02		W6170	1006	20		78-34-21	ALL
	B03		W6170	1007	20		78-34-21	ALL
	B04		W6170	1008	20		78-34-21	ALL
	B05		W6170	0512	20		78-35-21	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6170	2510B	20		36-11-22	ALL
	PERG	1F	W6170	1001Z			73-21-12	ALL
	PERG	1F	W6170	1005Z			78-34-21	ALL
	PERG	1F	W6170	1006Z			78-34-21	ALL
	PERG	1F	W6170	1007Z			78-34-21	ALL
	PERG	1F	W6170	1008Z			78-34-21	ALL
	PERG	1F	W6170	1302Z			73-22-11	ALL
	PERG	1F	W6170	1303Z			74-11-11	ALL
	PERG	1F	W6170	2510Z			36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46146J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	2012R	24		73-21-11	ALL
	A02		W0066	2012B	24		73-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	2012Z			73-21-11	ALL
D46146P		**AJ0046A/ /**		**PLUG-**				**ALL**
	A01		W6172	2610R	24		73-21-11	ALL
	A02		W6172	2610B	24		73-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46146P		**AJ0046A/ /**		**PLUG- (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W6172	2610Z			73-21-11	ALL
D46148J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0380	24		36-11-12	ALL
	A02		W0066	1023	24		73-21-12	ALL
	A03		W0066	2502R	20		36-11-12	ALL
	A04		W0066	2502B	20		36-11-12	ALL
	A05		W0066	0381	24		36-11-12	ALL
	A06		W0066	0107	22		30-31-12	ALL
	A07		W0066	0108	22		30-31-12	ALL
	A08		W0066	0109	22		30-31-12	ALL
	A09		W0066	0201	22		30-31-12	ALL
	A10		W0066	0162	24		SPARE	ALL
	B01		W0066	0428	22		27-61-42	ALL
	B02		W0066	0429	22		27-61-42	ALL
	B03		W0066	0430	22		27-61-42	ALL
	B04		W0066	0431	22		27-61-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46148J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B05		W0066	0024	24		21-51-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0066	1023Z			73-21-12	ALL
	PERG	1F	W0066	2502Z			36-11-12	ALL
D46148P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W2216	5537	24		36-11-12	ALL
	A02		W2216	1302	24		73-21-12	ALL
	A03		W2216	2502R	20		36-11-12	ALL
	A04		W2216	2502B	20		36-11-12	ALL
	A05		W2216	5569	24		36-11-12	ALL
	A06		W2216	5545	22		30-31-12	ALL
	A07		W2216	5546	22		30-31-12	ALL
	A08		W2216	5547	22		30-31-12	ALL
	A09		W2216	5548	22		30-31-12	ALL
	A10	UNUSED						ALL
	B01		W2216	2003B	22		27-61-42	ALL
	B02		W2216	2003R	22		27-61-42	ALL
	B03		W2216	2004B	22		27-61-42	ALL
	B04		W2216	2004R	22		27-61-42	ALL
	B05		W2216	0019	24		21-51-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46148P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	PERG	1F	W2216	1302Z			73-21-12	ALL
	PERG	1F	W2216	2502Z			36-11-12	ALL
D46150J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02		W0066	0276	20		27-62-11	ALL
	A03		W0066	0277	20		27-62-11	ALL
	A04		W0066	0179	20		73-22-11	ALL
	A05		W0066	0168	24		73-22-31	ALL
	A06		W0066	0200	20		74-11-11	ALL
	A07		W0066	0275	20		27-62-11	ALL
	A08	UNUSED						ALL
	A09		W0066	0184	24		76-21-21	ALL
	A10	UNUSED						ALL
	B01		W0066	0278	20		27-62-11	ALL
	B02	UNUSED						ALL
	B03		W0066	0135	20		32-64-21	ALL
	B04		W0066	0273	20		27-62-11	ALL
	B05		W0066	0265	20		44-21-10	ALL
	B06		W0066	0274	20		27-62-11	ALL
	B07		W0066	0266	20		44-21-10	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46150P		**AJ0046A/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02		W6208	0591	20		27-62-11	ALL
	A03		W6208	0558	20		27-62-11	ALL
	A04		W6208	0641	20		73-22-11	ALL
	A05		W6208	0642	24		73-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46150P		**AJ0046A/ /**		**PLUG- (continued)**				**ALL**
	A06		W6208	0643	20		74-11-11	ALL
	A07		W6208	0590	20		27-62-11	ALL
	A08	UNUSED						ALL
	A09		W6208	0644	24		76-21-21	ALL
	A10	UNUSED						ALL
	B01		W6208	0592	20		27-62-11	ALL
	B02	UNUSED						ALL
	B03		W6208	0549	22		32-64-21	ALL
	B04		W6208	0588	20		27-62-11	ALL
	B05		W6208	0028	20		44-21-10	ALL
	B06		W6208	0589	20		27-62-11	ALL
	B07		W6208	0029	20		44-21-10	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D46158J		**J046-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0066	0395	24		36-11-22	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0066	0348	22		27-61-45	ALL
	A05		W0066	2023R	24		31-65-15	ALL
	A06		W0066	2023B	24		31-65-15	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0066	2025R	24		31-65-25	ALL
	A10	UNUSED						ALL
	B01		W0066	2510R	20		36-11-22	ALL
	B02		W0066	2510B	20		36-11-22	ALL
	B03		W0066	2024R	24		32-64-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46158J		**J046-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B04		W0066	2024B	24		32-64-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0066	0394	24		36-11-22	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0066	2025B	24		31-65-25	ALL
	PERG	1F	W0066	2023Z			31-65-15	ALL
	PERG	1F	W0066	2024Z			32-64-31	ALL
	PERG	1F	W0066	2025Z			31-65-25	ALL
	PERG	1F	W0066	2510Z			36-11-22	ALL
D46158P		**J046-00/ /**		**PLUG-**				**ALL**
	A01		W2218	5648	24		36-11-22	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2218	5616	22		27-61-45	ALL
	A05		W2218	2011R	24		31-65-15	ALL
	A06		W2218	2011B	24		31-65-15	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W2218	2007R	24		31-65-25	ALL
	A10	UNUSED						ALL
	B01		W2218	2502R	20		36-11-22	ALL
	B02		W2218	2502B	20		36-11-22	ALL
	B03		W2218	2006R	24		32-64-31	ALL
	B04		W2218	2006B	24		32-64-31	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W2218	5640	24		36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46158P		**J046-00/ /**		**PLUG- (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W2218	2007B	24		31-65-25	ALL
	PERG	1F	W2218	2006Z			32-64-31	ALL
	PERG	1F	W2218	2007Z			31-65-25	ALL
	PERG	1F	W2218	2011Z			31-65-15	ALL
	PERG	1F	W2218	2502Z			36-11-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46200	**666/202/L056**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5580	6009	20		28-41-11	ALL
7		W5580	6008	20		28-41-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W5580	6009	20		28-41-11	ALL
17		W5580	1301	20		28-41-11	ALL
18		W5580	FRAD			28-41-11	ALL
19	UNUSED						ALL
20		W5580	1303	20		28-41-11	ALL
21		W5580	1302	20		28-41-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46200	**666/202/L056**		**PLUG-CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37		W5580	FRAC			28-41-11	ALL
38		W5580	6007	20		28-41-11	ALL
39		W5580	6008	20		28-41-11	ALL
S/R		W5580	1301ZO			28-41-11	ALL
S/R		W5580	1302Z			28-41-11	ALL
S/R		W5580	1303Z			28-41-11	ALL
S/R		W5580	6007	20		28-41-11	ALL
		W5580	1301ZI			28-41-11	ALL
		W5580	FRAC			28-41-11	ALL
		W5580	FRAD			28-41-11	ALL
D46201J	**E006-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
A01		W0625	2002R	24		23-51-51	ALL
A02		W0625	2002Z			23-51-51	ALL
A03		W0625	2003R	24		23-51-51	ALL
A04		W0625	2004R	24		23-51-51	ALL
A05		W0625	2004Z			23-51-51	ALL
A06		W0625	2005R	24		23-71-01	ALL
A07		W0625	2010R	24		23-71-01	ALL
A08		W0625	2006R	24		23-71-01	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11		W0625	2001R	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46201J		**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A12		W0625	2008R	24		23-27-35	ALL
	A13		W0625	0002	20		23-71-01	ALL
	A14		W0625	0003	22		23-71-01	ALL
	A15		W0625	0014	24		23-71-01	ALL
	A16		W0625	0017	20		23-71-01	ALL
	A17		W0625	0034	24		23-71-01	ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0625	2002B	24		23-51-51	ALL
	B02		W0625	2003Z			23-51-51	ALL
	B03		W0625	2003B	24		23-51-51	ALL
	B04		W0625	2004B	24		23-51-51	ALL
	B05		W0625	2005Z			23-71-01	ALL
	B06		W0625	2005B	24		23-71-01	ALL
	B07		W0625	2010B	24		23-71-01	ALL
	B08		W0625	2006B	24		23-71-01	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0625	2001B	24		31-65-15	ALL
	B12		W0625	2008B	24		23-27-35	ALL
	B13		W0625	0012	24		23-71-01	ALL
	B14		W0625	0004	22		23-71-01	ALL
	B15		W0625	0013	24		23-71-01	ALL
	B16		W0625	0030	22		23-71-01	ALL
	B17		W0625	0036	22		23-71-01	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46201J	**E006-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
PERG	1F	W0625	2001Z			31-65-15	ALL
PERG	1F	W0625	2008Z			23-27-35	ALL
PERG	1F	W0625	2010Z			23-71-01	ALL
D46201P	**E006-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5433	2002R	24		23-51-51	ALL
A02		W5433	2002Z			23-51-51	ALL
A03		W5433	2003R	24		23-51-51	ALL
A04		W5433	2004R	24		23-51-51	ALL
A05		W5433	2004Z			23-51-51	ALL
A06		W5433	2005R	24		23-71-01	ALL
A07		W5433	2010R	24		23-71-01	ALL
A08		W5433	2006R	24		23-71-01	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11		W5433	2001R	24		31-65-15	ALL
A12		W5433	2008R	24		23-27-35	ALL
A13		W5433	0002	20		23-71-01	ALL
A14		W5433	0003	22		23-71-01	ALL
A15		W5433	0014	24		23-71-01	ALL
A16		W5433	0006	20		23-71-01	ALL
A17		W5433	0034	24		23-71-01	ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5433	2002B	24		23-51-51	ALL
B02		W5433	2003Z			23-51-51	ALL
B03		W5433	2003B	24		23-51-51	ALL
B04		W5433	2004B	24		23-51-51	ALL
B05		W5433	2005Z			23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46201P		**E006-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B06		W5433	2005B	24		23-71-01	ALL
	B07		W5433	2010B	24		23-71-01	ALL
	B08		W5433	2006B	24		23-71-01	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W5433	2001B	24		31-65-15	ALL
	B12		W5433	2008B	24		23-27-35	ALL
	B13		W5433	0012	24		23-71-01	ALL
	B14		W5433	0004	22		23-71-01	ALL
	B15		W5433	0013	24		23-71-01	ALL
	B16		W5433	0030	22		23-71-01	ALL
	B17		W5433	0036	22		23-71-01	ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5433	2001Z			31-65-15	ALL
	PERG	1F	W5433	2008Z			23-27-35	ALL
	PERG	1F	W5433	2010Z			23-71-01	ALL
D46202		**666/202/L056**		**PLUG-CONDUCTIVE CONNECTOR**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W7580	6002	20		28-41-11	ALL
	7		W7580	6002	20		28-41-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46202	**666/202/L056**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W7580	6003	20		28-41-11	ALL
17		W7580	1301	20		28-41-11	ALL
18	18	W7580	FRAB			28-41-11	ALL
19	UNUSED						ALL
20		W7580	1303	20		28-41-11	ALL
21		W7580	1302	20		28-41-11	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	18	W7580	FRAA			28-41-11	ALL
38		W7580	6001	20		28-41-11	ALL
39		W7580	6001	20		28-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46202		**666/202/L056**		**PLUG-CONDUCTIVE CONNECTOR (continued)**				**ALL**
	S/R		W7580	1301ZO			28-41-11	ALL
	S/R		W7580	1302Z			28-41-11	ALL
	S/R		W7580	1303Z			28-41-11	ALL
	S/R		W7580	6003	20		28-41-11	ALL
			W7580	1301ZI			28-41-11	ALL
			W7580	FRAA			28-41-11	ALL
			W7580	FRAB			28-41-11	ALL
D46203J		**908/206/R023**		**RCPT-CONDUCTIVE**				**ALL**
	1		W5433	0002	20		23-71-01	ALL
	2		W5433	2001R	24		31-65-15	ALL
	3		W5433	2001B	24		31-65-15	ALL
	4		W5433	2008R	24		23-27-35	ALL
	5		W5433	2008B	24		23-27-35	ALL
	6		W5433	0004	22		23-71-01	ALL
	7		W5433	0003	22		23-71-01	ALL
	8		W5433	0006	20		23-71-01	ALL
	9		W5433	0014	24		23-71-01	ALL
	10		W5433	0013	24		23-71-01	ALL
	11		W5433	0012	24		23-71-01	ALL
	12		W5433	2006R	24		23-71-01	ALL
	13		W5433	2006B	24		23-71-01	ALL
	14		W5433	2005R	24		23-71-01	ALL
	15		W5433	2005B	24		23-71-01	ALL
	16		W5433	2005Z			23-71-01	ALL
	17		W5433	2002R	24		23-51-51	ALL
	18		W5433	2002B	24		23-51-51	ALL
	19		W5433	2002Z			23-51-51	ALL
	20		W5433	2003R	24		23-51-51	ALL
	21		W5433	2003B	24		23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46203J	**908/206/R023**		**RCPT-CONDUCTIVE (continued)**				**ALL**
22		W5433	2003Z			23-51-51	ALL
23		W5433	2004R	24		23-51-51	ALL
24		W5433	2004B	24		23-51-51	ALL
25		W5433	2004Z			23-51-51	ALL
26		W5433	2009R	24		23-71-01	ALL
27		W5433	2009B	24		23-71-01	ALL
28	UNUSED						ALL
29		W5433	0015	22		21-27-51	ALL
30		W5433	0016	22		21-27-51	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
S/R		W5433	2001Z			31-65-15	ALL
S/R		W5433	2008Z			23-27-35	ALL
S/R		W5433	2009Z			23-71-01	ALL
D46203P	**908/206/R023**		**PLUG-CONDUCTIVE**				**ALL**
1		W5431	0002	20		23-71-01	ALL
2		W5431	2001R	24		31-65-15	ALL
3		W5431	2001B	24		31-65-15	ALL
4		W5431	2008R	24		23-27-35	ALL
5		W5431	2008B	24		23-27-35	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46203P		**908/206/R023**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	6		W5431	0004	22		23-71-01	ALL
	7		W5431	0003	22		23-71-01	ALL
	8		W5431	0006	20		23-71-01	ALL
	9		W5431	0014	24		23-71-01	ALL
	10		W5431	0013	24		23-71-01	ALL
	11		W5431	0012	24		23-71-01	ALL
	12		W5431	2006R	24		23-71-01	ALL
	13		W5431	2006B	24		23-71-01	ALL
	14		W5431	2005R	24		23-71-01	ALL
	15		W5431	2005B	24		23-71-01	ALL
	16		W5431	2005Z			23-71-01	ALL
	17		W5431	2002R	24		23-51-51	ALL
	18		W5431	2002B	24		23-51-51	ALL
	19		W5431	2002Z			23-51-51	ALL
	20		W5431	2003R	24		23-51-51	ALL
	21		W5431	2003B	24		23-51-51	ALL
	22		W5431	2003Z			23-51-51	ALL
	23		W5431	2004R	24		23-51-51	ALL
	24		W5431	2004B	24		23-51-51	ALL
	25		W5431	2004Z			23-51-51	ALL
	26		W5431	2009R	24		23-71-01	ALL
	27		W5431	2009B	24		23-71-01	ALL
	28	UNUSED						ALL
	29		W5431	0029	22		21-27-51	ALL
	30		W5431	0030	22		21-27-51	ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46203P	**908/206/R023**		**PLUG-CONDUCTIVE (continued)**				**ALL**
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
S/R		W5431	2001Z			31-65-15	ALL
S/R		W5431	2008Z			23-27-35	ALL
S/R		W5431	2009Z			23-71-01	ALL
D46230A	**E003-02/ /**		**PLUG PLATE ASSEMBLY - VOR/MB -1**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46230A		**E003-02/ /**		**PLUG PLATE ASSEMBLY - VOR/MB -1 (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11	UNUSED						ALL
	C12	UNUSED						ALL
	C13	UNUSED						ALL
	C14	UNUSED						ALL
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46230A	**E003-02/ /**		**PLUG PLATE ASSEMBLY - VOR/MB -1 (continued)**				**ALL**
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
D06	UNUSED						ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
D11	UNUSED						ALL
D12	UNUSED						ALL
D13	UNUSED						ALL
D14	UNUSED						ALL
D15	UNUSED						ALL
D46230B	***/*/***		**PLUG PLATE ASSEMBLY - VOR/MB -1**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W0321	2365R	24		34-51-11	ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14	UNUSED						ALL
A15		W0321	0795	22		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46230B		***/*/***		**PLUG PLATE ASSEMBLY - VOR/MB -1 (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0321	2365B	24		34-51-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0321	2366R	24		34-51-11	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0321	2363R	24		34-51-11	ALL
	B12	UNUSED						ALL
	B13		W0321	2364R	24		34-51-11	ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0321	2346R	24		34-32-11	ALL
	C05	UNUSED						ALL
	C06	UNUSED						ALL
	C07		W0321	2366B	24		34-51-11	ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	C11		W0321	2363B	24		34-51-11	ALL
	C12	UNUSED						ALL
	C13		W0321	2364B	24		34-51-11	ALL
	C14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46230B		*/*/*		**PLUG PLATE ASSEMBLY - VOR/MB -1 (continued)**				**ALL**
	C15	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0321	2346B	24		34-32-11	ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	DED		W0321	2346ZI			34-32-11	ALL
	DED		W0321	2366ZI			34-51-11	ALL
	PERG	1A	W0321	2346ZO			34-32-11	ALL
	PERG	1A	W0321	2363Z			34-51-11	ALL
	PERG	1A	W0321	2364Z			34-51-11	ALL
	PERG	1A	W0321	2365Z			34-51-11	ALL
	PERG	1A	W0321	2366ZO			34-51-11	ALL
D46230C		*/*/*		**PLUG PLATE ASSEMBLY - VOR/MB -1**				**ALL**
	1	DN	W0321	002CX			34-51-11	ALL
	2		W0321	0792	22		34-51-11	ALL
	3		W0321	0793	20		34-51-11	ALL
	4		W0321	0794	20		34-51-11	ALL
	5	DN	W0321	001CX			34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46230C		***/*/***		**PLUG PLATE ASSEMBLY - VOR/MB -1 (continued)**				**ALL**
	=C1		W0321	002CO			34-51-11	ALL
	=C5		W0321	001CO			34-32-11	ALL
D46240J		**604/148/L002**		**RCPT - (TNC)**				**ALL**
	=A1		W7189	001CX			34-32-11	ALL
	=C1		W7189	001CO			34-32-11	ALL
D46240P		**604/148/2**		**PLUG - TNC**				**ALL**
	=A1		W7193	001CX			34-32-11	ALL
	=C1		W7193	001CO			34-32-11	ALL
D46246J		**E003-02/ /**		**RCPT - (TNC)**				**ALL**
	=A1		W0321	001CX			34-32-11	ALL
	=C1		W0321	001CO			34-32-11	ALL
D46246P		**E003-02/ /**		**PLUG - (TNC) STRAIGHT**				**ALL**
	=A1		W7189	001CX			34-32-11	ALL
	=C1		W7189	001CO			34-32-11	ALL
D46248J		**E004-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0410	0119	22		34-51-21	ALL
	A02		W0410	2015R	24		34-51-21	ALL
	A03		W0410	2016R	24		34-51-21	ALL
	A04		W0410	2019R	24		34-51-21	ALL
	A05		W0410	2050R	24		34-51-21	ALL
	A06		W0410	2051R	24		34-51-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0410	2051ZI			34-51-21	ALL
	B02		W0410	2015B	24		34-51-21	ALL
	B03		W0410	2016B	24		34-51-21	ALL
	B04		W0410	2019B	24		34-51-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46248J		**E004-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B05		W0410	2050B	24		34-51-21	ALL
	B06		W0410	2051B	24		34-51-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0410	2015Z			34-51-21	ALL
	PERG	1F	W0410	2016Z			34-51-21	ALL
	PERG	1F	W0410	2019Z			34-51-21	ALL
	PERG	1F	W0410	2050Z			34-51-21	ALL
	PERG	1F	W0410	2051ZO			34-51-21	ALL
D46248P		**E004-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5191	0004	22		34-51-21	ALL
	A02		W5191	2001R	24		34-51-21	ALL
	A03		W5191	2002R	24		34-51-21	ALL
	A04		W5191	2328R	24		34-51-21	ALL
	A05		W5191	2003R	24		34-51-21	ALL
	A06		W5191	2004R	24		34-51-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5191	2004ZI			34-51-21	ALL
	B02		W5191	2001B	24		34-51-21	ALL
	B03		W5191	2002B	24		34-51-21	ALL
	B04		W5191	2328B	24		34-51-21	ALL
	B05		W5191	2003B	24		34-51-21	ALL
	B06		W5191	2004B	24		34-51-21	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46248P		**E004-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5191	2001Z			34-51-21	ALL
	PERG	1F	W5191	2002Z			34-51-21	ALL
	PERG	1F	W5191	2003Z			34-51-21	ALL
	PERG	1F	W5191	2004ZO			34-51-21	ALL
	PERG	1F	W5191	2328Z			34-51-21	ALL
D46250A		**E004-01/ /**		**PLUG - VOR - 2**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46250A	**E004-01/ /**		**PLUG - VOR - 2 (continued)**				**ALL**
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11	UNUSED						ALL
C12	UNUSED						ALL
C13	UNUSED						ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46250A		**E004-01/ /**		**PLUG - VOR - 2 (continued)**				**ALL**
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
D46250B		**E004-01/ /**		**PLUG - VOR - 2**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0410	2019R	24		34-51-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15		W0410	0120	22		34-51-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46250B	**E004-01/ /**		**PLUG - VOR - 2 (continued)**				**ALL**
B03	UNUSED						ALL
B04		W0410	2019B	24		34-51-21	ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07		W0410	2018R	24		34-51-21	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
B11		W0410	2017R	24		34-51-21	ALL
B12	UNUSED						ALL
B13		W0410	2020R	24		34-51-21	ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
C06	UNUSED						ALL
C07		W0410	2018B	24		34-51-21	ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
C11		W0410	2017B	24		34-51-21	ALL
C12	UNUSED						ALL
C13		W0410	2020B	24		34-51-21	ALL
C14	UNUSED						ALL
C15	UNUSED						ALL
D01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46250B		**E004-01/ /**		**PLUG - VOR - 2 (continued)**				**ALL**
	D02		W0410	0124	22		34-51-21	ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	D11	UNUSED						ALL
	D12	UNUSED						ALL
	D13	UNUSED						ALL
	D14	UNUSED						ALL
	D15	UNUSED						ALL
	DED		W0410	2018ZI			34-51-21	ALL
	PERG	1A	W0410	2017Z			34-51-21	ALL
	PERG	1A	W0410	2018ZO			34-51-21	ALL
	PERG	1A	W0410	2019Z			34-51-21	ALL
	PERG	1A	W0410	2020Z			34-51-21	ALL
D46250C		**E004-01/ /**		**PLUG - VOR - 2**				**ALL**
	1	DN	W8195	001CX			34-51-21	ALL
	2		W0410	0121	22		34-51-21	ALL
	3		W0410	0122	20		34-51-21	ALL
	4		W0410	0123	20		34-51-21	ALL
	5	UNUSED						ALL
	=C1		W8195	001CO			34-51-21	ALL
	=C5	UNUSED						ALL
D46252J		**E003-02/ /**		**RCPT - (TNC)**				**ALL**
	=A1		W0321	002CX			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46252J	**E003-02/ /**		**RCPT - (TNC) (continued)**				**ALL**
=C1		W0321	002CO			34-51-11	ALL
D46252P	**E003-02/ /**		**PLUG - COAX**				**ALL**
=A1		W7191	001CX			34-51-11	ALL
=C1		W7191	001CO			34-51-11	ALL
D46258J	**E002-01/ /**		**RCPT-**				**ALL**
A01		W0212	2038R	24		34-33-11	ALL
A02		W0212	2401R	24		34-41-11	ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0212	2038B	24		34-33-11	ALL
B02		W0212	2401B	24		34-41-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0212	2038Z			34-33-11	ALL
PERG	1F	W0212	2401Z			34-41-11	ALL
D46258P	**E002-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W2112	2013R	24		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46258P		**E002-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A02		W2112	2014R	24		34-41-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W2112	2013B	24		34-33-11	ALL
	B02		W2112	2014B	24		34-41-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2112	2013Z			34-33-11	ALL
	PERG	1F	W2112	2014Z			34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46438J	**616/298/L015**		**RCPT-**				**ALL**
1		W4142	0442	20		52-71-14	ALL
2		W4142	0027	20		52-71-13	ALL
3	UNUSED						ALL
D46438P	**616/298/L015**		**PLUG-**				**ALL**
1		W3142	0405	20		52-71-14	ALL
2		W3142	0438	20		52-71-13	ALL
3	UNUSED						ALL
D46440J	**616/303/R010**		**RCPT-**				**ALL**
1		W4142	0460	20		52-71-14	ALL
2		W4142	0098	20		52-71-13	ALL
3	UNUSED						ALL
D46440P	**616/303/R010**		**PLUG-**				**ALL**
1		W3142	0098	20		52-71-14	ALL
2		W3142	0460	20		52-71-13	ALL
3	UNUSED						ALL
D46461J	**E001-01/ /**		**RECPT-CONDUCTIVE**				**ALL**
A01		W0111	2254R	24		27-32-12	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0111	0736	24		27-81-31	ALL
A06		W0111	0809	24		21-51-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W0111	0144	22		34-51-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46461J		**E001-01/ /**		**RECPT-CONDUCTIVE (continued)**				**ALL**
	A14		W0111	2175R	24		34-45-21	ALL
	A15		W0111	2175B	24		34-45-21	ALL
	A16		W0111	2175ZI			34-45-21	ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0111	2254B	24		27-32-12	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0111	0695	24		27-81-31	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11		W0111	0121	20		34-61-22	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W0111	0352	22		34-21-16	ALL
	B18		W0111	0357	22		34-21-16	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0111	2175ZO			34-45-21	ALL
	PERG	1F	W0111	2254Z			27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46461P	**E001-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
A01		W5461	2113R	24		27-32-12	ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W5461	0082	24		27-81-31	ALL
A06		W5461	0100	24		21-51-11	ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13		W5461	0012	22		34-51-41	ALL
A14		W5461	2024R	24		34-45-21	ALL
A15		W5461	2024B	24		34-45-21	ALL
A16		W5461	2024ZI			34-45-21	ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19	UNUSED						ALL
A20	UNUSED						ALL
B01		W5461	2113B	24		27-32-12	ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05		W5461	0081	24		27-81-31	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46461P		**E001-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	B11		W5461	0034	20		34-61-22	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17		W5461	0037	22		34-21-16	ALL
	B18		W5461	0038	22		34-21-16	ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W5461	2024ZO			34-45-21	ALL
	PERG	1F	W5461	2113Z			27-32-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46602J	**AB0727R/192/R044**		**RCPT-**				**ALL**
1		W5124	0566	18		29-25-11	ALL
2		W5124	0567	18		29-25-11	ALL
3		W5124	0568	18		29-25-11	ALL
4	UNUSED						ALL
5		W5124	0529	22		29-25-11	ALL
6		W5124	0530	18		29-25-11	ALL
7		W5124	0531	18		29-25-11	ALL
8		W5124	0535	18		29-25-11	ALL
9		W5124	0536	18		29-25-11	ALL
10		W5124	0516	22		27-31-37	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
D46602P	**AB0727R/192/R044**		**PLUG-**				**ALL**
1		W6124	0566	18		29-25-11	ALL
2		W6124	0567	18		29-25-11	ALL
3		W6124	0568	18		29-25-11	ALL
4	UNUSED						ALL
5		W6124	0529	22		29-25-11	ALL
6		W6124	0530	18		29-25-11	ALL
7		W6124	0532	22		29-25-11	ALL
8		W6124	0535	18		29-25-11	ALL
9		W6124	0536	18		29-25-11	ALL
10		W6124	0110	22		27-31-37	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46604J		**J011-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0096	0014	20		44-35-11	ALL
	4		W0096	0015	20		44-35-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D46604P		**AJ0011/ /**		**PLUG-**				**ALL**
	1		W4477	0017	20		44-21-10	ALL
	2	UNUSED						ALL
	3		W4477	0023	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46604P	**AJ0011/ /**		**PLUG- (continued)**				**ALL**
4		W4477	0010	20		44-35-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D46606J	**AB0500DL/ /**		**RCPT**				**ALL**
1		W5094	6001	22		26-16-22	ALL
2		W5094	6002	22		26-16-22	ALL
3		W5094	6003	22		26-16-22	ALL
4		W5094	6004	22		26-16-22	ALL
5		W5094	6005	22		26-16-22	ALL
6		W5094	6006	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46606J		**AB0500DL/ /**		**RCPT (continued)**				**ALL**
	7		W5094	6007	22		26-16-22	ALL
	8		W5094	6008	22		26-16-22	ALL
	9		W5094	6009	22		26-16-22	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W5094	6010	22		26-23-11	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27		W5094	6011	22		26-23-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30		W5094	6012	22		26-23-11	ALL
	31	UNUSED						ALL
D46606P		**AB0500DL/ /**		**PLUG**				**ALL**
	1		W5098	6001	22		26-16-22	ALL
	2		W5098	6002	22		26-16-22	ALL
	3		W5098	6003	22		26-16-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46606P	**AB0500DL/ /**		**PLUG (continued)**				**ALL**
4		W5098	6004	22		26-16-22	ALL
5		W5098	6005	22		26-16-22	ALL
6		W5098	6006	22		26-16-22	ALL
7		W5098	6007	22		26-16-22	ALL
8		W5098	6008	22		26-16-22	ALL
9		W5098	6009	22		26-16-22	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5098	6012	22		26-23-11	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W5098	6015	22		26-23-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5098	6018	22		26-23-11	ALL
31	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46610J		**J011-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0096	0011	20		44-35-11	ALL
	4		W0096	0012	20		44-35-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D46610P		**AJ0011/ /**		**PLUG-**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W4477	0328	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46610P	**AJ0011/ /**		**PLUG- (continued)**				**ALL**
4		W4477	0329	20		44-35-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D46612J	**J011-00/ /**		**RCPT-**				**ALL**
1		W0096	0053	22		21-27-51	ALL
2		W0096	0054	22		21-27-51	ALL
3		W0096	0055	22		21-27-51	ALL
4		W0096	0056	22		21-27-51	ALL
5	UNUSED						ALL
6	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46612J		**J011-00/ /**		**RCPT- (continued)**				**ALL**
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D46612P		**J011-00/ /**		**PLUG-**				**ALL**
	1		W2103	0050	20		21-27-51	ALL
	2		W2103	0051	20		21-27-51	ALL
	3		W2103	0052	20		21-27-51	ALL
	4		W2103	0053	22		21-27-51	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46612P	**J011-00/ /**		**PLUG- (continued)**				**ALL**
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D46614J	**J011-00/ /**		**RCPT-**				**ALL**
1		W0096	0081	22		21-27-51	ALL
2		W0096	0082	22		21-27-51	ALL
3		W0096	0083	22		21-27-51	ALL
4		W0096	0080	22		21-27-51	ALL
5		W0096	0084	22		21-27-51	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46614J		**J011-00/ /**		**RCPT- (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
D46614P		**J011-00/ /**		**PLUG-**				**ALL**
	1		W5434	0001	20		21-27-51	ALL
	2		W5434	0002	20		21-27-51	ALL
	3		W5434	0003	20		21-27-51	ALL
	4		W5434	0004	20		21-27-51	ALL
	5		W5434	0005	20		21-27-51	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46614P	**J011-00/ /**		**PLUG- (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D46616J	**J011-00/ /**		**RCPT-**				**ALL**
1		W0122	0026	20		27-31-11	ALL
2		W0122	0027	20		27-31-11	ALL
3		W0122	0028	20		27-31-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0122	0031	24		27-31-37	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0122	0029	24		27-31-37	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0122	0066	22		49-62-11	ALL
16		W0122	0070	18		49-62-11	ALL
17		W0122	0069	22		49-62-11	ALL
18		W0122	0068	18		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D46616J		**J011-00/ /**		**RCPT- (continued)**				**ALL**
	19	UNUSED						ALL
	20		W0122	0030	20		27-31-37	ALL
	21	UNUSED						ALL
	22		W0122	0032	20		27-31-37	ALL
	23	UNUSED						ALL
	24		W0122	0073	18		49-62-11	ALL
	25	UNUSED						ALL
D46616P		**J011-00/ /**		**PLUG-**				**ALL**
	1		W5124	0508	20		27-31-11	ALL
	2		W5124	0509	20		27-31-11	ALL
	3		W5124	0510	20		27-31-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5124	0513	24		27-31-37	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5124	0511	24		27-31-37	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5124	0550	22		49-62-11	ALL
	16		W5124	0554	18		49-62-11	ALL
	17		W5124	0552	22		49-62-11	ALL
	18		W5124	0555	18		49-62-11	ALL
	19	UNUSED						ALL
	20		W5124	0512	20		27-31-37	ALL
	21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46616P	**J011-00/ /**		**PLUG- (continued)**				**ALL**
22		W5124	0516	22		27-31-37	ALL
23	UNUSED						ALL
24		W5124	0556	18		49-62-11	ALL
25	UNUSED						ALL
D46618J	**J011-00/ /**		**RCPT-**				**ALL**
1		W0122	0001	18		29-25-11	ALL
2		W0122	0002	18		29-25-11	ALL
3		W0122	0003	18		29-25-11	ALL
4		W0122	0004	20		29-25-11	ALL
5		W0122	0005	22		29-25-11	ALL
6		W0122	0006	18		29-25-11	ALL
7		W0122	0007	18		29-25-11	ALL
8		W0122	0008	18		29-25-11	ALL
9		W0122	0009	18		29-25-11	ALL
10		W0122	0010	22		29-25-11	ALL
11		W0122	0011	22		29-25-11	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
D46618P	**J011-00/ /**		**PLUG-**				**ALL**
1		W5124	0566	18		29-25-11	ALL
2		W5124	0567	18		29-25-11	ALL
3		W5124	0568	18		29-25-11	ALL
4		W5124	0569	18		27-53-11	ALL
5		W5124	0529	22		29-25-11	ALL
6		W5124	0530	18		29-25-11	ALL
7		W5124	0531	18		29-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46618P		**J011-00/ /**		**PLUG- (continued)**				**ALL**
	8		W5124	0535	18		29-25-11	ALL
	9		W5124	0536	18		29-25-11	ALL
	10		W5124	0570	20		29-25-11	ALL
	11		W5124	0571	20		29-25-11	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
D46623J		**J011-00/ /**		**RCPT-**				**ALL**
	1	UNUSED						ALL
	2		W0122	0123	24		23-71-01	ALL
	3		W0122	0125	22		23-71-01	ALL
	4	UNUSED						ALL
	5		W0122	0122	24		23-71-01	ALL
	6	UNUSED						ALL
	7		W0122	0124	22		23-71-01	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W0122	0089	22		21-27-51	ALL
	13		W0122	0090	22		21-27-51	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46623J	**J011-00/ /**		**RCPT- (continued)**				**ALL**
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
D46623P	**J011-00/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W5433	1001	24		23-71-01	ALL
3		W5433	0046	22		23-71-01	ALL
4	UNUSED						ALL
5		W5433	1002	24		23-71-01	ALL
6	UNUSED						ALL
7		W5433	0020	22		23-71-01	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5433	0015	22		21-27-51	ALL
13		W5433	0016	22		21-27-51	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D46623P		**J011-00/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	S/R		W5433	1001Z			23-71-01	ALL
	S/R		W5433	1002Z			23-71-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47021J	**AB0370R/289/R033**		**RCPT**				**ALL**
1		W3477	0059	20		44-35-11	ALL
2		W3477	0060	20		44-35-11	ALL
3		W3477	0056	20		44-35-11	ALL
4		W3477	0062	20		44-35-11	ALL
5		W3477	0058	20		44-35-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W3477	0061	20		44-35-11	ALL
12		W3477	0057	20		44-35-11	ALL
D47027J	**405/295/R017**		**RCPT**				**ALL**
A		W3477	0123	20		44-35-11	ALL
B		W3477	0066	20		44-35-11	ALL
C		W3477	0067	20		44-35-11	ALL
D47027P	**405/295/R017**		**RCPT**				**ALL**
A		W3453	0043	20		44-35-11	ALL
B		W3453	0052	20		44-35-11	ALL
C		W3453	0051	20		44-35-11	ALL
D47029J	**405/295/R017**		**RCPT**				**ALL**
A		W3477	0056	20		44-35-11	ALL
B		W3477	0058	20		44-35-11	ALL
C		W3477	0059	20		44-35-11	ALL
D47029P	**405/295/R017**		**PLUG**				**ALL**
A		W3453	0044	20		44-35-11	ALL
B		W3453	0036	20		44-35-11	ALL
C		W3453	0037	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47035J		**405/294/R017**		**RCPT**				**ALL**
	=1		W3058	0537	20		44-35-20	ALL
D47035P		**404/294/R018**		**PLUG**				**ALL**
	=1		W3453	0035	20		44-35-20	ALL
D47036J		**407/198/R030**		**RCPT**				**ALL**
	A		W6168	0003	18		73-22-41	ALL
	B		W6168	0004	18		73-22-41	ALL
	C		W6168	0005	18		73-22-41	ALL
D47036P		**407/198/R031**		**PLUG-**				**ALL**
	A		W5160	0190	18		73-22-41	ALL
	B		W5160	0191	18		73-22-41	ALL
	C		W5160	0192	18		73-22-41	ALL
D47038J		**235/208/R037**		**RCPT - INLINE**				**ALL**
	=1	VS	W2237	0010	22		32-44-11	ALL
D47038P		**235/208/R037**		**PLUG-**				**ALL**
	=1	VR	W5514	5782	22		32-44-11	ALL
D47050J		**897/197/R058**		**RCPT-**				**ALL**
	A		W5124	0550	22		49-62-11	ALL
	B		W5124	0552	22		49-62-11	ALL
	C		W5124	0554	18		49-62-11	ALL
D47050P		**897/197/R058**		**PLUG-**				**ALL**
	A		W5726	0573	22		49-62-11	ALL
	B		W5726	0582	22		49-62-11	ALL
	C		W5726	0612	18		49-62-11	ALL
D47052J		**895/203/R061**		**RCPT-**				**ALL**
	A		W5124	0555	18		49-62-11	ALL
	B		W5124	0556	18		49-62-11	ALL
	C	UNUSED						ALL
D47052P		**900/196/R057**		**PLUG-**				**ALL**
	A		W5726	0606	18		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47052P	**900/196/R057**		**PLUG- (continued)**				**ALL**
B		W5726	0607	18		49-62-11	ALL
C	UNUSED						ALL
D47056J	**E006-03/ /**		**RCPT**				**ALL**
=A1	DS	W0635	001CX			44-35-12	ALL
=A2	DS	W0635	002CX			44-35-12	ALL
=C1		W0635	001CO			44-35-12	ALL
=C2		W0635	002CO			44-35-12	ALL
D47056P	**E006-03/ /**		**PLUG**				**ALL**
=A1	DW	W4479	001CX			44-35-12	ALL
=A2	DW	W4479	002CX			44-35-12	ALL
=C1		W4479	001CO			44-35-12	ALL
=C2		W4479	002CO			44-35-12	ALL
D47060J	**407/198/L002**		**RCPT-**				**ALL**
A		W5160	0183	18		73-22-41	ALL
B		W5160	0184	18		73-22-41	ALL
C		W5160	0186	18		73-22-41	ALL
D47060P	**408/198/L002**		**PLUG-**				**ALL**
A		W2510	0019	18		73-22-41	ALL
B		W2510	0018	18		73-22-41	ALL
C		W2510	0017	18		73-22-41	ALL
D47066J	**404/294/R018**		**RCPT**				**ALL**
=1		W3453	0045	20		44-35-20	ALL
D47066P	**404/294/R018**		**PLUG**				**ALL**
=1	VR	W3477	0068	20		44-35-20	ALL
D47069J	**335/290/L016**		**RCPT**				**ALL**
A		W3477	0060	20		44-35-11	ALL
B		W3477	0066	20		44-35-11	ALL
C		W3477	0067	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47069P		**335/289/L16**		**PLUG-**				**ALL**
	A	UNUSED						ALL
	B		W2218	0099	24		44-35-11	ALL
	C		W2218	0098	24		44-35-11	ALL
D47071J		**406/295/R020**		**RCPT**				**ALL**
	A		W3477	0065	20		44-35-11	ALL
	B		W3477	0064	20		44-35-11	ALL
	C		W3477	0063	20		44-35-11	ALL
D47071P		**406/295/R020**		**PLUG**				**ALL**
	A		W3453	0050	20		44-35-11	ALL
	B		W3453	0048	20		44-35-11	ALL
	C		W3453	0049	20		44-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47111J	**P001-00/ /**		**RCPT - FIBER OPTIC**				**ALL**
A		W0001	0001FO	16		31-65-12	ALL
B		W0001	0002FO	16		31-65-12	ALL
C		W0001	0003FO	16		31-65-12	ALL
D		W0001	0004FO	16		31-65-12	ALL
E	UNUSED						ALL
F	UNUSED						ALL
D47111P	**P009-00/ /**		**PLUG - FIBER OPTIC**				**ALL**
A		W2008	0001FO	16		31-65-12	ALL
B		W2008	0002FO	16		31-65-12	ALL
C		W2008	0003FO	16		31-65-12	ALL
D		W2008	0004FO	16		31-65-12	ALL
E	UNUSED						ALL
F	UNUSED						ALL
D47121J	**P003-00/ /**		**RCPT - FIBER OPTIC**				**ALL**
A		W0003	0001FO	16		31-65-22	ALL
B		W0003	0002FO	16		31-65-22	ALL
C		W0003	0003FO	16		31-65-22	ALL
D		W0003	0004FO	16		31-65-22	ALL
E	UNUSED						ALL
F	UNUSED						ALL
D47121P	**P009-00/ /**		**PLUG - FIBER OPTIC**				**ALL**
A		W2228	0001FO	16		31-65-22	ALL
B		W2228	0002FO	16		31-65-22	ALL
C		W2228	0003FO	16		31-65-22	ALL
D		W2228	0004FO	16		31-65-22	ALL
E	UNUSED						ALL
F	UNUSED						ALL
D47136J	**412/197/L035**		**RCPT**				**ALL**
A		W5168	0003	18		73-22-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47136J		**412/197/L035**		**RCPT (continued)**				**ALL**
	B		W5168	0004	18		73-22-41	ALL
	C		W5168	0005	18		73-22-41	ALL
D47136P		**411/197/L035**		**PLUG**				**ALL**
	A		W2112	6095	18		73-22-41	ALL
	B		W2112	6096	18		73-22-41	ALL
	C		W2112	6097	18		73-22-41	ALL
D47141J		**AB0839L/302/L12**		**INSERT RCPT**				**ALL**
	3		W3755	2503R	24		44-35-12	ALL
	4		W3755	2503B	24		44-35-12	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1		W3755	4012Y	24		44-35-12	ALL
	2-2		W3755	4012R	24		44-35-12	ALL
	2-3		W3755	4012G	24		44-35-12	ALL
	2-4		W3755	4012B	24		44-35-12	ALL
	=C1	UNUSED						ALL
	=C2		W3755	4012Z			44-35-12	ALL
	PERB		W3755	2503Z			44-35-12	ALL
D47141P		**AB0839L/302/L12**		**PLUG**				**ALL**
	3		W4479	2501R	24		44-35-12	ALL
	4		W4479	2501B	24		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47141P	**AB0839L/302/L12**		**PLUG (continued)**				**ALL**
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
1-1		W4479	4003Y	24		44-35-12	ALL
1-2		W4479	4003R	24		44-35-12	ALL
1-3		W4479	4003G	24		44-35-12	ALL
1-4		W4479	4003B	24		44-35-12	ALL
2-1		W4479	4004Y	24		44-35-12	ALL
2-2		W4479	4004R	24		44-35-12	ALL
2-3		W4479	4004G	24		44-35-12	ALL
2-4		W4479	4004B	24		44-35-12	ALL
=C1		W4479	4003Z			44-35-12	ALL
=C2		W4479	4004Z			44-35-12	ALL
PERB		W4479	2501Z			44-35-12	ALL
D47145J	**E006-03/*/***		**RCPT**				**ALL**
A-1		W0631	4028R	24		44-35-22	ALL
A-2		W0631	4028Y	24		44-35-22	ALL
A-3		W0631	4028B	24		44-35-22	ALL
A-4		W0631	4028G	24		44-35-22	ALL
B-1		W0631	4029R	24		44-35-22	ALL
B-2		W0631	4029Y	24		44-35-22	ALL
B-3		W0631	4029B	24		44-35-22	ALL
B-4		W0631	4029G	24		44-35-22	ALL
C-1		W0631	4031R	24		44-35-22	ALL
C-2		W0631	4031Y	24		44-35-22	ALL
C-3		W0631	4031B	24		44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47145J		**E006-03/*/***		**RCPT (continued)**				**ALL**
	C-4		W0631	4031G	24		44-35-22	ALL
	D-1		W0631	4030R	24		44-35-22	ALL
	D-2		W0631	4030Y	24		44-35-22	ALL
	D-3		W0631	4030B	24		44-35-22	ALL
	D-4		W0631	4030G	24		44-35-22	ALL
	=CA		W0631	4028Z			44-35-22	ALL
	=CB		W0631	4029Z			44-35-22	ALL
	=CC		W0631	4031Z			44-35-22	ALL
	=CD		W0631	4030Z			44-35-22	ALL
D47145P		**E006-03/*/***		**PLUG**				**ALL**
	A-1		W4479	4020R	24		44-35-22	ALL
	A-2		W4479	4020Y	24		44-35-22	ALL
	A-3		W4479	4020B	24		44-35-22	ALL
	A-4		W4479	4020G	24		44-35-22	ALL
	B-1		W4479	4021R	24		44-35-22	ALL
	B-2		W4479	4021Y	24		44-35-22	ALL
	B-3		W4479	4021B	24		44-35-22	ALL
	B-4		W4479	4021G	24		44-35-22	ALL
	C-1		W4479	4023R	24		44-35-22	ALL
	C-2		W4479	4023Y	24		44-35-22	ALL
	C-3		W4479	4023B	24		44-35-22	ALL
	C-4		W4479	4023G	24		44-35-22	ALL
	D-1		W4479	4022R	24		44-35-22	ALL
	D-2		W4479	4022Y	24		44-35-22	ALL
	D-3		W4479	4022B	24		44-35-22	ALL
	D-4		W4479	4022G	24		44-35-22	ALL
	=CA		W4479	4020Z			44-35-22	ALL
	=CB		W4479	4021Z			44-35-22	ALL
	=CC		W4479	4023Z			44-35-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47145P	**E006-03/*/***		**PLUG (continued)**				**ALL**
=CD		W4479	4022Z			44-35-22	ALL
D47151J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0311	2163R	24		31-65-15	ALL
A02		W0311	2164R	24		31-65-15	ALL
A03		W0311	2707R	24		31-65-15	ALL
A04		W0311	2709R	24		31-65-15	ALL
A05		W0311	2710R	24		31-65-15	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W0311	2716B	24		31-31-13	ALL
A09		W0311	2776R	24		31-65-16	ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W0311	2721R	24		36-11-14	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W0311	1773	24		27-81-31	ALL
A20		W0311	2666R	24		31-33-01	ALL
B01		W0311	2163B	24		31-65-15	ALL
B02		W0311	2164B	24		31-65-15	ALL
B03		W0311	2707B	24		31-65-15	ALL
B04		W0311	2709B	24		31-65-15	ALL
B05		W0311	2710B	24		31-65-15	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47151J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B08		W0311	2716R	24		31-31-13	ALL
	B09		W0311	2776B	24		31-65-16	ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14		W0311	2721B	24		36-11-14	ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W0311	2666B	24		31-33-01	ALL
	PERG	1F	W0311	2163Z			31-65-15	ALL
	PERG	1F	W0311	2164Z			31-65-15	ALL
	PERG	1F	W0311	2666Z			31-33-01	ALL
	PERG	1F	W0311	2707Z			31-65-15	ALL
	PERG	1F	W0311	2709Z			31-65-15	ALL
	PERG	1F	W0311	2710Z			31-65-15	ALL
	PERG	1F	W0311	2716Z			31-31-13	ALL
	PERG	1F	W0311	2721Z			36-11-14	ALL
	PERG	1F	W0311	2776Z			31-65-16	ALL
D47151P		**E003-01/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5111	2086R	24		31-65-15	ALL
	A02		W5111	2087R	24		31-65-15	ALL
	A03		W5111	2707R	24		31-65-15	ALL
	A04		W5111	2709R	24		31-65-15	ALL
	A05		W5111	2710R	24		31-65-15	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47151P	**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
A07	UNUSED						ALL
A08		W5111	2716B	24		31-31-13	ALL
A09		W5111	2765R	24		31-65-16	ALL
A10	UNUSED						ALL
A11	UNUSED						ALL
A12	UNUSED						ALL
A13	UNUSED						ALL
A14		W5111	2721R	24		36-11-14	ALL
A15	UNUSED						ALL
A16	UNUSED						ALL
A17	UNUSED						ALL
A18	UNUSED						ALL
A19		W5111	1702	24		27-81-31	ALL
A20		W5111	2764R	24		31-33-01	ALL
B01		W5111	2086B	24		31-65-15	ALL
B02		W5111	2087B	24		31-65-15	ALL
B03		W5111	2707B	24		31-65-15	ALL
B04		W5111	2709B	24		31-65-15	ALL
B05		W5111	2710B	24		31-65-15	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W5111	2716R	24		31-31-13	ALL
B09		W5111	2765B	24		31-65-16	ALL
B10	UNUSED						ALL
B11	UNUSED						ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14		W5111	2721B	24		36-11-14	ALL
B15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47151P		**E003-01/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20		W5111	2764B	24		31-33-01	ALL
	PERG	1F	W5111	2086Z			31-65-15	ALL
	PERG	1F	W5111	2087Z			31-65-15	ALL
	PERG	1F	W5111	2707Z			31-65-15	ALL
	PERG	1F	W5111	2709Z			31-65-15	ALL
	PERG	1F	W5111	2710Z			31-65-15	ALL
	PERG	1F	W5111	2716Z			31-31-13	ALL
	PERG	1F	W5111	2721Z			36-11-14	ALL
	PERG	1F	W5111	2764Z			31-33-01	ALL
	PERG	1F	W5111	2765Z			31-65-16	ALL
D47160J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0171	0006	20		33-11-33	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47160J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0171	0052	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47160P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2149	0050	20		33-11-33	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W2149	0049	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47161J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47161J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0171	0008	20		33-11-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0171	0028	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47161P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2151	0050	20		33-11-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47161P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W2151	0049	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47162J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0171	0029	20		33-18-62	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47162J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47162P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W2265	0007	20		33-18-62	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47163J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47163J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W0172	0079	20		33-18-62	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47163P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47163P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W2267	0007	20		33-18-62	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47165J		**J071-0A/ /**		**RCPT**				**ALL**
	A	UNUSED						ALL
	B		W0171	0045	20		33-18-62	ALL
	C		W0171	0070	24		23-12-41	ALL
	D	UNUSED						ALL
	E		W0171	0072	20		33-18-62	ALL
D47165P		**J071-0A/ /**		**PLUG**				**ALL**
	A	UNUSED						ALL
	B		W2413	0036	20		33-18-62	ALL
	C		W2413	0047	24		23-12-41	ALL
	D	UNUSED						ALL
	E		W2413	0035	20		33-18-62	ALL
D47166J		**J072-0A/ /**		**RCPT**				**ALL**
	A		W0172	0120	20		33-11-41	ALL
	B	UNUSED						ALL
	C		W0172	0110	20		33-18-61	ALL
	D		W0172	0111	20		33-18-61	ALL
	E	UNUSED						ALL
D47166P		**J072-0A/ /**		**PLUG**				**ALL**
	A		W2873	0016	20		33-11-41	ALL
	B	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47166P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	C		W2873	0011	20		33-18-61	ALL
	D		W2873	0010	20		33-18-61	ALL
	E	UNUSED						ALL
D47167J		**J071-0A/ /**		**RCPT**				**ALL**
	A01		W0171	0069	20		33-18-61	ALL
	A02	UNUSED						ALL
	A03		W0171	0003	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W0171	0032	20		33-18-61	ALL
	A06	UNUSED						ALL
	A07		W0171	0035	20		33-18-61	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0171	0004	20		33-11-33	ALL
	B04	UNUSED						ALL
	B05		W0171	0038	20		33-18-61	ALL
	B06		W0171	0042	20		33-18-61	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47167P		**J071-0A/ /**		**PLUG**				**ALL**
	A01		W2889	0018	20		33-18-61	ALL
	A02	UNUSED						ALL
	A03		W2889	0025	20		33-11-33	ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47167P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	A05		W2889	0010	20		33-18-61	ALL
	A06	UNUSED						ALL
	A07		W2889	0020	20		33-18-61	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W2889	0027	20		33-11-33	ALL
	B04	UNUSED						ALL
	B05		W2889	0011	20		33-18-61	ALL
	B06		W2889	0019	20		33-18-61	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47168J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0171	0046	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47168J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0171	0043	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47168P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W3323	0008	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W3323	0032	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47169J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0172	0105	20		27-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47169P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W3381	0025	20		27-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47169P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47170J		**J071-0A/ /**		**RCPT**				**ALL**
	A01		W0171	0070	24		23-12-41	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0171	0025	24		23-12-41	ALL
	B02		W0171	0031	24		23-12-41	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47170J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47170P		**J071-0A/ /**		**PLUG**				**ALL**
	A01		W5049	0001	24		23-12-41	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5049	0003	24		23-12-41	ALL
	B02		W5049	0002	24		23-12-41	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47171J		**J071-0A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0171	2201B	22		24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47171J		**J071-0A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A04	UNUSED						ALL
	A05		W0171	0080	22		26-23-11	ALL
	A06		W0171	0059	20		33-18-63	ALL
	A07		W0171	0061	20		33-18-63	ALL
	A08		W0171	0074	20		76-21-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0171	2201R	22		24-22-11	ALL
	B04	UNUSED						ALL
	B05		W0171	0085	20		33-11-33	ALL
	B06		W0171	0060	20		33-18-63	ALL
	B07		W0171	0076	20		73-22-41	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0171	2201Z			24-22-11	ALL
D47171P		**J071-0A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5506	2201B	22		24-22-11	ALL
	A04	UNUSED						ALL
	A05		W5506	6080	22		26-23-11	ALL
	A06		W5506	5506	20		33-18-63	ALL
	A07		W5506	5522	20		33-18-63	ALL
	A08		W5506	6013R	20		76-21-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47171P		**J071-0A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5506	2201R	22		24-22-11	ALL
	B04	UNUSED						ALL
	B05		W5506	5504	20		33-11-33	ALL
	B06		W5506	5509	20		33-18-63	ALL
	B07		W5506	0098	20		73-22-41	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5506	2201Z			24-22-11	ALL
D47172J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0171	0023	20		27-41-11	ALL
	A05		W0171	0027	20		27-41-11	ALL
	A06		W0171	0013	20		33-11-41	ALL
	A07	UNUSED						ALL
	A08		W0171	0036	20		33-18-61	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0171	0026	20		27-41-11	ALL
	B05		W0171	0024	20		27-41-11	ALL
	B06		W0171	0014	20		33-11-41	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47172J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B08		W0171	0019	20		33-18-61	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47172P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W6208	0610	20		27-41-11	ALL
	A05		W6208	0625	20		27-41-11	ALL
	A06		W6208	5501	20		33-11-41	ALL
	A07	UNUSED						ALL
	A08		W6208	5508	20		33-18-61	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6208	0612	20		27-41-11	ALL
	B05		W6208	0626	20		27-41-11	ALL
	B06		W6208	5503	20		33-11-41	ALL
	B07	UNUSED						ALL
	B08		W6208	5509	20		33-18-61	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47173J		**J071-0A/ /**		**RCPT**				**ALL**
	A		W0171	0012	20		33-11-41	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47173J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	E	UNUSED						ALL
D47173P		**J071-0A/ /**		**PLUG**				**ALL**
	A		W6208	5505	16		33-11-41	ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D	UNUSED						ALL
	E	UNUSED						ALL
D47174J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0172	0074	20		33-18-63	ALL
	A07		W0172	0076	20		33-18-63	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0172	0035	20		31-52-45	ALL
	B06		W0172	0075	20		33-18-63	ALL
	B07		W0172	0073	20		33-18-63	ALL
	B08		W0172	0080	20		73-22-41	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47174P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W6506	5506	20		33-18-63	ALL
	A07		W6506	5508	20		33-18-63	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6506	5509	20		31-52-45	ALL
	B06		W6506	5507	20		33-18-63	ALL
	B07		W6506	5511	20		33-18-63	ALL
	B08		W6506	6029R	20		76-21-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47175J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0172	0040	20		73-22-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47175J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47175P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6510	6002	20		76-21-21	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47175P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47176J		**J071-0A/ /**		**RCPT**				**ALL**
	A01		W0171	0021	20		27-41-12	ALL
	A02		W0171	0005	20		33-11-33	ALL
	A03		W0171	0006	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W0171	0008	20		33-11-41	ALL
	A06		W0171	0026	20		27-41-11	ALL
	A07		W0171	0075	20		76-21-11	ALL
	A08		W0171	0020	20		33-11-41	ALL
	A09		W0171	0085	20		33-11-33	ALL
	A10	UNUSED						ALL
	B01		W0171	0022	20		27-41-11	ALL
	B02	UNUSED						ALL
	B03		W0171	0014	20		33-11-41	ALL
	B04		W0171	0013	20		33-11-41	ALL
	B05		W0171	0012	20		33-11-41	ALL
	B06		W0171	0027	20		27-41-11	ALL
	B07		W0171	0052	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0171	0080	22		26-23-11	ALL
D47176P		**J071-0A/ /**		**PLUG**				**ALL**
	A01		W6201	0026	20		27-41-12	ALL
	A02		W6201	0019	20		33-11-33	ALL
	A03		W6201	0003	20		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47176P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	A04	UNUSED						ALL
	A05		W6201	0005	20		33-11-41	ALL
	A06		W6201	0011	20		27-41-11	ALL
	A07		W6201	0013	20		76-21-11	ALL
	A08		W6201	0022	20		33-11-41	ALL
	A09		W6201	0025	20		33-11-33	ALL
	A10	UNUSED						ALL
	B01		W6201	0010	20		27-41-11	ALL
	B02	UNUSED						ALL
	B03		W6201	0008	20		33-11-41	ALL
	B04		W6201	0007	20		33-11-41	ALL
	B05		W6201	0006	20		33-11-41	ALL
	B06		W6201	0012	20		27-41-11	ALL
	B07		W6201	0014	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W6201	0020	22		26-23-11	ALL
D47177J		**J071-0A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0171	2201R	22		24-22-11	ALL
	A02		W0171	0098	20		33-18-62	ALL
	A03		W0171	0057	20		31-52-45	ALL
	A04		W0171	0031	24		23-12-41	ALL
	A05		W0171	0034	20		33-18-61	ALL
	A06		W0171	0055	20		33-18-62	ALL
	A07		W0171	0056	20		33-18-62	ALL
	A08	UNUSED						ALL
	A09		W0171	0068	20		33-18-61	ALL
	A10		W0171	0062	20		33-18-63	ALL
	B01		W0171	2201B	22		24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47177J		**J071-0A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B02		W0171	0099	20		33-18-62	ALL
	B03		W0171	0071	20		31-52-45	ALL
	B04	UNUSED						ALL
	B05		W0171	0039	20		33-18-61	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0171	0047	20		33-18-62	ALL
	B09		W0171	0037	20		33-18-61	ALL
	B10		W0171	0066	20		33-18-61	ALL
	PERG	1F	W0171	2201Z			24-22-11	ALL
D47177P		**J071-0A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6103	2201R	22		24-22-11	ALL
	A02		W6103	0049	20		33-18-62	ALL
	A03		W6103	0001	20		31-52-45	ALL
	A04		W6103	0005	24		23-12-41	ALL
	A05		W6103	0006	20		33-18-61	ALL
	A06		W6103	0009	20		33-18-62	ALL
	A07		W6103	0013	20		33-18-62	ALL
	A08	UNUSED						ALL
	A09		W6103	0021	20		33-18-61	ALL
	A10		W6103	0015	20		33-18-63	ALL
	B01		W6103	2201B	22		24-22-11	ALL
	B02		W6103	0048	20		33-18-62	ALL
	B03		W6103	0004	20		31-52-45	ALL
	B04	UNUSED						ALL
	B05		W6103	0008	20		33-18-61	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W6103	0012	20		33-18-64	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47177P		**J071-0A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B09		W6103	0020	20		33-18-61	ALL
	B10		W6103	0016	20		33-18-61	ALL
	PERG	1F	W6103	2201Z			24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47260J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0172	0059	22		26-23-11	ALL
	A06		W0172	0042	20		33-18-64	ALL
	A07	UNUSED						ALL
	A08		W0172	0003	20		33-11-33	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0172	0036	20		33-18-64	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47260P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2110	6043	22		26-23-11	ALL
	A06		W2110	6029	20		33-18-64	ALL
	A07	UNUSED						ALL
	A08		W2110	6032	20		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47260P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W2110	6030	20		33-18-64	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47261J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0172	0005	20		33-11-33	ALL
	A05	UNUSED						ALL
	A06		W0172	0032	20		33-18-61	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0172	0030	20		33-18-61	ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47261J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47261P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W2177	0001	20		33-11-33	ALL
	A05	UNUSED						ALL
	A06		W2177	0021	20		33-18-61	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W2177	0018	20		33-18-61	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47262J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47262J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	A04	UNUSED						ALL
	A05		W0172	0029	24		23-12-41	ALL
	A06		W0172	0043	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08		W0172	0009	20		33-11-41	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0172	0062	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47262P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2415	0047	24		23-12-41	ALL
	A06		W2415	0035	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08		W2415	0037	20		33-11-41	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47262P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W2415	0036	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47263J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0171	0025	24		23-12-41	ALL
	A06		W0171	0098	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0171	0099	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47263J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B10	UNUSED						ALL
D47263P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W2417	0047	24		23-12-41	ALL
	A06		W2417	0035	20		33-18-62	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W2417	0036	20		33-18-62	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47264J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0172	0051	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W0172	0066	20		33-18-62	ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47264J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0172	0064	20		33-18-62	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47264P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W3319	0007	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W3319	0032	20		33-18-62	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W3319	0008	20		33-18-62	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47264P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47265J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0172	0024	20		27-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0172	0041	20		73-22-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47265P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47265P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5160	0127	20		27-41-12	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5160	0187	20		73-22-41	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47266J		**J072-0A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0172	2201B	22		24-22-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47266J		**J072-0A/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0172	2201R	22		24-22-11	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0172	2201Z			24-22-11	ALL
D47266P		**J072-0A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W5510	2201B	22		24-22-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5510	2201R	22		24-22-11	ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47266P		**J072-0A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5510	2201Z			24-22-11	ALL
D47267J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0171	0057	20		31-52-45	ALL
	A05		W0171	0033	20		33-18-61	ALL
	A06		W0171	0030	20		33-18-61	ALL
	A07		W0171	0019	20		33-18-61	ALL
	A08		W0171	0048	20		33-18-62	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0171	0071	20		31-52-45	ALL
	B05		W0171	0040	20		33-18-61	ALL
	B06		W0171	0041	20		33-18-61	ALL
	B07		W0171	0056	20		33-18-62	ALL
	B08		W0171	0055	20		33-18-62	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47267P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47267P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	A03	UNUSED						ALL
	A04		W5514	5535	20		31-52-45	ALL
	A05		W5514	5509	20		33-18-61	ALL
	A06		W5514	5511	20		33-18-61	ALL
	A07		W5514	5515	20		33-18-61	ALL
	A08		W5514	5576	20		33-18-62	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W5514	5536	20		31-52-45	ALL
	B05		W5514	5510	20		33-18-61	ALL
	B06		W5514	5512	20		33-18-61	ALL
	B07		W5514	5561	20		33-18-62	ALL
	B08		W5514	5577	20		33-18-62	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47268J		**J071-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W0171	0065	20		33-18-61	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47268J		**J071-0A/ /**		**RCPT (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47268P		**J071-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6110	0019	20		33-18-61	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47268P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47269J		**J072-0A/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0172	0015	20		33-11-41	ALL
	A04		W0172	0022	20		27-41-11	ALL
	A05	UNUSED						ALL
	A06		W0172	0061	20		33-18-61	ALL
	A07	UNUSED						ALL
	A08		W0172	0069	20		33-18-61	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0172	0025	20		27-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47269P		**J072-0A/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W6206	5533	20		33-11-41	ALL
	A04		W6206	0506	20		27-41-11	ALL
	A05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47269P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	A06		W6206	5554	20		33-18-61	ALL
	A07	UNUSED						ALL
	A08		W6206	5552	20		33-18-61	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W6206	0507	20		27-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47270J		**J072-0A/ /**		**RCPT**				**ALL**
	A		W0172	0054	16		33-11-33	ALL
	B		W0172	0055	16		33-11-33	ALL
	C		W0172	0056	16		33-11-33	ALL
	D		W0172	0048	16		33-11-33	ALL
	E	UNUSED						ALL
D47270P		**J072-0A/ /**		**PLUG**				**ALL**
	A		W6206	5503	16		33-11-33	ALL
	B		W6206	5504	16		33-11-33	ALL
	C		W6206	5506	16		33-11-33	ALL
	D		W6206	5509	16		33-11-33	ALL
	E	UNUSED						ALL
D47271J		**J072-0A/ /**		**RCPT**				**ALL**
	A		W0172	0053	16		33-11-33	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47271J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	B		W0172	0049	16		33-11-33	ALL
	C		W0172	0057	16		33-11-33	ALL
	D		W0172	0006	16		33-11-33	ALL
	E		W0172	0058	16		33-11-33	ALL
D47271P		**J072-0A/ /**		**PLUG**				**ALL**
	A		W6206	5511	16		33-11-33	ALL
	B		W6206	5512	16		33-11-33	ALL
	C		W6206	5543	16		33-11-33	ALL
	D		W6206	5545	16		33-11-33	ALL
	E		W6206	5546	16		33-11-33	ALL
D47272J		**J072-0A/ /**		**RCPT**				**ALL**
	A		W0172	0002	20		33-11-33	ALL
	B	UNUSED						ALL
	C		W0172	0050	16		33-11-41	ALL
	D		W0172	0014	16		33-11-41	ALL
	E	UNUSED						ALL
D47272P		**J072-0A/ /**		**PLUG**				**ALL**
	A		W6206	5569	16		33-11-33	ALL
	B	UNUSED						ALL
	C		W6206	5528	16		33-11-41	ALL
	D		W6206	5532	16		33-11-41	ALL
	E	UNUSED						ALL
D47273J		**J072-0A/ /**		**RCPT**				**ALL**
	A		W0172	0016	18		33-11-41	ALL
	B		W0172	0011	16		33-11-41	ALL
	C		W0172	0007	20		33-11-41	ALL
	D	UNUSED						ALL
	E	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47273P	**J072-0A/ /**		**PLUG**				**ALL**
A		W6206	0017	18		33-11-41	ALL
B		W6206	5563	16		33-11-41	ALL
C		W6206	5564	20		33-11-41	ALL
D	UNUSED						ALL
E	UNUSED						ALL
D47274J	**J071-0A/ /**		**RCPT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04	UNUSED						ALL
A05		W0171	0020	20		33-11-41	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
D47274P	**J071-0A/ /**		**PLUG**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47274P		**J071-0A/ /**		**PLUG (continued)**				**ALL**
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05		W6491	0530	20		33-11-41	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D47275J		**J072-0A/ /**		**RCPT**				**ALL**
	A01		W0172	0105	20		27-41-12	ALL
	A02		W0172	0002	20		33-11-33	ALL
	A03		W0172	0004	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W0172	0010	20		33-11-41	ALL
	A06		W0172	0026	20		27-41-11	ALL
	A07	UNUSED						ALL
	A08		W0172	0101	20		33-11-41	ALL
	A09		W0172	0052	20		33-11-33	ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47275J		**J072-0A/ /**		**RCPT (continued)**				**ALL**
	B01		W0172	0022	20		27-41-11	ALL
	B02	UNUSED						ALL
	B03		W0172	0018	20		33-11-41	ALL
	B04		W0172	0017	20		33-11-41	ALL
	B05		W0172	0012	20		33-11-41	ALL
	B06		W0172	0027	20		27-41-11	ALL
	B07		W0172	0077	20		33-18-61	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0172	0059	22		26-23-11	ALL
D47275P		**J072-0A/ /**		**PLUG**				**ALL**
	A01		W6201	0026	20		27-41-12	ALL
	A02		W6201	0002	20		33-11-33	ALL
	A03		W6201	0003	20		33-11-33	ALL
	A04	UNUSED						ALL
	A05		W6201	0005	20		33-11-41	ALL
	A06		W6201	0011	20		27-41-11	ALL
	A07	UNUSED						ALL
	A08		W6201	0022	20		33-11-41	ALL
	A09		W6201	0025	20		33-11-33	ALL
	A10	UNUSED						ALL
	B01		W6201	0010	20		27-41-11	ALL
	B02	UNUSED						ALL
	B03		W6201	0008	20		33-11-41	ALL
	B04		W6201	0007	20		33-11-41	ALL
	B05		W6201	0006	20		33-11-41	ALL
	B06		W6201	0012	20		27-41-11	ALL
	B07		W6201	0014	20		33-18-61	ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47275P		**J072-0A/ /**		**PLUG (continued)**				**ALL**
	B09	UNUSED						ALL
	B10		W6201	0020	22		26-23-11	ALL
D47276J		**J072-0A/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0172	2201R	22		24-22-11	ALL
	A02		W0172	0044	20		33-18-62	ALL
	A03		W0172	0071	20		31-52-45	ALL
	A04		W0172	0029	24		23-12-41	ALL
	A05		W0172	0030	20		33-18-61	ALL
	A06		W0172	0067	20		33-18-62	ALL
	A07		W0172	0065	20		33-18-62	ALL
	A08	UNUSED						ALL
	A09		W0172	0111	20		33-18-61	ALL
	A10		W0172	0072	20		33-18-63	ALL
	B01		W0172	2201B	22		24-22-11	ALL
	B02		W0172	0063	20		33-18-62	ALL
	B03		W0172	0070	20		31-52-45	ALL
	B04	UNUSED						ALL
	B05		W0172	0032	20		33-18-61	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0172	0036	20		33-18-64	ALL
	B09		W0172	0110	20		33-18-61	ALL
	B10		W0172	0061	20		33-18-61	ALL
	PERG	1F	W0172	2201Z			24-22-11	ALL
D47276P		**J072-0A/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W6103	2201R	22		24-22-11	ALL
	A02		W6103	0049	20		33-18-62	ALL
	A03		W6103	0001	20		31-52-45	ALL
	A04		W6103	0005	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47276P	**J072-0A/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
A05		W6103	0006	20		33-18-61	ALL
A06		W6103	0009	20		33-18-62	ALL
A07		W6103	0013	20		33-18-62	ALL
A08	UNUSED						ALL
A09		W6103	0021	20		33-18-61	ALL
A10		W6103	0015	20		33-18-63	ALL
B01		W6103	2201B	22		24-22-11	ALL
B02		W6103	0048	20		33-18-62	ALL
B03		W6103	0004	20		31-52-45	ALL
B04	UNUSED						ALL
B05		W6103	0008	20		33-18-61	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W6103	0012	20		33-18-64	ALL
B09		W6103	0020	20		33-18-61	ALL
B10		W6103	0016	20		33-18-61	ALL
PERG	1F	W6103	2201Z			24-22-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47311J		**E003-01/ /**		**RCPT - FIBER OPTIC**				**ALL**
	A		W0315	0001FO	16		31-65-12	ALL
	B		W0315	0002FO	16		31-65-12	ALL
	C		W0315	0003FO	16		31-65-12	ALL
	D		W0315	0004FO	16		31-65-12	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D47311P		**E003-01/ /**		**PLUG - FIBER OPTIC**				**ALL**
	A		W2008	0001FO	16		31-65-12	ALL
	B		W2008	0002FO	16		31-65-12	ALL
	C		W2008	0003FO	16		31-65-12	ALL
	D		W2008	0004FO	16		31-65-12	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D47321J		**E003-01/ /**		**RCPT - FIBER OPTIC**				**ALL**
	A		W0317	0001FO	16		31-65-22	ALL
	B		W0317	0002FO	16		31-65-22	ALL
	C		W0317	0003FO	16		31-65-22	ALL
	D		W0317	0004FO	16		31-65-22	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL
D47321P		**E003-01/ /**		**PLUG - FIBER OPTIC**				**ALL**
	A		W2228	0001FO	16		31-65-22	ALL
	B		W2228	0002FO	16		31-65-22	ALL
	C		W2228	0003FO	16		31-65-22	ALL
	D		W2228	0004FO	16		31-65-22	ALL
	E	UNUSED						ALL
	F	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47521J	**E003-01/ /**		**RCPT**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W0311	4003Z			46-13-11	ALL
1-1		W0311	4003R	24		46-13-11	ALL
1-2		W0311	4003Y	24		46-13-11	ALL
1-3		W0311	4003B	24		46-13-11	ALL
1-4		W0311	4003G	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
D47521P	**E003-01/ /**		**PLUG**				**ALL**
2	UNUSED						ALL
3	UNUSED						ALL
=1		W2031	4005Z			46-13-11	ALL
1-1		W2031	4005R	24		46-13-11	ALL
1-2		W2031	4005Y	24		46-13-11	ALL
1-3		W2031	4005B	24		46-13-11	ALL
1-4		W2031	4005G	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47521P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D47523J		**E003-01/ /**		**RCPT**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0313	4003Z			46-13-11	ALL
	1-1		W0313	4003R	24		46-13-11	ALL
	1-2		W0313	4003Y	24		46-13-11	ALL
	1-3		W0313	4003B	24		46-13-11	ALL
	1-4		W0313	4003G	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D47523P		**E003-01/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W2043	4003Z			46-13-11	ALL
	1-1		W2043	4003R	24		46-13-11	ALL
	1-2		W2043	4003Y	24		46-13-11	ALL
	1-3		W2043	4003B	24		46-13-11	ALL
	1-4		W2043	4003G	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47523P		**E003-01/ /**		**PLUG (continued)**				**ALL**
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D47524J		**258/182/R018**		**RECEPTACLE**				**ALL**
	A		W8036	A-R			32-64-12	ALL
	B		W8036	A-Y			32-64-12	ALL
	C		W8036	A-B			32-64-12	ALL
D47524P		**258/182/R018**		**PLUG**				**ALL**
	A		W5160	2205R	20		32-64-12	ALL
	B		W5160	0650	18		32-64-12	ALL
	C		W5160	2205B	20		32-64-12	ALL
D47525J		**258/181/L018**		**RECEPTACLE**				**ALL**
	A		W7036	A-R			32-64-11	ALL
	B		W7036	A-Y			32-64-11	ALL
	C		W7036	A-B			32-64-11	ALL
D47525P		**258/181/L018**		**PLUG**				**ALL**
	A		W5156	2205R	20		32-64-11	ALL
	B		W5156	0650	18		32-64-11	ALL
	C		W5156	2205B	20		32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47725J		**AE0100C/166/R027**		**RCPT- INSERT**				**ALL**
	1		W5526	5516	20		SPARE	ALL
	2		W5526	5517	20		SPARE	ALL
	3	UNUSED						ALL
	4		W5526	0501	20		47-30-11	ALL
	5		W5526	5531	20		29-11-11	ALL
	6		W5526	5530	20		29-11-11	ALL
	7		W5526	6003R	20		26-12-11	ALL
	8		W5526	6002R	20		26-12-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W5526	0513	24		32-44-11	ALL
	16		W5526	0511	24		32-44-11	ALL
	17		W5526	0591	22		32-41-11	ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W5526	6001R	20		26-12-11	ALL
	24		W5526	6007R	20		26-12-11	ALL
	25		W5526	6004R	20		26-12-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47725J	**AE0100C/166/R027**		**RCPT- INSERT (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32		W5526	0514	24		32-44-11	ALL
33		W5526	0516	24		32-44-11	ALL
34		W5526	0517	24		32-44-11	ALL
D47725P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0141	0224	20		47-30-11	ALL
5		W0141	0506	20		29-11-11	ALL
6		W0141	0505	20		29-11-11	ALL
7		W0141	0441R	20		26-12-11	ALL
8		W0141	0440R	20		26-12-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0141	0604	24		32-44-11	ALL
16		W0141	0603	24		32-44-11	ALL
17		W0141	0611	24		32-41-11	ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0141	0429R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47725P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	24		W0141	0423R	20		26-12-11	ALL
	25		W0141	0412R	20		26-12-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32		W0141	0607	24		32-44-11	ALL
	33		W0141	0606	24		32-44-11	ALL
	34		W0141	0605	24		32-44-11	ALL
	PERS	1A	W0141	0505Z			29-11-11	ALL
	PERS	1A	W0141	0506Z			29-11-11	ALL
D47726J		**AE0100C/ /**		**RCPT - INSERT**				**ALL**
	1		W5506	6089	20		76-21-11	ALL
	2		W5506	0602	20		47-30-11	ALL
	3	UNUSED						ALL
	4		W5506	6049R	22		26-11-21	ALL
	5	UNUSED						ALL
	6		W5506	6052R	22		26-11-21	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5506	0074	16		47-30-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12		W5506	0002	22		35-21-11	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47726J	**AE0100C/ /**		**RCPT - INSERT (continued)**				**ALL**
16		W5506	0601	20		47-30-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5506	6014R	22		26-12-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
D47726P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1		W0141	0454	20		76-21-11	ALL
2		W0141	0226	20		47-30-11	ALL
3	UNUSED						ALL
4		W0141	0401R	22		26-11-21	ALL
5	UNUSED						ALL
6		W0141	0403R	22		26-11-21	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0141	0227	16		47-30-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W0141	0657	22		35-21-11	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0141	0225	20		47-30-11	ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0141	0420R	22		26-12-11	ALL
21	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47726P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	22	UNUSED						ALL
D47727J		**AE0100C/ /**		**RCPT - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W5506	0507	20		29-11-11	ALL
	3		W5506	0508	20		29-11-11	ALL
	4		W5506	0516	24		29-33-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5506	0510	24		32-42-11	ALL
	10		W5506	0512	24		32-42-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W5506	0015	22		35-11-11	ALL
	14	UNUSED						ALL
	15		W5506	6505	24		34-61-26	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D47727P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W0141	0505	20		29-11-11	ALL
	3		W0141	0506	20		29-11-11	ALL
	4		W0141	0512	24		29-33-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0141	0601	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47727P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
10		W0141	0602	24		32-42-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0141	0658	22		35-11-11	ALL
14	UNUSED						ALL
15		W0141	0307	24		34-61-26	ALL
16	UNUSED						ALL
17	UNUSED						ALL
PERS	1A	W0141	0505Z			29-11-11	ALL
PERS	1A	W0141	0506Z			29-11-11	ALL
PERS	1A	W0141	0512Z			29-33-11	ALL
D47728J	**AE0100C/ /**		**RCPT- INSERT**				**ALL**
1		W2508	6031	20		80-11-11	ALL
2	UNUSED						ALL
3		W2508	5648	20		35-21-11	ALL
4		W2508	5645	22		35-21-11	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W2508	0540	24		75-11-11	ALL
9		W2508	6029	24		80-11-11	ALL
10		W2508	8015	22		34-21-15	ALL
11		W2508	8014	22		34-21-15	ALL
12	UNUSED						ALL
13		W2508	8005	22		34-21-15	ALL
14		W2508	8007	22		34-21-15	ALL
15		W2508	8012	22		34-21-15	ALL
16	UNUSED						ALL
17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47728P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0141	0462	20		80-11-11	ALL
	2	UNUSED						ALL
	3		W0141	0657	22		35-21-11	ALL
	4		W0141	0656	22		35-21-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0141	0241	24		75-11-11	ALL
	9		W0141	0463	24		80-11-11	ALL
	10		W0141	0211	22		34-21-15	ALL
	11		W0141	0210	22		34-21-15	ALL
	12	UNUSED						ALL
	13		W0141	0213	22		34-21-15	ALL
	14		W0141	0212	22		34-21-15	ALL
	15		W0141	0209	22		34-21-15	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D47729J		**AE0100C/ /**		**RCPT- INSERT**				**ALL**
	1	UNUSED						ALL
	2		W2508	0532	24		29-33-11	ALL
	3		W2508	1304R	20		26-12-11	ALL
	4		W2508	0524	18		24-11-11	ALL
	5		W2508	8004	22		34-51-41	ALL
	6		W2508	5643	22		35-11-11	ALL
	7		W2508	1303R	20		26-12-11	ALL
	8		W2508	1306R	20		26-12-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47729J	**AE0100C/ /**		**RCPT- INSERT (continued)**				**ALL**
12	UNUSED						ALL
13		W2508	1307R	20		26-12-11	ALL
14		W2508	1305R	20		26-12-11	ALL
DED		W2508	1303Z			26-12-11	ALL
DED		W2508	1304Z			26-12-11	ALL
DED		W2508	1305Z			26-12-11	ALL
DED		W2508	1306Z			26-12-11	ALL
DED		W2508	1307Z			26-12-11	ALL
D47729P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2		W0141	0511	24		29-33-11	ALL
3		W0141	0432R	22		26-12-11	ALL
4		W0141	0301	18		24-11-11	ALL
5		W0141	0716	22		34-51-41	ALL
6		W0141	0659	22		35-11-11	ALL
7		W0141	0431R	22		26-12-11	ALL
8		W0141	0434R	22		26-12-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0141	0435R	22		26-12-11	ALL
14		W0141	0433R	22		26-12-11	ALL
DED		W0141	0511Z			29-33-11	ALL
D47730J	**AE0100C/166/R027**		**RCPT - INSERT**				**ALL**
A01	UNUSED						ALL
A02		W5721	2005B	24		73-24-11	ALL
A03		W5721	2005R	24		73-24-11	ALL
A04		W5721	2003B	24		34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47730J		**AE0100C/166/R027**		**RCPT - INSERT (continued)**				**ALL**
	A05	UNUSED						ALL
	A06		W5721	2043B	24		22-11-51	ALL
	A07		W5721	1001	22		22-11-11	ALL
	A08	UNUSED						ALL
	A09		W5721	0017	22		22-14-11	ALL
	A10	UNUSED						ALL
	B01		W5721	0025	22		34-16-11	ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5721	2003R	24		34-21-13	ALL
	B06		W5721	2043R	24		22-11-51	ALL
	B07		W5721	0002	22		22-11-11	ALL
	B08	UNUSED						ALL
	B09		W5721	2049B	22		22-18-11	ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W5721	2054B	24		34-31-11	ALL
	C03		W5721	2001B	24		34-33-11	ALL
	C04		W5721	0018	22		34-51-41	ALL
	C05		W5721	2052B	24		31-65-15	ALL
	C06		W5721	2040B	24		22-11-51	ALL
	C07		W5721	0016	22		34-51-41	ALL
	C08	UNUSED						ALL
	C09		W5721	2049R	22		22-18-11	ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W5721	2054R	24		34-31-11	ALL
	D03		W5721	2001R	24		34-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47730J		**AE0100C/166/R027**		**RCPT - INSERT (continued)**				**ALL**
	D04		W5721	0022	22		34-51-41	ALL
	D05		W5721	2052R	24		31-65-15	ALL
	D06		W5721	2040R	24		22-11-51	ALL
	D07		W5721	0015	22		22-14-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W5721	1001Z			22-11-11	ALL
	PERS	1A	W5721	2001Z			34-33-11	ALL
	PERS	1A	W5721	2003Z			34-21-13	ALL
	PERS	1A	W5721	2005Z			73-24-11	ALL
	PERS	1A	W5721	2040Z			22-11-51	ALL
	PERS	1A	W5721	2043Z			22-11-51	ALL
	PERS	1A	W5721	2049Z			22-18-11	ALL
	PERS	1A	W5721	2052Z			31-65-15	ALL
	PERS	1A	W5721	2054Z			34-31-11	ALL
D47730P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W0141	2201B	24		73-24-11	ALL
	A03		W0141	2201R	24		73-24-11	ALL
	A04		W0141	2102B	24		34-21-13	ALL
	A05	UNUSED						ALL
	A06		W0141	2025B	24		22-11-51	ALL
	A07		W0141	1012	22		22-11-11	ALL
	A08	UNUSED						ALL
	A09		W0141	0105	22		22-14-11	ALL
	A10	UNUSED						ALL
	B01		W0141	0206	22		34-16-11	ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47730P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0141	2102R	24		34-21-13	ALL
	B06		W0141	2025R	24		22-11-51	ALL
	B07		W0141	0002	22		22-11-11	ALL
	B08	UNUSED						ALL
	B09		W0141	2037B	22		22-18-11	ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0141	2301B	24		34-31-11	ALL
	C03		W0141	2058B	24		34-33-11	ALL
	C04		W0141	0715	22		34-51-41	ALL
	C05		W0141	2362B	24		31-65-15	ALL
	C06		W0141	2026B	24		22-11-51	ALL
	C07		W0141	0729	22		34-51-41	ALL
	C08	UNUSED						ALL
	C09		W0141	2037R	22		22-18-11	ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0141	2301R	24		34-31-11	ALL
	D03		W0141	2058R	24		34-33-11	ALL
	D04		W0141	0716	22		34-51-41	ALL
	D05		W0141	2362R	24		31-65-15	ALL
	D06		W0141	2026R	24		22-11-51	ALL
	D07		W0141	0104	22		22-14-11	ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0141	1012Z			22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47730P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
PERS	1A	W0141	2025Z			22-11-51	ALL
PERS	1A	W0141	2026Z			22-11-51	ALL
PERS	1A	W0141	2058Z			34-33-11	ALL
PERS	1A	W0141	2102Z			34-21-13	ALL
PERS	1A	W0141	2201Z			73-24-11	ALL
PERS	1A	W0141	2301Z			34-31-11	ALL
PERS	1A	W0141	2362Z			31-65-15	ALL
D47731J	**AE0100C/166/R027**		**RCPT - INSERT**				**ALL**
1		W5721	0012	20		SPARE	ALL
2		W5721	0013	20		22-13-11	ALL
3		W5721	0014	20		22-13-11	ALL
4		W5721	0031	22		22-13-11	ALL
5		W5721	0011	20		22-13-11	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W5721	0032	22		30-11-11	ALL
10		W5721	0050	22		34-21-15	ALL
11		W5721	0051	22		34-21-15	ALL
12		W5721	0052	22		34-21-15	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W5721	4501R	20		26-12-11	ALL
19		W5721	4502R	20		26-12-11	ALL
20		W5721	0003	20		22-11-11	ALL
21		W5721	0006	20		22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47731J		**AE0100C/166/R027**		**RCPT - INSERT (continued)**				**ALL**
	22		W5721	0007	20		22-11-12	ALL
	23		W5721	0005	20		22-11-11	ALL
	24		W5721	0004	20		22-11-11	ALL
	25		W5721	0010	20		22-13-11	ALL
	26		W5721	0008	22		22-13-11	ALL
	27		W5721	0009	22		22-13-11	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31		W5721	0026	22		SPARE	ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
D47731P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0141	0101	22		SPARE	ALL
	2		W0141	0102	22		22-13-11	ALL
	3		W0141	0103	22		22-13-11	ALL
	4		W0141	0197	22		22-13-11	ALL
	5		W0141	0100	22		22-13-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0141	0514	22		30-11-11	ALL
	10		W0141	0209	22		34-21-15	ALL
	11		W0141	0210	22		34-21-15	ALL
	12		W0141	0211	22		34-21-15	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47731P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
16	UNUSED						ALL
17	UNUSED						ALL
18		W0141	0436R	20		26-12-11	ALL
19		W0141	0443R	20		26-12-11	ALL
20		W0141	0019	22		22-11-11	ALL
21		W0141	0021	22		22-11-12	ALL
22		W0141	0022	22		22-11-12	ALL
23		W0141	0017	22		22-11-11	ALL
24		W0141	0018	22		22-11-11	ALL
25		W0141	0099	22		22-13-11	ALL
26		W0141	0093	22		22-13-11	ALL
27		W0141	0094	22		22-13-11	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
D47732J	**AE0100C/ /**		**RCPT- INSERT**				**ALL**
1		W5514	0511	24		32-44-11	ALL
2		W5514	0513	24		32-44-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5		W5514	5556	22		34-16-11	ALL
6	UNUSED						ALL
7		W5514	0002	16		35-21-11	ALL
8	UNUSED						ALL
9		W5514	0516	24		32-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47732J		**AE0100C/ /**		**RCPT- INSERT (continued)**				**ALL**
	10		W5514	0517	24		32-44-11	ALL
	11		W5514	0001	22		35-21-11	ALL
	12		W5514	0514	24		32-44-11	ALL
	13		W5514	5572	20		SPARE	ALL
	14		W5514	5594	16		47-30-11	ALL
D47732P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0141	0603	24		32-44-11	ALL
	2		W0141	0604	24		32-44-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0141	0206	22		34-16-11	ALL
	6	UNUSED						ALL
	7		W0141	0654	16		35-21-11	ALL
	8	UNUSED						ALL
	9		W0141	0606	24		32-44-11	ALL
	10		W0141	0605	24		32-44-11	ALL
	11		W0141	0655	22		35-21-11	ALL
	12		W0141	0607	24		32-44-11	ALL
	13	UNUSED						ALL
	14		W0141	0218	16		47-30-11	ALL
D47733J		**AE0100C/ /**		**RCPT- INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W5514	0005	16		35-21-11	ALL
	5		W5514	6002R	22		26-11-21	ALL
	6		W5514	5558	22		23-22-11	ALL
	7		W5514	0004	16		35-21-11	ALL
	8		W5514	5573	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47733J	**AE0100C/ /**		**RCPT- INSERT (continued)**				**ALL**
9		W5514	6003R	22		26-11-21	ALL
10		W5514	6001R	22		26-11-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W5514	5521	20		31-52-11	ALL
14		W5514	0003	16		35-21-11	ALL
D47733P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W0141	0651	16		35-21-11	ALL
5		W0141	0405R	22		26-11-21	ALL
6		W0141	0901	22		23-22-11	ALL
7		W0141	0652	16		35-21-11	ALL
8	UNUSED						ALL
9		W0141	0406R	22		26-11-21	ALL
10		W0141	0408R	22		26-11-21	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W0141	0851	20		31-52-11	ALL
14		W0141	0653	16		35-21-11	ALL
D47735J	**AE0100C/166/R027**		**RCPT- INSERT**				**ALL**
1		W5375	2007B	20		22-11-31	ALL
2		W5375	2007R	20		22-11-31	ALL
3		W5375	2006R	22		22-11-31	ALL
4		W5375	3003Y	22		22-11-31	ALL
5		W5375	3004B	22		22-11-31	ALL
6		W5375	3004R	22		22-11-31	ALL
7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47735J		**AE0100C/166/R027**		**RCPT- INSERT (continued)**				**ALL**
	8		W5375	2003B	22		22-11-31	ALL
	9		W5375	2003R	22		22-11-31	ALL
	10		W5375	2006B	22		22-11-31	ALL
	11		W5375	3003B	22		22-11-31	ALL
	12		W5375	3003R	22		22-11-31	ALL
	13		W5375	3004Y	22		22-11-31	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5375	0009	20		SPARE	ALL
	18		W5375	0010	20		SPARE	ALL
	19		W5375	0011	20		SPARE	ALL
	20		W5375	0007	20		SPARE	ALL
	21	UNUSED						ALL
	22		W5375	3005Y	22		22-12-41	ALL
	23		W5375	0008	20		SPARE	ALL
	24	UNUSED						ALL
	25		W5375	2008R	22		22-11-11	ALL
	26		W5375	2008B	22		22-11-11	ALL
	27		W5375	0020	20		22-11-12	ALL
	28		W5375	0021	20		22-11-12	ALL
	29		W5375	3005B	22		22-12-41	ALL
	30		W5375	3005R	22		22-12-41	ALL
	PERS	1A	W5375	2008Z			22-11-11	ALL
	PERS	1A	W5375	3005Z			22-12-41	ALL
D47735P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0141	0067	22		22-11-31	ALL
	2		W0141	0065	22		22-11-31	ALL
	3		W0141	2015R	22		22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47735P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
4		W0141	3001Y	22		22-11-31	ALL
5		W0141	3002B	22		22-11-31	ALL
6		W0141	3002R	22		22-11-31	ALL
7	UNUSED						ALL
8		W0141	2014B	22		22-11-31	ALL
9		W0141	2014R	22		22-11-31	ALL
10		W0141	2015B	22		22-11-31	ALL
11		W0141	3001B	22		22-11-31	ALL
12		W0141	3001R	22		22-11-31	ALL
13		W0141	3002Y	22		22-11-31	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22		W0141	3003Y	22		22-12-41	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25		W0141	0138	22		22-11-11	ALL
26		W0141	0139	22		22-11-11	ALL
27		W0141	0032	20		22-11-12	ALL
28		W0141	0033	20		22-11-12	ALL
29		W0141	3003B	22		22-12-41	ALL
30		W0141	3003R	22		22-12-41	ALL
PERS	1A	W0141	0065Z			22-11-31	ALL
PERS	1A	W0141	0067Z			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47735P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0141	2014Z			22-11-31	ALL
	PERS	1A	W0141	2015Z			22-11-31	ALL
	PERS	1A	W0141	3001Z			22-11-31	ALL
	PERS	1A	W0141	3002Z			22-11-31	ALL
	PERS	1A	W0141	3003Z			22-12-41	ALL
D47736J		**AE0100C/ /**		**RCPT- INSERT**				**ALL**
	1	UNUSED						ALL
	2		W5158	0502	20		22-11-12	ALL
	3	UNUSED						ALL
	4		W5158	0517	22		34-21-21	ALL
	5		W5158	0544	20		22-11-11	ALL
	6		W5158	0501	20		22-11-12	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W5158	2604B	22		24-33-11	ALL
	10		W5158	2603B	22		24-33-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5158	2604R	22		24-33-11	ALL
	15		W5158	2603R	22		24-33-11	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	DED		W5158	2603Z			24-33-11	ALL
	DED		W5158	2604Z			24-33-11	ALL
D47736P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W0141	0030	22		22-11-12	ALL
	3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47736P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
4		W0141	0215	22		34-21-21	ALL
5		W0141	0016	22		22-11-11	ALL
6		W0141	0029	20		22-11-12	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9		W0141	2253B	22		24-33-11	ALL
10		W0141	2252B	22		24-33-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0141	2253R	22		24-33-11	ALL
15		W0141	2252R	22		24-33-11	ALL
16	UNUSED						ALL
17	UNUSED						ALL
DED		W0141	2252Z			24-33-11	ALL
DED		W0141	2253Z			24-33-11	ALL
D47737J	**AE0100C/166/R027**		**RCPT- INSERT**				**ALL**
1		W5711	0012	20		22-13-11	ALL
2	UNUSED						ALL
3		W5158	0635	20		47-30-11	ALL
4		W5158	6012R	20		26-12-11	ALL
5		W5158	0636	20		47-30-11	ALL
6		W5158	0108	20		28-23-11	ALL
7		W5158	0109	20		28-23-11	ALL
8	UNUSED						ALL
9		W5158	0638	16		47-30-11	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47737J		**AE0100C/166/R027**		**RCPT- INSERT (continued)**				**ALL**
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5158	0609	20		47-30-11	ALL
	18		W5158	0509	22		34-31-21	ALL
	19		W5158	0001	22		35-11-11	ALL
	20		W5158	0003	22		35-11-11	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
D47737P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0149	1001	22		22-13-11	ALL
	2	UNUSED						ALL
	3		W0141	0222	20		47-30-11	ALL
	4		W0141	0422R	20		26-12-11	ALL
	5		W0141	0223	20		47-30-11	ALL
	6		W0141	0231	20		28-23-11	ALL
	7		W0141	0232	20		28-23-11	ALL
	8	UNUSED						ALL
	9		W0141	0227	16		47-30-11	ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W0141	0228	20		47-30-11	ALL
	18		W0141	0706	22		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47737P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
19		W0141	0658	22		35-11-11	ALL
20		W0141	0659	22		35-11-11	ALL
21	UNUSED						ALL
22	UNUSED						ALL
DED		W0149	1001Z			22-13-11	ALL
D47738J	**AE0100C/166/R027**		**RCPT - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W5191	0025	20		23-71-01	ALL
7		W5191	0001	22		23-22-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12		W5191	2004B	24		34-51-21	ALL
13		W5191	2004R	24		34-51-21	ALL
14		W5191	2328B	24		34-51-21	ALL
15		W5191	2328R	24		34-51-21	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W5191	FRAB			34-31-21	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47738J		**AE0100C/166/R027**		**RCPT - INSERT (continued)**				**ALL**
	24	UNUSED						ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28		W5191	2505B	24		34-31-21	ALL
	29		W5191	2505R	24		34-31-21	ALL
	30		W5191	2003B	24		34-51-21	ALL
	31		W5191	2003R	24		34-51-21	ALL
	32		W5191	2517B	22		31-32-15	ALL
	33		W5191	2517R	22		31-32-15	ALL
	34	UNUSED						ALL
			W5191	2004ZI			34-51-21	ALL
			W5191	2505ZI			34-31-21	ALL
			W5191	FRAB			34-31-21	ALL
	PERS	1A	W5191	2003Z			34-51-21	ALL
	PERS	1A	W5191	2004ZO			34-51-21	ALL
	PERS	1A	W5191	2328Z			34-51-21	ALL
	PERS	1A	W5191	2505ZO			34-31-21	ALL
	PERS	1A	W5191	2517Z			31-32-15	ALL
D47738P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0141	0160	20		23-71-01	ALL
	7		W0141	0902	22		23-22-11	ALL
	8	UNUSED						ALL
	9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47738P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
10	UNUSED						ALL
11	UNUSED						ALL
12		W0141	2093B	24		34-51-21	ALL
13		W0141	2093R	24		34-51-21	ALL
14		W0141	2328B	24		34-51-21	ALL
15		W0141	2328R	24		34-51-21	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20		W0141	FRAA			34-31-21	ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28		W0141	2302B	24		34-31-21	ALL
29		W0141	2302R	24		34-31-21	ALL
30		W0141	2092B	24		34-51-21	ALL
31		W0141	2092R	24		34-51-21	ALL
32		W0141	2050B	22		31-32-15	ALL
33		W0141	2050R	22		31-32-15	ALL
34	UNUSED						ALL
		W0141	2093ZI			34-51-21	ALL
		W0141	2302ZI			34-31-21	ALL
		W0141	FRAA			34-31-21	ALL
PERS	1A	W0141	2050Z			31-32-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47738P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0141	2092Z			34-51-21	ALL
	PERS	1A	W0141	2093ZO			34-51-21	ALL
	PERS	1A	W0141	2302ZO			34-31-21	ALL
	PERS	1A	W0141	2328Z			34-51-21	ALL
D47739J		**AE0100C/166/R027**		**RCPT- INSERT**				**ALL**
	1		W5610	6060R	20		26-12-11	ALL
	2		W5610	6061R	20		26-12-11	ALL
	3		W5610	6066R	20		26-12-11	ALL
	4		W5610	6013R	20		26-12-11	ALL
	5		W5610	2007B	24		34-33-21	ALL
	6		W5610	2007R	24		34-33-21	ALL
	7	UNUSED						ALL
	8		W5610	6040R	20		26-12-11	ALL
	9		W5610	6034R	20		26-12-11	ALL
	10		W5610	6035R	20		26-12-11	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W5610	0504	22		49-62-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17		W5610	6055R	20		26-12-11	ALL
	18		W5610	6056R	20		26-12-11	ALL
	19		W5610	6038R	20		26-12-11	ALL
	20		W5610	0593	24		75-11-11	ALL
	21		W5610	6027	20		76-21-11	ALL
	22	UNUSED						ALL
	23		W5610	0519	20		78-34-21	ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47739J	**AE0100C/166/R027**		**RCPT- INSERT (continued)**				**ALL**
25		W5610	6059R	20		26-12-11	ALL
26		W5610	6062R	20		26-12-11	ALL
27		W5610	6041	20		80-11-11	ALL
28		W5610	6043	24		80-11-11	ALL
29	UNUSED						ALL
30	UNUSED						ALL
PERS	1A	W5610	2007Z			34-33-21	ALL
D47739P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1		W0141	0410R	20		26-12-11	ALL
2		W0141	0411R	20		26-12-11	ALL
3		W0141	0470R	20		26-12-11	ALL
4		W0141	0471R	20		26-12-11	ALL
5		W0141	2151B	24		34-33-21	ALL
6		W0141	2151R	24		34-33-21	ALL
7	UNUSED						ALL
8		W0141	0430R	20		26-12-11	ALL
9		W0141	0438R	20		26-12-11	ALL
10		W0141	0439R	20		26-12-11	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W0141	0354	22		49-62-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0141	0444R	20		26-12-11	ALL
18		W0141	0445R	20		26-12-11	ALL
19		W0141	0449R	20		26-12-11	ALL
20		W0141	0241	24		75-11-11	ALL
21		W0141	0454	20		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47739P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	22	UNUSED						ALL
	23		W0141	0467	20		78-34-21	ALL
	24	UNUSED						ALL
	25		W0141	0413R	20		26-12-11	ALL
	26		W0141	0414R	20		26-12-11	ALL
	27		W0141	0462	20		80-11-11	ALL
	28		W0141	0463	24		80-11-11	ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	PERS	1A	W0141	2151Z			34-33-21	ALL
D47740J		**AE0100C/166/R027**		**RCPT- INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W5610	6018R	22		26-11-21	ALL
	A03		W5610	0006	24		31-31-15	ALL
	A04		W5610	0523	24		29-33-11	ALL
	A05		W5610	0512	24		32-42-11	ALL
	A06	UNUSED						ALL
	A07		W5610	0501	22		SPARE	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5610	6019R	22		26-11-21	ALL
	B03		W5610	6042R	22		26-12-11	ALL
	B04		W5610	0591	22		32-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07		W5610	0502	22		SPARE	ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47740J		**AE0100C/166/R027**		**RCPT- INSERT (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W5610	6036R	22		26-11-21	ALL
	C03	UNUSED						ALL
	C04		W5610	0510	24		32-42-11	ALL
	C05	UNUSED						ALL
	C06		W5610	2601B	24		73-24-11	ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W5610	6037R	22		26-11-21	ALL
	D03	UNUSED						ALL
	D04		W5610	0524	24		29-33-11	ALL
	D05	UNUSED						ALL
	D06		W5610	2601R	24		73-24-11	ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W5610	2601Z			73-24-11	ALL
D47740P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W0141	0402R	22		26-11-21	ALL
	A03		W0141	0802R	22		31-31-15	ALL
	A04		W0141	0511	24		29-33-11	ALL
	A05		W0141	0602	24		32-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47740P		**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0141	0404R	22		26-11-21	ALL
	B03		W0141	0424R	22		26-12-11	ALL
	B04		W0141	0611	24		32-41-11	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02		W0141	0407R	22		26-11-21	ALL
	C03	UNUSED						ALL
	C04		W0141	0601	24		32-42-11	ALL
	C05	UNUSED						ALL
	C06		W0141	2201B	24		73-24-11	ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0141	0409R	22		26-11-21	ALL
	D03	UNUSED						ALL
	D04		W0141	0512	24		29-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47740P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
D05	UNUSED						ALL
D06		W0141	2201R	24		73-24-11	ALL
D07	UNUSED						ALL
D08	UNUSED						ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
PERS	1A	W0141	0511Z			29-33-11	ALL
PERS	1A	W0141	0512Z			29-33-11	ALL
PERS	1A	W0141	2201Z			73-24-11	ALL
D47741J	**AE0100C/ /**		**RCPT- INSERT**				**ALL**
1	UNUSED						ALL
2		W5510	0003	16		35-21-11	ALL
3		W5510	0042	20		28-23-11	ALL
4	UNUSED						ALL
5		W5510	0004	16		35-21-11	ALL
6		W5510	0005	16		35-21-11	ALL
7	UNUSED						ALL
8		W5510	0002	16		35-21-11	ALL
9		W5510	0043	20		28-23-11	ALL
D47741P	**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2		W0141	0653	16		35-21-11	ALL
3		W0141	0231	20		28-23-11	ALL
4	UNUSED						ALL
5		W0141	0652	16		35-21-11	ALL
6		W0141	0651	16		35-21-11	ALL
7	UNUSED						ALL
8		W0141	0654	16		35-21-11	ALL
9		W0141	0232	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47742J		**AE0100C/ /**		**RCPT- INSERT**				**ALL**
	1		W5510	2203B	22		24-33-11	ALL
	2		W5510	2203R	22		24-33-11	ALL
	3		W5510	0010	20		23-71-01	ALL
	4		W5510	0051	20		33-25-11	ALL
	5		W5510	6016	22		23-15-15	ALL
	6	UNUSED						ALL
	7		W5510	0052	20		33-25-11	ALL
	8	UNUSED						ALL
	9		W5510	0001	22		35-21-11	ALL
	10		W5510	0006	22		35-21-11	ALL
	11	UNUSED						ALL
	12		W5510	6021	22		30-11-11	ALL
	13	UNUSED						ALL
	14		W5510	0501	18		24-11-11	ALL
	DED		W5510	2203Z			24-33-11	ALL
D47742P		**AE0100C/166/R027**		**PLUG - INSERT**				**ALL**
	1		W0141	2251B	22		24-33-11	ALL
	2		W0141	2251R	22		24-33-11	ALL
	3		W0141	0160	20		23-71-01	ALL
	4		W0141	0244	20		33-25-11	ALL
	5		W0141	0158	22		23-15-15	ALL
	6	UNUSED						ALL
	7		W0141	0245	20		33-25-11	ALL
	8	UNUSED						ALL
	9		W0141	0655	22		35-21-11	ALL
	10		W0141	0656	22		35-21-11	ALL
	11	UNUSED						ALL
	12		W0141	0514	22		30-11-11	ALL
	13	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47742P	**AE0100C/166/R027**		**PLUG - INSERT (continued)**				**ALL**
14		W0141	0301	18		24-11-11	ALL
DED		W0141	2251Z			24-33-11	ALL
D47743J	**AE0100C/ /**		**RCPT- INSERT**				**ALL**
1	UNUSED						ALL
2		W5204	0003	20		47-30-11	ALL
3		W5204	0012R	20		26-12-11	ALL
4		W5204	0011R	20		26-12-11	ALL
5		W5204	0007	20		47-30-11	ALL
6		W5204	0006	20		47-30-11	ALL
7		W5204	0005	20		47-30-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W5204	0009	20		47-30-11	ALL
11		W5204	0008	20		47-30-11	ALL
12		W5204	0004	20		47-30-11	ALL
13		W5204	0002	20		SPARE	ALL
14		W5204	0001	20		47-30-11	ALL
D47743P	**AE0100C/ /**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2		W0141	0220	20		47-30-11	ALL
3		W0141	0448R	20		26-12-11	ALL
4		W0141	0447R	20		26-12-11	ALL
5		W0141	0224	20		47-30-11	ALL
6		W0141	0223	20		47-30-11	ALL
7		W0141	0222	20		47-30-11	ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0141	0226	20		47-30-11	ALL
11		W0141	0225	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47743P		**AE0100C/ /**		**PLUG - INSERT (continued)**				**ALL**
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0141	0229	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47823J		**AE0100B/ /**		**RCPT- INSERT**				**ALL**
	A01		W0523	0390	24		22-11-53	ALL
	A02		W0523	2841B	24		34-21-14	ALL
	A03	UNUSED						ALL
	A04		W0523	2829B	22		31-32-15	ALL
	A05	UNUSED						ALL
	A06		W0523	2760B	24		34-31-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0523	0391	24		22-11-53	ALL
	B02		W0523	2841R	24		34-21-14	ALL
	B03	UNUSED						ALL
	B04		W0523	2829R	22		31-32-15	ALL
	B05	UNUSED						ALL
	B06		W0523	2760R	24		34-31-21	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W0523	2730B	24		34-21-23	ALL
	C04		W0523	2759B	24		34-31-21	ALL
	C05		W0523	2790B	24		34-31-21	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47823J		**AE0100B/ /**		**RCPT- INSERT (continued)**				**ALL**
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0523	2730R	24		34-21-23	ALL
	D04		W0523	2759R	24		34-31-21	ALL
	D05		W0523	2790R	24		34-31-21	ALL
	D06		W0523	0385	22		34-51-41	ALL
	D07	UNUSED						ALL
	D08		W0523	0379	22		22-18-11	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0523	2730Z			34-21-23	ALL
	PERS	1A	W0523	2759Z			34-31-21	ALL
	PERS	1A	W0523	2760Z			34-31-21	ALL
	PERS	1A	W0523	2790Z			34-31-21	ALL
	PERS	1A	W0523	2829Z			31-32-15	ALL
	PERS	1A	W0523	2841Z			34-21-14	ALL
D47823P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	A01		W0141	0308	24		22-11-53	ALL
	A02		W0141	2057B	24		34-21-14	ALL
	A03	UNUSED						ALL
	A04		W0141	2048B	22		31-32-15	ALL
	A05	UNUSED						ALL
	A06		W0141	2312B	24		34-31-21	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0141	0309	24		22-11-53	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47823P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
B02		W0141	2057R	24		34-21-14	ALL
B03	UNUSED						ALL
B04		W0141	2048R	22		31-32-15	ALL
B05	UNUSED						ALL
B06		W0141	2312R	24		34-31-21	ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0141	2103B	24		34-21-23	ALL
C04		W0141	2311B	24		34-31-21	ALL
C05		W0141	2313B	24		34-31-21	ALL
C06	UNUSED						ALL
C07	UNUSED						ALL
C08	UNUSED						ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0141	2103R	24		34-21-23	ALL
D04		W0141	2311R	24		34-31-21	ALL
D05		W0141	2313R	24		34-31-21	ALL
D06		W0141	0720	22		34-51-41	ALL
D07	UNUSED						ALL
D08		W0141	0121	22		22-18-11	ALL
D09	UNUSED						ALL
D10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47823P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0141	2048Z			31-32-15	ALL
	PERS	1A	W0141	2057Z			34-21-14	ALL
	PERS	1A	W0141	2103Z			34-21-23	ALL
	PERS	1A	W0141	2311Z			34-31-21	ALL
	PERS	1A	W0141	2312Z			34-31-21	ALL
	PERS	1A	W0141	2313Z			34-31-21	ALL
D47824J		**AE0100B/172/R028**		**RCPT- INSERT**				**ALL**
	A01		W0523	0319	22		34-61-16	ALL
	A02		W0523	2866B	24		34-58-21	ALL
	A03		W0523	2783B	24		34-58-21	ALL
	A04		W0523	2787B	24		34-58-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0523	0375	24		34-61-26	ALL
	B02		W0523	2866R	24		34-58-21	ALL
	B03		W0523	2783R	24		34-58-21	ALL
	B04		W0523	2787R	24		34-58-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01		W0523	0392	24		22-11-53	ALL
	C02		W0523	2846B	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47824J		**AE0100B/172/R028**		**RCPT- INSERT (continued)**				**ALL**
	C03		W0523	2867B	24		34-58-21	ALL
	C04		W0523	2784B	24		34-58-21	ALL
	C05		W0523	2834B	24		22-11-53	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01		W0523	0393	24		22-11-53	ALL
	D02		W0523	2846R	24		34-21-24	ALL
	D03		W0523	2867R	24		34-58-21	ALL
	D04		W0523	2784R	24		34-58-21	ALL
	D05		W0523	2834R	24		22-11-53	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0523	2783Z			34-58-21	ALL
	PERS	1A	W0523	2784Z			34-58-21	ALL
	PERS	1A	W0523	2787Z			34-58-21	ALL
	PERS	1A	W0523	2834Z			22-11-53	ALL
	PERS	1A	W0523	2846Z			34-21-24	ALL
	PERS	1A	W0523	2866Z			34-58-21	ALL
	PERS	1A	W0523	2867Z			34-58-21	ALL
D47824P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	A01		W0141	0214	22		34-61-16	ALL
	A02		W0141	2095B	24		34-58-21	ALL
	A03		W0141	2501B	24		34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47824P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	A04		W0141	2503B	24		34-58-21	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0141	0307	24		34-61-26	ALL
	B02		W0141	2095R	24		34-58-21	ALL
	B03		W0141	2501R	24		34-58-21	ALL
	B04		W0141	2503R	24		34-58-21	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01		W0141	0310	24		22-11-53	ALL
	C02		W0141	2104B	24		34-21-24	ALL
	C03		W0141	2096B	24		34-58-21	ALL
	C04		W0141	2502B	24		34-58-21	ALL
	C05		W0141	2051B	24		22-11-53	ALL
	C06	UNUSED						ALL
	C07	UNUSED						ALL
	C08	UNUSED						ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01		W0141	0311	24		22-11-53	ALL
	D02		W0141	2104R	24		34-21-24	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47824P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	D03		W0141	2096R	24		34-58-21	ALL
	D04		W0141	2502R	24		34-58-21	ALL
	D05		W0141	2051R	24		22-11-53	ALL
	D06	UNUSED						ALL
	D07	UNUSED						ALL
	D08	UNUSED						ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0141	2051Z			22-11-53	ALL
	PERS	1A	W0141	2095Z			34-58-21	ALL
	PERS	1A	W0141	2096Z			34-58-21	ALL
	PERS	1A	W0141	2104Z			34-21-24	ALL
	PERS	1A	W0141	2501Z			34-58-21	ALL
	PERS	1A	W0141	2502Z			34-58-21	ALL
	PERS	1A	W0141	2503Z			34-58-21	ALL
D47825J		**AE0100B/ /**		**RCPT- INSERT**				**ALL**
	A01		W5463	0061	24		22-11-75	ALL
	A02		W5463	0065	24		22-11-75	ALL
	A03		W5463	0069	24		22-11-75	ALL
	A04		W5463	0073	24		22-11-75	ALL
	A05	UNUSED						ALL
	B01		W5463	0062	24		22-11-75	ALL
	B02		W5463	0066	24		22-11-75	ALL
	B03		W5463	0070	24		22-11-75	ALL
	B04		W5463	0074	24		22-11-75	ALL
	B05	UNUSED						ALL
	C01		W5463	0063	24		22-11-75	ALL
	C02		W5463	0067	24		22-11-75	ALL
	C03		W5463	0071	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47825J		**AE0100B/ /**		**RCPT- INSERT (continued)**				**ALL**
	C04		W5463	0075	24		22-11-75	ALL
	C05	UNUSED						ALL
	D01		W5463	0064	24		22-11-75	ALL
	D02		W5463	0068	24		22-11-75	ALL
	D03		W5463	0072	24		22-11-75	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
D47825P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	A01		W0141	0179	24		22-11-75	ALL
	A02		W0141	0182	24		22-11-75	ALL
	A03		W0141	0188	24		22-11-75	ALL
	A04		W0141	0192	24		22-11-75	ALL
	A05	UNUSED						ALL
	B01		W0141	0180	24		22-11-75	ALL
	B02		W0141	0183	24		22-11-75	ALL
	B03		W0141	0189	24		22-11-75	ALL
	B04		W0141	0193	24		22-11-75	ALL
	B05	UNUSED						ALL
	C01		W0141	0181	24		22-11-75	ALL
	C02		W0141	0186	24		22-11-75	ALL
	C03		W0141	0190	24		22-11-75	ALL
	C04		W0141	0194	24		22-11-75	ALL
	C05	UNUSED						ALL
	D01	UNUSED						ALL
	D02		W0141	0187	24		22-11-75	ALL
	D03		W0141	0191	24		22-11-75	ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47829J	**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
A01		W5463	0030	24		SPARE	ALL
A02		W5463	0010	22		34-51-41	ALL
A03		W5463	0001	22		34-21-21	ALL
A04	UNUSED						ALL
A05		W5463	2004B	24		22-31-52	ALL
A06		W5463	0076	24		22-11-75	ALL
A07		W5463	0047	24		22-11-75	ALL
A08		W5463	0042	24		22-11-75	ALL
A09		W5463	0038	24		22-11-75	ALL
A10		W5463	0034	24		22-11-75	ALL
B01		W5463	0031	24		SPARE	ALL
B02		W5463	0095	22		34-51-41	ALL
B03		W5463	0017	22		34-51-41	ALL
B04	UNUSED						ALL
B05		W5463	2004R	24		22-31-52	ALL
B06		W5463	0077	24		22-11-75	ALL
B07		W5463	0048	24		22-11-75	ALL
B08		W5463	0043	24		22-11-75	ALL
B09		W5463	0039	24		22-11-75	ALL
B10		W5463	0035	24		22-11-75	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W5463	0016	22		34-51-41	ALL
C04		W5463	2018B	24		34-61-14	ALL
C05		W5463	2009B	24		27-32-22	ALL
C06		W5463	0080	24		22-11-75	ALL
C07		W5463	0049	24		22-11-75	ALL
C08		W5463	0044	24		22-11-75	ALL
C09		W5463	0040	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47829J		**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
	C10		W5463	0036	24		22-11-75	ALL
	D01		W5463	0078	24		22-11-75	ALL
	D02	UNUSED						ALL
	D03		W5463	0033	22		SPARE	ALL
	D04		W5463	2018R	24		34-61-14	ALL
	D05		W5463	2009R	24		27-32-22	ALL
	D06		W5463	0023	22		22-13-11	ALL
	D07		W5463	0079	24		22-11-75	ALL
	D08		W5463	0045	24		22-11-75	ALL
	D09		W5463	0041	24		22-11-75	ALL
	D10		W5463	0037	24		22-11-75	ALL
	PERS	1A	W5463	2004Z			22-31-52	ALL
	PERS	1A	W5463	2009Z			27-32-22	ALL
	PERS	1A	W5463	2018Z			34-61-14	ALL
D47829P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W0141	0726	22		34-51-41	ALL
	A03		W0141	0215	22		34-21-21	ALL
	A04	UNUSED						ALL
	A05		W0141	2101B	24		22-31-52	ALL
	A06		W0141	0195	24		22-11-75	ALL
	A07		W0141	0082	24		22-11-75	ALL
	A08		W0141	0077	24		22-11-75	ALL
	A09		W0141	0073	24		22-11-75	ALL
	A10		W0141	0069	24		22-11-75	ALL
	B01	UNUSED						ALL
	B02		W0141	0737	22		34-51-41	ALL
	B03		W0141	0717	22		34-51-41	ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47829P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
B05		W0141	2101R	24		22-31-52	ALL
B06		W0141	0196	24		22-11-75	ALL
B07		W0141	0083	24		22-11-75	ALL
B08		W0141	0078	24		22-11-75	ALL
B09		W0141	0074	24		22-11-75	ALL
B10		W0141	0070	24		22-11-75	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0141	0718	22		34-51-41	ALL
C04		W0141	2105B	24		34-61-14	ALL
C05		W0141	2039B	24		27-32-22	ALL
C06		W0141	0199	24		22-11-75	ALL
C07		W0141	0085	24		22-11-75	ALL
C08		W0141	0079	24		22-11-75	ALL
C09		W0141	0075	24		22-11-75	ALL
C10		W0141	0071	24		22-11-75	ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0141	0719	22		34-51-41	ALL
D04		W0141	2105R	24		34-61-14	ALL
D05		W0141	2039R	24		27-32-22	ALL
D06		W0141	0095	22		22-13-11	ALL
D07		W0141	0131	24		22-11-75	ALL
D08		W0141	0080	24		22-11-75	ALL
D09		W0141	0076	24		22-11-75	ALL
D10		W0141	0072	24		22-11-75	ALL
PERS	1A	W0141	2039Z			27-32-22	ALL
PERS	1A	W0141	2101Z			22-31-52	ALL
PERS	1A	W0141	2105Z			34-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47830J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W5463	0102	20		47-30-11	ALL
	7	UNUSED						ALL
	8		W5463	0050	20		31-52-11	ALL
	9	UNUSED						ALL
	10		W5463	0012	20		22-13-11	ALL
	11		W5463	0011	20		22-13-11	ALL
	12		W5463	0013	20		22-13-11	ALL
	13		W5463	0100	20		47-30-11	ALL
	14		W5463	0101	20		47-30-11	ALL
	15		W5463	0020	22		SPARE	ALL
	16		W5463	0022	22		SPARE	ALL
	17		W5463	0099	20		78-34-11	ALL
	18		W5463	0046	22		22-31-51	ALL
	19		W5463	0009	22		22-31-51	ALL
	20		W5463	0008	22		22-31-51	ALL
	21		W5463	0014	22		22-31-51	ALL
	22		W5463	0103	20		47-30-11	ALL
D47830P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0141	0218	16		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47830P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
7	UNUSED						ALL
8		W0141	0851	20		31-52-11	ALL
9	UNUSED						ALL
10		W0141	0235	20		22-13-11	ALL
11		W0141	0234	20		22-13-11	ALL
12		W0141	0237	20		22-13-11	ALL
13		W0141	0228	20		47-30-11	ALL
14		W0141	0229	20		47-30-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17		W0141	0357	22		78-34-11	ALL
18		W0141	0243	22		22-31-51	ALL
19		W0141	0204	22		22-31-51	ALL
20		W0141	0203	22		22-31-51	ALL
21		W0141	0202	22		22-31-51	ALL
22		W0141	0220	20		47-30-11	ALL
D47831J	**AE0100B/ /**		**RCPT- INSERT**				**ALL**
1		W2510	0530R	20		26-12-11	ALL
2		W2510	0523R	20		26-12-11	ALL
3		W2510	0509	22		49-62-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W2510	2202R	22		24-33-11	ALL
9	UNUSED						ALL
10		W2510	2203R	22		24-33-11	ALL
11	UNUSED						ALL
12		W2510	2204R	22		24-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47831J		**AE0100B/ /**		**RCPT- INSERT (continued)**				**ALL**
	13		W2510	2202B	22		24-33-11	ALL
	14	UNUSED						ALL
	15		W2510	2203B	22		24-33-11	ALL
	16	UNUSED						ALL
	17		W2510	2204B	22		24-33-11	ALL
	DED		W2510	2202Z			24-33-11	ALL
	DED		W2510	2203Z			24-33-11	ALL
	DED		W2510	2204Z			24-33-11	ALL
D47831P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0437R	20		26-12-11	ALL
	2		W0141	0446R	20		26-12-11	ALL
	3		W0141	0354	22		49-62-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0141	2251R	22		24-33-11	ALL
	9	UNUSED						ALL
	10		W0141	2252R	22		24-33-11	ALL
	11	UNUSED						ALL
	12		W0141	2253R	22		24-33-11	ALL
	13		W0141	2251B	22		24-33-11	ALL
	14	UNUSED						ALL
	15		W0141	2252B	22		24-33-11	ALL
	16	UNUSED						ALL
	17		W0141	2253B	22		24-33-11	ALL
	DED		W0141	2251Z			24-33-11	ALL
	DED		W0141	2252Z			24-33-11	ALL
	DED		W0141	2253Z			24-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47832J	**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
1-1		W2043	4006Y	24		46-13-11	ALL
1-2		W2043	4006R	24		46-13-11	ALL
1-3		W2043	4006G	24		46-13-11	ALL
1-4	J5	W2043	4006B	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
=C1		W2043	4006Z			46-13-11	ALL
=C2	UNUSED						ALL
=C3	UNUSED						ALL
D47832P	**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
1-1		W0141	4001Y	24		46-13-11	ALL
1-2		W0141	4001R	24		46-13-11	ALL
1-3		W0141	4001G	24		46-13-11	ALL
1-4	J8	W0141	4001B	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
=C1		W0141	4001Z			46-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47832P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	=C2	UNUSED						ALL
	=C3	UNUSED						ALL
D47833J		**AE0100B/ /**		**RCPT- INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W2251	0006	22		22-14-11	ALL
	4		W2251	0004	22		22-14-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W2251	0011	22		22-14-11	ALL
	8		W2251	0001	22		22-13-11	ALL
	9	UNUSED						ALL
	10		W2251	0010	22		34-61-16	ALL
	11		W2251	2001B	24		31-65-22	ALL
	12		W2251	0005	22		22-14-11	ALL
	13		W2251	0002	22		22-14-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W2251	2001R	24		31-65-22	ALL
	17		W2251	0008	22		22-31-51	ALL
	PERS	1A	W2251	2001Z			31-65-22	ALL
D47833P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3		W0141	0115	20		22-14-11	ALL
	4		W0141	0112	22		22-14-11	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W0141	0114	22		22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47833P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
8		W0141	0096	22		22-13-11	ALL
9	UNUSED						ALL
10		W0141	0214	22		34-61-16	ALL
11		W0141	2361B	24		31-65-22	ALL
12		W0141	0113	22		22-14-11	ALL
13		W0141	0116	22		22-14-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W0141	2361R	24		31-65-22	ALL
17		W0141	0204	22		22-31-51	ALL
PERS	1A	W0141	2361Z			31-65-22	ALL
D47834J	**AE0100B/ /**		**RCPT- INSERT**				**ALL**
1		W2103	0004	20		22-18-11	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4		W2103	0011R	22		26-12-11	ALL
5		W2103	0008	20		34-53-21	ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13		W2103	0001	22		34-31-21	ALL
14		W2103	0009	22		34-55-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47834P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0119	20		22-18-11	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4		W0141	0415R	22		26-12-11	ALL
	5		W0141	0552	20		34-53-21	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13		W0141	0702	22		34-31-21	ALL
	14		W0141	0553	22		34-55-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D47835J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W5723	0041	20		78-34-21	ALL
	6	UNUSED						ALL
	7		W5723	0045	22		22-14-11	ALL
	8		W5723	0046	20		22-14-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W5723	2049B	24		73-24-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47835J	**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
12		W5723	2049R	24		73-24-21	ALL
13		W5723	2020B	22		34-53-21	ALL
14		W5723	2020R	22		34-53-21	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W5723	0031	22		34-55-21	ALL
25		W5723	0032	20		34-53-21	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W5723	2122B	24		34-58-21	ALL
30		W5723	2122R	24		34-58-21	ALL
31		W5723	2136B	24		34-31-21	ALL
32		W5723	2136R	24		34-31-21	ALL
33		W5723	2135B	24		34-31-21	ALL
34		W5723	2135R	24		34-31-21	ALL
PERS	1A	W5723	2020Z			34-53-21	ALL
PERS	1A	W5723	2049Z			73-24-21	ALL
PERS	1A	W5723	2122Z			34-58-21	ALL
PERS	1A	W5723	2135Z			34-31-21	ALL
PERS	1A	W5723	2136Z			34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47835P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5		W0141	0358	20		78-34-21	ALL
	6	UNUSED						ALL
	7		W0141	0107	22		22-14-11	ALL
	8		W0141	0108	20		22-14-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0141	2203B	24		73-24-21	ALL
	12		W0141	2203R	24		73-24-21	ALL
	13		W0141	2063B	22		34-58-21	ALL
	14		W0141	2063R	22		34-58-21	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W0141	0553	22		34-55-21	ALL
	25		W0141	0552	20		34-53-21	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0141	2043B	24		34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47835P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
30		W0141	2043R	24		34-58-21	ALL
31		W0141	2308B	24		34-31-21	ALL
32		W0141	2308R	24		34-31-21	ALL
33		W0141	2305B	24		34-31-21	ALL
34		W0141	2305R	24		34-31-21	ALL
PERS	1A	W0141	2043Z			34-58-21	ALL
PERS	1A	W0141	2063Z			34-58-21	ALL
PERS	1A	W0141	2203Z			73-24-21	ALL
PERS	1A	W0141	2305Z			34-31-21	ALL
PERS	1A	W0141	2308Z			34-31-21	ALL
D47836J	**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
1		W5723	0034	20		22-11-12	ALL
2		W5723	2130R	22		22-18-11	ALL
3		W5723	0147	20		22-11-11	ALL
4		W5723	1104	20		22-11-11	ALL
5		W5723	0148	20		22-11-11	ALL
6		W5723	0144	20		22-11-11	ALL
7		W5723	0145	20		22-11-11	ALL
8		W5723	0146	20		22-11-11	ALL
9		W5723	0140	22		22-11-18	ALL
10		W5723	2130B	22		22-18-11	ALL
11		W5723	0127	22		22-18-11	ALL
12		W5723	0126	22		22-18-11	ALL
13		W5723	0043	22		22-13-11	ALL
14		W5723	0042	22		22-13-11	ALL
15		W5723	0128	22		22-18-11	ALL
16		W5723	0055	22		22-11-11	ALL
17		W5723	0129	22		22-18-11	ALL
18		W5723	0125	20		22-18-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47836J		**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
	19		W5723	0103	20		SPARE	ALL
	20		W5723	0102	20		SPARE	ALL
	21		W5723	0101	20		32-64-21	ALL
	22		W5723	0064	22		32-64-21	ALL
	23		W5723	0106	20		22-11-12	ALL
	24		W5723	0107	20		22-11-12	ALL
	25		W5723	0108	20		22-11-12	ALL
	26		W5723	2040B	24		SPARE	ALL
	27		W5723	2040R	24		SPARE	ALL
	28	UNUSED						ALL
	29		W5723	2116B	22		22-11-51	ALL
	30		W5723	2116R	22		22-11-51	ALL
	31		W5723	2113B	22		22-11-51	ALL
	32		W5723	2113R	22		22-11-51	ALL
	33	UNUSED						ALL
	34		W5723	0133	22		22-18-11	ALL
	PERS	1A	W5723	1104Z			22-11-11	ALL
	PERS	1A	W5723	2040Z			SPARE	ALL
	PERS	1A	W5723	2113Z			22-11-51	ALL
	PERS	1A	W5723	2116Z			22-11-51	ALL
	PERS	1A	W5723	2130Z			22-18-11	ALL
D47836P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0031	22		22-11-12	ALL
	2		W0141	2038R	22		22-18-11	ALL
	3		W0141	0140	22		22-11-11	ALL
	4		W0141	1011	22		22-11-11	ALL
	5		W0141	0007	22		22-11-11	ALL
	6		W0141	0003	20		22-11-11	ALL
	7		W0141	0004	20		22-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47836P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
8		W0141	0005	20		22-11-11	ALL
9		W0141	0060	22		22-11-18	ALL
10		W0141	2038B	22		22-18-11	ALL
11		W0141	0126	22		22-18-11	ALL
12		W0141	0125	22		22-18-11	ALL
13		W0141	0098	22		22-13-11	ALL
14		W0141	0097	22		22-13-11	ALL
15		W0141	0127	22		22-18-11	ALL
16		W0141	0050	22		22-11-11	ALL
17		W0141	0128	22		22-18-11	ALL
18		W0141	0124	20		22-18-11	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W0141	0152	22		32-64-21	ALL
22		W0141	0612	22		32-64-21	ALL
23		W0141	0034	20		22-11-12	ALL
24		W0141	0036	20		22-11-12	ALL
25		W0141	0037	20		22-11-12	ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29		W0141	2027B	24		22-11-51	ALL
30		W0141	2027R	24		22-11-51	ALL
31		W0141	2028B	24		22-11-51	ALL
32		W0141	2028R	24		22-11-51	ALL
33	UNUSED						ALL
34		W0141	0129	22		22-18-11	ALL
PERS	1A	W0141	1011Z			22-11-11	ALL
PERS	1A	W0141	2027Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47836P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0141	2028Z			22-11-51	ALL
D47837J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	A01		W5121	2026B	24		73-24-21	ALL
	A02		W5121	2024B	24		SPARE	ALL
	A03		W5121	2703B	24		34-58-21	ALL
	A04		W5121	0003	22		34-51-41	ALL
	A05		W5121	2023B	24		SPARE	ALL
	A06		W5121	2001B	24		34-31-21	ALL
	A07		W5121	2774B	24		31-65-25	ALL
	A08	UNUSED						ALL
	A09		W5121	2022B	24		SPARE	ALL
	A10		W5121	0015	24		22-11-14	ALL
	B01		W5121	2026R	24		73-24-21	ALL
	B02		W5121	2024R	24		SPARE	ALL
	B03		W5121	2703R	24		34-58-21	ALL
	B04		W5121	0030	22		34-51-41	ALL
	B05		W5121	2023R	24		SPARE	ALL
	B06		W5121	2001R	24		34-31-21	ALL
	B07		W5121	2774R	24		31-65-25	ALL
	B08	UNUSED						ALL
	B09		W5121	2022R	24		SPARE	ALL
	B10		W5121	0501	22		22-11-18	ALL
	C01	UNUSED						ALL
	C02		W5121	0029	24		31-65-41	ALL
	C03		W5121	2704B	24		34-58-21	ALL
	C04		W5121	0010	22		SPARE	ALL
	C05		W5121	2016B	24		34-55-21	ALL
	C06		W5121	2003B	24		34-31-21	ALL
	C07		W5121	2013B	24		31-65-25	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47837J	**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
C08		W5121	2008B	24		31-65-22	ALL
C09	UNUSED						ALL
C10		W5121	0018	22		22-11-18	ALL
D01	UNUSED						ALL
D02		W5121	0011	22		SPARE	ALL
D03		W5121	2704R	24		34-58-21	ALL
D04	UNUSED						ALL
D05		W5121	2016R	24		34-55-21	ALL
D06		W5121	2003R	24		34-31-21	ALL
D07		W5121	2013R	24		31-65-25	ALL
D08		W5121	2008R	24		31-65-22	ALL
D09	UNUSED						ALL
D10	UNUSED						ALL
PERS	1A	W5121	2001Z			34-31-21	ALL
PERS	1A	W5121	2003Z			34-31-21	ALL
PERS	1A	W5121	2008Z			31-65-22	ALL
PERS	1A	W5121	2013Z			31-65-25	ALL
PERS	1A	W5121	2016Z			34-55-21	ALL
PERS	1A	W5121	2022Z			SPARE	ALL
PERS	1A	W5121	2023Z			SPARE	ALL
PERS	1A	W5121	2024Z			SPARE	ALL
PERS	1A	W5121	2026Z			73-24-21	ALL
PERS	1A	W5121	2703Z			34-58-21	ALL
PERS	1A	W5121	2704Z			34-58-21	ALL
PERS	1A	W5121	2774Z			31-65-25	ALL
D47837P	**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
A01		W0141	2203B	24		73-24-21	ALL
A02	UNUSED						ALL
A03		W0141	2086B	24		34-58-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47837P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	A04		W0141	0725	22		34-51-41	ALL
	A05	UNUSED						ALL
	A06		W0141	2309B	24		34-31-21	ALL
	A07		W0141	2094B	24		31-65-25	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0141	0045	24		22-11-14	ALL
	B01		W0141	2203R	24		73-24-21	ALL
	B02	UNUSED						ALL
	B03		W0141	2086R	24		34-58-21	ALL
	B04		W0141	0728	22		34-51-41	ALL
	B05	UNUSED						ALL
	B06		W0141	2309R	24		34-31-21	ALL
	B07		W0141	2094R	24		31-65-25	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0141	0061	22		22-11-18	ALL
	C01	UNUSED						ALL
	C02		W0141	0162	24		31-65-41	ALL
	C03		W0141	2087B	24		34-58-21	ALL
	C04	UNUSED						ALL
	C05		W0141	2152B	24		34-55-21	ALL
	C06		W0141	2310B	24		34-31-21	ALL
	C07		W0141	2363B	24		31-65-25	ALL
	C08		W0141	2361B	24		31-65-22	ALL
	C09	UNUSED						ALL
	C10		W0141	0063	22		22-11-18	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47837P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	D03		W0141	2087R	24		34-58-21	ALL
	D04	UNUSED						ALL
	D05		W0141	2152R	24		34-55-21	ALL
	D06		W0141	2310R	24		34-31-21	ALL
	D07		W0141	2363R	24		31-65-25	ALL
	D08		W0141	2361R	24		31-65-22	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0141	2086Z			34-58-21	ALL
	PERS	1A	W0141	2087Z			34-58-21	ALL
	PERS	1A	W0141	2094Z			31-65-25	ALL
	PERS	1A	W0141	2152Z			34-55-21	ALL
	PERS	1A	W0141	2203Z			73-24-21	ALL
	PERS	1A	W0141	2309Z			34-31-21	ALL
	PERS	1A	W0141	2310Z			34-31-21	ALL
	PERS	1A	W0141	2361Z			31-65-22	ALL
	PERS	1A	W0141	2363Z			31-65-25	ALL
D47838J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W5121	2117B	22		22-11-51	ALL
	A03		W5121	2032B	24		22-11-51	ALL
	A04		W5121	2030B	24		22-11-51	ALL
	A05		W5121	2037B	24		22-11-51	ALL
	A06	UNUSED						ALL
	A07		W5121	2039B	24		34-31-21	ALL
	A08		W5121	2751B	24		22-11-51	ALL
	A09	UNUSED						ALL
	A10		W5121	1702	22		22-11-31	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47838J		**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
	B02		W5121	2117R	22		22-11-51	ALL
	B03		W5121	2032R	24		22-11-51	ALL
	B04		W5121	2030R	24		22-11-51	ALL
	B05		W5121	2037R	24		22-11-51	ALL
	B06	UNUSED						ALL
	B07		W5121	2039R	24		34-31-21	ALL
	B08		W5121	2751R	24		22-11-51	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W5121	2009B	24		22-11-51	ALL
	C04		W5121	2031B	24		22-11-51	ALL
	C05		W5121	2029B	24		22-11-51	ALL
	C06	UNUSED						ALL
	C07		W5121	2511B	24		34-58-21	ALL
	C08		W5121	2752B	24		22-11-51	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W5121	2009R	24		22-11-51	ALL
	D04		W5121	2031R	24		22-11-51	ALL
	D05		W5121	2029R	24		22-11-51	ALL
	D06	UNUSED						ALL
	D07		W5121	2511R	24		34-58-21	ALL
	D08		W5121	2752R	24		22-11-51	ALL
	D09	UNUSED						ALL
	D10		W5121	0005	24		31-31-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47838J		**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
	PERS	1A	W5121	2009Z			22-11-51	ALL
	PERS	1A	W5121	2029Z			22-11-51	ALL
	PERS	1A	W5121	2030Z			22-11-51	ALL
	PERS	1A	W5121	2031Z			22-11-51	ALL
	PERS	1A	W5121	2032Z			22-11-51	ALL
	PERS	1A	W5121	2037Z			22-11-51	ALL
	PERS	1A	W5121	2039Z			34-31-21	ALL
	PERS	1A	W5121	2117Z			22-11-51	ALL
	PERS	1A	W5121	2511Z			34-58-21	ALL
	PERS	1A	W5121	2751Z			22-11-51	ALL
	PERS	1A	W5121	2752Z			22-11-51	ALL
D47838P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W0141	2074B	24		22-11-51	ALL
	A03		W0141	2022B	24		22-11-51	ALL
	A04		W0141	2020B	24		22-11-51	ALL
	A05		W0141	2018B	24		22-11-51	ALL
	A06	UNUSED						ALL
	A07		W0141	2303B	24		34-31-21	ALL
	A08		W0141	2084B	24		22-11-51	ALL
	A09	UNUSED						ALL
	A10		W0141	0242	22		22-11-31	ALL
	B01	UNUSED						ALL
	B02		W0141	2074R	24		22-11-51	ALL
	B03		W0141	2022R	24		22-11-51	ALL
	B04		W0141	2020R	24		22-11-51	ALL
	B05		W0141	2018R	24		22-11-51	ALL
	B06	UNUSED						ALL
	B07		W0141	2303R	24		34-31-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47838P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	B08		W0141	2084R	24		22-11-51	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W0141	2040B	24		22-11-51	ALL
	C04		W0141	2021B	24		22-11-51	ALL
	C05		W0141	2019B	24		22-11-51	ALL
	C06	UNUSED						ALL
	C07		W0141	2083B	24		34-58-21	ALL
	C08		W0141	2085B	24		22-11-51	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W0141	2040R	24		22-11-51	ALL
	D04		W0141	2021R	24		22-11-51	ALL
	D05		W0141	2019R	24		22-11-51	ALL
	D06	UNUSED						ALL
	D07		W0141	2083R	24		34-58-21	ALL
	D08		W0141	2085R	24		22-11-51	ALL
	D09	UNUSED						ALL
	D10		W0141	0801	24		31-31-15	ALL
	PERS	1A	W0141	2018Z			22-11-51	ALL
	PERS	1A	W0141	2019Z			22-11-51	ALL
	PERS	1A	W0141	2020Z			22-11-51	ALL
	PERS	1A	W0141	2021Z			22-11-51	ALL
	PERS	1A	W0141	2022Z			22-11-51	ALL
	PERS	1A	W0141	2040Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47838P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
PERS	1A	W0141	2074Z			22-11-51	ALL
PERS	1A	W0141	2083Z			34-58-21	ALL
PERS	1A	W0141	2084Z			22-11-51	ALL
PERS	1A	W0141	2085Z			22-11-51	ALL
PERS	1A	W0141	2303Z			34-31-21	ALL
D47839J	**AE0100B/172/R028**		**RCPT- INSERT**				**ALL**
1		W2383	0048	18		33-25-11	ALL
2		W2383	0049	18		33-25-11	ALL
3	UNUSED						ALL
4		W2383	0038	18		SPARE	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W2383	0026	22		SPARE	ALL
8		W2383	0024	20		SPARE	ALL
9		W2383	0009	24		SPARE	ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2383	0004	20		22-11-12	ALL
16		W2383	0012	20		22-11-12	ALL
17		W2383	0013	20		22-11-11	ALL
18		W2383	0025	20		22-11-12	ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47839P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0244	20		33-25-11	ALL
	2		W0141	0245	20		33-25-11	ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0141	0024	20		22-11-12	ALL
	16		W0141	0023	20		22-11-12	ALL
	17		W0141	0053	20		22-11-11	ALL
	18		W0141	0034	20		22-11-12	ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
D47840J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	1		W2465	1045	22		22-11-11	ALL
	2		W2465	1043	22		22-11-11	ALL
	3		W2465	1037	22		22-11-11	ALL
	4		W2465	1034	22		22-11-11	ALL
	5		W2465	1023	22		22-11-11	ALL
	6		W2465	2018B	22		22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47840J	**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
7	UNUSED						ALL
8		W2465	1003	20		22-11-12	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W2465	2018R	22		22-11-51	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W2465	2052B	22		22-11-11	ALL
22		W2465	2033B	22		22-11-51	ALL
23		W2465	1039	20		22-11-12	ALL
24		W2465	1054	20		22-11-12	ALL
25		W2465	1002	22		22-11-75	ALL
26		W2465	1022	22		22-14-11	ALL
27		W2465	1025	22		22-14-11	ALL
28		W2465	2052R	22		22-11-11	ALL
29		W2465	2033R	22		22-11-51	ALL
30	UNUSED						ALL
PERS	1A	W2465	1002Z			22-11-75	ALL
PERS	1A	W2465	1003Z			22-11-12	ALL
PERS	1A	W2465	1022Z			22-14-11	ALL
PERS	1A	W2465	1023Z			22-11-11	ALL
PERS	1A	W2465	1025Z			22-14-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47840J		**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
	PERS	1A	W2465	1034Z			22-11-11	ALL
	PERS	1A	W2465	1037Z			22-11-11	ALL
	PERS	1A	W2465	1039Z			22-11-12	ALL
	PERS	1A	W2465	1043Z			22-11-11	ALL
	PERS	1A	W2465	1045Z			22-11-11	ALL
	PERS	1A	W2465	1054Z			22-11-12	ALL
	PERS	1A	W2465	2018Z			22-11-51	ALL
	PERS	1A	W2465	2033Z			22-11-51	ALL
	PERS	1A	W2465	2052Z			22-11-11	ALL
D47840P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0009	22		22-11-11	ALL
	2		W0141	0012	22		22-11-11	ALL
	3		W0141	0010	22		22-11-11	ALL
	4		W0141	0008	22		22-11-11	ALL
	5		W0141	0014	22		22-11-11	ALL
	6		W0141	2017B	24		22-11-51	ALL
	7	UNUSED						ALL
	8		W0141	0025	20		22-11-12	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0141	2017R	24		22-11-51	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47840P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
20	UNUSED						ALL
21		W0141	2001B	22		22-11-11	ALL
22		W0141	2016B	24		22-11-51	ALL
23		W0141	0026	20		22-11-12	ALL
24		W0141	0141	20		22-11-12	ALL
25		W0141	0199	24		22-11-75	ALL
26		W0141	0117	22		22-14-11	ALL
27		W0141	0116	22		22-14-11	ALL
28		W0141	2001R	22		22-11-11	ALL
29		W0141	2016R	24		22-11-51	ALL
30	UNUSED						ALL
PERS	1A	W0141	2001Z			22-11-11	ALL
PERS	1A	W0141	2016Z			22-11-51	ALL
PERS	1A	W0141	2017Z			22-11-51	ALL
D47841J	**AE0100B/ /**		**RCPT - INSERT**				**ALL**
1		W5457	0007	20		22-13-11	ALL
2		W5457	0008	20		22-13-11	ALL
3		W5457	0009	20		22-13-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W5457	0105	22		22-31-51	ALL
9		W5457	0106	22		22-31-51	ALL
10		W5457	0108	22		22-31-51	ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47841J		**AE0100B/ /**		**RCPT - INSERT (continued)**				**ALL**
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D47841P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0234	20		22-13-11	ALL
	2		W0141	0235	20		22-13-11	ALL
	3		W0141	0236	20		22-13-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W0141	0202	22		22-31-51	ALL
	9		W0141	0203	22		22-31-51	ALL
	10		W0141	0243	22		22-31-51	ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
D47842J		**AE0100B/172/R028**		**RCPT - INSERT**				**ALL**
	1		W5457	0011	20		22-11-12	ALL
	2		W5457	0103	20		22-11-12	ALL
	3		W5457	0005	22		22-11-14	ALL
	4		W5457	0006	22		22-11-14	ALL
	5		W5457	2014B	22		22-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47842J	**AE0100B/172/R028**		**RCPT - INSERT (continued)**				**ALL**
8	UNUSED						ALL
9		W5457	2020B	22		22-12-41	ALL
10		W5457	2020R	22		22-12-41	ALL
11		W5457	2009B	22		22-12-41	ALL
12		W5457	2009R	22		22-12-41	ALL
13		W5457	2007R	22		22-11-11	ALL
14		W5457	2014R	22		22-11-11	ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21		W5457	2018R	22		22-11-11	ALL
22		W5457	2018B	22		22-11-11	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26		W5457	2016B	22		22-11-31	ALL
27		W5457	2016R	22		22-11-31	ALL
28	UNUSED						ALL
29	UNUSED						ALL
30		W5457	2007B	22		22-11-11	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
DED		W5457	2016Z			22-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47842P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1		W0141	0027	20		22-11-12	ALL
	2		W0141	0028	22		22-11-12	ALL
	3		W0141	0047	22		22-11-14	ALL
	4		W0141	0048	22		22-11-14	ALL
	5		W0141	0135	22		22-11-11	ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9		W0141	2031B	22		22-12-41	ALL
	10		W0141	2031R	22		22-12-41	ALL
	11		W0141	2032B	22		22-12-41	ALL
	12		W0141	2032R	22		22-12-41	ALL
	13		W0141	0136	22		22-11-11	ALL
	14		W0141	0134	22		22-11-11	ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21		W0141	0132	22		22-11-11	ALL
	22		W0141	0133	22		22-11-11	ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0141	2008B	22		22-11-31	ALL
	27		W0141	2008R	22		22-11-31	ALL
	28	UNUSED						ALL
	29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47842P	**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
30		W0141	0137	22		22-11-11	ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
DED		W0141	2008Z			22-11-31	ALL
D47843J	**AE0100B/ /**		**RCPT - INSERT**				**ALL**
1		W2465	1016	20		22-12-41	ALL
2	UNUSED						ALL
3		W2465	1004	20		22-11-31	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16		W2465	1020	22		22-14-11	ALL
17	UNUSED						ALL
PERS	1A	W2465	1004Z			22-11-31	ALL
PERS	1A	W2465	1016Z			22-12-41	ALL
PERS	1A	W2465	1020Z			22-14-11	ALL
D47843P	**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
1		W0141	0092	20		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47843P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	2	UNUSED						ALL
	3		W0141	0068	20		22-11-31	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16		W0141	0161	22		22-14-11	ALL
	17	UNUSED						ALL
	PERS	1A	W0141	0068Z			22-11-31	ALL
	PERS	1A	W0141	0092Z			22-12-41	ALL
D47844J		**AE0100B/172/R028**		**INSERT**				**ALL**
	1	UNUSED						ALL
	2		W3379	2007B	22		22-12-41	ALL
	3		W3379	2005B	20		22-12-41	ALL
	4		W3379	2017B	22		22-12-41	ALL
	5		W3379	3003B	22		22-12-41	ALL
	6		W3379	1001	20		22-12-41	ALL
	7	UNUSED						ALL
	8		W3379	1002	20		22-12-41	ALL
	9		W3379	2007R	22		22-12-41	ALL
	10		W3379	2005R	20		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47844J	**AE0100B/172/R028**		**INSERT (continued)**				**ALL**
11		W3379	2017R	22		22-12-41	ALL
12		W3379	3003R	22		22-12-41	ALL
13		W3379	3003Y	22		22-12-41	ALL
14	UNUSED						ALL
15		W3379	0011	20		22-11-12	ALL
16		W3379	2002B	22		22-12-41	ALL
17		W3379	2004B	22		22-12-41	ALL
18		W3379	2003B	22		22-12-41	ALL
19		W3379	2006B	22		22-12-41	ALL
20		W3379	3001Y	22		22-12-41	ALL
21		W3379	3001R	22		22-12-41	ALL
22	UNUSED						ALL
23	UNUSED						ALL
24		W3379	2002R	22		22-12-41	ALL
25		W3379	2004R	22		22-12-41	ALL
26		W3379	2003R	22		22-12-41	ALL
27		W3379	2006R	22		22-12-41	ALL
28		W3379	3001B	22		22-12-41	ALL
29	UNUSED						ALL
30		W3379	0012	20		22-11-12	ALL
PERS	1A	W3379	1001Z			22-12-41	ALL
PERS	1A	W3379	1002Z			22-12-41	ALL
PERS	1A	W3379	2002Z			22-12-41	ALL
PERS	1A	W3379	2003Z			22-12-41	ALL
PERS	1A	W3379	2004Z			22-12-41	ALL
PERS	1A	W3379	2005Z			22-12-41	ALL
PERS	1A	W3379	2006Z			22-12-41	ALL
PERS	1A	W3379	2007Z			22-12-41	ALL
PERS	1A	W3379	2017Z			22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47844J		**AE0100B/172/R028**		**INSERT (continued)**				**ALL**
	PERS	1A	W3379	3001Z			22-12-41	ALL
	PERS	1A	W3379	3003Z			22-12-41	ALL
D47844P		**AE0100B/172/R028**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W0141	2036B	22		22-12-41	ALL
	3		W0141	2035B	22		22-12-41	ALL
	4		W0141	2033B	22		22-12-41	ALL
	5		W0141	3004B	22		22-12-41	ALL
	6		W0141	0089	22		22-12-41	ALL
	7	UNUSED						ALL
	8		W0141	0091	20		22-12-41	ALL
	9		W0141	2036R	22		22-12-41	ALL
	10		W0141	2035R	22		22-12-41	ALL
	11		W0141	2033R	22		22-12-41	ALL
	12		W0141	3004R	22		22-12-41	ALL
	13		W0141	3004Y	22		22-12-41	ALL
	14	UNUSED						ALL
	15		W0141	0039	20		22-11-12	ALL
	16		W0141	2059B	22		22-12-41	ALL
	17		W0141	2097B	22		22-12-41	ALL
	18		W0141	2098B	22		22-12-41	ALL
	19		W0141	2099B	22		22-12-41	ALL
	20		W0141	3005Y	22		22-12-41	ALL
	21		W0141	3005R	22		22-12-41	ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24		W0141	2059R	22		22-12-41	ALL
	25		W0141	2097R	22		22-12-41	ALL
	26		W0141	2098R	22		22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47844P		**AE0100B/172/R028**		**PLUG - INSERT (continued)**				**ALL**
	27		W0141	2099R	22		22-12-41	ALL
	28		W0141	3005B	22		22-12-41	ALL
	29	UNUSED						ALL
	30		W0141	0040	20		22-11-12	ALL
	PERS	1A	W0141	0089Z			22-12-41	ALL
	PERS	1A	W0141	0091Z			22-12-41	ALL
	PERS	1A	W0141	2033Z			22-12-41	ALL
	PERS	1A	W0141	2035Z			22-12-41	ALL
	PERS	1A	W0141	2036Z			22-12-41	ALL
	PERS	1A	W0141	2059Z			22-12-41	ALL
	PERS	1A	W0141	2097Z			22-12-41	ALL
	PERS	1A	W0141	2098Z			22-12-41	ALL
	PERS	1A	W0141	2099Z			22-12-41	ALL
	PERS	1A	W0141	3004Z			22-12-41	ALL
	PERS	1A	W0141	3005Z			22-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47901J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DH	W3143	001CX			34-31-21	ALL
	=C1		W3143	001CO			34-31-21	ALL
D47901P		**AE0100A/ /**		**PLUG - INSERT**				**ALL**
	A1	DQ	W0141	005CX			34-31-21	ALL
	=C1		W0141	005CO			34-31-21	ALL
D47902J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DH	W3609	001CX			34-58-21	ALL
	=C1		W3609	001CO			34-58-21	ALL
D47902P		**AE0100A/ /**		**PLUG - INSERT**				**ALL**
	A1	DQ	W0141	004CX			34-58-21	ALL
	=C1		W0141	004CO			34-58-21	ALL
D47908J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DH	W3141	001CX			34-31-11	ALL
	=C1		W3141	001CO			34-31-11	ALL
D47908P		**AE0100A/ /**		**PLUG - INSERT**				**ALL**
	A1	DQ	W0121	008CX			34-31-11	ALL
	=C1		W0121	008CO			34-31-11	ALL
D47916J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DJ	W5039	001CX			34-53-31	ALL
	=C1		W5039	001CO			34-53-31	ALL
D47916P		**AE0100A/ /**		**PLUG - INSERT**				**ALL**
	A1	DR	W0121	004CX			34-53-31	ALL
	=C1		W0121	004CO			34-53-31	ALL
D47920J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A1	DH	W3607	001CX			34-58-11	ALL
	=C1		W3607	001CO			34-58-11	ALL
D47920P		**AE0100A/ /**		**PLUG - INSERT**				**ALL**
	A1	DQ	W0121	011CX			34-58-11	ALL
	=C1		W0121	011CO			34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47923J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
1		W0521	0280	24		22-11-53	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0521	2548R	24		34-21-14	ALL
12		W0521	2548B	24		34-21-14	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0521	0281	24		22-11-53	ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0521	2917R	24		22-11-53	ALL
19		W0521	2917B	24		22-11-53	ALL
20		W0521	0282	24		22-11-53	ALL
21		W0521	0284	24		22-11-53	ALL
22	UNUSED						ALL
A	UNUSED						ALL
B	UNUSED						ALL
C	UNUSED						ALL
D		W0521	0337	20		34-24-15	ALL
E	UNUSED						ALL
F	UNUSED						ALL
PERS	1A	W0521	2548Z			34-21-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47923J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	PERS	1A	W0521	2917Z			22-11-53	ALL
D47923P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	1		W0121	0076	24		22-11-53	ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W0121	2035R	24		34-21-14	ALL
	12		W0121	2035B	24		34-21-14	ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0121	0077	24		22-11-53	ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18		W0121	2079R	24		22-11-53	ALL
	19		W0121	2079B	24		22-11-53	ALL
	20		W0121	0078	24		22-11-53	ALL
	21		W0121	0079	24		22-11-53	ALL
	22	UNUSED						ALL
	A	UNUSED						ALL
	B	UNUSED						ALL
	C	UNUSED						ALL
	D		W0121	0022	20		34-24-15	ALL
	E	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47923P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
F	UNUSED						ALL
PERS	1A	W0121	2035Z			34-21-14	ALL
PERS	1A	W0121	2079Z			22-11-53	ALL
D47924J	**AE0100A/ /**		**RCPT - INSERT**				**ALL**
A01		W0521	2806B	24		34-58-11	ALL
A02		W0521	2614B	24		34-58-11	ALL
A03		W0521	2608B	24		34-58-11	ALL
A04		W0521	2940B	24		34-53-11	ALL
A05	UNUSED						ALL
A06		W0521	2617B	24		34-31-11	ALL
A07		W0523	2855B	24		34-21-23	ALL
A08		W0521	2688B	24		34-21-13	ALL
A09		W0521	2901B	24		34-21-13	ALL
A10	UNUSED						ALL
B01		W0521	2806R	24		34-58-11	ALL
B02		W0521	2614R	24		34-58-11	ALL
B03		W0521	2608R	24		34-58-11	ALL
B04		W0521	2940R	24		34-53-11	ALL
B05	UNUSED						ALL
B06		W0521	2617R	24		34-31-11	ALL
B07		W0523	2855R	24		34-21-23	ALL
B08		W0521	2688R	24		34-21-13	ALL
B09		W0521	2901R	24		34-21-13	ALL
B10	UNUSED						ALL
C01		W0521	2519B	24		34-61-14	ALL
C02		W0521	2805B	24		34-58-11	ALL
C03		W0521	2611B	24		34-58-11	ALL
C04		W0521	2589B	24		34-55-11	ALL
C05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47924J		**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
	C06		W0521	2579B	24		34-31-11	ALL
	C07		W0521	2580B	24		34-31-11	ALL
	C08	UNUSED						ALL
	C09		W0521	2921B	24		34-21-13	ALL
	C10	UNUSED						ALL
	D01		W0521	2519R	24		34-61-14	ALL
	D02		W0521	2805R	24		34-58-11	ALL
	D03		W0521	2611R	24		34-58-11	ALL
	D04		W0521	2589R	24		34-55-11	ALL
	D05	UNUSED						ALL
	D06		W0521	2579R	24		34-31-11	ALL
	D07		W0521	2580R	24		34-31-11	ALL
	D08	UNUSED						ALL
	D09		W0521	2921R	24		34-21-13	ALL
	D10	UNUSED						ALL
	PERS	1A	W0521	2519Z			34-61-14	ALL
	PERS	1A	W0521	2579Z			34-31-11	ALL
	PERS	1A	W0521	2580Z			34-31-11	ALL
	PERS	1A	W0521	2589Z			34-55-11	ALL
	PERS	1A	W0521	2608Z			34-58-11	ALL
	PERS	1A	W0521	2611Z			34-58-11	ALL
	PERS	1A	W0521	2614Z			34-58-11	ALL
	PERS	1A	W0521	2617Z			34-31-11	ALL
	PERS	1A	W0521	2688Z			34-21-13	ALL
	PERS	1A	W0521	2805Z			34-58-11	ALL
	PERS	1A	W0521	2806Z			34-58-11	ALL
	PERS	1A	W0521	2901Z			34-21-13	ALL
	PERS	1A	W0521	2921Z			34-21-13	ALL
	PERS	1A	W0521	2940Z			34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47924J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
PERS	1A	W0523	2855Z			34-21-23	ALL
D47924P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
A01		W0121	2112B	24		34-58-11	ALL
A02		W0121	2057B	24		34-58-11	ALL
A03		W0121	2055B	24		34-58-11	ALL
A04		W0121	2518B	24		34-53-11	ALL
A05	UNUSED						ALL
A06		W0121	2085B	24		34-31-11	ALL
A07		W0121	2094B	24		34-21-23	ALL
A08		W0121	2521B	24		34-21-13	ALL
A09		W0121	2502B	24		34-21-13	ALL
A10	UNUSED						ALL
B01		W0121	2112R	24		34-58-11	ALL
B02		W0121	2057R	24		34-58-11	ALL
B03		W0121	2055R	24		34-58-11	ALL
B04		W0121	2518R	24		34-53-11	ALL
B05	UNUSED						ALL
B06		W0121	2085R	24		34-31-11	ALL
B07		W0121	2094R	24		34-21-23	ALL
B08		W0121	2521R	24		34-21-13	ALL
B09		W0121	2502R	24		34-21-13	ALL
B10	UNUSED						ALL
C01		W0121	2045B	24		34-61-14	ALL
C02		W0121	2109B	24		34-58-11	ALL
C03		W0121	2056B	24		34-58-11	ALL
C04		W0121	2013B	24		34-55-11	ALL
C05	UNUSED						ALL
C06		W0121	2086B	24		34-31-11	ALL
C07		W0121	2021B	24		34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47924P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	C08	UNUSED						ALL
	C09		W0121	2511B	24		34-21-13	ALL
	C10	UNUSED						ALL
	D01		W0121	2045R	24		34-61-14	ALL
	D02		W0121	2109R	24		34-58-11	ALL
	D03		W0121	2056R	24		34-58-11	ALL
	D04		W0121	2013R	24		34-55-11	ALL
	D05	UNUSED						ALL
	D06		W0121	2086R	24		34-31-11	ALL
	D07		W0121	2021R	24		34-31-11	ALL
	D08	UNUSED						ALL
	D09		W0121	2511R	24		34-21-13	ALL
	D10	UNUSED						ALL
	PERS	1A	W0121	2013Z			34-55-11	ALL
	PERS	1A	W0121	2021Z			34-31-11	ALL
	PERS	1A	W0121	2045Z			34-61-14	ALL
	PERS	1A	W0121	2055Z			34-58-11	ALL
	PERS	1A	W0121	2056Z			34-58-11	ALL
	PERS	1A	W0121	2057Z			34-58-11	ALL
	PERS	1A	W0121	2085Z			34-31-11	ALL
	PERS	1A	W0121	2086Z			34-31-11	ALL
	PERS	1A	W0121	2094Z			34-21-23	ALL
	PERS	1A	W0121	2109Z			34-58-11	ALL
	PERS	1A	W0121	2112Z			34-58-11	ALL
	PERS	1A	W0121	2502Z			34-21-13	ALL
	PERS	1A	W0121	2511Z			34-21-13	ALL
	PERS	1A	W0121	2518Z			34-53-11	ALL
	PERS	1A	W0121	2521Z			34-21-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47925J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
1	UNUSED						ALL
2		W6491	0010	24		34-41-11	ALL
3		W6491	0011	24		34-41-11	ALL
4		W6491	2022B	24		34-49-11	ALL
5		W6491	2022R	24		34-49-11	ALL
6	UNUSED						ALL
7		W6491	0009	24		34-41-11	ALL
8		W6491	0019	24		34-41-11	ALL
9		W6491	0020	24		34-41-11	ALL
10		W6491	0005	22		34-41-11	ALL
11		W6491	2011B	24		34-41-11	ALL
12		W6491	2015B	24		34-41-11	ALL
13		W6491	2016B	24		34-41-11	ALL
14		W6491	0012	24		34-41-11	ALL
15		W6491	0169	24		34-41-11	ALL
16		W6491	2011R	24		34-41-11	ALL
17		W6491	2015R	24		34-41-11	ALL
18		W6491	2016R	24		34-41-11	ALL
19		W6491	0024	22		34-41-11	ALL
20	UNUSED						ALL
21		W6491	0023	22		34-41-11	ALL
22	UNUSED						ALL
A		W6491	0018	20		34-41-11	ALL
B	UNUSED						ALL
C	UNUSED						ALL
D		W6491	2001B	16		34-41-11	ALL
E	UNUSED						ALL
F		W6491	2001R	16		34-41-11	ALL
PERS	1A	W6491	2001Z			34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47925J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	PERS	1A	W6491	2011Z			34-41-11	ALL
	PERS	1A	W6491	2015Z			34-41-11	ALL
	PERS	1A	W6491	2016Z			34-41-11	ALL
	PERS	1A	W6491	2022Z			34-49-11	ALL
D47925P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W0121	0134	24		34-41-11	ALL
	3		W0121	0135	24		34-41-11	ALL
	4		W0121	2108B	24		34-49-11	ALL
	5		W0121	2108R	24		34-49-11	ALL
	6	UNUSED						ALL
	7		W0121	0130	24		34-41-11	ALL
	8		W0121	0131	24		34-41-11	ALL
	9		W0121	0132	24		34-41-11	ALL
	10		W0121	0129	22		34-41-11	ALL
	11		W0121	2097B	24		34-41-11	ALL
	12		W0121	2104B	24		34-41-11	ALL
	13		W0121	2105B	24		34-41-11	ALL
	14		W0121	0133	24		34-41-11	ALL
	15		W0121	0109	24		34-41-11	ALL
	16		W0121	2097R	24		34-41-11	ALL
	17		W0121	2104R	24		34-41-11	ALL
	18		W0121	2105R	24		34-41-11	ALL
	19		W0121	0139	22		34-41-11	ALL
	20	UNUSED						ALL
	21		W0121	0138	22		34-41-11	ALL
	22	UNUSED						ALL
	A		W0121	0126	20		34-41-11	ALL
	B	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47925P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
C	UNUSED						ALL
D		W0121	2098B	16		34-41-11	ALL
E	UNUSED						ALL
F		W0121	2098R	16		34-41-11	ALL
PERS	1A	W0121	2097Z			34-41-11	ALL
PERS	1A	W0121	2098Z			34-41-11	ALL
PERS	1A	W0121	2104Z			34-41-11	ALL
PERS	1A	W0121	2105Z			34-41-11	ALL
PERS	1A	W0121	2108Z			34-49-11	ALL
D47926J	**AE0100A/180/R081**		**RCPT - INSERT**				**ALL**
A01		W6491	0047	24		34-41-11	ALL
A02		W6491	2201ZI			34-41-11	ALL
A03		W6491	2201B	24		34-41-11	ALL
A04		W6491	0035	22		34-41-11	ALL
A05		W6491	2009B	24		34-41-11	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W6491	2008B	24		31-65-15	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W6491	0022	24		34-41-11	ALL
B02	UNUSED						ALL
B03		W6491	2201R	24		34-41-11	ALL
B04		W6491	0036	22		34-41-11	ALL
B05		W6491	2009W	24		34-41-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W6491	2008R	24		31-65-15	ALL
B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47926J		**AE0100A/180/R081**		**RCPT - INSERT (continued)**				**ALL**
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W6491	0034	24		34-49-11	ALL
	C04		W6491	0006	22		34-41-11	ALL
	C05		W6491	2055B	24		34-41-11	ALL
	C06		W6491	2007B	24		34-41-11	ALL
	C07	UNUSED						ALL
	C08		W6491	2010B	24		31-65-25	ALL
	C09	UNUSED						ALL
	C10	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W6491	0015	22		34-41-11	ALL
	D05		W6491	2055R	24		34-41-11	ALL
	D06		W6491	2007W	24		34-41-11	ALL
	D07	UNUSED						ALL
	D08		W6491	2010R	24		31-65-25	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W6491	2007Z			34-41-11	ALL
	PERS	1A	W6491	2008Z			31-65-15	ALL
	PERS	1A	W6491	2009Z			34-41-11	ALL
	PERS	1A	W6491	2010Z			31-65-25	ALL
	PERS	1A	W6491	2055Z			34-41-11	ALL
	PERS	1A	W6491	2201ZO			34-41-11	ALL
D47926P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	A01		W0121	0137	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47926P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
A02		W0121	2106ZI			34-41-11	ALL
A03		W0121	2106B	24		34-41-11	ALL
A04		W0121	0151	22		34-41-11	ALL
A05		W0121	2102B	24		34-41-11	ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08		W0121	2110B	24		31-65-15	ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W0121	0155	24		34-41-11	ALL
B02	UNUSED						ALL
B03		W0121	2106R	24		34-41-11	ALL
B04		W0121	0152	22		34-41-11	ALL
B05		W0121	2102W	24		34-41-11	ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08		W0121	2110R	24		31-65-15	ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0121	0156	24		34-49-11	ALL
C04		W0121	0153	22		34-41-11	ALL
C05		W0121	2103B	24		34-41-11	ALL
C06		W0121	2101B	24		34-41-11	ALL
C07	UNUSED						ALL
C08		W0121	2111B	24		31-65-25	ALL
C09	UNUSED						ALL
C10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47926P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W0121	0154	22		34-41-11	ALL
	D05		W0121	2103R	24		34-41-11	ALL
	D06		W0121	2101W	24		34-41-11	ALL
	D07	UNUSED						ALL
	D08		W0121	2111R	24		31-65-25	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0121	2101Z			34-41-11	ALL
	PERS	1A	W0121	2102Z			34-41-11	ALL
	PERS	1A	W0121	2103Z			34-41-11	ALL
	PERS	1A	W0121	2106ZO			34-41-11	ALL
	PERS	1A	W0121	2110Z			31-65-15	ALL
	PERS	1A	W0121	2111Z			31-65-25	ALL
D47927J		**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
	1-1	UNUSED						ALL
	1-2	UNUSED						ALL
	1-3	UNUSED						ALL
	1-4	UNUSED						ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1		W6491	4001Y	24		34-41-11	ALL
	3-2		W6491	4001R	24		34-41-11	ALL
	3-3		W6491	4001G	24		34-41-11	ALL
	3-4	J8	W6491	4001B	24		34-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47927J	**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
=C1	UNUSED						ALL
=C2	UNUSED						ALL
=C3		W6491	4001Z			34-41-11	ALL
D47927P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1-1	UNUSED						ALL
1-2	UNUSED						ALL
1-3	UNUSED						ALL
1-4	UNUSED						ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1		W0121	4002Y	24		34-41-11	ALL
3-2		W0121	4002R	24		34-41-11	ALL
3-3		W0121	4002G	24		34-41-11	ALL
3-4	J5	W0121	4002B	24		34-41-11	ALL
=C1	UNUSED						ALL
=C2	UNUSED						ALL
=C3		W0121	4002Z			34-41-11	ALL
D47928J	**AE0100A/ /**		**RCPT - INSERT**				**ALL**
1		W2651	0003	20		22-14-11	ALL
2	UNUSED						ALL
3		W2651	0016	20		34-55-11	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W2651	0011	20		34-53-11	ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47928J		**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W2651	0004	22		34-51-41	ALL
	15	UNUSED						ALL
	16		W2651	0007	22		34-31-11	ALL
	17	UNUSED						ALL
D47928P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	1		W0121	0068	20		22-14-11	ALL
	2	UNUSED						ALL
	3		W0121	0021	22		34-55-11	ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6		W0121	0002	20		34-53-11	ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14		W0121	0053	22		34-51-41	ALL
	15	UNUSED						ALL
	16		W0121	0034	22		34-31-11	ALL
	17	UNUSED						ALL
D47930J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47930J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
3		W2205	1001	20		34-24-15	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W2205	2013B	24		34-31-11	ALL
11		W2205	2011B	24		34-21-13	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W2205	2013R	24		34-31-11	ALL
16		W2205	2011R	24		34-21-13	ALL
17	UNUSED						ALL
PERS	1A	W2205	1001Z			34-24-15	ALL
PERS	1A	W2205	2011Z			34-21-13	ALL
PERS	1A	W2205	2013Z			34-31-11	ALL
D47930P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0121	0022	20		34-24-15	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10		W0121	2015B	24		34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47930P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	11		W0121	2502B	24		34-21-13	ALL
	12	UNUSED						ALL
	13	UNUSED						ALL
	14	UNUSED						ALL
	15		W0121	2015R	24		34-31-11	ALL
	16		W0121	2502R	24		34-21-13	ALL
	17	UNUSED						ALL
	PERS	1A	W0121	2015Z			34-31-11	ALL
	PERS	1A	W0121	2502Z			34-21-13	ALL
D47932J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5721	2052B	24		31-65-15	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5721	2052R	24		31-65-15	ALL
	B04	UNUSED						ALL
	B05		W5721	0018	22		34-51-41	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W5721	2054B	24		34-31-11	ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W5721	2054R	24		34-31-11	ALL
	D04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47932J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
D05	UNUSED						ALL
PERS	1A	W5721	2052Z			31-65-15	ALL
PERS	1A	W5721	2054Z			34-31-11	ALL
D47932P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0121	2052B	24		31-65-15	ALL
A04	UNUSED						ALL
A05	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0121	2052R	24		31-65-15	ALL
B04	UNUSED						ALL
B05		W0121	0056	22		34-51-41	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0121	2038B	24		34-31-11	ALL
C04	UNUSED						ALL
C05	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0121	2038R	24		34-31-11	ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
PERS	1A	W0121	2038Z			34-31-11	ALL
PERS	1A	W0121	2052Z			31-65-15	ALL
D47933J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
1		W5205	0063	20		22-14-11	ALL
2	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47933J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	3		W5205	0006	22		34-51-41	ALL
	4	UNUSED						ALL
	5		W5205	0005	22		34-51-41	ALL
	6	UNUSED						ALL
	7		W5205	0002	22		34-51-41	ALL
	8	UNUSED						ALL
	9		W5205	0007	22		34-51-41	ALL
	10	UNUSED						ALL
	11		W5205	0011	22		34-51-41	ALL
	12	UNUSED						ALL
	13		W5205	0001	22		34-51-41	ALL
	14		W5205	2006B	22		SPARE	ALL
	15		W5205	2006R	22		SPARE	ALL
	16		W5205	2031B	24		SPARE	ALL
	17		W5205	2031R	24		SPARE	ALL
	18		W5205	0012	22		34-51-41	ALL
	19	UNUSED						ALL
	20		W5205	0053	20		SPARE	ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W5205	0103	22		34-51-11	ALL
	27	UNUSED						ALL
	28		W5205	2104B	24		34-51-11	ALL
	29		W5205	2104R	24		34-51-11	ALL
	30		W5205	2105B	24		34-51-11	ALL
	31		W5205	2105R	24		34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47933J	**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
32		W5205	2009B	24		34-51-11	ALL
33		W5205	2009R	24		34-51-11	ALL
34	UNUSED						ALL
PERS	1A	W5205	2006Z			SPARE	ALL
PERS	1A	W5205	2009Z			34-51-11	ALL
PERS	1A	W5205	2031Z			SPARE	ALL
PERS	1A	W5205	2104Z			34-51-11	ALL
PERS	1A	W5205	2105Z			34-51-11	ALL
D47933P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1		W0121	0068	20		22-14-11	ALL
2	UNUSED						ALL
3		W0121	0005	22		34-51-41	ALL
4	UNUSED						ALL
5		W0121	0055	22		34-51-41	ALL
6	UNUSED						ALL
7		W0121	0052	22		34-51-41	ALL
8	UNUSED						ALL
9		W0121	0031	22		34-51-41	ALL
10	UNUSED						ALL
11		W0121	0030	22		34-51-41	ALL
12	UNUSED						ALL
13		W0121	0053	22		34-51-41	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18		W0121	0088	22		34-51-41	ALL
19	UNUSED						ALL
20	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47933P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL
	25	UNUSED						ALL
	26		W0121	0108	22		34-51-11	ALL
	27	UNUSED						ALL
	28		W0121	2070B	24		34-51-11	ALL
	29		W0121	2070R	24		34-51-11	ALL
	30		W0121	2088B	24		34-51-11	ALL
	31		W0121	2088R	24		34-51-11	ALL
	32		W0121	2089B	24		34-51-11	ALL
	33		W0121	2089R	24		34-51-11	ALL
	34	UNUSED						ALL
	PERS	1A	W0121	2070Z			34-51-11	ALL
	PERS	1A	W0121	2088Z			34-51-11	ALL
	PERS	1A	W0121	2089Z			34-51-11	ALL
D47934J		**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W2149	0045	22		22-11-18	ALL
	A03		W2149	2004B	24		22-11-51	ALL
	A04	UNUSED						ALL
	A05		W2149	2001B	24		34-31-11	ALL
	A06		W2149	0046	22		34-55-11	ALL
	A07	UNUSED						ALL
	A08		W2149	0033	22		34-51-41	ALL
	A09		W2149	0037	22		34-55-11	ALL
	A10		W2149	0054	22		34-51-11	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47934J	**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
B02	UNUSED						ALL
B03		W2149	2004R	24		22-11-51	ALL
B04	UNUSED						ALL
B05		W2149	2001R	24		34-31-11	ALL
B06		W2149	0004	22		34-55-11	ALL
B07		W2149	0032	22		34-51-41	ALL
B08		W2149	0026	22		34-55-11	ALL
B09		W2149	0012	22		34-51-41	ALL
B10	UNUSED						ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03	UNUSED						ALL
C04		W2149	0022	22		34-53-11	ALL
C05		W2149	2002B	24		34-51-11	ALL
C06		W2149	2003B	24		34-55-11	ALL
C07	UNUSED						ALL
C08		W2149	0051	22		34-51-41	ALL
C09		W2149	0023	22		SPARE	ALL
C10		W2149	0031	22		34-51-41	ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W2149	0025	22		34-51-41	ALL
D04		W2149	0013	22		34-55-11	ALL
D05		W2149	2002R	24		34-51-11	ALL
D06		W2149	2003R	24		34-55-11	ALL
D07		W2149	0053	22		34-55-11	ALL
D08		W2149	0030	22		34-55-11	ALL
D09		W2149	0038	22		34-51-41	ALL
D10		W2149	0027	22		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47934J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	PERS	1A	W2149	2001Z			34-31-11	ALL
	PERS	1A	W2149	2002Z			34-51-11	ALL
	PERS	1A	W2149	2003Z			34-55-11	ALL
	PERS	1A	W2149	2004Z			22-11-51	ALL
D47934P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W0121	0066	22		22-11-18	ALL
	A03		W0121	2046B	24		22-11-51	ALL
	A04	UNUSED						ALL
	A05		W0121	2039B	24		34-31-11	ALL
	A06		W0121	0032	22		34-55-11	ALL
	A07	UNUSED						ALL
	A08		W0121	0086	22		34-51-41	ALL
	A09	UNUSED						ALL
	A10		W0121	0108	22		34-51-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0121	2046R	24		22-11-51	ALL
	B04	UNUSED						ALL
	B05		W0121	2039R	24		34-31-11	ALL
	B06	UNUSED						ALL
	B07		W0121	0088	22		34-51-41	ALL
	B08	UNUSED						ALL
	B09		W0121	0052	22		34-51-41	ALL
	B10	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0121	0024	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47934P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
C05		W0121	2088B	24		34-51-11	ALL
C06		W0121	2007B	24		34-55-11	ALL
C07	UNUSED						ALL
C08		W0121	0087	22		34-51-41	ALL
C09	UNUSED						ALL
C10		W0121	0031	22		34-51-41	ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0121	0059	22		34-51-41	ALL
D04		W0121	0026	22		34-55-11	ALL
D05		W0121	2088R	24		34-51-11	ALL
D06		W0121	2007R	24		34-55-11	ALL
D07		W0121	0028	22		34-55-11	ALL
D08	UNUSED						ALL
D09		W0121	0054	22		34-51-41	ALL
D10	UNUSED						ALL
PERS	1A	W0121	2007Z			34-55-11	ALL
PERS	1A	W0121	2039Z			34-31-11	ALL
PERS	1A	W0121	2046Z			22-11-51	ALL
PERS	1A	W0121	2088Z			34-51-11	ALL
D47936J	**AE0100A/ /**		**RCPT - INSERT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W5723	2016B	24		34-21-24	ALL
A05	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47936J		**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
	B04		W5723	2016R	24		34-21-24	ALL
	B05	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W5723	2040B	24		SPARE	ALL
	C05	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04		W5723	2040R	24		SPARE	ALL
	D05	UNUSED						ALL
	PERS	1A	W5723	2016Z			34-21-24	ALL
	PERS	1A	W5723	2040Z			SPARE	ALL
D47936P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0121	2044B	24		34-21-24	ALL
	A05	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0121	2044R	24		34-21-24	ALL
	B05	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47936P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
C05	UNUSED						ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
PERS	1A	W0121	2044Z			34-21-24	ALL
D47937J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
1-1		W2043	4004Y	24		46-13-11	ALL
1-2		W2043	4004R	24		46-13-11	ALL
1-3		W2043	4004G	24		46-13-11	ALL
1-4	J5	W2043	4004B	24		46-13-11	ALL
2-1	UNUSED						ALL
2-2	UNUSED						ALL
2-3	UNUSED						ALL
2-4	UNUSED						ALL
3-1	UNUSED						ALL
3-2	UNUSED						ALL
3-3	UNUSED						ALL
3-4	UNUSED						ALL
=C1		W2043	4004Z			46-13-11	ALL
=C2	UNUSED						ALL
=C3	UNUSED						ALL
D47937P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1-1		W0121	4001Y	24		46-13-11	ALL
1-2		W0121	4001R	24		46-13-11	ALL
1-3		W0121	4001G	24		46-13-11	ALL
1-4	J8	W0121	4001B	24		46-13-11	ALL
2-1	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47937P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
	=C1		W0121	4001Z			46-13-11	ALL
	=C2	UNUSED						ALL
	=C3	UNUSED						ALL
D47938J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A01		W5111	2046B	24		SPARE	ALL
	A02		W5111	0024	22		SPARE	ALL
	A03		W5111	2013B	24		31-65-15	ALL
	A04	UNUSED						ALL
	A05		W5111	2053B	24		22-11-51	ALL
	B01		W5111	2046R	24		SPARE	ALL
	B02	UNUSED						ALL
	B03		W5111	2013R	24		31-65-15	ALL
	B04	UNUSED						ALL
	B05		W5111	2053R	24		22-11-51	ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03		W5111	2774B	24		31-65-15	ALL
	C04		W5111	2093B	24		34-45-21	ALL
	C05		W5111	0001	22		22-11-18	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W5111	2774R	24		31-65-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47938J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
D04		W5111	2093R	24		34-45-21	ALL
D05	UNUSED						ALL
PERS	1A	W5111	2013Z			31-65-15	ALL
PERS	1A	W5111	2046Z			SPARE	ALL
PERS	1A	W5111	2053Z			22-11-51	ALL
PERS	1A	W5111	2093Z			34-45-21	ALL
PERS	1A	W5111	2774Z			31-65-15	ALL
D47938P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03		W0121	2052B	24		31-65-15	ALL
A04	UNUSED						ALL
A05		W0121	2046B	24		22-11-51	ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0121	2052R	24		31-65-15	ALL
B04	UNUSED						ALL
B05		W0121	2046R	24		22-11-51	ALL
C01	UNUSED						ALL
C02	UNUSED						ALL
C03		W0121	2078B	24		31-65-15	ALL
C04		W0121	2064B	24		34-45-21	ALL
C05		W0121	0040	22		22-11-18	ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0121	2078R	24		31-65-15	ALL
D04		W0121	2064R	24		34-45-21	ALL
D05	UNUSED						ALL
PERS	1A	W0121	2046Z			22-11-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47938P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0121	2052Z			31-65-15	ALL
	PERS	1A	W0121	2064Z			34-45-21	ALL
	PERS	1A	W0121	2078Z			31-65-15	ALL
D47939J		**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
	A01		W5111	2702B	24		34-58-11	ALL
	A02		W5111	2110B	24		34-58-11	ALL
	A03		W5111	2054B	24		34-55-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5111	2004B	24		34-31-11	ALL
	A07		W5111	2002B	24		34-31-11	ALL
	A08		W5111	2005B	24		22-11-53	ALL
	A09	UNUSED						ALL
	A10		W5111	0013	24		22-11-53	ALL
	B01		W5111	2702R	24		34-58-11	ALL
	B02		W5111	2110R	24		34-58-11	ALL
	B03		W5111	2054R	24		34-55-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5111	2004R	24		34-31-11	ALL
	B07		W5111	2002R	24		34-31-11	ALL
	B08		W5111	2005R	24		22-11-53	ALL
	B09	UNUSED						ALL
	B10		W5111	0019	24		22-11-53	ALL
	C01		W5111	2703B	24		34-58-11	ALL
	C02		W5111	2042B	24		SPARE	ALL
	C03	UNUSED						ALL
	C04		W5111	2023B	24		34-55-11	ALL
	C05	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47939J	**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
C06		W5111	2001B	24		34-31-11	ALL
C07	UNUSED						ALL
C08		W5111	2003B	24		34-31-11	ALL
C09	UNUSED						ALL
C10		W5111	0020	24		22-11-53	ALL
D01		W5111	2703R	24		34-58-11	ALL
D02		W5111	2042R	24		SPARE	ALL
D03	UNUSED						ALL
D04		W5111	2023R	24		34-55-11	ALL
D05	UNUSED						ALL
D06		W5111	2001R	24		34-31-11	ALL
D07	UNUSED						ALL
D08		W5111	2003R	24		34-31-11	ALL
D09		W5111	0028	22		34-51-41	ALL
D10		W5111	0021	24		22-11-53	ALL
PERS	1A	W5111	2001Z			34-31-11	ALL
PERS	1A	W5111	2002Z			34-31-11	ALL
PERS	1A	W5111	2003Z			34-31-11	ALL
PERS	1A	W5111	2004Z			34-31-11	ALL
PERS	1A	W5111	2005Z			22-11-53	ALL
PERS	1A	W5111	2023Z			34-55-11	ALL
PERS	1A	W5111	2042Z			SPARE	ALL
PERS	1A	W5111	2054Z			34-55-11	ALL
PERS	1A	W5111	2110Z			34-58-11	ALL
PERS	1A	W5111	2702Z			34-58-11	ALL
PERS	1A	W5111	2703Z			34-58-11	ALL
D47939P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
A01		W0121	2090B	24		34-58-11	ALL
A02		W0121	2043B	24		34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47939P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	A03		W0121	2034B	24		34-55-11	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0121	2018B	24		34-31-11	ALL
	A07		W0121	2016B	24		34-31-11	ALL
	A08		W0121	2079B	24		22-11-53	ALL
	A09	UNUSED						ALL
	A10		W0121	0076	24		22-11-53	ALL
	B01		W0121	2090R	24		34-58-11	ALL
	B02		W0121	2043R	24		34-58-11	ALL
	B03		W0121	2034R	24		34-55-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0121	2018R	24		34-31-11	ALL
	B07		W0121	2016R	24		34-31-11	ALL
	B08		W0121	2079R	24		22-11-53	ALL
	B09	UNUSED						ALL
	B10		W0121	0077	24		22-11-53	ALL
	C01		W0121	2091B	24		34-58-11	ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04		W0121	2012B	24		34-55-11	ALL
	C05	UNUSED						ALL
	C06		W0121	2037B	24		34-31-11	ALL
	C07	UNUSED						ALL
	C08		W0121	2017B	24		34-31-11	ALL
	C09	UNUSED						ALL
	C10		W0121	0078	24		22-11-53	ALL
	D01		W0121	2091R	24		34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47939P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
D02	UNUSED						ALL
D03	UNUSED						ALL
D04		W0121	2012R	24		34-55-11	ALL
D05	UNUSED						ALL
D06		W0121	2037R	24		34-31-11	ALL
D07	UNUSED						ALL
D08		W0121	2017R	24		34-31-11	ALL
D09		W0121	0059	22		34-51-41	ALL
D10		W0121	0079	24		22-11-53	ALL
PERS	1A	W0121	2012Z			34-55-11	ALL
PERS	1A	W0121	2016Z			34-31-11	ALL
PERS	1A	W0121	2017Z			34-31-11	ALL
PERS	1A	W0121	2018Z			34-31-11	ALL
PERS	1A	W0121	2034Z			34-55-11	ALL
PERS	1A	W0121	2037Z			34-31-11	ALL
PERS	1A	W0121	2043Z			34-58-11	ALL
PERS	1A	W0121	2079Z			22-11-53	ALL
PERS	1A	W0121	2090Z			34-58-11	ALL
PERS	1A	W0121	2091Z			34-58-11	ALL
D47940J	**AE0100A/ /**		**RCPT - INSERT**				**ALL**
A01	UNUSED						ALL
A02	UNUSED						ALL
A03	UNUSED						ALL
A04		W5121	2516B	24		31-31-13	ALL
A05	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04		W5121	2516R	24		31-31-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47940J		**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
	B05	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03	UNUSED						ALL
	D04	UNUSED						ALL
	D05	UNUSED						ALL
	PERS	1A	W5121	2516Z			31-31-13	ALL
D47940P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0121	2516B	24		31-31-13	ALL
	A05	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04		W0121	2516R	24		31-31-13	ALL
	B05	UNUSED						ALL
	C01	UNUSED						ALL
	C02	UNUSED						ALL
	C03	UNUSED						ALL
	C04	UNUSED						ALL
	C05	UNUSED						ALL
	D01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47940P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
D02	UNUSED						ALL
D03	UNUSED						ALL
D04	UNUSED						ALL
D05	UNUSED						ALL
PERS	1A	W0121	2516Z			31-31-13	ALL
D47941J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
A01		W5719	0001	24		34-53-11	ALL
A02		W5719	0005	24		34-53-11	ALL
A03		W5719	0009	24		34-53-11	ALL
A04		W5719	2001B	24		34-45-21	ALL
A05		W5719	0013	24		34-53-11	ALL
A06		W5719	2036B	24		34-53-11	ALL
A07		W5719	0017	24		34-53-11	ALL
A08		W5719	0021	24		34-53-11	ALL
A09		W5719	0025	24		34-53-11	ALL
A10		W5719	0026	24		SPARE	ALL
B01		W5719	0002	24		34-53-11	ALL
B02		W5719	0006	24		34-53-11	ALL
B03		W5719	0010	24		34-53-11	ALL
B04		W5719	2001R	24		34-45-21	ALL
B05		W5719	0014	24		34-53-11	ALL
B06		W5719	2036R	24		34-53-11	ALL
B07		W5719	0018	24		34-53-11	ALL
B08		W5719	0022	24		34-53-11	ALL
B09		W5719	0049	22		34-31-11	ALL
B10		W5719	0027	24		SPARE	ALL
C01		W5719	0003	24		34-53-11	ALL
C02		W5719	0007	24		34-53-11	ALL
C03		W5719	0011	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47941J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	C04		W5719	2002B	24		34-45-21	ALL
	C05		W5719	0015	24		34-53-11	ALL
	C06		W5719	2017B	24		22-11-51	ALL
	C07		W5719	0019	24		34-53-11	ALL
	C08		W5719	0023	24		34-53-11	ALL
	C09		W5719	2011B	24		SPARE	ALL
	C10	UNUSED						ALL
	D01		W5719	0004	24		34-53-11	ALL
	D02		W5719	0008	24		34-53-11	ALL
	D03		W5719	0012	24		34-53-11	ALL
	D04		W5719	2002R	24		34-45-21	ALL
	D05		W5719	0016	24		34-53-11	ALL
	D06		W5719	2017R	24		22-11-51	ALL
	D07		W5719	0020	24		34-53-11	ALL
	D08		W5719	0024	24		34-53-11	ALL
	D09		W5719	2011R	24		SPARE	ALL
	D10		W5719	0051	22		SPARE	ALL
	PERS	1A	W5719	2001Z			34-45-21	ALL
	PERS	1A	W5719	2002Z			34-45-21	ALL
	PERS	1A	W5719	2011Z			SPARE	ALL
	PERS	1A	W5719	2017Z			22-11-51	ALL
	PERS	1A	W5719	2036Z			34-53-11	ALL
D47941P		**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
	A01		W0121	0201	24		34-53-11	ALL
	A02		W0121	0205	24		34-53-11	ALL
	A03		W0121	0209	24		34-53-11	ALL
	A04		W0121	2004B	24		34-45-21	ALL
	A05		W0121	0213	24		34-53-11	ALL
	A06		W0121	2022B	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47941P	**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
A07		W0121	0217	24		34-53-11	ALL
A08		W0121	0221	24		34-53-11	ALL
A09		W0121	0225	24		34-53-11	ALL
A10	UNUSED						ALL
B01		W0121	0202	24		34-53-11	ALL
B02		W0121	0206	24		34-53-11	ALL
B03		W0121	0210	24		34-53-11	ALL
B04		W0121	2004R	24		34-45-21	ALL
B05		W0121	0214	24		34-53-11	ALL
B06		W0121	2022R	24		34-53-11	ALL
B07		W0121	0218	24		34-53-11	ALL
B08		W0121	0222	24		34-53-11	ALL
B09		W0121	0037	22		34-31-11	ALL
B10	UNUSED						ALL
C01		W0121	0203	24		34-53-11	ALL
C02		W0121	0207	24		34-53-11	ALL
C03		W0121	0211	24		34-53-11	ALL
C04		W0121	2062B	24		34-45-21	ALL
C05		W0121	0215	24		34-53-11	ALL
C06		W0121	2510B	24		22-11-51	ALL
C07		W0121	0219	24		34-53-11	ALL
C08		W0121	0223	24		34-53-11	ALL
C09	UNUSED						ALL
C10	UNUSED						ALL
D01		W0121	0204	24		34-53-11	ALL
D02		W0121	0208	24		34-53-11	ALL
D03		W0121	0212	24		34-53-11	ALL
D04		W0121	2062R	24		34-45-21	ALL
D05		W0121	0216	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47941P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	D06		W0121	2510R	24		22-11-51	ALL
	D07		W0121	0220	24		34-53-11	ALL
	D08		W0121	0224	24		34-53-11	ALL
	D09	UNUSED						ALL
	D10	UNUSED						ALL
	PERS	1A	W0121	2004Z			34-45-21	ALL
	PERS	1A	W0121	2022Z			34-53-11	ALL
	PERS	1A	W0121	2062Z			34-45-21	ALL
	PERS	1A	W0121	2510Z			22-11-51	ALL
D47942J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	1	UNUSED						ALL
	2		W5719	0028	20		SPARE	ALL
	3		W5719	0039	20		SPARE	ALL
	4		W5719	0043	22		SPARE	ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7		W5719	0069	22		34-51-41	ALL
	8		W5719	2038B	24		34-51-11	ALL
	9		W5719	2003B	24		34-55-11	ALL
	10		W5719	2037B	24		34-58-11	ALL
	11		W5719	2004B	24		34-58-11	ALL
	12	UNUSED						ALL
	13		W5719	2038R	24		34-51-11	ALL
	14		W5719	2003R	24		34-55-11	ALL
	15		W5719	2037R	24		34-58-11	ALL
	16		W5719	2004R	24		34-58-11	ALL
	17		W5719	0041	22		SPARE	ALL
	PERS	1A	W5719	2003Z			34-55-11	ALL
	PERS	1A	W5719	2004Z			34-58-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47942J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
PERS	1A	W5719	2037Z			34-58-11	ALL
PERS	1A	W5719	2038Z			34-51-11	ALL
D47942P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0121	0023	22		34-51-41	ALL
8		W0121	2068B	24		34-51-11	ALL
9		W0121	2008B	24		34-55-11	ALL
10		W0121	2042B	24		34-58-11	ALL
11		W0121	2065B	24		34-58-11	ALL
12	UNUSED						ALL
13		W0121	2068R	24		34-51-11	ALL
14		W0121	2008R	24		34-55-11	ALL
15		W0121	2042R	24		34-58-11	ALL
16		W0121	2065R	24		34-58-11	ALL
17	UNUSED						ALL
PERS	1A	W0121	2008Z			34-55-11	ALL
PERS	1A	W0121	2042Z			34-58-11	ALL
PERS	1A	W0121	2065Z			34-58-11	ALL
PERS	1A	W0121	2068Z			34-51-11	ALL
D47943J	**AE0100A/180/R031**		**RCPT - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47943J		**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8		W2177	0003	20		34-53-11	ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11		W2177	0011	24		34-53-11	ALL
	12		W2177	0012	24		34-53-11	ALL
	13		W2177	0007	24		34-53-11	ALL
	14	UNUSED						ALL
	15	UNUSED						ALL
	16	UNUSED						ALL
	17	UNUSED						ALL
	18	UNUSED						ALL
	19	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23		W2177	0005	20		34-53-11	ALL
	24		W2177	0010	20		34-53-11	ALL
	25		W2177	0009	20		34-53-11	ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W2177	2001R	24		34-53-11	ALL
	30		W2177	2001B	24		34-53-11	ALL
	31		W2177	0024	24		34-53-11	ALL
	32		W2177	0020	24		34-53-11	ALL
	33		W2177	0016	24		34-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47943J	**AE0100A/180/R031**		**RCPT - INSERT (continued)**				**ALL**
34		W2177	0015	24		34-53-11	ALL
PERS	1A	W2177	2001Z			34-53-11	ALL
D47943P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8		W0121	0003	20		34-53-11	ALL
9	UNUSED						ALL
10	UNUSED						ALL
11		W0121	0011	24		34-53-11	ALL
12		W0121	0012	24		34-53-11	ALL
13		W0121	0007	24		34-53-11	ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W0121	0025	20		34-53-11	ALL
24		W0121	0010	20		34-53-11	ALL
25		W0121	0009	20		34-53-11	ALL
26	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47943P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	27	UNUSED						ALL
	28	UNUSED						ALL
	29		W0121	2001R	24		34-53-11	ALL
	30		W0121	2001B	24		34-53-11	ALL
	31		W0121	0024	24		34-53-11	ALL
	32		W0121	0020	24		34-53-11	ALL
	33		W0121	0016	24		34-53-11	ALL
	34		W0121	0015	24		34-53-11	ALL
	PERS	1A	W0121	2001Z			34-53-11	ALL
D47944J		**AE0100A/ /**		**RCPT - INSERT**				**ALL**
	A01	UNUSED						ALL
	A02		W5189	2501R	24		34-55-11	ALL
	A03		W5189	2501B	24		34-55-11	ALL
	A04		W5189	2505B	24		34-31-11	ALL
	A05	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W5189	2501ZI			34-55-11	ALL
	B04		W5189	2505R	24		34-31-11	ALL
	B05		W5189	2505ZI			34-31-11	ALL
	C01	UNUSED						ALL
	C02		W5189	2010ZI			34-51-11	ALL
	C03		W5189	2010R	24		34-51-11	ALL
	C04		W5189	2009ZI			34-32-11	ALL
	C05		W5189	2009R	24		34-32-11	ALL
	D01	UNUSED						ALL
	D02	UNUSED						ALL
	D03		W5189	2010B	24		34-51-11	ALL
	D04		W5189	2009B	24		34-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D47944J	**AE0100A/ /**		**RCPT - INSERT (continued)**				**ALL**
D05	UNUSED						ALL
PERS	1A	W5189	2009ZO			34-32-11	ALL
PERS	1A	W5189	2010ZO			34-51-11	ALL
PERS	1A	W5189	2501ZO			34-55-11	ALL
PERS	1A	W5189	2505ZO			34-31-11	ALL
D47944P	**AE0100A/180/R031**		**PLUG - INSERT**				**ALL**
A01	UNUSED						ALL
A02		W0121	2009R	24		34-55-11	ALL
A03		W0121	2009B	24		34-55-11	ALL
A04		W0121	2504B	24		34-31-11	ALL
A05	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03		W0121	2009ZI			34-55-11	ALL
B04		W0121	2504R	24		34-31-11	ALL
B05		W0121	2504ZI			34-31-11	ALL
C01	UNUSED						ALL
C02		W0121	2067ZI			34-51-11	ALL
C03		W0121	2067R	24		34-51-11	ALL
C04		W0121	2051ZI			34-32-11	ALL
C05		W0121	2051R	24		34-32-11	ALL
D01	UNUSED						ALL
D02	UNUSED						ALL
D03		W0121	2067B	24		34-51-11	ALL
D04		W0121	2051B	24		34-32-11	ALL
D05	UNUSED						ALL
PERS	1A	W0121	2009ZO			34-55-11	ALL
PERS	1A	W0121	2051ZO			34-32-11	ALL
PERS	1A	W0121	2067ZO			34-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D47944P		**AE0100A/180/R031**		**PLUG - INSERT (continued)**				**ALL**
	PERS	1A	W0121	2504ZO			34-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48080	**P028-00/171/R018**		**PLUG-CONDUCTIVE**				**ALL**
1		W8524	0513	18		49-62-11	ALL
2		W8524	0514	18		49-62-11	ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W8524	6007R	18		26-21-11	ALL
8		W8524	6008R	18		26-21-11	ALL
9	UNUSED						ALL
10		W8524	6004R	18		26-11-31	ALL
11		W8524	6001R	18		26-11-31	ALL
12		W8524	6002R	18		26-11-31	ALL
13		W8524	6003R	18		26-11-31	ALL
14	UNUSED						ALL
15		W8524	2202B	18		24-22-31	ALL
16		W8524	2202R	18		24-22-31	ALL
DED		W8524	2202Z			24-22-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48100J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0026	20		27-53-11	ALL
	A02		W0088	0027	20		27-53-11	ALL
	A03		W0088	0031	22		29-11-12	ALL
	A04		W0088	0032	22		29-11-12	ALL
	A05		W0088	0033	20		29-33-11	ALL
	A06		W0088	0022	20		27-53-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48100P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W2104	0517	20		27-53-11	ALL
	A02		W2104	0518	20		27-53-11	ALL
	A03		W2104	0521	22		29-11-12	ALL
	A04		W2104	0522	22		29-11-12	ALL
	A05		W2104	0509	24		29-33-11	ALL
	A06		W2104	0511	20		27-53-11	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48100P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48102J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0001	22		21-27-21	ALL
	A02		W0088	0007	22		21-27-21	ALL
	A03		W0088	0120	22		24-22-11	ALL
	A04		W0088	0023	24		24-33-11	ALL
	A05	UNUSED						ALL
	A06		W0088	0240	22		34-21-11	ALL
	A07		W0088	0034	22		30-11-11	ALL
	A08		W0088	0035	22		30-11-11	ALL
	A09		W0088	0245	22		30-11-11	ALL
	A10		W0088	1003	24		73-21-12	ALL
	B01		W0088	0084	22		31-31-11	ALL
	B02		W0088	0085	22		31-31-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48102J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0088	1003Z			73-21-12	ALL
D48102P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W2112	5505	22		21-27-21	ALL
	A02		W2112	5504	22		21-27-21	ALL
	A03		W2112	0503	22		24-22-11	ALL
	A04		W2112	0510	24		24-33-11	ALL
	A05	UNUSED						ALL
	A06		W2112	0179	22		34-21-11	ALL
	A07		W2112	6023	22		30-11-11	ALL
	A08		W2112	6024	22		30-11-11	ALL
	A09		W2112	0016	22		30-11-11	ALL
	A10		W2112	1301	24		73-21-12	ALL
	B01		W2112	8003	22		31-31-11	ALL
	B02		W2112	8004	22		31-31-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W2112	1301Z			73-21-12	ALL
D48104J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0011	22		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48104J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	A02		W0088	0043	22		30-31-11	ALL
	A03		W0088	0044	22		30-31-11	ALL
	A04		W0088	0045	22		30-31-11	ALL
	A05		W0088	0046	22		30-31-11	ALL
	A06	UNUSED						ALL
	A07		W0088	0047	22		SPARE	ALL
	A08		W0088	0018	20		21-42-11	ALL
	A09		W0088	0019	20		21-42-11	ALL
	A10	UNUSED						ALL
	B01		W0088	0205	20		52-71-13	ALL
	B02		W0088	0202	20		52-71-13	ALL
	B03		W0088	0201	20		52-71-13	ALL
	B04		W0088	0210	20		52-71-14	ALL
	B05		W0088	0207	20		52-71-14	ALL
	B06		W0088	0206	20		52-71-14	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48104P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W2114	5501	22		21-27-31	ALL
	A02		W2114	5517	22		30-31-11	ALL
	A03		W2114	5518	22		30-31-11	ALL
	A04		W2114	5519	22		30-31-11	ALL
	A05		W2114	5520	22		30-31-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W2114	0027	20		21-42-11	ALL
	A09		W2114	0028	20		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D48104P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	A10	UNUSED						ALL
	B01		W2114	0030	20		52-71-13	ALL
	B02		W2114	0031	20		52-71-13	ALL
	B03		W2114	0040	20		52-71-13	ALL
	B04		W2114	0035	20		52-71-14	ALL
	B05		W2114	0036	20		52-71-14	ALL
	B06		W2114	0045	20		52-71-14	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48106J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0020	24		21-43-21	ALL
	A02	UNUSED						ALL
	A03		W0088	0121	22		24-28-11	ALL
	A04		W0088	0122	22		24-28-11	ALL
	A05		W0088	2003R	20		24-31-11	ALL
	A06		W0088	2003B	20		24-31-11	ALL
	A07		W0088	2004R	20		24-31-12	ALL
	A08		W0088	2004B	20		24-31-12	ALL
	A09		W0088	0024	24		24-33-11	ALL
	A10		W0088	0028	20		28-21-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W0088	0082	20		76-21-11	ALL
	B04		W0088	0081	20		76-21-11	ALL
	B05		W0088	0192	24		76-21-11	ALL
	B06		W0088	0062	22		34-51-41	ALL
	B07	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48106J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B08	UNUSED						ALL
	B09		W0088	1015	22		30-31-11	ALL
	B10	UNUSED						ALL
	DED		W0088	2003Z			24-31-11	ALL
	DED		W0088	2004Z			24-31-12	ALL
	PERG	1F	W0088	1015Z			30-31-11	ALL
D48106P		**J048-00/ /**		**PLUG**				**ALL**
	A01		W2508	5616	24		21-43-21	ALL
	A02	UNUSED						ALL
	A03		W2508	0536	22		24-28-11	ALL
	A04		W2508	0537	22		24-28-11	ALL
	A05		W2508	2201R	20		24-31-11	ALL
	A06		W2508	2201B	20		24-31-11	ALL
	A07		W2508	2202R	20		24-31-12	ALL
	A08		W2508	2202B	20		24-31-12	ALL
	A09		W2508	0529	24		24-33-11	ALL
	A10		W2508	6015	20		28-21-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03		W2508	6023	20		76-21-11	ALL
	B04		W2508	6025	20		76-21-11	ALL
	B05		W2508	6040	24		76-21-11	ALL
	B06		W2508	8002	22		34-51-41	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5158	1001	22		30-31-11	ALL
	B10	UNUSED						ALL
	DED		W2508	2201Z			24-31-11	ALL
	DED		W2508	2202Z			24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48106P		**J048-00/ /**		**PLUG (continued)**				**ALL**
	PERG	1F	W5158	1001Z			30-31-11	ALL
D48108J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	2003R	20		24-31-11	ALL
	A02		W0088	2003B	20		24-31-11	ALL
	A03		W0088	2004R	20		24-31-12	ALL
	A04		W0088	2004B	20		24-31-12	ALL
	A05		W0088	0024	24		24-33-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	DED		W0088	2003Z			24-31-11	ALL
	DED		W0088	2004Z			24-31-12	ALL
D48108P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W2532	2201R	20		24-31-11	ALL
	A02		W2532	2201B	20		24-31-11	ALL
	A03		W2532	2202R	20		24-31-12	ALL
	A04		W2532	2202B	20		24-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48108P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	A05		W2532	0533	24		24-33-11	ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48110J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W0088	1001	24		73-21-12	ALL
	A04	UNUSED						ALL
	A05		W0088	1005	20		73-22-11	ALL
	A06		W0088	1006	20		74-11-11	ALL
	A07		W0088	2510R	20		36-11-12	ALL
	A08	UNUSED						ALL
	A09		W0088	0409	20		78-34-11	ALL
	A10		W0088	0407	20		78-34-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Bundle	Description				
	Term	Type		Wire No.	GA	CO	Diagram	Effectivity
D48110J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0088	0071	20		78-35-11	ALL
	B06	UNUSED						ALL
	B07		W0088	2510B	20		36-11-12	ALL
	B08	UNUSED						ALL
	B09		W0088	0410	20		78-34-11	ALL
	B10		W0088	0408	20		78-34-11	ALL
	PERG	1F	W0088	1001Z			73-21-12	ALL
	PERG	1F	W0088	1005Z			73-22-11	ALL
	PERG	1F	W0088	1006Z			74-11-11	ALL
	PERG	1F	W0088	2510Z			36-11-12	ALL
D48110P		**J048-00/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03		W5170	1001	24		73-21-12	ALL
	A04	UNUSED						ALL
	A05		W5170	1302	20		73-22-11	ALL
	A06		W5170	1301	20		74-11-11	ALL
	A07		W5170	2510R	20		36-11-12	ALL
	A08	UNUSED						ALL
	A09		W5170	1007	20		78-34-11	ALL
	A10		W5170	1005	20		78-34-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W5170	0512	20		78-35-11	ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48110P	**J048-00/ /**		**PLUG- (continued)**				**ALL**
B07		W5170	2510B	20		36-11-12	ALL
B08	UNUSED						ALL
B09		W5170	1008	20		78-34-11	ALL
B10		W5170	1006	20		78-34-11	ALL
PERG	1F	W5170	1001Z			73-21-12	ALL
PERG	1F	W5170	1005Z			78-34-11	ALL
PERG	1F	W5170	1006Z			78-34-11	ALL
PERG	1F	W5170	1007Z			78-34-11	ALL
PERG	1F	W5170	1008Z			78-34-11	ALL
PERG	1F	W5170	1301Z			74-11-11	ALL
PERG	1F	W5170	1302Z			73-22-11	ALL
PERG	1F	W5170	2510Z			36-11-12	ALL
D48112J	**J048-00/ /**		**RCPT-**				**ALL**
A01		W0088	0008	22		21-27-21	ALL
A02		W0088	0023	24		24-33-11	ALL
A03		W0088	0034	22		30-11-11	ALL
A04	UNUSED						ALL
A05		W0088	0203	20		52-71-13	ALL
A06		W0088	0202	20		52-71-13	ALL
A07		W0088	0204	20		52-71-13	ALL
A08		W0088	0201	20		52-71-13	ALL
A09		W0088	0241	22		21-27-21	ALL
A10		W0088	0161	22		21-27-21	ALL
B01		W0088	0017	24		21-42-11	ALL
B02		W0088	0084	22		31-31-11	ALL
B03		W0088	0035	22		30-11-11	ALL
B04		W0088	0052	22		34-21-16	ALL
B05		W0088	0178	24		21-51-12	ALL
B06		W0088	0163	22		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D48112J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	B07	UNUSED						ALL
	B08		W0088	0189	22		27-33-11	ALL
	B09		W0088	0190	22		27-33-11	ALL
	B10		W0088	0191	22		27-33-11	ALL
D48112P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W5156	5514	22		21-27-21	ALL
	A02		W5156	0541	22		24-33-11	ALL
	A03		W5156	6016	22		30-11-11	ALL
	A04		W5156	0594	24		SPARE	ALL
	A05		W5156	0007	20		52-71-13	ALL
	A06		W5156	0005	20		52-71-13	ALL
	A07		W5156	0006	20		52-71-13	ALL
	A08		W5156	0569	20		52-71-13	ALL
	A09		W5156	5535	22		21-27-21	ALL
	A10		W5156	5531	22		21-27-21	ALL
	B01		W5156	5519	24		21-42-11	ALL
	B02		W5156	0529	22		31-31-11	ALL
	B03		W5156	6015	22		30-11-11	ALL
	B04		W5156	5515	22		34-21-16	ALL
	B05		W5156	5590	24		21-51-12	ALL
	B06		W5156	5508	22		21-27-21	ALL
	B07	UNUSED						ALL
	B08		W5156	0071	22		27-33-11	ALL
	B09		W5156	0070	22		27-33-11	ALL
	B10		W5156	0069	22		27-33-11	ALL
D48114J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	2013R	24		73-21-11	ALL
	A02		W0088	0076	24		76-21-11	ALL
	A03		W0088	0192	24		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48114J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A04		W0088	0048	22		32-64-21	ALL
	A05		W0088	0063	22		34-53-11	ALL
	A06		W0088	1005	20		73-22-11	ALL
	A07		W0088	0050	22		34-21-16	ALL
	A08		W0088	0164	22		21-27-21	ALL
	A09		W0088	2017R	20		78-32-51	ALL
	A10	UNUSED						ALL
	B01		W0088	2013B	24		73-21-11	ALL
	B02		W0088	0077	24		76-21-11	ALL
	B03	UNUSED						ALL
	B04		W0088	0049	22		32-64-21	ALL
	B05		W0088	0069	22		34-55-11	ALL
	B06		W0088	2017B	20		78-32-51	ALL
	B07		W0088	0123	22		SPARE	ALL
	B08		W0088	0124	22		SPARE	ALL
	B09		W0088	0125	22		SPARE	ALL
	B10		W0088	0126	22		SPARE	ALL
	PERG	1F	W0088	1005Z			73-22-11	ALL
	PERG	1F	W0088	2013Z			73-21-11	ALL
	PERG	1F	W0088	2017Z			78-32-51	ALL
D48114P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W5156	2601R	24		73-21-11	ALL
	A02		W5156	6010	24		76-21-11	ALL
	A03		W5156	6026	24		76-21-11	ALL
	A04		W5156	0570	22		32-64-21	ALL
	A05		W5156	0514	22		34-53-11	ALL
	A06		W5156	1301	20		73-22-11	ALL
	A07		W5156	5513	22		34-21-16	ALL
	A08		W5156	5532	22		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48114P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	A09		W5156	2501R	20		78-32-51	ALL
	A10	UNUSED						ALL
	B01		W5156	2601B	24		73-21-11	ALL
	B02		W5156	6011	24		76-21-11	ALL
	B03	UNUSED						ALL
	B04		W5156	0572	22		32-64-21	ALL
	B05		W5156	0515	22		34-55-11	ALL
	B06		W5156	2501B	20		78-32-51	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5156	1301Z			73-22-11	ALL
	PERG	1F	W5156	2501Z			78-32-51	ALL
	PERG	1F	W5156	2601Z			73-21-11	ALL
D48116J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0011	22		21-27-31	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W0088	0051	22		34-21-16	ALL
	A05		W0088	0191	22		27-33-11	ALL
	A06		W0088	0190	22		27-33-11	ALL
	A07		W0088	0189	22		27-33-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0088	0015	22		21-27-31	ALL
	B01		W0088	0012	22		21-27-31	ALL
	B02	UNUSED						ALL
	B03		W0088	0085	22		31-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48116J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B04	UNUSED						ALL
	B05		W0088	0206	20		52-71-14	ALL
	B06		W0088	0047	22		SPARE	ALL
	B07		W0088	0209	20		52-71-14	ALL
	B08		W0088	0208	20		52-71-14	ALL
	B09		W0088	0207	20		52-71-14	ALL
	B10		W0088	0014	22		21-27-31	ALL
D48116P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5158	0579	22		21-27-31	ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04		W5158	0675	22		34-21-16	ALL
	A05		W5158	0053	22		27-33-11	ALL
	A06		W5158	0054	22		27-33-11	ALL
	A07		W5158	0055	22		27-33-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5158	0670	22		21-27-31	ALL
	B01		W5158	0580	22		21-27-31	ALL
	B02	UNUSED						ALL
	B03		W5158	0684	22		31-31-11	ALL
	B04		W5158	0680	22		SPARE	ALL
	B05		W5158	0530	20		52-71-14	ALL
	B06		W5158	0678	22		SPARE	ALL
	B07		W5158	0012	20		52-71-14	ALL
	B08		W5158	0013	20		52-71-14	ALL
	B09		W5158	0011	20		52-71-14	ALL
	B10		W5158	0569	22		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48118J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0113R	22		26-21-11	ALL
	A02		W0088	0114R	22		26-21-11	ALL
	A03		W0088	0115R	22		26-21-11	ALL
	A04		W0088	0116R	22		26-21-11	ALL
	A05		W0088	0117R	22		26-21-11	ALL
	A06		W0088	0118R	22		26-21-11	ALL
	A07		W0088	0103R	22		26-21-11	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0088	0105R	22		26-21-11	ALL
	B01	UNUSED						ALL
	B02		W0088	0086R	22		26-21-11	ALL
	B03		W0088	0094R	22		26-21-11	ALL
	B04		W0088	0088R	22		26-21-11	ALL
	B05		W0088	0090R	22		26-21-11	ALL
	B06		W0088	0095R	22		26-21-11	ALL
	B07		W0088	0097R	22		26-21-11	ALL
	B08		W0088	0096R	22		26-21-11	ALL
	B09		W0088	0104R	22		26-21-11	ALL
	B10		W0088	1002	24		73-21-12	ALL
	PERG	1F	W0088	1002Z			73-21-12	ALL
D48118P		**J048-00/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01		W5506	6074R	22		26-21-11	ALL
	A02		W5506	6073R	22		26-21-11	ALL
	A03		W5506	6072R	22		26-21-11	ALL
	A04		W5506	6076R	22		26-21-11	ALL
	A05		W5506	6077R	22		26-21-11	ALL
	A06		W5506	6078R	22		26-21-11	ALL
	A07		W5506	6056R	22		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48118P		**J048-00/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5506	6065R	22		26-21-11	ALL
	B01	UNUSED						ALL
	B02		W5506	6054R	22		26-21-11	ALL
	B03		W5506	6055R	22		26-21-11	ALL
	B04		W5506	6057R	22		26-21-11	ALL
	B05		W5506	6058R	22		26-21-11	ALL
	B06		W5506	6059R	22		26-21-11	ALL
	B07		W5506	6061R	22		26-21-11	ALL
	B08		W5506	6060R	22		26-21-11	ALL
	B09		W5506	6064R	22		26-21-11	ALL
	B10		W5506	1001	24		73-21-12	ALL
	PERG	1F	W5506	1001Z			73-21-12	ALL
D48120J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0010	24		21-27-31	ALL
	A02		W0088	0013	22		21-27-31	ALL
	A03		W0088	0016	24		21-42-11	ALL
	A04		W0088	0028	20		28-21-11	ALL
	A05		W0088	0029	20		28-21-11	ALL
	A06		W0088	0033	20		29-33-11	ALL
	A07		W0088	0079	20		76-21-11	ALL
	A08		W0088	0080	20		76-21-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0088	0071	20		78-35-11	ALL
	B02	UNUSED						ALL
	B03		W0088	0165	24		21-43-21	ALL
	B04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D48120J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48120P		**J048-00/ /**		**PLUG**				**ALL**
	A01		W5506	5520	24		21-27-31	ALL
	A02		W5506	5514	22		21-27-31	ALL
	A03		W5506	5511	24		21-42-11	ALL
	A04		W5506	6031	20		28-21-11	ALL
	A05		W5506	6082	20		28-21-11	ALL
	A06		W5506	0515	24		29-33-11	ALL
	A07		W5506	6012	20		76-21-11	ALL
	A08		W5506	6089	20		76-21-11	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5506	6084	20		78-35-11	ALL
	B02	UNUSED						ALL
	B03		W5506	5523	24		21-43-21	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48122J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48122J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A02		W0088	0020	24		21-43-21	ALL
	A03	UNUSED						ALL
	A04		W0088	0049	22		32-64-21	ALL
	A05		W0088	0242	22		30-11-11	ALL
	A06		W0088	0029	20		28-21-11	ALL
	A07		W0088	0244	22		30-11-11	ALL
	A08		W0088	0243	22		30-11-11	ALL
	A09		W0088	0048	22		32-64-21	ALL
	A10		W0088	2002B	22		24-22-31	ALL
	B01		W0088	1006	20		74-11-11	ALL
	B02	UNUSED						ALL
	B03		W0088	0076	24		76-21-11	ALL
	B04		W0088	0077	24		76-21-11	ALL
	B05	UNUSED						ALL
	B06		W0088	0082	20		76-21-11	ALL
	B07		W0088	0078	20		76-21-11	ALL
	B08		W0088	0165	24		21-43-21	ALL
	B09	UNUSED						ALL
	B10		W0088	2002R	22		24-22-31	ALL
	DED		W0088	2002Z			24-22-31	ALL
	PERG	1F	W0088	1006Z			74-11-11	ALL
D48122P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W5510	5503	24		SPARE	ALL
	A02		W5510	5502	24		21-43-21	ALL
	A03	UNUSED						ALL
	A04		W5510	0572	22		32-64-21	ALL
	A05		W5510	6090	22		30-11-11	ALL
	A06		W5510	6013	20		28-21-11	ALL
	A07		W5510	6021	22		30-11-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48122P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	A08		W5510	6020	22		30-11-11	ALL
	A09		W5510	0570	22		32-64-21	ALL
	A10		W5510	2202B	22		24-22-31	ALL
	B01		W5510	1301	20		74-11-11	ALL
	B02	UNUSED						ALL
	B03		W5510	6002	24		76-21-11	ALL
	B04		W5510	6003	24		76-21-11	ALL
	B05	UNUSED						ALL
	B06		W5510	6005	20		76-21-11	ALL
	B07		W5510	6006	20		76-21-11	ALL
	B08		W5510	5511	24		21-43-21	ALL
	B09		W5510	5510	24		SPARE	ALL
	B10		W5510	2202R	22		24-22-31	ALL
	DED		W5510	2202Z			24-22-31	ALL
	PERG	1F	W5510	1301Z			74-11-11	ALL
D48124J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0006	24		21-27-21	ALL
	A02		W0088	0003	22		21-27-21	ALL
	A03		W0088	0009	22		21-27-21	ALL
	A04		W0088	0017	24		21-42-11	ALL
	A05		W0088	0120	22		24-22-11	ALL
	A06		W0088	0121	22		24-28-11	ALL
	A07		W0088	0122	22		24-28-11	ALL
	A08		W0088	0026	20		27-53-11	ALL
	A09		W0088	0027	20		27-53-11	ALL
	A10		W0088	0031	22		29-11-12	ALL
	B01		W0088	0032	22		29-11-12	ALL
	B02		W0088	0018	20		21-42-11	ALL
	B03		W0088	0019	20		21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48124J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W0088	0022	20		27-53-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48124P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W6110	5501	22		21-27-21	ALL
	A02		W6110	5508	20		21-27-21	ALL
	A03		W6110	5502	22		21-27-21	ALL
	A04		W6110	5514	24		21-42-11	ALL
	A05		W6110	0501	22		24-22-11	ALL
	A06		W6110	0508	22		24-28-11	ALL
	A07		W6110	0509	22		24-28-11	ALL
	A08		W6110	0525	20		27-53-11	ALL
	A09		W6110	0526	20		27-53-11	ALL
	A10		W6110	0511	22		29-11-12	ALL
	B01		W6110	0512	22		29-11-12	ALL
	B02		W6110	5517	20		21-42-11	ALL
	B03		W6110	5518	20		21-42-11	ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08		W6110	0514	20		27-53-11	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48125J		**J048-00/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W0088	0410	20		78-34-11	ALL
	A10		W0088	0408	20		78-34-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W0088	0409	20		78-34-11	ALL
	B10		W0088	0407	20		78-34-11	ALL
D48125P		**J048-00/ /**		**PLUG**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48125P		**J048-00/ /**		**PLUG (continued)**				**ALL**
	A09		W5506	0118	20		78-34-11	ALL
	A10		W5506	0116	20		78-34-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09		W5506	0117	20		78-34-11	ALL
	B10		W5506	0115	20		78-34-11	ALL
D48126J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0012	22		21-27-31	ALL
	A02		W0088	0010	24		21-27-31	ALL
	A03	UNUSED						ALL
	A04		W0088	0016	24		21-42-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D48126J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48126P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W5142	0100	22		21-27-31	ALL
	A02		W5142	0101	22		21-27-31	ALL
	A03	UNUSED						ALL
	A04		W5142	0102	22		21-42-11	ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48130J		**J048-00/ /**		**RCPT-**				**ALL**
	A01		W0088	0005	24		21-27-21	ALL
	A02		W0088	0001	22		21-27-21	ALL
	A03		W0088	0003	22		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48130J		**J048-00/ /**		**RCPT- (continued)**				**ALL**
	A04	UNUSED						ALL
	A05		W0088	0123	22		SPARE	ALL
	A06		W0088	0124	22		SPARE	ALL
	A07		W0088	0125	22		SPARE	ALL
	A08		W0088	0126	22		SPARE	ALL
	A09		W0088	0161	22		21-27-21	ALL
	A10		W0088	0162	22		21-27-21	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W0088	0178	24		21-51-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48130P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W6510	5504	24		21-27-21	ALL
	A02		W6510	5502	24		21-27-21	ALL
	A03		W6510	5503	24		21-27-21	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09		W6510	6009	22		21-27-21	ALL
	A10		W6510	6010	22		21-27-21	ALL
	B01	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48130P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05		W6510	0013	24		21-51-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
D48132J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0198R	20		26-21-11	ALL
	A02		W0088	2002R	22		24-22-31	ALL
	A03		W0088	2002B	22		24-22-31	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W0088	0218R	22		26-11-21	ALL
	A07		W0088	0220R	22		26-11-21	ALL
	A08		W0088	0239R	20		26-11-21	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0088	0199R	20		26-21-11	ALL
	B02		W0088	0222R	20		26-21-11	ALL
	B03		W0088	0223R	20		26-21-11	ALL
	B04	UNUSED						ALL
	B05		W0088	0226R	22		26-11-21	ALL
	B06		W0088	0227R	22		26-11-21	ALL
	B07		W0088	0219R	22		26-11-21	ALL
	B08		W0088	0221R	22		26-11-21	ALL
	B09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48132J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B10	UNUSED						ALL
	DED		W0088	2002Z			24-22-31	ALL
D48132P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W6506	6083R	22		26-21-11	ALL
	A02		W6506	2202R	22		24-22-31	ALL
	A03		W6506	2202B	22		24-22-31	ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W6506	6035R	22		26-11-21	ALL
	A07		W6506	6038R	22		26-11-21	ALL
	A08		W6506	6057R	20		26-11-21	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W6506	6082R	22		26-21-11	ALL
	B02		W6506	6068R	22		26-21-11	ALL
	B03		W6506	6074R	22		26-21-11	ALL
	B04	UNUSED						ALL
	B05		W6506	6032R	22		26-11-21	ALL
	B06		W6506	6034R	22		26-11-21	ALL
	B07		W6506	6036R	22		26-11-21	ALL
	B08		W6506	6037R	22		26-11-21	ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	DED		W6506	2202Z			24-22-31	ALL
D48136J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	2013R	24		73-21-11	ALL
	A02		W0088	2013B	24		73-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48136J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A05	UNUSED						ALL
	A06		W0088	2017B	20		78-32-51	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W0088	2017R	20		78-32-51	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0088	2013Z			73-21-11	ALL
	PERG	1F	W0088	2017Z			78-32-51	ALL
D48136P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W5172	2609R	24		73-21-11	ALL
	A02		W5172	2609B	24		73-21-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06		W5172	2201B	20		78-32-51	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48136P		**J048-00/ /**		**PLUG- (continued)**				**ALL**
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06		W5172	2201R	20		78-32-51	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5172	2201Z			78-32-51	ALL
	PERG	1F	W5172	2609Z			73-21-11	ALL
D48138J		**J048-00/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0088	0004	24		21-27-21	ALL
	A02		W0088	0093R	22		26-21-11	ALL
	A03		W0088	0087R	22		26-21-11	ALL
	A04		W0088	0089R	22		26-21-11	ALL
	A05		W0088	0091R	22		26-21-11	ALL
	A06		W0088	0098R	22		26-21-11	ALL
	A07		W0088	0099R	22		26-21-11	ALL
	A08		W0088	0101R	22		26-21-11	ALL
	A09		W0088	0102R	22		26-21-11	ALL
	A10		W0088	2098B	20		32-49-11	ALL
	B01	UNUSED						ALL
	B02		W0088	0107R	22		26-21-11	ALL
	B03	UNUSED						ALL
	B04		W0088	0109R	22		26-21-11	ALL
	B05		W0088	0110R	22		26-21-11	ALL
	B06		W0088	0111R	22		26-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48138J		**J048-00/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B07		W0088	0112R	22		26-21-11	ALL
	B08		W0088	2099R	20		32-49-11	ALL
	B09		W0088	2099B	20		32-49-11	ALL
	B10		W0088	2098R	20		32-49-11	ALL
	PERG	1F	W0088	2098Z			32-49-11	ALL
	PERG	1F	W0088	2099Z			32-49-11	ALL
D48138P		**J048-00/ /**		**PLUG-**				**ALL**
	A01		W6506	5510	24		21-27-21	ALL
	A02		W6506	6042R	22		26-21-11	ALL
	A03		W6506	6043R	22		26-21-11	ALL
	A04		W6506	6050R	22		26-21-11	ALL
	A05		W6506	6051R	22		26-21-11	ALL
	A06		W6506	6052R	22		26-21-11	ALL
	A07		W6506	6041R	22		26-21-11	ALL
	A08		W6506	6044R	22		26-21-11	ALL
	A09		W6506	6049R	22		26-21-11	ALL
	A10		W6506	2003B	20		32-49-11	ALL
	B01	UNUSED						ALL
	B02		W6506	6055R	22		26-21-11	ALL
	B03	UNUSED						ALL
	B04		W6506	6054R	22		26-21-11	ALL
	B05		W6506	6069R	22		26-21-11	ALL
	B06		W6506	6070R	22		26-21-11	ALL
	B07		W6506	6071R	22		26-21-11	ALL
	B08		W6506	2004R	20		32-49-11	ALL
	B09		W6506	2004B	20		32-49-11	ALL
	B10		W6506	2003R	20		32-49-11	ALL
	PERG	1F	W6506	2003Z			32-49-11	ALL
	PERG	1F	W6506	2004Z			32-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48202P	**E006-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
1	UNUSED						ALL
2		W3307	0102	22		44-21-22	ALL
3		W3307	0093	22		44-21-22	ALL
4	UNUSED						ALL
5	UNUSED						ALL
6		W3307	0106	22		44-21-22	ALL
7		W3307	2012R	22		44-21-22	ALL
8		W3307	2012B	22		44-21-22	ALL
9	UNUSED						ALL
10		W3307	2014R	22		44-21-22	ALL
11		W3307	2014B	22		44-21-22	ALL
12	UNUSED						ALL
13	UNUSED						ALL
14		W3307	2011R	22		44-21-22	ALL
15		W3307	2011B	22		44-21-22	ALL
16		W3307	2512R	22		44-21-22	ALL
17		W3307	2512B	22		44-21-22	ALL
18	UNUSED						ALL
19		W3307	0088	22		44-21-22	ALL
20		W3307	0089	22		44-21-22	ALL
21		W3307	0127	22		44-21-22	ALL
22		W3307	0128	22		44-21-22	ALL
23	UNUSED						ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL
28	UNUSED						ALL
29	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48202P	**E006-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
30	UNUSED						ALL
31	UNUSED						ALL
32	UNUSED						ALL
33	UNUSED						ALL
34	UNUSED						ALL
35	UNUSED						ALL
36	UNUSED						ALL
37	UNUSED						ALL
38	UNUSED						ALL
39	UNUSED						ALL
40	UNUSED						ALL
41	UNUSED						ALL
42	UNUSED						ALL
43	UNUSED						ALL
44	UNUSED						ALL
45	UNUSED						ALL
46	UNUSED						ALL
47	UNUSED						ALL
48	UNUSED						ALL
49	UNUSED						ALL
50	UNUSED						ALL
51	UNUSED						ALL
52	UNUSED						ALL
53	UNUSED						ALL
54	UNUSED						ALL
55	UNUSED						ALL
PERB		W3307	2011Z			44-21-22	ALL
PERB		W3307	2012Z			44-21-22	ALL
PERB		W3307	2014Z			44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48202P	**E006-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
PERB		W3307	2512Z			44-21-22	ALL
D48204J	**E006-01/ /**		**RCPT-**				**ALL**
1	UNUSED						ALL
2	UNUSED						ALL
3		W0611	2511R	22		44-21-20	ALL
4		W0611	2511B	22		44-21-20	ALL
5	UNUSED						ALL
6	UNUSED						ALL
7		W0611	2513R	22		44-21-20	ALL
8		W0611	2513B	22		44-21-20	ALL
9		W0611	2514R	22		44-21-20	ALL
10		W0611	2514B	22		44-21-20	ALL
11		W0611	2509R	22		44-21-20	ALL
12		W0611	2509B	22		44-21-20	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W0611	2516R	22		44-21-20	ALL
16		W0611	2516B	22		44-21-20	ALL
17	UNUSED						ALL
18		W0611	2556R	22		44-21-20	ALL
19		W0611	2556B	22		44-21-20	ALL
20	UNUSED						ALL
21		W0611	2557R	22		44-21-20	ALL
22		W0611	2557B	22		44-21-20	ALL
23		W0611	2555R	22		44-21-20	ALL
24		W0611	2555B	22		44-21-20	ALL
25	UNUSED						ALL
26	UNUSED						ALL
27	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48204J		**E006-01/ /**		**RCPT- (continued)**				**ALL**
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W0611	2509Z			44-21-20	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48204J	**E006-01/ /**		**RCPT- (continued)**				**ALL**
PERB		W0611	2511Z			44-21-20	ALL
PERB		W0611	2513Z			44-21-20	ALL
PERB		W0611	2514Z			44-21-20	ALL
PERB		W0611	2516Z			44-21-20	ALL
PERB		W0611	2555Z			44-21-20	ALL
PERB		W0611	2556Z			44-21-20	ALL
PERB		W0611	2557Z			44-21-20	ALL
D48204P	**E006-01/ /**		**PLUG**				**ALL**
1		W4477	2501R	22		44-21-20	ALL
2		W4477	2501B	22		44-21-20	ALL
3		W4477	2503R	22		44-21-20	ALL
4		W4477	2503B	22		44-21-20	ALL
5		W4477	2502R	22		44-21-20	ALL
6		W4477	2502B	22		44-21-20	ALL
7		W4477	2504R	22		44-21-20	ALL
8		W4477	2504B	22		44-21-20	ALL
9		W4477	2505R	22		44-21-20	ALL
10		W4477	2505B	22		44-21-20	ALL
11		W4477	2532R	22		44-35-12	ALL
12		W4477	2532B	22		44-35-12	ALL
13	UNUSED						ALL
14	UNUSED						ALL
15		W4477	2530R	22		44-35-12	ALL
16		W4477	2530B	22		44-35-12	ALL
17	UNUSED						ALL
18		W4477	2507R	22		44-35-12	ALL
19		W4477	2507B	22		44-35-12	ALL
20	UNUSED						ALL
21		W4477	2506R	22		44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48204P		**E006-01/ /**		**PLUG (continued)**				**ALL**
	22		W4477	2506B	22		44-35-12	ALL
	23		W4477	2531R	22		44-35-12	ALL
	24		W4477	2531B	22		44-35-12	ALL
	25	UNUSED						ALL
	26	UNUSED						ALL
	27	UNUSED						ALL
	28	UNUSED						ALL
	29	UNUSED						ALL
	30	UNUSED						ALL
	31	UNUSED						ALL
	32	UNUSED						ALL
	33	UNUSED						ALL
	34	UNUSED						ALL
	35	UNUSED						ALL
	36	UNUSED						ALL
	37	UNUSED						ALL
	38	UNUSED						ALL
	39	UNUSED						ALL
	40	UNUSED						ALL
	41	UNUSED						ALL
	42	UNUSED						ALL
	43	UNUSED						ALL
	44	UNUSED						ALL
	45	UNUSED						ALL
	46	UNUSED						ALL
	47	UNUSED						ALL
	48	UNUSED						ALL
	49	UNUSED						ALL
	50	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48204P		**E006-01/ /**		**PLUG (continued)**				**ALL**
	51	UNUSED						ALL
	52	UNUSED						ALL
	53	UNUSED						ALL
	54	UNUSED						ALL
	55	UNUSED						ALL
	PERB		W4477	2501Z			44-21-20	ALL
	PERB		W4477	2502Z			44-21-20	ALL
	PERB		W4477	2503Z			44-21-20	ALL
	PERB		W4477	2504Z			44-21-20	ALL
	PERB		W4477	2505Z			44-21-20	ALL
	PERB		W4477	2506Z			44-35-12	ALL
	PERB		W4477	2507Z			44-35-12	ALL
	PERB		W4477	2530Z			44-35-12	ALL
	PERB		W4477	2531Z			44-35-12	ALL
	PERB		W4477	2532Z			44-35-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D48501J		**E004-02/ /**		**RCPT**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	F		W0422	0132	18		24-32-11	ALL
	G	UNUSED						ALL
	H	UNUSED						ALL
	J		W0422	0130	18		24-32-11	ALL
	K		W0422	0131	18		24-32-11	ALL
D48501P		**E004-02/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48501P	**E004-02/ /**		**PLUG- (continued)**				**ALL**
A04	UNUSED						ALL
A05	UNUSED						ALL
A06	UNUSED						ALL
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01	UNUSED						ALL
B02	UNUSED						ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
F		W6128	0009	18		24-32-11	ALL
G	UNUSED						ALL
H	UNUSED						ALL
J		W6128	0007	18		24-32-11	ALL
K		W6128	0008	18		24-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48888J		**E003-01/198/L11**		**RCPT - CONDUCTIVE**				**ALL**
	A01		W0311	2990W	24		23-70-11	ALL
	A02		W0311	2991W	24		23-70-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0311	2990B	24		23-70-11	ALL
	B02		W0311	2991B	24		23-70-11	ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0311	2990Z			23-70-11	ALL
	PERG	1F	W0311	2991Z			23-70-11	ALL
D48888P		**E003-01/ /**		**PLUG**				**ALL**
	A01		W3710	2501W	24		23-70-11	ALL
	A02		W3710	2502W	24		23-70-11	ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D48888P	**E003-01/ /**		**PLUG (continued)**				**ALL**
A07	UNUSED						ALL
A08	UNUSED						ALL
A09	UNUSED						ALL
A10	UNUSED						ALL
B01		W3710	2501B	24		23-70-11	ALL
B02		W3710	2502B	24		23-70-11	ALL
B03	UNUSED						ALL
B04	UNUSED						ALL
B05	UNUSED						ALL
B06	UNUSED						ALL
B07	UNUSED						ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W3710	2501Z			23-70-11	ALL
PERG	1F	W3710	2502Z			23-70-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49001J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2157R	24		34-61-15	ALL
	A02		W0321	2377R	24		34-21-24	ALL
	A03		W0321	2239R	24		34-41-11	ALL
	A04	UNUSED						ALL
	A05		W0321	2230R	24		34-57-21	ALL
	A06		W0321	2352R	24		31-31-13	ALL
	A07		W0321	2348R	22		31-32-15	ALL
	A08		W0321	2245R	24		31-35-04	ALL
	A09		W0321	2256R	24		31-35-04	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W0321	2315R	24		27-61-47	ALL
	A17		W0321	2297R	24		34-51-21	ALL
	A18		W0321	2295R	24		34-51-21	ALL
	A19	UNUSED						ALL
	A20		W0321	2381R	24		31-65-24	ALL
	B01		W0321	2157B	24		34-61-15	ALL
	B02		W0321	2377B	24		34-21-24	ALL
	B03		W0321	2239B	24		34-41-11	ALL
	B04	UNUSED						ALL
	B05		W0321	2230B	24		34-57-21	ALL
	B06		W0321	2352B	24		31-31-13	ALL
	B07		W0321	2348B	22		31-32-15	ALL
	B08		W0321	2245B	24		31-35-04	ALL
	B09		W0321	2256B	24		31-35-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49001J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
B10	UNUSED						ALL
B11		W0321	0098	24		31-31-17	ALL
B12	UNUSED						ALL
B13	UNUSED						ALL
B14	UNUSED						ALL
B15	UNUSED						ALL
B16		W0321	2315B	24		27-61-47	ALL
B17		W0321	2297B	24		34-51-21	ALL
B18		W0321	2295B	24		34-51-21	ALL
B19	UNUSED						ALL
B20		W0321	2381B	24		31-65-24	ALL
PERG	1F	W0321	2157Z			34-61-15	ALL
PERG	1F	W0321	2230Z			34-57-21	ALL
PERG	1F	W0321	2239Z			34-41-11	ALL
PERG	1F	W0321	2245Z			31-35-04	ALL
PERG	1F	W0321	2256Z			31-35-04	ALL
PERG	1F	W0321	2295Z			34-51-21	ALL
PERG	1F	W0321	2297Z			34-51-21	ALL
PERG	1F	W0321	2315Z			27-61-47	ALL
PERG	1F	W0321	2348Z			31-32-15	ALL
PERG	1F	W0321	2352Z			31-31-13	ALL
PERG	1F	W0321	2377Z			34-21-24	ALL
PERG	1F	W0321	2381Z			31-65-24	ALL
D49001P	**E003-02/ /**		**PLUG**				**ALL**
A01		W5049	2510R	24		34-61-15	ALL
A02		W5049	2514R	24		34-21-24	ALL
A03		W5049	2507R	24		34-41-11	ALL
A04	UNUSED						ALL
A05		W5049	2509R	24		34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49001P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	A06		W5049	2518R	24		31-31-13	ALL
	A07		W5049	2517R	22		31-32-15	ALL
	A08		W5049	2515R	24		21-51-22	ALL
	A09		W5049	2516R	24		21-51-22	ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16		W5049	2522R	24		27-61-47	ALL
	A17		W5049	2520R	24		34-51-21	ALL
	A18		W5049	2521R	24		34-51-21	ALL
	A19	UNUSED						ALL
	A20		W5049	2527R	24		31-65-24	ALL
	B01		W5049	2510B	24		34-61-15	ALL
	B02		W5049	2514B	24		34-21-24	ALL
	B03		W5049	2507B	24		34-41-11	ALL
	B04	UNUSED						ALL
	B05		W5049	2509B	24		34-57-21	ALL
	B06		W5049	2518B	24		31-31-13	ALL
	B07		W5049	2517B	22		31-32-15	ALL
	B08		W5049	2515B	24		21-51-22	ALL
	B09		W5049	2516B	24		21-51-22	ALL
	B10	UNUSED						ALL
	B11		W5049	0004	24		31-31-17	ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49001P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	B15	UNUSED						ALL
	B16		W5049	2522B	24		27-61-47	ALL
	B17		W5049	2520B	24		34-51-21	ALL
	B18		W5049	2521B	24		34-51-21	ALL
	B19	UNUSED						ALL
	B20		W5049	2527B	24		31-65-24	ALL
	PERG	1F	W5049	2507Z			34-41-11	ALL
	PERG	1F	W5049	2509Z			34-57-21	ALL
	PERG	1F	W5049	2510Z			34-61-15	ALL
	PERG	1F	W5049	2514Z			34-21-24	ALL
	PERG	1F	W5049	2515Z			21-51-22	ALL
	PERG	1F	W5049	2516Z			21-51-22	ALL
	PERG	1F	W5049	2517Z			31-32-15	ALL
	PERG	1F	W5049	2518Z			31-31-13	ALL
	PERG	1F	W5049	2520Z			34-51-21	ALL
	PERG	1F	W5049	2521Z			34-51-21	ALL
	PERG	1F	W5049	2522Z			27-61-47	ALL
	PERG	1F	W5049	2527Z			31-65-24	ALL
D49002J		**E003-02/ /**		**RCPT-**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W0321	4000Z			46-13-11	ALL
	1-1		W0321	4000R	24		46-13-11	ALL
	1-2		W0321	4000Y	24		46-13-11	ALL
	1-3		W0321	4000B	24		46-13-11	ALL
	1-4		W0321	4000G	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49002J		**E003-02/ /**		**RCPT- (continued)**				**ALL**
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D49002P		**E003-02/ /**		**PLUG**				**ALL**
	2	UNUSED						ALL
	3	UNUSED						ALL
	=1		W2043	4002Z			46-13-11	ALL
	1-1		W2043	4002R	24		46-13-11	ALL
	1-2		W2043	4002Y	24		46-13-11	ALL
	1-3		W2043	4002B	24		46-13-11	ALL
	1-4		W2043	4002G	24		46-13-11	ALL
	2-1	UNUSED						ALL
	2-2	UNUSED						ALL
	2-3	UNUSED						ALL
	2-4	UNUSED						ALL
	3-1	UNUSED						ALL
	3-2	UNUSED						ALL
	3-3	UNUSED						ALL
	3-4	UNUSED						ALL
D49003J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	2350B	24		31-31-13	ALL
	A02		W0321	2408R	24		22-11-51	ALL
	A03		W0321	2342R	24		22-11-51	ALL
	A04		W0321	2414B	24		36-11-14	ALL
	A05		W0321	2010R	24		31-65-15	ALL
	A06		W0321	2249R	24		31-65-15	ALL
	A07		W0321	2085R	24		31-65-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49003J	**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
A08	UNUSED						ALL
A09		W0321	0636	22		22-11-31	ALL
A10	UNUSED						ALL
B01		W0321	2350R	24		31-31-13	ALL
B02		W0321	2408B	24		22-11-51	ALL
B03		W0321	2342B	24		22-11-51	ALL
B04		W0321	2414R	24		36-11-14	ALL
B05		W0321	2010B	24		31-65-15	ALL
B06		W0321	2249B	24		31-65-15	ALL
B07		W0321	2085B	24		31-65-16	ALL
B08	UNUSED						ALL
B09	UNUSED						ALL
B10	UNUSED						ALL
PERG	1F	W0321	2010Z			31-65-15	ALL
PERG	1F	W0321	2085Z			31-65-16	ALL
PERG	1F	W0321	2249Z			31-65-15	ALL
PERG	1F	W0321	2342Z			22-11-51	ALL
PERG	1F	W0321	2350Z			31-31-13	ALL
PERG	1F	W0321	2408Z			22-11-51	ALL
PERG	1F	W0321	2414Z			36-11-14	ALL
D49003P	**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
A01		W5111	2716B	24		31-31-13	ALL
A02		W5111	2752R	24		22-11-51	ALL
A03		W5111	2751R	24		22-11-51	ALL
A04		W5111	2721B	24		36-11-14	ALL
A05		W5111	2707R	24		31-65-15	ALL
A06		W5111	2709R	24		31-65-15	ALL
A07		W5111	2765R	24		31-65-16	ALL
A08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49003P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	A09		W5111	1701	22		22-11-31	ALL
	A10	UNUSED						ALL
	B01		W5111	2716R	24		31-31-13	ALL
	B02		W5111	2752B	24		22-11-51	ALL
	B03		W5111	2751B	24		22-11-51	ALL
	B04		W5111	2721R	24		36-11-14	ALL
	B05		W5111	2707B	24		31-65-15	ALL
	B06		W5111	2709B	24		31-65-15	ALL
	B07		W5111	2765B	24		31-65-16	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5111	2707Z			31-65-15	ALL
	PERG	1F	W5111	2709Z			31-65-15	ALL
	PERG	1F	W5111	2716Z			31-31-13	ALL
	PERG	1F	W5111	2721Z			36-11-14	ALL
	PERG	1F	W5111	2751Z			22-11-51	ALL
	PERG	1F	W5111	2752Z			22-11-51	ALL
	PERG	1F	W5111	2765Z			31-65-16	ALL
D49004J		**E003-02/ /**		**RCPT - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W0321	0432	24		31-35-05	ALL
	A09	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49004J		**E003-02/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W0321	0433	24		31-35-05	ALL
	B03		W0321	2090R	24		31-35-04	ALL
	B04		W0321	2090B	24		31-35-04	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2090Z			31-35-04	ALL
D49004P		**E003-02/ /**		**PLUG - CONDUCTIVE**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08		W5610	0026	24		31-35-05	ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01	UNUSED						ALL
	B02		W5610	0027	24		31-35-05	ALL
	B03		W5610	2010R	24		31-35-04	ALL
	B04		W5610	2010B	24		31-35-04	ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49004P		**E003-02/ /**		**PLUG - CONDUCTIVE (continued)**				**ALL**
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5610	2010Z			31-35-04	ALL
D49005J		**404/198/L033**		**RCPT-**				**ALL**
	A		W5526	0601	20		78-34-11	ALL
	B		W5526	0602	20		78-34-11	ALL
	C	UNUSED						ALL
D49005P		**404/198/L033**		**PLUG-**				**ALL**
	A		W5156	6030	20		78-34-11	ALL
	B		W5156	6031	20		78-34-11	ALL
	C	UNUSED						ALL
D49007J		**E003-02/ /**		**RCPT-CONDUCTIVE**				**ALL**
	A01		W0321	0567	24		23-12-41	ALL
	A02		W0321	0568	24		23-12-41	ALL
	A03		W0321	2255R	24		23-12-41	ALL
	A04		W0321	2254R	24		23-12-41	ALL
	A05		W0321	2251R	24		23-12-41	ALL
	A06		W0321	2253R	24		23-12-41	ALL
	A07		W0321	2252R	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W0321	0569	24		23-12-41	ALL
	B02	UNUSED						ALL
	B03		W0321	2255B	24		23-12-41	ALL
	B04		W0321	2254B	24		23-12-41	ALL
	B05		W0321	2251B	24		23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49007J		**E003-02/ /**		**RCPT-CONDUCTIVE (continued)**				**ALL**
	B06		W0321	2253B	24		23-12-41	ALL
	B07		W0321	2252B	24		23-12-41	ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W0321	2251Z			23-12-41	ALL
	PERG	1F	W0321	2252Z			23-12-41	ALL
	PERG	1F	W0321	2253Z			23-12-41	ALL
	PERG	1F	W0321	2254Z			23-12-41	ALL
	PERG	1F	W0321	2255Z			23-12-41	ALL
D49007P		**E003-02/ /**		**PLUG**				**ALL**
	A01		W5049	0001	24		23-12-41	ALL
	A02		W5049	0002	24		23-12-41	ALL
	A03		W5049	2506R	24		23-12-41	ALL
	A04		W5049	2505R	24		23-12-41	ALL
	A05		W5049	2502R	24		23-12-41	ALL
	A06		W5049	2504R	24		23-12-41	ALL
	A07		W5049	2503R	24		23-12-41	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	B01		W5049	0003	24		23-12-41	ALL
	B02	UNUSED						ALL
	B03		W5049	2506B	24		23-12-41	ALL
	B04		W5049	2505B	24		23-12-41	ALL
	B05		W5049	2502B	24		23-12-41	ALL
	B06		W5049	2504B	24		23-12-41	ALL
	B07		W5049	2503B	24		23-12-41	ALL
	B08	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49007P		**E003-02/ /**		**PLUG (continued)**				**ALL**
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	PERG	1F	W5049	2502Z			23-12-41	ALL
	PERG	1F	W5049	2503Z			23-12-41	ALL
	PERG	1F	W5049	2504Z			23-12-41	ALL
	PERG	1F	W5049	2505Z			23-12-41	ALL
	PERG	1F	W5049	2506Z			23-12-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49947J	**221/193/R034**		**RCPT**				**ALL**
A		W5160	2227R	20		32-31-12	ALL
B	UNUSED						ALL
C		W5160	2227B	20		32-31-12	ALL
D49947P	**222/193/R034**		**PLUG**				**ALL**
A		W5156	2619R	20		32-31-12	ALL
B	UNUSED						ALL
C		W5156	2619B	20		32-31-12	ALL
D49949J	**281/186/L022**		**RCPT**				**ALL**
1		W5156	2621R	24		32-64-31	ALL
2		W5156	2621B	24		32-64-31	ALL
3		W5156	2621Z			32-64-31	ALL
D49949P	**281/186/L022**		**PLUG**				**ALL**
1		W5158	2612R	24		32-64-31	ALL
2		W5158	2612B	24		32-64-31	ALL
3		W5158	2612Z			32-64-31	ALL
D49961J	**411/198/R032**		**RCPT-**				**ALL**
A		W2218	0518	20		27-61-43	ALL
B		W2218	0520	20		27-61-43	ALL
C	UNUSED						ALL
D49961P	**411/198/R032**		**PLUG**				**ALL**
A		W6032	0542	20		27-61-43	ALL
B		W6032	0512	20		27-61-43	ALL
C	UNUSED						ALL
D49994J	**E003-01/ /**		**RCPT - CONDUCTIVE**				**ALL**
A01		W0311	2065R	24		77-12-11	ALL
A02		W0311	3001R	24		79-31-11	ALL
A03		W0311	3001B	24		79-31-11	ALL
A04		W0311	0090	24		29-31-11	ALL
A05		W0311	0092	24		29-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49994J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	A06		W0311	2050B	24		73-24-12	ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL
	A20	UNUSED						ALL
	B01		W0311	2065B	24		77-12-11	ALL
	B02		W0311	3001Y	24		79-31-11	ALL
	B03	UNUSED						ALL
	B04		W0311	0091	24		29-31-11	ALL
	B05		W0311	2050R	24		73-24-12	ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49994J		**E003-01/ /**		**RCPT - CONDUCTIVE (continued)**				**ALL**
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W0311	2050Z			73-24-12	ALL
	PERG	1F	W0311	2065Z			77-12-11	ALL
	PERG	1F	W0311	3001Z			79-31-11	ALL
D49994P		**E003-01/ /**		**PLUG-CONDUCTIVE**				**ALL**
	A01		W3170	2605R	24		77-12-11	ALL
	A02		W3170	3601R	24		79-31-11	ALL
	A03		W3170	3601B	24		79-31-11	ALL
	A04		W3170	0501	24		29-31-11	ALL
	A05		W3170	0503	24		29-31-11	ALL
	A06		W3170	2611B	24		73-24-12	ALL
	A07		W3170	2606B	20		SPARE	ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10	UNUSED						ALL
	A11	UNUSED						ALL
	A12	UNUSED						ALL
	A13	UNUSED						ALL
	A14	UNUSED						ALL
	A15	UNUSED						ALL
	A16	UNUSED						ALL
	A17	UNUSED						ALL
	A18	UNUSED						ALL
	A19	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49994P		**E003-01/ /**		**PLUG-CONDUCTIVE (continued)**				**ALL**
	A20	UNUSED						ALL
	B01		W3170	2605B	24		77-12-11	ALL
	B02		W3170	3601Y	24		79-31-11	ALL
	B03	UNUSED						ALL
	B04		W3170	0502	24		29-31-11	ALL
	B05		W3170	2611R	24		73-24-12	ALL
	B06		W3170	2606R	20		SPARE	ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10	UNUSED						ALL
	B11	UNUSED						ALL
	B12	UNUSED						ALL
	B13	UNUSED						ALL
	B14	UNUSED						ALL
	B15	UNUSED						ALL
	B16	UNUSED						ALL
	B17	UNUSED						ALL
	B18	UNUSED						ALL
	B19	UNUSED						ALL
	B20	UNUSED						ALL
	PERG	1F	W3170	2605Z			77-12-11	ALL
	PERG	1F	W3170	2606Z			SPARE	ALL
	PERG	1F	W3170	2611Z			73-24-12	ALL
	PERG	1F	W3170	3601Z			79-31-11	ALL
D49996J		**E002-01/ /**		**RCPT-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49996J		**E002-01/ /**		**RCPT- (continued)**				**ALL**
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W0212	0213	20		28-23-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W0212	0214	20		28-23-11	ALL
	F		W0212	3202R	18		28-23-11	ALL
	G		W0212	3202Y	18		28-23-11	ALL
	H		W0212	3202B	18		28-23-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL
D49996P		**E002-01/ /**		**PLUG-**				**ALL**
	A01	UNUSED						ALL
	A02	UNUSED						ALL
	A03	UNUSED						ALL
	A04	UNUSED						ALL
	A05	UNUSED						ALL
	A06	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
D49996P		**E002-01/ /**		**PLUG- (continued)**				**ALL**
	A07	UNUSED						ALL
	A08	UNUSED						ALL
	A09	UNUSED						ALL
	A10		W5112	0214	20		28-23-11	ALL
	B01	UNUSED						ALL
	B02	UNUSED						ALL
	B03	UNUSED						ALL
	B04	UNUSED						ALL
	B05	UNUSED						ALL
	B06	UNUSED						ALL
	B07	UNUSED						ALL
	B08	UNUSED						ALL
	B09	UNUSED						ALL
	B10		W5112	0215	20		28-23-11	ALL
	F		W5112	3205R	18		28-23-11	ALL
	G		W5112	3205Y	18		28-23-11	ALL
	H		W5112	3205B	18		28-23-11	ALL
	J	UNUSED						ALL
	K	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D70007J		**405/197/L035**		**REPT-**				**ALL**
	=1	VS	W6420	0313	24		36-11-13	ALL
D70007P		**407/198/L035**		**PLUG - QUICK DISC**				**ALL**
	=1	VR	W2112	6085	24		36-11-13	ALL
D70046J		**338/291/L019**		**RCPT-**				**ALL**
	A		W6212	0003	20		44-21-10	ALL
	B		W6212	0004	20		44-21-10	ALL
	C	UNUSED						ALL
D70046P		**338/291/L019**		**PLUG-**				**ALL**
	A		W3477	0001	20		44-21-10	ALL
	B		W3477	0051	20		44-21-10	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
D71133J		**405/294/R019**		**PLUG - QUICK DISC**				**ALL**
	A		W3453	0053	20		44-35-11	ALL
	B		W3453	0056	20		44-35-11	ALL
	C	UNUSED						ALL
D71133P		**405/294/R019**		**PLUG**				**ALL**
	A		W3477	0122	20		44-35-11	ALL
	B		W3477	0125	20		44-35-11	ALL
	C	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
DA17859	**467/305/R005**		**INSERT A - PLUG**				**ALL**
1		W4920	0006	22		46-13-52	ALL
2	UNUSED						ALL
3	UNUSED						ALL
4	UNUSED						ALL
5	UNUSED						ALL
6	UNUSED						ALL
7	UNUSED						ALL
8	UNUSED						ALL
9	UNUSED						ALL
10	UNUSED						ALL
11	UNUSED						ALL
12	UNUSED						ALL
13	UNUSED						ALL
14	UNUSED						ALL
15	UNUSED						ALL
16	UNUSED						ALL
17	UNUSED						ALL
18	UNUSED						ALL
19	UNUSED						ALL
20	UNUSED						ALL
21	UNUSED						ALL
22	UNUSED						ALL
23		W4920	0005	22		46-13-52	ALL
24	UNUSED						ALL
25	UNUSED						ALL
26	UNUSED						ALL
27		W4920	0003	22		46-13-52	ALL
28		W4920	0004	22		46-13-52	ALL
29		W4920	0001	22		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
DA17859		**467/305/R005**		**INSERT A - PLUG (continued)**				**ALL**
	30		W4920	0002	22		46-13-52	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
DM7777		**532/195/L67**		**FEED-THRU (OF W1186 AT STA 540L)**				**ALL**
	PERB		W1186	YAAB			24-21-11	ALL
	PERB		W1186	YAAC			24-21-11	ALL
	PERB		W1186	YAAD			24-21-11	ALL
DM7778		**532/195/R67**		**FEED-THRU (OF W1286 AT STA 540R)**				**ALL**
	PERB		W1286	YAAB			24-21-21	ALL
	PERB		W1286	YAAC			24-21-21	ALL
	PERB		W1286	YAAD			24-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
G00013		**1100/232/R010**		**STARTER/GENERATOR-AUXILIARY POWER UNIT**				**ALL**
	T1	R	W4722	0001	02		24-21-31	ALL
	T2	R	W4722	0002	02		24-21-31	ALL
	T3	R	W4722	0003	02		24-21-31	ALL
	N	R	W4722	0004	04		24-21-31	ALL
G00016		**ENG/ /**		**GEN-INTEGRATED DRIVE**				**ALL**
	T1	R	W1062	1001	02		24-21-11	ALL
	T2	R	W1062	1002	02		24-21-11	ALL
	T3	R	W1062	1003	02		24-21-11	ALL
	N	R	W1062	1004	04		24-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
GD00085		**727A+7/300/R002**		**GND-**				**ALL**
	ST..	=	W5275	0003	20		34-57-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
L00001		**P005-00/ /**		**LT-EMERG EXIT UNARMED**				**ALL**
	1	B	W2114	0010	20		33-51-11	ALL
	2	B	W2508	5579	20		33-18-37	ALL
	3	B	W2508	5576	20		33-18-37	ALL
	4	B	W2508	5578	20		33-18-37	ALL
L00009		**221/264/R015**		**LT-MAP (F/O)**				**ALL**
	=G		W2204	B-BG			33-17-11	ALL
	=P		W2204	B-BP			33-17-11	ALL
L00012		**265/243/R022**		**LT-F/OBS READING**				**ALL**
	=G		W0044	A-AG			33-17-11	ALL
	=P		W0044	A-AH			33-17-11	ALL
L00023		**342/277/L027**		**LT-NO SMOKING FASTEN SEAT BELTS SIGN**				**ALL**
	1	C	W0026	0001	20		33-25-21	ALL
	2	C	W0026	0002	18		33-25-21	ALL
	3	C	W0026	0003	18		33-25-21	ALL
L00034		**500C+10/222/L074**		**LT-WING ILLUMINATION-LEFT**				**ALL**
	PWR	E	W3142	0034	18		33-41-11	ALL
	RTN	E	W3142	0061	18		33-41-11	ALL
	CASE	E	W3142	0062	18		33-41-11	ALL
L00035		**500C+10/222/R074**		**LT-WING ILLUMINATION-RIGHT**				**ALL**
	PWR	E	W4142	0034	18		33-41-11	ALL
	RTN	E	W4142	0071	18		33-41-11	ALL
	CASE	E	W4142	0072	18		33-41-11	ALL
L00047		**P005-00/ /**		**LT-EQUIP COOLING EXHAUST OFF**				**ALL**
	1	B	W2112	5589	20		33-18-37	ALL
	1	B	W2112	5590	20		33-18-37	ALL
	2	B	W2112	5502	22		21-27-21	ALL
	4	B	W2508	5574	20		33-18-37	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
L00194		**463/198/R064**		**LT-FWD CARGO DOOR SILL**				**ALL**
	PWR	C	W5248	0002	20		33-36-11	ALL
	RTN	C	W5248	0012	20		33-36-11	ALL
L00195		**795/199/R064**		**LT-AFT CARGO DOOR SILL**				**ALL**
	PWR	C	W6248	0180	20		33-36-12	ALL
	RTN	C	W6248	0280	20		33-36-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
L00205		**1089/220/L003**		**LT-APU SERVICE LIGHT**				**ALL**
	A	G7	W7538	1005	18		33-35-11	ALL
	B	G7	W7538	1004	18		33-35-11	ALL
			W7538	1004Z			33-35-11	ALL
			W7538	1005Z			33-35-11	ALL
L00273		**270/274/L017**		**LIGHT-WHITEDOME, LEFT**				**ALL**
	=G	C	W2508	5613	20		33-14-12	ALL
	=P	C	W2508	5523	20		33-14-12	ALL
L00274		**254/274/R016**		**LIGHT-WHITEDOME, RIGHT**				**ALL**
	=G		W0044	A-AB			33-14-12	ALL
	=P		W0044	A-AA			33-14-12	ALL
L00277		**P005-00/ /**		**LIGHT-CONTROL STAND**				**ALL**
	=G		W2218	A-AB			33-14-12	ALL
	=P		W2218	A-AA			33-14-12	ALL
L00278		**1181/289/L009**		**LT-TAIL CONE**				**ALL**
	=G	G7	W7150	1202	18		33-35-11	ALL
	=P	BK	W7150	1203	18		33-35-11	ALL
			W7150	1202Z			33-35-11	ALL
			W7150	1203Z			33-35-11	ALL
L00279		**RW380/P04/RLE**		**LT-OUTBOARD REFUEL NOZZLE FLOOD**				**ALL**
	=A		W1664	A-C			28-44-11	ALL
L00280		**RW350/M03/RLE**		**LT-OUTBOARD REFUEL PANEL FLOOD**				**ALL**
	=A		W1664	A-B			28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L00342	**P007-00/ /**		**LT-MASTER CAUTION DISPLAY,LEFT**				**ALL**
1	C	W0104	5508	20		31-52-25	ALL
2	C	W0104	5509	20		31-52-71	ALL
3	C	W0104	5510	20		31-52-41	ALL
4	C	W0104	5511	20		31-52-31	ALL
5	C	W0104	5512	20		31-52-35	ALL
6	C	W0104	5513	20		31-52-45	ALL
7	C	W0104	5501	20		31-52-11	ALL
8	C	W0104	5502	20		31-52-11	ALL
9	C	W0104	5503	20		31-52-11	ALL
L00343	**P007-00/ /**		**LT-MASTER CAUTION DISPLAY,RIGHT**				**ALL**
1	C	W0204	5508	20		31-52-55	ALL
2	C	W0204	5509	20		31-52-21	ALL
3	C	W0204	5510	20		31-52-65	ALL
4	C	W0204	5511	20		31-52-61	ALL
5	C	W0204	5512	20		31-52-75	ALL
6	C	W0204	5513	20		31-52-51	ALL
7	C	W0204	5501	20		31-52-11	ALL
8	C	W0204	5502	20		31-52-11	ALL
9	C	W0204	5503	20		31-52-11	ALL
L00348	**P019-00/ /**		**LT-EXT PWR CONN**				**ALL**
=G	Z	W0048	0503	22		24-41-11	ALL
=P	Z	W0048	0504	22		24-41-11	ALL
L00349	**P019-00/ /**		**LT-EXT PWR NOT IN USE**				**ALL**
=G	Z	W0048	2201R	22		24-41-11	ALL
=P	Z	W0048	2201B	22		24-41-11	ALL
L00382	**P010-00/226/L002**		**LT-PARKING BRAKE**				**ALL**
1		W0008	C-BK			33-18-61	ALL
4		W0008	C-RD			33-18-61	ALL
5		W0008	C-GN			33-18-61	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
L00383		**P005-00/ /**		**LT PLT- P5 MISC, HORIZONTAL**				**ALL**
	=G	G	W2218	5609	20		33-12-12	ALL
	=P	B	W2218	5608	20		33-12-12	ALL
L00384		**P005-00/ /**		**LT PLT- P5 MISC, VERTICAL**				**ALL**
	=G	G	W2218	5605	20		33-12-12	ALL
	=P	B	W2218	5604	20		33-12-12	ALL
L00399		**P010-00/ /**		**LT PLT-FLAP POS P10 PNL**				**ALL**
	GND	B	W0008	0012	20		33-11-41	ALL
	PWR	B	W0008	0011	20		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L00400		**P010-00/ /**		**LT PLT-STAB TRIM, CAPT**				**ALL**
	GND	B	W0008	0010	20		33-11-41	ALL
	PWR	B	W0008	0009	20		33-11-41	ALL
L00401		**P010-00/ /**		**LT PLT-STAB TRIM, F/O**				**ALL**
	GND	B	W0008	0014	20		33-11-41	ALL
	PWR	B	W0008	0013	20		33-11-41	ALL
L00410		**243/237/L046**		**LIGHT- P18 CIRCUT BREAKER PANEL**				**ALL**
	=G	C	W2102	5517	18		33-14-12	ALL
	=P		W2102	J-JP			33-14-12	ALL
L00411		**245/257/L033**		**LIGHT-P18 CIRCUIT BREAKER PANEL**				**ALL**
	=P	C	W2102	5503	18		33-14-12	ALL
L00412		**235/268/R013**		**LIGHT-PG CIRCUIT BREAKER PANEL**				**ALL**
	=G	E	W2204	5507	18		33-14-12	ALL
	=P	C	W2204	5506	18		33-14-12	ALL
L00413		**250/207/R026**		**LIGHT-P6 CIRCUIT BREAKER PANEL**				**ALL**
	=P	C	W2204	5504	18		33-14-12	ALL
L00414		**243/237/R046**		**LIGHT-P6 CIRCUIT BREAKER PANEL**				**ALL**
	=G	C	W2204	5503	18		33-14-12	ALL
	=P		W2204	D-DP			33-14-12	ALL
L00462		**P010-00/ /**		**LT PLT-SPEED BRAKE POS LTS**				**ALL**
	GND	B	W0008	0039	20		33-11-41	ALL
	PWR	B	W0008	0015	20		33-11-41	ALL
L00481		**P005-00/ /**		**LT-RIGHT MAIN GEAR SYS 2**				**ALL**
	1	B	W2508	5622	20		33-18-42	ALL
	1	B	W2508	5624	20		33-18-42	ALL
	2	B	W2218	0602	24		32-64-12	ALL
	3	B	W2508	5620	20		33-18-42	ALL
	3	B	W2508	5625	20		33-18-42	ALL
	4	B	W2508	5623	20		33-18-42	ALL
	4	B	W2508	5627	20		33-18-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L00482		**P005-00/ /**		**LT-LEFT MAIN GEAR SYS 2**				**ALL**
	1	B	W2508	5624	20		33-18-42	ALL
	2	B	W2218	0603	24		32-64-12	ALL
	3	B	W2508	5625	20		33-18-42	ALL
	3	B	W2508	5626	20		33-18-42	ALL
	4	B	W2508	5627	20		33-18-42	ALL
	4	B	W2508	5628	20		33-18-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01001		**P005-00/ /**		**LT-NOSE GEAR SYS 2**				**ALL**
	1	B	W2508	5621	20		33-18-42	ALL
	1	B	W2508	5622	20		33-18-42	ALL
	2	B	W2218	0601	24		32-64-12	ALL
	3	B	W2508	5620	20		33-18-42	ALL
	4	B	W2508	5623	20		33-18-42	ALL
L01004		**229/268/R016**		**LT- CHART, F/O**				**ALL**
	=G	C	W2204	5510	20		33-17-11	ALL
	=P	C	W2204	5511	20		33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01141		**P005-00/ /**		**LT-EQUIP COOLING SUPPLY OFF**				**ALL**
	1	B	W2112	5585	20		33-18-37	ALL
	1	B	W2112	5590	20		33-18-37	ALL
	2	B	W2216	5501	22		21-27-31	ALL
	4	B	W2508	1023	20		33-18-37	ALL
	4	B	W2508	5574	20		33-18-37	ALL
	4	B	W2508	5575	20		33-18-37	ALL
L01146		**MULTI/289/**		**SIGN-LAV OCCUPIED**				**ALL**
	=G	Z	W0158	0008	20		33-26-31	ALL
	=G	Z3	W0144	0002	20		33-26-31	ALL
	=P	Z	W0144	0001	20		33-26-31	ALL
	=P	Z3	W0158	0009	20		33-26-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01240		**P007-00/ /**		**LIGHT PLATE-REMOTE CLOCK/PTT SW, CAPT**				**ALL**
	=G	G	W0104	5528	20		33-11-31	ALL
	=P	B	W0104	5527	20		33-11-31	ALL
L01241		**P007-00/ /**		**LIGHT PLATE-REMOTE CLOCK/PTT SW, F/O**				**ALL**
	=G	G	W0204	5528	20		33-11-21	ALL
	=P	B	W0204	5527	20		33-11-21	ALL
L01293		**J023-00/ /**		**LT-EQUIP COOL SPLY SMK DET CONN**				**ALL**
	+	B	W0098	0129	22		26-19-11	ALL
	+	B	W0098	0130	22		26-19-11	ALL
	-	B	W0098	0131	22		26-19-11	ALL
L01294		**J023-00/ /**		**LT-EQUIP COOL EXH SMK DET CONN**				**ALL**
	+	B	W0098	0130	22		26-19-11	ALL
	-	B	W0098	0132	22		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01300		**323/289/R021**		**FLUORESCENT LAMP - COOL WHITE**				**ALL**
	=A		W0010	A-A			33-26-21	ALL
	=B		W0010	A-B			33-26-21	ALL
	=C		W0010	A-C			33-26-21	ALL
	=D		W0010	A-D			33-26-21	ALL
L01301		**331/289/L014**		**LT-WORK**				**ALL**
	=G	I	W0142	0015	20		33-26-11	ALL
	=P	I	W0142	0016	22		33-26-11	ALL
L01302		**971/288/R034**		**LT-WORK**				**ALL**
	=G	C	W0442	0006	22		33-26-11	ALL
	=P	C	W0442	0005	22		33-26-11	ALL
L01303		**960/288/L032**		**LT-WORK**				**ALL**
	=G	C	W0452	0006	22		33-26-11	ALL
	=P	C	W0452	0005	22		33-26-11	ALL
L01308		**1132/239/R017**		**LT-APU SERVICE**				**ALL**
	A	G7	W7538	1007	18		33-35-11	ALL
	B	G7	W7538	1006	18		33-35-11	ALL
			W7538	1006Z			33-35-11	ALL
			W7538	1007Z			33-35-11	ALL
L01309								**ALL**
	CAP	Y	W5146	0203	20		38-32-13	ALL
	CAP	Y	W5146	0250	20		38-32-13	ALL
L01383		**P005-00/ /**		**LT-ASSIST ON**				**ALL**
	1	B	W2218	6601	20		33-18-41	ALL
	2	B	W2508	0052	20		31-52-25	ALL
	3	B	W2508	1017	20		33-18-41	ALL
	4	B	W2508	1018	20		33-18-41	ALL
L01384		**P010-00/ /**		**LT PLT-ENGINE FUEL CUTOFF CONTROL**				**ALL**
	GND	B	W0008	0017	20		33-11-41	ALL
	PWR	B	W0008	0016	20		33-11-41	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01456		**234/260/L030**		**LIGHT- CHART, CAPT**				**ALL**
	=G	C	W2102	5530	20		33-17-11	ALL
	=P	C	W2102	5529	20		33-17-11	ALL
L01462		**723/171/R013**		**NGS - LED HOLDER (GREEN)**				**ALL**
	+	B	W0063	1002	20		47-30-11	ALL
	-	B	W0063	1001	20		47-30-11	ALL
	-	B	W0063	1005	20		47-30-11	ALL
L01463		**723/169/R013**		**NGS - LED HOLDER (BLUE)**				**ALL**
	+	B	W0063	1003	20		47-30-11	ALL
	-	B	W0063	1005	20		47-30-11	ALL
	-	B	W0063	1006	20		47-30-11	ALL
L01464		**723/167/R013**		**NGS - LED HOLDER (AMBER)**				**ALL**
	+	B	W0063	1004	20		47-30-11	ALL
	-	B	W0063	1006	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L01554		**P005-00/ /**		**LT-EQUIP COOL SMOKE**				**ALL**
	1	B	W2112	5585	20		33-18-37	ALL
	2	B	W2508	0041	22		26-19-11	ALL
	3	B	W2508	1021	20		33-18-37	ALL
	4	B	W2508	1023	20		33-18-37	ALL
L01555		**P005-00/ /**		**LIGHT - MAINT**				**ALL**
	1	B	W2508	5654	20		33-18-42	ALL
	2	B	W2508	0018	22		31-65-41	ALL
	3	B	W2508	5656	20		33-18-42	ALL
	4	B	W2508	0019	20		31-65-41	ALL
	4	B	W2508	5655	20		33-18-42	ALL
L01556		**P005-00/ /**		**LT PLT- ELEVATOR JAM/LANDING ASSIST/DOME**				**ALL**
	=G	G	W2218	5675	20		33-12-12	ALL
	=P	B	W2218	5674	20		33-12-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
L03014		**249/245/L026**		**LT-MAP(CAPT)**				**ALL**
	=G		W2102	B-BG			33-17-11	ALL
	=P		W2102	B-BP			33-17-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M00005		**E002-01/ /**		**BATTERY CHARGER**				**ALL**
	+	R	W2532	0538	02		24-31-11	ALL
	-	Q	W2532	0534	02		24-31-11	ALL
M00009		**E002-02/184/L040**		**STATIC INVERTER-**				**ALL**
	+	Q	W2536	0506	08		24-34-11	ALL
	-	P	W2536	0513	08		24-34-11	ALL
M00053		**220/186/R004**		**HORN-GRD CREW CALL**				**ALL**
	=G	C	W6024	0513	22		23-43-11	ALL
	=P	C	W6024	0512	22		23-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M00157		**310/290/L030**		**SPEAKER-FWD ATTD**				**ALL**
	4K	Z	W0352	2001R	22		23-31-04	ALL
	COM	Z	W0352	2001B	22		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M00200		**995/186/L019**		**HTR ASSY-AFT DRAIN MAST**				**ALL**
	=G		W6248	E-B			30-71-11	ALL
	GRA		W6248	E-C			30-71-11	ALL
M00207		**P006-00/ /**		**DIODE-MASTER DIM**				**ALL**
	=A	F	W0044	0123	20		33-18-11	ALL
	=C	L	W0044	1101	20		33-18-11	ALL
M00208		**P006-00/ /**		**DIODE-MASTER DIM**				**ALL**
	=A	F	W0044	0134	20		33-18-11	ALL
	=A	F	W0044	0146	20		33-18-11	ALL
	=C	L	W0044	1102	20		33-18-11	ALL
M00209		**P006-00/ /**		**DIODE-MASTER DIM**				**ALL**
	=A	F	W0044	0135	20		33-18-11	ALL
	=A	F	W0044	0148	20		33-18-11	ALL
	=C	L	W0044	1104	20		33-18-11	ALL
M00210		**P006-00/ /**		**DIODE-MASTER DIM**				**ALL**
	=A	F	W0044	0136	20		33-18-11	ALL
	=A	F	W0044	0150	20		33-18-11	ALL
	=C	L	W0044	1105	20		33-18-11	ALL
M00270		**684/200/MULT**		**DETECTOR-MAIN WHEEL WELL FIRE**				**ALL**
	=A	N	W8122	6002R	20		26-12-11	ALL
	=B	N	W7522	6003R	20		26-12-11	ALL
M00277		**726/172/R023**		**HORN-APU FIRE WARN**				**ALL**
	+	C	W8524	6006R	18		26-11-31	ALL
	-	D	W8524	6005R	18		26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment		Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M00394		**P006-00/ /**		**DIODE-MASTER DIM**				**ALL**
	=A	E	W0044	0160	20		33-18-21	ALL
	=C	$	W0044	0213	20		33-18-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M00542		**P006-02/ /**		**DIODE ASSY-CAPT INPH-2 BUS**				**ALL**
	BLU		W0044	A-AE			23-51-51	ALL
	RED		W0044	A-BE			23-51-51	ALL
M00543		**P006-02/ /**		**DIODE ASSY-CAPT INPH-2 BUS**				**ALL**
	BLU		W0044	C-AA			23-51-51	ALL
	RED		W0044	C-BA			23-51-51	ALL
M00544		**P006-02/ /**		**DIODE ASSY-F/O INPH-2 BUS**				**ALL**
	BLU		W0044	B-AA			23-51-51	ALL
	RED		W0044	B-BB			23-51-51	ALL
M00545		**P006-02/ /**		**DIODE ASSY-F/O INPH BATT BUS**				**ALL**
	BLU		W0044	D-AA			23-51-51	ALL
	RED		W0044	D-BA			23-51-51	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01212		**973/287/L032**		**SPEAKER-AFT ATTD LH**				**ALL**
	2K	Z	W0452	2001R	22		23-31-04	ALL
	COM	Z	W0452	2001B	22		23-31-04	ALL
M01213		**980/287/R032**		**SPEAKER-AFT ATTD RH**				**ALL**
	2K	Z	W0442	2001R	22		23-31-04	ALL
	COM	Z	W0442	2001B	22		23-31-04	ALL
M01220		**387/181/R048**		**DIODE TR3**				**ALL**
	=C	P	W5036	0505	08		24-32-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01464		**310/290/**		**SPEAKER-FWD ATTD**				**ALL**
	4K	Z	W0342	2001R	22		23-31-04	ALL
	COM	Z	W0342	2001B	22		23-31-04	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M01755		**1095/246/L001**		**APU UPPER FIRE DETECTOR ASSY**				**ALL**
	T/1	GW	W7538	6001R	18		26-11-31	ALL
	T/1	GW	W7538	6003R	18		26-11-31	ALL
	GND	GY	W7538	6004R	18		26-11-31	ALL
M01756		**1145/231/L003**		**APU LOWER FIRE DETECTOR ASSY**				**ALL**
	T/1	GW	W7540	6001R	18		26-11-31	ALL
	GND	GY	W7540	6002R	18		26-11-31	ALL
M01761		**NSTA 188/ /**		**L ENG STRUT CAVITY FWD OVHT DET**				**ALL**
	=A	GW	W1166	1007R	18		26-12-11	ALL
	=B	GW	W1166	1006R	18		26-12-11	ALL
			W1166	1006Z			26-12-11	ALL
			W1166	1007Z			26-12-11	ALL
			W1166	FRAA			26-12-11	ALL
M01762		**OFSS-260/ /**		**L ENG STRUT CAVITY AFT OVHT DET**				**ALL**
	=A	E	W1182	1003R	18		26-12-11	ALL
	=B	E	W1188	1014R	18		26-12-11	ALL
M01763		**TBD/ /**		**R ENG STRUT CAVITY FWD OVHT DET**				**ALL**
	=A	GW	W1266	1007R	18		26-12-11	ALL
	=B	GW	W1266	1006R	18		26-12-11	ALL
			W1266	1006Z			26-12-11	ALL
			W1266	1007Z			26-12-11	ALL
			W1266	FRAA			26-12-11	ALL
M01764		**OFSS 260/ /**		**R ENG STRUT CAVITY AFT OVHT DET**				**ALL**
	=A	E	W1282	1003R	18		26-12-11	ALL
	=B	E	W1288	1014R	18		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M01907		**949/178/R002**		**HTR-HEATED HOSE GRAY WATER DRAIN**				**ALL**
	=G		W6248	H-B			30-71-11	ALL
	=P		W6248	H-A			30-71-11	ALL
M01909		**603/156/L007**		**LEFT MID A/C PACK OVHT DET**				**ALL**
	=A	GW	W5502	1010R	20		26-12-11	ALL
	=B	GW	W5502	1011R	20		26-12-11	ALL
M01910		**604/158/R007**		**RIGHT MID A/C PACK OVHT DET**				**ALL**
	=A	GW	W6502	1003R	20		26-12-11	ALL
	=B	GW	W6502	1002R	20		26-12-11	ALL
M01911		**660/159/L016**		**LEFT AFT A/C PACK OVHT DET**				**ALL**
	=A	GW	W5102	1025R	20		26-12-11	ALL
	=B	GW	W5102	1013R	20		26-12-11	ALL
M01912		**660/159/R016**		**RIGHT AFT A/C PACK OVHT DET**				**ALL**
	=A	GW	W6202	1009R	20		26-12-11	ALL
	=B	GW	W6202	1008R	20		26-12-11	ALL
M01918		**949/176/0000**		**HEATER CUFF,GRAY WATER DRAIN VALVE**				**ALL**
	=G		W6248	I-B			30-71-11	ALL
	=P		W6248	I-A			30-71-11	ALL
M01919		**920/172/R013**		**HTR-POTABLE FILL FITTING**				**ALL**
	=G		W6248	G-B			30-71-11	ALL
	=P		W6248	G-A			30-71-11	ALL
M01922		**868/177/L010**		**HTR-WASTE SYSTEM RINSE FITTING LINE**				**ALL**
	=G		W6248	F-B			30-71-11	ALL
	=P		W6248	F-A			30-71-11	ALL
M01925		**1156/250/R009**		**APU TAILPIPE OVERHEAT DETECTOR ASSY**				**ALL**
	T/1	GW	W4724	1101R	18		26-11-31	ALL
	T/1	GW	W4724	1108R	18		26-11-31	ALL
			W4724	0005	20		26-11-31	ALL
			W4724	1101Z			26-11-31	ALL
			W4724	1108Z			26-11-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01987	**E001-03/ /**		**DIP SWITCH-AIR TRAFFIC CONTROL 1**				**ALL**
1	1A	W0131	0201	24		34-53-11	ALL
2	1A	W0131	0202	24		34-53-11	ALL
3	1A	W0131	0203	24		34-53-11	ALL
4	1A	W0131	0204	24		34-53-11	ALL
5	1A	W0131	0205	24		34-53-11	ALL
6	1A	W0131	0206	24		34-53-11	ALL
7	1A	W0131	0207	24		34-53-11	ALL
8	1A	W0131	0208	24		34-53-11	ALL
9	1A	W0131	0209	24		34-53-11	ALL
10	1A	W0131	0210	24		34-53-11	ALL
11	1A	W0131	0211	24		34-53-11	ALL
12	1A	W0131	0212	24		34-53-11	ALL
13	1A	W0131	0213	24		34-53-11	ALL
14	1A	W0131	0214	24		34-53-11	ALL
15	1A	W0131	0215	24		34-53-11	ALL
16	1A	W0131	0216	24		34-53-11	ALL
17	1A	W0131	0217	24		34-53-11	ALL
18	1A	W0131	0218	24		34-53-11	ALL
19	1A	W0131	0219	24		34-53-11	ALL
20	1A	W0131	0220	24		34-53-11	ALL
21	1A	W0131	0221	24		34-53-11	ALL
22	1A	W0131	0222	24		34-53-11	ALL
23	1A	W0131	0223	24		34-53-11	ALL
24	1A	W0131	0224	24		34-53-11	ALL
25	1A	W0131	0225	24		34-53-11	ALL
M01988	**E001-03/ /**		**DIP SWITCH-AIR TRAFFIC CONTROL 2**				**ALL**
1	1A	W0131	0301	24		34-53-21	ALL
2	1A	W0131	0302	24		34-53-21	ALL
3	1A	W0131	0303	24		34-53-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01988		**E001-03/ /**		**DIP SWITCH-AIR TRAFFIC CONTROL 2 (continued)**				**ALL**
	4	1A	W0131	0304	24		34-53-21	ALL
	5	1A	W0131	0305	24		34-53-21	ALL
	6	1A	W0131	0306	24		34-53-21	ALL
	7	1A	W0131	0307	24		34-53-21	ALL
	8	1A	W0131	0308	24		34-53-21	ALL
	9	1A	W0131	0309	24		34-53-21	ALL
	10	1A	W0131	0310	24		34-53-21	ALL
	11	1A	W0131	0311	24		34-53-21	ALL
	12	1A	W0131	0312	24		34-53-21	ALL
	13	1A	W0131	0313	24		34-53-21	ALL
	14	1A	W0131	0314	24		34-53-21	ALL
	15	1A	W0131	0315	24		34-53-21	ALL
	16	1A	W0131	0316	24		34-53-21	ALL
	17	1A	W0131	0317	24		34-53-21	ALL
	18	1A	W0131	0318	24		34-53-21	ALL
	19	1A	W0131	0319	24		34-53-21	ALL
	20	1A	W0131	0320	24		34-53-21	ALL
	21	1A	W0131	0321	24		34-53-21	ALL
	22	1A	W0131	0322	24		34-53-21	ALL
	23	1A	W0131	0323	24		34-53-21	ALL
	24	1A	W0131	0324	24		34-53-21	ALL
	25	1A	W0131	0325	24		34-53-21	ALL
M01990		**P059-00/ /**		**DIP SWITCH ASSY**				**ALL**
	1	1A	W0737	0001	22		34-61-19	ALL
	2	1A	W0737	0002	22		34-61-19	ALL
	3	1A	W0737	0003	22		34-61-19	ALL
	4	1A	W0737	0004	22		34-61-19	ALL
	5	1A	W0737	0005	22		34-61-19	ALL
	6	1A	W0737	0006	22		34-61-19	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01990	**P059-00/ /**		**DIP SWITCH ASSY (continued)**				**ALL**
7	1A	W0737	0007	22		34-61-19	ALL
8	1A	W0737	0008	22		34-61-19	ALL
9	1A	W0737	0009	22		34-61-19	ALL
10	1A	W0737	0010	22		34-61-19	ALL
11	1A	W0737	0011	22		34-61-19	ALL
12	1A	W0737	0012	22		34-61-19	ALL
13	1A	W0737	0034	22		34-61-19	ALL
14	1A	W0737	0035	22		34-61-19	ALL
25	1A	W0737	0036	22		34-61-19	ALL
M01991	**P059-00/ /**		**DIP SWITCH ASSY**				**ALL**
1	1A	W0737	0013	22		34-61-19	ALL
2	1A	W0737	0040	22		34-61-19	ALL
3	1A	W0737	0015	22		34-61-19	ALL
4	1A	W0737	0016	22		34-61-19	ALL
5	1A	W0737	0017	22		34-61-19	ALL
6	1A	W0737	0018	22		34-61-19	ALL
7	1A	W0737	0019	22		34-61-19	ALL
8	1A	W0737	0020	22		34-61-19	ALL
9	1A	W0737	0021	22		34-61-19	ALL
10	1A	W0737	0022	22		34-61-19	ALL
11	1A	W0737	0023	22		34-61-19	ALL
12	1A	W0737	0024	22		34-61-19	ALL
13	1A	W0737	0038	22		34-61-19	ALL
14	1A	W0737	0039	22		34-61-19	ALL
25	1A	W0737	0037	22		34-61-19	ALL
M01992	**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS A**				**ALL**
1	1A	W0111	0101	24		22-11-75	ALL
2	1A	W0111	0102	24		22-11-75	ALL
3	1A	W0111	0103	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01992		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS A (continued)**				**ALL**
	4	1A	W0111	0104	24		22-11-75	ALL
	5	1A	W0111	0105	24		22-11-75	ALL
	6	1A	W0111	0106	24		22-11-75	ALL
	7	1A	W0111	0107	24		22-11-75	ALL
	8	1A	W0111	0108	24		22-11-75	ALL
	9	1A	W0111	0109	24		22-11-75	ALL
	10	1A	W0111	0110	24		22-11-75	ALL
	11	1A	W0111	0111	24		22-11-75	ALL
	12	1A	W0111	0112	24		22-11-75	ALL
	14	1A	W0111	0114	24		22-11-75	ALL
	15	1A	W0111	0115	24		22-11-75	ALL
	16	1A	W0111	0444	24		22-11-75	ALL
	24	1A	W0111	0124	24		22-11-75	ALL
	25	1A	W0111	0125	22		22-11-75	ALL
M01993		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS B**				**ALL**
	1	1A	W0111	0201	24		22-11-75	ALL
	2	1A	W0111	0202	24		22-11-75	ALL
	3	1A	W0111	0203	24		22-11-75	ALL
	4	1A	W0111	0204	24		22-11-75	ALL
	5	1A	W0111	0205	24		22-11-75	ALL
	6	1A	W0111	0206	24		22-11-75	ALL
	7	1A	W0111	0207	24		22-11-75	ALL
	8	1A	W0111	0208	24		22-11-75	ALL
	9	1A	W0111	0209	24		22-11-75	ALL
	10	1A	W0111	0210	24		22-11-75	ALL
	11	1A	W0111	0211	24		22-11-75	ALL
	12	1A	W0111	0212	24		22-11-75	ALL
	14	1A	W0111	0214	24		22-11-75	ALL
	15	1A	W0111	0215	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M01993		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS B (continued)**				**ALL**
	16	1A	W0111	0449	24		22-11-75	ALL
	24	1A	W0111	0224	24		22-11-75	ALL
	25	1A	W0111	0225	22		22-11-75	ALL
M01995		**E004-01/ /**		**SELCAL SWITCH**				**ALL**
	1	1A	W0411	0100	24		23-22-11	ALL
	2	1A	W0411	0101	24		23-22-11	ALL
	3	1A	W0411	0102	24		23-22-11	ALL
	4	1A	W0411	0103	24		23-22-11	ALL
	5	1A	W0411	0104	24		23-22-11	ALL
	6	1A	W0411	0105	24		23-22-11	ALL
	7	1A	W0411	0106	24		23-22-11	ALL
	8	1A	W0411	0107	24		23-22-11	ALL
	9	1A	W0411	0108	24		23-22-11	ALL
	10	1A	W0411	0109	24		23-22-11	ALL
	11	1A	W0411	0110	24		23-22-11	ALL
	12	1A	W0411	0111	24		23-22-11	ALL
	13	1A	W0411	0112	24		23-22-11	ALL
	14	1A	W0411	0113	24		23-22-11	ALL
	15	1A	W0411	0114	24		23-22-11	ALL
	16	1A	W0411	0115	24		23-22-11	ALL
	17	1A	W0411	0116	24		23-22-11	ALL
	18	1A	W0411	0117	24		23-22-11	ALL
	25	1A	W0411	0118	24		23-22-11	ALL
M01996		**E003-02/ /**		**SW-FDRS AIRPLANE ID CONFIGURATION**				**ALL**
	13	1A	W0321	0809	24		31-31-16	ALL
	14	1A	W0321	0810	24		31-31-16	ALL
	15	1A	W0321	0811	24		31-31-16	ALL
	16	1A	W0321	0812	24		31-31-16	ALL
	17	1A	W0321	0813	24		31-31-16	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M01996		**E003-02/ /**		**SW-FDRS AIRPLANE ID CONFIGURATION (continued)**				**ALL**
	18	1A	W0321	0814	24		31-31-16	ALL
	19	1A	W0321	0815	24		31-31-16	ALL
	26	1A	W0321	0820	24		31-31-16	ALL
M01996S1		**E003-02/ /**		**DIP SWITCH**				**ALL**
	1	UNUSED						ALL
	2	UNUSED						ALL
	3	UNUSED						ALL
	4	UNUSED						ALL
	5	UNUSED						ALL
	6	UNUSED						ALL
	7	UNUSED						ALL
	8	UNUSED						ALL
	9	UNUSED						ALL
	10	UNUSED						ALL
	11	UNUSED						ALL
	12	UNUSED						ALL
	20	UNUSED						ALL
	21	UNUSED						ALL
	22	UNUSED						ALL
	23	UNUSED						ALL
	24	UNUSED						ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M02115	**794/300/L015**		**MODULE-PROGRAMMABLE SWITCH, ELT**				**ALL**
1	1A	W3419	0101	24		23-24-11	ALL
2	1A	W3419	0102	24		23-24-11	ALL
3	1A	W3419	0103	24		23-24-11	ALL
4	1A	W3419	0104	24		23-24-11	ALL
5	1A	W3419	0105	24		23-24-11	ALL
6	1A	W3419	0106	24		23-24-11	ALL
7	1A	W3419	0107	24		23-24-11	ALL
8	1A	W3419	0108	24		23-24-11	ALL
9	1A	W3419	0109	24		23-24-11	ALL
10	1A	W3419	0110	24		23-24-11	ALL
11	1A	W3419	0111	24		23-24-11	ALL
12	1A	W3419	0112	24		23-24-11	ALL
13	1A	W3419	0113	24		23-24-11	ALL
14	1A	W3419	0114	24		23-24-11	ALL
15	1A	W3419	0115	24		23-24-11	ALL
16	1A	W3419	0116	24		23-24-11	ALL
17	1A	W3419	0117	24		23-24-11	ALL
18	1A	W3419	0118	24		23-24-11	ALL
19	1A	W3419	0119	24		23-24-11	ALL
20	1A	W3419	0120	24		23-24-11	ALL
21	1A	W3419	0121	24		23-24-11	ALL
22	1A	W3419	0122	24		23-24-11	ALL
23	1A	W3419	0123	24		23-24-11	ALL
24	1A	W3419	0124	24		23-24-11	ALL
26	1A	W3419	0034	20		23-24-11	ALL
M02175	**627/222/R067**		**R AFT CLOSE OUT PANEL HEATER**				**ALL**
=W/B		W4142	C-A			21-42-11	ALL
=WHT		W4142	C-B			21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M02177		**627/222/L067**		**L AFT CLOSE OUT PANEL HEATER**				**ALL**
	=W/B		W3142	C-A			21-42-11	ALL
	=WHT		W3142	C-B			21-42-11	ALL
M02179		**591/224/R068**		**RIGHT FWD CLOSE OUT PANEL HEATER**				**ALL**
	=W/B		W4142	J-A			21-42-11	ALL
	=WHT		W4142	J-B			21-42-11	ALL
M02183		**583/224/L068**		**LEFT FWD CLOSE OUT PANEL HEATER**				**ALL**
	=W/B		W3142	E-A			21-42-11	ALL
	=WHT		W3142	E-B			21-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M02219		**633/256/L068**		**SOL-OVERWING FLIGHT LOCK-LEFT**				**ALL**
	=BLK		W3142	F-A			52-71-13	ALL
	=BLK		W3142	F-B			52-71-13	ALL
M02220		**595/256/L068**		**SOL-OVERWING FLIGHT LOCK-LEFT FWD**				**ALL**
	=BLK		W3142	N-A			52-71-13	ALL
	=BLK		W3142	N-B			52-71-13	ALL
M02221		**621/256/R068**		**SOL-OVERWING FLIGHT LOCK-RIGHT**				**ALL**
	=BLK		W4142	F-A			52-71-14	ALL
	=BLK		W4142	F-B			52-71-14	ALL
M02222		**583/256/R068**		**SOL-OVERWING FLIGHT LOCK-RIGHT FWD**				**ALL**
	=BLK		W4142	N-A			52-71-14	ALL
	=BLK		W4142	N-B			52-71-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M02539		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS A-2**				**ALL**
	1	1A	W0111	0761	24		22-11-75	ALL
	2	1A	W0111	0762	24		22-11-75	ALL
	3	1A	W0111	0763	24		22-11-75	ALL
	5	1A	W0111	0765	24		22-11-75	ALL
	6	1A	W0111	0766	24		22-11-75	ALL
	7	1A	W0111	0767	24		22-11-75	ALL
	8	1A	W0111	0768	24		22-11-75	ALL
	9	1A	W0111	0769	24		22-11-75	ALL
	10	1A	W0111	0770	24		22-11-75	ALL
	11	1A	W0111	0771	24		22-11-75	ALL
	12	1A	W0111	0772	24		22-11-75	ALL
	13	1A	W0111	0773	24		22-11-75	ALL
	14	1A	W0111	0774	24		22-11-75	ALL
	15	1A	W0111	0786	24		22-11-75	ALL
	17	1A	W0111	0787	24		22-11-75	ALL
	18	1A	W0111	0788	24		22-11-75	ALL
	19	1A	W0111	0789	24		22-11-75	ALL
	25	1A	W0111	0790	24		22-11-75	ALL
M02540		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS B-2**				**ALL**
	1	1A	W0111	0908	24		22-11-75	ALL
	2	1A	W0111	0909	24		22-11-75	ALL
	3	1A	W0111	0910	24		22-11-75	ALL
	4	1A	W0111	0911	24		22-11-75	ALL
	5	1A	W0111	0912	24		22-11-75	ALL
	6	1A	W0111	0913	24		22-11-75	ALL
	7	1A	W0111	0914	24		22-11-75	ALL
	8	1A	W0111	0915	24		22-11-75	ALL
	9	1A	W0111	0916	24		22-11-75	ALL
	10	1A	W0111	0917	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M02540		**E001-01/ /**		**MDL-PROGRAM SWITCH AUTOPILOT SYS B-2 (continued)**				**ALL**
	11	1A	W0111	0918	24		22-11-75	ALL
	12	1A	W0111	0919	24		22-11-75	ALL
	13	1A	W0111	0920	24		22-11-75	ALL
	14	1A	W0111	0921	24		22-11-75	ALL
	15	1A	W0111	0922	24		22-11-75	ALL
	17	1A	W0111	0923	24		22-11-75	ALL
	18	1A	W0111	0924	24		22-11-75	ALL
	19	1A	W0111	0925	24		22-11-75	ALL
	24	1A	W0111	0926	24		22-11-75	ALL
	25	1A	W0111	0927	24		22-11-75	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M03055		**E003-03/ /**		**AUXILIARY BATTERY CHARGER**				**ALL**
	+	R	W2532	0526	02		24-31-12	ALL
	-	Q	W2532	0532	02		24-31-12	ALL
M03057		**NSTA 567/ /**		**LEFT FWD STRUT CAVITY OVHT DET**				**ALL**
	=A	GW	W1166	1005R	18		26-12-11	ALL
	=B	GW	W1166	1007R	18		26-12-11	ALL
			W1166	1005Z			26-12-11	ALL
			W1166	1007Z			26-12-11	ALL
			W1166	FRBB			26-12-11	ALL
M03058		**564/ /**		**RIGHT FWD STRUT CAVITY OVHT DET**				**ALL**
	=A	GW	W1266	1005R	18		26-12-11	ALL
	=B	GW	W1266	1007R	18		26-12-11	ALL
			W1266	1005Z			26-12-11	ALL
			W1266	1007Z			26-12-11	ALL
			W1266	FRBB			26-12-11	ALL
M03064		**PYLON/ /**		**ENGINE 1 BURN THROUGH FIRE DETECTOR**				**ALL**
	C-A1	GW	W1194	2001R	20		26-11-11	ALL
	C-B2	GW	W1194	2002R	20		26-11-11	ALL
	G-A1	G3	W1194	2001B	20		26-11-11	ALL
	G-A1	G3	W1194	2001Z			26-11-11	ALL
	G-B2	G3	W1194	2002B	20		26-11-11	ALL
	G-B2	G3	W1194	2002Z			26-11-11	ALL
M03065		**PYLON/ /**		**ENGINE 2 BURN THROUGH FIRE DETECTOR**				**ALL**
	C-A1	GW	W1294	2001R	20		26-11-21	ALL
	C-B2	GW	W1294	2002R	20		26-11-21	ALL
	G-A1	G3	W1294	2001B	20		26-11-21	ALL
	G-A1	G3	W1294	2001Z			26-11-21	ALL
	G-B2	G3	W1294	2002B	20		26-11-21	ALL
	G-B2	G3	W1294	2002Z			26-11-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
M03067		**625/162/L041**		**NGS POINT SENSOR**				**ALL**
	=A	GW	W7202	1001R	20		26-12-11	ALL
	=B	GW	W7202	1002R	20		26-12-11	ALL
			W7202	1001Z			26-12-11	ALL
			W7202	1002Z			26-12-11	ALL
M03068		**685/200/MULT**		**MAIN WHEEL WELL OVHT DETECTOR**				**ALL**
	=A	N	W8222	6003R	20		26-12-11	ALL
	=B	N	W7230	6005R	20		26-12-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
M03233		**527/149/R020**		**THERMOSTAT-HEATED HOSE FWD-1 AMPERE**				**ALL**
	=G		W6202	A-AB			30-71-11	ALL
	=P		W6202	A-AA			30-71-11	ALL
M03235		**526/148/R018**		**HEATED HOSE FWD MAST**				**ALL**
	=G		W6202	A-AD			30-71-11	ALL
	=P		W6202	A-AC			30-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00057		**J004-00/ /**		**RLY-ALTERNATE TRAILING EDGE FLAP DOWN**				**ALL**
	A1	C	W0094	0028	16		27-53-12	ALL
	A2	C	W0094	0026	16		27-53-12	ALL
	B1	C	W0094	0024	16		27-53-12	ALL
	B2	C	W0094	0030	16		27-53-12	ALL
	C1	C	W0094	0032	16		27-53-12	ALL
	C2	C	W0094	0034	16		27-53-12	ALL
	D2	C	W0094	0021	20		27-53-12	ALL
	D3	C	W0094	0042	20		27-53-12	ALL
	X1	C	W0094	0035	20		27-53-12	ALL
	X2	C	W0094	0041	20		27-53-12	ALL
R00058		**J004-00/ /**		**RLY-ALTERNATE TRAILING EDGE FLAP UP**				**ALL**
	A1	C	W0094	0023	16		27-53-12	ALL
	A1	C	W0094	0024	16		27-53-12	ALL
	A2	C	W0094	0025	16		27-53-12	ALL
	A2	C	W0094	0026	16		27-53-12	ALL
	B1	C	W0094	0027	16		27-53-12	ALL
	B1	C	W0094	0028	16		27-53-12	ALL
	B2	C	W0094	0029	16		27-53-12	ALL
	B2	C	W0094	0030	16		27-53-12	ALL
	C1	C	W0094	0031	16		27-53-12	ALL
	C1	C	W0094	0032	16		27-53-12	ALL
	C2	C	W0094	0033	16		27-53-12	ALL
	C2	C	W0094	0034	16		27-53-12	ALL
	D2	C	W0094	0035	20		27-53-12	ALL
	D3	C	W0094	0036	20		27-53-12	ALL
	X1	C	W0094	0021	20		27-53-12	ALL
	X2	C	W0094	0022	20		27-53-12	ALL
R00064		**J004-00/ /**		**RLY-STABILIZER TRIM CONTROL**				**ALL**
	L1	E	W0094	3003B	14		27-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00064		**J004-00/ /**		**RLY-STABILIZER TRIM CONTROL (continued)**				**ALL**
	L2	E	W0094	3003Y	14		27-41-12	ALL
	L3	E	W0094	3003R	14		27-41-12	ALL
	T1	E	W0094	3001B	14		27-41-12	ALL
	T2	E	W0094	3001Y	14		27-41-12	ALL
	T3	E	W0094	3001R	14		27-41-12	ALL
	X1	C	W0094	0055	20		27-41-12	ALL
	X2	C	W0094	0052	20		27-41-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00331		**P006-00/ /**		**RLY-CABIN AIR RECIRCULATE FAN**				**ALL**
	A1	D	W0044	0429	14		21-25-11	ALL
	A2	D	W0044	0436	14		21-25-11	ALL
	B1	D	W0044	0430	14		21-25-11	ALL
	B2	D	W0044	0437	14		21-25-11	ALL
	C1	D	W0044	0431	14		21-25-11	ALL
	C2	D	W0044	0438	14		21-25-11	ALL
	X1	C	W0044	0613	24		21-25-11	ALL
	X2	C	W0044	0614	24		21-25-11	ALL
R00340		**270/284/R010**		**RESISTOR**				**ALL**
	=G		W2114	A-AG			33-51-12	ALL
	=P		W2114	A-AP			33-51-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00429		**J022-00/ /**		**RLY-CABIN AIR RECIRCULATE**				**ALL**
	A1	D	W0076	0253	14		21-25-11	ALL
	A2	D	W0076	0254	14		21-25-11	ALL
	B1	D	W0076	0255	14		21-25-11	ALL
	B2	D	W0076	0256	14		21-25-11	ALL
	C1	D	W0076	0257	14		21-25-11	ALL
	C2	D	W0076	0258	14		21-25-11	ALL
	X1	C	W0076	0251	22		21-25-11	ALL
	X2	C	W0076	0252	22		21-25-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00669		**P006-00/ /**		**DIODE-FUEL SHUT OFF VALVE BUS BLOCKING**				**ALL**
	=A	L	W0044	1106	20		28-21-21	ALL
	=A	L	W0044	1107	20		28-21-21	ALL
	=C	F	W0044	0649	20		28-21-21	ALL
	=C	F	W0044	6002	20		28-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
R00916		**P006-00/ /**		**RLY-XFR BUS 1 IFE/PASS SEAT SW CTRL RLY**				**ALL**
	A1	E	W0040	0203	08		24-51-15	ALL
	A2	E	W0040	0218	08		24-51-15	ALL
	B1	E	W0040	0204	08		24-51-15	ALL
	B2	E	W0040	0219	08		24-51-15	ALL
	C1	E	W0040	0205	08		24-51-15	ALL
	C2	E	W0040	0220	08		24-51-15	ALL
	X1	C	W0044	0890	24		24-28-41	ALL
	X2	C	W0044	0891	24		24-28-41	ALL
R00917		**P006-00/ /**		**RLY-XFR BUS 2 IFE/PASS SEAT SW CTRL RLY**				**ALL**
	A1	E	W0040	0209	08		24-51-25	ALL
	A2	E	W0040	0221	08		24-51-25	ALL
	B1	E	W0040	0210	08		24-51-25	ALL
	B2	E	W0040	0222	08		24-51-25	ALL
	C1	E	W0040	0211	08		24-51-25	ALL
	C2	E	W0040	0223	08		24-51-25	ALL
	X1	C	W0044	0892	24		24-28-41	ALL
	X2	C	W0044	0893	24		24-28-41	ALL
R00962		**371/166/L035**		**RELAY-SECONDARY BOOST PUMP CTR TANK L**				**ALL**
	A1	E	W5112	3205R	18		28-23-11	ALL
	A2	E	W5112	3202R	18		28-23-11	ALL
	B1	E	W5112	3205Y	18		28-23-11	ALL
	B2	E	W5112	3202Y	18		28-23-11	ALL
	C1	E	W5112	3205B	18		28-23-11	ALL
	C2	E	W5112	3202B	18		28-23-11	ALL
	X1	D	W5112	0214	20		28-23-11	ALL
	X2	D	W5112	0215	20		28-23-11	ALL
R00963		**361/166/R036**		**RELAY-SECONDARY BOOST PUMP CTR TANK R**				**ALL**
	A1	E	W6210	3205R	18		28-23-11	ALL
	A2	E	W6210	3202R	18		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R00963		**361/166/R036**		**RELAY-SECONDARY BOOST PUMP CTR TANK R (continued)**				**ALL**
	B1	E	W6210	3205Y	18		28-23-11	ALL
	B2	E	W6210	3202Y	18		28-23-11	ALL
	C1	E	W6210	3205B	18		28-23-11	ALL
	C2	E	W6210	3202B	18		28-23-11	ALL
	X1	D	W6210	0214	20		28-23-11	ALL
	X2	D	W6210	0215	20		28-23-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R01172		**J023-00/ /**		**RLY-ENG 1 EEC FAN BLOWERS**				**ALL**
	A1	D	W0098	0407	18		73-22-41	ALL
	A2	D	W0098	0412	18		73-22-41	ALL
	B1	D	W0098	0406	18		73-22-41	ALL
	B2	D	W0098	0411	18		73-22-41	ALL
	C1	D	W0098	0405	18		73-22-41	ALL
	C2	D	W0098	0410	18		73-22-41	ALL
	X1	C	W0098	0408	20		73-22-41	ALL
	X2	C	W0098	0409	20		73-22-41	ALL
R01173		**J004-00/ /**		**RLY-ENG 2 EEC FAN BLOWERS**				**ALL**
	A1	D	W0094	0251	18		73-22-41	ALL
	A2	D	W0094	0254	18		73-22-41	ALL
	B1	D	W0094	0249	18		73-22-41	ALL
	B2	D	W0094	0255	18		73-22-41	ALL
	C1	D	W0094	0248	18		73-22-41	ALL
	C2	D	W0094	0256	18		73-22-41	ALL
	X1	C	W0094	0252	20		73-22-41	ALL
	X2	C	W0094	0253	20		73-22-41	ALL
R01199		**P010-00/ /**		**DIODE-ENGINE 1 FMU SUPPRESSION**				**ALL**
	A		W0008	0097	22		76-21-11	ALL
	C		W0008	0096	22		76-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
R01200		**P010-00/ /**		**DIODE-ENGINE 2 FMU SUPPRESSION**				**ALL**
	A		W0008	0095	22		76-21-21	ALL
	C		W0008	0094	22		76-21-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00007		**P005-00/ /**		**SW-EMERGENCY EXIT LT**				**ALL**
	1C	B	W2218	0029	20		33-51-11	ALL
	3C	B	W2114	0006	20		33-51-11	ALL
	4C	B	W2114	0009	20		33-51-11	ALL
	5C	B	W2218	0032	20		33-51-11	ALL
	6C	B	W2218	0035	22		33-51-11	ALL
	1NO	B	W2218	0030	22		33-51-11	ALL
	1NO	B	W2218	0031	22		33-51-11	ALL
	3NO	B	W2114	0007	20		33-51-11	ALL
	3NO	B	W2114	0008	20		33-51-11	ALL
	4NO	B	W2114	0008	20		33-51-11	ALL
	5NO	B	W2218	0031	22		33-51-11	ALL
	5NO	B	W2218	0033	22		33-51-11	ALL
	6NO	B	W2218	0034	22		33-51-11	ALL
S00022		**P005-00/ /**		**SW-RIGHT WINDSHIELD WIPER CONTROL**				**ALL**
	21	C	W2218	5575	18		30-42-11	ALL
	22	C	W2214	5501	18		30-42-11	ALL
	23	C	W2218	5574	24		30-42-11	ALL
S00032		**P005-00/ /**		**SW-GRD CREW CALL**				**ALL**
	1	C	W2218	0009	22		23-43-11	ALL
	2	C	W2035	0034	22		23-43-11	ALL
S00033		**P019-00/ /**		**SW-CAPTAIN CALL**				**ALL**
	=A	C	W0048	8001	20		23-43-11	ALL
	=B	C	W0048	8004	20		23-43-11	ALL
	=C	C	W0048	8003	20		23-43-11	ALL
S00036		**P005-00/ /**		**SW-ATTENDANTS CALL**				**ALL**
	1	C	W2218	0001	22		23-42-11	ALL
	2	C	W2218	0009	22		23-43-11	ALL
	2	C	W2218	0010	22		23-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00045		**P005-00/ /**		**SW-NO SMOKING**				**ALL**
	1	C	W2218	0028	24		33-25-11	ALL
	4	C	W2218	0015	20		33-25-11	ALL
	5	C	W2218	0014	24		33-25-11	ALL
	5	C	W2218	0041	24		23-31-06	ALL
S00046		**P005-00/ /**		**SW-FASTEN BELTS**				**ALL**
	1	C	W2218	0022	24		33-25-11	ALL
	2	C	W2218	0018	24		33-25-11	ALL
	4	C	W2218	0016	20		33-25-11	ALL
	5	C	W2218	0017	24		33-25-11	ALL
	5	C	W2218	0042	24		23-31-06	ALL
	6	C	W2218	0018	24		33-25-11	ALL
S00050		**P005-00/ /**		**SW-INPH CUTOFF P5 PNL**				**ALL**
	1	C	W3327	2004R	24		23-41-11	ALL
	2	C	W3327	2004B	24		23-41-11	ALL
S00057		**P005-00/ /**		**SW-RED ANTI-COLLISION LIGHTS**				**ALL**
	1	C	W2104	0014	20		33-44-11	ALL
	2	C	W2104	0015	20		33-44-11	ALL
	2	C	W2104	1016	20		33-44-11	ALL
S00058		**P005-00/ /**		**SW-POS LT**				**ALL**
	1	C	W2218	0039	20		33-43-11	ALL
	2	C	W2218	0038	20		33-43-11	ALL
	3	C	W2218	0037	20		33-43-11	ALL
	3	C	W2218	0039	20		33-43-11	ALL
	4	C	W2112	0006	20		33-43-11	ALL
	5	C	W2112	0004	20		33-43-11	ALL
	6	C	W2112	0005	20		33-43-11	ALL
	6	C	W2112	0006	20		33-43-11	ALL
	8	C	W2104	0009	20		33-44-12	ALL
	9	C	W2104	0008	20		33-44-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00058		**P005-00/ /**		**SW-POS LT (continued)**				**ALL**
	11	C	W2104	0031	20		33-44-12	ALL
	12	C	W2104	0032	20		33-44-12	ALL
S00059		**P005-00/ /**		**SW-EQUIP COOLING**				**ALL**
	2	C	W2112	5505	22		21-27-21	ALL
	3	C	W2112	5506	22		21-27-21	ALL
	4	C	W2218	5502	22		21-27-21	ALL
	5	C	W2218	5501	22		21-27-21	ALL
S00061		**P005-00/ /**		**SW-TAXI LIGHT**				**ALL**
	1	1A	W2218	0085	20		33-42-21	ALL
	2	1A	W2218	0090	20		33-42-21	ALL
	4	1A	W2104	0027	20		33-42-21	ALL
	5	1A	W2104	0030	20		33-42-21	ALL
S00062		**P005-00/ /**		**SW-WHEEL WELL LT**				**ALL**
	1	C	W2218	0025	20		33-32-11	ALL
	2	C	W2218	0027	20		33-32-11	ALL
	4	C	W2218	0024	20		33-32-11	ALL
	4	C	W2218	0025	20		33-32-11	ALL
	5	C	W2218	0026	20		33-32-11	ALL
S00063		**P019-00/ /**		**SW-NOSE WHL WELL LT**				**ALL**
	1	C	W0048	0008	20		33-32-11	ALL
	2	C	W0048	0009	20		33-32-11	ALL
	3	C	W0048	0010	20		33-32-11	ALL
S00064		**689/160/L070**		**SW-MAIN WHEEL WELL LIGHT**				**ALL**
	1	C	W7026	1001	20		33-32-11	ALL
	2	C	W7026	1003	20		33-32-11	ALL
	3	C	W7026	1002	20		33-32-11	ALL
S00065		**544/153/R034**		**SW-A/C BAY SERVICE LIGHT,R**				**ALL**
	1	G7	W6202	0002	20		33-33-11	ALL
	1	G7	W6202	1014	20		33-33-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00065		**544/153/R034**		**SW-A/C BAY SERVICE LIGHT,R (continued)**				**ALL**
	2	G7	W6202	1003	20		33-33-11	ALL
	2	G7	W6202	1017	20		33-33-11	ALL
	4	G7	W6202	0002	20		33-33-11	ALL
	4	G7	W6202	1015	20		33-33-11	ALL
	5	G7	W6202	1016	20		33-33-11	ALL
S00066		**544/154/L039**		**SW-A/C BAY SERVICE LIGHT,L**				**ALL**
	1	G7	W5102	0003	20		33-33-11	ALL
	1	G7	W5102	1019	20		33-33-11	ALL
	2	G7	W5102	1016	20		33-33-11	ALL
	2	G7	W5102	1018	20		33-33-11	ALL
	4	G7	W5102	0003	20		33-33-11	ALL
	5	G7	W5102	1004	20		33-33-11	ALL
	5	G7	W5102	1017	20		33-33-11	ALL
S00067		**440/158/R033**		**SW-CARGO LIGHTS PUSH ON PUSH OFF**				**ALL**
	1	C	W5248	0017	20		33-36-11	ALL
	2	C	W5248	0007	20		33-36-11	ALL
S00068		**793/160/R033**		**SW-AFT CARGO LIGHTS**				**ALL**
	1	C	W6248	0287	20		33-36-12	ALL
	2	C	W6248	0286	20		33-36-12	ALL
S00071		**700/180/L90**		**SW- #1 L MLG DN + LOCKED SENSOR**				**ALL**
	BLU		W7022	A-B			32-64-11	ALL
	RED		W7022	A-R			32-64-11	ALL
	YEL		W7022	A-Y			32-64-11	ALL
S00072		**693/188/L056**		**SW- #1 L MLG UP + LOCKED SENSOR**				**ALL**
	BLU		W7230	A-B			32-64-11	ALL
	RED		W7230	A-R			32-64-11	ALL
	YEL		W7230	A-Y			32-64-11	ALL
S00073		**700/180/R90**		**SW- #1 R MLG DN + LOCKED SENSOR**				**ALL**
	BLU		W8022	A-B			32-64-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00073		**700/180/R90**		**SW- #1 R MLG DN + LOCKED SENSOR (continued)**				**ALL**
	RED		W8022	A-R			32-64-11	ALL
	YEL		W8022	A-Y			32-64-11	ALL
S00074		**693/188/R056**		**SW- #1 R MLG UP + LOCKED SENSOR**				**ALL**
	BLU		W8228	A-B			32-64-11	ALL
	RED		W8228	A-R			32-64-11	ALL
	YEL		W8228	A-Y			32-64-11	ALL
S00077		**P008-00/ /**		**SW-HORN CUT OUT**				**ALL**
	3	B	W0008	0004	22		32-64-21	ALL
	4	B	W0008	0005	22		32-64-21	ALL
S00084		**200/181/R022**		**SW-FWD LWR SERV COMPT LTS**				**ALL**
	1	C	W6110	0001	20		33-34-11	ALL
	2	C	W6110	0002	20		33-34-11	ALL
S00085		**359/164/R007**		**SW-E/E COMPT LIGHTS**				**ALL**
	1	C	W6110	0010	20		33-34-11	ALL
	2	C	W6110	0020	20		33-34-11	ALL
S00086		**1090/220/L003**		**SW-APU COMPT LT**				**ALL**
	2	G7	W7538	1005	18		33-35-11	ALL
	2	G7	W7538	1007	18		33-35-11	ALL
	3	G7	W7538	1002	18		33-35-11	ALL
			W7538	1002Z			33-35-11	ALL
			W7538	1005Z			33-35-11	ALL
			W7538	1007Z			33-35-11	ALL
S00087		**1064/209/L018**		**SW-ACCESSORY LIGHTS**				**ALL**
	1	G7	W4724	1019	20		33-35-11	ALL
	2	G7	W4724	1020	18		33-35-11	ALL
			W4724	1019Z			33-35-11	ALL
			W4724	1020Z			33-35-11	ALL
S00098		**P005-00/ /**		**SW-WING SCANNING LTS**				**ALL**
	1	C	W2114	0001	18		33-41-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00098		**P005-00/ /**		**SW-WING SCANNING LTS (continued)**				**ALL**
	2	C	W2114	0002	18		33-41-11	ALL
S00099		**1164/245/R016**		**SW-TAIL CONE LT**				**ALL**
	1	G7	W7150	1201	18		33-35-11	ALL
	2	G7	W7150	1203	18		33-35-11	ALL
			W7150	1201Z			33-35-11	ALL
			W7150	1203Z			33-35-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00100		**210/200/L014**		**SW-PARKING BRAKE**				**ALL**
	1C	B	W5514	0520	20		32-44-11	ALL
	2C	B	W5514	5781	22		32-44-11	ALL
	1NC	B	W5514	0511	24		32-44-11	ALL
	2NC	B	W5514	5782	22		32-44-11	ALL
	1NO	B	W5514	0513	24		32-44-11	ALL
	2NO	B	W5514	5783	22		32-44-11	ALL
S00103		**P005-00/ /**		**SW-WHITE DOME LT**				**ALL**
	1	C	W2508	5522	20		33-14-12	ALL
	1	C	W2508	5523	20		33-14-12	ALL
	2	C	W2508	5521	20		33-14-12	ALL
S00113		**216/220/**		**SW-THROTTLE DISENG 1**				**ALL**
	1	A	W0049	0008	22		22-31-51	ALL
	2	A	W0049	0005	22		22-31-51	ALL
	3	A	W0049	0006	22		22-31-51	ALL
	4	A	W0049	0007	22		22-31-51	ALL
S00114		**216/220/**		**SW-THROTTLE DISENG 2**				**ALL**
	1	A	W0051	0008	22		22-31-51	ALL
	2	A	W0051	0005	22		22-31-51	ALL
	3	A	W0051	0006	22		22-31-51	ALL
	4	A	W0051	0007	22		22-31-51	ALL
S00132		**1082/270/L015**		**SW-NOSE UP STAB TAKE-OFF WARN**				**ALL**
	1		W4134	B-F			31-53-11	ALL
	2		W4134	B-D			31-53-11	ALL
	3		W4134	B-C			31-53-11	ALL
	4		W4134	B-E			31-53-11	ALL
	5		W4134	B-B			31-53-11	ALL
	6		W4134	B-A			31-53-11	ALL
	CAP	Y	W4134	B-A			31-53-11	ALL
	CAP	Y	W4134	B-B			31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00132	**1082/270/L015**		**SW-NOSE UP STAB TAKE-OFF WARN (continued)**				**ALL**
CAP	Y	W4134	B-C			31-53-11	ALL
CAP	Y	W4134	B-E			31-53-11	ALL
S00144	**1084/255/L018**		**SW-STAB NOSE UP LIMIT**				**ALL**
1		W3391	A-1			22-13-11	ALL
2		W3391	A-2			22-13-11	ALL
3		W3391	A-3			22-13-11	ALL
4		W3391	A-4			27-41-12	ALL
5		W3391	A-5			27-41-12	ALL
6		W3391	A-6			27-41-12	ALL
CAP	Y	W3391	A-2			22-13-11	ALL
CAP	Y	W3391	A-5			27-41-12	ALL
S00145	**1082/ /L001**		**SW-STAB NOSE DOWN LIMIT**				**ALL**
1		W3391	B-1			22-13-11	ALL
2		W3391	B-2			22-13-11	ALL
3		W3391	B-3			22-13-11	ALL
4		W4222	A-K			27-41-12	ALL
5		W4222	A-G			27-41-12	ALL
6		W4222	A-F			27-41-12	ALL
CAP	Y	W3391	B-2			22-13-11	ALL
CAP	Y	W4222	A-G			27-41-12	ALL
S00149	**P008-00/ /**		**SW-BACKUP STAB TRIM CUTOUT**				**ALL**
2	1	W0008	0085	20		27-41-11	ALL
3	1	W0008	0061	20		27-41-11	ALL
5	1	W0008	0087	20		22-13-11	ALL
6	1	W0008	0064	20		22-13-11	ALL
S00156	**OFSS 394/ /**		**SW-REFUEL POWER CONTROL**				**ALL**
A		W1664	A-E			28-44-11	ALL
B		W1664	A-D			28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00161		**200/ /**		**SW-MIC CONTROL COL CAPT**				**ALL**
	3	A	W0443	0001	20		SPARE	ALL
	3	A	W0443	0003KN	20		23-51-11	ALL
	4	A	W0443	0006KR	20		23-51-11	ALL
S00168		**IFSS 193/ /**		**SNSR-LEADING EDGE FLAP 1 RETRACT**				**ALL**
	BLU		W1180	J-B			27-81-11	ALL
	RED		W1180	J-R			27-81-11	ALL
	YEL		W1180	J-Y			27-81-11	ALL
S00169		**IFSS 193/ /**		**SNSR-LEADING EDGE FLAP 1 EXTEND**				**ALL**
	BLU		W1180	I-B			27-81-11	ALL
	RED		W1180	I-R			27-81-11	ALL
	YEL		W1180	I-Y			27-81-11	ALL
S00170		**IFSS 137/ /**		**SNSR-LEADING EDGE FLAP 2 RETRACT**				**ALL**
	BLU		W1180	K-B			27-81-11	ALL
	RED		W1180	K-R			27-81-11	ALL
	YEL		W1180	K-Y			27-81-11	ALL
S00171		**IFSS 137/ /**		**SNSR-LEADING EDGE FLAP 2 EXTEND**				**ALL**
	BLU		W1180	L-B			27-81-11	ALL
	RED		W1180	L-R			27-81-11	ALL
	YEL		W1180	L-Y			27-81-11	ALL
S00172		**IFSS 137/ /**		**SNSR-LEADING EDGE FLAP 3 RETRACT**				**ALL**
	BLU		W1280	K-B			27-81-21	ALL
	RED		W1280	K-R			27-81-21	ALL
	YEL		W1280	K-Y			27-81-21	ALL
S00173		**IFSS 137/ /**		**SNSR-LEADING EDGE FLAP 3 EXTEND**				**ALL**
	BLU		W1280	L-B			27-81-21	ALL
	RED		W1280	L-R			27-81-21	ALL
	YEL		W1280	L-Y			27-81-21	ALL
S00174		**IFSS 193/ /**		**SNSR-LEADING EDGE FLAP 4 RETRACT**				**ALL**
	BLU		W1280	J-B			27-81-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00174	**IFSS 193/ /**		**SNSR-LEADING EDGE FLAP 4 RETRACT (continued)**				**ALL**
RED		W1280	J-R			27-81-21	ALL
YEL		W1280	J-Y			27-81-21	ALL
S00175	**IFSS 193/ /**		**SNSR-LEADING EDGE FLAP 4 EXTEND**				**ALL**
BLU		W1280	I-B			27-81-21	ALL
RED		W1280	I-R			27-81-21	ALL
YEL		W1280	I-Y			27-81-21	ALL
S00194	**332/267/R055**		**SW-FWD SERVICE DOOR SENSOR**				**ALL**
BLU		W6412	C-B			52-71-11	ALL
RED		W6412	C-A			52-71-11	ALL
YEL		W6412	C-C			52-71-11	ALL
S00195	**992/265/R059**		**SW-AFT SERVICE DOOR SENSOR**				**ALL**
BLU		W6248	D-B			52-71-11	ALL
RED		W6248	D-A			52-71-11	ALL
YEL		W6248	D-C			52-71-11	ALL
S00196	**197/170/L004**		**SW-FWD ACCESS DOOR**				**ALL**
1		W5160	A-A			52-71-12	ALL
3		W5160	A-B			52-71-12	ALL
S00197	**338/151/L011**		**SW-ELECTRONIC ACCESS DOOR**				**ALL**
C	C	W5156	0001	18		52-71-12	ALL
NO	C	W5156	0002	18		52-71-12	ALL
S00199	**308/267/L050**		**SW-FWD ENTRY DOOR SENSOR**				**ALL**
BLU		W5110	A-B			52-71-11	ALL
RED		W5110	A-A			52-71-11	ALL
YEL		W5110	A-C			52-71-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00200		**993/265/L055**		**SW-AFT ENTRY DOOR SENSOR**				**ALL**
	BLU		W6248	B-B			52-71-11	ALL
	RED		W6248	B-A			52-71-11	ALL
	YEL		W6248	B-C			52-71-11	ALL
S00214		**200/ /**		**SW-MIC CONTROL COL F/O**				**ALL**
	3	A	W0445	0002	20		SPARE	ALL
	3	A	W0445	0023KN	20		23-51-21	ALL
	4	A	W0445	0026KR	20		23-51-21	ALL
S00231		**214/237/R014**		**SW-A/P DISENGAGE CAPT**				**ALL**
	=B	GS	W0443	0005B	20		22-14-11	ALL
	=G	GS	W0443	0008G	20		22-11-12	ALL
	=N	GS	W0443	0018N	20		22-11-12	ALL
	=Y	GS	W0443	0007Y	20		22-11-12	ALL
	=KA	GS	W0443	0004KA	20		22-14-11	ALL
	=KB	GS	W0443	0017KB	20		22-11-12	ALL
	CAP	Y	W0443	0002K	20		SPARE	ALL
	CAP	Y	W0443	0013KG	20		SPARE	ALL
	CAP	Y	W0443	0014KY	20		SPARE	ALL
	CAP	Y	W0443	0015RN	20		SPARE	ALL
	CAP	Y	W0443	0016ON	20		SPARE	ALL
	CAP	Y	W0443	0019KV	20		SPARE	ALL
	CAP	Y	W0443	0051	20		SPARE	ALL
	CAP	Y	W0443	0052	20		SPARE	ALL
S00232		**214/237/L031**		**SW-A/P DISENGAGE F/O**				**ALL**
	=B	GS	W0445	0025B	20		22-14-11	ALL
	=G	GS	W0445	0028G	20		22-11-12	ALL
	=N	GS	W0445	0038N	20		22-11-12	ALL
	=Y	GS	W0445	0027Y	20		22-11-12	ALL
	=KA	GS	W0445	0024KA	20		22-14-11	ALL
	=KB	GS	W0445	0037KB	20		22-11-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00232		**214/237/L031**		**SW-A/P DISENGAGE F/O (continued)**				**ALL**
	CAP	Y	W0445	0022K	20		SPARE	ALL
	CAP	Y	W0445	0033KG	20		SPARE	ALL
	CAP	Y	W0445	0034KY	20		SPARE	ALL
	CAP	Y	W0445	0035RN	20		SPARE	ALL
	CAP	Y	W0445	0036ON	20		SPARE	ALL
	CAP	Y	W0445	0039KV	20		SPARE	ALL
	CAP	Y	W0445	0061	20		SPARE	ALL
	CAP	Y	W0445	0062	20		SPARE	ALL
S00238		**212/260/**		**SW-COMPASS LT**				**ALL**
	1	C	W2508	2002R	20		33-14-12	ALL
	2	C	W2508	1001	20		33-14-12	ALL
			W2508	1001Z			33-14-12	ALL
			W2508	2002B	20		33-14-12	ALL
S00246		**714/194/R055**		**SW-TE FLAPS DOWN**				**ALL**
	1		W8226	B-AA			27-53-12	ALL
	2		W8226	B-BB			27-53-12	ALL
	3		W8226	B-CC			27-53-12	ALL
	4		W8226	B-DD			27-53-12	ALL
	5		W8226	B-EE			27-53-12	ALL
	6		W8226	B-FF			27-53-12	ALL
	CAP	Y	W8226	B-BB			27-53-12	ALL
	CAP	Y	W8226	B-DD			27-53-12	ALL
	CAP	Y	W8226	B-EE			27-53-12	ALL
	CAP	Y	W8226	B-FF			27-53-12	ALL
S00248		**P005-00/ /**		**SW-AUXILIARY POWER UNIT MASTER**				**ALL**
	1C	B	W2510	0510	22		49-62-11	ALL
	2C	B	W2510	0510	22		49-62-11	ALL
	2C	B	W2510	0511	20		49-62-11	ALL
	2NC	B	W2702	0003	20		49-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00248		**P005-00/ /**		**SW-AUXILIARY POWER UNIT MASTER (continued)**				**ALL**
	1NO	B	W2510	0509	22		49-62-11	ALL
	2NO	B	W2702	0002	20		49-62-11	ALL
S00258		**P005-00/ /**		**SW-LANDING LIGHT - LEFT**				**ALL**
	1	1A	W2104	0035	20		33-42-21	ALL
	2	1A	W2104	0025	20		33-42-21	ALL
	4	1A	W2104	0029	20		33-42-21	ALL
	5	1A	W2104	0035	20		33-42-21	ALL
	6	1A	W2104	0026	20		33-42-21	ALL
S00259		**P005-00/ /**		**SW-LANDING LIGHT - RIGHT**				**ALL**
	1	1A	W2218	0091	20		33-42-21	ALL
	2	1A	W2218	0087	20		33-42-21	ALL
	4	1A	W2218	0083	20		33-42-21	ALL
	5	1A	W2218	0091	20		33-42-21	ALL
	6	1A	W2218	0086	20		33-42-21	ALL
S00266		**P005-00/ /**		**SW-ENG 1 START**				**ALL**
	X1	C	W2508	6029	24		80-11-11	ALL
	X2	C	W2508	6030	24		80-11-11	ALL
	1A	C	W2112	6050	20		80-11-11	ALL
	2A	C	W2112	6017	24		74-31-11	ALL
	3A	C	W2112	6016	24		74-31-11	ALL
	1B	C	W2508	6030	24		80-11-11	ALL
	1B	C	W2508	6031	20		80-11-11	ALL
	2B	C	W2112	6018	20		74-31-11	ALL
	3B	C	W2112	6015	20		74-31-11	ALL
S00267		**P005-00/ /**		**SW-ENG 2 START**				**ALL**
	X1	C	W2510	6022	24		80-11-11	ALL
	X2	C	W2510	6023	24		80-11-11	ALL
	1A	C	W2510	6021	20		80-11-11	ALL
	2A	C	W2218	6017	24		74-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00267	**P005-00/ /**		**SW-ENG 2 START (continued)**				**ALL**
3A	C	W2218	6016	24		74-31-11	ALL
1B	C	W2510	6023	24		80-11-11	ALL
1B	C	W2510	6024	20		80-11-11	ALL
2B	C	W2218	6015	20		74-31-11	ALL
3B	C	W2218	6014	20		74-31-11	ALL
S00268	**P005-00/ /**		**SW-TURNOFF LIGHT - LEFT**				**ALL**
1	1A	W2104	0028	20		33-42-21	ALL
2	1A	W2104	0024	20		33-42-21	ALL
S00269	**P005-00/ /**		**SW-TURNOFF LIGHT - RIGHT**				**ALL**
1	1A	W2218	0084	20		33-42-21	ALL
2	1A	W2218	0088	20		33-42-21	ALL
S00272	**F010/ /**		**SW-STAB TRIM C/O**				**ALL**
2	1	W0008	0081	20		27-41-11	ALL
3	1	W0008	0085	20		27-41-11	ALL
5	1	W0008	0080	20		22-13-11	ALL
6	1	W0008	0087	20		22-13-11	ALL
8	1	W0008	0093	20		22-13-11	ALL
9	1	W0008	0088	20		22-13-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00301		**710/180/R90**		**SW- #2 R MLG DN + LOCKED SENSOR**				**ALL**
	BLU		W8024	A-B			32-64-12	ALL
	RED		W8024	A-R			32-64-12	ALL
	YEL		W8024	A-Y			32-64-12	ALL
S00302		**710/180/L90**		**SW- #2 L MLG DN + LOCKED SENSOR**				**ALL**
	BLU		W7024	A-B			32-64-12	ALL
	RED		W7024	A-R			32-64-12	ALL
	YEL		W7024	A-Y			32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00519	**200/ /**		**SW-INT CONTROL COL CAPT**				**ALL**
3	A	W0443	0001	20		SPARE	ALL
4	A	W0443	0001A	20		23-51-11	ALL
S00520	**200/ /**		**SW-INT CONTROL COL F/O**				**ALL**
3	A	W0445	0002	20		SPARE	ALL
4	A	W0445	0021A	20		23-51-21	ALL
S00546	**1082/283/L014**		**SW-NOSE DOWN STAB TAKE-OFF WARNING**				**ALL**
1		W4134	A-F			31-53-11	ALL
2		W4134	A-D			31-53-11	ALL
3		W4134	A-C			31-53-11	ALL
4		W4134	A-E			31-53-11	ALL
5		W4134	A-B			31-53-11	ALL
6		W4134	A-A			31-53-11	ALL
CAP	Y	W4134	A-A			31-53-11	ALL
CAP	Y	W4134	A-B			31-53-11	ALL
CAP	Y	W4134	A-C			31-53-11	ALL
CAP	Y	W4134	A-E			31-53-11	ALL
S00574	**W0479/ /LFS**		**SW-TANK 1 REFUEL FLOAT**				**ALL**
=A		W1662	M-R			28-44-11	ALL
=B		W1662	M-B			28-44-11	ALL
S00576	**IFSS 127/ /RFS**		**SW-CENTER TANK REFUEL FLOAT**				**ALL**
=A		W1664	B-A			28-44-11	ALL
=B		W1664	B-B			28-44-11	ALL
S00578	**OFSS 590/ /RFS**		**SW-TANK 2 REFUEL FLOAT**				**ALL**
=A		W1664	A-J			28-44-11	ALL
=B		W1664	A-K			28-44-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00635		**P005-08/ /**		**SW-LOGO LIGHT**				**ALL**
	1	C	W2112	0002	20		33-49-11	ALL
	2	C	W2112	0001	20		33-49-11	ALL
S00650		**P008-00/ /**		**REJECTED TAKE-OFF SW**				**ALL**
	C	B	W0008	0041	20		27-62-11	ALL
	NO	B	W0008	0042	20		27-62-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00755		**241/241/L043**		**SW-LEFT WINDOW 3 (85F) THERMAL**				**ALL**
	=A	B	W2102	5525	20		30-41-11	ALL
	=B	B	W2102	5524	20		30-41-11	ALL
S00756		**241/245/R043**		**SW-RIGHT WINDOW 3 (85F) THERMAL**				**ALL**
	=A	B	W2204	5537	20		30-41-12	ALL
	=B	B	W2204	5536	20		30-41-12	ALL
S00786A		**220/ /**		**SW-TAKE-OFF/GO-AROUND**				**ALL**
	C	$	W0049	0001	22		22-11-14	ALL
	NO	$	W0049	0002	22		22-11-14	ALL
S00786B		**220/ /**		**SW-TAKE-OFF/GO-AROUND**				**ALL**
	C	$	W0051	0001	22		22-11-14	ALL
	NO	$	W0051	0002	22		22-11-14	ALL
S00787A		**220/ /**		**SW-TAKE-OFF/GO-AROUND**				**ALL**
	C	$	W0049	0003	22		22-11-14	ALL
	NO	$	W0049	0004	22		22-11-14	ALL
S00787B		**220/ /**		**SW-TAKE-OFF/GO-AROUND**				**ALL**
	C	$	W0051	0003	22		22-11-14	ALL
	NO	$	W0051	0004	22		22-11-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00828		**P008-00/ /**		**T/R 1 CONTROL SWITCH**				**ALL**
	C	Z2	W0049	0014	22		78-34-11	ALL
	NC	Z2	W0049	0011	22		78-34-11	ALL
	NO	Z2	W0049	0015	22		78-34-11	ALL
S00829		**P008-00/230/0001**		**T/R 2 CONTROL SWITCH**				**ALL**
	C	Z2	W0051	0034	22		78-34-21	ALL
	NC	Z2	W0051	0031	22		78-34-21	ALL
	NO	Z2	W0051	0036	22		78-34-21	ALL
S00844		**1082/278/L006**		**SW-ELECT STAB TRIM-NOSE DN FLP UP**				**ALL**
	1		W4222	A-H			27-41-12	ALL
	2		W4222	A-A			27-41-12	ALL
	3		W4222	A-B			27-41-12	ALL
	4		W4222	A-J			27-41-12	ALL
	5		W4222	A-C			27-41-12	ALL
	6		W4222	A-E			27-41-12	ALL
	CAP	Y	W4222	A-A			27-41-12	ALL
	CAP	Y	W4222	A-B			27-41-12	ALL
	CAP	Y	W4222	A-C			27-41-12	ALL
	CAP	Y	W4222	A-H			27-41-12	ALL
S00845		**260/200/L10**		**SW- #1 NOSE GEAR DOWN SENSOR**				**ALL**
	BLU		W7036	A-B			32-64-11	ALL
	RED		W7036	A-R			32-64-11	ALL
	YEL		W7036	A-Y			32-64-11	ALL
S00846		**280/170/L0.0**		**SW- #1 NOSE GESR LOCKED SENSOR**				**ALL**
	BLU		W7034	A-B			32-64-11	ALL
	RED		W7034	A-R			32-64-11	ALL
	YEL		W7034	A-Y			32-64-11	ALL
S00853		**261/190/R10**		**SW- #2 NOSE GEAR DOWN SENSOR**				**ALL**
	BLU		W8036	A-B			32-64-12	ALL
	RED		W8036	A-R			32-64-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00853		**261/190/R10**		**SW- #2 NOSE GEAR DOWN SENSOR (continued)**				**ALL**
	YEL		W8036	A-Y			32-64-12	ALL
S00854		**280/170/R0.0**		**SW- #2 NOSE GEAR LOCKED SENSOR**				**ALL**
	BLU		W8034	A-B			32-64-12	ALL
	RED		W8034	A-R			32-64-12	ALL
	YEL		W8034	A-Y			32-64-12	ALL
S00858		**P005-00/ /**		**SW-ENG IGN**				**ALL**
	2	C	W2218	6019	24		74-31-11	ALL
	3	C	W2218	6020	20		74-31-11	ALL
	7	C	W2112	6020	20		74-31-11	ALL
	8	C	W2112	6019	24		74-31-11	ALL
S00870		**P005-00/ /**		**SW-EQUIP COOLING SUPPLY**				**ALL**
	2	C	W2216	5524	22		21-27-31	ALL
	3	C	W2216	5525	22		21-27-31	ALL
	4	C	W2114	5502	22		21-27-31	ALL
	5	C	W2114	5501	22		21-27-31	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S00960		**441/164/R042**		**SW-FWD CARGO DOOR IND**				**ALL**
	C	C	W5248	A-B			52-71-12	ALL
	NO	C	W5248	A-A			52-71-12	ALL
S00961		**797/170/R041**		**SW-AFT CARGO DOOR IND**				**ALL**
	C	C	W6248	A-B			52-71-12	ALL
	NO	C	W6248	A-A			52-71-12	ALL
S00989		**P007-00/ /**		**SWITCH-PTT FIRST-OFFICERS GLARESHIELD**				**ALL**
	1C	Z2	W0204	0001	24		23-51-21	ALL
	1NO	Z2	W0204	0002	24		23-51-21	ALL
S00994		**714/FSS/L**		**SNSR-LEADING EDGE SLAT 1 OUTBOARD**				**ALL**
	BLU		W1188	A-B			27-81-12	ALL
	RED		W1188	A-R			27-81-12	ALL
	YEL		W1188	A-Y			27-81-12	ALL
S00995		**659/FSS/L**		**SNSR-LEADING EDGE SLAT 1 INBOARD**				**ALL**
	BLU		W1188	B-B			27-81-12	ALL
	RED		W1188	B-R			27-81-12	ALL
	YEL		W1188	B-Y			27-81-12	ALL
S00996		**583/FSS/L**		**SNSR-LEADING EDGE SLAT 2 OUTBOARD**				**ALL**
	BLU		W1188	C-B			27-81-12	ALL
	RED		W1188	C-R			27-81-12	ALL
	YEL		W1188	C-Y			27-81-12	ALL
S00997		**533/FSS/L**		**SNSR-LEADING EDGE SLAT 2 INBOARD**				**ALL**
	BLU		W1188	D-B			27-81-12	ALL
	RED		W1188	D-R			27-81-12	ALL
	YEL		W1188	D-Y			27-81-12	ALL
S00998		**466/FSS/L**		**SNSR-LEADING EDGE SLAT 3 OUTBOARD**				**ALL**
	BLU		W1188	E-B			27-81-12	ALL
	RED		W1188	E-R			27-81-12	ALL
	YEL		W1188	E-Y			27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S00999	**415/FSS/L**		**SNSR-LEADING EDGE SLAT 3 INBOARD**				**ALL**
BLU		W1188	F-B			27-81-12	ALL
RED		W1188	F-R			27-81-12	ALL
YEL		W1188	F-Y			27-81-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S01000		**349/ /RFS**		**SNSR-LEADING EDGE SLAT 4 OUTBOARD**				**ALL**
	BLU		W1188	G-B			27-81-12	ALL
	RED		W1188	G-R			27-81-12	ALL
	YEL		W1188	G-Y			27-81-12	ALL
S01001		**300/ /RFS**		**SNSR-LEADING EDGE SLAT 4 INBOARD**				**ALL**
	BLU		W1188	H-B			27-81-12	ALL
	RED		W1188	H-R			27-81-12	ALL
	YEL		W1188	H-Y			27-81-12	ALL
S01002		**OFSS 349/ /RFS**		**SNSR-LEADING EDGE SLAT 5 OUTBOARD**				**ALL**
	BLU		W1288	A-B			27-81-22	ALL
	RED		W1288	A-R			27-81-22	ALL
	YEL		W1288	A-Y			27-81-22	ALL
S01003		**300/ /RFS**		**SNSR-LEADING EDGE SLAT 5 INBOARD**				**ALL**
	BLU		W1288	B-B			27-81-22	ALL
	RED		W1288	B-R			27-81-22	ALL
	YEL		W1288	B-Y			27-81-22	ALL
S01004		**466/ /RFS**		**SNSR-LEADING EDGE SLAT 6 OUTBOARD**				**ALL**
	BLU		W1288	C-B			27-81-22	ALL
	RED		W1288	C-R			27-81-22	ALL
	YEL		W1288	C-Y			27-81-22	ALL
S01005		**415/ /RFS**		**SNSR-LEADING EDGE SLAT 6 INBOARD**				**ALL**
	BLU		W1288	D-B			27-81-22	ALL
	RED		W1288	D-R			27-81-22	ALL
	YEL		W1288	D-Y			27-81-22	ALL
S01006		**583/ /**		**SNSR-LEADING EDGE SLAT 7 OUTBOARD**				**ALL**
	BLU		W1288	E-B			27-81-22	ALL
	RED		W1288	E-R			27-81-22	ALL
	YEL		W1288	E-Y			27-81-22	ALL
S01007		**OFSS 533/ /RFS**		**SNSR-LEADING EDGE SLAT 7 INBOARD**				**ALL**
	BLU		W1288	F-B			27-81-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S01007		**OFSS 533/ /RFS**		**SNSR-LEADING EDGE SLAT 7 INBOARD (continued)**				**ALL**
	RED		W1288	F-R			27-81-22	ALL
	YEL		W1288	F-Y			27-81-22	ALL
S01008		**715/RFS/**		**SNSR-LEADING EDGE SLAT 8 OUTBOARD**				**ALL**
	BLU		W1288	G-B			27-81-22	ALL
	RED		W1288	G-R			27-81-22	ALL
	YEL		W1288	G-Y			27-81-22	ALL
S01009		**660/RFS/**		**SNSR-LEADING EDGE SLAT 8 INBOARD**				**ALL**
	BLU		W1288	H-B			27-81-22	ALL
	RED		W1288	H-R			27-81-22	ALL
	YEL		W1288	H-Y			27-81-22	ALL
S01010		**695/135/R120**		**SW- #1 R GEAR ON GROUND**				**ALL**
	BLU		W8234	A-B			32-31-11	ALL
	RED		W8234	A-R			32-31-11	ALL
	YEL		W8234	A-Y			32-31-11	ALL
S01011		**700/135/R110**		**SW- #2 R GEAR ON GROUND**				**ALL**
	BLU		W8236	A-B			32-31-12	ALL
	RED		W8236	A-R			32-31-12	ALL
	YEL		W8236	A-Y			32-31-12	ALL
S01012		**695/135/L115**		**SW- #1 L GEAR ON GROUND**				**ALL**
	BLU		W7134	A-B			32-31-11	ALL
	RED		W7134	A-R			32-31-11	ALL
	YEL		W7134	A-Y			32-31-11	ALL
S01013		**695/135/L110**		**SW- #2 L GEAR ON GROUND**				**ALL**
	BLU		W7136	A-B			32-31-12	ALL
	RED		W7136	A-R			32-31-12	ALL
	YEL		W7136	A-Y			32-31-12	ALL
S01014		**300/135/L0.0**		**SW- #1 NOSE GEAR ON GND**				**ALL**
	BLU		W7032	A-B			32-31-11	ALL
	RED		W7032	A-R			32-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S01014		**300/135/L0.0**		**SW- #1 NOSE GEAR ON GND (continued)**				**ALL**
	YEL		W7032	A-Y			32-31-11	ALL
S01015		**300/135/R0.0**		**SW- #2 NOSE GEAR ON GROUND**				**ALL**
	BLU		W8032	A-B			32-31-12	ALL
	RED		W8032	A-R			32-31-12	ALL
	YEL		W8032	A-Y			32-31-12	ALL
S01016		**695/188/L056**		**SW- #2 L MLG UP + LOCKED SNSR**				**ALL**
	BLU		W7126	A-B			32-64-12	ALL
	RED		W7126	A-R			32-64-12	ALL
	YEL		W7126	A-Y			32-64-12	ALL
S01017		**695/188/R020**		**SW- #2 R MLG UP + LOCKED SNSR**				**ALL**
	BLU		W8224	A-B			32-64-12	ALL
	RED		W8224	A-R			32-64-12	ALL
	YEL		W8224	A-Y			32-64-12	ALL
S01039		**P008-00/ /**		**SW-FLAP HANDLE 10 TO 40**				**ALL**
	C		W0008	A-RD			27-54-11	ALL
	NC		W0008	A-BL			27-54-11	ALL
	NO		W0008	A-YL			27-54-11	ALL
S01084		**788/199/R059**		**SW-BELLY LOADER (BFE/STC)**				**ALL**
	1C	B	W3154	0039	22		25-51-21	ALL
	1NC	B	W3154	0040	22		25-51-21	ALL
S01090		**P008-00/ /**		**SW-FLAP HANDLE UP**				**ALL**
	C		W0008	B-RD			27-81-51	ALL
	NC		W0008	B-BL			27-81-51	ALL
	NO		W0008	B-YL			27-81-51	ALL
S01091		**200/ /**		**SWITCH-PTT CAPTAIN'S GLARESHIELD**				**ALL**
	1C	Z2	W0104	0001	24		23-51-11	ALL
	1NO	Z2	W0104	0002	24		23-51-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S01104		**616/259/L067**		**SW-OVERWING DOOR-LEFT AFT-A**				**ALL**
	=RED		W3142	I-A			52-71-13	ALL
	=WHT		W3142	I-B			52-71-13	ALL
S01105		**639/259/L067**		**SW-OVERWING DOOR-LEFT AFT-B**				**ALL**
	=RED		W3142	G-A			52-71-13	ALL
	=WHT		W3142	G-B			52-71-13	ALL
S01106		**616/259/R067**		**SW-OVERWING DOOR-RIGHT AFT-A**				**ALL**
	=RED		W4142	I-A			52-71-14	ALL
	=WHT		W4142	I-B			52-71-14	ALL
S01107		**639/259/R067**		**SW-OVERWING DOOR-RIGHT AFT-B**				**ALL**
	=RED		W4142	G-A			52-71-14	ALL
	=WHT		W4142	G-B			52-71-14	ALL
S01108		**578/259/L067**		**SW-OVERWING DOOR-LEFT FWD-A**				**ALL**
	=RED		W3142	P-A			52-71-13	ALL
	=WHT		W3142	P-B			52-71-13	ALL
S01109		**601/259/L067**		**SW-OVERWING DOOR-LEFT FWD-B**				**ALL**
	=RED		W3142	Q-A			52-71-13	ALL
	=WHT		W3142	Q-B			52-71-13	ALL
S01110		**578/259/R067**		**SW-OVERWING DOOR-RIGHT FWD-A**				**ALL**
	=RED		W4142	P-A			52-71-14	ALL
	=WHT		W4142	P-B			52-71-14	ALL
S01111		**601/259/R067**		**SW-OVERWING DOOR-RIGHT FWD-B**				**ALL**
	=RED		W4142	Q-A			52-71-14	ALL
	=WHT		W4142	Q-B			52-71-14	ALL
S01112		**633/256/L068**		**SW-OVERWING FLIGHT LOCK-LEFT**				**ALL**
	=WHT		W3142	H-A			52-71-13	ALL
	=WHT		W3142	H-B			52-71-13	ALL
S01113		**595/256/L068**		**SW-OVERWING FLIGHT LOCK-LEFT FWD**				**ALL**
	=WHT		W3142	R-A			52-71-13	ALL
	=WHT		W3142	R-B			52-71-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S01114		**621/256/R068**		**SW-OVERWING FLIGHT LOCK-RIGHT**				**ALL**
	=WHT		W4142	H-A			52-71-14	ALL
	=WHT		W4142	H-B			52-71-14	ALL
S01115		**583/256/R068**		**SW-OVERWING FLIGHT LOCK-RIGHT FWD**				**ALL**
	=WHT		W4142	R-A			52-71-14	ALL
	=WHT		W4142	R-B			52-71-14	ALL
S01127		**358/166/R007**		**SW-GEAR DOWN DISPATCH SWITCH**				**ALL**
	2	C	W5337	0005	22		34-21-12	ALL
	3	C	W5337	0004	22		34-21-12	ALL
	5	C	W6414	0012	22		34-21-22	ALL
	6	C	W6414	0011	22		34-21-22	ALL
S01147		**347.4/270/53.9**		**SW - FWD ENTRY DOOR**				**ALL**
	1		W3058	A-1			52-71-11	ALL
	2		W3058	A-2			52-71-11	ALL
	3		W3058	A-3			52-71-11	ALL
	4		W3058	A-4			52-71-11	ALL
	5		W3058	A-5			52-71-11	ALL
	6		W3058	A-6			52-71-11	ALL
	CAP	Y	W3058	A-2			52-71-11	ALL
	CAP	Y	W3058	A-4			52-71-11	ALL
	CAP	Y	W3058	A-5			52-71-11	ALL
	CAP	Y	W3058	A-6			52-71-11	ALL
S01183		**1079/282/L014**		**SW-NOSE DOWN STAB TAKE-OFF WARN**				**ALL**
	1		W4134	D-F			31-53-11	ALL
	2		W4134	D-D			31-53-11	ALL
	3		W4134	D-C			31-53-11	ALL
	4		W4134	D-E			31-53-11	ALL
	5		W4134	D-B			31-53-11	ALL
	6		W4134	D-A			31-53-11	ALL
	CAP	Y	W4134	D-A			31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S01183		**1079/282/L014**		**SW-NOSE DOWN STAB TAKE-OFF WARN (continued)**				**ALL**
	CAP	Y	W4134	D-B			31-53-11	ALL
	CAP	Y	W4134	D-D			31-53-11	ALL
	CAP	Y	W4134	D-E			31-53-11	ALL
S01184		**1079/267/L017**		**SW-NOSE UP STAB TAKE-OFF WARN**				**ALL**
	1		W4134	C-F			31-53-11	ALL
	2		W4134	C-D			31-53-11	ALL
	3		W4134	C-C			31-53-11	ALL
	4		W4134	C-E			31-53-11	ALL
	5		W4134	C-B			31-53-11	ALL
	6		W4134	C-A			31-53-11	ALL
	CAP	Y	W4134	C-A			31-53-11	ALL
	CAP	Y	W4134	C-B			31-53-11	ALL
	CAP	Y	W4134	C-D			31-53-11	ALL
	CAP	Y	W4134	C-E			31-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
S01200		**NSTA 202/119/L33**		**LH T/R PROXIMITY SENSOR ACTUATOR**				**ALL**
	BLU		W1080	A-B			78-36-11	ALL
	RED		W1080	A-R			78-36-11	ALL
	=GND		W1080	A-Z			78-36-11	ALL
S01201		**NSTA 202/119/L33**		**LH T/R PROXIMITY SENSOR ACTUATOR**				**ALL**
	BLU		W1080	B-B			78-36-11	ALL
	RED		W1080	B-R			78-36-11	ALL
	=GND		W1080	B-Z			78-36-11	ALL
S01202		**NSTA 197/128/R26**		**RIGHT T/R PROXIMITY SENSOR ACTUATOR**				**ALL**
	BLU		W1084	A-B			78-36-11	ALL
	RED		W1084	A-R			78-36-11	ALL
	=GND		W1084	A-Z			78-36-11	ALL
S01203		**NSTA 197/128/R26**		**RIGHT T/R PROXIMITY SENSOR ACTUATOR**				**ALL**
	BLU		W1084	B-B			78-36-11	ALL
	RED		W1084	B-R			78-36-11	ALL
	=GND		W1084	B-Z			78-36-11	ALL
S01204		**J023-00/ /**		**SW-EQUIP COOL SMK DET TEST**				**ALL**
	3	A	W0098	0133	22		26-19-11	ALL
	4	A	W0098	0134	22		26-19-11	ALL
S01212		**P007-00/ /**		**SWITCH-REMOTE CLOCK FIRST-OFFICER'S**				**ALL**
	1C	Z2	W0204	2751B	24		31-65-13	ALL
	C	Z2	W0204	2752B	24		31-65-23	ALL
	1NO	Z2	W0204	2751R	24		31-65-13	ALL
	NO	Z2	W0204	2752R	24		31-65-23	ALL
S01213		**P007-00/ /**		**SWITCH-REMOTE CLOCK CAPTAIN'S**				**ALL**
	1C	Z2	W0104	2751B	24		31-65-13	ALL
	C	Z2	W0104	2752B	24		31-65-23	ALL
	1NO	Z2	W0104	2751R	24		31-65-13	ALL
	NO	Z2	W0104	2752R	24		31-65-23	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
S01214		**P005-00/ /**		**SWITCH-ELEVATOR JAM**				**ALL**
	3C	Z2	W2216	2003R	22		27-61-42	ALL
	4C	Z2	W2216	2004R	22		27-61-42	ALL
	3NO	Z2	W2216	2003B	22		27-61-42	ALL
	4NO	Z2	W2216	2004B	22		27-61-42	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
T00006		**385/160/R027**		**XFMR-28V AC**				**ALL**
	LV1	E	W6110	0517	10		24-53-11	ALL
	G	E	W6110	0518	08		24-53-11	ALL
	HV	E	W6210	0530	18		24-53-11	ALL
T00010		**386/159/L026**		**XFMR-28V AC**				**ALL**
	LV1	E	W5030	0504	10		24-53-11	ALL
	G	E	W5030	0505	10		24-53-11	ALL
	HV	E	W5112	0501	20		24-53-11	ALL
T00031		**P005-00/ /**		**XFMR-VARIABLE P5 LIGHTING 0V/28V**				**ALL**
	G	D	W2216	5543	16		33-12-11	ALL
	HV	D	W2216	5542	18		33-12-11	ALL
	LV	D	W2216	5544	10		33-12-11	ALL
T00033		**P006-00/ /**		**XFMR-LIGHTING 28V/5V**				**ALL**
	LV1	E	W0044	0075	16		33-12-11	ALL
	G	E	W0044	0074	10		33-12-11	ALL
	HV	E	W0044	0073	10		33-12-11	ALL
T00034		**P006-00/ /**		**XFMR-LIGHTING 28V/5V**				**ALL**
	LV1	E	W0044	0081	16		33-12-12	ALL
	G	E	W0044	0084	10		33-12-12	ALL
	HV	E	W0044	0083	10		33-12-12	ALL
T00038		**P018-00/ /**		**XFMR-28V AC**				**ALL**
	G	E	W0020	0889	06		24-53-11	ALL
	HV	E	W0020	0891	18		24-53-11	ALL
	LV	E	W0020	0892	08		24-53-11	ALL
T00052		**P006-00/ /**		**XFMR-28V AC**				**ALL**
	LV1	E	W0040	6203	10		24-53-11	ALL
	G	E	W0040	6204	08		24-53-11	ALL
	HV	E	W0040	6202	20		24-53-11	ALL
T00060		**P005-00/ /**		**CONTROL-CB PNL LIGHTS,0-28V**				**ALL**
	G	D	W2218	5563	18		33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
T00060		**P005-00/ /**		**CONTROL-CB PNL LIGHTS,0-28V (continued)**				**ALL**
	HV	D	W2218	5562	18		33-14-12	ALL
	LV	D	W2218	5564	18		33-14-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
T00335		**200/ /**		**TB-CAPT CONTROL WHEEL(STAB TRIM SW)**				**ALL**
	1	C	W0443	0009O	20		27-41-11	ALL
	2	C	W0443	0012V	20		27-41-11	ALL
	3	C	W0443	0011R	20		27-41-11	ALL
	4	C	W0443	0010KO	20		27-41-11	ALL
T00336		**200/ /**		**TB-F/O CONTROL WHEEL (STAB TRIM SW)**				**ALL**
	1	C	W0445	0029O	20		27-41-11	ALL
	2	C	W0445	0032V	20		27-41-11	ALL
	3	C	W0445	0031R	20		27-41-11	ALL
	4	C	W0445	0030KO	20		27-41-11	ALL
T00362		**251/204/L001**		**TS-CONT STAND-P8**				**ALL**
	LV1	E	W6206	5503	16		33-11-33	ALL
	LV1	E	W6206	5542	20		33-14-11	ALL
	HV	E	W6206	5501	20		33-11-33	ALL
	GND	E	W6206	5502	16		33-11-33	ALL
T00371		**P006-00/ /**		**XFMR-PRESSURIZATION CONTROL-LCD LIGHTING**				**ALL**
	LV1	D	W0044	0457	24		21-31-25	ALL
	HV	D	W0044	0455	24		21-31-25	ALL
	GND	D	W0044	0456	20		21-31-25	ALL
T00391		**P006-00/ /**		**XFMR-28V AC**				**ALL**
	G	E	W0040	6207	10		24-53-11	ALL
	HV	E	W0040	6205	22		24-53-11	ALL
	LV	E	W0040	6206	12		24-53-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
T00434		**IRSS 208/ /**		**SNSR-FUEL TEMPERATURE TANK 1**				**ALL**
	=A		W7230	A-AA			28-42-11	ALL
	=B		W7230	B-BB			28-42-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Term	Station / WL / BL Type	Bundle	Description Wire No.	GA	CO	Diagram	Effectivity
T03037		**P006-00/ /**		**XFMR- 28/5V AC ELEX PANEL LIGHTING 1**				**ALL**
	HV	E	W0044	6215	14		33-11-41	ALL
	HV	E	W0044	6216	14		33-11-41	ALL
	LV	E	W0044	6222	14		33-11-41	ALL
	LV	E	W0044	6226	14		33-11-41	ALL
	GND	E	W0044	6221	16		33-11-41	ALL
T03038		**P006-00/ /**		**XFMR- 28/5V AC ELEX PANEL LIGHTING 2**				**ALL**
	HV	E	W0044	6216	14		33-11-41	ALL
	LV	E	W0044	6224	14		33-11-41	ALL
	LV	E	W0044	6225	14		33-11-41	ALL
	LV	E	W0044	6228	14		33-11-41	ALL
	GND	E	W0044	6223	16		33-11-41	ALL
T03073		**P007-00/ /**		**REMOTE LIGHT SENSOR-CAPT**				**ALL**
	BLK		W0104	A-AB			31-65-11	ALL
	BLU		W0104	A-AE			31-65-11	ALL
	ORG		W0104	A-AA			31-65-11	ALL
	RED		W0104	A-AD			31-65-11	ALL
	YEL		W0104	A-AC			31-65-11	ALL
T03074		**P007-00/ /**		**REMOTE LIGHT SENSOR-F/O**				**ALL**
	BLK		W0204	A-AB			31-65-21	ALL
	BLU		W0204	A-AE			31-65-21	ALL
	ORG		W0204	A-AA			31-65-21	ALL
	RED		W0204	A-AD			31-65-21	ALL
	YEL		W0204	A-AC			31-65-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0020DY		**J020-0B/ /**		**TERMINAL BLOCK -**				**ALL**
	A001	1A	W0072	0133	22		21-27-31	ALL
	A001	1A	W0072	0512	24		21-27-31	ALL
	A003	1A	W0072	0512	24		21-27-31	ALL
	A005	1A	W0072	0120	24		21-27-31	ALL
	A005	1A	W0072	0132	24		21-27-31	ALL
	A023	1A	W0072	0201	22		23-31-06	ALL
	A023	1A	W0072	0203	22		23-31-06	ALL
	B001	1A	W0072	0113	24		21-27-31	ALL
	B001	1A	W0072	0511	22		21-27-31	ALL
	B003	1A	W0072	0515	24		21-27-31	ALL
	B005	1A	W0072	0514	22		21-27-31	ALL
	B005	1A	W0072	0515	24		21-27-31	ALL
	B023	1A	W0072	0202	20		23-31-06	ALL
	B023	1A	W0072	0208	20		23-31-06	ALL
TB0022DY		**J022-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A013	1A	W0076	0073	24		21-42-11	ALL
	A013	1A	W0076	0075	24		21-42-11	ALL
	A015	1A	W0076	0075	24		21-42-11	ALL
	A021	1A	W0076	0519	20		52-71-13	ALL
	B013	1A	W0076	0076	24		21-42-11	ALL
	B015	1A	W0076	0077	24		21-42-11	ALL
	B021	1A	W0076	0518	20		52-71-13	ALL
	B021	1A	W0076	0520	20		52-71-13	ALL
TB0022DZ		**J022-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A017	1A	W0076	0019	20		52-71-13	ALL
	A017	1A	W0076	0517	20		52-71-13	ALL
	A017	1A	W0076	0519	20		52-71-13	ALL
	B017	1A	W0076	0009	20		52-71-13	ALL
	B017	1A	W0076	0500	20		52-71-13	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0024DY		**J024-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A003	1A	W0080	0018	20		52-71-14	ALL
	A009	1D	W0080	6026	18		78-32-61	ALL
	A011	1D	W0080	6029	18		78-32-61	ALL
	A017	1A	W0080	5607	24		21-43-21	ALL
	A017	1A	W0080	5609	24		21-43-21	ALL
	A019	1A	W0080	5606	24		21-43-21	ALL
	A019	1A	W0080	5633	22		21-27-21	ALL
	B003	1A	W0080	0015	20		52-71-14	ALL
	B003	1A	W0080	0021	20		52-71-14	ALL
	B009	1D	W0080	6041	18		78-32-61	ALL
	B009	1D	W0080	6048	18		78-32-61	ALL
	B011	1D	W0080	6042	18		78-32-61	ALL
	B011	1D	W0080	6047	18		78-32-61	ALL
	B017	1A	W0080	5610	24		21-43-21	ALL
	B019	1A	W0080	5607	24		21-43-21	ALL
TB0025DY		**J011-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1D	W0122	0001	18		29-25-11	ALL
	A003	1D	W0122	0002	18		29-25-11	ALL
	A005	1D	W0122	0003	18		29-25-11	ALL
	B001	1D	W0122	0012	18		29-25-11	ALL
	B003	1D	W0122	0013	18		29-25-11	ALL
	B005	1D	W0122	0014	18		29-25-11	ALL
TB0028DY		**J020-0A/ /**		**TERMINAL BLOCK -**				**ALL**
	A001	1A	W0074	0172	20		21-31-22	ALL
	A003	1A	W0074	0173	20		21-31-23	ALL
	B001	1A	W0074	0005	22		26-16-21	ALL
	B001	1A	W0074	0006	22		26-16-21	ALL
	B003	1A	W0074	0006	22		26-16-21	ALL
	B003	1A	W0074	0007	22		26-16-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0032DY		**J022-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A005	1D	W0076	0529	18		78-32-51	ALL
	A007	1D	W0076	0530	18		78-32-51	ALL
	B005	1D	W0076	0311	18		78-32-51	ALL
	B005	1D	W0076	0317	18		78-32-51	ALL
	B007	1D	W0076	0309	18		78-32-51	ALL
	B007	1D	W0076	0313	18		78-32-51	ALL
TB0034DY		**J024-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W0080	5533	24		21-27-21	ALL
	A003	1A	W0080	5533	24		21-27-21	ALL
	A003	1A	W0080	5538	24		21-27-21	ALL
	A005	1A	W0080	5536	24		21-27-21	ALL
	A007	1A	W0080	0018	20		52-71-14	ALL
	A007	1A	W0080	0050	20		52-71-14	ALL
	A009	1A	W0080	5553	22		21-25-11	ALL
	A009	1A	W0080	5554	22		21-25-11	ALL
	A011	1A	W0080	5560	22		21-25-11	ALL
	A011	1A	W0080	5561	22		21-25-11	ALL
	A015	1A	W0080	5611	24		21-43-21	ALL
	B001	1A	W0080	5532	24		21-27-21	ALL
	B001	1A	W0080	5565	22		21-27-21	ALL
	B003	1A	W0080	5534	24		21-27-21	ALL
	B005	1A	W0080	5534	24		21-27-21	ALL
	B005	1A	W0080	5535	24		21-27-21	ALL
	B007	1A	W0080	0005	20		52-71-14	ALL
	B007	1A	W0080	0016	20		52-71-14	ALL
	B009	1A	W0080	5559	22		21-25-11	ALL
	B011	1A	W0080	5562	22		21-25-11	ALL
	B015	1A	W0080	5520	24		21-43-21	ALL
	B015	1A	W0080	5610	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0098DY		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A009	1A	W0098	0125	22		26-19-11	ALL
	A009	1A	W0098	0126	22		26-19-11	ALL
	A021	1A	W0098	0183	24		21-27-31	ALL
	B009	1A	W0098	0149	22		26-19-11	ALL
	B021	1A	W0098	0156	22		26-19-11	ALL
	B021	1A	W0098	0187	22		21-43-21	ALL
TB0098DZ		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W0098	0101	22		26-19-11	ALL
	A001	1A	W0098	0103	22		26-19-11	ALL
	B001	1A	W0098	0109	22		26-19-11	ALL
	B001	1A	W0098	0110	22		26-19-11	ALL
	B001	1A	W0098	0118	22		26-19-11	ALL
TB0098RY		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A017	1A	W0098	0158	22		26-19-11	ALL
	A017	1A	W0098	0161	22		26-19-11	ALL
	B017	1A	W0098	0159	22		26-19-11	ALL
TB0098RZ		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A005	1A	W0098	0111	22		26-19-11	ALL
	A005	1A	W0098	0153	22		26-19-11	ALL
	A005	1A	W0098	0157	22		26-19-11	ALL
	A013	1A	W0098	0118	22		26-19-11	ALL
	A013	1A	W0098	0120	22		26-19-11	ALL
	A013	1A	W0098	0127	22		26-19-11	ALL
	A013	1A	W0098	0137	22		26-19-11	ALL
	A013	1A	W0098	0166	22		26-19-11	ALL
	A013	1A	W0098	0184	24		21-25-11	ALL
	B005	1A	W0098	0104	22		26-19-11	ALL
	B005	1A	W0098	0124	22		26-19-11	ALL
	B005	1A	W0098	0142	22		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0098RZ		**J023-00/ /**		**TERMINAL BLOCK- (continued)**				**ALL**
	B005	1A	W0098	0164	22		26-19-11	ALL
	B013	1A	W0098	0122	22		26-19-11	ALL
	B013	1A	W0098	0139	22		26-19-11	ALL
TB0099DY		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A009	1A	W0098	0126	22		26-19-11	ALL
	A013	1A	W0098	0171	22		26-19-11	ALL
	B009	1A	W0098	0143	22		26-19-11	ALL
	B009	1A	W0098	0186	22		26-19-11	ALL
	B013	1A	W0098	0115	22		26-19-11	ALL
	B013	1A	W0098	0167	22		26-19-11	ALL
TB0099DZ		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W0098	0102	22		26-19-11	ALL
	A001	1A	W0098	0106	22		26-19-11	ALL
	B001	1A	W0098	0110	22		26-19-11	ALL
	B001	1A	W0098	0111	22		26-19-11	ALL
	B001	1A	W0098	0112	22		26-19-11	ALL
TB0099RZ		**J023-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A005	1A	W0098	0112	22		26-19-11	ALL
	A005	1A	W0098	0129	22		26-19-11	ALL
	A005	1A	W0098	0158	22		26-19-11	ALL
	B005	1A	W0098	0107	22		26-19-11	ALL
	B005	1A	W0098	0165	22		26-19-11	ALL
	B005	1A	W0098	0185	22		26-19-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0201DY		**P002-00/ /**		**TRACK-GND/TERM BLOCK**				**ALL**
	A011	1A	W0001	1765	22		32-31-15	ALL
	A011	1A	W0001	1767	22		32-31-15	ALL
	A013	1A	W0003	1773	22		32-31-15	ALL
	A013	1A	W0003	1774	22		32-31-15	ALL
	B011	1A	W0001	1766	22		32-31-15	ALL
	B013	1A	W0003	1775	22		32-31-15	ALL
TB0261DY		**261/280/R005**		**TERMINAL BLOCK-**				**ALL**
	A009	1A	W2508	6025	20		76-21-11	ALL
	A011	1A	W5170	6009	20		28-21-11	ALL
	A011	1A	W5170	6011	20		28-21-11	ALL
	B009	1A	W2508	6024	20		76-21-11	ALL
	B011	1A	W2508	6007	20		28-21-11	ALL
TB0262DY		**264/280/R005**		**TERMINAL BLOCK-**				**ALL**
	A009	1A	W2510	6018	20		76-21-21	ALL
	A011	1A	W6170	6007	20		28-21-11	ALL
	A011	1A	W6170	6011	20		28-21-11	ALL
	B009	1A	W2510	6019	20		76-21-21	ALL
	B011	1A	W2510	6002	20		28-21-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0403DY		**J004-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A003	1A	W0094	0162	22		44-21-22	ALL
	B003	1A	W0094	0163	22		44-21-22	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0502DY		**P005-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A021	1A	W2112	5501	22		21-27-21	ALL
	A021	1A	W2112	5503	22		21-27-21	ALL
	B021	1A	W2112	5502	22		21-27-21	ALL
	B021	1A	W2112	5504	22		21-27-21	ALL
TB0505DY		**P005-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A011	1A	W2112	5503	22		21-27-21	ALL
	A013	1A	W2508	5505	24		21-31-11	ALL
	B011	1A	W2216	5501	22		21-27-31	ALL
	B011	1A	W2216	5502	22		21-27-31	ALL
	B013	1A	W2112	5510	24		21-31-11	ALL
	B013	1A	W2508	5504	24		21-31-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0608DY		**J046-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A013	1A	W2218	5809	22		30-31-11	ALL
	A013	1A	W2218	5810	22		30-31-11	ALL
	A015	1A	W2218	5810	22		30-31-11	ALL
	B013	1A	W2237	0005	22		30-31-11	ALL
	B015	1A	W2237	0006	22		30-31-11	ALL
TB0610DY		**P006-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W0044	0262	24		32-42-11	ALL
	A001	1A	W0044	0266	24		32-42-11	ALL
	A003	1A	W0044	0264	24		32-42-11	ALL
	A003	1A	W0044	0269	24		32-42-11	ALL
	B001	1A	W0044	0268	24		32-42-11	ALL
	B001	1A	W0044	0271	24		32-42-11	ALL
	B003	1A	W0044	0270	22		32-42-11	ALL
	B003	1A	W0044	0271	24		32-42-11	ALL
TB0662DY		**J046-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A019	1A	W0066	0018	22		21-33-11	ALL
	A019	1A	W0066	0336	22		31-53-11	ALL
	B019	1A	W0066	0017	22		21-33-11	ALL
	B019	1A	W0066	0357	22		21-33-11	ALL
TB0666DY		**J046-00/ /**		**TERMINAL BLOCK-**				**ALL**
	A005	1A	W0066	0454	22		21-27-21	ALL
	A007	1A	W0066	0453	22		21-43-21	ALL
	A009	1A	W0066	0461	22		21-27-51	ALL
	A011	1A	W0066	0449	22		21-27-51	ALL
	A013	1A	W0066	0459	22		21-27-51	ALL
	A015	1A	W0066	0464	24		21-43-21	ALL
	B005	1A	W0066	0455	22		21-27-21	ALL
	B005	1A	W0066	0456	22		21-27-21	ALL
	B007	1A	W0066	0456	22		21-27-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0666DY		**J046-00/ /**		**TERMINAL BLOCK- (continued)**				**ALL**
	B009	1A	W0066	0460	22		21-27-51	ALL
	B011	1A	W0066	0457	22		21-27-51	ALL
	B013	1A	W0066	0458	22		21-27-51	ALL
	B015	1A	W0066	0465	24		21-43-21	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB0952DY		**953/305/L003**		**TERMINAL BLOCK-**				**ALL**
	A009	1A	W3058	0249	22		23-42-15	ALL
	A011	1A	W3058	0266	22		23-42-15	ALL
	A013	1A	W3311	0053	22		23-31-01	ALL
	A015	1A	W3311	0055	22		23-42-12	ALL
	B009	1A	W3058	0187	22		23-42-15	ALL
	B011	1A	W3058	0166	22		23-42-15	ALL
	B013	1A	W3311	0046	22		23-31-01	ALL
	B013	1A	W3311	0054	22		23-31-01	ALL
	B015	1A	W3311	0054	22		23-31-01	ALL
TB0952X		**953/305/L003**		**TERMINAL BLOCK-**				**ALL**
			W5433	0072	20		23-71-01	ALL
			W5433	2010Z			23-71-01	ALL
TB0952Y		**953/305/L003**		**TERMINAL BLOCK-**				**ALL**
			W5433	0070	20		23-71-01	ALL
			W5433	0071	20		23-71-01	ALL
			W5433	1001Z			23-71-01	ALL
			W5433	1002Z			23-71-01	ALL
			W5433	2009Z			23-71-01	ALL
TB0954DY		**322/296/L003**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W3058	0245	22		23-42-14	ALL
	A003	1A	W3058	0246	22		23-42-14	ALL
	A013	1A	W3307	0104	22		23-31-01	ALL
	A015	1A	W3307	0107	22		23-42-12	ALL
	B001	1A	W3058	0176	22		23-42-14	ALL
	B003	1A	W3058	0098	22		23-42-14	ALL
	B013	1A	W3307	0094	22		23-31-01	ALL
	B013	1A	W3307	0105	22		23-31-01	ALL
	B015	1A	W3307	0105	22		23-31-01	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB1102DY		**E001-01/ /**		**TERMINAL BLOCK -**				**ALL**
	A005	1A	W0111	1035	20		27-25-11	ALL
	A007	1A	W0111	1032	20		27-25-11	ALL
	B005	1A	W0111	1036	20		27-25-11	ALL
	B007	1A	W0111	1033	22		27-25-11	ALL
	B007	1A	W0111	1036	20		27-25-11	ALL
TB1106Y		**E001-01/ /**		**TERMINAL BLOCK -**				**ALL**
	CAP	Y	W0111	0154	20		SPARE	ALL
	CAP	Y	W0111	0162	22		SPARE	ALL
	CAP	Y	W0111	0168	20		SPARE	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB1304DY		**E001-03/ /**		**TERMINAL BLOCK**				**ALL**
	A009	1A	W0131	0256	22		44-21-22	ALL
	A009	1A	W0131	0517	22		44-21-22	ALL
	A019	1A	W0131	0146	22		44-21-22	ALL
	A019	1A	W0131	0252	22		44-21-22	ALL
	A021	1A	W0131	0251	22		44-21-22	ALL
	A021	1A	W0131	0252	22		44-21-22	ALL
	B009	1A	W0131	0251	22		44-21-22	ALL
	B019	1A	W0131	0143	22		44-21-22	ALL
	B021	1A	W0131	0142	22		44-21-22	ALL
TB1304DZ		**E001-03/ /**		**TERMINAL BLOCK**				**ALL**
	A005	1A	W0131	0144	22		44-21-22	ALL
	A005	1A	W0131	0256	22		44-21-22	ALL
	A013	1A	W0131	0138	22		23-31-06	ALL
	A013	1A	W0131	0144	22		44-21-22	ALL
	B005	1A	W0131	0271	22		44-21-22	ALL
	B013	1A	W0131	0260	22		23-31-06	ALL
	B013	1A	W0131	0390	22		23-31-06	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB1404DY		**E001-04/ /**		**TERMINAL BLOCK**				**ALL**
	A007	1A	W0141	0158	22		23-15-15	ALL
	B007	1A	W0141	0159	22		23-15-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB2101DY		**E002-01/ /**		**TERMINAL BLOCK-**				**ALL**
	A011	1A	W0212	0210	22		28-23-11	ALL
	B011	1A	W0212	0208	22		28-43-11	ALL
	B011	1A	W0212	0209	22		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB2201DY		**E002-02/ /**		**TERMINAL BLOCK-**				**ALL**
	A021	1A	W0220	0055	24		21-31-22	ALL
	A023	1A	W0220	0055	24		21-31-22	ALL
	A023	1A	W0220	0057	24		21-31-22	ALL
	A035	1A	W0220	0355R	22		26-11-21	ALL
	A035	1A	W0220	0356R	22		26-11-21	ALL
	A037	1A	W0220	0327	22		30-31-12	ALL
	A039	1A	W0220	0326	22		30-31-12	ALL
	A039	1A	W0220	0327	22		30-31-12	ALL
	B021	1A	W0220	0056	24		21-31-22	ALL
	B023	1A	W0220	0049	24		21-31-23	ALL
	B035	1A	W0220	0317	22		26-16-21	ALL
	B035	1A	W0220	0318	22		26-16-21	ALL
	B037	1A	W0220	0328	22		30-31-12	ALL
	B039	1A	W0220	0329	22		30-31-12	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL		Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB3101DY		**E003-01/ /**		**TERMINAL BLOCK**				**ALL**
	A047	1A	W0313	0570	24		31-65-41	ALL
	A061	1A	W0311	0220	24		31-65-41	ALL
	B047	1A	W0313	0571	24		31-65-41	ALL
	B061	1A	W0311	0221	24		31-65-41	ALL
TB3101RZ		**E003-01/ /**		**TERMINAL BLOCK**				**ALL**
	A053	1A	W0311	2144W	24		34-41-11	ALL
	A053	1A	W0313	2644W	24		34-41-11	ALL
	A053	1A	W0313	2671W	24		34-41-11	ALL
	A057	1A	W0311	2145W	24		34-41-11	ALL
	A057	1A	W0313	2643W	24		34-41-11	ALL
	A057	1A	W0313	2645W	24		34-41-11	ALL
	A073	1A	W0311	2760W	24		34-49-11	ALL
	A073	1A	W0311	2761W	24		34-49-11	ALL
	A073	1A	W0311	2763W	24		34-49-11	ALL
	A077	1A	W0311	2762W	24		34-49-11	ALL
	A077	1A	W0311	2764W	24		34-49-11	ALL
	A077	1A	W0311	2765W	24		34-49-11	ALL
	B053	1A	W0311	2144B	24		34-41-11	ALL
	B053	1A	W0313	2644B	24		34-41-11	ALL
	B053	1A	W0313	2671B	24		34-41-11	ALL
	B057	1A	W0311	2145B	24		34-41-11	ALL
	B057	1A	W0313	2643B	24		34-41-11	ALL
	B057	1A	W0313	2645B	24		34-41-11	ALL
	B073	1A	W0311	2760B	24		34-49-11	ALL
	B073	1A	W0311	2761B	24		34-49-11	ALL
	B073	1A	W0311	2763B	24		34-49-11	ALL
	B077	1A	W0311	2762B	24		34-49-11	ALL
	B077	1A	W0311	2764B	24		34-49-11	ALL
	B077	1A	W0311	2765B	24		34-49-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB4101DY		**E004-01/ /**		**TERMINAL BLOCK-**				**ALL**
	A065	1A	W0410	0032	24		49-52-31	ALL
	A081	1A	W0410	0616	24		21-51-11	ALL
	A081	1A	W0410	0619	24		21-51-11	ALL
	B065	1A	W0410	0031	24		49-52-31	ALL
	B081	1A	W0410	0618	24		21-51-11	ALL
TB4102DY		**E004-01/ /**		**TERMINAL BLOCK-**				**ALL**
	A001	1A	W0410	0386	24		21-61-11	ALL
	A003	1A	W0410	0392	24		21-61-11	ALL
	A005	1A	W0410	0391	24		21-61-11	ALL
	A005	1A	W0410	0392	24		21-61-11	ALL
	A007	1A	W0410	0414	24		21-61-13	ALL
	A009	1A	W0410	0421	24		21-61-13	ALL
	A011	1A	W0410	0420	24		21-61-13	ALL
	A011	1A	W0410	0421	24		21-61-13	ALL
	A013	1A	W0410	0431	24		21-61-14	ALL
	A015	1A	W0410	0438	24		21-61-14	ALL
	A017	1A	W0410	0437	24		21-61-14	ALL
	A017	1A	W0410	0438	24		21-61-14	ALL
	B001	1A	W0410	0387	24		21-61-11	ALL
	B001	1A	W0410	0393	24		21-61-11	ALL
	B003	1A	W0410	0385	24		21-61-11	ALL
	B005	1A	W0410	0446	24		21-61-15	ALL
	B005	1A	W0410	0448	24		21-61-15	ALL
	B007	1A	W0410	0416	24		21-61-13	ALL
	B007	1A	W0410	0422	24		21-61-13	ALL
	B009	1A	W0410	0413	24		21-61-13	ALL
	B011	1A	W0410	0446	24		21-61-15	ALL
	B011	1A	W0410	0447	24		21-61-15	ALL
	B013	1A	W0410	0433	24		21-61-14	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB4102DY		**E004-01/ /**		**TERMINAL BLOCK- (continued)**				**ALL**
	B013	1A	W0410	0439	24		21-61-14	ALL
	B015	1A	W0410	0430	24		21-61-14	ALL
	B017	1A	W0410	0447	24		21-61-15	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB4201DY		**E004-02/ /**		**TERMINAL BLOCK**				**ALL**
	A019	1A	W0422	0243	22		28-23-11	ALL
	B019	1A	W0422	0241	22		28-43-11	ALL
	B019	1A	W0422	0242	22		28-43-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details

Equipment	Station / WL / BL			Description				
	Term	Type	Bundle	Wire No.	GA	CO	Diagram	Effectivity
TB4601RY		**721/204/R035**		**TERMINAL BLOCK**				**ALL**
	A001	1A	W5204	1005	20		47-30-11	ALL
	A001	1A	W5204	1007	20		47-30-11	ALL
	A003	1A	W5204	1005	20		47-30-11	ALL
	A003	1A	W5204	1006	20		47-30-11	ALL
	A005	1A	W5204	1001	20		47-30-11	ALL
	A005	1A	W5204	1006	20		47-30-11	ALL
	B001	1A	W5204	1002	20		47-30-11	ALL
	B001	1A	W5204	1008	20		47-30-11	ALL
	B003	1A	W5204	1003	20		47-30-11	ALL
	B003	1A	W5204	1009	20		47-30-11	ALL
	B005	1A	W5204	1004	20		47-30-11	ALL
	B005	1A	W5204	1010	20		47-30-11	ALL

ECCN 9E991 BOEING PROPRIETARY - See title page for details