Crossfeed Valve Position Indicator – Maintenance Practices

1. Adjustment/Test

   A. Operational Test

      Note To test the operation of the crossfeed valve position indicator, refer to 28-20-21, Crossfeed Valve – Maintenance Practices.

This Page Intentionally Left Blank