## Levelling and Weighing – General data

1. Aircraft Leveling

   Leveling the aircraft laterally is accomplished by placing a straight-edge and spirit level or digital protractor (for higher degree of accuracy) across the seat rail, or rail and track assembly, and longitudinally by placing the spirit level or digital protractor along the rail, or rail and track assembly, then adjusting the supporting jacks until the aircraft is level.

**This Page Intentionally Left Blank**