PTF ALL

EQUIP SMOKE Light Is On - Fault Isolation

CORRECTIVE ACTION SUMMARY

Clean/Replace Bad LRU
Do Corrective Action per Observed Fault
Replace Equipment Cooling Smoke Time Off Delay Relay [R1150]
Replace Equipment Cooling Smoke Time On Delay Relay [R1149]
Repair Wiring Between Equipment Cooling Smoke Time Off Delay Relay and Equipment Cooling Smoke Inhibit Relay
Repair Wiring Between Equipment Cooling Smoke Time Off Delay Relay and Equipment Cooling Smoke Time On Delay Relay
Repair Wiring Between Equipment Cooling Smoke Time On Delay Relay and Equipment Cooling Smoke Purge Mode Relay
Repair Wiring Between Equipment Cooling Smoke Purge Mode Relay and Equipment Cooling Supply Smoke Detector
Repair Wiring Between Equipment Cooling Smoke Purge Mode Relay and Equipment Cooling Exhaust Smoke Detector
Repair Wiring Between Flight Recorder/Mach Airspeed Warning Panel and Equipment Cooling SMOKE Light
Repair Wiring Between Equipment Cooling SMOKE Light and Equipment Cooling Smoke Inhibit Relay
Replace Equipment Cooling Smoke Purge Mode Relay [R1183]

A. Description

(1) This task is for this observed fault:
  (a) EQUIP SMOKE light is on.

(2) For intermittent EQUIP SMOKE Light is On faults, reference Service Letter 737-SL-26-071.

B. Fault Isolation Procedure

(1) Do a check of the E/E bay compartment equipment:
  (a) Operate the heaters, fans, lights, and other E/E bay compartment equipment.
  (b) Operate one LRU at a time to isolate the source of smoke or fumes.
  (c) If you find smoke or fumes when the LRU operates, then do these steps:
    1) Clean or replace the LRU.
    2) Do this task:
      • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
    3) If the system operates as specified in the AMM task, then you corrected the fault.
  (d) If you do not find smoke or fumes when the LRU operates, then continue.

(2) For the equipment cooling smoke detectors, do this task:
  • E/E Cooling Smoke Detector - Operational Test, AMM TASK 26-19-00-710-802.
  (a) If the equipment cooling SPLY SMK DET CONN light, L1293 did not come on, then do these steps:
    1) Go to the FIM task for the observed fault "E/E cooling smoke detector: operational test failed - supply" and do the steps in the task.
    2) Do this task:
      • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
    3) If the system operates as specified in the AMM task, then you corrected the fault.
  (b) If the equipment cooling EXH SMK DET CONN light, L1294 did not come on, then do these steps:
    1) Go to the FIM task for the observed fault "E/E cooling smoke detector: operational test failed - exhaust" and do the steps in the task.
    2) Do this task:
      • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
    3) If the system operates as specified in the AMM task, then you corrected the fault.

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

(c) If the system does not operate as specified in the AMM task, then continue.

(3) Replace the equipment cooling smoke time off delay relay, R1150.
   (a) Do this task:
      • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
   (b) If the system operates as specified in the AMM task, then you corrected the fault.
   (c) If the system does not operate as specified in the AMM task, then continue.

(4) Replace the equipment cooling smoke time on delay relay, R1149.
   (a) Do this task:
      • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
   (b) If the system operates as specified in the AMM task, then you corrected the fault.
   (c) If the system does not operate as specified in the AMM task, then continue.

(5) Do a check of the wiring between the equipment cooling smoke time off delay relay, R1150 and the equipment cooling smoke inhibit relay, R1151 (WDM 26-19-11).
   (a) If you find a problem with the wiring, then do these steps:
      1) Repair the wiring.
      2) Do this task:
         • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
      3) If the system operates as specified in the AMM task, then you corrected the fault.
   (b) If you do not find a problem with the wiring, then continue.

(6) Do a check of the wiring between the equipment cooling smoke time off delay relay, R1150 and the equipment cooling smoke time on delay relay, R1149 (WDM 26-19-11).
   (a) If you find a problem with the wiring, then do these steps:
      1) Repair the wiring.
      2) Do this task:
         • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
      3) If the system operates as specified in the AMM task, then you corrected the fault.
   (b) If you do not find a problem with the wiring, then continue.

(7) Do a check of the wiring between the equipment cooling smoke time on delay relay, R1149 and the equipment cooling smoke purge mode relay, R1183 (WDM 26-19-11).
   (a) If you find a problem with the wiring, then do these steps:
      1) Repair the wiring.
      2) Do this task:
         • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
      3) If the system operates as specified in the AMM task, then you corrected the fault.
   (b) If you do not find a problem with the wiring, then continue.

(8) Do a check of the wiring between the equipment cooling smoke purge mode relay, R1183 and the equipment cooling supply smoke detector, M2959 (WDM 26-19-11).
   (a) If you find a problem with the wiring, then do these steps:
      1) Repair the wiring.
      2) Do this task:
         • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.
      3) If the system operates as specified in the AMM task, then you corrected the fault.
   (b) If you do not find a problem with the wiring, then continue.

(9) Do a check of the wiring between the equipment cooling smoke purge mode relay, R1183 and the equipment cooling exhaust smoke detector, M2960 (WDM 26-19-11).
   (a) If you find a problem with the wiring, then do these steps:
      1) Repair the wiring.
      2) Do this task:
         • E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

3) If the system operates as specified in the AMM task, then you corrected the fault.

(b) If you do not find a problem with the wiring, then continue.

(10) Do a check of the wiring between the flight recorder/mach airspeed warning panel, P5-19 and the equipment cooling SMOKE light, L1554 (WDM 26-19-11).

(a) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.

2) Do this task:

- E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.

3) If the system operates as specified in the AMM task, then you corrected the fault.

(b) If you do not find a problem with the wiring, then continue.

(11) Do a check of the wiring between the equipment cooling SMOKE light, L1554 and the equipment cooling smoke inhibit relay, R1151 (WDM 26-19-11).

(a) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.

2) Do this task:

- E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.

3) If the system operates as specified in the AMM task, then you corrected the fault.

(b) If you do not find a problem with the wiring, then continue.

(12) Replace the equipment cooling smoke time off delay relay, R1150.

(a) Do this task:

- E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.

(b) If the system operates as specified in the AMM task, then you corrected the fault.

(c) If the system does not operate as specified in the AMM task, then continue.

(13) Replace the equipment cooling smoke purge mode relay, R1183.

(a) Do this task:

- E/E Cooling Smoke Detection - Operational Test, AMM TASK 26-19-00-710-801.

(b) If the system operates as specified in the AMM task, then you corrected the fault.

--------- END OF CONTENT ---------

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details