PTF ALL

Maintenance Message 21-30081 - Fault Isolation

CABIN PRESSURE SELECTOR PANEL MANUAL MODE SIGNAL IS INVALID

DETECTED BY: CABIN PRESSURE CONTROLLER (CPC)-2

CORRECTIVE ACTION SUMMARY

Replace Cabin Pressure Control Module [P5-6]
Repair Wiring D10726-D10740B

A. Description

(1) This task is for this maintenance message:

(a) CABIN PRESSURE SELECTOR PANEL MANUAL MODE SIGNAL IS INVALID

B. Initial Evaluation

(1) Do this task:

- Cabin Pressure Controller (CPC) BITE Procedure, AMM TASK 21-31-00-740-801.

(2) If the OMF shows ACTIVE for the maintenance message, then do the Fault Isolation Procedure below.

(3) If the OMF shows NOT ACTIVE for the maintenance message, then there was an intermittent fault.

C. Fault Isolation Procedure

(1) Replace the cabin pressure control module, P5-6. These are the tasks:

- Cabin Pressure Control Module Removal, AMM TASK 21-31-02-000-801,
- Cabin Pressure Control Module Installation, AMM TASK 21-31-02-400-801.

(a) Do the AMM test that you did at the start of this task.

(b) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(c) If the OMF shows ACTIVE for the maintenance message, then continue.

(2) Do this check of the wiring:

(a) Disconnect connector D10726 from the cabin pressure control module, P5-6.

(b) Remove the cabin pressure controller 2, M1654. This is the task:

- Cabin Pressure Controller (CPC) Removal, AMM TASK 21-31-01-000-801.

(c) Do a wiring check between this pin of connector D10726 at the cabin pressure control module and this pin of connector D10740B at the E1-1 rack (WDM 21-31-11, WDM 21-31-22):

D10726		**D10740B**
pin 8	.....	pin B3

(d) Do a wiring check to make sure that pin 21 of D10726 has continuity to ground.

(e) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.

2) Re-connect connector D10726 to the cabin pressure control module, P5-6.

3) Re-install the cabin pressure controller 2, M1654. This is the task:

- Cabin Pressure Controller (CPC) Installation, AMM TASK 21-31-01-400-801.

4) Do the AMM test that you did at the start of this task.

5) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

--------- END OF CONTENT ---------

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details