PTF ALL

Cabin Pressure Control Module AUTO FAIL and ALTN Light On, AUTO FAIL Light Goes Off When Mode Selector Switch Is At ALTN - Fault Isolation

CORRECTIVE ACTION SUMMARY

Correct Related Maintenance Messages

A. Description

(1) This task is for this observed fault:

(a) Cabin pressure control module: AUTO FAIL and ALTN light on, AUTO FAIL light goes off when mode selector switch is at ALTN.

B. Fault Isolation Procedure

(1) Look in OMF Existing Faults, 21 Cabin Pressure for related maintenance messages.

(a) If you find any related maintenance messages, then do these steps:

1) Do the fault isolation task for each related maintenance message.

2) If the observed fault symptom is gone, then you corrected the fault.

--------- END OF CONTENT ---------

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details