Indicating – General Data

1. General

The hydraulic power indicating system comprises of two transducers, two hydraulic/nitrogen accumulator pressure indicators, and a thermal overheat switch.

A. Hydraulic Pressure Indicator

Two hydraulic pressure transducers are mounted in the lower cockpit floor inside the center pedestal area.

One transducer senses airframe hydraulic pressure, and one transducer senses brake hydraulic pressure.

These airframe hydraulic and brake pressure transducers send a signal to display the amount of hydraulic pressure on the cockpit multi-function display screen.

B. Hydraulic/Nitrogen Accumulator Pressure Indicators

Two hydraulic/nitrogen pressure indicators (each combined with a charging valve) are installed, one for damping airframe system accumulator, and the other for wheel brakes system accumulator. Both indicators with charging valves are mounted on the hydraulic power package, and are accessible through the left-hand access panel on the underside of the nose section. Each indicator is direct-reading bourdon tube type, with dials marked X 1000, and scales marked from 0 to 2.0 in increments of 0.1.

C. Pump Thermal Overheat

A thermal switch on the pump end bell triggers a CAS message. When the temperature reaches 180°F ± 5°F, the switch will open and turn on the indication. When the temperature reaches 165°F ± 5°F, the switch will close and extinguish the indication.

This Page Intentionally Left Blank