PTF ALL

Cabin Pressure Controller Shows A Maintenance Message (Controller 1) - Fault Isolation

A. Initial Evaluation

(1) When the cabin pressure controller 1 shows a maintenance message that requires maintenance action, there is an equivalent maintenance message that shows on the OMF.

(2) Do the Fault Isolation Procedure below.

B. Fault Isolation Procedure

(1) For ACFT RATE HI, do the fault isolation task for OMF maintenance message 21-30310.

(2) For AUTO/MAN ERROR, do the fault isolation task for OMF maintenance message 21-30080.

(3) For CAB DIFF PRESS HI, do the fault isolation task for OMF maintenance message 21-30040.

(4) For CAB RATE HI, do the fault isolation task for OMF maintenance message 21-30050.

(5) For CONTRLR LRU FAIL, do the fault isolation task for OMF maintenance message 21-30330.

(6) For DADC #1 INVALID, do the fault isolation task for OMF maintenance message 21-30220.

(7) For DADC #2 INVALID, do the fault isolation task for OMF maintenance message 21-30230.

(8) For DRV ENBL ERROR, do the fault isolation task for OMF maintenance message 21-30330.

(9) For HI CAB ALT, do the fault isolation task for OMF maintenance message 21-30030.

(10) For LDG/GEAR DISAGREE, do the fault isolation task for OMF maintenance message 21-30280.

(11) For LO INFL/HI LEAKG, do the fault isolation task for OMF maintenance message 21-30300.

(12) For N1/N2 LOW, do the fault isolation task for OMF maintenance message 21-30290.

(13) For OFV LRU FAIL, do the fault isolation task for OMF maintenance message 21-30070.

(14) For OFV OR WIRING, do the fault isolation task for OMF maintenance message 21-30150.

(15) For SEL PNL LRU FAIL, do the fault isolation task for OMF maintenance message 21-30160.

(16) For SMC #1 INVALID, do the fault isolation task for OMF maintenance message 21-30260.

(17) For SMC #2 INVALID, do the fault isolation task for OMF maintenance message 21-30270.

(18) For SYSTEM WIRING, do the fault isolation task for OMF maintenance message 21-30010, 21-30020.

--------- END OF CONTENT ---------

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details