Audio Integration – General Data

1. General

The audio integration system gives the pilot and co-pilot the ability to monitor all of the communication, navigation receivers, and microphones transmission over the selected radio transmitter. The integrating system is provided by the pilot's and the co-pilot's audio controls panels, supports the cockpit, the aural warning system, receiver monitoring, transmission, and the passenger address system (if installed). (Refer to 44-00-00, Cabin Systems – General Data).

2. Description

The audio integration system receives audio information from the following systems:

- VHF Communication system
- VHF Navigation System which include:
    - Automatic Direction Finding Systems (ADF 1 and ADF 2) (if installed)
    - Distance Measuring Equipment Systems (DME 1 and DME 2 [if installed])
    - Marker Beacon System
- HF Communication System (if installed)
- VHF-FM (if installed)
- Pilot, Co-pilot and Crew Headsets

The audio integration system also receives signals and warning tones generated by the Master Warning and Caution System through the Modular Avionics Unit. These signals and warning tones are from the speed and attitude correction system and the Crew Alerting System.

The audio integration system receives signals and warning generated directly from the Traffic Alert and Collision Avoidance System, TCAS I and TCAS II (if installed) and from the Terrain Awareness Warning System (TAWS).

Aircraft incorporating Mod S.O.O. 6229 provides a fourth (standard, non-noise cancelling) headset/mic jack, for use by an attendant sitting in the aft row of passenger seats. The jacks are installed on the aft R/H cabin side wall.

This Page Intentionally Left Blank