Electrical Load Distribution (Mod 6/2028) – Maintenance Practices

1. Adjustment/Test

A. Operational Test DC Bus Feed Circuits

Refer to PSM 1-64-2W for electrical schematic.

1) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

2) Set BUS TIE switch to NORMAL.

3) If required, remove upholstery beneath circuit breaker brackets on power distribution and generator control box to gain access to bus feed circuit breakers.

4) Check the left bus feed circuits (CB5A, CB7A and CB9A) by observing that the Hydraulic Power Fail CAS message does not come ON and remains OFF for the duration of the following tests and the cabin lights; select CABIN GENERAL switch BRIGHT, remain ON (make sure the HYDRAULIC OIL PUMP and HYDRAULIC PRESSURE INDICATION circuit breakers and CABIN LIGHTS circuit breaker are engaged on the main circuit breaker panel:

a) Pull circuit breakers CB5 and CB7 together, then reset CB5.

b) Pull circuit breaker CB9, then reset CB7.

c) Pull circuit breaker CB5, then reset CB9 and CB5.

5) Check the right bus feed circuits (CB4A, CB6A and CB8A) by observing that the Fuel Cross Feed Fail CAS message does not come ON and remains OFF for the duration of the following tests and the CABIN reading lights remain ON (make sure the FUEL CROSSFEED and READING LIGHTS circuit breaker is engaged on the main circuit breaker panel:

a) Pull circuit breakers CB4 and CB6 together, then reset CB4.

b) Pull circuit breaker CB5, then reset CB6.

c) Pull circuit breaker CB4, then reset CB8 and CB4.

6) To check the left bus feed circuits (CB13, CB15 and CB17), verify that the pilot's PFD and upper MFD remain ON for the following tests which is fed from the left DC bus, and proceed as follows:

a) Pull circuit breakers CB13 and CB15 together, then reset CB13.

b) Pull circuit breaker CB17, then reset CB15.

c) Pull circuit breaker CB13, then reset CB17 and CB13.

7) To check the right bus feed circuits (CB12, CB14 and CB16), verify that the co-pilot's PFD and lower MFD remain ON for the following tests which are fed from the right DC bus, and proceed as follows:

a) Pull circuit breakers CB12 and CB14 together, then reset CB12.

b) Pull circuit breaker CB16, then reset CB14.

c) Pull circuit breaker CB12, then reset CB16 and CB12.

8) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

9) Reinstall upholstery removed in Para 1.A.3).

This Page Intentionally Left Blank